Pro C7100s/C7100sx/C7110s/C7110sx









User Guide

What You Can Do with This Machine	1
Getting Started	2
Сору	3
Print	4
Scan	5
Document Server	6
Web Image Monitor	7











Adding Paper and Toner

Information for This Machine

Troubleshooting





TABLE OF CONTENTS

How to Read the Manuals	6
Symbols Used in the Manuals	6
Model-Specific Information	7
Names of Major Features	8
1. What You Can Do with This Machine	
Searching by What You Want to Do	
Reducing My Costs	9
Using Scanned Files on the Computer	1C
Registering Destinations	11
Operating the Machine More Effectively	11
What You Can Do with This Machine	13
Customizing the [Home] Screen	13
Making Copies Using Various Functions	14
Printing Data Using Various Functions	15
Utilizing Stored Document	16
Using the Scanner in a Network Environment	17
Embedding Text Information in Scanned Files	17
Preventing Information Leakage (Security Functions)	18
Centrally Controlling Scan Conditions and Distribution	19
Monitoring and Setting the Machine Using a Computer	19
Preventing Unauthorized Copying	20
2. Getting Started	
Guide to Names and Functions of Components	23
Guide to Functions of the Attention Light	26
Guide to Functions of the Machine's Options	29
Guide to Functions of the Machine's External Options	29
Guide to the Names and Functions of the Machine's Control Panel	31
Changing the Display Language	34
How to Use the [Top] Screen and the [Home] Screen	35
Adding Icons to the [Home] Screen	37
Registering Functions in a Program	41
Example of Programs	43
Turning On/Off the Power	47

Turning On the Main Power	47
Turning Off the Main Power	47
Logging In the Machine	49
When the Authentication Screen Is Displayed	49
User Code Authentication Using the Control Panel	49
Logging In Using the Control Panel	49
Logging Out Using the Control Panel	50
Placing Originals	51
Placing Originals on the Exposure Glass	51
Placing Originals in the Auto Document Feeder	51
3. Сору	
Basic Procedure	53
Auto Reduce / Enlarge	55
Duplex Copying	57
Specifying the Original and Copy Orientation	59
Combined Copying	61
One-Sided Combine	62
Two-Sided Combine	63
Copying onto Custom Size Paper from the Multi Bypass Tray (Tray A)	66
Copying onto Envelopes	68
Copying onto Envelopes from the Multi Bypass Tray (Tray A)	68
Copying onto Envelopes from the Wide Large Capacity Tray	69
Sort	70
Changing the Number of Sets	70
Storing Data in the Document Server	72
4. Print	
Quick Install	73
Displaying the Printer Driver Properties	74
Standard Printing	75
When Using the PCL 6 Printer Driver	75
Printing on Both Sides of Sheets	76
When Using the PCL 6 Printer Driver	76
Types of Two-sided Printing	76

Combining Multiple Pages into Single Page	77
When Using the PCL 6 Printer Driver	77
Types of Combine Printing	77
Printing on Envelopes.	79
Configuring Envelope Settings Using the Control Panel	79
Printing on Envelopes Using the Printer Driver	79
Saving and Printing Using the Document Server	81
Storing Documents in Document Server	81
Managing Documents Stored in Document Server	82
5. Scan	
Basic Procedure When Using Scan to Folder	83
Creating a Shared Folder on a Computer Running Windows/Confirming	g a Computer's Information
Registering an SMB Folder	
Deleting an SMB Registered Folder	
Entering the Path to the Destination Manually	
Basic Procedure for Sending Scan Files by E-mail	
Registering an E-mail Destination	
Deleting an E-mail Destination	94
Entering an E-mail Address Manually	94
Basic Procedure for Storing Scan Files	95
Checking a Stored File Selected from the List	96
Specifying the File Type	97
Specifying Scan Settings	98
6. Document Server	
Storing Data	99
Printing Stored Documents	101
7. Web Image Monitor	
Displaying Top Page	103
8. Adding Paper and Toner	
Loading Paper	105
Precautions for Loading Paper	105
Loading Paper into Tray 1	107

Loading Paper into the A3/11 × 17 Tray Unit	109
Loading Paper into Tray 2	110
Loading Paper into the Multi Bypass Tray (Tray A)	112
Loading Paper into the Three-tray Wide Large Capacity Tray	114
Loading Paper into the Two-tray Wide Large Capacity Tray	115
Loading Paper into the Interposer	11 <i>7</i>
Loading Cover Sheets into the Interposer of the Perfect Binder	118
Loading Orientation-fixed Paper or Two-sided Paper	120
Recommended Paper	124
Recommended Paper Sizes and Types	124
Registering a Custom Paper	149
Selecting the Paper's Name from the Paper Library	149
Registering a Paper Whose Paper Name Is Not Displayed in the Paper Library	150
Registering a New Custom Paper by Modifying an Existing Paper	153
Adding Toner	156
Sending Scanned Documents When Toner Has Run Out	158
Disposing of Used Toner	158
Menu Items and Functions	159
9. Troubleshooting	
When a Status Icon Is Displayed	163
When the Indicator Lamp for the [Check Status] Key Is Lit or Flashing	165
When the Machine Makes a Beeping Sound	167
When You Have Problems Operating the Machine	168
When Multiple Functions Cannot Be Executed Simultaneously	176
Messages Displayed When You Use the Copy/Document Server Function	177
Messages Displayed When You Use the Printer Function	182
Messages Displayed on the Control Panel When You Use the Printer Function	182
Messages Printed on the Error Logs or Reports When You Use the Printer Functi	on185
Messages Displayed When You Use the Scanner Function	198
Messages Displayed on the Control Panel When You Use the Scanner Function	า198
Messages Displayed on the Client Computer	208
When Other Messages Appear	214
When There Is a Problem Scanning or Storing Originals	215

When the Home Screen Cannot Be Edited	215
When the Address Book Is Updated	216
When Data Cannot Be Sent Due to a Problem with the Destination	217
When the Machine Cannot Be Operated Due to a Problem with the User Certificate	217
When Problems Occur While Logging In	219
When the User Lacks Privileges to Perform an Operation	219
When the LDAP Server Cannot Be Used	219
10. Information for This Machine	
Information on Environmental Regulations	221
ENERGY STAR Program	221
Energy Saving Functions	221
User Information on Electrical and Electronic Equipment Region (mainly Europe)	223
Note for the Battery and/or Accumulator Symbol (For EU Countries Only) <u>Region</u>	-
Environmental Advice for Users <u>Region</u> (mainly Europe)	224
Notes to Users in the State of California (Notes to Users in USA) — Region B (mainly North	
INDEX	

How to Read the Manuals

Symbols Used in the Manuals

This manual uses the following symbols:



Indicates points to pay attention to when using the machine, and explanations of likely causes of paper misfeeds, damage to originals, or loss of data. Be sure to read these explanations.



Indicates supplementary explanations of the machine's functions, and instructions on resolving user errors.

Reference

This symbol is located at the end of sections. It indicates where you can find further relevant information.

[]

Indicates the names of keys on the machine's display or control panels.

Region A (mainly Europe and Asia), (mainly Europe), or (mainly Asia)


 \bigcirc Region **B** (mainly North America)

Differences in the functions of Region A and Region B models are indicated by two symbols. Read the information indicated by the symbol that corresponds to the region of the model you are using. For details about which symbol corresponds to the model you are using, see page 7 "Model-Specific Information".

Model-Specific Information

This section explains how you can identify the region your machine belongs to.

There is a label on the rear of the machine, located in the position shown below. The label contains details that identify the region your machine belongs to. Read the label.



The following information is region-specific. Read the information under the symbol that corresponds to the region of your machine.

Region A (mainly Europe and Asia)

If the label contains the following, your machine is a Region A model:

- CODE XXXX -27, -29, -67
- 220-240 V

Region B (mainly North America)

If the label contains the following, your machine is a Region B model:

- CODE XXXX -17, -57
- 208–240 V



- Dimensions in this manual are given in two units of measure: metric and inch. If your machine is a
 Region A model, refer to the metric units. If your machine is a Region B model, refer to the inch
 units.
- If your machine is a Region A model and "CODE XXXX -27, -67" is printed on the label, see
 "
 Region A (mainly Europe)" also.
- If your machine is a Region A model and "CODE XXXX -29" is printed on the label, see
 "
 Region A (mainly Asia)" also.

Names of Major Features

In this manual, major features of the machine are referred to as follows:

- Auto Document Feeder → ADF
- Multi Bypass Tray BY5010 → Multi bypass tray (Tray A)
- Wide Large Capacity Tray > Wide LCT (in this manual, "wide LCT" refers to the three-tray wide LCT and the two-tray wide LCT)
- LCIT RT5090 → Three-tray wide Large Capacity Tray (Three-tray wide LCT)
- Vacuum Feed LCIT RT5100 → Two-tray wide Large Capacity Tray (Two-tray wide LCT)
- Multi-Folding Unit FD5020 → Multi-folding unit
- Decurl Unit DU5040 → Decurl unit
- Buffer Pass Unit Type S3 → Buffer pass unit
- Ring Binder RB5020 → Ring binder
- High Capacity Stacker SK5030 → High capacity stacker
- Trimmer Unit TR5040 → Trimmer
- Cover Interposer Tray CI5030 → Interposer
- Perfect Binder GB5010 → Perfect binder
- Tab Sheet Holder Type 3260 → Tab sheet holder


1. What You Can Do with This Machine

You can search for a description by what you want to do.

Searching by What You Want to Do

You can search for a procedure by what you want to do.

Reducing My Costs



Printing multi-page documents on both sides of sheets (Duplex Copy)

⇒ See "Duplex Copying", Copy/ Document Server.

Printing multi-page documents on a single sheet (Combine)

⇒ See "Combined Copying", Copy/ Document Server.

Checking how much paper is saved ([Information] screen)

 \Rightarrow See "How to Use the [Information] Screen", Getting Started.

Reducing electricity consumption

⇒ See "Saving Energy", Getting Started.

Using Scanned Files on the Computer



Sending scan files

 \Rightarrow See "Basic Procedure for Sending Scan Files by E-mail", Scan.

Sending the URL of the folder in which scan files are stored

 \Rightarrow See "Sending the URL by E-mail", Scan.

Storing scan files in a shared folder

 \Rightarrow See "Basic Procedure When Using Scan to Folder", Scan.

Storing scan files on media

 \Rightarrow See "Basic Procedure for Saving Scan Files on a Memory Storage Device", Scan.

Embedding text information in scanned files

⇒ See "Embedding Text Information in Scanned Data", Scan.

Managing and using documents converted to electronic formats (Document Server)

 \Rightarrow See "Relationship between Document Server and Other Functions", Copy/ Document Server.


Registering Destinations



Using the control panel to register destinations in the Address Book

 \Rightarrow See "Registering a destination in the address book manually", Scan.

Operating the Machine More Effectively



Registering and using frequently-used settings (Program)

⇒ See "Registering Functions in a Program", Convenient Functions.

Registering frequently-used settings as initial settings (Program as Defaults (Copier/Document Server/Scanner))

⇒ See "Changing the Default Functions of the Initial Screen", Convenient Functions.

Registering frequently-used printing settings to the printer driver

⇒ See "Using One Click Presets", Print.

Changing the initial settings of the printer driver to frequently-used printing settings

⇒ See "Displaying the Printing Preferences Dialog Box", Print.

Adding shortcuts to frequently used programs

 \Rightarrow See "Adding Icons to the [Home] Screen", Convenient Functions.

Changing the order of the function and shortcut icons


⇒ See "Changing the Order of Icons on the [Home] Screen", Convenient Functions.

What You Can Do with This Machine

This section describes the features of this machine.

Customizing the [Home] Screen

The icons of each function are displayed on the [Home] screen.




DER15

- You can add shortcuts to often used programs to the [Home] screen. The programs can be recalled
 easily by pressing the shortcut icons.
- You can display only the icons of functions and shortcuts that you use.
- You can change the order of the function and shortcut icons.

Reference

- For details about the features on the [Home] screen, see "How to Use the [Top] Screen and the [Home] Screen", Getting Started.
- For details about how to customize the [Home] screen, see "Types of [Home] Screens and How to Customize Them", Convenient Functions.


Making Copies Using Various Functions



- You can make copies in full color. You can switch the color copy mode depending on the type of originals used and the desired finish.
 - ⇒ See "Copying in Color", Copy/ Document Server.
- You can print stamps on copies. Stamps can include background numbers, scanned images, dates, page numbers, and texts.
 - ⇒ See "Stamps", Copy/ Document Server.
- You can adjust the color tones and image quality of your copies.
 - ⇒ For details about a color adjustment, see "Adjusting Color", Copy/ Document Server.
 - ⇒ For details about an image adjustment, see "Image Adjustment", Copy/ Document Server.
- You can reduce or enlarge the copy image. Auto Reduce / Enlarge function enables the machine
 to detect the original size automatically. Also, it enables the machine to select an appropriate
 reproduction ratio based on the paper size you specify. If the orientation of the original is different
 from that of the paper you are copying onto, the machine rotates the original image by 90 degrees
 to match it with the copy paper.
 - ⇒ See "Reducing or Enlarging Originals", Copy/ Document Server.
- Copier functions such as Duplex, Combine, Booklet, and Magazine allow you to save on paper by copying multiple pages onto single sheets.
 - ⇒ For details about duplex copying, see "Duplex Copying", Copy/ Document Server.
 - ⇒ For details about combined copying, see "Combined Copying", Copy/ Document Server.
 - ⇒ For details about the booklet and magazine functions, see "Booklet/Magazine", Copy/
- You can copy onto various types of paper such as envelopes and transparencies.

- \Rightarrow See "Copying onto Various Types of Paper", Copy/ Document Server.
- The finisher allows you to sort, staple, and punch holes in your copies.
 - ⇒ See "Finishing", Copy/ Document Server.
- The multi-folding unit allows you to fold your copies.
 - ⇒ See "Finishing", Copy/ Document Server.
- The ring binder allows you to bind your copies with a ring comb.
 - ⇒ See "Finishing", Copy/ Document Server.
- The perfect binder allows you to apply adhesive to the spine of gathered pages to bind them in a booklet.
 - ⇒ See "Finishing", Copy/ Document Server.

Printing Data Using Various Functions




- This machine supports network and local connections.
- You can print or delete print jobs stored on the machine's hard disk, which have been previously sent from computers using the printer driver. The following types of print jobs can be selected: Sample Print, Locked Print, Hold Print, and Stored Print.
 - ⇒ See "Storing Documents in the Hard Disk Drive and Printing Them", Print.
- The finisher allows you to staple and punch holes in your prints.
 - ⇒ For details about stapling, see "Staple", Print.
 - ⇒ For details about punching, see "Punch", Print.
- The multi-folding unit allows you to fold your prints.
 - \Rightarrow For details about multi-folding, see "Fold", Print.

- The ring binder allows you to bind your prints with a ring comb.
 - ⇒ See "Ring Binding", Print.
- The perfect binder allows you to apply adhesive to the spine of gathered pages to bind them in a booklet.
 - ⇒ See "Perfect Binding", Print.
- You can print files stored on a removable memory device and specify print conditions such as print quality and print size.
 - ⇒ See "Direct Printing from a Memory Storage Device", Print.

Utilizing Stored Document

You can store files scanned in copier, printer, or scanner mode on the machine's hard disk. Web Image Monitor allows you to use your computer to search for, view, print, delete, and send stored files via the network. You can also change print settings and print multiple documents (Document Server).




You can retrieve stored documents scanned in scanner mode to your computer.

Reference

- For details about how to use the Document Server, see "Storing Data in the Document Server", Copy/ Document Server.
- For details about the Document Server in copier mode, see "Document Server", Copy/ Document Server.
- For details about the Document Server in printer mode, see "Saving and Printing Using the Document Server", Print.
- For details about the Document Server in scanner mode, see "Storing and Saving the Scanned Documents", Scan.

Using the Scanner in a Network Environment




- You can send scan files to a specified destination using e-mail (Sending scan files by e-mail).
 - \Rightarrow See "Basic Procedure for Sending Scan Files by E-mail", Scan.
- You can send scan files directly to folders (Sending scan files by Scan to Folder).
 - \Rightarrow See "Basic Procedure When Using Scan to Folder", Scan.
- You can use Web Services on Devices (WSD) to send scan files to a client computer.
 - \Rightarrow See "Basic Operating Procedure of WSD Scanner (Push Type)", Scan.

Embedding Text Information in Scanned Files

You can extract text information from a scanned document and embed it in the file without using a computer.

If you scan a document using this function, embedded text can be searched by using the text search function or copied to another document.




CWW107

- To use this function, the OCR unit is required.
- You can select a file type from [PDF], [High Compression PDF], or [PDF/A].
- This function can optically recognize characters in various languages and up to approximately 40,000 characters a page.

Reference

• See "Embedding Text Information in Scanned Data", Scan.

Preventing Information Leakage (Security Functions)



CWW108

- You can protect documents from unauthorized access and stop them from being copied without permission.
- You can control the use of the machine, as well as prevent machine settings from being changed without authorization.
- By setting passwords, you can prevent unauthorized access via the network.
- You can erase or encrypt the data on the hard disk to minimize the risk of information leakage.

• You can limit the usage of functions for each user.


Reference

· See Security Guide.

Centrally Controlling Scan Conditions and Distribution

You can use the distributed scan management (DSM) system in Windows Server 2008 R2/2012 to manage the destinations and scan settings for each individual user in a group and to use the information when distributing scanned data.

You can also use this system to centrally manage information about people using the network and the machine's scanner functions. Both delivered files and user information can be controlled.




You must set up and configure a Windows server to use the distributed scan management system.
 This system is supported by Windows Server 2008 R2 or later.

Reference

For details about how to deliver files using the distributed scan management system, see
 "Managing Scan Conditions and Other Settings in the Block using Distributed Scan Management",
 Scan.

Monitoring and Setting the Machine Using a Computer

Using Web Image Monitor, you can check the machine's status and change the settings.




You can check which tray is running out of paper, register information in the Address Book, specify the network settings, configure and change the system settings, manage jobs, print the job history, and configure the authentication settings.

Reference

- See "Using Web Image Monitor", Connecting the Machine/ System Settings.
- See Web Image Monitor Help.

Preventing Unauthorized Copying

You can print embedded patterns on printouts to prevent unauthorized copying.



DEITH

- Using the printer driver, you can embed a pattern in the printed document. If the document is
 copied on a machine with the Copy Data Security unit, protected pages are grayed out in the
 copy. This can minimize the risk of confidential information being copied. If a document protected
 by unauthorized copy guard is copied on a machine that is equipped with the Copy Data Security
 unit, the machine beeps to notify users that unauthorized copying is being attempted.
 - If the document is copied on a machine without the Copy Data Security Unit, the hidden text becomes conspicuous in the copy, showing that the copy is unauthorized.
- Using the printer driver, you can embed text in the printed document for unauthorized copy
 prevention. If the document is copied, scanned, or stored in a Document Server by a copier or
 multifunction printer, the embedded text appears conspicuous in the copy, discouraging such
 unauthorized copying.



- For details, see the printer driver Help and Security Guide.
- For details about this function in the printer mode, see "Printing Documents That Are Not Authorized for Duplication", Print.

2. Getting Started


This chapter describes how to start using this machine.

Guide to Names and Functions of Components



 Do not obstruct the machine's vents. Doing so risks fire caused by overheated internal components.

Front and left view



1. Main power switch

To operate the machine, the main power switch must be on. If it is off, open the main power switch's cover and turn the switch on.

2. ADF

Lower the ADF over originals placed on the exposure glass.

If you load a stack of originals in the ADF, the ADF will automatically feed the originals one by one.

3. Exposure glass

Place originals face down here.

4. Front left cover

Open to remove paper jams or turn on/off the AC power switch.

5. Control panel

See page 31 "Guide to the Names and Functions of the Machine's Control Panel".

6. Front upper right cover

Open to change toner cartridges.

7. Front right cover

Open to remove paper jams.

8. Paper trays (Trays 1-2)

Load paper here. Tray 1 is a tandem tray where paper on the left side automatically moves to the right when paper there has run out.

An indicator on the front left side of the tray lights while paper is feeding.


9. Front lower left cover

Open to replace the waste toner bottle.

10. AC power switch

Press to completely turn off the power of the machine. The AC power switch must be kept on in normal use. The switch is inside the front left cover. For details, see "Dos and Don'ts", Maintenance and Specifications.

Front and right view



DER004


1. Attention light

See page 26 "Guide to Functions of the Attention Light".

2. ADF's extender

Pull this extender to support large paper.

Rear and right view



1. Vents

Prevent overheating.

2. Earth leakage breaker

Protects users from electric shock. For details about checking the earth leakage breaker, see "Checking the Earth Leakage Breakers", Maintenance and Specifications.

Guide to Functions of the Attention Light



• Do not push or pull the attention light when installed to the machine. Doing so may result in damage or malfunction of the attention light or the machine.



CUV121

The attention light notifies the user by light when there is a paper jam or no paper is left.


The colors of the lamp and their meanings are as follows:

Lamp	Status
The bottom lamp lights blue.	Printing
The bottom lamp flashes blue.	Scanning Data in
The top lamp lights red.	Error occurred (Example) • When the service call message appears • Paper jam • Out of paper • Out of toner • Memory overflow Read the message on the display panel, and then take appropriate action. For details, see "When Messages Appear", Troubleshooting.

Lamp	Status
The top lamp flashes yellow.	Warning
	(Example)
	Toner has nearly run out.
	 Waste toner bottle is nearly full.
	Read the message on the display panel, and then take appropriate action. For details, see "When Messages Appear", Troubleshooting.

Guide to Functions of the Machine's Options

Guide to Functions of the Machine's External Options



1. Booklet Finisher SR5060

Sorts, stacks, and staples multiple sheets of paper. The saddle stitch function can staple multiple sheets of paper in the center and fold them into booklets. Consists of the following paper trays:

- Finisher upper tray
- · Finisher shift tray
- Finisher booklet tray

Copies can be punched if the optional punch unit is installed on the finisher.

2. Trimmer

Cuts the fore edge of the book block after the book block is saddle stitched.

3. High capacity stacker

Consists of the following paper trays:

- Stacker upper tray
- Stacker tray

The stacker upper tray can hold up to 250 sheets of paper, and stacker tray can hold up to 5,000 sheets of paper. You can connect up to two high capacity stackers.

4. Ring binder

Binds sheets of paper with a ring comb.

5. Multi-folding unit

Applies the following folds: Half Fold, Letter Fold-out, Letter Fold-in, Double Parallel Fold, Gate Fold, and Z-fold.

6. Interposer

Inserts cover or slip sheets into copied or printed paper.

7. Buffer pass unit

Cools copies or prints.

8. Decurl unit

Flattens curls from sheets to prevent paper jams.

9. Three-tray wide LCT

Holds up to 4,400 sheets of paper. You can load paper whose sizes are up to SRA3 or $13 \times 19^{1}/_{5}$.

10. Multi bypass tray (Tray A)

Holds up to 500 sheets of paper.

11. Multi bypass attachment kit

Attaches the multi bypass tray (Tray A) to the two-tray wide LCT.

12. Banner sheet tray of multi bypass tray (Tray A)

Allows you to load large-sized paper in the multi bypass tray (Tray A).

13. Finisher SR5050

Sorts, stacks, and staples multiple sheets of paper. Consists of the following paper trays:

- Finisher upper tray
- · Finisher shift tray

Copies can be punched if the optional punch unit is installed on the finisher.

14. Perfect binder

Applies adhesive to the spine of gathered pages to bind them in a booklet.

15. A3/11 × 17 tray unit

You can load A3, 11×17 or larger size paper in Tray 1 using this unit. If you install the A3/11 × 17 tray unit on your machine, you cannot use it as a tandem tray.

An indicator on the front left side of the tray lights while paper is feeding.

16. Two-tray wide LCT

Holds up to 4,800 sheets of paper. You can load paper whose sizes are up to SRA3 or $13 \times 19^{1}/_{5}$. You can connect up to three two-tray wide LCTs.


17. Bridge unit of two-tray wide LCT

Connects a two-tray wide LCT to an additional two-tray wide LCT.

18. Banner sheet tray of two-tray wide LCT

Allows you to load large-sized paper in the two-tray wide LCT.

Guide to the Names and Functions of the Machine's Control Panel



1. Display panel

Displays keys for each function, operation status, or messages. See "How to Use the Screens on the Control Panel", Getting Started.

2. [Reset] key

Press to clear the current settings.

3. [Program] key (copier, Document Server, and scanner mode)

- Press to register frequently used settings, or to recall registered settings.
 - See "Registering Frequently Used Functions", Convenient Functions.
- Press to program defaults for the initial display when modes are cleared or reset, or immediately after the main power switch is turned on.
 - See "Changing the Default Functions of the Initial Screen", Convenient Functions.

4. [Interrupt] key

Press to make interrupt copies. See "Interrupt Copy", Copy/ Document Server.

5. Main power indicator

The main power indicator goes on when you turn on the main power switch.

6. [Energy Saver] key

Press to switch to and from Low Power mode or Sleep mode. See "Saving Energy", Getting Started.

When the machine is in Low Power mode, the [Energy Saver] key is lit. In Sleep mode, the [Energy Saver] key flashes slowly.

7. [Login/Logout] key

Press to log in or log out.

8. [User Tools] key

Press to change the default settings to meet your requirements. See "Accessing User Tools", Connecting the Machine/ System Settings.

You can find out where to order expendable supplies and where to call when a malfunction occurs. You can also print these details. See "Checking Inquiry using the User Tools", Maintenance and Specifications.

9. [Paper Setting] key

Specify settings for the paper tray. See Paper Settings.

10. [Counter] key

Press to check or print the counter value. See "Counter", Maintenance and Specifications.

11. [Language] key

Press to change the language of the display. See page 34 "Changing the Display Language".

12. [Simple Screen] key

Press to switch to the simple screen. See "Switching Screen Patterns", Getting Started.

13. [#] key (Enter key)

Press to confirm values entered or items specified.

14. [Start] key

Press to start copying, printing, scanning, or sending.

15. [Sample Copy] key

Press to make a single set of copies or prints to check print quality before making multiple sets. See "Sample Print", Copy/ Document Server.

16. [Stop] key

Press to stop a job in progress, such as copying, scanning or printing.

17. [Clear] key

Press to delete a number entered.

18. Number keys

Use to enter the numbers for copies and data for the selected function.

19. Data In indicator (printer mode)

Flashes when the machine is receiving print jobs from a computer. See Print.

20. [Check Status] key

Press to check the machine's system status, operational status of each function, and current jobs. You can also display the job history and the machine's maintenance information.

21. Function keys

No functions are registered to the function keys as a factory default. You can register often used functions and programs. For details, see "Configuring function keys", Getting Started.

22. [Home] key

Press to display the [Home] screen. For details, see page 35 "How to Use the [Top] Screen and the [Home] Screen".

23. Screen brightness slider

Adjusts display panel brightness.

24. Media access lamp


Lights up when a memory storage device is inserted in the media slot.

25. Media slots

Use to insert an SD card or a USB flash memory device.

You can change the language used on the display. English is set as default.

1. Press the [Language] key until the language you want to display appears.



_

How to Use the [Top] Screen and the [Home] Screen

The [Top] screen is displayed when the machine is turned on.


Using the [Top] screen, you can check the job list, toner status, and paper status.

The icons of each function are displayed on the [Home] screen.

You can add shortcuts to frequently used programs to the [Home] screen. The program shortcuts appear on the [Home] screen. The programs can be recalled easily by pressing the shortcuts.


To display the [Home] screen, press the [Home] key. If the [Home] screen does not appear, press the licon at the upper right corner of the screen to switch to the menu screen.

[Top] screen



DER021

[Home] screen



1. Operational status and messages

Displays operational status and messages.

2. [Job List]

Press to display the [Current Job] tab on the [Check Status] screen.

3. Estimated time

Indicated by the time estimated to complete the job at the top of the currently displayed job list.

4. [Maintenance Info]

Press to display the [Maintnc./Inquiry/Mach. Info] tab on the [Check Status] screen.

5. Switch screens

Press to switch between the [Home] screen and the [Top] screen.

6. [Supplies Info]

Displays the information about supplies, such as the remaining amount of toner.

7. [Tray Paper Settings]

Press to display the [Tray Paper Settings] screen.

8. [Tray Info]/[Interposer Info]

Displays the status of the paper trays and the interposer.

9. [Job List]

Displays current and pending jobs.

10. [Copier]

Press to make copies.

For details about how to use the copy function, see Copy/ Document Server.

11. Home screen image

You can display an image on the [Home] screen, such as a corporate logo. To change the image, see "Displaying an Image on the [Home] Screen", Convenient Functions.

12. [Scanner]

Press to scan originals and save images as files.

For details about how to use the scanner function, see Scan.

13. [Printer]

Press to make settings for using the machine as a printer.

For details about how to make settings for the printer function, see Print.

14. ▲/▼

Press to switch pages when the icons are not displayed on 1 page.

15. Shortcut icon

You can add shortcuts to programs to the [Home] screen. For details about how to register shortcuts, see page 37 "Adding Icons to the [Home] Screen". The program number appears on the bottom of the shortcut icon. For details about examples of shortcuts that you can program, see page 43 "Example of Programs".

16. [Address Book Management]

Press to display the Address Book.

For details about how to use the Address Book, see "Address Book", Connecting the Machine/ System Settings.

17. [Document Server]

Press to store or print documents on the machine's hard disk.

For details about how to use the Document Server function, see Copy/ Document Server.

Adding Icons to the [Home] Screen

You can add shortcuts to programs stored in copier or scanner mode.

You can also review icons of functions and embedded software applications that you deleted from the [Home] screen.



- Shortcuts to programs stored in Document Server mode cannot be registered to the [Home] screen.
- Shortcut names of up to 32 characters can be displayed in a standard screen. If the name of the shortcut is longer than 32 characters, the 32nd character is replaced with "...". Only 30 characters can be displayed in a simple screen. If the name of the shortcut is longer than 30 characters, the 30th character is replaced with "...".
- For details about how to make a program, see page 41 "Registering Functions in a Program".
- For details about the procedure for registering a shortcut using the [Program] screen, see
 "Registering a Shortcut to a Program to the [Home] Screen", Convenient Functions.

- You can register up to 72 function and shortcut icons. Delete unused icons if the limit is reached. For
 details, see "Deleting an Icon on the [Home] Screen", Convenient Functions.
- You can change the position of icons. For details, see "Changing the Order of Icons on the [Home]
 Screen", Convenient Functions.


Adding icons to the [Home] screen using Web Image Monitor

- Start Web Image Monitor.
 For details, see "Using Web Image Monitor", Connecting the Machine/ System Settings.
- 2. Log in to Web Image Monitor.
- To add icons to the default [Home] screen, point to [Device Management], and then click [Device Home Management]. To add icons to a user's [Home] screen, point to [Customize Screen per User].
- 4. Click [Edit Icons].
- Point to [+Icon can be added.] of the position that you want to add, and then click [+ Add].
- 6. Select the function or shortcut icon you want to add.
- 7. Click [OK] four times.


Adding icons to the [Home] screen using the User Tools

In the following procedure, a shortcut to a copier program is registered to the [Home] screen.


- 1. Register a program.
- 2. Press the [User Tools] key.




3. Press [Edit Home].



4. Press [Add Icon].



5. Press the [Program] tab.




6. Make sure that [Copier Program] is selected.



- 7. Select the program you want to add.
- 8. Specify the position where [Blank] is displayed.



9. Press [OK].



10. Press the [User Tools] key.



• Press on the upper-right corner of the screen to check the position on the simple screen.

Registering Functions in a Program

Depending on the functions, the number of programs that can be registered is different.

• Copier: 25 programs

• Document Server: 25 programs

• Scanner: 25 programs

The following settings can be registered to programs:

Copier:

Color mode, original type, density, Original Size, Mixed Sizes, Batch, SADF, Original Orientation, Reverse Orientation, paper tray, Store File (except for User Name, File Name, and Password), Auto Reduce / Enlarge, Create Margin, Output/ Customize Function/ Finisher, Stamp (except for Change Start No. in Stamp Text), Cover/ Slip Sheet, Edit / Color, Dup./ Combine/ Series, Reduce/ Enlarge, number of copies

Document Server (on the initial document print screen):


Output/Finisher, Stamp, Cover/Slip Sheet (except for Main Sheets in Designate / Chapter), Edit, 2 Sided / Book, number of prints

Scanner:

Scan Settings, density, Original Feed Type, Send File Type / Name (except for Security Settings and Start No.), Store File (except for User Name, File Name, and Password), Preview, Text, Subject, Security, Recept. Notice


This section explains how to register functions in a program using copier function as an example.

Press the [Home] key on the control panel, and press the [Copier] icon on the screen.
 If the [Copier] icon does not appear, press the icon at the upper right corner of the screen to switch to the menu screen.




2. Edit the copy settings so all functions you want to store in a program are selected.

3. Press the [Program] key.



- 4. Press [Program].
- 5. Press the program number you want to register.



- 6. Enter the program name.
- 7. Press [OK].
- 8. Press [Exit].



- You can enter up to 40 characters for a program name.
- When a specified program is registered as the default, its values become the default settings, which
 are displayed without pressing the [Program] key, when modes are cleared or reset, and after the
 machine is turned on. See "Changing the Default Functions of the Initial Screen", Convenient
 Functions.
- When the paper tray you specified in a program is empty and if there is more than one paper tray
 with the same size paper in it, the paper tray prioritized under [Paper Tray Priority: Copier] will be
 selected first. For details, see "System Settings", Connecting the Machine/ System Settings.
- Destinations can be registered to a program of the scanner mode only when [Include Destinations] is selected for [Program Setting for Destinations] in [Scanner Features]. For details about the setting, see "General Settings", Scan.

- Folder destinations that have protection codes cannot be registered to a program of the scanner mode.
- Programs are not deleted by turning the power off or by pressing the [Reset] key unless the program is deleted or overwritten.
- Program numbers with next to them already have settings made for them.
- Programs can be registered to the [Home] screen, and can be recalled easily. For details, see
 "Registering a Shortcut to a Program to the [Home] Screen", Convenient Functions and page 37
 "Adding Icons to the [Home] Screen". Shortcuts to programs stored in Document Server mode cannot be registered to the [Home] screen.

Example of Programs

Copier mode

Program name	Program description	Effect	
Есо сору	Specify [Combine 2 Sides] in [Dup./ Combine/ Series].	You can save paper and toner.	
Dated confidential copy	In [Stamp], specify [CONFIDENTIAL] under [Preset Stamp], and [Date Stamp].	You can increase security awareness by printing "CONFIDENTIAL" and the date on copies.	
Conference material copy	Specify [Combine 2 Sides] in [Dup./ Combine/ Series] and [Staple] in [Output/ Customize Function/ Finisher].	You can copy conference materials efficiently.	
Magazine copy	Specify [Magazine] in [Dup./ Combine/ Series] and [Staple: Center] in [Output/ Customize Function/ Finisher].	You can save paper. Also, you can perform printing jobs such as producing leaflets in-house instead of having them printed by an outside printing company.	
Unified-size copy	Specify [Mixed Sizes] and [Auto Reduce / Enlarge].	You can print various size copies onto one size of paper, so they are easier to manage.	

Program name	Program description	Effect	
Stamping corporate name copy	Specify [User Stamp] in [Stamp].	You can stamp the name of your company on copies of working or architectural drawings. Your company name needs to be preregistered in the machine.	
Z-folding copy	Specify [Z-fold] in [Output/ Customize Function/ Finisher].	A3 size paper is folded to A4 size. You can print various size copies onto one size of paper, so they are easier to manage.	
Thumbnail copy	Specify [Combine 1 Side] in [Dup./Combine/Series].	You can copy up to eight pages onto one side of a sheet, so that you can save paper.	
Storage copy: XXXX (replace XXXX by a folder name)	Specify a folder in [Target Folder to Store] in [Store File].	You can use folders to organize stored files by user name or intended use.	

Scanner mode

Program name	Program description	Effect	
Easy PDF scan	Select [Full Color: Text / Photo] in [Scan Settings]. In [Send File Type / Name], select [PDF] under [File Type] and enter the business details such as "London branch: daily report" under [File Name].	You can scan documents efficiently.	
High compression PDF scan	Select [Full Color: Text / Photo] in [Scan Settings] and [High Compression PDF] in [Send File Type / Name].	You can compress the data size of scanned documents, so that you can send and store them.	
Long-term storage scan	Select [PDF/A] in [Send File Type / Name].	You can easily digitize documents to "PDF/A" file format, which is suitable for long-term storage.	

Program name	Program description	Effect	
Unified-size scan	In [Scan Settings], select [Mixed Original Sizes] in [Scan Size] and specify the finished size of scanned data in [Reduce / Enlarge] under [Edit].	You can skip this procedure to unify the size when reprinting scanned data.	
Digital signature scan	In [Send File Type / Name], specify [PDF] in [File Type], and also specify [Digital Signature].	You can add a digital signature to an important document such as a contract, so that any data tampering can be detected.	
Dividing file scan	Specify [Divide] in [Original Feed Type].	You can scan a multiple page original as one file by splitting it into groups of a specified number of pages.	
High resolution scan	In [Send File Type / Name], specify TIFF format in [File Type]. Also, specify a higher resolution in [Scan Settings].	Scanned documents maintain much of the detail of the originals, but the size of the data may be quite large.	
Batch document scan	Select [Batch] in [Original Feed Type].	You can apply multiple scans to a large volume of originals and send the scanned originals as a single job.	
Scan to XXXX (replace XXXX by a destination name)	Select e-mail or folder destinations from the list that is registered in the machine's Address Book, and then specify the scan settings.	If you register destinations and scan settings that you use often, you can skip the procedures to specify them when sending a scanned file.	
Storage scan: XXXX (replace XXXX by a folder name)	Specify a folder in [Target Folder to Store] in [Store File].	You can use folders to organize stored files by user name or intended use.	

U Note

- Depending on the options installed, some functions cannot be registered. For details, see "Functions Requiring Optional Configurations", Getting Started.
- The names of programs given above are just examples. You can assign any name to a program according to your objectives.

• Depending on your business details or the type of documents to be scanned, registering a program cannot be recommended.

Turning On/Off the Power

Important

- Do not push the main power switch repeatedly.
- When you push the main power switch, wait at least 10 seconds after it is confirmed that the main power indicator has lit up or gone out.
- If the main power indicator does not light up or go out in 5 minutes after you push the main power switch, contact your service representative.

The main power switch is on the top left of the machine. When this switch is turned on, the main power turns on and the main power indicator on the right side of the control panel lights up. When this switch is turned off, the main power turns off and the main power indicator on the right side of the control panel goes out. When this is done, machine power is off.

Confirm how much power the options draw, and then plug them into an outlet that is nearby but separate from the outlet that the main machine is plugged into.

Turning On the Main Power

- 1. Make sure the power cord is firmly plugged into the wall outlet.
- 2. Open the main power switch cover, and then push the main power switch.

The main power indicator goes on.



Turning Off the Main Power



⚠ CAUTION

 When disconnecting the power cord from the wall outlet, always pull the plug, not the cord. Pulling the cord can damage the power cord. Use of damaged power cords could result in fire or electric shock.

- Do not turn off the power while the machine is in operation.
- Do not hold down the main power switch while turning off the main power. Doing so forcibly turns off the machine's power and may damage the hard disk or memory and cause malfunctions.
- 1. Open the main power switch cover, and then push the main power switch.
 - The main power indicator goes out. The main power turns off automatically when the machine shuts down. If the screen on the control panel does not disappear, contact your service representative.

Logging In the Machine

When the Authentication Screen Is Displayed

If Basic Authentication, Windows Authentication, or LDAP Authentication is active, the authentication screen appears on the display. The machine only becomes operable after entering your own Login User Name and Login Password. If User Code Authentication is active, you cannot use the machine until you enter the User Code.

If you can use the machine, you can say that you are logged in. When you go out of the operable state, you can say that you are logged out. After logging in the machine, be sure to log out of it to prevent unauthorized usage.




- Ask the user administrator for the Login User Name, Login Password, and User Code. For details
 about user authentication, see Security Guide.
- User Code to enter on User Code Authentication is the numerical value registered in the Address Book as "User Code".

User Code Authentication Using the Control Panel

If User Code Authentication is active, a screen prompting you to enter a User Code appears.

Enter a User Code (up to eight digits), and then press [OK].



Logging In Using the Control Panel

This section explains the procedure for logging in to the machine when Basic Authentication, Windows Authentication, or LDAP Authentication is set.

1. Press [Login].



- 2. Enter a Login User Name, and then press [OK].
- 3. Enter a Login Password, and then press [OK].


When the user is authenticated, the screen for the function you are using appears.

Logging Out Using the Control Panel

This section explains the procedure for logging out the machine when Basic Authentication, Windows Authentication, or LDAP Authentication is set.



- To prevent use of the machine by unauthorized persons, always log out when you have finished using the machine.
- 1. Press the [Login/Logout] key.



2. Press [Yes].

Placing Originals


Placing Originals on the Exposure Glass

ACAUTION

• Keep your hands away from the hinges and exposure glass when lowering the ADF. Not doing so may result in an injury if your hands or fingers are pinched.

- Do not lift the ADF forcefully. Otherwise, the cover of the ADF might open or be damaged.
- 1. Lift the ADF.
 - Be sure to lift the ADF by more than 30 degrees. Otherwise, the size of the original might not be detected correctly.
- 2. Place the original face down on the exposure glass. The original should be aligned to the rear left corner.


Start with the first page to be scanned.



- 1. Positioning mark
- Lower the ADF.

Placing Originals in the Auto Document Feeder

Be sure not to block the sensor or load the original untidily. Doing so may cause the machine to detect the size of the original incorrectly or display a paper misfeed message. Also, be sure not to place originals or other objects on the top cover. Doing so may cause a malfunction.



- 1. Sensors
- 2. Original guide
- 1. Adjust the original guide to the original size.
- 2. Place the aligned originals squarely face up in the ADF.

Do not stack originals beyond the limit mark.

The first page should be on the top.



1. Limit mark

3. Copy

This chapter describes frequently used copier functions and operations. For the information not included in this chapter, see Copy/Document Server on the supplied CD-ROM.

Basic Procedure

To make copies of originals, place them on the exposure glass or in the ADF.


When placing the original on the exposure glass, start with the first page to be copied. When placing the original in the ADF, place them so that the first page is on the top.

For details about placing the original on the exposure glass, see page 51 "Placing Originals on the Exposure Glass".

For details about placing the original in the ADF, see page 51 "Placing Originals in the Auto Document Feeder".

To copy onto paper other than plain paper, specify the paper type in [Tray Paper Settings] according to the weight of the paper you are using. For details, see "Changing Tray Paper Settings", Paper Settings.

1. Press the [Home] key on the control panel, and press the [Copier] icon on the screen. If the [Copier] icon does not appear, press the 🚨 icon at the upper right corner of the screen to switch to the menu screen.



2. Make sure that no previous settings remain.

When there are previous settings remaining, press the [Reset] key.

- 3. Place the originals.
- 4. Make desired settings.
- 5. Enter the number of copies with the number keys.

The maximum copy quantity that can be entered is 9999.


6. Press the [Start] key.

When placing the original on the exposure glass, press the [#] key after all originals are scanned. Some functions such as Batch mode may require that you press the [#] key when placing originals in the ADF. Follow the messages that appear on screen.

7. When the copy job is finished, press the [Reset] key to clear the settings.

Auto Reduce / Enlarge

The machine automatically detects the original size and then selects an appropriate reproduction ratio based on the paper size you select.



CKNOOS



• If you select a reproduction ratio after pressing [Auto Reduce / Enlarge], [Auto Reduce / Enlarge] is canceled and the image cannot be rotated automatically.

This is useful to copy different size originals to the same size paper.

If the orientation in which your original is placed is different from that of the paper you are copying onto, the machine rotates the original image by 90 degrees and fits it on the copy paper (Rotate Copy). For example, to reduce A3 (11 × 17) \Box originals to fit onto A4 (8 $^1/_2$ × 11) \Box paper, select a paper tray containing A4 (8 $^1/_2$ × 11) \Box paper, and then press [Auto Reduce / Enlarge]. The image is automatically rotated. For details about Rotate Copy, see "Rotate Copy", Copy/ Document Server.

The original sizes and orientations you can use with this function are as follows:


Region A (mainly Europe and Asia)

Original location	Original size and orientation
Exposure glass	A3D, B4 JISD, A4DD, B5 JISDD, A5D, 8 ¹ / ₂ × 13D
ADF	A3 \Box , B4 JIS \Box , A4 \Box \Box , B5 JIS \Box \Box , A5 \Box \Box , B6 JIS \Box \Box , 11 × 17 \Box , 8 $^{1}/_{2}$ × 11 \Box \Box , 8 $^{1}/_{2}$ × 13 \Box

Region B (mainly North America)

Original location	Original size and orientation
Exposure glass	$11 \times 17^{\Box}$, $8^{1}/_{2} \times 14^{\Box}$, $8^{1}/_{2} \times 11^{\Box}$, $5^{1}/_{2} \times 8^{1}/_{2}^{\Box}$
ADF	$11 \times 17^{\Box}$, $8^{1}/_{2} \times 14^{\Box}$, $8^{1}/_{2} \times 11^{\Box}$, $5^{1}/_{2} \times 8^{1}/_{2}^{\Box}$ \Box , $10 \times 14^{\Box}$, $7^{1}/_{4} \times 10^{1}/_{2}^{\Box}$, A3 \Box , A4 \Box


1. Press [Auto Reduce / Enlarge].



- 2. Select the paper size.
- 3. Place the originals, and then press the [Start] key.

Duplex Copying

Copies two 1-sided pages or one 2-sided page onto a 2-sided page. During copying, the image is shifted to allow for the binding margin.



There are two types of Duplex.

1 Sided → 2 Sided

Copies two 1-sided pages on one 2-sided page.

2 Sided → 2 Sided


Copies one 2-sided page on one 2-sided page.

The resulting copy image will differ according to the orientation in which you place your originals (\square or \square).


Original orientation and completed copies

To copy on both sides of the paper, select the original and copy orientation according to how you want the printout to appear.

Original	Placing originals	Original Orientation	Orientation	Сору
A	A	RR	Top to Top	→
	A A MANAGEMENT OF THE PROPERTY	e e	Top to Bottom	A




1. Press [Dup./ Combine/ Series].



- 2. Make sure that [Duplex] is selected. If [Duplex] is not selected, press [Duplex].
- Select [1 Sided → 2 Sided] or [2 Sided → 2 Sided] according to how you want the document to be output.


To change the original or copy orientation, press [Orientation].



- 4. Press [OK].
- 5. Place the originals.
- 6. Press [Special Original].



7. Select the original orientation, and then press [OK].




8. Press the [Start] key.


Specifying the Original and Copy Orientation

Select the orientation of the originals and copies if the original is two-sided or if you want to copy onto both sides of the paper.

• Top to Top




• Top to Bottom



1. Press [Orientation].

2. Select [Top to Top] or [Top to Bottom] for [Original:] if the original is two-sided.



- 3. Select [Top to Top] or [Top to Bottom] for [Copy:].
- 4. Press [OK].

Combined Copying


This mode can be used to select a reproduction ratio automatically and copy the originals onto a single sheet of copy paper.

The machine selects a reproduction ratio between 25 and 400%. If the orientation of the original is different from that of the copy paper, the machine will automatically rotate the image by 90 degrees to make copies properly.


Orientation of the original and image position of Combine

The image position of Combine differs according to original orientation and the number of originals to be combined.

Portrait (□) originals



• Landscape (□) originals




CKN016


Placing originals (originals placed in the ADF)

The default value for the copy order in the Combine function is [From Left to Right]. To copy originals from right to left in the ADF, place them upside down.

· Originals read from left to right



• Originals read from right to left



One-Sided Combine

Combine several pages onto one side of a sheet.



There are six types of One-Sided Combine.

1 Sided 2 Originals → Combine 1 Side

Copies two 1-sided originals to one side of a sheet.

1 Sided 4 Originals → Combine 1 Side

Copies four 1-sided originals to one side of a sheet.

1 Sided 8 Originals → Combine 1 Side

Copies eight 1-sided originals to one side of a sheet.

2 Sided 2 Pages → Combine 1 Side

Copies one 2-sided original to one side of a sheet.


2 Sided 4 Pages → Combine 1 Side

Copies two 2-sided originals to one side of a sheet.

2 Sided 8 Pages → Combine 1 Side


Copies four 2-sided originals to one side of a sheet.

1. Press [Dup./ Combine/ Series].



- 2. Press [Combine].
- 3. Select [1 Sided] or [2 Sided] for [Original:].


If you selected [2 Sided], you can change the orientation.



- 4. Make sure that [Combine 1 Side] is selected.
- 5. Select the number of originals to combine.
- 6. Press [OK].
- 7. Select the paper size.
- 8. Place the originals, and then press the [Start] key.

Two-Sided Combine

Combines various pages of originals onto two sides of one sheet.



CKN074

There are six types of Two-Sided Combine.

1 Sided 4 Originals → Combine 2 Sides

Copies four 1-sided originals to one sheet with 2 pages per side.

1 Sided 8 Originals → Combine 2 Sides

Copies eight 1-sided originals to one sheet with 4 pages per side.

1 Sided 16 Originals → Combine 2 Sides

Copies 16 1-sided originals to one sheet with 8 pages per side.

2 Sided 4 Pages → Combine 2 Sides

Copies two 2-sided originals to one sheet with 2 pages per side.


2 Sided 8 Pages → Combine 2 Sides

Copies four 2-sided originals to one sheet with 4 pages per side.

2 Sided 16 Pages → Combine 2 Sides


Copies eight 2-sided originals to one sheet with 8 pages per side.

1. Press [Dup./ Combine/ Series].



2. Press [Combine].

3. Select [1 Sided] or [2 Sided] for [Original:].



- 4. Press [Combine 2 Sides].
- 5. Press [Orientation].
- 6. Select [Top to Top] or [Top to Bottom] for [Original:] if the original is two-sided.
- 7. Select [Top to Top] or [Top to Bottom] for [Copy:], and then press [OK].
- 8. Select the number of originals to combine.
- 9. Press [OK].
- 10. Select the paper size.
- 11. Place the originals, and then press the [Start] key.


Copying onto Custom Size Paper from the Multi Bypass Tray (Tray A)

Sizes of paper that can be fed from the multi bypass tray (Tray A) are as follows:

- When the banner sheet tray of multi bypass tray (Tray A) is installed:
 Horizontal length: 139.7–700.0 mm (5.50–27.55 inches), vertical length: 210.0–330.2 mm (8.27–13.00 inches)
- When the banner sheet tray of multi bypass tray (Tray A) is not installed:
 Horizontal length: 139.7-487.7 mm (5.50-19.20 inches), vertical length: 100.0-330.2 mm (3.94-13.00 inches)

Note however that the limitation on the horizontal and vertical length range will vary depending on which options are installed.

- When prints are delivered to the upper tray of the finisher or the high capacity stacker: Horizontal length: 139.7–700.0 mm (5.50–27.55 inches), vertical length: 100.0–330.2 mm (3.94–13.00 inches)
- When prints are delivered to the shift tray of the finisher:
 Horizontal length: 139.7–700.0 mm (5.50–27.55 inches), vertical length: 139.7–330.2 mm (5.50–13.00 inches)
- When prints are delivered to the stacker tray:
 Horizontal length: 139.7–487.7 mm (5.50–19.20 inches), vertical length: 139.7–330.2 mm (5.50–13.00 inches)
- 1. Load the paper face up in the multi bypass tray (Tray A).
- 2. Press [Tray A].
- 3. Make sure that [Paper Size] is selected.
- 4. Press [Program Custom Size].
- 5. Enter the horizontal size with the number keys, and then press [#].



- 6. Enter the vertical size with the number keys, and then press [#].
- 7. Press [OK] twice.
- 8. Place the originals, and then press the [Start] key.

Copying onto Envelopes

This section describes how to copy onto regular size and custom size envelopes. Place the original on the exposure glass and place the envelope in the multi bypass tray (Tray A) or wide LCT.


Specify the thickness of the paper according to the weight of the envelopes you are printing on. For details about the relationship between paper weight and paper thickness and the sizes of envelopes that can be used, see page 124 "Recommended Paper Sizes and Types".


For details about handling envelopes, supported envelope types, and how to load envelopes, see page 147 "Envelopes".



• The Duplex function cannot be used with envelopes. If the Duplex function is specified, cancel the setting.

To copy onto custom size envelopes, you must specify the envelope's dimensions. Specify the horizontal and vertical length of the envelope.





: Vertical

Be sure to include the fully open flap in the horizontal dimension.

Copying onto Envelopes from the Multi Bypass Tray (Tray A)

- 1. Load the envelopes face up in the multi bypass tray (Tray A).
- 2. Press [Tray A].
- 3. Make sure that [Paper Size] is selected.

- 4. Specify the envelope size, and then press [OK].
- 5. Press [Special Paper].
- 6. Select [Envelope], and then press [OK].
- 7. Place the originals, and then press the [Start] key.

Copying onto Envelopes from the Wide Large Capacity Tray

Before using this function, specify the paper size and type under [Tray Paper Settings]. For the paper type, select [Envelope]. For details, see "Changing Tray Paper Settings", Paper Settings.

- 1. Select the paper tray where the envelopes are loaded.
- 2. Place the originals, and then press the [Start] key.

The machine assembles copies as sets in sequential order.


Sort/Shift Sort

Copies are assembled as sets in sequential order.

To use Shift Sort, a finisher or high capacity stacker is required. Each time the copies of one set or a job are delivered, the next copy is shifted to separate each set or job.



1. Select the Sort function (under [Sort / Stack].



- 2. Enter the number of copy sets using the number keys.
- 3. Place the originals.

To confirm the type of finishing, press the [Sample Copy] key.

4. Press the [Start] key.

Changing the Number of Sets


You can change the number of copy sets during copying.



- This function can be used only when the Sort function is selected.
- 1. While "Copying..." is displayed, press the [Stop] key.

3

2. Enter the number of copy sets with the number keys.



3. Press [Continue].


Copying starts again.

Storing Data in the Document Server

The Document Server enables you to store documents being read with the copy feature on the hard disk of this machine. Thus you can print them later applying necessary conditions.

You can check the stored documents on the Document Server screen. For details about the Document Server, see page 99 "Storing Data".

1. Press [Store File].



- 2. Enter a user name, file name, or password if necessary.
- 3. Specify a folder in which to store the document if necessary.
- 4. Press [OK].
- 5. Place the originals.
- 6. Make the scanning settings for the original.
- 7. Press the [Start] key.

Stores scanned originals in memory and makes one set of copies. If you want to store another document, do so after copying is complete.

4. Print

This chapter describes frequently used printer functions and operations. For the information not included in this chapter, see Print on the supplied CD-ROM.

Quick Install

You can install the printer drivers easily from the CD-ROM provided with this machine.

Using Quick Install, the PCL 6 printer driver is installed under network environment, and the Standard TCP/IP port will be set.



- Manage Printers permission is required to install the drivers. Log on as an Administrators group member.
- 1. Click [Quick Install] on the installer screen.
- 2. The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- 3. Click [Next>].
- 4. Select the machine model you want to use in the [Select Printer] dialog box.
- 5. Click [Install].
- 6. Configure the user code, default printer, and shared printer as necessary.
- 7. Click [Continue].

The installation starts.

8. Click [Finish].

When you are prompted to restart your computer, restart it by following the instructions that appear.

9. Click [Exit] in the first window of the installer, and then take out the CD-ROM.

Displaying the Printer Driver Properties

This section explains how to open the printer driver properties from [Devices and Printers].

Mportant (

- Manage Printers permission is required to change the printer settings. Log on as an Administrators group member.
- You cannot change the machine default settings for individual users. Settings made in the printer properties dialog box are applied to all users.
- 1. On the [Start] menu, click [Devices and Printers].
- 2. Right-click the icon of the printer you want to use.
- 3. Click [Printer properties].

Standard Printing



 The default setting is two-sided printing. If you want to print on only one side, select [Off] for the two-sided printing setting.

When Using the PCL 6 Printer Driver

- Click the WordPad menu button in the upper left corner of the window, and then click [Print].
- 2. In the [Select Printer] list, select the printer you want to use.
- 3. Click [Preferences].
- 4. Click the [Frequently Used Settings] tab.
- 5. In the "Job Type:" list, select [Normal Print].
- 6. In the "Document Size:" list, select the size of the original to be printed.
- In the "Orientation" area, select [Portrait] or [Landscape] as the orientation of the original.
- 8. In the "Paper Type:" list, select the type of paper that is loaded in the paper tray.
- In the "Input Tray:" list, select the paper tray that contains the paper you want to print onto.
 - If you select [Auto Tray Select] in the "Input Tray:" list, the source tray is automatically selected according to the paper size and type specified.
- 10. Select [Color] or [Black and White] in the "Color/Black and White:" list.
- 11. If you want to print multiple copies, specify a number of sets in the "Copies:" box.
- 12. Click [OK].
- 13. Start printing from the application's [Print] dialog box.

Printing on Both Sides of Sheets

This section explains how to print on both sides of each page using the printer driver.



- The types of paper that can be printed on both sides are as follows:
 - Plain, Recycled, Color, Letterhead, Preprinted, Prepunched, Black, Coated Paper: Gloss Print, Coated (Glossy), Coated (Matted), Synthetic, Textured

When Using the PCL 6 Printer Driver

- Click the WordPad menu button in the upper left corner of the window, and then click [Print].
- 2. In the [Select Printer] list, select the printer you want to use.
- 3. Click [Preferences].
- 4. Click the [Frequently Used Settings] tab.

You can also click the [Detailed Settings] tab, and then click [2 Sided/Layout/Booklet] in the "Menu:" box.

- 5. Select the method for binding the output pages in the "2 sided:" list.
- 6. Change any other print settings if necessary.
- 7. Click [OK].
- 8. Start printing from the application's [Print] dialog box.

Types of Two-sided Printing

You can select which way the bound pages open by specifying which edge to bind.

Orientation	Open to Left	Open to Top	
Portrait	A:		
Landscape	A	A	

Combining Multiple Pages into Single Page

This section explains how to print multiple pages onto a single sheet. The combine printing function allows you to economize on paper by printing multiple sheets at reduced size onto a single sheet.

When Using the PCL 6 Printer Driver

- Click the WordPad menu button in the upper left corner of the window, and then click [Print].
- 2. In the [Select Printer] list, select the printer you want to use.
- 3. Click [Preferences].
- 4. Click the [Frequently Used Settings] tab.

You can also click the [Detailed Settings] tab, and then click [2 Sided/Layout/Booklet] in the "Menu:" box.

5. Select the combination pattern in the "Layout:" list, and then specify the method for combining pages in the "Page Order:" list.

To draw a border line around each page, select [Draw Frame Border] in [2 Sided/Layout/Booklet] in the [Detailed Settings] tab.

- 6. Change any other print settings if necessary.
- 7. Click [OK].
- 8. Start printing from the application's [Print] dialog box.

Types of Combine Printing

This function allows you to print 2, 4, 6, 9, or 16 pages at reduced size onto a single sheet and to specify a page ordering pattern for the combination. When combining 4 or more pages onto a single sheet of paper, four patterns are available.

The following illustrations show example page ordering patterns for 2- and 4-page combinations.

2 Pages per Sheet

Orientation	From Left to Right/Top to Bottom	From Right to Left/Top to Bottom
Portrait	3 4 1 2	2 1

4 Pages per Sheet

Right, then Down	Down, then Right	Left, then Down	Down, then Left
1 2 3 4	1 3 2 4	2 1 4 3	3 1 4 2

Printing on Envelopes


Configure the paper settings appropriately using both the printer driver and the control panel.



To print on envelopes, load them into the optional wide LCT or Tray A, and be sure to specify an
appropriate paper type. For details, see page 124 "Recommended Paper Sizes and Types".

Configuring Envelope Settings Using the Control Panel

- 1. Load envelopes in the paper tray.
- 2. Press the [Paper Setting] key.



- 3. Select the paper tray in which the envelopes are loaded.
- 4. Press [Manual Paper Settings].
- 5. Press [Envelope] in the "Paper Type" area, and then select the appropriate item in the "Paper Weight" area.
- 6. Press the [Paper Size] tab.
- 7. Select the envelope size, and then press [OK].
- 8. Press [OK].
- 9. Press the [Paper Setting] key.

Printing on Envelopes Using the Printer Driver

When using the PCL 6 printer driver

 Click the WordPad menu button in the upper left corner of the window, and then click [Print].

- 2. In the [Select Printer] list, select the printer you want to use.
- 3. Click [Preferences].
- 4. In the "Document Size:" list, select the envelope size.
- 5. In the "Paper Type:" list, select [Envelope].
- 6. In the "Input Tray:" list, select the paper tray where the envelopes are loaded.
- 7. Change any other print settings if necessary.
- 8. Click [OK].
- 9. Start printing from the application's [Print] dialog box.

Saving and Printing Using the Document Server

The Document Server enables you to store documents on the machine's hard disk, and allows you to edit and print them as necessary.

Mportant ...

- Applications with their own drivers, such as PageMaker, do not support this function.
- Do not cancel the file transfer process while the data is being sent to the Document Server. The
 process may not be canceled properly. If you accidentally cancel a print job, use the control panel
 of the machine to delete the transferred data. For details about how to delete documents that are
 stored in the Document Server, see "Deleting Stored Documents", Copy/ Document Server, or
 Web Image Monitor Help.
- Up to 3,000 files can be stored in the Document Server. New files cannot be stored when 3,000 files have already been stored. Even if less than 3,000 files are stored, new files cannot be stored when
 - The number of pages in a document exceeds 5,000.
 - The total number of stored pages in the machine and the sent data has reached 15,000 (It
 may be fewer depending on the print data).
 - The hard disk is full.

You can send data created on a client computer to the Document Server.

Storing Documents in Document Server

- If the machine is not used as the Document Server, the maximum number of the documents that can
 be stored in the server may be less than the number described in the specification.
- Click the WordPad menu button in the upper left corner of the window, and then click [Print].
- 2. In the "Select Printer" list, select the printer you want to use.
- 3. Click [Preferences].
- 4. In the "Job Type:" list, click [Document Server].
- 5. Click [Details...].
- 6. Enter a user ID, file name, password, and user name as required.
- 7. Specify the folder number to store the document in the "Folder Number:" box.
 When "0" is specified in the "Folder Number:" box, documents will be saved in the Shared folder.

- If the folder is protected by a password, enter the password in the "Folder Password:" box.
- 9. Click [OK].
- 10. Change any other print settings if necessary.
- 11. Click [OK].
- 12. Start printing from the application's [Print] dialog box.



 You can print the documents stored in the Document Server using the control panel. For details, see page 101 "Printing Stored Documents".

Managing Documents Stored in Document Server

If this machine is configured as a network printer using TCP/IP, you can view or delete the documents stored in the machine's Document Server using Web Image Monitor from a client computer connected to the network. You can print and operate this machine remotely without operating the control panel.

5. Scan


This chapter describes frequently used scanner functions and operations. For the information not included in this chapter, see Scan on the supplied CD-ROM.

Basic Procedure When Using Scan to Folder



- Before performing this procedure, see "Preparation for Sending by Scan to Folder", Scan and
 confirm the details of the destination computer. See also "Registering Folders", Connecting the
 Machine/ System Settings, and register the address of the destination computer to the address
 book.
- 1. Press the [Home] key on the bottom left of the control panel, and press the [Scanner] icon on the [Home] screen.

If the [Scanner] icon does not appear, press the 🕮 icon at the upper right corner of the screen to switch to the menu screen.



2. Make sure that no previous settings remain.


If a previous setting remains, press the [Reset] key.

3. Press the [Folder] tab.



4. Place originals.

5. If necessary, specify the scan settings according to the original to be scanned.



Example: Scanning the document in color/duplex mode, and saving as a PDF file.

- Press [Scan Settings], press [Full Color: Text / Photo] in the [Original Type] tab, and then
 press [OK].
- Press [Original Feed Type], press [2 Sided Original], and then press [OK].
- Press [Send File Type / Name], press [PDF], and then press [OK].
- 6. Specify the destination.

You can specify multiple destinations.

7. Press the [Start] key.

Creating a Shared Folder on a Computer Running Windows/Confirming a Computer's Information

The following procedures explain how to create a shared folder on a computer running Windows, and how to confirm the computer's information. In these examples, Windows 7 Ultimate is the operating system, and the computer is a member in a network domain. Write down the confirmed information.

Step 1: Confirming the user name and computer name

Confirm the user name and the name of the computer you will send scanned documents to.

- On the [Start] menu, point to [All Programs], then [Accessories], and then click on [Command Prompt].
- 2. Enter the command "ipconfig/all", and then press the [Enter] key.
- 3. Confirm the name of the computer.

The computer's name is displayed under [Host Name].

You can also confirm the IPv4 address. The address displayed under [IPv4 Address] is the IPv4 address of the computer.

- Next, enter the command "set user", and then press the [Enter] key. (Be sure to put a space between "set" and "user".)
- 5. Confirm the user name.

The user name is displayed under [USERNAME].

Step 2: Creating a shared folder on a computer running Microsoft Windows

Create a shared destination folder in Windows and enable sharing. In the following procedure, a computer which is running under Windows 7 Ultimate and participating in a domain is used as an example.

€ Important

- You must log in as an Administrators group member to create a shared folder.
- If "Everyone" is left selected in Step 6, the created shared folder will be accessible by all users. This is a security risk, so we recommend that you give access rights only to specific users. Use the following procedure to remove "Everyone" and specify user access rights.
- Create a folder, just as you would create a normal folder, in a location of your choice on the computer.
- 2. Right-click the folder, and then click [Properties].
- 3. On the [Sharing] tab, select [Advanced Sharing...].
- 4. Select the [Share this folder] check box.
- 5. Click [Permissions].
- 6. In the [Group or user names:] list, select "Everyone", and then click [Remove].
- 7. Click [Add...].
- 8. In the [Select Users or Groups] window, click [Advanced...].
- 9. Specify one or more object types, select a location, and then click [Find Now].
- From the list of results, select the groups and users you want to grant access to, and then click [OK].
- 11. In the [Select Users or Groups] window, click [OK].
- 12. In the [Group or user names:] list, select a group or user, and then, in the [Allow] column of the permissions list, select either the [Full Control] or [Change] check box.
 - Configure the access permissions for each group and user.
- 13. Click [OK].

Step 3: Specifying access privileges for the created shared folder


If you want to specify access privileges for the created folder to allow other users or groups to access the folder, configure the folder as follows:

- 1. Right-click the folder created in Step 2, and then click [Properties].
- 2. On the [Security] tab, click [Edit...].
- 3. Click [Add...].
- 4. In the [Select Users or Groups] window, click [Advanced...].
- Specify one or more object types, select a location, and then click [Find Now].
- From the list of results, select the groups and users you want to grant access to, and then click [OK].
- 7. In the [Select Users or Groups] window, click [OK].
- 8. In the [Groups or user names:] list, select a group or user, and then, in the [Allow] column of the permissions list, select either the [Full Control] or [Modify] check box.
- 9. Click [OK].

Registering an SMB Folder

- Press the [Home] key on the bottom left of the control panel, and press the [Address Book Management] icon on the [Home] screen.
 - If the [Address Book Management] icon does not appear, press the 😅 icon at the upper right corner of the screen to switch to the [Home] screen.
- 2. Check that [Program / Change] is selected.
- 3. Press [New Program].
- 4. Press [Change] under "Name".
 - The name entry display appears.
- 5. Enter the name, and then press [OK].
- 6. Press [▼Next].

7. Press the key for the classification you want to use under "Select Title".




The keys you can select are as follows:

- [Frequent]: Added to the page that is displayed first.
- [AB], [CD], [EF], [GH], [IJK], [LMN], [OPQ], [RST], [UVW], [XYZ], [1] to [10]: Added to the list of items in the selected title.

You can select [Frequent] and one more key for each title.

8. Press [Auth. Info], and then press [▼Next].



9. Press [Specify Other Auth. Info] on the right side of "Folder Authentication".

When [Do not Specify] is selected, the SMB User Name and SMB Password that you have specified in "Default User Name / Password (Send)" of File Transfer settings are applied.

- 10. Press [Change] under "Login User Name".
- 11. Enter the login user name of the destination computer, and then press [OK].
- 12. Press [Change] under "Login Password".
- 13. Enter the password of the destination computer, and then press [OK].
- 14. Enter the password again to confirm, and then press [OK].
- 15. Press [Folder].



17. Press [Change] or [Browse Network], and then specify the folder.

To specify a folder, you can either enter the path manually or locate the folder by browsing the network.

- 18. Press [Connection Test] to check the path is set correctly.
- 19. Press [Exit].


If the connection test fails, check the settings, and then try again.

- 20. Press [OK].
- 21. Press the [User Tools] key.

Locating the SMB folder manually

- 1. Press [Change] under "Path".
- 2. Enter the path where the folder is located.

For example: if the name of the destination computer is "User", and the folder name is "Share", the path will be \\User\Share.



If the network does not allow automatic obtaining of IP addresses, include the destination computer's IP address in the path. For example: if the IP address of the destination computer is "192.168.0.191", and the folder name is "Share", the path will be \\192.168.0.191\Share.

3. Press [OK].

If the format of the entered path is not correct, a message appears. Press [Exit], and then enter the path again.

Locating the SMB folder using Browse Network


1. Press [Browse Network].

The client computers sharing the same network as the machine appear.

Network display only lists client computers you are authorized to access.

- 2. Select the group that contains the destination computer.
- 3. Select the computer name of the destination computer.

Shared folders under it appear.



You can press [Up One Level] to switch between levels.

- 4. Select the folder you want to register.
- 5. Press [OK].

Deleting an SMB Registered Folder

 Press the [Home] key on the bottom left of the control panel, and press the [Address Book Management] icon on the [Home] screen.

If the [Address Book Management] icon does not appear, press the 🕮 icon at the upper right corner of the screen to switch to the [Home] screen.

- 2. Check that [Program / Change] is selected.
- 3. Select the name whose folder you want to delete.

Press the name key, or enter the registered number using the number keys.

You can search by the registered name, user code, folder name, or e-mail address.

4. Press [Folder].


5. Press the protocol which is not currently selected.

A confirmation message appears.

- 6. Press [Yes].
- 7. Press [OK].
- 8. Press the [User Tools] key.

Entering the Path to the Destination Manually

1. Press [Manual Entry].



- 2. Press [SMB].
- 3. Press [Manual Entry] on the right side of the path field.
- 4. Enter the path for the folder.

In the following example path, the shared folder name is "user" and the computer name is "desk01":

\\desk01\user

- 5. Press [OK].
- 6. Depending on the destination setting, enter the user name for logging in to the computer.
 Press [Manual Entry] to the right of the user name field to display the soft keyboard.
- 7. Depending on the destination setting, enter the password for logging in to the computer.
 Press [Manual Entry] for the password to display the soft keyboard.
- 8. Press [Connection Test].

A connection test is performed to check whether the specified shared folder exists.

If the message "Connection with PC has failed. Check the settings." appears, see "Troubleshooting When You Use the Scanner Function", Troubleshooting.


- 9. Check the connection test result, and then press [Exit].
- 10. Press [OK].

b

Basic Procedure for Sending Scan Files by E-mail

1. Press the [Home] key on the bottom left of the control panel, and press the [Scanner] icon on the [Home] screen.


If the [Scanner] icon does not appear, press the 🕮 icon at the upper right corner of the screen to switch to the menu screen.



2. Make sure that no previous settings remain.

If a previous setting remains, press the [Reset] key.

3. Press the [Email] tab.



4. Place originals.

5. If necessary, specify the scan settings according to the original to be scanned.



Example: Scanning the document in color/duplex mode, and saving as a PDF file.

- Press [Scan Settings], press [Full Color: Text / Photo] in the [Original Type] tab, and then press [OK].
- Press [Original Feed Type], press [2 Sided Original], and then press [OK].
- Press [PDF] under [Send File Type / Name], and then press [OK].
- 6. Specify the destination.

You can specify multiple destinations.

- 7. To specify the e-mail sender, press [Sender Name], and then press [OK].
- 8. To use Message Disposition Notification, press [Recept. Notice].

If you select [Recept. Notice], the selected e-mail sender will receive e-mail notification when the e-mail recipient has opened the e-mail.

9. Press the [Start] key.

Registering an E-mail Destination

 Press the [Home] key on the bottom left of the control panel, and press the [Address Book Management] icon on the [Home] screen.


If the [Address Book Management] icon does not appear, press the 🕮 icon at the upper right corner of the screen to switch to the [Home] screen.

- 2. Check that [Program / Change] is selected.
- 3. Press [New Program].
- 4. Press [Change] under "Name".

The name entry display appears.

- 5. Enter the name, and then press [OK].
- 6. Press [▼Next].

7. Press the key for the classification you want to use under "Select Title".




The keys you can select are as follows:


- [Frequent]: Added to the page that is displayed first.
- [AB], [CD], [EF], [GH], [IJK], [LMN], [OPQ], [RST], [UVW], [XYZ], [1] to [10]: Added to the
 list of items in the selected title.

You can select [Frequent] and one more key for each title.

- 8. Press [Email].
- 9. Press [Change] under "Email Address".



10. Enter the e-mail address.



- 11. Press [OK] twice.
- 12. Press the [User Tools] key.

Deleting an E-mail Destination

 Press the [Home] key on the bottom left of the control panel, and press the [Address Book Management] icon on the [Home] screen.

If the [Address Book Management] icon does not appear, press the 🕮 icon at the upper right corner of the screen to switch to the [Home] screen.

- 2. Check that [Program / Change] is selected.
- 3. Select the name whose e-mail address you want to delete.

Press the name key, or enter the registered number using the number keys. You can search by the registered name, user code, folder name, or e-mail address.

- 4. Press [Email].
- 5. Press [Change] under "Email Address".
- 6. Press [Delete All], and then press [OK].
- 7. Press [OK].
- 8. Press the [User Tools] key.

Entering an E-mail Address Manually

1. Press [Manual Entry].




- 2. Enter the e-mail address.
- 3. Press [OK].

Basic Procedure for Storing Scan Files



- You can specify a password for each stored file. We recommend that you protect stored files from unauthorized access by specifying passwords.
- Scan file stored in the machine may be lost if some kind of failure occurs. We advise against using
 the hard disk to store important files. The supplier shall not be responsible for any damage that may
 result from the loss of files.
- 1. Press the [Home] key on the bottom left of the control panel, and press the [Scanner] icon on the [Home] screen.


If the [Scanner] icon does not appear, press the 🕮 icon at the upper right corner of the screen to switch to the menu screen.



2. Make sure that no previous settings remain.

If a previous setting remains, press the [Reset] key.

- 3. Place originals.
- 4. Press [Store File].



5. Press [Store to HDD].

- 6. If necessary, specify the stored file's information, such as [User Name], [File Name], [Password], and [Select Folder].
 - User Name

Press [User Name], and then select a user name. To specify an unregistered user name, press [Manual Entry], and then enter the name. After specifying a user name, press [OK].

File Name

Press [File Name], enter a file name, and then press [OK].

Password

Press [Password], enter a password, and then press [OK]. Re-enter the password for confirmation, and then press [OK].


Select Folder
 Specify the folder in which to save the stored files.

- 7. Press [OK].
- 8. If necessary, press [Scan Settings] to specify scanner settings such as resolution and scan size.
- 9. Press the [Start] key.

Checking a Stored File Selected from the List

This section explains how to preview a file selected from the list of stored files.

1. Press [Select Stored File].



- 2. Specify the folder in which to save the stored files.
- 3. From the list of stored files, select the file you want to check.

You can select more than one file.

4. Press [Preview].

Specifying the File Type

This section explains the procedure for specifying the file type of a file you want to send.

File types can be specified when sending files by e-mail or Scan to Folder, sending stored files by e-mail or Scan to Folder, and saving files on a memory storage device.

You can select one of the following file types:

• Single Page: [TIFF / JPEG], [PDF]


If you select a single-page file type when scanning multiple originals, one file is created for each single page and the number of files sent is the same as the number of pages scanned.

• Multi-page: [TIFF], [PDF]

If you select a multi-page file type when scan multiple originals, scanned pages are combined and sent as a single file.

Selectable file types differ depending on the scan settings and other conditions. For details about file types, see "Notes about and limitations of file types", Scan.

1. Press [Send File Type / Name].



2. Select a file type.




If the File Type is set to [PDF], configure PDF File Setting as required.


3. Press [OK].

Specifying Scan Settings

1. Press [Scan Settings].



2. Specify resolution, scan size, and other settings, as required.



3. Press [OK].

6. Document Server

This chapter describes frequently used Document Server functions and operations. For the information not included in this chapter, see Copy/ Document Server on the supplied CD-ROM.

Storing Data

This section describes the procedure for storing documents on the Document Server.



- A document accessed with a correct password remains selected even after operations are complete, and it can be accessed by other users. After the operation, be sure to press the [Reset] key to cancel the document selection.
- The user name registered to a stored document in the Document Server is to identify the document creator and type. It is not to protect confidential documents from others.
- When scanning by the scanner, make sure that all other operations are ended.

File Name

A file name such as "COPY0001" and "COPY0002" is automatically attached to the scanned document. You can change the file name.

User Name

You can register a user name to identify the user or user group that stored the documents. To assign it, select the user name registered in the Address Book, or enter the name directly. Depending on the security setting, [Access Privileges] may appear instead of [User Name].


For details about the Address Book, see "Registering Addresses and Users", Connecting the Machine/System Settings.

Password

To prevent unauthorized printing, you can specify a password for any stored document. A protected document can only be accessed if its password is entered. If a password is specified for the documents, the lock icon appears on the left side of the file name.

 Press the [Home] key on the control panel, and press the [Document Server] icon on the screen.

If the [Document Server] icon does not appear, press the 🕮 icon at the upper right corner of the screen to switch to the menu screen.



- 2. Press [To Scanning Screen].
- 3. Press [Target Folder to Store].
- 4. Specify a folder in which to store the document, and then press [OK].
- 5. Press [User Name].
- 6. Specify a user name, and then press [OK].

The user names shown are names that were registered in the Address Book. To specify a name not shown in the screen, press [Manual Entry], and then enter a user name.

- 7. Press [File Name].
- 8. Enter a file name, and then press [OK].
- 9. Press [Password].
- 10. Enter a password with the number keys, and then press [OK].

You can use four to eight digits for the password.

- 11. For double-check, enter the password again, and then press [OK].
- 12. Place the original.
- 13. Specify the original scanning conditions.
- 14. Press the [Start] key.

The original is scanned. The document is saved in the Document Server.

After scanning, a list of folders will be displayed. If the list does not appear, press [Finish Scanning].

Printing Stored Documents


Prints stored documents on the Document Server.

The items you can specify on the printing screen are as follows:

- Paper tray
- The number of prints
- [Output/Finisher] ([Output], [Finisher], [Folding Unit], [Perfect Binding], [Stacker])
- [Stamp] ([Preset Stamp], [User Stamp], [Date Stamp], [Page Numbering], [Stamp Text])
- [Cover/ Slip Sheet] ([Front Cover], [Back Cover], [Designate / Chapter], [Slip Sheet])
- [Edit] ([Margin Adj.], [Edit Image])
- [2 Sided / Book] ([1 Sided Print], [2 Sided Top to Top], [2 Sided Top to Bottom], [Specify Duplex Pages], [Booklet], [Magazine])

For details about each function, see Copy/ Document Server.

1. Select a folder.



- 2. Select a document to be printed.
- 3. When printing two or more documents at a time, repeat Step 2.

Up to 30 documents can be printed.

- 4. When specifying printing conditions, press [To Printing Screen], and then configure print settings.
- 5. Enter the number of print copies with the number keys.

The maximum quantity that can be entered is 9999.

6. Press the [Start] key.

7. Web Image Monitor

This chapter describes frequently used Web Image Monitor functions and operations. For the information not included in this chapter, see Connecting the Machine/ System Settings on the supplied CD-ROM or Web Image Monitor Help.

Displaying Top Page

This section explains the Top Page and how to display Web Image Monitor.



- When entering an IPv4 address, do not begin segments with zeros. For example: If the address is "192.168.001.010", you must enter it as "192.168.1.10".
- 1. Start your web browser.
- Enter "http://(machine's IP address or host name)/" in your web browser's URL bar.
 Top Page of Web Image Monitor appears.

If the machine's host name has been registered on the DNS or WINS server, you can enter it.

When setting SSL, a protocol for encrypted communication, under environment which server authentication is issued, enter "https://(machine's IP address or host name)/".

Web Image Monitor is divided into the following areas:



1. Menu area

If you select a menu item, its content will be shown.

2. Header area

Display icons for the links to Help and the keyword search function. This area also displays [Login] and [Logout], which allow you to switch between the administrator and guest mode.

3. Refresh/Help

- (Refresh): Click at the upper right in the work area to update the machine information. Click the web browser's [Refresh] button to refresh the entire browser screen.
- (Help): Use Help to view or download Help file contents.

4. Basic Information area

Display the basic information of the machine.

5. Work area

Display the contents of the item selected in the menu area.

8. Adding Paper and Toner

This chapter describes how to load paper into the paper tray and recommended paper sizes and types.

Loading Paper

Precautions for Loading Paper



ACAUTION

When loading paper, take care not to trap or injure your fingers.

Mportant !

• Do not stack paper over the limit mark.

Jams and misfeeds can occur when printing on thick glossy sheets. To prevent such problems, be sure to fan glossy sheets thoroughly before loading them.

When loading paper, set the paper direction according to its grain, as shown in the following diagram:

Direction of paper grain	Tray 1	A3/11 × 17 tray unit, Tray 2, or the wide LCT	Multi bypass tray (Tray A)
###	Not recommended	1111	1111




- Even if paper is loaded as described above, normal operations and print quality might still not be possible, depending on the paper type.
- When loading 52.3 g/m² (14.0 lb. Bond) paper into paper trays or loading translucent paper into the wide LCT or the multi bypass tray (Tray A), always use long grain paper.
- Prints might be noticeably curled. Flatten out prints if they are creased or curled. For details about settings for flattening out curled paper, see "Adjustment Settings for Operators", Paper Settings.
- To prevent multiple sheets from being fed at once, fan the paper before loading it.

- If you load paper when only a few sheets of paper remain in the tray, multiple sheet feeding may occur. Remove any remaining paper, stack them with the new sheets of paper, and then fan the entire stack before loading it into the tray.
- Straighten curled or warped paper before loading.
- When paper in trays that are set to automatically eject unnecessary tab stock sheets runs out, reload the tab stock from the beginning of the cycle (the first sheet).
- When you load paper into the paper tray for the first time or when you change the size or type of
 paper in the paper tray, be sure to specify the appropriate paper settings in Tray Paper Settings.
 For details, see "Changing Tray Paper Settings", Paper Settings.
- For details about the paper sizes and types that can be used, see page 124 "Recommended Paper Sizes and Types".
- You might at times hear a rustling noise from paper moving through the machine. This noise does not indicate a malfunction.


Fanning the paper




- If you load coated paper, label paper, or thick paper of 163.1–360.0 g/m² (60.1 lb. Cover–198.0 lb. Index) in the three-tray wide LCT, it is important that you fan the sheets thoroughly.
 Misfeeds may occur if paper is not fanned thoroughly.
- 1. Loosen the stack by riffling the sheets.




2. Holding its shorter ends, flex the stack back and forth to create space between the sheets. Repeat this several times.





3. Make sure there is space between the sheets.



Loading Paper into Tray 1


Region A (mainly Europe and Asia)

Tray 1 can hold A4D paper only. If you want to print on $8^{1}/_{2} \times 11D$ from Tray 1, contact your service representative.

Region B (mainly North America)



- When paper loaded in the right side of Tray 1 runs out, paper on the left is automatically shifted to
 the right. Do not pull out Tray 1 while the tray is moving paper; wait until sounds stop coming from
 the tray.
- If Tray 1 is closed too quickly, the paper in the tray may force the right tray's side fence to slip out of place. If the paper misfeeds because of this, open the tray, adjust the fence, and close the tray slowly.
- For the right stack, align the right edge of the paper with the right edge of the tray. For the left stack, align the left edge of the paper to the left edge of the tray.
- 1. Carefully pull out the paper tray until it stops.




DER05

2. Square the paper and load it print side down.


Do not stack paper over the limit mark.

· Whole tray pulled out



DER05

• Left half of the tray pulled out



3. Carefully push the paper tray fully in.



You can load paper even if Tray 1 is in use. It is okay to pull out the left half of the tray while Tray 1
is in use.

Loading Paper into the A3/11 × 17 Tray Unit

Region A (mainly Europe and Asia)


A3/11 × 17 tray unit can hold A3 \square paper only. If you want to print on A4 \square \square , B4 JIS \square , 11 × 17 \square , 8 $^{1}/_{2}$ × 14 \square , or 8 $^{1}/_{2}$ × 11 \square \square D, contact your service representative.

Region B (mainly North America)


A3/11 × 17 tray unit can hold 11 × 17 \square paper only. If you want to print on A3 \square , A4 \square \square , B4 JIS \square , 8 $^1/_2$ × 14 \square , or 8 $^1/_2$ × 11 \square \square , contact your service representative.



- Check the paper edges are aligned at the right side.
- Check that paper in the paper tray is not being used, and then pull the tray carefully out until it stops.



Do not stack paper over the limit mark.




3. Carefully push the paper tray fully in.

Loading Paper into Tray 2

Mportant !


- Check the paper edges are aligned at the right side.
- · If a paper tray is pushed vigorously when putting it back into place, the position of the tray's side fences may slip out of place.
- · When loading a low number of sheets, be sure not to squeeze the side fences in too tightly. If the side fences are squeezed too tightly against the paper, the edges may crease, the paper may misfeed, or if it weighs between 52.3-63.0g/m² (14.0-16.9 lb. Bond), it may wrinkle.
- 1. Check that paper in the paper tray is not being used, and then pull the tray carefully out until it stops.



2. Square the paper and load it print side down.

Do not stack paper over the limit mark.






3. Carefully push the paper tray fully in.




 Various sizes of paper can be loaded in Tray 2 by adjusting the positions of side fences and end fence. For details, see "Changing the Paper Size in Tray 2", Paper Specifications and Adding Paper.

Loading tab stock into Tray 2

• When loading tab stock, always use the tab sheet holder.




- Load tab stock so that the side with the tab faces the tab sheet holder.
- When loading tab stock, adjust the end fence position so that the tab sheet holder will fit the tab stock.



Loading Paper into the Multi Bypass Tray (Tray A)

Use the multi bypass tray (Tray A) to use transparencies, translucent paper, and paper that cannot be loaded in the paper trays.


- The maximum number of sheets you can load at the same time depends on paper type. Do not stack paper over the limit mark. For the maximum number of sheets you can load, see page 124 "Recommended Paper Sizes and Types".
- Check the paper edges are aligned at the left side.
- When loading a low number of sheets, be sure not to squeeze the side fences in too tightly. If the
 side fences are squeezed too tightly against the paper, the edges may crease, the paper may
 misfeed, or if it weighs between 52.3-63.0 g/m² (14.0-16.9 lb. Bond), it may wrinkle.
- Set the side fences to the paper size, and then square the paper and load it print side up.
 Do not stack paper over the limit mark.



DER069

8


2. Set the end fence.




1. End fence

2. Extender

To remove the end fence, slide it to the right by pressing the stopper down.



3. Press the elevator switch on the multi bypass tray (Tray A).



1. Elevator switch


The lamp of the elevator switch is blinking while the tray is going up, and keeps lit when it stops.

Press the elevator switch to move down the tray if you want to either add paper or remove jammed ones.

- Pull the extender out when loading A4□, 8¹/₂ × 11□ or larger sheets in the multi bypass tray (Tray A).
- Letterhead paper must be loaded in a specific orientation. For details, see page 120 "Loading Orientation-fixed Paper or Two-sided Paper".
- You can load envelopes into the multi bypass tray (Tray A). Envelopes must be loaded in a specific orientation. For details, see page 147 "Envelopes".
- Specify the sizes of paper that are not automatically detected. For details about the sizes that can be detected automatically, see page 124 "Recommended Paper Sizes and Types". For details about how to specify sizes, see "Changing to a Size That Is Not Automatically Detected", Paper Specifications and Adding Paper.
- When copying from the multi bypass tray (Tray A), see "Copying from the Multi Bypass Tray (Tray A)", Copy/ Document Server.

Loading tab stock into the multi bypass tray (Tray A)

When setting tab stock, always use the tab fence. Tabs must be set at the right side of the multi bypass tray (Tray A).




- 1. Tab fence
- 2. End fence

Loading Paper into the Three-tray Wide Large Capacity Tray

The three-tray wide LCT is identified as Tray 3, Tray 4, and Tray 5.


- Check that the paper edges are aligned with the left side.
- If a paper tray is pushed vigorously when putting it back into place, the position of the tray's side fences may slip out of place.

 Check that paper in the paper tray is not being used, and then pull the tray carefully out until it stops.



2. Load paper into the paper tray with print side up.

Do not stack paper over the limit mark.



3. Carefully push the paper tray fully in.




- If you select Paper Weight 5 to 8, [Coated: Glossy], [Coated: Matte], [Coated Paper: Gloss], or [Label Paper] in [Tray Paper Settings], air is blown out automatically to fan the paper loaded in the three-tray wide LCT. Fan this paper before loading it. For details, see page 106 "Fanning the paper".
- Various sizes of paper can be loaded in the three-tray wide LCT by adjusting the positions of side fences and end fence. For details, see "Changing the Paper Size in the Three-tray Wide Large Capacity Tray", Paper Specifications and Adding Paper.
- You can load envelopes in the three-tray wide LCT. When loading envelopes, place them in the correct orientation. For details, see page 147 "Envelopes".

Loading Paper into the Two-tray Wide Large Capacity Tray

The two-tray wide LCT is identified as Tray 3, Tray 4, Tray 5, Tray 6, Tray 7, and Tray 8.




- Check the paper edges are aligned at the left side.
- 1. Check that paper in the paper tray is not being used, and then pull the tray carefully out until it stops.



2. Load paper into the paper tray with print side up.

Do not stack paper over the limit mark.



3. Carefully push the paper tray fully in.




- Various sizes of paper can be loaded in the two-tray wide LCT by adjusting the positions of side fence and end fence. For details, see "Changing the Paper Size in the Two-tray Wide Large Capacity Tray", Paper Specifications and Adding Paper.
- You can load envelopes in the two-tray wide LCT. When loading envelopes, place them in the correct orientation. For details, see page 147 "Envelopes".

8

Loading Paper into the Interposer




- Do not place anything on top of or leave documents on the sensor. This may lead to the paper size not being correctly scanned or paper jams.
- 1. While pressing the release lever, align the side fences with the paper size to be loaded.



2. Load paper orderly.

Do not stack paper over the limit mark.


Align the side fences gently against the paper you loaded, if necessary.



1. Paper extender



- Load paper with its printed side up (the front side). If you are using the booklet finisher, load sheets print side down.
- Load paper in the interposer in the same orientation as paper in the paper tray.
- The staple position or punch hole position will be on the left side of the paper, when you are facing the machine.
- When loading paper larger than A4 ($8^{1}/_{2} \times 11$) \square , pull out the paper extender.
- To load the paper in the interposer, align the orientation of originals in the ADF as shown below.



Loading Cover Sheets into the Interposer of the Perfect Binder



- The length/size of cover sheets depends on the thickness of the spine.
- Load paper in the 🗗 orientation.
- Do not place anything on top of or leave documents on the sensor. This may lead to the paper size not being correctly detected or paper jams.

Estimating the thickness of the spine

This section explains how to calculate the approximate spine thickness and the cover sheet length and size.

Note that the length and size of a cover sheet depends on the thickness of the book block spine.


The following list shows examples for A4 or $8^{1}/_{2} \times 11$ size, 80.0 g/m² (20.0 lb. Bond) paper:

- 10-sheet book block: 1 mm (0.04 inches)
- 30-sheet book block: 3 mm (0.12 inches)
- 50-sheet book block: 5 mm (0.20 inches)
- 80-sheet book block: 8 mm (0.32 inches)
- 100-sheet book block: 10 mm (0.40 inches)
- 200-sheet book block: 20 mm (0.80 inches)

Specify the cover sheet size based on the thickness of the book block spine. Use the following equation to calculate the length of the cover sheet:

Minimum length of cover sheet (mm/inch) = "length of book block sheet (mm/inch)" \times 2 + "thickness of spine (mm/inch)"

To perfect bind a booklet with the following dimensions, specify a cover sheet length of at least 440 mm (17.4 inches):



- 1. Length of book block sheet
- 2. Thickness of spine
- 3. Length of cover sheet

Orientation and binding position of covers and originals


This section explains the orientation and binding positions of covers and originals.

Place covers and originals in the orientation in which they are read.

	Placing the cover in the interposer	Placing the book block sheet in the ADF	Binding position
Left binding	RR	R	R
Top binding*1	72		R
Right binding	RR		R


^{* 1} Select $\[\]$ (unreadable orientation) in Original Orientation, and then select top binding.

1. While lightly pinching the side fence, align it with the paper size to be loaded.



2. Load paper face up and neatly stacked.

Do not stack paper over the limit mark.



U Note

- You cannot perfect bind a booklet if the thickness of the book block's spine exceeds 23 mm (0.9 inches).
- Depending on your machine, the procedure for selecting the orientation of covers and originals for the printer function might be slightly different. For details, refer to the procedure for your machine.
- When loading thick paper of 251.0 g/m² (138.8 lb. Index) or heavier in the interposer trays of the perfect binder, make sure the grain of the paper is perpendicular to the feed direction.
- If you are loading sheets that are likely to stick together (such as sheets of coated paper), be sure to fan them thoroughly before loading. Fanning them will help prevent jams and allow them to be fed in one sheet at a time.
- The perfect binding process may scratch glossy paper.

Loading Orientation-fixed Paper or Two-sided Paper

Orientation-fixed (top to bottom) or two-sided paper (for example, letterhead paper, punched paper, or copied paper) might not be printed correctly, depending on how the originals and paper are placed.

Settings for the User Tools

• Copier mode

Specify [Yes] for [Letterhead Setting] in [Input / Output] under the Copier / Document Server Features menu, and then place the original and paper as shown below.

• Printer mode

Specify [Auto Detect] or [On (Always)] for [Letterhead Setting] in [System] under the Printer Features menu, and then place the paper as shown below.

For details about the letterhead settings, see "Input / Output", Copy/ Document Server, or "System", Print.

Original orientation and paper orientation

The meanings of the icons are as follows:

lcon	Meaning
R	Place or load paper scanned or printed side face up.
	Place or load paper scanned or printed side face down.
e	

• Original orientation

Original orientation	Exposure glass	ADF
Readable orientation		R

Original orientation	Exposure glass	ADF
Unreadable orientation	• Copy	
	• Scanner	
Paper orientation		

- Paper orientation
 - Copier mode

Copy side	Tray 1	Tray 2 or A3/11 × 17 tray unit	Multi bypass tray (Tray A) or wide LCT
One-sided	·····	·····	
		80	[.
Two-sided			
		80	[.

• Printer mode

Print side	Tray 1	Tray 2 or A3/11 × 17 tray unit	Multi bypass tray (Tray A) or wide LCT
One-sided	······	C	
		ff.6	

ರ

Print side	Tray 1	Tray 2 or A3/11 × 17 tray unit	Multi bypass tray (Tray A) or wide LCT
Two-sided	·····		



- In copier mode:
 - For details about how to make two-sided copies, see "Duplex Copying", Copy/ Document Server.
- In printer mode:
 - To print on letterhead paper when [Auto Detect] is specified for [Letterhead Setting], you must specify [Letterhead] as the paper type in the printer driver's settings.
 - If a print job is changed partway through printing from one-sided to two-sided printing, one-sided output after the first copy may be printed facing a different direction. To ensure all paper is output facing the same direction, specify different input trays for one-sided and two-sided printing. Note also that two-sided printing must be disabled for the tray specified for one-sided printing.
 - For details about how to make two-sided prints, see "Printing on Both Sides of Sheets", Print.

Recommended Paper

Recommended Paper Sizes and Types

This section describes recommended paper sizes and types.

Important

- If you use paper that curls, either because it is too dry or too damp, a staple clogging or paper jam may occur.
- Do not use paper designed for inkjet printers, as these may stick to the fusing unit and cause a
 misfeed
- When you load transparencies, check the front and back of the sheets, and place them correctly, or a misfeed might occur.

Tray 1

Paper type and weight	Paper size	Paper capacity
52.3-300.0g/m² (14.0 lb. Bond-165.0 lb. Index) Paper Weight 1-Paper Weight 7	Region \mathbf{A} A4 \mathbf{D} Region \mathbf{B} $8^{1}/_{2} \times 11\mathbf{D}$	1,000 sheets × 2
52.3–300.0g/m² (14.0 lb. Bond–165.0 lb. Index) Paper Weight 1–Paper Weight 7	*1 Region \mathbf{A} $8^{1}/_{2} \times 11D$ Region \mathbf{B} $A4D$	1,000 sheets × 2

^{*1} To load paper any of the sizes specified above, contact your service representative.

Tray 1 (A3/11 × 17 tray unit)

Paper type and weight	Paper size	Paper capacity
52.3-300.0g/m ² (14.0 lb. Bond-165.0 lb. Index)	Region A	1,000 sheets
Paper Weight 1–Paper Weight 7		

Paper type and weight	Paper size	Paper capacity
52.3–300.0g/m² (14.0 lb. Bond–165.0 lb. Index) Paper Weight 1–Paper Weight 7	*1 —Region A A4DD, B4 JISD, 11 × 17D, 8 ¹ / ₂ × 14D, 8 ¹ / ₂ × 11DD —Region B A3D, A4DD, B4 JISD, 8 ¹ / ₂	1,000 sheets
52.3-300.0g/m ² (14.0 lb. Bond-165.0 lb. Index)	× 14 \square , 8 $^1/_2$ × 11 \square \square Custom size *2:	1,000 sheets
Paper Weight 1–Paper Weight 7	Vertical: 210.0–305.0 mm Horizontal: 210.0–439.0 mm Region B Vertical: 8.27–12.00 inches	
	Horizontal: 8.27–17.28 inches	

^{* 1} To load paper any of the sizes specified above, contact your service representative.

Tray 2

Paper type and weight	Paper size	Paper capacity
52.3-256.0g/m ² (14.0 lb. Bond-141.0 lb. Index)	Paper sizes that can be detected automatically:	500 sheets
Paper Weight 1–Paper Weight 6	A3D, A4DD, A5DD, B4 JISD, B5 JISDD, 11 × 17D, $8^{1}/_{2}$ × 14 DD, $8^{1}/_{2}$ × 13DD, $8^{1}/_{2}$ × 11DD, $8^{1}/_{4}$ × 13DD, 8 × 13DD, $7^{1}/_{4}$ × $10^{1}/_{2}$ DD, $5^{1}/_{2}$ × $8^{1}/_{2}$ DD, 8K D, 16 KDD, 12 × 18 D	

^{*2} For details about how to load custom size paper, contact your service representative.

Paper type and weight	Paper size	Paper capacity
52.3-256.0g/m ² (14.0 lb. Bond-141.0 lb. Index) Paper Weight 1-Paper	Select the paper size using the Tray Paper Settings menu: $8^{1}/_{4} \times 14\Box$, $8 \times 10\Box$, 11×15	500 sheets
Weight 6	□, 11 × 14□, 10 × 15□, 10 × 14□, 13 × 18□, SRA3□, SRA4□ □	
52.3-256.0g/m ² (14.0 lb. Bond-141.0 lb. Index)	Custom size:	500 sheets
Paper Weight 1–Paper Weight 6	Vertical: 139.7–330.2 mm Horizontal: 139.7–457.2 mm Region B Vertical: 5.50–13.00 inches Horizontal: 5.50–18.00 inches	
Translucent paper 52.3-63.0 g/m² (14.0-16.9 lb. Bond) Paper Weight 1	A30, A400, B4 JISO, B5 JISOO	*1
Transparencies 163.1–220.0 g/m² (60.1– 80.9 lb. Cover) Paper Weight 5	A4DD	*1
Tab stock*2	A4 \mathbb{D} , 8 $^{1}/_{2} \times 14\mathbb{D}$, 8 $^{1}/_{2} \times 11\mathbb{D}$	200 sheets (80.0–199.0 g/m², 21.0 lb. Bond–110.0 lb. Index)

^{* 1} Do not stack paper over the limit mark. The maximum number of sheets you can set at once depends on the paper's thickness and condition.

^{*2} The optional tab sheet holder is required.

9

Multi bypass tray (Tray A)

Paper type and weight	Paper size	Paper capacity
52.3–216.0 g/m ² (14.0 lb. Bond–79.9 lb. Cover)	Paper sizes that can be detected automatically:	500 sheets
Paper Weight 1-Paper	Region	
Weight 5	A3 \square , A4 \square \square , A5 \square \square , A6 \square , B4 JIS \square , B5 JIS \square , 11 × 17 \square , 8 ¹ / ₂ × 11 \square , 8 × 13 \square , 5 ¹ / ₂ × 8 ¹ / ₂ \square , 12 × 18 \square	
	Region B	
	A3, A4, A5, A6, B4, JIS D, B5, JIS, 11 × 17, 8 ¹ / ₂ × 11, B5, 8 × 13, 5 ¹ / ₂ × 8 ¹ / ₂ D, 12 × 18, 5	

Paper type and weight	Paper size	Paper capacity
52.3–216.0 g/m² (14.0 lb. Bond–79.9 lb. Cover) Paper Weight 1–Paper Weight 5	*1 *1 **Begion A **B5 JISD*, B6 JISD*, 8\frac{1}{2} \times 14D*, 8\frac{1}{4} \times 13D*, 8\frac{1}{2} \times 11D*, 8\frac{1}{4} \times 14D*, 8\frac{1}{4} \times 13D*, 8 \times 10D*, 7\frac{1}{4} \times 10\frac{1}{2}DD*, 5\frac{1}{2} \times 8\frac{1}{2}D*, 16\times 12D*, 11 \times 15D*, 10 \times 14D*, 13 \times 19\frac{1}{5}D*, 13 \times 19D*, 12\frac{3}{5} \times 19\frac{1}{5}D*, 12\frac{3}{5} \times 18D*, 8\times 13D*, 8\frac{1}{4}DD*, 13D*, 8\frac{1}{4}DD*, 4\frac{1}{5} \times 5\frac{1}{2}D*, 8\frac{1}{2}D*, 8\frac{1}{2}D*, 8\frac{1}{2}D*, 16\frac{1}{2}D*, 8\frac{1}{2}D*, 16\frac{1}{2}D*, 16\frac{1}{2}D	500 sheets
52.3–216.0 g/m² (14.0 lb. Bond–79.9 lb. Cover) Paper Weight 1–Paper Weight 5	Custom size:*2 Region A Vertical: 100.0–330.2 mm Horizontal: 139.7–487.7 mm*3 Region B Vertical: 3.94–13.00 inches Horizontal: 5.50–19.20 inches*3	500 sheets

Paper type and weight	Paper size	Paper capacity
Translucent paper 52.3-63.0 g/m² (14.0-16.9 lb. Bond) Paper Weight 1	A30, A400, B5 JIS00	*4
Transparencies 163.1–216.0 g/m² (60.1–79.9 lb. Cover) Paper Weight 5	A4D□, 8 ¹ / ₂ × 11D□	*4
Tab stock*5 52.3-216.0 g/m² (14.0 lb. Bond-79.9 lb. Cover) Paper Weight 1-Paper Weight 5	A4D, 8 ¹ / ₂ × 11D	_
Envelopes 163.1–216.0 g/m² (60.1 lb. Cover–79.9 lb. Cover) Paper Weight 5	Vertical: 100.0–330.2 mm Horizontal: 139.7–487.7 mm Region B Vertical: 3.94–13.00 inches Horizontal: 5.50–19.20 inches	10 sheets

- *1 Select the paper size. For details, see "Changing Tray Paper Settings", Paper Settings.
- *2 Enter the paper size. For details, see "Changing Tray Paper Settings", Paper Settings.
- *3 When the banner sheet tray is installed, the maximum horizontal length of custom size paper is 700.0 mm (27.55 inches).
- *4 The maximum number of sheets you can set at once depends on paper thicknesses and conditions.
- *5 The tab fence is required.

Three-tray wide LCT (Trays 3 and 5)

Paper type and weight	Paper size	Paper capacity
52.3-256.0 g/m ² (14.0 lb. Bond-141.0 lb. Index)	Paper sizes that can be detected automatically:	1,000 sheets
Paper Weight 1-Paper	Region	
Weight 6	A3 \Box , A4 \Box D, A5 \Box D, B4 JISD, B5 JISD, 11 × 17 \Box , 8 ¹ / ₂ × 11 \Box , 8 × 13 \Box , 5 ¹ / ₂ × 8 ¹ / ₂ \Box , 12 × 18 \Box	
	Region	
	A3 \Box , A4 \Box , A5 \Box , B4 JIS \Box , B5 JIS \Box , 11 × 17 \Box , 8 ¹ / ₂ × 11 \Box \Box , 8 × 13 \Box , 5 ¹ / ₂ × 8 ¹ / ₂ \Box \Box , 12 × 18 \Box	

Paper type and weight	Paper size	Paper capacity
52.3-256.0 g/m ² (14.0 lb. Bond-141.0 lb. Index) Paper Weight 1-Paper	Select the paper size using the Tray Paper Settings menu:	1,000 sheets
Weight 6	A6 \Box^{*1} , B5 JIS \Box , B6 JIS \Box^{*1} , $8^{1}/_{2} \times 14\Box$, $8^{1}/_{2} \times 13\Box$, $8^{1}/_{2} \times 11\Box$, $8^{1}/_{4} \times 14\Box$, $8^{1}/_{4} \times 13\Box$, $8 \times 10\Box$, $7^{1}/_{4} \times 10^{1}/_{2}\Box$, $5^{1}/_{2} \times 8^{1}/_{2}\Box$, 8K \Box , 16K \Box C, 11 × 15 \Box , 11 × 14 \Box , 10 × 15 \Box C, 10 × 14 \Box C, 13 × 19 \Box C, 13 × 19 \Box C, 12 \Box C, 13 × 19 \Box C, 12 \Box C, 13 × 18 \Box C, SRA3 \Box C, SRA4 \Box C, 4 \Box C, 4 \Box C, 5 \Box C, 12 \Box C, 13 × 18 \Box C, SRA4 \Box C, 4 \Box C, 4 \Box C, 5 \Box C, 12 \Box C, 13 × 18 \Box C, SRA4 \Box C, 4 \Box C, 4 \Box C, 5 \Box C, 13 × 18 \Box C, 14 \Box C, 15 \Box C, 16 \Box C, 16 \Box C, 16 \Box C, 17 \Box C, 18 \Box C, 19	
	⊕ Region B A4□, A5□, A6□ *1 , B5 JIS□, B6 JIS□ *1 , 8 1 / ₂ × 14□, 8 1 / ₂ × 13□, 8 1 / ₄ × 14□, 8 1 / ₄ × 13 □, 8 × 10□, 7^{1} / ₄ × 10 1 / ₂ □□, 8K□, 16K□□, 11 × 15□, 11 × 14□,	
	$10 \times 15^{\circ}$, $10 \times 14^{\circ}$, $13 \times 19^{\circ}$, $13 \times 19^{\circ}$, 12^{3} , $12^{$	
52.3-256.0 g/m ² (14.0 lb. Bond-141.0 lb. Index)	Custom size: Region A	1,000 sheets
Paper Weight 1–Paper Weight 6	Vertical: 100.0-330.2 mm ^{*1} Horizontal: 139.7-487.7 mm	
	Region B	
	Vertical: 3.94–13.00 inches ^{*1} Horizontal: 5.50–19.20 inches	
	Fronzoniai. J.JO-19.20 inches	

Paper type and weight	Paper size	Paper capacity
Coated: Glossy Coated: Matte 63.1–256.0 g/m² (17.0 lb. Bond –141.0 lb. Index) Paper Weight 2–Paper Weight 6	Paper sizes that can be detected automatically: Region A A3D, A4DD, A5DD, B4 JISD, B5 JISD, 11 × 17D, 8 ¹ / ₂ × 11 D, 8 × 13D, 5 ¹ / ₂ × 8 ¹ / ₂ D, 12 × 18D Region B A3D, A4D, A5D, B4 JISD, B5 JISD, 11 × 17D, 8 ¹ / ₂ × 11DD, 8 × 13D, 5 ¹ / ₂ × 8 ¹ / ₂ DD, 12 × 18D	-
Coated: Glossy Coated: Matte 63.1–256.0 g/m² (17.0 lb. Bond –141.0 lb. Index) Paper Weight 2–Paper Weight 6	Select the paper size using the Tray Paper Settings menu: Region A B5 JISD, $8^{1}/_{2} \times 14D$, $8^{1}/_{2} \times 13D$, $8^{1}/_{2} \times 11D$, $8^{1}/_{4} \times 14D$, $8^{1}/_{4} \times 14D$, $8^{1}/_{4} \times 13D$, $8 \times 10D$, $7^{1}/_{4} \times 10^{1}/_{2}DD$, $5^{1}/_{2} \times 8^{1}/_{2}D$, 8KD, 16 KDD, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $13 \times 19^{1}/_{5}D$, $13 \times 19D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $12^{3}/_{5} \times 18^{1}/_{2}D$, $13 \times 18D$, SRA3D, SRA4DD Region B A4D, A5D, B5 JISD, $8^{1}/_{2} \times 14D$, $8^{1}/_{4} \times 13D$, $8 \times 10D$, $7^{1}/_{4} \times 10^{1}/_{2}DD$, 8KD, 16 KDD, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $13 \times 19^{1}/_{5}D$, $13 \times 19D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $13 \times 19D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $13^{3}/_{5} \times 18^{1}/_{2}D$, $13 \times 18D$, SRA3D, SRA4DD	

Paper type and weight	Paper size	Paper capacity
Coated: Glossy	Custom size:	_
Coated: Matte	Region	
63.1–256.0 g/m ² (17.0 lb.	Vertical: 139.7-330.2 mm	
Bond –141.0 lb. Index) Paper Weight 2–Paper	Horizontal: 139.7–487.7 mm	
Weight 6	Region B	
	Vertical: 5.50–13.00 inches	
	Horizontal: 5.50–19.20 inches	
Translucent paper	A30, A400, B5 JIS00	*2
52.3-63.0 g/m ² (14.0-16.9 lb. Bond)		
Paper Weight 1		
Transparencies	A4DD, 8 ¹ / ₂ × 11DD	*2
163.1-220.0 g/m ² (60.1- 80.9 lb. Cover)		
Paper Weight 5		
Tab stock*3	A4D, 8 ¹ / ₂ × 11D	-
52.3-256.0 g/m ² (14.0 lb. Bond-141.0 lb. Index)		
Paper Weight 1–Paper Weight 6		
Envelopes	*1, *4, *5, *6	10 sheets
163.1–256.0 g/m ² (60.1 lb. Cover–141.0 lb. Index)	240 × 332 mm, 235 × 120mm, 120 × 235 mm, 105 × 241 mm,	
(Thickness of overlapping part of the envelope.)	110 × 220 mm	

^{*1} The postcard side fences are required to load paper that is between 100.0 and 139.2 mm (3.94 and 5.49 inches).

^{*2} The maximum number of sheets you can set at once depends on the paper's thickness and condition.

^{*3} The tab fence is required.

^{*4} Open the flaps, and load the envelopes with their flaps pointed toward the right side of the paper tray.

^{*5} Enter the sizes of the envelopes including their flap sizes using the Tray Paper Settings function.

*6 Sizes do not include flap sizes.

Three-tray wide LCT (Tray 4)

Paper type and weight	Paper size	Paper capacity
52.3-360.0 g/m ² (14.0 lb. Bond-198.0 lb. Index)	Paper sizes that can be detected automatically:	2,000 sheets
Paper Weight 1 – Paper Weight 8	Region A A3 \Box , A4 \Box , A5 \Box , B4 JIS \Box , B5 JIS \Box , 11 × 17 \Box , 8 1 / ₂ × 11 \Box , 8 × 13 \Box , 5 1 / ₂ × 8 1 / ₂ \Box , 12	
	× 18□ Region B A3□, A4□, A5□, B4 JIS□, B5 JIS□, 11 × 17□, 8¹/ ₂ × 11□□, 8 × 13□, 5¹/ ₂ × 8¹/ ₂ □□, 12 × 18□	

Paper type and weight	Paper size	Paper capacity
52.3–360.0 g/m² (14.0 lb. Bond–198.0 lb. Index) Paper Weight 1–Paper Weight 8	Select the paper size using the Tray Paper Settings menu: Region A A6D*1, B5 JISD, B6 JISD*1, 81/2 × 14D, 81/4 × 14D, 81/4 × 13D, 81/2 DD, 51/2 × 81/2DD, 51/2 × 81/2DD, 51/2 × 81/2DD, 10 × 14D, 10 × 15D, 11 × 15D, 11 × 14D, 10 × 15D, 123/5 × 191/5D, 123/5 × 181/2DD, 41/5 × 51/2DD Region B A4D, A5D, A6D*1, B5 JISD, B6 JISD*1, 81/4 × 14D, 81/4 × 13DD, 81/4 × 14DD, 81/4 × 13DD, 81/4 × 14DD, 81/4 × 13DD, 81/4 × 14DD, 11 × 15DD, 11 × 14DD, 11 × 15DD, 11 × 14DD, 11 × 15DD, 11 × 14DD, 123/5 × 191/5DD, 123/5 × 191/5DD, 123/5 × 191/5DD, 123/5 × 191/5DD, 123/5 × 181/2DD, 123/5 × 181/2DD, 13 × 18DD, SRA3DD, SRA4DDD, SRA4DDD,	2,000 sheets
	$4^{1}/_{5} \times 5^{1}/_{2}$	
52.3–360.0 g/m² (14.0 lb. Bond–198.0 lb. Index) Paper Weight 1–Paper Weight 8	Custom size: Region A Vertical: 100.0-330.2 mm*1 Horizontal: 139.7-487.7 mm Region B Vertical: 3.94-13.00 inches*1	2,000 sheets
	Horizontal: 5.50–19.20 inches	

Paper type and weight	Paper size	Paper capacity
Coated: Glossy Coated: Matte 63.1–360.0 g/m² (17.0 lb. Bond –198.0 lb. Index) Paper Weight 2–Paper Weight 8	Paper sizes that can be detected automatically: Region A A3 D, A4DD, A5DD, B4 JISD, B5 JISD, 11 × 17D, 8 ¹ / ₂ × 11 D, 8 × 13D, 5 ¹ / ₂ × 8 ¹ / ₂ D, 12 × 18D Region B A3D, A4D, A5D, B4 JISD, B5 JISD, 11 × 17D, 8 ¹ / ₂ × 11DD, 8 × 13D, 5 ¹ / ₂ × 8 ¹ / ₂ DD, 12 × 18D	
Coated: Glossy Coated: Matte 63.1–360.0 g/m² (17.0 lb. Bond –198.0 lb. Index) Paper Weight 2–Paper Weight 8	Select the paper size using the Tray Paper Settings menu: Region A B5 JISD, $8^{1}/_{2} \times 14D$, $8^{1}/_{4} \times 13D$, $8 \times 10D$, $7^{1}/_{4} \times 10^{1}/_{2}DD$, $5^{1}/_{2} \times 8^{1}/_{2}D$, 8KD, 16 KDD, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $13 \times 19^{1}/_{5}DD$, $13 \times 19D$, $12^{3}/_{5} \times 19^{1}/_{5}DD$, $13 \times 19D$, $13 \times 19D$, $13 \times 18D$, SRA3D, SRA4DD Region B A4D, A5D, B5 JISD, $8^{1}/_{2} \times 14DD$, $8^{1}/_{2} \times 14DD$, $8^{1}/_{2} \times 13DD$, $8^{1}/_{4} \times 14DD$, $8^{1}/_{4} \times 13DD$, $8 \times 10DD$, $7^{1}/_{4} \times 10^{1}/_{2}DDD$, 8 KD, 16 KDD, $11 \times 15DD$, $11 \times 15DD$, $11 \times 14DD$, $13 \times 19^{1}/_{5}DD$, $13 \times 19DD$, $12^{3}/_{5} \times 19^{1}/_{5}DD$, $13 \times 19DD$, $12^{3}/_{5} \times 19^{1}/_{5}DD$, $12^{3}/_{5} \times 18^{1}/_{2}DD$, $13 \times 18DD$, SRA3D, SRA4DDD	

Paper type and weight	Paper size	Paper capacity
Coated: Glossy	Custom size:	-
Coated: Matte	Region	
63.1–360.0 g/m ² (17.0 lb. Bond –198.0 lb. Index)	Vertical: 139.7–330.2 mm	
Paper Weight 2–Paper Weight 8	Horizontal: 139.7–487.7 mm	
	Vertical: 5.50–13.00 inches	
	Horizontal: 5.50–19.20 inches	
Translucent paper 52.3-63.0 g/m² (14.0-16.9 lb. Bond) Paper Weight 1	A3C, A4DC, B5 JISDC	*2
	A4DD, 8 ¹ /2 × 11DD	*2
Transparencies 163.1–220.0 g/m² (60.1– 80.9 lb. Cover) Paper Weight 5	A400, 8.72 × 1100	
Tab stock*3 52.3-360.0 g/m² (14.0 lb. Bond-198.0 lb. Index) Paper Weight 1-Paper Weight 8	A4D, 8 ¹ / ₂ × 11D	-
Label paper 52.3–360.0 g/m² (14.0 lb. Bond–198.0 lb. Index) Paper Weight 1–Paper Weight 8	A4DD, 8 ¹ / ₂ × 11DD	-
Envelopes 163.1–300.0 g/m² (60.1 lb. Cover–165.0 lb. Index) (Thickness of overlapping part of the envelope.)	*1, *4, *5, *6 240 × 332 mm, 235 × 120 mm, 120 × 235 mm, 105 × 241 mm, 110 × 220 mm	10 sheets

- *1 The postcard side fences are required to load paper that is between 100.0 and 139.2 mm (3.94 and 5.49 inches).
- *2 The maximum number of sheets you can set at once depends on the paper's thickness and condition.
- *3 The tab fence is required.
- *4 Open the flaps, and load the envelopes with their flaps pointed toward the right side of the paper tray.
- *5 Enter the sizes of the envelopes including their flap sizes using the Tray Paper Settings function.
- *6 Sizes do not include flap sizes.

Two-tray wide LCT (Trays 3 to 8) *1

Paper type and weight	Paper size	Paper capacity
52.3-360.0 g/m ² (14.0 lb. Bond-198.0 lb. Index)	Paper sizes that can be detected automatically: *3	2,400 sheets
Paper Weight 1–Paper Weight 8 ^{*2}	A3D, A4DD, A5DD, B4 JISD, 11 × 17D, 8 ¹ / ₂ × 14D, 8 ¹ / ₂ × 10 ¹ / ₂ D, 5 ¹ / ₂ × 8 ¹ / ₂ D, 12 × 18D, 13 × 19 ¹ / ₅ D, SRA3D, SRA4D Region B A3D, A4D, A5D, B4 JISD, 11 × 17D, 8 ¹ / ₂ × 14D, 8 ¹ / ₂ × 11 DD, 8 × 13D, 7 ¹ / ₄ × 10 ¹ / ₂ D, 5 ¹ / ₂ × 8 ¹ / ₂ DD, 12 × 18D, 13 × 19 ¹ / ₅ D, SRA3D, SRA4D	

Paper type and weight	Paper size	Paper capacity
52.3–360.0 g/m² (14.0 lb. Bond–198.0 lb. Index) Paper Weight 1–Paper Weight 8 ^{*2}	Select the paper size using the Tray Paper Settings menu:*4	2,400 sheets
	A6 \square , B5 JIS \square \square , B6 JIS \square , 8 $^{1}/_{2}$ × 13 \square , 8 $^{1}/_{2}$ × 11 \square , 8 $^{1}/_{4}$ × 14 \square , 8 $^{1}/_{4}$ × 13 \square , 8 × 10 \square , 7 $^{1}/_{4}$ × 10 $^{1}/_{2}$ \square , 5 $^{1}/_{2}$ × 8 $^{1}/_{2}$ \square , 8K \square , 16K \square \square , 11 × 15 \square , 11 × 14 \square , 10 × 15 \square , 10 × 14 \square , 13 × 19 \square , 12 $^{3}/_{5}$ × 19 $^{1}/_{5}$ \square , 12 $^{3}/_{5}$ ×	
	$18^{1}/_{2}$, 13×18 , SRA4D, $4^{1}/_{5} \times 5^{1}/_{2}$ Region B	
	A4 \Box , A5 \Box , A6 \Box , B5 JIS \Box C, B6 JIS \Box C, 8 ¹ / ₂ × 13 \Box C, 8 ¹ / ₄ × 14 \Box C, 8 ¹ / ₄ × 13 \Box C, 8 × 10 \Box C, 7 ¹ / ₄ × 10 ¹ / ₂ \Box C, 8K \Box C, 16K \Box C, 11 × 15 \Box C, 11 × 14 \Box C,	
	$10 \times 15\Box$, $10 \times 14\Box$, 13×19 \Box , $12^{3}/_{5} \times 19^{1}/_{5}\Box$, $12^{3}/_{5} \times 18^{1}/_{2}\Box$, $13 \times 18\Box$, SRA4 \Box , $4^{1}/_{5} \times 5^{1}/_{2}\Box$	
52.3–360.0 g/m² (14.0 lb. Bond–198.0 lb. Index) Paper Weight 1–Paper Weight 8 ^{*2}	Custom size: *5	2,400 sheets ^{*6}
	Vertical: 100.0-330.2 mm	
	Horizontal: 139.7–487.7 mm	
	Vertical: 3.94–13.00 inches Horizontal: 5.50–19.20 inches	

Paper type and weight	Paper size	Paper capacity
Coated: Glossy Coated: Matte 63.1–360.0 g/m² (17.0 lb. Bond –198.0 lb. Index) Paper Weight 2–Paper Weight 8*2	Paper sizes that can be detected automatically: Region A A3 D, A4DD, A5DD, B4 JISD, B5 JISD, 11 × 17D, 8 ¹ / ₂ × 11 Region B A3D, A4D, A5D, B4 JISD, B5 JISD, 11 × 17D, 8 ¹ / ₂ × 11DD, 8 × 13D, 5 ¹ / ₂ × 8 ¹ / ₂ DD, 12 × 18D	
Coated: Glossy Coated: Matte 63.1–360.0 g/m² (17.0 lb. Bond –198.0 lb. Index) Paper Weight 2–Paper Weight 8*2	Select the paper size using the Tray Paper Settings menu: Region A B5 JISD, $8^{1}/_{2} \times 14D$, $8^{1}/_{4} \times 14D$, $8^{1}/_{2} \times 8^{1}/_{2}D$, $8KD$, $16KD$ D, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $13 \times 19^{1}/_{5}D$, $13 \times 19D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $12^{3}/_{5} \times 18^{1}/_{2}D$, $13 \times 18D$, SRA3D, SRA4DD Region B A4D, A5D, B5 JISD, $8^{1}/_{4} \times 14D$, $8^{1}/_{4} \times 13D$, $8 \times 10D$, $7^{1}/_{4} \times 10^{1}/_{2}D$ D, $8KD$, $16KD$ D, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$ D, $10 \times 14D$, $13 \times 19^{1}/_{5}D$, $13 \times 19D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $13 \times 19D$, 13×1	

Paper type and weight	Paper size	Paper capacity
Coated: Glossy	Custom size:	-
Coated: Matte	Region	
63.1–360.0 g/m ² (17.0 lb. Bond –198.0 lb. Index)	Vertical: 139.7–330.2 mm Horizontal: 139.7–487.7 mm	
Paper Weight 2–Paper Weight 8 ^{*2}	Region B	
	Vertical: 5.50–13.00 inches	
	Horizontal: 5.50–19.20 inches	
Translucent paper*7	A30, A400, B5 JIS00	*8
52.3-63.0 g/m² (14.0- 16.9 lb. Bond)		
Paper Weight 1		
Transparencies* ⁷	A4DD, 8 ¹ / ₂ × 11DD	*8
163.1-220.0 g/m ² (60.1-		
80.9 lb. Cover)		
Paper Weight 5		
Tab stock* ⁷ , *9	$A4D$, $8^{1}/_{2} \times 11D$	_
52.3-360.0 g/m² (14.0 lb. Bond-198.0 lb. Index)		
Paper Weight 1–Paper Weight 8		
Label paper*7	A4DD, 8 ¹ / ₂ × 11DD	_
52.3-360.0 g/m ² (14.0 lb. Bond-198.0 lb. Index)		
Paper Weight 1–Paper Weight 8		
Envelopes*7	*10, *11, *12	10 sheets
163.1–300.0 g/m ² (60.1 lb. Cover–165.0 lb. Index)	240 × 332 mm, 235 × 120 mm, 120 × 235 mm, 105 × 241 mm,	
(Thickness of overlapping part of the envelope.)	110 × 220 mm	

^{*1} You can install the banner sheet tray for Tray 3, 5, or 7.

- *2 When paper whose horizontal length is 487.8 mm (19.20 inches) or more is specified, the maximum paper weight of the tray is Paper Weight 7.
- *3 When the banner sheet tray is installed, paper sizes are not detected automatically.
- *4 When the banner sheet tray is installed, you cannot select paper sizes.
- *5 You can print on paper whose size is between 210.0–330.2 mm (8.27–13.00 inches) vertically and 420.0–700.0 mm (16.54–27.55 inches) horizontally if the banner sheet tray is installed.
- *6 When the horizontal length of paper is 420.0–559.9 mm (16.54–22.00 inches), paper capacity is 800 sheets. When the horizontal length of paper is 560.0–700.0 mm (22.00–27.55 inches), paper capacity is 1,100 sheets.
- *7 When the banner sheet tray is installed, you cannot select paper types.
- *8 The maximum number of sheets you can set at once depends on the paper's thickness and condition.
- *9 The tab fence is required.
- *10 Open the flaps, and load the envelopes with their flaps pointed toward the right side of the paper tray.
- *11 Enter the sizes of the envelopes including their flap sizes using the Tray Paper Settings function.
- *12 Sizes do not include flap sizes.

Interposer

Paper type and weight	Paper size	Paper capacity
64.0–216.0 g/m ² (17.1 lb. Bond–79.9 lb. Cover)	Paper sizes that can be detected automatically:	200 sheets × 2
Paper Weight 2–Paper Weight 5	A3□, A4□□, A5□□, B4 JIS□, B5 JIS□, 11 × 17□, 8¹/2 × 11 □, 8 × 13□, 5¹/2 × 8¹/2□, 12 × 18□ Region B A3□, A4□, A5□, B4 JIS□, B5 JIS□, 11 × 17□, 8¹/2 × 11□□, 8 × 13□, 5¹/2 × 8¹/2□□, 12 × 18□	

Paper type and weight	Paper size	Paper capacity
64.0–216.0 g/m² (17.1 lb. Bond–79.9 lb. Cover) Paper Weight 2–Paper Weight 5	Select the paper size using the Tray Paper Settings menu: Region A B5 JISD, $8^{1}/_{2} \times 14D$, $8^{1}/_{2} \times 13D$, $8^{1}/_{2} \times 11D$, $8^{1}/_{4} \times 14D$, $8^{1}/_{4} \times 14D$, $8^{1}/_{4} \times 13D$, $8 \times 10D$, $7^{1}/_{4} \times 10^{1}/_{2}DD$, $5^{1}/_{2} \times 8^{1}/_{2}D$, $8KD$, $16KD$ D, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $13 \times 19^{1}/_{5}D$, $13 \times 19D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $13 \times 19D$, $13 \times 19D$, $13 \times 18D$, SRA3D, SRA4DD Region B A4D, A5D, B5 JISD, $8^{1}/_{2} \times 14D$, $8^{1}/_{2} \times 13D$, $8 \times 10D$, $7^{1}/_{4} \times 10^{1}/_{2}DD$, $8KD$, $16KD$ D, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $11 \times 14D$	200 sheets × 2
64.0–216.0 g/m² (17.1 lb. Bond–79.9 lb. Cover) Paper Weight 2–Paper Weight 5	Custom size: Region A Vertical: 139.7–330.2 mm Horizontal: 139.7–487.7 mm Region B Vertical: 5.50–13.00 inches Horizontal: 5.50–19.20 inches	200 sheets × 2

Weight 7

Paper type and weight

 $90.0-300.0 \text{ g/m}^2 (24.1 \text{ lb.})$

 $90.0-300.0 \text{ g/m}^2 (24.1 \text{ lb.})$

Bond-165.0 lb. Index)

Paper Weight 3-Paper

Bond-165.0 lb. Index)

Paper Weight 3-Paper

8	Weight 7	B4 JISD, $11 \times 17D$, $8KD$, $12 \times 18D$, $11 \times 15D$, $13 \times 19^{1}/_{5}D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $12^{3}/_{5} \times 18^{1}/_{2}D$, 13×18 D, SRA3D BRegion B A3D, B4 JISD, $8KD$, $12 \times 18D$, $11 \times 15D$, $13 \times 19^{1}/_{5}D$, $12^{3}/_{5} \times 19^{1}/_{5}D$, $12^{3}/_{5} \times 18^{1}/_{2}D$, 13×18 D, SRA3D	
	90.0–300.0 g/m² (24.1 lb. Bond–165.0 lb. Index)	Custom size:	200 sheets (or up to 24 mm in height) × 2
	Paper Weight 3–Paper Weight 7	Vertical: 257.0-330.2 mm	

Region B

inches

Paper size

Paper sizes that can be

detected automatically:

11 × 17□, 13 × 19□

Select the paper size using the

Horizontal: 364.0-487.7 mm

Vertical: 10.12-13.00 inches Horizontal: 14.34-19.20

Tray Paper Settings menu:

Region

Region R

Region

A3□, 13 × 19□

Paper capacity

200 sheets (or up to 24 mm in

200 sheets (or up to 24 mm in

height) × 2

height) × 2

Paper thickness

Paper thickness*1	Metric	Bond paper	Cover paper	Index paper
Paper Weight 1*2	52.3-63.0	14.0–16.9 lb.	19.0-23.0 lb.	29.0–34.9 lb.
	g/m ²	Bond	Cover	Index
Paper Weight 2	63.1-80.0	17.0-21.0 lb.	23.1–29.9 lb.	35.0-44.0 lb.
	g/m ²	Bond	Cover	Index
Paper Weight 3	80.1-105.0	21.1–28.0 lb.	30.0–38.9 lb.	44.1–58.0 lb.
	g/m ²	Bond	Cover	Index
Paper Weight 4	105.1-163.0	28.1–43.0 lb.	39.0-60.0 lb.	58.1–90.0 lb.
	g/m ²	Bond	Cover	Index
Paper Weight 5	163.1-220.0	43.1–58.9 lb.	60.1–80.9 lb.	90.1–121.0 lb.
	g/m ²	Bond	Cover	Index
Paper Weight 6	220.1-256.0	59.0-68.0 lb.	81.0-94.0 lb.	121.1-141.0 lb.
	g/m ²	Bond	Cover	Index
Paper Weight 7	256.1-300.0	68.1–80.0 lb.	94.1–110.0 lb.	141.1-165.0 lb.
	g/m ²	Bond	Cover	Index
Paper Weight 8	300.1-360.0	80.1–96.0 lb.	110.1–132.0 lb.	165.1–198.0 lb.
	g/m ²	Bond	Cover	Index

- *1 Print quality will decrease if the paper you are using is close to the minimum or maximum weight. Change the paper weight setting to thinner or thicker.
- *2 When loading paper of 52.3–63.0 g/m² (14.0–16.9 lb. Bond), the edges may crease or the paper misfeed depending on the paper type.



- Certain types of paper, such as translucent paper or transparencies, may produce noise when delivered. This noise does not indicate a problem and print quality is unaffected.
- The paper capacity described in the tables above is an example. Actual paper capacity might be lower, depending on the paper type.
- When loading paper, make sure the stack height does not exceed the limit mark of the paper tray.
- If multiple sheet feeding occurs, fan sheets thoroughly or load sheets one by one from the multi bypass tray (Tray A).
- You can specify whether or not the machine auto detects multi-sheet feeds in paper from every tray.
 In the Adjustment Settings for Operators menu, you can also specify whether current jobs are suspended or continued when a multi-sheet feed is detected. However, depending on the condition

- of the paper, the machine may not detect a multi-sheet feed correctly. For details about Adjustment Settings for Operators, see "Adjustment Settings for Operators", Paper Settings.
- Flatten out curled sheets before loading them.
- The Adjust Paper Curl function might not be able to fully remove curl, depending on the type of
 paper and the direction of its grain. If long grain paper does not uncurl properly, try short grain
 paper instead. For details about the Adjust Paper Curl function, see "Adjustment Settings for
 Operators", Paper Settings.
- Depending on the paper's size, weight, and type, the copy/print speed may be slower than usual.
- When loading envelopes, see page 147 "Envelopes".
- When copying or printing onto letterhead paper, the paper placing orientation is different depending on which function you are using. For details, see page 120 "Loading Orientation-fixed Paper or Two-sided Paper".
- If you load paper of the same size and same type in two or more trays, the machine automatically feeds from one of the trays in which [Yes] is selected for [Apply Auto Paper Select] when the first tray in use runs out of paper. This function is called Auto Tray Switching. This saves interrupting a copy run to replenish paper when making a large number of copies. You can specify the paper type of the paper trays under [Paper Type] tab. For details, see "Tray Paper Settings", Paper Settings. For the setting procedure of the Auto Tray Switching function, see "General Features", Copy/ Document Server.
- The paper types you can select in Tray Paper Settings are only general classifications. Print quality
 for every kind of paper in a classification is not guaranteed. For details, see "Unusable Paper",
 Paper Specifications and Adding Paper.
- If the surface of the paper is dusty, white spots might appear on prints. To remove dust, fan the paper thoroughly.
- When loading label paper:
 - Select [Label Paper] for [Paper Type] in [Tray Paper Settings], and select an appropriate paper thickness under [Paper Weight].
- When loading transparencies:
 - When copying onto transparencies, see "Copying onto Transparencies", Copy/ Document Server.
 - To print on transparencies, select [Transparency] for [Paper Type] in [Tray Paper Settings].
 - When you load transparencies, check the front and back of the sheets, and place them correctly, or a misfeed might occur.
 - Fan transparencies thoroughly whenever you use them. This prevents transparencies from sticking together, and from feeding incorrectly.
 - Remove copied or printed sheets one by one.
- When loading translucent paper:

- When loading translucent paper, always use long grain paper, and set the paper direction according to the grain.
- Translucent paper easily absorbs humidity and becomes curled. Remove curl in the translucent paper before loading. For details about settings for flattening out curled paper, see "Adjustment Settings for Operators", Paper Settings.
- · Remove copied or printed sheets one by one.
- When loading coated paper:
 - If you want to use glossy paper, select [Coated: Glossy] for [Paper Type]. If you want to use
 matted paper (including silk, dull, and satin paper), select [Coated: Matte] for [Paper Type].
 For details about the settings for using coated paper with custom paper, see "Registering a
 Custom Paper", Paper Settings.
 - When loading coated paper or glossy paper, always fan the paper before using it.
 - If a paper jam occurs or if the machine makes a strange noise when feeding stacks of coated paper, feed the coated paper one sheet at a time.
 - To load coated paper into the wide LCT, you must specify [Coated: Glossy], [Coated: Matte], or [Coated Paper: Gloss] as the paper type and select an appropriate paper thickness under [Paper Weight].

Envelopes


This section describes loading envelopes.




- Misfeeds might occur depending on the length and shape of the flaps.
- Only envelopes that are at least 139.7 mm (5.5 inches) wide can be loaded.

To print on envelopes, load them into the Wide LCT or multi bypass tray (Tray A), and be sure to specify an appropriate paper type.

To load envelopes, be sure to unfold their flaps and set them in the \Box orientation with print side face up.



If you are copying onto side-opening envelopes, be sure to unfold their flaps and set them in the \Box orientation with print side face up. Flaps must be at the right side of the Wide LCT or multi bypass tray (Tray A).



Recommended envelopes

For information about recommended envelopes, contact your local dealer.

Storage of envelopes

Keep envelopes stored in sealed plastic bags and remove only the quantity needed. Do not add envelopes during printing, as this might cause misfeeds.



- Be sure to specify the size of the envelope and flap size in [Tray Paper Settings]. For details, see "Changing to a Custom Paper Size", Paper Specifications and Adding Paper.
- When using envelopes, set [Paper Weight] in [Tray Paper Settings] to the same value as two sheets of the paper used for the envelopes.
- Before loading envelopes, press down on them to remove any air inside and to flatten any edges or creases. When loading envelopes, make sure they do not go over the limit mark.
- Place one envelope at a time if you still get any of the following results:
 - The envelope jams
 - The envelope is not fed
 - Multiple envelopes are fed at the same time
- Humidity levels of over 50% can cause envelopes to come out creased or misprinted.
- Certain types of envelopes might come out creased, dirtied, or misprinted. If you are printing a solid color or image on an envelope, lines may appear where the overlapped edges of the envelope make it thicker.
- If the horizontal size of the envelope is 297 mm (11.7 inches) or less, a paper misfeed might occur.
 If this happens, turn off Skew Detection. For details, see "Adjustment Settings for Operators", Paper Settings.
- When printing on envelopes thicker than 127.0 g/m² (47.0 lb. Cover), do not use [Adjust ^ Curl: Strong] or [Adjust ` Curl: Strong] for [Adjust Paper Curl] of [Adjustment Settings for Operators].

You can register up to 100 custom papers.

Check the product name, size, and type of your paper before registering it.

Registering a Custom Paper


Check that the size and type of your paper are compatible with the paper tray that you want to use. Tray compatibility depends on the paper's size and type. For details about the paper sizes and types that can be used, see page 124 "Recommended Paper Sizes and Types".



 When the number of registered custom papers reaches the maximum, you will not be able to register a new custom paper. Delete any unnecessary custom papers from the list, and then try registering again. For details, see "Deleting a Custom Paper", Paper Settings.

Selecting the Paper's Name from the Paper Library

1. Press the [Paper Setting] key.



- 2. Press [Edit Custom Paper].
- 3. Press [Recall from Paper Library].
- 4. Select the name of the paper that you want to register.

Press [▲Previous] or [▼Next] to scroll through the list to find the paper that you want to select.

You can select two or more types of paper.

- 5. Press [Program to Custom Paper].
- 6. Press [Yes].
- 7. Press [Exit] twice.
- 8. Press the [Paper Setting] key.

You can also close the [Tray Paper Settings] screen by pressing [Exit].



 You can check and change the settings of the registered custom paper such as the paper size setting on the [Edit Custom Paper] screen. For details about modifying the custom paper, see "Modifying a Custom Paper", Paper Settings.

Registering a Paper Whose Paper Name Is Not Displayed in the Paper Library

If the paper you want is not in the library's paper list or you don't know the name of the paper, use the following procedures:


- Selecting the paper's type from the paper library
 - The paper library contains the optimum printing conditions not only for each commercially available paper but also for each type of paper.
 - You can select the type of paper from the paper library and register it as a custom paper even if you don't know the name of the paper. The selectable paper types are as follows: Plain, Gloss coated, Matte coated, Envelope, Light colored, Dark colored, Textured, and Black. Each type is divided into several categories according to weight.
- Manually specifying a paper's type and weight
 You can register a custom paper by manually specifying its type and weight.

Selecting the paper's type from the paper library

You can select the type of paper from the paper library and register it as a custom paper.

The selectable paper types are as follows: Plain, Gloss coated, Matte coated, Envelope, Light colored, Dark colored, Textured, and Black.

1. Press the [Paper Setting] key.



- 2. Press [Edit Custom Paper].
- 3. Press [Recall from Paper Library].
- 4. Select the most appropriate combination of type and weight for your paper.

The list of paper types appears on the first and following pages in the paper library.

Press [▲Previous] or [▼Next] to scroll through the list to find the paper that you want to select.



- 5. Press [Program to Custom Paper].
- 6. Press [Yes].
- 7. Press [Exit] twice.
- 8. Press the [Paper Setting] key.


You can also close the [Tray Paper Settings] screen by pressing [Exit].



 You can check and change the settings of the registered custom paper such as the paper size setting on the [Edit Custom Paper] screen. For details about modifying the custom paper, see "Modifying a Custom Paper", Paper Settings.

Manually specifying a paper's type and weight

1. Press the [Paper Setting] key.



- 2. Press [Edit Custom Paper].
- Select a number that is [XNot Programd.].
 Press [APrevious] or [Next] to scroll through the list.



- 4. Press [Change] for [Custom Paper Name].
- 5. Enter the name of the paper, and then press [OK].
- 6. Press [Change] for [Paper Size].
- 7. Select a paper size, and then press [OK].
- 8. Press [Change] for [Paper Weight].
- Specify the paper's weight, and then press [OK].
 Press [Change] if you changed the paper weight.
- 10. Press [Change] for [Paper Type].
- 11. Specify the paper type, and then press [OK].
 Press [Change] if you changed the paper type.

12. Specify other items, such as [Coated Paper Type], [Paper Color], [Prepunched or Not], [Textured or Not], [Apply Duplex], and [Apply Auto Paper Select] as necessary.

If you change the [Coated Paper Type], [Paper Color], [Prepunched or Not], or [Textured or Not] and press [OK], a message appears to notify you that the [Advanced Settings] will be initialized. To apply the changes for those settings, select [Change]. To cancel the changes, select [Do not Change].

- 13. Press [OK].
- 14. Press [Exit].
- 15. Press the [Paper Setting] key.

You can also close the [Tray Paper Settings] screen by pressing [Exit].



- If you want to use glossy paper, select [Glossy] for [Coated Paper Type]. If you want to use matte paper (including silk, dull, and satin paper), select [Matte] for [Coated Paper Type].
- For details about custom paper settings, see "Custom Paper Settings", Paper Settings.
- For details about [Advanced Settings], contact your machine administrator.

Registering a New Custom Paper by Modifying an Existing Paper

You can open and modify the settings of a registered custom paper and register them as a new custom paper.


This function is useful when registering paper that is the same type as an existing paper, but a different size.

Depending on which settings you modify, details of a newly registered custom paper will be as follows:

- When the settings of the selected custom paper are not changed:
 - All settings of the selected custom paper ([Custom Paper Name], [Paper Size], [Paper Weight], and [Paper Type], including the attributes specific to the color controller) are copied to the newly registered custom paper.
- When the settings [Custom Paper Name], [Paper Size], [Apply Duplex], [Apply Auto Paper Select], or [Advanced Settings] of the selected custom paper are changed:
 - The changes are applied to the newly registered custom paper.
- When the settings [Paper Weight], [Paper Type], [Coated Paper Type], [Paper Color], [Prepunched or Not], or [Textured or Not] of the selected custom paper are changed:
 - The changes are applied to the newly registered custom paper and its advanced settings are reset to their default values according to the changes that are applied to the settings.

When modifying a custom paper that is registered from the paper library, you can change its [Custom Paper Name], [Paper Size], [Apply Duplex], and [Apply Auto Paper Select] settings. You can also confirm the brand name and the version of data from [Product Name in Paper Library].

1. Press the [Paper Setting] key.



- 2. Press [Edit Custom Paper].
- 3. Select a number that is [XNot Programd.].

Press [▲Previous] or [▼Next] to scroll through the list.




- 4. Press [Use Another Custom Paper's Settings].
- 5. Select the custom paper whose settings you want to modify.
- 6. Press [OK].
- Change the settings for custom paper (such as paper's name, size, and type), as necessary.

If you change the [Paper Weight], [Paper Type], [Coated Paper Type], [Paper Color], [Prepunched or Not], or [Textured or Not] and press [OK], a message appears to notify you that the [Advanced Settings] will be initialized. To apply the changes for those settings, select [Change]. To cancel the changes, select [Do not Change].

- 8. Press [OK].
- 9. Press [Exit].
- 10. Press the [Paper Setting] key.

You can also close the [Tray Paper Settings] screen by pressing [Exit].



- For details about custom paper settings, see "Custom Paper Settings", Paper Settings.
- For details about [Advanced Settings], contact your machine administrator.

Adding Toner

This section explains precautions when adding toner, how to send scanned documents when the toner has run out, and how to dispose of used toner.

MARNING

- Do not incinerate toner (new or used) or toner containers. Doing so risks burns. Toner will ignite on contact with naked flame.
- Do not store toner (new or used) or toner containers anywhere near naked flames. Doing so
 risks fire and burns. Toner will ignite on contact with naked flame.
- The following explains the warning messages on the plastic bag used in this product's packaging.
 - Keep the polythene materials (bags, etc.) supplied with this machine away from babies
 and small children at all times. Suffocation can result if polythene materials are brought into
 contact with the mouth or nose.
- Do not use a vacuum cleaner to remove spilled toner (including used toner). Absorbed toner
 may cause a fire or explosion due to electrical contact flickering inside the vacuum cleaner.
 However, it is possible to use a vacuum cleaner that is explosion-proof and dust ignition-proof. If
 toner is spilled on the floor, remove the spilled toner slowly using a wet cloth, so that the toner is
 not scattered.

ACAUTION

- Do not crush or squeeze toner containers. Doing so can cause toner spillage, possibly resulting in dirtying of skin, clothing, and floor, and accidental ingestion.
- Store toner (new or used), toner containers, and components that have been in contact with toner out of reach of children.
- If toner or used toner is inhaled, gargle with plenty of water and move into a fresh air environment. Consult a doctor if necessary.
- If toner or used toner gets into your eyes, flush immediately with large amounts of water. Consult a doctor if necessary.
- If toner or used toner is swallowed, dilute by drinking a large amount of water. Consult a doctor
 if necessary.

ACAUTION

- When removing jammed paper or replacing toner, avoid getting toner (new or used) on your clothing. If toner comes into contact with your clothing, wash the stained area with cold water. Hot water will set the toner into the fabric and make removing the stain impossible.
- When removing jammed paper or replacing toner, avoid getting toner (new or used) on your skin. If toner comes into contact with your skin, wash the affected area thoroughly with soap and water.
- When replacing a toner or waste toner container or consumables with toner, make sure that the
 toner does not splatter. Put the waste consumables in a bag after they are removed. For
 consumables with a lid, make sure that the lid is shut.

Important

- Always replace the toner cartridge when a notification appears on the machine.
- Fault may occur if you use toner other than the recommended type.
- When adding toner, do not turn off the main power. If you do, settings will be lost.
- Store toner where it will not be exposed to direct sunlight, temperatures above 35°C (95°F), or high humidity.
- Store toner horizontally.
- Do not shake the toner cartridge with its mouth down after removing it. Residual toner may scatter.
- Do not repeatedly install and remove toner cartridges. This will result in toner leakage.

Follow the instruction on the screen regarding how to replace a toner cartridge.




- If "Toner Cartridge is almost empty." appears, the toner has almost run out. Have a replacement toner cartridge at hand.
- You can check the name of the required toner and the replacement procedure using the [LAdd Toner] screen.
- For details about how to check contact number where you can order supplies, see "Inquiry", Maintenance and Specifications.
- If depears when there is still toner in the cartridge, hold the cartridge with the opening upward, shake it well, and then reinstall it.
- You can add all four color toners in the same way.

Sending Scanned Documents When Toner Has Run Out

When the machine has run out of toner, the indicator on the display lights. Note that even if there is no toner left, you can still send scanned documents.

Press the [Home] key on the control panel, and press the [Scanner] icon on the screen.
 If the [Scanner] icon does not appear, press the icon at the upper right corner of the screen to switch to the menu screen.



2. Perform transmission operation.



• Any reports are not printed.

Disposing of Used Toner

This section describes what to do with used toner.

Toner cannot be re-used.

Pack used toner containers in the container's box or a bag to prevent the toner from leaking out of the container when you dispose of it.

Region A (mainly Europe and Asia)

If you want to discard your used toner container, please contact your local sales office. If you discard it by yourself, treat it as general plastic waste material.

Region B (mainly North America)

Please see our local company website for information on the recycling of supply products, or you can recycle items according to the requirements of your local municipalities or private recyclers.

0

Menu Items and Functions

All items in Adjustment Settings for Operators appear regardless of which of the machine's optional components are installed. If you change the settings of options that are not installed, the changes will have no effect.

Machine: Image Position

For details about the following items, see "Machine: Image Position", Paper Settings.

No.	ltem	Description
0104	Skew Detection	Specify whether or not to detect paper skew.

Machine: Image Quality

For details about the following items, see "Machine: Image Quality", Paper Settings.

No.	ltem	Description
0201	Adjust Image Density/ DEMS	Execute image density control manually. DEMS can reduce the variations in thickness that occur in the intervals between the photoconductor and development sleeve operations.
0208	Photoconductor Special Mode	Increase the amount of lubricant applied to the photoconductor.

Machine: Paper Feed/ Output

For details about the following items, see "Machine: Paper Feed/ Output", Paper Settings.

No.	ltem	Description
0304	Adjust Paper Curl	Specify the method for straightening curled sheets. Select the method according to the direction and degree of curl.
0305	Illumination Mode for Color Paper Detection	Specify a detection method of the contact image sensor (CIS).
0309	Double Feed Detection	Specify whether or not to detect double feeding of paper.
0310	When Double Feed is Detected	Specify how the machine responds when it detects a double feed.

For details about the following items, see "Machine: Maintenance", Paper Settings.

No.	ltem	Description
0505	Fusing Belt Smoothing Setting	Specify whether or not to automatically execute [For Uneven Gloss (Short Time)] for fusing belt smoothing.
0506	Smooth Fusing Belt	Remove vertical and horizontal lines from printouts.
0509	Temperature / Humidity inside the Machine	Display the internal temperature and humidity.
0510	Temperature / Humidity outside the Machine	Display the external temperature and humidity.
0513	Back Up / Restore Custom Paper Data	Back up and restore custom paper profiles.
0515	Execute Developer Refreshing	The machine uses degraded toner in the development unit and adds new toner from the toner bottle.
0516	Switch Print Screen	Select the mode that appears when [To Print Screen] is pressed: copier mode or printer mode.

Finishing: Finisher

For details about the following items, see "Finishing: Finisher", Paper Settings.

No.	ltem	Description
0601	Adjust Staple Position Across Feed Direction 1	Adjust the vertical position of the staple (applied at an edge) when using Finisher SR5050 or Booklet Finisher SR5060.
0602	Adjust Staple Position Across Feed Direction 2	Adjust the vertical position of the staples (dual) when using Finisher SR5050 or Booklet Finisher SR5060.
0603	Adjust Staple Position With Feed Direction	Adjust the horizontal position of the staples when using Finisher SR5050 or Booklet Finisher SR5060.
0607	Adjust Punch Position Across Feed Direction	Adjust the vertical position of the punch holes when using Finisher SR5050 or Booklet Finisher SR5060.
0608	Adjust Punch Position With Feed Direction	Adjust the horizontal position of the punch holes when using Finisher SR5050 or Booklet Finisher SR5060.

No.	ltem	Description
0618	Adjust Staple Position for Booklet	Adjust the horizontal position of the booklet staples when using Booklet Finisher SR5060.
0619	Adjust Folding Position for Booklet	Adjust the horizontal position of the folding when using Booklet Finisher SR5060.
0621	Set Number of Folds for Booklet	Specify the number of booklet folds to be performed when using Booklet Finisher SR5060.

Finishing: Fold

For details about the following items, see "Finishing: Fold", Paper Settings.

No.	ltem	Description
0701	Half Fold Position (Multi- sheet Fold)	Adjust the fold position of half folded sheets when using the multi-folding unit.
0702	Letter Fold-out Position 1 (Multi-sheet Fold)	Adjust the fold position for the bottom segment of letter fold-out sheets when using the multi-folding unit.
0703	Letter Fold-out Position 2 (Multi-sheet Fold)	Adjust the overall fold size of letters fold-out sheets when using the multi-folding unit.
0704	Letter Fold-in Position 1 (Multi-sheet Fold)	Adjust the fold position of the bottom segment of letter fold-in sheets when using the multi-folding unit.
0705	Letter Fold-in Position 2 (Multi-sheet Fold)	Adjust the fold position of letters fold-in sheets when using the multi-folding unit.

Finishing: Perfect Binder

For details about the following items, see "Finishing: Perfect Binder", Paper Settings.

No.	ltem	Description
0801	Cover Sheet Position for Perfect Binding With Feed Dir	Adjust the horizontal alignment of the cover sheet position when performing perfect binding.
0802	Cover Sheet Position for Perfect Binding Across Feed Dir	Adjust the vertical alignment of the cover sheet position when performing perfect binding.

No.	ltem	Description
0803	Adjust Perfect Binding Finishing Angle	Square the top, bottom, and outside edges when trimming a deck of paper.
0804	Adjust Applying Binding Glue	Adjust the amount of binding glue for perfect binding.

Finishing: Stacker

For details about the following items, see "Finishing: Stacker", Paper Settings.

No.	ltem	Description
0907	Maximum Stack Quantity in Stacker Tray	Set the maximum number of sheets for the stacker tray.

9. Troubleshooting

This chapter describes basic troubleshooting procedures.

When a Status Icon Is Displayed

This section describes the status icons displayed when the machine requires the user to remove misfed paper, to add paper, or to perform other procedures.


Status Icon	Status	
♣ : Paper Misfeed icon	Appears when a paper misfeed occurs.	
	For details about removing jammed paper, see "Removing Jammed Paper", Troubleshooting.	
	Appears when an original misfeed occurs.	
	For details about removing jammed paper, see "Removing Jammed Paper", Troubleshooting.	
🛓 : Load Paper icon	Appears when paper runs out.	
	For details about loading paper, see "Loading Paper", Paper Specifications and Adding Paper.	
🛓 : Add Toner icon	Appears when toner runs out.	
	For details about adding toner, see "Adding Toner", Maintenance and Specifications.	
🛓 : Add Staple icon	Appears when staples run out.	
	For details about adding staples, see "Adding Staples", Maintenance and Specifications.	
☑ : Waste Toner Full icon	Appears when the waste toner bottle is full.	
	Contact your service representative.	
🖆 : Hole Punch Receptacle Full icon	Appears when the hole punch receptacle is full.	
	For details about removing punch waste, see "Removing Punch Waste", Troubleshooting.	
៨ : Waste Staple Full icon	Appears when the waste staple receptacle is full. For details about removing staple waste, see "Removing Staple Waste", Troubleshooting.	

Status Icon	Status	
† : Service Call icon	Appears when the machine is malfunctioning or requires maintenance.	
☐• : Open Cover icon	Appears when one or more covers of the machine are open.	

When the Indicator Lamp for the [Check Status] Key Is Lit or Flashing

If the indicator lamp for the [Check Status] key lights up or flashes, press the [Check Status] key to display the [Check Status] screen. Check the status of each function in the [Check Status] screen.

[Check Status] screen



1. [Mach./Applic. Stat] tab

Indicates the status of the machine and each function.

2. [Check]

If an error occurs in the machine or a function, press [Check] to view details.

Pressing [Check] displays an error message or the corresponding function screen. Check the error message displayed on the function screen and take the appropriate action. For details about how to resolve the problems described in error messages, see "When Messages Appear", Troubleshooting.

3. Messages

Displays a message that indicates the status of the machine and each function.

4. Status icons

The status icons that can be displayed are described below:

D: The function is performing a job.

An error has occurred on the machine.

①: The function cannot be used because an error has occurred in the function or machine. This icon may also appear if the toner is running low.

The following table explains problems that cause the indicator lamp for the [Check Status] key to light or flash.

Problem	Cause	Solution
Documents and reports do not print out.	The paper output tray is full.	Remove the prints from the tray.
Documents and reports do not print out.	There is no paper left.	Load paper. For details about loading paper, see "Loading Paper", Paper Specifications and Adding Paper.
An error has occurred.	A function which has the status "Error Occurred" in the [Check Status] screen is defective.	Press [Check] in the function which the error has occurred. Then read the displayed message, and take the appropriate action. For details about error messages and their solutions, see "When Messages Appear", Troubleshooting. You can use other functions normally.
The machine is unable to connect to the network.	A network error has occurred.	 Check that the machine is correctly connected to the network and that the machine is correctly set. For details about how to connect the network, see "Interface Settings", Connecting the Machine/ System Settings. For details about connecting to the network, contact your administrator. If the indicator lamp is still lit even after you try to solve the problem as described here, contact your service representative.

٤

When the Machine Makes a Beeping Sound

The following table describes the meaning of the various beep patterns that the machine issues to alert users about left originals and other machine conditions.

Beep pattern	Meaning	Cause
Single short beep	Panel/screen input accepted.	A control panel or screen key was pressed.
Short, then long beep	Panel/screen input rejected.	An invalid key was pressed on the control panel or screen, or the entered password was incorrect.
Single long beep	Job completed successfully.	A Copier/Document Server Features job has finished.
2 long beeps	Machine has warmed up.	When the power is turned on or the machine exits Sleep mode, the machine has fully warmed up and is ready for use.
5 long beeps	Soft alert	An auto reset was performed through the simple screen of the Copier/ Document Server function or the Scanner function.
5 long beeps repeated four times.	Soft alert	An original has been left on the exposure glass or paper tray is empty.
5 short beeps repeated five times.	Strong alert	The machine requires user attention because paper has jammed, the toner needs replenishing, or other problems have occurred.



- Users cannot mute the machine's beep alerts. When the machine beeps to alert users of a paper jam or toner request, if the machine's covers are opened and closed repeatedly within a short space of time, the beep alert might continue, even after normal status has resumed.
- You can enable or disable beep alerts. For details about Panel Key Sound, see "General Features", Connecting the Machine/ System Settings.

When You Have Problems Operating the Machine

Problem	Cause	Solution
The machine does not turn on.	The AC power switch has not been turned on.	Turn on the AC power switch. For details about the AC power switch, see "General Requirements", Maintenance and Specifications.
When the machine is turned on, the only icon that appears on the home screen is the [Copier] icon.	Functions other than the copier function are not yet ready.	Wait a little longer.
The machine has just been turned on and the User Tools screen is displayed, but the User Tools menu has items missing.	Functions other than the copier function are not yet ready. Time required varies by function. Functions appear in the User Tools menu when they become ready for use.	Wait a little longer.
The indicator lamp remains lit and the machine does not enter Sleep mode even though the [Energy Saver] key was pressed.	In some cases, the machine does not enter Sleep mode when the [Energy Saver] key is pressed.	Before you press the [Energy Saver] key, check that Sleep mode can be enabled. For details about enabling Sleep mode, see "Saving Energy", Getting Started.
The display is turned off.	The machine is in Low Power mode.	Touch the display panel or press one of the keys on the control panel to cancel Low Power mode.
The display is turned off.	The machine is in Sleep mode.	Press the [Energy Saver] key or the [Check Status] key to exit Sleep mode.
Nothing happens when the [Check Status] key or the [Energy Saver] key is pressed.	The power is turned off.	Make sure the main power indicator is off, and then turn on the power.

Problem	Cause	Solution
The power turns off automatically.	The Weekly Timer setting is set to [Main Power Off].	Change the Weekly Timer setting. For details about the Weekly Timer setting, see "Timer Settings", Connecting the Machine/ System Settings.
The user code entry screen is displayed.	Users are restricted by User Code Authentication.	For details about how to log in when User Code Authentication is enabled, see "When the Authentication Screen is Displayed", Getting Started.
The Authentication screen appears.	Basic Authentication, Windows Authentication, or LDAP Authentication is set.	Enter your login user name and user password. For details about the Authentication screen, see "When the Authentication Screen is Displayed", Getting Started.
An error message is still displayed, even if misfed paper is removed.	Paper is still jammed in the tray.	Remove the jammed paper by following the procedures displayed on the control panel. For details about removing jammed paper, see "Removing Jammed Paper", Troubleshooting.
An error message is still displayed, even if the indicated cover is closed.	One or more of the covers that are not indicated are still open.	Close all the covers of the machine.
Images are printed on the reverse side of the paper.	You may have loaded the paper incorrectly.	Load the paper correctly. For details about loading paper, see "Loading Paper", Paper Specifications and Adding Paper.

Problem	Cause	Solution
Misfeeds occur frequently.	Using curled paper often causes misfeeds, soiled paper edges, or slipped positions while staple or stack printing is performed.	 Flatten the paper with your hands to straighten out the curl. Load the paper up side down so that the curled edges face downward. For details about recommended paper, see "Recommended Paper", Paper Specifications and Adding Paper. Place the cut paper on a flat surface to prevent it from curling, and do not lean it against the wall. For details about the proper way to store paper, see "Paper Storage", Paper Specifications and Adding Paper.
Misfeeds occur frequently.	The tray's side or end fences may not be set properly.	 Remove the misfed paper. For details about removing jammed paper, see "Removing Jammed Paper", Troubleshooting. Check that the side or end fences are set properly. Also, check that the side fences are locked. For details about setting the side and end fences, see "Changing the Paper Size", Paper Specifications and Adding Paper.

Problem	Cause	Solution
Misfeeds occur frequently.	Paper of undetectable size has been loaded.	Remove the misfed paper. For details about removing jammed paper, see "Removing Jammed Paper", Troubleshooting.
		 If you load a paper size that is not selected automatically, you need to specify the paper size with the control panel. For details about specifying paper size using the control panel, see "Changing to a Size That Is Not Automatically Detected", Paper Specifications and Adding Paper.
Misfeeds occur frequently.	There is a foreign object on the output tray.	 Remove the misfed paper. For details about removing jammed paper, see "Removing Jammed Paper", Troubleshooting. Do not place anything on the output tray.
Misfeeds occur frequently.	The staple cartridge is not set correctly.	Set the staple cartridge properly. For details about how to add staples, see "Adding Staples", Maintenance and Specifications.
Misfeeds occur when printing to envelopes.	The envelopes are curled.	Make sure you fully flatten curled envelopes before you load them. Do not stack envelopes over the specified limit for the paper tray. If misfeeds still occur after the envelopes have been flattened, load envelopes on the tray one at a time and print them individually. For details about how to load envelopes, see "Envelopes", Paper Specifications and Adding Paper.

Problem	Cause	Solution
Misfeeds occur when printing to envelopes.	You printed envelopes with a non-rectangular flap when [Skew Detection] was set to [On].	 Make sure you set [Skew Detection] to [Off] when printing envelopes with a non-rectangular flap. For details about setting of skew detection, see "Adjustment Settings for Operators", Paper Settings.
When printing to envelopes, the envelopes may be fed in together, or the envelopes may not be fed.	The envelopes are curled.	Make sure you fully flatten curled envelopes before you load them. Do not stack envelopes over the specified limit for the paper tray. If misfeeds still occur after the envelopes have been flattened, load envelopes on the tray one at a time and print them individually. For details about how to load envelopes, see "Envelopes", Paper Specifications and Adding Paper.
Cannot print in duplex mode.	You have selected a paper tray that is not set for duplex printing.	Change the setting for "Apply Duplex" in "Tray Paper Settings" to enable duplex printing for the paper tray. For details about setting "Apply Duplex", see "Tray Paper Settings", Paper Settings.
Cannot print in duplex mode.	You have selected a paper type that cannot be used for duplex printing.	In "Tray Paper Settings", select a paper type that can be used for duplex printing. For details about setting "Paper Type", see "Tray Paper Settings", Paper Settings.
The machine does not turn off in 13 minutes after the main power is turned off.	The machine cannot perform the shutdown procedure.	Repeat the shutdown procedure. If the machine does not turn off, turn off the AC power switch.

Problem	Cause	Solution
An error has occurred when the Address Book is changed from the display panel or Web Image Monitor.	The Address Book cannot be changed while you delete the multiple stored documents.	Wait a while, and then retry the operation.
Cannot use Web Image Monitor to print documents stored in Document Server.	When print volume limits are specified, users cannot print beyond their print volume limit. Print jobs selected by users who have reached their print volume limits will be canceled.	 For details about specifying print volume limits, see Security Guide. To view the status of a print job, see [Print Job History]. In Web Image Monitor, click [Job] on the [Status/Information] menu. And then click [Print Job History] in "Document Server".
The function does not run or cannot be used.	If you cannot carry out your job, it may be that the machine is being used by another function.	Wait until the current job is completed before trying again. For details about Function Compatibility, see "When Multiple Functions Cannot Be Executed Simultaneously", Troubleshooting.
Paper is bent.	Paper may be bent when it is ejected from the finisher upper tray.	Change the output tray to the finisher shift tray.
The print image is not properly positioned on the paper.	 The machine has not detected the paper type and/or width correctly. The print position is not aligned properly. 	Contact the machine administrator or your service representative.

Problem

Cause

Solution

9

Fold

Problems	Causes	Solutions
Wrinkling occurs when Gate Fold, Letter Fold-in, or Letter Fold-out is applied.	Wrinkling can occur if Gate Fold, Letter Fold-in, or Letter Fold-out is applied to B4 JIS (Japanese Industrial Standard) □, A3□, 8¹/2" × 14"□, 11" × 17"□, 12" × 18"□, 8K□, or larger sizes of paper.	When applying Gate Fold, Letter Fold-in, or Letter Fold-out to paper larger than A4, we recommend you enable image reduction and use paper no larger than A4.
When you print Z-folded paper, the machine indicates that the output tray is full even though the amount of output paper on the tray is less than the stack capacity.	The Z-fold support tray is not set.	Set the Z-fold support tray for finisher or multi-folding unit. For details about how to add the Z-fold support tray, see "Guide to Functions of the Machine's Options", Getting Started.
The multi-folding unit outputs sheets with creased edges when Gate Fold is applied.	The paper is curled.	 Remove the paper, and then reload it upside down. Remove the paper, and then reload it in the opposite direction.
The position of the fold is incorrect when Letter Fold-in is applied to a B5 JIS sheet.	Multi-sheet Fold has been specified when only one sheet is being printed.	In [Output/Customize Function/Finisher] on the initial copier screen, under [Folding Unit], select [Letter Fold-in]. Press [Change], and then set "Multi-sheet Fold" to [Off]. For details about how to specify the Multi-sheet Fold function, see "Fold", Copy/ Document Server. When using the printer function, change the printer driver Letter Fold-in settings so that Multi- sheet Fold is not specified.



 There are times when images might not turn out as you want because of paper type, paper size, or paper capacity problems, use the recommended paper. For details about recommended paper, see page 124 "Recommended Paper Sizes and Types".

When Multiple Functions Cannot Be Executed Simultaneously

If you cannot carry out your job, it may be that the machine is being used by another function.

Wait until the current job is completed before trying again. In certain cases, you can carry out another job using a different function while the current job is being performed.

For details about Function Compatibility, see "Function Compatibility", Troubleshooting.

٤

Messages Displayed When You Use the Copy/ Document Server Function

 If you cannot make copies as you want because of the paper type, paper size or paper capacity problems, use recommended paper. For details about recommended paper, see page 124 "Recommended Paper Sizes and Types".

Message	Cause	Solution
"Adjusting the temperature of the binding glue."	The binding glue is being heated.	Wait until the glue has reached the correct temperature for binding.
"Cannot delete the folder because it contains locked files. Please contact the file administrator."	The folder cannot be deleted because it contains a locked original.	Unlock the locked original to delete it. For details about locked files, see Security Guide.
"Cannot detect original size."	The original placed on the exposure glass is a nonstandard size.	 Place the original on the exposure glass again. Face the original down. If the machine cannot detect the size of the original, specify the size manually - do not use Auto Paper Select mode or the Auto Reduce/Enlarge function. For details about specifying the settings, see "Sizes Detectable with Auto Paper Select", Paper Specifications and Adding Paper.
"Cannot detect original size."	No original has been placed, or the original placed on the exposure glass is a nonstandard size.	 Place the original correctly. Specify the original size. When placing an original directly on the exposure glass, the lifting/lowering action of the Auto Document Feeder (ADF) triggers the automatic original size detection process. Lift the ADF 30 degrees or more.

Message	Cause	Solution
"Cannot display preview of this page."	The image data may have been corrupted.	Press [Exit] to display the preview screen without a thumbnail. If the selected document contains several pages, press [Switch] on the "Display Page" area to change the page, and then a preview of the next page will appear.
"Cannot punch this paper size."	The Punch function cannot be used with paper size selected.	For details about paper sizes, see "Specifications for Punch Unit", Maintenance and Specifications.
"Cannot staple paper of this size."	The Staple function cannot be used with the paper size selected.	Select an appropriate paper size. For details about paper sizes, see "Specifications for Finisher SR5050" or "Specifications for Booklet Finisher SR5060", Maintenance and Specifications.
"Check paper size."	An irregular paper size is set.	If you press the [Start] key, the copy will start using the selected paper.
"Duplex is not available with this paper size."	A paper size not available in Duplex mode.	Select an appropriate paper size. For details about paper sizes, see "Specifications for the Main Unit", Maintenance and Specifications.
"Exceeded the maximum number of sheets that can be used. Copying will be stopped."	The number of pages the user is permitted to copy has been exceeded.	For details about how to check the number of copies available per user, see Security Guide.
"Exceeded the maximum number of multi-sheet fold. Printing will be cancelled."	A print job was canceled because more than the maximum number of Multisheet Fold was specified.	Specify fewer sheets for the Multi-sheet Fold function. For details about the maximum number of Multi-sheet Fold, see "Specifications for Multi-Folding Unit", Maintenance and Specifications.
"Exceeded max. No. of sheets possible for Ring Binding."	The number of sheets per set exceeds the limit for Ring Binding.	Check the maximum number of sheets that can be ring bound. For details about the limit for Ring Binding, see "Specifications for Ring Binder", Maintenance and Specifications.

Message	Cause	Solution
"File being stored exceeded max. number of pages per file. Copying will be stopped."	The scanned originals have too many pages to store as one document.	Press [Exit], and then store again with an appropriate number of pages.
"Magazine or Booklet mode is not available due to mixed image mode."	You selected the "Magazine" or "Booklet" function for originals scanned using different functions, such as copy and printer.	Make sure originals to which the "Magazine" or "Booklet" function is applied are scanned using the same function.
"Maximum number of sets is n." ("n" is replaced by a variable.)	The number of copies exceeds the maximum copy quantity.	You can change the maximum copy quantity from [Max. Copy Quantity] in [General Features] under [Copier / Document Server Features]. For details about Max. Copy Quantity, see "General Features", Copy/ Document Server.
"Memory is full. nn originals have been scanned. Press [Print] to copy scanned originals. Do not remove remaining originals." ("n" is replaced by a variable.)	The number of scanned originals exceed the number of pages that can be stored in memory.	Press [Print] to copy scanned originals and cancel the scanning data. Press [Clear Memory] to cancel the scanning data and not copy.
"Perfect Binding is not available for different paper sizes."	Mixed Sizes mode is specified.	Cancel Mixed Sizes mode, or specify the Auto Reduce / Enlarge function.
"Perfect Binding is not available with the settings."	Perfect Binding is not possible under the settings that you have specified.	Check the current settings. For details about which functions are not available when Perfect Binding is specified, see "Perfect Binding", Copy/Document Server.
"Perfect Binding is not available with this finishing size."	Perfect Binding cannot be used with the finishing size that you have specified.	Select a proper finishing size. For details about proper finishing sizes, see "Specifications for Perfect Binder", Maintenance and Specifications.

Message	Cause	Solution
"Perfect Binding is not available with this No. of sheets."	Perfect Binding is not possible with the number of sheets that you have specified.	Check the number of sheets. Specify the proper number of sheets. For details about the proper number of sheets, see "Specifications for Perfect Binder", Maintenance and Specifications.
"Contains incorrect setting(s) for Perfect Binding."	Perfect Binding cannot be used with the paper size that you have specified.	Select a proper paper size. For details about proper paper sizes, see "Specifications for Perfect Binder", Maintenance and Specifications.
"Press [Continue] to scan and copy remaining originals."	The machine checked if the remaining originals should be copied, after the scanned originals were printed.	Remove all copies, and then press [Continue] to continue copying. Press [Stop] to stop copying.
"Ring Binding is not available for different paper sizes."	Mixed Sizes mode is specified.	Cancel Mixed Sizes mode, or specify the Auto Reduce / Enlarge function.
"Ring Binding is not available with the selected position."	Ring Binding cannot be applied in the position that you have specified.	Select a proper binding position. For details about proper binding positions, see "Ring Binding", Copy/ Document Server.
"Ring Binding is not available with the settings."	Ring Binding is not possible under the settings that you have specified.	Check the current settings. For details about which functions are not available when Ring Binding is specified, see "Ring Binding", Copy/Document Server.
"Ring Binding is not available with this paper size."	Ring Binding cannot be used with the paper size that you have specified.	Select a proper paper size. For details about proper paper sizes, see "Specifications for Ring Binder", Maintenance and Specifications.

Message	Cause	Solution
"Stapling capacity exceeded."	The number of sheets per set is over the staple capacity.	Check the stapler capacity. For details about the stapler capacity, see "Specifications for Finisher SR5050" or "Specifications for Booklet Finisher SR5060", Maintenance and Specifications.
"The selected folder is locked. Please contact the file administrator."	An attempt was made to edit or use a locked folder.	For details about locked folders, see Security Guide.

U Note

• If you set [Memory Full Auto Scan Restart] in [Input / Output] of User Tools to [On], even if the memory becomes full, the memory overflow message will not be displayed. The machine will make copies of the scanned originals first, and then automatically proceed to scan and to copy the remaining originals. In this case, the resulting sorted pages will not be sequential. For details about Memory Full Auto Scan Restart, see "Input / Output", Copy/ Document Server.

Messages Displayed When You Use the Printer Function

This section describes the principal messages that appear on the display panel, error logs or reports. If other messages appear, follow their instructions.

Messages Displayed on the Control Panel When You Use the Printer Function



• Before turning off the power, see "Turning On/Off the Power", Getting Started.

Message	Cause	Solution
"Exceeded the maximum number of sheets possible for Ring Binding with the currently set binding ring combs. Printing will be stopped."	The ring combs currently loaded are too small for the number of sheets that need to be bound.	Change to ring combs that are big enough to bind the sheets.
"Exceeded max. No. of sheets possible for Ring Binding."	The number of sheets per set exceeds the limit for Ring Binding.	Check the maximum number of sheets that can be ring bound. For details about the limit for Ring Binding, see "Specifications for Ring Binder", Maintenance and Specifications.
"Hardware Problem: Ethernet"	An error has occurred in the Ethernet interface.	Turn off the power, and then back on again. If the message appears again, contact your service representative.
"Hardware Problem: HDD"	An error has occurred in the hard disk.	Turn off the power, and then back on again. If the message appears again, contact your service representative.
"Hardware Problem: USB"	An error has occurred in the USB interface.	Turn off the power, and then back on again. If the message appears again, contact your service representative.

Message	Cause	Solution
"Load following paper in n. To force print, select another tray and press [Continue]." ("n" is replaced by a variable.)	The printer driver settings are incorrect or the tray does not contain paper of the size selected in the printer driver.	Check that the printer driver settings are correct, and then load paper of the size selected in the printer driver into the input tray. For details about how to change the paper size, see "Changing the Paper Size", Paper Specifications and Adding Paper.
"Paper in staple tray. Open cover and remove paper."	If printing is stopped before it is finished, paper may remain in the finisher.	Remove the paper remaining in the finisher.
"Paper size and type are mismatched. Select another tray from the following and press [Continue]. To cancel job, press [Job Reset]. Paper size and type can also be changed in User Tools."	The printer driver settings are incorrect or the tray does not contain paper of the size or type selected in the printer driver.	 Check that the printer driver settings are correct, and then load paper of the size selected in the printer driver into the input tray. For details about how to change the paper size, see "Changing the Paper Size", Paper Specifications and Adding Paper. Select the tray manually to continue printing, or cancel a print job. For details about how to select the tray manually, or cancel a print job, see "If an Error Occurs with the Specified Paper Size and Type", Print.
"Paper type of n is mismatched. Select another tray from the following and press [Continue]. Paper type can also be changed in User Tools." (A tray name is placed at n.)	The type of the paper in the tray does not match the paper type specified in the printer driver.	Select a tray containing paper that is the same type as the specified paper type.

When using direct print from a memory storage device

Message	Cause	Solution
"Exceeded the limit value for total data size of the selected files. Cannot select more files."	 The size of the selected file exceeds 1 GB. The total size of the selected files exceeds 1 GB. 	Files or groups of files larger than 1 GB cannot be printed. • When the total size of the multiple files that are selected exceeds 1 GB, select files separately. • When the size of the selected file exceeds 1 GB, print from a memory storage device using a function other than the Direct printing function. You cannot select files of different formats at the same time.
"Unable to access the specified memory storage device."	 An error occurred when the machine accessed the memory storage device or a file stored on the memory storage device. An error occurred when the user used the Direct printing function to print from a memory storage device. 	Save the file to a different memory storage device, and then print again.

Messages Printed on the Error Logs or Reports When You Use the Printer Function

This section describes likely causes of and possible solutions for the error messages that are printed on the error logs or reports.

Message	Cause	Solution
"91: Error"	Printing was canceled by the auto job cancel function due to a command error.	Check that the data is valid.
"A function which cannot be used with Fold mode was set. The job has been cancelled."	A print job was canceled because a function(s) not available with Fold was selected.	Cancel the function(s) not available with Fold. For details about the functions not available with Fold, see "Fold", Print.
"A function which cannot be used with Perfect Binding was set. The job was cancelled."	A function not available with Perfect Binding has been selected.	For details about which functions are not available with Perfect Binding, see "Perfect Binding", Print.
"A function which cannot be used with Ring Binding was set. The job was cancelled."	A function not available with Ring Binding has been selected.	For details about which functions are not available with Ring Binding, see "Ring Binding", Print.
"A job via the network that was not printed exists because an error occurred. It was stored as a job not printed."	Jobs with errors were stored because an error occurred with a print job via the network while the error job storing function was enabled.	Contact your administrator to check whether the machine is connected correctly to the network. For details about how to check and print jobs stored when print configuration errors occur, see "Printing of Documents Stored When Print Configuration Errors Occur", Print.
"An error occurred with the interface box. The job has been cancelled."	There is a problem with the interface box.	Check the interface box settings.
"Error occurred while processing an Unauthorized Copy Prevention job. Job cancelled."	You tried to store a file in the Document Server when the [Unauthorized Copy Prevention] was specified.	On the printer driver, select a job type other than [Document Server] in "Job Type:" or deselect [Unauthorized Copy Prevention].

Message	Cause	Solution
"Error occurred while processing an Unauthorized Copy Prevention job. Job cancelled."	The [Enter User Text:] field on the [Unauthorized Copy Prevention for Pattern Details] screen is blank.	On the printer driver's [Detailed Settings] tab, click [Effects] in "Menu:". Select [Unauthorized Copy Prevention], and then click [Details] to display [Unauthorized Copy Prevention for Pattern Details]. Enter text in [Enter User Text:].
"Error occurred while processing an Unauthorized Copy Prevention job. Job cancelled."	The resolution is set to a value less than 600 dpi when [Unauthorized Copy Prevention] is specified.	On the printer driver, set the resolution to 600 dpi or higher, or cancel [Unauthorized Copy Prevention].
"Error occurred while processing an Unauthorized Copy Prevention job. Job cancelled."	A color other than black was specified as the pattern color when a command was used to specify Unauthorized Copy Prevention for Pattern for a document and print it.	Specify black as the pattern color.
"Error occurred while processing an Unauthorized Copy Prevention job. Job cancelled."	In [Administrator Tools] under [System Settings], priority was specified to be given to Unauthorized Copy Prevention Printing set on this machine.	Cancel Unauthorized Copy Prevention Printing for the printer driver. For details about how to cancel the settings, see the printer driver Help.
"Collate Cancelled"	Collate was canceled.	Turn off the power, and then back on again. If the message appears again, contact your service representative.
"You reach the usage limit. This job has been cancelled."	The number of pages the user is permitted to print has been exceeded.	For details about print volume use limitation, see Security Guide.
"Exceeded the maximum number of multi-sheet fold. The job has been cancelled."	The maximum number of Multi-sheet Fold was exceeded.	Specify fewer sheets for the Multi-sheet Fold function. For details about the maximum number of Multi-sheet Fold, see "Specifications for Multi-Folding Unit", Maintenance and Specifications.

Message	Cause	Solution
"Fold is not available with the settings. The job has been cancelled."	Fold function is not available with the current settings.	Check the paper settings. For details about the limitations of the Fold function, see "Fold", Print.
"Receiving data failed."	Data reception was aborted.	Resend the data.
"Sending data failed."	The machine received a command to stop transmission from the printer driver.	Check if the computer is working correctly.
"The selected paper size is not supported. This job has been cancelled."	Job reset is automatically performed if the specified paper size is incorrect.	Specify the correct paper size, and then print the file again.
"The selected paper type is not supported. This job has been cancelled."	Job reset is automatically performed if the specified paper type is incorrect.	Specify the correct paper type, and then print the file again.
"Z-fold error."	Z-folding was canceled.	Check the tray, paper orientation, print orientation, and Z-fold settings again.

When there is a problem with the print settings

Message	Cause	Solution
"Booklet/Half Fold Error"	The job was canceled because you specified invalid settings for saddle stitching or half fold.	Check the settings for saddle stitching or half fold.
"Classification Code is incorrect."	The classification code has not been entered, or the classification code has been entered incorrectly.	Enter the correct classification code.
"Classification Code is incorrect."	The classification code is not supported with the printer driver.	Select [Optional] for classification code. For details about how to specify classification code settings, see "Configuring Classification Codes", Print.

Message	Cause	Solution
"Duplex Cancelled"	Duplex printing was canceled.	 Select an appropriate paper size for the duplex function. For details about paper, see "Specifications for the Main Unit", Maintenance and Specifications. Change the setting for "Apply Duplex" in [Tray Paper Settings] to enable duplex printing for the paper tray. For details about setting "Apply Duplex", see "Tray Paper Settings", Paper Settings.
"Exceeded Max. Pages (Collate)"	The number of pages exceeds the maximum number of sheets that you can use Collate with.	Reduce the number of pages to print.
"Exceeded the maximum number of multi-sheet fold (Half Fold)."	The maximum number of multi- sheet folds (Half Fold) was exceeded.	For details about the maximum number of multi-sheet folds (Half Fold), see "Fold", Print.
"Output Tray Changed"	The output tray was changed because the paper size of the specified output tray is limited.	Specify the proper output tray.
"Perfect Binding is not available with the settings."	Perfect Binding is not possible under the settings that you have specified.	Check the current settings. For details about which functions are not available when Perfect Binding is specified, see "Perfect Binding", Print.

Message	Cause	Solution
"Perfect Binding is not available with this number of sheets."	Perfect Binding is not possible with the number of sheets that you have specified.	Check the number of sheets. Specify the proper number of sheets. For details about the proper number of sheets, see "Specifications for Perfect Binder", Maintenance and Specifications.
"Print Overrun"	Images were discarded while printing.	Select a lower resolution on the printer driver. For details about how to change the resolution setting, see the printer driver Help.
"Punch Cancelled"	Punch printing was canceled.	Check the paper orientation, print orientation, and then punch position. Certain settings can produce print results that might not be as expected.
"Ring Binding is not available with the settings."	Ring Binding is not possible under the settings that you have specified.	Check the current settings. For details about which functions are not available when Ring Binding is specified, see "Ring Binding", Print.
"Staple Cancelled"	Stapling printing was canceled.	Check the paper orientation, paper quantity, print orientation, and staple position. Certain settings can produce print results that might not be as expected.

C

When documents cannot be stored in the Document Server

Message	Cause	Solution
"Cannot store data of this size."	The paper size exceeded the capacity of the Document Server.	Reduce the paper size of the file that you want to send to a size that the Document Server can store. Custom size files can be sent but not stored afterward.
"Document Server is not available to use. Cannot store."	You cannot use the Document Server function.	For details about using Document Server function, contact your administrator. For details about how to set permissions, see Security Guide.
"Exceeded max. capacity of Document Server. Cannot store."	The hard disk became full after a file was stored.	Delete some of the files stored in the Document Server or reduce the size that you want to send.
"Exceeded max. number of files of Document Server. Cannot store."	The maximum file capacity of the Document Server was exceeded.	Delete some of the files stored in the Document Server.
"Exceeded max. number of files. (Auto)"	While you were using the error job store function to store Normal Print jobs as Hold Print files, the maximum file capacity for file storage or Hold Print file management (automatic) was exceeded.	Delete Hold Print files (automatic) or unneeded files stored on the machine.
"Exceeded max. number of pages of Document Server. Cannot store."	The maximum page capacity of the Document Server was exceeded.	Delete some of the files stored in the Document Server or reduce the number of pages that you want to send.
"Exceeded max. number of pages. (Auto)"	While you were using the error job store function to store Normal Print jobs as Hold Print files, the maximum page capacity was exceeded.	Delete unneeded files stored on the machine. Reduce the number of pages to print.

Message	Cause	Solution
"Job cancelled because capture file could not be stored: Exceeded max. memory."	The hard disk became full after a file was stored.	Delete the files stored in the Document Server or reduce the file size to be sent.
"Job cancelled because capture file could not be stored: Exceeded max. files."	The maximum file capacity of the Document Server was exceeded.	Delete the files stored in the Document Server.
"Job cancelled because capture file could not be stored: Exceeded max pages per file."	The maximum page capacity of the Document Server was exceeded.	Delete some of the files stored in the Document Server or reduce the number of pages that you want to send.
"The specified folder in Document Server is locked. Cannot store."	The specified folder is locked.	Unlock the folder or specify another folder number that can be used. For details about locked folders, see Security Guide.

When there is not enough free hard disk space

Message	Cause	Solution
"HDD Full"	When you were printing with the PostScript 3 printer driver, the hard disk capacity for fonts and forms was exceeded.	Delete unneeded forms or fonts registered on the machine.
"HDD Full"	The hard disk became full while you were printing a Sample Print, Locked Print, Hold Print, or Stored Print file.	Delete unneeded files stored on the machine. Alternatively, reduce the data size of the Sample Print, Locked Print, Hold Print, or Stored Print file.
"HDD is full. (Auto)"	The hard disk became full while you were using the error job store function to store Normal Print jobs as Hold Print files.	Delete unneeded files stored on the machine. Alternatively, reduce the data size of the Temporary Print file and/or the Stored Print file.

When there is not enough memory

Message	Cause	Solution
"84: Error"	There is no work area available for image processing.	Decrease the number of files sent to the machine.

When there is a problem with a parameter

Message	Cause	Solution
"86: Error"	Parameters of the control code are invalid.	Check the print settings.

When the user lacks privileges to perform an operation

Message	Cause	Solution
"No response from the server. Authentication has failed."	A timeout occurred while connection to the server was being established for LDAP authentication or Windows Authentication.	Check the status of the server.
"Printing privileges have not been set for this document."	You have no privileges to print the PDF document you tried to print.	Contact the owner of the document.
"You do not have a privilege to use this function. This job has been cancelled."	The entered login user name or login password is not correct.	Check that the user name and password are correct.
"You do not have a privilege to use this function. This job has been cancelled."	The logged in user is not allowed to use the selected function.	For details about how to set permissions, see Security Guide.
"You do not have a privilege to use this function. This operation has been cancelled."	The logged in user does not have the privileges to register programs or change the paper tray settings.	For details about how to set permissions, see Security Guide.

When a user cannot be registered

Message	Cause	Solution
"Auto-registration of user information has failed."	Automatic registration of information for LDAP Authentication or Windows Authentication failed because the Address Book is full.	For details about automatic registration of user information, see Security Guide.
"Information for user authentication is already registered for another user."	The user name for LDAP was already registered in a different server with a different ID, and a duplication of the user name occurred due to a switching of domains (servers), and so on.	For details about user authentication, see Security Guide.


When other errors occur

Message	Cause	Solution
"85: Error"	The specified graphics library is unavailable.	Check that the data is valid.
"98: Error"	The machine could not access the hard disk correctly.	Turn off the power, and then back on again. If the message appears frequently, contact your service representative.
"99: Error"	This data cannot be printed. The specified data is either corrupt or it cannot be printed from a memory storage device using the Direct printing function.	Check that the data is valid. For details about the kinds of data that can be printed from a memory storage device using the Direct printing function, see "Direct Printing from a Memory Storage Device", Print.

Message	Cause	Solution
"Command Error"	An RPCS command error occurred.	 Check using the following procedure: Check if the communication between the computer and the machine is working correctly. Check if the correct printer driver is being used. Check if the machine's memory size is set correctly in the printer driver. Check that the printer driver is the most up-to-date version available.
"Compressed Data Error."	The printer detected corrupt compressed data.	 Check the connection between the computer and the printer. Check that the program you used to compress the data is functioning correctly.
"Data Storage Error"	You tried to print a Sample Print, Locked Print, Hold Print, or Stored Print file, or to store a file in the Document Server when the hard disk was malfunctioning.	Contact your service representative.
"Error has occurred."	A syntax error, etc., occurred.	Check that the PDF file is valid.
"Exceeded Max. Stored Files"	While printing a Sample Print, Locked Print, Hold Print, or Stored Print file, the maximum file capacity was exceeded.	Delete unneeded files stored on the machine.
"Exceeded Max. Stored Pages"	While printing a Sample Print, Locked Print, Hold Print, or Stored Print file, the maximum page capacity was exceeded.	Delete unneeded files stored on the machine. Reduce the number of pages to print.

Message	Cause	Solution
"Failed to obtain file system."	PDF direct printing could not be performed because the file system could not be obtained.	Turn off the power, and then back on again. If the message appears again, contact your service representative.
"File system is full."	PDF file does not print out because the capacity of the file system is full.	Delete all unnecessary files from the hard disk, or decrease the file size sent to the machine.
"Folding Unit Error."	There is a problem with the multi-folding unit.	Contact your service representative.
"I/O buffer overflow."	An input buffer overflow occurred.	 In [Printer Features], under [Host Interface], select [I/O Buffer], and then set the maximum buffer size to a larger value. Reduce the number of files being
		sent to the machine.
"Insufficient Memory"	A memory allocation error occurred.	PCL 6 On the printer driver's [Detailed Settings] tab, click [Print Quality:Advanced] in "Menu:", and then select [Raster] in the "Vector/Raster:" list. In some cases, it will take a long time to complete a print job.
"Memory Retrieval Error"	A memory allocation error occurred.	Turn off the power and then back on again. If the message appears again, replace the RAM. For details about replacing the RAM, contact your service representative.
"Paper Type Error"	The specified paper type name is not set in the machine.	Re-obtain the latest paper type information set in the machine.

If printing does not start, contact your service representative.



• The contents of errors may be printed on the Configuration Page. Check the Configuration Page in conjunction with the error log. For details about how to print the Configuration Page, see "List / Test Print", Print.

Messages Displayed When You Use the Scanner Function

Messages Displayed on the Control Panel When You Use the Scanner Function

This section describes likely causes of and possible solutions for the error messages that appear on the control panel. If a message not described here appears, act according to the message.

Message	Cause	Solution
"Cannot find the specified path. Please check the settings."	The destination computer name or folder name is invalid.	Check whether the computer name and the folder name for the destination are correct.
"Cannot find the specified path. Please check the settings."	An antivirus program or a firewall is preventing the machine from connecting to your computer.	 Antivirus programs and firewalls can prevent client computers from establishing connection with this machine.
		If you are using antivirus software, add the program to the exclusion list in the application settings. For details about how to add programs to the exclusion list, see the antivirus software Help.
		To prevent a firewall from blocking the connection, register the machine's IP address in the firewall's IP address exclusion settings. For details about the procedure for excluding an IP address, see your operating system's Help.
"Entered user code is not correct. Please re-enter."	You have entered an incorrect user code.	Check the authentication settings, and then enter a correct user code.

Message	Cause	Solution
"Exceeded max. number of alphanumeric characters for the path."	The maximum number of specifiable alphanumeric characters in a path has been exceeded.	Check the maximum number of characters which can be entered, and then enter it again. For details about the maximum enterable number of characters, see "Values of Various Set Items for Transmission/Storage Function", Scan.
"Exceeded max. number of alphanumeric characters."	The maximum enterable number of alphanumeric characters has been exceeded.	Check the maximum number of characters which can be entered, and then enter it again. For details about the maximum enterable number of characters, see "Values of Various Set Items for Transmission/Storage Function", Scan.
"Exceeded the maximum number of OCR jobs that can be on standby for storing, please wait. Try again after storing of the current job has completed."	The maximum allowable number of jobs on standby was exceeded because large quantities of documents were stored by the OCR function.	Up to 100 jobs can be placed on standby by the OCR function. Scan the next document after the current jobs have finished being stored.
"File types have been automatically set for some files because multiple files were selected."	If there are selected stored documents which cannot be converted to a specified file format, those documents are automatically converted to a convertible format before they are transmitted.	For details about the file formats used to transmit stored documents, see "Sending a Stored File", Scan.
"Programmed. Cannot program the destination(s) that is not programmed in the address book."	The destinations that were selected while registered to the program contain a folder destination for which one of the following destinations is set: manually entered destination, WSD destination, or DSM destination	WSD destinations and DSM destinations cannot be registered to the program because they cannot be registered in the address book. For manually entered destinations, register the destinations in the address book, and then try to register them to the program again.

Message	Cause	Solution
"Scanner journal is full. Please check Scanner Features."	"Print & Delete Scanner Journal" in [Scanner Features] is set to [Do not Print: Disable Send], and Scanner Journal is full.	Print or delete Scanner Journal. For details about Scanner Features, see "General Settings", Scan.
"The entered file name contains invalid character(s). Enter the file name again using any of the following 1 byte characters. "O to 9", "A to Z", "a to z", " ""	The file name contains a character that cannot be used.	Check the file name set at the time of scanning. For details about characters that can be used in file names, see "Specifying the File Name", Scan.
"The entered file name contains invalid character(s). Enter the file name again using any of the following 1 byte characters. "O to 9", "A to Z", "a to z", " ""	The file name contains a character that cannot be used.	Check the file name specified at the time of scanning. The file name specified in the Sending Scan Files to Folders function cannot contain the following characters: \(/: * ? " <> The file name cannot start or end with a period "."
"The program is recalled. Cannot recall the destination(s) for which access privileges are required."	The currently logged-in user does not have permission to view the destination that was registered in the program.	For details about how to set permissions, see Security Guide.
"The program is recalled. Cannot recall the destination(s) that is deleted from the address book."	The destination stored in the program could not be recalled because it was deleted from the address book.	Enter the destination directly to send data separately.
"The program is recalled. Cannot recall the folder destination(s) with protection code(s)."	The folder destinations for which the protection code was set were registered in the program.	A destination for which the protection code is set cannot be recalled by the program. Cancel the protection code setting or send scanned files to the destination separately.

C

When documents cannot be scanned properly

Message	Cause	Solution
"All the pages are detected as blank. No file was created."	No PDF file was created because all the pages of the scanned original were detected as blank when [On] is specified for [Delete Blank Page] in [OCR Settings].	Check whether the original is set upside down. Change [OCR Scanned PDF: Blank Page Sensitivity] in [Scanner Features] to "Sensitivity Level 1".
"Check original's orientation."	Originals may sometimes not be scanned depending on a combination of items such as the specified scaling factor and document size.	Change the orientation of the original, and then scan the original again.
"Exceeded max. data capacity." "Check scanning resolution, then press Start key again."	The scanned data exceeded maximum data capacity.	Specify the scan size and resolution again. Note that it may not be possible to scan very large originals at a high resolution. For details about the settings for the scanner function, see "Relationship between Resolution and Scan Size", Scan.
"Exceeded max. data capacity." "Check the scanning resolution, then reset n original(s)." ("n" in the message represents a variable.)	The scanned original exceeded maximum data capacity.	Specify the scan size and resolution again. Note that it may not be possible to scan very large originals at a high resolution. For details about the settings for the scanner function, see "Relationship between Resolution and Scan Size", Scan.
"Exceeded max. data capacity." "Check the resolution and the ratio and then press the Start key again."	The data being scanned is too large for the scale ratio specified in [Specify Size].	Reduce the resolution or [Specify Size] value, and then scan the original again.

Message	Cause	Solution
"Exceeded max. number of files which can be used in Document Server at the same time."	The maximum number of files that can be stored in the Document Server has been exceeded.	Check the files stored by the other functions, and then delete unneeded files. For details about how to delete files, see "Deleting Stored Documents", Copy/ Document Server.
"Not all of the image will be scanned." "Check the ratio and then press the Start key again."	If the scaling factor specified in "Specify Reproduction Ratio" is too large, part of the image may be lost.	Reduce the scaling factor in "Specify Reproduction Ratio", and then try to scan the original again. If displaying the entire image is not necessary, press the [Start] key to start scanning with the current scaling factor.
"Not all of the image will be scanned." "Check the ratio and then press the Start key again."	Using "Specify Reproduction Ratio" to scale down a large document may cause part of the image to be lost.	Specify a large size in [Specify Size], and then scan the original again. If displaying the entire image is not necessary, press the [Start] key to start scanning with the current scaling factor.
"The size of the scanned data is too small." "Check the resolution and the ratio and then press the Start key again."	The data being scanned is too small for the scale ratio specified in [Specify Size].	Specify a higher resolution or a large size in [Specify Size], and then scan the original again.

C

When documents cannot be scanned because the memory is full

Message	Cause	Solution
"Memory is full. Cannot scan. The scanned data will be deleted."	Because of insufficient hard disk space, the first page could not be scanned.	Try one of the following measures: • Wait for a while, and then retry the scan operation. • Reduce the scan area or scanning resolution. For details about changing scan area and scanning resolution, see "Scan Settings" of Various Scan Settings, Scan. • Delete unneeded stored files. For details about how to delete stored files, see "Deleting a Stored File", Scan.
"Memory is full. Do you want to store scanned file?"	Because there is not enough free hard disk space in the machine for storing in the Document Server, only some of the pages could be scanned.	Specify whether or not to use the data.
"Memory is full. Scanning has been cancelled. Press [Send] to send the scanned data, or press [Cancel] to delete."	Because there is not enough free hard disk space in the machine for sending by e- mail while data is being stored in the Document Server, only some of the pages could be scanned.	Specify whether or not to use the data.

Message	Cause	Solution
"Authentication with the destination has failed. Check settings. To check the current status, press [Scanned Files Status]."	The entered user name or password was invalid.	 Check that the user name and password are correct. Check that the ID and password for the destination folder are correct. A password of 128 or more characters may not be recognized.
"Exceeded max. email size. Sending email has been cancelled. Check [Max. Email Size] in Scanner Features."	The file size per page has reached the maximum email size specified in [Scanner Features].	Change the scanner features settings as follows: Increase the e-mail size limit in [Max. Email Size]. Change the [Divide & Send Email] setting to [Yes (per Page)] or [Yes (per Max. Size)]. For details about these settings, see "Send Settings", Scan.
"Sending the data has failed. The data will be resent later."	A network error has occurred and a file was not sent correctly.	Wait until sending is retried automatically after the preset interval. If sending fails again, contact your administrator.
"Transmission has failed. Insufficient memory in the destination hard disk. To check the current status, press [Scanned Files Status]."	Transmission has failed. There was not enough free space on the hard disk of the SMTP server, FTP server, or client computer at the destination.	Allocate sufficient space.
"Transmission has failed. To check the current status, press [Scanned Files Status]."	While a file was being sent, a network error occurred and the file could not be sent correctly.	If the same message appears again after scanning again, the cause could be a mixed network, or network settings were changed during WSD scanner transmission. For details about network error, contact your administrator.

,

When data cannot be sent because a currently used file is selected

Message	Cause	Solution
"Selected file is currently in use. File name cannot be changed."	You cannot change the name of a file whose status is "Waiting".	Cancel transmission ("Waiting" status cleared), and then change the file name.
"Selected file is currently in use. Password cannot be changed."	You cannot change the password of a file whose status is "Waiting".	Cancel transmission ("Waiting" status cleared), and then change the password.
"Selected file is currently in use. User name cannot be changed."	You cannot change the sender's name whose status is "Waiting".	Cancel transmission ("Waiting" status cleared), and then change the user name.
"Some of selected files are currently in use. They could not be deleted."	You cannot delete a file which is waiting to be transmitted ("Waiting" status displayed).	Cancel transmission ("Waiting" status cleared), and then delete the file.

When data cannot be sent because there are too many documents or pages

Message	Cause	Solution
"Exceeded max. number of pages per file. Do you want to store the scanned pages as 1 file?"	The file being stored has exceeded the maximum number of pages for one file.	Specify whether to store the data or not. Scan the pages that were not scanned, and then store them as a new file. For details about storing files, see "Storing and Saving the Scanned Documents", Scan.
"Exceeded max. number of stored files. Cannot send the scanned data as capturing files is unavailable."	Too many files are waiting to be sent.	Try again after they have been sent.
"Exceeded max. page capacity per file. Press [Send] to send the scanned data, or press [Cancel] to delete."	The number of scanned pages exceeded the maximum page capacity.	Specify whether to send the data that has already been scanned.

Message	Cause	Solution
"Exceeded maximum number of file to store. Delete all unnecessary files."	Too many files are waiting to be sent.	Try again after they have been sent.

When the WSD scanner function cannot be used

Message	Cause	Solution
"Cannot communicate with PC. Contact the administrator."	WSD (Device) protocol or WSD (Scanner) protocol is disabled.	For details about how to enable or disable the WSD protocol, see Security Guide.
"Cannot start scanning because communication was failed."	Scan Profile is not set on the client computer.	Set Scan Profile. For details about how to do this, see "Creating a New Scan Profile", Scan.
"Cannot start scanning because communication was failed."	The [Take no action] setting has been selected on the client computer, forcing the client computer to remain inactive when it receives scan data.	Open scanner properties, click the [Events] tab, and then select [Start this program] as the computer's response when it receives scan data. For details, see your operating system's Help.
"Cannot start scanning. Check the setting(s) on the PC."	The Scan Profile might be incorrectly configured.	Check the Scan Profile configuration.
"Could not send the data because the PC timed out before it was sent."	A time out occurred when WSD Scanner was used. Time outs occur when too much time passes between scanning an original and sending its data. The followings are likely causes of time outs: Too many originals per set. Misfed originals. Transmission of other jobs.	 Reduce the number of originals, and then scan again. Remove any misfed original, and then scan again. Use Scanner Journal to check there are no jobs awaiting transmission, and then scan again.

When documents cannot be stored on a memory storage device

Message	Cause	Solution
"Cannot write on the memory storage device because remaining free space is insufficient."	The memory storage device is full and scan data cannot be saved. Even if the memory storage device appears to have sufficient free space, data might not be saved if the maximum number of files that can be saved is exceeded.	Replace the memory storage device. If the document is scanned as single-page or divided into multiple pages, data already written to the memory storage device is saved as is. Replace the memory storage device, and then press [Retry] to save the remaining data, or press [Cancel] to redo the scan.
"Cannot write on the memory storage device because the device is write-protected."	The memory storage device is write-protected.	Unlock the write-protection on the memory storage device.
"Cannot write on the memory storage device. Check the memory storage device and machine settings."	The memory storage device is faulty, or the file name contains a character that cannot be used.	 Check to see if the memory storage device is defective. Check the memory storage device. It might be unformatted, or its format might be incompatible with this machine. Check the file name set at the time of scanning. For details about the characters that can be used in file names, see "Specifying the File Name", Scan.
"Exceeded max. page capacity per file. Press [Write] to write the scanned data to the memory storage device, or press [Cancel] to delete."	The scan could not be completed because the maximum number of pages that can be scanned by this machine was exceeded during the scanned data was written to the memory storage device.	Reduce the number of documents to be written to the memory storage device, and then try again.

Message	Cause	Solution
"Memory is full. Press [Write] to write the current scanned data to the memory storage device, or press [Cancel] to delete."	The scan could not be completed because there was insufficient hard disk memory when the scanned data was saved to the memory storage device.	Specify whether or not to save the scanned document to the memory storage device.

Messages Displayed on the Client Computer

This section describes likely causes of and possible solutions for the main error messages displayed on the client computer when you use the TWAIN driver. If a message not described here appears, follow the instruction.

Message	Cause	Solution
"Any of Login User Name, Login Password or Driver Encryption Key is incorrect."	The entered login user name, password, or driver encryption key was invalid.	Check your login user name, login password, or driver encryption key, and then enter them correctly. For details about login user name, login password, and driver encryption key, see Security Guide.
"Authentication succeeded. However, the access privileges for scanner function has been denied."	The logged in user name does not have permissions for scanner function.	For details about how to set permissions, see Security Guide.
"Cannot add any more scanning mode."	The maximum number of registrable scan modes has been exceeded.	The maximum number of modes that can be stored is 100. Delete unneeded modes.
"Cannot detect the paper size of the original. Specify the scanning size."	The set original was misaligned.	 Place the original correctly. Specify the scan size. When placing an original directly on the exposure glass, the lifting/lowering action of the ADF triggers the automatic original size detection process. Lift the ADF 30 degrees or more.

Message	Cause	Solution
"Cannot specify any more scanning area."	The maximum number of registrable scan modes has been exceeded.	The maximum number of scanning areas that can be stored is 100. Delete unneeded scanning areas.
"Clear Misfeed(s) in ADF."	A paper misfeed has occurred inside the ADF.	 Remove the jammed originals, and then insert them again. For details about jammed paper, see "Removing Jammed Paper", Troubleshooting. When a misfeed occurs, replace the jammed originals. Check whether the originals are suitable to be scanned by the machine.
"Error has occurred in the scanner driver."	An error has occurred in the driver.	 Check whether the network cable is connected correctly to the client computer. Check whether the Ethernet board of the client computer is recognized correctly by Windows. Check whether the client computer can use the TCP/IP protocol.
"Error has occurred in the scanner."	The application-specified scan conditions have exceeded the setting range of the machine.	Check whether the scanning settings made with the application exceed the setting range of the machine.
"Fatal error has occurred in the scanner."	An unrecoverable machine error has occurred.	An unrecoverable machine error has occurred. Contact your service representative.
"Insufficient memory. Close all other applications, then restart scanning."	Memory is insufficient.	 Close all the unnecessary applications running on the client computer. Uninstall the TWAIN driver, and then reinstall it after restarting the computer.

Message	Cause	Solution
"Scanner is in use for other function. Please wait."	A function of the machine other than the Scanner function is being used such as the Copier function.	 Wait for a while, and then connect to the network again. Cancel the job that is being processed. Press the [Stop] key. Follow the instructions in the message that appears and exit the function that is running.
"Scanner is not available on the specified device."	The TWAIN scanner function cannot be used on this machine.	Contact your service representative.
"Scanner is not ready. Check the scanner and the options."	The ADF cover is open.	Check whether the ADF cover is closed.
"The name is already in use. Check the registered names."	You tried to register a name that is already in use.	Use another name.

When there is a problem connecting to the scanner

Message	Cause	Solution
"Cannot connect to the scanner. Check the network Access Mask settings in User Tools."	An access mask is set.	For details about an access mask, contact your administrator.
"Cannot find "XXX" scanner used for the previous scan. "YYY" will be used instead." ("XXX" and "YYY" indicate scanner names.)	The main power of the previously used scanner is not set to "On".	Check whether the main power of the scanner used for the previous scan is turned on.

Message

"Scanner is not available.

Check the scanner

connection status."

Cause

Network communication is

not available because the

machine's IP address could

not be obtained from the

set to [Active], the IPv6

address might not be

obtained.

host name. If only "IPv6" is

Solution

• Check whether the machine's host

Connection Tool. For the WIA

driver, check the [Network

• Use Web Image Monitor to set

"LLMNR" of "IPv6" to [Active].

name is specified in the Network

Connection] tab in the properties.

When Other Messages Appear

Message	Cause	Solution
"Clean the scanning glass. (Located next to the exposure glass.)"	The scanning glass or guide plate of the ADF is dirty.	Clean the scanning glass or guide plate. See "Maintaining Your Machine", Maintenance and Specifications.
"Following output tray is full. Remove paper."	The output tray is full.	 Remove paper from the output tray to resume printing. If paper is delivered to the finisher shift tray and you want to prevent paper from falling off the tray, press the [Stop] key to suspend printing, and then remove the paper. Press [Continue] on the display panel to resume printing. When using the multi-folding unit, the number of sheets per paper stack depends on the paper type and fold type.
"Internal cooling fan is active."	Large print runs will cause the machine's interior to heat up, triggering the cooling fan.	The fan will emit noise, but this is normal and the machine will be operable while the fan is running. The amount of paper that can be printed and the total operation time until the fan starts running depends on the temperature of the location at which the machine is installed.
"Self checking"	The machine is performing image adjustment operations.	The machine may perform periodic maintenance during operations. The frequency and duration of maintenance depends on the humidity, temperature, and printing factors such as number of prints, paper size, and paper type. Wait for the machine to resume operation.

q

9

When There Is a Problem Scanning or Storing Originals

Message	Cause	Solution
"Cannot detect original size. Select scan size."	The machine failed to detect the size of the original.	 Place the original correctly. Specify the scan size, and then place the originals again. When placing an original directly on the exposure glass, the lifting/lowering action of the ADF triggers the automatic original size detection process. Lift the ADF 30 degrees or more.
"Captured file exceeded max. number of pages per file. Cannot send the scanned data."	The maximum number of pages per file has been exceeded.	Reduce the number of pages in the transmitted file, and then resend the file. For details about the maximum number of pages per file, see "Storage Function", Scan.
"Original(s) is being scanned for a different function."	Another function of the machine is being used.	Cancel the job in progress. Press [Exit], and then press the [Stop] key. Follow the instructions in the message that appears and exit the function that is running.

When the Home Screen Cannot Be Edited

Message	Cause	Solution
"The image data size is not valid. See the manual for required data."	The image data size is not valid.	For details about file size for shortcut image, see "Displaying an Image on the [Home] Screen", Convenient Functions.
"The format of the image data is not valid. See the manual for required data."	The file format of the shortcut image to be added is not supported.	The file format of shortcut images to be added must be PNG. Specify the image again.

When the Address Book Is Updated

Message	Cause	Solution
"Updating the destination list has failed. Try again?"	A network error has occurred.	Check whether the server is connected.
		 Antivirus programs and firewalls can prevent client computers from establishing connection with this machine.
		If you are using antivirus software, add the program to the exclusion list in the application settings. For details about how to add programs to the exclusion list, see the antivirus software Help.
		To prevent a firewall from blocking the connection, register the machine's IP address in the firewall's IP address exclusion settings. For details about the procedure for excluding an IP address, see your operating system's Help.
"Updating the destination list Please wait. Specified destination(s) or sender's name has been cleared."	The destination list is being updated from the network using Web Image Monitor.	Wait until the message disappears. Do not turn off the power while this message is displayed. Depending on the number of destinations to be updated, there may be some delay before operation is resumed. Operation is not possible while this message is displayed.
"Updating the destination list Please wait. Specified destination(s) or sender's name has been cleared."	A specified destination or sender's name was cleared when the destination list in the delivery server was updated.	Specify the destination or sender's name again.

q

When Data Cannot Be Sent Due to a Problem with the Destination

Message	Cause	Solution
"Some invalid destination(s) contained. Do you want to select only valid destination(s)?"	The specified group contains either an e-mail destination and/or folder destination that is not supported by the specified transmission method.	In the message that appears at each transmission, press [Select].
"SMTP authentication email address and administrator email address mismatch."	The SMTP authentication e- mail address and the administrator's e-mail address do not match.	For details about how to set SMTP authentication, see "File Transfer", Connecting the Machine/ System Settings.

When the Machine Cannot Be Operated Due to a Problem with the User Certificate

Message	Cause	Solution
"The destination cannot be selected because its encryption certificate is not currently valid."	The user certificate (destination certificate) has expired.	A new user certificate must be installed. For details about the user certificate (destination certificate), see Security Guide.
"The group destination cannot be selected because it contains a destination with a encryption certificate that is not currently valid."	The user certificate (destination certificate) has expired.	A new user certificate must be installed. For details about the user certificate (destination certificate), see Security Guide.
"Transmission cannot be performed because the encryption certificate is not currently valid."	The user certificate (destination certificate) has expired.	A new user certificate must be installed. For details about the user certificate (destination certificate), see Security Guide.

Message

"XXX cannot be YYY

because the device

certificate used for the S/

(XXX and YYY indicate the

MIME signature is not

currently valid."

user action.)

Cause

The device certificate (S/

MIME) has expired.

Solution

A new device certificate (S/MIME)

must be installed. For details about

MIME), see Security Guide.

how to install a device certificate (S/

9



If an e-mail cannot be sent and a message appears which states that there is a problem with the
device certificate or user certificate, a new certificate must be installed. For details about how to
install a new certificate, see Security Guide.

When Problems Occur While Logging In

Message	Cause	Solution
"Authentication has failed."	The entered login user name or login password is not correct.	For details about the correct login user name and login password, see Security Guide.
"Authentication has failed."	The machine cannot perform authentication.	For details about authentication, see Security Guide.

When the User Lacks Privileges to Perform an Operation

Message	Cause	Solution
"You do not have the privileges to use this function."	The logged in user name does not have permissions for the selected function.	For details about how to set permissions, see Security Guide.
"The selected file(s) contained file(s) without access privileges. Only file(s) with access privileges will be deleted."	You have tried to delete files without the permission to do so.	To check your access permission for stored documents, or to delete a document you do not have permission to delete, see Security Guide.

When the LDAP Server Cannot Be Used

Message	Cause	Solution
"Connection with LDAP server has failed. Check the server status."	A network error has occurred and connection has failed.	Try the operation again. If the message is still displayed, the network may be busy. Check the settings for LDAP server in
		[System Settings]. For details about settings for LDAP server, see "Programming the LDAP server", Connecting the Machine/ System Settings.

Message

"Exceeded time limit for

Cause

A network error has

Solution

• Try the operation again. If the

a

10. Information for This Machine

This chapter describes environmental precautions and regulations.

Information on Environmental Regulations

ENERGY STAR Program

ENERGY STAR® Program Requirements for Imaging Equipment



This company is a participant in the ENERGY STAR® Program. This machine is compliant with the regulations specified by the ENERGY STAR® Program.

The ENERGY STAR[®] Program Requirements for Imaging Equipment encourage energy conservation by promoting energy efficient computers and other office equipment.

The program backs the development and dissemination of products that feature energy saving functions.

It is an open program in which manufacturers participate voluntarily.

Targeted products are computers, monitors, printers, facsimiles, copiers, scanners, and multi-function devices. Energy Star standards and logos are internationally uniform.



• For details about the "default delay time", see page 221 "Energy Saving Functions".

Energy Saving Functions

To reduce its power consumption, this machine has the following functions:

Low Power mode

• If this machine remains idle for a specified period, it automatically reduces its electrical consumption.

The default period the machine waits before entering Low Power mode is 15 minutes. This
default time can be changed.

Sleep mode

- If this machine remains idle for a specified period or when the [Energy Saver] key is pressed, it
 enters Sleep mode to further reduce its electrical consumption.
- The default delay time the machine waits before entering Sleep mode is 60 minutes. This
 default time can be changed.
- The machine can print jobs from computers while in Sleep mode.

Specification

	Type 1	Type 2	Туре 3	Type 4
Reduced electrical consumption in Low Power mode *1	293 W	293 W	293 W	293 W
Time of switch into Low Power mode	15 minutes	15 minutes	15 minutes	15 minutes
Time of switch out from Low Power mode *1	26 seconds	26 seconds	26 seconds	26 seconds
Reduced electrical consumption in Sleep mode *1	2.0 W	2.0 W	2.0 W	2.0 W
Time of switch into Sleep mode	60 minutes	60 minutes	60 minutes	60 minutes
Time of switch out from Sleep mode *1	298 seconds	298 seconds	298 seconds	298 seconds
Duplex Function *2	Standard	Standard	Standard	Standard

- *1 The time it takes to switch out from energy saving functions and electrical consumption may differ depending on the conditions and environment of the machine.
- *2 Achieves ENERGY STAR energy savings; product fully qualifies when packaged with (or used with) a duplex tray and the duplex function is enabled as an option.



- Specifications can vary depending on which options are installed on the machine.
- For details about how to change the default interval, see "Timer Settings", Connecting the Machine/ System Settings.

IU

- The machine enters sleep mode directly in the following situations:
 - · Low Power Mode Timer and Sleep Mode Timer are set to the same time
 - Sleep Mode Timer is set to a shorter time than Low Power Mode Timer
- Depending on which embedded software application is installed on it, the machine might take longer than indicated to enter Sleep mode.

User Information on Electrical and Electronic Equipment Region A (mainly Europe)

Users in the countries where this symbol shown in this section has been specified in national law on collection and treatment of E-waste

Our Products contain high quality components and are designed to facilitate recycling.

Our products or product packaging are marked with the symbol below.



The symbol indicates that the product must not be treated as municipal waste. It must be disposed of separately via the appropriate return and collection systems available. By following these instructions you ensure that this product is treated correctly and help to reduce potential impacts on the environment and human health, which could otherwise result from inappropriate handling. Recycling of products helps to conserve natural resources and protect the environment.

For more detailed information on collection and recycling systems for this product, please contact the shop where you purchased it, your local dealer or sales/service representatives.

All Other Users

If you wish to discard this product, please contact your local authorities, the shop where you bought this product, your local dealer or sales/service representatives.

Note for the Battery and/or Accumulator Symbol (For EU Countries Only) Region (mainly Europe)



In accordance with the Battery Directive 2006/66/EC Article 20 Information for end-users Annex II, the above symbol is printed on batteries and accumulators.

This symbol means that in the European Union, used batteries and accumulators should be disposed of separately from your household waste.

In the EU, there are separate collection systems for not only used electrical and electronic products but also batteries and accumulators.

Please dispose of them correctly at your local community waste collection/recycling centre.

Environmental Advice for Users Region A (mainly Europe)

Users in the EU, Switzerland and Norway

Consumables yield

Please refer to either the User's Manual for this information or the packaging of the consumable.

Recycled paper

The machine can use recycled paper which is produced in accordance with European standard EN 12281:2002 or DIN 19309. For products using EP printing technology, the machine can print on 64 g/m^2 paper, which contains less raw materials and represents a significant resource reduction.

Duplex printing (if applicable)

Duplex printing enables both sides of a sheet of paper to be used. This saves paper and reduces the size of printed documents so that fewer sheets are used. We recommend that this feature is enabled whenever you print.

Toner and ink cartridge return program

Toner and ink cartridge for recycling will be accepted free of charge from users in accordance with local regulations.

For details about the return program, please refer to the Web page below or consult your service person.

https://www.ricoh-return.com/

Energy efficiency

The amount of electricity a machine consumes depends as much on its specifications as it does on the way you use it. The machine is designed to allow you to reduce electricity costs by switching to Ready mode after it prints the last page. If required, it can immediately print again from this mode. If no additional prints are required and a specified period of time passes, the device switches to an energy saving mode.

In these modes, the machine consumes less power (watts). If the machine is to print again, it needs a little longer to return from an energy saving mode than from Ready mode.

For maximum energy savings, we recommend that the default setting for power management is used.

Products that comply with the Energy Star requirement are always energy efficient.

Notes to Users in the State of California (Notes to Users in USA) Region B (mainly North America)

Perchlorate Material - special handling may apply. See: www.dtsc.ca.gov/hazardouswaste/perchlorate

INDEX

A	Destination	212
	Display panel	3
A3/11 × 17 tray unit30, 109	Distributed scan management	19
AC power switch	Document Server10, 16, 72,	81, 82, 99, 10
Address Book	DSM	19
ADF	Duplex	9, 14, 57
ADF's extender	E	
Adjustment Settings for Operators		
Attention light25, 26	E-mail address	
Authentication screen	E-mail destination	
Auto document feeder8	Earth leakage breaker	
Auto Reduce / Enlarge14, 55	Edit Custom Paper	
В	Embedding text information	
Banner sheet tray of multi bypass tray (Tray A) 30	Energy Saver key	
Banner sheet tray of two-tray wide LCT30	Energy saving functions	22
Basic procedure53, 75, 83, 91, 95, 99	ENERGY STAR program	
Beeping pattern	Enter key	
Booklet14	Envelope	.68, 69, 79, 147
Booklet finisher	Environmental advice for users	224
	Error log	185
Bridge unit of two-tray wide LCT30	Error report	185
Buffer pass unit	Exposure glass	24, 5
С	External options	29
Changing the display language 34	F	
Changing the number of sets70	Fanning the paper	100
Check Status key33, 165	File type	
Checking a stored file96	Finisher	
Clear key33	Folder destination	
Combine	Frequently-used settings	
Combine printing77	Front left cover	
Computer	Front lower left cover	
Control panel24, 31	Front right cover	
Copier	Front upper right cover	
Copy orientation59	Function keys	
Copy/Document Server177	· ·	
Counter key32	Н	
Creating a shared folder84	High capacity stacker	8, 29
Custom paper149	Hold Print	
Custom size paper66	Home key	
D	Home screen	13, 35, 213
Data In indicator	How to Read the Manuals	

<u> </u>	0
lcon35, 37, 38	OCR unit17
Indicator165	One-sided combine
Information on environmental regulations221	Options29
Information screen9	Orientation-fixed paper120
Initial settings12	Original orientation57, 59
Interposer	P
Interposer of the perfect binder118	D ::
Interrupt key32	Paper capacity12
L	Paper Setting key
	Paper size
Language key	Paper thickness
LDAP Server	Paper type
Loading cover sheets	PCL 6
Loading paper 105, 107, 109, 110, 112, 114, 115, 117, 120	Perfect binder
Loading tab stock111, 114	Placing originals
Locked Print	Preventing information leakage
Logging in219	Preventing unauthorized copying
Logging in the machine49	Printer 75, 182, 185, 186, 188, 191, 192, 193, 194
Logging out the machine50	Printer driver properties
Login/Logout key32	
,	Program key
<u>M</u>	-
Magazine14	Q
Main power indicator32	Quick Install73
Main power switch23, 47	R
Managing documents82	
Media access lamp33	Recommended paper124
Media slots	Reduce my costs
Message168, 177, 182, 185, 186, 188, 191, 192, 193, 194, 198, 201, 203, 204, 205, 206,	Region A
207, 208, 211, 214, 215, 216, 217, 219	Region B
Model-Specific Information	Registering destinations1
Multi bypass attachment kit30	Reset key
Multi bypass tray (Tray A). 8, 30, 66, 68, 112, 114	Ring binder
Multi-folding unit	Running out of toner158
N ,	S
	Sample Copy key32
Note for the battery and/or accumulator symbol	Sample Print13
Notes to users in the state of California225	Scan Settings99
Number keys	Scan to E-mail9
. tombor koyummumumumumumumumumumumumumumumumumumu	Scan to Folder17, 83

Scanner 83, 91, 95, 198, 201, 203, 204, 205, 206, 207, 211
Screen brightness slider
Searching by what you want to do9
Sending scan files
Shared folder84
Shortcut icon
Simple Screen key32
SMB folder86, 88, 89
Sort
Standard printing75
Start key32
Status icon
Stop key 32
Stored documents
Stored Print15
Storing data72, 99
Storing documents81
Storing scan files95
Symbols6
T
Tab sheet holder8
Three-tray wide large capacity tray8, 114
Three-tray wide LCT
Toner
Top screen35
Tray 124, 107
Tray 224, 110, 111
Trimmer 8, 29
Turning off the power47
Turning on the power47
Two-sided combine63
Two-sided paper120
Two-sided printing76
Two-tray wide large capacity tray 8, 115
Two-tray wide LCT 8, 30
U
Used toner
User certificate217
User Code Authentication49
User information on electrical and electronic equipment

User Tools key
<u>V</u>
Vents
W
Web Image Monitor

MEMO

MEMO

MEMO



