# Pro C651EX/Pro C751EX/Pro C751 Machine Code: D074/D075/M044

# **Field Service Manual**

# Safety, Symbols, Trademarks

### **Conventions**

These manuals cover three machines: M074, M075, and M044.

- The M074 and M075 are the copier versions. They both have the ARDF and scanner unit.
- The MO44 is the printer version. It has neither ARDF nor scanner unit.


The following notations are used in text to indicate were a component, SC code, SP code, etc. apply to a specific machine.

Notation in Text	Meaning
D074	Applies to D074 only
D075	Applies to D075 only
D074/D075	Applies to D074/D074 but not M044
M044	Applies to M044 only


### Symbols Used in Text

Symbol	What it means
\$	Binding screw (shoulder hexagonal head)
8	Binding screw (round flathead)
*	Black screw (heavy, fusing unit, TCRU)
4	Bushing
ℴ	C-ring
E)II	Connector
©	E-ring
	FFC (Flat Film Connector)
	FFC (Flat Film Connector)
•	Gear
2	Harness clamp

Symbol	What it means
₩	Harness clamp (metal: fusing unit)
-	Hook (or tab release)
<b>₽</b>	Knob screw (black)
4/0	Knob screw (sliver)
A	Pivot screw
P	Screw (common screw)
<b>A</b> II	Shoulder screw
galler.	Spring
•	Standoff
<b>₽</b>	Stud screw
F	Tapping screw (for plastic)
0	Timing belt



The notations "SEF" and "LEF" describe the direction of paper feed. The arrows indicate the direction of paper feed.



In this manual "Main Scan" means "Horizontal" and "Sub Scan" means "Vertical", both relative to the direction of paper feed.

# Warnings, Cautions, Notes

In this manual, the following important symbols and notations are used.

### **⚠ WARNING**

• A Warning indicates a potentially hazardous situation. Failure to obey a Warning could result in death or serious injury.

# **ACAUTION**

• A Caution indicates a potentially hazardous situation. Failure to obey a Caution could result in minor or moderate injury or damage to the machine or other property.

# 

 Obey these guidelines to avoid problems such as misfeeds, damage to originals, loss of valuable data and to prevent damage to the machine

# **U** Note

• This information provides tips and advice about how to best service the machine.

# Commonly Used Terms and Abbreviations

Here is a list of commonly used terms and abbreviations that are used throughout the Field Service Manual and Appendices.

Terms	Meaning
(ccw)	Counter-clockwise rotation of a drum, roller, gear, etc.

Terms	Meaning		
(cw)	Clockwise rotation of a drum, roller, gear, etc.		
BW	Black and white (monochrome) copying or printing		
Bank	Paper Bank (1st, 2nd Tray of the main machine)		
CIT	Cover Interposer Tray (D518) (option)		
FC	Full Color copying or printing		
FIN	Finisher (D512/D513) (option)		
HCS	High Capacity Stacker (D515) (option)		
ITB	Image Transfer Belt		
JG	Junction Gate		
LCIT	Large Capacity Input Tray		
LD	Laser Diode (Laser Unit)		
LDB	Laser Diode Board (Laser Unit)		
LE	Leading Edge		
LSDB	Laser Synchronization Detection Board (Laser Unit)		
MFU	Multi Folding Unit (D521) (option)		
MUSIC	Mirror Unit Skew Interval Correction		
PCDU	Photoconductor Development Unit		
PFU	Paper Feed Unit (for Tray 1 and Tray 2: Pickup and feed rollers, sensors, solenoids)		
PTB	Paper Transport Belt		
PTR	Paper Transfer Roller		
PTU	Paper Transfer Unit		
RB	Ring Binder (D519) (option)		
TCRU	Trained Customer Replacement Units		
TE	Trailing Edge		

Terms	Meaning
ТМ	Toner Mark sensors, the three sensors of the ITB sensor array. They detect MUSIC patterns on the ITB. In this manual, these are the ID/MUSIC sensors, but you may see "TM" in the SP mode.
TM/P	"Toner Mark/Photo"-sensor. The "P" refers to the center sensor of the ITB sensor array. In this manual, "ID/MUSIC sensors" is used. However, you may see "TM/P" in the SP mode.
TRM	Trimmer Unit (D520) (option)
VTU	Vertical Transport Unit (paper feed between paper banks and right drawer)
YCMK	Yellow, Cyan, Magenta, blacK

# **General Safety Instructions**


For your safety, please read this manual carefully before you use this product. Keep this manual handy for future reference.

### **Safety Information**

Always obey the following safety precautions when using this product.

#### **Safety During Operation**

In this manual, the following important symbols and notations are used.



#### **Switches and Symbols**

Where symbols are used on or near switches on machines for Europe and other areas, the meaning of each symbol conforms with IEC60417.

### Responsibilities of the Customer Engineer

#### **Customer Engineer**

Maintenance shall be done only by trained customer engineers who have completed service training for the machine and all optional devices designed for use with the machine.

#### Reference Material for Maintenance

- Maintenance shall be done using the special tools and procedures prescribed for maintenance of
  the machine described in the reference materials (service manuals, technical bulletins, operating
  instructions, and safety guidelines for customer engineers).
- Use only consumable supplies and replacement parts designed for use with the machine.

### Before Installation, Maintenance

### Shipping and Moving the Machine

# **ACAUTION**

- Work carefully when lifting or moving the machine. If the machine is heavy, two or more customer
  engineers may be required to prevent injuries (muscle strains, spinal injuries, etc.) or damage to the
  machine if it is dropped or tipped over.
- Personnel moving or working around the machine should always wear proper clothing and footwear. Never wear loose fitting clothing or accessories (neckties, loose sweaters, bracelets, etc.) or casual footwear (slippers, sandals, etc.) when lifting or moving the machine.
- Always unplug the power cord from the power source before you move the machine. Before you
  move the product, arrange the power cord so it will not fall under the machine.

#### **Power**

# **<b>∴** WARNING

- Always disconnect the power plug before doing any maintenance procedure. After switching off
  the machine, power is still supplied to the main machine and other devices. To prevent electrical
  shock, switch the machine off, wait for a few seconds, then unplug the machine from the power
  source.
- Before you do any checks or adjustments after turning the machine off, work carefully to avoid injury. After removing covers or opening the machine to do checks or adjustments, never touch electrical components or moving parts (gears, timing belts, etc.).

 After turning the machine on with any cover removed, keep your hands away from electrical components and moving parts. Never touch the cover of the fusing unit, gears, timing belts, etc.

### Installation, Disassembly, and Adjustments

# **CAUTION**

- After installation, maintenance, or adjustment, always check the operation of the machine to make sure that it is operating normally. This ensures that all shipping materials, protective materials, wires and tags, metal brackets, etc., removed for installation, have been removed and that no tools remain inside the machine. This also ensures that all release interlock switches have been restored to normal operation.
- Never use your fingers to check moving parts causing spurious noise. Never use your fingers to lubricate moving parts while the machine is operating.

#### **Special Tools**

# **ACAUTION**

- Use only standard tools approved for machine maintenance.
- For special adjustments, use only the special tools and lubricants described in the service manual.
   Using tools incorrectly, or using tools that could damage parts, could damage the machine or cause injuries.

# **During Maintenance**

#### General

# **ACAUTION**

- Before you begin a maintenance procedure: 1) Switch the machine off, 2) Disconnect the power plug from the power source, 3) Allow the machine to cool for at least 10 minutes.
- Avoid touching the components inside the machine that are labeled as hot surfaces.

#### Safety Devices

# **MARNING**

- Never remove any safety device unless it requires replacement. Always replace safety devices immediately.
- Never do any procedure that defeats the function of any safety device. Modification or removal of
  a safety device (fuse, switch, etc.) could lead to a fire and personal injury. Always test the

- operation of the machine to ensure that it is operating normally and safely after removal and replacement of any safety device.
- For replacements use only the correct fuses or circuit breakers rated for use with the machine. Using
  replacement devices not designed for use with the machine could lead to a fire and personal
  injuries.

#### **Organic Cleaners**

# **CAUTION**

- During preventive maintenance, never use any organic cleaners (alcohol, etc.) other than those
  described in the service manual.
- Make sure the room is well ventilated before using any organic cleaner. Use organic solvents in small amounts to avoid breathing the fumes and becoming nauseous.
- Switch the machine off, unplug it, and allow it to cool before doing preventive maintenance. To avoid fire or explosion, never use an organic cleaner near any part that generates heat.
- Wash your hands thoroughly after cleaning parts with an organic cleaner to prevent contamination of food, drinks, etc. which could cause illness.
- Clean the floor completely after accidental spillage to prevent slippery surfaces that could cause accidents leading to hand or leg injuries. Use dry rags to soak up spills.

#### Lithium Batteries

# **MARNING**

- Always replace a lithium battery on a PCB with the same type of battery prescribed for use on that board. Replacing a lithium battery with any type other than the one prescribed for use on the board could lead to an explosion or damage to the PCB.
- Never discard used batteries by mixing them with other trash. Remove them from the work site and dispose of them in accordance with local laws and regulations regarding the disposal of such items.

#### **Ozone Filters**

# **ACAUTION**

- Always replace ozone filters as soon as their service life expires (as described in the service manual).
- An excessive amount of ozone can build up around machines that use ozone filters if they are not replaced at the prescribed time. Excessive ozone could cause personnel working around the machine to feel unwell.

 To avoid possible accumulation of ozone in the work area, locate the machine in a large well ventilated room that has an air turnover rate of more than 50 m<sup>3</sup>/hr/person.

#### **Power Plug and Power Cord**

# **WARNING**

- Before servicing the machine (especially when responding to a service call), always make sure that
  the power plug has been inserted completely into the power source. A partially inserted plug could
  lead to heat generation (due to a power surge caused by high resistance) and cause a fire or other
  problems.
- Always check the power plug and make sure that it is free of dust and lint. Clean it if necessary. A
  dirty plug can generate heat which could cause a fire.
- Inspect the length of the power cord for cuts or other damage. Replace the power cord if necessary. A frayed or otherwise damaged power cord can cause a short circuit which could lead to a fire or personal injury from electrical shock.
- Check the length of the power cord between the machine and power supply. Make sure the power cord is not coiled or wrapped around any object such as a table leg. Coiling the power cord can cause excessive heat to build up and could cause a fire.
- Make sure that the area around the power source is free of obstacles so the power cord can be removed quickly in case of an emergency.
- Make sure that the power cord is grounded (earthed) at the power source with the ground wire on the plug.
- Connect the power cord directly into the power source. Never use an extension cord.
- When you disconnect the power plug from the power source, always pull on the plug, not the cable.

# After Installation, Servicing

#### Disposal of Used Items

# **⚠** WARNING

- Never incinerate used toner or toner cartridges.
- Toner or toner cartridges thrown into a fire can ignite or explode and cause serious injury. At the
  work site always carefully wrap used toner and toner cartridges with plastic bags to avoid spillage
  before disposal or removal.

# **CAUTION**

- Always dispose of used items (developer, toner, toner cartridges, OPC drums, etc.) in accordance
  with the local laws and regulations regarding the disposal of such items.
- To protect the environment, never dispose of this product or any kind of waste from consumables at a household waste collection point. Dispose of these items at one of our dealers or at an authorized collection site.
- Return used drums to the service center for handling in accordance with company policy regarding the recycling or disposal of such items.

# **ACAUTION**

- The development unit cooling system circulates propylene glycol from a sealed tank through hoses that pass behind cooling plates on the sides of each development unit.
- The coolant tank is located at the bottom of the cooling box on the back of the main machine.
- Always obey local laws and regulations if you need to dispose of a tank or the propylene glycol coolant.
- The tank must never be emptied directly into a local drainage system, river, pond, or lake.
- Contact a professional industrial waste disposal organization and ask them to dispose of the tank.

### **Points to Confirm with Operators**

At the end of installation or a service call, instruct the user about use of the machine. Emphasize the following points.

- Show operators how to remove jammed paper and troubleshoot other minor problems by following the procedures described in the operating instructions.
- Point out the parts inside the machine that they should never touch or attempt to remove.
- Confirm that operators know how to store and dispose of consumables.
- Make sure that all operators have access to an operating instruction manual for the machine.
- Confirm that operators have read and understand all the safety instructions described in the
  operating instructions.
- Demonstrate how to turn off the power and disconnect the power plug (by pulling the plug, not the cord) if any of the following events occur: 1) something has spilled into the product, 2) service or repair of the product is necessary, 3) the product cover has been damaged.
- Caution operators about removing paper fasteners around the machine. They should never allow paper clips, staples, or any other small metallic objects to fall into the machine.

### **Special Safety Instructions for Toner**

### **Accidental Physical Exposure**

# **ACAUTION**

- Work carefully when removing paper jams or replacing toner bottles or cartridges to avoid spilling toner on clothing or the hands.
- If toner is inhaled, immediately gargle with large amounts of cold water and move to a well ventilated location. If there are signs of irritation or other problems, seek medical attention.
- If toner gets on the skin, wash immediately with soap and cold running water.
- If toner gets into the eyes, flush the eyes with cold running water or eye wash. If there are signs of irritation or other problems, seek medical attention.
- If toner is swallowed, drink a large amount of cold water to dilute the ingested toner. If there are signs of any problem, seek medical attention.
- If toner spills on clothing, wash the affected area immediately with soap and cold water. Never use hot water! Hot water can cause toner to set and permanently stain fabric.

#### **Handling and Storing Toner**

# **⚠WARNING**

- Toner, used toner, and developer are extremely flammable.
- Never store toner, developer, toner cartridges, or toner bottles (including empty toner bottles or cartridges) in a location where they will be exposed to high temperature or an open flame.

# **ACAUTION**

- Always store toner and developer supplies such as toner and developer packages, cartridges, and bottles (including used toner and empty bottles and cartridges) out of the reach of children.
- Always store fresh toner supplies or empty bottles or cartridges in a cool, dry location that is not exposed to direct sunlight.

### **Toner Disposal**

# **MARNING**

- Never attempt to incinerate toner, used toner, or empty toner containers (bottles or cartridges). Burning toner can explode and scatter, causing serious burns.
- Always wrap used toner and empty toner bottles and cartridges in plastic bags to avoid spillage.
   Follow the local laws and regulations regarding the disposal of such items.

Dispose of used toner and toner cartridges at one of our dealers or at an authorized collection site.
 Always dispose of used toner cartridges and toner bottles in accordance with the local laws and regulations regarding the disposal of such items.

# Safety Instructions for the Machine

#### Prevention of Physical Injury

- 1. Before disassembling or assembling parts of the machine and peripherals, make sure that the machine and peripheral power cords are unplugged.
- 2. The plug should be near the machine and easily accessible.
- 3. Note that some components of the machine and the paper tray unit are supplied with electrical voltage even if the main power switch is turned off.
- 4. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
- 5. If the [Start] key is pressed before the machine completes the warm-up period (the [Start] key starts blinking red and green), keep hands away from the mechanical and the electrical components, because the machine starts making copies as soon as the warm-up period is completed.
- 6. The inside and the metal parts of the fusing unit become extremely hot while the machine is operating. Be careful to avoid touching those components with your bare hands.

# **⚠ WARNING**

 To avoid the danger of fire or explosion, keep the machine away from flammable liquids, gases, and aerosols.

# **Health Safety Conditions**

- 1. Never operate the machine without the ozone filters installed.
- 2. Always replace the ozone filters with the specified types at the proper intervals.
- 3. To avoid possible accumulation of ozone in the work area, locate the machine in a large well ventilated room that has an air turnover rate of more than 30m<sup>3</sup>/hr/person.
- 4. Toner and developer are non-toxic, but if you get either of them in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

#### Observance of Electrical Safety Standards

1. The machine and its peripherals must be installed and maintained by a customer service representative who has completed the training course on those models.

2. The NVRAM on the system control board has a lithium battery which can explode if replaced incorrectly. Replace the NVRAM only with an identical one. The manufacturer recommends replacing the entire NVRAM. Do not recharge or burn this battery. Used NVRAM must be handled in accordance with local regulations.

#### Safety and Ecological Notes for Disposal

- 1. Never incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.
- 2. Dispose of used toner, developer, and organic photoconductors in accordance with local regulations. (These are non-toxic supplies.)
- 3. Dispose of replaced parts in accordance with local regulations.
- 4. When keeping used lithium batteries in order to dispose of them later, do not put more than 100 batteries per sealed box. Storing larger numbers or not sealing them apart may lead to chemical reactions and heat build-up.

# **ACAUTION**

- The danger of explosion exists if a battery of this type is incorrectly replaced.
- Replace only with the same or an equivalent type recommended by the manufacturer. Discard used batteries in accordance with the manufacturer's instructions.

#### Laser Safety



d074c004

- 1. The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field.
- 2. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment.
- 3. The laser subsystem is replaceable in the field by a qualified Customer Engineer.
- 4. The laser chassis is not repairable in the field.
- 5. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

# **WARNING**

- Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.
- Turn off the main switch before attempting any of the procedures in the Laser Unit section. Laser beams can seriously damage your eyes.

# Safety Instructions for the Fiery Controller

#### **Fuse**

### **CAUTION**

The Fiery controller uses a double pole fuse. If this fuse blows, be sure to replace it with an identical
fuse.

#### **Batteries**

- Always replace a battery with the same type of battery prescribed for use with the Fiery controller unit. Replacing a battery with any type other than the one prescribed for use could cause an explosion.
- Never discard used batteries by mixing them with other batteries or other refuse.
- Always remove used batteries from the work site and dispose of them in accordance with local laws and regulations regarding the disposal of such items.

#### Trademarks

- Microsoft<sup>®</sup>, and Windows<sup>®</sup> are registered trademarks of Microsoft Corporation in the United States and /or other countries.
- PostScript<sup>®</sup> is a registered trademark of Adobe Systems, Incorporated.
- $\bullet \;\; \mathsf{PCL}^{\circledR}$  is a registered trademark of Hewlett-Packard Company.
- Ethernet<sup>®</sup> is a registered trademark of Xerox Corporation.
- PowerPC® is a registered trademark of International Business Machines Corporation.
- Fiery is a registered trademark of Electronics for Imaging (EFI), Inc.
- Other product names used herein are for identification purposes only and may be trademarks of their respective companies. We disclaim any and all rights involved with those marks.

# **New Features**

# Main Machines


#### **Model Numbers and Names**

The "Production No." numbers in the 2nd column of the table below are used exclusively in the manuals to refer to different machines. The names in the 1st and 3rd columns are not used in the service manuals.

Production Name	Production No.	Model Name
Taurus C1a (65 ppm)	D074	Pro C651EX
Taurus C1b (75 ppm)	D075	Pro C751EX
Taurus P1 (75 ppm)	M044	Pro C751

#### **Base Machine**

### D074/D075




No.	Copier D074 (65 ppm)/D075 (75 ppm)	
(1)	ARDF	
(2)	Touch-panel operation with LCD (SVGA)	
(3)	Attention light (standard), no installation required.	

15

No.	Copier D074 (65 ppm)/D075 (75 ppm)
(4)	1 st Tray, tandem tray, fixed size A4 (or LT) 1000 + 1000 sheets (80 g/m²)
(5)	2nd Tray, universal cassette, 500 sheets (80 g/m²)


# M044



(1)	Touch-panel operation with LCD (SVGA)
(2)	Attention light (standard), no installation required.
(3)	1 st Tray, tandem tray, fixed size A4 (or LT) 1000 + 1000 sheets (80 g/m²)
(4)	2nd Tray, universal cassette, 500 sheets (80 g/m²)

# **Base Configuration**

# D074/D075




d074f902

No.	Paper Source	Paper Capacity	Total
(1)	Main 1st Tray	1000 + 1000	2000
(2)	Main 2nd Tray	500	500
(3)	LCIT 1 st Tray	1000	1000
(4)	LCIT 2nd Tray	2000	2000
(5)	LCIT 3rd Tray	1000	1000
(6)	Bypass Tray	500	500
		Total (80g/m²)	7000

- Only one LCIT is available
- Two finisher models are available: The D512 which performs corner stapling and booklet stapling, and the D513 which performs corner stapling only.
- The finisher (7) in the illustration above is the Booklet Finisher D512.

#### M044




m044f902

No.	Paper Source	Paper Capacity	Total
(1)	Main 1st Tray	1000 + 1000	2000
(2)	Main 2nd Tray	500	500
(3)	LCIT 1 st Tray	1000	1000
(4)	LCIT 2nd Tray	2000	2000
(5)	LCIT 3rd Tray	1000	1000
(6)	Bypass Tray	500	500
		Total (80g/m²)	7000

- Only one LCIT is available.
- Two finisher models are available: The D512 which performs corner stapling and booklet stapling, and the D513 which performs corner stapling only.
- $\bullet~$  The finisher (7) in the illustration above is the Booklet Finisher D512 .

# **Full System**

### D074/D075



No.	Unit	Comment
(1)	Main machine D074/D075	Copier
(2)	Decurler Unit (D544)	Inside the left side of the main machine.
(3)	ARDF	Feeds originals for copying
(4)	Multi Bypass Tray (D517)	Requires LCIT
(5)	A3/DLT LCIT (D516)	Only one LCIT available
(6)	Buffer Pass Unit (D548)	Not shown. This is a cooling unit, recommended for use with the Multi Folding Unit.
(7)	Cover Interposer Tray (D518)	Feeds covers from two trays
(8)	Multi Folding Unit (D521)	Straight through, or 6 types of folds
(9)	Ring Binder (D519)	Ring binding with 50/100 sheet plastic rings
(10)	High Capacity Stacker (D515)	Stacking capacity: 2500 to 5000 sheets
(11)	Finisher (D512)	Corner/booklet stapling
(12)	Trimmer Unit (D520)	Automatically trims edges of booklets


- The illustration above does not show the Buffer Pass Unit and the Decurler Unit.
- A later section ("Main Machine and Peripherals") gives more information about system peripherals and configurations.
- The two tone color scheme, dark and light gray, with rounded corners and soft lines are distinctive features of these machines.



d074f905

• Most screws are recessed or hidden with easily removed plastic covers to enhance the overall smooth appearance of the main machine and peripheral units.

### M044



No.	Unit	Comment
(1)	Main machine M044	Printer
(2)	Decurler Unit (D544)	Inside the left side of the main machine.
(3)	A3/DLT LCIT (D516)	Only one LCIT available
(4)	Multi Bypass Tray (D517)	Requires LCIT
(5)	Buffer Pass Unit (D548)	Not shown. This is a cooling unit, recommended for use with the Multi Folding Unit.
(6)	Cover Interposer Tray (D518)	Feeds covers from two trays
(7)	Multi Folding Unit (D521)	Straight through, or 6 types of folds
(8)	Ring Binder (D519)	Ring binding with 50/100 sheet plastic rings
(9)	High Capacity Stacker (D515)	Stacking capacity: 2500 to 5000 sheets
(10)	Finisher (D512)	Corner/booklet stapling

No.	Unit	Comment
(11)	Trimmer Unit (D520)	Automatically trims edges of booklets

- A later section ("Main Machine and Peripherals") gives more information about system peripherals
  and configurations.
- The two tone color scheme, dark and light gray, with rounded corners and soft lines is a distinctive features of this machine.




d074f905

 Most screws are recessed or hidden with easily removed plastic covers to enhance the overall smooth appearance of the main machine and peripheral units.

#### **New Features**

#### **New Toner**



This machine uses new toner (SPR-Ce $\gamma$ ). This toner is an extremely fine oil-less chemical toner of uniform particle size. This enables a smoother toner surface after fusing, and good adhesion to thick paper. A grain of toner, approximately 5  $\mu$ m in diameter, is comprised of [1] wax, [2] polyester resin, and [3] colorant.

- This new toner has a low melting point. Less energy is consumed by the fusing unit and image
  quality is improved.
- No lubrication oil is required in the fusing unit.

 The new toner also allows printing on a wider range of media, including cotton and linen texture paper.

### Thicker Print Media

The machine automatically adjusts the printing speed for heavy stock paper (paper thicker than 220  $g/m^2$ ). The printing speed can be slowed down by as much as 30% for some types of thick paper.

#### **Better Paper Folding**

The optional Multi Folding Unit can be used with this machine. It can fold paper in the range 64 to  $105 \text{ g/m}^2$ , including coated paper. Multiple page folding with up to three sheets can be done with paper in the range 64 to  $80 \text{ g/m}^2$ . The Multi Folding Unit performs six types of folds, including Z-folding.

#### Wide Range of Peripheral Units

The lineup of main peripheral units available for this machine includes:

- Decurl Unit
- A3/DLT LCIT
- Buffer Pass Unit
- · Multi Bypass Tray
- Cover Interposer Tray
- · Multi Folding Unit
- Ring Binder
- High Capacity Stacker
- Finisher
- Trimmer Unit

These peripheral units are available with earlier machines. However, for this machine they have rounded covers to match those of the main machine, and some of them have been modified slightly to improve their performance. (\*\*\* p.57\*)

#### Fiery Base Controller



The base controller of this machine is the Fiery standard controller [1] (Color Controller E-41A), with FACI [2] available as an option. (The FACI Kit allows the operator to manage jobs more efficiently near the machine.)

- Although this machine also has the GW controller, there are no GW printer applications. All
  printing features are provided by the Fiery E-41A external controller.
- The D074/D075 is equipped with both GW and Fiery scanner functions. Both features are available at any time when the GW and Fiery controllers are connected via the same network.
- However, @Remote can acquire only a limited amount of information via the Fiery controller network port. For full functionality with @Remote, the system must be connected via the GW controller network as well. (This means the machine needs two IP addresses for full function support with @Remote.)

#### **GW Controller**

The Data Overwrite Security and Data Encryption applications will be provided together from the factory on one SD card. The machine will be shipped with this SD card in Slot 1 (application slot).

#### New Drum Design

The drums have been enhanced to improve performance and lengthen service life (1200K for the D074 and 1350 K for the D075/M044). The external layer of the drum is composed of durable material that is resistant to wear. Its electrostatic properties have also been improved to promote stable charging during long print jobs.

#### Single Direction Development

The development unit uses "trickle developing" where toner in each toner bottle is pre-mixed with a small amount of developer. In the single-direction development system, the function of the development auger is split between a development auger and a recovery auger. The recovery auger collects developer of reduced characteristics to prevent its re-use. Recovered developer is delivered to the agitator auger directly. This system prevents density fluctuation during high color coverage and large volume printing.

#### **Drum Drive Control**




d074f913

This machine uses a continuous feedback system to adjust the rotation speed of each drum motor. A drum drive sensor mounted on the drive shaft and inside the motor casing [1] of the development motor monitors fluctuation in drum speed and feeds this information back to the machine. The machine adjusts

for any deviation from the prescribed speed to maintain the correct drum speed. This system minimizes color registration errors. This motor casing should never be disassembled.


#### **Decurl Unit**



d074f914

A decurl unit (available as an option) fits compactly into the left side of the main machine. The decurl unit has no purge tray (the purge tray is built into the main machine). The decurl unit is designed to correct both convex and concave curling, a common problem with thin paper, and prints with high toner coverage. The decurl unit has two paper paths. The lower paper path [1] corrects face curling (concave curling), and the upper path [2] corrects back curling (convex curling). The decurl unit is raised and lowered with an operator setting to select the paper path, depending on which type of correction is needed.


#### Improved Fusing



d074f915

The fusing unit is compact. Although the fusing unit is relatively light at 17 kg (37 lb.), it is capable of exerting enough pressure for printing on thick and heavily textured paper. The fusing unit can be lifted and carried easily by one service technician. The fusing unit has a web cleaning mechanism to clean the fusing belt.. There is no oil lubrication system for the fusing belt.

#### Improved Paper Path



To support printing on  $300 \text{ g/m}^2$  paper and duplex printing on paper up to  $256 \text{ g/m}^2$ , the arcs in the curvature of the paper path are wider at three critical turning points:

- [1] Paper feed (2nd tray, 1st tray, and duplex path junction where these paths merge)
- [2] Paper entrance from LCIT and paper registration
- [3] Inverter/duplex path. The number of shift rollers has been increased from two to four to accommodate postcards and large-size thick paper.

#### **Purge Tray**




d074f926

After a jam occurs, paper in the paper path that has not yet exited the main machine is shunted to the purge tray on the left side of the main machine. This eliminates the time consuming task of searching for every sheet remaining in the main machine or LCIT after a jam occurs downstream. The operator can remove the paper at the jam point as instructed and then collect other sheets from the purge tray by opening the left front door. The purge tray is behind the left front door and next to the used toner bottle.

#### New ITB/PTR Separation Mechanism

There is a new motor in the ITB unit that functions as a PTR separation mechanism.



When the right drawer is closed, a strong spring below the PTR unit rotates two cams up that lock the PTR [1] in the up position against the bias roller [2] of the ITB unit above.

The ITB [3] and paper pass between the bias roller above and PTR below.

The bias roller rotates freely around the cam shaft [4]. When the PTR separation motor [5] turns on, the belt [6] turns the cam shaft counter-clockwise until the actuator [7] of the PTR separation sensor [8] rotates out of the sensor gap (this stops the motor). At this point, the front [9] and rear [10] cams are pushing down on the front [11] and rear [12] collars of the PTR. This separates the PTR from the bias roller. When the machine switches on the separation motor again, it rotates the cam shaft and cams clockwise and up. This releases the pressure of the cams on the PTR below, and the PTR and bias roller come together.

The cams are rotated down to separate the bias roller and the PTR at the following times:

- Ready mode. After the machine enters Ready mode. This keeps the PTR separated from the bias
  roller. If the rollers were to remain in contact while the machine is idle, the hard surface of the PTR
  would deform the shape of the soft bias roller.
- Thick Paper. Just before thick paper enters the nip of the bias roller and PTR, the cams are rotated down briefly to widen the nip for the thicker paper, and then rotated up again to close the nip. This action eliminates "shock jitter" which can occur when the leading edge of thick paper enters a narrow nip.
- Belt Lubrication Mode. The cams are rotated down to open the nip for lubrication of the belt after the ITB has been replaced, for example.

The cams remain up and the rollers pressed together in all other cases, for color and monochrome printing, process control, and MUSIC adjustments, and so on. This mechanism is unique in that the mechanism that separates the rollers has been moved from the PTR unit to the ITB unit. The PTR separation motor, PTR separation sensor, and cam shaft are in the ITB unit. The PTR separation motor

and separation sensor are on the front of the ITB unit. In previous machines, this mechanism consisted of a PTR lift motor in the PTR unit below the ITB unit.

#### Ease of Use

#### **Paper Library**

The Paper Library presents paper settings that can be set up easily and then saved as profiles for future use. For more about this feature, please refer to the Operation Instructions.

#### **Operation Panel**



d074f968

The operation panel features an easy-to-access design with a 10.4 inch LCD and touch-panel. The tilt and angle of the operation panel can be easily adjusted by the operator to reduce glare on the LCD. The standard position of the operation panel can be extended and tilted down so that the machine can be operated with the operator seated. This special adjustment must be done by a service technician.

#### **Toner Bottles**




d074f927

The toner bottles are designed for easy handling and replacement. The large knob handles on the ends of the toner bottles make them easy to grip for removal. They can be replaced by the operator from a seated position.

# **Maximized Operation Time**

### **Active Tray Indicators**



All five paper trays, the two trays of the main machine [1] and three trays of the LCIT [2], have LEDs that light and remain on while the tray is feeding paper. This alerts the operator about which tray is being used. If an indicator is on, the tray cannot be opened as long as paper is feeding from that tray. The operators can re-fill any tray that is not in use while the machine is printing.

#### Attention Light




To minimize down time in a high-volume printing environment, the attention light alerts operators immediately when a problem occurs so they can respond quickly. The attention light is slightly higher, making it easier to see from any direction. The attention light is standard (not an option).

#### TCRU (Trained Customer Replaceable Units)

The TCRU system is designed to allow trained operators to replace key components of the machine that are designated as "TCRU units" without the assistance of a service technician. This greatly reduces down time if a key component requires replacement. A total of eight units can be replaced by TCRU trained operators:

- Drum cleaning unit (PCDU)
- OPC Drum (PCDU)
- Charge roller unit (PCDU)
- Fusing unit
- · Fusing cleaning unit
- Paper transfer roller unit
- ITB cleaning unit
- Paper feed roller sets (two sets, one for each tray of the main machine, three sets, one for the each tray of the LCIT, and one set for the bypass tray on top of the LCIT)

#### Liquid Cooling System



d074f922

In addition to the air cooling ducts and fans, this machine is equipped with a liquid cooling system that keeps the temperature of the developer in the PCDUs at the correct level for optimum performance. Liquid coolant is pumped from a tank [1] and circulated across the cooling jackets of each development


unit through two hoses [2]. The coolant keeps the toner/developer at optimum temperature. This system has two advantages over a circulating air cooling system.

- First, the liquid cooling system requires much less space.
- Second, the liquid cooling system maximizes operation time because the machine does not need to
  halt operation temporarily for a PCDU to cool if temperature exceeds the upper limit.

The liquid cooling unit is a robust design. Its tubing is guaranteed for 20 years of use at 70°C (158°F). Rate of evaporation of coolant:

- 150 cc/7 years at 32°C (90°F) running 24 hours/day with FC duplexing.
- 86 cc/7 years at 25°C (77°F) running 24 hours/day with FC duplexing.


#### Non-Interruptive Toner Replenishment



d074f923

An empty toner bottle [1] can be replaced while the machine is printing. After the machine signals toner end for a bottle, there is still enough toner in the sub hopper [2] for the machine to print 480 sheets (A4 LT @ 5% coverage). The gives the operator sufficient time to replace an empty bottle without shutting down the machine.

#### Non-Interruptive Used Toner Bottle Replacement



d074f924

After the used toner bottle [1] becomes full, it can be removed and replaced with an empty bottle while the machine is operating. The reservoir [2] above the bottle can continue to receive and hold used toner while the bottle is out of the machine. (A spring loaded stopper tightly seals the toner port between the reservoir and bottle when the bottle is removed.) The bottle replacement is done by the service technician (or operator if an empty toner bottle is available). However, the service technician must remove the full bottle and empty it at the service center. A full toner bottle will not be emptied at the work site.

#### @Remote

This machine supports @Remote. Both the embedded @Remote function (Cumin) or external device (such as Basil) are available for this machine. Either can be enabled (or installed) at the work site. @Remote monitors information about the machine and relays this data (counters, supply levels, device status, device failures, etc.) via the @Remote Gateway to a remote service center. This information is used to optimize servicing.

#### Other New Features

#### Laser Unit

The skew motor in the laser unit adjusts the position of the mirrors to correct color registration. This is a new motor. In previous machines, a small motor attached to the BTL did this adjustment. The new VCSEL technology also improves mechanical performance by reducing the number of revolutions of the polygon motors. This extends the service life of the motors and also reduces motor noise.

Only two SP settings are required after a laser unit is replaced. There are no service parts inside the laser unit. If a problem occurs in the field, the laser unit is replaced.

#### **Process Control**


New toner control technology samples MUSIC patterns rapidly at specified intervals. Increasing the number of samples from the patterns ensures even density in filled areas. (In previous machines, patterns were sampled during process control after each printed sheet.)

#### **New Boards**



d074r786

• TDRB (Transfer Drive Relay Board) [A]. This is a new board located in the center of the ITB unit that controls operation of the ITB components.



d074r787

• TDCU. (Transfer Drive Control Unit) [A]. Located on the back of the machine, controls operation of the fusing motor, drum motors, development motor, PTR motor, and transfer timing motor. Also controls the following via the TDRB: ITB sensor, ITU set sensor, and ITB motor.



d074r788

• Power Packs. Three power packs for processes around the drum are arranged across the back of the machine for easier access: (1) CB Power Pack (CK) [charge and development bias for C and K], (2) Potential Sensor Power pack (x4 one above each drum), and (3) CB Power Pack (YM) [charge and development bias for Y and M].



d074r785

• IOB [A]/BCU [B]. The BCU is mounted behind the IOB. The IOB swings down so that the BCU can be checked and serviced without removing the IOB.

#### **New Sensor**



d074r789

• 2nd Tray Motor Sensor. In the ITB unit, in addition to the 2nd tray lift motor sensor 1 ① (above the 2nd tray lift motor), a 2nd Lift Motor (K) Sensor 2 ② has been added at the rear right corner of the ITB unit.

# **TABLE OF CONTENTS**

Safety, Symbols, Trademarks	1
Conventions	1
Warnings, Cautions, Notes	3
Commonly Used Terms and Abbreviations	3
General Safety Instructions	5
Responsibilities of the Customer Engineer	6
Before Installation, Maintenance	6
During Maintenance	7
After Installation, Servicing	9
Special Safety Instructions for Toner	11
Safety Instructions for the Machine	12
Safety Instructions for the Fiery Controller	14
Trademarks	14
New Features	15
Main Machines	15
Full System	19
New Features	21
1. Product Information	
Specifications	51
Main Machine and Peripherals	52
Main Peripherals	52
Other Options (Not Shown Above)	55
Guidance for Those Who Are Familiar with Predecessor Products	57
Main Machine Specifications	57
Peripherals	67
Overview	83
Machine Layout	83
Paper Paths	85
Main Motors	87
2. Installation	
Installation Requirements	91
Operating Environment	91
Power Requirements	92

Machine Level	93
Space Requirements	94
Switching the System On/Off	97
Main Machine	99
Accessories	99
Installation Flow	100
Installation: Power Off	101
Installation: Power On	129
Fiery Controller Connection and Setup	130
Fiery Controller Setup	133
Paper Library Data Installation	137
Paper Trays	138
Printing an SMC Report	139
Test Color Print (D074/D075)	139
ACC Adjustment (D074/D075)	140
MUSIC Color Registration Adjustment	142
Checking the Print Quality	143
TCRU Setting	160
Tray Heaters	161
Moving the Machine	162
A3/11"x17" Tray Unit (B331-14)	175
Accessories	175
Installation	175
Decurler Unit (D544)	180
Accessories	180
Installation	181
Curl Correction	192
A3/DLT LCIT (D516)	194
Accessories	194
Installation	195
LCIT (D516) Tray Heaters	210
Multi Bypass Tray (D517)	216
Accessories	216

Installation	216
Buffer Pass Unit Type 5010 (D548)	234
Accessory Check	234
Installation	235
Cover Interposer Tray (D518)	245
Accessories	245
Installation	246
Multi Folding Unit (D521)	256
Accessories	256
Installation	257
Ring Binder (D519)	266
Accessories	266
Before You Begin	267
Installation Procedure	268
Centering Paper in the Paper Path	275
After Installation	280
High Capacity Stacker (D515)	282
Accessories	282
Installation	283
Finishers (D512/D513)	294
Accessories	294
Installation	295
Punch Unit PU5020 NA, EU, SC (D449-17, -27, -28)	305
Installation	306
Trimmer Unit (D520)	315
Accessories	315
Installation	316
Common Adjustments	322
Height and Level Adjustment	322
Skew and Side-to-Side Registration	324
GW Controller Options	335
Overview	335
VM Card Type R (D554) D074/D075	337

# 3. Preventive Maintenance

PM Counter Display	339
Opening the PM Counter	339
PM Parts Screen Details	340
PM Tables for Main Machines	343
PM Parts List Key	343
Optics (D074/D075)	343
Development	344
Around the Drum	344
Image Transfer Unit	346
Paper Transfer Unit	346
Fusing Unit	347
Filters	348
Main Paper Feed	348
Main Paper Transport	349
Inverter, Exit	350
Duplexer	351
ARDF (D074/D075)	351
PM Tables for Peripherals	355
LCIT (D516)	355
Multi-Bypass Tray (D517)	356
Decurler Unit (D544)	356
Cover Interposer Tray (D518)	356
Multi-Folding Unit (D521)	357
Ring Binder (D519)	357
High Capacity Stacker (D515)	358
Booklet Finisher (D512/D513)	359
Trimmer Unit (D520)	360
Lubrication Points	361
Fusing Unit Main Drive Gears	361
Cleaning, Lubrication Around Fusing Unit Heating Roller	361
Cleaning and Lubrication Around Pressure Roller	363
Lubrication Around Hot Roller	365

Cleaning Points	367
Overview	367
Inspection and Cleaning	367
4. Replacement and Adjustments	
General Cautions	393
Rear Boxes	393
Drum	393
PCDU	394
ITB Unit	394
Scanner Unit (D074/D075)	395
Laser Unit	395
Development	395
Cleaning	396
Fusing Unit	396
Paper Feed	396
Used Toner	396
Fiery Controller	396
Liquid Coolant Disposal	397
Special Tools and Lubricants	398
Special Tools	398
Lubricants	398
Common Procedures	399
Turning the Machine On/Off	399
Opening the Rear Boxes	400
Removing Doors, Covers	401
Pulling Out and Closing the Left Drawer	407
Removing the Right Drawer	408
Pulling Out the ITB Unit	410
Removing the Canopy Cover	415
Removing PCDUs	426
Removing the ITB Cleaning Unit	430
Removing the PTR Unit	432
Removing the Fusing Unit, Fusing Cleaning Unit, Covers	433

Removing the PTB Unit	438
Removing the Left Drawer	440
Removing the Paper Feed Units (PFU)	441
Removing the Vertical Transport Unit (VTU)	444
Operation Panel	452
Changing the Operation Panel Position	452
Operation Panel PCBs, Touch Panel Unit	456
Touch Panel Position Adjustment	460
ARDF	461
ARDF Covers	461
Original Feed Unit	463
Feed Belt, Pickup Roller	464
Bottom Plate Position Sensor	465
Interval, Original Width, Skew Correction Separation Sensors	466
Original Length Sensors	467
Cover Open, Original Set, Bottom Plate, Pickup Roller HP, Feed-Out Sensors	468
ARDF Position Sensor, APS Start Sensor	469
Original Registration Sensor Exit Sensors	470
ARDF Separation Roller	471
ARDF Transport Belt	472
ARDF Control Board	477
ARDF Bottom Plate Lift Motor	478
ARDF Feed Motor, ARDF Transport Motor	478
ARDF Pick-up Roller Lift Motor	479
Scanner Unit	480
Exposure Glass	480
Right, Left Plate Covers	481
Lens Block, Paper Size Sensors	483
Exposure Lamp	484
Scanner Motor	485
Scanner HP Sensor	486
Scanner Interface Board (SIOB)	486
Scanner Wire	487

Scanner Unit Cooling Fan	488
Lamp Regulator Board and Fan	489
Wire Re-installation, Scanner Position Adjustment	493
Laser Unit	495
Laser Units	495
YM Laser Unit Removal: D074/D075	495
YM Laser Unit Removal: M044	505
Removing the CK Laser Unit: D074/D075/M044	508
Toner Shield Glass	515
Toner Supply	517
Toner Bottle Port Cleaning	517
Toner Supply Unit Removal	518
Toner Supply Clutch	524
Toner Pump Clutch	526
Toner End Sensor	527
RFID Boards, RFID CPU	528
Toner Bottle Motors	530
Toner Supply Motor	534
Used Toner Collection	536
Used Toner Bottle	536
Used Toner Transport Motor, Sensor, Timing Belt	537
Used Toner Bottle Motor	540
Used Toner Bottle Sensors, Bottle Set Switch	542
Photoconductor Development Unit (PCDU)	547
PCDU Replacement	547
Vent Filter	550
Drum Charge Unit	551
Drum Cleaning Unit	552
Drum Replacement	553
Development Unit Replacement	558
Replacing Developer	559
PCDU Parts Replacement	567
Drum Cleaning Unit Gears	569

Drum Cleaning Blade	570
Drum Lubrication Blade	573
Drum Lubrication Bar	575
Drum Lubrication Roller	577
Drum Cleaning Motors, Development Motors, Drum Motors	579
Liquid Cooling Unit	583
Drum Cooling Unit Fan Replacement	585
Charge Roller Cleaning Roller Solenoids	586
Potential Sensors (YMCK)	588
TD Sensor	590
Image Transfer Belt (ITB) Unit	592
ITB Cleaning Unit	592
ITB Cleaning Unit Removal	593
Cleaning Blade	594
Lubrication Roller	595
Lubrication Bar	596
Lubrication Blade	598
Transfer Belt Replacement	599
After Transfer Belt Replacement	607
ITB Unit Cover Plates	608
ID/MUSIC Sensor Fan	609
PTR Separation Motor	610
1 st Lift Motor (YMC)	611
Transfer Belt Drive Motor	612
2nd Lift Motor (K)	613
Belt Centering Motor	616
PTR/ITB Cleaning Unit Motor	617
ID Sensor/MUSIC Sensors	619
PTR Separation Sensor	621
1 st Lift Motor Sensor (YMC)	621
Belt Centering Roller HP Sensor	622
Belt Centering Sensor	623
2nd Lift Motor Sensor 1 (K)	626

2nd Lift Motor Sensor 2 (K)	627
Transfer Belt Speed Sensor	627
Front Overrun Sensor	629
Rear Overrun Sensor	630
Image Transfer Rollers	631
ITB Bias Roller	633
ITB Transfer Power Pack	635
TDRB	640
ITB Cleaning Unit Cover Set Switch	641
ITB Cleaning Unit Set Switch	643
Right Anti-Condensation Heater	644
Left Anti-Condensation Heater	645
ITB Unit Thermostat	645
Paper Feed	647
Main Machine Tray Removal	647
PFU Pick-up, Feed, Separation Rollers	649
Paper End Sensor	650
Pickup Roller Lift Sensor	650
Paper Feed Sensor	651
Pickup Roller Solenoid	651
Separation Roller Solenoid	653
Tray 1 Rear Fence Return Sensor (Left Tandem Tray)	654
Tray 1 Rear Fence HP Sensor (Left Tandem Tray)	655
Tray 1 Right Tray Paper Sensor (Right Tandem Tray)	655
Bottom Plate Lift Wire	656
Paper Feed Motors, Grip Motors	658
Lift Motors (Tray 1, Tray 2)	664
Tray 1 Solenoids	667
Vertical Transport Unit	670
Bank Exit Motor	670
Vertical Transport Motor	671
Main Relay Sensor 1	672
Bank Exit Sensor	673

	1st Transport Sensor	674
	Vertical Transport Sensor	675
	2nd Transport Sensor	676
R	Right Drawer	677
	Right Drawer Front Cover	677
	Shift Unit	677
	Registration Entrance Motor	680
	Registration Timing Motor	683
	Registration Gate Motor	684
	Shift Roller Motor	686
	Shift Unit Motor	688
	Shift Timing Motor	690
	CIS Fan	690
	Main Relay Sensor 2	691
	Main Relay Sensor 3	692
	LCIT Relay Sensor 2	693
	Double-Feed Sensor 1 (LED)	693
	Double-Feed Sensor 2 (Receptor)	694
	Shift Unit Sensor	695
	Registration Gate Sensor	695
	CIS	696
	Transfer Timing Sensor	697
	Duplex Transport Sensor 4	698
	Duplex Transport Sensor 5	699
	DRB	700
	Separation Power Pack	702
Р	Paper Transfer Roller (PTR) Unit	708
	PM Parts List: Replacement	708
	PTR Servicing SP Codes	708
	Cleaning	709
	Separation Plate	710
	Lubrication Bar	710
	Lubrication Blade	712

Lubrication Roller	713
PTR (Paper Transfer Roller)	714
Cleaning Roller	716
PTR/ITB Cleaning Unit Motor	717
Paper Separation Power Pack	719
Paper Transport Belt (PTB) Unit	720
Paper Transport Belts	720
PTB Sensor	720
PTB Fans	721
Pressure Roller Fan	721
Belt Cooling Fan	722
Fusing Unit	724
Before You Begin	724
Periodic Cleaning	726
Periodic Lubrication	728
Heating Roller Fusing Lamps	728
Heating Roller	741
Hot Roller, Fusing Belt	744
Pressure Roller Fusing Lamps, Pressure Roller	751
Hot Roller Thermistor (Front)	761
Hot Roller NC Sensor (Center)	762
Heating Roller NC Sensors	763
Heating Roller Rear Thermistor	765
Heating Roller Thermostats	768
Heating Roller Thermostat (Center)	769
Pressure Roller Sensors (Front and Rear)	771
Fusing Motor, Pressure Roller Lift Motor	772
Fusing Cleaning Unit	777
Fusing Cleaning Unit PM Parts	777
Web Supply Roller	777
Web Contact Roller	783
Brake	784
Web End Sensor	785

Web Motor	787
Left Drawer	789
Exit Relay Motor	789
Invert Exit Motor	790
Duplex Transport Motor 1	793
Web Motor	794
Belt Cooling Fan	795
Exit Motor	796
Duplex Inverter Motor	798
Exit Unit Entrance Sensor	800
Exit JG Sensor	800
Duplex Transport Sensor 1	801
Duplex Transport Sensor 2	802
Duplex Transport Sensor 3	802
Exit Relay Sensor	803
Purge Relay Sensor	803
Duplex Invert Sensor	804
Exit Sensor	804
Web End Sensor	805
Purged Paper Sensor	805
Duplex Motors and Rollers	807
Main Boards, HDD Units	808
CB Power Pack (CK)	808
CB Power Pack (YM)	810
Potential Sensor Power Pack	812
AC Drive Board	814
PSU 2, PSU 2 Fans	816
Relay Board (RYB)	821
TDCU	823
PSU 1, PSU 1 Fans	826
IOB/BCU	830
Controller Board (GW), NVRAM, Controller Board Fan	833
IPI I	836

HDD Units	837
Controller Box Fans	840
Fans and Filters	843
Before You Refer to This Section	843
Fan Layout	844
Ozone Exhaust Fans (YMCK), Ozone Collection Fan	848
Toner Supply Cooling Fan	852
Heat Sink Intake Fan	854
Heat Sink Exhaust Fan	856
Fusing Exit Exhaust Fan	857
Drive Exhaust Fan	860
Belt Cleaning Exhaust Fan	862
Stray Toner Exhaust Fan	865
Paper Cooling Intake Fan	867
Paper Cooling Exhaust Fan	869
Fusing Unit Transport Exhaust Fan	870
Duplex Exhaust Fans	871
Used Toner Intake Fan	873
ITB Intake Fan	875
Cooling Box Fans	877
Ozone Filter, Air Filters	883
Air Filter	884
Control Box Filter	884
ITB Area Filters	885
Paper Exit Fans	885
Firmware Update	887
Before You Begin	887
Firmware Update Procedure	887
Verifying the Firmware Update	889
Fiery Controller System Update	891
5. System Maintenance	
Service Program Mode	897

# 6. Troubleshooting

SC Table Key	899
SC Tables	901
SC100: Scanning 1	901
SC200: Image Writing	904
SC300: Development	914
SC400: Around the Drum	923
SC500: Paper Feed, Transport, Duplexing	936
SC600: Communications	955
SC700: Peripherals	961
SC 800: Firmware	1004
SC900: Other	1014
Special Troubleshooting Procedures	1020
Clearing SC471, SC475 or SC476	1020
SP3812 001 (Development Fill) Errors	
Process Control Troubleshooting	1022
MUSIC Adjustment Result	1031
Troubleshooting for Image Quality Problems	1032
Development-related Troubleshooting	1032
Color Toner Spotting/Staining	1035
Toner Scatter	1043
Color Loss	1046
Density Problems	1052
Gloss Problems	1072
Fusing-related Troubleshooting	1073
Troubleshooting for Paper Delivery Problems	
Frequent Paper Misfeeds	
Messages Reporting Paper Misfeeds	
Paper Skew	
Wrong Detection of Skew	
Double Feeding	
Wrong Detection of Double Feeding	
Paper Misfeedina	

Paper Feed Problems Affecting Image Quality	1093
Attaching the Tab Sheet Holder	1105
Cleaning the Paper Feed Path	1107
No Error Message at Initializing of the Double Feed Sensors	1114
Efficient SP for Paper Jam Analyzing	1114
Troubleshooting for Options	1115
Finisher SR5030/ Booklet Finisher SR5040	1115
Multi-Folding Unit	1127
Buffer Pass Unit	1138
High Capacity Stacker	1139
LCIT RT5060	1144
Cover Interposer Tray Cl5020	1149
Multi Bypass Tray BY5010	1150
Troubleshooting for Throughput	1152
Reducing the Waiting Time Prior to Printing	1152
Throughput When Printing on Paper with a Thickness Equivalent to Paper Weight 6 or 7	1152
Throughput when Printing Black-and-White Jobs and Color Jobs	1153
Fuses	1155
Blown Fuse Conditions	1155
Jam Codes	1157
Paper Late Jams: Main Machine	1157
Paper Lag Jams: Main Machine	1159
Finisher Jams (D512/D513) Jam Code Table	1161
Cover Interposer Tray CI5020 (D518) Jam Code Table	1162
Trimmer Unit TR5040 (D520) Jam Code Table	1163
Multi Folding Unit FD5010 (D521) Jam Code Table	1164
High Capacity Stacker SK5020 (D515) Jam Code Table	1165
Ring Binder RB5010 (D519) Jam Code Table	1166
Buffer Pass Unit Type (5010 D548) Jam Code Table	1167
ARDF Jam Code Table	1168
D074/D075, M044 Jam Displays	1169

# 1. Product Information

# **Specifications**

See "Appendices" for the following information:


- Main Specifications
- Peripheral Specifications

1

# Main Machine and Peripherals

# Main Peripherals

# D074/D075




No.	Unit	Comment	
(1)	Main machine D074/D075	Copier	
(2)	Decurler Unit (D544)	Inside the machine	
(3)	A3/DLT LCIT (D516)	Only one LCIT available	
(4)	Multi Bypass Tray (D517)	Requires LCIT	

#### Notes:

- If the Trimmer Unit (11) is not installed, the booklet tray for the Booklet Finisher (D512) must be
  installed to hold stapled booklets. (The booklet tray must be removed in order to install the Trimmer
  Unit.)
- The Trimmer Unit (11) cannot be installed with the Finisher (D513) (13). This finisher performs only corner and flat stapling (no booklet stapling). The Trimmer Unit processes booklet-stapled stacks only.
- If the Multi Folding Unit (7) is installed, the Booklet Finisher (10) or Finisher (13) must also be installed.

<sup>\* 1:</sup> These peripherals are released at the same as the Pro C751 (M044) launch.

# M044



No.	Unit	Comment
(1)	Main machine M044	Printer
(2)	Decurl Unit (D544)	Installed inside the machine
(3)	A3/DLT LCIT (D516)	Only one LCIT available
(4)	Multi Bypass Tray (D517)	Requires LCIT
(5)	Buffer Pass Unit (D548)	Cools paper with 8 fans before it goes to downstream peripherals. This option is recommended for use with the High Capacity Stacker.
(6)	Cover Interposer Tray (D518)	Feeds covers from two trays
(7)	Multi Folding Unit (D521)	Straight through, or 6 types of folds

ч

No.	Unit	Comment
(8)	Ring Binder (D519)	Ring binding with 50/100 sheet plastic rings
(9)	High Capacity Stacker (D515)	Stacking capacity: 2500 to 5000 sheets
(10)	Booklet Finisher (D512)	Booklet stapling with Trimmer Unit.
(11)	Trimmer Unit (D520)	Automatically trims open edges of booklets
(12)	Finisher (D512)	Booklet stapling without Trimmer Unit.
(13)	Finisher (D513)	Corner stapling only.

## Notes:

- If the Trimmer Unit (11) is not installed, the booklet tray for the Booklet Finisher (D512) must be installed to hold stapled booklets. (The booklet tray must be removed in order to install the Trimmer Unit.)
- The Trimmer Unit (11) cannot be installed with the Finisher (D513) (13). This finisher performs only corner and flat stapling (no booklet stapling). The Trimmer Unit processes booklet-stapled stacks only.
- If the Multi Folding Unit (7) is installed, the Booklet Finisher (10) or Finisher (13) must also be installed.

# Other Options (Not Shown Above)

Туре	Option	Comment
Main Machine	Original Tray	Holds originals to be copied
	Key Counter	Key counter device for customers
	USB 2.0/SD Slot Type E (TBD)	Allows direct sending of jobs to USB 2.0 or SD card storage.
	A3/11"x17" Tray Unit (B331-12)	Converts 1st tray (tandem tray) to large capacity tray.
Finisher (D512/D513)	Punch Unit (D449)	Installed inside the Finisher (D512/D513)
Controller Option	VM Card	VM ware (Calypso)
	@Remote	Basil/UZ-A1


# Notes

- The USB Host and Cumin-N (for @Remote) are standard (no installation required).
- Cumin-M and File Format Converter are not available.

# Guidance for Those Who Are Familiar with Predecessor Products

# **Main Machine Specifications**

# Maximum Printing Area



The maximum printing area is  $320 \times 480$  ( $12.6 \times 18.9$  in.). Length can be expanded up to 630 mm (24.8 in.) with SP 5150-1. This allows full-bleed printing with A3 ( $11 \times 17$  in.) to preserve crop marks and borders.

#### Warm-up Time

Warm-up time: 300 sec. This is longer than many previous machines, such as the D014/D015 which has a warm-up time of less than 90/75 sec.)

## **ARDF**

The ARDF on the D074/D075 is basically the same as that used with the D014/D015. However, there are some minor differences:

- Design changes in the front cover, rear cover, feed cover, and handles.
- Color of the external covers has changed.
- Shoulder screws are rounded.
- Harness routing has changed.
- Length and color of the interface cable have changed.
- Speed is faster (426 mm/s), compared to D014/D015 (394 mm/s)

Magnification range is 66% to 400% (D014/D015 is 50% to 400%)

#### Laser Unit

The machine automatically "reads" a new laser unit and only two SP code settings are required. With previous machines when a laser unit was replaced, the technician had to set several SP codes for the new laser unit. With older machines, the SP settings that had to be entered were printed on a label attached to the new unit. This procedure has been eliminated.

## **ITB Unit**

• This machine uses two motors that raise and lower the ITB. One motor operates the left tray (YMC) and one motor operates the right tray (K).




d074f929

- A belt speed sensor [1] reads an encoder strip under the front edge of the ITB [2] to monitor the speed of the belt. (The photo above shows a top view of the sensor with the ITB removed. The red dotted line represents the front edge of the ITB.) This is not a new mechanism. But in previous machines, the encoder strip was on the back edge of the belt and the encoder sensor was at the left rear corner of the ITB unit. In this machine, the encoder strip is on the front edge of the belt and the encoder sensor is at the front right corner of the ITB unit. The ITB must be installed with the encoder strip at the front edge of the belt. The image transfer belts of some previous machines could be installed in either direction because there was no encoder strip on either edge of the belt.
- In the D016, the belt centering sensor was comprised of a photosensor mounted above the belt
  and above a free-swinging actuator touching the edge of the belt. The sensor detected belt
  deviation from center by measuring the angle of reflection from the top of the actuator.




d074f933

The belt centering sensor for this machine is simpler. A small CIS inside the cover (shown above with the ITB removed) is below the rear edge of the belt. It monitors the position of the belt directly. The pendulum actuator mechanism has been replaced with this new detection mechanism.



• This machine uses the same steering control mechanism used in the D016 that checks and corrects the positioning of the ITB to keep it centered to prevent color offset in images. An ITB feedback sensor (a photosensor), located at the right upper corner [1] of the ITB unit constantly monitors the position of the ITB. If the ITB shifts forward or backward, the steering control motor [2] (located on the left front of the ITB unit) corrects the position of the belt with the steering control mechanism [3]. This system eliminates physical wear on the edge of the belt that would be caused by an ITB guide fence.



The location of the ITB sensor array (ID and MUSIC sensors) has changed. In previous machines,
the ITB sensor array [A] is located farther downstream and below the ITB. In this machine, the ITB
sensor array [B] is located above the ITB on the right end of the ITB unit below the K\_PCDU.

# Paper: Trays, Transport, etc.

## Paper Transport Unit

The paper is held onto the paper transfer belt by three fans: Rear, Front, Center (not two fans).

Compared to previous machines:


- The paper transport unit frame of this machine is made of plastic, making it lighter for TCRU
  operators to handle.
- The unit is easier to remove with its drive intact

## **Paper Cooling Unit**

Previous machines have four belts in the paper cooling unit. To improve the accuracy and efficiency of paper feed, one large belt is used in these machines.

## **Paper Registration**


The high-precision paper registration unit of earlier machines has been adopted for use in this machine. The position of the paper in the paper path is corrected twice by the paper registration unit in the main machine, once to correct for skew in the sub scan direction and once for side-to-side registration in the main scan direction.



- Skew correction. The paper pauses very briefly in the registration unit, as its leading edge hits a raised registration gate [1] to buckle the paper and align it.
- Side-to-side adjustment. After the registration gate lowers, the paper passes through the shift roller unit. In this unit, a CIS [2] detects the paper's front edge to determine if the paper has shifted forward or back. If adjustment is needed, the shift roller unit [3] holds the paper and moves forward or back to adjust the paper position before the paper feeds to the paper transfer roller.

The combination of laser VCSEL technology and double paper registration correction ensures that paper is always precisely positioned in the paper path. Paper registration is done once in the main machine. There is no paper registration correction mechanism in the optional LCIT.


## Shift Unit



d074f936

The visible springs at the top of the shift unit were weak in previous machines. These springs have been replaced with stronger springs. The photo above shows the old springs. The new springs are black.

## Heaters



d074f930


There are two heater switches on the front of the machine. The left switch controls the operation of the paper bank heaters of the main machine and the LCIT heaters. The right switch controls the operation of the ITB heaters.

When these switches are set to ON, the heaters switch on when the main machine is switched off
(or enters energy save mode), and then switch off when the main machine is switched on again (or
leaves energy save mode).

- 1
- When these switches are set to OFF, the heaters do not switch on when the main machine is switched off (or enters energy save mode). Both heaters are switched OFF before the machine leaves the factory.
- When these switches are set to ON and SP5965-1 is set to "1", the heaters always remain on.

# **Common Cleaning Mechanisms**

One basic cleaning and lubrication mechanism is used in key components of the machine.



A cleaning blade [1], lubrication bar [2], lubrication roller [3], and lubrication blade [4] comprise the cleaning mechanisms (with some variation) in the following units:

- [A] Drum cleaning unit
- [B] ITB cleaning unit
- [C] PTR cleaning unit




• Only the PTR cleaning unit has a cleaning brush roller (5).

All of these units use a dry lubricant (Zinc Stearate) supplied by a lubrication bar and lubrication roller.


## **Retraction to Reduce Wear**

As in previous machines, this machine employs mechanisms to separate important parts subject to pressure and wear during normal operation. These mechanisms reduce wear on parts and prolong service life of important components.

• ITB and OPC drum separation mechanism




The 1st lift motor (1) raises and lowers the 1st tray (2). The tray is raised against the bottoms of the YMC drums for full color printing. The tray is lowered for black and white printing, and remains down while the machine is idle. This prevents wear on the drums and the ITB and prevents deformation of the ITB bias rollers below the drums.




The 2nd lift motor (1) raises and lowers tray 2 (2). The tray is raised against the bottom of the black drum only while the machine is operating. The tray remains down while the machine is idle. This reduces wear on the ITB and prevents deformation of the ITB bias roller below the drum.

# • ITB and PTR separation



A PTR separation motor (1) raises and lowers the ITB bias roller (2). The roller remains down against the PTR roller below to transfer the toner image from the ITB to the paper between the rollers. While the machine is idle, the motor rotates two cams to raise the ITB bias roller away from the PTR below. This prevents deformation of the soft ITB bias roller. In this machine, the ITB bias roller is raised and lowered. In previous machines, the PTR was raised and lowered to separate the rollers.

## · Pressure and hot roller separation




A pressure roller lift motor (1) rotates large cams (2) that raise and lower the pressure roller lift arm (3). The lift arm applies pressure to the pressure roller (4) below the stationary hot roller (5) above. During a job, this mechanism can vary the pressure applied to the paper and fusing belt between the nip of the

pressure roller and hot roller. When the machine is idle, the cams are rotated down to prevent the deformation of the soft sponge surface of the hot roller.

# Photo Conductor Development Units (PCDU)


# Charge Unit

• This machine uses charge rollers to charge the drums. There are no charge corona units. This reduces the amount of ozone created in and around the machine.



• There is a charge roller cleaning roller [A] above each charge roller [B] in each PCDU. This cleaning roller is lowered to clean the charge roller every 1,000 prints. The solenoids [C] that operate these rollers are mounted behind the laser units.

# **Drum Cleaning Unit**



d074f935

Mylars [A] have been added above the used toner transport coil [B] in each PCDU. The slight
vibration set up by the auger turning against the mylar prevents used toner from clumping when it is
transported out of the back of the unit.

 The brush cleaning roller in the drum cleaning unit has been eliminated. The drum cleaning unit is comprised of the drum cleaning blade, lubrication bar, lubrication roller, and lubrication blade.

# **Fusing Belt Cleaning**


- The fusing cleaning unit of previous machines had a fusing belt cleaning roller between the fusing
  belt below and the cleaning fabric above. The roller scavenged toner, dust, etc. from the surface of
  the fusing belt. In this machine the cleaning roller has been eliminated. The cleaning fabric touches
  the surface of the fusing belt directly.
- There is no oil supply mechanism for lubricating the fusing belt in this machine.

# **GW Controller Options**

The base controller for this machine is the Fiery controller. However, the GW controller is still provided.


- Data Overwrite and HDD Encryption will be provided with the machine in Slot 1. Both must be enabled with User Tools.
- A VM card option will also be available.
- The GW controller is still required for @Remote because the functionality of the Fiery controller with @Remote is limited.

#### **Process Control**



- The number of sensors in the ITB sensor array has been reduced. The D016, for example, had
  seven sensors as shown above: three MUSIC sensors and four ID sensors. This machine has only
  three sensors. Only the middle sensor 2 functions as an ID sensor, but all three sensors function as
  MUSIC sensors.
- There are two temperature/humidity sensors used during process control. One is located on the
  left, below the used toner bottle motor. Another is on the right near the K\_PCDU. In previous
  machines, the left sensor was higher and near the Y\_PCDU.

# **RFID** with Toner Bottles



d074f938

This machine uses RFID (Radio Frequency IDentification) technology. Each reader PCB [A] is paired with a tag PCB [B] on top of each toner bottle. The tag PCBs are the toner bottle ID chips. The reader PCBs can read/write data to/from the ID chips.

# **Peripherals**

# General

- The covers of all peripheral units have been re-designed to match the shape and color of the main machine.
- The breaker switches have been removed from all peripheral units (with the exception of the Ring Binder which still has a breaker switch). The only breaker switches in the system are on the main machine and the Ring Binder.

# **Decurl Unit**



d074f939


• The Decurl Unit is inside the left side of the main machine.

## **LCIT**



d074f946

The illustration above shows the LCIT without the Multi Bypass Unit installed on top.



d074f940


# Side fence adjustment

The side fence adjustment mechanism of the LCIT has been re-designed to make it easier to change paper sizes. The side fences can be adjusted just by loosening the screws and sliding the fences. The screws do not need to be removed.

## No CIS unit

There is no CIS adjustment at installation. The LCIT has no CIS unit. The side-to-side registration is done with a CIS in the main machine. The LCIT does not have a CIS unit for paper registration. Side-to-side registration is performed once in the registration unit of the main machine.

# New paper release mechanism



There is a new mechanism at the paper exit to retract the exit idle roller from the paper. This releases the paper for side-to-side registration in the main machine. The mechanism consists of a retractor motor [A] on the back of the unit and the idle roller HP sensor [B] at the LCIT paper exit.

# Jam release lever



d074f942

The LCIT jam release mechanism has been re-designed for "one-action" removal.

# Rollers



d074f943

The LCIT rollers are black but their construction and shape are the same as the previous model.

# **Coated Paper**


The LCIT can handle coated paper without replacement of the pick-up rollers, feed rollers, and separation rollers.

# Multi Bypass Tray



The Multi Bypass Tray is installed on top of the LCIT.

# **New Lift Motor**



d074f944

The Bypass Tray lift motor has been replaced with a new motor.

#### **Buffer Pass Unit**



d074f945

Installed on the left side of the main unit, this option provides a paper path that allows paper and toner to cool before it is fed to downstream peripherals. This prevents toner from sticking to other sheets of paper after stacking. It has a total of 8 fans. The DC motor is slightly slower than the motor of the previous model. This option is recommended for use with the Multi Folding Unit.

## **Cover Interposer Tray**



### Paper Path

The CIT is taller than the previous model. The paper feed path is 20 mm longer but there are no added rollers.

#### Installation

- The black mylar is no longer required for connection to the next peripheral unit downstream.
- The separate joint brackets (x2) for docking have been replaced with a T-bar just like all the other peripherals.

#### Lift Motor



d074f949

The lift motor has been replaced with a new type of motor.

#### **Multi Folding Unit**




d074f953


#### **General Changes**

- Glossy paper mode (half speed). 1st fold motor, crease motor have been replaced by motors capable of slower speeds to accommodate half-speed mode for glossy paper.
- Elimination of stripe tracks at the leading edges of folded coated paper. The ribs of the gate-fold guide plate have been removed and replaced with a smooth surface.
- Up to 3 sheets of paper can now be folded (64 to 80 g/m<sup>2</sup>)
- Coated paper can be folded.
- The relay guide is now the same as other peripheral units.
- Two accessories have been discarded (proof tray auxiliary trays).

#### Modifications to Improve Performance




- [1] Roller marks on coated paper. The exit roller has been replaced with the same type of roller used in the High Capacity Stacker to reduce roller marks on coated paper.
- [2] Gate folded (FM6) cloth coated paper fold position. The gap before and after the guide plate of the 2nd stopper has been widened to accommodate cloth coated paper for gate folding.




d074f963

[3] Improved feed-out of small Z-folded paper. An extra drive roller [A] above the exit roller [B] at the top tray exit has been added to improve feed-out of small Z-Folded (FM1) paper.




d074f958

Improvement in multiple folding. The entrance roller [A] and other transport rollers are driven independently. This allows effective control of the line speed while paper is fed from the main machine.




d074f960

Elimination of roller marks during multiple folding. The movement of the TE stop pawl [A] raises and lowers the paper for registration. At the same time, the transport rollers stop rotating to prevent the rollers from marking the paper.




d074f959

Elimination of possible damage to leading edges of paper. Above the 1st feed roller [A], the guide plate [B] above the nip has been lengthened, and the width of the path has been narrowed to prevent distortion of the leading edges of paper.




d074f965

[7] Improved folding for coated paper. The guide plate [A] can be moved to widen the space in the turn of the transport path for easier folding with the fold plate.




d074f961

[8] Elimination of roller marks when two sheets are folded. When two sheets are folded at the same time, the 2nd fold roller [A] pulls away to widen the 2nd nip [B].



[9] Elimination of wrinkling in gate-folded large paper sizes. The shape of the FM6 pawl [A] has been changed [B] to prevent the wrinkling of large paper sizes during FM6 (gate) folding.



d074f964

Early top tray full alert with FM1 folding large paper sizes. An auxiliary tray [A] is provided to keep Z-folded paper (FM1) flat in the tray so that a trailing edge does not trigger an early tray-full alert in the top tray.





d074f962

[11]


Early top tray full alert with FM3 folding. The trailing edge of a multi-folded sheet can occasionally open and trigger an early top tray alert. A flexible fold depressor [A] is provided as an accessory to prevent folded paper (especially FM3 Letter Fold-out sheets) from triggering an early tray full alert in the top tray.

## **Ring Binder**



The differences in the Ring Binder Unit are very minor:

• The rear and top covers are metal.



d074f95

• The surge PCB [A] has been removed and a noise filter [B] has been added.

## **High Capacity Stacker**



d074f952

Minor changes in the High Capacity Stacker:

- The operation and LED panel have been moved from right to left side at front edge.
- The door catch has changed slightly (a "bump" roller has been added.)
- Capacity: 5,000 sheets (SRA3, A4 LT) on the shift tray, and 250 sheets on the proof tray. Total: 5,250 sheets.
- This machine allows installation of **only one** High Capacity Stacker in the system. (Some previous models allowed two High Capacity Stackers.)
- One roll-away cart is provided with the stacker. Additional carts are available as options.

#### Finishers and Punch Unit



d074f954

This machine supports two finishers:

- D512 Booklet Finisher (shown above) that performs both corner and booklet stapling. (Max. stack: 20 sheets with paper 80 g/m²)
- D513 Staple Finisher that performs corner stapling only.

#### Minor changes:

- Side-to-side registration can be adjusted manually on the finisher. The side-to-side registration with an SP code at installation has been eliminated.
- The stacking buffer where paper is shunted long enough for the unit to staple the downstream stack can hold 5 sheets of paper.


#### **Trimmer Unit**



d074f955

#### Minor changes:

- Transport belt. The color of the transport belt was changed to white. This prevents dirty images on A3 Full-bleed paper.
- **Entrance guide**. The shape of the movable entrance guide has been modified to prevent pages from slipping.




d074f956

• New sensor. A new sensor has been added inside the booklet tray. The new sensor detects when the end stopper is installed or removed for limitless output on the tray.

# Overview

# Machine Layout



1	Attention Light	9	Right Drawer
2	Operation Panel		Left Drawer
3	ARDF (D074/D075)	11	Vertical Transport Unit
4	Toner Bank	12	PFU (Tray 1)
5	Scanner Unit (D074/D075)	13	Tray 1 (Tandem Tray)
6	Laser Units	14	PFU (Tray 2)
7	PCDUs	15	Tray 2 (Universal Tray)


1

8 ITB Unit	16 Used Toner Bottle
------------	----------------------

- Attention Light. Provided with the machine (not an option) but requires installation.
- Operation Panel. Requires installation. Standard installation for operating the machine while standing, or easy-access installation for operating the machine from a sitting position.
- ARDF. Standard auto reverse document feeder (D074/D074).
- Toner Bank. Holds four toner bottles, one for each color (YMCK).
- Scanner Unit. Color or black-and-white scanning (D074/D075).
- Laser Units. There are two laser units. Each laser unit handles two colors (YM, CK).
- PCDUs. Photoconductor development units. One for each color (YMCK). Each unit contains the drum (and charge unit), development unit, and cleaning unit.
- ITB Unit. Image Transfer Belt Unit. The image is transferred from the drum to the ITB and then transferred from the ITB to the paper.
- **Right Drawer.** Holds the paper registration unit, PTR (Paper Transfer Roller) unit, and the right-half of the duplex path.
- Left Drawer. Holds the PTB (Paper Transport Belt), fusing unit, paper cooling unit, exit unit, and the left half of the duplex path.
- Vertical Transport Unit. Feeds paper from the paper bank (Tray 1, Tray 2) to the registration unit above.
- **PFU (Tray 1)**. Paper Feed Unit for Tray 1. Contains the pickup roller, feed rollers, separation roller, and grip rollers that feed paper from Tray 1.
- Tray 1 (Tandem Tray). Contains a left tray and a right tray. When paper runs out in the right tray,
  the left stack is shifted to the right tray to continue feeding paper when a large job is in progress.
   Tray 1 can be opened to replenish the left tray while paper continues to feed from the locked right
  tray. Feeds LT/A4 paper.
- **PFU (Tray 2)**. Paper Feed Unit for Tray 2. Contains the pickup roller, feed rollers, separation roller, and grip rollers that feed paper from Tray 2.
- Tray 2 (Universal Tray). Adapts to a variety of paper sizes. The inner tray can be easily removed. Automatic paper size detection.
- Used Toner Bottle. Holds used toner transported from the PCDU development units, PCDU cleaning
  units, ITB cleaning unit, and PTR cleaning unit. The machine can continue to print while the bottle is
  removed.

# Paper Paths

## D074/D075




d074v102

No.	ltem	Comment
1	Original Path	ARDF (D074/D075 Only)
2	Paper Bank	Tray 1 (Tandem: 2,000 sheets), Tray 2 (Universal: 500 sheets)
3	Vertical Paper Path	Path for paper from where paper from the paper bank and duplex path converge.
4	LCIT	Tray 3 (1,000 sheets), Tray 4 (2,000 sheets), Tray 5 (1,000 sheets)
5	Multi Bypass Unit	Tray 6 (500 sheets)
6	Paper Entrance	From LCIT and Multi Bypass Unit (options)
7	Paper Registration Unit	Corrects paper skew and side-to-side registration for all paper (including paper fed from the LCIT/Multi Bypass Unit)
8	Paper Transfer	Toner image transferred from ITB to paper
9	Transport Belt	Transports paper between paper transfer roller and fusing unit.  Three fans hold the paper in the paper path. Fans (not rollers) are used to hold the paper in the paper path because the toner is not yet fused.

No.	ltem	Comment
10	Fusing Unit	Fuses the toner image to paper
11	Paper Cooling	Cools paper to reduce curl before it exits or descends to the duplex paper path
12	Paper Exit	Common paper exit for all paper
13	Inverter/Exit Tray	Paper is fed into this tray, and reverse fed to invert it for face-down output.
14	Purge Tray	Bottom of the inverter/exit tray. All paper in the paper path of the main machine is shunted here when a jam occurs downstream.
15	Paper Invert/Switchback	Paper is stopped and reverse fed here to feed it into the duplex paper path for printing the 2nd side of the sheet.
16	Duplex Paper Path	Transports paper back to the upper horizontal feed path for paper registration and printing on the second side.

## M044




m044v102

No.	Item	Comment
1	Paper Bank	Tray 1 (Tandem: 2,000 sheets), Tray 2 (Universal: 500 sheets)

No.	ltem	Comment
2	Vertical Paper Path	Path for paper from where paper from the paper bank and duplex path converge.
3	LCIT	Tray 3 (1,000 sheets), Tray 4 (2,000 sheets), Tray 5 (1,000 sheets)
4	Multi Bypass Unit	Tray 6 (500 sheets)
5	Paper Entrance	From LCIT and Multi Bypass Unit (options)
6	Paper Registration Unit	Corrects paper skew and side-to-side registration for all paper (including paper fed from the LCIT/Multi Bypass Unit)
7	Paper Transfer	Toner image transferred from ITB to paper
8	Transport Belt	Transports paper between paper transfer roller and fusing unit.  Three fans hold the paper in the paper path. Fans (not rollers) are used to hold the paper in the paper path because the toner is not yet fused.
9	Fusing Unit	Fuses the toner image to paper
10	Paper Cooling	Cools paper to reduce curl before it exits or descends to the duplex paper path
11	Paper Exit	Common paper exit for all paper
12	Inverter/Exit Tray	Paper is fed into this tray, and reverse fed to invert it for face-down output.
13	Purge Tray	Bottom of the inverter/exit tray. All paper in the paper path of the main machine is shunted here when a jam occurs downstream.
14	Paper Invert, Switchback	Paper is stopped and reverse fed here to feed it into the duplex paper path for printing the 2nd side of the sheet.
15	Duplex Paper Path	Transports paper back to the upper horizontal feed path for paper registration and printing on the second side.

## **Main Motors**

Here is a list of the main motors inside the machine. This list is not complete, but this perspective drawing shows you the approximate location of the main motors viewed from the back of the machine.



No.	Name
1	ITB Lift Motor K (on back of ITB unit)
2	Drum Cleaning Motors
3	Development Motors
4	Drum Motors
(5)	Exit Motor
6	Fusing Motor
7	Pressure Roller Lift Motor
8	PTR Motor
9	Used Toner Collection Motor (Main)
10	Belt Centering Motor (on back of ITB unit)
11)	ITB Drive Motor (on back of ITB unit)

#### Notes:

• There is a drum cleaning motor, development motor, and drum motor for each PCDU (YMCK).



d074r005


• To access most of these motors for servicing, both rear doors must be opened. Some boards and air ducts may also require removal.

# 2. Installation

# **Installation Requirements**

## **Operating Environment**

Recommended Temperature/Humidity Range for Operation



Recommended: 23C (73.4F), 50% Rh d074i503

ltem	Details
Target Temperature & Humidity	23°C (73.4°F), 50% RH
Temperature range	10° to 32°C (10° to 90°F)
Humidity range	15 to 80% RH
Ambient illumination	Less than 1500 lux
Ventilation	Air turnover rate of more than 30m <sup>3</sup> /hr/person
Ambient dust	Less than 0.10 mg/m <sup>3</sup>

### Mportant (

- If the machine is installed in a location where the ambient temperature is more than 30°C (86°F), do not run full color printing longer than 2 hours, and never turn the main power switch off immediately after a long print job. Leave the machine on so that the fans can expel the hot air from the machine and cool the electronic components.
- If this machine is to be used in a location where both temperature and humidity are high, the tray
  heaters should be turned on. The tray heaters for the paper bank are built in. Just open the 1st and
  2nd tray and turn them on.
- 1. If the installation site has air-conditioners or heaters, put the machine in a location that agrees with these conditions:
  - Where there are no sudden temperature changes from low to high, or high to low.
  - Where the machine will not be directly exposed to cool air from an air conditioner in the summer.
  - Where the machine will not be directly exposed to reflected heat from a heater in the winter
- 2. Do not put the machine where it will be exposed to gases like ammonia that can cause corrosion.
- 3. Put the machine on a strong level surface. The front and rear of the machine must be level ±2.5 mm (0.1").
- 4. Never put the machine where it can be subjected to strong vibration.
- 5. Never connect the machine to a power source shared with other electrical devices.
- 6. The machine can generate an electromagnetic field which can cause interference with radio or television reception.

#### RTB 38

New information added at the end of this section.

#### **Power Requirements**

## **<b>⚠WARNING**

- Make sure that the wall outlet is near the mainframe.
- Keep the area around the power outlet open and free of clutter so the operator can get to it easily and quickly.
- Make sure the plug connection to the power outlet is tight..
- Do not connect more than one electrical device to the same power outlet.
- Be sure to ground the machine.
- · Never place anything on the cord and never wrap the cord around itself or around another object.

#### Input voltage level

North America	208 to 240V, 50/60 Hz: More than 20 A
---------------	---------------------------------------

Europe/Asia 220/230/240V, 50/60 Hz: More than 16 A

Permissible voltage fluctuation: ±10%

#### **Breaker Switch**

The machine is equipped with a breaker switch located at the rear, lower right corner. Inspect and test the breaker switch at least once a year.



d074i801

## 

• If the breaker switch appears dirty and covered with soot, it probably requires replacement.

## Machine Level

### D074/D075



d074i802

#### M044



m044i802

The covers should be removed before leveling the machines.


1	Front to rear	Less than 5.0 mm (0.2") away from level
2	Right to left	Less than 5.0 mm (0.2") away from level

The machine feet can be rotated to raise and lower each corner of the machine until it is level.

## **Space Requirements**

Put the mainframe near the power source. Consideration should be given not only to machine operation, but servicing the machine as well, with front doors and rear boxes fully open.

#### Space Around the Main Machine




The illustration above is a top view of the main machine. This illustration is not drawn to scale. Measurements are rounded up slightly, but they will allow you to estimate how much space will required to work around the machine and service the machine without moving it.

- Approximately 670 mm (26.5 in.) clearance required behind the machine with both rear boxes open.
- Approximately 630 mm (25 in.) at the front of the machine with both front doors open.

No.	Part	Range of Movement
1	Front Doors	Both doors swing open to the front
2	Main Machine	Remains stationary.
3	Cooling Box	Swings open to the rear ( 🗗 x3)
4	Controller Box	Swings open to the rear ( 🗗 x3)
5	Left Drawer	Slides open to the front for servicing (fusing unit, etc.)
6	Right Drawer	Slides open to the front for servicing (registration unit, etc.)

- The rear boxes (cooling box and controller box) are on hinges and can be swung open to the rear
  in order to service parts on the back of the machine (motors, sensors, etc.).
- The front doors swing open to the front, and then the left drawer or right drawer (or the ITB unit as well) can be pulled out the front of the machine on their rails for servicing.

# **Total Space Required**



No.	Unit	mm	in.
1	A3/DLT LCIT	880	35
2	Main machine	1320	52
3	Buffer Pass Unit* 1	330	13
4	Cover Interposer Tray*1	164	7
5	Multi Folding Unit	470	19
6	Ring Binder* 1	870	35
7	High Capacity Stacker*1	900	36
8	Finisher	990	39

No.	Unit	mm	in.
9	Trimmer Unit* <sup>1</sup>	1115	44
	Total 1 (mm, in.)	7,422 mm	292 in.
	Total 2 (m, ft.)	7.4 m	25 ft

<sup>\*1:</sup> These peripherals are schedule for release with the MO44..

#### Notes:

- The Decurl Unit is not listed because it is installed inside the left side of the main machine.
- The Multi Bypass Tray is not listed because it is installed on top of the LCIT.
- The Buffer Pass Unit (3) is required for the Multi Folding Unit (5).
- Only one High Capacity Stacker (7) can be installed in the line.
- If the Trimmer Unit (9) is not installed, the booklet tray for the Booklet Finisher (D512) must be
  installed to hold stapled booklets. (The booklet tray must be removed in order to install the Trimmer
  Unit.)
- The Trimmer Unit (9) cannot be installed with the Finisher (D513). This finisher performs only corner and flat stapling (no booklet stapling). The Trimmer Unit processes booklet-stapled stacks only.

## Switching the System On/Off

#### Main Power and Operation Power Switch

#### Main Power Switch

The main power switch is located inside the front left door. This machine should be left on at the end of the work day.

## **ACAUTION**

• This switch should always be turned off before servicing the machine.

#### **Operation Switch**

The operation switch is located on the operation panel. This is the switch that the operator uses to turn the machine on and off and the beginning and end of each work day.

## **ACAUTION**

- Never turn off the main power switch when its power LED is lit or flashing.
- To prevent damage to the hard disk or memory, push the operation switch to turn the power off, wait for the power LED to go off, and then turn the main power switch off.
- Never turn off the main power switch of the mainframe before shutting down the Fiery controller.

The correct shut down procedure for the Fiery controller is described below.

#### Power On with Fiery Controller

- 1. Turn on the main power switch of the main machine.
- 2. Turn on the switch on the back of the Fiery Controller box.
- 3. Press and turn on the switch on the front of the Fiery Controller box.

## **Turning the System Off**

#### On the Fiery controller operation panel:

- 1. Press the [Fiery] tab.
- 2. Press the [Restart Fiery] button.
- 3. Press the [Shut Down" button.

#### On the Main Machine

- 1. Push the operation switch on the operation panel to turn the power off.
- 2. Wait for the operation switch power LED to stop flashing.




- Never turn off the main power switch when the power LED is lit or flashing.
- 3. After the power LED goes off, open the left front door.
- 4. Turn the main power switch off.

#### 2

# Main Machine

## Accessories

## D074/D075/M044



No.	Description	Q'ty
1.	Operation Panel	1
2.	Screw Cover - Small	1
3.	Arm Cover	1

No.	Description	Q'ty
4.	Screw Cover - Large	1
5.	Attention Light	1
6.	Arm	1
7.	Rear Cover - Convex	1
8.	Rear Cover - Flat	1
9.	Original Set Decals (D074/D075)	1
10.	Paper Set Decals	1
11.	Ink Jet Paper Caution Decal (NA only)	1
12.	Logo Plate (NA only)	1
13.	Sponge Strip - L	1
14.	Sponge Strip - Long Hooked	1
15.	Harness Cover	1
16.	Nylon Clamp	1
17.	Screws (M4x6)	4
18.	Screws (M4x8)	11
19.	Cleaning Cloth (D074/D075)	1
20.	Wrench	1
21.	Shoes	4
22.	Fusing Roller Knob Holder	1
23.	Fusing Roller Knob	1

## Installation Flow

F	Procedure
Installation: Power Off	

	Procedure		
Install Operation Panel  Connect ARDF (D074/D075)  Attach Fusing Roller Knob Holder  Level the Main Machine  Test Breaker Switch  Install Toner Bottles  Installation: Power On  Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Unpack		
Connect ARDF (D074/D075)  Attach Fusing Roller Knob Holder  Level the Main Machine  Test Breaker Switch  Install Toner Bottles  Installation: Power On  Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Install Attention Light		
Attach Fusing Roller Knob Holder  Level the Main Machine  Test Breaker Switch  Install Toner Bottles  Installation: Power On  Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Install Operation Panel		
Level the Main Machine  Test Breaker Switch  Install Toner Bottles  Installation: Power On  Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Connect ARDF (D074/D075)		
Test Breaker Switch  Install Toner Bottles  Installation: Power On  Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Attach Fusing Roller Knob Holder		
Installation: Power On  Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Level the Main Machine		
Installation: Power On  Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Test Breaker Switch		
Connect Main Machine to Power Source and Power On  Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Install Toner Bottles		
Start Toner Fill  SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Installation: Power On		
SP3051-001 (Manual Toner Fill)  Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Connect Main Machine to Power Source and Power On		
Initialize Process Control  SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Start Toner Fill		
SP3020-001 (Process Setup)  SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	SP3051-001 (Manual Toner Fill)		
SP3012-001 to check whether initialization was successful  Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	Initialize Process Control		
Exit SP Mode and Power Off  Fiery Controller Connection  Fiery Controller Setup	SP3020-001 (Process Setup)		
Fiery Controller Connection Fiery Controller Setup	SP3012-001 to check whether initialization was successful		
Fiery Controller Setup	Exit SP Mode and Power Off		
	Fiery Controller Connection		
Paper Library Data Installation	Fiery Controller Setup		
	Paper Library Data Installation		
Finishing the Installation			

Installation: Power Off

# **ACAUTION**

• The unit must be connected to a power source that is close to the unit and easily accessible.


Make sure that the main machine is switched off and that its power cord is disconnected before
doing the following procedures.

## **Rating Voltages for Connection Points**

## **ACAUTION**


• Be sure to plug cable connectors into the correct sockets.

## Right Side



- ARDF Max. DC24V (D0074/D075)
- LCIT [B]: Max. DC24V
- LCIT Anti-condensation Heaters [C]: Max. AC 230V ±10%

#### Left Side




d074c009

• Finisher [E]: Max. DC24V

## Unpack

### Removal from Pallet

The main machine must be removed from its pallet with a forklift.



d074i896

- 1. Knock down the front edge of the cardboard [A].
- 2. Insert the arms of the forklift at [B] and [C].

## Shrink Wrap, Bubble Wrap




d074i808

3. Remove shrink wrap [A] and bubble wrap [B].

## External Tape


- 4. Remove the tape from the front and right side.
- 5. Remove tape at the rear and left side.

## Shipping Rod




- d074i812
- 6. Open the front door.
- 7. Remove cover [A] ( \*\* x2).
- 8. Pull out the shipping rod.

#### ITB Lever



d074i813

9. Remove the tape and ITB lever.



- 10. Attach the ITB lever [A] to the tip of the bare shaft.
- 11. Rotate the lever up [B] to lock the ITB in place.

## **Right Drawer**



d074i895

- 12. Lower the handle.
- 13. Pull the right drawer out until it stops.
- 14. Remove the tape.

#### **Paper Trays**

- 15. Pull out the top tray and remove any tape and packing material.
- 16. Pull out the bottom tray and remove any tape and packing material.

#### **Factory Settings Sheet**



d074r992

- 17. The Factory Settings Sheet is stored at the factory under the used toner bottle.
- 18. Remove the sheet and keep it in a safe place.

#### RTR 20

Peel off and remove the bottom Mylar from the PTR entrance guide plate when making new customer site installations

## **Attention Light**



d074i815

1. The attention light is installed on the top rear edge [A] with accessory screws ( x3 M4x6).




- The three screws must be removed from their holes (these screws are not accessories).
- 2. Connect the light [B] (🗗 x1, 🖨 x2).



d074i816

- 3. Set the base of the light [A] in the socket so that the back of the socket [B] fits into the knockout.
- 4. Fasten the base to the main machine ( x3).

## **Operation Panel Installation**




d074i816a

There are four possible ways to configure the operation panel when it is installed.

Config.	Description
1	<b>Standard</b> . The support arm is perpendicular to the right side of the machine and the operation panel is recessed from the front of the machine.
2	<b>Standard Diagonal</b> . The support arm is set at an angle so that the operation panel is flush with the front of the machine.
3	Standard Diagonal Extended. The support arm is set an angle (same as Configuration 2) and the arm is extended so that the operation panel extends beyond the front of the machine.
4	<b>Easy Access (Sitting Position)</b> . This is the same as Configuration 3 but the operation panel is removed and re-hung on lower hooks so it is lower. This allows access to the operation panel from a sitting position.


- This installation procedure describes how to install the operation panel with Configuration 1 or 4.


# Install Operation Panel: Standard Installation



d074i860


1. Remove the right cover [A] ( Fx8).






d074i863

- 2. Set the arm on the machine and route the harness [A] down through the hole.
- 3. Reach inside the right side of the machine and pull the harness down to take up all of the slack.
- 4. Set the base of the arm [B] on the shoulder screws.




d074i864

- 5. Make sure that the base of the arm [A] is flat and that the wide ends of the keyholes on both sides are centered on the shoulder screws.
- 6. Push the base of the arm [B] to the left to lock the narrow ends of the keyholes onto the shoulder screws.
- 7. Make sure that the three screw holes in the base are aligned with the three holes below.



d074i865


8. Fasten the base of the arm [A] (  $\mathcal{F}$  x3).






d074i866

- 9. Set the back of the operation panel [A] in front of the mounting plate [B].
  - There are four cutouts on the back of the operation panel [A] and two hooks on the mounting plate [B]
  - The bottom cutouts ①, ② in the operation panel [A] are attached to the two hooks ①, ② on the mounting plate [B].
  - The other two cutouts on the back of the operation panel [A] (marked blue in the photo above) are not used.
- 10. Attach the operation panel to the mounting plate as shown on the right.



d074i867

- 11. At the back of the operation panel, make sure that both hooks are connected securely.
- 12. Connect the harnesses at [B] (🗗 x2).



d074i868

13. Fasten the back of the operation panel [A] to the mounting bracket [B] (\*\* x4 M4x6). You will need a short screwdriver to attach the screw at ①.



• You must use the M4x6 screws to fasten the operation panel at this step. If you use the longer screws (M4x8) they could touch and damage the operation panel board.




d074i871

14. Attach the convex rear cover to the back of the operation panel ( \*\mathcal{F} x2).




d074i872

15. Attach the flat rear cover above the lower cover (  $\slash\hspace{-0.6em}P$  x2).




d074i872a

16. Attach the arm cover ( 🗗 x2).



d074i873

17. Attach the screw covers on the top of the support arm, small screw cover at [A] and large cover at [B].




d074i874

- 18. On the right side of the machine where the right cover was removed:
  - [A] Fasten the nylon clamp ( $\mathcal{F} \times 1$ ).
  - [B] Connect the operation panel harnesses ( x2).
- 19. Re-attach the right cover ( x7).

# **Operation Panel: Easy Access Installation**


Follow this procedure to install the operation panel for easy access so it can be used from a sitting position.

1. Do Steps 1 to 4 of the previous procedure for the standard installation.




d074i863a

2. Route harness [A] down through the hole.



d074r289a


- 4. Remove shoulder screw [B] and re-fasten it at the upper hole (🔊 x1). The screws should now be diagonally opposite one another as shown above.



d074r290

5. Set the base of the arm [A] on the shoulder screws.

- 6. Make sure the base of the arm is flat against the top of the machine.
- 7. Push the support arm to the right to lock the base onto the shoulder screws. You can see the three holes of the base aligned with the holes below.




d074r291

8. Attach the base [A] ( \*x3).




- Make sure that these screws are fastened tightly.
- 9. Remove the screws on top of the support arm [B] ( \*\*x4). **Keep these screws.**



d074r292


- 10. At the bottom of the base [A], open the clamp and pull a short length of the harness out of the hole to create some slack in the harness (🚉 x1).
- 11. Slowly push the arm [B] to the left to extend it.




d074r293

- 12. Push the arm [A] to the left until the holes on the top of the arm are aligned with the four holes below.
- 13. At [A] re-attach the screws you removed in Step 9 ( Fx4).
  - **Important** 
    - Make sure that these screws are fastened tightly.
- 14. At the base of the arm [B], push the harness into the hole and close the clamp (🖼 x1).

### Display Installation for Easy Access





d074r294

- Remove cover [A] ( x1).
- 2. Push harness [B] down behind the mounting plate.




d074r294a

- 3. Position the back of the operation panel near the mounting plate.
- 4. Connect the operation panel harness [B] ( x2).
- 5. Raise the operation panel and hang the cutouts [C] (marked with red dotted lines) on the hooks (also marked with red dotted lines).



• You must hang the operation panel using the cutouts [C]. Do not use the cutouts closest to the mounting plate (marked with blue squares).




d074r295

- 6. Check the hooks at ① and ② to make sure that the operation panel [A] is hung correctly on the mounting plate [B].
- 7. Fasten the operation panel and mounting plate together ( \*x4 M4x6). (You will need a short screwdriver to attach screw [C]).



 You must use the M4x6 screws to fasten the operation panel at this step. If you use the longer screws (M4x8) they could touch and damage the operation panel board.



d074r869a


8. Fasten the harness cover to the back of the operation panel (  $\slash\hspace{-0.6em}P x 1$  ).



d074i869b

9. Loosen the swivel screw so that you have the full range of horizontal movement for adjusting the position of the operation panel. Do not remove this screw!

Cover Attachment




d074r296

- 1. Attach the convex plate [A] at the top (  $\mathcal{F}x$ ).
- 2. Attach the flat plate [B] at the bottom ( Fx).


## 

- In Configurations 1, 2, 3, the convex plate [A] is attached below, and the flat plate [B] is attached above.
- For this installation (Configuration 4), the positions of these plates are reversed as shown above. (The convex plate is attached above and the flat plate below.)



d074r297


- 3. Attach the arm cover [A] ( Fx2).
- 4. Attach the large and small screw covers [B].
- 5. Attach the support arm outer cover [B] ( \*x2).



d074i874

- 6. On the right side of the machine where the right cover was removed:
  - [A] Fasten the nylon clamp ( 🗗 x 1 ).
  - [B] Connect the operation panel harnesses ( x2).
- 7. Re-attach the right cover (🗗 x7).

## Opening the Toner Bank Door



d074r298

- With the operation panel [A] fully depressed, the toner bank door [B] cannot be opened.
- To open the toner bank door, swing the operation panel up, and then open the door.

## Connect ARDF (D074/D075)




d074i817

1. Connect the ARDF I/F cable on the right side of the machine.


## Attach Fusing Roller Knob Holder

A fusing roller knob is provided as an accessory.




d074r303a

This knob can be attached as shown and rotated by hand to feed jammed paper out of the fusing unit. This knob is stored in a holder that must be attached to the inside surface of the left front door. (Procedure described below.)



- 1. Open the left front door [A].
- 2. Use a clean cloth and alcohol to clean the surface around [B] on the inner surface of the left front door.



d074i881

3. Peel the strip from the back of the holder to expose its adhesive surface.



d074i882

4. Attach the holder to the door.



d074i883

5. Set the knob in the holder and close the door.

### Level the Main Machine

The machine must be leveled front-to-rear and side-to-side within ±2.5 mm/1000 mm.

- Install the leveling shoes, one at each corner of the main machine. Adjust the height of the legs so that the machine is level left-to-right.
- 2. Adjust the height of the legs so that the machine is level front-to-back.



 These leveling adjustments are critical. The level of all the peripheral options (LCIT, Finisher, etc.) must be adjusted to match the level adjustment of the main machine.

### **Test Breaker Switch**



The breaker switch is at the bottom corner of the rear right side of the machine. The optional ring binder also has a breaker switch.

The breaker switches should be tested at installation and after that at least once a year:


- After prolonged use, if the breaker switch is covered with soot, this could indicate that the switch has malfunctioned or been damaged.
- To prevent damage to the breaker switch, installation of a voltage stabilizer (constant voltage transformer) is recommended for work sites where there is significant fluctuation in the AC power source.


#### To test the breaker switch:


1. Plug the power cord into its power source.



• Do not turn on the main machine. The main machine must be off.







d074i855

- 2. To test the breaker switch:.
  - [1] is the normal position of the breaker switch test button.

- Use the tip of a small screwdriver or pen to push the breaker test button. The breaker switch should flip to the "O" position [2]. This indicates that the breaker switch is operating normally.
- If the breaker switch does not flip to the "O" position, the switch must be replaced.
- Push the switch up to the " | " position [3] for normal operation.



 The main machine will not turn on if the breaker switch is not returned to the "|" position as shown at [1].

#### **Install Toner Bottles**



• The toner bottles contain pre-mixed toner and developer.


#### **Toner Bottle Installation**





d074i818

- 1. Open the toner bank door [1].
- 2. Remove the yellow toner bottle [2] from its package.
- 3. Rock the bottle gently on its long axis to loosen the contents of the toner bottle.



d074i819

- 4. Insert the bare end of the bottle into the machine.
- 5. Turn the bottle so that the toner port [1] is down and the RFID chip [2] is up, with the protrusions [3] lined up with the grooves of the cover.



- The front end of each toner bottle has protrusions that fit snugly into grooves in each color holder. These grooves are arranged in a unique pattern to prevent installation of a toner bottle accidentally in the wrong position.
- If a bottle does not slide easily into the holder, make sure that the green RFID chip is facing up
  and the protrusions on the front end of the bottle match the pattern of the cutouts around the
  mouth of the holder.
- 6. Push the bottle in until you hear it click and lock.




d074i820

7. Repeat Steps 2 to 6 to install the other toner bottles from left to right in this order: Y, M, C, K. Be sure to rock each toner bottle along its length before you insert it.

RTB 71
Lubricate the drum cleaning blade after installing a new machine.


## **Attach Decals**

## D074/D075



- 1. Attach the decals at the locations shown above.
  - [A] Precautions for Printing decal
  - [B] Original Set Precautions decal
  - [C] Cleaning, Prohibited Copying decals
  - [D] Caution When Turning Off the Main Power Switch decal

### M044



- 1. Attach the decals at the locations shown above.
  - [A] Precautions for Printing decal
  - [B] Caution When Turning Off the Main Power Switch decal

### Installation: Power On

### Connect Main Machine to Power Source and Power On

- 1. Connect the power cord of the main machine to the power source.
- 2. Turn on the main power switch.



- The main power switch is behind the open left front door.
- 3. Watch the operation panel. The operation panel LED will light red, and you will see the "Door Open" alert on the operation panel.

### RTB 31 Change this part

### **Start Toner Fill**

- 1. Execute SP3051-1.
- 2. Watch the operation panel.

3. When you see "Complete", this means the machine has filled the sub hoppers of the toner supply unit.

Initial check results of SP3025 & SP3031

#### **Initialize Process Control**

- 1. Leave the front doors closed.
- 2. Execute **SP3020-001** to start process control. (Process control sets the machine for optimum operation based on the conditions around the drums.)
- 3. Watch the operation panel. When you see "Complete", the process control settings are done.
- 4. Check with SP3012-001 to make sure that initialization was successful.

#### Exit SP Mode and Power Off

- 1. Exit the SP mode.
- 2. Push the operation power switch on the operation panel to switch the machine off.
- 3. Switch the main power switch off.

## Fiery Controller Connection and Setup

#### Connect EFI Box to Main Machine



- Refer to the Fiery controller service manual for more details about the installation requirements for the controller.
- 1. Make sure the main power switch behind the left front door is off.
- 2. Set the Fiery controller box on the floor.



d074i857

3. Connect the shielded cable to the lower network cable slot of the Fiery Controller box.



 You must use the shielded cable provided with the accessories to connect the Fiery Controller box and the main machine.



d074i858

4. Connect the other end of the shielded cable to the controller box of the main machine. The correct connection point is marked "External CTL".



d074i858a

5. Connect the cable from the client network to the upper network cable slot.

### Connect the EFI Box Power Cord



d074i856

- 1. Connect the power cord to the back of the controller box.
- 2. Connect the other end of the power cord to a power source.

# Power On with Fiery Controller

1. Turn on the main power switch of the main machine.



d074i858b

2. Turn on the switch on the back of the Fiery Controller box.



d074i858c

3. Press and turn on the switch on the front of the Fiery Controller box.

## **Fiery Controller Setup**

### **Fiery Controller Selection**

- 1. Enter the SP mode.
- 2. Set SP5193-001 to "6" (Fiery controller).

RTB 31

Set the SP to 1, not 6.

### Fiery Language Selection


If the operator wants to use a language other than English to operate the Fiery controller, the language selection must be done first. To select a different language, the Fiery system must be re-installed. For details, the Field Service Manual for the Color Controller: E-41A.

### **Fiery Controller Settings**

You must do the Fiery controller settings immediately after you turn the machine on for the first time.


- Make sure that that the Activity light on the Controller LCD is flashing green and then go to the machine's operation panel.
- 1. Wait for the "Please wait" message to go off.
- 2. Press the "Fiery" tab on the LCD after the Fiery operating menu has appeared.
- 3. Press the "Setup" button on the operation panel.
- 4. The "Login" screen appears.
- 5. Press the "Password" button to open the soft keyboard.

- 6. Enter "Fiery. 1" with the soft keyboard, and then press the "OK" button.
  - Password entry is case sensitive (the machine distinguishes between lower case and upper case letters).
  - Use the "Shift" button to enter a capital letter.
- 7. The setup screen appears after you enter the password correctly.




g178i555


8. Press the "WINS" button.




9. Press the "Use WINS" button to disable this function then "Save".



10. Press the "DNS" button.




11. Press "Get DNS address automatically" to disable this function, and then press "Save". The button color turns gray to indicate that this button is disabled.




g178i559

12. Press "IP Address" to enter the IP address.




g178i560

13. Press "IPvd Address".



d074r001b

- 14. Press the "Manual Configuration Button".
- 15. Press the "IP Address" bar [A] to enter the IPv4 address, and then enter the IPv4 address.
  - The soft keyboard appears
  - Enter the IP address with the soft keyboard, and then press the "OK" button.
- 16. Press the "Subnet Mask" bar [B] to enter the subnet mask IP, and then enter the subnet mask IP.
  - The soft keyboard appears.
  - Enter the IP address with the soft keyboard, and then press the "OK" button.
- 17. Press the "Default gateway" bar [C] to enter the default gateway IP address, and then enter the default gateway IP address.
  - The soft keyboard appears.
  - Enter the IP address with the soft keyboard, and then press the "OK" button.
- 18. Press the "Save" button after IP address setting has been completed.
- 19. Press the "Go Back" button, then the "Exit Setup" button.




g178i563

- 20. Press the "Reboot Now" button.
- 21. The Fiery server and copier system automatically turn off to reboot.

## **Paper Library Data Installation**


Follow this procedure to install the Paper Library data.

- 1. Create a folder in the root directory of an SD card and name the folder "map".
- 2. Copy the paper database file into the "map" folder, and then rename the copied file "library.map".
- 3. Make sure that the machine is turned off.
- 4. Insert the SD card which has the "library.mqp" file into SD card Slot 2 (lower slot) on the right side of the controller box.
- 5. Turn on the machine.
- 6. Make sure that the data version of the SD card is newer than the data version of the flash ROM on the controller. If not, prepare the latest data version of the Paper Library on an SD card.
  - The version of the data on the SD card can be checked with SP5711-202.
  - The version of the data in the flash ROM on the controller can be checked with SP5711-201.



d095i612a

7. Enter SP5-711-001, and then touch [EXECUTE].



d095i612b

8. Next, touch [EXECUTE] again.



d095i613

- 9. When the machine displays "Completed" and prompts you to re-boot, touch [Exit] to leave the SP mode.
- 10. Turn off the machine and remove the SD card from SD card Slot 2.
- 11. Turn on the machine.
- 12. Check the Paper Library data version with SP5-711-201 (Flash ROM) to confirm that the Paper Library data has been updated.

## **Paper Trays**

### **Loading the Paper Trays**

Load each paper tray.

- 1. Move the side fence and bottom fence to the correct positions for the paper.
- 2. Attach the paper size decals to the front of the paper cassette trays and the tandem tray.
- 3. Load the left side of Tray 1 (tandem tray).
- 4. Close Tray 1 and confirm that the machine moves the stack in the left side of the tray to the empty right side of the tray.

5. Fill Tray 1 and Tray 2 with paper with the A4/LT paper provided with the machine.



• The size of the paper in Tray 2 is detected automatically.

### **Tray Paper Settings**

RTB 22 Check the settings in this RTB.

- 1. Press the [Paper Settings] key on the operation panel.
- 2. Select the Tray icon.



d095i809

3. Select the paper type and paper weight for each tray.



 The paper type and paper weight for the paper provided with the machine should be set to "Plain Paper" and "Weight 2".

# **Printing an SMC Report**

Print the SMC report. This is a complete list of all SP settings and defaults.

- 1. Go into the SP mode.
- 2. Do SP5990-6 to print a list of the non-default SP code settings for future reference.
  - The SP5990-1 (All) printout is about 140 pages single-sided.
  - SP5990-6 (non-default) requires only about 5 sheets.
- 3. Keep the SMC report in a safe location with the factory setting sheet under the used toner bottle.

# Test Color Print (D074/D075)

1. Make sure that A3 or DLT paper is in one of the trays. Use the same type of paper that the customer normally uses for color output.

- 2. Place a "Color Chart C-4" on the exposure glass.
- 3. Select the Full Color mode and print one copy of the chart. (This is the copy that you will use in the ACC procedure if calibration is necessary.)
- 4. Check the quality of the copy with the operators.

If the quality of the color is satisfactory, ACC adjustment is not necessary.

-or

If the quality of the color is not satisfactory, do the ACC adjustment described in the next section.

## ACC Adjustment (D074/D075)

Automatic color calibration (ACC) is done at the factory with the procedure below.

- Do this procedure only if the color quality is not satisfactory.
- If you do this procedure at installation, use the A4/LT paper provided with the machine.
- 1. Make sure that you have a copy of the C4 Color Chart before you begin, and write "Before ACC adjustment" in the Memo box.
- 2. Push [User Tools].
- 3. To print a color pattern, select "Maintenance"> "Auto Color Calibration".
- 4. Touch [Start].

Machine will start self-check before printing test pattern


Press [Start Printing].

5. Touch [Start Printing].

Now self-checking.

Test pattern will be printed.

Please wait.



The machine does process control, and then it prints a test pattern.

Place Test Pattern on the exposure glass correctly.

Then press [Start Scanning]

- 6. Remove the C-4 test chart placed on the exposure glass during the previous procedure.
- 7. Place the color test pattern face-down that you made in Step 4 and 10 sheets of blank paper on the color test pattern.
- 8. Make sure that the arrow and notation on the color test pattern ("Face down and align the arrow with the rear left corner of the exposure glass.") is at the rear left corner.
- 9. Touch [Start Scanning] on the display. The machine scans the pattern once.
  - If you see this message the "Scanning failed..." message after you press [Start Scanning], check the position of the pattern on the exposure glass.
  - Make sure that the arrow on the test pattern is in the upper left corner of the exposure glass.
- 10. Remove the pattern from the exposure glass and replace it with the C-4 Color Chart.
- 11. Touch [Exit] three times to return to the Copy mode screen.
- 12. Make another Full Color copy of the C4 Color Chart, and write "After ACC adjustment" in the Memo box...



13. Compare the results of the first copy marked "Before ACC adjustment" and the and the second copy marked "After ACC adjustment".

If the results of the second copy after ACC adjustment are better than the results of the copy before adjustment, you are finished.

-or-

If the results of the second copy are worse than the results of the first copy:

- Push the [User Tools] key.
- Touch "Maintenance"> "Auto Color Calibration"> "Previous Setting".
- 14. If the operator is satisfied with neither the first nor second copy:
  - Enter the SP mode and do SP3011-2 to execute process control.
  - Do this procedure again from Step 2.

# **MUSIC Color Registration Adjustment**

- 1. Push [User Tools].
- 2. Touch [Maintenance]> [Color Registration].
- 3. Touch [OK].

This completes color registration.

# **Checking the Print Quality**

The print quality must be checked after installation before the customer starts to use the machine. Here is a list of the points that must be checked and adjusted if necessary.

- Color Image Check. Make sure that the PS test page has solid colors without imperfections (no blotches, no scratches). Confirm that the density differences in the PS test pattern are clearly visible.
- Color Registration Check. Make sure that the grid lines on the test pattern are superimposed correctly.
- Ruled Line Check. Make sure that the grid lines on the test pattern are not scratched.
- Image Shift Check between 1st and 2nd Pages. Print a test pattern and fold it in half vertically and horizontally. Make sure that the vertical and horizontal center lines on the printed test pattern are not shifted with respect to the fold lines.
- Image Skew Check. Make sure the distance between the image edge and paper edge at two points in the main-scan direction and two points in the sub-scan direction are the same.
- Front and Rear Image Density Check. Check printing density on the front and back of pages by checking another test print.

The procedures for each of these checks are described below.

Request Regarding Reference Print Samples

# **Color Image Check**

#### Before You Begin...

- Use "T6000 (70W)", Mondi: Color Copy 100gsm or Hammermill Color COPY digital 28 lb (105gsm) paper to check the image quality of the printout.
- To do these checks at installation, use the accessory paper provided with the machine

#### **Procedure**

- 1. Turn on the main power switch.
- 2. Press the "Fiery" tab on the LCD.
- 3. Press the "Printable Info" button.
- 4. Press the "PS Test Page" button, and then the "OK" button.



- 5. Confirm that each 100% pattern [A] has a solid color without imperfections (no blotches, no scratches).
- 6. Make sure that the difference in the density between the 60% [B] and 50% [C] patterns is clearly obvious.

#### Recovery

Do one or both of these procedures if you see a problem on the printout.

- If you detected a solid color problem in the 100% patterns, enter the SP mode, and then execute process control manually with SP3011-2 (Density Adjustment).
- 2. If you could not see any difference between the 50% and 60% patterns, execute color calibration with the "Fiery Controller".

#### **Color Registration Check**

#### Procedure for Copier (D074/D075)

- 1. Turn on the main power switch.
- 2. Set a sheet of paper on the original tray of ADF.
- 3. Enter the SP mode and then select SP2109-3.
- 4. Select Pattern 8 (Grid Pattern Large), and then touch [OK].
- 5. Do SP5070-1 (Switching Print Application), select "3" (Copy), and then touch "COPY Window".

**RTB 54** 

This procedure was modified

- 6. Select a paper Tray and print mode (simplex or duplex).
- 7. Select the "Full Color" mode.



 Make sure that the "Full Color" mode is selected. Otherwise, the color registration check cannot be done correctly.

- 8. Press the [Start] key on the operation panel.
- 9. Confirm that the grid lines for each color are superimposed correctly.

#### Recovery

Do this procedure if you see the lines do not overlap correctly.

- 1. Exit from SP2109-3 and then select SP3011-4 (Full MUSIC).
- 2. Do SP2109-3 to print out Grip Pattern Large and then check the test pattern again.

#### Procedure for Printer (MO44)

- 1. Turn on the main power switch.
- 2. Enter the SP mode and then select SP2109-3.
- 3. Select Pattern 8 (Grid Pattern Large), and then touch [OK].
- 4. Press the "APL Window" button at the top of the LCD.
- 5. Select a paper tray and print mode (simplex or duplex).
- 6. Prepare the PC for printing.
- 7. Print a test page with the Fiery printer driver.
- 8. Confirm that the grid lines for each color are superimposed correctly.



- Do not use the [Print] button on the LCD to print the test pattern. Only a black and white image will be output if you use the [Print] button on the LCD. The color registration check requires a color image output.
- Make sure that the test page has black, red, green, and blue colors.

#### Recovery

Do this procedure if you see the lines do not overlap correctly.

- 1. Exit from SP2109-3 and then select SP3011-4 (Full MUSIC).
- 2. Do SP2109-3 to print out Grip Pattern Large and then check the test pattern again.

#### **Ruled Line Check**

#### Before You Begin...

- Use "T6000 (70W)", Mondi: Color Copy 100gsm or Hammermill Color COPY Digital 28 lb (105gsm) paper to check the image quality of the printout.
- To do these checks at installation, use the accessory paper provided with the machine.


#### Procedure for Copier (D074/D075)

- 1. Turn on the main power switch.
- 2. Set a sheet of paper on the original tray of ADF.
- 3. Enter the SP mode and then select SP2109-003.

**RTB 54** 

This procedure was modified

- 4. Select the Pattern No. 8 (Grid Pattern Large), and then touch [OK].
- 5. Print out the grid pattern sample for each single color with SP2109-5.




d074r988

- 6. Do SP5070-1 (Switching Print Application), select "3" (Copy), and then touch "COPY Window".
- 7. Select a paper Tray and print mode (simplex or duplex).
- 8. Select the "Full Color" mode.



- Make sure that the "Full Color" mode is selected. Otherwise, the color registration check cannot be done correctly.
- 9. Press the [Start] key on the operation panel. A grid pattern prints for the selected color.
- 10. Repeat this procedure for each color (2: C, 3: M, 4: Y, 5: K).



d074r994

11. Check that the grid lines for each single color test pattern are not scratchy.

#### Recovery

Do this procedure if you see any scratches in the lines.

- 1. Enter the SP mode and execute SP3011-2 (Density Adjustment).
- 2. Repeat the Ruled Line Check.

#### Procedure for Printer (MO44)

- 1. Turn on the main power switch.
- 2. Enter the SP mode and then select SP2109-3.
- 3. Select Pattern 8 (Grid Pattern Large), and then touch [OK].
- 4. Print out the grid pattern sample for each color with SP2109-5.
- 5. Press the "APL Window" button at the top of the LCD.
- 6. Select a paper tray and print mode (simplex or duplex).
- 7. Prepare the PC for printing.
- 8. Print a test page with the Fiery printer driver. A grid pattern prints for the selected color.
- 9. Repeat this procedure for each color (2:C, 3:M, 4:6, 5:K).

10. Confirm that the grid lines for each color test pattern are not scratched.



- Do not use the [Print] button on the LCD to print the test pattern. Only a black and white image will be output if you use the [Print] button on the LCD. The color registration check requires a color image output.
- Make sure that the color is correct for each test pattern.

#### Recovery

Do this procedure if you see the lines do not overlap correctly.

- 1. Exit from SP2109-3 and then select SP3011-4 (Full MUSIC).
- 2. Do SP2109-3 to print out Grip Pattern Large and then check the test pattern again.


## Image Shift Check between the 1st and 2nd Pages

#### Before You Begin...

- Use "T6000 (70W)", Mondi: Color Copy 100gsm or Hammermill Color Copy Digital 28 lb (105gsm) paper to check the image quality of the printout.
- To do these checks at installation, use the accessory paper provided with the machine


#### **Procedure**

- 1. Turn on the main power switch.
- 2. Press the "User Tool" button, and then the "Adjustment Settings for Skilled Operators" button.
- 3. For the D074/D075 only:
  - Select "0703: Switch Print Screen"
  - Select "Printer", then touch [OK] (Default: Copy).
- 4. Select "0101:Adjust Image Position With Feed Direction".
- 5. Press the "To Print Screen" button on the top of the LCD.
- 6. Select Tray and duplex print mode.
- 7. Press the [Print] button, and then [OK] to print the "Adjustment Printing" test pattern.




₩Note

• The information [A] indicates the paper size and side (1st or 2nd).



8. Fold the printed test pattern in half vertically [A] and horizontally [B].





- 9. Check the vertical and horizontal center lines [A] on the 1st page of the printed test pattern (shown as solid lines in the above diagram).
  - Make sure these lines are not shifted away from the fold lines [B] (shown as dotted lines in the above diagram).
  - Acceptable shift range: **≤** 1 mm
  - The diagram on the left above shows no image shift.
  - The diagram on the right shows a test pattern where the lines have shifted.
- Check the 2nd side of the test pattern to see if the lines have or have not shifted as on the 1st page.
   Acceptable shift range: ≤ 1 mm

#### Before You Begin Adjustment

- Adjustments for sub-scan shift and main-scan shift are required at machine installation.
- To adjust the sub-scan shift and main-scan shift, use the user program mode or SP mode described below.
- The adjustment for sub-scan shift can be done for each paper weight.
- The adjustment for main-scan shift can be done for each paper tray.

#### Adjustment





g178r914

- Adjust the sub-scan shift [A] on the 1st page with "0101:Adjust Image Position With Feed Direction" of the UP Skilled Operators mode or SP1001-001 to -007.
- 2. To adjust the sub scan shift [A]:

Use "0101: Adjust Image Position With Feed Direction" on the Skilled Operators mode to adjust the sub scan shift.

-or-

Execute SP1001-1 to 7.

- Enter a minus (-) value to shift the image towards the leading edge.
- Enter a plus (+) value to shift the image towards the trailing edge.
- 3. To adjust the main-san shift [B] on the 1st and 2nd pages:

Use "0102:Adjust Image Position Across Feed Direction" in the Skilled Operators mode -or-


Execute SP1003-1 to 7.

- Enter a minus (-) value to shift the image towards the front edge.
- Enter a plus (+) value to shift the image towards the rear edge.
- 4. Print out the test pattern in the User Tools mode and then check the printed test pattern.




- Side 1 and Side 2 can be adjusted together in the Skilled Operator mode with this machine.
- If fine adjustment is needed, we recommend using the Custom Paper Profile.
- Side 1 and Side 2 can be fine adjusted separately (main scan, sub scan, magnification) with the Custom Paper Profile feature described below.


#### Adjustment with Custom Paper Profile



The main does not use the Custom Paper Profile when it prints the pattern above.

Tray image adjustment is done using the Custom Paper Profile after image shift is checked in the customer print job, and then adjustment is done in Advanced Settings.





d074r989

The frame and crop mark data are printed on both sides of the paper when a print job is done to check the amount of shift between the front and back of the paper

#### **Procedure**

- 1. Before you start, check the content of the duplex printed paper of the tray for which the adjustment is to be done.
- 2. On the operation panel touch [User Tools] > [Login], and then after logging in touch [Admin] > [Paper Setting].

- 3. Select the tray for which the adjustment is to be done.
- 4. Select the Custom Paper Profile, and then touch [Advanced Settings].

A list of items that can be adjusted is listed in the table below. For more details about adjustment ranges and other details, please refer to the "Adjustment Item Menu Guide: TCRU/ORU.

No.	ltem	Description
08	Adj Image Position ofSide 1 With Feed	Adjust the horizontal position of the image to be printed on the side 1 of the paper.
09	Adj Image Position ofSide2 With Feed	Adjust the horizontal position of the image to be printed on the side 2 of the paper.
10	Adj Image Position ofSide1 Across Feed	Adjust the vertical position of the image to be printed on the side 1 of the paper.
11	Adj Image Position ofSide2 Across Feed	Adjust the vertical position of the image to be printed on the side 2 of the paper.
15	Adj Magnification of Side 1 Across Feed	Adjust the vertical image scaling on the side 1 of the paper according to the paper expansion or shrinkage.
16	Adj Magnification of Side 1 With Feed	Adjust the horizontal image scaling on the side 1 of the paper according to the paper expansion or shrinkage.
17	Adj Magnification of Side2Across Feed	Adjust the vertical image scaling on the side 2 of the paper according to the paper expansion or shrinkage.
18	Adj Magnification of Side2With Feed	Adjust the horizontal image scaling on the side 2 of the paper according to the paper expansion or shrinkage.

- 5. Touch [OK] after you change a setting to save it and return to the Profile screen.
- 6. Do a test print and check the results.

# **Image Skew Check**

#### Before You Begin...


- Use "T6000 (70W)", Mondi: Color Copy 100gsm or Hammermill Color COPY Digital 28 lb (105gsm) paper to check the image quality of the printout.
- To do these checks at installation, use the accessory paper provided with the machine

#### RTB 54

#### Procedure: Measurement Using the "Adjustment Printing" Test Pattern

This procedure was modified

- 1. Turn on the main power switch.
- 2. M074/M075: Open SP5070-1 (Switching Print Application), and then select "6" (Printer) (D074/D075).
- 3. Touch the "COPY Window" (D074/D075) or "APL Window" (M044) button at the top of the display.
- 4. Select a tray and the duplex print mode.
- 5. Touch [Print] to print the "Adjustment Printing" test pattern.



6. Measure the distance in the main scan direction between the image edge and paper edge at points [A<sub>1</sub>] and [A<sub>2</sub>] shown above.

Acceptable range:  $[A_1]$  -  $[A_2]$  < ±0.5 mm (A4 or LT SEF or more)

#### Procedure: Measurement Using "Trimming Area" Test Pattern

RTB 54


This procedure was modified


- 1. Turn on the main power switch.
- 2. Open SP5070-1 (Switching Print Application), and then select "6" (Printer) (D074/D075).
- 3. Do SP2109-3 and select Pattern 14 (Trimming Area), and then touch [OK].
- 4. Touch "COPY Window" (D074/D075) or "APL Window" (M044) at the top of the display.
- 5. Select a tray and the duplex mode.
- 6. Touch [Print] to print the Trimming Area test pattern.
- Measure the distance in the main scan direction between the image edge and paper edge at points [A1] and [A2] shown above.

Acceptable range:  $[A_1]$  -  $[A_2]$  < ±0.5 mm (A4 or LT SEF or more)

#### Procedure: Adjustment

- 1. After checking the gap between  $[A_1]$  and  $[A_2]$  described above, turn off the power of the machine, and then pull out the power cord.
- 2. Pull out the right drawer until it stops.





d074r037


- 3. Remove handle **B3** [A] ( \*\*\varphi x1).
- 4. Remove the knobs [B] (x4) ( \*\* x1 each)






d074r038

- 5. Disconnect the faceplate [A] ( \*\* x4).
- 6. Lower plate [B] so that it floats free.
- 7. Remove the faceplate. You may need to release plate [B] to free the faceplate.




d074r993

- 8. Loosen the screws [A] on adjustor [B].
- 9. Move adjustor [B] left or right to adjust the image skew.



If [A1] < [A2] move the adjustor to the right to compensate for the size of the gap (A2 - A1).</li>
 One notch on the scale = 0.15 mm



If [A1] > [A2] move the adjustor to the left to compensate for the size of the gap (A1 - A2).
 One notch on the scale = 0.15 mm

- 10. Tighten the screws on the adjustor, and then re-assemble the machine.
- 11. Re-connect the power cord, and then turn on the machine.
- 12. Check the image skew again.

## Front and Rear Image Density Check

#### Before You Begin...


- Use "T6000 (70W)", Mondi: Color Copy 100gsm or Hammermill Color COPY Digital 28 lb (105 gsm) paper to check the image quality of the printout.
- To do these checks at installation, use the accessory paper provided with the machine

#### Procedure for D074/D075

Do this procedure to check the ruled lines on the output.

RTB 54
This procedure was modified

- 1. Turn on the main power switch.
- 2. Set a sheet of paper on the original tray of ADF.
- 3. Enter the SP mode and open SP2109-003.
- 4. Select the No. 26 (Full Dot Pattern) in the test pattern list, and then touch [OK].



d074r988

5. Print out the solid image for each single color with SP2109-005: 2:Cyan, 3:Magenta, 4:Yellow, 5:Black.



- Do not select "1: Full Color" when a solid image is printed out. Too much toner coverage can cause the fusing unit to malfunction.
- 6. Do SP5070-1 (Switching Print Application), select "3" (Copy), and then touch "COPY Window".
- 7. Select a paper Tray and print mode (simplex or duplex).
- 8. Select the "Full Color" mode.



- Make sure that the "Full Color" mode is selected. Otherwise, the color registration check cannot be done correctly.
- 9. Press the [Start] key on the operation panel.
- 10. Confirm that there is no difference in the density of the solid image on the front and rear for each color.

#### Procedure for M044

- 1. Turn on the main power switch.
- 2. Enter the SP mode and open SP2109-3.
- 3. Select Pattern No. 26 (Full Dot Pattern), and then touch [OK].
- 4. Print out the solid image for each color with SP2109-5 (2:Cyan, 3:Magenta, 4:Yellow, 5:Black).



- Do not select "1: full Color" when a solid image is printed out. Too much toner coverage can cause the fusing unit to malfunction.
- 5. Touch "APL Window" at the top of the LCD.
- 6. Select a paper tray and print mode (simplex or duplex),
- 7. Prepare the PC for printing.
- 8. Print a test page with the Fiery printer driver. A solid image prints for the selected color.
- 9. Confirm that there is no difference in the density of the solid image on the front and rear for each color.




- Do not use the [Print] button on the LCD to print the test pattern. Only a black and white image
  will be output if you use the [Print] button on the LCD. The color registration check requires a
  color image output.
- Make sure that the color is correct for each test pattern.

#### Recovery

If there is a problem in the test, do these SP codes.

- SP2113-001 (K)
- SP2113-002 (C)
- SP2113-003 (M)
- SP2113-004 (Y)




In the illustration above the black arrow shows direction of feed and:

[A]	Leading edge
[B]	Trailing edge
[C]	Тор
[C]	Bottom

## Supplementary Explanation on the Front and Rear Image Density Check

Full coverage test patterns can be created using two colors for further verification of the front and rear image density check.

- 1. Open SP2109-3 and select a test pattern to print.
- 2. Open SP2109-5 and select "1" (Full Color).
- 3. Open SP2109-6 to 9 and confirm that each is set to default "15" (Density 100%).



d074r991

For example, if you do the test prints with the settings below, the two colors of the C and Y toner will create full-green coverage.


- Select SP2109-003 "No.26 (Full Dot Pattern)".
- Select SP2109-005 "1" (Full Color)
- Open SP2109-006 (Density: K) and -008 (Density: M), and then change both settings from "15" to "0".
- Open SP2109-007 (Density: C) and -009 (Density: Y), and then make sure that both settings are set to "15" (default settings).

### TCRU Setting

If the client is participating in the TCRU program, the TCRU feature must be initialized so the TCRU setting menus can be displayed.

- 1. Go into the SP mode.
- 2. Execute SP5185-001 (TCRU: Set Machine).

# Tray Heaters



d074f978

There are two heater switches on the front of the machine.

- The left switch [A] controls the operation of the paper bank heaters of the main machine and the LCIT heaters. This heater prevents the collection of moisture around the paper feed trays. It should be switched on when there the machine is subject to high humidity.
- The right switch [B] controls the operation of the ITB unit heaters. This heater keeps the area around the ITB warm to facilitate cold starts. It should be switched on in areas where it is cold, especially in the early morning hours.
- If the temperature sensor (a thermostat) inside the machine will automatically shut the heaters off if the internal temperature becomes too high.

#### When these switches are ON:

- The heaters turn on when the main machine is turned off (or enters energy save mode).
- The heaters turn off when the main machine is turned on again (or leaves energy save mode).

#### When these switches are OFF:

- The heaters do not turn on when the main machine is turned off (or enters energy save mode).
- Both heaters are turned OFF before the machine leaves the factory.

When these switches are ON and SP5965-1 is set to "1", the heaters always remain on.

- 1. Open the top tray.
- 2. Press the left switch [A] to set up the main machine tray bank heaters and the LCIT heaters.
- 3. Press the right switch [B] to set up the ITB unit heaters.

# 

- Do not switch on the heaters unless they are needed.
- Please explain to the operator that while the heaters can improve machine performance when humidity is high or temperatures are low, the heaters will consume slightly more power.


2

• Set SP5965-1 to "1" if you want to have the heaters on at all times. Use this setting only if the work area is extremely humid or exceptionally cold.

# Moving the Machine


The machine is extremely heavy. When it is necessary to move the machine even a short distance to relocate it, apply pressure only on the areas that are marked with red squares in the illustrations below.

# **Pushing the Machine**



d074i893


[A]	Front
[B]	Left Side



d074i894

[C]	Right Side
[D]	Rear

# Removing the Rear Boxes



If the machine cannot fit through a door, the cooling box ① and controller box ② can be removed. With both boxes removed the machine is 750 mm (30 in.) wide.

# Cooling Box



d074i831

1. If the ARDF is connected, disconnect it (D074/D075).



d074i832

2. Remove the screws on the flat edge of the cooling box door [1] (  $\slash\hspace{-0.4em}P$  x3).



d074i833

3. Slowly, swing the cooling box open.




d074i834

4. On top of the box, remove the screw covers (x4) and screws (  $\rlap{/}{\it F}$  x4).



d074i835

5. Remove the top cover.





d074i836


- 6. On the open side of the box [1], remove the screws ( \*\* x2).
- 7. On the hinged side of the box [2], remove the screws ( \*\bar{x} x3).






d074i837

- 8. On the back of the cooling box [1], remove the screws (  $\slash\hspace{-0.4em}P$  x8).
- 9. Remove the cooling box cover.



d074i838

10. Disconnect the harnesses (🗗 x2).




d074i839

- 11. Depress the release buttons [1] on both coolant hoses to disconnect them.
- 12. Use a cloth to soak up any fluid leakage from the hoses.

# 

- There will be a small amount of leakage.
- If there is a large amount of leakage, re-connect the hoses and disconnect them again.
- Cover the ends of the hoses with a plastic bag when you move the machine, to prevent drops
  of the liquid from getting on the customer's floor.






d074i840


- 13. On the inside panel, release the hose conduit band at [1] ( $\overline{\$}$  x1).
- 14. Pull the hose conduit [2] away from the box.






d074i841

- 15. Slowly pull the hose conduit and hoses [1] out of the cooling box.
- 16. Stow the conduit [2] inside the machine.



d074i842

- 17. Remove upper hinge cover [1] ( \*\bar{x} x 1).
- 18. Remove lower hinge cover [2] ( Fx1).




d074i843

19. Raise the handles.



- The cooling box weighs about 16 kg (36 lb).
- 20. Lift the box off its hinges and set it down.

# **Controller Box**



d074i844

1. Remove the screws from the flat edge of the controller box door (  $\slash\hspace{-0.4em}P$  x3).



d074i845

2. Slowly, swing the controller box open.



d074i846

3. On top of the box, remove the screw covers (x4) and screws (  $\ref{x4}$ ).



d074i847

4. Remove the top cover.



d074i848


- 5. On the hinged side of the box [1], remove the screws (  $\mathcal{F}$  x3).
- 6. On the open side of the box [2], remove the screws (  $\slash\hspace{-0.6em}P$  x2).





d074i849


- 7. On the back of the controller box [1], remove the screws ( \*\mathbb{P} x8).
- 8. Remove the controller box cover.
- 9. Swing the controller box open.



- 10. Remove plate [1] ( \*\bar{x} x2).
- 11. Disconnect fan harness [2] (🖨 x1, 💋 x1).
  - - The fan harness is thin and much smaller than the other harnesses. Be sure to disconnect it.


#### 12. Disconnect:

- [3] Harnesses ( x5, x8) and the ground clamp ( x1).
- [4] HDD connectors and ground wires ( x4, 2x2, x4).
- [5] Harnesses, ground wire, clamps (□ x2, x1, x3).
- [6] Harnesses, clamps ( x6, x4)
- [7] Harness ( x1, 2x3)
- Note
  - There are 7 fan harness connectors at [6]. They can be re-connected in any order.
- 13. At [7], disconnect the harness (🗗 x1, 🖨 x4).



d074i851

- 14. Remove upper hinge cover [1] ( Fx1).
- 15. Remove lower hinge cover [2] ( Fx1).



d074i852

16. Raise the handles [1].




- The cooling box weighs about 21 kg (47 lb).
- 17. Lift the box [2] off its hinges and set it down.

# 2

# A3/11"x17" Tray Unit (B331-14)

## **Accessories**




Check the quantity and condition of the accessories in the box against the following illustration and list.

No.	Description	Q'ty
1.	A3/DLT Tray	1
2.	Paper Size Decals	2
3.	Short Connector	1
4.	Pin Bracket	1
5.	Screw	2


# Installation

# **ACAUTION**


- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before
  doing the following procedures.




- Remove the stay [A] ( \$\beta x2 ).
- 2. Remove the retainers [B] [C] and the shipping material [D] ( Fx1).
- 3. Check the position of the front and back side fences and make sure that they are set for DLT or A3.
- 4. If you need to adjust the positions of the side fences for the paper to be loaded in the tray, remove the front panel [E] ( $\mathcal{F}$  x4).
- 5. Remove the fences and adjust their positions for the paper to be loaded:
  - [F] Front fence ( Fx1)
  - [G] Back fence ( Fx1)
  - [H] End fence ( Px1)



- 6. Open the front doors.
- 7. Pull out the tandem feed tray [A] completely.
- 8. Push the right tandem tray [B] into the machine.
- 9. Remove the left tandem tray [C] ( \*\* x2 left, \*\* x3 right).




- 10. From the left tandem tray, remove the front cover [A] (  $\mathcal{F}$  x3).
- 11. Pull out the right tandem tray [B] then remove it ( \*\varphi x2).



12. Insert the short connector [A] into the socket inside the machine [B].




• Hold the connector as shown in the illustration.




13. Using the screw removed in Step 9, attach the pin bracket [A] to the center rail.

- 14. Using the screws removed in Steps 11 for the right rail and screws provided in the accessories for the left rail, install the tray [B] on the right rail [C], center rail [D], and left rail [E].
  - Make sure that three screw holes [F] are visible before tightening the tray.



- If one of the three screw holes is not visible [G], the paper tray cannot be opened after the paper tray is closed.
- Tighten the screw holes indicated by triangle marks.
- Make sure that the pin on the bracket [C] is put through the hole in the bottom plate of the tray.




- 15. Re-install the front cover [A] ( Fx3).
- 16. Use SP5959-2 to select the paper size for Tray 1 (A3 or DLT).
- 17. After selecting the paper size, switch the machine off and on to change the indicator on the operation panel.

## Decurler Unit (D544)

## Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.





No.	Description	Q'ty
1.	Main Board unit	1
2.	Harness A (for motor)	1
3.	Harness B (for sensor)	1
4.	Screw (M4×8)	12
5.	Clamp (Black)	1
6.	Clamp (White)	2
7.	Sheet for upper/lower path adjustment	1
8.	Safety plate	1
9.	Connector guide plate A	1


2

No.	Description	Q'ty
10.	Connector guide plate C	1
11.	Decurler Unit	1

## Installation

## **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before
  doing the following procedures.



- 1. Prepare a place to lay the Decurler Unit [A].
- 2. Lay the Decurler Unit [A] on the carton box [B] as shown above so that the entrance gate of the decurler unit does not touch any object or the floor.
  - Keep this position before attaching this unit to the main machine.

## **ACAUTION**


• Do not lay the Decurler Unit on the floor with the entrance gate of the decurler unit facing downward. Otherwise, the mylars [C] on the entrance gate may be bent or folded.



3. Remove the left cover of the main machine (  $\slash\hspace{-0.4em}P$  x7).

## 


• Support the cover with your hand when you remove the last screw, to prevent the cover from falling.



4. Remove:


- [A] Bracket ( **?** x4).
- [B] Side stay ( 🗗 x4).
- [C] Guide plate ( Fx2).

## [D] Noise reduction plate ( 🗗 x3).




d544i004

- 5. Attach white clamps [A] and [B] (🖨 x2).
- 6. Attach **black** clamp [C] (♣x1).




7. Remove shipping plate [A] from the Decurler Unit ( \*\varPx4).



- 8. Lay the Decurler Unit down at the location prepared in Step 1.
- 9. Connect accessory harness A at [A] (🖾 x2).

### 

- The connectors at [A] have the same shape. Connect the white connector on the left (white-to-white) and the red connector on the right (red-to-red) as shown above.
- 10. Connect accessory harness B at [B] ( x1).




11. Align the safety plate [A] with the embossed guide and fasten it ( Fx2).



d544i007

12. Install the Decurler Unit [A] on the left side of the main machine ( Fx4).



d544i008


13. Route accessory harness A [A] (for the motor) through the white clamp, and close the clamp ( x1).

14. Route accessory harness B [B] (for the sensor) through the black clamp and the white clamp, and close the clamps (♠x2).




d544i009

15. On the front side at both ends of the connection bracket of the first downstream unit, remove the screws and replace them with the accessory screws provided ( \*\*x2 M4x8).




d544i028

16. Re-attach the bracket [A] ( Fx4).



d544i010

17. Align the bracket [A] of the board unit with the embossed guide and fasten it ( \*F x4).




d544i011

- 18. Connect accessory harness A at [A] ( x1).
- 19. Connect accessory harness B at [B] ( x1).
- 20. Route harness A through white clamp [C] and close the clamp (🖨 x1).
- 21. Route harness B through clamps [D] and [E] and close the clamps (🖨 x2).
- 22. At [F], make sure that the band is on the left side of the clamp.



• There must be no slack in harness B at [G]. This prevents the harness from interfering with the left drawer when it is pulled out.



d544i025


23. Release the unconnected harnesses at [A] and [B] from the main machine (🖼 x2).



- Do not remove the heavy tape at [C] This tape prevents the harnesses from interfering with reinstallation of the left cover.
- 24. Close the clamps again around the connected fan harnesses.

## **☆ Important**

• These fan harnesses must be clamped correctly at their original positions.



d544i026

- 25. Connect the harnesses [A] and [B] to the board ( $\square$  x2).
- 26. Clamp the harness at [C] (🖨 x 1).
- 27. Check the following:
  - Make sure that the sealed band on the harness [C] is positioned above the clamp as shown above.

• The taped portion of the harness [D] should be positioned away from the right cover screw hole as shown. This prevents the harness from interfering with re-installation of the cover.

## Installing the Guide Plate



- There are two connector guide plates "A" and "C".
- You must select the correct guide plate for the peripheral unit that will be connected to the left side
  of the main machine.
- Each guide plate is marked to tell you which guide plate to install. Refer to the table below.

Downstream Unit	Letter Embossed on Plate	
Multi Folding Unit		
Ring Binder	A	
Cover Interposer Tray		
Finisher (D512 or D513)		
High Capacity Stacker		
Buffer Pass Unit	Not Required	

1. If the Buffer Pass Unit is to be installed, skip this section and go to the next section.



d999i013

2. Remove the guide plate from the right side of the downstream unit ( \*\varphi x2). **Keep these screws in a** safe place!



3. Select the correct guide plate ("A" or "C") for the peripheral unit. The guide plate in the illustration above is marked "A" (for Multi Folding Unit, Ring Binder, or Cover Interposer Tray).




4. Attach the guide plate with the screws removed in Step 2.

When you attach guide plate A to the downstream unit:

- There are two sets of holes on guide plate A.
- Attach the screws to the outer holes (marked above by the red arrows) if the next downstream
  unit is the Multi Folding unit.
- Attach the screws to the inner holes (marked by the blue arrows) if the Ring Binder or Cover Interposer Tray is the next downstream unit.

### **SP Settings**


1. Switch on the machine and enter the SP mode.



d999i016

- 2. Refer to the accessory sheet and enter the settings for SP1927 and SP1928.
- 3. Exit SP mode and turn off the main machine.

### **Docking**



d999i018

- 1. Connect the downstream peripheral unit to the main machine.
- 2. Dock the downstream peripheral unit.
- 3. Turn on the main machine.
- 4. Make sure that the front door of the main machine and decurler unit are both closed.
- 5. Do SP5804-210. This sets the upper path in the decurler unit as the default paper path.



- If either door is open when you execute SP5804-210, the machine will issue SC593.
- In this occurs, execute SP5804-209, make sure both doors are closed, then cycle the machine off/on and execute SP4804-210 again.
- 6. Turn off the main machine.
- 7. Check if the upper path of the decurler unit is positioned as the default paper path.




Two procedures are described below. Do the procedure for whichever peripheral unit you
are installing.

### Guide Plate A

Follow this procedure if plate "A" is installed for:

- · Multi Folding Unit
- Ring Binder
- Cover Interposer Tray




d999i020

- 1. Look down between the machine and unit and locate the red reference points.
  - [A] is the red reference point on the downstream unit.
  - [B] is the red reference point on the Decurler Unit.
- 2. Remove the rear cover of the peripheral unit.
- 3. Adjust the leveling bolts on the left side of the main machine (front and rear corners) until reference points [A] and [B] are at the same height.

### Guide Plate C

Follow this procedure if plate "C" is installed for:

- High Capacity Stacker
- Finisher (D512 or D513)



d999i021

- 1. Look between the machine and unit and locate the reference points.
  - [A] is the cutout on guide plate C attached to the main machine.
  - [B] is the red reference point on the on the Decurler Unit.

- 2. Remove the rear cover of the finisher.
- 3. Adjust the leveling bolts on the left side of the main machine (front and rear corners) until the cutout [A] and reference point [B] are at the same height.


### **Curl Correction**

### **SP Mode Adjustments**

Turn on the machine and do some test prints and check for excessive curling.



• Do test prints with paper feed from each paper tray.



d999i022



d999i023

## Back Curl [A]

Back curling (convex curling) occurs when the leading and trailing edges of the sheets curl under.

### Face Curl [B]

Face curling (concave curling) occurs when the leading and trailing edges of the sheets curl up.

#### **Curl Correction**

Curl correction is done with settings in the SP mode. There are six SP codes for curl correction, one for each paper tray.

	Paper Source	SP No.	Range
Tray 1	1st Tray: Main Machine	SP1906 001	
Tray 2	2nd Tray: Main Machine	SP1906 002	, , , , , , , , , , , , , , , , , , ,
Tray 3	Top Tray: LCIT	SP1906 003	
Tray 4	Middle Tray: LCIT	SP1906 004	[0 to 5 / <b>3</b> / 1]
Tray 5	Bottom Tray: LCIT	SP1906 005	
Tray 6	Multi Bypass Tray: On top of LCIT	SP1906 006	

### 1st Tray Main Machine: SP1906 001

This is the list of settings (range) for Tray 1. These settings are identical for each paper tray.

Setting	Used For	Sample	
1	Slight Face Curl	Sample [B] in previous	
2	Excessive Face Curl	illustration.	
3	None. This is the normal default setting.	No pressure applied by soft roller.	
4	Slight Back Curl	Sample [A] in previous	
5	Excessive Back Curl	illustration.	

### **Tray Heaters**


If the machine is being used where humidity is high:

- Turn on the tray heaters of the main unit. This will prevent moisture from collecting around and in the paper trays while the machine is idle or switched off.
- If the LCIT is installed, recommend installing the optional tray heaters in the LCIT. This will prevent
  moisture from collecting around and the paper trays in the LCIT while the machine is idle or
  switched off.

# A3/DLT LCIT (D516)

## Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.



No.	Description	Q'ty
1.	Rear Cover	1
2.	Side Cover	1
3.	Top Cover	1
4.	Decals - Paper Set	3
5.	Tray Number Decals	3
6.	Flat Cover (for Bypass Tray D517)	1
7.	Tab Fences	3
8.	Front Cover	1
9.	Washer	1
10.	Screws (M4x8) - Blue	2

2


No.	Description	Q'ty
11.	Screws (M4x8) - Silver	10
12.	Binding Screw (with lock washer)	1
13.	Upper Joint Pins (Grooved)	2
14.	Lower Joint Pins (Smooth)	2
15.	Leveling Shoes	4
16.	Sponge Strip	1
17.	Frame – Sheet Metal	1

## Installation


## **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedures.

### Tapes, Retainers




- 1. At the front [A] and right, remove all visible tapes.
- 2. On the left [B], remove visible tapes.
- 3. Remove tape and cover from the I/F connector [C].




d516i020

4. Open each drawer and remove the tape.

### Covers





d516i001


1. Locate the positioning pins at the front [A] and rear [B].



d516i002


2. Position the holes on the bottom of the frame with the positioning pins at the front and back, and set the frame [A] on the left side of the unit.

3. Make sure that the holes and positioning pins [B] are engaged at the front and back.




d516i003

4. At the front, fasten the base of the frame [A] ( \*\bar{x} x 2 M4x8).



d516i004

5. At the rear, fasten the base of the frame [A] (  $\nearrow$  x2 M4x8).




d516i005

- 6. Attach the right cover to the right side of the frame.
  - First, set the bottom tabs of the right cover [A] into the cutouts in the flat plate.


• Next, set the claws on the left side of the right cover [B] into the holes in the frame.






d516i006

- 7. Check the left side under the top of the frame [A], and make sure that the claws and holes are matched correctly and that the right cover is flat against the right side of the frame.
- 8. Fasten the right cover [B] to the frame ( \*\*\begin{align\*} 2 \ M4x8 \end{align\*}).






d516i007

- 9. Set the top cover on top of the frame.
  - Insert the claws [A] on the left underside of the top cover into the holes in the frame.
  - At the same time, insert the tabs on the top left edge of the top cover [B] into the holes in the frame.



d516i008


10. Make sure the top cover is flat against the frame.






d516i009


11. Fasten the top cover at the front [A] and rear [B] (  $\slash\hspace{-0.4em}P$  x2 M4x8).



d516i010


12. Open the front door.






d516i011

- 13. Hang the keyholes in the bracket on the back of the front cover [A] onto the shoulder screws of the front frame plate [B].
- 14. Slide front cover [C] down until the top is flat and level with the top of the top cover [D].




d516i012

- 15. Attach the front cover [A] ( \*x2 M4x8)
- 16. Close the front door [B].




d516i013

- 17. Make sure the front cover is set correctly.
  - Top right edge [A]
  - Bottom right edge [B]




d516i014

- 18. Hang the keyholes in the bracket on the back of the rear cover [A] onto the shoulder screws of the rear frame plate [B].
- 19. Slide the cover [C] down so that the cover joints are at the same level.



d516i015

20. Fasten the rear cover [A] (  $\rat{x}2$  M4x8).



d516i016

- 21. Make sure the rear cover is set correctly.
  - Top left edge [A]
  - Bottom left edge [B]



d516i017


- 22. Peel the tape from the back of the sponge strip.
- 23. Attach the sponge strip [A] to the top left edge of the unit.

### **Docking**




- If you are going to install the Multi Bypass Tray or the LCIT tray heaters (or both), do this now before you dock the LCIT to the right side of the main machine.
- (**p**.216)

### **Ground Plate**




1. At the base of the left side of the unit, remove the ground plate ( \*\*x2). Keep these screws.




d516i022

- 2. Turn the plate over so that the tines [A] are pointing down.
- Re-attach the plate [B] at the same holes, using the screws that you just removed ( x2).
   Covers, Joint Brackets




- 4. Use the tip of a small screwdriver [A] to remove the six snap-off cover plates from the left side of the main machine.
- 5. The heater connection point cover [B] requires removal of one screw ( Fx1).



d516i024

6. Attach the two joint pins with the grooved heads to the top two holes.




d516i025

7. Attach the two joint pins with the smooth heads to the bottom two holes.


### Ground Wire

• If the LCIT tray heaters are to be installed, follow steps from 8 to 12. If not, skip these steps.



d516i026


- 8. Pull the ground wire out of the machine.
- 9. Push the unit toward the side of the main machine until the unit and main machine are about 30 cm (1 ft.) apart.




10. Attach the ground wire [A] with the washer [B] to the base of the main machine (ground screw; \*\*\vec{x}\).



• The ground screw is provided with the accessories of the LCIT. It has a wide flat head and one washer permanently attached.






d516i028

- 11. Locate the ground wire [A] between the main machine and LCIT.
- 12. Push it into the base of the LCIT [B] and confirm that it is straight.




• In order prevent damage to the ground wire, make sure that it is straight so that it will not be pinched between the main machine and LCIT after they are pushed together.

### **Docking**




d516i029

- 13. Open the front door of the LCIT.
- 14. Remove the lock screw [A] ( \*x1). Keep this screw!
- 15. Pull the spring loaded lever [B] forward and let it snap back to confirm that it is moving freely.



d074i886

- 16. Push the LCIT close to the right side of the main machine.
- 17. On the left side of the main machine [A], check the height of the LCIT paper exit [B].
- 18. Move the main machine entrance plate [C] up and down and confirm that it does not contact the paper exit of the LCIT.




19. If the main machine entrance plate does touch the LCIT exit, adjust the height of the LCIT. (IPp. 322)



d516i030

- 20. Line up the joint brackets on the main machine with the holes in the LCIT.
- 21. Slowly push the LCIT against the main machine. You will hear the lock bar of the LCIT lock onto the upper joint pins on the right side of the main machine.





d516i031

- 22. Open the front door.
- 23. Re-attach the lock screw [A] ( \*\* x 1).
- 24. Hang one tab fence [B].



• Three tab fences are provided, but only one can be stored inside the LCIT. Give the remaining two tab fences to the operator for safekeeping.

### I/F Cable Connection




d516i032

25. Attach the LCIT I/F cable to the right side of the machine.

### **Tray Number Decals**

One tray number decal is provided for each tray. Follow this procedure to attach each decal.

Tray	Decal No.
Тор	3
Middle	4
Bottom	5




- 1. Attach the decal [1] above the tray LED.
- 2. Pull the back strip [2] from behind the upper part of the decal, and then press where the strip was removed.
- 3. Pull the back strip [3] from behind the lower part of the decal, and then press where the strip was removed.
- 4. Pull the clear sheet [4] from the surface of the decal.

## LCIT (D516) Tray Heaters

### Accessories


Check the accessories against the list below.



No.	Description	Qty
1.	Cover Plate	1
2.	Heaters (230V 18W)	2
3.	Screws (M4x6)	7
4.	Harness Clamps (small)	2
5.	Harness Clamps (large)	2
6.	Relay Harness (long)	1
7.	Relay Harness (short)	1

## **☆ Important**


- The accessory kit contains items for this and other LCIT units.
- Only the items shown below are required for this LCIT.




### Installation

## **ACAUTION**

Make sure that the main machine is switched off and that its power cord is disconnected before
doing the following procedure.





d453i451


- 2. If the LCIT is already installed, disconnect it and pull it about 30 cm (12 in.) away from the side of the main machine.
- 3. Disconnect ground wire [A].
- 4. Disconnect the LCIT I/F connector [B].
- 5. Pull out the top drawer. (This makes it easier to remove the right cover of the LCIT.)



d453i452


- 6. Remove the screws from the right cover of the LCIT ( \*\mathcal{P} x6).
- 7. Hold the bottom of the right cover, push it to the left to disconnect the hooks at the top edge of the cover, and pull it away.

### 8. Close the top tray.




d453i453

- 9. Pull out the middle tray and bottom tray [A] until they stop.
- 10. Look into the right side of the LCIT and locate the holes [B] where the heaters will be installed.




- 11. Attach the front heater [A] ( Fx2).
- 12. Attach the rear heater [B] ( Fx2).
- 13. Pass the relay harness [C] through the right side of the LCIT and connect it to the heaters (🕮 x2).
- 14. Attach the cover plate [D] ( Fx3).
- 15. Load paper in the paper trays.
- 16. Push the trays into the LCIT.
- 17. Reattach the right cover ( Fx6).



18. Close the clamps around the harnesses (🖨 x4).



- Be sure to use the correct type of clamps. On the left use type [A], and on the right use type [B].



- 20. Remove the cover [A] (  $\mathcal{F}$  x 1).
- 21. Attach the LCIT relay harness [B] to the mainframe.
- 22. Reconnect the ground wire [C] to the mainframe ( $\mathcal{F}x1$ ).
- 23. Dock the LCIT to the mainframe.
  - Lock bar ( 🗗 x 1 )
  - Interface cable


## 

- Confirm that the relay harness and the ground wire are not pinched between the mainframe and the LCIT.
- Be sure to pull out the top tray before you try to re-install the right cover. (It is easier to re-install the cover with the top tray open.)

# Multi Bypass Tray (D517)

## Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.



No.	Description	Q'ty
1.	Tab Sheet Fence	1
2.	Sponge Strip	1
3.	Bracket	1
4.	End Fence	1
5.	Decal (Tray 6)	1
6.	Screws (M4x8)	2
7.	Screws (M4x6)	4
8.	Left Cover	1
9.	Joint Pins	2

## Installation

# **ACAUTION**

• The unit must be connected to a power source that is close to the unit and easily accessible.

Make sure that the main machine is switched off and that its power cord is disconnected before
doing the following procedures.


#### Before You Begin...

- The Multi Bypass Unit must be installed on the LCIT before the LCIT is docked to the mainframe.
- If the LCIT is already installed, it must be disconnected from the mainframe before installation of the Multi Bypass Unit.

#### If the LCIT Has Already Been Installed...

Skip to the next section if you are installing the LCIT and bypass tray together.

- 1. If the LCIT is connected to the machine, disconnect it.
- To prevent damage to the connectors and ground wire, before pulling the LCIT away from the mainframe:
  - Pull the LCIT about 20 cm (8") away from the main machine.
  - Disconnect the connectors and the ground wire ( x1 M4x8)
  - Pull the LCIT completely away from the machine.
- 3. Remove the sheet metal frame on the left top edge of the LCIT, and its covers:




d516i018

- 4. Open the front door [1].
- 5. Remove the covers:
  - [2] Front cover ( \*\* x2 M4x8).
  - [3] Rear cover ( Fx2 M4x8).
  - [4] Top cover ( \*\bar{\mathbb{e}} x2 M4x8).
  - [5] Side cover ( 🗗 x2 M4x8)
- 6. Remove the frame [6]




• Do not remove the sponge strip from the left side of the frame.

# Unpacking




- 1. Remove the accessory packet [A] and open it.
- 2. Remove all tape and shipping materials.

#### **Flat Covers**




1. Remove the left top cover [A] ( \*x2 M4x8).




d517i003

- 2. Disconnect the right top cover [A] ( \*x2 M4x8). **Keep these screws!** You need them to attach the next cover.
- 3. Slide the cover to the right to disconnect the claws under the right edge, then lift it off.



d517i004

- 4. Attach the top cover [A] with the screws removed from the previous flat cover ( \*\* x2 M4x8).
  - This large cover is provided with the LCIT accessories.
  - This large cover (like the previous cover) has three large claws under the right edge. Make sure these claws engage in the holes in the LCIT frame.






d517i005

5. Set the bracket [A] and fasten it ( Fx1 M4x6).

# Mounting and Connecting the Bypass Unit



1. Attach the joint pins [A] and [B].




2. Locate the alignment marks for the bypass unit.

- Two thin vertical lines [A] on the bypass unit (one on the front, one on the rear).
- Two arrows on the LCIT frame cover [A] at the front, [B] at the rear.
- These lines and arrows must be aligned correctly when you mount the bypass tray on top of the LCIT.

## **ACAUTION**


The bypass unit weights 20 kg (44 lb.). You may need assistance to set the bypass unit on top
of the LCIT.





d517i008

3. Pick up the bypass unit on its left side [A] and right side [B].



d517i007a

4. Set the bypass unit on top of the LCIT. Align the thin lines on the front [A] and rear [B] of the bypass covers with the arrows on the front and rear sides of the LCIT frame.



 Aligning these points ensures that the holes on the bottom of the bypass unit will slip easily over the vertical joint pins on the LCIT.



d517i009

5. Open the bypass unit.






d517i010


6. Remove the front cover [A] ( \*x1 M4x8).



d517i011


7. Fasten the front side of the bypass unit ( \*Fx1 M4x6).






d517i012

8. Remove the rear cover [A] (  $\mathcal{F}$  x2 M4x8).





d517i013


- 9. Fasten the rear side [A] of the bypass unit ( Fx1 M4x6).
- 10. Free the harnesses [B] (🖨 x 1).



d517i014


11. Connect and clamp the harnesses (🗗 x3, 🖨 x1).

# **Bypass Covers**




d517i015


1. Set the left cover [A]. Make sure that the claws are set correctly in their holes.



d517i016

2. Fasten the left cover [A] ( \*\*\bigsiz x2, M4x8).






d517i017

3. Re-attach:

- [A] Front cover ( \* x1 M4x8)
- [B] Rear cover ( \*\* x2 M4x8)



- d517i018
- 4. Remove the tape from the sponge strip [A].
- 5. Position the sponge strip to the left side of the bypass unit.

## **LCIT Covers**




• The frame, covers, screws and sponge strip in this section are provided with the LCIT accessories.




d517i019

1. Remove the right stay [A] from the frame ( \*\* x2 M4x8).




- 2. Position the holes on the bottom of the frame with the positioning pins at the front and back, and set the frame [A] on the left side of the unit.
- 3. Make sure that the holes and positioning pins are engaged at the front and back.



d517i021


4. At the front, fasten the base of the frame [A] ( \*\* x2 M4x8).






d517i022


5. At the rear, fasten the base of the frame [A] (  $\nearrow$  x2 M4x8).






d517i023

- 6. Set the top cover on top of the frame.
  - Insert the claws [A] on the left underside of the top cover into the holes in the frame.
  - At the same time, insert the tabs on the top left edge of the top cover [B] into the holes in the frame.







d517i024

7. Fasten the top cover.

[A] Front ( Fx1 M4x8)


[B] Rear ( Fx1 M4x8)






d517i025


- 8. Open the front door.
- 9. Hang the keyholes in the bracket [A] on the back of the front cover onto the shoulder screws of the front frame plate.
- 10. Slide the front cover [B] down until the top is flat and level with the top of the top cover.
- 11. Fasten the front cover ( \*\* x2 M4x8).
- 12. Close the front door.






d517i026


- 13. Make sure the front cover is set correctly.
  - Top front edge [A]
  - Bottom front edge [B]






d517i027

14. Hang the keyholes in the bracket on the back of the rear cover [A] onto the shoulder screws of the rear frame plate [B].




d517i028

- 15. Slide the cover [A] down so that the cover joints are at the same level.
- 16. Fasten the rear cover ( \*\bar{x} x 2 M4x8).



d517i029

- 17. Make sure the rear cover is set correctly.
  - Top rear edge [A]
  - Bottom rear edge [B]




d517i030

- 18. Peel the tape from the back of the sponge strip if the sponge strip has not been attached to the LCIT.
- 19. Attach the sponge strip [A] to the left edge of the frame.
- 20. Close the bypass unit [B].

#### End fence and tab sheet fence




• The items in this section are bypass unit accessories.




d517i031

1. Set the end fence [A].




2. Store the tab sheet fence [A] as shown. Also store the end fence [B] here if the customer does not need to use it at this time.

## **Attaching the Tray Number Decals**



1. Attach the number decals to the front of the unit as shown above.



- 2. First, attach the "6" decal [1] at the position shown.
- 3. Pull the back strip [2] from behind the upper part of the decal, and then press where the strip was removed.
- 4. Pull the back strip [3] from behind the lower part of the decal, and then press where the strip was removed.
- 5. Pull the clear sheet [4] from the surface of the decal.
- 6. Follow the same procedure to attach the "3" and "4" decals.

#### 9

## Docking, Height Adjustment


Follow the procedures in the LCIT installation section to complete this installation.

- Docking (\*\*p.203)
- Height adjustment (Pp.322)

# Buffer Pass Unit Type 5010 (D548)

## **Accessory Check**

Check the quantity and condition of the accessories in the box against the following list:



No. **Description** Q'ty 1. Screws 6 Leveling Shoes 2. 4 Docking Bracket (L) 1 3. Docking Bracket (R) 1 4. 5. Mylars 4 Caution Decal for Multi Power Sources 1 6. Sponge Strip - Long Hooked 1 7. 8. Sponge Strip - Long Straight 1 9. Sponge Strip - Medium Straight 3 10. 1 Sponge Strip - L 1 11. Sponge Strip - Short Straight 12. Power Cord 1 13. **Ground Plate** 1


2

## Installation

# **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedures.
- The buffer pass unit is unstable and can fall over easily. To avoid personal injury or damage to the
  unit, use caution when you pull out the buffer pass unit drawer until the unit has been docked to the
  main machine.
- The power cord that comes with the buffer pass unit is for use with this equipment only. Do not use it with other appliances. Doing so could result in fire or electric shock.

## Unpacking



- d548i101
- 1. Remove all visible external tapes on the external surfaces.
- 2. Open the front door and remove all visible tapes.

## **ACAUTION**


- There are no tapes inside the unit.
- The unit is top heavy and unstable. Use caution when you pull out the buffer pass unit drawer until this unit has been docked to the main machine.

## Ground Plate, Unit Entrance Mylars



d666i010

1. Remove the right cover of the buffer pass unit ( \*\* x6).




d666i011

2. Attach the ground plate ( Fx2).

## **Buffer Unit Entrance Mylars**


This procedure describes how to attach two mylars to the entrance guide of the Buffer Unit.

- 1. Check the main machine and determine if the Decurler Unit option is installed.
  - If the Decurler Unit option is installed, do not install the mylars. Re-attach the right cover, and go to 'Docking the Unit'.
  - If the Decurler Unit is not installed, follow this procedure to attach two mylars to the entrance guide of the Buffer Unit.




d548i250

2. On the right side of the Buffer Unit, remove the entrance guide [A] ( Fx2).



- 3. One mylar is attached to the underside of the upper plate of the Buffer Unit entrance guide [A].
  - Select one mylar ① and remove the tape.
  - Position the mylar as shown 2 and attach it to the underside of the upper plate.
- 4. One mylar is attached to the topside of the bottom plate of the Buffer Unit entrance guide [B].
  - Select one mylar 3 and remove the tape.
  - Position the mylar as shown 4 and attach it to the topside of the lower plate.
- 5. Re-attach the entrance guide, and then re-attach the right cover.

## **Sponges**




1. Remove the tape from each sponge strip and attach them to the right side of the unit as shown above.



- The two yellow sponge strips in the illustration are provided as accessories with the main machine. The other strips are accessories provided with this peripheral unit.
- 2. After attaching all sponges, use a sharp cutter to cut the sponge on the corner at [A].

## Docking the Unit to the Mainframe

#### **Joint Brackets**




- 1. Attach the docking brackets to the main machine:
  - [A] Rear ( 🗗 x2)
  - [B] Front ( Fx2)
- 2. Open the front door.

## Docking



d666i004

- 1. Pull out the locking lever ( Fx 1).
- 2. Push the buffer pass unit against the main machine.



d666i005

3. Push in the lock lever and fasten it with the screw just removed (  $\mathcal{F}$  x 1).




d666i006


4. Connect the I/F cable of the buffer pass unit to the socket of the main machine.

## 2

# Removing the Shipping Brackets



1. Open the front door [A] and remove tapes [B].



2. Remove two screws [A] on the clamp bracket [B].


3. Slowly pull out the buffer pass unit drawer [C].

## **ACAUTION**

- Work carefully! The unit is unstable with the drawer pulled out and can tip over easily before it is docked to the main machine.
- 4. Remove the clamp bracket [B] ( Fx 2).
- 5. Remove the four shipping brackets [D] ( Fx 1 each).
- 6. Push in the buffer pass unit drawer [C].
- 7. Close the front door.

## Connecting the Downstream Peripheral

#### **Connection Bracket**




1. Attach the docking bracket provided with the downstream peripheral to the left side [A] of the buffer pass unit ( \*\*\varPsi x4).

#### Downstream Unit Mylars




- Two mylars must be attached to the upper and lower plates on the entrance guide of the downstream unit.
- 1. Remove the entrance guide of the downstream unit ( Fx2).



- 2. One mylar is attached to the underside of the upper plate of the downstream unit entrance guide [A].
  - Select one mylar ① and remove the tape.
  - Position the mylar as shown 2 and attach it to the underside of the upper plate.
- 3. One mylar is attached to the topside of the bottom plate of the downstream entrance guide [B].
  - Select one mylar 3 and remove the tape.
  - Position the mylar as shown 4 and attach it to the topside of the lower plate.
- 4. Re-attach the entrance guide, and then re-attach the right cover.
- 5. Re-attach the entrance guide to the downstream unit ( Fx2).


#### Connect the Power Cord

1. Connect the power cord to the buffer pass unit and connect the other end of the cord to a power outlet.



2. Approximately 30 mm (1 in.) from the plug, attach the caution decal [A] for multi power sources to power plug [B] (NA) or [C] (EU) of the main machine.

## Leveling the Unit




- 1. Set the leveling shoes and adjust the height of the unit. (\*\*p.322)
- 2. Load some B4 paper in the 2nd tray of the main machine, and make several copies.
- 3. Check paper skew and side-to-side registration and correct if necessary. (\*\*p.324)

## 2

# Cover Interposer Tray (D518)

## Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.



No.	Description	Q'ty
1.	Base Cover (Tray Unit)	1
2.	Front Cover	1
3.	Spacer	1
4.	Relay Guide Plate	1
5.	"L" Hinge Pins (Tray Unit Front Cover)	2
6.	Sponge Strip	1
7.	Leveling Shoes	4
8.	Joint Bracket	1
9.	Screw (M4x8)	4


No.	Description	Q'ty
10.	Screw (M3x8)	1
11.	Screw (M3 x 6)	2
12.	Screw (M4 x 8)	2
13.	Knob Screw	3
14.	Flat Knob Screw (M3 x 8)	1
15.	Shoulder Screw	2

## Installation

# **CAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedures.

## **Tapes**



1. Remove all the tape and shipping materials from the tray unit [A].


- 2. Remove all tape and shipping material [B] from the transport unit [C].
- 3. Remove tape and covers from both connectors [D].

## Sponge Strips, Relay Guide Plate, Ground Plate

## Mportant (

- There are two procedures for installation of the sponge strips.
- Follow "Procedure 1" below if the Cover Interposer Tray will be connected to the Buffer Pass Unit.
- Follow "Procedure 2" if the Cover Interposer Tray will be connected directly to the main machine (more sponge strips are required).


#### Procedure 1



- 1. Peel the tape from the back of the sponge strip [A] and attach it as shown.
- 2. Attach the relay guide plate [B] ( F x2).
- 3. Remove the ground plate [C] from the bottom cross-piece ( x2).
- 4. Turn the ground plate over.
- 5. Reattach the ground plate with the same screws as shown ( \*x2).

#### Procedure 2

1. Attach the relay guide plate and ground plate as described in "Procedure 1" above.




2. Remove the tape from each sponge strip and attach them to the right side of the unit as shown above.




- The two yellow sponge strips in the illustration are provided as accessories with the main machine. The horizontal sponge strip is provided with the Cover Interposer Tray.
- 3. After attaching all sponges, use a sharp cutter to cut the sponge on the corner at [A].


# **Docking**



- 1. If the upstream unit is the main machine, remove the interface connector cover.
- 2. Attach the joint bracket [A] to the upstream unit ( \*\bar{x} x 4).



- 3. Push the unit close to the upstream unit.
- 4. Loosen the screws for the rear runner [A] and front runner [B]
- 5. Push the runners in and re-fasten them with the screws.



- 6. Open the front door [A] of the cover interposer tray.
- 7. Remove the screw of the lock bar [B]. Keep this screw.
- 8. Pull out the lock bar until it stops.
- 9. Push the unit [C] against the upstream unit so that the lock bar is below the joint bracket [D].

- 10. Connect the unit's cable [E] to the upstream unit.
- 11. Push in the lock bar [B] and fasten it with the screw removed in **Step 7**.
- 12. Close the front door.

## **Dock the Downstream Peripheral Unit**



- The tray unit of the cover interposer tray is supported by both the cover interposer transport unit and the top of the downstream peripheral unit.
- The next peripheral device downstream must be docked to the cover interposer tray relay unit (the base) before the cover interposer tray unit can be installed.


Go to the appropriate section to dock the next downstream peripheral unit before installing the tray unit of the cover interposer tray:

- Multi Folding Unit (IPp.256)
- Ring Binder (1 p.266)
- High Capacity Stacker (\*\*p.282)
- Finishers ( p.294)


# **ACAUTION**

- Never attempt to mount the tray unit of the cover interposer tray until the next downstream peripheral unit has been docked to the transport unit (base) of the cover interposer tray.
- To prevent bending the frame of the tray unit and damaging its alignment, always remove the tray
  unit from the cover interposer tray transport unit at the following times: 1) Before disconnecting
  either the cover interposer tray or the next downstream peripheral unit, or 2) Before doing any
  maintenance on either the cover interposer tray or the next downstream peripheral unit.

## **Mounting the Tray Unit**




- 1. Remove the rear cover [A] ( Fx2). Keep these screws.
- 2. Confirm that the connectors [B] are free.
- 3. Place the tray unit [C] on top of the cover interposer transport unit and the downstream unit.
- 4. Attach the knob screw [D] ( \*\bigset x1).
- 5. Connect the harness connectors [E] ( x5).
- 6. Reattach the rear cover with the screws removed in Step 1.




- 7. Remove the front inner cover [A] from the tray unit (  $\mathcal{F}$  x2).
- 8. Fasten the tray unit to the top of the transport unit with the knob screws [B] (  $\mathcal{F}$  x2).
- 9. Attach the base cover [C] (Flat knob screw;  $\mathcal{F}$ x1).
  - **☆ Important** 
    - Make sure the holes in the cover match the positions of the reference pins.
- 10. Use the two "L" hinges to attach the door [D] to the front inner cover [A].



- It is easier to connect the door to the front inner cover before re-attaching the cover to the tray unit.
- 11. Re-attach the front inner cover [A] (with door attached) ( Fx2).
- 12. If the Buffer Pass Unit is installed, remove its rear cover.



- 13. At the back of the cover interposer tray, remove:
  - [A] Upper cover ( Fx4)
  - [B] Lower cover ( Px2)




- 14. With the rear covers of both the buffer pass unit and cover interposer unit removed, use a short screwdriver to loosen bracket [A] ( \*\*x2\*).
- 15. Fasten the bracket to the buffer pass unit at [B] ( Fx1).
- 16. Tighten the screws ( \*x3).
- 17. Re-attach the rear covers.



d518i302

18. Attach the shoulder screws to the front of the unit ( $\triangle x2$ ).




- 19. Set the spacer [A].
  - Hang wide ends of the keyholes of the side of the spacer over the heads of the shoulder screws.
  - Slide the spacer up to set the heads of the shoulder screws in the narrow end of the keyholes [B] and [C].



d518i304

20. Fasten the spacer to the unit ( \*\* x2 M4x8)

## Finishing the Installation




- 1. Set the leveling shoes and adjust the height of the unit. (\*\*p.322)
- 2. Load some B4 paper in the 2nd tray of the main machine, and make several copies.
- 3. Check paper skew and side-to-side registration and correct if necessary. (\*\*p.324)

# **Multi Folding Unit (D521)**

## Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.



No.	Description	Q'ty
1.	Joint Bracket	1
2.	Paper Guide	1
3.	Mylar (for downstream unit)	1
4.	Ground Plate	1
5.	Screws M3x6	2
6.	Screws M3x6	2
7.	Screws M4x14	4
8.	Leveling Shoes	5
9.	Power Cord* <sup>1</sup>	1
10.	Sponge Strip	1


<sup>\*1:</sup> In China, do not use the power cord provided with this unit. Contact your supervisor and use the power cord specified for use in China.

## Installation


# **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before
  doing the following procedures.

## **Tapes**



1. Remove all tape and packing material from the front, left, rear, and right sides.




- 2. Open the front door [A].
- 3. Grip handle [B] and slowly pull the fold unit out of the machine.
- 4. Remove all tape and packing material from inside.

## Paper Guide, Sponge Strips

# Mportant !

- There are two procedures for installation of the sponge strips.
- Follow "Procedure 1" below if the Multi Folding Unit will be connected to another peripheral unit.
- Follow "Procedure 2" if the Multi Folding Unit will be connected directly to the main machine (more sponge strips are required).


#### Procedure 1



- 1. Attach the paper guide [A] ( Fx2 M3x6).
- 2. Peel the tape from the sponge strip [B] and attach the strip to the top right edge of the unit.

#### Procedure 2


3. Attach the paper guide as described in "Procedure 1" above.



4. Remove the tape from each sponge strip and attach them to the right side of the unit as shown above.


- The two yellow sponge strips in the illustration are provided as accessories with the main machine. The horizontal sponge strip is provided with the Multi Folding Unit.
- 5. After attaching all sponges, use a sharp cutter to cut the sponge on the corner at [A].

## **Ground Plate**




1. Attach the ground plate [A] to the lower right edge of the unit ( \*x2 M3x6).

## **Docking**



1. Fasten the joint bracket [A] to the left side of the upstream unit (  $\checkmark$  x4 M4x14).




- 2. Open the front door [A].
- 3. At the front right corner, remove the screw of the lock bar [B] ( \*\* x1 M3x6). **Keep this screw.**
- 4. Push in the lock bar.
- 5. Slowly push the unit [C] against the left side of the upstream unit (or main machine) so that the lock bar is directly and squarely under the arms of the joint bracket.
- 6. Pull out the lock bar so it slides up into the notches in the arms on both ends of the joint bracket [D].
- 7. Fasten the lock bar by re-attaching the screw removed in Step 3 (  $\mathcal{F}$  x1).


8. Connect the I/F cable [E] to the upstream unit (or main machine).



• If you are docking to the main machine, you must first remove the plastic cap at the I/F cable connection point.



- 9. Remove:
  - [A] Rear upper cover ( Fx4)
  - [B] Rear lower cover ( Fx3)



- 10. Use a short screwdriver to loosen bracket [A] ( \*\*x2).
- 11. Fasten the bracket to the upstream unit at [B] ( \*\*x1).

- 12. Tighten the screws ( \*\bar{x} x3).
- 13. Re-attach the rear covers.


### Removing Parts for the Cover Interposer Tray (D518)

Three parts must be removed before the tray unit of the cover interposer tray can be mounted on top of the Multi Folding Unit.

1. Open the front door.



- The following parts require removal only if the upstream unit is the Cover Interposer Tray (D518).
- These parts must be removed so that the tray unit of the Cover Interposer Tray will fit on top of the Multi Folding Unit.



2. Remove:


[A] Bracket ( Fx1)

[B] Cross-piece ( \* x2)

[C] Metal plate from the door ( F x2)

3. After removing [B] and [C], reattach [A].

#### **Power Cord**




1. Insert the power cord socket [A] into the power connection point.



- In China, do not use this power cord provided with this unit. Contact your supervisor and use the power cord specified for use in China.
- 2. Connect the power supply cord plug to a power outlet.

# Finishing the Installation




1. Set the leveling shoes and adjust the height of the unit. (\*\*p.322)

- 2. Load some B4 paper in the 2nd tray of the main machine, and make several copies.
- 3. Check paper skew and side-to-side registration and correct if necessary. (\*\*p.324)




4. Peel the tape from the accessory mylar strip.



5. Attach the mylar to the top of the downstream paper guide as shown above (top view).

## **Auxiliary Tray, Fold Depressor**



1. Set the auxiliary tray [A] or flexible page depressor [B] when required.



- These items are available. They are not accessories.
- The auxiliary tray [A] keeps Z-folded paper (FM1) flat in the tray so that the trailing edges do not trigger an early tray full alert in the top tray.
- The flexible page depressor [B] prevents folded paper (especially FM3 Letter Fold-out sheets) from opening out and triggering an early tray full alert in the top tray.
- Both items can be installed together. Install [A], and then install [B].


# Ring Binder (D519)

## Accessories


Check each accessory against the list below to make sure that you have everything.

No.	ltem	Q'ty
1.	Docking Bracket	1
2.	Entrance Guide Plate	1
3.	Sponge Strip	1
4.	Power Cord	1
5.	Ring Opener	1
6.	Ring Supply Level Indicator	1
7.	Screws (M4 x 14)	4
8.	Tapping Screws (M3 x 6)	4
9.	Leveling Shoes	4
10.	Ground (Earth) Plate	1

9



# Before You Begin



The ring binder weighs 140 kg (308 lb.).


**IMPORTANT**: To prevent bending or breaking the top cover, never lift the unit by its top cover [A]. Always raise the unit from the base [B].

#### Installation Procedure


# **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedure.


### **Remove All Shipping Materials**



- 1. Remove all visible tapes, cushion, two accessory boxes, and wrapping material attached to the outside of the unit.
- 2. Remove:
  - [A] Brace x1 ( Fx4)
  - [B] Brace x1 ( \*\* x4)
  - **Important** 
    - Do not discard these braces. They must be reattached to the unit before it is moved or shipped to another location.



- 3. Open the right door and left door.
- 4. Remove all tapes and packing material.
- 5. Remove the brace and red tag [A] ( F x2).



- 6. Pull the binder unit [A] out of the unit until it stops.
- 7. Remove the tape [B] on top of the unit.
- 8. Pull down the ring cartridge handle and cover [C].
- 9. Pull the ring cartridge out and remove the cushion [D].


- 10. Push the ring cartridge in and close its cover.
- 11. Push the binder unit into the unit.
- 12. Close the left front door and right front door.

#### Prepare the Unit for Docking



- There are two procedures for installation of the sponge strips.
- Follow "Procedure 1" below if the Ring Binder will be connected to another peripheral unit.
- Follow "Procedure 2" if the Ring Binder will be connected directly to the main machine (more sponge strips are required).


#### Procedure 1



- 1. Attach the ground plate [A] ( Fx2).
- 2. Attach the entrance guide plate [B] (  $\slash\hspace{-0.4em}P x2$  ).
- 3. Remove the tape from the back of the sponge strip [C].
- 4. Attach the sponge strip to the top edge [D] of the unit as shown above.

#### Procedure 2

1. Attach the ground plate and entrance guide as described in "Procedure 1" above.




2. Remove the tape from each sponge strip and attach them to the right side of the unit as shown above.




- The two yellow sponge strips in the illustration are provided as accessories with the main machine. The horizontal sponge strip is provided with the Ring Binder.
- 3. After attaching all sponges, use a sharp cutter to cut the sponge on the corner at [A].

## Prepare the Main Machine for Docking




1. Attach the docking bracket [A] (M4x14 Px4).

#### Dock the Unit to the Main Machine



- 1. Open the right door of the unit.
- 2. Pull out the locking lever [A] ( Fx1).
- 3. Align the right side of the unit with the docking brackets [B] and [C] on the left side of the main machine, and then slowly push the unit onto the brackets.
- 4. Connect the unit's I/F cable [D] to the main machine.
- 5. Push in the locking lever and check that it slides into the slots of the docking brackets.
- 6. Check that the top edge of the unit is parallel with the left edge of the main machine.
- 7. Refasten the locking lever [A] ( \*\*x1) and close the right front door.


#### Install the Shoes and Level the Unit



- 1. Set the leveling shoes (x4) under the feet of the unit.
- 2. Open the right front door and left front door.
- 3. Place a level on the frame.
- 4. Use a wrench to turn the nut at each foot until the machine is level.


## **Attach Ring Supply Level Indicator**

- 1. Open the front door.
- 2. Pull out the ring binder.
- 3. Lift the ring supply cartridge out of the top of the binder unit.



4. Set the ring supply level indicator [1] behind the tabs on the side of the ring supply cartridge [2].

#### Test the Breaker Switch



- 1. If the main machine is on, turn it off.
- 2. Confirm that the breaker switch [A] is set to the right.



- The breaker switch is at the bottom of the left rear corner near the power cord. When it is set to the right, you should see a straight line (-).
- 3. Connect the power cord to the finisher, then connect the other end to a power supply outlet.
- 4. Use the sharp point of a pen [B] or similar tool to push in the breaker switch until it snaps to the off position. (You should see "0".)
- 5. If the breaker does not snap to the off position:
  - Check that the power cord is correctly connected to the finisher and power supply.
  - Push the breaker switch again to see if it snaps to the off position.
  - If the breaker switch does not snap to the off position, it must be replaced.
- 6. Be sure to reset the breaker switch to the on (-) position.

## Centering Paper in the Paper Path

At installation you must confirm that the paper is exiting the ring binder correctly and do the necessary correction if required. There are two checks:


- The paper should be centered in the paper path.
- The paper should feed straight out of the ring binder.

#### Checking and Correcting Side-to-Side Registration

#### Checking Side-to-Side Registration

Do this check to confirm that the paper is centered in the paper path.

- 1. Make sure that the I/F cable of the ring binder unit is connected.
- 2. If the finisher is connected to the left side of the ring binder, disconnect it and pull it away from the left side of the ring binder.
- 3. Execute a run by feeding paper (A4 or LT) from Tray 2 of the host machine (punching only, no ring binding).




d3912r0204a

- 4. During the run, each sheet of paper briefly protrudes about 5 to 10 mm before it switches back into the ring binder and feeds to the punch unit, as shown above.
  - There are two scales on the left side of the ring binder below the paper exit.
  - The rear scale [1] is for LT-size paper and the front scale [2] is for A4-size paper. Be sure to read the correct scale for the paper size in use.
- 5. Check the position of the paper on the scale to determine if the paper is centered.

# 

- Read the rear scale for LT-size paper and the front scale for A4-size paper.
- The scale lines are spaced 1 mm apart.
- The edges of the paper should be at the center line and not deviate more than ±2 mm.



[/	A]	Leading/trailing edges centered. No adjustment necessary.	
[8	В]	Leading/trailing edges offset to the rear more than 2 mm. Adjustment required.	
[(	C]	Leading/trailing edges offset to the front more than 2 mm. Adjustment required.	


6. If the edge of the paper is on the scale at the center [A], no adjustment is required.

-or-

If the edge of the paper is ±2 mm off the center line on the scale, adjustment is required. Do the procedure in the next section.

### Correcting Side-to-Side Registration: Bracket Adjustment

1. Disconnect the ring binder from the upstream unit.



2. On the docking bracket attached to the upstream unit, loosen screws ①, ②, ③, and ④.

- 3. Remove bracket [A] ( x1), rotate it 90 degrees, and re-fasten the screw. Changing the position of this bracket aligns the oval cut-out horizontally and frees the joint bracket so it can slide side-to-side.
- 4. Look at the scale [B].
- Slide the bracket to the left or right and tighten the screw.
   If the deviation from center was toward the front, slide the bracket to the rear and tighten the screw (1).
  - -or-

If the deviation from center was toward the rear, side the bracket to the front and tighten screw  $\odot$ .


- 6. Tighten screws 2, 3, and 4.
- 7. Do another test run to check the results of the adjustment.

#### **Checking and Correcting Skew**

#### Checking for Paper Skew

Do this check to confirm that the paper is not skewed in the paper path.

- 1. Make sure that the I/F cable of the ring binder unit is connected.
- 2. If the finisher is connected to the left side of the ring binder, disconnect it and pull it away from the left side of the ring binder.
- 3. Execute a straight-through run (no ring binding, no punching) with A3 or DLT from Tray 2 of the host machine.




d3912r0204b

- 4. During the run, each sheet of paper exits the side of the ring binder, as shown above.
  - There are two scales on the left side of the ring binder below the paper exit.
  - The rear scale [1] is for DLT-size paper and the front scale [2] is for A3-size paper. Be sure to read the correct scale for the paper size in use.
- 5. Check the position of the paper on the scale to determine if the paper skews as it exits.

## **Important**

- Read the rear scale for DLT-size paper and front scale for A3-size paper.
- The scale lines are spaced 1 mm apart.
- The paper must not deviate more than ±2 mm on the scale.



[A]	Centered. No adjustment necessary.
[B]	Trailing edge skew to the front, total skew more than ±2 mm. Adjustment required.
[C]	Trailing edge skew to the rear, total skew more than ±2 mm. Adjustment required.


## **Correcting Skew**

1. Disconnect the ring binder from the upstream unit.



d392i905

2. Remove the spacers from the right side of the ring binder at the base ( Fx2).



- 3. On the docking bracket attached to the upstream unit, loosen the screws.
- 4. Insert a spacer and tighten the screws.

If the trailing edge is skewing toward the **front** of the machine, insert a spacer [A] under the **rear** end of the bracket and tighten the screws.

-or-

If the trailing edge is skewing toward the **rear** of the machine, insert a spacer [B] under the **front** end of the bracket and tighten the screws.

5. To another run to check the adjustment. If skew is still present, insert another spacer.

#### After Installation

Confirm that the operators understand the following important points:

- Decals attached to the machine that provide guidance for removing paper jams. Point out the decal locations.
- Detailed instructions on removing ring jams are provided in the operating instructions under "Removing Jammed Ring Combs".
- When pulling out and pushing in the binder unit on its rails, always grip the binder unit by its handle (Mc8).





d392r902

# **ACAUTION**

- Always grip handle Mc8 when pulling out or pushing in the binder unit.
- Never touch any other surface of the binder unit when it is moving on its rails.
- To avoid injury to the fingers, never push on the top of the binder unit to slide it back into the finisher as shown above.



d519i910


• Never store paper, extra rings, manuals or any other material below the output tray. Obstacles in this area (shown in red in the illustration below) will interfere with the raising and lowering of the tray and cause an error.

# High Capacity Stacker (D515)

## Accessories

Check the quantity and condition of the accessories in the box against the following illustrations and lists.

# High Capacity Stacker (D515)




No.	Description	Q'ty
1.	Power Cord* <sup>1</sup>	1
2.	Leveling Shoes	4
3.	Ground Plate	1
4.	Lock Hasp – Left*2	1
5.	Lock Hasp – Right	1
6.	Joint Bracket	1
7.	Sponge Strip	1
8.	Paper Guide	1
9.	Screws M4x8	2
10.	Screws M3x6	4
11.	Screws M4x6	2
12.	Screws M4x14	4

9

\* 1: In China, do not use this power cord provided with this unit's accessories. Contact your supervisor and use the power cord specified for use in China.

## Roll-Away Cart Type 5010 (D456-17)




No.	Description	Q'ty
1.	Paper Tray	1
2.	Tray Cart Handle	1
3.	Tray Cart Base	1
4.	Screws M10x25	2
5.	Paper Press Lever	1

## Installation


# **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before
  doing the following procedure.

<sup>\*2:</sup> A lock is not provided.



1. Remove all visible tape from the front [A] and back [B].




- 2. Open the front panel [A] and remove all visible tapes.
- 3. Open the front door [B] and remove all visible tapes.

#### Paper Guide, Sponge Strips, Ground Plate



- There are two procedures for installation of the sponge strips.
- Follow "Procedure 1" below if the High Capacity Stacker will be connected to another peripheral unit.
- Follow "Procedure 2" if the High Capacity Stacker will be connected directly to the main machine (more sponge strips are required).


#### Procedure 1



1. Remove the tape from the sponge strip [A] and attach the strip to the top right edge of the unit.



- The sponge strip closes the gap between the High Capacity Stacker and the upstream unit to prevent paper or other objects from falling between the units.
- 2. Fasten the paper guide [B] to the right side of the unit ( Fx2).




3. Attach the ground plate [A] to the bottom right edge of the unit ( \*\* x2 M3x6).



 If the High Capacity Stacker will be docked to the left side of the main machine, more sponge strips must be attached.

#### Procedure 2

1. Attach the paper guide and ground plate as described in "Procedure 1" above.




2. Remove the tape from each sponge strip and attach them to the right side of the unit as shown above.



- The two yellow sponge strips in the illustration are provided as accessories with the main machine. The horizontal sponge strip is provided with the High Capacity Stacker.
- 3. After attaching all sponges, use a sharp cutter to cut the sponge on the corner at [A].


#### **Docking**




1. Fasten the joint bracket [A] to the upstream unit ( Fx4).



- If this unit is to be installed on the left side of the Multi Folding Unit, use three M4x20 screws and one M4x14 screw.
- The screw [B] (front-lower) must be "M4x14". The other three screws must be "M4x20".
   Otherwise, these screws may interfere with the upstream unit.
- M4x20 screws are provided with the Multi Folding Unit.
- 2. Open the front door.




3. Remove the front right cover [A] ( \*\mathbb{P} x3).




- 4. At the front right corner, remove the screw of the lock bar [A] ( \*\*\infty x1 M3x6). **Keep this screw.**
- 5. Pull the lock bar toward you until it stops.
- 6. Slowly push the unit [B] against the left side of the upstream unit (or main machine) so that the lock bar is directly and squarely under the arms of the joint bracket [C].
- 7. Push the lock bar in completely so that it slides up into the notches in the arms on both ends of the joint bracket.
- 8. Fasten the lock bar by re-attaching the screw removed in Step 4. (  $\slash\hspace{-0.4em}P$  x 1).

9. Attach the I/F cable [D] to the upstream unit.




10. Remove the right rear lower cover [A] ( \*\bar{x} x4).




- 11. Use a short screwdriver to loosen bracket [A] ( \*\*\varphi x2).
- 12. Fasten the bracket to the upstream unit at [B] (  $\slash\hspace{-0.4em}P x1$ ).
- 13. Tighten the screws ( \*\bar{x} x3).
- 14. Re-attach the rear covers.

## Lock Hasps



- 1. Fasten left lock hasp [A] ( Fx2) to the door.
- 2. Fasten right lock hasp [B] to the door frame (  $\slash\hspace{-0.6em}P$  x2).

## **Height Adjustment**



- 1. Set the leveling shoes [A].
- 2. Adjust the height of the unit and make sure that it is level.


## Finishing the Installation

1. Connect the power cord to the unit.



- In China, do not use this power cord provided with this unit's accessories. Contact your supervisor and use the power cord specified for use in China.
- 2. Set the leveling shoes and adjust the height of the unit. (\*\*p.322)
- 3. Load some B4 paper in the 2nd tray of the main machine, and make several copies.
- 4. Check paper skew and side-to-side registration and correct if necessary. (\*\*p.324)


#### **Docking: Downstream**



## 

- Do this procedure only if another peripheral device will be installed downstream.
- 1. Remove the left exit cover [A] from the left side of the unit ( \*\* x2).

## Roll-Away Cart (D456)




- 1. Align the holes in the brackets of the paper tray [A] with the studs on the tray base [B].
- 2. Set the holes over the studs.
- 3. Set the paper press lever [C] into the recessed cut-out in the paper tray.
- 4. Insert the ends of the tray cart handle [D] into the handle holes. One end of the handle passes through the paper press lever on the paper tray.



d447i115

- 5. Lay the assembly down with the handles on the floor.
- 6. Fasten the end of each handle ( Fx 1 each, M10x25).
- 7. Make sure that both screws [E] are fastened securely.

8. Set the cart upright on its casters.




d515i111


- 9. Open the front door [A].
- 10. Push the tray cart [B] into the unit and close the door.

# Finishers (D512/D513)

## Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.





No.	Description	Q'ty
1.	Screws M4x14 (Joint Bracket)	4
2.	Screws M3x8 (Shift Tray)	4
3.	Screws M3x6 (Ground Plate)	2
4.	Screws M3x6 (Paper Guide)	2
5.	Leveling Shoes	4

2

No.	Description	Q'ty
6.	Ground Plate	1
7.	Power Cord*1	1
8.	Joint Bracket	1
9.	Sponge Strip	1
10.	Paper Guide	1
11.	Auxiliary Tray – Glossy Paper	1
12.	Auxiliary Tray – Z-Fold Paper	1
13.	Auxiliary Tray – Coated Thin Paper	1
14.	Booklet Tray (D512)	1
15.	Shift Tray	1

<sup>\*1:</sup> In China, do not use this power cord provided with this unit's accessories. Contact your supervisor and use the power cord specified for use in China.

#### Installation


## **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedure.


## Tapes, Retainers, Shipping Plates

## Mportant !


• The shipping plates prevent the staple unit from moving during transport. The plates should be kept and re-attached before the unit is transported to another location.



1. Remove all tapes and packing material from the external coves.




- 2. Open the front door [A].
- 3. Remove:
  - [B] Tapes, retainers inside
  - [C] Tag, wire, shipping plate ( \*\bar{\mathbb{E}} x2)



- 4. Loosen the screws of the caster cover [A] ( \*\* x2).
- 5. Push the caster [B] down until it touches the floor.
- 6. With the caster touching the floor, tighten the caster cover screws.


## **ACAUTION**

• This prevents the unit from tipping over when you pull out the staple unit.



- 7. Grip handle [A] and slowly pull the staple unit out until it stops.
- 8. Remove:
  - [B] All tapes, retainers
  - [C] Tag, wire, shipping plate ( Fx2)

- [D] Tag, wire, shipping plate ( Fx2)
- 9. Re-attach screw [E] where it was removed.




- 10. Remove:
  - [A] Tapes, retainer
  - [B] Tapes

## Ground Plate, Sponge Strips




- There are two procedures for installation of the sponge strips.
- Follow "Procedure 1" below if the "Finisher" will be connected to another peripheral unit.
- Follow "Procedure 2" if the "Finisher" will be connected directly to the main machine (more sponge strips are required).

#### Procedure 1




1. Attach the ground plate [A] to the bottom right edge of the unit (  $\nearrow$  x2 M3x6).



- 2. Attach the paper guide [A] ( Fx2 M3x6).
- 3. Peel the tape from the sponge strip [B] and attach the strip to the top right edge of the unit.

#### Procedure 2

1. Attach the paper guide and ground plate as described in "Procedure 1" above.




2. Remove the tape from each sponge strip and attach them to the right side of the unit as shown above.



- The two yellow sponge strips in the illustration are provided as accessories with the main machine. The horizontal sponge strip is provided with the Finisher.
- 3. After attaching all sponges, use a sharp cutter to cut the sponge on the corner at [A].


#### 2

## **Booklet Tray, Shift Tray**




- 1. Attach the booklet tray [A] to the notch in the left cover (no screws).
- 2. Attach the shift tray [B] to the left side of the unit ( Fx4 M3x8).


## **Docking**



1. Fasten the joint bracket [A] to the upstream unit ( \*\bar{\mathbb{P}} \times 4 M4x14).




- 2. Open the front door [A] of the unit.
- 3. At the front right corner, remove the screw of the lock bar [B] ( \*x1 M3x6). **Keep this screw.**
- 4. Pull the lock bar toward you until it stops.
- 5. Slowly push the unit [C] to the left side of the upstream unit (or main machine) so that the lock bar is directly and squarely under the arms of the joint bracket [D].
- 6. Attach the I/F cable [E] to the upstream unit.




- 7. Push the finisher close to the side of the upstream unit.
- 8. Confirm that the height of the finisher entrance [A] is at the same height as the upstream unit's paper exit [B].
- 9. Push the finisher closer to the side of the upstream unit, and then once again confirm that the height of the finisher entrance still matches the height of the upstream unit exit.
- 10. If the exit and entrance are not at the same height, adjust the height of the finisher. (Pp.322)

- 11. Push the finisher against the side of the upstream unit.
- 12. Push the lock bar in completely so that it slides up into the notches in the arms on both ends of the joint bracket.
- 13. Fasten the lock bar by re-attaching the screw removed in **Step 3**. ( Fx1)



#### 14. Remove:

- [A] Rear upper cover (Capsx2, 🗗 x5)
- [B] Rear lower cover ( Fx4)




d457i110

- 15. Use a short screwdriver to loosen bracket [A] ( 🗗 x3).
- 16. Fasten the bracket to the upstream unit at [B] ( Fx1).

- 17. Tighten the screws ( \*\bar{x} x3).
- 18. Re-attach the rear covers.

#### **Auxiliary Trays**

1. Instruct the operator about when to use these auxiliary trays, as explained below.



- Before feeding glossy paper, pull out the extension [A] of the shift tray and mount the glossy paper auxiliary tray [B].
- Before feeding Z-folded paper from the Multi Folding Unit, set the Z-fold auxiliary tray [C] on the shift tray.
- Before feeding coated thin paper from the Multi Folding Unit, set the coated thin paper auxiliary tray [D].

## Finishing the Installation

1. Connect the power cord to the unit




- In China, do not use this power cord provided with this unit's accessories. Contact your supervisor and use the power cord specified for use in China.
- 2. Set the leveling shoes and adjust the height of the unit. (\*\*p.322)
- 3. Load some B4 paper in the 2nd tray of the main machine, and make several copies.
- 4. Check paper skew and side-to-side registration and correct if necessary. (\*\*p.324)

## Punch Unit PU5020 NA, EU, SC (D449-17, -27, -28)

#### Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.



No.	Description	Q'ty
1.	Punch Drive Unit	1
2.	Punch Unit	1
3.	Punch Registration Unit	1
4.	Punch Control Board	1
5.	Sensor Arm and Sensor	1
6.	Punch-out Hopper	1
7.	Harness: Long	1
8.	Harness: Board Relay	1
9.	Spring	1
10.	Step Screw	1
11.	Screws M3x6	9


RTB 109 Notes for installing the punch unit.

## Installation




• Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedure.

## **Shipping Materials**



1. Remove motor protector plate [A] ( \*\* x4).


#### **Rear Cover**



1. Remove upper rear cover [A] ( \*\* x4).

PU5020 RTB 1
It may be necessary to replace a bracket at installation. See the RTB for details.


## **Right Upper Panel**



d449i117


1. Remove the right upper panel [A] ( F x4).

## **Punch Registration Unit**




d449i103


- 1. Use a pair of nippers to remove knockouts [A].
- 2. Raise and open lever "RB3" [B].



3. Remove plate [A] and discard it ( \*\* x4).




- 4. Insert the harness connectors [A] through the hole [B].
- 5. Make sure the harness connectors are through the hole completely and visible at the rear of the machine.
- 6. Set and fasten the punch registration unit [C] ( \*\* x4, 2 screws each at front and back).




- 7. Clamp harness [A] (🖨 x4).
- 8. Clamp harness [B] (🖨 x2).

#### Sensor Arm




- 1. Attach sensor arm [A] ( \*\* x1 Step Screw, Spring x1).
- 2. Make sure the sensor arm swings freely on the step screw and spring.
- 3. Attach harness [B] to the sensor on top of the arm.


### Punch Drive Unit, Punch Unit



1. On the punch unit, connect harness [A] ( $\square$  x1,  $\square$  x1).



- 2. Attach the punch mechanism [A] to the rails of the punch unit (  $\rat{P}$  x1).
  - If you are installing the punch unit for Europe [1], connect the harness [B] (🗗 x1, 🖨 x2).
  - The punch unit for North America [2] has no punch switching motor, so this harness is not required.




d449i108


- 3. At the front, insert the punch unit [A] into the finisher and fasten it ( \*\* x4).
- 4. Remove the shoulder screw with red tag [B], and detach the tag and wire.
- 5. After removing the screw from hole  $\bigcirc$ , re-attach it at hole  $\bigcirc$ .

## **Important**


- This screw must remain attached to the punch unit.
- Before removing the punch unit from the finisher, the screw must be removed from hole ② and re-attached at hole ①. This stabilizes the punch unit and prevents it from wobbling from side to side while it is being removed and handled after removal.



6. At the front, slide the punch-out hopper [A] into the finisher.




- 7. Route the harnesses from the CIS unit [A] through the hole.
- 8. Connect the harnesses at 1 and 2 (1 x2).
- 9. If you are installing the punch unit for Scandinavia, fasten the extra connector (not used) at ③ (🖨 x1).




10. Finish clamping the harnesses as shown above.

#### **Punch Control Board**




- 1. Install the punch control board ① (Standoffs x4, no screws).
- 2. Connect the punch relay harness 2 to the punch control board and punch main control board 3.


#### **Final Connection**



1. Fasten the connectors to the punch unit PCB [A] ( x2).



2. Release harness [A] from the frame (🖨 x2).



- 3. Connect harness [A] to the punch control board ( $\square$  x1).
- 4. Gather harness [A] and the board relay harness [B] and clamp them (2 x3).


## Trimmer Unit (D520)



• The Trimmer Unit can be installed only with the Booklet Finisher (D512) (not the Finisher D513).

#### **Accessories**

Check the quantity and condition of the accessories in the box against the following illustration and list.



No.	Description	Q'ty
1.	Output Tray*1	1
2.	Joint Bracket – Left (Marked "L")	1
3.	Joint Bracket – Right (Marked "R")	1
4.	Ground Plate	1
5.	Sponges	2
6.	Screws (M3x6 for Ground Plate)	2
7.	Screws (M4x10 for Joint Bracket)	4
8.	Leveling Shoes	4
9.	Power Cord	1


<sup>\* 1:</sup> Screws (x2) for the output tray are attached to the left side of the unit.

#### Installation


## **ACAUTION**

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before
  doing the following procedure.

#### Tapes, Stopper Plate



- 1. Remove the tape on the right side to free the I/F cable [A].
- 2. Remove the tape from the left side [B].




- 3. Open the front door and remove the retainer [A].
- 4. Remove the stopper plate [B] ( \*\bar{p} x 1).




• Keep the stopper plate. It should be re-installed before transporting the unit to a new location.

## **Output Tray**



- 1. Make sure that the front door [A] is open.
- 2. Remove:
  - [B] Left upper cover( ₱x2)
  - [C] Left lower cover ( Fx2)




- 3. Remove the screws 1 and 2 from the left side.
- 4. Use the removed screws to attach the output tray [A].
- 5. Connect the output tray at [B].
- 6. Remove the sheet [C] of paper.




- Do not remove this sheet [C] of paper before connecting the output tray to the trimmer unit.
- 7. Reattach the left lower cover and left upper cover.

#### **Ground Plate**




1. Attach the ground plate [A] to the right bottom edge ( \*\* x2 M3x6).

## Preparing the Booklet Finisher (D512) for Docking




1. Open the front door [A] of the finisher.

#### 2. Pull out the staple unit [B].




- 3. At the rear of the finisher, remove:
  - [A] Rear upper cover (Capsx2, 🗗 x5)
  - [B] Rear lower cover ( Fx4)




- d455i108
- 4. Unfasten the booklet tray sensor actuator arm [A] ( Fx2).
- 5. Disconnect the actuator arm [B] and remove it (\$\$x5, \$\$1\$x1).
- 6. Store the actuator arm in a safe location for future use.

7. Reinstall the rear upper and lower cover.

## **Docking**



- 1. Attach:
  - [A] Left joint bracket, marked "L" ( \*x2, M4x10)
  - [B] Right joint bracket, marked "R" ( \*x2, M4x10)
- 2. Peel the tape from the back of the sponges and attach sponges 1 and 2.




d455i110

3. At the rear, remove screw 1 from plate [A].

- 4. Loosen screw 2 and lower the plate so that you can see the lock bar [B].
- 5. Remove the lock bar screw 3 ( Fx1 M3x6). Keep this screw.
- 6. Push the lock bar [B] until it is unlocked.
- 7. Slowly push the unit [C] against the left side of the finisher so that the lock bar is directly and squarely under the arms of the joint brackets.
- 8. At the rear, pull the lock bar [B] toward you so that it slides up into the notches in the arms of the joint brackets.
- 9. Fasten the lock bar by re-attaching the screw removed in **Step 5**. ( Fx1).
- 10. Connect the unit I/F cable [D] to the finisher.
- 11. Connect the plug of the power cord to the power source.

#### Finishing the Installation



- 1. Set the leveling shoes and adjust the height of the unit. (\*\*p.322)
- 2. Load some B4 paper in the 2nd tray of the main machine, and make several copies.
- 3. Check paper skew and side-to-side registration and correct if necessary. ( pp.324)

## **Common Adjustments**

## Height and Level Adjustment

#### Before you begin:

- The main machine should be installed first and adjusted to level front-to-back, and side-to-side.
- Note the settings on the leveling gauge. Due to the length of the paper path with optional
  peripheral units installed, it is extremely important that every unit be leveled to match the front-toback and side-to-side measurements of the main machine.
- The height and level of each peripheral unit must be adjusted at installation.
- The height and level of each unit must be adjusted before testing for the presence of skew and checking that side-to-side registration is correct.

#### **Setting the Leveling Shoes**

## **☆ Important**

- Do this procedure near each caster where an adjustable bolt is provided.
- The number of leveling shoes will differ, depending on which unit you are leveling.



d059i821

1. Turn the **lower** nut to lower the bolt.




- The upper bold is spot-welded to the frame and does not move.
- 2. Set a leveling shoe below the bolt.




d059i822

- 3. Continue to turn the lower nut until it stops against the shoe.
- 4. Set a level on the front, rear, and side edges to determine if the unit is level.
- 5. Adjust the height at each corner until the unit is level.



- 6. Check the results of the adjustments.
  - The top of the first peripheral unit on the left must be at the same height as the left side of the main machine.
  - The tops of the other peripheral units on the left where the units are joined must be at the same height.
  - The top of the LCIT on the right must at the same height as the right side of the main machine.



d074i898


- Make sure that the plate at the paper exit on the left side of the main machine [A] moves freely
  and is not bent. It must be able to move to handle thick paper.
- Between the right side of the main machine and the LCIT, make sure that the LCIT guide plate
  moves freely and does not interfere with the main machine guide plate.

### Skew and Side-to-Side Registration

RTB 60: Complete Registration Procedure (Skew/ Image Position/ Front and Back Correction)

#### Overview


The paper feed path is extremely long when many peripheral units are installed. In such a long path, the cumulative effect of paper skew or deviation in side-to-side registration may require adjustment.



- Skew [A] occurs when the trailing edge of the paper rotates away from the direction of paper feed.
- If side-to-side registration shift [B] occurs, the sheet remains straight but shifts left or right away from center of the paper path.




• Before adjusting skew manually, be sure to enter the SP mode and set SP1206 to "2" (OFF).



### Scales

- Skew and side-to-side registration are checked with graduated scales (shown above) where paper exits the units.
- The scales are provided so that you can visually check and measure the amount of skew or deviation in side-to-side registration.
- A scale for detecting skew and checking side-to-side registration ("S-to-S") is provided on the following peripheral units.
- Correction for both skew and side-to-side registration are possible.


Name	Skew	S-to-S	Comment	
LCIT			Correction is done in the registration unit of the main machine.	
Other Peripheral Units	Yes	Yes	Correction for both skew and side-to-side registration are possible when the unit is attached to the upstream unit with the single bracket.	



Use either the rear scale or front scale, depending on the type of paper used in your area:

- Rear [A]: DLT SEF (LT LEF for Ring Binder)
- Front [B]: A3 SEF (A4 LEF for Ring Binder)

The illustrations below show where the scale for each peripheral unit is located:



d059i813


• [A]: DLT/[B]: A3

The illustration above shows the scale on the left side of the Booklet Finisher (D512) tray. The same scale is at approximately the same position (paper exit) for the following units:

- Multi Folding Unit: Proof Tray, or Left Exit
- Ring Binder: Left Exit
- High Capacity Stacker: Proof Tray

In the illustration below:

- The RED lines indicate the single-piece brackets where adjustments can be done to eliminate skew and to correct side-to-side registration.
- The GREEN lines indicated 2-piece joint brackets where adjustment is not possible between the finisher and trimmer unit.



Unit	Name	Comment
[1]	LCIT	
[2]	Main Machine	
[3]	Decurler Unit (inside main machine)	Inside main machine
[4]	Cover Interposer Tray	
[5]	Multi Folding Unit	
[6]	Ring Binder	
[7]	High Capacity Stacker	
[8]	Finisher (D513 or D512)	D513 or D512
[9]	Trimmer Unit (Joint Brackets x2)	Joint Brackets x2

**Note**: The Trimmer Unit [9] does not have the single bracket for the upstream unit that allows side-to-side adjustment with shims (described below).

Here are some general rules for testing and adjusting for paper skew or a shift in side-to-side registration.

- 1. After installation of each peripheral device, do some test prints and check for the presence of skew, and check that side-to-side registration is correct.
- 2. When you detect a problem with skew or side-to-side registration, do the adjustment on the joint bracket attached to the peripheral unit **upstream of the unit where the problem occurred**.
- 3. Side-to-side registration is corrected by shifting the upstream joint bracket left or right. (See the next procedure.)
- 4. Skew is eliminated by inserting spacers (shims) under the rear or front end of the joint bracket. These attached by screws to the peripheral units before they leave the factory.


### **Checking Side-to-Side Registration**

Do this procedure to confirm that the paper is centered in the paper path.

- 1. Make sure that the I/F cable of the unit is connected to the upstream unit.
- 2. Disconnect the unit to the left of the unit to be tested.
- 3. Execute a run by feeding paper from Tray 2 of the host machine.



- If you are testing the Ring Binder, execute the run by feeding paper (A4 or LT LEF) from Tray 2 of the host machine (punching only, no ring binding). (The Ring Binder cannot accept a larger paper size.) Feed A3 SEF for other units.
- 4. When each sheet exits, check the position of the paper on the scale to see if the paper is centered.
  - Read the **rear scale** for **DLT**-size paper.
  - Read the front scale for A3-size paper.
  - If you are testing the ring binder, read the rear scale for LT LEF paper and the front scale for A4 LEF paper. With the Ring Binder, the paper does not exit. It will switch back and feed to the punch unit.
  - The scale lines are spaced 2 mm apart.
- 5. The paper must not deviate more than ±2 mm on the scale.



[A]	Leading/trailing edges centered. No adjustment necessary.				
[B]	Leading/trailing edges offset to the rear by more than 2 mm. Adjustment required.				
[C]	Leading/trailing edges offset to the front by more than 2 mm. Adjustment required.				

If the edge of the paper is on the scale at the center [A], no adjustment is required.


-or-

If the edge of the paper is  $\pm 2$  mm off the center line on the scale, adjustment is required. Do the procedure in the next section.

### **Correcting Side-to-Side Registration**

Each peripheral unit for this machine has the same single-piece connection bracket shown below. This adjustment can be done for every unit on the connection bracket attached to the upstream unit

- 1. Enter the SP mode and set SP1206 to "2" (OFF).
- 2. Disconnect the peripheral unit from the upstream unit.



- 3. On the joint bracket attached to the upstream unit, loosen screws ①, ②, ③, and ④.
- 4. Remove bracket [A] ( > x1), rotate it 90 degrees, and re-fasten the screw. Changing the position of this bracket aligns the oval cut-out horizontally and frees the joint bracket so it can slide from side to side.
- 5. Look at the scale [B].
- 6. Slide the bracket to the left or right and tighten the screw.
- If the deviation from center was toward the front, slide the bracket to the rear and tighten screw ①.
   -or-

If the deviation from center was toward the rear, side the bracket to the front and tighten screw ①.


- 8. Tighten screws 2, 3, and 4
- 9. Do another test run, so that you can check the results of the adjustment.
- 10. When you are finished, enter the SP mode and re-set SP1206 to "1".

### **Detecting Paper Skew**

Do this check to detect the presence of skew in the paper path.

- 1. Make sure that the I/F cable of the unit is connected to the upstream unit.
- 2. If a peripheral unit is connected on the left side, disconnect it and pull it away.

- 3. Execute a straight-through run.
- 4. Check the scale where each sheet exits.
  - The **rear scale** is for **DLT**-size paper.
  - The front scale [2] is for A3-size paper.
  - Be sure to read the correct scale for the paper size in use.



[A]	] Centered. No adjustment necessary.					
[B]	Trailing edge skew to the front, total skew more than ±2 mm. Adjustment required.					
[C]	Trailing edge skew to the rear, total skew more than ±2 mm. Adjustment required.					

### **Correcting Skew**

- 1. Enter the SP mode and set SP1206 to "2" (OFF).
- 2. Disconnect the peripheral unit from the upstream unit.
- 3. Locate and remove the spacers from the peripheral unit where the problem occurred.

### Locating and Removing Spacers

The photos below show where you can find the spacers for each unit.

### Multi Folding Unit (D521)



d454i111

### High Capacity Stacker (D515)



d059i817

- 1. Open the front door.
- 2. Remove the right lock hasp [A] ( Fx2).
- 3. Remove the right front cover [B] (  $\nearrow$  x2).
- 4. Remove the spacers ( 🗗 x 1 ).


### Finisher (D512/D513)



d059i818

- 1. Open the front door ( Px1).
- 2. Remove the spacers ( 🗗 x 1 ).

### **Inserting Spacers**



1. Loosen the screws ( \*\varphi x4) of the joint bracket attached to the peripheral upstream of the unit where the problem occurred.

2. Insert a spacer and tighten the screws.

If the trailing edge of the paper is **skewing toward the front** of the machine, insert a spacer [A] under the **rear end of the bracket** and tighten the screws.

-or-

If the trailing edge is **skewing toward the rear** of the machine, insert a spacer [B] under the **front end of the bracket** and tighten the screws.

- 3. Do another run to check the adjustment. If skew is still present, insert another spacer.
  - Each spacer is 2 mm thick.
  - Only two spacers are provided, so the maximum adjustment is 4 mm (using two spacers).
- 4. Enter the SP mode and re-set SP1206 to "1".

# **GW Controller Options**

### Overview


### **Available Options**

The VM Card (an SD card) is the only option available for this machine.



• The Security & Encryption SD card contains both the HDD Encryption and Data Overwrite Security applications. This SD card is shipped with the machine in SD card Slot 1.

### **Controller Board Slots**



No.	Name	Function					
1	USB Host	Japan only					
2	Web Monitor	Connection point for Web Monitor					
3	Slot 1	Applications: Data Overwrite Security, HDD Encryption					

No.	Name	Function					
4	Slot 2	VM Card, Service slot for firmware update					
(5)	EFI	Gigabit Ethernet. Connection for Fiery Controller					

### **Application Move**

"Move Exec" (SP5873-1) moves one application program from the original SD card to another SD card. The application program is moved from Slot 2 to Slot 1.

- 1. Turn off the main power switch.
- 2. Remove the SD card slot cover ( Fx1).
- 3. Insert the original SD card with the application in Slot 2.
- 4. Insert the SD card to receive the application in Slot 1.
- 5. Turn on the main power switch.
- 6. Enter the SP mode and do SP5873-1 "Move Exec".
- 7. Follow the messages on the operation panel to complete the procedure.
- 8. Exit the SP mode.
- 9. Turn off the main power switch.
- 10. Remove the original SD card from Slot 2.
- 11. Leave the other SD card in Slot 1.
- 12. Turn on the main power switch.
- 13. Check that the application program runs normally.
- 14. Tell the customer to store the original SD card in a safe place.

#### **Undo Exec**

"Undo Exec" (SP5873-2) restores an application to its original SD card. The application is moved from Slot 2 to Slot 1.


- 1. Turn off the main power switch.
- 2. Remove the SD card slot cover ( 🗗 x 1 ).
- 3. Insert the SD card that currently holds the application in Slot 2.
- 4. Insert the original SD card to receive the restored application in Slot 1.
- 5. Turn on the main power switch.
- 6. Enter the SP mode and do SP5873-2 "Undo Exec".
- 7. Follow the messages on the operation panel to complete the procedure.

- 8. Exit the SP mode.
- 9. Turn off the main power switch.
- 10. Remove both SD cards.
- 11. Insert the SD card with the restored application in Slot 1.
- 12. Turn on the main power switch.
- 13. Check that the application operates normally.

### VM Card Type R (D554) D074/D075


The VM card application cannot be moved to another SD card. However, other applications can be moved onto the VM card.

1. Turn off the machine.



d074i541a

- 2. Remove the SD card slot cover [1] (x1).
- 3. Turn the SD-card label face [2] to the rear of the machine. Then push it slowly into slot 2 (lower slot) until you hear a click.
- 4. Reattach the SD card slot cover.
- 5. Switch the machine on.



- 6. On the operation panel, remove the bottom blank keytop [3] and replace it with the keytop provided [4].
- 7. For NA and AA models, attach the decal [5] to the copier.


# 3. Preventive Maintenance

# **PM Counter Display**

The PM Counter main menu and submenu allows you to review the PM counts for both units and individual components.

### **Opening the PM Counter**

1. Enter the SP mode.



d074p901

2. Touch [PM Counter].



d074p902

**All PM Parts List.** Displays all PM items (all PM items, not only PM units). Lists all PM items regardless of PM yield indicator settings.

Parts list for PM yield indicator. Displays on the items with their PM yield indicator settings set to "Yes".


**Clear all PM settings.** Resets all PM counter settings to "0" at the same time. PM items can be reset one by one with the [Clear] button.

Counter list print out. Prints the PM counter on paper.

### **PM Parts Screen Details**

#### All PM Parts list: Main Menu

The "All PM Parts list" displays all PM units and individual items. This list shows all PM items, regardless of their "PM yield indicator settings".



RTB 36 Units Used for PM Counter Display


d074p903

- [A]: Number buttons. Pressing a number button opens a submenu.
- [B]: Descriptions. The # mark denotes a "unit" (not individual item).
- [C]: PM yield buttons. Function is the same as the "PM yield indicator settings" button.
- [D]: Current PM counter value.
- [E]: Target PM interval. This can be changed by pressing a number button [A].
- [F]: PM counter clear button. Function is the same as the [Clear current counter] button.

### **Number Button Submenu**

Press any number button to open the submenu for a part. In the example below, the number button [001] #Development Unit was pressed.

3



d074p904

[A]: Clear current counter. Press to reset the selected PM counter (in this example 001 #Development Unit) to "0". You can also clear the settings by pressing the [Clear] button on the right side of the PM Counter Main Menu ([F] in the previous section).

[B]: Change target yield. Press the change the target PM yield. To change the setting:

- Press [Change target yield]
- Enter the number for the new target with the 10-key pad.
- Press [#] on the operation panel.

[C]: PM yield indicator settings. [Yes] is the default. Press [No] to remove the current item from the "Parts list for PM yield indicator".


- When set to "Yes", items marked with the # mark (# = a unit) will not have their individual items
  displayed automatically in the "Parts list for PM yield indicator list".
- When set to "No", items marked with the # mark (# = a unit) only the individual components will appear in the list (the units will not appear).

[D]: PM counter history. This is a summary of the most recent counts

- Latest 1. The latest PM count since the unit (or part) was replaced.
- Latest 2. The previous PM count since the unit (or part) was replaced.
- Latest 3. The previous but one PM count since the unit (or part) was replaced.

#### Parts List for PM Yield Indicator

This list shows the PM Parts Main Menu with only items set to "Yes" displayed.



d074p905

### Note the following:

- The # mark denotes a unit.
- Items without the # (for example, 065 ITB) denote individual components.
- An asterisk (\*) will appear in the Exceed column [A] to show items that have exceeded their target PM yields.

# **PM Tables for Main Machines**

### **PM Parts List Key**

Column	Meaning	Notations				
Part	Name of the component, unit	Name	of the part			
Ву	Person responsible	S	Service technician			
		U	User			
		Т	TCRU trained user at work site			
At	Interval for checking, cleaning, replacement	Example: 300K where K = 1000, or 300,000 printed sheets. (Recorded in Log Counter)				
Action	What must be done	I Inspect				
		С	Clean			
		L Lubricate				
		R Replace				
Comment	What to use	Materials required for cleaning, lubrication				

## Optics (D074/D075)

Part	Ву	At	Action	Comments
White Plate (under ARDF)	S	600K	I/C	Optics cloth
1st Mirror	S	600K	I/C	Optics cloth
2nd Mirror	S	600K	I/C	Optics cloth
3rd Mirror	S	600K	I/C	Optics cloth
Original Width Sensors (APS)	S	600K	I/C	Dry cloth
Exposure Glass* 1	S, U	300K	I/C	Ricoh cleaner
Exposure Lamp	S	300K	I/C	Dry cloth

Part	Ву	At	Action	Comments
Guide Rail (2-level both ends)	S	600K	I/C	Alcohol damp
ARDF Exposure Glass*1	S, U	300K	I/C	Ricoh cleaner
Dust Filter	S	600K	I/C	Blower brush
Toner Shield Glass* 1	S	300K	I/C	Optics cloth

<sup>\*1:</sup> Clean these parts at every service call.

## Development

Part			At	Action	Comments
Developer	D074	S	750K	R	Vacuum clean old toner
	D075/M044	S	900K	R	from toner collection roller.
Filter D074		S	750K	R	
	D075/M044	S	900K	R	
Gears		S	300K	С	
Toner Supply Unit		S	300K	I/C	
Heat shield plate		S,U		С	Clean every time the PCDU is pulled out.

## Around the Drum

Part	Ву	At	Action	Comments
Drum Cleaning Unit* <sup>1</sup>	S,T			
Cleaning Blade	S	300K* <sup>2</sup>	R	This blade does not include the side seals below. Replace both parts at the same time.

Part	Part		At	Action	Comments
Side Seals		S	300K* <sup>2</sup>	R	These are required for installing a new drum cleaning blade.
Lubrication Roller		S	300K* <sup>2</sup>	R	
Lubrication Bar		S	300K* <sup>2</sup>	R	RTB 105 Important note
Lubrication Blade		S	300K* <sup>2</sup>	R	This blade does not include the side seals below. Replace both parts at the same time.
Side Seals		S	300K* <sup>2</sup>	R	These are required for installing a new drum lubrication blade.
Lubrication Roller	Coupling	S	300K* <sup>2</sup>	R	
Gears		S	300K* <sup>2</sup>	R	
Charge Unit*1		S, <b>T</b>	300K	R	
Drum*1	D074	S, <b>T</b>	980K		
D075/M044		S, <b>T</b>	1100K	R	
Potential Sensor		S	600K	I/C	Dry cloth
QL		S	600K	I/C	Dry cloth
Used Toner Bottle		S, U	Full	R or I/C	When tank becomes full.

RTB 75 PM part added

\*1: TCRU qualified operators can replace these units. Service Technicians can replace the unit and also disassemble the unit and replace individual parts.

The PM life of these parts is calculated by referring to the rotations of the drum. The PM Parts Replacement message is displayed when the drum rotations reach the timing equal to 300K sheets outputs with 25 P/J, A4 LEF (LT LEF) and simplex mode. As a result, the timing of the PM Parts Replacement message may be different from the PM counter (number of outputs) of the drum.

RTB 75 Note added to bottom of PM table

# Image Transfer Unit

Part	Ву	At	Action	Comments
ITB	S	1600K	R	
Transfer Belt Speed Sensor RTB 77 Notes on cleaning these sensors.	S	300K	I/C	Water damp cloth; SP adjustment needed after cleaning
ID Sensor	S	300K	I/C	Water damp cloth
Belt Centering Sensor	S	600K	I/C	Blower brush
ITB Unit Internal Rollers	S	600K	I/C	Water damp cloth
Bias Roller RTB 103 Should be Image Transfer Roll	ers S	1800K	R	
ITB Cleaning Unit*1	Т			
ITB Cleaning Blade	S	600k	R	
ITB Lubrication Roller	S	600K	R	
ITB Lubrication Bar	S	600K	R	
ITB Lubrication Blade	S	600K	R	

<sup>\*1:</sup> TCRU qualified operators can replace this unit. Service Technicians can replace the unit and also disassemble the unit and replace individual parts.

## Paper Transfer Unit

Part		Ву	At	Action	Comments
PTR Cleaning Unit* <sup>1</sup>		Т			
PTR Cleaning Blade		S	300K	R	
PTR Lubricant Bar	D074	S	450K	R	
	D075/M044	S	500K	R	
PTR Anti-Static Brush		S	300K	R	
PTR		S	300K	R	

Part	Ву	At	Action	Comments
Paper Sensors	S, T	300	I/C	Dry cloth to wipe away paper dust, toner

\*1: TCRU qualified operators can replace this unit and clean paper sensors. Service Technicians can replace the unit and also disassemble the unit and replace individual parts.

RTB 129 This table was changed

## **Fusing Unit**

Part	Ву	At	Action	Comments
Fusing Unit* <sup>1</sup>	Т	1		
Fusing Belt	S	650K	R	
Hot Roller	S	650K	R	
Pressure Roller	S	650K	R	
Pressure Roller Bearings	S	650K	R	
Hot Roller Separation Plate	S	300K	I/C	
Pressure Roller Separation Plate	S	300K	I/C	
Fusing Unit Entrance Guide	S	300K	I/C	Dry cloth to wipe
Pressure Roller Contact Thermistor	S	650K	I/C	away paper dust,
Heating Roller Contact Thermistor	S	650K	I/C	toner
Hot Roller Contact Thermistor	S	650K	I/C	
Main Gears	S	650K	L	FLUOTRIBO MG
Hot Roller Bearings	S	650K	L	grease
Heating Roller Bearings	S	650K	I/C	
Web Cleaning Unit* <sup>1</sup>	Т			
Cleaning Web	S	450K	R	
Web Tension Roller	S	450K	R	

Part	Ву	At	Action	Comments
Web Stopper	S	450K	R	

\*1: TCRU qualified operator can replace these units. Service Technician can replace the unit and also disassemble the unit to clean and replace individual parts.

### Filters

Part		Ву	At	Action	Comments
Dust Filter		S	600K	R	
Ozone Filters	D074	S	1200K	R	
	D075/M044	S	1350K	R	

## Main Paper Feed

Part	Ву	At	Action	Comments
1 st Disk our Dallan (v.1)	6 11	100K	I/C	Water damp cloth
1 st Pick-up Roller (x1)	S, U	1000K	R	
Let Enad Paller (v.1)	C 11	100K	I/C	Water damp cloth
1 st Feed Roller (x1)	S, U	1000K	R	
1-t Communicar Dollar (v.1)	C 11	100K	I/C	Water damp cloth
1st Separation Roller (x1)	S, U	1000K	R	
2 -   Did D -      - 1 \		100K	I/C	Water damp cloth
2nd Pick-up Roller (x1)	S, U	1000K	R	
2-d 5d Dallas (v.1)	C 11	100K	I/C	Water damp cloth
2nd Feed Roller (x1)	S, U	1000K	R	
		100K	I/C	Water damp cloth
2nd Separation Roller (x1)	S, U	1000K	R	

Part	Ву	At	Action	Comments
2nd Feed Guide Plate (x1)	S	100K	I/C	Dry cloth
2nd Feed Sensor (x1)	S, U	100K	I/C	
2nd Vertical Transport Sensor (x1)	S	100K	I/C	Blower brush
2nd Paper End Sensor (x1)	S, U	100K	I/C	
2nd Grip Drive Roller (x1)	S	100K	I/C	
2nd Grip Idle Roller (x1)	S	100K	I/C	)   NAZ
Vertical Transport Drive Roller (x3)	S	100K	I/C	Water damp cloth
Vertical Transport Idle Roller (x3)	S	100K	I/C	

## Main Paper Transport

Part	Ву	At	Action	Comments	
Transfer Timing Drive Roller (x1)	S	100K	I/C	NAZ akan alaman alam	
Transfer Timing Idle Roller (x1)	S	100K	I/C	Water damp cloth	
Transfer Timing Sensor (x1)	S	100K	I/C	Blower brush	
Shift Drive Roller (x1)	S	100K	I/C	)	
Shift Idle Roller (x1)	S, U	100K	I/C	Water damp cloth	
Registration Timing Drive Roller (x1)	S	100K	I/C	Dry cloth	
Registration Timing Idle Roller (x1)	S, U	100K	I/C	Water damp cloth	
Registration Timing Sensor (x1)	S, U	100K	I/C	Blower brush	
Registration Entrance Drive Roller (x1)	S	100K	I/C	NA/	
Registration Entrance Idle Roller (x1)	S, U	100K	I/C	Water damp cloth	
Entrance Drive Roller (LCT) (x1)	S	100K	I/C	D 1.1	
Entrance Idle Roller (LCT	S, U	100K	I/C	Dry cloth	
Dust Collection Unit (x1)	S	100K	I/C	Empty bin, wipe with dry cloth	

Part	Ву	At	Action	Comments
Double-Feed Sensor (x2)	S	100K	I/C	
Upper Relay Sensor (x2)	S	100K	I/C	
Relay Sensor (LCT) (x2)	S	100K	I/C	Blower brush
CIS Sensor (x1)	S	100K	I/C	
Guide Plate Sensor (x1)	S, U	100K	I/C	
Relay Drive Roller (Main) (x1)	S	100K	I/C	NA/ ot on all one or all other
Relay Idle Roller (Main) (x1)	S, U	100K	I/C	Water damp cloth

## Inverter, Exit

Part	Ву	At	Action	Comments
Cooling Roller (x1)	S	100K	I/C	NAZ at a mala a managal at la
Cooling Belt (x1)	S, U	100K	I/C	Water damp cloth
Exit Anti-Static Brush (x1)	S, U	100K	I/C	Dry cloth, replace if deformed
Exit Drive Roller (Main) (x1)	S, U	100K	I/C	NAZ at a mala a managal at la
Exit Idle Roller (Main) (x1)	S, U	100K	I/C	Water damp cloth
Exit Transport Roller (x1)	S, U	100K	I/C	Dry cloth
Inverter Relay Roller (x1)	S	100K	I/C	) A/
Inverter Exit Roller (x1)	S	100K	I/C	Water damp cloth
Exit Sensor (x3)	S, U	100K	I/C	Blower brush
Inverter Roller (x1)	S	100K	I/C	Water damp cloth

## Duplexer

Part	Ву	At	Action	Comments
Duplex Anti-Static Brush (x1)	S, U	100K	I/C	Dry cloth. Replace if deformed.
Duplex Switchback Roller (x1)	S, U	100K	I/C	Water damp cloth
Duplex Switchback Sensor (x1)	S, U	100K	I/C	51 1 1
Purged Paper Sensor (x1)	S, U	100K	I/C	Blower brush
Duplex Transport Rollers (x8)	S, U	100K	I/C	NAZ at a salaman al ath
Duplex Timing Rollers (Drive, Idle) (x2)	S, U	100K	I/C	Water damp cloth
Duplex Transport Sensors (x2)	S, U	100K	I/C	Blower brush

# ARDF (D074/D075)

Part	Ву	At	Action	Comments
External Covers	S	120K	I/C	Alcohol or water, dry
Feed Belt	S	120K	R	
Pick-up Roller	S	120K	R	
Separation Roller	S	120K	R	
Original Length Sensors				
Skew Correction Sensor				
Interval Sensor				
Registration Sensor	S	120K	С	Blower brush
Paper Exit Sensor	3			
Lower Inverter Sensor				
Separation Sensor				
Upper Inverter Sensor				

Part	Ву	At	Action	Comments	
White Cover	S, U	120K	С	Alcohol or water, dry	
Transport Belt	S	120K	R		
Feed Drive Gears	S	120K	L	G501 Grease	
Grip Roller					
Transport Rollers	S				
Scanner Rollers (Entrance/Exit)		120K	КС	Alcohol or water, dry	
Exit Rollers					
Inverter Rollers (Lower, Exit, Upper)					
Idle Rollers	S	120K	С	Alcohol or water, dry	

### **SP Setting Summary**

Г	Tack	Detaile	Inctallation					PM Parts	Jarte				
				Development Unit	Developer	Drum Charge Unit	Drum	Drum Cleaning Unit	ШВ	Belt Cleaning Unit	PTR Unit	Fusing Unit	Fusing Web Cleaning Unit
	PM Parts	Applicable part only	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
2	Set Toner Bottle		Yes	,	1	,	1	_	-	-	-	-	1
3	Open Front Doors	Both left, right doors	í	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
4	Main Power ON		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
2	Enter SP Mode		1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
9	Reset PM Part	Applicable part only	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
7	Install Developer	SP3024-001(K) SP3024-002 (C) SP3024-003 (M) SP3024-004 (Y)	1	Yes	Yes	1	ı	1	1	1	1	ı	1
ω	Developer File OK?	SP3025-001 Results for YMCK reading left to right	-	Yes	Yes	-	-	-	1	-	1	1	ı
6	Apply Lubricant	Close left/right doors.     Open right door.     SP2310-1     Close right door.	1	-	1	1	1	1	Yes	-	1	1	1
10	Close Front Door		ī	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Ξ	Wait for Warmup ("Ready")	Wait 5 min. for the audible beep and the "Ready" message on the operation panel.	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
12	Manual Toner Fill	SP3051-001	Yes	1	1	1	1	1	1	-	-	1	I
13	Oleaning	SP3032-001 (All) SP3032-02 (CMY) SP3032-03 (K) SP3032-04 (C) SP3032-04 (M) SP3032-05 (M)	1	ı	1	1	1	Yes	1	1	1	1	1
14	Initialize TD Sensor	SP3030-01 (AII) SP3030-02 (CMY) SP3030-03 (K) SP3030-04 (C) SP3030-05 (M)	1	Yes	Yes	-	-	ı	-	1	-	1	ı
15	Confirm TD Sensor Initialization	SP3031-001 Results for YMCK, reading left to right.	-	Yes	Yes	J	-	-	-	-	-	1	1
16	Initialize Process Control	SP3020-001	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
17	Confirm Process Control Initialization	SP3012-001	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
18	Exit SP Mode		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
1													d074p910b

This is a quick reference table that tells you which SP codes to execute for PM part and unit replacements.

# **PM Tables for Peripherals**

Column	Meaning		Notations
Part	Name of the component, unit	Name of	the part
***K	Interval for checking, cleaning, replacement		300K where K = 1000, or 300,000 eets. (Recorded in Log Counter)
		ı	Inspect
		С	Clean
		L Lubricate	
		R	Replace
Note	What to use, etc.	Materials	required for cleaning, lubrication

## LCIT (D516)

The PM interval is for the number of sheets that have been fed.

Part	500K	1000K	Note
Transport guide plate	I/C	300K	
Grip rollers (drive, idle rollers)	I/C		
Transport rollers	I/C		Clean with damp,
Pick-up rollers (4th, 5th, 6th tray)*1	I/C	I/R	clean cloth
Paper feed roller (4th, 5th, 6th tray) *1	I/C	I/R	
Separation rollers (4th, 5th, 6th tray) *1	I/C	I/R	

RTB 40 Should be 3rd, 4th, 5th trays

- 1. At 300K, display the PM Counts for the pick-up, feed, and separation rollers.
- 2. Replace if "Target" has been exceeded.

*	
1	These rollers can be replaced by a TCRU trained operator for each tray.

## Multi-Bypass Tray (D517)

The PM interval is for the number of sheets that have been fed.

Part	500K	1000K	Note
Transport guide plate	I/C		
Grip rollers (drive, idle rollers)	I/C		
Pick-up roller*1	I/C	I/R	
Paper feed roller* <sup>1</sup>	I/C	I/R	
Separation roller*1	I/C	I/R	

- At 1000K, display the PM Counts for the pick-up, feed, and separation rollers.
- Replace if "Target" has been exceeded.
- These rollers can be replaced by a TCRU trained operator for each tray.

## Decurler Unit (D544)

Part	500K	Note
Transport guide plate	I/C	
Decurler rollers (drive, idle roller	I/C	Clean with damp (alcohol or
Transport rollers (drive, idle roller)	I/C	water) cloth
Purge tray paper sensors (x3)	I/C	

## Cover Interposer Tray (D518)

The PM interval is for the number of sheets that have been fed.

Part	60K	As Needed	Note
Drive rollers		С	
Idle rollers		С	
Feed belt	R		Dry cloth
Separation roller	R		
Pick-up roller	R		
Sensors		С	Blower brush.
Drive gears		I	Lubricate with very small amount of G501.

# Multi-Folding Unit (D521)

Part	PM Visit	Notes
Rollers (drive, idle rollers)	I/C	Alaskalakan dal
Anti-static brush	I/C	Alcohol, clean cloth
Shafts	I/C	Lubricate with silicone oil if noisy.
Sensors	I/C	Blower brush
Positioning roller	I/C	Inspect for scratches or nicks
Fold rollers (1st, 2nd, 3rd)	I/C	Alaskal damadal
Crease rollers (drive, idle roller)	I/C	Alcohol, clean cloth

# Ring Binder (D519)

Periodically inspect and clean the parts listed in the table below.

	Item	Action
Horizontal Transport Path		
Anti-static brushes		Blower brush

ltem	Action
Horizontal transport path sensors	Blower brush
Drive rollers, idle rollers	Damp cloth
Switchback Unit	
Anti-static brushes	Blower brush
Switchback area sensors	Blower brush
Drive rollers, idle rollers	Damp cloth
Binder Unit	
Paddle roller	Blower brush
Transport path sensors	Blower brush
Drive rollers, idle rollers	Damp cloth

# High Capacity Stacker (D515)

Part	500K	PM Visit	
Rollers (drive, idle rollers)	I/C	I/C	- Alcohol, clean cloth
Anti-static brush	I/C	I/C	
Shafts	I/C	I/C	Lubricate with silicone oil if noisy.
Sensors	I/C	I/C	Blower brush
Sub jogger fences	I/C	I/C	
Main jogger fences	I/C	I/C	Alcohol, clean cloth
LE stopper	I/C	I/C	

# Booklet Finisher (D512/D513)

#### Main

Part	5000K	25000K	
Rollers (drive, idle)	I/C		Alaskalakan alak
Discharge brush	I/C		Alcohol, clean cloth
Shafts	I/C		Lubricate with silicone oil if noisy
Sensors	I/C		Blower brush
Jogger fences	I/C		Tighten screws
Staple trimmings hopper	I/C		Empty hopper
Alignment brush roller		I/R	
Positioning roller		I/R	See below
Drag roller (sponge)		I/R	

- At 25000K, display the PM Counts for the alignment brush roller, positioning roller, and drag sponge roller.
- Replace if "Target" has been exceeded.

#### **Punch Unit**

Part	20000K	
Punch unit	I/C	<ul><li>Display PM Count for punch unit.</li><li>Replace if "Target" has been exceeded.</li></ul>

## **Staplers**

Part	50000K	200000K	
Corner stapler	I/R		Display PM Count.
Booklet Staplers (x2)		I/R	Replace if "Target" exceeded.

	×
ш	- 1
	V
	. 1

Part	PM Visit	
Rollers (drive, idle rollers)	I/C	Material and del
Belts	I/C	Water, clean cloth
Discharge brush	IC	Cloth, blower brush
Roller shafts		Lubricate with silicone oil if noisy
Sensors	I/C	Blower brush
Paper trimmings hopper	I/C	Empty, make sure the operator knows how to empty the hopper
Trimming Blade	R	Replace the blade after 400K. SP7989 (Trim Count) displays the total count.

#### 3

# **Lubrication Points**

# Fusing Unit Main Drive Gears






d074r303

- 1. Remove the rear plate [A] ( \*\* x3).
- 2. Apply FLUOTRIBO MG Grease to the two gears marked by red arrows. Apply about 2 g at both points.

# Cleaning, Lubrication Around Fusing Unit Heating Roller

Do the following procedures before reassembling the fusing unit.

Part Name	Interval	Action
Heating Roller Thermistors (x2)	650K	Clean



d074r405

- $1. \ \ \, \text{Use a dry cloth to remove toner and paper dust from the surface of the thermistors:}$ 
  - [A] Front
  - [B] Rear



d074r405a

- 2. Rotate the races to make sure the contact surfaces of the bearings and race turn freely. If the races do not rotate freely, they must be replaced.
- 3. Insert the heating roller at the front end of the unit.




4. The flanges must be set so that both edges of the fusing belt rim overlap the collar of the flanges.



d074r404e

5. Re-attach the bearing races at the front [A] and rear [B].




6. Re-attach the C-rings at the front and rear.

# **Cleaning and Lubrication Around Pressure Roller**

Do these procedures before re-assembling the fusing unit.


Part Name	Interval	Action	
Pressure roller thermistor	650K	Clean	



d074r407

1. Use a dry cloth to remove toner and paper dust from the sensitive surface of the thermistor.

Part Name	Interval	Action
Pressure Roller Bearing Races (x2)	650K	Lubricate



d074r408

2. Use a small brush to apply FLUROTRIBO MG Grease to the pressure roller bearing races.

#### K

# **Lubrication Around Hot Roller**





d074r997

- 1. Use a small brush to apply FLUOTRIBO MG grease to the front bearing race:
  - [A] Inner surface of bearing race
  - [B] Set bearing race and apply to outer surface



d074r998

2. Install the front bearing race.





d074r999

- 3. Use a small brush to apply FLUOTRIBO MG grease to the rear bearing race:
  - [A] Inner surface of bearing race
  - [B] Set rear bearing race and apply to outer surface




d074r001a

4. Install the rear bearing race.

# **Cleaning Points**

## Overview

This section describes how to clean the rollers and sensors in the paper path with minimal disassembly. Four units comprise the paper path.



1	Paper Bank	Paper supply, 1st Tray, 2nd Tray
2	Vertical Transport Unit	Relays paper to right drawer
3	Right Drawer	Paper registration, PTR unit, 2nd half of duplex path
4	Left Drawer	PTB, fusing unit, paper cooling unit, 1st half of duplex path

## **Inspection and Cleaning**

## **Before You Begin**

Here are some rules to follow for cleaning rollers and sensors.

#### **Roller Cleaning**

- Clean rollers with a dry cloth.
- Try to avoid touching the surfaces of the rollers with bare hands.

#### Sensor Cleaning


- Clean sensors with a blower brush. Do not use cloth or tissue paper.
- Most of the sensors are below holes in plates so you may not be able to see them.
- Insert tip of the blower brush into the hole and squeeze it to blow any paper dust off the sensor.

### 1st Tray, 2nd Tray


- 1. Turn the machine off and disconnect it from its power source.
- 2. Allow the machine to cool for at least 20 minutes.

## **ACAUTION**

 Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedures.




1 st Tray		2nd Tray	
1	1st Pickup Roller	6	2nd Pickup Roller
2	1st Paper Feed Roller	7	2nd Paper Feed Roller
3	1st Separation Roller	8	2nd Separation Roller
4	1st Paper Feed Sensor	9	2nd Paper Feed Sensor
5	1 st Grip Rollers	10	2nd Grip Rollers



d074t505


- 1. Remove the right half of Tray 1. This will allow you to see the rollers of Tray 2 and Tray 1. (\*\*p. 647)
- 2. Clean the rollers with a dry cloth.
- 3. Blower brush: 2nd paper end sensor [1] and 2nd paper feed sensor [2].
- 4. Blower brush: 1st paper end sensor [3] and 1st paper feed sensor [4].

## **Vertical Transport Unit**



1	Horizontal Transport Rollers	6	Vertical Transport Sensor
2	1st Transport Sensor	7	Bank Exit Sensor
3	2nd Transport Sensor	8	Bank Exit Rollers

4	Lower Transport Rollers	9	Main Relay Sensor 1
5	Upper Transport Rollers		



d074t506

- 1. Open the right front door.
- 2. Lower lever [1] to release the lower and upper transport plates [2].




d074t507

- 3. Blower brush:
  - [1] 2nd Transport sensor
  - [2] Vertical transport sensor




d074t508

- 4. Dry cloth:
  - [1] Lower transport drive rollers
  - [2] Upper transport drive rollers
- 5. Turn the knob as you hold the cloth against the rollers.



d074t509

- 6. Dry cloth:
  - [1] Lower transport idle rollers
  - [2] Upper transport idle rollers
  - [3] 2nd Vertical plate
  - [4] 1st Vertical plate



d074t510

### 7. Blower brush:


- [1] Bank exit sensor
- [2] Main relay sensor 1



# 8. Dry cloth:

- [1] Bank exit drive rollers
- [2] Bank exit idle rollers

# **Right Drawer**



1	Main Relay Rollers	11	Registration Timing Sensor
2	Main Relay Sensor 2	12	Shift Rollers*1
3	Registration Entrance Rollers	13	CIS (Shift Unit)
4	Main Relay Sensor 3	14	Transfer Timing Rollers
5	LCT Relay Sensor 1	15	Transfer Timing Sensor
6	LCT Relay Rollers	16	PTR (Paper Transfer Roller)
7	LCT Relay Sensor 2	17	Duplex Transport Sensor 6
8	Double-Feed Sensor (Emitter)	18	Duplex Transport Rollers 5
9	Double-Feed Sensor (Receptor)	19	Duplex Transport Sensor 7
10	Registration Timing Rollers	20	Duplex Transport Rollers 6


 $<sup>^{*1}</sup>$  Shift drive roller cleaning requires disassembly.





d074t511a

1. Lower the lever [1] and pull out the right drawer [2] until it stops.





d074t513


2. On the right side of the drawer, lower lever [1] to release the plates [2].






d074t514

- 3. Hold the dry cloth against the relay drive rollers [1].
- 4. At the right lower corner of the drawer, slowly rotate the roller shaft [2].




d074t516

- 5. Disconnect main relay sensor 1 bracket [1] and turn it over so that you can see the sensor ( $\mathcal{F}x1$ ).
- 6. Blower brush: main relay sensor 1 [2].




d074t517

- 7. Rotate knob [1].
- 8. Dry cloth: Registration entrance idle rollers [2].




d074r001c

9. Dry cloth: Registration entrance driver rollers [1].




d074t520

- 10. Disconnect main relay sensor 3 bracket [1] and turn it over so that you can see the main relay sensor ( \*\varPx1).
- 11. Blower brush: Main relay sensor 3 [2]




d074t518

- 12. Open the plate on the top right of the drawer so that you can see the LCT relay drive rollers [1] and LCT relay idle rollers [2].
- 13. Turn knob [3].
- 14. Hold a dry cloth between the plates and the rollers to clean both idle and drive rollers as they rotate [4].




d074t522

- 15. Disconnect the LCT relay sensor 1 bracket [1] and turn it over so that you can see the sensor ( \*\* x1).
- 16. Blower brush: LCT relay sensor 1 [2].



d074t524

- 17. Disconnect the LCT relay sensor 2 bracket [1] and turn it over so that you can see the sensor ( \*\*\vec{x} 2).
- 18. Blower brush: LCT relay sensor 2 [2].




d074t526

- Remove the double-feed sensor bracket [1] and turn it over so that you can see the top sensor (\*\*x1).
- 20. Blower brush: Double-feed sensor (receptor) [2].
- 21. Blower brush: Double-feed sensor (LED) [3].




d074t527

- 22. Turn the knob at the front.
- 23. Dry cloth: Registration timing idle rollers [1]
- 24. Inside the right drawer, while turning the knob, Dry cloth: Registration timing drive rollers [2]



d074t529


- 25. Disconnect the registration timing sensor bracket [1] and turn it over so that you can see the sensor.
- 26. Blower brush: Registration timing sensor [2].



d074t530

## 27. Dry cloth:

- [1] Shift idle rollers (rear)
- [2] Shift idle rollers (front)




d074t531

- 28. Remove the dust tray cover plate [1] (  $\mathcal{F}$  x3).
- 29. Remove the dust tray [2] ( \*\* x2).




d074t532

- 30. If there is any paper dust in the tray, empty it into a waste bin.
- 31. Use a dry cloth to wipe the tray clean.




dU/4t533

- 32. Disconnect the CIS bracket [1] and turn it over so that you can see the clear surface of the CIS ( \*\*x2).
- 33. Use a damp cloth and then a dry cloth to wipe the surface [2] clean.




d074t533a

34. While slowly turning the roller gear at the rear, clean the PTR with a dry cloth.




d074t534

- 35. Disconnect the PTR unit [1] support arms ( Fx2).
- 36. Push both disconnected arms toward the center [2] until they stop.
- 37. Remove the PTR unit [3].



d074t535


- 38. Turn knob [1].
- 39. Dry cloth: Transfer timing idle roller.
- 40. While turning the knob, Dry cloth: Transfer timing drive roller [3].



d074t537


41. Disconnect the transfer timing sensor bracket [1] and turn it over so that you can see the sensor ( \*\vec{x}\) x1).

### 42. Blower brush: Transfer timing sensor [2].



d074t538

- 43. At the front right corner of the drawer, lower the duplex transport path plate (Z4) [1].
- 44. Rotate the duplex transport roller knob [2].




d074t539

45. Under the right drawer, clean the rollers (as you rotate the knob) and sensors.

1	Duplex transport sensor 6	Blower brush	
2	Duplex transport drive rollers 5	Dry cloth	
3	Duplex transport idle rollers 5	Dry cloth	
4	Duplex transport sensor 7	Blower brush	

5	Duplex transport drive rollers 6	Dry cloth
6	Duplex transport idle rollers 6	Dry cloth

### Left Drawer




#### d074t504a

1	PTB Sensor	14	Exit Relay Sensor
2	Fusing Exit Sensor	15	Invert Exit Rollers 1
3	Exit Unit Entrance Rollers	16	Purge Relay Sensor
4	Cooling Unit Entrance Sensor	17	Duplex/Invert Rollers*1
5	Cooling Unit Entrance Rollers	18	Duplex/Invert Sensor
6	Cooling Pipe Roller	19	Duplex Transport Rollers 1
7	Cooling Belt	20	Duplex Transport Sensor 1
8	Exit JG Sensor	21	Duplex Transport Rollers 2
9	Exit Relay Rollers	22	Duplex Transport Sensor 2
10	Exit Sensor	23	Duplex Transport Rollers 3


11	Exit Rollers	24	Duplex Transport Sensor 3
12	Invert Exit Rollers 2	25	Duplex Transport Rollers 4
13	Invert Entrance Rollers*1		

# \*<sup>1</sup> Cleaning requires disassembly.




d074t540

1. Lower handle [1] and pull out the left drawer [2].




d074t541

2. Blower brush: PTB sensor [1]




d074t542

3. Dry cloth: Fusing unit entrance plates [1]



d074t543

- 4. Open the top of the fusing unit [1]
- 5. Dry cloth: Rollers, strippers, plates [2]
- 6. Blower brush: Fusing unit exit sensor [3]




d074t544

- 7. Open the cooling unit entrance cover [1]
- 8. Turn knob [2].
- 9. Dry cloth: Exit unit entrance rollers [3]




d074t545

- 10. Dry cloth: Cooling unit entrance rollers [1]
- 11. Blower brush: Cooling unit entrance sensor [2]
- 12. Close the cooling unit entrance cover.




d074t546

13. Raise and open the transport cover [1].




d074t547

- 14. Turn the knob.
- 15. Dry cloth:
  - [1] Cooling belt
  - [2] Cooling pipe roller




d074t548

- 16. Dry cloth:
  - [1] Exit relay drive rollers
  - [2] Exit relay idle rollers



d074t549

- 17. Dry cloth:
  - [1] Exit idle roller
  - [2] Exit drive roller




d074t550

- 18. Blower brush:
  - [1] Exit sensor
  - [2] Exit JG sensor
- 19. Lower and close the transport cover,




d074t551

20. Open the inverter/exit transport cover [1].



d074t552

- 21. Turn the knob.
- 22. Dry cloth: Invert exit rollers 2 [1]



d074t553

- 23. Open the left feed unit [1].
- 24. Clean with a damp cloth (thoroughly wrung out):
  - [2] Invert exit drive rollers 1
  - [3] Invert exit idle rollers 1



d074t554

- 25. Blower brush:
  - [1] Exit relay sensor
  - [2] Duplex/invert sensor




d074t555

26. Use a hand-held vacuum cleaner to clean the anti-static brush near the exit rollers.




d074t557

27. Release and lower the duplex transport path plate (Z4) [1].



d074t558

# 28. Rotate the duplex transport roller knob [1].




d074t559

1	Duplex transport drive roller 1	Dry cloth
2	Duplex transport idle roller 1	Dry cloth
3	Duplex transport sensor 1	Blower brush
4	Duplex transport drive roller 2	Dry cloth
5	Duplex transport idle roller 2	Dry cloth
6	Duplex transport sensor 2	Blower brush
7	Duplex transport drive roller 3	Dry cloth

8	Duplex transport idle roller 3	Dry cloth
9	Duplex transport sensor 3	Blower brush
10	Duplex transport drive roller 4	Dry cloth
11	Duplex transport idle roller 4	Dry cloth

# **Purged Paper Sensor**



d074t556

- 1. Open the left front door.
- 2. If there is paper in the purge tray, remove it.
- 3. Blower brush: Purged paper sensor

# 4. Replacement and Adjustments

# **General Cautions**

## **CAUTION**

- This machine has a Fiery controller (server type). The Fiery controller must be shut down before turning off the power supply to the main machine.
- Always turn off the Fiery controller first on the Fiery operation panel before turning off the main power switch of the machine.
- To prevent damage to the ITB, drum, or development unit when removing them or putting them
  back into the machine, never switch off the main power switch or operation power switch while the
  machine is operating.

#### **Rear Boxes**

Exercise caution when operating the machine with the rear boxes open, especially the cooling box:

- This machine has many fans and ventilation ducts to expel ozone, paper dust, and hot air from around the PCDUs and other areas inside the machine.
- If you service the machine and then check printing operation with the rear boxes open, dust or gases may adhere to the OPC drums and cause problems with image output (white block patterns for example).
- Normally, process control can handle such minor problems, but if you want to recover the print
  quality as soon as possible, print several sheets with solid color images.

#### Drum


The organic photoconductor (OPC) drums are very sensitive to light and ammonia gas. When handling an OPC drum:


- 1. Never expose a drum to direct sunlight.
- 2. Never expose a drum to direct light of more than 1,000 lux for more than a minute.
- Never touch a drum surface with bare hands. If the drum surface is touched or becomes dirty, wipe it with a dry cloth or clean it with a damp cotton ball. Wipe with a dry cloth after cleaning with damp cotton.
- Never use alcohol to clean a drum. Alcohol can dissolve the drum surface and damage it permanently.
- 5. Store drums in a cool, dry place.

- 6. The photo-conductive layer of a drum is very thin and scratches easily. Always handle a drum with care.
- 7. Never expose a drum to corrosive gases such as ammonia.
- 8. Always dispose of used drums in accordance with local laws and regulations.

#### **PCDU**

- 1. To prevent scratching a drum or the ITB, always lower the ITB before you remove a PCDU or pull out the ITB unit.
- 2. The charge rollers should always be replaced together as a set.





d074r052

- 3. Before you push the PCDU into the machine, you must confirm:
  - Charge unit lock lever [1] is down and locked
  - Cleaning unit lever [2] is up and locked.

#### **ITB Unit**

- 1. Never touch the surface of the ITB surface with bare hands.
- 2. Pull the ITB unit out of the machine only when it is absolutely necessary.
- 3. Always work carefully around the ITB (to avoid dropping tools, screws, etc.) when it is pulled out of the machine.
- 4. Before installing a new ITB, clean all the rollers and the inner surface of the ITB unit with a dry cloth to prevent the new belt from slipping.

4

### Scanner Unit (D074/D075)

- 1. When installing a new exposure glass, always make sure that the white paint mark is at the rear left corner.
- 2. Clean the exposure glass with alcohol or glass cleaner to reduce the amount of static electricity on the glass surface.
- 3. Use a cotton pad dampened with water or a blower brush to clean the scanner optics.
- 4. Never bend or twist the exposure lamp cables.
- Never disassemble a lens unit. Attempting to disassemble a lens unit will throw the lens and the copy image out of focus.
- 6. Never attempt to adjust a CCD positioning screw. Doing so will throw the CCD out of position.

#### Laser Unit

1. Never open the laser unit. The laser units are replaced as units in the field.

### **Development**

- 1. Avoid nicking or scratching the development roller.
- 2. Place a development unit on a sheet of paper after removing it.
- 3. Always clean the drive gears after removing used developer.
- 4. Always dispose of used developer in accordance with local regulations.
- Never load any type of developer or toner into the development unit other than those specified for this machine. Doing so will cause poor print quality and toner scattering.
- Immediately after replacing the developer, be sure to execute the SPs to initialize the developer/ toner
- 7. Never do SP3030 with used developer.
- 8. When using a vacuum cleaner to clean the development unit casing, always ground the casing with your fingers to avoid damaging the toner density sensor with static electricity.
- 9. The TD sensor must be initialized:
  - After replacing developer. (Initialize the TD sensor only for the PCDU where the developer was replaced.)
  - Never initialize the TD sensor more than once. Initializing the TD sensor more than once can cause toner scatter inside the machine.

- 1. When servicing cleaning unit components, avoid nicking the edges of the cleaning blades.
- 2. Never touch the edges or surfaces of a cleaning blade with bare hands.
- 3. Before disassembling a cleaning unit, place a sheet of paper under it to catch stray toner or dry lubricant.

### Fusing Unit

- 1. Never handle fusing lamps and rollers with bare hands.
- 2. Make sure that the fusing lamps are positioned correctly and do not touch the inner surface of the rollers.

### **Paper Feed**

When replacing the pick-up, feed, and separation rollers in tray 1 or 2 of the main machine, trays 3, 4, 5 of the LCIT, or tray 6 (bypass tray):

- Use only rollers specified for use with this machine or peripheral unit.
- When handling the new rollers, avoid touching the surfaces of the rollers.

#### **Used Toner**

- 1. Check the level of the used toner in the used toner bottle at every service visit.
- 2. Always dispose of used toner in accordance with local laws and regulations.
- 3. Never attempt to incinerate used toner.

### Fiery Controller

- 1. Use the "Shut Down" button on the operation panel to turn off the Fiery controller.
- 2. Never turn off the main power switch of the mainframe before shutting down the Fiery controller. Here is the correct shut down sequence for the Fiery and the main machine:

#### On the Fiery controller operation panel:

- Press the [Fiery] tab.
- Press the [Restart Fiery] button.
- Press the [Shut Down" button.

4

#### To shut down the main machine

- Push the operation switch to turn the power off
- When the power LED goes off, turn the main power switch off. Never turn off the main power switch when the power LED is lit or flashing.

## Liquid Coolant Disposal

- The coolant tank is located at the bottom of the cooling box on the back of the main machine.
- The coolant tank holds the propylene glycol coolant that circulates from the tank through hoses that pass behind the cooling plates on the sides of the four development units.
- Always obey local laws and regulations if you need to dispose of a tank or coolant.
- The tank must never be emptied directly into a local drainage system, river, pond, or lake.
- Contact a professional industrial waste disposal organization and ask them to dispose of the tank.

# **Special Tools and Lubricants**

## **Special Tools**

### D074/D075

Part No.	Description
A0069104	Scanner Positioning Pin (4 pcs./set)
A0929503	Test Chart-C4 (3 pcs./set)
A0299387	Digital Multi-meter: FLUKE 87
B6455010	SD Card
C401 9503	20x Magnification Scope

### M044

Part No.	Description
A0299387	Digital Multi-meter: FLUKE 87
B6455010	SD Card
C401 9503	20x Magnification Scope

## Lubricants

Part No.	Description
A2579300	Grease Barrierta - S552R
52039502	Silicone Grease G-501
B132 9700	Drum Setting Powder
VSSG 9002	FLUOTRIBO MG Grease

4

### 4

## **Common Procedures**

This section describes important procedures that are referenced in other replacement and adjustment procedures. Service technicians must be familiar with the basic procedures before servicing the machine.

## Turning the Machine On/Off

### **Turning the Machine On**

- 1. Turn on the Fiery controller.
- 2. Switch on the main switch of the main machine.


### **Turning the Machine Off**

### On the Fiery controller operation panel:

- 1. Press the [Fiery] tab.
- 2. Press the [Restart Fiery] button.
- 3. Press the [Shut Down] button.

#### On the main machine

- 1. Push the operation switch on the operation panel to turn the power off.
- 2. Wait for the operation switch power LED to stop flashing.
  - **☆ Important** 
    - Never turn off the main power switch when the power LED is lit or flashing.
- 3. After the power LED goes off, open the left front door.
- 4. Turn the main power switch off.



d074r004

On the right edge of the controller box [A] and the left edge of the cooling box [B], remove the top, middle, and bottom screws ( \*\*x6\*).




d074r005

2. Swing open both boxes.

#### 4

## Removing Doors, Covers


## **Right Front Door**



d074r001

- 1. Open the right front door.
- 2. Use the tip of a small screwdriver to release and remove the lock clip [A].
- 3. Lift the door [B] off the bottom hinge and remove it.


### **Left Front Door**



d074r002

- 1. Open the left front door.
- 2. Use the tip of a small screwdriver to release and remove the lock clip [A].
- 3. Lift the door [B] off the bottom hinge and remove it.


### **Left Cover**



d074r003

1. Remove the left cover [A] ( \*\* x7).

## **Cooling Box Covers**




d074r006

- 1. On the left edge of the cooling box [A], remove the top, middle, and bottom screws (  $\mathcal{F}$  x3).
- 2. Swing the cooling box open.



d074r007

- 3. Use the tip of a small screwdriver to remove the screw covers (x4) on the top of the cooling box [A].
- 4. Remove the screws where the covers were removed ( Fx4).
- 5. Remove the top of the cooling box.





d074r008

### 6. Disconnect:

[A] Left side ( 🗗 x2)

[B] Back ( 🗗 x8)

[C] Right side ( \*\bar{x} x3)



d074r009


7. Remove the cover.

### **Controller Box Covers**



d074r010


- 1. On the side of the main machine, disconnect the ARDF [A] on the D0704/D075 ( $\square$  x1).
- 2. On the right edge of the controller box [B], remove the top, middle, and bottom screws (  $\mathcal{F}$  x3).
- 3. Swing the controller box open.





d074r011

- 4. Use the tip of a small screw driver to remove the screw covers (x4) on the top of the controller box [A].
- 5. Remove the screws where the covers were removed ( \*\mathbb{P} x4).
- 6. Remove the top of the controller box.





d074r012

### 7. Disconnect:

[A] Right side ( Fx2)

[B] Back ( 🗗 x8)


[C] Left side ( \*\bar{\mathbb{P}} x3)



d074r013

8. Remove the controller box cover.

## **Right Cover**



m044r014

1. Remove the right cover ( \*\bar{x} x8).

## Pulling Out and Closing the Left Drawer


### **Pulling Out the Left Drawer**

- 1. Make sure that the system is off and confirm that the machine power cord is disconnected from the power source.
- 2. Spread a drop cloth or some paper in front of the machine.
- 3. Prepare a flat clean surface where you can place the fusing unit after it has been removed.
- 4. Open both front doors.




d074u401

5. The fusing unit is in the left drawer.




d074u402

- 6. Lower the lock lever [A].
- 7. Pull the fusing unit [B] out completely until it stops.



d074u414

The rear fusing unit handle is spring loaded to keep it down and completely flat when not in use.



d074u415

- 1. Push the left drawer [A] slowly into the machine until it locks in place.
  - The left drawer should move smoothly into the machine.
  - Never force the left drawer into the machine if you feel any resistance.
  - If you feel resistance, stop pushing and pull the left drawer out again. Check the wire handle
    at the back of the fusing unit, and make sure that this handle is down completely.

## Removing the Right Drawer



- Removal of the right drawer unit requires two people.
- One person cannot lift and move the right drawer unit.






d074r036


- 1. Lower the handle.
- 2. Pull the right drawer out until it stops.





d074r037


- 3. Remove handle **B3** [A] ( \*\*\bigsiz x1).
- 4. Remove the knobs [B] (x4) ( \*\* x1 each).





d074r038

- 5. Disconnect the faceplate [A] ( \*\bar{x} x4).
- 6. Lower plate [B] so that it floats free.
- 7. Remove the faceplate. You may need to move plate [B] to free the faceplate.



- 8. Remove:
  - [A] Screw on the left rail ( Fx1)
  - [B] Screw on the right rail ( Fx1)



d074r040

9. With one person on each side of the unit, lift it off the rails as shown above.

### **CAUTION**

 The unit is extremely heavy. Two persons are required to lift the unit off the rails (and to reinstall it).


## **Pulling Out the ITB Unit**


## Before Pulling Out the ITB Unit and PCDUs

## **ACAUTION**

• At job end or when the machine is switched off, both sides of the ITB unit are lowered and separated from the drums.

- However, after a power failure or accidental disconnection of the power cord, or after the machine
  issues an SC code after a malfunction, both or one side of the ITB may remain up against the
  drums.
- To avoid damage to the ITB and drums, both sides of the ITB must be checked and lowered before
  the ITB unit and PCDUs can be pulled out of the unit





d074r040a

- 1. Always check the front edge of the ITB at two points [A] before you pull the ITB unit out of the machine.
- 2. If you see either white cap [B] (or both), this means the ITB lift motors have failed to lower the belt when the machine was powered off.

### **ACAUTION**

• If you see the belt up as shown at [B], the ITB must be lowered manually before the ITB unit is pulled out of the machine.



d074r040b

3. To lower the left half of the ITB unit, turn the gear until the left side of the belt is down and you no longer see the left white cap.



d074r040c


- 4. To lower the right half of the ITB unit, remove cover [A] (  $\mathcal{F}$  x2).
- 5. Turn screw [B] until the right half of the ITB is down and you no longer see the right white cap.



d074r040d

- 6. Check again to make sure that both caps are down.
- 7. With both caps down, the ITB unit can be pulled out.

## 1st Stop Position





d074r041

- 1. Lower the ITB lever [A].
- 2. Remove the ITB lever lock plate [B] ( \*x2).





d074r042


3. Remove the right ITB plate [A] ( Fx2).





d074r043


4. Remove the left ITB plate [A] ( \*\* x2).





d074r044

- 5. Disconnect:
  - [A] Left end of ITB unit ( Fx1)
  - [B] Right end of ITB unit ( Fx1)



6. Grip both handles of the ITB unit [A] and pull it out until it stops. This is the first stop position.


### **2nd Stop Position**

1. Depress the rail release levers [B] on both sides of the ITB unit tray and pull it out until it stops. This is the second stop position.



• Never leave the ITB unit out and fully extended longer than necessary.

### Re-installation



d074r046

Before you push the ITB unit into the machine:

- Make sure handle B3 [A] below the ITB unit tray is down. You cannot push the ITB unit tray into the
  machine if this lever is up.
- You must depress the rail lock levers [B] in on both sides of the tray. (The rail locks engage automatically when the ITB tray is pulled out completely.

## Removing the Canopy Cover

The procedure for removal of the canopy cover for the D074/D075 is different from the procedure for the M044.


- D074/D075. The ARDF and some covers around the exposure glass on the left side of the machine must be removed.
- M044. Only three plastic covers need to be removed on the left side of the machine.


In addition, the toner bank door, attention light, operation panel, and toner bank cover must be removed for all models.

### Canopy Cover: D074/D075

Before you can remove the canopy cover, you must remove the ARDF and some plates around the exposure glass.

#### **ARDF**






d074r015

- 1. On the right side of the machine, disconnect the ARDF [A] ( x1). (Press in at [1] to release then pull out [2].)
- 2. Raise the ARDF [B].



d074r016

3. Remove the ARDF base screws ( \*\bar{\mathbb{E}} x2).



4




- Confirm that the ARDF cable has been disconnected from the right side of the machine before
  you lift the ARDF off the machine.
- 4. Grip the base of the ARDF [A] on both sides.
- 5. Pull the ARDF toward you to free the shoulder screws [B] and [C] from the keyholes of the plates.
- 6. Lift the ARDF off the machine and set it down.

### Around the Exposure Glass



d074r018

- 7. Open the toner bank door [A].
- 8. Remove the front "L" plate [B] ( \$\infty\$ x3).




d074r019

- 9. Remove the rear plate [A] ( Fx5).
- 10. Go to "Canopy Cover Removal Continued (D074/D075/M044" below to complete removal of the canopy cover.

The MO44 has no ARDF or exposure glass. You need to remove only three plastic covers before you can remove the canopy cover.

1. Confirm that the machine is switched off and disconnected from the power source.


### Rear Cover



m004c001

- 2. Use the tip of a small screwdriver to remove the three screw hole covers [A].
- 3. Disconnect cover [B] and remove it ( \*\bar{x} x 3).

### Center Cover



m004c002

4. Disconnect center cover [A] and remove it ( \*\bar{x} x4).

### Front Cover

4




m004c003

- 5. Disconnect front cover [A] and remove it ( \*\bar{x} x 3).
- 6. Go to the next section to complete removal of the canopy cover.

## Canopy Cover Removal Continued (D074/D075/M044)

### **Toner Bank Door**



d074r021

- 1. Open the toner bank door.
- 2. To remove the top hinge [A], swing the "L" hinge pin out [1] and pull it up [2] to remove it.
- 3. Remove the bottom "L" hinge pin [B] and remove the door.

### Attention Light






d074r022

- 4. Remove the base screws of the attention light (\$\infty\$ x3).
- 5. Lay the light on its side and disconnect it ( $\mathbf{L}^{1} \times 1$ ,  $\mathbf{L}^{2} \times 2$ ).

### Operation Panel






d074r023


- 6. Remove the right cover [A] ( Fx8).
- 7. Disconnect the operation panel harness at [B] ( $\square$  x2).
- 8. Inside the machine, disconnect the harness cable ( $\mathcal{F}$ x1).

4



d074r024

- 9. Use the tip of a small screwdriver to remove screw cover [A].
- 10. Remove arm cover [B] ( \*\bar{x} x2).



d074r025


- 11. Disconnect the base of the operation panel [A] (  $\mathcal{F}$  x3).
- 12. Push the arm [B] away to slide the shoulder screws out of the keyholes.
- 13. Lift the operation panel and set it slightly to the left.



d074r026

- 14. Pull the operation panel harness out of the hole.
- 15. Lift the operation panel off the machine and set it down.

### **Canopy Cover**




d074r027

- 16. Use the tip of a small screwdriver to remove the screw covers.
- 17. Remove the screws where the covers were removed ( Fx4).



d074r028

- 18. At the front [A], remove a screw (  $\mathcal{F}_{x1}$ ).
- 19. At the rear [B] (near the scanner unit), remove a screw ( \*\varPx1).






d074r029

- 20. Disconnect the cover on the left ( Fx2).
- 21. Lift the canopy cover off.


### **Toner Bank Cover**





d074r030

22. At the rear [A], disconnect the attention light harness (🖨 x3).





d074r031

- 23. Disconnect the cover at the rear [A] ( \*\* x2).
- 24. Disconnect the cover at the front [B] ( \*\*x2).







d074r032

- 25. Disconnect the cover on the left side [A] ( \*\*\varphi x4).
- 26. Lift the canopy cover off.

### **Toner Bottles**






d074r033

- 27. Push the toner bottle release lever [A] of each bottle to the left. Each bottle will pop out as it is released.
- 28. Remove each bottle.

## **Toner Bottle Cradles**



d074r034

- 29. Disconnect each cradle:
  - [A] Front ( 🗗 x4)

[B] Rear ( 🗗 x4)



d074r035

30. Remove each cradle (x4) and set it aside.




• The cradles are identical. They can be re-installed at any position.

### **Removing PCDUs**

## **ACAUTION**

- At job end or when the machine is switched off, both sides of the ITB unit are lowered and separated from the drums.
- However, after a power failure or accidental disconnection of the power cord, or after a the
  machine issues an SC code after a malfunction, both or one side of the ITB may remain up against
  the drums.
- To avoid damage to the ITB and drums, both sides of the ITB must be checked and lowered before
  the ITB unit and PCDUs can be pulled out of the unit
- 1. Spread a drop cloth or some paper in front of the machine.
- 2. Open both front doors.



d074r102a

3. There are four PCDUs (YMCK).



d074r102b

4. Lower the ITB release lever. (This separates the ITB from the bottoms of the drums so that the surface of the ITB or drum will not be scratched when a PCU is removed.)

### To Remove the Y\_PCDU or M\_PCDU Lock Screw





d074r102c

5. Remove the PCDU lock screw.

### To Remove the C\_PCDU or K\_PCDU Lock Screw



d074r102d

6. A plate must be removed before you can remove the two PCDUs on the right.





d074r102e


- 7. Make sure that the ITB lever [A] is down.
- 8. Remove the screws and remove the plate [B].




d074r102f

9. Remove the PCDU lock screw.

#### To Remove a PCDU






d074r068

- 10. Depress the PCDU lock lever [A] and pull the PCDU out slowly until it stops.
- 11. Remove lock screw [B] ( Fx1).
- 12. Lift the PCDU [C] off the rails and then lay the PCDU on the prepared surface.

## 

- Place the PCDU upright on a flat clean surface.
- There is only a small gap between the surface of the drum and the table surface, so the surface must be smooth, flat, and clean.
- To avoid damage to the surface of the drum, never place the PCDU on a carpet or rough cloth.
- 13. Push the PCDU rails into the machine.

#### Re-Installation




d074r987

- 1. Always check the left side of the PCDU before you push it back into the machine. (This is the shield plate that conducts heat away from the development unit.)
- 2. If you see any toner on the plate, wipe it off with a clean dry cloth.


## **ACAUTION**

- To prevent toner scatter or gear damage, never apply excessive force on the PCDU when you
  push it into the machine.
- 3. After you push the PCDU into the machine, make sure that PCDU is locked correctly.



d074r915

• When the PCDU is locked correctly, the top of the lock lever is straight as shown above.



- d074r916
- If the PCDU is not locked correctly, the top of the lock lever is slanted slightly down to the left as shown above.
- 4. If the PCDU lock lever is not locked correctly, pull the PCDU out about 30 mm (1.5 in.) and push it in again so the top of the lock lever is level.

## Removing the ITB Cleaning Unit


- 1. Make sure that the system is off and confirm that the machine power cord is disconnected from the power source.
- 2. Spread a drop cloth or some paper in front of the machine.
- 3. Open both front doors.



d074u201


4. The ITB cleaning unit is below the PCDUs.





d074u202

- 5. Remove the two screws and cover [A].
- 6. Raise both levers [B].
- 7. Remove screw [C].



d074u203

- 8. There is a tab release on the left side of the ITB cleaning unit. Pull the cleaning unit [A] about half way out.
- 9. Press tab release [B] to the right.

d074u204

10. Pull out the ITB cleaning unit.

## Removing the PTR Unit


- 1. Make sure that the system is off and confirm that the machine power cord is disconnected from the power source.
- 2. Spread a drop cloth or some paper in front of the machine.
- 3. Open both front doors.



d074u301

4. The PTR unit is located in the right drawer unit.






d074u302

5. Lower lever [A] and pull out the right drawer [B] completely until it stops.

Λ



d074u303

- 6. Remove two screws [A].
- 7. Push both arm supports [B] in toward the center until they stop.
- 8. Grip both ends of the unit by the metal handles [C].



d074u304

9. Rotate the unit toward you to disconnect it from the shaft below and remove it.

# Removing the Fusing Unit, Fusing Cleaning Unit, Covers


#### **Preparation**

- 1. Make sure that the system is off and confirm that the machine power cord is disconnected from the power source.
- 2. Spread a drop cloth or some paper in front of the machine.
- 3. Prepare a flat clean surface where you can place the fusing unit after it has been removed.
- 4. Open both front doors.




d074u401

1. The fusing unit is in the left drawer.



d074u402

- 2. Lower the lock lever [A].
- 3. Pull the fusing unit [B] out completely until it stops.



d074u403

4. Remove screw [A].

5. Push lock lever [B] to the right.



d074u404

- 6. Raise the fusing exit idle roller cover [A].
- 7. Raise the wire handle [B] and grip the front of the fusing unit [C].




- The fusing unit weighs about 17 kg (37 lb.).
- 8. Lift the fusing unit out of the left drawer and set it on a flat clean surface.

## Removing the Fusing Cleaning Unit



d074u405

- 1. Position the fusing unit so that the fusing cleaning unit [A] is facing you.
- 2. Remove screw [B].



d074u406

- 3. Push plastic-capped lever [A] to the left.
- 4. The fusing cleaning unit [B] will pop out slightly.



d074u407

5. Push the unit [A] slightly to the left to disconnect the shafts on the right, then pull it out of the fusing unit.


#### **Cover Removal**

The fusing unit covers must be removed to service thermistors and sensors in the fusing unit



d074r410

1. Remove the fusing unit from the machine and place it on a flat clean surface.




d074r411

#### 2. Remove:

[A] Separation unit cover ( > x1, > x1)

[B] Top cover ( \*x1, \*x2)



d074r412

- 3. Remove:
  - [A] Rear harness cover ( x1)
  - [B] Rear cover ( x3)

# Removing the PTB Unit

- 1. Open the front doors.
- 2. Pull out the left drawer until it stops.
- 3. Remove the fusing unit ( p.433).



d074r752

4. Remove the left drawer cover ( \*\bar{x} x8).



d074r737

5. Raise the PTB unit ( 🗗 x2).



d074r738

6. Disconnect the PTB unit (🖼 x 1,📫 x 1).



d074r739

7. Disconnect the clamp and shaft.





d074r740

8. Remove the PTB drive belt.




d074r741

9. Remove the PTB unit.

# Removing the Left Drawer




- The left drawer is heavy. Two people are required for this procedure.
- 1. Open the front doors.
- 2. Pull the left drawer out until it stops.
- 3. Remove the fusing unit ( p.433)



d074r750

- 4. Remove the lock screws:
  - [1] Left lock screw ( \*\begin{align\*} x 1)
  - [2] Right lock screw ( Fx1)




d074r751

5. With one person on the left side and one on the right as shown, lift the left drawer off its rails and set it on a flat surface.

## Removing the Paper Feed Units (PFU)


## Tray 1 Paper Feed Unit Removal

1. Open Tray 1 and remove the right tandem tray (x2).




d074r440

2. Remove knobs [1] and [2] ( \*\* x1 each).




d074r441

3. Remove cover [1] ( \*\* x2).



d074r442

- 4. Disconnect the front bracket [1] ( x1, x1, x2).
- 5. Remove the Tray 1 PFU [2].




d074r442a

6. Lay the PFU on a clean flat surface.


## Tray 2 Paper Feed Unit Removal

1. Open Tray 1 and remove the right tandem tray (x2).




d074r443

2. Remove bracket [1] ( \*\* x4).




d074r444

- 3. Disconnect the front bracket [1] (🗗 x1, 🎉 x2).
- 4. Pull out Tray 2 [2].



d074r445

- 5. Remove the inner tray [1] of Tray 2.
- 6. Remove the Tray 2 PFU [2].



d074r442a


7. Lay the PFU on a clean flat surface.

# Removing the Vertical Transport Unit (VTU)



d074r529

- 1. The vertical transport unit is located at the lower right corner of the main machine.
- 2. Open the right door.
- 3. If the LCIT is connected, disconnect it and pull it away from the machine.
- 4. Remove the right cover of the main machine ( \*\*x7).
- 5. Open Tray 1 and remove the right tandem tray ( Fx2).
- 6. Open the right drawer.



d074r530

#### 7. Remove:


[1] Knob ( 🗗 x 1 )

[2] Lever ( x1)




d074r531

8. Disconnect cover [1] ( \*\* x4).




d074r440

9. Remove knobs [1] and [2] ( \*\* x1 each).



d074r441

10. Remove cover [1] ( \*\* x2).



d074r996

11. Where you removed the cover in the previous step, remove the drive gear bracket [A] (  $\mathcal{F}$  x2).





d074r532

## 12. Remove the funnel holder ( Fx1).




d074r533

## 13. Remove cover [1].



d074r534



d074r535

15. Pull the lower cover to the side. You do not need to disconnect the harness.



d074r536


16. Disconnect the top bracket [1] of the vertical transport unit. ( 🗗 x3)

4



d074r537

17. Disconnect the front bracket [1] ( \*\* x2)



d074r538

18. Remove the rear bracket top screw [1] and bottom screw [2] ( \*x2). These screws are difficult to see but they are at the same height as the front bracket screws.



d074r539

- 19. Disconnect the unit (🖾 x2).
- 20. Pull out the right drawer until it stops.




d074r540

 $21.\,$  Slide the unit slightly to the right and remove it.


## Re-installation

1. Make sure that the right drawer is open.



d074r541

2. Hang the top bracket of the vertical transport unit [1] on the machine frame.




d074r542

- 3. Hold the unit level and insert the front guide pin [1] into the hole in the main frame [2].
  - There are two of these pins, one at the front (shown above) and one at the rear.
  - Check the top bracket and make sure that the front and rear ends of the bracket are flat against the frame.
  - If the rear end of the bracket is not flat, the rear pin is not inserted correctly.
  - Repeat the procedure and hold the unit as level as possible when you insert the front pin.

# **Operation Panel**

# **Changing the Operation Panel Position**



d074i816a


There are four possible ways to configure the operation panel when it is installed.

Config.	Description
1	<b>Standard</b> . The support arm is perpendicular to the right side of the machine and the operation panel is recessed from the front of the machine. This procedure is described in the Installation section.
2	<b>Standard Diagonal</b> . The support arm is set at an angle so that the operation panel is flush with the front of the machine. Described in this section.
3	Standard Diagonal Extended. The support arm is set an angle (same as Configuration 2) and the arm is extended so that the operation panel extends beyond the front of the machine. Described in this section.
4	<b>Easy Access (Sitting Position)</b> . This is the same as Configuration 3 but the operation panel is removed and re-hung on lower hooks so it is lower. This allows access to the operation panel from a sitting position. This procedure is described in the Installation section.

• The installation procedure describes how to install the operation panel with Configuration 1 or 4.

4


• Refer to this section if you need to remove the operation panel and re-install it with Configuration 2 or 3.



d074r281


1. Remove the screw covers of the arm support [A] (x2).






d074r287


2. Remove the arm cover [A] ( Fx2).





d074r288

- 3. Disconnect the arm base [A] ( Fx3).
- 4. Push the arm to the left, to disconnect the shoulder screws from the narrow ends of the keyholes on the base.




d074r289a

5. Lift the base off the shoulder screws and set it a short distance from the hole, as shown.



- The harness is connected below. Pull the support arm away only a very short distance.
- 6. Remove shoulder screw [A] and re-fasten it at the lower hole ( $\triangle x1$ ).
- 7. Remove shoulder screw [B] and re-fasten it at the upper hole (🔊 x1).

  The screws should now be diagonally opposite one another as shown above.



d074r290

- 8. Set the base of the support arm [A] onto the shoulder screws.
- 9. Make sure the base is flat against the top of the machine.
- 10. Push the support arm to the right to lock the base onto the shoulder screws. You can see the three holes of the base aligned with the holes below.
- 11. Re-attach the base screws [B] ( Fx3).




• Make sure that these screws are fastened tightly.

12. This completes the adjustment for **Configuration 2**. Re-attach the cover.

-or-


Do the next procedure if you want to extend the arm for Configuration 3.

#### To Extend the Support Arm




d074r291

1. Remove the screws on top of the support arm [A] ( \*\*\mathbb{P} x4). **Keep these screws .** 



d074r292

- 2. At the bottom of the base [A], open the clamp and pull a short length of the harness out of the hole to create some slack in the harness (🗟 x1).
- 3. Slowly push the support arm [B] to the left to extend it.



d074r293

- 4. Push the arm [A] to the left until the holes on the top of the arm are aligned with the four holes below.
- 5. Re-attach the screws you removed in Step 1 ( \*\bar{x} x4).
- 6. Push the harness [B] into the hole, and then clamp it (🖼 x1).



• Make sure that these screws are fastened tightly.


This completes the installation for Configuration 3.

## **Operation Panel PCBs, Touch Panel Unit**

#### **Operation Panel Removal**

1. Follow Steps 1 to 6 of the previous procedure "Adjustment for Easy Access".


#### Rear Cover






d074r330

2. Remove the rear cover [A] ( \*\*\* x8).



d074r331


3. Disconnect and remove the OPU ( x3, FFC Thin x1, 8 x5)





d074r332

4. Remove the PCB cover [A] ( \*x10).






d074r333

There are three boards on the back of the operation panel.

- ① Sub Keys PCB
- 2 Main Keys PCB
- 3 Application Keys PCB


Sub Keys PCB



d074r334

5. Disconnect and remove the sub keys PCB [A] ( x1, x2)


## Main Keys PCB



d074r335

6. Remove the main keys PCB [A] (  $\ref{P}$  x8).

#### **Application Keys PCB**



d074r336

7. Remove the application keys PCB [A] ( \*x2).

#### 4

#### Touch Panel Unit with LCD



d074r337


8. Remove the touch panel unit [A] ( \*x3).



d074r338

This is a front view of the removed touch panel unit.

## Re-installation



d074r339


- When you re-attach the PCB cover [A], fasten the screws as shown ( \*\*x10).
- Do not fasten screws at 10 and 20. These holes are for rear cover screws.

It is necessary to calibrate touch panel:

- After replacing the operation panel.
- After replacing the controller board.
- If the touch panel detection function is not operating correctly.


#### Mportant !

- Do not use items [2] to [9] on the Self-Diagnostic Menu. These items are for design use only.
- 1. Press [Reset], press [1] [9] [9] [3], and then press [Clear] 5 times to open the Self-Diagnostics menu.



b178r548

- 2. On the touch screen press "Touch Screen Adjust" (or press "1").
- 3. Use a pointed (not sharp) tool to press the upper left mark .



b178r549

- 4. Press the lower right mark when **b** shows.
- 5. Press [#] OK on the screen when you are finished.
- 6. Touch [#] Exit on the screen to close the Self-Diagnostic menu. Save the calibration settings.

4

# **ARDF**

# ARDF Covers



d074r792

1. Open the feed cover.



d074r793

2. Remove the screws on the top edge of the front cover (  $\mbox{\em psi} x2$ ).



d074r794

3. Press down on the right end of the cover to release the tab and remove the cover.



d074r795


- 4. Remove screw [1] on the top edge of the rear cover ( $\mathcal{F}$ x1).
- 5. Remove screw [2] on the back of the rear cover (  ${\cal F}$  x1).




d074r796

6. Remove the rear cover.

# **Original Feed Unit**



- 1. Open the feed cover [A].
- 2. Remove the snap fitting [B].
- 3. Pull [C] toward you slightly to disconnect the rear end of the shaft.
- 4. Disconnect the front end of the shaft [D].




#### 1. Remove

- Original feed unit (1 p.463)
- [A] E-ring (@x1)
- [B] Cover
- [C] Slide out (■x2)

## **U** Note

• At re-assembly, make sure that the tab ① on the front guide plate is above the pick-up roller unit.




d132r107

#### 2. Slowly remove:

- [A] Feed belt holder
- [B] Feed belt




• Do not let springs 1 and 2 fall out and get lost.



d132r106a


3. Remove the ARDF pickup roller [A].

## **Bottom Plate Position Sensor**




- 1. Remove:
  - Front cover (**1**p.461)
  - Original feed unit (\*\*p.463)
- 2. Remove the pivot screw [A] ( x1)
- 3. Raise the bottom plate [B].
- 4. Remove the bottom plate position sensor [C] (□ x1, ¬x3).

## Interval, Original Width, Skew Correction Separation Sensors



- 1. Open the feed cover [A].
- 2. Remove guide plate [B] ( Fx 3).




3. Remove

- [A] Width sensor assembly ( Fx2)
- [B] Original width sensors (🞜 x5)


4

- [C] Interval sensor ( x1)
- [D] Skew correction sensor ( x1)
- [E] Separation sensor (🕮 x1)

### Original Length Sensors




- 1. Remove the front and rear covers (\*\*p.461)



- 3. Disconnect the lower cover [A] ( \*\bar{x} x4).
- 4. Disconnect sensors at [B]:


- 1 B5 original length (1 x1)
- ② A4 original length (🞜 x1)
- ③ LG original length (□ x1)

# Cover Open, Original Set, Bottom Plate, Pickup Roller HP, Feed-Out Sensors




d132r116

- 1. Remove the front and rear covers (\*\*p.461)
- 2. Remove
  - [A] Original tray (🗗 x1, 👨 x2, Collars x2)
  - [B] Lift tray (🗗 x1, 🖍 x1)




- 3. Disconnect and remove
  - [A] Original set sensor (🗗 x1, 🎉 x1)
  - [B] Upper inverter sensor ( x1, x1)
  - [C] Feed cover sensor ( x1)
  - [D] Pickup roller HP sensor ( x1)
  - [E] Bottom plate position sensor (🗂 x1)

### **ARDF Position Sensor, APS Start Sensor**




- 1. Raise the ARDF [A] to the vertical position.
  - [B] APS assembly ( \*\begin{align\*} x 1)
  - [C] ARDF position sensor (🚅 x1, ▼x3)

# Original Registration Sensor Exit Sensors



- 1. Remove
  - Front and rear covers, feed cover (10 p.461)
  - Original feed unit (1 p.463)
- 2. Rotate the inverter guide [A] 180 degrees.
- 3. Remove the original guide plate [B] ( \*\begin{align\*} x4 \).




d132r113

4. Remove

[A] Assembly ( 🗗 x 1)


[B] Registration sensor (🚅 x 1)



d132r115

- 5. Remove:
  - [A] Assembly ( 🗗 x 1)
  - [B] Original exit sensor (🛍 x1)

# **ARDF Separation Roller**




- 1. Open the feed cover.
- 2. Remove the original feed unit. (\*\*p.463)

#### 3. Remove:


- [A] Separation roller cover. Use the tip of a small flathead screwdriver.
- [B] Separation roller ( \$\overline{O}\_{\times} 1 \)
- [C] Torque limiter

### **ARDF Transport Belt**

### Removing the ARDF Transport Belt Assembly



- 1. Open the feed cover.
- 2. Remove the ARDF front cover. (\*\*p.461)
- 3. Raise the ARDF [A] to the vertical position.
- 4. Pull off the white cover [B] (Velcro fasteners).




- 5. Release the stopper pin [A] of the transport guide [B].
- 6. Remove the transport belt unit [C] (Pin screw x1).



• At re-installation, attach the timing belt as shown then insert the pin screw [D].

#### Removing the Belt




- 1. Remove the front plastic cover [A] ( Fx1).
- 2. Remove the rear plastic cover [B] (  $\slash\hspace{-0.4em}P$  x 1 ).
- 3. Loosen the front lock screw [C]. **Do not remove**.
- 4. Loosen the rear lock screw [D]. Do not remove. This releases the spring-loaded tension on the belt.

- 5. Grip the roller in the center [E] then squeeze the belt to bring the rollers together.
- 6. While squeezing the belt and rollers together in the center, tighten screws [C] and [D]. This compresses the spring and releases tension on the belt.




- To avoid stripping the threads of the screws, do not apply excessive force to these screws!
- 7. Release the belt.
- 8. Make sure that the belt is loose and that the rollers do not move.
- 9. Repeat Steps 5 and 6 if the rollers expand and tighten the belt.




d132r139

- 10. Remove the Teflon sleeve [A].
- 11. Push the rear shaft bearing [B] out of its bracket.
- 12. Push the front shaft bearing [C] out of its bracket.
- 13. Push the front end of the shaft [D] over the top of the bracket.
- 14. Push the rear end of the shaft [E] over the top of the bracket.
- 15. Pull the shaft [F] out of the belt.
- 16. Pull the belt [G] toward the front to remove it.
- 17. Slide the new belt over the assembly.
- 18. Insert the shaft [F] into the new belt, snap the shaft into its brackets, and push in the shaft bearings.



19. Make sure that studs on the underside of the belt [H] are aligned with the grooves of the Teflon rollers on each end of the shaft below.


#### Reinstalling the Belt



- 1. Remove the ARDF front cover [A].
- 2. Take out the special tool [B].



• The special tool [B] is attached to the front side plate. It is used to adjust the tension on the belt on both ends of the shaft.




- 3. Fit the special tool onto the front [A].
- 4. Slowly loosen the front lock screw [1] until you see the tip of the shaft (① aligned with the hole ②, then tighten the screw.




- To avoid stripping the threads of the screws, do not apply excessive force to these screws!
- 5. Remove the special tool and fit it onto the rear [B].
- If the Teflon sleeve has been reattached at [2], remove it. Do not reattach the sleeve until after adjusting the belt tension. (The special tool does not fit over the rear end with the Teflon sleeve attached.)
- 7. Slowly loosen the rear lock screw [3] until you see the tip of the shaft (3) aligned with the hole 4 then tighten the screw.
- 8. Re-install the Teflon sleeve.
- 9. Re-install the front and rear plastic cover.
- 10. Reinstall the transport belt assembly in the ARDF.

#### Reattaching the White Cover



- 1. With its white side down, set the cover [A] on the exposure glass.
- 2. Make sure the upper left corner is aligned with the arrow at the corner of the exposure glass.
- 3. Close the ARDF [B] on top of the cover.


#### **ARDF Control Board**



d132r124

- 1. Remove the ARDF rear cover (\*\*p.461)
- 2. Remove the ARDF control board [A] ( x17, x4).


### ARDF Bottom Plate Lift Motor



d132r121

- 1. Open the feed cover.
- 2. Remove the ARDF rear cover (\*\*p.461)
- 3. ARDF bottom plate lift motor [A] ( x1, x2, x2, x1)

# ARDF Feed Motor, ARDF Transport Motor



- 1. Open the feed cover.
- 2. Remove the ARDF rear cover (\*\*p.461).




- The right motor must be removed before the left motor.
- 3. Remove:
  - [A] Screw ( F x1)
  - [B] Feed motor assembly ( \*\* x4, \*\* x1, \*\* x1)
  - [C] Feed motor ( Fx2)
  - [D] Transport motor assembly ( \*\bar{x}2, \*\bar{x}1, \*\bar{x}1)
  - [E] Transport motor ( Fx2)



• Re-installation is easier if you first set the spring tension with the screws and then fasten the motor bracket with screws.

### ARDF Pick-up Roller Lift Motor



d132r120

- 1. Open the feed cover.
- 2. Remove the ARDF rear cover (1 p.461).
- 3. Remove the pickup roller lift motor [A] (  $\mathcal{F}$  x2,  $\mathfrak{CI}$  x1,  $\mathcal{O}$  x1).

# **Scanner Unit**

# Exposure Glass




d074r797

1. Remove the left plate (\*x3).



• Screw [1] is a larger screw.



d074r798

2. Remove the rear scale (\*\*x3).



d074r799

3. Carefully slide the right rear corner out of the groove at [1] and then remove the exposure glass.

### Right, Left Plate Covers

Remove these covers to allow easier access to the plates of the scanner unit below.





d074r800

- 1. Remove the exposure glass. (Pp.480)
- 2. Remove the right plate ( > x1). (This is a larger screw.)




- d074r801
- 3. Open the toner bank door [1].
- 4. Disconnect the front plate [2] ( > x3).
- 5. Remove the front plate [3].




d074r802

#### Lens Block, Paper Size Sensors



- 1. Before you remove the lens block, note the settings of the following SP codes that are used for ADF density adjustments for R, G, B.
  - SP4609-2
  - SP4610-2
  - SP4611-2
- 2. Remove the exposure glass. (Pp.480)
  - [A] Lens cover ( Fx9)
  - [B] Lens block ( \*\* x4, \*\* x4)



- 3. Remove the lens block carefully to avoid damaging the attached PCB.
- 4. Do not touch the paint-locked screws on the lens block.
  - [A] Original width sensor ( x1, x1,
  - [B] Original length sensors x2 (No screws, 🗗 x1 each)
- 5. After replacing the lens block, do the following SP codes.

SP4008 001	Sub Scan Mag	Sub Scan Magnification Adjustment
SP4010 001	Sub Scan Reg	Sub Scan Registration Adjustment


<b>SP4011 001</b> Main Scan Re	g Main Scan Registration Adjustment
--------------------------------	-------------------------------------

- 6. After lens block replacement, do some copy samples with the ADF. Check these points:
  - Do the copies have background?
  - Is the copy output of the ADF and platen mode different?

If these problems occur, restore the following SP codes to their previous settings (noted in Step 1), or adjust these SP codes until the background is acceptable.

- SP4609-2
- SP4610-2
- SP4611-2

#### **Exposure Lamp**




- 1. Remove the exposure glass. (\*\*p.480)
- 2. Slide the 1st scanner [A] to the cutout in the frame.
- 3. Remove the exposure lamp [B] ( (x1, x1, x1).


**Important** 

- Never touch the surface of the exposure lamp with bare fingers.
- Work carefully to avoid damaging the relay plugs attached to the rear ends of the lamp.


#### Scanner Motor



- 1. Do the first two procedures in this section to remove the exposure glass and right and left covers.
- 2. Remove:
  - [A] Bracket ( Fx4)
  - [B] Lens cover ( \*\bar{x} x9)
  - [D] Right lens cover ( Fx5)




- 3. Remove the scanner motor assembly [A] ( $\mathcal{O}$  x1,  $\stackrel{\triangle}{\rightleftharpoons}$  x2,  $\stackrel{\square}{\longleftarrow}$  x1,  $\stackrel{\nearrow}{\blacktriangleright}$  x3).
- 4. Remove the scanner motor ( \*\bar{x} x2).



- 1. Remove ARDF, Exposure Glass, and Covers
- 2. Remove:
  - [A] Ground plate ( 🗗 x 1 )
  - [B] Left stay ( **?** x3)
  - [C] Right stay ( Fx4)
  - [D] Rear stay ( 🗗 x6)
  - [E] Scanner HP sensor (□ x1)


# Scanner Interface Board (SIOB)



- 1. Remove:
  - ADF

- Exposure glass
- Covers
- Right stay, rear stay
- Lens cover
- 2. Remove the scanner interface board [A] (x8, x4).

#### **Scanner Wire**




- 1. Remove the wire ground [A] ( Fx1).
- 2. Disconnect the head of wire [B] from tension bracket 1.
- 3. Remove spring [C].
- 4. Loosen the screw [D] of tension bracket 1.
- 5. Disconnect the end of wire at [E].
- 6. Remove lock bracket [F] of the 1st scanner ( Fx1).
- 7. Disconnect the wire from the pulley [G] ( \*x1).
- 8. Remove the wire from the scanner.




d074r803

1. Remove covers and exposure glass. (\*\*p.480)



d074r804

2. Remove the right metal cover plate (\*\* x4).



d074r805

3. Disconnect the motor ( Fx2).



d074r806

4. Remove the motor (x2, x2, x1).

# Lamp Regulator Board and Fan

1. Remove ARDF, covers, and exposure glass. (\*\*p.480)



d074r807

2. At the front, disconnect the scanner unit (  $\slash\hspace{-0.4em}P$  x2).




d074r808


3. At the rear, remove the scanner support arm (\(\hat{\text{\text{\text{\text{\text{e}}}}}\x2).\)



- d074r809
- 4. Disconnect the right rear corner hinge [A] of the scanner unit (  $\mathcal{F}$  x2).
- 5. Open the clamps and free large harness [B] (🖨 x2).



- d074r810
- 6. At the left rear corner, disconnect the scanner heater [A] ( x1, x1, x1).
- 7. Disconnect ground wire [B] ( x1).



- d074r811
- 8. At the front of the machine, slowly push the scanner unit off the left hinge [A], then rotate the right side of the unit [B] slightly counter-clockwise and set it down.
- 9. Make sure that the rubber grommet [C] does not come off its shaft and fall down into the machine.




• If the rubber grommet comes off the shaft as shown above, remove it and re-attach it to the shaft of the scanner unit.




d074r812

10. At the rear, disconnect the right end of the lamp regulator board bracket (🖼 x1, 🗗 x1, 🎉 x2).



d074r813

- 11. Free cable harness [A] (🖨 x4).
- 12. Disconnect the fan at [B] (🖾 x1).




d074r814

13. Disconnect the left end of the lamp regulator board bracket (  $\mathcal{F}$  x2).


d074r815

14. Remove the lamp regulator board bracket with the board and fan attached.



d074r816

15. Set the bracket on a flat clean surface.





d074r817

16. Remove the lamp regulator board fan ( $\mathcal{F}$ x2).






d074r818


17. Remove the lamp regulator board.

Λ

#### Wire Re-installation, Scanner Position Adjustment



- 1. Place the bead [A] on the middle of the wire on the pulley openings.
- 2. Wind the ball end of the wire [B] 4 times.
- 3. Wind the other end of the wire [C] 5 times.
- 4. Attach tape [D] across the pulley to temporarily hold the wires in place.



- d081r138
- 5. Position the 1st scanner [A] so that its holes are aligned, and insert the positioning pins [B] (x4).
- 6. Position the 2nd scanner [C] so that its holes are aligned, and insert the positioning pins [D].
- 7. Attach the lock bracket [E] to fasten the wire to the 1st scanner.
- 8. Tighten the screw of tension bracket.

- 9. Attach the pulley and tighten its lock screw.
- 10. Remove the four positioning pins.
- 11. Remove the tape from the pulley.
- 12. Slowly push the scanner left and right to confirm that the wires are engaged correctly. The 1st and 2nd scanners should move smoothly.

### Laser Unit

#### Laser Units

#### **RTB 73**

Additional procedure before replacing the laser unit

#### **Before You Begin**

### **MARNING**

• Turn off the main power switch and unplug the machine before performing any procedure in this section. Laser beams can seriously damage the eyes and cause permanent blindness.

#### Mportant ...

- An accidental static discharge could damage the laser diode board attached to the lens block unit.
- Touch a metal surface to discharge any static electricity from your hands.
- The polygon motors rotate at extremely high speed and continue to rotate after the machine has been turned off.

### **ACAUTION**

• The scanner unit of the D074/D075 is very heavy and needs to be propped up with a support rod during servicing. Never remove the support rod during servicing.

There are two laser units.

- The unit on the left is for yellow and magenta (YM).
- The unit on the right is for cyan and black (CK).

The removal procedures for each machine are different.

- The D074/D075 has an ARDF that must be removed, and the scanner unit must be propped up with a support rod for servicing.
- The MO44 has no ARDF or scanner unit, so removal of the laser unit is much easier.

### YM Laser Unit Removal: D074/D075

- 1. Confirm that the machine is switched off and disconnected from the power source.
- 2. If the LCIT is installed, disconnect it and pull it away from the right side of the machine.

#### Attention Light

d074c101

### ARDF



d074c100

4. On the right side of the machine, disconnect the ARDF.



d074c102


- 5. Raise the ARDF.
- 6. Remove the base screws ( x2).
- 7. Grip the ARDF from behind, and pull it toward you to disengage the base plates from the shoulder screws on the left and right.



d074c103

8. While holding the ARDF at the base, lift it off.

#### Plates Around the Exposure Glass



d074c104



d074c105

10. Remove the right cover plate ( > x1).




d074c106

11. Remove the front cover plate ( > x3).



• [1] is a larger screw.

#### **ARDF Base Plates**



d074c107


#### 12. Remove:

- [A] ARDF base plate ( Fx4)
- [B] ARDF base plate ( Fx4)
- [C] Shield plate ( 🗗 x4)



• It is not necessary to remove the exposure glass.

#### **Operation Panel**




d074c108


- 13. Remove the right cover [A] ( Fx7).
- 14. Disconnect the operation panel ( x2).
- 15. Disconnect the harness cable inside the machine ( Fx1).



d074c109

- 16. Remove screw cover [A].
- 17. Remove the operation panel arm cover [B] ( Fx2).





d074c110

- 18. Disconnect the operation panel arm [A] ( \*\*x3).
- 19. Push the end of the arm [B] to disengage the base plate from shoulder screws [1] and [2].






d074c111

20. Pull the arm off its base and pull the harness up through the plate.

21. Lift the operation panel off the main machine.

#### **Toner Bank Canopy**




d074c112

22. Remove the four screw covers from the top of the canopy, and then remove the screws (  $\mathcal{F}$  x4).




d074c113

23. On the right side of the machine, remove the canopy side screws (  $\mathcal{F}$  x2).




- 24. Open the toner bank door [A].
- 25. Remove screw [B] ( \*\* x1).



d074c115


- 26. At the left rear corner of the canopy [A], remove the screw (  $\mathcal{F}$  x1).
- 27. Remove the toner bank canopy [B].

#### Raising the Scanner Unit



d074c115a

28. Remove the shield plate ( \*\* x8).




- 29. Make sure both ARDF base plates have been removed ( \*\*\begin{align\*} x4 & ea. \end{align\*}.
- 30. At the front of the machine, disconnect the scanner unit at [B] ( x1).
- 31. Disconnect the scanner unit at [C] and [D] ( \*\*x2).



d074c117


32. At the back of the machine, behind the scanner unit, remove the scanner unit support arm.



d074c118


- 33. Raise the scanner unit [A].
- 34. Set the base of the scanner unit support arm in hole [B].
- 35. Set the top of the arm in hole [C].
- 36. Push the top of the arm [D] down to lock it.

#### Removing the YM Laser Unit



d074c118c

37. Disconnect the ground wires ( \*x2),




d074c119

- 38. At the rear, disconnect the YM laser unit (🖾 x6).
- 39. Remove the YM laser unit screws ( \*\bar{x} x4).
- 40. Grip the chain handles on either side, and lift the YM laser unit out of the machine.

### YM Laser Unit Removal: M044

1. Confirm that the machine is switched off and disconnected from the power source.


#### Rear Cover



m004c001

- 2. Use the tip of a small screwdriver to remove the three screw hole covers [A].
- 3. Disconnect cover [B] and remove it ( \*\bar{x} x 3).

#### Center Cover



m004c002

4. Disconnect the center cover [A] and remove it ( \*\mathbb{P} x4).


#### Front Cover



m004c003

5. Disconnect the front cover [A] and remove it (  $\ensuremath{\rlap/ P} x3$ ).

### Metal Cover Plates




m004c003a


6. Remove metal cover plates:

[A] Plate ( 🗗 x7)

[B] Plate( **?**x6)

[C] Plate ( \*\bar{\mathbb{P}} x4)





m004c004

7. At the rear [A], disconnect the three metal cover plates on the right ( \*Fx3).



- 8. Each plate is fastened with a hook [1].
  - Slide the plate to the left to disconnect the hook [2]
  - Pull the disconnected hook out of the hole [3] and remove the plate.




m004c006

9. Remove the three plates.



• Plate [A] does not need to be removed.

#### YM Laser Unit



m004c007

- 10. At the rear, disconnect the YM laser unit ( x6).
- 11. Remove the YM laser unit screws ( Fx4).
- 12. Grip the chain handles on either side, and lift the YM laser unit out of the machine.

### Removing the CK Laser Unit: D074/D075/M044

- 1. Confirm that the machine is switched off and disconnected from the power source.
- 2. Do the following:


#### D074/D075

If you are removing the right laser unit from the D074/D075, do the procedure for D074/D075 YM Laser Unit removal as far as raising the scanner unit. (Raising the scanner unit is not required.)

#### M044

If you are removing the right laser unit from the M044, do the procedure for M044 YM Laser
Unit Removal as far as removing the three plastic covers. (The three metal covers do not need
to be removed.)

#### Toner Bank Door



d074c120

- 3. To remove the toner bank door:
  - Swing out the "L" pin of hinge [A].
  - Swing out the "L" pin of hinge [B].
  - Remove both "L" pins.
  - Remove the door [C].

#### **Toner Bank Cover Plate**



d074c121

- 4. At the rear [A], disconnect the attention light harness (🖨 x3).
- 5. Disconnect the toner bank plate ( Fx2).
- 6. At the front [B], disconnect the toner bank plate ( Fx2).



d074c122


7. Remove the toner bank plate.

### **Toner Bottles**




8. Push each lever to unlock each toner bottle and remove all the toner bottles.

### **Toner Bottle Cradles**



d074c123

- 9. At the front [A], disconnect the toner bottle cradles ( Fx4).
- 10. At the rear [B], disconnect the toner bottle cradles ( $\mathcal{F}$ x4).



D074c123a

11. Remove the four toner bottle cradles.




• The cradles are identical. They can be re-installed at any position.

#### **CK Laser Unit**

d074c118d


12. Disconnect the two ground wires ( \*x2).



d074c124

- 13. At the rear, disconnect the CK laser unit (🖼 x6).
- 14. Remove the CK laser unit screws ( \*\* x4).


4




d074c125

15. Grip the chain handles on either side, and lift the CK laser unit out of the machine.

### Re-installation (D074, D075, M044)



1. There are two mylars attached to each laser unit. After you re-install a laser unit, confirm that both these mylars are visible and pointing up at the bottom of the laser unit.



d074c127

2. When you re-connect a laser unit, confirm that the rear cables are connected correctly. The gray cable [1] must be connected on the left, and the red cable [2] must be connected on the right.



- The cable connectors have identical shapes. Do not reverse them when you re-connect a laser unit.
- This rule applies to both laser units (gray on the left, red on the right).



d074c127a

The illustration on the right shows how reversing the connection of the rear cables can adversely affect image reproduction.

### SP Adjustments After Laser Unit Replacement

After the laser unit is replaced, two SP codes must be executed: SP2108-1 for the CK LD unit and SP2108-2 for the YM LD unit. These SP codes set the operation parameters for the laser unit (main scan registration, main scan magnification, shading, and bow skew adjustment).

- 1. Enter the SP mode.
- 2. Execute the SP codes in the table below.

No.	Name
SP2108-1	Image Parameter - K/C Writing Unit
SP2108-2	Image Parameter - Y/M Writing Unit

**U**Note


**RTB 86** 

• SP codes are written on an A5-size sheet of paper provided with the laser unit. No A5 sheet with the laser unit.

RTB 73
Additional procedure after replacing the laser unit


### **Toner Shield Glass**

1. Remove the PCDU. (IPp.547)



d074r782

2. Remove cover plate [A] ( Fx1).



d074r783

3. Pull the shield straight out of the machine.





d074r784

#### 4

# **Toner Supply**

### **Toner Bottle Port Cleaning**

1. Open the toner bank door.



d074r081

- 2. Remove all the toner bottles.
  - Push each lock lever [1] to the left. The bottle will pop out.
  - Grasp the bottle by its knob handle [2] and remove the bottle.



d074r082

- 3. At the bottom edge of each toner bottle cradle, push back the spring-loaded nozzle cover to expose the plunger.
- 4. Use a vacuum cleaner to pull away loose toner.

• To avoid toner scattering, never use a blower brush to clean these areas.

#### What You Need...



d074r060

- You will need a large damp cloth and a clamp when you disconnect the toner hose from the toner sub hopper.
- Spread some clean paper on a flat surface where you can set the PCDU after it has been removed.
- Spread some paper on a flat surface to catch scattered toner.

#### Covers

1. Confirm that the machine is switched off and disconnected from the power source.

### D074/D075






d074r061

1. Remove the "L" cover [A] (🔊 x3).

M044

4



m004c001

- 1. Use the tip of a small screwdriver to remove the three screw hole covers [A].
- 2. Disconnect cover [B] and remove it ( \*\bar{x} x3).



m004c002

3. Disconnect center cover [A] and remove it ( \*\bar{x}4).



m004c003


### D074/D075/M044 Continued

1. Disconnect front cover [A] and remove it ( \*\*\var{x}3).



d074r062


2. Remove the toner port tray [A] ( Fx2).



m044r063

- 3. Disconnect the toner supply unit cover:
  - [A] Left end ( 🗗 x4)
  - [B] Center ( 🗗 x2)
  - [C] Right end ( 🗗 x2)


1




m044r064

4. Lift the cover up [A] and then pull it toward you [B] to remove it.

#### **PCDU**





d074r068




- There is a toner supply unit above each PCDU. To work on a toner supply unit, the PCDU below must be removed.
- 1. Depress the PCDU lock lever [A] and pull the PCDU out slowly until it stops.
- 2. Remove lock screw [B] ( Fx1).
- 3. Lift the PCDU [C] off the rails, and then lay the PCDU on the prepared surface.



- Place the PCDU upright on a flat clean surface.
- There is only a small gap between the surface of the drum and the table surface so the surface must be smooth, flat, and clean.
- To avoid damage to the surface of the drum, never place the PCDU on a carpet or rough cloth.


4. Push the PCDU rails into the machine.






d074r065


- 1. At the upper left corner of the toner supply unit, disconnect the unit from the toner supply motor drive shaft:
  - [A] Snap ring (\$\overline{10}\$x1)
  - [B] Bushing (■x1)



d074r066


- 2. Attach a clip at [A] to clamp the toner supply tube.
- 3. Wrap the hose connection with a damp cloth [B] and very slowly pull the tube off the nozzle.
- 4. While holding the cloth over the mouth of the tube [C], remove the clip [D].






d074r067

- 5. Slowly and very carefully tap the open mouth of the tube [A] until toner stops flowing.
- 6. Re-attach the clip [B] to close the mouth of the hose.






d074r069

- 7. Disconnect the supply unit:
  - [A] Connectors and harnesses (🖨 x4, 📫 x3).
  - [B] Top of the bracket ( Fx2)





d074r070

8. Disconnect the bottom of the bracket [A] (  $\mathcal{F}$ x1).

9. Lift the unit [B] off its hooks and remove it.




d074r071


- 10. Set the toner supply unit on some paper or waste cloth.
- 11. Tap the nozzle of the sub hopper nozzle until no more toner comes out.



 Before servicing the unit, taping or plugging the nozzle is recommended to prevent toner scattering from the open nozzle.

#### Re-installation






d074r080

- Be sure to re-set the harness connectors [A] on their pegs.
- · Confirm that the connection of the toner supply tube [B] and sub hopper nozzle is straight and tight.

# **Toner Supply Clutch**


1. Remove the toner supply unit. (Pp.518)





d074r072

2. Remove drive gear [A] ( $\mathfrak{C}_{x1}$ ).






d074r073

- 3. Disconnect shaft [A] (♡x1, ■x1).
- 4. Remove the toner supply clutch [B].

### Re-installation




d074r074

- Make sure that the lock arm [A] of the clutch engages the pawl.
- On the other side of the unit, you can look through the cut-out [B] to confirm that the lock arm and pawl are engaged.

## **Toner Pump Clutch**

- 1. Remove the toner supply unit. (Pp.518)
- 2. Remove the toner supply clutch. (\*\*p.524)



d074r075


- 3. Disconnect the shaft [A] (©x1).
- 4. Release both ends of the shaft [B] ( x2).



d074r076

5. Remove the toner pump clutch.

#### Re-installation




d074r077

- Make sure that the lock arm [A] of the clutch engages the pawl.
- On the other side of the unit, you can look through the cut-out [B] to confirm that the lock arm and pawl are engaged.

### **Toner End Sensor**

1. Remove the toner supply unit. (Pp.518)



d074r079

- 2. Disconnect the toner end sensor [A] ( \*\bar{x} 1).
- 3. Twist the sensor [B] slightly to the right (counter-clockwise) and remove it.




- Do not touch the rear surface of the toner end sensor.
- To avoid damaging the sensitivity of the sensor, handle it carefully during removal.

### RFID Boards, RFID CPU

#### **RFID Boards**

1. Remove the canopy cover and toner bank cover plate. (\*\*p.415)



d074r083

2. Remove the RFID board ( $\mathbf{T}$  x2,  $\mathbf{L}^{\mathbf{J}}$  x1).

#### **RFID CPU**


1. Remove: ( p.415)

- Canopy cover
- Toner bank cover plate
- Toner bottles and toner bottle cradles




d074r084

The RFID CPU is behind the plate on the right side of the toner bank faceplate.



d074r085

- 2. From the rear [A], disconnect the toner bottle frame (🖾 x1, 🎉 x5).
- 3. Remove the frame [B].



d074r086

4. Disconnect leaf springs [A] and [B].




d074r087

5. Remove the RFID CPU and disconnect it ( x2).


### **Toner Bottle Motors**

- 1. Remove: (**p**.415)
  - Canopy cover
  - Toner bank cover plate




d074r088

2. Remove the toner bottle cradle [A] for the motor to be removed.




- 3. Disconnect the toner bottle motor plate:
  - [A] Right side ( 🗗 x2)
  - [B] Left side ( **?** x1)
- 4. Remove the plate.






d074r090

- 5. Disconnect the motor mount:
  - [A] Harness [🖨 x2, 📬 x1]
  - [B] Base ( 🗗 x3)






d074r091

- 6. Rotate the motor mount [A] toward you and remove it.
- 7. Set the motor mount upright on a flat surface.
- 8. Release harness [B] (🖨 x2).







d074r092

#### 9. Disconnect:


- [A] Rear end of shaft (€x1, ■x1)
- [B] Front end of shaft (€x1, ■x1)





d074r093

- 10. Remove the drive shaft [A].
- 11. Disconnect the motor [B] ( > x2).



d074r094

12. Remove the toner bottle motor.

# **Toner Supply Motor**

### Before You Begin...





d074r095

The toner supply motor is on the left front corner of the machine. To access this motor, you must remove:

- Left top cover.
- Left cover.


### **Toner Supply Motor**





d074r096

- 1. Inside the left front corner, disconnect spring [A] (  $\nearrow$  x1).
- 2. Disconnect the motor drive shaft [B] ( $\mathcal{O}_{x1}$ ).



d074r097

- 3. Outside the front left corner, disconnect the harnesses [A] (🕮 x2).
- 4. Disconnect the motor [B] ( \*\bar{x}4).





d074r098

5. Remove the motor.

# **Used Toner Collection**

### **Used Toner Bottle**



d074r489

The used toner bottle is located at the lower left corner of the main machine behind the left door.
 Just pull it out by its handle.



d074r499

 $2. \ \ \, \text{The cap of the used toner bottle has a reverse thread. Turn it clockwise to remove it.}$ 

4




d074r986

- 3. After emptying the used toner bottle, check the auger inside the bottle and make sure that there are no clumps of used toner sticking to the auger.
- 4. If you see any clumping on the auger, gently tab the sides of the bottle to shake them loose, then empty the bottle again.


## Used Toner Transport Motor, Sensor, Timing Belt

### Transport Motor



d074r470

1. Remove the IOB. (\*\*p.830)



d074r471


- 2. Remove the spring [1] (\*\*x1).
- 3. Disconnect the motor assembly [2] ( \*\bar{x}4).
- 4. At the top [3], slide the timing belt off the gear.
- 5. Remove the motor with the timing belt.



d074r472

6. Remove the motor from the assembly (  $\mathcal{F}$  x4).

### **Used Toner Transport Motor Sensor**







d074r473

- 1. Remove the sensor assembly [1] ( Fx1).
- 2. Remove the sensor [2] ( $\mathbf{T} \times 3$ ).


# **Timing Belt**






d074r474

1. Remove the assembly [1] ( Fx2).






d074r475

- 2. Remove the actuator gear [1].
- 3. Remove the timing belt [2].




d074r476

- 1. Remove the used toner bottle at the front of the machine.
- 2. Remove the AC drive board [1]. (\*p.814)



- 3. Open the two large clamps [1] and take out the harness, so that you can see the screw (🕮 x2).
- 4. Remove the screw [2] ( 🗗 x1). You will need a short screwdriver to remove this screw.



d074r478

- 5. Disconnect the motor [1] (🖨 x2, 📬 x2).
- 6. Disconnect the plate [2] ( \*\bar{x} x2).
- 7. Remove the plate [3].





d074r479

8. Remove the motor ( \*\bar{x} x4).



d074r480


# Used Toner Bottle Sensors, Bottle Set Switch

1. Remove the used toner bottle at the front of the machine.




d074r490

- 2. At the rear, open the controller box and the cooling box. (\*\*p.400)
- 3. Remove the AC drive board [1]. (\*p.814)




d074r491

- 4. Disconnect the toner bottle motor [1] (🗗 x1, 🖨 x1). You do not need to remove the motor.
- 5. Disconnect connector [2] (🗗 x1).
- 6. Open clamp [3] and pull away the harnesses (🖨 x1).




d074r492

- 7. At the front of the machine, pull out the left drawer.
- 8. Disconnect the left drawer set sensor [1] (🖨 x1, 🚅 x1)




d074r493

- 9. Inside the used toner bottle well, unclamp the left drawer set sensor harness [1] (🗟 x3).
- 10. At the rear, slowly pull the disconnected harness [2] out of the machine.



d074r494

11. Remove the rear plate [1] with the motor attached (  $\slash\hspace{-0.4em}P$  x3).




d074r495

### 12. Set the plate on a flat surface.

1	Used Toner Bottle Set Switch	
2	Toner Bottle Near Full Sensor	
3	Toner Bottle Full Sensor	
4	Toner Bottle Motor Sensor	


### **Used Toner Bottle Set Switch**



d074r496

- 1. Use a pair of needle-nose pliers to pinch and release the base of the switch [1].
- 2. Push the switch [2] out and disconnect it (🖾 x1).


### Near Full, Full Sensors



d074r497

- 1. Pinch the two prongs at the base of the bottle full sensor [1] (or the bottle near-full sensor [2]) to release and remove it.
- 2. Disconnect the sensor ( x1).

### Toner Bottle Motor Sensor



d074r498

- 1. Disconnect the sensor harness [1] ( $\Re x1$ ).
- 2. Disconnect the sensor [2] (☐ x1, ▼x3).

#### 4

# **Photoconductor Development Unit (PCDU)**

RTB 80

Notes on handling the PCDU

### **PCDU Replacement**

1. Remove the PCDU and replace it with a new one. (\*\*p.426)




d074r926

2. Raise the drum bracket [1], and dust the exposed surface of the drum with the resin pad.



• Do not apply powder near the development unit entrance seal [3].



d074r927



- [1] shows too much powder on the drum.
- If an excessive amount of powder enters the development unit entrance seal [2], this can cause poor image reproduction. Remove excess powder with a clean dry cloth [3].



d074r928

- 3. Rotate the drum slowly until the applied powder is no longer visible.
- 4. The machine should be OFF.
- 5. Open both front doors.
- 6. Turn the main power switch ON.
- 7. Enter the SP mode.
- 8. Reset the counter for the replaced unit or unit part.
- 9. Install the developer.
- 10. Execute the SP code to fill the PCDU with the new developer.

Replaced Developer	Do This SP
Black	SP3024-001(K)
Cyan	SP3024-002 (C)
Magenta	SP3024-003 (M)
Yellow	SP3024-004 (Y)

- 11. Do SP3025-001 to confirm that each PCDU was filled successfully.
- 12. Close the front doors.
- 13. Wait for about 5 minutes. When you hear an audible beep and see "Ready" displayed on the operation panel, you are ready to continue.
- 14. Do one or more of the SP codes listed below, whichever is appropriate, to initialize TD sensors.



- Choose the correct SP code.
- Initialize the TD sensor only for the development units that were replaced.
- Never initialize the TD sensor of a development unit that has not been replaced.


Condition	SP Code	TD Sensor Initialization
All development units replaced.	3030-01 (All)	All TD sensors (YMCK)
CMY development units replaced.	3030-02 (CMY)	Color TD sensors only (CMY)
K development unit replaced.	3030-03 (K)	Black TD sensor only.
C development unit replaced.	3030-04 (C)	Cyan TD sensor only.
M development unit replaced.	3030-05 (M)	M TD sensor only.
Y development unit replaced.	3030-06 (Y)	Y TD sensor only.

- 15. Do SP3031-001 to confirm successful TD sensor initialization.
- 16. You will see a 4-digit code. Each digit represents one unit "YMCK". A a"1111" display indicates that each TD sensor was initialized successfully.
- 17. Execute these SP codes.

SP	What It Does
3020-001	Initializes process control.
3012-001	Confirms successful initialization of process control.

18. Exit the SP mode.

#### Re-Installation




d074r987

- 1. Always check the left side of the PCDU before you push it back into the machine. (This is the shield plate that conducts heat away from the development unit.)
- 2. If you see any toner on the plate, wipe it off with a clean dry cloth.


# **ACAUTION**

- To prevent toner scatter or gear damage, never apply excessive force on the PCDU when you
  push it into the machine.
- 3. After you push the PCDU into the machine, make sure that PCDU is locked correctly.



d074r915

• When the PCDU is locked correctly, the top of the lock lever is straight as shown above.



- If the PCDU is not locked correctly, the top of the lock lever is slanted slightly down to the left as shown above.
- 4. If the PCDU lock lever is not locked correctly, pull the PCDU out about 30 mm (1.5 in.) and push it in again so the top of the lock lever is level.

### Vent Filter

1. Pull out the PCDU. (\*\*p.426)




d074r781

2. Lift the filter off the top of the PCDU.

# **Drum Charge Unit**

- 1. Turn off the machine and disconnect its power plug.
- 2. Pull out the PCDU (IPp.426)



d074r048

- 3. Press the drum charge unit lock lever to the rear [1] to unlock it and then raise it [2].
- 4. Lift the front end of the charge unit [3] and remove it.
- 5. Lay the charge unit on a clean surface with the roller side up.

#### After Replacing a Drum Charge Unit

- 1. The machine power must be OFF.
- 2. Open both front doors.
- 3. Turn the main power switch ON.
- 4. Enter the SP mode.
- 5. Reset the counter for the replaced drum charge unit.


- 6. Close the front doors.
- 7. Wait for about 5 minutes. When you hear an audible beep and see "Ready" displayed on the operation panel, you are ready to continue.
- 8. Execute these SP codes.

SP	What It Does
3020-001	Initializes process control.
3012-001	Confirms successful initialization of process control.

9. Exit the SP mode.

# **Drum Cleaning Unit**


- 1. Turn off the machine and disconnect its power plug.
- 2. Pull out the PCDU (IPp.426)
- 3. Remove the drum charge unit (\*\*p.551)



d074r049

- 4. Raise the drum wing [1] to the vertical position.
- 5. Lower the cleaning unit lock lever [2].

4



RTB 71

Lubricate the drum cleaning blade after installing a new drum cleaning unit.


6. Roll the cleaning unit toward you [1] and lift it straight up [2].

Notes on re-installing the drum cleaning unit

# Drum Replacement

#### **Drum Removal**

- 1. Turn off the machine and disconnect its power plug.
- 2. Pull out the PCDU (\*p.426)
- 3. Remove the drum charge unit (1 p.551)
- 4. Remove the drum cleaning unit (1 p.552)



d074r050a

5. Grip both ends of the drum wing and lift the drum out.

### 4




d074r920

6. Lay the drum on a flat clean surface and cover it with a piece of clean paper.

1. Stand the new drum on its end with the drive gear [1] up.



• Always hold the drum steady by gripping it at the drum gear [1]. Never touch the surface of the drum.




d074r921

 $2. \ \ While \ holding \ the \ frame \ [1] \ steady, \ depress \ the \ drum \ [2] \ slightly \ and \ separate \ it \ from \ the \ frame.$ 




d074r922

3. Remove the protective sheet from the new drum.




d074r923

- 4. While holding the drum upright by the drive gear [1], use the resin pad [2] to dust the drum lightly.
- 5. Turn the drum as you dust it to make sure that the entire surface is covered.



- 6. Do not apply too much powder to the drum.
  - [1] shows too much powder on the drum.
  - [2] shows the correct amount of powder on the dusted drum.
  - Excess powder can be removed with a clean dry cloth.



7. While pressing down slightly on the drive-gear end of the drum [1], set the end of the frame [2] over the end of the drum.



d074r925

8. Inspect the surface of the drum and make sure that there are no scratches, dirt, etc. on the surface of the drum.

9. Re-install the drum in the PCDU.

### After Replacing a Drum


- 1. The machine should be OFF.
- 2. Open both front doors.
- 3. Turn the main power switch ON.
- 4. Reset the counter for the replaced drum.
- 5. Close the front doors.
- 6. Wait for about 5 minutes. When you hear an audible beep and see "Ready" displayed on the operation panel, you are ready to continue.
- 7. Execute these SP codes.

SP	What It Does
3020-001	Initializes process control.
3012-001	Confirms successful initialization of process control.

8. Exit the SP mode.

# **Development Unit Replacement**

- 1. Turn off the machine and disconnect its power plug.
- 2. Pull out the PCDU (IPp.426)
- 3. Remove the drum charge unit ( p.551)
- 4. Remove the drum cleaning unit (\*\*p.552)
- 5. Remove the drum (Pp.553)



4


- 6. Unfasten the development unit [1] ( $\triangle x$ 1).
- 7. Lift the development unit off the rails [2].

# Replacing Developer

RTB 102
Revised developer removal procedure

### **Emptying the Development Unit**

- 1. Remove the PCDU (\*p.426)
- 2. Remove the development unit (Pp.558)





d074r100


- 3. Unfasten the front plate [A] ( Fx3).
- 4. Remove the developer supply port cover [B].






d074r101


- 5. Depress the PCDU lock [A].
- 6. Remove the front cover [B] ( Fx3).





d074r102


- 7. Disconnect the entrance seal [A] ( \*\*\begin{align\*} x 3 \).
- 8. Remove the entrance seal [B].




d074r103

- 9. Remove the developer supply port cap [A].
- 10. Spread some paper or plastic to catch the old developer.
- 11. Hold the development unit [B] on end over the paper with the open port down, and pour the old developer onto the paper.
- 12. Keep dumping the developer, until you see what resembles curls of smoke.









d074r104

- 13. Lay the development unit flat.
- 14. Rotate the development roller [A] (counter-clockwise) to loosen the developer inside the sleeve.
- 15. Once again, hold the development unit [B] on end over the paper with the open port down, and dump the developer until you see what resembles curls of smoke.



d074r105

- 16. Rotate the development roller [A] (clockwise).
- RTB 98
  A tool has been issued to help rotate the development roller.
- 17. As you continue to rotate the roller, use a vacuum cleaner to clean all the developer from the top of the sleeve. The illustration above shows the area to be cleaned. When this area is free of loose developer, you are finished.
- 18. Re-assemble the PCDU and install it in the machine.



d074r052

- 19. Before you push the PCDU into the machine, you must confirm:
  - Charge unit lock lever [1] is down and locked
  - Cleaning unit lever [2] is up and locked.

### **Installing New Developer**

- 1. Open both front doors.
- Throughout the following procedures, pay close attention to the opening and closing of the front doors.
- 3. Connect the power cord of the main machine to the power source.
- 4. Turn on the main power switch.



- The main power switch is behind the open left front door.
- 5. Watch the operation panel. The operation panel LED will light red, and you will see the "Please Wait" and then "Door Open" on the operation panel.
- 6. Reset the PM counter for the developer(s) that you replaced.




d074i888

4

- 7. Remove the developer funnel cover [1] from the right lower corner of the machine ( $\mathcal{F}$ x1).
- 8. Disconnect the funnel [2] from the back of the cover (\(\nabla x2\)).

# **ACAUTION**

- The front doors must remain open.
- Turning on the machine with the front doors open prevents the machine from performing the initial process control self-check.
- If the front doors are closed, the drums will start rotating with no toner in the PCDUs.
- If the drums rotate with no toner in the PCDUs, this can cause the cleaning blades to catch on a dry drum and damage the drum surface



d074i889

9. Remove the developer port cap cover [1] on the front of the PCDU so that you can see the port cap [2].



d074i890

- 10. Remove the port cap [1].
- 11. Insert the narrow end of the funnel [2] into the open port of the PCDU.



d074i891

- 12. Make sure that the inserted funnel is parallel with the top edge of the machine.
- 13. Select the developer pack. Make sure the pack is the correct color for the PCDU.
- 14. Shake the developer pack vigorously. This ensures that all the developer will flow through the funnel into the PCDU.



d074i892

- 15. Open SP3024. See the table below.
- 16. Cut off the top of the developer pack along the dotted line.
- 17. Set the open end of the package down in the funnel so that the developer starts pouring into the PCDU.
- 18. While still holding the package, select the correct number (001 to 004) for the package color and press [EXECUTE].



 Make sure that you execute the correct SP code for the color of the developer that you are replacing!

SP	Initializes	Color	Comment
3024-001	K	Black	The PCDU starts operating and it takes about
3024-002	С	Cyan	30 seconds to complete.
3024-003	М	Magenta	
3024-004	Y	Yellow	

- 19. Shake the developer pack gently to make sure that all the developer drains into the machine.
- 20. When the SP execution is finished, tap the edge of the pack to avoid spillage when the pack is removed.
- 21. Remove the emptied developer pack.



- Check the pack to see if any developer remains. If a substantial amount of developer did not go into the PCDU, repeat the SP3024 execution.
- The 30 sec. time interval for execution of SP3024 can be adjusted. If more time is needed to
  empty the power pack, increase the PCDU run time with SP3024-11.
- 22. Remove the funnel.
- 23. Re-attach the developer port cap.
- 24. Clean the funnel thoroughly before installing another developer pack or storing it in the machine.
- 25. Do SP3025-1 (Dev Fill OK? to confirm that developer installation succeeded.

You will see a 4-digit number: 1111. Reading from left-to-right each number is a result code for the Y, M, C, K developer execution with SP3024. Check the results against the table below.

Code	Meaning	Comment
0	No execution	Default
1	Succeeded	No problems
2	No developer exited	Before execution, TD sensor output was above 1.5V (developer present).
3	No developer entered	After execution, TD sensor output was below 1.5V (no developer present).
4	Used toner bottle full	The used toner bottle was detected full.
5	Development motor lock	The development motor was not operating.

Code	Meaning	Comment
6	Used toner transport lock	One or both motors locked: Used Toner Transport Motor or Used Toner Bottle Motor.
9	Forced abort	Front doors were closed, machine was powered off, or some other event interrupted execution.

#### Close Both Front Doors

- 1. Close both front doors.
- 2. Switch to the copy display (or print display for the MO44). Watch the operation panel display.

You will see "Please Wait"

After you see "Ready", wait at least 5 minutes for the machine to complete its warm-up cycle.

3. Do not leave the SP mode.

#### Initialize TD Sensors

- 1. Leave the front doors closed.
- 2. Execute SP3030-001 (Init. TD Sensor) to initialize the TD sensor of each development unit.



• Be sure to select the correct number for the PCDU where the developer was replaced.

SP3030	Init TD Sensor :Exe
001	Execute: ALL
002	Execute: COL
003	Execute: K
004	Execute: C
005	Execute: M
006	Execute: Y

# **☆ Important**

- Failure to initialize the TD sensor will cause incorrect readings of the toner density.
- 3. Watch the operation panel. First, you will see "Complete" and then a four-digit number will appear.
- 4. Do SP3031-001 to confirm successful TD sensor initialization.
  - A "1111" display indicates successful initialization of each development unit (YMCK).

• If a TD sensor fails to initialize, the machine will display an SC code. Follow the instructions under the indicated SC code to correct the problem.


#### Initialize Process Control

- 1. Leave the front doors closed.
- 2. Execute SP3020-001 to start process control. (Process control sets the machine for optimum operation based on the conditions around the drums.)
- 3. Watch the operation panel. When you see "Complete", the process control settings are done.
- 4. Do SP3012-001 to confirm that initialization was successful.

#### Exit SP Mode and Power Off

- 1. Exit the SP mode.
- 2. Push the operation power switch on the operation panel to switch the machine off.
- 3. Switch the main power switch off.


## **PCDU Parts Replacement**



RTB 80 Notes on handling the PCDU

d074r108a

	Îtem	PM Interval	
		D074	D075/M044
1	Charge Unit	300 K	
	Developer, Vent Filter	750K	900K
2	Development Unit	5250K	6000K
3	OPC Drum	1200K	1350K
4	Drum Cleaning Unit	300 K	



1	Charge Roller
2	Charge Roller Cleaning Roller
3	Drum Lubrication Blade
4	Drum Lubrication Bar
5	Drum Lubrication Roller
6	Lubricant Collection Coil
7	Quenching Lamp (QL)
8	Toner Collection Coil
9	Drum Cleaning Blade
10	OPC Drum


### PM Parts List

PM Part Name	Interval	Replaced By
Gears (21Z Front)	300K	Service Technician, or TCRU
Gears (Idle: 20Z: Front)	300K	Service Technician, or TCRU
Gears (Idle: 31Z: Front)	300K	Service Technician, or TCRU
Gears (19Z: Front)	300K	Service Technician, or TCRU

PM Part Name	Interval	Replaced By
Cleaning Unit Coupling	300K	Service Technician, or TCRU
Drum Lubrication Roller	300K	Service Technician, or TCRU
Drum Lubrication Bar	300K	Service Technician, or TCRU
Drum Lubrication Blade	300K	Service Technician, or TCRU
Drum Cleaning Blade	300K	Service Technician, or TCRU

# **Drum Cleaning Unit Gears**

1. Remove the drum cleaning unit from the PCDU. (\*\*p.552)





d074r109

2. Remove the front plate [A] ( Fx2).



d074r110

3. Remove gears 1 to 4.




d074r111

- 4. Remove the last gear (©x1).
- 5. Replace the gears at the front.

1	Gears (Idle 20Z)
2	Gear (21Z)
3	Gears (Idle 31Z)
4	Gear (21Z)

# **Drum Cleaning Blade**


- 1. Remove:
  - PCDU (\*\*p.426)
  - Drum cleaning unit from the PCDU (\*\*p.552)
  - Drum cleaning unit gears (Pp.569)



2. Rear plate [A] ( Fx1, hook)




• Place the drum cleaning unit on a sheet of paper, and then remove the rear plate. Used toner may spill out from the cleaning unit after removing the rear plate [A].




d074r112a

- 3. Vibration plate [A]
- 4. Separate the lubrication unit [B] and cleaning unit [C] ( Fx1).



d074r113

- 5. Disconnect the cleaning blade:
  - [A] Front ( **?** x1)
  - [B] Rear ( 🗗 x 1)




d074r114

6. Remove the cleaning blade.

When installing a new drum cleaning blade, side seals must be replaced with new parts. Follow the replacement procedure for the side seals as shown below.



1. Remove the side seals [A] on the cleaning unit.




- 2. Clean the area [A] where the side seals were attached with alcohol and a cloth.
- 3. Attach new side seals to both sides of the cleaning unit.
  - Align the edges [B] of the side seal with the edges [C] of the cleaning unit and cleaning blade, and then attach it.
  - Check that the drum cleaning blade does not hook the side seal when pressing the drum cleaning blade [D].

#### When reattaching the cleaning unit and lubrication unit

- 1. Attach the cleaning unit and lubrication unit.
- 2. Install the drum cleaning unit gears and front plate first.

4





- d074r055
- 3. Install the vibration plate [A] in the rear of the cleaning unit.
- 4. Attach the rear plate [B] to the cleaning unit ( Fx1, hook).
- 5. Secure the cleaning unit [C] and lubrication unit [D] ( Fx1).

RTB 71 3. Secure the cleaning unit [C] and lubrication unit [D] ( # x Lubricate the drum cleaning blade after installing a new drum cleaning blade.


### **Drum Lubrication Blade**

- 1. Remove:
- PCDU (**▶**p.426)
- Drum cleaning unit from the PCDU (\*\*p.552)
- Drum cleaning unit gears (Pp.569)
- Separate the lubrication unit and cleaning unit. (\*\*p.570)



d074r115

- 1. Disconnect the lubrication blade:
  - [A] Front ( Fx1)
  - [B] Rear ( Fx1)



d074r116

2. Remove the lubrication blade.


### When installing a new lubrication blade


When installing a new lubrication blade, side seals must be replaced with new parts. Follow the replacement procedure for the side seals as shown below.



1. Remove the side seals [A] on the lubrication unit.









d074r054

- 1. Clean the area [A] where the side seals were attached with alcohol and a cloth.
- 2. Attach new side seals to both sides of the lubrication unit.
  - Align the edges [B] of the side seal with the edges [C] of the lubrication unit and lubrication blade, and then attach it.
  - Check that the lubrication blade does not hook the side seal when pressing the lubrication blade [D].

### **Drum Lubrication Bar**

#### 1. Remove:


- PCDU (**▶**p.426)
- Drum cleaning unit from the PCDU (\*p.552)
- Drum cleaning unit gears (1 p.569)
- Separate the lubrication unit and cleaning unit. (\*\*p.570)

# **Important**

 The lubrication bar must be removed before the lubrication roller, and re-installed after the lubrication roller.


d074r117

2. Disconnect the lubrication bar cover plate stay [A] ( \*\*x2).



d074r118

- 3. Raise the left and right ends of the lubrication bar base [1]. The spring arms will pop on both ends.
- 4. Lift the bar [2] and place it flat on the table.



5. Disconnect the springs and arms:

[A] Center ( x2)

[B] Front ( \*x1, Arm x1)

[C] Rear ( \*x1, Arm x1)


Λ



• Do not discard these springs and arms. They are not provided as service parts and must be reattached to the new lubrication bar.


### **Drum Lubrication Roller**

1. Remove the drum lubrication blade (\*\*p.573)



d074r120

- 2. Disconnect the rear end [A] of the roller (Coupling x1 19Z, ■x1).
- 3. To disconnect the front end of the roller, push the lock plate [B] off to release the end of the roller.



d074r121

4. Remove the lubrication roller.

#### Re-installation



x\_pcdu\_17\_22

- Before pushing a PCDU into the machine, always make sure that the PCDU lock lever is down and locked.
- Always push the PCDU in slowly and firmly until you hear it lock.

### After Replacing a Drum Cleaning Blade or Drum

- 1. The machine should be OFF.
- 2. Open both front doors.
- 3. Turn the main power switch ON.
- 4. Reset the counter for the replaced unit or parts.
- 5. Close the front doors.
- 6. Wait for about 5 minutes. When you hear an audible beep and see "Ready" displayed on the operation panel, you are ready to continue.
- 7. Do one or more of the SP codes listed below, whichever is appropriate, to clean and lubricate the drum of the unit where the unit or parts were replaced.

Condition	SP Code	Cleaning Done For:
All cleaning units replaced.	3032-01 (All)	All units (YMCK)
CMY cleaning units replaced.	3032-02 (CMY)	Color units only (CMY)
K cleaning unit replaced.	3032-03 (K)	Black unit only.
C cleaning unit replaced.	3032-04 (C)	Cyan unit only.
M cleaning unit replaced.	3032-05 (M)	M unit only.
Y cleaning unit replaced.	3032-06 (Y)	Y unit only.

### 8. Execute these SP codes.

SP	What It Does	
3020-001	Initializes process control.	
3012-001	Confirms successful initialization of process control.	

9. Exit the SP mode.

# Drum Cleaning Motors, Development Motors, Drum Motors


## **Before Removing Any Motor**

1. Open the controller box and cooling box on the back of the machine. (\*\*p.400)




d074r123

2. Remove the center stay ( \*\* x3).




3. Disconnect the horizontal cooling duct:

[B] Right (🗗 x1, 🗗 x3)




d074r125

4. Remove the horizontal cooling duct.



d074r126

Viewed from the rear, the sets of motors from left to right are  $\mathsf{KCMY}$ 




d074r127

There are three motors in each set:

- [A] Cleaning motor
- [B] Development motor
- [C] Drum motor

# **Drum Cleaning Motor**






d074r128

- 1. Prepare for motor removal (\*\*\*p.579)
- 2. Remove the motor (☐ x1, x3).

# **Development Motor**






d074r129

- 1. Prepare for motor removal (\*\*p.579)
- 2. Remove the motor ( x1, \*x3).

### **Drum Motor**



d074r130

- 1. Prepare for motor removal (\*\*p.579)
- 2. Disconnect the motor [A] (🗂 x1, 🎉 x3).
- $3. \ \, \text{As you slowly remove the motor [B], support the long drive shaft with your other hand}.$



d074r131


4. Disconnect the motor drive shaft [A] from the motor [B] and separate them ( $\mathcal{F}$ x1).



- Never disassemble the motor [B]. There are no serviceable parts inside the motor.
- If the motor is taken apart, it is very difficult to re-assemble correctly because the parts are spring loaded.

# **Liquid Cooling Unit**

1. Remove the cooling box cover ( \*\* x13 M4x8). (\*\*\* p.402)




d074r132

- 2. Disconnect the hose at [A].
  - Press the blue release buttons on both sides of the coupling to disconnect.

• Use a dry rag to soak up any coolant leakage around the open ends of the couplings [A] and [B].

### Mportant !

• There will be a small amount of leakage. If there is a large amount of leakage, re-connect the hoses and then disconnect them again.





d074r133

- 3. Pull the long tube [A] down and out of the duct.
- 4. Disconnect the hose at [B] (🖨 x 1).
  - Press the blue release buttons on both sides of the coupling to disconnect.
  - Use a dry rag to soak up any coolant leakage around the open ends of the couplings.

## Mportant !

• There will be a small amount of leakage. If there is a large amount of leakage, re-connect the hoses and then disconnect them again.



d074r134


- 5. On the left [A], disconnect the base ( Px1).
- 6. On the right [B], disconnect the base and harness ( ♠x1,♠x2,♥ x1)



d074r135

7. Lift the tank straight up and remove it.

#### Re-installation



d074r135a


1. Set the keyholes [A] over the shoulder screws [B] to position the base of the tank correctly.

### Tank and Coolant Disposal

- The liquid coolant is propylene glycol.
- Always obey local laws and regulations if you need to dispose of a tank or coolant.
- The tank must never be emptied directly into a local drainage system, river, pond, or lake.
- Contact a professional industrial waste disposal organization and ask them to dispose of the tank.

# **Drum Cooling Unit Fan Replacement**

1. Remove the cooling box cover ( \*x13 M4x8). (\*\*p.402)



d074r136


- 2. There are three fans [A].
- 3. Disconnect the fan [B] ( \*x2 M3x30).
- 4. Disconnect the fan harness [C] (🖨 x 1, 📬 x 1)

# Charge Roller Cleaning Roller Solenoids

The four charge roller solenoids (one for each PCDU charge roller) are located on top of the machine below the laser units.


- 1. Remove the laser unit for the solenoid that needs to be replaced. (\*\*p.495)
  - The Y, M solenoids are behind laser unit 1 on the left.
  - The C, K, solenoids are behind laser unit 2 on the right
  - You will need a short screwdriver (or ratchet driver) to remove the screws of the solenoids below the raised scanner unit (Y, M solenoids)

### Y Charge Roller Cleaning Roller Solenoid




d074r137


- 2. Free the harnesses [A] (🗗 x1, 🖨 x1).
- 3. Disconnect the solenoid assembly [B] ( \*\*\bigsiz x2).



d074r138


- 4. Remove the solenoid [A].
- 5. Disconnect the solenoid [B] from the bracket ( x2).





d074r139

6. Disconnect the spring [A] (\*x1).



d074r140

- 7. Disconnect the solenoid plunger [A] from the bracket ( $\mathfrak{C}_{x1}$ ).
- 8. Remove the solenoid [B] with plunger attached.

The potential sensors are under the laser units and above the PCDUs.

- There is one potential sensor for each PCDU.
- Dirt or dust around or on the potential sensor probe or window can cause errors (SC405 to SC413).
- 1. Remove the laser unit above the affected potential sensor. (\*\*p.495)




d074r981

2. Disconnect the sensor bracket ( \*\* x2).



d074r982


- 3. Disconnect the sensor harness at the end of the bracket (2x2).
- 4. Lift the bracket out.





d074r983


- 5. Turn the bracket over.
- 6. Disconnect the harness (□ x1, □ x2).






d074r984

7. The sensor can be separated easily from the bracket (it is held in place by snap tabs) if it needs to be replaced.



d074r985

- 1. Turn off the machine and disconnect its power plug.
- 2. Remove the development unit (\*\*p.558)




d074r931

8. The potential sensor probe and window should be cleaned with a blower brush and a clean dry


cloth. (It does not need to be separated from the bracket for cleaning.)

3. Tape the toner supply port to prevent toner spillage.




d074r932

4. Disconnect the TD sensor plate ( Fx1).



d074r933

- 5. Pull the harness out from behind the tab [A].
- 6. Disconnect the harnesses [B] (🗗 x1).




d074r934

7. Pry the sensor plate and sensor off the bottom of the development unit.

# Image Transfer Belt (ITB) Unit


# ITB Cleaning Unit



### **PM Parts List**


No.	PM Part Name	Replacement Interval
[1]	ITB Cleaning Blade	600K
[2]	ITB Lubrication Roller	600K
[3]	ITB Lubrication Bar	600K
[4]	ITB Lubrication Blade	600K

# ITB Cleaning Unit Removal




d074r150

- 1. Spread some paper or a drop cloth on a table where you can place the ITB cleaning unit for disassembly.
- 2. Remove the cleaning unit cover ( \*x2).



d074r151


- 3. Remove screw [A] ( \*x1).
- 4. Raise both levers [B].



d074r152

- 5. Pull the cleaning unit out slowly until it stops at [A].
- 6. Press the release tab [B].
- 7. Pull the unit [C] out completely and lay it on a table covered with paper or a drop cloth.

# **Cleaning Blade**




d074r153

1. ITB cleaning unit ( p.430)



- When removing and re-installing blades, work carefully to avoid damaging the sponge seals
   [A] at the ends of the blade. These sponge seals cannot be replaced in the field.
- 2. Remove the cleaning blade [B] ( Fx2).


### **Lubrication Roller**






d074r154


- 1. ITB cleaning unit ( p.430)
- 2. Disconnect the roller at the front (♥x1, ♥x1, ♥x1, ...x1).





d074r155


- 3. Remove screw [A] ( \*\* x1).
- 4. Move the roller [B] slightly to the left.



d074r156


5. Remove the roller [A].

# **Lubrication Bar**



d074r157

- 1. ITB cleaning unit (IPp.430)
- 2. Lift the edge of the lubrication bar [A] (the spring loaded arms will pop out).
- 3. Remove the lubrication bar [B].





d074r158

- 4. Disconnect the spring from the arms [A] and [B] (\*x1).
- 5. Remove the arms [C] and [D] ( Fx2).



• Do not discard these springs and arms. They are not provided as service parts and must be reattached to the new lubrication bar.





d074r159

1. ITB cleaning unit ( p.430)



- · When removing and re-installing blades, work carefully to avoid damaging the sponge seals at the ends of the blade. These sponge seals cannot be replaced in the field.
- 2. Remove the lubrication blade [A] ( Fx2).

### After Replacement

- 1. Install the cleaning unit.
  - Keep the levers in the unlocked position.
  - Do not attach the cove yet.
- 2. Make sure that the machine power is OFF.
- 3. Remove the PTR unit.
- 4. Turn the main power switch ON and close both front doors.
- 5. Enter the SP mode.

- 6. Reset the counter for the replaced unit or parts. RTB 137: Wrong SP number
- 7. Open the right front door and execute SP2301-1 (Force Lubricant Belt Cleaning).
- 8. Immediately after executing, close the right door to run the above SP
- 9. Wait for about 5 minutes. When you see "Completed" displayed on the operation panel, you are ready to continue.
- 10. Re-install the PTR unit.
- 11. Rotate both levers of the ITB cleaning unit counter clockwise and re-install the front cover.
- 12. Execute these SP codes.


SP	What It Does
3020-001	Initializes process control.
3012-001	Confirms successful initialization of process control.

13. Exit the SP mode.

## **Transfer Belt Replacement**

#### Transfer Belt Removal

1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)






d074r160

- Remove screw [A] ( \*x1).
- 3. Raise both levers [B].
- 4. Pull the cleaning unit out slowly unit it stops.
- 5. Press the release lever [C].
- 6. Pull the cleaning unit [D] out.

### Right Handle






d074r161

- 7. Disconnect the handle plate [A] ( Fx3).
- 8. Slowly swing the handle to the right [B].
- 9. Disconnect harness [C] (📬 x1).

### ID Sensor/MUSIC Sensor Plate






d074r162

- 10. Disconnect plate [A] (♠x1, ♣x1, ♣x1).
- 11. Remove the sensor plate [B].

### **Lower Cover Plate**






d074r163

12. Disconnect the lower cover plate at [A] ( Fx1).

13. The plate will drop and be held by the small cable [B].

### **Guide Plate**



d074r164

- 14. Disconnect the guide plate [A] ( Fx1).
- 15. Lower the guide plate slightly [B] and pull it out [C].

### Belt Speed Sensor Bracket, Left Handle



d074r165

16. At the front edge of the ITB unit, remove the belt speed sensor bracket [A] ( Fx1).





d074r166


17. Remove the left handle plate [A] ( Fx3).

Belt Tension Roller, Removing the ITB

- 4
- 18. Disconnect the front spring [A].
- 19. Disconnect the rear spring [B].



- Do not remove these springs. Let them hang free. They will not fall off.
- 20. Disconnect the belt tension roller assembly [C] ( \*x1).



d074r168

- 21. Slowly lower the belt tension roller assembly [A], while you support the other end of the roller with your other hand [B] under the ITB unit.
- 22. Remove the tension roller assembly [C] and tension roller.



d074r169

23. Removal of the tension roller relieves tension on the transfer belt and it will sag.



• You will see an encoding strip on the front edge of the transfer belt. The transfer belt must be re-installed with this strip on the front edge as shown above.



d074r170

24. Slowly remove the transfer belt.




d074r171

1. Before re-installing the transfer belt, cover the top of the ITB unit with a long sheet of paper.




- A sheet of paper is provided as an accessory with a new transfer belt.
- If you are re-installing the same transfer belt, you can cover the top of the unit with several sheets of A3 paper. (The paper prevents the front edge of the belt from catching on top of the unit.)




d074r172


2. Confirm that the encoding strip is on the front edge of the belt [A].



d074r173


3. Make sure that the front edge of the belt is parallel with the straight lines embossed on the plates at three locations [A]. This ensures correct alignment of the belt.






d074r174

4. Re-attach the springs of the tension roller at the front [A] and rear [B] as shown above.



d074r175

- 5. Before you re-attach the tension roller assembly:
  - Look under the ITB unit, and make sure that the actuators of the rear overrun sensor [A] and front overrun sensor [B] are visible near the rear and front edges of the belt.
  - Check the alignment of the belt again at the top front edge (see Step 3).



d074r176

6. Before you slide the ITB unit into the machine, turn the ITB lever [A] to confirm that the lift plate raises and lowers.

The plate should move up and down smoothly.

-or-

If the action of the ITB lever is loose and the lift plate does not move, this means the right lift plate is in the up position.

- Reach under the unit [B] and turn the white drive gears of the 2nd lift motor (K) to lower the lift plate until it is down.
- Turn the ITB lever [A] again to confirm that the lift plate moves up and down smoothly.
- Turn the ITB lever [A] to the down position so that the lift plate and transfer belt are down.

# Mportant ...

• Never push the ITB unit into the machine with the lift plate in the up position.

# 4

### After Transfer Belt Replacement

#### RTB 100 Procedure was modified

- 1. The machine power must be OFF.
- Procedure was 2. Open both front doors.
  - 3. Remove the front cover of the ITB cleaning unit.
  - 4. Rotate both levers of the ITB cleaning unit clockwise to retract the blades from the ITB.
  - 5. Remove the PTR unit. (Pp.432)
  - 6. Turn the main power switch ON and close both front doors.
  - 7. Enter the SP mode.
  - 8. Reset the counter for the replaced ITB belt.
  - 9. Open the right front door and execute SP2310-1 (Force Lubricant Belt Cleaning).
  - 10. Immediately after executing, close the right door to run the above SP.
  - 11. Wait for about 5 minutes. When you see "Completed" displayed on the operation panel, you are ready to continue.



- Do not open any door or remove the used toner bottle while lubrication is in progress.
- 12. Re-install the PTR unit.
- 13. Rotate both levers of the ITB cleaning unit counter-clockwise and re-install the front cover.
- 14. Do SP2912-1. This SP adjusts the strength of the LED beam of the ITB feed-back sensors (main sensor and sub sensor).
- 15. Do SP2914-1. This SP code resets the ITB feed-back sensors.

After a new ITB has been installed, or the original belt re-installed, the physical condition of the belt should be checked. The three ID/MUSIC sensors (Rear, Center, Front) scan the belt to detect nicks and scratches.

#### **Belt Check**

- 1. First, execute SP2310-1 to clean and lubricate the belt.
- 2. Do SP3011 to manually execute process control.
- 3. Do SP3012-1 to confirm the successful initialization of process control.
- 4. Do these SP codes to confirm the scan results:
  - SP2112-15
  - SP2112-16
  - SP2112-17
- 5. Each SP execution should return a "O". If an SP returns any value other than "O", do Steps 2, 3 again..

"O", the belt is damaged and must be replaced.

### **ITB Unit Cover Plates**



6. After repeated executions, if one or more of the SP codes continues to return any value other than

d074r227

After the transfer belt has been removed, there are five plates on top of the ITB unit that must be removed for some procedures.

Pull the ITB unit out to the 2nd stop position. (\*\*p.410)


- 1. Transfer belt (IPp.599)
- 2. Plate ① ( 🗗 x2)
- 3. Plate 2 ( 🗗 x3)
- 4. Plate 3 ( 🗗 x4)
- 5. Plate 4 ( Fx4)
- 6. Plate (5) ( Fx6)

In order to remove the front screws, you must first disconnect the 1st lift motor (YMC) (\*\*p.611)

### 4

# ID/MUSIC Sensor Fan

1. Pull the ITB unit out to the 1st stop position (\*\*p.410)



d074r177

- 2. Disconnect the right handle plate [A] ( \*\bar{x} x3).
- 3. Swing the plate [B] slowly to the right.
- 4. Disconnect the fan harness [C] (🖾 x1) and remove the handle.



d074r178

5. Disconnect the fan motor assembly ( 🗗 x3)






d074r179

6. Remove the fan motor ( Fx2).

# PTR Separation Motor

1. Pull the ITB unit out to the 1st stop position. (\*\*p.410)







d074r180

2. Remove the motor assembly [A] ( \*x1, \*\text{\$\exitt{\$\exitt{\$\text{\$\titt{\$\text{\$\$\exittit{\$\texitt{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\text{\$\texi\}\$\exititit{\$\text{\$\exititt{\$\text{\$\text{\$\text{\$\text{\$\text{\$\








d074r181

3. Remove the motor [A] ( Fx2).


# 1 st Lift Motor (YMC)


1. Pull the ITB unit out to the 1st stop position. (\*\*p.410)



d074r182

2. Remove the motor assembly [A] (⊜x1, 🗗 x1, 🎉x3).





d074r184

3. Remove the motor [A] (  $\mathcal{F}$  x2).


### **Transfer Belt Drive Motor**


1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)



d074r185

2. At the top of the right rear corner of the ITB unit, disconnect the motor [A] ( x1, \*x2).






d074r186

4

4

3. Below the ITB unit, remove screw [A] and screw [B] ( \*\*x2).




d074r187


4. Remove the transfer belt drive motor [A].

## 2nd Lift Motor (K)

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transfer belt (\*\*p.599)
- 3. ITB unit cover plate 3 (\*p.608)




d074r188



d074r189

- 5. Disconnect the front end of the shaft [A] ( $\mathfrak{C}_{x1}$ ).
- 6. Disconnect the rear end of the shaft [B] ( $\mathbb{C} \times 1$ ).




d074r190

- 7. Remove screw [A] ( Fx).
- 8. Remove e-ring [B] (**©** x).


4






d074r191


- 9. Disconnect the motor harness [A] and the motor ( $\upolesize{1}{12}$  x1,  $\upolesize{1}{12}$ x2,  $\upolesize{1}{12}$ x1)
- 10. Push the shaft to the right to disconnect it at the front [B], lower it, and pull it out from below the ITB unit.





d074r192

- 11. Remove the cover [A] ( \*\* x2).
- 12. Disconnect and remove gears [B] and [C] ( ${\overline{\mathbb{Q}}}$ x2,  ${f \odot}$ x2).




d074r193

- 13. Make sure the harness is disconnected at [A] (🗟 x1).
- 14. Remove the motor [B] ( \*\begin{align\*} 2 \)

# **Belt Centering Motor**

- 1. Pull the ITB unit out to the 2nd stop position. (Pp.410)
- 2. Transfer belt (Pp.599)




d074r194

- 3. Below the ITB unit at the rear, disconnect the motor [A] ( $\mathcal{O}$  x1,  $\mathcal{F}$  x4).
- 4. Remove the motor (🗗 x1).



d074r195

#### Re-installation




d074r196

- 1. Look down at the back of the ITB unit and check the spool [A].
- 2. If the cable is free as shown above, wrap it once around the spool (counter-clockwise). [B] shows the cable wound on the spool correctly.

# PTR/ITB Cleaning Unit Motor

This motor has two functions. It drives the PTR and all the moving parts of the ITB cleaning unit.

1. Open the cooling box and controller box. (\*\*p.400)




d074r197

- 2. Remove the center stay [A] ( \*\bar{x} x3).
- 3. Disconnect clamps and connectors of the TDCU around [B].
- 4. Disconnect clamps and connectors of the TDCU around [C].




• These boards can be lowered on their bottom hinges after the top connectors and clamps are disconnected. You do not need to disconnect all clamps and connectors.




d074r198

5. Lower the IOB [A] and TDCU [B].



d074r199

6. After the boards are lowered, you can see the ITB cleaning unit motor.






d074r200

7. Remove the motor (♠x2, ♣x1, ♠x4).


## ID Sensor/MUSIC Sensors

1. Pull the ITB unit out to the 1st stop position. (\*\*p.410)



d074r201

- 2. Disconnect the handle plate [A] ( \*x3).
- 3. Slowly swing the handle plate to the right [B].
- 4. Disconnect the harness [C] ( x1).



d074r202

5. Disconnect the plate [A] and remove it(🖨 x1, 🗗 x1, 🎉 x1).



d074r203

6. Remove the sensor board (♠x5, 📬 x1, 🗗 x6).

#### After ID/MUSIC Sensor Replacement

Do the following procedure after installing new ID/MUSIC sensors and re-assembling the machine.

- 1. Plug in the power cord and turn on the machine.
- 2. Enter the SP mode.



#### SJ100412003A

D104/D105/D106 SP3-362-016 = 0.324 SP3-362-013 = 1.02


D074/D075/M044 SP3-331-021 = 0.324 SP3-331-031 = 1.02


d0704r144

- 3. Refer to the sheet provided with the new ID/MUSIC sensor set.
- 4. Do the SP codes for D074/D075/M044 on the right side of the sheet (enclosed in the red box in the illustration above). The numbers on the left are for another machine.
- 5. Next, do SP3011-1 (Manual Process Control).
- 6. Do SP3012-1 to confirm successful complete of process control initialization.

### **PTR Separation Sensor**

1. Pull the ITB unit out to the 1st stop position. (\*\*p.410)






d074r204

- 2. Remove the PTR separation motor assembly [A] ( \*x1, \*\sum x1, \*\text{\$\text{\$\pi}\$} x1, \*\text{\$\pi\$} x2).
- 3. Remove the sensor [B] (□ x1, x3).


## 1st Lift Motor Sensor (YMC)

1. Pull the ITB unit out to the 1st stop position. (Pp.410)



d074r205

- 2. Remove the sensor assembly [A] (🖨 x1, 🗗 x1, 🎉 x2).
- 3. Disconnect the sensor [B] (🗂 x1)




d074r206


4. Remove the sensor (▼x3).

# Belt Centering Roller HP Sensor

1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)



2. At the top of the left rear corner of the ITB unit [A], disconnect the sensor assembly ( $\textcircled{x}1, \ref{x}2$ )




d074r208

- 3. Disconnect at [A] (📬 x1, 🖨 x1).
- 4. Disconnect the sensor [B] (▼x3).


### **Belt Centering Sensor**

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transfer belt (Pp.599)




d074r209

3. The belt centering sensor is located at the rear upper right corner [A] of the ITB unit.




d074r210


- 4. Disconnect the front end of the ITB drive roller [A] (  $\mathcal{F}$  x1).
- 5. Disconnect the rear end of the ITB drive roller [B] (  $\mathcal{F}$  x1).



d074r211


- 6. Behind the ITB unit, disconnect the transfer belt drive motor and drive train [A] (🖨 x3, 📬 x3).
- 7. Remove the drive train screws on the right [B] ( \*x2).






d074r212


- 8. Remove the drive train screw on the left [A] ( Fx2).
- 9. Remove the ITB drive train with the transfer belt drive motor attached [B].






d074r213


- 10. Remove the ITB drive roller [A].
- 11. At the bottom right rear corner [B], remove the sensor assembly (  $\mathcal{F}$  x2).






d074r214

- 12. At the top, remove the belt centering sensor assembly [A] (🗂 x1).
- 13. Remove cover [B] ( \*\* x2).






d074r215

14. Remove the belt centering sensor [A] ( \*\*x2).

# 2nd Lift Motor Sensor 1 (K)

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transfer belt (\*\*p.599)
- 3. ITB unit cover plate 3 and 4 (\*p.608)




d074r218

- 4. Disconnect the sensor from the plate [A] (♠x3, ▼x3).
- 5. Disconnect the sensor [B] ( x1).

Re-installation

Л




d074r219

- 1. Disconnect and slide the actuator [A] toward the rear.
- 2. Re-connect and set the sensor [B] (□ x1, □ x3, ¬ x3).

### 2nd Lift Motor Sensor 2 (K)

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transfer belt (\*\*p.599)
- 3. ITB unit cover plate 3 (IPp.608)



d074r220

- 4. At the top right rear corner of the ITB unit [A], remove the sensor assembly (🖨 x2, 🎉 x1).
- 5. Remove the sensor [B] (

  x1, 


  x3).

# Transfer Belt Speed Sensor

1. Pull the ITB unit out to the 2nd stop position. (IPp.410)


- 2. Transfer belt (\*\*p.599)
- 3. ITB unit cover plate ① (IPp.608)






d074r221

- 4. Remove the belt speed sensor assembly [A] (♠x1, ♥x3).
- 5. Turn the sensor assembly [B] over.





d074r222

- 6. Separate the bracket [A] and sensor [B] ( Fx2).
- 7. Enter the SP mode and set the following SP codes to their default settings after replacing or cleaning the transfer belt speed sensor:
  - SP2920-1
  - SP2912-1


#### **RTB 77**


• SP2914-1

### Front Overrun Sensor

Notes on cleaning the speed sensors

- 1. Pull the ITB unit out to the 2nd stop position. (IPp.410)
- 2. Transport belt (\*\*p.599)






d074r223

- 3. At the front [A], disconnect the sensor bracket ( \*\mathbb{P} x1).
- 4. Grip the bracket under the ITB unit, then push it to the right and then up.
- 5. Remove the sensor [B] (♠x1, ♣x1, ▼x3).

### Rear Overrun Sensor


- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (IPp.599)



d074r224


3. Disconnect the bottom cover plate [A] and lower the plate. The spring loaded cable retracts automatically to [B].

4



d074r225

- 4. Behind the ITB unit [A], remove the sensor bracket screw.
- 5. Remove the bracket [B] and lower it.



d074r226

6. Remove the sensor [A] ( $x_1, x_2, x_3$ ).

# Image Transfer Rollers


- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (\*\*p.599)



d074r228



- There are four image transfer rollers. The following procedure is the same for each image transfer roller.
- The image transfer rollers should all be replaced together at 1800K.




d074r229

- 4. Slide the roller to the rear so that the front end disconnects from the coupling, and then remove the roller.

## ITB Bias Roller





- The bias roller should be replaced every 1800K.
- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (Pp.599)



d074r230


- 3. Disconnect the sensor assembly [A] ( \*\bar{x} x2).
- 4. Push the assembly to the side [B]. (You do not need to disconnect the sensor.)






d074r231


- 5. Disconnect the timing belt [A] ( $\mathcal{O}$  x1).
- 6. Disconnect the end of the bias roller [B] (\$\overline{O}\$\times 1).
- 7. Remove the actuator [C].



d074r232

8. Remove bracket [A] ( 🗗 x2).






d074r233

9. At the rear bottom edge of the ITB unit [A] (top view), remove the screws, but do not remove the black bracket ( \*\*\varphi x2).




- If you pull out the black bracket at the rear, the bias roller will fall.
- 10. Under the rear edge of the ITB unit [B], pull the rear end of the bias roller out and remove the roller.





11. Remove the coupling from the rear end [A] of the bias roller ( $\mathfrak{C}_{x1}$ , Pin x1).





d074r235

12. Pull the shaft out the front end of the bias roller.

### ITB Transfer Power Pack


- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (\*\*p.599)
- 3. ITB unit cover plate 3 and 4 (\*p.608)
- 4. Image transfer roller (1 p.631)






d074r237

- 5. At the front edge [A] where you removed the two plates, free the harness [B] from the plate below (🗟 x3).
- 6. Free the right heater harness at the center [C], remove the right heater plate, and then move the plate [D] to the left side (🖨 x3, 🌶 x2).






d074r239


- 7. Free the gray harness [A] at the rear.
- 8. At the rear, disconnect harness [B] (🖨 x2, z📫 x1)

4



d074r240

- 9. Disconnect the plate on the left side [A] ( \*\*x2).
- 10. Raise the lift arm [B] and disconnect the plate on the right [C] ( \*\bar{k}^2 x2).



d074r241

11. Remove the transfer power pack cover plate [A].


d074r242


- 12. Disconnect the transfer power plate:
  - [A] Right top corner ( x1)
  - [B] Right bottom corner ( x1)



d074r243


13. Disconnect the left side of the transfer power pack ( $$^{\circ}_{x7}$, <math>$^{\circ}_{x4}$)$ .






d074r244


- 14. Disconnect the right side of the power pack bracket:
  - [A] Right top corner ( \*\begin{align\*} x 1 )
  - [B] Right bottom corner ( Px1)






d074r245

- 15. Disconnect the left side of the power pack bracket:
  - [A] Left top corner ( Px1)
  - [B] Left bottom corner ( Fx1)



d074r246

16. Remove the transfer power pack [A].




d074r247

17. Remove the transfer power pack from its bracket ( \*\* x6).

### TDRB

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (\*\*p.599)
- 3. Remove the ITB transfer power pack. (See the previous section.) The TDRB is under the transfer power pack.



d074r248

- 4. Disconnect the TDRB [A] (♠x5, 🗗 x10).
- 5. Disconnect the TDRB bracket [B] ( \*\bar{p} x2).
- 6. Remove the TDRB on its bracket.



d074r249

7. Remove the TDRB from the bracket ( \*\* x4).

# ITB Cleaning Unit Cover Set Switch


1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)

### 2. Transport belt (\*\*p.599)




d074r250

- 3. The cleaning unit cover set switch [A] is on the front plate of the ITB unit.
- 4. Behind the front plate and above the switch, remove the spring [B] (\*\*x1).



d074r251


5. Disconnect the switch harness [A] (🖨 x3).



- d074r252
- 6. Use the flat tip of a small screwdriver to press in each side of the switch [A] to release it from its slot.
- 7. Pull the switch [B] out the front and disconnect it ( x1).


### **ITB Cleaning Unit Set Switch**

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (\*\*p.599)



d074r253

- 3. The cleaning unit set switch [A] is on the inner side of the rear panel, just above the rear end of the bias roller.
- 4. At the rear [B], disconnect the switch harness (🖨 x2).
- 5. Press in both sides of the switch to release it. (You can probably do this with your fingers.)




d074r254

- 6. Push the switch [A] through the hole.
- 7. Disconnect the switch [B] (🗂 x1).

### **Right Anti-Condensation Heater**

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (\*\*p.599)
- 3. ITB unit cover plate 3 and 4 (\*p.608)







d074r256

- 5. Disconnect the right heater plate and turn it over (  $\mbox{\em p} x2$ ).
- 6. The heater is taped to the underside of the plate.

### Left Anti-Condensation Heater

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt (\*\*p.599)
- 3. ITB unit cover plate (5) (1 p.608)






d074r257

- 4. The left heater is under plate [A].
- 5. Disconnect the harness (🖨 x4, 🚅 x1).
- 6. Disconnect the left heater plate and turn it over ( \*x2).
- 7. The heater is taped to the underside of the plate.

### **ITB Unit Thermostat**

- 1. Pull the ITB unit out to the 2nd stop position. (\*\*p.410)
- 2. Transport belt
- 3. ITB unit cover plate 4 ( \*\* x4) (\*\*\* p.608)





d074r255

4. Disconnect the thermostat [A] (🖾 x2, 🔊 x2).

## **MARNING**

- Always replace a blown thermostat with the same type.
- Never attempt to reset a blown thermostat by manipulating the edges of the black cover with a screw driver.
- Resetting a thermostat manually could cause the thermostat to fail and cause a fire.


4

#### 4


# **Paper Feed**

#### Main Machine Tray Removal


#### Tray 1



- 1. Pull out Tray 1 [A] completely so that the right tandem tray [B] separates from the left side.
- 2. Push the right tandem tray [B] into the machine.



- 3. Disconnect the left rail [A] ( \*\* x2 M4x4)
- 4. Disconnect the right rail [B] and remove the tray ( \*\* x3 M4x6).




5. Pull out the right tandem tray [A] and remove it ( $\mathcal{F}$ x2).




Work carefully to avoid bending or damaging the mylar [B] on the side plate of the tray. This
mylar prevents paper in the tray from hitting the reverse roller before it is ready to feed.

#### Re-installation



- When you re-install the right tandem tray, make sure that the wheels ride on slide rail [A].
- Also, make sure that the tandem tray stopper [B] is set behind stopper [C] (inside the machine).


#### Tray 2 (Universal Tray)



- 1. Pull out Tray 2 [A].
- 2. Lift the inner tray [B] out of the tray.

#### PFU Pick-up, Feed, Separation Rollers

1. Tray 1 or Tray 2 ( p.441)



- 2. Remove:
  - [A] Pick-up roller (🛱 x 1)
  - [B] Feed roller ( ( x1)
  - [C] Separation roller ( $\overline{\mathbb{O}}$ x1)




- The feed rollers of the main machine and LCIT are not interchangeable because they turn in different directions.
- After replacing a feed roller in the main machine, make sure that it turns counter-clockwise in the direction of paper feed.
- Avoid touching the surfaces of these rollers with bare hands.
- 3. Reset the PM counter to zero for replaced rollers.

#### Paper End Sensor

1. PFU (**p**.441)



• The procedure below is the same for both tray 1 and tray 2 paper feed units.



d074r446

- 2. Disconnect the pickup roller lift sensor [1] ( \*\*\bigs1).
- 3. Remove the sensor [2] (**□** x1, **¬** x4).

#### Pickup Roller Lift Sensor


1. PFU ( p.441)

UNote

• The procedure below is the same for both tray 1 and tray 2 paper feed units.

4





d074r447


- 2. Remove the sensor assembly [1] ( Fx1).
- 3. Remove the sensor [2] (□ x1, x4).

### Paper Feed Sensor

1. PFU (**p**.441)



• The procedure below is the same for both tray 1 and tray 2 paper feed units.



d074r448


- 2. Remove the sensor assembly [1] (  $\mathcal{F}$  x1).
- 3. Remove the sensor [2] (♥ x1, ▼ x3).

### Pickup Roller Solenoid

1. PFU (**p**.441)





• The procedure below is the same for both tray 1 and tray 2 paper feed units.



d074r449

- 2. On top of the PFU, disconnect spring [1] (\*\*x1).
- 3. Disconnect harness [2] (🛱 x1, 📬 x1).






d074r450

- 4. Disconnect the solenoid bracket [1] ( \*\var{x}2).
- 5. Remove the solenoid and bracket [2].

#### Re-installation



d074r451

1. When you re-install the pickup roller solenoid [1], raise the pickup roller [2] and then lower it after the solenoid is set. This ensures that the actuator is positioned correctly.

4

2. Depress the pickup roller and make sure that it bounces up and down.




- If the actuator of the solenoid is not positioned correctly, the pickup roller will catch on the frame and jam the right tandem tray when the PFU is re-installed.
- 3. After re-installing the PFU, set the right tandem tray on its rails without installing its screws. Then slowly push the right tray into the machine and then pull it out to make sure that it does not jam.

#### Separation Roller Solenoid

1. PFU (**p**.441)




• The procedure below is the same for both tray 1 and tray 2 paper feed units.



d074r452


- 2. Turn the PFU upside down.
- 3. On the bottom of the PFU, disconnect spring [1] ( $\sqrt[p]{x}$ 1).
- 4. Disconnect harness [2] (♠x1,₩x1).



d074r453

5. Disconnect the solenoid bracket [1] ( \*\* x2).

# Tray 1 Rear Fence Return Sensor (Left Tandem Tray)




d016r987a

- 1. Pull out Tray 1.
- 2. Push the right tandem tray into the machine.
- 3. Remove:
  - [A] Rear bottom plate ( Fx1)
  - [B] Rear fence return sensor (🛍 x1)


4

### Tray 1 Rear Fence HP Sensor (Left Tandem Tray)



- 1. Pull out Tray 1.
- 2. Push the right tandem tray into the machine.
- 3. Remove:
  - [A] Rear bottom plate
  - [B] Rear fence transport gear
- 4. Push the left fence [C] to the right.
- 5. Remove the rear fence HP sensor [D] ( x1).


# Tray 1 Right Tray Paper Sensor (Right Tandem Tray)



- 1. Right tandem tray (1 p.647)
- 2. Remove:
  - [A] Cover ( \*x2)
  - [B] Side fences ( Px2)



 When re-installing the side fences, make sure that they are positioned correctly (A4: Outer, LT: Inner)




- 3. Remove:
  - [A] Bottom plate ( Fx4)
  - [B] Right tray paper sensor ( Fx1, LL x1)

#### **Bottom Plate Lift Wire**




- Before you remove the rear bottom plate lift wire, you must remove the front bottom plate lift wire.
- The removal procedure is the same for both wires.
- 1. Right tandem tray (1 p.647)
- 2. Remove the right tandem tray cover ( Fx2).



- 3. At the front, remove sensor assembly [A] ( \*\*x3).
- 4. Lift the front bottom plate slightly, unhook the wire stoppers [B], and then remove stopper [C] and actuator [D].
- 5. Remove:
  - [E] Wire covers (©x2).
  - [F] Bracket (front only) ( Fx1, €x1, ■x1)
  - [G] Gear (front only)
  - [H] Bottom plate lift wire


#### Re-installation (Bottom Plate Lift Wire)



- 1. Set positioning pin [A] in hole [B].
- 2. Set projection [C] in hole [D].
- 3. Position the wire [E] correctly without crossing the wires.

### Paper Feed Motors, Grip Motors

1. Open the cooling box and controller box. (\*\*p.400)



d074r500

- 2. Remove the center stay [1] ( \*\bar{x} x3).
- 3. Remove the relay board [2] (IFRelay Board).
- 4. Remove PSU 2 [3] ( PSU 2).




d074r501

1	Tray 1 Paper Feed Motor
2	Tray 1 Grip Motor
3	Tray 2 Paper Feed Motor

1

- 4 Tray 2 Grip Motor
- The paper feed and grip motor pairs of each tray must be removed together (they are attached to one bracket).
- The following steps describe removal of the Tray 1 motors. The procedure for removal of the Tray 2 motors is the same.



d074r502

5. Disconnect the grip motor [1] and the paper feed motor [2] (🗗 x2).



d074r503


6. Disconnect the motor mount bracket ( \*\bar{x} x 3).





d074r504


7. Remove the motor mount bracket with both motors attached.



d074r505


- 8. Disconnect:
  - [1] Grip motor timing belt ( $\mathcal{O}$  x1)
  - [2] Paper feed timing belt ( $\mathcal{O}_{x1}$ )
  - [3] Paper feed bracket spring (\*\*x1)

#### Paper Feed Motor



d074r506

1. Disconnect the bracket on the left [1] and on the right [2] (  $\mathcal{F}$  x3).






d074r507

2. Disconnect the motor at the top [1] and the bottom [2] (  $\mathcal{F}$  x2).




d074r508

## Grip Motor



d074r509

- 1. Disconnect the spring [1] (\*\*x1).
- 2. Disconnect the bracket of the motor [2] (  $\ensuremath{\rlap{/}\!\!\!/} x3$  ).




d074r510

3. Disconnect the motor at the bottom [1] and top [2] (  $\mathcal{F}$  x2).



d074r511

#### **Timing Belts**




d074r512

1. Use the tip of a small screwdriver to remove the e-ring [2] ( $\mathfrak{C} \times 1$ ).

# Lift Motors (Tray 1, Tray 2)

1. Open the cooling box and controller box. (\*\*p.400)



d074r500

- 2. Remove the center stay [1] ( Fx3).
- 3. Remove the relay board [2] (PRelay Board).
- 4. Remove PSU 2 [3] ( PSU 2).




d074r513

5. 1 is the tray lift motor for Tray 1, and 2 is the tray lift motor for tray 2.

Tray 1 Lift Motor

4



d074r514

1. Disconnect the motor [1] (🗟 x 1).







d074r515


2. Disconnect the motor [1] ( \*\bar{x} x3).






d074r516

3. Remove the motor.



- d074r517
- 1. Disconnect the motor at [1] ( x1).
- 2. Open clamp [2] (🗟 x 1).
- 3. Disconnect harness [3] (🖼 x1).



d074r518

4. Disconnect the motor ( \*\bar{x} x2).




d074r519

5. Remove the motor.

# Tray 1 Solenoids

1. Open the cooling box and controller box. (\*\*\*p.400)



d074r500

- 2. Remove the center stay [1] ( Fx3).
- 3. Remove the relay board [2] (\*\*Relay Board).
- 4. Remove PSU 2 [3] ( PSU 2).




d074r520

1 Tray 1 Left Tray Lock Solend
--------------------------------

2 Tray 1 Right Tray Lock Solenoid

### Tray 1 Left Tray Lock Solenoid



d074r521

- 1. Disconnect the solenoid [1] (🗗 x1).
- 2. Disconnect the solenoid bracket [2] ( Fx1).





d074r522

#### 3. Remove the solenoid.

Tray 1 Right Tray Solenoid






d074r523

- 1. Disconnect the solenoid [1] (🖼 x1).
- 2. Disconnect the solenoid bracket [2] ( Fx1).





d074r524

3. Remove the solenoid.


# **Vertical Transport Unit**

#### **Bank Exit Motor**



d074r641

1. Vertical transport unit (Pp.444)



d074r642

2. Disconnect and remove the motor bracket (🖨 x1, 🗗 x1, 🏲 x3, 🗸 x1).

4







d074r643


3. Separate the motor from the bracket (  $\slash\hspace{-0.4em}P x2$  ).

## Vertical Transport Motor




d074r644

1. Vertical transport unit (Fp.444)



d074r645

2. Disconnect and remove the motor bracket ((x)x1, (x)x3, (x)x3, (x)x1).



d074r646

3. Separate the motor from the bracket (  $\slash\hspace{-0.6em}P x2$ ).

# Main Relay Sensor 1



d074r647

1. Vertical transport unit (Pp.444)



d074r648

2. Disconnect the long bracket ( Fx2).

Л



d074r649

3. Disconnect and remove the sensor ( ♠x1,♠x1, ♣x1, ►x4).

### **Bank Exit Sensor**



d074r650

1. Vertical transport unit (1 p.444)



d074r651

2. Disconnect and remove the sensor ( ♣x1, ♣x1, ♣x1, ♣x1, ▼x4).

## 1st Transport Sensor



d074r652

1. Vertical transport unit (Pp.444)



d074r653

2. Remove the wide bracket ( \*\bar{x} x4).



d074r654

3. Disconnect and remove the sensor ( ♠x1, ♣x1, ♣x1, ₹x4).


4

# Vertical Transport Sensor



d074r655

1. Vertical transport unit (1 p.444)



d074r656

2. Disconnect and remove the sensor ( ♠x1,♣x1, ♣x1, ►x4).



d074r657

1. Vertical transport unit ( p.444)




d074r658

2. Disconnect and remove the sensor (  $\mathscr{F}$ x1,  $\mathfrak{S}$ x1,  $\mathfrak{T}$ x4).

#### 4

# **Right Drawer**

## Right Drawer Front Cover





d074r660

- 1. Open the front doors.
- 2. Pull out the right drawer until it stops.
- 3. Right drawer ( p.408)
- 4. Remove the front cover and handle B3 ( Fx9).

#### Shift Unit

1. Right drawer (\*\*p.408)




d074r661

- 2. Remove:
  - [1] Cover ( 🗗 x3)
  - [2] Dust tray ( 🗗 x2)




d074r662

3. Remove the relay board ( x2, \*x2).




d074r663

- 4. Disconnect and remove the transfer timing motor.
  - [1] Side (🗟 x 1, 🗗 x 1, 🌶 x 1)
  - [2] Bottom (🗟 x 1, 🌶 x 2)




d074r664

5. Remove the CIS [1] ( \$\mathbb{E} \times 2, □ x1, □ x1).




d074r665

6. Remove the guide ( \*\* x4).




d074r666

7. Remove the plate ( 🗗 x 1 ).



d074r667

- 9. Slide the shift unit [2] to the left.
- 10. Remove spring [3] ( \*x 1).



d074r668


11. Remove the shift unit.

# Registration Entrance Motor




d074r669

1. Right drawer (**\***p.408)




d074r670

2. Press the tab releases on the bottom [1] and top [2] and remove the motor cover.




d074r671

3. Release the clamps (🖨 x4).



d074r672

4. Disconnect the motor (♣x2,♣ x2).



d074r673

5. Remove the motor (  $\nearrow$  x2,  $\nearrow$  x1).





d074r674

6. Separate the motor and the bracket ( Fx2).


#### 4

# **Registration Timing Motor**




d074r675

1. Right drawer (**p**.408)



d074r676


2. Press the tab releases and remove the motor cover.



d074r677

[2] Bottom ( Fx2)

3. Disconnect the motor:





d074r678


- 4. Disconnect the timing belt [1] ( $\mathfrak{O}$  x1).
- 5. Separate the motor [2] and the bracket ( $\mathcal{F}$ x2).

# Registration Gate Motor



d074r679

1. Right drawer (**\***p.408)



d074r680

2. Press the tab releases [1] and remove the motor cover [2].



d074r681


- 3. Remove the motor:
  - [1] Top (x1)
  - [2] Bottom (🖨 x 1, 🗗 x 1, 🌶 x 2)



d074r682


4. Separate the motor and the bracket (  $\mathcal{F}$  x2).

# Shift Roller Motor




d074r683

1. Right drawer (**p**.408)




d074r684

2. Press the tab releases and remove the motor cover.



d074r685

- 3. Remove the motor:
  - [1] Bottom ( 🗗 x2)
  - [2] Top (🞜 x1,🗟x2, 🏞x1)





d074r686

4. Separate the motor and the bracket ( Fx2).

### **Shift Unit Motor**

- 1. Right drawer (**\***p.408)
- 2. Shift unit ( p.677)





d074r687

3. Remove the registration gate spring (\*\*x1).




d074r688

- 4. Remove the registration gate and its shaft:
  - [1] Rear ( 🗗 x 1)
  - [2] Front ( \*\* x2).



d074r689


5. Disconnect the motor mount ( $\Re x4$ ,  $\Re x4$ )



d074r690

6. Separate the motor and the mount (2x2, 1x2, 2x3).

1. Right drawer (**P**p.408)



d074r691

2. Disconnect the motor bracket ( \*\*\varkappa x3, \*\*\varkappa x1).





d074r692


3. Separate the motor and the bracket ( $\mathcal{F}$ x2).

#### CIS Fan

- 1. Right drawer (**1**p.408)
- 2. Shift unit ( p.677)

4








d074r693


3. Remove the fan cover ( Fx1).



d074r694


4. Remove the fan (♣x2,**11** x1).

# Main Relay Sensor 2



d074r695


1. Open the front doors and pull out the right drawer until it stops.



d074r696


2. Disconnect the sensor bracket and remove the sensor ( ♠x1,♣x1, ♣x1, ♣x1, ★x3).

# Main Relay Sensor 3



d074r697

1. Open the front doors and pull out the right drawer until it stops.



d074r698


2. Disconnect the sensor bracket and remove the sensor (x2, x1, x1, x3).

/

### **LCIT Relay Sensor 2**

1. Open the front doors and pull out the right drawer until it stops.






d074r699

- 2. Disconnect the sensor bracket [1] ( Fx2).
- 3. Disconnect the sensor (🖨 x1, 🚅 x1).

# Double-Feed Sensor 1 (LED)

1. Open the front doors and pull out the right drawer until it stops.



d074r700


- 2. Remove bracket [1] ( \*x1).
- 3. Remove screw [2] ( \*\* x1).



d074r701

4. Disconnect the sensor ( x1).





d074r702

5. Pull out the sensor bracket and disconnect the sensor (  $\mathcal{F}$ x1, $\mathcal{C}$  x1).

# Double-Feed Sensor 2 (Receptor)



d074r703

1. Open the front doors and pull out the right drawer until it stops.




d074r704

2. Disconnect the sensor bracket and remove the sensor (\*x1, \*x1, \*\bar{x}1).

#### **Shift Unit Sensor**

1. Shift motor mount (\*\*p.688)






d074r705

2. Remove the sensor bracket and remove the sensor ( \*\*\sigma x3).

# Registration Gate Sensor

- 1. Remove:
  - Right drawer (1 p.408)
  - Shift unit (1 p.677)

Registration gate (\*\*p.688)



1. Remove the sensor ( ₱x1, □ x1, x3).

# CIS


1. Open the front doors and pull out the right drawer until it stops.

RTB 59 Procedure modified for adjusting the CIS after replacement



d074r707

2. Remove the cover (\*x3).



3. Remove the CIS assembly ( \*\varPx2, \subseteq x1, \subseteq x1).




d074r709

4. Separate the CIS and its bracket.

### **Transfer Timing Sensor**

1. Open the front doors and pull out the right drawer until it stops.




d074r710

2. Remove the sensor bracket and disconnect the sensor (  $\Re x1$ ,  $\Re x1$ , 11, 11).




d074r711

2. Duplex transport sensor 4 is on the left bottom edge of the drawer unit.



d074r712

3. Disconnect the sensor bracket ( \*\* x1, \*\* x1).




d074r713

4. Pull out the sensor bracket and disconnect the sensor (2x1, 21x1).

4


# Duplex Transport Sensor 5

1. Open the front doors and pull out the right drawer until it stops.




d074r714

2. Duplex Transport Sensor 5 is located at the bottom front edge of the drawer unit.



d074r715

3. Disconnect the sensor bracket and pull it out (  $\mathcal{F}$  x1,  $\mathcal{L}^{1}$  x1).




d074r716

# DRB


1. Right drawer (\*\*p.408)

4. Disconnect the sensor (♠x1,♥ x1).



d074r717


2. Disconnect the front [1] of the DRB (🖨 x 1, 🞜 x 3).



d074r718


- 3. At the rear, press the tab releases and remove the cover of the registration entrance motor [1].
- 4. Disconnect the harness [2] (🖨 x4).

/




d074r719

5. Disconnect the motor (☎ x2,৯x1).



d074r720

- 6. Disconnect the harnesses at [1] (🗂 x2).
- 7. Disconnect the bracket [2] (🞜 x3).



d074r721

- 8. Pull the assembly out of the drawer unit.
- 9. Disconnect the bracket ( Fx4).



d074r722

10. Remove the DRB ( 🗗 x6, 🗂 x All

# Separation Power Pack

- 1. Remove:
  - Right drawer (\*\*p.408)
  - PTR unit (\*\*p.432)
  - Shift Unit (1 p.677)
  - Transfer Timing Sensor (\*p.697)




d074r723

2. Remove the bracket (₱x1,♀x1).

4





d074r724


- 3. Set lever **B3** at the front.
- 4. Push in on the brackets at rear.






d074r725

5. While pressing both ends, raise the lever to the upright position.



d074r726

6. Disconnect the end of the transport roller (@x1).




d074r727

- 7. Disconnect the transfer timing roller encoder [1] ( $\mbox{$\cong$} x2$ , Pins x4,  $\mbox{$\swarrow$} x2$ ).
- 8. Remove the encoder [2] ( Fx1).



d074r728

9. Remove the encoder stopper (©x1).






d074r729

Re-Installation

4


- When you re-install the stopper on the shaft, be sure to align the groove of the shaft with the tab of the stopper.
- The small triangle on the stopper indicates the location of the tab.





d074r730

- 1. Remove the bracket ( \*\bar{x} 1, \*\bar{x} x 1).
- 2. Remove:
  - [1] Gear (**©**x1)
  - [2] Belt (**O**x1)





d074r731

- 3. Disconnect both ends of the shift drive roller:

  - [2] Rear ( 🖋 x 1 , © x 1 )



d074r732

4. Remove the shift drive roller.




d074r733

5. Disconnect the springs on both sides of the tension arm ( $\mathscr{I}$ x2).




d074r734

6. Disconnect the tension arm (@x2).



d074r735


- 7. Remove the tension arm [1].
- 8. Depress the tab releases and remove the power pack cover [2] ( x4).



d074r736

9. Remove the separation power pack ( x2, x6).

# Paper Transfer Roller (PTR) Unit



d074r260a

# PM Parts List: Replacement

No.	PM Part Name	Interval
[1]	PTR Separation Plate	300K
[2]	PTR Lubrication Bar	450K (D074) 500K (D075/M044)
[3]	PTR Cleaning Blade	300K
[4]	Paper Transfer Roller (PTR)	600K

# PTR Servicing SP Codes

You must execute these SP codes after replacing and the PTR unit or replacing parts.

- 1. The machine power must be OFF.
- 2. Open both front doors.


4

- 3. Turn the main power switch ON.
- 4. Enter the SP mode.
- 5. Reset the counter for the replaced unit or parts.
- 6. Close the front doors.
- 7. Wait for about 5 minutes. When you hear an audible beep and see "Ready" displayed on the operation panel, you are ready to continue.
- 8. Execute these SP codes.

SP	What It Does	
3020-001	Initializes process control.	
3012-001	Confirms successful initialization of process control.	

9. Exit the SP mode.

### Cleaning



d074t260


No.	PM Part Name	Interval	Replaced By
[A]	PTB Sensor	300K	Service Technician, or TCRU

# Separation Plate



d074r263


- 1. PTR unit ( p.432)
- 2. Disconnect the separation plate at the rear [A] and front [B] ( \*\*x2).



d074r264

- 3. Remove the separation plate [A].
- 4. After replacement, do the SP codes. (\*\*p.708)

#### Lubrication Bar




d074r265

4




- 1. PTR unit ( p.432)
- 2. Remove the entrance guide plate [A] ( Fx2).



d074r266

3. Remove the lubrication bar casing [A] ( Fx2).




d074r267


4. Release the bar on either end [A] and remove it [B] (\ x2).



- Do not remove the springs [C]. The springs must be positioned as shown above for reinstallation. Do not lose them (they can easily fall out of the casing if it is handled carelessly).
- 5. After replacement, do the SP codes. (\*\*p.708)








d074r267a

#### 

• When removing and re-installing blades, work carefully to avoid damaging the sponge seals [A] and [B] at the ends of the blade. These sponge seals are fragile and cannot be replaced in the field.



d074r268

- 1. PTR unit (**p**.432)
- 2. Remove the lubrication blade.
- 3. After replacement, do the SP codes. (\*\*\*p.708)


#### **Lubrication Roller**

- 1. PTR unit ( p.432)
- 2. Remove:
  - Lubrication bar (\*\*p.710)
  - Lubrication blade (\*\*p.712)




d074r269

3. At the front [A], remove the gear ( $\overline{\mathbb{Q}}$ x1).



d074r270

4. At the front [A], disconnect and remove the lock plate [B](  $\mathcal{F}$  x2).




d074r271

5. Pull out the rear end of the shaft [A] and remove the roller [B].

6. After replacement, do the SP codes. (\*\*p.708)


# PTR (Paper Transfer Roller)

- 1. PTR unit ( p.432)
- 2. Remove:
  - Lubrication bar (\*\*p.710)
  - Lubrication blade (\*\*p.712)
  - Lubrication roller (Pp.713)



d074r272

- 3. Disconnect the front end of the roller [A] ( $\mathfrak{C}x1$ ).
- 4. Remove the ring bearing [B].



d074r273





d074r274

6. Remove the other gear [A] (©x1).



d074r275

7. Remove the ring bearing and bearing race from the shaft.




d074r276

8. Remove the PTR [A].

9. After replacement, do the SP codes. (\*\*p.708)

# **Cleaning Roller**


- 1. PTR unit ( p.432)
- 2. Remove:
  - Lubrication bar (\*\*p.710)
  - Lubrication blade (\*\*p.712)
  - Lubrication roller (Pp.713)
  - PTR (See the previous section.)





d074r277


3. At the front, remove the gear [A] ( $\overline{\Omega}$ x1).



d074r278

- 4. Remove the gear [A].
- 5. Remove the washer and bushing [B].






d074r279

6. At the front, pull out the shaft [A] and remove the cleaning roller [B].

#### Re-installation




d074r280

- 1. Attach the pawl [A] to the top of the metal bar base.
- Push the top of the bar [B] lightly. The spring should bounce up and down.If the bar does not bounce, make sure the springs under the lubrication bar are set correctly.
- 3. After replacement, do the SP codes. (\*\*p.708)

### PTR/ITB Cleaning Unit Motor

This motor has two functions. It drives the PTR and all the moving parts of the ITB cleaning unit.




d074r481

- 1. Open the rear boxes. (\*\*p.400)
- 2. Remove the center stay [1] ( Fx3).
- 3. Lower the TDCU [2]. ( p.823)
- 4. Lower the IOB [3]. ( p.830)



 Both of these boards can be lowered without removing all the connectors and removing the boards. Just remove the top edge connectors and enough of the harnesses that will allow you to lower the boards.





d074r482

5. Remove the motor ( x1, 74).



d074r483


# Paper Separation Power Pack

The paper separation power pack is located near the center of the right drawer. (IPPp.408)

# Paper Transport Belt (PTB) Unit

# Paper Transport Belts

1. PTB (**p**.438)



d074r742

- 2. Pull the roller in the direction of the arrow to disconnect the belt from the roller.
- 3. Repeat this procedure for each belt.

#### PTB Sensor

- 1. PTB unit ( p.438)
- 2. Paper transport belts (\*\*p.720)



d074r744


3. Remove the sensor bracket and disconnect the sensor ( ₱x1,♥ x1, x3).

4

#### 4

# PTB Fans

- 1. PTB unit ( p.438)
- 2. Paper transport belts (\*\*p.720)



d074r743

3. Remove the fan ((x)x1, (x)x1, (x)x2). The procedure is the same for each fan.

# Pressure Roller Fan

1. Left drawer cover (IPp.438)




• Only cover removal is necessary.



d074r745

2. Disconnect the right side of the duct ( \*\bar{x} x2).




- 3. Disconnect the fan and remove it:
  - [1] Front ( **?** x2)
  - [2] Bottom (🗟 x2,🞜 x1)

# **Belt Cooling Fan**

1. Left drawer cover (Pp.438)



• Only cover removal is necessary.





d074r747

2. Remove the fan bracket ( Fx2).





d074r748


3. Separate the duct, bracket, and fan (  $\slash\hspace{-0.4em}P x2$  ).

# **Fusing Unit**

# Before You Begin...

# **MARNING**

- The fusing unit can become very hot during normal operation.
- Before removing the fusing unit, switch the machine off and wait at least 10 min. for the fusing unit to cool so it can removed and handled safely.



d074r299

1	Pressure Roller
2	Hot Roller
3	Heating Roller

#### **Specifications**

Nip time	45 ms	
Print speed	D074	65 ppm (B&W, FC)
	D075, M044	75 ppm (B&W, FC)

4

Warm-up time Less than 300 sec.

	Interval	
Removing the Fusing Unit		
Periodic Cleaning, Lubrication		
Fusing Belt Stripper Plate	300K	Clean
Pressure Roller Stripper Plate	300K	Clean
Entrance Guide Plate	300K	Clean
Main Drive Gears	650K	Lubricate
Fusing Unit		
Heating Roller Fusing Lamps		
Heating Roller		
Hot Roller	650K	Replace
Fusing Belt	650K	Replace
Hot Roller Thermistors	650K	Clean
Hot Roller Bearings	650K	Lubricate
Pressure Roller Fusing Lamp		
Pressure Roller	650K	Replace
Pressure Roller Thermistors	650K	Clean
Pressure Roller Bearings	650K	Replace

#### Notes

- Periodic Cleaning, Lubrication. This can be done by simply removing the fusing unit from the machine (\*\*x1). Disassembly of the fusing unit is not required.
- Fusing Unit. Full disassembly of the fusing unit is required at 650K. All these parts must be serviced together.

The following parts can be cleaned or lubricated without disassembling the fusing unit.

### Cleaning

Part Name	Interval	Cleaning By
Fusing belt stripper plate	300K	Service Technician, or TCRU
Pressure roller stripper plate	300K	Service Technician, or TCRU
Entrance guide plate	300K	Service Technician, or TCRU

### Lubrication

Part Name	Interval	Cleaning By
Main drive gears	650K	Service Technician

# **Fusing Belt Stripper Plate**



d074r300

1. Use a dry cloth to clean the stripper plate on the fusing belt.

4

# **Pressure Roller Stripper Plate**



d074r301

1. Use a dry cloth to clean the stripper plate on the pressure roller.

# **Entrance Guide Plate**



d074r302

1. Use a dry cloth to clean the entrance guide plate.

### **Periodic Lubrication**

#### **Main Drive Gears**





d074r303

- 1. Fusing cleaning unit (**P**p.433)
- 2. Remove the rear plate [A] ( \*\*\varphi x3).
- 3. Apply FLUOTRIBO MG Grease to the two rollers marked by red arrows. Apply about 2 g at both points

# **Heating Roller Fusing Lamps**

1. Fusing cleaning unit ( p.433)



d074r341


4

- 2. Remove screws ( > x1, > x1).
- 3. Remove the separation unit cover.



d074r342

4. Remove the screws of the top cover [A] (  $\mbox{\em $x$} \times 1$  ,  $\mbox{\em $x$} \times 2$  )



d074r343

5. Remove the top cover.






d074r344

6. Carefully, remove the rear harness cover ( x1).




• The bottom of the cover is held in place by a tab and post.



d074r344a

- The tab [A] is fragile and can break easily.
- The tab must be positioned behind the post [B] when the cover is re-installed. This positions the cover correctly so that the cover screw can be re-attached.



d074r345

- 7. Disconnect bayonet connectors [A] (🞜 x2).
- 8. Disconnect connector [B] (🚅 x1, 🖨 x1).




d074r346

9. Remove the rear cover [A] ( $\gg$  x3).




d074r347

10. Remove the lock plate ( 🗗 x1 M3x6).




d074r348

11. Remove the guide plate [A].




d074r349

- 12. Remove the screws on the left [A] ( \*\* x4 M3x6).
- 13. Remove the screw on the right [B] ( $\gg$  x1).
- 14. Pull connectors [C] and [D] slightly to the left.




d074r350

- 15. Press in on the sides of the connectors [A] and [B] to release them.
- 16. Pull the connectors up to disconnect them (🗗 x2).



d074r351

- 17. Pull away the drawer connector [A].
- 18. Disconnect the rear frame [B] (  $\mbox{\it P} x5 \mbox{\it M}3x6$ ).




d074r352


### 19. Remove the rear frame.



d074r353


20. Remove the rear lift plate [A] (  $\mbox{\it P}$  x2 M3x6).






d074r353a


- 21. At the front, remove spring [A] (x1).
- 22. Remove lever [B].



d074r354


- 23. At the front, remove screws [A] ( \*\* x4 M3x6).
- 24. At the top, behind the cover, remove screw [B] ( \*x1 M3x6).






d074r355

- 25. Insert a long screwdriver through hole [A].
- 26. Remove the screw [B] ( \*\* x1 M3x6).




d074r356

27. Remove the front cover.




d074r357

28. Remove the front lift plate [A] ( \*\* x2 M3x6).



d074r358

- 29. Loosen screw [A] ( \*\* x1 M3x6).
- 30. Slide plate [B] away from the front.



d074r359


- 31. Raise the paper separation unit [A].
- 32. Disconnect it on the left [B].
- 33. Lift and remove the unit [C].

d074r360

34. At the front, disconnect the ground connectors at [A] (🗗 x4, 🖨 x1) and then pull the harnesses away from the unit.



• These are ground connectors so they do not need to be re-connected in any particular order.



d074r361

35. Remove the fusing lamp holder [A] ( \*\* x3 M3x6).




d074r362

4

#### 36. At the rear:

- Open the clamp at [A] (🗟 x 1).
- Remove screw [B] ( \*\* x2 M3x6).
- Remove the anti-static brush [C].



d074r363

- 37. Open clamp [A] (♣x1).
- 38. Pull the connector assembly [B] out slightly.



d074r364

39. Mark these connectors 1 to 4 before you remove them. (The colors may be different than those in the photo.)




- These connectors must be re-connected in the same order.
- 40. Disconnect the bayonet connectors ( x4).



d074r365


41. Remove the rear fusing lamp holder [A] (  $\rat{x}2\ \text{M3x6}$ ).



d074r366

- 42. Note the positioning of the top ① and bottom ② fusing lamps. They must be re-installed as shown in the photo.
- 43. Pull the fusing lamps [A] slowly out of the heating roller.

#### Re-installation



d074r367

 When re-installing the heating roller fusing lamps, make sure that the sleeves of the dual lamps are inserted correctly as shown above.

- The end of the lamp with the large projection [A] faces up toward the thermostats, and the lamp with the small projection [B] faces down.
- This arrangement ensures that they are re-installed correctly.

# **Heating Roller**

1. Heating roller fusing lamps (Pp.728)




d074r368

2. Disconnect both ends of the upper entrance guide plate ( Fx2 Right).



d074r368a


3. Remove the upper entrance guide plate.




d074r370

4. Disconnect and remove springs:

[A] Front ( \*x1).





d074r371

- 5. At the rear [A], use a pair of spreaders to remove the C-ring.
- 6. Remove the bearing race [B].




d074r371a

7. Remove the belt flange.



d074r371b

#### 8. At the front, remove the C-ring.




d074r371c

- 9. Remove bearing race [A].
- 10. Remove flange [B].
- 11. Pull out the heating roller.


#### Re-installation

Always inspect and clean a heating roller for contamination by grease before re-installing it. Grease contamination can cause uneven heating on the surface of the roller and cause problems during fusing.



d074r371g

- 1. Clean the entire surface of the heating roller with a dry cloth [A].
- 2. Next, clean the entire surface with a cloth dampened with water (not alcohol) [B].
- 3. Finally, clean the entire surface once more with a dry cloth.



d074r375


No.	PM Part Name	Service Life
[1]	Hot Roller	650K
[2]	Fusing Belt	650K

- 1. Fusing lamps (**P**p.728)
- 2. Heating roller (IPp.741)



d074r374

- 3. Raise the unit [A] up to the vertical position.
- 4. Remove the upper unit [B].




d074r376

5. At the rear [A], remove the main fusing drive gear ( $\mathbb{C} \times 1$ ).




d074r377

6. At the same location, remove the rear arch plate ( Fx2 M3x6).




d074r378

7. At the front, remove the front arch plate ( \*\* x2 M3x6).



d074r379

- 8. Use a pair of spreaders to remove C-ring [A].
- 9. Remove the bearing race [B].



d074r380


- 10. Remove the hot roller and fusing belt [A] together.
- 11. Pull the hot roller out of the belt.

#### Before Hot Roller Re-installation

Always inspect and clean a hot roller for contamination by grease before re-installing it. This is especially important for a removed roller that is to be re-installed.

- Grease on the surface of the hot roller can cause the surface of the roller to peel.
- If peeled particles reach the surface of the heating roller, this can cause glossy patches or streaks to appear on prints.

4



d074r381

#### To clean the surface of a hot roller

- 1. Clean the entire surface of the hot roller with a dry cloth [A].
- 2. Next, clean the entire surface with a cloth dampened with water (not alcohol) [B].
- 3. Finally, clean the entire surface once more with a dry cloth.

#### After New Hot Roller Installation

A newly installed hot roller may have a tendency to catch and cause spurious noise. Do the following procedure to avoid this problem.



d075r001


1. Remove the top cover screws ( x2, x2).



d075r002


2. Remove top cover [A].


3. Loosen screw [B] ( \*\* x1 M3x6).



d075r003


- 4. Slide plate [A] to the rear.
- 5. Remove separation unit [B].





d074r005

6. Lower the spring arm for position [A] to [B] as shown above.



d075r004


- 7. Re-attach the top cover [A] ( \*\varphi x1, \*\varphi x2).
- 8. Turn the machine on.


- 9. Wait a few moments for the pressure roller to move to the start position.
- 10. Enter the SP mode.
  - Switch ON SP5805-102 (Output Check Press Roller Lift Motor (Up)).
  - If you hear no belt noise, or if the belt makes noise and then goes off, switch ON SP5805-101 (Output Check - Press Roller Lift Motor (HP))
  - If the roller noise does not stop, switch ON SP5804-114 (Output Check Fusing Motor: High Speed) and with SP5804-114 ON do SP5805-102 and then wait for the noise to stop.
  - Once the noise stops, switch SP5805-101 ON, switch SP5804-114 OFF, and then exit the SP mode.
  - After doing these SP codes, be sure the remove the cover and reassemble the fusing unit.

#### Cleaning, Lubrication

Do the following procedures before reassembling the fusing unit.

Part Name	Interval	Action
Heating Roller Thermistors (x2)	650K	Clean





d074r405


- 1. Use a dry cloth to remove toner and paper dust from the surface of the thermistors:
  - [A] Front
  - [B] Rear

RTB 128 Hot roller bearing lubrication



d074r405a

2. Rotate the races to make sure the contact surfaces of the bearings and race turn freely. If the races do not rotate freely, they must be replaced.



d074r404c

3. Insert the heating roller



4. The flanges must be set so that both edges of the fusing belt rim overlap the collar of the flanges.



d074r404e

5. Re-attach the bearing races at the front [A] and rear [B].



d074r404f

6. Re-attach the C-rings at the front and rear.

# Pressure Roller Fusing Lamps, Pressure Roller


- 1. Fusing lamps (\*\*p.728)
- 2. Heating roller (Pp.741)
- 3. Hot roller and fusing belt (\*\*p.744)



d074r382


### PM Parts

No.	PM Part Name	Interval	Action
[1]	Pressure roller	650K	Replace
[2]	Pressure roller bearings	650K	Lubricate



d074r383


4. Remove the lower exit guide plate [A] (  $\rat{p}$  x2 M3x6).



5. Disconnect the sensor bracket [A] ( \$\infty\$ x1 Left, \$\infty\$ x1 Right).



- These screws are different. Be sure to re-attach them at the correct location.
- A horizontal hook at [B] also holds the sensor bracket.



d074r384

- 6. Slide the sensor bracket [A] to the left to unfasten the hook.
- 7. Pull the bracket [B] away from the frame. It is not necessary to disconnect the harnesses




d074d640


1	Pressure Roller Paper Sensor	Monitors pressure roller
2	Accordion Jam Sensor	Monitors fusing belt
3	Fusing Exit Sensor	Monitors fusing exit



d074r385


8. Disconnect the pressure roller separation unit [A] ( \*x2 M3x6).






d074r386

- 9. Remove the peg lock plates:
  - [A] Rear
  - [B] Front




d074r387

10. Remove the separation unit.




d074r388


11. Remove the entrance lower guide plate cover [A] (  $\slash\hspace{-0.4em}P$  x2 M3x6).




d074r389


12. At the front, remove screw [A] (  $\ref{x1}$  M3x6).






- 14. At the front, locate coiled harness [A] and pull it out.
- 15. Remove screw [B] ( \*\bar{x} x 1).






d074r391

- 16. Remove bracket [B] with the harness still attached.
- 17. Disconnect connectors [B] (🚅 x2).



d074r394

18. Remove the fusing lamp holder [A] (  $\mathcal{F}_{x1}$ ).



d074r395

19. Pull the lamp connectors out of the unit.



d074r396

20. At the rear [A], remove the fusing lamp holder ( $\slashed{x}$  x1).




d074r397

- 21. Use a small rubber band to fasten the ends of the fusing lamps [A] together. This prevents these fusing lamp connectors from catching during removal and re-installation.
- 22. At the front [B], pull the fusing lamps out of the pressure roller.




d074r398

23. Lay the pressure roller fusing lamp on a flat clean surface.




d074r399

24. Remove the front positioning plate [A] ( \*\* x2 M3x6).




25. Remove the rear positioning plate ( \*\* x2 M3x6).



d074r401


- 26. At the rear [A], use a pair of spreaders to remove the C-ring of the pressure roller gear.
- 27. Remove the gear.



d074r402

#### 28. Disconnect:

[A] Rear ring handle ( Fx2 M3x6).






29. Lift and remove the pressure roller, and then place it on a flat clean surface.

#### **Cleaning and Lubrication**

Do these procedures before re-assembling the fusing unit.

Part Name	Interval	Action
Pressure roller thermistor	650K	Clean




d074r407

1. Use a dry cloth to remove toner and paper dust from the sensitive surface of the thermistor.

Part Name	Interval	Action
Pressure Roller Bearing Races (x2)	650K	Lubricate

RTB 128 Details concerning lubricating the bearings




2. Use a small brush to apply FLUOTRIBO MG Grease to the pressure roller races.

RTB 85 Install the pressure roller bearings the correct way around


## **Hot Roller Thermistor (Front)**

1. Fusing unit covers (Pp.433)



d074r413


2. Open the six pairs of clamps on top of the unit ( \*x12).



d074r414


Connection pin [1] blocks removal of the hot roller thermistor.


- 3. Loosen screw [2]. Do not remove it.
- 4. Slide the spring and pin [3] to the rear.



d074r415

- 5. Disconnect the thermistor bracket [1] ( \*\varphi x1, \square x1).
- 6. Remove the thermistor bracket [2].






d074r416

- 7. Disconnect:
  - [1] Bracket ( 🗗 x 1 )
  - [2] Thermistor ( Fx1)

# Hot Roller NC Sensor (Center)

1. Fusing unit covers (Pp.433)




d074r417

- 2. Disconnect the sensor [1] ( Fx2)
- 3. Remove the sensor [2] and set it aside. (It is still connected to the harness.)


## **Heating Roller NC Sensors**

1. Fusing unit covers (Pp.433)



d074r418

2. Open the three pairs of metal clamps (\$\nu\$x6).




d074r419

3. Disconnect:

[A] Heating Roller NC Sensor: Front ( \*\bar{\mathbb{P}} x2)


[B] Heating Roller NC Sensor: Center ( \*F x2)



d074r420


4. Disconnect the upper entrance guide plate [1] ( \*x2).

5. At the center of the loosened guide plate, free the harness [2] and pull out the center heating roller NC sensor [3].



The thermostat harness [1] blocks the harness of the heating roller sensor.

- 6. Disconnect the thermostat harnesses [2] ( \*\bar{x} x2).
- 7. Pull both sensors and the harness free.




d074r422

- 8. Separate both heating roller NC sensors from their brackets.
  - While pressing gently on the front of the sensor [1], open the pawl at [2] (▼x1).
  - Only one side has a pawl. Be sure to push open the arm with the pawl.

## **Heating Roller Rear Thermistor**


1. Fusing unit covers (Pp.433)

- 2. Disconnect the thermistor bracket [1] ( \*\bar{p} x1).
- 3. Remove the bracket and thermistor [2].




d074r424


4. Separate the thermistor and bracket.



d074r425

- 5. At the rear, free the harnesses [1] (🖨 x1).
- 6. Disconnect the upper connector bracket [2] ( \*\*x3).
- 7. With the harnesses still connected, pull the disconnected connector bracket [3] a short distance away from the unit.






d074r426

- 8. Use the tip of a small screwdriver to release the first harness connector [1].
- 9. Press the edge of the connector [2] from below to remove it.





d074r427

- 10. Follow the same procedure to release and remove the 2nd connector.
- 11. Remove the harnesses with the thermistors and NC sensors attached.


1	Heating Roller NC Sensor - Front
2	Heating Roller NC Sensor - Center
3	Hot Roller NC Sensor
4	Heating Roller Thermistor (rear)

5 Hot Roller Thermistor (front)

## **Heating Roller Thermostats**


## **Heating Roller Thermostat (Front)**

1. Fusing unit covers (IPp.433)



d074r428

- 2. At the front, disconnect the thermostat [A] (  $\slash\hspace{-0.6em}P x3$ ).
- 3. Remove the gold strip [B].




d074r429

4. Remove the front hot roller thermostat.


# Heating Roller Thermostat (Center)

1. Fusing unit covers (Pp.433)




d074r430

- 2. Disconnect the gold strip [A] ( \*\*\bigsiz x2).
- 3. Remove the gold strip.



d074r431

- 4. Disconnect the thermistor [A] ( 🗗 x3).
- 5. Remove the gold leaf [B].



d074r432

6. Remove the thermostat.



d074r433


## **MARNING**

- To prevent a fire, never attempt to reset a blown thermostat by manipulating the exposed edges of the black cover with a screwdriver, or by hitting it on a table.
- A thermostat that has been reset manually could fail if the unit overheats and cause a fire.
- Always replace a blown thermostat with a new one.

## Pressure Roller Sensors (Front and Rear)




- You do not need to remove any covers for this procedure.
- 1. Remove the fusing unit from the machine and turn it upside down. (\*\*p.433)



d074r434

- 2. At the rear, disconnect the sensor bracket [1] ( Fx1).
- 3. Raise the sensor bracket [2] with the sensor connected.
- Separate the sensor and bracket (<sup>1</sup>√2x1, <sup>1</sup>√x4).



- 5. At the front, disconnect the sensor bracket [1] ( \*\*\varphi x1).
- 6. Raise the sensor bracket [2] with the sensor connected.
- 7. Separate the sensor and bracket (♠x1, ▼x4).


#### After Installing a New Fusing Unit

- 1. The machine power must be OFF.
- 2. Open both front doors.
- 3. Turn the main power switch ON.
- 4. Enter the SP mode.
- 5. Reset the counter for the replaced unit or parts.
- 6. Close the front doors.
- 7. Wait for about 5 minutes. When you hear an audible beep and see "Ready" displayed on the operation panel, you are ready to continue.
- 8. Exit the SP mode.

## Fusing Motor, Pressure Roller Lift Motor


#### **Preparation**

- 1. The fusing motor and pressure roller lift motor are at the same location behind the TDCU.
- 2. Open both rear boxes ( \*\*\varphi x3). ( \*\*\varphi p.400)



d074r460


3. Remove the center stay [1] and the TDCU [2]. (IPTCDU)



d074r461

4. Remove the cooling air duct [1] ( x1, x4).

## **Fusing Motor**




d074r462

1. Remove the fusing motor [1] ( x2, x2, x4).



d074r463

#### **Pressure Roller Lift Motor**




d074r464

1. Disconnect the motor harness [1] (🖾 x1)



d074r465

- 2. Disconnect the pressure roller lift motor drive assembly:
  - [1] Left ( 🗗 x2)
  - [2] Right ( 🗗 x 1 )



d074r466

3. Remove the pressure roller lift motor assembly.



4. Remove the motor from the drive bracket (  $\slash\hspace{-0.4em}P$  x4).

# **Fusing Cleaning Unit**

## **Fusing Cleaning Unit PM Parts**


	Interval
Fusing Belt Cleaning Unit	
Web Contact Roller	450K
Cleaning Web	450K
Brake	450K


#### Notes

• Web Cleaning Unit. The web cleaning unit can be serviced at 450K. Remove the web cleaning unit and disassemble. Disassembly of the fusing unit is not required.

## Web Supply Roller

1. Fusing cleaning unit ( p.433)






d074r307

2. Remove:

[A] Screw ( \*x1)

3. Remove the cleaning unit cover [C].




d074r308

4. Remove stay 1 [A] ( \*\* x4).




d074r309

5. Remove the 1st bracket [A] ( > x2).




d074r310

6. Remove the 2nd bracket [A] ( \*\* x2).



d074r311

7. At the rear, remove the inner cover [A] ( \*\*x4).



d074r312


8. Remove gears and spacers ( x3, x2).



d074r313

9. Disconnect stay 2 at the rear ( \*x2).





d074r314

10. Disconnect stay 2 [A] at the front and remove it ( \*\* x2 M3x6, M3x8).








d074r315


- 11. Disconnect the side screws ( \*\*\bigsiz x3).
- 12. Disconnect the top screw ( \*x1).
- 13. Remove the front outer bracket [A].






d074r316

14. Remove the front inner bracket [A] ( \*\bar{p} x1).



d074r317

15. At the front [A], disconnect the take-up roller ( $\mathfrak{C}x1$ ).






d074r318

16. At the rear [A], disconnect the take-up roller ( $\mathfrak{O}$  x2,  $\mathfrak{C}$ x1).


d074r319

17. Lift the take-up roller out of the frame.




d074r320

- 18. Disconnect the supply roller at the front [A] ( $\mathbb{C} \times 1$ ).
- 19. Disconnect the supply roller at the rear [B] ( $\mathbb{C} \times 1$ ).




d074r321

- 20. Lift the supply roller out of the frame.
- 21. Separate the supply roller [A] and take-up roller [B] together from the frame.



d074r322

22. Remove the web end actuator (\*\*x1).




**U** Note

• Note carefully how the web is routed from the supply roller [1] under the actuator [2], and over the contact roller [3] to the take-up roller [4]. Make sure the unit is re-assembled this way.

#### Web Contact Roller

1. Fusing cleaning unit ( p.433)



d074r323

- 1. Remove the fusing unit cleaning web supply roller. (See the previous section)
- 2. Release and remove tension springs [A] and [B] at either end of the roller.




d074r324

3. Remove the roller.


## Brake

1. Fusing cleaning unit ( p.433)



d074r307

2. Remove the cleaning unit cover [A] ( > x)2.





d074r325


3. Remove the brake.

## Web End Sensor

The web end sensor is mounted on the left drawer below the front left corner of the fusing unit.

1. Fusing unit ( p.433)

- 2. Locate the web end sensor cover [A] where you just removed the fusing unit.
- 3. Remove the web end sensor cover [B] (  $\nearrow$  x1,  $\[ \implies \]$ x1).



d074r327


4. Disconnect the web end sensor at [A] and [B] ( $\mbox{$\mathbb{G}$} x1$ ,  $\mbox{$\mathbb{T}$} x3$ ).


## Web Motor



d074r765

1. Fusing unit ( p.433)





d074r766

- 2. Disconnect the motor at [A] ( $\square$  x1).
- 3. Disconnect the motor bracket at [B] ( \*\* x2 M3x6).





d074r767

4. Separate the motor and the bracket ( \*\* x2 M3x6).


#### After Replacing or Servicing the Fusing Cleaning Unit

- 1. The machine power must be OFF.
- 2. Open both front doors.
- 3. Turn the main power switch ON.
- 4. Enter the SP mode.
- 5. Reset the counter for the replaced unit or parts.
- 6. Close the front doors.
- 7. Wait for about 5 minutes. When you hear an audible beep and see "Ready" displayed on the operation panel, you are ready to continue.
- 8. Exit the SP mode.

#### 4


# Left Drawer

# **Exit Relay Motor**




d074r753

- 1. Left drawer (1 p.440).
- 2. The shaded area above shows the location of the motor.



d074r754

3. Remove the motor bracket (😂 x1, 🗗 x1, 🏲 x2, 🗘 x1).



d074r755

4. Disconnect the motor harness (🗗 x1).






d074r756


5. Separate the motor and the bracket ( $\mathcal{F}$ x2).

## Invert Exit Motor




d074r757

- 1. Left drawer (1 p.440)
- 2. The shaded area above shows the location of the motor.



- d074r758
- 3. Disconnect the drawer connector to the right of the motor, so that you can move it out of the way:
  - [1] Left (🖨 x 1)
  - [2] Top, bottom ( 🗗 x2)
  - [3] Right (🗟 x 1)



d074r759

4. Disconnect the motor bracket (♠x1, ♣x2, ♠x2, ♠x1)



d074r760

5. Disconnect the motor harness (🖾 x1).




d074r761

6. Separate the motor and the bracket (  $\slash\hspace{-0.4em}P x2$  ).


#### 4

## **Duplex Transport Motor 1**



d074r762

- 1. Left drawer (1 p.440)
- 2. The shaded area above shows the location of the motor.



d074r763

- 3. Disconnect the motor bracket:
  - [1] Right (🕮 x1, 🖨 x1, 🎉 x1)
  - [2] Bottom ( \*\bar{x}2, \*\bar{O} x1)





d074r764


4. Separate the motor and the bracket ( Fx2).


### Web Motor



d074r765

- 1. Fusing unit (**P**p.433)
- 2. The shaded area above shows the location of the motor.






d074r766

3. Disconnect the motor at [1] ( x1).

4. Disconnect the motor bracket at [2] ( Fx1).




d074r767

5. Separate the motor and the bracket ( $\mathcal{F}$ x2).

## **Belt Cooling Fan**

1. Left drawer (**P**p.440)



d074r768

2. Disconnect the fan and the bracket (x1, x1, x1, x1).

3. Separate the fan and the bracket (x2).


#### **Exit Motor**




d074r819

- 1. Open the cooling box door. (\*\*p.400)
- 2. The exit motor is mounted on the back of the main machine behind a cooling duct. The shaded area above shows the location of the motor.

Λ



3. Remove the duct (🕰 x1, 🎉 x3).



d074r821

4. Remove the motor (  $\Re x4$ ).



d074r822

## **Duplex Inverter Motor**

The duplex inverter motor is mounted on the back of the machine.

- 1. Open the cooling box (\*\*p.400)
- 2. Left cover (1 p.402)




d074r826

3. Remove the purged paper tray ( Fx4).



d074r827


4. Disconnect the motor (♣x1).



d074r828

5. At the rear, disconnect the motor ( x1, x3).





d074r829

- 6. At the side, remove the motor [1].
- 7. Remove the timing belt [2] ( $\mathcal{O}_{\times 1}$ ).

8. Separate the motor and motor bracket ( Fx2).

#### **Exit Unit Entrance Sensor**

1. Left drawer unit (Pp.440)




d074r770

- 2. Remove the bracket [1] (  $\mathcal{F}$  x2).
- 3. Remove the sensor [2] (♠x1,♠ x1, x3).

#### **Exit JG Sensor**

1. Left drawer unit (IPp.440)


4




- 2. Disconnect the sensor bracket [1] ( \*\*x1, \*\hat{\text{\$\delta}}x1).
- 3. Disconnect the sensor [2] (☐ x1, ▼x3).

## **Duplex Transport Sensor 1**


1. Pull out the left drawer until it stops and remove its front cover.





d074r772


2. Disconnect the sensor (♠x1, ♣x1, ♣x1).



3. Pull the sensor bracket out of the left drawer unit and disconnect the sensor ( $\mathfrak{C} \times 1, \mathfrak{T} \times 3$ ).

### **Duplex Transport Sensor 2**

1. Fusing unit (**P**p.433)



2. Disconnect the sensor bracket and remove the sensor ( ♣x1,♣x1,♣x1,♣x1,, x3).

## **Duplex Transport Sensor 3**

1. Fusing unit (**IP**p.433)




d074r775

2. Disconnect the sensor bracket and remove the sensor ( ♠x1,♠x1,♥x3).

### **Exit Relay Sensor**

1. Open the front doors and pull out the left tray until it stops.



d074r776

- 2. Open the exit guide [1].
- 3. Disconnect the sensor bracket [2] and remove the sensor (  $\mathcal{F}$  x1,  $\mathcal{T}$  x3).

## **Purge Relay Sensor**

1. Open the front doors and pull out the left tray until it stops.




2. Disconnect the sensor bracket and remove the sensor ( ₱x1,₺ x1, x3).

## **Duplex Invert Sensor**

1. Open the front doors and pull out the left tray until it stops.






2. Under the left drawer unit, disconnect the sensor bracket and sensor ( ♠x1,♠x1,♥ x1, ▼x3)

#### **Exit Sensor**

1. Open the front doors and pull out the left tray until it stops.




d074r779

- 2. Raise the transport cover.
- 3. Disconnect the sensor bracket and remove the sensor ( ♠x1,♠x1,♥x3).

#### Web End Sensor

1. Fusing unit ( p.433)





d074r780

2. Disconnect the sensor bracket and remove the sensor ( \*\varphi x1, \*\varphi x3).

## **Purged Paper Sensor**

- 1. Left cover ( p.402)
- 2. Remove the lower left inner cover ( Fx7).



d074r823

3. Remove the base plate ( Fx7).



d074r824

4. Disconnect the sensor bracket ( Fx1).




d074r825

5. Remove the sensor ( \*\varksigma 1, \*\varksigma x 1).

#### 4

# **Duplex Motors and Rollers**

The duplex path is split between the left drawer and the right drawer. Identify the component that requires servicing or replacement, then go to the appropriate section of the manual.



d074r977

	Left Drawer		Right Drawer
1	Duplex Invert Motor	6	Duplex Transport Roller 3
2	Duplex Invert Rollers	7	Duplex Transport Roller 4
3	Duplex Transport Motor 1	8	Duplex Transport Motor 2
4	Duplex Transport Roller 1	9	Duplex Transport Roller 5
5	Duplex Transport Roller 2	10	Duplex Transport Roller 6

- For a duplex component in the left drawer, see p.440 "Removing the Left Drawer".
- For a duplex component in the right drawer, see p.408 "Removing the Right Drawer"

# Main Boards, HDD Units

### CB Power Pack (CK)



d074r550

- 1. Open the rear boxes ( \*\* x6). (\*\*\* p.400)
- 2. The CB power pack (CK) is located at [1].



d074r551

- 3. Under the power pack [1], open the clamps and free the harnesses (🕮 x5).
- 4. Disconnect the power pack bracket [2] ( Fx2).




d074r552

- 5. Slide the bracket [1] slightly to the left and lower it.
- 6. Disconnect the power pack [2] (♣x6,₺\$x4)

4





d074r553

7. Place the bracket on a flat surface and remove the power pack ( Fx6).

#### Re-installation




d074r553a



• After re-installing the power pack, check the motor connections below and make sure that they are not loose or disconnected.



- 1. Open the rear boxes ( \*\* x6). (\*\*\* p.400)
- 2. The CB power pack (YM) is located at [1].



d074r555

- 3. Under the power pack [1], open the clamps and free the harnesses (x3).
- 4. Disconnect the power pack bracket [2] ( Fx2).



d074r556

- 5. Slide the bracket [1] slightly to the left and lower it.
- 6. Disconnect the power pack [2] (♣x6,♬ x4).



d074r557

7. Remove the power pack bracket and lay it on a flat surface.





d074r558

8. Remove the power pack ( Fx6).

#### Re-installation



d074r559



• After re-installing the power pack, check the motor connections below and make sure that they are not loose or disconnected.




d074r560

- 1. Open the rear boxes ( \*\* x6). (\*\*\* x6).
- 2. The potential sensor power pack is located at [1].




d074r561

- 3. Under the power pack [1], open the clamps and free the harnesses ( $\Re x3$ ).
- 4. Disconnect the power pack bracket [2] ( \*\* x2).



d074r562

- 5. Slide the bracket [1] slightly to the left and lower it.
- 6. Disconnect the power pack [2] (🖾 x3).



d074r563

7. Remove the power pack bracket and lay it on a flat surface.






d074r564

8. Remove the power pack ( Fx6).

#### Re-installation



d074r565

#### 


• After re-installing the power pack, check the motor connection below and make sure that it is not loose or disconnected.

#### **AC Drive Board**



d074r566


- 1. Open the rear boxes ( \*\bar{p} x6). ( \bar{p} .400)
- 2. The AC drive board is located at [1].





d074r567


3. Disconnect the board (🖨 x6, 📬 x7).



d074r568

4. Disconnect the board bracket and remove it ( Fx4).






d074r569


5. Lay the bracket on a flat surface and remove the board ( Fx8).

## PSU 2, PSU 2 Fans



d074r570


- 1. Open the rear boxes ( \*\* x6). (\*\*\* x6).
- 2. PSU 2 is located at [1].
- 3. Remove the center stay [2] ( Fx3).



d074r571

**U** Note


• The AC relay board [1] can be removed without removing PSU 2 (  $\slash\hspace{-0.4em}P$  x3,  $\slash\hspace{-0.4em}T$  x2).



d074r572

4. Disconnect the board (♠x6,➪x6).

- 5. Disconnect the bracket and remove it ( \*\mathbb{P} x4).
- 6. Lay the bracket on a flat surface.



- 7. Disconnect the AC relay board [1] ( \*\*\varphi x3, \*\*\varphi x1).
- 8. Slide the board to the right and remove it.




9. Remove the board ( 🗗 x 10).

#### **PSU 2 Fans**



d074r576

1. Remove the fans (🖾 x1, 🎉 x2 each).



d074r577

2. Remove the shield plate ( Fx4).



- There are no fuses under the shield plate.
- If you are replacing the board, be sure to install this plate over the new board.



d074r578


3. There are four fuses on the left [1] and two fuses on the right [2].

## Relay Board (RYB)




d074r579

- 1. Open the rear boxes ( 🗗 x6). (🏲 p.400)
- 2. The relay board is located at [1].



d074r580

3. Disconnect the board (♠x7,🚅 x19)




d074r581

- 4. Disconnect the bracket and remove it ( \*\bar{x} x4).
- 5. Lay the bracket on a flat surface.



6. Remove the board ( 🗗 x6).


## TDCU



d074r583

- 1. Open the rear boxes ( \*\* x6). (\*\*\* x6).
- 2. The TDCU is located at [1].






4. Disconnect the board (\$\text{\$\text{\$\text{\$\text{\$\geq}}\$}\$x2,**\$\text{\$\text{\$\geq}\$**} x16).



d074r585

5. Disconnect the bracket ( 🗗 x4).






d074r586

6. Lower the board slowly until it stops.


4



- Do not try to remove the bracket and board.
- Connector [1] is attached to the back of the board and must be disconnected before the bracket can be removed.



- d074r587
- 7. On the back of the board, pull out the harness connector [1].
- 8. Disconnect the harness from the back of the board [2] ( $\sqrt[3]{x}$ 2, $\sqrt[4]{x}$ 1).



d074r588

9. Remove the bracket and lay it on a flat surface.



d074r589

10. Remove the board ( Fx6).




d074r590

- 1. Open the controller box ( Fx6). (Fp.400)
- 2. Remove the controller box covers. (\*\*\*p.404)
- 3. PSU 1 is at the bottom of the controller box.



d074r591

4. Disconnect the board (🖾 x10).




d074r592

- 5. Disconnect the bracket:
  - [1] Left side ( 🔊 x2)
  - [2] Right side ( \*\* x2)




d074r593

6. Remove the bracket and lay it on a flat surface.




d074r594

7. Remove the three bridge harnesses (🖾 x6).



d074r595

8. Remove the right board ( \*\mathbb{P} x6).






d074r596

9. Remove the left board ( 🗗 x9).

# Fans



d074r597

1. At the base of the controller box, remove the fans ( ) x1, x2 each).

# IOB/BCU

# Lowering the IOB




d074r598

- 1. Open the rear boxes ( Fx6). ( p.400)
- 2. The IOB and BCU are located at [1].




• The BCU is not visible. It is mounted on the back of the IOB.



d074r599

3. To the right of the IOB, disconnect the TDCU [1] ( $\Re x3$ ).

4



d074r600

4. Disconnect the IOB (♣x9,🖼 x29).



d074r601

5. Lower the IOB [1] to the horizontal position so that you can see the BCU [2].



 $\bullet\,\,$  This platform is stable enough to allow removal of the BCU.

# BCU



d074r602

- 1. Disconnect harness [1] ( \*\varphi x1, \*\varphi x1).
- 2. Disconnect the other harnesses (🗗 x4).
- 3. Disconnect the BCU ( \*x4).






d074r603

4. Remove the BCU.

#### Removing the IOB






d074r604

1. Disconnect harnesses [1] on the back of the IOB where the BCU was removed (😂 x3).

4

2. Remove the bracket and lay it on a flat surface.




d074r605

3. Remove the IOB ( \*\bar{x} x8).

# Controller Board (GW), NVRAM, Controller Board Fan

- 1. Open the controller box ( Fx6). (Fp.400)
- 2. Controller box covers (Pp.404)



d074r606

- 3. The controller board is behind the slide cover.
- 4. **Remove** screws [1] and [2] ( \*\mathbb{P} x2).
- 5. Loosen the other screws ( \*x10). You do not need to remove all of these screws.



d074r607

6. Slide the cover to the left and remove it.





d074r608

- 7. Disconnect the HDD unit at [1] (🖨 x3).
- 8. On the side of the controller box, disconnect the controller board bracket [2] (  $\mathcal{F}$  x3).



d074r609

9. Remove the bracket and lay it on a flat surface.




d074r609b

10. Remove the board [1] ( \*\bar{p} x6).

#### NVRAM

RTB 92 Before/after replacing the NVRAM



d074r609a

1. Press in the sides of the NVRAM and remove it.

#### Controller Board Fan



d074r610

Remove the fan (□ x1, x2).

# IPU

1. Follow the previous procedure to remove the controller board.




- You do not need to pull out the controller board.
- Just pull it out far enough to separate the controller board and IPU.





d074r611

2. Disconnect and remove the HDD bracket ( Fx4).



d074r612

- 3. On the other side of the controller box, remove shield plate [1] (  $\mathcal{F}$  x2).
- 4. Disconnect the IPU [2] (🗂 x12).




d074r613

5. On the other side of the controller box, remove the IPU ( x2, x8).


#### **HDD Units**

- 1. Open the controller box ( Fx6). (Fp.400)
- 2. Controller box covers (\*\*p.404)



d074r606

- 3. The HDD unit is behind the slide cover.
- 4. **Remove** screws [1] and [2] ( **\***x2).
- 5. Loosen the other screws (  $\mathcal{F}$  x10). You do not need to remove all of these screws.



d074r607a

- 6. Slide the cover [1] to the left and remove it.
- 7. Disconnect the HDD unit [2] ( x3).





d074r615

8. Remove the HDD bracket and lay it on a flat surface ( Fx4).



d074r616

9. Disconnect the HDD (🖼 x2).



d074r617

10. Disconnect the HDD from the base bracket ( \*\varPx4).



d074r618

11. Disconnect the HDD from the floating bracket ( \*\* x4).



• Do not remove the four rubber grommets from the screw holes of the bracket.



d074r619

#### Re-installation



d074r620


# 

- When you re-attach the HDD unit bracket, do not tighten the four screws.
- These screws must remain up so the slide cover can be re-installed. Tighten these four screws after the slide cover has been re-attached.

# Controller Box Fans

- 1. Open the controller box ( Fx6). (Pp.400)
- 2. Controller box covers. (Pp.404)


#### Left Corner Fan



d074r621

- 1. Disconnect the fan [1] on the corner ( \*\bar{x} x2).
- 2. Disconnect the fan at the rear and remove it ( $\mathfrak{L}^{\bullet}$  x1).

#### **Top Fans**



d074r622


1. Disconnect the top of the controller box ( \*\bar{x}6).



• At the corners [1] and [2], note that the cover is tucked behind the vertical frame. The cover must be re-attached in the same way.


d074r623

- 2. Disconnect the left end of the cover [1] ( \*\*x1).
- 3. Disconnect the right end of the cover [2] ( \*\*x2).



d074r624

4. Disconnect the vertical connector [1] ( x1).



d074r625

- 5. Remove the vertical fan [1] ( \*\* x2).
- 6. Remove the horizontal fan [2] (🖼 x1, 🎉 x2).

4


# **Fans and Filters**

# Before You Refer to This Section

The removal procedures for the following fans are described in other sections of the Replacement and Adjustment section of this manual.

Fan	See
CIS Fan	(IPp.408 "Removing the Right Drawer")
Controller Board Fan	(IPp.808 "Main Boards, HDD Units")
Controller Box Drive Exhaust Fan	
Controller Box Exhaust Fan 1 (Top)	
Controller Box Exhaust Fan 2 (Top)	
Controller Box Intake Fan 1 (Bottom)	
Controller Box Intake Fan 2 (Bottom)	
Development Unit Cooling Fan 1	(PCDU)")
Development Unit Cooling Fan 2	
Development Unit Cooling Fan 3	
ID/MUSIC Sensor Fan	(ITB) Unit")
ITB Belt Cleaning Cooling Fan	(IPp.440 "Removing the Left Drawer")
Lamp Regulator Cooling Fan	(Pp.480 "Scanner Unit")
PSU 2 Cooling Fan 1	( <b>P</b> p.816 "PSU 2, PSU 2 Fans")
PSU 2 Cooling Fan 1	( <b>P</b> p.816 "PSU 2, PSU 2 Fans")
PSU 2 Intake Fans (x2)	(IPp.808 "Main Boards, HDD Units")
PTB Fan - Center	
PTB Fan - Front	
PTB Fan - Rear	


# Fan Layout



1	Pressure Roller Fan
2	ITB Belt Cooling Fan
3	PTB Fan - Front
4	PTB Fan - Center
5	PTB Fan - Rear


4

# Inside the Main Machine



1	ITB Intake Fan	12	Duplex Exhaust Fan - Rear
2	Used Toner Intake Fan	13	Drive Exhaust Fan
3	Ozone Exhaust Fan (K)	14	Paper Cooling Intake Fan
4	Ozone Exhaust Fan (C)	15	Paper Cooling Exhaust Fan
5	Ozone Exhaust Fan (M)	16	Fusing Unit Transport Exhaust Fan
6	Ozone Exhaust Fan (Y)	17	Fusing Exit Exhaust Fan
7	Ozone Collection Fan	18	Used Toner Exhaust Fan
8	Toner Supply Cooling Fan	19	Heat Sink Exhaust Fan
9	Paper Exit Exhaust Fan - Front	20	Belt Cleaning Exhaust Fan
10	Paper Exit Exhaust Fan - Rear	21	Heat Sink Intake Fan
11	Duplex Exhaust Fan - Front		






1	Controller Box Exhaust Fan 1	7	Development Unit Cooling Fan 2
2	Controller Box Exhaust Fan 2	8	Development Unit Cooling Fan 3
3	Cooling Box Ozone Exhaust Fan	9	Controller Box Intake Fan 2
4	Cooling Box Emission Exhaust Fan	10	Controller Box Intake Fan 1
5	Cooling Box Heat Fan	11	Controller Box Exhaust Fan
6	Development Unit Cooling Fan 1		

#### **Ducts and Fans Back of Main Machine**


The removal procedures for the following fans are described in this section.



This drawing illustrates the back of the machine with the right and left covers removed and the rear boxes open. Most of these fans are not visible because they are inside the ducts.

1	Ozone Exhaust Fan (K)	13	Belt Cleaning Exhaust Fan
2	Ozone Exhaust Fan (C)	14	Used Toner Exhaust Fan
3	Ozone Exhaust Fan (M)	15	Paper Cooling Intake Fan
4	Ozone Exhaust Fan (Y)	16	Fusing Unit Transport Exhaust Fan
5	Ozone Collection Fan	17	Paper Cooling Exhaust Fan
6	Toner Supply Cooling Fan	18	Duplex Exhaust Fan - Front
7	Paper Exit Exhaust Fan - Front	19	Duplex Exhaust Fan - Rear
8	Paper Exit Exhaust Fan - Rear	20	ITB Intake Fan
9	Drive Exhaust Fan	21	Used Toner Exhaust Fan
10	Heat Sink Intake Fan	22	PSU 2 Cooling Fan 1
11	Heat Sink Exhaust Fan	23	PSU 2 Cooling Fan 2
12	Fusing Exit Exhaust Fan		

#### **Ducts: Cooling Box Fans**




This drawing illustrates the fans inside the cooling box with all covers removed.

24	Cooling Box Ozone Exhaust Fan
25	Cooling Box Emission Exhaust Fan
26	Cooling Box Heat Fan

# Ozone Exhaust Fans (YMCK), Ozone Collection Fan

- 1. Open the rear boxes ( \*\*\varphi(x3) ( \*\*\varphi(x400))
- 2. Remove the center stay ( Fx3).

4



d074r831

- 3. Disconnect the horizontal duct:
  - [1] Left ( 🗗 x 1)
  - [2] Center ( 🗗 x 1)
  - [3] Right (🖾 x1, 🌶 x2)



d074r832

4. Remove the duct and lay it on a flat surface.


#### Ozone Exhaust Fans



• The following procedure is the same for all four ozone exhaust fans (YMCK) mounted inside the duct.


d074r833

- 1. Disconnect the fan [1] (♣x1,♬x1).
- 2. Disconnect the fan bracket [2] ( 🗗 x2).



d074r834


3. Remove the fan [1] from the bracket (  $\slash\hspace{-0.4em}P x2$  ).



d074r835


4. Remove the ozone exhaust fan.

#### Ozone Collection Fan



d074r836


- 1. On the end of the duct, disconnect the fan bracket [1] (  $\mathcal{F}$  x2).
- 2. Turn over the duct and disconnect harness [2] (🖨 x 1, 🞜 x 1).



d074r837

3. Remove the fan.


# **Toner Supply Cooling Fan**






d074r838

- 1. Open the cooling box (\*\*p.400)
- 2. Disconnect the duct bracket (  $\mathcal{F}$  x 1).




3. Disconnect the duct at the top [1] and bottom [2] (  $\mathcal{F}$  x2).




d074r840

4. Disconnect the fan and remove the duct (  $\mathcal{F}$ x1).




d074r841

5. Release all the lock tabs around the seam where the top and bottom of the duct are connected.



d074r842

7. Remove the fan and bracket.



d074r843


8. Remove the fan ( 🗗 x2).

# Heat Sink Intake Fan

- 1. Open the rear boxes ( \*\* x3) (\*\*\* p.400)
- 2. Remove the center stay ( 🗗 x3).


4






d074r844

3. Disconnect the duct bracket and disconnect the fan (  $Fx1, \square x1$ ).



d074r845


4. Remove the duct and then remove the fan (  $\mathcal{F}$  x2).



d074r846


# Heat Sink Exhaust Fan

- 1. Open the rear boxes ( \*\* x3) (\*\*\* p.400)
- 2. Remove the center stay ( \*\bar{x} x3).



d074r847


3. Disconnect the duct, fan harness, and fan ( $x = x_1, x_2, x_1, x_2$ ).



d074r848

4. Remove the duct and lay it on a flat surface.

4



d074r849


- 5. Release all the lock tabs around the seam where the top and bottom of the duct are connected.
- 6. Raise the top of the duct [1].
- 7. Remove the fan and bracket assembly [2] and then disconnect the fan [3] (  $\mathcal{F}$  x2).



d074r850


# Fusing Exit Exhaust Fan

1. Open the rear boxes ( \*\* x3) (\*\*\* p.400)




d074r851

2. Free the harnesses (🖨 x 1).




d074r852

- 3. Disconnect the fan [1] (📬 x1).
- 4. Disconnect the fan bracket [2] ( 🗗 x1).



d074r853

- 5. Free the harness at the left (🗟 x 1).
- 6. Pull the fan and bracket assembly straight out to remove it.



d074r854

# 7. Remove the fan from the bracket ( $\slash\hspace{-0.6em}P x2$ ).



d074r855



d074r856

- 1. Remove the left cover of the main machine ( $\mathcal{F}x7$ ).
- 2. Open the cooling box. (\*\*p.400)



d074r857

3. Behind the cooling box, disconnect the fan (\$\sigma\$x1).





# 4. Remove the fan ( 🗗 x2).




d074r859




d074r860

- 1. Open the rear boxes ( \*x3) (\*p.400)
- 2. Remove the center stay ( Fx3).



d074r861

3. On the left, disconnect the duct bracket and fan (  $\mbox{\ensuremath{\not\sim}} x2,\mbox{\ensuremath{\not\sim}} x1).$ 




d074r862

4. On the right, disconnect the duct bracket and remove the duct (  $\mathcal{F}$  x2).




d074r863

5. Lay the duct on a flat surface.



d074r864

- 6. Release all the lock tabs around the seam where the top and bottom of the duct are connected.
- 7. Separate the top and bottom.



d074r865


8. Remove the fan bracket and fan.



d074r866

9. Remove the fan ( 🗗 x2).

# Stray Toner Exhaust Fan




d074r867

1. Open the cooling box (\*\*p.400)




d074r868

2. Disconnect the fan and duct bracket ( $\square$  x1,  $\nearrow$ x1).



d074r869


3. Free harness [1] (♣x1).



d074r870

4. Release all the lock tabs [2] around the seam where the top and bottom of the duct are connected.


6. Remove the bracket and fan.



d074r871


7. Remove the fan ( 🗗 x2).

# Paper Cooling Intake Fan




d074r872

1. Open the cooling box (\*\*p.400).



d074r873


2. Disconnect the fan and duct, and then remove the duct ( $x = x_1, x = x_2$ ).



d074r874


[2] Right ( \*\bar{\mathbb{P}} \times 2).

[3] Duct



d074r875


- 4. Release all the lock tabs [1] around the seam where the top and bottom of the duct are connected.
- 5. Open the duct [2].



d074r876

6. Remove the bracket and fan, and then remove the fan (  $\mathcal{F}$  x2).

# Paper Cooling Exhaust Fan




d074r877

1. Open the cooling box (\*\*p.400).




d074r878

2. Disconnect and remove the fan (  $\mathcal{F}$  x2,  $\mathfrak{A}$ x1,  $\mathfrak{U}$ x1)




d074r879

1. Open the cooling box (\*\*p.400).



d074r880

2. Disconnect the fan and bracket, and then remove the bracket ( x1, x1).



d074r881

3. Free the harness and then remove the fan ((x)x2).



d074r882

# **Duplex Exhaust Fans**

## Duplex Exhaust Fan - Rear




- 1. Open the cooling box (\*\*p.400).
- 2. Remove the left cover of the main machine ( Fx7).



d074r884

3. Behind the cooling box, disconnect the fan ( $\mathfrak{C}$  x1).




d074r885

## 4. Remove the fan ( 🗗 x2).




d074r886

## **Duplex Exhaust Fan - Front**



d074r887

1. Remove the left cover of the main machine ( $\mathcal{F}$ x7).






d074r888

2. Disconnect and remove the fan (🗗 x1, 🖨 x2, 🎉 x2).

## Used Toner Intake Fan




d074r890



d074r891

- 2. Disconnect the duct bracket [1] ( Fx2).
- 3. Disconnect the fan [2] (♠x1,♬ x1).




d074r892

4. Remove the duct.



d074r893


5. Release all the lock tabs around the seam where the top and bottom of the duct are connected and open the duct.



d074r894

6. Remove the bracket and fan.





d074r895

7. Remove the fan ( 🗗 x2).

## ITB Intake Fan




d074r896

- 1. Right cover (**p**.406)
- 2. Open the controller box. (IPp.400)



d074r897

- 3. Lower the IOB [1] (\*\*p.830).
- 4. Disconnect the fan [2] (🗗 x1).



d074r898

5. On the right side of the machine, disconnect and remove the fan bracket ( Px1).





d074r899

6. Remove the fan ( 🗗 x2).

#### Δ

# **Cooling Box Fans**

## **Preparation**




d074r900

Remove the cooling box covers. (\*\*p.402)

1. Remove the collar ( Fx4).




d074r901



d074r902

3. Remove the lower fan cover ( \*\* x8).



d074r903

4. Remove the upper fan cover ( \*x5).



d074r903a

There are three duct fans in the cooling box.

1	Cooling Box Ozone Exhaust Fan
2	Cooling Box Emission Exhaust Fan
3	Cooling Box Heat Fan

## Cooling Box Emission Exhaust Fan



d074r903b

1. The fan is behind the bottom "L" cover.





d074r904

2. Disconnect and remove the fan (🕮 x1, 🔊 x2).



d074r905

## **Cooling Box Heat Fan**



d074r903c

1. The fan is behind the bottom "L" cover.






d074r906

2. Disconnect and remove the fan (🕮 x1, 🖋 x2).



d074r907

## Cooling Box Ozone Exhaust Fan




d074r910

- 1. Remove the cover lock screw and remove the cover.
- 2. Remove the filters and ozone filter.



d074r903d


3. The fan is behind the top cover.






d074r908

- 4. Disconnect the fan bracket [1] ( \*\* x2).
- 5. Disconnect the fan [2] (🛍 x1).




d074r909

## Ozone Filter, Air Filters



d074r910

- 1. Open the cooling box (\*\*p.400).
- 2. Remove the cover lock screw and remove the cover.
- 3. Remove the four air filters.




d074r911

4. Remove the ozone filter [1].

5. Vacuum clean the air filters.


## Air Filter



d074r912

- 1. Open the cooling box (\*\*p.400).
- 2. Remove the cover lock screw and remove the cover [1].
- 3. Remove the filter [2].
- 4. Vacuum clean the filter.


## **Control Box Filter**



d074r913

- 1. At the right bottom corner of the controller box, remove the intake filter cover [1].
- 2. Vacuum clean the filter [2].

## ITB Area Filters



d074r889


- 1. Right cover (**p**.406)
- 2. Vacuum clean both filters.

# Paper Exit Fans




d074r938

1. Left cover (1 p.402)



d0074r935

- 2. On **both sides** of the fan plate:
  - Depress the sides of the connector [1] and push it back through the plate.
  - Disconnect harness [2] (🖨 x 1).
  - Disconnect fan harness [3] (🖼 x1).



d0074r936

- 3. Disconnect the fan plate ( Fx4).
- 4. Remove the plate and fans together.



d0074r937

# Firmware Update

#### Before You Begin...

Always obey these rules when handling and using SD cards:

- Never connect or remove an SD card with the machine on.
- Never turn the power off while the machine is downloading data from an SD card.
- The SD card is a precision item. Use it carefully. Do not keep the card in a location where there is high temperature, high humidity, or light from the sun.
- Handle SD cards carefully to avoid bending, scratching, or dropping them.
- If a power failure occurs during the firmware update, turn the machine power off/on without removing the SD card. The firmware update procedure should start again.

#### Firmware Update Procedure


- 1. Obtain the System SD card.
- 2. Disconnect the network cable and other interface cables. This prevents outside interference caused by data transfers to the machine while the software is being uploaded.
- 3. Turn off the machine.



- Shut down the Fiery controller first.
- 4. Remove the SD card slot cover ( F x 1).
- 5. Insert the SD card into Slot 2 (lower slot).
- 6. Turn on the main switch.

You will see "Please Wait" then "Preparing to start firmware update."

The first screen appears after about 90 sec.



d014r912

- 7. Check the notations to the right.
  - "ROM" tells you the module number and version of the currently installed software.

- "NEW" tells you the module number and version of software on the SD card in Slot 2.
- 8. Touch "Engine" or "OpePanel.xxx". The item that you select changes to dark gray.




- You can select "Engine" and one "OpePanel" selection if you want to update both.
- 9. Touch [Update] or push [#] on the 10-key pad to start the update.

While the Update Is in Progress


- Remain with the machine. Do not leave it unattended.
- The [Start] key flashes RED during firmware update, and then lights GREEN when the update
  is finished.
- When the [Start] key LED starts flashing rapidly, this means the update is almost finished.
- Never switch the machine off while the [Start] key is flashing RED.
- If the machine is switched off or accidentally unplugged before the update is finished, do not remove the SD card. Just switch the machine on again. The firmware update should restart automatically. If the firmware update does not recover, obtain a new System SD card.

The following screen sequence appears after selecting one "OpePanel" selected for update.

#### **Operation Panel Update**



- The blocks of the progress bar fill as the update is done.
- The update requires about 9 to 10 minutes.




• When you see the 'update completed' message, the firmware update is complete.

#### **Engine Update**



d014r913

- The middle bar tells you the name of the item that you are updating.
- The bottom bar shows the progress of the update procedure.



d014r914

- The update is complete when you see the "Update done" message.
- The update requires about xx minutes.
- 1. When you see the update completed message, turn the machine off.
- 2. Remove the SD card from the SD card slot.
- 3. Switch the machine on.
- 4. This completes the update procedure.

## Verifying the Firmware Update

This "Verify" procedure is not necessary but is strongly recommended.

- 1. With the System SD card in Slot 2, turn the main power switch on. You see "Please Wait". The first screen appears after about 10 sec.
- 2. Touch "Firmware".
- 3. Select the items that you updated, and then push the [Verify] button.
- 4. If there are no errors the machine displays the "Verify done" message for each updated item. Go to the next step.

-or-

If you see "Verify Error" in the first bar on the screen, then you must do the procedure again for the module shown in the bottom bar. For more details, see "Errors During Firmware Update" below.

- 5. After the firmware is correctly updated, turn the main power switch off.
- 6. Push the System SD card in a small distance to release it, then pull it out of the slot.
- 7. Turn the main power switch on, and confirm that the machine operates correctly.

#### **Errors During Firmware Update**

If an error occurs during a download, an error message will be shown in the first line. The error code consists of the letter "E" and a number ("E20", for example).

#### Error Message Table

No.	Meaning	Solution
20	Cannot map logical address	Make sure the SD card is installed correctly, or use a different SD card.
21	Cannot access memory	HDD connection not correct, or replace hard disk.
22	Cannot decompress compressed data	The ROM data on the SD card is not correct, or data is damaged.
23	Error occurred when ROM update program started	Controller program defective. If the second attempt fails, replace the controller board.
24	SD card access error	Make sure the SD card is installed correctly, or use a different SD card.
30	No HDD available for stamp data download	HDD connection not correct or replace hard disks.
31	Data incorrect for continuous download	Install the SD card with the remaining data necessary for the download, then re-start the procedure.
32	Data incorrect after download interrupted	Do the recovery procedure for the module, then repeat the installation procedure.
33	Incorrect SD card version	The ROM data on the SD card is not correct, or data is damaged.
34	Module mismatch - Correct module is not on the SD card	The data on the SD is not correct. Get the correct data (Japan, Overseas, OEM, etc.) then install again.
35	Module mismatch – Module on SD card is not for this machine	SD update data is not correct. The data on the SD card is for a different machine. Get the correct data then install again.

No.	Meaning	Solution
36	Cannot write module – Cause other than E34, E35	SD update data is not correct. The data on the SD card is for a different machine. Get the correct data then install again.
40	Engine module download failed	Replace the data for the module on the SD card and try again, or replace the BCU board.
42	Operation panel module download failed	Replace the data for the module on the SD card and try again, or replace the LCDC.
43	Stamp data module download failed	Replace the data for the module on the SD card and try again, or replace the hard disk.
44	Controller module download failed	Replace the data for the module on the SD card and tray again, or replace the controller board.
50	Electronic confirmation check failed	SD update data is not correct. The data on the SD card is for a different machine. Get the correct data then install again.

## Fiery Controller System Update

#### **Fiery System Installation**

System and user software are provided on the following media:

- System Software DVD
- User Software DVD

The System and User Software DVDs include the system software, fonts, and user software.

You install system and user software when you:

- Remedy an error.
- Replace the HDD.
- Upgrade to a more recent version of the software.

Software installation takes approximately one hour (not including the time required to configure or restore Setup).

#### To Install System and User Software



Notify the network administrator at the customer site that some archived jobs may no longer print
after you install an updated version of system software.

- 1. If you have not yet done so, consider backing up configuration settings. The settings are deleted when you install system and user software (see "Backing up and restoring the Fiery Setup Configuration" in the "Installation and Service Guide").
- 2. Allow the network administrator the opportunity to print the Job Log. Also, print the following (if possible):
  - Configuration page—lists any installed options and records the customer's current Setup configuration.
  - Font List—lists the fonts currently on the HDD. In addition to the fonts provided in system software, the customer may have installed other fonts.
- Remove all USB storage devices and dongles (if any) that may be connected to any Fiery controller USB ports.



- The system will hang up if USB storage devices or dongles are connected to Fiery controller USB ports during software installation.
- 4. Insert the System Software DVD into the DVD/CD-RW drive.



- If you installed a new HDD, power on the system, insert the System Software DVD, allow the system to boot, and then proceed to step 6.
- 5. From the Fiery Control Panel or the copier/printer display panel (or the Start menu, if a monitor is connected), reboot the Fiery controller.

Allow the system to shut down and reboot. Do not push any buttons during this time.

- 6. At the message "All data will be deleted?", select Yes.
- 7. When prompted, select a language.

Wait as messages display describing the installation process.



- This installation segment takes approximately 12 minutes.
- 8. At the message "System Software is copied to the system. Remove media and select OK to reboot," remove the System Software DVD, and then select OK.

The Fiery controller reboots several times and status messages display as the installation process continues.



- This installation segment takes approximately 12 minutes.
- 9. At the message "Please insert User Software to continue installation", insert the User Software DVD into the DVD/CD-RW drive.



• If a monitor is connected (FACI), click OK to continue.

During this process, the following installations are performed:

 The entire contents of the System Software DVD are copied to a shared folder on the Fiery controller HDD, in e:\efi\user\_sw.

After installation, when the Fiery controller is connected to the customer's network, users can access the user software in the shared folder and install it onto client computers.

The message "Copying User Software to Fiery shared folder. Please wait" and other messages display describing the user software installation process.



- This installation segment takes approximately 30 minutes.
- At the message "Setup finished. Remove CD/DVD. Press OK to reboot," remove the User Software DVD and select OK.

If the User Software DVD does not eject automatically, wait for the system to boot completely and the following logo screen to display on the Fiery controller Control Panel, then access the Functions menu on the Fiery controller Control Panel and select Eject CD/DVD to remove the User Software DVD.



d095s504

The drawing above indicates that the Fiery controller is idle.



- This installation segment takes approximately 5 minutes.
- 11. If user documentation was previously resident on the Fiery controller, remind the site administrator that user documentation files may be reinstalled to the Fiery controller shared folder from the User Documentation CD as follows:
  - If the Fiery controller is equipped with FACI:
    - Insert the User Documentation CD in the Fiery controller DVD drive.
    - Browse to the desired language folder on the CD.
    - Select and copy the files you want to place in the shared folder on the Fiery controller.

- Browse to the shared file location: e:\efi\user\_software\Documentation and paste the documentation files.
- From a client computer on the same network as the Fiery controller (assumes that the Fiery controller is powered on, has an IP address, and is accessible on the customer's network):
  - Insert the User Documentation CD in the CD drive of the client computer.
  - Browse to the desired language folder on the CD.
  - Open a web browser and type two back-slashes followed by the Fiery controller IP address.

For example: \\xx.xx.xx.x, where xx.xx.xx.x is the IP address of the Fiery controller.

- Open the User-Docs folder.
- Copy and paste the documentation files into the folder.
- 12. Use the System Updates feature to install required software updates that may be available for the Fiery controller that would have been deleted when you installed system software (see "Updating the Fiery Controller" described below).
- 13. Reconnect any USB storage devices or dongles that you may have removed earlier.
- 14. Input the settings from the Configuration page that you printed earlier, or restore settings if they were backed up prior to system software installation.
  - If a backup file of the configuration settings exists, restore it after the network configuration is completed (see "Backing up and restoring the Fiery Setup Configuration" in the "Installation and Service Guide").
  - Bypass any settings that are not included on the Configuration page if it is more appropriate for the network administrator to set them. For more information, see Configuration and Setup on the User Documentation CD.
- 15. Reinstall fonts or custom simulations that may have been deleted when you installed software.

#### **Updating the Fiery Controller**

#### Patch installation instructions

- 1. Make sure the Fiery controller is idle.
- 2. Execute "\_exe" and follow the instructions in the Fiery Patch Downloader.
- 3. Notes about the Fiery Patch Downloader
  - a) Login must be admin. This is fixed and cannot be modified.
  - b) Password is the Fiery administrator login password.
  - c) Hostname can be either the IP address or the Fiery server name.
- 4. After the patch is downloaded, and when prompted by the Fiery Patch Downloader, choose Reboot. (If you choose to Restart later, make sure that you manually reboot the server for changes to take effect.)

- 5. Wait until the Fiery controller comes to Idle and print the configuration page.
- 6. Verify that the System Updates Log section contains the patch number "\*\*\*\*\*\*"

# 5. System Maintenance

# Service Program Mode

See Appendices about Service Program Mode.

# 6. Troubleshooting

# **SC Table Key**

## SC Code Table Key

Level	Definition	Reset Procedure
А	Fusing unit SC codes shown on the operation panel. The machine is disabled. The operator cannot reset the machine.	The machine requires immediate servicing by a service technician.
В	These SC codes disable only the features that use the defective item. Normally, the user does not see these SC codes, but the SC code is displayed on the operation panel when the defective feature is used.	Cycle the machine off/on with the main power switch
С	These are SC codes are not shown on the operation panel. They are logged internally.	Recorded only. Do SP**** to display the SC error log.
D	These SC codes are shown on the operation panel.	To reset machine, cycle the machine off/on. The SC codes are displayed again if the error occurs again.

#### **Preliminary Instructions**

- After a Level A SC code is issued, the machine is disabled and cannot be used until it has been serviced by a qualified technician. Execute SP5810 to release the machine for servicing.
- If the problem is in an electrical circuit board, disconnect then connect the board connectors again before you replace the PCB.
- When a Level A or Level B SC error occurs while the machine is in the SP mode, the SC number will
  not be shown. If this occurs, check the SC number after the machine goes out of the SP mode.
- Many SC codes contain more than one level (SC303-1, SC303-2, SC303-3, and others). Some SC codes may display a "-1", even if there is only one level.

The following abbreviations are used in these SC tables:

- (F) means "Front"
- (R) means "Rear"
- "GW" means "GW controller"; there is a problem with the controller.

## 6

## **ACAUTION**

- At job end or when the machine is switched off, both sides of the ITB unit are lowered and separated from the drums.
- However, after a power failure or accidental disconnection of the power cord, or after a machine
  issues an SC code after a malfunction, both or one side of the ITB may remain up against the
  drums.
- To avoid damage to the ITB, both sides of the ITB must be checked and lowered before the ITB unit can be pulled out of the unit. (IPp.410)

# **SC Tables**

## SC100: Scanning 1

SC101	D	Exposure Lamp Error	D074/D075
		The white level peak did not reach the prescribed threshold when the white plate was scanned.	
		Condensation in scanner unit	
		Dirty lenses, mirrors dirty or position.	ed incorrectly
		White plate dirty or installed incorre	ctly
		Harness between lamp and lamp sto	abilizer disconnected or defective
		Exposure lamp defective	
		Lamp stabilizer defective	
		High voltage line leak	
		SIOB defective	
		SBU defective	

SC120	D	Scanner Home Position Error 1	D074/D075
		The scanner home position sensor did not OFF) after the scanner moved forward 20	, ,
		Scanner motor defective     Scanner HP sensor defective	
		Harness between scanner motor and     SIOB defective	d SIOB disconnected or defective.

SC121
-------

The scanner home position sensor did not go ON after the scanner moved forward 6 mm and the feeler dropped into the HP sensor.

- Scanner motor harness disconnected or defective
- Scanner motor defective
- Scanner HP sensor disconnected or defective
- HP sensor feeler (actuator) not positioned correctly
- SIOB defective

SC141	D	Black Level Detection Error	D074/D075
		The black level value did not reach $\pm 3$ of Gain Control) that executed immediately	the prescribed value for AGC (Automatic after the scanner unit powered on.
		Cycle the machine off/on	
		Harness between SBU and IPU disco	onnected or defective
		SBU defective	
		IPU defective	
		BCU defective	

SC142	D	White Level Detection Error	D074/D075
		The 2nd white level value did not reach the target range (-7 to 0) for AGC (Automatic Gain Control) that executed immediately after the scanner unit powered on.	
		Cycle the machine off/on	
		Condensation in the scanner unit	
		Dirty exposure glass, optics	
		White plate dirty, or set incorrectly	
		Harness between SBU-IPU disconne	cted or defective
		Exposure lamp defective	
		SBU defective	
		IPU defective	
		BCU defective	

SC144 D SBU Communication Error	D074/D075
---------------------------------	-----------

When the machine was switched on, or when the machine returned to full operation from the energy save mode, the machine could not access the SBU register, or the SBU register values are abnormal.

Note: The ASIC IDs read during automatic adjustment of the SBU can be displayed with SP4600 (SBU Version Display).

SBU-BCU harness loose, disconnected, defective

SBU board defective

SIOB board defective

BCU board defective

SC161	D	IPU Errors	D074/D075
	D	IPU Error 1: LSYNC	
SC161-1		An error occurred during the self-diagnostic test performed every time the machine is powered on, or returns to full operation from energy save mode.	
30101-1		Harness between IPU and SBU disconnected or defective	
		Defective BCU board	
		Defective IPU board	
	D	IPU Error 2: Ri No Response	
		The machine detected an error during	Ri access
SC161-2		IPU board defective	
		BCU board defective	
		Controller board defective	

SC180	D	Scanner Unit Exhaust Fan Lock	D074/D075	
		The scanner unit exhaust fan did not switc the ON signal.	h on within 10 sec. after the CPU issued	
		Foreign object interfering with operations	ation of fan	
		Fan motor harness disconnected or defective		
		Fan defective		
		SIOB board defective		
		SBU board defective		

SC181	D	Lamp Regulator Cooling Fan	D074/D075
		The fan next to the lamp regulator board did not switch on within 10 sec. after the CPU issued the ON signal.	
		Fan motor harness disconnected or a	defective
		SBU harness disconnected or defect	ive
		SIOB harness disconnected or defect	tive
		Fan defective	
		SBU board defective	
		SIOB board defective	

D	Scanner Unit Exhaust Fan Lock	D074/D075
	The scanner unit exhaust fan did not switc the ON signal.	h on within 10 sec. after the CPU issued
	Fan motor harness disconnected or a	defective
	SBU harness disconnected or defect	ive
	SIOB harness disconnected or defect	tive
	Fan defective	
	SBU board defective	
	SIOB board defective	
	D	The scanner unit exhaust fan did not switch the ON signal.  • Fan motor harness disconnected or defect to SIOB harness disconnected or defect to Fan defective to SBU board defective

SC195	D	Machine serial number error
		The 11-digit number registered for the machine serial number does not match.
		NVRAM defective
		BCU replaced without original NVRAM
		Check the serial number with SP5-811-002.
		If the stored serial number is incorrect, contact your supervisor.

# SC200: Image Writing

SC202	D	Polygon Motor 1: ON Timeout Error
-------	---	-----------------------------------

After the C K polygon motor turned on, or within 10 sec. after the rpm's changed, the motor did not enter READY status.

• Cycle the machine off/on

- IPU harness loose, disconnected, broken, defective
- Polygon motor defective (replace laser unit)
- IPU defective

SC203

D Polygon Motor 1: OFF Timeout Error

The C, K polygon motor lock signal (XSCRDY signal) failed to unlock (go HIGH) within 3 sec. after the C, K polygon motor went OFF.

Cycle the machine off/on

IPU harness loose, disconnected, broken, defective

Polygon motor defective (replace laser unit)

IPU defective

SC204

D Polygon Motor 1: XCRDY Signal Error

The C, K polygon motor left the lock status once the motor achieved normal rotation speed.

Cycle the machine off/on

IPU harness loose, disconnected, broken, defective

Polygon motor defective (replace laser unit)

IPU defective

SC206

D Polygon Motor 2: ON Timeout Error

After the Y,M polygon motor turned on, or within 10 sec. after the rpm's changed, the motor did not achieve motor lock (READY) status.

Cycle the machine off/on

IPU harness loose, disconnected, broken, defective

Polygon motor defective (replace laser unit)

IPU defective

SC207 D Polygon Motor 2: OFF Timeout Error

The Y, M motor lock signal (XSCRDY signal) failed to unlock (go HIGH) within 3 sec. after the Y, M polygon motor went OFF.

Cycle the machine off/on

IPU harness loose, disconnected, broken, defective

Polygon motor defective (replace laser unit)

SC208

D Polygon Motor 2: XCRDY Signal Error

The Y,M polygon motor left the lock status once after the motor achieved regular rotation speed.

Cycle the machine off/on

IPU harness loose, disconnected, broken, defective

Polygon motor defective (replace laser unit)

IPU defective

• IPU defective

SC210 C Trailing Edge Beam Error (K)

One of the following occurred:

• When the K main scan magnification rate was measured, there was no output for the trailing edge beam detection signal

• The K magnification rate could not be detected

• The detected K magnification rate was not within specification.

• Cycle the machine off/on

• CK Laser unit defective

SC211	С	Trailing Edge Beam Error (C)
		When the C main scan magnification rate was measured, there was no output for the trailing edge beam detection signal
		The C magnification rate could not be detected
		The detected C magnification rate was not within specification.
		Cycle the machine off/on
		CK laser unit defective

SC212	С	Trailing Edge Beam Error (M)
		<ul> <li>When the M main scan magnification rate was measured, there was no output for the trailing edge beam detection signal</li> <li>The M magnification rate could not be detected</li> </ul>
		The detected M magnification rate was not within specification.
		Cycle the machine off/on     YM laser unit defective
SC213	C	Trailing Edge Beam Error (Y)

SC213	С	Trailing Edge Beam Error (Y)
		When the Y main scan magnification rate was measured, there was no output for the trailing edge beam detection signal
		The Y magnification rate could not be detected
		The detected Y magnification rate was not within specification.
		Cycle the machine off/on
		YM laser unit defective

SC22x RTB 50

SC220	D	TE LD1 Laser Synchronization Detection Error (K)
		A signal was not output from the K LSDB after more than 100 ms (100 ms x2) after the LD fired.
		Cycle the machine off/on
		CK Laser unit defective

SC22x RTB 50

SC222	D	TE LD1 Laser Synchronization Detection Error (C)
		A signal was not output from the C LSDB after more than 100 ms (100 ms x2) after the LD fired.
		Cycle the machine off/on CK laser unit defective

SC22x RTB 50

SC224 D TE LD1 Laser Synchronization Detection Error (M)

A signal was not output from the M LSDB after more than 100 ms (100 ms x2) after the LD fired.

• Cycle the machine off/on

• YM laser unit defective

## SC22x RTB 50

SC226	D	TE LD1 Laser Synchronization Detection Error (Y)
		A signal was not output from the Y LSDB after more than 100 ms (100 ms x2) after the LD fired.
		Cycle the machine off/on
		YM Laser unit defective

SC230	D	K FGATE Failed to go ON
		The K FGATE signal did not go ON within the prescribed time after printing started and the STTRIG single went ON.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		CK Laser unit defective

SC231	D	K FGATE Failed to go OFF
		After the K FGATE signal went on, it failed to go OFF within the prescribed time.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		CK Laser unit defective

SC232	D	C FGATE Failed to go ON
-------	---	-------------------------

The C FGATE signal did not go ON within the prescribed time after printing started and the STTRIG single went ON.

• Cycle the machine off/on

- IPU harness loose, disconnected, broken, defective
- IPU defective
- CK Laser unit defective

SC233	D	C FGATE Failed to go OFF
		After the C FGATE signal went on, it failed to go OFF within the prescribed time.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		CK Laser unit defective

SC234	D	M FGATE Failed to go ON
		The M FGATE signal did not go ON within the prescribed time after printing started and the STTRIG signal went ON.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		YM laser unit defective

SC235	D	M_FGATE Failed to go OFF
		After the M FGATE signal went on, it failed to go OFF within the prescribed time.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		YM laser unit defective

SC236	Y FGATE Failed to go ON
-------	-------------------------

		The Y FGATE signal did not go ON within the prescribed time after printing started and the STTRIG single went ON.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		YM laser unit defective
SC237	D	Y FGATE Failed to go OFF

SC237	D	Y FGATE Failed to go OFF
		After the Y FGATE signal went on, it failed to go OFF within the prescribed time.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		YM laser unit defective

SC240	D	LD Error (K)
		The LD current exceeded the prescribed limit when the K LD fired.
		Cycle the machine off/on
		CK laser unit defective

SC241	D	LD Error (C)
		The LD current exceeded the prescribed limit when the C LD fired.
		Cycle the machine off/on
		CK laser unit defective

SC242	D	LD Error (M)	
		The LD current exceeded the prescribed limit when the M LD fired.	
		Cycle the machine off/on	
		YM laser unit defective	

SC243	D	LD Error (Y)
-------	---	--------------

	The LD current exceeded the prescribed limit when the Y LD fired.
	Cycle the machine off/on
	YM laser unit defective

#### SC26x RTB 50

SC260	С	Laser Thermistor Error (CK)
SC262	С	Laser Thermistor Error (YM)
		One of the following occurred:
		<ul> <li>The reading of the thermistor in the CK or YM laser unit was less than 10°C (50°F), indicating that the thermistor has disconnected.</li> </ul>
		• The reading of the thermistor in the CK or YM laser unit was more than 80°C (176°F), indicating that the thermistor has shorted out.
		Cycle the machine off/on
		IOB harness loose, disconnected, broken, defective
		CK or YM laser unit defective
		IOB defective

## SC26x RTB 50

SC263	С	Laser Thermistor (Y) Error
		The laser thermistor in the YM laser unit is not functioning properly because it is disconnected or shorted out.
		Replace the YM laser unit.

## SC26x RTB 50 RTB 81

SC265	С	Skew Control: Out of Range Error (C)
		The C skew control pulse total (SP2104-7) is not within range.
		Cycle the machine off/on
		CK laser unit defective

SC26x RTB 50 RTB 81

SC266	С	Skew Control: Out of Range Error (M)
		The M skew control pulse total (SP2104-8) is not within range.
		Cycle the machine off/on
		YM laser unit defective

SC267	С	Skew Control: Out of Range Error (Y)
		The Y skew control pulse total (SP2104-9) is not within range.
		Cycle the machine off/on
		YM laser unit defective

SC270	D	Image Transfer Error (K)
		The image data that the K LDB received generated a fatal error.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		CK laser unit defective

6

SC271	D	Image Transfer Error (C)
		The image data that the C LDB received generated a fatal error.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		CK laser unit defective

SC272	D	Image Transfer Error (M)
		The image data that the M LDB received generated a fatal error.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		YM laser unit defective

SC273
-------

		The image data that the Y LDB received generated a fatal error.
		Cycle the machine off/on
		IPU harness loose, disconnected, broken, defective
		IPU defective
		YM laser unit defective
SC275	D	PC Communication Error (K)
		The K LDB is not functioning normally.
		Cycle the machine off/on
		CK laser unit defective
SC276	D	PC Communication Error (C)
		The C LDB is not functioning normally.
		Cycle the machine off/on
		CK laser unit defective
SC277	D	PC Communication Error (M)
		The M LDB is not functioning normally.
		Cycle the machine off/on
		YM laser unit defective
SC278	D	PC Communication Error (Y)
		The Y LDB is not functioning normally.
		Cycle the machine off/on
		YM laser unit defective
SC280	D	IPU Image Transfer Error
		<u> </u>

An error occurred during data sending between components (GRIFFON, LEO) on the IPU board.
<ul><li>Cycle the machine off/on</li><li>If the problem persists, replace the IPU</li></ul>

SC285 RTB 50 RTB 81

SC285	D	MUSIC Error
		The results of MUSIC pattern reading failed 4 times (SC496 issued 4 times).
		A PCDU is set incorrectly
		ITB is set incorrectly
		Execute manual process control with SP3011-2 (Density Adjustment)
		MUSIC sensor harness loose, disconnected, broken, defective
		MUSIC sensor defective
		ITB damaged
		Laser unit defective

# SC300: Development

## Charge, Development

SC300	D	Charge Roller Power Pack Output Error (K)
SC301	D	Charge Roller Power Pack Output Error (C)
SC302	D	Charge Roller Power Pack Output Error (M)
SC303	D	Charge Roller Power Pack Output Error (Y)

The interrupt that checks the status of the PCU power pack every 10 ms detected a short at the high-voltage harness or charge leak at the charge roller. The high-voltage harness could be broken or defective, or the charge roller could be dirty.

- Disconnect the high voltage cable from Terminal C of the power pack.
- Attach a voltmeter to the terminal.
- If there is no output from the terminal, replace the power pack.

-or-

- If there is output from the terminal, test the resistance between the high voltage cable and the ground.
- If resistance is nearly "0", check the high-voltage harness for defects and replace it if necessary.
- Test the conductivity between the PCU and the ground. If there is no conductivity between the PCU and ground, replace the PCU.
- If there is no charge PWM signal, replace the harness and/or BCU.

SC310	D	Charge FB Voltage Error (K)
SC311	D	Charge FB Voltage Error (C)
SC312	D	Charge FB Voltage Error (M)
SC313	D	Charge FB Voltage Error (Y)
		Just before beginning to print, the charge FB (feed-back) voltage was detected less than 0.3V for 50 consecutive readings within 400 ms.
		High-voltage harness disconnected or broken
		Charge roller not installed correctly
		Drum not installed correctly

SC320	D	Separation Power Pack Output Error (K)
SC321	D	Separation Power Pack Output Error (C)
SC322	D	Separation Power Pack Output Error (M)
SC323	D	Separation Power Pack Output Error (Y)

The BCU detected an electrical short during development charge output for K,C,M, or Y. Possible causes for this are: • IOB harness disconnected or defective • High-voltage cable defective • Power pack defective • Development unit defective IOB defective 1. Disconnect the high voltage cable from Terminal B of the development power pack. 2. Attach a voltmeter to the terminal. 3. If there is no output from the terminal, replace the power pack. -or-1. If there is output from the terminal, test the resistance between the highvoltage cable and the ground. 2. If resistance is "0" or nearly "0", check the high-voltage harness for defects and replace it if necessary. 3. If replacing the harness does not solve the problem, test the resistance between the development unit terminal and the ground. 4. If there is no resistance (0 ohms) between the development unit and the ground, replace the PCU.

SC325	D	Development Motor Error (K)
SC326	D	Development Motor Error (C)
SC327	D	Development Motor Error (M)
SC328	D	Development Motor Error (Y)
		The development motor failed to start within the prescribed time or failed during normal operation.
		<ul> <li>Motor harness disconnected or defective</li> <li>Motor shaft locked, blocked by obstruction</li> <li>Motor defective</li> </ul>

5. If there is no development PWM signal, replace the IOB harness and/or

SC330	D	Toner Supply Bottle Motor Error (K)
SC331	D	Toner Supply Bottle Motor Error (C)
SC332	D	Toner Supply Bottle Motor Error (M)
SC333	D	Toner Supply Bottle Motor Error (Y)
SC334	D	Toner Supply Bottle Motor Error (S)
		The machine detected that the toner supply motor was not operating.
		Toner bottle installed incorrectly
		Toner bottle rotation blocked by an obstruction
		Toner bottle damaged
		Toner supply bottle motor defective

SC335	D	Developer Set Error (K)
SC336	D	Developer Set Error (C)
SC337	D	Developer Set Error (M)
SC338	D	Developer Set Error (Y)
		Before the TD sensor control voltage (Vcnt = 4.75V) is adjusted when the TD sensor is initialized (SP3-030), the development unit is always checked for the presence of developer. The check revealed that the K, C, M, or Y development unit did not have a sufficient amount of toner. Vt (the TD sensor output) was less than 0.7V  • Replace the developer

SC345	D	Toner Supply Pump Motor Error (K, M, C, Y)
-------	---	--

The toner supply pump motor failed to start within the prescribed time or failed during normal operation.

- Motor harness disconnected or broken
- Toner pump unit harness disconnected or broken
- Toner pump unit panel mount connector broken
- Check each toner supply unit (K, M, C, Y) for any obstructions that could be blocking operation of a pump or sub hopper
- Toner supply pump motor defective

SC355	D	Toner Supply Error (K)
		Amount of toner on the ID sensor pattern printed and read between sheets less than 0.100 (SP3300-1).
		Accumulated toner clutch ON time in the K sub hopper of the toner supply unit greater than 5000 (SP3301-41)
SC356	D	Toner Supply Error (C)
		Amount of toner on the ID sensor pattern printed and read between sheets less than 0.200 (SP3300-3).
		<ul> <li>Accumulated toner clutch ON time in the C sub hopper of the toner supply unit greater than 5000 (SP3301-43)</li> </ul>
SC357	D	Toner Supply Error (M)
		Amount of toner on the ID sensor pattern printed and read between sheets less than 0.200 (SP3300-3).
		<ul> <li>Accumulated toner clutch ON time in the M sub hopper of the toner supply unit greater than 5000 (SP3301-43)</li> </ul>
SC358	D	Toner Supply Error (Y)
		Amount of toner on the ID sensor pattern printed and read between sheets less than 0.200 (SP3300-4).
		<ul> <li>Accumulated toner clutch ON time in the Y sub hopper of the toner supply unit greater than 5000 (SP3301-43)</li> </ul>

A small rectangular wire attached to the shaft of an augur in each toner supply unit scrapes the surface of the toner end sensor with each rotation of the augur. The cleaning wire may be bent or the toner end sensor is defective. If the toner end sensor is damaged or out of position, the toner end sensor will cease to function normally.

• Replace the affected toner supply unit.

SC36x RTB 79

SC360	D	TD Sensor (Vt High) Error (K)
		The TD sensor output for the K development unit was greater than 4.7V (SP3210-1)
SC361	D	TD Sensor (Vt High) Error (C)
		The TD sensor output for the C development unit was greater than 4.7V (SP3210-2)
SC362	D	TD Sensor (Vt High) Error (M)
		The TD sensor output for the M development unit was greater than 4.7V (SP3210-3)
SC363	D	TD Sensor (Vt High) Error (Y)
		The TD sensor output for the C development unit was greater than 4.7V (SP3210-4)
		These SC codes are issued if the TD sensor output is greater than 4.7V after 20 consecutive readings.
		TD sensor harness of the affected unit defective, disconnected, or broken.  Replace the TD sensor.
		TD sensor defective on the affected development unit

SC36x RTB 79

SC365	D	TD Sensor (Vt Low) Error (K)
		The TD sensor output for the K development unit was less than 0.5V (SP3210-1)
SC366	D	TD Sensor (Vt Low) Error (C)
		The TD sensor output for the C development unit was less than 0.5V (SP3210-2)
SC367	D	TD Sensor (Vt Low) Error (M)
		The TD sensor output for the M development unit was less than 0.5V (SP3210-3)

-
И.

SC368	D	TD Sensor (Vt Low) Error (Y)
		The TD sensor output for the Y development unit was less than 0.5V (SP3210-4)
		These SC codes are issued if the TD sensor output is less than 0.5V after 10 consecutive readings.
		TD sensor harness of the affected unit defective, disconnected, or broken. Replace the TD sensor.
		Replace development unit

SC370	D	TD Sensor Initialization Error (K)
SC371	D	TD Sensor Initialization Error (C)
SC372	D	TD Sensor Initialization Error (M)
SC373	D	TD Sensor Initialization Error (Y)
		The TD sensor of the affected development unit could not be initialized within 2.9±0.2V.
		TD sensor harness of the affected unit defective, disconnected, or broken.  Replace the TD sensor.
		Replace development unit

SC375	D	ID Sensor Calibration Error
		The voltage reading during process control for Vsg_reg was not within the correct range (4.0±0.5V). Vsg_reg is the voltage reading of the light reflected directly from the bare surface of the ITB.
		ID sensor harness disconnected or broken
		ID sensor dirty. Check sensor window and clean with clean cloth moistened with alcohol. Do not use a dry cloth.
		ID sensor defective
		ITB deformed or out of position (replace damaged ITB)
		Note:
		This error can occur as a result of cleaning the sensors with a dry cloth, which can cause a static charge to build up on the sensor and attract particles of paper dust.
		Always clean the ID sensor with a clean cloth moistened with alcohol.

SC377	D	LED Error During Vsg Adjustment
		ID sensor (PWM) value is greater than the threshold value (Ifsg > 27 mA) set by SP3320-15 (Default: 0) This can be caused by one or more of these conditions:
		ID sensor dirty
		ID sensor defective
		ITB dirty
		Clean the window of the ID sensor with a clean cloth moistened with alcohol.  Do not use a dry cloth.
		ITB belt dirty
		ITB out of position
		ID sensor defective
		Note:
		This error can occur as a result of cleaning the sensors with a dry cloth, which can cause a static charge to build up on the sensor and attract particles of paper dust.
		Always clean these with a clean cloth moistened with alcohol.

SC380	D	ID Sensor Pattern Density High Error (K)
		The density of the Black reading in the ID sensor patterns created between pages (SP3300-1) is greater than the threshold value set by SP3301-21.
SC381	D	ID Sensor Pattern Density High Error (C)
		The density of the Cyan reading in the ID sensor patterns created between pages (SP3300-2) is greater than the threshold value set by SP3301-22.
SC382	D	ID Sensor Pattern Density High Error (M)
		The density of the Magenta reading in the ID sensor patterns created between pages (SP3300-3) is greater than the threshold value set by SP3301-22.
SC383	D	ID Sensor Pattern Density High Error (Y)
		The density of the Yellow reading in the ID sensor patterns created between pages (SP3300-4) is greater than the threshold value set by SP3301-22.
		The ID sensor reading for the affected color was probably due to excessive toner.
		Replace the toner supply unit

SC39x RTB 71 RTB 72 RTB 120

SC385	D	ID Sensor Pattern Density Low Error (K)
		The density of the Black reading in the ID sensor patterns created between pages (SP3300-1) is less than the threshold value set by SP3301-23.
SC386	D	ID Sensor Pattern Density Low Error (C)
		The density of the Cyan reading in the ID sensor patterns created between pages (SP3300-2) is less than the threshold value set by SP3301-24.
SC387	D	ID Sensor Pattern Density Low Error (M)
		The density of the Magenta reading in the ID sensor patterns created between pages (SP3300-3) is less than the threshold value set by SP3301-24.
SC388	D	ID Sensor Pattern Density Low Error (Y)
		The density of the Yellow reading in the ID sensor patterns created between pages (SP3300-4) is less than the threshold value set by SP3301-24.
		<ul> <li>Dust shield glass dirty</li> <li>Insufficient application of development bias</li> <li>Check the ITB unit</li> </ul>

SC390	D	Drum Motor (K) Error
SC391	D	Drum Motor (C) Error
SC392	D	Drum Motor (M) Error
SC393	D	Drum Motor (Y) Error
		An error was detected at power on, when the affected motor started up, or during normal rotation of the motor. Excessive torque was detected on the motor, possibly caused by a jammed drum cleaning blade. A LOCK signal could not be detected after 1 sec.
		Disassemble the PCDU and inspect the drum and cleaning blade for damage. Replace is necessary.
		<ul> <li>Execute SP7988 for whichever unit was affected.</li> <li>Reset the counter with 7987 for whichever unit was affected.</li> </ul>

SC39x RTB 71 RTB 72 RTB 88 RTB 120

SC395	D	Drum Motor Error (K)
SC396	D	Drum Motor Error (C)

SC39x RTB 71 RTB 72 RTB 88 RTB 120

SC397	D	Drum Motor Error (M)
SC398	D	Drum Motor Error (Y)
		A lock signal could not be detected within one sec. after the motor start signal was sent, or the LOCK signal was lost during normal operation of the motor.
		Motor harness disconnected or broken
		Obstruction is blocking operation of the drum or motor
		TDCU defective
		Drum motor defective

## SC400: Around the Drum

SC400	D	Development Gamma Error (K)
SC401	D	Development Gamma Error (C)
SC402	D	Development Gamma Error (M)
SC403	D	Development Gamma Error (Y)
		Development gamma for the affected color is not within range:
		0.3 < Development Gamma < 6.0
		One of the following problems (identified by a process control error code) has occurred during the potential control phase of process control (ACC gamma correction);
		• Code 55, 56. Development gamma was not in the range 0.3 to 6.0. Process control halts and a process control code is issued: 55, 56.
		Code 59. Development gamma calculation point error.
		Code 61. LD did not fire and data array has all negative values.
		Note: To display the 2-digit process control error codes, do SP3012.

- Dust shield glass is dirty
- ITB unit transfer power pack defective
- LD unit inside laser unit defective

If SP3012 returned a process control error code:

- Code 55, 59. Replace developer.
- Code 56. Clean the toner shield glass, or replace transfer power pack.
- Code 61. Replace laser unit.

SC405	D	Development Start Voltage (Vk) Error (K)
SC406	D	Development Start Voltage (Vk) Error (C)
SC407	D	Development Start Voltage (Vk) Error (M)
SC408	D	Development Start Voltage (Vk) Error (Y)
		The detected development start voltage was not within the range of ±150V. Process control error codes: 57, 58 (displayed with SP3012).
		<ul> <li>Potential sensor dirty or defective (Process control error code 58)</li> <li>Developer requires replacement (Process control error: 57, 58)</li> </ul>

SC410-413 RTB 122 RTB 131

SC410	D	Potential Sensor Vd Error (K)
SC411	D	Potential Sensor Vd Error (C)
SC412	D	Potential Sensor Vd Error (M)
SC413	D	Potential Sensor Vd Error (Y)

The reading of the potential sensor above the drum of the affected color is incorrect. Specifically, Vd was out of range:

500 **≦** Vd (700) **≦** -800

Process control error codes: 15, 16 (displayed with SP3012)

**Note**: Vd is the potential sensor reading of the unexposed surface of the OPC drum (no laser applied to the drum). This is read during the potential process control self-check.

## Error Code 15

- Potential sensor probe dirty.
- Clean area around potential sensor with a blower brush
- Potential sensor defective

## Error Code 16

• Potential sensor board defective

#### SC415-418 RTB 131

SC415	С	Potential Sensor Vd Adjustment Error (K)
SC416	С	Potential Sensor Vd Adjustment Error (C)
SC417	С	Potential Sensor Vd Adjustment Error (M)
SC418	С	Potential Sensor Vd Adjustment Error (Y)
		The DC bias charge could not be adjusted to the target voltage Vd±8V  Process control error code: 63 (displayed with SP3012).  Note: Vd is the potential sensor reading of the unexposed surface of the OPC drum (no laser applied to this area of the drum). This is read during the potential process control self-check. Vd is adjusted with the charge roller.  Error Code 63  Charge roller dirty  Charge roller defective

SC420	С	Potential Sensor VI Adjustment Error (K)
SC421	С	Potential Sensor VI Adjustment Error (C)
SC422	С	Potential Sensor VI Adjustment Error (M)
SC423	С	Potential Sensor VI Adjustment Error (Y)

The LD power could not be adjusted to the target for Vpl±5V.

Process control error code: 64 (displayed with SP3012).

#### Note:

- VI is the OPC drum potential after maximum laser exposure. The potential sensor measures VI by reading the white patches of the potential sensor pattern.
- To change VI, the machine adjusts the input current (VpI) of the laser diode.

#### Error Code 64

- Charge roller dirty
- Charge roller defective
- OPC drum is worn and needs to be replaced

SC430	С	Potential Sensor Vr Adjustment Error (K)
SC431	С	Potential Sensor Vr Adjustment Error (C)
SC432	С	Potential Sensor Vr Adjustment Error (M)
SC433	С	Potential Sensor Vr Adjustment Error (Y)
		Potential sensor adjustment was out of range:  Vr >-200V.  Process control error code: 62 (displayed with SP3012).  Note: Vr is residual voltage, the slight trace of voltage that remains after the QL neutralizes the surface of the drum. There is always some residual voltage after quenching, even on a new drum. Vr can cause dirty backgrounds on copies. The only way to compensate for Vr is to increase development bias.  Error Code 62:  OPC drum is worn, needs replacement

SC440	D	Image Transfer Power Pack Voltage Leak (K)
SC441	D	Image Transfer Power Pack Voltage Leak (C)
SC442	D	Image Transfer Power Pack Voltage Leak (M)
SC443	D	Image Transfer Power Pack Voltage Leak (Y)

The machine detected a problem with the image transfer power pack. An interrupt checks the status of the power pack every 10 ms. This SC is issued if a problem exists with 50 consecutive samplings (500 ms).

Power pack high-voltage harness disconnected or broken

IOB defective

Image transfer power pack defective

ITB defective

• PCU charge roller defective

SC446 RTB 50 RTB 127

SC446	D	Transfer Belt Drive Motor
		The transfer belt drive motor failed to start within the prescribed time or failed during normal operation.
		Motor harness disconnected or broken
		Physical obstruction is blocking operation of the ITB unit
		Motor or motor drive board defective

SC447	D	1 st Lift Motor Sensor (YCM) Error
		The 1st lift motor (YCM) was operating but the 1st lift motor sensor failed to detect the position of the sensor feeler within the prescribed time.
		Sensor dirty
		Sensor harness disconnected or broken
		Sensor defective
		Motor defective

SC448	D	ITB Unit Set Error (K)
		After the front door was closed, the ITB lift sensor (K) failed to detect the ITB at the correct position.
		Operator forgot to set lever before closing front cover
		2nd lift motor sensor (K) 1 or 2 dirty
		Sensor harness disconnected or broken
		Sensor defective

## SC449 RTB 111

SC449	D	ITB Tray Lift (K) Error
		The 2nd lift motor (K) was operating but 2nd lift motor sensor 1 or 2 failed to detect the position of the sensor feeler for the 2nd lift tray (K) within the prescribed time.
		<b>Note</b> : There are two lift sensors for the 2nd lift tray below the K_PCDU. Sensor 1 is above the 2nd lift motor near the front of the ITB unit. Sensor 2 is at the rear left corner of the ITB unit below the ITB.
		Sensor 1 or 2 dirty
		Sensor harness disconnected or broken
		Sensor 1 or 2 defective
		2nd lift motor (K) defective

SC452	D	ITB Unit Transfer Power Pack Low Voltage Error (K)
SC453	D	ITB Unit Transfer Power Pack Low Voltage Error (C)
SC454	D	I ITB Unit Transfer Power Pack Low Voltage Error (M)
SC455	D	ITB Unit Transfer Power Pack Low Voltage Error (Y)
		The machine detected a power pack voltage output at less than 0.1 kV due to a problem with the power pack power supply.
		<ul> <li>Power pack power supply harness disconnected or broken</li> <li>Replace the power pack</li> </ul>

SC457	D	ITB Cleaning Unit Motor Error
		The ITB cleaning unit motor failed to start within the prescribed time or failed during normal operation.
		Motor harness disconnected or broken
		Physical obstruction is blocking the operation of the ITB cleaning unit
		ITB cleaning unit motor defective

SC458	С	Image Transfer Roller Error (K)
SC459	С	Image Transfer Roller Error (C)
SC460	С	Image Transfer Roller Error (M)

SC461	С	Image Transfer Roller Error (Y)
		The machine detected that the electrical resistance of the roller exceeded the allowed limit, indicating that the service life of the roller has expired or there could be a problem with the transfer power pack.
		<ul> <li>High-voltage harness disconnected or broken</li> <li>Connection point at the roller broken</li> <li>Image transfer roller worn out, needs replacement</li> <li>Image transfer power pack defective</li> </ul>

SC464	D	ITB Unit Transfer Power Pack Leak Error
		The machine detected a voltage leak at the paper transfer power pack
		Harness between power pack and IOB disconnected or broken
		High-voltage harness defective
		Power pack defective
		IOB defective
		ITB defective
		PTR defective

## SC465 RTB 134

SC465	D	PTR Motor Error
		The PTR motor failed to start within the prescribed time or failed during normal operation.
		PTR motor harness disconnected or broken
		Physical obstruction blocking operation of the PTR unit
		Motor or motor drive board defective

SC466	D	PTR Separation Motor Error
-------	---	----------------------------

SC467 RTB 135

		The PTR separation motor was operating but the PTR separation sensor failed to detect the feeler that triggers detection of the PTR separation sensor.
		Sensor dirty
		Motor harness disconnected or broken
		Sensor defective
		Motor defective
SC468	D	ITB Unit Power Pack Error: Low Output
		During the execution of bias feedback control, the machine detected that the output of the paper transfer power pack was less than 0.1 kV.
		High-voltage harness disconnected or broken
		Paper transfer power pack defective
SC469	С	ITB Bias Roller Service Expired
		The machine detected that the electrical resistance of the roller exceeded the allowed limit, indicating that the service life of the roller has expired or there could be a problem with the paper transfer power pack.
		High-voltage harness disconnected or broken
		Connection point at the roller broken
		ITB bias roller worn out, needs replacement
		Paper transfer power pack defective
SC470	D	ITB Unit Power Pack Leak Error
		The machine detected a voltage leak at the separation power pack
		Harness between power pack and IOB disconnected or broken
		High-voltage harness defective
		Power pack defective
		IOB defective
		ITB defective
		ITB bias roller defective
SC471	D	Belt Position Ready Timeout

The machine could not center the belt correctly with 400 sec. after the ITB motor starting rotating the ITB.

- Belt centering roller out of position
- ITB encoder sensor defective
- Belt centering roller sensor defective
- Belt centering roller motor defective
- 1. Do the procedure to clear SC471 (\*\*p.1020)
- 2. Replace ITB motor rotation sensor
- 3. Replace belt centering roller sensor
- 4. Replace belt centering roller motor

# SC472 D Belt Centering Roller HP Error The belt centering roller sensor did not detect the belt centering roller at HP during initialization, or the belt centering roller sensor still detected the belt centering roller at HP after the belt centering roller motor switched on • Belt centering roller sensor detective • Belt centering roller motor defective

SC474	D	ITB Position Error 1
		The belt centering sensor detected the ITB out of position.  ITB not set correctly, re-set ITB.  Belt centering roller out of home position  ITB encoder sensor defective  Belt centering roller sensor defective  Belt centering roller motor defective
		<ol> <li>Re-set ITB correctly.</li> <li>Do the procedure to clear SC474 (Pp.1020)</li> <li>Replace ITB motor rotation sensor</li> <li>Replace belt centering roller sensor.</li> <li>Replace belt centering roller motor.</li> </ol>

	SC475	D	ITB Position Error 2
--	-------	---	----------------------

The front belt overrun sensor detected an ITB position error.

- Front belt overrun sensor defective
- ITB defective or worn
- Belt centering roller out of home position
- ITB motor rotation sensor defective
- Belt centering roller sensor defective
- Belt centering roller motor defective
- 1. Replace the belt overrun sensor (front).
- 2. Do the procedure to clear SC475 (\*\*p.1020)
- 3. Replace ITB motor encoder
- 4. Replace belt centering roller sensor
- 5. Replace belt centering roller motor

SC476	D	ITB Position Error 3
		The rear belt overrun sensor detected an ITB position error.
		Rear belt overrun sensor defective
		ITB defective or worn
		Belt centering roller out of home position
		ITB motor rotation sensor defective
		Belt centering roller sensor defective
		Belt centering roller motor defective
		1. Replace the belt overrun sensor (front).
		2. Do the procedure to clear SC476 (IPT p.1020)
		3. Replace ITB motor encoder
		4. Replace belt centering roller sensor
		5. Replace belt centering roller motor

SC477	D	Belt Centering Sensor Error
		The readings of the belt centering sensor dropped below one volt after 62 samples.
		Belt centering sensor connector loose, broken, defective     Belt centering sensor defective

SC480	D	Drum Cleaning Motor Error (K)
SC481	D	Drum Cleaning Motor Error (C)
SC482	D	Drum Cleaning Motor Error (M)
SC483	D	Drum Cleaning Motor Error (Y)
		The drum cleaning motor failed to start within the prescribed time or failed during normal operation.
		Physical obstruction is blocking normal motor operation     Motor harness disconnected or broken
		Motor defective
1		

SC485	D	Used Toner Transport Motor Error
		The used toner transport motor failed to start within the prescribed time or failed during normal operation.
		Physical obstruction is blocking motor or used toner transport path
		Motor harness disconnected or broken
		Motor defective

SC486	D	Used Toner Bottle Motor Error
		The used toner bottle motor failed to start within the prescribed time or failed during normal operation.
		Physical obstruction is blocking motor or interfering with rotation of used toner bottle
		Motor harness disconnected or broken
		Used toner bottle motor defective

SC488	D	Used Toner Transport Blockage
		Used toner is not being moved to the used toner bottle.
		Blockage in the used toner transport path
		Used toner motor (main machine) harness disconnected or broken
		Used toner transport motor ensor defective
		Used toner motor (main machine) defective

SC490	С	Impending Failure Detection: Code 01
`SC491	С	Impending Failure Detection: Code 02
SC492	С	Impending Failure Detection: Code 03
SC493	С	Impending Failure Detection: Code 04
SC494	С	Impending Failure Detection: Code 05
SC495	С	Impending Failure Detection: Code 99
		The TDCU (Transfer Drive Control Board) monitors the mechanisms. If the TDCU detects an impending failure in a system, it will notify the engine of the problem with an ASAP command. The main cause of such impending failures are:
		Expiration of service life of components
		Dirty sensors
		Clean the part
		Replace the part

SC496	С	MUSIC Sensor Error
		This SC is issued if one or more of the following occurred:
		MUSIC sensor sampling abnormal
		Sensor LED adjustment abnormal
		Number of patches abnormal
		ITB scratched
		Main scan registration abnormal
		Sub scan registration abnormal
		Main scan magnification abnormal
		Main scan magnification error diffusion abnormal
		Lens refraction abnormal

- A PCDU is set incorrectly
- ITB is set incorrectly
- · Execute process control density adjustment
- MUSIC sensor harness loose, disconnected, broken, defective
- ITB damaged
- PCDU defective
- Laser unit defective

# SC497 C Temperature/Humidity Sensor Error (PCU) The machine detected one of these problems with the temperature/humidity sensor located under the rear end of the K PCDU: • The temperature sensor output was less than 0.5V or more than 2.8V three times in one minute, indicating a problem with the temperature detection. • The humidity sensor output was more than 2.4V for three times in one minute, indicating a problem with humidity detection. • Sensor harness disconnected or broken • Sensor has slipped out of position • Sensor defective

SC498	С	Temperature/Humidity Sensor Error (Main)	
		The machine detected one of these problems with the temperature/humidity sensor located under the rear end of the K PCDU:	
		The temperature sensor output was less than 0.5V or more than 2.8V three times in one minute, indicating a problem with the temperature detection.	
		The humidity sensor output was more than 2.4V for three times in one minute, indicating a problem with humidity detection.	
		Sensor harness disconnected or broken	
		Sensor has slipped out of position	
		Sensor defective	

# SC499 C Paper Transfer Control Error

SC499 RTB 50

The ITB sensor that reads the encoded film strip on the edge of the image transfer belt was not operating correctly. (The TDCU constantly monitors operation of the ITB with transfer feed-back control.)

- ITB encoder sensor dirty
- Sensor harness disconnected or damaged
- Encoded scale on the edge of the ITB is damaged or dirty
- ITB installed incorrectly
- TDCU harness disconnected or broken
- TDCU defective

## SC500: Paper Feed, Transport, Duplexing

SC501	В	1 st Tray (Tandem Tray) Feed Error
SC502	В	2nd Tray (Universal Cassette) Feed Error
		<ul> <li>One of the following occurred at the start of the job:</li> <li>The tray 1 lift sensor does not switch on 10 s after the tray lift motor switches on and starts lifting the bottom plate.</li> <li>The tray lift sensor was on before the pick-up solenoid switched on.</li> <li>When the tray lowered, the tray lift sensor did not go off within 1.5 sec.</li> <li>The paper end sensor of the tandem tray did not detect the lower limit within 10 sec.</li> <li>Note: Another paper tray cannot be used until the problem is resolved.</li> <li>Remove and reset the paper tray</li> <li>Tray lift motor harness disconnected or broken</li> <li>Paper or other obstacle trapped between tray and motor</li> <li>Pick-up solenoid disconnected or broken</li> <li>Paper or other obstacle blocking operation of pick-up solenoid</li> </ul>

SC503	В	3rd Tray Feed Error	LCIT top tray
SC504	В	4th Tray Feed Error	LCIT middle tray
SC505	В	5th Tray Feed Error	LCIT bottom tray

The tray lift motor, pick-up solenoid, or lift sensor did not operate correctly.

- Tray lift motor harness disconnected or broken
- Pick-up solenoid harness disconnected or broken
- Tray lift sensor harness disconnected or broken
- Tray lift motor defective
- Pick-up solenoid defective
- Tray lift sensor defective

SC506	В	6th Tray Feed Error	oth Tray Feed Error Bypass tray on top of LCIT			
		The tray lift motor, pick-up solenoid, lift sensor, or lower limit sensor did not operate correctly.				
		Tray lift motor harness disconnected	d or broken			
		Pick-up solenoid harness disconnected or broken				
		Tray lift sensor harness disconnected or broken				
		Lower limit sensor disconnected or broken				
		Tray lift motor defective				
		Pick-up solenoid defective				
		Tray lift sensor defective  Lower limit sensor defective				

SC507 B Tandem Tray Rear Fence Motor Error (1st Tray)

One of the following occurred:

- The return sensor does not switch on within 10 sec. after the rear fence motor switches on.
- The HP sensor does not switch on 10 sec. after the rear fence motor switches on.
- The HP sensor and return sensor switch on at the same time.
- Rear fence motor harness disconnected or broken
- Paper or other obstacle interfering with operation of the sensors
- Paper or other obstacle trapped between tray and motor
- Motor mechanical overload due to obstruction
- Return sensor or HP sensor harness disconnected or broken
- Return sensor or HP sensor dirty
- Rear fence motor defective
- Return sensor or HP sensor defective

SC511	В	LCIT Exit Roller Lift Motor Error	
		The exit roller lift motor of lift motor sensor is not operating.	
		Motor harness disconnected or broken	
		Sensor harness disconnected or broken	
		Motor defective	
		Sensor defective	

	SC513	D	Registration Gate Position Error
--	-------	---	----------------------------------

The registration gate could not be detected on or off within the prescribed time. Specifically:

- The registration gate HP sensor did not switch off within 500 ms after the gate retract motor switched on.
- After the registration HP sensor switched off, the HP sensor did not switch on within 500 ms.
- Gate retract motor harness disconnected or broken
- Gate HP sensor harness disconnected or broken
- Physical obstacle (paper, etc.) is blocking operation of the motor
- Gate HP sensor actuator bent, broken, or out of position
- Gate HP sensor defective
- Gate retract motor or motor drive board defective

## SC514 D Registration Shift Position Error The HP sensor did not go on or off within the prescribed time. Specifically: • During normal homing operation, before the unit shift motor starting rotating clockwise, the unit was detected at the HP (on). Or, after the unit shift motor had rotated clockwise for 20 pulses, the unit could not be detected at the HP (on). • During homing operation with the unit out of HP, The unit could not be detected off or on within 1068 ms after the unit shift motor started rotating count-clockwise and the cam shaft had rotated twice. • Shift motor harness disconnected or broken • Physical obstruction is blocking operation of the motor • HP sensor harness disconnected or broken Sensor actuator bent, broken, or out of position Motor or motor drive board defective

# SC515 D CIS Cleaning Fan Error The CIS cleaning fan motor in the right drawer failed to start within the prescribed time or failed during normal operation. • Fan motor harness disconnected or broken • Physical obstruction is blocking operation of the fan

SC516	D	Transport Belt Drive Motor Error	
		A LOW motor LOCK signal was not detected after the motor switched off after 10 consecutive attempts.	
		Motor connector loose, broken, defective	
		Motor or motor drive board defective	

SC520	D	Fusing Motor Error	
		The fusing motor failed to start within the prescribed time or failed during normal operation.	
		Fusing motor harness disconnected or broken	
		Physical obstruction is blocking the operation of the 1st fusing processing unit	
		Fusing motor defective	
		Blown fused on PSU 2 on the back of the main machine	

SC521	D	Exit Motor Error	
		The exit motor failed to start within the prescribed time or failed during normal operation.	
		Exit motor harness disconnected or defective	
		Exit motor shaft locked, blocked by obstruction	
		Exit motor defective	

SC525	D	Cooling Unit Transport Motor 1 Error	
SC526	D	Cooling Unit Transport Motor 2 Error	
		A transport motor of the optional cooling unit failed to switch on within the prescribed time after startup.	
		Motor harness disconnected or broken     Motor defective	

SC527-001	D	Cooling Fan Alarm 1 (Buffer Pass Unit D548)
SC527-002	D	Cooling Fan Alarm 2 (Buffer Pass Unit D548)
SC527-003	D	Cooling Fan Alarm 3 (Buffer Pass Unit D548)

SC527-004	D	Cooling Fan Alarm 4 (Buffer Pass Unit D548)
		The fan stopped during operation. This alarm is issued if the fan lock sensor detects that the fan has been off for 10 sec.
		Fan motor harness disconnected or broken     Fan motor defective

SC527-005	D	Exhaust Fan Alarm 1 (Buffer Pass Unit D548)
SC527-006	D	Exhaust Fan Alarm 2 (Buffer Pass Unit D548)
SC527-007	D	Exhaust Fan Alarm 3 (Buffer Pass Unit D548)
SC527-008	D	Exhaust Fan Alarm 4 (Buffer Pass Unit D548)
		The fan stopped during operation. This alarm is issued if the fan lock sensor detects that the fan has been off for 10 sec.
		Fan motor harness disconnected or broken
		Fan motor defective

SC530	D	Heat Sink Intake Fan Error
		The one of the fans in the heat sink duct stopped during operation. This alarm is issued if the fan lock sensor detects that the fan has been off for 5 sec.
		Fan motor harness disconnected or broken
		Fan motor defective

SC531	D	Paper Cooling Fan Error
		One of the fans in the paper cooling duct stopped during operation. This alarm is issued if the fan lock sensor detects that the fan has been off for 5 sec. The paper cooling duct surrounds the circular baffle at the back of the left drawer.
		Fan motor harness disconnected or broken     Fan motor defective

SC532-01	В	3rd Tray Front Blower Fan Error	LCIT Top Tray: Front
SC532-02	В	3rd Tray Rear Blower Fan Error	LCIT Top Tray: Rear

SC533-01	В	4th Tray Front Blower Fan Error	LCIT Middle Tray: Front
SC533-02	В	4th Tray Rear Blower Fan Error	LCIT Middle Tray: Rear
SC534-01	В	5th Tray Front Blower Fan Error	LCIT Bottom Tray: Front
SC534-02	В	5th Tray Rear Blower Fan Error	LCIT Bottom Tray: Rear
		The fan motor failed to start within the pre normal operation.	escribed time or stopped during
		Fan motor harness disconnected or l     Fan motor defective	oroken

SC535	D	ITB Belt Cleaning Cooling Fan Error
		This is the small fan to the left or the large pressure roller fan on the front of the left drawer.
		Fan motor harness disconnected or broken     Fan motor defective

SC536	D	Drive Exhaust Fan Error
		The fan motor failed to start within the prescribed time or stopped during normal operation. The drive exhaust fan is located near the upper left corner of the machine at the rear.
		Fan motor harness disconnected or broken     Fan motor defective

SC537	D	Toner Supply Cooling Fan Error
		The fan motor failed to start within the prescribed time or stopped during normal operation. The toner supply cooling fan is inside the duct at the upper right corner at the rear of the machine. It is inside the duct that runs past the YM laser unit and connects behind the toner supply units.
		Fan motor harness disconnected or broken     Fan motor defective

SC538	D	Controller Box Intake Fan Error
-------	---	---------------------------------

One of the fans at the bottom edge of the controller box failed to start within the prescribed time or stopped during normal operation.

- Fan motor harness disconnected or broken
- Fan motor defective

SC539	D	Development Unit Cooling Fan Error
		One of the three large fans that cool the liquid coolant through the radiator failed to start within the prescribed time or stopped during normal operation.  These fans are located in the cooling box at the back of the machine.
		Fan motor harness disconnected or broken     Fan motor defective

SC541	Α	Heating Roller Thermistor Error: Poor Connection
		Temperature (t1) detected at less than 0°C. <b>Note</b> : This is the contact thermistor at the front of the fusing unit that touches the core shaft of the hot roller.
		Do SP5810 to cancel the fatal error     Harness disconnected or broken
		Poor contact with surface of hot roller     Thermistor defective

SC542	Α	Heating Roller Thermistor Error: Warm-up Temperature
		Fusing temperature control failed to achieve the warm-up temperature.
		Do SP5810 to cancel the fatal error
		Thermistor deformed
		Thermistor floating free, not in contact with hot roller surface
		Input voltage incorrect
		Fusing lamp disconnected

SC543	Α	Heating Roller Thermistor Error: Software Error
SC544	Α	Thermistor 1 Error: Hardware Error

Temperature incorrect due to a TRIAC short or other problem with IOB or AC drive board

- Do SP5810 to cancel the fatal error
- IOB harness disconnected or broken
- AC drive board harness disconnected or broken
- AC drive board defective
- IOB defective

SC547	D	Zero Cross Error
		Zero cross signals, generated from the AC power supply, are used to generate trigger pulses to control the applied power accurately. When the main switch is turned on, the machine checks how many zero-cross signals are generated within a prescribed time. This SC code is issued if the number of zero-cross signals detected is not within specification.
		Do SP5810 to cancel the fatal error
		A fuse has blown on the AC drive board
		Electrical noise on the power supply line
		Fusing relay damaged, replace AC drive board.

SC551	Α	Pressure Roller Thermistor Error: Poor Connection
		Temperature detected at less than 0°C.
		Do SP5810 to cancel the fatal error
		Harness disconnected or broken
		Poor contact with surface of pressure roller
		Thermistor defective

SC552	Α	Pressure Roller Thermistor Error: Warm-up Temperature
-------	---	---

	Fusing temperature control failed to achieve the warm-up temperature.
	Do SP5810 to cancel the fatal error
	Do 3736 to to cancer the latal error
	Thermistor deformed
	Thermistor floating free, not in contact with pressure roller surface
	Input voltage incorrect
	Fusing lamp disconnected

SC553	Α	Pressure Roller Thermistor Error: Software Error
SC554	Α	Pressure Roller Thermistor Error: Hardware Error
		Temperature incorrect due to a TRIAC short or other problem with IOB or AC drive board
		<ul> <li>Do SP5810 to cancel the fatal error</li> <li>IOB harness disconnected or broken</li> </ul>
		AC drive board harness disconnected or broken
		AC drive board defective
		IOB defective

SC555	Α	Pressure Roller Fusing Lamp Error
		The fusing lamp reached the warm-up temperature and then attained fusing temperature (full power), but remained on after paper passed through the fusing unit (hot roller was not rotating)
		Do SP5810 to cancel the fatal error     Thermistor damaged, or out of position
		Fusing lamp disconnected, broken

SC557	С	Zero Cross Over Error
		At power-on the machine detected that the main power supply was unstable, probably due to electrical noise on the line.
		Logged SP, no action

SC558	Α	Fusing Lamp 4 Error
-------	---	---------------------

The fusing lamp reached the warm-up temperature and then attained fusing temperature (full power), but remained on after paper passed through the fusing unit (hot roller was not rotating).

Note: Fusing lamp 4 is in the heating roller.

- Do SP5810 to cancel the fatal error
- Thermistor damaged, or out of position
- Fusing lamp disconnected, broken

SC559	Α	Three consecutive fusing jams
		This SC only occurs if <b>SP1142</b> is on (Default: OFF), and paper jams occurred in the fusing unit for three consecutive feeds. With SP1142 set to "1" the machine operation can be restored only by the service technician after three consecutive jams occur.
		Remove jammed paper
		Check inside the fusing unit for paper scraps
		Make sure the paper path is clean and free

SC561	Α	Heating Roller Thermistor Error: Poor Connection
		Temperature detected at less than 0°C.
		Note: These are the two NC sensors on the side of the fusing unit.
		Do SP5810 to cancel the fatal error
		Harness disconnected or broken
		Poor contact with surface of heating roller
		Thermistor defective

SC562 A Heating Roller Thermistor Error: Warm-up Temperature

Fusing temperature control failed to achieve the warm-up temperature.

Note: These are the two NC sensors on the side of the fusing unit.

Do SP5810 to cancel the fatal error

Thermistor deformed

Thermistor floating free, not in contact with heating roller surface

Input voltage incorrect

Fusing lamp disconnected

### SC563 RTB 140

SC563	Α	Heating Roller Thermistor Error: Software Error
SC564	Α	Pressure Roller Thermistor Error: Hardware Error
		Temperature incorrect due to a TRIAC short or other problem with IOB or AC drive board
		Do SP5810 to cancel the fatal error
		IOB harness disconnected or broken
		AC drive board harness disconnected or broken
		AC drive board defective
		IOB defective

SC566	Α	Thermistor 4 Error: Poor Connection
		Temperature detected at less than 0°C.
		Note: This is the contact thermistor at the top rear of the fusing unit.
		Do SP5810 to cancel the fatal error
		Harness disconnected or broken
		Poor contact with surface of heating roller
		Thermistor defective

SC567	А	Thermistor 4 Error: Software Error
SC568	Α	Thermistor 4 Error: Hardware Error

Temperature incorrect due to a TRIAC short or other problem with IOB or AC drive board

- Do SP5810 to cancel the fatal error
- IOB harness disconnected or broken
- AC drive board harness disconnected or broken
- AC drive board defective
- IOB defective

SC569	D	Pressure Roller Lift Error
		Pressure roller lift motor not operating correctly. No signal to indicate completion of operation.
		Pressure roller lift sensor harness disconnected or broken
		Pressure roller lift sensor dirty
		Pressure roller lift harness disconnected or broken
		Pressure roller lift motor blocked by an obstruction
		Pressure roller lift motor defective

# RTB 142 The ozone collection fan is the large fan on the right end of the upper horizontal duct across the back of the machine. • Fan harness disconnected or broken • Fan overload due to physical obstruction • Fan motor defective

SC571	А	Thermistor 6 Error: Poor Connection
		Temperature detected at less than 0°C.  Note: This is the contact thermistor under the pressure roller at the front of the fusing unit.
		<ul> <li>Do SP5810 to cancel the fatal error</li> <li>Harness disconnected or broken</li> <li>Poor contact with surface of pressure roller</li> <li>Thermistor defective</li> </ul>

SC572	Α	Thermistor 6 Error: Warm-up Temperature
		Fusing temperature control failed to achieve the warm-up temperature.
		Do SP5810 to cancel the fatal error
		Thermistor deformed
		Thermistor floating free
		Input voltage incorrect
		Fusing lamp disconnected

SC573	Α	Thermistor 6 Error: Software Error
SC574	Α	Thermistor 6 Error: Hardware Error
		Temperature incorrect due to a TRIAC short or other problem with IOB or AC drive board
		Do SP5810 to cancel the fatal error
		IOB harness disconnected or broken
		AC drive board harness disconnected or broken
		AC drive board defective
		IOB defective

### SC575 RTB 65

SC575	Α	Fusing Lamp 6 Error
		The fusing lamp in the pressure roller reached the warm-up temperature and then attained fusing temperature (full power), but remained on after paper passed through the fusing unit (hot roller was not rotating)
		<ul> <li>Do SP5810 to cancel the fatal error</li> <li>Thermistor damaged, or out of position</li> <li>Fusing lamp disconnected, broken</li> </ul>

SC576	Α	Hot Roller NC Sensor (Sensor 7) Poor Connection
-------	---	---

	The hot roller NC sensor (infrared thermistor) on top of the fusing unit detected temperature less than 0C for 75 sec.
	Do SP51810 to cancel the fatal error
	Sensor disconnected
	Sensor connector harness or connector broken or defective

SC577	Α	Thermistor 7 Error: Software Error
SC578	Α	Thermistor 7 Error: Hardware Error
		Temperature incorrect due to a TRIAC short or other problem with IOB or AC drive board
		Do SP5810 to cancel the fatal error
		IOB harness disconnected or broken
		AC drive board harness disconnected or broken
		AC drive board defective
		IOB defective

SC579	Α	Thermistor 8 Error: Poor Connection
		Temperature detected at less than 0°C.  Note: This is the contact thermistor at the front of the fusing unit that touches the shaft of the hot roller.
		<ul> <li>Do SP5810 to cancel the fatal error</li> <li>Harness disconnected or broken</li> <li>Poor contact with surface of hot roller shaft (thermistor blade out of position)</li> <li>Thermistor defective</li> </ul>

SC580	Α	Thermistor 8 Error: Warm-up Temperature	
-------	---	---	--

Fusing temperature control failed to achieve the warm-up temperature.

Do SP5810 to cancel the fatal error
Thermistor deformed
Thermistor floating free, not in contact with the hot roller shaft surface.
Input voltage incorrect
Fusing lamp disconnected

SC581	D	Fusing Exit Exhaust Fan Error
		The fan motor failed to start within the prescribed time or stopped and remained off for one sec. This motor is the blower fan mounted flat on the rear side of the machine on the right.
		Fan motor harness disconnected or broken     Fan defective

SC582	D	Cooling Box Emission Exhaust, Cooling Box Heat Fan Error	
		One of these fan motors failed to start within the prescribed time or stopped and remained off for one sec. These fans are inside the cooling box below the blower fan on the right.	
		Fan motor harness disconnected or broken     Fan defective	

SC583	D	Fusing Unit Transport Exhaust Fan
		The fan motor failed to start within the prescribed time or stopped and remained off for one sec. This is the lower blower fan mounted at a right angle on the rear of the machine behind the cooling box.
		Fan motor harness disconnected or broken     Fan defective

SC584 D Cooling Box Ozone Exhaust Fan

The fan motor failed to start within the prescribed time or stopped and remained off for one sec. This is the blower fan inside the "L" duct inside the cooling box and below the air and ozone filters.

- Fan motor harness disconnected or broken
- Fan defective

SC585	D	Stray Toner Exhaust Fan Error
		The fan motor failed to start within the prescribed time or stopped and remained off for one sec. This is the small fan on the right end of the third duct from the top at the rear side of the machine behind the cooling box.
		Fan motor harness disconnected or broken     Fan defective

SC586	D	ITB Intake Fan, Stray Toner Intake Fan Error
		One of these fan motors failed to start within the prescribed time or stopped and remained off for one sec. These are the two motors visible on the right side of the machine with the right cover removed.
		Fan motor harness disconnected or broken     Fan defective

SC587	С	YM Thermistor Error
		The YM thermistor is inside the YM laser unit. One of the following occurred:  • The YM thermistor registered a reading of less than -10°C, indicating a disconnection.
		The YM thermistor registered a reading of more than 80°C, indicating an electrical short circuit
		Thermistor harness disconnected or broken Thermistor defective

	SC588	D	Duplex Exhaust Fan, Exit Paper Exhaust Fan Error
--	-------	---	--

One of these fan motors failed to start within the prescribed time or stopped and remained off for one sec. These are the four large fans visible on the left side of the machine with the left cover removed.

- Fan motor harness disconnected or broken
- Fan blocked by an obstruction
- Fan defective

SC589	D	Drive Exhaust Fan Error
3C369	D	Drive Extigusi Fari Error
		The fan motor failed to start within the prescribed time or stopped and remained off for one sec. This is the small fan located at the upper rear corner on the left side of the machine.
		Fan motor harness disconnected or broken     Fan blocked by an obstruction
		Fan defective

SC590-1	D	Stepper Motor Error 1
		A stepper motor controlled by the Relay Board (RYB) has failed.
SC590-2		Stepper Motor Error 2
		A stepper motor controlled by the DRB in the right drawer has failed.
SC590-3		Stepper Motor Error 3
		A stepper motor controlled by the TDCU on the back of the machine has failed.
SC590-4		Stepper Motor Error 4
		A stepper motor controlled by the DDRB in the decurler unit has failed.

Motor connector loose, broken, defective
Motor drive board overheated
Motor shorted out
Motor or drive board defective
Note:
<ul> <li>Look at the Point-to-Point diagram to determine which motors the referenced board controls.</li> </ul>
<ul> <li>Go into the SP mode and use SP5804 to test the operation of the motors to determine which motor is not operating.</li> </ul>

SC591	С	Double-Feed Sensor Error
		The strength of the double-feed sensor LED light could not be calibrated within the prescribed range after three attempts.
		Sensor harness disconnected or broken
		Physical obstruction (paper scrap) between the sensor pair (emitter/receiver)
		One or both of the sensors are dirty (paper dust)

SC593	D	Decurler Unit Over Limit Error
		The over-limit sensor went on because the decurler unit has moved farther than the allowed distance (±13.85 mm).
		Adjust the distance
		Cycle the machine off/on

SC594	D	Decurler Unit HP Error
		The decurler unit was not detected at its home position within 6 sec.
		HP sensor disconnected or broken
		Sensor defective

SC595 RTB 42

SC595	D	TDCU Hardware Error
-------	---	---------------------

A command was received from the TDCU due to a stepper motor error, FPGA configuration error, or FPGA power source error.

- TDCU harness disconnected or broken
- TDCU board defective
- Stepper motor(s) defective

**Note**: The stepper motors directly controlled by the TDCU include: fusing motor, drum cleaning motor, development motor, drum motor, PTR motor, transfer timing motor.

SC599	D	P <del>aper Height Sensor Error</del>	
		One or more of the four paper height sensors in Tr functioning correctly.	ray 1 of the main machine is not
		Condensation on one or more of the sensors     Sensor harness damaged, defective	SC599 RTB 43: Correction to service
		Sensor connector loose, broken, defective	manual
		IOB defective	_

### SC600: Communications

SC620	D	ADF Communication Error
		No response from the ADF after connection to the main machine or an error occurred after connection.
		ADF I/F cable disconnected or loose
		Electrical noise on the line (noise filter required)
		ADF defective
		IPU board defective

SC621 D Peripheral Communication Error

	The UART generated an error when the finisher was connected.
	Peripheral I/F cable disconnected or broken
	Peripheral main board disconnected or defective
	BCU defective
	IOB defective

SC622	D	Paper Bank Communication Error
		The UART generated an error.
		Poor bank drawer connection
		BCU harness disconnected or broken
		IOB harness disconnected or broken
		BCU defective
		IOB defective

SC625	D	TDCU Master Communication Error
SC626	D	TDCU Slave Communication Error
		An error was generated by ASAP protocol. ASAP (Aggregate Server Access Protocol) provides the high-availability data transfer mechanism over IP networks.
		TDCU harness disconnected or broken IOB harness disconnected or broken
		TDCU defective
		IOB defective

SC641	D	Engine-Controller Communication Error: No Response	GW
		There was no response to a frame sent from The Controller Board To the engine.	
		Cycle the machine off/on.	

SC652	В	@Remote Service ID2 Mismatch Error 1	GW	

One of the following problems occurred with ID2 stored in NVRAM:

- A control board from another machine where Cumin was set up was installed in this machine.
- NVRAM was replaced with the NVRAM from another machine.
- If Cumin has already been installed, confirm that the NVRAM is compatible for use with Cumin.
- If Cumin has just been installed, confirm that the NVRAM is compatible for use with Cumin, clear the Cumin setting, set the common authentication, then try again.

SC653	D	@Remote Service ID2 Mismatch Error 2	GW
		One of the following problems exist with the ID2 stored in NVRAM  ID2 has less than 17 digits  A non-printable character exists in ID2  ID2 is all spaces  ID2 is NULL	:
		<ul> <li>Replace NVRAM.</li> <li>Clear the Cumin setting, set the common authentication, then</li> </ul>	try again.

SC669	D	EEPROM Communication Error
		After three re-tries there was still no response from the EEPROM on the BCU.
		Electrical noise
		Cycle machine off/on
		If problem persists, install a noise filter

SC670	D	Engine start failure	GW
		The engine did not respond within 30s after power on, or the engine went suddenly at power on or during warm up because a communication reset occurred between the BCU and the controller.	down
		<ul> <li>A fused has blown on PSU 1</li> <li>BCU installed incorrectly</li> <li>BCU defective</li> </ul>	

SC672 RTB 94

SC671	D	Incorrect board detected	GW
		An illegal engine board was detected at power on.	
		Replace BICU	

SC678-01	D	Transport Cooling Unit CTB+24V Power Supply Error
SC678-02	D	Transport Cooling Unit CTB+24VINT Power Supply Error
		The control board of the transport cooling unit detected that the power supply was off and not functioning.
		Unit PSU harness disconnected or broken
		Unit main board harness disconnected or broken
		Motor harness disconnected or broken
		Fan harness disconnected or broken
		Unit PSU defective
		Main unit control board defective
		Motor defective
		Fan motor defective

RTB 28 SC681

SC681	D	Toner Cartridge RFID Communication Error
		A communication error occurred when the RFID tried to communicate with the RFID receptor on the toner cartridge. This SC was issued after the third attempt to communicate failed.
		RFID reader/writer defective
		ASAP I/F disconnected
		No ID chip on toner cartridge (replace toner cartridge)
		Electrical noise

SC682 RTB 87

SC68	2	D	RFID ID Chip Communication Error: PCU
------	---	---	---------------------------------------

RFID made three unsuccessful attempts to communicate with the ID chip on the PCU. • ID chip data corrupted

- ID chip installed incorrectly
- ID chip missing
- Electrical noise
- Replace RFID controller board
- Replace PCU

SC683	С	Toner Cartridge RFID Unit Check Error	
		The RFID unit communication check failed regardless of whether toner cartridges have been installed or not.	
Electrical noise		Electrical Holle	
		Cycle the machine off/on	

SC684 **RTB 90** 

SC684	D	Fusing Unit ID Chip Error	
		The machine made three unsuccessful attempts to communicate with the fusing unit ID chip.	
	ID chip missing		
		ID chip data corrupted	
		ID chip disconnected or broken	
		Electrical noise	

S	C685	С	Power Supply Error 1
			PSU 2 failure.
			PSU 2 harness disconnected or broken
			PSU 2 defective
			Interlock relay board defective

SC686	С	Power Supply Error 2
-------	---	----------------------

GAVD Transmission Error (M)

PSU 2 failure. A fuse has blown on PSU 2 on the back of the main machine.

PSU 2 harness disconnected or broken

SC692

The machine cannot communicate (data read/write) normally with the M LDB (laser control ASIC).

- Cycle the machine off/on
- Replace BCU harness or BCU
- Laser unit defective

SC693	D	GAVD Transmission Error (Y)
		The machine cannot communicate (data read/write) normally with the Y LDB (laser control ASIC).
		Cycle the machine off/on
		Replace BCU harness or BCU
		Laser unit defective

# SC700: Peripherals

SC701	D	ADF original pickup operation error
		Even though the pickup motor is rotating clock-wise, the pickup roller home position sensor cannot detect the position of the pickup roller.
		<ul> <li>Pickup roller HP sensor harness loose, disconnected, defective</li> <li>Pickup roller HP sensor defective</li> <li>Pickup motor harness loose, disconnected, defective</li> <li>Pickup motor defective</li> </ul>
		ADF control board defective

SC705	D	ADF bottom plate lift motor
		The bottom plate HP sensor did not detect the home position of the bottom plate after the bottom plate lift motor switches on and lowers the bottom plate.
		The bottom plate position sensor does not detect the position of the plate after the lift motor switches on and raises the bottom plate.
		ADF feed motor disconnected, defective
		Bottom plate HP sensor disconnected, defective
		ADF main board defective

SC719-1	D	Downstream CIT Communication Error
		The downstream Cover Interposer Tray (CIT) failed to respond to three attempts by the main machine to communicate.
		CIT I/F cable disconnected, loose, or broken
		CIT main board harness disconnected or broken
		Main machine controller harness disconnected or broken
		CIT main board defective
		Main machine controller board defective

SC719-2	D	Downstream MFU Communication Error	
		The downstream Multi Folding Unit (MFU) failed to respond to communication from the main machine.	
		MFU I/F cable disconnected, loose, or broken	
		MFU main board harness disconnected or broken	
		Main machine controller harness disconnected or broken	
		MFU main board defective	
		Main machine controller board defective	

SC719-3	D	Downstream HCS Communication Error	
		The unit installed immediately to the left of the HCS failed to respond.	
		HCS I/F cable disconnected, loose, or broken	
		HCS main board harness disconnected or broken	
		Main machine controller harness disconnected or broken	
		<ul> <li>HCS main board defective</li> <li>Main machine controller board defective</li> </ul>	

SC719-5	D	Downstream FIN Communication Error
---------	---	------------------------------------

The downstream Finisher (FIN) failed to respond to communication from the main machine.
FIN I/F cable disconnected, loose, or broken
FIN main board harness disconnected or broken
Main machine controller harness disconnected or broken
FIN main board defective
Main machine controller board defective

SC719-6	D	Downstream RB Communication Error	
		The downstream Ring Binder (RB) failed to respond to communication from the main machine.	
		RB I/F cable disconnected, loose, or broken	
		RB main board harness disconnected or broken	
		Main machine controller harness disconnected or broken	
		<ul><li>RB main board defective</li><li>Main machine controller board defective</li></ul>	

SC720-1	D	Entrance roller motor error	Booklet Finisher (D512)
		Motor stopped operating, due to a physical obstruction or another problem.	
		Check for and remove any physical obstructions around the motor and timing belts	
		Motor harness or connector disconnected or defective	
		Motor defective	

	SC720-2	D	Junction gate motor error	Booklet Finisher (D512)
--	---------	---	---------------------------	-------------------------

One or both motors at the junction gates (stapler junction gate motor, proof tray junction gate motor) stopped operating, due to a physical obstruction or another problem.

• Check for and remove any physical obstructions around the motor and timing belt

- Motor harness or connector disconnected or defective
- Motor defective
- Finisher main board defective

SC720-3	D	Punch roller motor (rear) error	Booklet Finisher (D512)
	Motor stopped operating, due to a physical obstruction or another problem.      Check for and remove any physical obstructions around the motor and timing belts		cal obstruction or another problem.
			obstructions around the motor and
		<ul> <li>Motor harness or connector disconnected or defective</li> <li>Motor defective</li> <li>Finisher main board defective</li> </ul>	

SC720-4	D	Registration motor error	Booklet Finisher (D512)
		Motor stopped operating, due to a physical obstruction or another problem.	
		Check for and remove any physical obstructions around the motor and timing belts	
		Motor harness or connector disconnected or defective	
		Motor defective	
		Finisher main board defective	

SC721-1	D Front jogger fence motor	D	Booklet Finisher (D512)
---------	----------------------------	---	-------------------------

The system did not detect the front jogger fence at its home position (or out of its home position) within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- Check for and remove any obstructions around the jogger fence
- Motor harness or connector disconnected or defective
- Front jogger fence HP sensor dirty
- Front jogger fence HP sensor harness or connector disconnected or defective
- Front jogger fence HP sensor defective
- Front jogger fence motor defective
- Finisher main board defective

SC721-2	D	Rear jogger fence motor	Booklet Finisher (D512)
		The system did not detect the rear jogger fence at its home position (or out of its home position) within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		Check for and remove any obstructions around the jogger fence	
		<ul> <li>Motor harness or connector disconnected or defective</li> <li>Rear jogger fence HP sensor dirty</li> <li>Rear jogger fence HP sensor harness or connector disconnected or defective</li> <li>Rear jogger fence HP sensor defective</li> <li>Rear jogger fence motor defective</li> <li>Finisher main board defective</li> </ul>	

SC723	B Positioning roller rotation motor error	SC723	Finishers (D512/D513)
-------	---	-------	-----------------------

The motor that drives the rotation of the positioning sponge roller is not operating.

Cycle the machine off/on

Check for and remove any obstruction that blocks the operation of the roller or roller arm

Motor harness loose, defective

Positioning roller HP sensor dirty

Positioning roller HP sensor harness or connector disconnected or defective

Motor defective

Sensor defective

• Finisher main board defective

SC724	В	Positioning roller motor	Finishers (D512/D513)	
		The motor that lowers and raises the positioning roller above the stapling tray not operating.		
		Cycle the machine off/on		
		<ul> <li>Check for and remove any obstruction that blocks the operation of the roller arm</li> </ul>		
		Motor harness loose, defective		
		Positioning roller HP sensor dirty		
		Positioning roller HP sensor harness or connector disconnected or defective		
		Motor defective		
		Sensor defective		
		Finisher main board defective		

SC725	В	Exit guide motor error	Finishers (D512/D513)
-------	---	------------------------	-----------------------

The motor that opens and closes the exit guide at the shift tray exit is not operating correctly.

- Motor harness or connector disconnected or defective
- Check for and remove any obstruction that interferes with the operation of the exit guide
- Exit guide plate HP sensor dirty
- Exit guide plate HP sensor harness or connector disconnected or defective
- Motor defective
- Sensor defective
- Finisher main board defective

SC726	В	Shift jogger retraction motor error 1	Finishers (D512/D513)
		The drag roller arm with the sponge roller did no the prescribed time.	t return to its home position within
		Arm blocked by an obstruction	
		Motor harness disconnected or defective	
		HP sensor harness disconnected or defective	е
		Motor defective	
		HP sensor defective	

SC728	В	Shift jogger retraction motor error 2	Finishers (D512/D513)
		The side fences at the exit of the finisher did not positions within the prescribed time. The 1st occ 2nd occurrence causes this SC code.	·
		If the motor is rotating, positioning roller HP ser	nsor disconnected or defective
		-or-	
		If the motor is not rotating:	
		Remove any obstruction blocking movement	
		Positioning roller motor overloaded due to obstruction	
		Positioning roller motor disconnected, def	ective
		Main board connectors disconnected or a	defective
		Finisher main board defective	

D	Proof (upper) tray exit motor error	Finishers (D512/D513)	
	Motor drive board output abnormal, or short circuit detected on the board. The 1st failure issues this SC code.		
	Motor disconnected, defective		
	Finisher connection to motor loose, defective		
	Motor blocked by an obstruction		
	Motor defective		
	Cl.:(4.1	F:::.L /D512 /D513)	
D	Shift fray exil motor error	Finishers (D512/D513)	
	The shift tray exit motor is not operating.		
	Motor harness disconnected or defectiv	e	
	Motor is blocked by an obstruction		
	Motor defective		
	Finisher main board defective		
D	Stapler exit motor error	Finishers (D512/D513)	
	The stapler exit motor is not operating.		
	Motor harness disconnected or defectiv	e	
	Motor is blocked by an obstruction		
	Motor defective		
	Finisher main board defective		
D	Proof tray junction gate motor error	Finishers (D512/D513)	
	The proof tray JG HP sensor did not detect the home position within 2 s.	e junction gate at (or out of) its	
	Proof junction gate HP sensor dirty		
	Sensor harness or connector disconnect	ed or defective	
	D	Motor drive board output abnormal, or short 1st failure issues this SC code.  Motor disconnected, defective Finisher connection to motor loose, defeed to Motor blocked by an obstruction Motor defective  District tray exit motor error  The shift tray exit motor is not operating.  Motor harness disconnected or defective Motor is blocked by an obstruction Motor defective Finisher main board defective  District motor error  The stapler exit motor is not operating.  Motor harness disconnected or defective Motor is blocked by an obstruction Motor defective Finisher main board defective  Proof tray junction gate motor error  The proof tray JG HP sensor did not detect the home position within 2 s.	

• Proof junction gate motor harness or connector disconnected or defective

Sensor defectiveMotor defective

• Finisher main board defective

SC735	D	Stapler junction gate motor error	Finishers (D512/D513)	
		The stapler JG HP sensor did not detect the stapler junction gate at (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		Stapler junction gate HP sensor dirty		
		<ul> <li>Sensor harness or connector disconnected or defective</li> <li>Stapler junction gate motor harness or connector disconnected or defective</li> <li>Sensor defective</li> </ul>		
		Motor defective		
		Finisher main board defective		

SC737	В	Pre-stack motor error	Finishers (D512/D513)
		The pre-stack motor that moves the pre-st	ack roller is not operating.
		Motor harness disconnected or defe	ective
		<ul> <li>Motor is blocked by an obstruction</li> </ul>	
		Pre-stack roller HP sensor dirty	
		<ul> <li>Pre-stack roller HP sensor harness or connector disconnected or defective</li> </ul>	
		Motor defective	
		Sensor defective	
		Finisher main board defective	

SC738	В	Pre-stack jg motor error	Finishers (D512/D513)
		The pre-stack JG motor that operates operating. The pre-stack junction gate (or out of) its home position within the	e sensor did not detect the junction gate in
		Pre-stack JG motor harness or connector disconnected or defective	
		Pre-stack JG HP sensor dirty	
		Sensor harness or connector disconnected or defective	
		Motor defective	
		Sensor defective	
		Finisher main board defective	

SC740	В	Finisher corner stapler motor error	Finishers (D512/D513)
		The stapler motor did not switch off within the prescribed time. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.  • Number of sheets in the stack exceeded the limit for stapling  • If error occurred during stapling, stapler rotation sensor 1 defective (replace stapler)  • If error did not occur during stapling: staple jam:  1. Motor blocked by an obstruction  2. Stapler motor harness disconnected or defective	
		3. Corner stapler motor defective	
		4. Finisher main board defective	

SC741	В	Finisher Corner Stapler Rotation Motor Error	Finishers (D512/D513)	
		The stapler did not return to its home position (or did not leave its home position) within the specified time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		If the motor is running,		
	Stapler rotation home position sensor harnesses are broken, loose, or defective      Stapler rotation home position sensors are defective			
	If the motor is not running:			
		<ol> <li>Motor is blocked by an obstruction</li> <li>Motor harness is disconnected or defective</li> </ol>		
3. Motor is defective				
SC742	В	Corner stapler movement motor error	Finishers (D512/D513)	

The stapler did not return to its home position (or leave its home position) within the specified time after stapling. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- If the motor is running,
  - 1. Stapler home position sensor harness is broken, loose, or defective
  - 2. Stapler home position sensor is defective
- If the motor is not running:
  - 1. Motor is blocked by an obstruction
  - 2. Motor harness is disconnected or defective
  - 3. Motor is defective

SC743	D	Booklet Stapler Motor Error	Booklet Finisher (D512)
			rt stapling within the prescribed time. The 2nd occurrence causes this SC code.
		Front motor harness disconnected or defective	
		Front motor overloaded due to obstruction	
		Front motor defective	
		Finisher main board defective	

SC745	В	Feed-out belt motor error	Finishers (D512/D513)	
		The stack feed-out belt HP sensor did not activate within the specified time after the stack feed-out belt motor turned on. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		If the motor is operating	If the motor is operating	
		1. Stack feed-out belt HP sensor harness disconnected or defective		
		2. Sensor defective		
		If the motor is not operating:		
		1. Feed-out belt motor blocked by an obstruction		
		2. Motor harness disconnected or defective		
		3. Motor defective		
		4. Finisher main board defective		

SC746	Stack plate motor error 1: front motor	Finishers (D512/D513)
-------	--	-----------------------

The stack plate HP sensor (front) did not activate within the prescribed time after the motor turned on. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- If the motor is operating
  - 1. Front stack plate HP sensor harness disconnected or defective
  - 2. Front stack plate HP sensor defective
- If the motor is not operating:
  - 1. Motor blocked by an obstruction
  - 2. Motor harness disconnected or defective
  - 3. Motor defective
  - 4. Booklet finisher main board defective

SC747	В	Stack plate motor error 2: center motor	Finishers (D512/D513)	
		The stack plate HP sensor (center) did not activate within the prescribed time after the motor turned on. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		If the motor is operating		
		1. Center stack plate HP sensor harness disconnected or defective		
		Center stack plate HP sensor defective     If the motor is not operating:		
		1. Motor blocked by an obstruction		
		2. Motor harness disconnected or defective		
		3. Motor defective		
		4. Booklet finisher main board defective		

The stack plate HP sensor (rear) did not activate within the prescribed time after the motor turned on. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- If the motor is operating
  - 1. Rear stack plate HP sensor harness disconnected or defective
  - 2. Rear stack plate HP sensor defective
- If the motor is not operating:
  - 1. Motor blocked by an obstruction
  - 2. Motor harness disconnected or defective
  - 3. Motor defective
  - 4. Booklet finisher main board defective

SC750 D512 RTB 4

SC750	В	Proof tray lift motor error	Finishers (D512/D513)
		The shift tray paper height sensor did not change its status within the prescribed time after the tray was raised or lowered. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		Lift motor disconnected, defective	
		<ul> <li>Paper height sensor disconnected, defective</li> </ul>	
		<ul> <li>Finisher main board connection to motor loose</li> </ul>	
		Finisher main board defective	

SC753	D	Drag drive motor error	Finishers (D512/D513)	
		The drag roller HP sensor did not detect the drag roller in (or out of) its home position within the prescribed time. (The drag drive motor drives the timing belt that rotates the drag roller at the shift tray exit.)		
		If the motor is operating	If the motor is operating	
		1. Drag roller HP sensor harness disconnected or defective		
		2. Drag roller HP sensor defective		
		If the motor is not operating:		
		1. Motor blocked by an obstruction	on	
		2. Motor harness disconnected or	defective	
		3. Motor defective		
		4. Finisher main board defective		

SC754	В	Drag roller motor error	Finishers (D512/D513)
		The drag roller motor did not turn on. (The drag roller motor drives the shaft that moves the drag roller left and right at the shift tray exit.)	
		Motor harness disconnected or d	efective
		Motor defective     Finisher control board defective	

SC755	D	Shift motor error	Finishers (D512/D513)
		The shift tray HP sensors did not detect the shift tray in (or out of) its home position within the prescribed times. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		Note: In the Finisher SR5000 (B830),	these sensors are the "half-turn" sensors.
		If the motor is operating	
		<ul><li>1. HP sensor harnesses disconnected or defective</li><li>2. HP sensor defective</li><li>If the motor is not operating:</li></ul>	
		1. Motor blocked by an obstruction	on
		2. Motor harness disconnected or	r defective
		3. Motor defective	
		4. Finisher main board defective	

The punch HP sensor did not detect the punch movement motor in (or out) of its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- If the motor is operating:
  - 1. Punch HP sensor disconnected or defective
  - 2. Punch HP sensor defective
- If the motor is not operating:
  - 1. Motor blocked by an obstruction
  - 2. Motor harness disconnected or defective
  - 3. Motor defective
  - 4. Finisher main board defective

SC761	D	Fold plate motor error	Booklet Finisher (D512)
		The fold plate moves but:	
		The fold plate HP sensor did not detect it at the home position within the specified time.	
		-or-	
		The plate remained at the home position long	ger than the specified time.
		The 1st occurrence causes a jam, and the 2n	d occurrence causes this SC code.
		If the motor is operating:	
		1. Fold plate HP sensor dirty	
		2. Fold plate HP sensor harness or connector disconnected or defective	
		3. Fold plate HP sensor defective	
		If the motor is not operating:	
		1. Fold plate motor blocked by an obst	ruction
		2. Motor harness disconnected or defe	ctive
		3. Motor defective	
		4. Finisher main board defective	

SC762 D Punch switch motor error Booklet Fir
--

The punch switch motor failed to turn on within the specified time.
Check for and remove obstruction blocking the motor
Motor harness or connector disconnected or defective
Motor defective

SC763	В	Punch movement motor error	Booklet Finisher (D512)
		The punch movement HP sensor did not detect the punch at its home position (or out of its home position) within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		Check for and remove any obstructions that block the movement of the punch unit	
		Punch movement HP sensor dirty	
		Sensor harness or connector disconnected or defective	
		Sensor defective	
		Motor defective	

SC764	D	Punch registration (CIS) error	Booklet Finisher (D512)
The system detected an error at the CIS (Contact Image Sensor) insic punch unit during paper registration for paper punching.			
	<ul> <li>Check for and remove any obstructions that block the movement of the punch unit</li> <li>Punch CIS unit harness or connectors disconnected or defective</li> </ul>		
CIS unit defective			
		Punch movement motor defective	

SC765	В	Bottom fence lift motor error	Booklet Finisher (D512)
3C/03	D	bottom tence lift motor error	bookiet rinisher (D3 1 2)

The bottom fence in the booklet fold unit did not return to the home position within the specified time.

Bottom fence mechanism overloaded due to an obstruction
Bottom fence HP sensor connector disconnected or defective
Bottom fence HP sensor defective
Bottom fence lift motor connector disconnected or defective

• Bottom fence lift motor defective

Main board defective

SC766	В	Clamp roller retraction motor	Booklet Finisher (D512)		
		The clamp roller did not return to the home	position within the specified time.		
		Clamp roller mechanism overloaded	due to an obstruction		
		Clamp roller HP sensor connector disconnected or defective			
		Clamp roller HP sensor defective			
		Clamp roller retraction motor connector disconnected or defective			
		Clamp roller retraction motor defective	/e		
		Main board defective			

SC767-1	D	Stack JG motor	Booklet Finisher (D512)
		The stack junction gate motor did not return to the home position within the prescribed time.	
		Check junction gate for obstruction	
		Stack JG HP sensor connector disconnected or defective	
		Sensor defective	
		Stack JG motor connector disconnected or defective	
		Motor defective	
		Finisher main board defective	

SC767-2	В	Stack transport unit motor	Finishers D434
---------	---	----------------------------	----------------

The stack transport unit HP sensor did not detect the stack transport unit at (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- Check for any obstruction around the motor and remove it
- Stack transport unit motor harness or connector disconnected or defective
- Stack transport unit HP sensor dirty
- Sensor harness connector disconnected or defective
- Sensor defective
- Motor defective

Finisher main board defective

SC770	В	Cover interposer lift motor 1 error CIT D518				
		In the first tray:				
			<ul> <li>The upper limit sensor did not detect the bottom plate within the specified time after the lift motor switched on to lift the bottom plate.</li> </ul>			
		The lower limit sensor did not direct the botto time after the lift motor switched on to lower				
		Note: In both cases, 1 error count indicates a jam code.	n, 2 error counts issue this SC			
		Lift motor, upper limit sensor, lower limit sens disconnected or defective	sor harnesses, connectors			
Lift motor defective						
	Upper limit sensor defective					
Lower limit sensor defective						
SC771	В	Cover interposer lift motor 2 error	CIT D518			

## In the second tray:

- The upper limit sensor did not detect the bottom plate within the specified time after the lift motor switched on to lift the bottom plate.
- The lower limit sensor did not direct the bottom plate within the specified time after the lift motor switched on to lower the bottom plate.

**Note:** In both cases, 1 error count indicates a jam, 2 error counts issue this SC code.

- Lift motor, upper limit sensor, lower limit sensor harnesses, connectors disconnected or defective
- Lift motor defective
- Upper limit sensor defective
- Lower limit sensor defective

## SC772 В Cover interposer pickup motor 1 error CIT D518 In the first tray: • While the pick-up roller motor was on, the pick-up roller HP sensor did not detect the pick-up roller at the home position within the specified number of pulses. • While the pick-up roller motor was on, the pick-up roller HP sensor did not detect the pick-up roller at the home position above the specified number of pulses. Note: In both cases, 1 error count indicates a jam, 2 error counts issue this SC code. • The pick-up motor, pick-up roller HP sensor harnesses, connectors were disconnected or defective • Pick-up motor overload due to an obstruction • Pick-up motor defective • Pick-up roller HP sensor defective

SC773 D Cover interposer pickup motor 2 error CIT D518

In the second tray:

- While the pick-up roller motor was on, the pick-up roller HP sensor did not detect the pick-up roller at the home position within the specified number of pulses.
- While the pick-up roller motor was on, the pick-up roller HP sensor did not detect the pick-up roller at the home position above the specified number of pulses.

**Note:** In both cases, 1 error count indicates a jam, 2 error counts issue this SC code.

- The pick-up motor, pick-up roller HP sensor harnesses, connectors were disconnected or defective
- Pick-up motor overload due to an obstruction
- Pick-up motor defective
- Pick-up roller HP sensor defective

SC775	В	Top Fence Motor Error	Finishers D512/D513		
		The top fence HP sensor did not detect the top fence at (or out of) the home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.			
		If the top fence motor is operating:			
		1. Top fence HP sensor dirty			
		<ol> <li>Sensor harness disconnected or defective</li> <li>Sensor defective</li> <li>If the jogger top fence motor is not operating:         <ol> <li>Top fence motor blocked by an obstruction</li> <li>Motor harness disconnected or defective</li> </ol> </li> <li>Motor defective</li> <li>Finisher main board defective</li> </ol>			

Finishers D512/D513

SC776

В

Bottom Fence Motor Error

The bottom fence HP senstor did not detect the bottom fence at (or out of) the home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- If the bottom fence motor is operating:
  - 1. Bottom fence HP sensor dirty
  - 2. Sensor harness disconnected or defective
  - 3. Sensor defective
- If the bottom fence motor is not operating:
  - 1. Bottom fence motor blocked by an obstruction
  - 2. Motor harness disconnected or defective
  - 3. Motor defective
  - 4. Finisher main board defective

SC778-1	D	Horizontal transport motor error	Multi Folding Unit (D521)
		The motor drive PCB detected an error at	the motor.
		Motor harness or connector disconn	ected or defective
		Motor or motor drive board defectiv	е

SC778-2	D	Top tray exit motor	Multi Folding Unit (D521)
		The motor drive PCB detected an error	at the motor.
		<ul> <li>Motor harness or connector disco</li> <li>Motor or motor drive board defea</li> </ul>	

SC778-3	D	Top tray jg motor	Multi Folding Unit (D521)
		The top tray JG HP sensor did not detect the top tray junction gate at (or out of) its home position. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		Top tray JG HP sensor dirty	
		Sensor harness or connector disconnected or defective	
		<ul> <li>Top tray JG motor harness or connector disconnected or defective</li> </ul>	
		Sensor defective	
		Motor or motor drive board defective	

SC778-4	D	Entrance jg motor	Multi Folding Unit (D521)		
		The entrance junction gate HP sensor did not detect the entrance junction gate at (or out of) its home position. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.			
		Entrance JG HP sensor dirty			
		Sensor harness or connector disc			
		<ul> <li>Entrance JG motor harness or co</li> <li>Sensor defective</li> </ul>	nnector disconnected or defective		
		Motor or motor drive board defe	ective		
		Moder of motor diffe bodic dete	301110		
SC779	В	1 st Stopper motor error	Multi Folding Unit (D521)		
		The 1st stopper HP sensor did not detect the 1st stopper in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.			
		1st stopper HP sensor dirty			
		Sensor harness or connector disconnected or defective			
		1st stopper motor harness or conn	ector disconnected or defective		
		Sensor defective			
		Motor or motor drive board defective			
SC783-1	В	2nd Stopper motor error	Multi Folding Unit (D521)		
30/03-1	D	Zna Sioppei moior error	Monit Folding Offit (D321)		
		The 2nd stopper HP sensor did not detect the 2nd stopper in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.			

SC783-2	В	3rd Stopper motor error	Multi Folding Unit (D521)

• Motor or motor drive board defective

• Sensor harness or connector disconnected or defective

• 2nd stopper motor harness or connector disconnected or defective

• 2nd stopper HP sensor dirty

• Sensor defective

		The 3rd stopper HP sensor did not detect the 3rd stopper in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		3rd stopper HP sensor dirty		
		Sensor harness or connector disco	nnected or	defective
		3rd stopper motor harness or cont	nector disco	onnected or defective
		Sensor defective		
		Motor or motor drive board defec	tive	
SC783-3	В	1 st Fold motor error		AAk: E-14: 11-: /D-521\
3C/83-3	В	I ST FOID MOTOR EFFOR		Multi Folding Unit (D521)
		The motor drive PCB detected an error	at the moto	r.
		Motor harness or connector disco	nnected or	defective
		Motor or motor drive board defective		
SC783-4	В	2nd Fold motor error		Multi Folding Unit (D521)
		The motor drive PCB detected an error at the motor.		r.
		Motor harness or connector disconnected or defective		defective
		Motor or motor drive board defec	tive	
SC783-5	В	Crease motor error		Multi Folding Unit (D521)
		The motor drive PCB detected an error	at the moto	r.
		Motor harness or connector disco	nnected or	defective
		Motor or motor drive board defec	tive	
				T
SC783-6	В	Dynamic roller transport motor error		Multi Folding Unit (D521)
		The motor drive PCB detected an error at the motor.		r.
		Motor harness or connector disco	nnected or	defective
		Motor or motor drive board defective		
SC783-7	В	Reg. roller transport motor error		Multi Folding Unit (D521)

		The motor drive PCB detected an error at the motor.		
		Motor harness or connector disconn	ected or defective	
		Motor or motor drive board defective	е	
		I		
SC783-8	В	Dynamic roller lift motor error	Multi Folding Unit (D521)	
		The dynamic roller HP sensor did not detect the dynamic roller in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		Dynamic roller HP sensor dirty		
		Sensor harness or connector disconnected or defective		
		Dynamic roller lift motor harness or connector disconnected or defective		
		Sensor defective		
		Motor or motor drive board defective	e	
SC783-9	В	Registration roller release motor error	Multi Folding Unit (D521)	
		The registration roller HP sensor did not detect the registration roller in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		Registration roller HP sensor dirty     Sensor harness or connector disconnected or defective		
		Registration roller release motor harness or connector disconnected or defective		
		Sensor defective		
		Motor or motor drive board defective	е	
	1	1		

Multi Folding Unit (D521)

SC783-10

В

Fold plate motor error

The fold plate HP sensor did not detect the fold plate in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- Fold plate HP sensor dirty
- Sensor harness or connector disconnected or defective
- Fold plate motor harness or connector disconnected or defective
- Sensor defective
- Motor or motor drive board defective

SC783-11	В	Jogger Fence Motor	Multi Folding Unit (D521)
		The jogger fence HP sensor did not detect the jogger fence in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		Jogger fence HP sensor dirty     Sensor harness or connector disconnected or defective	
		Jogger fence motor harness or connector disconnected or defective	
		Sensor defective	
		Motor or motor drive board defective	

SC783-12	В	Positioning Roller Motor Error	Multi Folding Unit (D521)	
		The positioning roller HP sensor did not detect the positioning roller in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		Positioning roller HP sensor dirty     Sensor harness or connector disconnected or defective     Positioning roller motor harness or connector disconnected or defective     Sensor defective		

SC783-13	В	FM2 Direct-send JG motor	Multi Folding Unit (D521)
		•	

The direct-send JG HP sensor did not detect the direct-send JG in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- FM2 direct-send JG HP sensor dirty
- Sensor harness or connector disconnected or defective
- FM2 direct-send JG motor harness or connector disconnected or defective
- Sensor defective
- Motor or motor drive board defective

SC783-14	В	FM6 Pawl motor	Multi Folding Unit (D521)
		The FM6 pawl HP sensor did not detect the FM6 pawl in (or out of) its home position. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		FM6 pawl HP sensor dirty	
		Sensor harness or connector disconnected or defective	
		FM6 pawl motor harness or connector disconnected or defective	
		Sensor defective	
		Motor or motor drive board defective	

SC786-10	D	Path junction gate error	Ring Binder (D519)
		The path junction gate that directs paper to the punch unit below is not operating correctly.	
		Physical obstruction interfering with the smooth operation of the path junction gate.	
		Path junction gate HP sensor dirty, disconnected, damaged, or out of position.	
		<ul> <li>Path junction gate motor connection harness loose, disconnected, damaged</li> <li>Path junction gate motor defective</li> </ul>	

	SC787-1	D	Entrance motor error	Stacker (D515)
--	---------	---	----------------------	----------------

		The motor drive PCB detected an error at the motor.		
		Motor harness or connector disconnected or defective		
		Motor or motor drive board c	efective	
SC787-2	D	Shift JG Motor Error	Stacker (D515)	
		The shift tray JG HP sensor did not de home position. The 1st occurrence causes this SC code	etect the shift junction gate in (or out of) its auses a jam, and the 2nd occurrence	
		Shift tray JG HP sensor dirty		
		Sensor harness or connector dis-	connected or defective	
		Shift tray JG motor harness or c	onnector disconnected or defective	
		Sensor defective		
		Motor or motor drive board def	ective	
SC787-3	В	Transport motor error	Stacker (D515)	
		The motor drive PCB detected an e	rror at the motor.	
		Motor harness or connector disconnected or defective		
		Motor or motor drive board c	efective	
SC787-4	D	Proof tray JG motor	Stacker (D515)	
30707-4		11001 lidy jo illolol	Sidekei (DS13)	
		The proof tray JG HP sensor did not detect the proof tray junction gate in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.		
		Proof tray JG HP sensor dirty		
		Sensor harness or connector disconnected or defective		
		Proof tray JG motor harness or connector disconnected or defective		
		Sensor defective		
		Motor or motor drive board defective		
SC787-5	D	Proof tray exit motor error	Stacker (D515)	

		The motor drive PCB detected an error at	he motor.		
	Motor harness or connector disconnected or defective				
		Motor or motor drive board defective	9		
SC789	В	Proof tray exit motor error	Multi Folding Unit (D521)		
		The motor drive PCB detected an error at the motor due to overload, overheating. Paper cannot exit at proof tray.			
		Motor, motor drive board defective			
SC790	D	Booklet stapler jogger motor error	Booklet Finisher (D512)		
		The jogger fence HP sensor failed to detect the position within the specified time.	ne jogger fence at the home		
		If the booklet stapler jogger motor is op	erating:		
		1. Jogger fence HP sensor harness disconnected or defective			
		2. Jogger fence HP sensor defective			
		If the jogger bottom fence motor is not operating:			
		1. Motor blocked by an obstruction			
		2. Motor harness disconnected or defective			
		3. Motor defective			
		4. Finisher main board defective			
SC791	В	Booklet stapler bottom fence motor	Booklet Finisher (D512)		
	The bottom fence failed to return to home position or failed to leave the hom position within the prescribed time.				
		An obstruction is blocking the movement	t of the bottom fence		
		Motor harness disconnected or defective	e		
	Bottom fence HP sensor disconnected or defective		r defective		
		Motor defective			
		Sensor defective			
CC700 1			D: D: 1 (D:10)		
SC792-1	D	Junction gate error	Ring Binder (D519)		

Detected at HP after the time prescribed to leave the HP had elapsed (more than 36 pulses) (1 detection, jam, twice detected, SC error)

-or

Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 22 pulses) (1 detection, jam, twice detected, SC error)

- Path JG motor (M201) defective
- Motor connector disconnected or defective
- Motor overload
- Path JG sensor (S203) connector disconnected or defective
- Sensor (S203) defective

SC792-2	В	Pre-punch side fence HP error	Ring Binder (D519)	
		Detected at HP after the time prescribed to lear than 400 pulses) (1st detection, jam, 2nd dete	•	
		Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 600 pulses) (1st detection, jam, 2nd detection, SC error)		
		Side jogger motor (M302) connector disconnected or defective     Motor overload		
		<ul> <li>Motor defective</li> <li>Pre-punch jogger HP sensor (S301) connector disconnected or defective</li> <li>Sensor (S301) defective</li> </ul>		

SC792-3	D	Pre-punch jogger roller HP error	Ring Binder (D519)
SC/92-3	D	Pre-punch jogger roller HP error	Ring Binder (D519)

Detected at HP after the time prescribed to leave the HP had elapsed (more than 36 pulses) (1st detection, jam, 2nd detection, SC error)
-or-

Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 22 pulses) (1st detection, jam, 2nd detection, SC error)

- Jog roller lift motor (M305) connector disconnected or defective
- Motor overload
- Motor defective
- Jog roller lift HP sensor (S309) connector disconnected or defective
- Sensor defective

SC792-4	В	Ring binder punch defective	Ring Binder (D519)	
		One or more of the following occurred:		
		Punch unit not detected at initialization.		
		No motor rotation detected at HP at 30 ms after	the DC motor turned on	
		No encoder pulse detected at HP at 5 ms after t	he DC motor turned on	
		Not detected at HP at 400 ms after the DC motor turned on		
		Punch motor (M304) connector disconnected or defective		
		Motor overload		
		<ul> <li>Motor defective</li> <li>Punch HP sensor (S302) connector disconnected or defective, or sensor defective</li> </ul>		
	Punch encoder sensor (S303) connector disconnected or defective, sensor defective			

SC792-5 B Paddle roller HP error Ring Binder (D519)

Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)

-or
Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)

• Paddle roller lift motor (M603) connector disconnected or defective

- Motor overload
- Motor defective
- Paddle roller HP sensor (S602) connector disconnected or defective
- Sensor defective

SC792-6	В	Jogger fence 1 error	Ring Binder (D519)		
		Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)			
		-or-	-or-		
		Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)			
		<ul> <li>Jogger fence 1 motor (M604) connector, disconnected or defective</li> <li>Motor defective</li> </ul>			
		<ul> <li>Motor overload</li> <li>Side fence 1 HP sensor (S601) connector, disconnected or defective</li> <li>Sensor defective</li> </ul>			

SC792-7	B	logger fence 2 error	Ring Binder (D519)
3C/9Z-/	В	Jogger tence 2 error	king binder (D319)

Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)
-orDetected at HP after the time prescribed to leave the HP had elapsed (more

Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)

- Jogger fence 2 motor (M606) connector, disconnected or defective
- Motor defective
- Motor overload
- Side fence HP sensor 1 (Só11) connector disconnected or defective
- Sensor defective

SC792-8	В	Stack tamper HP error	Ring Binder (D519)	
		Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)  -or-  Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)  • Stack tamper motor (M607) connector, disconnected or defective  • Motor defective  • Motor overload  • Stack tamper HP sensor (S612) connector disconnected or defective  • Sensor defective		

SC792-9	В	Pre-bind jogger clamp HP error	Ring Binder (D519)
JC/ 72-7	0	Tre-billa logger clailib Fil error	Killy billder (D3 17)

Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)

-or-

Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)

- Spine clamp motor (M605) connector disconnected or defective
- Motor defective
- Motor overload
- Clamp HP sensor (S603) connector disconnected or defective
- Sensor defective

SC792-10	В	Binder unit run-out error	Ring Binder (D519)	
		Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)		
		-or-		
		Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)		
		Run-out press roller motor (M610) connector disconnected or defective     Motor defective		
		Motor overload		
		Run-out roller HP sensor (S614) connector disconnected or defective		
		Sensor defective		

SC792-11	В	Clamp thickness error	Ring Binder (D519)	
		50-sheet detection sensor (S606) went OFF during pre-bind jogging was 100-sheet thickness was detected. (1st detection jam, 2nd detection serror)		
		-or-		
		50-sheet detection sensor went OFF at initialization when the clamp motor to the open position.		
		<ul> <li>50-sheet detection sensor (S606) connector disconnected or defective</li> <li>Sensor defective</li> </ul>		

SC792-12	В	Alignment pin error	Ring Binder (D519)	
Not detected at HP after the time prescribed to arrive a (more than 400 ms) (1st detection, jam, 2nd detection,			•	
		Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)		
		<ul> <li>Alignment pin motor (M602) connector disconnected or defective</li> <li>Motor overload</li> <li>Motor defective</li> </ul>		
Motor detective     Alignment pin HP sensor (S604) connector disconnected of     Sensor defective		disconnected or defective		

SC792-13	В	Pre-bind jogger shutter error	Ring Binder (D519)		
		Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)			
		-or-	or-		
		Detected at HP after the time prescribed to leave the HP had elapsed (more han 400 ms) (1st detection, jam, 2nd detection, SC error)			
		Shutter motor (M608) connector disconnected or defective			
		Motor overload			
		Motor defective			
		Shutter HP sensor (S605) connector disconnected or defective			
		Sensor defective			

Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)

Detected at HP after the time prescribed to leave the HP had elapsed (more than 400 ms) (1st detection, jam, 2nd detection, SC error)

- 50/100 adjustment motor (M702) connector disconnected or defective
- Motor overload
- Motor defective
- Ring switch HP sensor (S706) connector disconnected or defective, or sensor defective
- Ring switch timing sensor (S707) connector disconnected or defective, or sensor defective

SC792-15	В	Timing sensor interval error	Ring Binder (D519)	
		The bind timing sensor (S702) remained ON or OFF longer than the prescribed time (1500 ms) during initialization or ring binding (1st detection: jam, 2nd detection: SC error)		
		Clamp unit motor (M701) connector disconnected or defective  Motor overload  Motor defective  Bind timing sensor (S702) connector disconnected or defective  Sensor defective		

SC792-16	В	Clamp unit HP error	Ring Binder (D519)
----------	---	---------------------	--------------------

At initialization or during ring binding, did not arrive at the home position within the prescribed time (1500 ms) (1st detection: jam, 2nd detection: SC error)

-or
Detected at HP after the time prescribed to leave the HP had elapsed (more than 1500 ms) (1st detection, jam, 2nd detection, SC error)

- Clamp unit motor (M701) connector disconnected or defective
- Motor overload
- Motor defective
- Clamp unit HP sensor (S701) connector disconnected or defective
- Sensor defective

SC792-17	В	Spine alignment error	Ring Binder (D519)
		During pin alignment operation, the pin did return to the home position within the prescretry failed within the same time limit.	
	<ul> <li>Alignment pin motor (M602) connector disconnected or defective</li> <li>Motor overload</li> </ul>		or disconnected or defective
		<ul> <li>Motor defective</li> <li>Alignment pin HP sensor (S604) connector disconnected or defective or sensor defective</li> </ul>	
	<ul> <li>Alignment pin up sensor (S610) connector disconnected or defeors or sensor defective</li> </ul>		ector disconnected or defective,
Stack not jogged correctly, or not punched correctly		ched correctly	

SC792-18	В	Binder unit not detected	Ring Binder (D519)
		The binder unit could not be detected at initialization	tion.
		Drawer connector disconnected or defective	)
		Drawer connector defective	

SC792-19	В	Output belt unit rotation error	Ring Binder (D519)
			_

Detected at HP after the time prescribed to leave the HP had elapsed (more than 800 pulses) (1st detection, jam, 2nd detection, SC error)

-orNot detected at HP after the time prescribed to arrive at the HP had elapsed (more than 2300 pulses) (1st detection, jam, 2nd detection, SC error)

• Output belt rotation motor (M403) connector disconnected or defective

• Motor overload

• Motor defective

• Output belt rotation HP sensor (S403) connector disconnected or defective

• Sensor defective

SC792-20	В	Output belt 1 HP error	Ring Binder (D519)
		Detected at HP after the time prescribed to leave the HP had elapsed (than 200 pulses) (1st detection, jam, 2nd detection, SC error)	
		-or-	
		Not detected at HP after the time prescribed to arrive at the HP had elapsed (more than 2125 pulses) (1st detection, jam, 2nd detection, SC error)	
		Output belt 1 motor (M401) connector disconnected or defective	
		Motor overload	
		Motor defective	
		Output belt 1 HP sensor (S401) connector disconnected or defective	
		Sensor defective	

SC792-21	В	Output belt 2 HP error	Ring Binder (D519)

Detected at HP after the time prescribed to leave the HP had elapsed (more than 200 pulses) (1st detection, jam, 2nd detection, SC error)

-orNot detected at HP after the time prescribed to arrive at the HP had elapsed (more than 3130 pulses) (1st detection, jam, 2nd detection, SC error)

• Output belt 2 motor (M402) connector disconnected or defective

- Motor overload
- Motor defective
- Output belt 2 HP sensor (\$402) connector disconnected or defective
- Sensor defective

SC792-22	В	Stack height error	Ring Binder (D519)
		Stack height sensor remained ON while moving toward the top.	
		-or-	
		The sensor did not go ON within 6 sec. after the motor turned on.	
		Stacker motor (M501) connector disconnected or defective	
		Motor overload	
		Stack height sensor (\$502) connector disconnected or defective	
		Sensor defective	

Although the stacker was full at the start and end of stacker operation with the stacker full (stacker sensors ON together), no documents were detected (also when documents were leaning)

-or-

Although the stacker was detected full with the stacker stopped, no documents were detected within 2 sec.

(1st detection jam, 2nd detection SC error)

- Stacker HP sensor (S501) connector disconnected or defective, or sensor defective
- Stacker height HP sensor (S502) connector disconnected or defective, or sensor defective
- Stacker detect sensor (S504) disconnected or defective, or sensor defective

SC793-1	В	Shift motor error	Stacker (D515)
		The shift roller HP sensor did not detect the shift roller position within the prescribed time. The 1st occurrenc 2nd occurrence causes this SC code.	•
		Shift roller HP sensor dirty     Sensor harness or connector disconnected or de     Check for and remove any obstructions that inte     of the motor	
		Shift motor harness or connector disconnected a     Sensor defective	r defective
		Motor or motor drive board defective	

The front jogger fence HP sensor did not detect the front jogger fence at (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- Front jogger fence HP sensor dirty
- Sensor harness or connector disconnected or defective
- Check for and remove any obstructions that interfere with the operation of the motor
- Motor harness or connector disconnected or defective
- Sensor defective
- Motor or shift motor drive board defective

SC793-3	В	Rear Jogger Fence Motor Error	Stacker (D515)
		The rear jogger fence HP sensor did not detect the recof) its home position within the prescribed time. The 1 jam, and the 2nd occurrence causes this SC code.	
		Rear jogger fence HP sensor dirty     Sensor harness or connector disconnected or de	efective
		Check for and remove any obstructions that interfere with the operation of the motor	
	Motor harness or connector disconnected or defective		fective
		Sensor defective	
		Motor or shift motor drive board defective	

The jogger fence retraction HP sensor did not detect the jogger fences at (or out of) their home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- Jogger fence retraction HP sensor dirty
- Sensor harness or connector disconnected or defective
- Check for and remove any obstructions that interfere with the operation of the motor
- Motor harness or connector disconnected or defective
- Sensor defective
- Motor or shift motor drive board defective

SC793-5	В	Sub jogger motor error	Stacker (D515)
		The sub jogger HP sensor did not detect the sub jogger home position within the prescribed time. The 1st occur and the 2nd occurrence causes this SC code.	
		Sub jogger fence HP sensor dirty     Sensor harness or connector disconnected or de	fective
		Check for and remove any obstructions that interfere with the operation of the motor	
	Motor harness or connector disconnected or defective		fective
		Sensor defective	
		Motor or shift motor drive board defective	

SC793-6	В	LE Stopper Motor Error	Stacker (D515)

The LE stopper HP sensor did not detect the leading edge stopper at (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.

- LE stopper HP sensor dirty
- Sensor harness or connector disconnected or defective
- Check for and remove any obstructions that interfere with the operation of the motor
- Motor harness or connector disconnected or defective
- Sensor defective
- Motor or shift motor drive board defective

SC793-7	В	Tray lift motor error	Stacker (D515)
		When the tray was ascending (or descending), the sta sensor did not change at the prescribed time to detect and adjust the height of the tray. The 1st occurrence of 2nd occurrence causes this SC code.	t the height of the stack
		<ul> <li>Check for and remove any obstructions that interfere with the operation of the tray lift motor or paper height sensor actuator</li> </ul>	
		Sensor actuator loose or broken	
		Sensor harness or connector disconnected or de	efective
		<ul> <li>Motor harness or connector disconnected or defective</li> <li>Sensor defective</li> </ul>	
		Motor defective	

SC793-8	D	Shift tray exit motor error	Stacker (D515)
		The motor drive PCB detected an error at the motor.	
	Motor harness or connector disconnected or defective		fective
		Motor or motor drive board defective	

SC799-1	D	Trimming blade motor error	Trimmer (D520)
---------	---	----------------------------	----------------

The trimming blade HP sensor did not detect the blade at (or out of) its home position within the prescribed time during trimming. The 1st detection causes a jam signal if the error occurred during cutting. The 2nd detection causes this SC code if the error occurred at the start or end of cutting.

- Check for and remove any obstacles (jammed paper scraps) around the blade, motor, or sensor
- Trimming blade HP sensor dirty
- Sensor harness or connector disconnected or defective
- Trimming blade motor harness or connector disconnected or defective
- Motor defective
- · Trimming unit main board defective

SC799-2	В	Press roller motor error	Trimmer (D520)	
		The press roller HP sensor did not detect the press roll position within the prescribed time. The 1st occurrence 2nd occurrence causes this SC code.		
		Check for and remove any obstacles around the motor and sensor		
		<ul> <li>Press roller motor HP sensor dirty</li> <li>Sensor harness or connector disconnected or defective</li> </ul>		
		<ul> <li>Press roller motor harness or connector disconnected or defective</li> <li>Motor defective</li> </ul>		
		Trimming unit main board defective		

SC799-3	В	Cut Position Motor Error	Trimmer (D520)		
		The cut position HP sensor did not detect the cut position stopper at (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.			
		Check for and remove any obstacles around the motor and sensor			
		Cut position HP sensor dirty			
		Sensor harness or connector disconnected or de	Sensor harness or connector disconnected or defective		
		<ul> <li>Cut position motor harness or connector disconnected or defective</li> </ul>			
		Motor defective			
		Trimming unit main board defective			

## SC 800: Firmware

SC816	D	Energy save I/O subsystem error				
		An error was detected in the signal from the ASIC (controller board) which controls the STR (Suspend to RAM) function.				
			<b>Note</b> : STR is a feature of this machine that minimizes energy consumption while the machine is in the energy saver mode.			
		Reboot the ma     Replace the co				
			SCS			
		SC816-5	Machine attempted to enter STR mode before engine was OFF.			
		00017.00	Sub System			
		SC816-39	Error occurred during system start up.			
		CC014 FO	Hardware			
		SC816-50	Printer version only. Not used for this machin	ne.		

0

		NCS (Network Control Service)
	SC816-67	An error occurred in the access control port list:  Number of registrations exceeded 125  Data notifications exceeded 12  Data extension incorrect
	SC816-79	Sub System
	30010-79	Message mismatch.
	SC816-90	Hardware/System
		A forced system reset (WDOG) occurred.

SC819	D	Fatal kernel e	error	GW		
			trol error, a RAM overflow occurred during system pro Illowing messages was displayed on the operation po	Ü		
		<ul> <li>System program defective</li> <li>Controller board defective</li> <li>Optional board defective</li> <li>Replace controller firmware</li> </ul>				
		0x5032	HAIC-P2 decompression error  Error occurred in the compression/decompression of ASIC Veena in HAIC-P2.  If EFI (Fiery Controller) is connected, refer to the EFI EFI is not connected:  • HDD defective  • System memory defective			
		0x6261	HDD Defective  There was no response from HDD. The power suppl HDD may have been interrupted suddenly.  • Re-format HDD.  • Replace HDD	ly to the		

	554C	USB loader defect
		USB loader was detected as defective.
	Note: For more details about these SC code errors, execute SP5990 to print an SMC report so you can read the error code list. The error code is not displayed on the operation panel.	

SC820	D	Self-diagnostic Error: CPU: ASIC Interrupt Error	
		One of the following occurred:  • System program defective	
		Controller board defective	
0612		Optional board defective     Replace controller firmware	
		<b>Note</b> : For more details about these SC code errors, execute SP5990 an SMC report so you can read the error code. The error code is not on the operation panel.	•

SC833	D	Self-diagnostic error: Engine I/F ASIC		
OF30		ASIC (Mandolin) for system control could not be detected. After the PCI configuration, the device ID for the ASIC could not be checked.		
OF31		ASIC (Mandolin) for system control could not be detected. After the PCI configuration, the device ID for the ASIC could not be checked.		
OF41		The read/write check done for resident RAM on the mother board could not be done correctly.		
50B1		Could not initialize or read the bus connection.		
50B2		Value of the SSCG register is incorrect.		
		One or more MB (Motherboard) connections loose, damaged, de     MB defective	efective	

SC842	В	NAND-Flash Update Verify Error Detected.	GW
-------	---	--	----

This SC can occur when the remote ROM and ROM is updated. SCS detected a verify error when a module was written into NAND-Flash. After the second attempt, the machine returns SC819 (Kernel Error).

**Note**: SCS is the "System Control Service" or Service Resource Manager that performs processing between applications/ECS and the engine. It receives and delivers information about the engine, engine status, and job processing. It also exercises exclusive control of the operation panel and engine resources.

• Cycle the machine off/on.

SC851	В	IEEE 1394 I/F Error	GW
		Driver setting incorrect and cannot be used by the 1394 I/F.	
		NIB (PHY), LINK module defective; change the Interface Board	
		Controller board defective	

SC853	В	Wireless LAN Error 1	G	€W
	During machine start-up, the machine can access the board that holds the wireless LAN (Bluetooth), but not access the wireless LAN card.		nolds the	
Wireless LAN card missing (was removed)				

SC854	В	Wireless LAN Error 2	GW
		The board that holds the wireless LAN card (Bluetooth) could be accessed, but the wireless LAN card could not be accessed while the machine was operating.	
		Wireless LAN card has been removed.	

SC855	В	Wireless LAN Error 3	GW
		An error was detected for the wireless LAN card (802.11b or Bluetooth).	
		Wireless card not installed correctly.	
		Wireless LAN card defective	

SC856	В	Wireless LAN Error 4	GW
		An error was detected for the wireless LAN board (Bluetooth).	

Wireless LAN card board defective.
PCI connector disconnected or defective.

SC857	В	USB I/F Error	GW
		The USB driver is unstable and generated an error.	
		USB board defective	
		Controller board defective	

SC858	A	Data Encryption Error 1	GW	
30030	A	These are errors of the HDD Data Encryption Option D377.		
	0	Key Acquisition		
		Key could be acquired.		
		Replace the controller board		
	1	HDD Key Setting Error		
		The key was acquired but the HDD coul	d not be set.	
		Turn the machine power off/on sev	veral times.	
		Replace the controller board.		
	2	NVRAM Read Error		
		NVRAM data conversion failed (mismat	ch with nvram.conf)	
		Replace the NVRAM		
	30	NVRAM Before Replace Error		
		DFU. May occur during development.		
		Turn the machine power off/on sev	veral times.	
		Replace the controller board.		
	31	Other Error		
		An unexpected error occurred while data same as SC991. See SC991 below.	ta was being converted. This error is the	

20050		Data Encryption Error 2	GW	
SC859	В	These are errors of the HDD Data Encryption Option D377.		
	8	HDD Check Error		
		Data conversion was attempted with no HDD unit present.		
		Confirm that HDD unit installed correctly		
		Initialize HDD with SP5832-1		
	Note: After installation, a new HDD should be formatted with SP5832-1			
	9	Power Loss During Data Conversion		
		Data conversion stopped before NVRAM/HDD data was converted.		
		Format HDD with SP5832-1		
	10	Data Read Command Error		
		More than two illegal DMAC communications were returned.		
		HDD defective		
		Format HDD with SP5832-1		
		Replace HDD		

SC860	В	HDD startup error at power on	GW
		HDD is connected but a driver error is detected, or the driver did not respond with the status of the HDD within 30 s.	
		HDD is not initialized	
		Level data is corrupted	
		HDD is defective (attempt to initialize the HDD with SP5832-0)	001)

SC861	D	HDD re-try failure	GW
		At power on with the HDD detected, power supply to the HDD is in the HDD is awakened from the sleep mode, the HDD is not ready v	
		Harness between HDD and board disconnected, defective	
		HDD power connector disconnected	
		HDD defective	
		Controller board defective	

SC863	D	HDD data read failure		GW
		The data written to the HDD cannot be read normally, due to bad generated during operation.	sectors	
		HDD defective		
		Note: If the bad sectors are generated at the image partition, the binformation is written to NVRAM, and the next time the HDD is accessed sectors will not be accessed for read/write operation.		
SC864	D	HDD data CRC error		GW
		During HDD operation, the HDD cannot respond to an CRC error transfer did not execute normally while data was being written to the		
		HDD defective		
SC865	D	HDD access error		GW
		HDD responded to an error during operation for a condition other SC863, 864.	than the	ose for
		HDD defective.		
SC866	В	SD card error 1: Confirmation		GW
		The machine detected an electronic license error in the application card in the controller slot immediately after the machine was turn Note:		e SD
		The program on the SD card contains electronic confirmatic	on licens	se data.
If the program does not contain this license data, or if the res shows that the license data in the program on the SD card is the checked program cannot execute and this SC code is dis				he check ect, then
		Program missing from the SD card		
		Download the correct program for the machine to the SD co	ard	

The SD card was removed while the machine is on.
Insert the SD card.
Turn the machine off and on.

SC868	D	SD card error 3: SD card access	GW
		An error occurred while an SD card was in use.	
		SD card not inserted correctly	
		SD card defective	
		Controller board defective	
		Note: You can try to reformat the SD with the SD Formatter Ver. 1.7	1

SC870	В	Address book data error	GW
		The address book data cannot be read from the HDD or SD card where it is stored, or the data read from the media is defective.	
		Cycle the machine off/on.	
		Software defective.	
		Replace controller firmware.	
		HDD defective.	
		More Details	
		Do SP5846-50 to reset all address book data.	
		Reset the user information with SP5832-6.	
		Replace the HDDs.	

SC872	В	HDD mail receive data error	GW
		An HDD error was detected immediately after power on, or the machine detected that the HDD was not operating correctly (data read or write) while receiving mail. The HDD may be defective or the machine was accidentally powered off while the HDD was being accessed.	
		<ul> <li>Reformat the mail RX data on the HDD with SP5832-7</li> <li>Replace the HDD</li> </ul>	

SC873	В	HDD mail send data error	GW
		An error was detected on the HDD immediately after the machine was or power was turned of while the machine was using the HDD.	as turned on,
		<ul> <li>Do SP5832-007 (Format HDD – Mail TX Data) to initialize the</li> <li>Replace the HDD.</li> </ul>	∍ HDD.

SC874	D	Delete All error 1: HDD	GW
		A data error was detected for the HDD/NVRAM after the Delete A used.	II option was
		<b>Note</b> : The source of this error is the Data Overwrite Security Unit ru SD card.	nning from an
		Turn the main switch off/on and try the operation again.	
		Install the Data Overwrite Security Unit again	
		HDD defective	

SC875	D	Delete All error 2: Data area	GW
		An error occurred while the machine deleted data from the HDD.  Note: The source of this error is the Data Overwrite Security Unit D from an SD card.	377 running
		<ul><li>Cycle the machine off/on.</li><li>Try the operation again.</li></ul>	

SC876	D	Log data er	Log data errors										
			Log data error 1										
		876-1	An error was detected in the handling of the log data a during machine operation. This can be caused by switch machine off while it is operating.	•									
			Initialize the HDD with SP5832-4										
												Log data error 2	
		876-2	HDD encryption unit not installed.										
				Install the HDD encryption unit.									

	Log data error 3
	Invalid log encryption key due to defective NVRAM data.
876-3	Initialize the HDD with SP5832-4     Request customer's system administrator to disable HDD encryption with the User Tool.
	Log data error 4
876-4	Erratic HDD encryption due to defective NVRAM data.
	Initialize HDD with SP5832-4
	Log data error 5
876-5	Re-install the previous NVRAM or HDD.
	Initialize the HDD with SP5832-4.
	Log data error 6
876-99	An error other than Log Data Errors 1 to 5 occurred.
	Request assistance from your supervisor.

SC877	В	Data Overwrite Security SD card error	GW
		An error occurred, preventing successful execution of the Data Overwri Security function, even though it has been set up and enabled.	te
		DOS card is not inserted completely into the SD card slot	
		DOS card has been removed from the SD card slot.	
		DOS card is damaged.	
		Note:	
		<ul> <li>If the SD card has been removed (or was not installed correctly), s</li> <li>the machine off, insert the SD card, then switch on the machine ag</li> </ul>	
		If the SD card has been damaged, procure a new SD card, replace NVRAM, then do the DOS option installation.	e the

SC878	D	TPM authentication error	GW
	The system firmware could not be authenticated by the TMP security chip		hip.

**Trusted Platform Module**. In computing, Trusted Platform Module (TPM) is both the name of a published specification detailing a secure cryptoprocessor that can store cryptographic keys that protect information, as well as the general name of implementations of that specification, often called the "TPM chip" or "TPM Security Device" (as designated in certain Dell BIOS settings).

SC881	D	Management area error	GW
		This is a software error than can occur:	
		At login	
		When a print job was received	
		When WEB browser was opened	
		Cycle the machine off/on.	

SC899	D	Software error	GW
		A software error occurred in the GW controller.	
		Cycle the machine off/on	
		Update controller firmware	
		Controller board defective	

# SC900: Other

SC900	D	Electrical total counter error	GW
		The total counter contains data that is not a number.	
		NVRAM incorrect type	
		NVRAM defective or corrupted	
		Unexpected error from external source	

SC910	В	External controller error 1	GW
SC 911	В	External controller error 2	GW

6

SC 912	В	External controller error 3	GW
SC 913	В	External controller error 4	GW
SC 914	В	External controller error 5	GW
		The external controller alerted the m	achine about an error.
		Refer to the instructions for the external controller	

SC 919	D	External controller error 6	GW
		While EAC (External Application Converter), the conversion module, was operating normally, the receipt of a power line interrupt signal from the FLUTE serial driver was detected, or BREAK signal from the other station was detected.	
		<ul><li>Controller power outage</li><li>Controller rebooted</li><li>Connection to controller loose</li></ul>	

SC920	В	Printer Error 1		GW
		An internal application error was detected and operation of	cannot continue.	
		<ul><li>Software defective, switch off/on, or change the cont</li><li>Insufficient memory</li></ul>	roller firmware	

SC921	D	Printer Error 2: Font error	GW
		When the printer application started, the specified font cou SD card.	ld not be found on the
		<ul><li> The specified font is not on the SD card</li><li> SD card data corrupted</li></ul>	

SC9	25	В	Net File function error	GW	
-----	----	---	-------------------------	----	--

The NetFile file management on the HDD cannot be used, or a NetFile management file is corrupted and operation cannot continue. The HDDs are defective and they cannot be debugged or partitioned, so the Scan Router functions (delivery of received faxes, document capture, etc.), Web services, and other network functions cannot be used.

HDD status codes are displayed below the SC code:

• Refer to the four procedures below (Recovery from SC 925).

#### Here is a list of HDD status codes:

Display	Meaning
(-1)	HDD not connected
(-2)	HDD not ready
(-3)	No label
(-4)	Partition type incorrect
(-5)	Error returned during label read or check
(-6)	Error returned during label read or check
(-7)	"filesystem" repair failed
(-8)	"filesystem" mount failed
(-9)	Drive does not answer command
(-10)	Internal kernel error
(-11)	Size of drive is too small
(-12)	Specified partition does not exist
(-13)	Device file does not exist

# Recovery from SC 925

### Procedure 1

If the machine shows SC codes for HDD errors (SC860 to SC865) with SC 925, do the recovery procedures for SC860 to SC865.

#### Procedure 2

- 1. If the machine does not show one of the five HDD errors (SC860 to SC865), turn the machine power off and on.
- 2. If this is not the solution for the problem, then initialize the NetFile partition on the HDD with SP5832-11 (HDD Formatting Ridoc I/F).

NetFiles: These are jobs printed from the document server using a PC and DeskTopBinder. Before you initialize the NetFile partition on the HDD, tell the customer:

- · Received faxes on the delivery server will be erased
- · All captured documents will be erased
- Desk Top Binder/Print Job Manager/Desk Top Editor job history will be erased
- Documents on the document server, and scanned documents, will not be erased.
- The first time that the network gets access to the machine, the management information must be configured again (this will use a lot of time).
- 3. Before you initialize the Netfile partition with SP5832-11, do these steps:
- 4. Go into the User Tools mode and do "Delivery Settings" to print all received fax documents that are scheduled for delivery. Then erase them.
- 5. In the User Tools mode, do Document Management> Batch Delete Transfer Documents.
- 6. Do SP5832-11, and turn the machine off and on.

#### Procedure 3

- 1. If "Procedure 2" is not the solution for the problem, do SP5832-1 (HDD Formatting All)
- 2. Cycle the machine off/on.



 SP5832-001 erases all document and address book data on the hard disks. Consult with the customer before you do this SP code.

#### Procedure 4

If "Procedure 3" does not solve the problem, replace the HDD.

SC990	D	Software error 1	GW
		An unexpected operation was encountered by the software.	

SC991	С	Software Error 2		GW
		The software peformed an unexpected function and the program cannot continue. Recovery processing allows the program to continue.		
		Software defective, re-boot		

In order to get more details about SC991:

- Execute SP7403 or print an SMC Report (SP5990) to read the history of the 10 most recent logged errors.
- 2. If you press the zero key on the operation panel with the SP selection menu displayed, you will see detailed information about the recently logged SC991, including the software file name, line number, and so on. Of these two methods, 1) is the recommended method, because another SC could write over the information for the previous SC.

SC992	D	Undefined Error (No SC Code)	GW
		An error not controlled by the system occurred (the error does not cor any other SC code).	ne under
		<ul> <li>Software defective</li> <li>Turn the machine power off and on. The machine cannot be used error is corrected.</li> <li>Re-install firmware</li> </ul>	d until this

SC994	С	Operation Panel Management Records Exceeded	GW

An error occurred because the number of records exceeded the limit for images managed in the service layer of the firmware. This can occur if there if there are too many application screens open on the operation panel.

• No action required because this SC does not interfere with operation of the machine.

SC997	В	Application selection error 1 GV	
		An application did not start after pressing the appropriate key on the operation panel.	
		<ul> <li>Software bug (change the firmware for the application that failed)</li> <li>A RAM or DIMM option required by the application is not installed or r installed correctly.</li> </ul>	

SC998	D	Application selection error 2	
		Register processing did not execute for an application within 60 sec. after the machine was switched on. No applications start correctly, and all end abnormally.	
	<ul> <li>Software bug (change the firmware for the application that failed)</li> <li>A RAM or DIMM option required by the application is not installed or n installed correctly.</li> </ul>		·

SC995 RTB 39

# **Special Troubleshooting Procedures**

# Clearing SC471, SC475 or SC476

The machine issues SC471, SC475, or SC476 when the ITB is out of position. If the countermeasures for these SC codes described in the SC tables do not correct the problem, the ITB is too far out of position for the machine to correct the problem automatically. Physical adjustment of the ITB is required.

### **Cam Position Check**

- 1. First, do SP2920-1 to check the belt centering cam position.
- If the cam position (number of steps) is within ±20 steps, physical adjustment is not necessary.
   -or-

If the cam position is out of range, follow the procedure in the next section to do the physical adjustment.


# **Physical Adjustment**

1. Open the left and right front door.



d074r790

- 2. Remove the left ITB unit front cover ( Fx 2).
- 3. Calculate how many notches on the scale to adjust, and check the adjustment direction (+/-) with the following formula:
  - Checked cam position (Steps)/18 = necessary number of adjustment notches.
  - For example, if the checked cam position is -27, the necessary adjustment is -1.5 notches (-27/18 = -1.5).



- 4. Loosen the screw.
- 5. Push the adjustor arm up or down for the number of notches calculated in the previous step.
  - Move the arm up if the result of the calculation is positive, down if the result is negative.
  - Each line on the scale marks one notch.
- 6. Tighten the screw.
- 7. Reassemble the machine.

### **ITB Condition Check**

An ITB condition check is required after installing a new ITB or after doing the physical adjustment described in the previous section. After the check, the detection time is stored in SP codes SP112-15, -16, -17.

- 1. Turn the machine on.
- 2. Enter the SP mode and do SP3011-001 (Manual Procon: Exe) to execute manual process control.
- 3. Do SP2112-001 to scan the surface of the belt with all three sensors to check for damage to the surface of the belt.
- 4. Do the following three SP codes to check the results of the belt scan
  - SP2112-015 (Error Code: Front)
  - SP2112-016 (Error Code: Center)
  - SP2112-017 (Error Code: Rear)
- 5. If the results of the three SP executions are all "0" the condition of the belt is satisfactory.

-or-

If any of these SP codes return any value other than "0", repeat Steps 2 and 3.

# SP3812 001 (Development Fill) Errors

After SP3025-1 executes normally, you should see four 1s:

1111

Reading from left to right, each "1" indicates the status of the PCDUs: YMCK.

If you see any number other than a "1", this indicates an error.

### SP3025-1 Error Codes

Code	Error	Comments
0	No execution	Default
1	Success	Operation succeeded
2	No developer flow	TD sensor output > 1.5V before developer installed (developer detected)
3 No developer installed		TD sensor output < 1.5V after developer installed (no developer detected)
4	Used toner bottle full	Used toner bottle detected full
5	Development motor lock	Development motor lock detected
6	Used toner bottle motor lock	Used toner transport motor or used toner bottle development motor lock detected
9	Force end	Operation end because door open or power off

# **Process Control Troubleshooting**

# **Summary of Process Control SC Codes**

This is a list of SC codes that may occur during process control. For more, please refer to the process control tables on the following pages.

### **Pre-Processing Check**

Ó

SC316 to SC319  Vpp is not within the normal range (Vpp: the AC current applied roller to compensate for changes in the ambient temperature and Insufficient charge causes white spotting and too much charge of film on the surface of the drum. Vpp must be > 2.8 kV.		
SC400	ID sensor could not be calibrated. An abnormal ID sensor condition is detected when before calibration begins, Vsg < 0.5V or after calibration, Vsg cannot be adjusted to 4.0±0.2V.	
SC418	Correct current could not be supplied to the ID sensor.	
SC436 to SC439	A problem is detected with a potential sensor during calibration.	
Potential Control		
SC410 to SC413	The development gamma is out of range (not between 0.3 and 6.0) for a color.	
SC414 to SC417	Vk is out of range (not within $\pm 150$ V) for a color. If the development potential is less than Vk, toner is not applied to the drum.	
SC420 to SC423 Vd cannot be adjusted to the target voltage for a drum.		
SC424 to SC427	The potential sensor detects that Vpl is not $\pm 10V$ of the target Vpl after exposure of the ID sensor patterns.	
SC432 to SC435	The residual voltage on a drum is greater than -200V.	
TD Sensor Output Cal	libration	
SC360 to SC367	An abnormal condition is detected when output of one of the TD sensors fails to fall within the range of 0.5V to 4.5V.	
Process Control Gamma Correction		
SC410 to SC413	The development gamma for black, magenta, cyan, or yellow is not within range (0.3 to 6.0).	
SC414 to SC417 The development start voltage (Vk) for black, magenta, cyan, or yell is not within range (±150V)		

# **Process Control Self-Check: SP3012**

After the process control self-check is executed manually with SP3012-1 to 9, you can execute SP3012 to check the results of the self-check. The possible error codes are listed in the "Displayed Code" column in the table below.

10101010

Reading from left to right each "10" represents a color: YMCK.

If a problem occurs, the code will appear in the column for the color PCDU where the error has occurred. For example, If a Vdhome error (Code 15) (see table below) occurs in the M PCDU, the display will look like this:

10151010

Or if an ID sensor error (Code 21) (see table below) occurs in the Y PCDU:

10101021

"99" displays while SP3821 executes.



 Noise and static electricity can damage the many sensors that are used during the process control self-check. Because of this, always turn the machine off before doing any procedure described below that requires disassembly.

#### Normal

Displayed Code	Item	Major Cause
10 Successful		

# **Potential Sensors**

Displayed Code	ltem	Major Cause	
	VdHome Error 1	VdHome (SP3641) above -800V.  • The window of the potential sensor probe fouled with toner  • Potential sensor damaged	
15	Action:  Do SP3070 to check the function of the potential sensor.  Do SP3071 to check the Voffset readings. If Voffset is over 1V, the potential sensor might be dirty due to scattered toner.		
	<ul> <li>Remove the PCDU. Use a blower brush to clean the window of the potential sensor probe, then check the sensor again with SP3070.</li> <li>If normal operation cannot be restored, replace the potential sensor probe.</li> </ul>		
	VdHome Error 2	VdHome (SP3772) below –500V.  • Potential sensor relay board damaged  • Drum abnormal  • Drum motor not operating	
16	<ul> <li>Do SP3017 to che</li> <li>Remove the malfur then on, then do th</li> <li>If the replaced PCI machine side, or th</li> </ul>	Do SP3070 to check the function of the potential sensor.  Do SP3017 to check the Vd reading  Remove the malfunctioning PCDU with a functioning PCDU, turn the machine off then on, then do the potential sensor check again.  If the replaced PCDU does not function normally, then the problem is on the machine side, or the potential sensor relay board is malfunctioning.  If the replaced PCDU functions normally, then there may be a problem with the	

# **ID Sensors**

Displayed Code	ltem	Major Cause	
	ID Sensor Vsg Adjust Error	Vsg_reg (SP3321) is out of range (not within 4.0 ±0.2V).  • ID sensor fouled with dust, toner  • ITB undulating or out of position	
21	Action:  Remove the ITB unit.  Make sure the belt is mounted correctly.  Clean the windows of the ID sensors with a cloth moistened with alcohol.  Be sure to wipe the sensor apertures with a wet cloth. A dry cloth may generate static which can attract dust.		
	ID Sensor LED Current Error	LED PWM (SP3322) greater than 27 mA.  ID sensor fouled with dust, toner  ID sensor deteriorated	
22	<ul> <li>Action:</li> <li>Remove the ITB unit and check the ID sensors.</li> <li>Clean the windows of the ID sensors with alcohol and a clean cloth.</li> <li>Be sure to wipe the sensor apertures with a wet cloth. A dry cloth may generate static which can attract dust.</li> <li>If the apertures are clean, then the LED of an ID sensor may have deteriorated. Replace the ID sensor plate.</li> </ul>		

Displayed Code	ltem	Major Cause
	ID Sensor Output Error	Vsg_reg (SP3321) less than 0.5V.  • ID sensor harness loose, disconnected, damaged  • ID sensor damaged  Note: Vsg_reg refers to the reading of the ITB surface done with the direct reflection sensors in both the color and black ID sensors.
23	Action:  Remove the ITB unit.  Check the ID sensor harness connections and make sure that they are tight.  Check the harnesses for breaks.  If the harnesses are undamaged and tightening the connections does not so the problem, replace the ID sensor plate.	

# TD Sensor (MUSIC)

Displayed Code	ltem	Major Cause
41	TD Sensor Output Exceeded Upper Range	Vt > 4.7V
TD Sensor Output Below Lower Range		Vt < 0.5V
43	TD Sensor Malfunction: Upper Range	Development gamma not within range:  0.5V ≦ Dev Gamma ≦ 2.0V  or Vt > 4.7V
44	TD Sensor Malfunction: Lower Range	Development gamma not within range:  0.5V ≦ Dev Gamma ≦ 2.0V  or Vt < 0.5V

# **ID Sensor Pattern Detection**

Displayed	played .			
Code	Item	Major Cause		
	Development Gamma Error 1 SP400 to SC403	Development gamma (SP3561) greater than 6.0 (mg/cm2/-kV).		
55	Action:  Switch the machine off and on then do SP3011.  Do SP3630 to confirm that development gamma is within the target range (-0.1 to +0.1)  If not within the target range, do the procedure again.			
56	Development Gamma Error 2	Development gamma (SP3630) less than 0.3 (mg/cm2/-kV)		
	SP400 to SC403	Toner shield glass dirty		
	Action:			
	1. Do SP2109-002 and select Pattern "12".			
	2. Do SP2109-005 to (default)" to "0".	o 008 and change the settings of these SP codes from "15		
	3. Return to the print window and do the test print 1 pattern.			
	4. Check the pattern to determine whether the image density is extremely light.			
	5. Turn the machine off.			
	6. Open the toner hopper door, remove the toner bottles and check the toner shield glass for dirt.			
	7. Remove the face plate, replace the malfunctioning PCDU with a functioning PCDU, then turn the machine on and repeat Steps 1 to 3 to print the coverage test pattern.			
	8. If normal operation cannot be recovered:			

Displayed Code	ltem	Major Cause		
	Replace the image transfer power pack.			
	Open the development unit to see if there is too much or too little developer.			
	If the developer su toner in the sub ho	pply is normal, remove the toner end sensor to see if there is pper.		
	If the sub hopper is supply unit.	s empty, the powder pump is defective. Replace the toner		
	If the sub hopper is supply unit.	s full, the toner end sensor is defective. Replace the toner		
	If the level of devel	loper is either too high or too low, replace the developer.		
	Vk Error 1	Vk (development start voltage) greater than 150V.		
57	Action:			
	Replace the developer.			
		Vk (development start voltage) less than –150V.		
	Vk Error 2	The window of the potential sensor probe is covered with toner.		
		Potential sensor damaged		
	Action:			
58	1. Do SP3070 to check the function of the potential sensor.			
	<ol><li>Do SP3071 to check the Voffset readings. If Voffset is over 1V, the potential sensor might be dirty due to scattered toner.</li></ol>			
	<ol><li>Remove the PCDU. Use a blower brush to clean the window of the potential sensor probe, then check the sensor again with SP3070.</li></ol>			
	4. If normal operation cannot be recovered, replace the potential sensor probe.			
	5. If the Voffset reading is normal, replace the developer.			
	Insufficient Active Data	Not enough active data to calculate development gamma (only "0" or "1").		
59	Action:			
	Do the "Action" procedu	ure for code "55" described above.		

# **Potential Adjustment**

Displayed Code	ltem	Major Cause
	LD Failure	A laser diode failed to fire and write the ID sensor pattern.     Toner shield glass dirty     PCDU set incorrectly     Laser diode defective
61	<ul> <li>Laser diode defective</li> <li>Action: <ol> <li>Print the color test pattern to determine which color is abnormal.</li> <li>Turn the machine off.</li> <li>Check the toner shield glass for the laser unit. (I p.495) &gt; "Toner Shield Glas 4. Reassemble the machine, switch the machine on, then do SP3011.</li> </ol> </li> <li>Notes: <ol> <li>The probes of the potential sensors of each PCDU are located at different positions. This failure can be caused by installing a potential sensor at the incorrect position. However, you can eliminate this as a cause if a new PCDU installed. (A guide ensures prevents a PCDU from being installed at the wrong location.)</li> <li>If the machine fails to return SC240 to SC243, you can eliminate a defective as the cause of the problem.</li> </ol> </li></ul>	
62	Vr Error	Vr (residual voltage) greater than -200V.  • Drum deteriorated  • Toner shield glass dirty
	Action:  Open the front door, remove the toner supply unit, and check the toner shield glass for dirt.  Clean the glass then do SP3011.  If this does not solve the problem, replace the drum.	
63	Vd Adjust Error	Vd could not be adjusted within ±8V.  • Drum defective
	Action:  • Replace the drum.	

Displayed Code	Item	Major Cause
64	Vpl Adjust Error	Vpl could not be adjusted within ±5V.  • Drum deteriorated due to filming
	Action: • Replace the drum.	

### Abnormal End

Displayed Code	ltem	Major Cause
99	Forced Termination	Door open, power off, or other problem interfering with process control self-check.
	Action:  • Make sure the machine is turned on.  • Make sure the front door is closed completely.	

# **MUSIC Adjustment Result**

SP2-194-010 to -012 (MUSIC Execution Result M/C/Y Error)

This SP shows the number as a MUSIC result on the LCD. It shows which color has an error (M, Y or C).

No.	Result	Description
0	Not done	MUSIC has not been done.
1	Completed successfully	MUSIC has been done correctly.
2	Cannot detect patterns	ID sensors have not detected the patterns for MUSIC.
3	Fewer lines on the pattern than the target	The patterns detected by the ID sensors are not complete enough for MUSIC.
5	Out of the adjustment range	ID sensors have correctly detected the patterns for MUSIC, but the position of the patterns is too far away from the adjustable range.
6	Belt damage	Accurate detection is not possible due to damage to the ITB.

# **Troubleshooting for Image Quality Problems**

This section describes some common image quality problems and explains how to resolve them.




• The dark arrow in each illustration indicates the direction of paper feed.

# **Development-related Troubleshooting**

#### Vertical White Line

#### Problem:



Vertical white line [A] appears on the output when a solid single color image is output.

#### Cause:

- Dust or dirt under the PCDU
- Laser path interruption between the laser unit and the drum unit due to dust or dirt on the toner shield glass
- Uneven developer supply due to a foreign substance stuck in the doctor gap in the development unit

#### Solution:

1. Print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets and 1 dot halftone (SP2-109-003: "11") A3 or DLT sheets for each of black, cyan, magenta, and green.

### To make a full-green coverage page

- Select No.26 (Full Dot Pattern) with SP2-109-003.
- Select "1" (Full Color) with SP2-109-5.

6

- Open SP2-109-6 and change Density K from "15" to "0".
- Open SP2-109-8 and change Density M from "15" to "0".
- Open SP2-109-7 and -9 and make sure that Density C and Density Y are both set "15" (default settings).
- 2. Does the problem vertical white line appear at the same place on some color's outputs?

Yes Go to "Recovery of dust or dirt under the PCDU".

No Clean the toner shield glass for the affected color.


3. Print the problem image. Does this eliminate the problem?

Yes Finished!

No Clean the doctor gap at the development unit.

- Cut an OHP sheet [A] or plastic material as shown below.
- Clean the doctor gap with this sheet and vacuum developer.

RTB 104 More details on cleaning the doctor gap with the special tool



d074t708

4. Print the problem image. Does this eliminate the problem?

Yes Finished!

No Replace the affected drum unit.

5. Print the problem image. Does this eliminate the problem?

Yes Finished!

No Contact your supervisor.

### Recovery of dust or dirt under the PCDU

1. Check the color which causes a vertical line.

- The PCDU's stations are placed as follows from the right; K (black), C (cyan), M (magenta) and Y (yellow). For example, check the magenta PCDU if yellow and magenta has a vertical line problem.
- 2. Does dust or dirt adhere under the affected PCDU?

**Yes** Pull out the affected PCDU, and then clean the bottom area [A] of the affected PCDU with a cloth and alcohol.



No Contact your supervisor.

3. Print the image. Is the problem resolved?


Yes Finished!

No Contact your supervisor.

# 6

# **Color Toner Spotting/Staining**

### Paper Is Spotted with Toner



Paper has toner spots of 0.5-1 mm (0.02-0.04 inches) in diameter.

#### Cause:

Toner fragments have slipped through the cleaning web.

This may occur in any of the following cases:

Duplex printing, printing on uncoated (especially rough-textured) paper, halftone printing, printing another job after halftone printing, or printing another job after printing on many small-size sheets



To adjust the following settings, pre-register the type of paper in use as a custom paper. For details
about registering custom papers, see "Registering a Custom Paper", Paper Settings Reference.

#### Solution:

- 1. Increase the temperature by 5 °C in [44: Fusing Heat Roller Temperature Adj] in [Advanced Settings] or with SP1-984.
- 2. Print 20 sheets of the image, then another 10. Does this eliminate the problem?

Yes Finished!

No Go to the next step.

- 3. Increase the temperature by an additional 5°C in [44: Fusing Heat Roller Temperature Adj] or with SP1-984.
- 4. Print 20 sheets of the image, then another 10. Does this eliminate the problem?

Yes Finished!

No Go to the next step.

5. Has changing the setting caused glossy lines to appear or paper to misfeed?

Yes Decrease the temperature by 10°C, and then go to the next step.

No Go to the next step.

- 6. Set [50: Adjust Cleaning Web Motor Interval] to -30% in [Advanced Settings] or with SP1-992 for the custom paper in use
- 7. Print 20 sheets of the image, then another 10. Does this eliminate the problem?

Yes Finished!

No Go to the next step.

- 8. Set [50: Adjust Cleaning Web Motor Interval] to -60% in [Advanced Settings] or with SP1-992 for the custom paper in use.
- 9. Print 20 sheets of the image, then another 10. Does this eliminate the problem?

Yes Finished!


No Go to the next step.

- 10. Set [50: Adjust Cleaning Web Motor Interval] to -75% in [Advanced Settings] or with SP1-992 for the custom paper in use.
- 11. If the problem persists, contact your supervisor.



• Decreasing the value in [50: Adjust Cleaning Web Motor Interval] will shorten the replacement cycle of the cleaning unit for the fusing unit.

# **Colored Spots**





- [A]: 189 mm (7.5 in.)
- [B]: 40 mm (1.6 in.)

Colored spots appear at 189 mm or 40 mm (7.5 inch or 1.6 inch) intervals.

#### Cause:

- (a) Colored spots appear at 189 mm (7.5 inch) intervals. The drum is scratched or stained.
- (b) Colored spots appear at 40 mm (1.6 inch) intervals. The charge roller is scratched or stained.


#### Solution:

The solution depends on the interval at which the colored spots appear. If they appear every 189 mm (7.5 inches), follow Procedure (a) on the following page; if they appear every 40 mm (1.6 inches), follow Procedure (b) on the following page.

### (a) Colored spots at 189 mm (7.5 inch) intervals

- To identify the affected color, print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets for each of white and black, and three full-page, halftone (SP2-109-003: "12") A3 or DLT sheets for each of cyan, magenta, and yellow.
- Detach the drum unit of the affected color and check the drum surface. Is the surface scratched?
   Yes Replace the drum unit. (Pp.553)

**No** Wipe the drum surface with a well-wrung-out damp cloth, wipe it with a dry rag until no moisture remains, and then reattach the drum unit.






- Do not use ethanol or any other organic solvent to clean the drum. Otherwise it may cause damage to the drum.
- After cleaning the surface of the drum, dust the surface of the drum completely with Drum Powder B1329700.
- 3. If the problem persists, contact your supervisor.

### (b) Colored spots at 40 mm (1.6 inch) intervals

- 1. To identify the affected color, print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets for each of white and black, and three full-page, halftone (SP2-109-003: "12") A3 or DLT sheets for each of cyan, magenta, and yellow.
- 2. Detach the charge roller of the affected color and check its surface. Is the surface scratched?

## Yes Replace the charge roller. (\*\*p.551)


**No** Wipe the charge roller surface with a well-wrung-out damp cloth, wipe it with a dry rag until no moisture remains, and then reattach the roller.





- Do not use ethanol or any other organic solvent to clean the charge roller. Otherwise it may cause damage to the charge roller.
- 3. If the problem persists, contact your supervisor.

# Colored Streaks (1)



Colored streaks parallel to the paper feed direction appear.

### Cause:

- The charge roller is stained.
- The cleaning unit for PCU has worn out.
- The drum surface is scratched.

#### Solution:

- To identify the affected color, print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets for white, and three full-page, halftone (SP2-109-003: "12") A3 or DLT sheets for each of cyan, magenta, and yellow.
- Detach the charge roller of the affected color and check its surface. Is the surface stained?
   Yes Wipe the charge roller with a dry rag to remove the stain. If the stain cannot be removed, replace the drum charge unit. (\*\*p.551)

Go to the next step.

No Go to the next step.

3. Detach the drum unit of the affected color and check the drum surface. Is the surface stained or scratched?


Stained: Replace the drum cleaning unit. (\*\*p.552)

Scratched: Replace the drum unit. (\*\*p.553)

Neither: Contact your supervisor.

4. If the problem persists even if you replace the cleaning unit for PCU or drum unit, contact your supervisor.

### Colored Streaks (2)



Extended, blurred colored streaks parallel to the paper feed direction appear. The streaks also appear randomly in the margins.

If the temperature or humidity is low, remaining toner might be missed by the cleaning blade of the cleaning unit for the transfer belt or transfer unit, causing streaks to appear sporadically.

# Solution:

- 1. To identify the affected color, print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets for each of cyan, yellow, magenta, and black.
- 2. Which side is affected by the problem?

Printed side (1st side): Proceed to Step 6.

No image side (2nd side): Replace the PTR cleaning blade or lubrication bar. (\*\*p.708)

3. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 4. Replace the paper transfer roller. (\*\*p.708)
- 5. Print the image. Is the problem resolved?

Yes Finished!

No Check and clean other units (fusing unit or paper path).

- 6. Replace the cleaning unit for the transfer belt or one of the following (\*\*p.430)
  - ITB Cleaning Blade
  - ITB Lubrication Roller
  - ITB Lubrication Bar
  - ITB Lubrication Blade
- 7. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 8. Replace the transfer belt. (\*\*p.599)
- 9. Print the image. Is the problem resolved?

Yes Finished!


No Go to the next step.

 If the problem persists even if you replace the cleaning unit for the transfer belt, contact your supervisor.

6

# 6

## Colored Streaks (3)



Colored streaks appear in solid-filled areas.

#### Cause:

If the toner contains small clumps, they disintegrate in the development unit, producing colored streaks.

This problem may occur if the machine is left unattended for a long period or the toner bottle is kept out of its moisture-proof bag for a long period.

#### Solution:

- To identify the affected color, print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets for each of cyan, yellow, magenta, and black. The color affected by colored streaks is the cause of the problem.
- 2. Print 200 full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets in the affected color.
- 3. Print the image. Is the problem resolved?

Yes Finished!

### No Replace the toner bottle for the affected color.

- 4. Print 200 full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets in the affected color.
- 5. Print the image. Is the problem resolved?

Yes Finished!

### No Replace the toner supply unit for the affected color. (\*\*p.518)

- 6. Print 200 full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets in the affected color.
- 7. Print the image. Is the problem resolved?

Yes Finished!

No Replace the development unit and developer for the affected color. (\*\*p.558 or p.559)

1. Print 200 full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets in the affected color.

2. Print the image. Is the problem resolved?

Yes Finished!


No Contact your supervisor.

# **Stained Paper Edges**

#### Solution:

1. If the paper edges are stained, carry out the procedure on p.1074 "Insufficient Toner Fusing".

# Stained Background



- [A]: Completely stained background
- [B]: Partially stained background

Random "powdered" dots appear, creating a dirty background.

The background may be partially or completely stained.

#### Cause:

This may occur because of wearing of the developer and drum unit or staining of the charge roller.

### Solution:

- 1. If a message prompting replacement of a unit has appeared, replace the unit.
  - Developer (\*\*p.559)
  - Drum unit (\*\*p.553)
  - Drum charge unit (IPp.551)
- 2. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 3. Print the image. Is the problem resolved?


Yes Finished!

**No** In the [Adjustment Settings for Skilled Operators] menu, execute [0302: Execute Process Initial Setting] or execute SP3-020-1 in the SP mode.

- 4. Replace one of the following units, even if the service life of these parts has not reached the PM life.
  - Developer (\*\*p.559)
  - Development unit (1 p.558)
  - Drum unit (1 p.553)
  - Drum charge unit (\*\*p.551)
- 5. If the problem persists, contact your supervisor.

#### Toner Scatter

#### **Area Scatter**



Toner is scattered around a solid-fill print.

#### Cause:

This may occur if printed at low temperature or humidity.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

1. Check both sides of the paper for the problem. If it appears only on side 2 of the paper, skip to Step 3.

#### <Printing in black and white>

Increase the absolute value of the negative current by 5% in [31: Paper Transfer Current: B&W] or with SP2-970.

Example: If the present current is -40  $\mu$ A, change it to -42  $\mu$ A.

#### <Printing in full color>

Increase the absolute value of the negative current by 5% in [32: Paper Transfer Current: FC] or with SP2-971.

Example: If the present current is -70 µA, change it to -73 µA.

3. Adjust the setting for side 2 of the paper. Configure the following settings in [Advanced Settings] for the custom paper in use.

#### <Printing in black and white>

Increase the scaling factor by 5 percentage points in [33: Paper Transfer Current; Side 2: B&W] or with SP2-995.

Example: If the present value is 100%, change it to 105%

#### <Printing in full color>

Increase the scaling factor by 5 percentage points in [34: Paper Transfer Current; Side 2: FC] or with SP2-996.


Example: If the present value is 100%, change it to 105%

4. Print the image. Is the problem resolved?

#### Yes Finished!

No Repeat Steps 1 to 3. If the problem persists, contact your supervisor.

#### **Line Scatter**





Parts of a line exhibit splatter. This may occur in a line 5 mm or less from the leading edge, or in a line 1.5 to 5 mm from an image element on the side of the element facing the trailing edge.

[A]: 5 mm (0.2 in.), [B]: 1.5 - 5 mm (0.06 - 0.2 in.)

#### Cause:

This may occur when printing lines on coated or other slippery paper.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

The solution depends on the area in which the line splatter occurs. If the splatter occurs 5 mm (0.2 inches) or less from the leading edge, follow Procedure (a) below; otherwise, follow Procedure (b) below.

#### a) Line splatter that is 5 mm (0.2 inches) or less from the leading edge

Increase the leading edge margin to more than 5 mm (0.2 inches) using one of the following procedures:

#### 1. Adjusting the shift image

In [Advanced Settings] for the custom paper in use, specify [08: Adj Image Position of Side 1 With Feed] for the side 1 of the paper and [09: Adj Image Position of Side 2 With Feed] for the side 2.

#### 2. Adjusting the mask width at the leading edge

In [Advanced Settings] for the custom paper in use, specify [13: Adjust Erase Margin of Leading Edge].

#### 3. Adjusting the file's leading edge margin

Increase the leading edge margin in the print settings for the image to be printed.

For details about adjusting the shift image and adjusting the mask width at the leading edge, see "Adjustment Item Menu Guide".

If you cannot increase the leading edge margin to more than 5 mm (0.2 inches), use another type of paper.

#### b) Line splatter that is in an area more than 5 mm (0.2 inches) from the leading edge

1. Configure the following settings in [Advanced Settings] for the custom paper in use.

#### <Printing in black and white>

Increase the absolute value of the current by 10  $\mu$ A in [26: Image Transfer Current: B&W] or with SP2-990.

#### <Printing in full color>

Increase the absolute value of the current by 10  $\mu$ A in [27: Image Transfer Current: FC: Black] or with SP2-991.

2. Print the image. Is the problem resolved?


Yes Finished!

No Increase the value by 10  $\mu$ A.

3. Repeat Step 2. If the problem persists even though you have set the current to 70 µA (maximum), use another type of paper.

#### Color Loss

#### **Colorless Spots**



Colorless spots appear in solid-filled areas.

#### Cause:

If the toner contains small clots, they fail to be transferred, producing colorless spots.


This problem may occur if the machine is left unattended for a long period or the toner bottle is taken out of its moisture-proof bag for a long period of time.

#### Solution:

If colorless spots appear in color printing, carry out the procedure on p.1041 "Colored Streaks (3)".

6

#### White Dots/Lines



White dots or small lines appear, spaced at 189 mm (7.5 inch) [A] intervals in the direction of the paper feed.

#### Cause:

The drum is stained.


#### Solution:

- 1. To identify the affected color, print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets or each of cyan, magenta, black, and green.
  - Because it is difficult to identify white spots on yellow, green is used instead of yellow.
- 2. Detach the drum unit of the affected color and check the drum surface. Is the drum surface stained?
  Yes Carry out all of the following:
  - (1) Wipe the drum surface with a clean, dry cloth to remove the stain.
  - (2) After cleaning the surface of the drum, dust the surface of the drum completely with Drum Powder B1329700.
  - (3) Replace the cleaning unit for PCU. (\*\*p.552)
  - (4) In the [Adjustment Settings for Skilled Operators] menu, set [0208: Photoconductor Special Mode] to [Special Mode] or set SP2-225-12 to 15 to "1: ON".

No Replace the drum unit. (\*\*p.553)

3. If the problem persists, contact your supervisor.

#### **Vertical White Streaks**



White streaks 1 to 8 mm long perpendicular to the paper feed direction appear.

#### Cause:


One of the charge rollers is dirty.



 If white streaks appear at 189- or 40-mm intervals, carry out the procedure on p.1036 "Colored Spots".

#### Solution:

- 1. To identify the affected color, print three full-page, halftone (SP2-109-003: "12") A3 or DLT sheets for each of cyan, magenta, yellow, and black.
- 2. Detach the charge roller of the affected color, wipe its surface with a well wrung-out damp cloth, wipe it with a dry cloth until no moisture remains, and then reattach the roller.




6





- Do not use ethanol or any other organic solvent to clean the charge roller. Otherwise it may cause damage to the charge roller.
- 3. If the problem persists, contact your supervisor.

#### White Spots



White spots of 0.2-0.3 mm (0.008-0.01 inches) in diameter appear.

#### Cause:

This may occur if printed at low temperature or humidity.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

- 1. Check both sides of the paper for the problem. If it appears only on side 2 of the paper, skip to Step 3.
- 2. Adjust the setting for side 1 of the paper. Configure the following settings in [Advanced Settings] for the custom paper in use.

#### <Printing in black and white>

Decrease the absolute value of the negative current by 5% in [31: Paper Transfer Current: B&W] or with SP2-970.

Example: If the present current is -40  $\mu$ A, change it to -38  $\mu$ A.

#### <Printing in full color>

with SP2-971.

Example: If the present current is -70 µA, change it to -67 µA.

3. Adjust the setting for side 2 of the paper. Make the following settings in [Advanced Settings] for the custom paper in use.

Decrease the absolute value of the negative current by 5% in [32: Paper Transfer Current: FC] or

#### <Printing in black and white>

Decrease the scaling factor by 5 percentage points in [33: Paper Transfer Current; Side 2: B&W] or with SP2-995.

Example: If the present value is 100%, change it to 95%.

#### <Printing in full color>

Decrease the scaling factor by 5 percentage points in [34: Paper Transfer Current; Side 2: FC] or with SP2-996.


Example: If the present value is 100%, change it to 95%.

4. Print the image. Is the problem resolved?

Yes Finished!

No Repeat Steps 1 to 4. If the problem persists, contact your supervisor.

#### **Blister-like White Spots**



d074t617

White spots 0.3–0.5 mm in diameter surrounded by denser spots (blister-like white spots) appear.

#### Cause:

This may occur if a solid image is printed on coated paper, if a solid image is printed during duplex printing, or if printing is done at low temperature.

#### Solution:


If blister-like white spots appear, carry out the procedure on p.1074 "Insufficient Toner Fusing".

6

6

# Mottling

RTB 113
This section has been modified



- [A]: Normal
- [B]: Mottled

Mottling occurs in solid-filled areas.

#### Cause:

This may occur if:

- Using paper with a rough surface
- Continuously printing solid fills covering small areas
- Printing in a low humidity environment
- Printing in a high humidity environment



 If the problem occurs only if black is used when printing in full-color mode, carry out the procedure on p.1067 "Color (1): Black Faint During Full Color Printing".

#### Solution:

- 1. If a message prompting replacement of a unit has appeared, replace the unit.
- 2. To identify the affected color, print three full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets for each of cyan, yellow, magenta, and black.
- 3. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or with SP3-011-002.

4. Print the image. Is the problem resolved?

**Yes** Check if the customer executes multiple prints job with low coverage. If so, increase the setting of SP3-820-001 to -004 for affected color. If not, contact your supervisor.

No Print 100 full-page, solid-fill (SP2-109-003: "26") A3 or DLT sheets in the affected color.

5. Print the image. Is the problem resolved?

Yes Finished!

No Reload with new paper.

6. Print the image. Is the problem resolved?

Yes Finished!

No Replace the paper with smoother paper.

7. Is any SC is issued?

**Yes** Do the countermeasure for the issued SC. If this does not solve the problem, contact your supervisor.

**No** Increase the value by 1 for all colors in [0203: Adjust Maximum Image Density] or use SP3-620-011 to 014. If this does not solve the problem, contact your supervisor.

#### **Density Problems**

#### **Uneven Image Density**


The density is uneven.

#### Solution:

The solution depends on the type of unevenness.

Carry out the appropriate procedure from those in the following table:

(A) The density is uneven across the entire image.



The density from top to bottom is uneven.

#### Solution

1. Is there any part in the machine with its PM life ended?

Yes Replace the unit. If the problem persists, go to the next step.

No Go to the next step.

- 2. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 4. See "Uneven Density within 90 mm (3.5 in.) of the Trailing Edge" or replace one of the following units:
  - Drum unit ( p.553)
  - Drum charge unit (\*\*p.551)
  - Development unit ( p.558)
- 5. Print the image. Is the problem resolved?

Yes Finished!

No Check the ITB roller lift mechanism or PTR roller contact mechanism.

# Affected area

The sides are fainter or denser.

#### Solution

1. Is there any part in the machine with its PM life ended?

Yes Replace the unit. If the problem persists, go to the next step.

No Go to the next step.

- 1. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 2. Print the image. Is the problem resolved?


Yes Finished!

No Go to the next step.

- 3. Replace the development unit. (\*\*p.558)
- 4. Print the image. Is the problem resolved?

Yes Finished!

No Check the ITB roller lift mechanism or PTR roller contact mechanism.



# Solution

1. Is there any part in the machine with its PM life ended?

Yes Replace the unit. If the problem persists, go to the next step.

No Go to the next step.

- 1. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.


- 3. Replace the development unit. (Pp.558)
- 4. Print the image. Is the problem resolved?

Yes Finished!

No Check the ITB roller lift mechanism or PTR roller contact mechanism.

#### (B) The density is uneven in a part of the image.

#### Affected area



The leading edge is fainter.

#### Solution

1. Is there any part in the machine with its PM life ended?

Yes Replace the unit. If the problem persists, go to the next step.


No Go to the next step.

- 2. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No If the problem persists, see p.1061 "Fainter Leading Edge".

#### Affected area



The trailing edge is fainter.

#### Solution

1. Is there any part in the machine with its PM life ended?


Yes Replace the unit. If the problem persists, go to the next step.

No Go to the next step.

- 1. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No If the problem persists, see p. 1061 "Fainter Leading Edge"...



The area within 90 mm (3.5 inches) of the trailing edge is fainter or denser.

#### Solution

1. Is there any part in the machine with its PM life ended?

Yes Replace the unit. If the problem persists, go to the next step.

No Go to the next step.

- 2. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 3. Print the image. Is the problem resolved?

Yes Finished!

**No** If the problem persists, see p. 1064 "Uneven Density within 90 mm (3.5 in.) of the Trailing Edge".

# Affected area One of the centre is fainter or denser.

#### Solution

1. Is there any part in the machine with its PM life ended?


Yes Replace the unit. If the problem persists, go to the next step.

No Go to the next step.

- 2. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No If the problem persists, replace the development unit. (\*\*p.558)



1. Is there any part in the machine with its PM life ended?

**RTB 114** 

This procedure was modified

Yes Replace the unit. If the problem persists, go to the next step.


No Go to the next step.

- 2. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or SP3-011-002.
- 3. Print the image. Is the problem resolved?

Yes Finished!


4. No If the problem persists, replace the development unit or developer. (\*\*p.558) or (\*\*p.559)

#### (C) The vertical density fluctuates periodically



#### Solution

- 1. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or execute SP3-011-002 in the SP mode.
- 2. If the problem persists, see p. 1066 "Periodic Density Fluctuation".



The density is uneven from top to bottom.



• You can adjust the density of halftone images, but not that of solid fills.

#### Cause:

This may occur at high temperature or humidity.

#### Solution:

- 1. To identify the affected color, print three full-page, halftone (SP2-109-003: "12") A3 or DLT sheets for each of cyan, yellow, magenta, and black.
- 2. In the [Adjustment Settings for Skilled Operators] menu, select [0205: Adjust Density Difference Across Feed Direction] or use SP2-113-001 to 004.

Decreasing the value for the affected color makes the area above the centre denser and the area below fainter.

Increasing the value for the affected color makes the area above the centre fainter and the area below denser.

- 3. Turn off the power and the main power switch, and then turn the main power switch back on.

  The setting specified in step 2 takes effect.
- 4. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 5. Replace one of the following units:
  - Development unit (IPp.558)
  - Drum unit ( p.553)
  - Drum charge unit (IPp.551)
  - PTR unit (\*\*p.432)


6

- ITB roller (1 p.631)
- 6. Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

#### Fainter Leading Edge



The leading edge is fainter.

#### Cause:

At low temperature or when using thin coated paper, this may occur if the paper transfer current is insufficient.

At high temperature, this may occur if the paper transfer current is excessive.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

# **Important**

- This solution only works when the thickness of the paper is equivalent to Paper Weight 4 or above.
- If the leading edge coefficient is set too high, this could cause paper separation after image transfer to deteriorate and lead to paper jams. This is particularly true with thickness settings of 3 or lower.

#### Solution:

1. Make a note of the present value in the following setting in [Advanced Settings] for the custom paper in use.

[35: Paper Transfer Current; Lead Edge: B&W] or SP2-972.

#### <Printing in full color>

[36: Paper Transfer Current; Lead Edge: FC] or SP2-973.

- 2. Increase the scaling factor in the above setting by 10 percentage points.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Increase the scaling factor by 10 percentage points.


- 4. Repeat Step 3. If the problem persists even though you have increased the scaling factor by 50 percentage points, restore the value noted in Step 1 and go to the next step.
- 5. Decrease the scaling factor in the above setting by 10 percentage points.
- 6. Print the image. Is the problem resolved?

Yes Finished!

No Decrease the scaling factor by 10 percentage points.

7. Repeat Step 6. If the problem persists even though you have decreased the scaling factor by 50 percentage points, restore the value noted in Step 1 and contact your supervisor.

#### Fainter Trailing Edge



The trailing edge is fainter.

#### Cause:

This may occur because of insufficient or excessive paper transfer current when using paper weighing approximately  $160 \text{ g/m}^2$  (60 lb. Cover) or heavier at low temperature.

6



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

- 1. Measure in millimeters how far the fainter area extends from the trailing edge.
- 2. Configure the following settings in [Advanced Settings] for the custom paper in use.

#### <Printing in black and white>

In [41: Ppr Transfer Current Trail Edg Dist: BW] or SP2-978, enter the value you measured in Step 1 plus an additional 10 mm.

#### <Printing in full color>

In [42: Ppr Transfer Current Trail Edg Dist: FC] or SP2-979, enter the value you measured in Step 1 plus an additional 10 mm.

3. Make a note of the present value in the following setting in [Advanced Settings] for the custom paper in use.

#### <Printing in black and white>

[39: Paper Transfer Current; Trail Edge: B&W] or SP2-2-977

#### <Printing in full color>

[40: Paper Transfer Current; Trail Edge: FC] or SP2-977

- 4. Increase the scaling factor in the above setting by 10 percentage points.
- 5. Check test print. Printing recovered?

Yes. Succeeded, go to 6

No. Failed. Restore original setting, and then lower the trailing edge correction coefficient. Go to 9.

6. Trailing edge margin satisfactory?

Yes. Success. End

No. Go to 7.

- 7. Raise the value another 5%.
- 8. Do a test print and check results. Image satisfactory?

Yes. Succeeded, to 7 (as long as image is satisfactory, you can keep adding 5%).

No. Failed. Restore original setting before it was raised 5%. No further adjustment is possible.

- 9. Lower the setting 10% below its original value.
- 10. Do a test print, check the results. Printing satisfactory?

Yes. Succeeded, go to 11.

No. Failed. Restore original setting. No further adjustment is possible.

11. Problem with trailing edge margin solved?

Yes. End.


No. Go to 12.

- 12. Reduce the setting another 5%.
- 13. Do a test print, check the results. Printing recovered?

Yes. Succeeded, go to 12. (as long as image is satisfactory, you can keep adding 5%).

No. Failed. Restore original setting before it was raised 5%. No further adjustment is possible.

#### Uneven Density within 90 mm (3.5 in.) of the Trailing Edge



• [A]: 90 mm (3.5 in.)

Printing in the area extending approximately 90 mm (3.5 inches) from the trailing edge is fainter or denser when the temperature or humidity is low.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

The solution depends on whether the area within 90 mm (3.5 inches) of the trailing edge is denser or fainter.

#### <If the area within 90 mm (3.5 inches) of the trailing edge is fainter>

- In [Advanced Settings] for the custom paper in use, select [20: Transfer Timing Roller Feed Speed Adj] or SP1-963.
- 2. Check the present value. Is it higher than +0.5%?

Yes Use another type of paper.

No Increase the value by 0.1 percentage point.

3. Print the image. Is the problem resolved?

Yes Finished!

**No** Repeat Steps 1 to 3. If the problem persists even if you increase the value to +0.5%, contact your supervisor.

#### <If the area within 90 mm (3.5 inches) of the trailing edge is denser>

- In [Advanced Settings] for the custom paper in use, select [20: Transfer Timing Roller Feed Speed Adi] or SP1-963.
- 2. Check the present value. Is it lower than -0.5%?

Yes Use another type of paper.

No Decrease the value by 0.1 percentage point.

3. Print the image. Is the problem resolved?

Yes Finished!

**No** Repeat Steps 1 to 3. If the problem persists even if you decrease the value to -0.5%, contact your supervisor.

#### <If you fail to solve the problem>

Follow this procedure to adjust the speed of the transfer timing roller.

- 1. Check the type and thickness of the paper in use.
- 2. Paper not registered?

No. Register the paper, or adjust the speed of the time roller with SP1-006.

**Yes**, In [Advanced Settings] for the custom paper in use, select [20: Transfer Timing Roller Feed Speed Adi] and adjust or use SP1-963.

3. Trailing edge margin dark?

Yes. Adjust the speed of the transfer timing roller down -0.1% from its present setting. Go to 4.

No. Adjust the speed of the transfer timing roller up +0.1% from its present setting. Go to 4

4. Operator satisfied with the results?

Yes. Finished.


No. Repeat 3

5. Operator satisfied with the results?

Yes. Finished.

No. Repeat 4.

## **Periodic Density Fluctuation**



The vertical density fluctuates periodically.


#### Solution:

The solution depends on the interval.

Interval	Solution
Approximately 12-18 mm (0.5-0.7 inches)	Replace the development unit.  If the problem persists, contact your supervisor.
Approximately 50 mm (2 inches)	Replace the charge roller.  If the problem persists, contact your supervisor.
Approximately 60 mm (2.4 inches)	Replace the transfer unit.  If the problem persists, contact your supervisor.
Approximately 95 mm (3.7 inches)	Replace the ITB drive roller.  If the problem persists, contact your supervisor.
Approximately 190 mm (7.5 inches)	Replace the drum unit.  If the problem persists, contact your supervisor.

6

#### Color (1): Black Faint During Full Color Printing



- [A]: Normal
- [B]: Black is fainter.

Black is fainter than normal during full color printing.

#### Cause:

If black is used when printing in full color mode with black toner only, the printing may become faint.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

Carry out the following sequence of procedures. Terminate the sequence as soon as the problem is resolved.

#### Procedure 1: Increasing the image transfer current for black in full color mode

- 1. In [Advanced Settings] for the custom paper in use, select [27: Image Transfer Current: FC: Black] or SP2-991.
- 2. Increase the value by 10 PA.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Increase the value by 5  $\mu$ A.

4. Repeat Step 3. If doing this adversely affects colors other than black, reduce the value by 5 µA and carry out Procedure 2, "Executing image processing".

#### Procedure 2: Executing image processing

Do the following on the Command WorkStation (CWS).

- 1. Select "Properties..." for the image.
- 2. Click the "Color" tab.
- 3. In "Color mode", select "Expert Settings...".
- 4. If "CMYK/Grayscale" is set to "Colorwise OFF", change it to an appropriate image process.
- 5. If an appropriate image process has already been selected but the problem persists, carry out Procedure 3, "Printing black using four colors (YMCK) in full-color mode".

#### Procedure 3: Printing black using four colors (YMCK) in full-color mode

Do the following on the Command WorkStation (CWS).

- 1. Select "Properties..." for the image.
- 2. Click the "Color" tab.
- 3. In "Color mode", select "Expert Settings...".
- 4. Click the "Gray & Black processing" tab.
- Set "Black text graphics" to "Normal".Black is printed with 4 colors (YMCK).



- If "Black text graphics" is set to "Pure Black On", black is printed with only black toner.
- 6. If the problem persists, contact your supervisor.

#### Color (2): Entire Image Faint

The quick brown fox jumps over the lazy dog. Buvez de ce whisky que le patron juge fameux. El veloz murciélago hindú comfa feliz cardillo y kiwi. The quick brown fox jumps over the lazy dog. Buvez de ce whisky que le patron juge fameux. El veloz murciélago hindú comfa feliz cardillo y kiwi. The quick brown fox jumps over the lazy dog. Buvez de ce whisky que le patron juge fameux. El veloz murciélago hindú comfa feliz cardillo y kiwi. The quick brown fox jumps over the lazy dog. Buvez de ce whisky que le patron juge fameux. El veloz murciélago hindú comfa feliz cardillo y kiwi. El veloz murciélago hindú comfa feliz cardillo y kiwi.



The entire image is fainter than normal.

#### Cause:

This may occur if:

- · Continuously printing an image that consumes little toner
- The machine has not been used for a long time

• The machine is located somewhere very humid and has not been used for a while

#### Solution:

- 1. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or execute SP3-011-002 in the SP mode.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 3. Increase/decrease the value by 1 for all colors in [0203: Adjust Maximum Image Density] or with SP3-620-011 to 014..
- 4. Execute [0201: Adjust Image Density] or execute SP3-011-002 in the SP mode.
- 5. Print the image. Is the problem resolved?

Yes Finished!

**No** Repeat Steps 3 to 5. If the problem persists even if you increase the value to 5, go to the next step.

6. Execute the ACC (Automatic Color Calibration) Adjustment.



- "ACC" is machine calibration for copier jobs.
- For printer jobs, execute Fiery calibration.
- 7. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

8. Is there any defective part, SC issued, or a part with the PM life ended?

Yes Replace the necessary part. If this does not solve the problem, contact your supervisor.

**No** Contact your supervisor.

The quick brown fox jumps over the lazy dog. Buvez de ce whisty que le patron juge fameux. El veicz murciólago hindú comfe feltz cerdillo y ldwi. The quick brown fox jumps over the lazy dog. Buvez de ce whisty que le patron juge fameux. El veicz murciólago hindú comfe feltz cardillo y ldwi. The quick brown fox jumps over the lazy dog. Buvez de ce whisty que le patron juge fameux. El veicz murciólago hindú comfe feltz cardillo y ldwi. The quick brown fox jumps over the lazy dog. Buvez de ce whisty que le patron juge fameux. El veicz murciólago hindú comfe feltz cardillo y ldwi.

d074t635

The entire image is denser than normal.

#### Cause:

This may occur if:

- Continuously printing an image that consumes much toner
- The machine has not been used for a long time
- The machine is located somewhere very humid and has not been used for a while

#### Solution:

- 1. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or execute SP3-011-002 in the SP mode.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 3. Increase/decrease the value by 1 for all colors in [0203: Adjust Maximum Image Density] or with SP3-620-011 to 014.
- 4. Execute [0201: Adjust Image Density] or execute SP3-011-002 in the SP mode.
- 5. Print the image. Is the problem resolved?

Yes Finished!

**No** Repeat Steps 3 to 5. If the problem persists even if you decrease the value to -5, go to the next step.

6. Execute the ACC (Automatic Color Calibration) Adjustment



- "ACC" is machine calibration for copier jobs.
- For printer jobs, execute Fiery calibration.

7. Print the image. Is the problem resolved?

Yes Finished!


No Go to the next step.

8. Is there any defective part, SC issued, or a part with the PM life ended?

Yes Replace the necessary part. If this does not solve the problem, contact your supervisor.

No Contact your supervisor.

#### **Broken Thin Lines**



Thin lines (1 dot lines in 1200 dpi images) break.

#### Cause:

Oblique (approximately 45°) thin lines or thin lines printed in faint colors are likely to contain breaks.

#### Solution:

- 1. In the [Adjustment Settings for Skilled Operators] menu, execute [0201: Adjust Image Density] or execute SP3-011-002 in the SP mode.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.


- 3. Increase/decrease the value by 1 for all colors in [0204: Adjust Line Width] or with SP3-623-061 to 064.
- 4. Execute [0201: Adjust Image Density] or execute SP3-011-002 in the SP mode.
- 5. Print the image. Is the problem resolved?

**Yes** Finished! However, execute the ACC adjustment for the copier or printer if the current color output is different from the previous color output.

**No** Repeat Steps 3 to 5. If the problem persists even if you increase the value to 5, contact your supervisor.

#### Gloss Problems

#### **Glossy Lines**



• [A]: 20 mm or 26.5 mm (0.8 or 1.0 in.)

Glossy lines appear every 20 or 26.5 mm (0.8 or 1.0 inches).

#### Cause:

This may occur if coated or thin paper is used.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.




- If the glossy lines appear at irregular intervals, you cannot resolve the problem with this procedure. Contact your supervisor.
- Decreasing the temperature may cause unsatisfactory fusing.

#### Solution:

- 1. In [Advanced Settings] for the custom paper in use, select [44: Fusing Heat Roller Temperature Adj] or select SP1-984 in the SP mode.
- 2. Decrease the value by 10 °C. If the gloss of the entire image drops after this, decrease the value only by 5 °C instead of 10 °C.
- 3. If the problem persists, contact your supervisor.

#### **Vertical Glossy Lines**



• [A]: 251 mm (10 inches)

Glossy lines parallel to the paper feed direction appear.

#### Cause:

Glossy lines parallel to the paper feed direction may appear 251 mm from the boundary of the margin and solid image (in the direction opposite to the paper feed direction).

#### Solution:

If vertical glossy lines appear, carry out the procedure in " Glossy Lines ".

#### Insufficient Gloss

The image is not glossy enough.

#### Solution:

If the gloss of the image is not glossy enough, carry out the procedures in Procedure 1 and Procedure 4 on p.1074 "Insufficient Toner Fusing".

### **Fusing-related Troubleshooting**

#### **Optimizing Productivity for Mixed Paper Stocks**

#### **Problem**

The fusing temperature is normally adjusted for each paper type. As a result, down time of the machine may be longer if the machine gets a sequence of jobs in which the paper type changes between jobs. If

a customer considers that the productivity of the machine has more priority than print quality, do the procedure below.

#### Solution

1. Change the setting of SP1-131-001 from "0" to "1".

This solution may get good results in the following cases:

- Small difference in the target fusing temperature between two jobs
- Same line speed between two jobs

#### Side Effects

- If paper weight is changed from light to heavy; a fusing problem may occur for several prints just
  after paper weight has been changed due to insufficient fusing temperature.
- If paper weight is changed from heavy to light; a fusing problem (glossy lines) may occur for several prints just after paper weight has been changed due to too much fusing temperature.
- Some troubleshooting by adjusting the heating roller temperature may not be effective after selecting the setting of SP1-131-001 to "1".

#### **Insufficient Toner Fusing**

This section explains how to resolve the problem of insufficient toner fusing on printed copies.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

Carry out the following sequence of procedures. Terminate the sequence as soon as the problem is resolved.

#### Procedure 1: Changing the fusing temperature

- 1. In [Advanced Settings] for the custom paper in use, select [44: Fusing Heat Roller Temperature Adj] or select SP1-984 in the SP mode, and then make a note of the currently selected temperature.
- 2. Increase the temperature by 5 °C.
- 3. Print the image and check toner fusion. Is the problem resolved?

Yes Finished!

**No** Increase the temperature another 5 °C.

4. Repeat Step 3.

If the problem persists even if you increase the temperature to 180 °C, return the temperature to the one you noted in Step 1, and then carry out Procedure 2, "Image processing 1".

#### Procedure 2: Image processing 1

Do the following on the Command WorkStation (CWS).

- 1. Select "Properties..." for the image.
- 2. Click the "Color" tab.
- 3. In "Color mode", select "Expert Settings...".
- 4. If "CMYK/Grayscale" is set to "Colorwise OFF", change it to "Colorwise ON". If not, carry out Procedure 3, "Image processing 2".
- 5. Print the image and check toner fusion. Is the problem resolved?

Yes Finished!

No Carry out Procedure 3, "Image processing 2".

#### Procedure 3: Image processing 2

1. Are the images printed in one or two colors?

Yes Carry out Procedure 4, "Changing the process speed".

No (three-color printing or unknown): In the printer driver setting, select toner reduction mode.

2. Print the image and check toner fusion. Is the problem resolved?

Yes Finished!

No Carry out Procedure 4, "Changing the process speed".

#### Procedure 4: Changing the process speed

This will slow down the printing to give the toner more time to fuse. However, because of this, throughput will be reduced.

Example when printing on A4/LT paper:

#### <D074>

If the process speed is changed from [High] to [Middle]: 65 cpm  $\rightarrow$  45 cpm

If the process speed is changed from [Middle] to [Low]: 45 cpm → 32 cpm

#### <D075>

If the process speed is changed from [High] to [Middle]: 75 cpm  $\rightarrow$  52 cpm

If the process speed is changed from [Middle] to [Low]: 52 cpm  $\rightarrow$  37 cpm

 In [Advanced Settings] for the custom paper in use, select [19: Process Speed Setting] or select SP1-986 in the SP mode.

The settings for the Advanced Settings and the SP settings correspond to one another as shown in the table below.

Advance Settings	SP Code Settings
High	0: Target Speed
Middle	1: Medium Speed

Advance Settings	SP Code Settings
Low	2: Low Speed

2. Decrease the value by one level.

If the present value is [High], select [Middle]. If it is [Middle], select [Low].

3. Print the image and check toner fusion. Is the problem resolved?

Yes Finished!

**No** If the problem persists, the machine may be faulty or the paper unsupported. Contact your supervisor.

# **Troubleshooting for Paper Delivery Problems**

#### Frequent Paper Misfeeds

#### Coated or another type of unsupported paper is loaded in the machine's tray.

Load paper not supported by the machine's paper tray (Trays 1 and 2) in the wide LCT (Trays 3-5) or another paper tray supporting the paper. For details about the size and type of paper that can be loaded in the paper trays, see "Recommended Paper Sizes and Types", About This Machine.

#### The side fences in the paper tray are too close together.

If the distance between the side fences is less than the paper width, it may interfere with paper transfer and so cause paper misfeeds.

Adjust the side fences to match the paper width.

For details about loading paper, see "Loading Paper", About This Machine.

#### The side fences in the paper tray are too far apart.

If the side fences are too far apart, paper misfeeds may occur due to wrong paper size detection.

Adjust the side fences to match the paper width.

For details about loading paper, see "Loading Paper", About This Machine.

#### The paper size/orientation is not specified correctly.

In tray paper settings, specify the size and orientation of the paper in use.

For details about tray paper settings, see "Changing Tray Paper Settings", Paper Settings Reference.

#### Too many sheets of paper are loaded in the paper tray.

When loading paper, do not exceed the limit.

For details about how many sheets can be loaded in the paper trays, see "Recommended Paper Sizes and Types".

#### The edges of the sheets are rough.

Turn the sheets the other way up or smooth the edges before loading.

#### Sheets are curled or wavy.

- Flatten curls and waviness before loading paper.
- Turn the sheets the other way up or smooth the edges before loading.

#### Sheets absorbed moisture and became limp.

Sheets that will not be used for a long time should be protected from moisture by, for example, storing them in a sealed bag.

If you switch the anti-humidity heater on, the heater is inside the paper tray will operate to prevent sheets from absorbing moisture even when the main power is off.

For details about operating the anti-humidity heater, see "Anti-humidity Heater Switch", About This Machine.

#### When using thick paper or slippery paper.

Enable the Pickup Assist setting.

#### <If custom paper is used>

1. In [Advanced Settings] for the custom paper in use, set [03: Pickup Assist Setting] to [On] or set SP1-977 to "1: ON".

#### <If custom paper is not used>

1. In the [Adjustment Settings for Skilled Operators] menu, set [0115: Pickup Assist Setting] to [On] or by setting SP1-923-001 to 006 to "1: FORCE ON".

#### The paper feed sensor is stained with paper dust.

Clean the part of the paper feed sensor where the paper misfeed is detected.

For details about cleaning the paper feed sensor, see the Replacement Guide.

The paper feed performance is less sufficient because the paper transport roller is soiled with toner.

Clean the part of the paper transport roller where the paper misfeed is detected.

For details about cleaning the paper transport roller, see the Replacement Guide.

Frequent jam (J031 or J080 detected by the transfer timing sensor/ J028, J029 or J078 detected by the registration timing sensor) occurs due to the wrong operation of the transfer timing motor.

- 1. Check the following points:
  - The harness of the transfer timing motor is correctly connected.
  - The encoder of the transfer timing roller is correctly installed.
  - No obstruction on the transfer timing roller exists.
- 2. Replace the transfer timing motor.

## Messages Reporting Paper Misfeeds



d074t639

Paper misfeeds are reported by messages prefixed with problem codes.

Resolve the problem according to the code.

This section only lists the codes for problems that can be resolved by the user.

If a problem code not listed in this section appears, contact your supervisor.

## If (J032) Appears

### Cause:

The edge of a sheet is jammed in the transfer belt or paper transfer roller.

Floppy paper is likely to cause paper misfeeding because it tends to stick to the intermediate transfer belt and paper transfer roller.



- To adjust the following settings, pre-register the type of paper in use as a custom paper.
- For details about how to register Custom Paper settings, see "Registering a Custom Paper" in the Paper Settings Reference.

#### Solution:

#### <Color printing>

- 1. In [Advanced Settings] for the custom paper in use, set [36: Paper Transfer Current; Lead Edge: FC] to "100%" or set SP2-973 to "100%".
- 2. Print 25 sheets of the image. Is the problem resolved?

### Yes Finished!

No Go to the next step.

- 3. Set [36: Paper Transfer Current; Lead Edge: FC] to "80%" or set SP2-973 to "80%".
- 4. Print 25 sheets of the image.
  - If paper misfeeding no longer occurs, the problem has been solved.
  - If the leading edge of the printed image becomes faint as a result of this, go to the next step.
  - If the paper misfeeding persists, skip to step 7.
- 5. Set [38: Ppr Transfer Current Lead Edg Dist: FC] or set SP2-975 to "5 mm".
- 6. Print 25 sheets of the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

- Ask a customer to increase the leading edge margin in the print settings (10 mm) for the image to be printed.
- 8. Set [36: Paper Transfer Current; Lead Edge: FC] to "0%" or set SP2-973 to "0%".
- 9. Print 25 sheets of the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

### <Black-and-white printing>

- 1. In [Advanced Settings] for the custom paper in use, set [35: Paper Transfer Current; Lead Edge: B&W] to "100%" or set SP2-972 to "100%".
- 2. Print 25 sheets of the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 3. Set [35: Paper Transfer Current; Lead Edge: B&W] to "80%" or set SP2-972 to "80%".
- 4. Print 25 sheets of the image.
  - If paper misfeeding no longer occurs, the problem has been solved.
  - If the leading edge of the printed image becomes faint as a result of this, go to the next step.
  - If the paper misfeeding persists, skip to step 7.
- 5. Set [37: Ppr Transfer Current Lead Edg Dist: BW] to "5 mm" or set SP2-975 to "5 mm".
- 6. Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

- 7. Ask a customer to increase the leading edge margin in the print settings (10 mm) for the image to be printed.
- 8. Set [35: Paper Transfer Current; Lead Edge: B&W] to "0%" or set SP2-972 to "0%".
- 9. Print 25 sheets of the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.



If you cannot change the leading edge margin, paper misfeeding may be eliminated by reorienting
the loaded paper according to its grain. For details about paper grain and orientation, see
"Loading Paper", About This Machine.

## If (J080) Appears

#### Cause:

The correct paper feed speed is not being maintained.

When using slippery paper, traction may be lost, reducing paper feed speed.

#### Solution:


- In [Advanced Settings] for the custom paper in use, set [07: Regist Jam Detection with Feed Dir] to [Off] or set SP1-958 to [Off].
- 2. When you set this to [Off], the printed image may become misaligned at the leading edge.

Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

# If (J033) or (J083)Appears



- [A]: Leading edge margin
- [B]: Trailing edge margin

At installation the service technician executes machine position adjustment using. If the sub scan registration adjustment exceeds  $\pm 0.3$  mm, the service technician should inform the operator about the amount of adjustment and then guide the operator through the user adjustment settings. The relevant settings are:

- Side 1 image position adjustment: Direction of paper feed
- Side 2 image adjustment: Direction of paper feed

#### Cause:

Paper is jammed in the fusing belt stripper plate.

This is likely to occur if:

- Thin or coated paper is used
- · A solid image that consumes a lot of toner is printed at the leading edge
- The leading/trailing edge margin is too narrow

Paper feed direction

Leading-edge margin Trailing-edge margin

#### Solution:

Increase the leading/trailing edge margin.

By increasing the margin, paper can separate more easily from the fusing belt stripper plate.

### When printing on one side only

### <If it is acceptable for the image to be incompletely printed at its edge>

Trim the image at its leading edge to increase the margin.

- 1. In [Advanced Settings] for the custom paper in use, select [13: Adjust Erase Margin of Leading Edge] or select SP2-122.
- 2. Increase the value by 0.5 mm.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing the value by 0.5 mm until the problem is resolved.

If the problem persists even though the setting has reached its maximum value, contact your supervisor.

#### <If it is not acceptable for the image to be incompletely printed at its edge>

- In [Advanced Settings] for the custom paper in use, select [08: Adj Image Position of Side 1 With Feed] or select SP1-950.
- 2. Increase the value by 0.5 mm.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing the value by 0.5 mm until the problem is resolved.

If the problem persists even though the setting has reached its maximum value, contact your supervisor.

### When printing on both sides

### If it is acceptable for the image to be incompletely printed at its edge>

- In [Advanced Settings] for the custom paper in use, select [14: Adjust Erase Margin of Trailing Edge] or select SP2-123.
- 2. Increase the value by 0.5 mm.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing the value by 0.5 mm until the problem is resolved.

If the problem persists even though the setting has reached its maximum value, contact your supervisor.

#### <If it is not acceptable for the image to be incompletely printed at its edge>

- In [Advanced Settings] for the custom paper in use, select [08: Adj Image Position of Side 1 With Feed] or select SP1-950.
- 2. Increase the value by 0.5 mm.
- 3. Select [09: Adj Image Position of Side2 With Feed] or select SP1-951.
- 4. Decrease the value by 0.5 mm.
- 5. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing/decreasing the value by 0.5 mm until the problem is resolved.

If the problem persists even though the setting has reached its maximum/minimum value, contact your supervisor.

## If (J097) Appears

#### Cause:

Paper is skewed.

#### Solution:

Depending on the cause of the problem, do one the following:

#### The side fences in the paper trays are not positioned correctly.

Adjust the side fences to match the paper width.

For details about loading paper, see "Loading Paper", About This Machine.

#### The paper size/orientation/type is not specified correctly.

In tray paper settings, specify the size, orientation, and type of the paper in use.

For details about tray paper settings, see "Changing Tray Paper Settings", Paper Settings Reference.

#### Sheets of mixed type, thickness, or color are loaded in the paper tray.

Load identical sheets in the paper tray. When printing from a tray containing sheets of mixed color, you can prevent paper mis-feeding by specifying the following settings.

#### <If custom paper is used>

- 1. In [Advanced Settings] for the custom paper in use, set [12: Deactivate Image Position Adjustment Across Feed Dir] to [On] or set the setting of SP1-957 to [1].
- 2. In [Advanced Settings] for the custom paper in use, set [05: Skew Detection] to [Off] or set SP1-955 to [0].

### <If custom paper is not used>

- 1. In the [Adjustment Settings for Skilled Operators] menu, set [0107: Deactivate Image Position. Adjustment Across Feed Dir] to [On] or set the setting of SP1-917-001 to -007 to [1].
- 2. Set [0108: Skew Detection] to [Off] or SP1-021-001- to -007 to [0].

### An envelope is used.

If an envelope with a beveled flap is fed with the flap open, the machine may detect it as a skew. Disable the skew detection function.

### <If custom paper is used>

 In [Advanced Settings] for the custom paper in use, set [05: Skew Detection] to [Off] or set SP1-955 to [0].

#### <If custom paper is not used>

1. In the [Adjustment Settings for Skilled Operators] menu, set [0108: Skew Detection] to [Off] or set SP1-021-001 to -007 to [0].

### The skew detection level is too high.

The skew detection level may be too high.

#### <If custom paper is used>

 In [Advanced Settings] for the custom paper in use, set [05: Skew Detection] to [Off] or set SP1-955 to [0].

## <If custom paper is not used>

1. Set [0108: Skew Detection] to [Off] or SP1-021-001- to -007 to [0].



- If the skew detection level is reduced or the skew detection function is disabled, no misfeed report will be displayed. However, this may result in paper skew feeding. If you do not want this result, contact your supervisor.
- If the machine wrongly detects skew, see p.1088 "Wrong Detection of Skew".

## If (J098) Appears

#### Cause:

Sheets cannot be positioned properly by image position adjustment.

#### Solution:

Depending on the cause of the problem, do one of the following:

## The side fences in the paper trays are not positioned correctly.

Adjust the side fences to match the paper width.

For details about loading paper, see "Loading Paper", About This Machine.

### The paper size/orientation/type is not specified correctly.

In tray paper settings, specify the size, orientation, and type of the paper in use.

For details about tray paper settings, see "Changing Tray Paper Settings", Paper Settings Reference.

## Sheets of mixed type, thickness, or color are loaded in the paper tray.

Load identical sheets in the paper tray.

When printing from a tray containing sheets of mixed color, you can prevent paper misfeeding by specifying the following settings:

- 1. In the [Adjustment Settings for Skilled Operators] menu, set [0107: Deactivate Image Position Adjustment Across Feed Dir] to [On] or set the setting of SP1-917-001 to -007 to [On].
- 2. Set [0108: Skew Detection] or SP1-021-001- to -007 to [Off].

#### Colored paper or transparencies are loaded in the paper tray.

Paper edges may not have been detected correctly.

Adjust the color paper edge detection.

- 1. Make a note of the present value in [06: Colour Paper Edge Detection Adjustment] in [Advanced Settings] or a note of the present value in SP1-962 in the SP mode for the custom paper in use.
- 2. Increase the value in [06: Colour Paper Edge Detection Adjustment] or SP1-962.
- 3. Print the image. Is the problem resolved?

### Yes Finished!

No Keep increasing the value until the problem is resolved.

If the problem persists even though the setting has reached its maximum value, restore the value noted in step 1 and go to the next step.

- 4. Decrease the value in [06: Colour Paper Edge Detection Adjustment] or SP1-962.
- 5. Print the image. Is the problem resolved?

Yes Finished!

No Keep decreasing the value until the problem is resolved.

If the problem persists even though the setting has reached its minimum value, restore the value noted in step 1 and go to the next step.

- 6. Set [12: Deactivate Image Position Adjustment] to [Activate] or set the setting of SP1-957 to [Active].
- 7. Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

## If (J099) Appears

#### Cause:

Double feeding has occurred.

#### Solution:

Depending on the cause of the problem, do one of the following:

## Coated or another type of unsupported paper is loaded in the machine's tray.

Load paper not supported by the machine's paper tray (Trays 1 and 2) in the wide LCT (Trays 3-5) or another paper tray that supports the paper.

For details about the size and type of paper that can be loaded in the paper trays, see "Recommended Paper Sizes and Types", About This Machine.

#### Sheets are stuck to each other.

Fan the paper before loading it to loosen the sheets.

For details about fanning the paper, see "Fanning the Paper", About This Machine.

## The edges of the sheets are rough.

Turn the sheets the other way up or smooth the edges before loading the paper.

### Wrong detection of double feeding

The machine may have wrongly detected a double feed.

For details, see p. 1090 "Wrong Detection of Double Feeding".

## Paper Skew

## The side fences in the paper tray are too far apart.

If the side fences are too far apart, the paper may misfeed.

Adjust the side fences to match the paper width.

For details about loading paper, see "Loading Paper", About This Machine.

A scrap of paper or some other small fragment is jammed in the paper feed path.

6

Remove the fragment.

For details about cleaning the paper feed path, see the Replacement Guide.

The correct degree of paper arching has not been specified.

Adjust the degree of paper arching at the registration gate.

## <If using paper of Paper Weight 1 to 4>

- Make a note of the present value in [0103: Adjust Registration Paper Buckle] in the [Adjustment Settings for Skilled Operators] menu or a note of the present value in SP1-004-001 to -003 in the SP mode for the custom paper in use.
- 2. Increase the value in [0103: Adjust Registration Paper Buckle] or SP1-004-001 to -003.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing the value until the problem is resolved.

If the problem persists even though the setting has reached its maximum value, restore the value noted in step 1 and go to the next step.

- 4. Decrease the value in [0103: Adjust Registration Paper Buckle] or SP1-004-001 to -003.
- 5. Print the image. Is the problem resolved?

Yes Finished!

No Keep decreasing the value until the problem is resolved.

If the problem persists even though the setting has reached its minimum value, adjust the registration gate position. (\*\*p.324)

## <If using paper of Paper Weight 5 to 7>

- Make a note of the present value in [0104: Adjust Registration Paper Buckle (Thick Paper)] in the [Adjustment Settings for Skilled Operators] menu or a note of the present value in SP1-005-001 to -003 in the SP mode for the custom paper in use.
- 2. Increase the value in [0104: Adjust Registration Paper Buckle (Thick Paper)] or SP1-005-001 to -003.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing the value until the problem is resolved.

If the problem persists even though the setting has reached its maximum value, restore the value noted in step 1 and go to the next step.

- 4. Decrease the value in [0104: Adjust Registration Paper Buckle (Thick Paper)] or SP1-005-001 to -003.
- 5. Print the image. Is the problem resolved?

Yes Finished!

No Keep decreasing the value until the problem is resolved.

If the problem persists even though the setting has reached its minimum value, adjust the registration gate position. (Pp.324)

#### The skew detection level is too low.

Increase the skew detection level.

1. In [Adjustment Settings for Skilled Operators], select [0109: Skew Detection Level] and reduce the value or select SP1-116-001 to -007 and reduce the value.

Reduce the value to decrease the detection level.

This will allow the machine to continue printing even for a slight skew.

However, if you set the detection level too high, a paper misfeeding message (J097) will be appear frequently.

2. Print the image. Is the problem resolved?

Yes Finished!

No Adjust the registration gate position. (1) p.324)

# Wrong Detection of Skew

### An envelope is used.

If an envelope with its flap's edges cut at a bevel is fed, the machine may detect it as a skew.

<If custom paper is used>

1. In [Advanced Settings] for the custom paper in use, set [05: Skew Detection | to [Off] or set SP1-995 to [0].

<If custom paper is not used>

1. In the [Adjustment Settings for Skilled Operators] menu, set [0108: Skew Detection] to [Off] or set the setting of SP1-021-001 to -007 to [0].



 Disabling the skew detection function will allow skewed printing. If this is not acceptable, contact your supervisor.

# **Double Feeding**

## Is the paper feed roller covered with paper dust?

Paper dust may decrease the traction of the paper feed roller and result in double feeding due to paper slippage or insufficient separation.

Cleaning the paper feed roller will restore traction and so prevent double feeding.

For details about cleaning the paper feed roller of each of the machine's trays (Trays 1 and 2), see the Replacement Guide.

For details about cleaning the paper feed roller of the multi bypass tray (Tray 6), see p.1110 "Cleaning the Paper Feed Path in the Multi Bypass Tray (Tray 6)".

For details about cleaning the paper feed roller of the interposer, see p.1113 "Cleaning the Paper Feed Rollers and Paper Feed Belt in the Interposer".

### Have you ruffled the paper sufficiently?

Double feeding may result if the paper is not ruffled properly.

Remove the paper, ruffle it, and reload it.

For details about ruffling the paper, see "Fanning the Paper", About This Machine.

## Is the paper feed roller covered with paper dust?

Paper dust or the surface of coated paper may decrease the traction of the paper feed roller and result in double feeding due to paper slippage or insufficient separation.

Cleaning the paper feed roller will restore traction and prevent double feeding.

For details about cleaning the paper feed roller of each of the machine's trays (Trays 1 and 2), see the Replacement Guide.

For details about cleaning the paper feed roller of the wide LCT (Trays 3-5), see p.1107 "Cleaning the Paper Feed Path in the Wide LCT (Trays 3-5)".

For details about cleaning the paper feed roller of the multi bypass tray (Tray 6), see p.1110 "Cleaning the Paper Feed Path in the Multi Bypass Tray (Tray 6)".

For details about cleaning the paper feed roller of the interposer, see p.1113 "Cleaning the Paper Feed Rollers and Paper Feed Belt in the Interposer"..

#### Is the Pickup Assist setting enabled?

If the Pickup Assist function operates too much, it may cause double feeding with coated paper.

By disabling the Pickup Assist setting, you can prevent double feeding.

#### <If custom paper is used>

1. In [Advanced Settings] for the custom paper in use, set [03: Pickup Assist Setting] to [Off] or set the setting of SP1-977 to [0: OFF].

#### <If custom paper is not used>

1. In the [Adjustment Settings for Skilled Operators] menu, set [0115: Pickup Assist Setting] to [Off], or set SP1-923-001 to 006 to [2: FORCE OFF].

#### Special or coated paper is used.

• Is the airflow strong enough?

The factory-set airflow of the wide LCT may not be strong enough to separate the sheets. Increase the airflow.

#### <If custom paper is used>

1. In [Advanced Settings] for the custom paper in use, increase the value in [02: Adjust Wide LCT Fan Level] or with SP1-975.

## <If custom paper is not used>

- In the [Adjustment Settings for Skilled Operators] menu, increase the value in [0113: Adjust Wide LCT Fan Level] or with SP1-920-001 to 003.
- Is the tab sheet holder attached?

By attaching the tab sheet holder, you can prevent air from leaking at the trailing edge of the paper and improve separation. See p.1105 "Attaching the Tab Sheet Holder".

## Wrong Detection of Double Feeding

### Preprinted paper is used.

If the sensor detects the printed part of preprinted paper, it may wrongly detect it as double feeding. Disable the double feeding detection function.

### <If custom paper is used>

1. In [Advanced Settings] for the custom paper in use, set [04: Double Feed Detect] to [Off] or set the setting of SP1-956 to [0: Off].

### <If custom paper is not used>

1. In the [Adjustment Settings for Skilled Operators] menu, set [0105: Double Feed Detect] to [Off], or set SP1302-001 to 006 to [0: Off].



 Disabling double feed detection may reduce print image quality or cause blank sheets to be delivered.

#### An envelope is being used.

The seams of envelopes may cause double feeds to be erroneously detected.

Disable the double feed detection.

#### <If custom paper is used>

 In [Advanced Settings] for the custom paper in use, set [04: Double Feed Detect] to [Off] or set the setting of SP1-956 to [0: Off].

#### <If custom paper is not used>

1. In the [Adjustment Settings for Skilled Operators] menu, set [0105: Double Feed Detect] to [Off] or set SP1-302-001 to 006 to [0: Off].



 Disabling double feed detection may reduce print image quality or cause blank sheets to be delivered.

#### The double feed detection sensor is soiled.

If the double feed detection sensor is soiled with paper dust or other fragments, it may wrongly detect double feeding.

Clean the double feed detection sensor.

For details about cleaning the double feed detection sensor, see the Replacement Guide.

### Transparency rate of paper in use is not same.

Adjust the transparency rate for customer paper settings with SP1-304-001, -002 and -003.



Changing one of these settings will affects other settings. Adjust all customer paper settings which a
customer usually uses.

# **Paper Misfeeding**

## Have you ruffled the paper properly?

Not ruffling the paper properly may cause paper misfeeding.

Remove the paper, ruffle it, and reload it.

For details about ruffling paper, see "Fanning the Paper", About This Machine.

#### The side fences in the paper tray are too close together.

If the distance between the side fences is less than the paper width, it may interfere with paper transfer and so cause paper misfeeds.

Adjust the paper guides to match the paper width.

For details about loading paper, see "Loading Paper", About This Machine.

#### Special or coated paper is used.

• Is the airflow powerful enough?

The factory-set airflow of the wide LCT may not be strong enough to separate the sheets. Increase the airflow.

#### <If custom paper is used>

1. In [Advanced Settings] for the custom paper in use, increase the value in [02: Adjust Wide LCT Fan Level] or increase the value in SP1-975.

#### <If custom paper is not used>

- In the [Adjustment Settings for Skilled Operators] menu, increase the value in [0113: Adjust Wide LCT Fan Level] or with SP-1920-001 to 003.
- Is the tab sheet holder attached?

By attaching the tab sheet holder, you can prevent air from escaping at the trailing edge of the paper and so improve separation. See p.1105 "Attaching the Tab Sheet Holder"...

Pape

• Is the paper feed roller covered with paper dust?

Paper dust or the surface of coated paper may reduce the traction of the paper feed roller and cause paper misfeeding due to paper slippage or insufficient separation.


By cleaning the paper feed roller, the frictional force can be restored so that double feeding will not occur.

For details about cleaning the paper feed roller of the wide LCT (Trays 3-5), see p.1107 "Cleaning the Paper Feed Path in the Wide LCT (Trays 3-5)".

## An envelope is used.

Depending on the type of envelope, air trapped inside may be squeezed out when the paper feed roller picks up the envelope and cause slippage leading to a misfeed.

- Is the wide LCT fan disabled?
   In [Advanced Settings] for the custom paper in use, set [01: Wide LCT Fan Setting] to [Off] or set the setting of SP1-976.
- Have you flattened the envelope?




Flatten the envelope and all its edges to eliminate air before loading. If the envelope is curled, decurl it before loading.

6

# Paper Feed Problems Affecting Image Quality

## The Image Is Positioned Incorrectly



- [A]: Original
- [B]: Output

#### Cause.

Depending on the paper thickness, floppiness, edge roughness, and curl, the image may become positioned incorrectly.

#### Solution:

Adjust the image position.

## <If custom paper is used>

1. In [Advanced Settings] or SP mode for the custom paper in use, adjust the image position.

## The side 1 of paper

- To adjust the position horizontally, change the value in [08: Adj Image Position of Side 1 With Feed] or change the value in SP1-950.
- To adjust the position vertically, change the value in [10: Adj Image Position of Side1 Across Feed] or change the value in SP1-952.

#### The side 2 of paper

- To adjust the position horizontally, change the value in [09: Adj Image Position of Side 2 With Feed] or change the value in SP1-951.
- To adjust the position vertically, change the value in [11: Adj Image Position of Side2 Across Feed] or change the value in SP1-953.

## <If custom paper is not used>

1. In the [Adjustment Settings for Skilled Operators] menu, adjust the image position.


- To adjust the position horizontally, change the value in [0101: Adjust Image Position With Feed Direction] or change the value of SP1-001-001 to 007.
- To adjust the position vertically, change the value in [0102: Adjust Image Position Across Feed Direction] or change the value of SP1-003-001 to 007.

If the problem persists even though you have adjusted the setting to its maximum and minimum values, contact your supervisor.



· For details about specifying settings in the [Adjustment Settings for Skilled Operators] menu, see the Adjustment Item Menu Guide.

## Image Scaling Error on the Side 1 of Paper



- [A]: Original
- [B]: Output

#### Cause:

An image scaling error may occur because of expansion or contraction of the paper.

#### Solution:

Adjust the image scaling.

- 1. In [Advanced Settings] for the custom paper in use, adjust the image scaling.
  - To adjust the horizontal scaling, change the value in [15: Adj Magnification of Side 1 Across Feed] or change the value in SP2-950.
  - To adjust the vertical scaling, change the value in [16: Adj Magnification of Side1 With Feed] or change the value in SP2-951.


Press [+] to increase the scaling and [-] to decrease it.

2. Print the image. Is the problem resolved?

#### Yes Finished!

No Contact your supervisor.

## Image Scaling Error on the Side 2 of Paper



- [A]: Original
- [B]: Output side 1
- [C]: Output side 2

#### Cause:

An image scaling error on the side 2 of the paper may occur because the paper expands or contracts after the image on the side 1 of the paper has been fused.

#### Solution:

Adjust the scaling for the side 2 of the paper and minimize the difference in print size between the side 1 and the side 2.

- 1. In [Advanced Settings] for the custom paper in use, adjust the image scaling.
  - To adjust the horizontal scaling, change the value in [17: Adj Magnification of Side2 Across Feed] or change the value in SP2-952.
  - To adjust the vertical scaling, change the value in [18: Adj Magnification of Side2 With Feed] or change the value in SP2-953.

Press [+] to increase and [-] to decrease the scaling.

2. Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

[A]

- [A]: Original
- [B]: Output

#### Cause:

Depending on the machine's operating environment (levelness and temperature), the printed image may become vertically skewed.

#### Solution:

Adjust image skew.

- 1. Print the image in black and white.
- 2. Check the direction of the skew.
- 3. In the [Adjustment Settings for Skilled Operators] menu, adjust the value in [0117: Perpendicularity Adjustment] or SP2-104-040.

You can adjust the skew in steps of 16.5 µm.

Press [+] to skew the image counterclockwise or [-] to skew it clockwise.

4. Print the image in black and white.

Gradually increase the value and check the printed image.

- If the problem is resolved, go to the next step.
- If the problem persists even though the setting has reached its maximum value, contact your supervisor.
- 5. Execute color registration.

In executing color registration, the black adjustment will also be applied to cyan, magenta, and yellow.

For details about color registration, see "Adjusting the Color Registration" in the Troubleshooting guide supplied with the machine.


6





 You cannot skew paper with [0117: Perpendicularity Adjustment]. For details about adjusting paper skew, see p.1086 "Paper Skew".


## White Spots



#### Cause:

Paper dust on the guide board and transfer timing roller may stick to the paper and produce white spots. Some types of paper, such as recycled paper, roughly cut paper, and high-friction coated paper produce a lot of paper dust, which will likely stick to the paper.

#### Solution:



Clean the paper feed path (dust catcher, transfer timing roller, guide board, and paper feed roller) between the paper tray in use and the transfer unit's nip (where the images are transferred from the intermediate transfer belt to the paper).

The paper feed paths between each paper tray and the nip are as follows:

- For details about cleaning the dust catcher, transfer timing roller, and the machine's paper trays (Trays 1 and 2), see the Replacement Guide.
- For details about cleaning the paper feed roller of the wide LCT (Trays 3-5), see p.1107 "Cleaning the Paper Feed Path in the Wide LCT (Trays 3-5)".
- For details about cleaning the paper feed roller of the multi bypass tray (Tray 6), see p.1110
   "Cleaning the Paper Feed Path in the Multi Bypass Tray (Tray 6)".
- For details about periodic cleaning of the machine, see the Replacement Guide.

## Paper Edges Are Soiled

#### Cause:

The paper feed rollers or anti-static brushes are soiled.

#### Solution:

Depending on the cause of the problem, do one of the following:

<The surface of the paper is dirty>

- 1. In [Advanced Settings] for the custom paper in use, select [20: Transfer Timing Roller Feed Speed Adj] and decrease the value by 0.5% or decrease the value by 0.5% in SP1-963.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Keep decreasing the value by 0.5% until the problem is resolved.

If the problem persists even though you have decreased the value by 0.5%, contact your supervisor.

<The paper transport rollers are soiled.>

Clean the paper transport rollers in the machine's left drawer.


For details about cleaning the paper transport roller, see the Replacement Guide.

<The anti-static brushes are soiled.>


Clean the anti-static brushes in the exit transport and inverter transport of the machine's left drawer.

Clean the anti-static brushes with a blower brush.

6




• The anti-static brush [A] in the exit transport



• The anti-static brush [B] in the inverter transport


# **Expansion and Contraction (1)**



• [A]: Original

• [B]: Output

The leading edge margin is too narrow and the image has shrunk lengthwise.



• [A]: Original

• [B]: Output

The paper has creased and no print appears where the crease has occurred.

6

#### Cause:

The paper feed speed of the transfer timing roller is too high.

#### Solution:

Decrease the feed speed of the transfer timing roller.


- 1. In [Advanced Settings] for the custom paper in use, select [20: Transfer Timing Roller Feed Speed Adj] and decrease the value by 0.5% or decrease the value by 0.5% in SP1-963.
- 2. Print the image. Is the problem resolved?

Yes Finished!

**No** Keep decreasing the value by 0.5% until the problem is resolved.

If the problem persists even though you have decreased the value by 0.5%, contact your supervisor.

## **Expansion and Contraction (2)**



- [A]: Original
- [B]: Output

The leading edge margin is too wide and the image has stretched lengthwise.

#### Cause:

The paper feed speed of the transfer timing roller is too high.

#### Solution:

Increase the feed speed of the transfer timing roller.

 In [Advanced Settings] for the custom paper in use, select [20: Transfer Timing Roller Feed Speed Adj] and increase the value by 0.1% or increase the value by 0.1% in SP1-963.

2. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing the value by 0.1% until the problem is resolved.

If the problem persists even though you have increased the value by 1.0%, contact your supervisor.

## Scratches, Streaks, or Vertical Creases Appear on the Image Cause:

The paper feed speed of the exit motor, switchback entrance, or switchback exit is too high or too low.

#### Solution:

#### <If scratches or streaks appear on the side 2 of the paper>

1. You can lessen the problem by decreasing the paper feed speed.

In [Advanced Settings] for the custom paper in use, adjust the paper feed speed for delivery.

Depending on the type of printing, specify one of the following:

- For one-sided printing, decrease the value in [23: Exit Motor Feed Speed Adjustment] by 0.1% or decrease the value by 0.1% in SP1-964.
- For duplex printing, reduce the value in [24: Switchback Entrance Feed Speed Adj] by 0.1% or decrease the value by 0.1% in SP1-965.
- For one-sided printing (delivery of inverted paper), reduce the value in [25: Switchback Exit Feed Speed Adj] by 0.1% or decrease the value by 0.1% in SP1-966.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Keep decreasing the value by 0.1% until the problem is resolved.

If the problem persists even though you have decreased the value by 1.0%, contact your supervisor.

### <If scratches or streaks appear on the side 1 of the paper>

You can lessen the problem by increasing the paper feed speed.

1. In [Advanced Settings] for the custom paper in use, adjust the paper feed speed for delivery.

Depending on the type of printing, specify one of the following:

- For one-sided printing, increase the value in [23: Exit Motor Feed Speed Adjustment] by 0.1% or increase the value by 0.1% in SP1-964.
- For duplex printing, increase the value in [24: Switchback Entrance Feed Speed Adj] by 0.1% or increase the value by 0.1% in SP1-965.
- For one-sided printing (delivery of inverted paper), decrease the value in [25: Switchback Exit Feed Speed Adj] by 0.1% or increase the value by 0.1% in SP1-966.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Keep increasing the value by 0.1% until the problem is resolved.

If the problem persists even though you have increased the value by 1.0%, contact your supervisor.

## Decurling Results in Scratches, Streaks, or Creases

#### Cause:

The paper feed speed of the decurler unit is too high or too low.

#### Solution:

#### If scratches or streaks appear on the side 2 of the paper or continuous

#### noise results>

You can lessen the problem by decreasing the paper feed speed of the decurler unit.

- 1. In the [Adjustment Settings for Skilled Operators] menu, check the present degree of decurling (Off, Weak, or Strong) in [0116: Adjust Paper Curl].
- 2. In [Advanced Settings] for the custom paper in use, adjust the paper feed speed of the decurler unit.
  - If the degree of decurling is set to "Off", reduce the value in [51: Decurler Feed Speed Adj: Curl Adj Off] by 0.5% or reduce the setting of SP1-959 by 0.5%.
  - If the degree of decurling is set to "Weak", reduce the value in [52: Decurler Feed Speed Adj: Curl Adj Weak] by 0.5% or reduce the setting of SP1-960 by 0.5%.
  - If the degree of decurling is set to "Strong", reduce the value in [53: Decurler Feed Speed Adj: Curl Adj Strg] by 0.5% or reduce the setting of SP1-961 by 0.5%.
- 3. Print the image. Is the problem resolved?

#### Yes Finished!

No Keep decreasing the value by 0.5% until the problem is resolved.

If the problem persists even though the setting has reached its minimum value, contact your supervisor.

#### <If scratches, streaks, or creases appear on the side 1 of the paper>

You can lessen the problem by increasing the paper feed speed of the decurler unit.

- In the [Adjustment Settings for Skilled Operators] menu, check the present degree of decurling (Off, Weak, or Strong) in [0116: Adjust Paper Curl].
- 2. In [Advanced Settings] for the custom paper in use, adjust the paper feed speed of the decurler unit.
  - If the degree of decurling is set to "Off", increase the value in [51: Decurler Feed Speed Adj: Curl Adj Off] by 0.5% or increase the value by 0.5% in SP1-959.
  - If the degree of decurling is set to "Weak", increase the value in [52: Decurler Feed Speed Adj: Curl Adj Weak] by 0.5% or increase the value by 0.5% in SP1-960.


- If the degree of decurling is set to "Strong", increase the value in [53: Decurler Feed Speed Adj: Curl Adj Strg] by 0.5% or increase the value by 0.5% in SP1-961.
- 3. Print the image. Is the problem resolved?

#### Yes Finished!

No Keep increasing the value by 0.5 mm until the problem is resolved.

If the problem persists even though the value has reached its maximum value, contact your supervisor.

## Leading/Trailing Edge Margin Is Long



- [A]: Leading-edge margin
- [B]: Trailing-edge margin

#### Cause:

In some custom paper presets, the leading/trailing edge margins are set very long to prevent paper jamming.

#### Solution:

Adjust the leading/trailing edge margins.

- In [Advanced Settings] for the custom paper in use, decrease the value by 0.5 mm in [13: Adjust Erase Margin of Leading Edge] or decrease the value by 0.5 mm in SP2-122.
  - This will decrease the leading edge margin by 0.5 mm.
- 2. Decrease the value by 0.5 mm in [14: Adjust Erase Margin of Trailing Edge] or decrease the value by 0.5 mm in SP2-123.
  - This will decrease the trailing edge margin by 0.5 mm.
- 3. Print the image. Is the problem resolved?

Yes Finished!

No If this causes a paper jam in duplex printing, restore the previous setting.



- The adjusted margin cannot be applied to masked images that are solid-filled or contain ruled lines at the leading/trailing edges.
- Decreasing the leading/trailing edge margin may cause paper to jam in the fusing belt stripper plate.

## Curling

To reduce curling without using the decurler unit, reduce the heat roller temperature.

Decreasing the temperature can cause the following side effects:

- Unsatisfactory fusing
- Reduced glossiness
- A tendency for halftone images on uncoated paper to smear
- 1. In [Advanced Settings] for the custom paper in use, select [44: Fusing Heat Roller Temperature Adj] and decrease the value by 5°C or decrease the value by 5°C in SP1-984.
- 2. Print a full-page solid-fill image (SP2109-011: "11"). Is the problem resolved?

Yes Finished!

No Keep decreasing the value by 5°C until the problem is solved.

If the problem persists, contact your supervisor.




- Decreasing the temperature may cause unsatisfactory fusing.
- To use the decurler unit, specify [0116: Adjust Paper Curl] in the [Adjustment Settings for Skilled Operators] menu.


# Attaching the Tab Sheet Holder

By attaching the tab sheet holder, you can prevent air from escaping at the trailing edge of the paper and so improve separation.


This will prevent double feeding and misfeeding of special or coated paper loaded in the wide LCT (Trays 3–5).



1. Unlock the end fence, and then slide it away from the paper.



2. Place the tab sheet holder [A] on the paper.



3. Slide the end fence against the paper so that the tab sheet holder's clips [B] pass through the fence and click into place.



- You can use the tab sheet holder for paper of the following sizes:
- Paper with a width of 288.0–330.2 mm (11.34–13.00 inches) and a length of 182.0–487.7 mm (7.17–19.20 inches).
- Paper with a width of 139.7–287.9 mm (5.50–11.33 inches) and a length of 335.5–487.7 mm (13.21–19.20 inches).

# Cleaning the Paper Feed Path

Clean the paper feed path if white spots appear because of paper dust sticking to the paper, or if paper misfeeding or double feeding occurs.

#### Guide Board

Wipe the guide board with a well-wrung-out damp cloth. To reach the inmost recesses, the cloth should be the size of your palm.

### **Paper Feed Roller**



Wipe the entire surface of the paper feed roller lengthwise with a well-wrung-out damp cloth, and then with a dry, unused, lint-free cloth until no moisture remains.


# Cleaning the Paper Feed Path in the Wide LCT (Trays 3-5)

Clean the guide board and paper feed rollers in the wide LCT.


The procedure is explained using Tray 3 as an example.

The procedure is the same for Trays 4 and 5.

1. Open the wide LCT front cover.




3. Clean the side fences and front guide.



4. Remove the two black screws on the side plate, and then remove the plate.


6






- 5. Remove the two black screws on the paper feed unit U2, and then pull out the paper feed unit U2 until it stops.
- 6. Clean the paper feed rollers.

For details about detaching and reattaching the paper feed rollers, see the Replacement Guide.



7. Clean the guide board [A] of the paper feed unit.



- 8. Open the guide board (U1), (U3), and (U5), and then clean the guide board interior [B].
- 9. After cleaning, restore the machine to its operational state.




• For details about the general and periodic cleaning of the machine, see the Replacement Guide.

## Cleaning the Paper Feed Path in the Multi Bypass Tray (Tray 6)


Clean the guide board and paper feed rollers in the multi bypass tray (Tray 6).

Wipe the guide board with a well-wrung-out damp cloth. To reach the inmost recesses, the cloth should be the size of your palm.


1. Remove the loaded paper.




2. Clean the side fences and front guide.




# 3. Pull off the snap-off cover.




# 4. Remove black screw.



## 5. Remove the plate.




- 1. Remove the black screw on the sensor positioning plate [A].
- Push the sensor positioning plate [A] to the left.If this plate is not pushed to the left, you will not be able to remove the feed roller.
- Clean the paper feed rollers.
   For details about detaching and reattaching the paper feed rollers, see the Replacement Guide.



4. Slide the paper tray [B] to the right.





- 5. Clean the guide board [C].
- 6. After cleaning, restore the machine to its operational state.




• For details about the general and periodic cleaning of the machine, see the Replacement Guide.

## Cleaning the Paper Feed Rollers and Paper Feed Belt in the Interposer


Clean the paper feed belt and paper feed rollers in the interposer.

The procedure is explained using the interposer upper tray. The procedure is the same for the lower tray.

1. Remove the loaded paper.



Open the upper cover [A], and then detach the paper feed unit [B].
 Pull out the paper feed unit slightly, release the metal shaft, and then detach it.



- 3. Clean the paper feed belt and pick-up roller in the detached paper feed unit.
- 4. After cleaning, restore the machine to its operational state.

# No Error Message at Initializing of the Double Feed Sensors

After SC591 (Double-Feed Sensor Error) has occurred, the machine automatically disables the function of the double feed sensors to continue operating. However, a customer cannot notice that the machine has disabled the double feed sensors because no message is displayed on the LCD.

If a customer wants to display the message for disabling the double feed sensors, change the setting of SP1-310-001 from "0" to "1".

# **Efficient SP for Paper Jam Analyzing**

This machine has the paper jam purge system to purge jammed paper in the paper path if possible. However, this may disturb the paper jam analyzing correctly because you are not sure where jammed paper is stuck.

If you want to know where jammed paper is stuck, change the setting of SP1-909-001 from "1" to "0" (no paper purge).

# 6

# **Troubleshooting for Options**

## Finisher SR5030/ Booklet Finisher SR5040

## **Delivered Sheets Are Not Stacked Properly**

#### Solution:

Depending on the cause of the problem, do one of the following:

#### Coated paper is being used.

If coated paper is being used, attach the auxiliary tray for thin coated paper.

For details about attaching the auxiliary tray for thin coated paper, see "When Coated Paper Is Not Properly Aligned" in the Troubleshooting supplied with the machine.

#### There is a draft in the room.

Minimize drafts. For instance, turn the air conditioner off.

#### Printed sheets are curled.

#### <If the decurler unit is attached>

1. In the [Adjustment Settings for Skilled Operators] menu, adjust the degree of decurling in [0116: Adjust Paper Curl].

To correct curls facing up, specify "Adjust Curl".

To correct curls facing down, specify "Adjust ^ Curl".

Select "Strong" or "Weak" as the degree of decurling as required.

## <If the decurler unit is not attached>

1. Load the sheets the other way up.

#### There are too many stacked sheets.

To keep the number of stacked sheets within reason, pause printing once in a while, remove the sheets and resume printing.

For details about pausing printing, see "Pausing Print When Using Finisher SR5030 or Booklet Finisher SR5040" in the Troubleshooting supplied with the machine.

## Large Delivered Sheets Are Not Stacked Properly


#### Cause:

When using large-size or coated paper that produces considerable inter-sheet friction, problems such as one sheet pushing out another or a sheet becoming kinked occur.

This is likely to occur if:

- B4 SEF, 8" x 14" SEF, or larger paper is used.
- Paper that produces considerable inter-sheet friction is used.
- The temperature or humidity is high.


## Sheet bending



- [A]: Paper exit
- [B]: Output tray

The leading edge of the delivered sheet bends upward and back.


## One sheet pushing out another



- [A]: Paper exit
- [B]: Output tray

The sheet being delivered gets stuck to the top sheet of the stack and pushes the top sheet out.

## Sheet becoming kinked



- [A]: Paper exit
- [B]: Output tray

The sheet being delivered gets stuck to the top of the stack by its leading edge, arches up, and becomes kinked.

#### Solution:

Depending on the cause of the problem, do one of the following:

### <Sheet bending>

### The auxiliary tray is not attached.

- If using paper of Paper Weight 3 or below, attach the auxiliary tray for thin coated paper.
   For details about attaching the auxiliary tray for thin coated paper, see "Using Thin Coated Paper" in the Troubleshooting supplied with the machine.
- If using paper of Paper Weight 4 or above, attach the auxiliary paper tray.
   For details about attaching the auxiliary paper tray, see "Using Thick Coated Paper" in the Troubleshooting supplied with the machine.

## There is a draft in the room.

Minimize drafts. For instance, turn the air conditioner off.

### Sheets are curled upward.

#### <If the decurler unit is attached>

In the [Adjustment Settings for Skilled Operators] menu, set [0116: Adjust Paper Curl] to "Adjust Curl".

As the degree of decurling, select "Weak" if the present setting is "Off" or "Strong" if the present value is "Weak".

#### <If the decurler unit is not attached>

1. Load the sheets the other way up.

## <One sheet pushing out another or a sheet becoming kinked>

## The auxiliary tray is not attached.

- If using paper of Paper Weight 3 or below, attach the auxiliary tray for thin coated paper.
   For details about attaching the auxiliary tray for thin coated paper, see "Using Thin Coated Paper" in the Troubleshooting supplied with the machine.
- If using paper of Paper Weight 4 or above, attach the auxiliary paper tray.
   For details about attaching the auxiliary paper tray, see "Using Thick Coated Paper" in the Troubleshooting supplied with the machine.

## Sheets are curled downward.

#### <If the decurler unit is attached>

1. In the [Adjustment Settings for Skilled Operators] menu, set [0116: Adjust Paper Curl] to "Adjust Curl".

As the degree of decurling, select "Weak" if the present setting is "Off" or "Strong" if the present value is "Weak".


### <If the decurler unit is not attached>

1. Load the sheets the other way up.



- If the sheets cannot be stacked properly even by the abovementioned solution, the problem may
  be reduced by attaching the auxiliary tray for thin coated paper when using paper of Paper
  Weight 4 or above and attaching the auxiliary paper tray when using paper of Paper Weight 3 or
  below.
- If the auxiliary tray is attached, the number of sheets that can be stacked is reduced.
- If the auxiliary tray for thin coated paper is attached, the misalignment of the last sheet of each print job may exceed ±2 mm when using the Shift Collate function.

## Trailing Edge of Stapled Sheets Too Near Paper Exit



- [A]: Paper exit
- [B]: Output tray

#### Cause:

If there is a tight curl on a delivered set of stapled sheets or if the sheets are limp, the trailing edge of the set may be left too near the paper exit when the set is stacked.

If this happens, the next set of stapled sheets to be delivered may collide with the stacked set, resulting in paper bending or misfeeding.

This is likely to occur if:

- There is a tight curl on a delivered set of stapled sheets.
- Limp paper, such as thin or recycled paper, is used.

#### Solution:

- 1. Attach the Z-fold support tray.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

To carry out the following steps, the decurler unit must be attached.

3. In the [Adjustment Settings for Skilled Operators] menu, set [0116: Adjust Paper Curl] to "Adjust Curl".

Select "Strong" or "Weak" as the degree of decurling as required.

4. Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.



- For details about attaching the Z-fold support tray, see "When Z-folded Paper Is Not Properly Aligned" in the Troubleshooting supplied with the machine.
- If the Z-fold support tray is attached, the problem of the trailing edge being too near the paper exit can be reduced, but the stapled sheets may not be stacked properly.

## Sheets Cannot Be Stapled Properly

### Cause:

When the sheets are fed to the staple unit inside the finisher, they may be overlaid, resulting in their becoming misaligned by  $\pm 5$  mm relative to each other after stapling.

When using coated or other paper producing considerable inter-sheet friction, the paper edge stop may fail to ensure correct positioning, resulting in misaligned stapling.

- Coated or other paper producing considerable inter-sheet friction is used.
- Thin or other limp paper is used.

#### Solution:

Reduce the number of sheets sent in bulk to the staple unit.

- 1. In the [Adjustment Settings for Skilled Operators] menu, select [0416: Number of Sheet Align for Stapling] and reduce the number of sheets from the present value.
- 2. Print the image. Is the problem resolved?


Yes Finished!

**No** If the problem persists even though the setting has reached its minimum value, contact your supervisor.




 Reducing the number of sheets causes the machine to take longer for sheet alignment, reducing throughput.

## **Creases on Stapled Paper Stack**



When a few sheets [A] of paper are stapled, creases [B] may occur on the stapled paper stack. This is because the gap [C] between the bottom fence [D] and corner stapler unit [E] causes creases on the paper stack. To prevent this problem, follow the procedure below.




- 1. Open the front door [A].
- 2. Pull out the stack/stapler unit [B].
  - Corner stapler unit [C]




- 3. Remove the corner stapler cover [A] ( \*\*x2).
- 4. Disconnect three harnesses.

5. Turn the corner stapler unit [A] counterclockwise, and then remove it.



6. Remove the corner stapler base [A] from the corner stapler unit (  $\mathcal{F}$  x4).








d074t721

- 7. Attach washers at the screw holes on the bottom of the corner stapler unit [A].
  - Measure the gap between the bottom fence and corner stapler unit, and then calculate haw many washers are necessary (adjustable limit: 2.0 mm or less). The thickness of each washer is 0.5 mm.
- 8. Reattach the corner stapler base [B] to the corner stapler unit ( Fx4).
- 9. Reinstall the corner stapler unit in the finisher.
- 10. Reassemble the finisher.


## Staple Position is Too Close to Paper Edge



When a few sheets [A] of paper are stapled, miss-stapling may occur on the stapled paper stack. This is because the gap [B] between the bottom fence [C] and corner stapler unit [D] makes paper buckle on the paper stack which causes the miss-stapling. To prevent this problem, follow the procedure below.

- 1. Remove the corner stapler unit (see "Creases on Stapled Paper Stack").
- 2. Attach washers on the bottom of the corner stapler unit.
  - Refer to the "Creases on Stapled Paper Stack" described above.
- 3. Go to next step if attaching washers does not solve the problem.
- 4. Mark the current position between corner stapler base and corner stapler unit.





d074t723

- 5. Remove the positioning screw [A].
- 6. Remove other three screws [B].
- 7. Slide the corner stapler base [C] down (relatively corner stapler unit up).

## 

- Do not slide either of the corner stapler base beyond 2.0 mm. Otherwise, corner stapler unit
  may interrupt other parts when the corner stapler unit moves.
- 8. Secure the two units ( Fx3).
- 9. Reinstall the corner stapler unit in the finisher.
- 10. Reassemble the finisher.

### **Booklet Stack Feed Out Error**


When some conditions are met, booklet stack is not properly fed out to the booklet tray.

- 10 sheets or more to be stapled
- High coverage image
- Plain paper or recycle paper


This is because the friction coefficient between sheets of paper is low.

To prevent this problem, follow the procedure below.


1. Remove the booklet unit (see "Field Service Manual" for the Finisher D512/D513).



2. Release three clamps [A].



3. Remove the upper stay [A] on the booklet unit (  $\mbox{\ensuremath{\not\sim}} x4\mbox{)}.$ 



d074t726


4. Rotate the jam removal knob [A] clockwise until it stops.



RTB 133 Corrected







d074t727

- 5. Remove four screws on the both sides of the booklet unit, and then move the guide plate [A] to the arrow direction.
- 6. Remove the fold plate holder [A] (  $\slash\hspace{-0.4em}P x3$ ).
- 7. The fold plate [B] is removed.
- 8. Install a new modified fold plate.
  - Ask your supervisor about the new modified fold plate.
- 9. Reassemble the finisher.

## **Multi-Folding Unit**

## **Out-of-True Folding (Folding Deviation)**

#### Cause:

Depending on how floppy the paper is, folds may shift out of true. This is referred to as folding deviation.

#### Solution:

Adjust the folding position by adjusting the position of the paper edge stopper for folding.

- For multi-sheet folding, adjust the folding position by means of the following settings:
  - 0601: Half Fold Position (Multi-sheet Fold)
  - 0602: Letter Fold-out Position 1 (Multi-sheet Fold)
  - 0603: Letter Fold-out Position 2 (Multi-sheet Fold)
  - 0604: Letter Fold-in Position 1 (Multi-sheet Fold)
  - 0605: Letter Fold-in Position 2 (Multi-sheet Fold)
- For single-sheet folding, adjust the folding position by means of the following settings:
  - 54: Adjust Z-fold Position 1
  - 55: Adjust Z-fold Position 2
  - 56: Half Fold Position: Single-sheet Fold
  - 57: Letter Fold-out Posn 1: Single-sheet Fld
  - 58: Letter Fold-out Posn 2: Single-sheet Fld
  - 59: Letter Fold-in Position 1: Single-sheet Fold
  - 60: Letter Fold-in Position 2: Single-sheet Fold
  - 61: Double Parallel Fold Position 1
  - 62: Double Parallel Fold Position 2
  - 63: Adjust Gate Fold Position 1
  - 64: Adjust Gate Fold Position 2
  - 65: Adjust Gate Fold Position 3



 For details about specifying settings in the [Adjustment Settings for Skilled Operators] menu, see the Adjustment Item Menu Guide.

## **Folding Deviation**


#### Cause:

Depending on the paper floppiness, folding deviation (skewed folding) may occur.

Deviation refers to the difference in edge dimension of the parts between folds.


For example, in the following illustration, the dimensional difference between the top (L2[2]) and bottom (L2[1]) edges is the deviation.

## <Folding deviation sample of L2 for Z-fold>




## Solution:

Adjust the deviation.




The multi-folding unit has three adjusting screws (L1, L2, and L3) with which to adjust deviation.

L1



- [A]: Adjusting screw
- [B]: Mounting screw
- [C]: Adjusting screw hole

L2



- [A]: Adjusting screw
- [B]: Mounting screw
- [C]: Adjusting screw hole

L3


- [A]: Adjusting screw
- [B]: Mounting screw
- [C]: Adjusting screw hole

The screws adjust the deviation of the following parts:




The mark ○ indicates the leading edge (relative to the paper feed direction), and the mark ○ indicates the trailing edge.


## Z-fold




Half Fold



Double Parallel



Gate Fold




## <How to adjust the folding deviation>

This procedure is the same for L1, L2, and L3.

- 1. Open the front cover of the multi-folding unit.
- 2. Remove the mounting screw.

If the mounting screw is attached to the adjusting screw hole, unfasten it.





- 3. Turn the adjusting screw [A] to adjust the deviation.
  - To increase the length at the bottom part of paper, turn the screw clockwise.
  - To decrease the length at the bottom part of paper, turn the screw counterclockwise.
- 4. Attach the mounting screw to fasten the adjusting screw.
- 5. If the mounting screw is attached to the adjusting screw hole, fasten it.
- 6. Close the front cover of the multi-folding unit.




- For multi-sheet folding, the folding deviation of the sheet in the center is adjusted.
- If the deviation is large, the paper may be skewed. In that case, see Paper Skew.

## Folds Soiled by Multi-Sheet Folding

#### Cause:

If multi-sheet folding is performed after a large number of z-folds have been performed, the tip of the blade used for the multi-sheet folding may be soiled, in turn soiling the paper.




This will produce soiling 1-3 cm (0.4-1.2 inches) in width (equal to the width of the blade) in the fold [A] of the center sheet.


## Solution:

Clean the blade.


1. Open the front cover of the multi-folding unit.




2. Pull the multi-folding unit [A] out.



Turn the N11 dial [B] counterclockwise until the blade appears.
 The blade is located in the right part of the multi-folding unit.



- Wipe the tip and top of the blade with a soft dry cloth.
   Be careful not to damage the blade.
- After cleaning, restore the machine to its operational state.
   The soiling will be removed by printing between three and five copies with multi-sheet fold.



When letter folding multiple sheets, the edge of the inner flap may become bent.

### Solution:

- 1. Load the paper the other side up.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 3. In the [Adjustment Settings for Skilled Operators] menu, set [0604: Letter Fold-in Position 1 (Multisheet Fold)] to "0.0 mm".
- 4. In [General Features] in [System Settings], set [Letter Fold-in Position] to "7 mm".
- 5. Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

## **Z-Folding is Not Performed Properly**



d074t693

• Upward curl (radius 4 cm [1.6 in.] or less) [A] at leading edge of delivered paper.

### Cause:

Because the paper is curled, its leading edge catches on the guide board, leaving it in the wrong position to be folded properly.

### Solution:

- 1. Load the sheets the other way up.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Move to the next step.

To carry out the following steps, the decurler unit must be attached.

- 3. In the [Adjustment Settings for Skilled Operators] menu, set [0116: Adjust Paper Curl] to [Adjust Curl: Weak].
- 4. Print the image. Is the problem resolved?


Yes Finished!

No Contact your supervisor.



• This folding error will not occur when using uncurled sheets or sheets that curl downward.

## Folded Sheets Are Not Stacked Properly




#### Cause:

If a large number of half-folded multi-sheet bundles have been delivered, the spines of the delivered bundles form a bulge. If a subsequently delivered bundle catches on this bulge, it may flip over in the output tray.

This is likely to occur if:


• Thick, relatively stiff paper is used.

As a bundle is delivered, its folded edge droops and catches on the stacked bundles, causing the delivered bundle to flip over.



Use the Z-fold support tray for multi-folding unit.

This will reduce the angle of stacked bundles and prevent bundles flipping over as they are delivered. For details about attaching the Z-fold support tray for multi-folding unit, see "When Z-folded Paper Is Not Properly Aligned" in the Troubleshooting supplied with the machine.



• The flipping over of delivered sheets during other types of folding operations (such as letter-fold and gate-fold) cannot be prevented by the Z-fold support tray for the multi-folding unit.

## **Buffer Pass Unit**

## The Fan Is Noisy

You can change the buffer pass unit fan activation setting according to the type of paper and ambient temperature.

 In the [Adjustment Settings for Skilled Operators] menu, change the value in [0118: Buffer Pass Unit Fan Activation Setting].



• Depending on the setting, blocking (heat and pressure causing toner particles on stacked copies to form clumps which then detach) may occur.

## b

## **High Capacity Stacker**

## **Delivered Sheets Are Severely Curled**

#### Cause:

Sheets with downward curls rub too much at their leading edges. This can cause a sheet to stop short with its trailing edge still in the paper exit.


Subsequently delivered sheets may become bent as they slip under the trailing edge of the partially delivered sheet.

This is likely to occur if:


• A4 or larger coated paper weighing up to 135 g/m2 (50 lb. Cover) is used.

## <How the problem occurs>


• (1) Downward curled paper is delivered to the stacker tray.




- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray
- (2) The leading edge of the sheet being delivered rubs against the top sheet of the stack, there being no air gap between the sheets, and the sheet being delivered gets stuck.



- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray
- (3) The trailing edge of the sheet being delivered is left in the paper exit.



- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray
- (4) The next sheet to be delivered slips under the sheet still in the paper exit and bends back.



- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray

### Solution:

Straighten out the paper by decurling it upward.

- 1. Load the sheets the other way up.
- 2. Print the image. Is the problem resolved?

Yes Finished!

No Move to the next step.

To carry out the following steps, the decurler unit must be attached.

- 3. In the [Adjustment Settings for Skilled Operators] menu, set [0116: Adjust Paper Curl] to [Adjust Curl: Weak].
- 4. Print the image. Is the problem resolved?

Yes Finished!

No Go to the next step.

- 5. Set [0116: Adjust Paper Curl] to [Adjust Curl: Strong].
- 6. Print the image. Is the problem resolved?

Yes Finished!

No Contact your supervisor.

## **Delivered Sheets Are Not Aligned**


#### Cause:

When delivering sheets to the stacker tray, because of the friction between the sheets, the paddle fails to drag the trailing edge back into the front guide, resulting in misalignment.


• Thick (280 g/m2 [105 lb. Cover] or heavier), uncurled A3 or larger paper is used.

## <How the problem occurs>

• (1) An uncurled sheet is delivered to the stacker shift tray.




- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray
- [D]: Paper edge stopper
- (2) The friction at the trailing edge is too great for the paddle to drag the sheet back and align the edges of the sheet with the edges of the stack.




- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray
- [D]: Paper edge stopper

• (3) The paper edge stopper fails to push back the protruding leading edge and align the sheet that way.



- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray
- [D]: Paper edge stopper
- (4) Stacked sheets are not aligned properly.



- [A]: Paper exit
- [B]: Paddle
- [C]: Stacker shift tray
- [D]: Paper edge stopper

## Solution:

Curl the paper upward.

To do this, the decurler unit must be attached.

1. In the [Adjustment Settings for Skilled Operators] menu, set [0116: Adjust Paper Curl] to [Adjust Curl: Weak].

**Yes** Finished!

No Go to the next step.

- 3. Set [0116: Adjust Paper Curl] to [Adjust Curl: Strong].
- 4. Print the image. Is the problem resolved?

2. Print the image. Is the problem resolved?

Yes Finished! (Sheets are aligned to an accuracy of 7 mm [0.27 inches].)

No Contact your supervisor.

### LCIT RT5060

## Misfeeding due to the Paper Character

Misfeeding from the LCT tray may occur on the paper which has strong resistance against bending strength.

### Installing the tray heater for the LCT

- 1. Install the tray heater for the LCT. For details, refer to the installation procedure for "LCIT (D516) Tray Heaters" in A3/DLT LCIT (D516).
- 2. If the tray heater does not solve the problem, go to "Changing the upper limit of the paper stack in the LCT tray" described below.


## Changing the upper limit of the paper stack in the LCT tray

Changing the upper limit of the paper stack in the LCT tray can prevent paper misfeeding for the paper which has strong resistance against bending strength.




- For the paper feed unit in the top tray or middle tray, remove the inner upper cover.
- For the paper feed unit in the bottom tray, remove the inner lower cover.
- 1. Pull out the top, middle or bottom tray.
- 1. Open the front door.
- 2. Pull out the top and middle trays.







- 3. Pull down the U1 lever [A].
- 4. Remove:
  - [B] Knob ( 🗗 x 1 )
  - [C] Inner upper cover ( Fx2)
- 5. Pull out the middle and bottom trays.




6. Inner lower cover [A] ( \*\bar{x}2)



- 7. Pull the paper feed unit [A] ( Fx 2).
- 8. Stopper bracket [B] ( 🗗 x 1)



9. Pull out the paper feed unit [A] fully, and then lift it.




- 10. Note the default position of the paper lift sensor bracket by referring to the scale [A] on the frame.
  - The scale on the frame is divided into units of 1 mm.

- 11. Loosen the screw on the paper lift sensor bracket [B].
- 12. Move the bracket 0.5 mm in the arrow direction as shown above.
- 13. Tighten the screw on the paper lift sensor bracket [B].



- To return the upper limit position to the default position, move the paper lift sensor bracket 0.5 mm to the opposite side.
- Return the upper limit position to the default if a paper jam occurs at the paper feed sensor in the LCT.




- 14. This adjustment raises the upper limit position by 0.8 mm.
  - [A]: Paper stack before adjustment
  - [B]: Paper stack after adjustment

## Double Feeding or Misfeeding from the LCT

### Changing the upper limit of the paper stack in the LCT tray


Changing the upper limit of the paper stack in the LCT tray can prevent paper double feeding or misfeeding from the LCT tray.



- 1. Pull the paper feed unit of the LCT unit (see "Misfeeding due to the Paper Character").
- 2. Note the default position of the paper lift sensor bracket by referring to the scale [A] on the frame.
  - The scale on the frame is divided into units of 1 mm.
- 3. Loosen the screw on the paper lift sensor bracket [B].
- 4. Move the bracket 0.5 mm in the arrow direction as shown above.
- 5. Tighten the screw on the paper lift sensor bracket [B].



- To return the upper limit position to the default position, move the paper lift sensor bracket 0.5 mm to the opposite side.
- Return the upper limit position to the default if a paper jam occurs at the paper feed sensor in the LCT.



- 6. This adjustment lowers the upper limit position by 0.8 mm.
  - [A]: Paper stack before adjustment
  - [B]: Paper stack after adjustment

## 6

## Cover Interposer Tray CI5020

## Paper Misfeeding due to Non-supported Paper Use


### Cause:

- Paper in use is not supported for this unit.
- Paper in use is low friction coefficient.


## Solution:




- 1. Open the top cover [A].
- 2. Remove the pressure block [B] (spring x 1, hooks).



- 3. Install the spring [A].
- 4. Reinstall the pressure block [B].



- 5. Remove the feed belt unit [A].
- 6. Align the cork pad [B] to two lines [C], and then attach it on the feed belt unit.



7. Check if no gap [A] between the pressure block and cork pad after the top of the stack in the tray pushes up the feed belt unit.


## Multi Bypass Tray BY5010

## Paper Misfeeding due to Paper Character

Misfeeding from the bypass tray may occur on the coated paper which has strong smoothness in the low temperature and low humidity condition.



- 1. Remove six covers.
  - For details about removing these covers, refer to the Filed Service Manual for the Multi Bypass Tray BY5010.



- 2. Note the default position of the paper lift sensor bracket [A] by referring to the scale on the frame.
  - The scale on the frame is divided into units of 1 mm.
- 3. Loosen the screw on the paper lift sensor bracket [A].
- 4. Move the bracket 0.5 mm in the arrow direction as shown above.
- 5. Tighten the screw on the paper lift sensor bracket [B].



- To return the upper limit position to the default position, move the paper lift sensor bracket 0.5 mm to the opposite side.
- Return the upper limit position to the default if a paper jam occurs at the paper feed sensor in the Multi Bypass Unit.

# **Troubleshooting for Throughput**

#### Reducing the Waiting Time Prior to Printing

After receiving a print job, the machine usually stops to let the fusing temperature reach an appropriate level for printing.

The waiting time for the fusing unit to cool down may be quite long, especially before printing on thin paper. By decreasing the fusing temperature during standby, you can reduce the waiting time.

 In the [Adjustment Settings for Skilled Operators] menu, decrease the temperature by 10°C in [0206: Adjust Fusing Temperature on Standby] or decrease the settings of SP1-107-001, 003, and 007.

Decrease the value in "Temperature on Standby Mode", "Temperature on Panel Off Mode", and "Temperature Before Performing a Process" by 10°C.



 When printing on paper other than thin paper, we recommend leaving the above settings unchanged.

# Throughput When Printing on Paper with a Thickness Equivalent to Paper Weight 6 or 7

When printing on paper with a thickness equivalent to Paper Weight 6 or 7, the machine's copy/print speed must be reduced to 70% of full speed so that the degree of toner fixation can be enhanced.

However, depending on the type of paper in use and printed image, you can have the machine print at full copy/print speed.

The following are requirements for improving throughput when using paper with a thickness equivalent to Paper Weight 6 or 7:

- Uncoated paper
- Printing in black-and-white mode
- Room temperature
- In [Advanced Settings] for the custom paper in use, increase the value in [19: Process Speed Setting] by one step or increase the value of SP1-986 by 1 step.

The settings for the Advanced Settings and the SP settings correspond to one another as shown in the table below.

Advance Settings	SP Code Settings
High	0: Target Speed

Advance Settings	SP Code Settings
Middle	1: Medium Speed
Low	2: Low Speed

- If it is presently set to [Low], change it to [Middle].
- If it is presently set to [Middle], change it to [High].
- 2. Set [44: Fusing Heat Roller Temperature Adj] to "180°C".
- 3. Print the image. Does it exhibit any fusing problem?

Yes You cannot improve throughput under the present condition. Restore the previous setting.

No You can operate the machine using this setting.

#### Note:

The following list shows the copy/print speed for each item in [19: Process Speed Setting]:

#### <D074>

• High: 65 cpm (full speed)

• Middle: 45 cpm (70% of full speed)

Low: 32 cpm (50% of full speed)

#### <D075/M044>

• High: 75 cpm (full speed)

• Middle: 52 cpm (70% of full speed)

• Low: 37 cpm (50% of full speed)

### Throughput when Printing Black-and-White Jobs and Color Jobs

When printing intermixed black-and-white and color print jobs, switching from full-color mode to black-and-white mode takes time, causing loss of throughput each time the mode is switched.

When the machine prints a full-color print job followed by a black-and-white job, you can improve throughput by adjusting the number of black-and-white sheets the machine prints in full-color mode before switching to black-and-white mode.

 In the [Adjustment Settings for Skilled Operators] menu, change the value in [0207: Auto Colour Selection Setting] or change the value in SP2-907-001.

Specify the appropriate number of sheets for your operating environment.

Value	Machine Operation
	The machine will switch to the black-and-white mode for all black-and-white printing.
1 (Minimum)	This does not improve throughput, but prevents the cyan, magenta, and yellow development units from working when printing blackand-white sheets.
10 (Maximum)	When the machine prints a full-color print job followed by a black-and-white job, it will switch from full-color to black-and-white mode after printing 10 black-and-white sheets.



- If you print black-and-white sheets in full-color mode, the cyan, magenta, and yellow development units will work during the black-and-white printing, resulting in a shorter replacement cycle for the drum unit.
- When the machine prints a black-and-white print job followed by a full-color job, it will always switch to full-color mode, as color printing is impossible in black-and-white mode.

#### 6

## **Fuses**

### Blown Fuse Conditions

#### **AC Fuses**

#### AC drive board

Fuse	Rating 200V - 240V	Symptom at Power On
FU101	10A	The machine stops during warming-up and SC547 is issued.
FU102	10A	The machine stops during warming-up and SC547 is issued.

#### PSU 2 AZ240166 200V

E	Rating	Symptom at Power On
Fuse	200V - 240V	
FU101	8A	The machine stops during warming-up and SC547 is issued.

#### **DC Fuses**

#### PSU 2 AZ240166 200V

Fuse	Rating 200V - 240V	- Symptom at Power On
FU102	6.3A	The machine normal during operation and SC686 or other SC is issued.
FU1	10A	The machine stops during normal operation, and an SC code related to scanner optics, paper transport, or SC686 is issued.
FU2	10A	The machine stops during normal operation, and an SC code related to the paper bank unit of the main machine, paper transport, or SC686 is issued.

Fuse	Rating 200V - 240V	Symptom at Power On
FU3	10A	The machine stops during normal operation, and an SC code related to the Decurler Unit, SC520, or SC686 is issued.
FU4	10A	Not Used
FU5	2A	Not Used
FU6	5A	Not Used
FU7	5A	Not Used
FU8	2A	The machine stops and a jam related to the paper transport unit is issued.

#### PSU 1 AZ250041

Fuse	Rating 200V - 240V	Symptom at Power On
FUSO01	8A	The machine stops and SC670 or "Please Wait" is issued.

6

## Jam Codes

These are lists of jam codes for the main machine and peripheral devices. Please note:

- Late jam. The paper has failed to arrive within the prescribed time due to a jam that has occurred upstream of the referenced sensor.
- Lag jam. The paper has failed to leave the location of the referenced sensor within the prescribed time due to a jam downstream of the referenced sensor.

#### Paper Late Jams: Main Machine

Code No	Meaning	
J001	Standby Jam (Initial)	
J003	1 st Paper Feed Sensor	
J004	2nd Paper Feed Sensor	
J005	1 st Paper Feed Sensor (LCT)	
J006	2nd Paper Feed Sensor (LCT)	
J007	3rd Paper Feed Sensor (LCT)	
J008	4th Paper Feed Sensor (LCT)	
J009	1 st Transport Sensor	
J010	2nd Transport Sensor	
J011	1 st Transport Sensor (LCT)	
J012	2nd Transport Sensor (LCT)	
J013	3rd Transport Sensor (LCT)	
J014	4th Transport Sensor (LCT)	
J015	Vertical Transport Sensor	
J016	Bank Exit Sensor (Simplex)	
J017	Bank Exit Sensor (Duplex)	
J018	Main Relay Sensor 1	

Code No	Meaning
J019	Main Relay Sensor 2
J020	Main Relay Sensor 3
J021	1 st Relay Sensor: Lower (LCT)
J022	1 st Relay Sensor: Upper (LCT)
J023	2nd Transport Sensor (LCT)
J024	3rd Transport Sensor (LCT)
J025	Exit Sensor (LCT)
J026	Relay Sensor 1 (LCT)
J027	Relay Sensor 2 (LCT)
J028	Registration Sensor (Main)
J029	Registration Sensor (LCT)
J030	Paper Late Jam
J031	Transfer Timing Sensor
J032	Transport Thermistor
J033	Fusing Exit Sensor
J034	Feed-out Entrance Sensor
J035	Exit JG Sensor
J036	Exit Sensor
J037	-
J038	Exit Relay Sensor (2nd Pass)
J039	Exit Relay Sensor (Duplex)
J040	Duplex Invert Sensor (1 st Pass)
J041	Duplex Invert Sensor (2nd Pass)
J042	Duplex Transport Sensor 1
J043	Duplex Transport Sensor 2

Code No	Meaning
J044	Duplex Transport Sensor 3
J045	Duplex Transport Sensor 6
J046	Duplex Transport Sensor 7

## Paper Lag Jams: Main Machine

Code No	Meaning	
J053	1st Paper Feed Sensor	
J054	2nd Paper Feed Sensor	
J055	1 st Paper Feed Sensor (LCT)	
J056	2nd Paper Feed Sensor (LCT)	
J057	3rd Paper Feed Sensor (LCT)	
J058	4th Paper Feed Sensor (LCT)	
J059	1 st Transport Sensor	
J060	2nd Transport Sensor	
J061	1 st Transport Sensor (LCT)	
J062	2nd Transport Sensor (LCT)	
J063	3rd Transport Sensor (LCT)	
J064	4th Transport Sensor (LCT)	
J065	Vertical Transport Sensor	
J066	Bank Exit Sensor	
J067	-	
J068	Main Relay Sensor 1	
J069	Main Relay Sensor 2	
J070	Main Relay Sensor 3	

Code No	Meaning
J071	1 st Relay Sensor: Lower (LCT)
J072	1 st Relay Sensor: Upper (LCT)
J073	2nd Transport Sensor (LCT)
J074	3rd Transport Sensor (LCT)
J075	Exit Sensor (LCT)
J076	Relay Sensor 1 (LCT)
J077	Relay Sensor 2 (LCT)
J078	Registration Sensor
J080	Sub Scan Registration Correction
J081	Transfer Timing Sensor
J082	Transport Thermistor
J083	Fusing Exit Sensor
J084	Feed-out Entrance Sensor
J085	Exit JG Sensor
J086	Exit Sensor
J087	Exit Relay Sensor (1st Pass)
J089	Exit Relay Sensor (Duplex)
J090	Duplex Invert Sensor (1 st Pass)
J091	Duplex Invert Sensor (2nd Pass)
J092	Duplex Transport Sensor 1
J093	Duplex Transport Sensor 2
J094	Duplex Transport Sensor 3
J095	Duplex Transport Sensor 6
J096	Duplex Transport Sensor 7
J097	Over Skew

Code No	Meaning
J098	Over Shift
J099	Double-Feed

### Finisher Jams (D512/D513) Jam Code Table

Code No.	Meaning
J101	Entrance: Late Jam
J102	Entrance: Lag Jam
J103	Proof Tray Exit: Late Jam
J104	Proof Tray Exit: Lag Jam
J105	Proof Tray Exit: Late Jam
J106	Shift Tray Exit: Lag Jam
J107	Stapler Exit: Late Jam
J108	Stapler Exit: Lag Jam
J109	Pre-stack Tray: Late Jam
J110	Pre-Stack Tray: Lag Jam
J111	Output
J112	Booklet Stapler: Late Jam
J113	Booklet Stapler: Lag Jam
J114	Booklet Stapler Exit: Late Jam
J115	Booklet Stapler Exit: Lag Jam
J116	Paper Transport Path
J117	Shift Tray Operation Mechanism
J118	Jogger Operation Mechanism
J119	Shift Tray Drive Mechanism

Code No.	Meaning
J120	Stapler Drive Mechanism
J121	Output Drive Mechanism
J122	Punch Drive Mechanism
J123	Jogger Fences
J124	Pre-stack Drive Mechanism
J125	Stacking Mechanism
J126	Booklet Stapling Mechanism
J127	Booklet Folding Mechanism
J128	For Debugging ( Error cause unknown)
J129	Main Machine Data Corrupt

## Cover Interposer Tray CI5020 (D518) Jam Code Table

Code No.	Meaning
J150	1 st Feed Sensor: Late Jam
J151	1 st Feed Sensor: Lag Jam
J152	2nd Feed Sensor: Late Jam
J153	2nd Feed Sensor: Lag Jam
J154	1 st Transport Sensor: Late Jam
J155	1 st Transport Sensor: Lag Jam
J156	2nd Transport Sensor: Late Jam
J1 <i>57</i>	2nd Transport Sensor: Lag Jam
J158	1 st Tray Transport Sensor: Late Jam
J159	1 st Transport Sensor: Lag Error
J160	2nd Tray Transport Sensor: Late Jam

Code No.	Meaning
J161	2nd Transport Sensor: Lag Error
J162	Vertical Exit Sensor: Late Jam
J163	Vertical Exit Sensor: Lag Error
J164	Entrance Sensor: Late Error
J165	Entrance Sensor: Lag Error
J166	Exit Sensor: Late Error
J167	Exit Sensor: Lag Error
J168	1 st Lift Motor Drive Mechanism
J169	2nd Lift Motor Drive Mechanism
J170	1 st Pick-up Motor Drive Mechanism
J171	2nd Pick-up Motor Drive Mechanism

### Trimmer Unit TR5040 (D520) Jam Code Table

Code No.	Meaning
J200	Entrance Sensor: Late Jam
J201	Entrance Sensor: Lag Jam
J202	Skew Sensor: Late Jam
J203	Skew Sensor: Lag Jam
J204	Exit Sensor: Late Jam
J205	Exit Sensor: Lag Jam
J206	Trimming Blade Motor Lock
J207	Cut Position Motor
J208	Press Roller
J209	Press/Stopper Roller

Code No.	Meaning
J210	Tray Motor

### Multi Folding Unit FD5010 (D521) Jam Code Table

Code No.	Meaning
J250	Entrance Sensor: Late Jam
J251	Entrance Sensor: Lag Jam
J252	Top Tray Exit: Lag Jam
J253	Top Tray Exit: Lag Jam
J254	Horizontal Path Exit: Late Jam
J255	Horizontal Path Exit: Lag Jam
J256	1st Stopper: Late Jam
J257	1st Stopper: Lage Jam
J258	2nd Stopper: Late Jam
J259	2nd Stopper: Lag Jam
J260	3rd Stopper: Late Jam
J261	3rd Stopper: Lag Jam
J262	Skew Correction Jam
J263	Top Tray Path Jam
J264	Entrance/Top Tray JG Motor Jam
J265	Entrance/Fold JG Motor Jam
J266	1st Stopper Motor Jam
J267	2nd Stopper Motor Jam
J268	3rd Stopper Motor Jam
J269	Dynamic Roller Lift Motor Jam

Code No.	Meaning
J270	Registration Roller Release Motor Jam
J271	Fold Blade Drive Motor Jam
J272	Jogger Fence Motor Jam
J273	Positioning Roller Motor Jam
J274	FM2 Direct Send Motor Error
J275	FM6 Pawl Motor
J276	Main Machine Data Corrupt

## High Capacity Stacker SK5020 (D515) Jam Code Table

Code No	Meaning
J300	Entrance: Late Jam
J301	Entrance: Lag Jam
J302	Proof Tray Exit: Late Jam
J303	Proof Tray Exit: Lag Jam
J304	Stack Tray Exit: Late Jam
J305	Stack Tray Exit: Lag Jam
J306	Relay Path: Late Jam
J307	Relay Path: Lag Jam
J308	Straight-through Paper Path Exit: Late Error
J309	Straight-through Paper Path Exit: Lag Jam
J310	Shift JG Motor
J311	Proof Tray JG Motor
J312	Shift Motor
J313	Front Jogger Fence Motor

### Ring Binder RB5010 (D519) Jam Code Table

Code No	Meaning
J350	Entrance: Late Jam
J351	Entrance: Lag Jam
J352	Central Transport Path: Late Jam
J353	Central Transport Path: Lag Jam
J354	Transport Exit: Late Jam
J355	Transport Exit: Lag Jam
J356	Before Pre-punch Unit Jam
J357	After Pre-punch Unit Jam
J358	Binder Unit TE Jam
J359	Binder Unit LE Jam
J360	Ring Jam: Wrong Ring Type
J361	Binder Unit Jam
J362	Output Belt 1 Jam
J363	Output Belt 2 Jam

Code No	Meaning
J364	Stacker Jam
J365	Punch Motor Jam
J366	Shutter Motor Jam
J367	Alignment Pin Motor Jam
J368	Pre-Punch Jogger Jam
J369	Alignment Pin Jam
J370	Clamp Motor Jam
J371	50/100 Clamp Adjust Motor Jam
J372	Output Belt Rotation Motor Jam
J373	Main Machine Data Corrupt

## Buffer Pass Unit Type (5010 D548) Jam Code Table

Code No	Meaning
J400	Transport Sensor 1: Late Jam
J401	Transport Sensor 1: Lag Jam
J402	Transport Sensor 2: Late Jam
J403	Transport Sensor 2: Lag Jam
J404	Transport Sensor 3: Late Jam
J405	Transport Sensor 3: Lag Jam
J406	Transport Sensor 4: Late Jam
J407	Transport Sensor 4: Lag Jam
J408	Transport Sensor 5: Late Jam
J409	Transport Sensor 5: Lag Jam
J410	Transport Sensor 6: Late Jam

#### **ARDF Jam Code Table**

Code No	Meaning
000	Jam Release
001	Standby Jam (Initial)
002	Reserved
003 to 007	Paper Late Jams: Main Machine
003	Separation Sensor
004	Skew Correction Sensor
005	Interval Sensor
006	Registration Sensor
007	Exit Sensor
008	Invert/Switchback Sensor
009	Lower Invert Sensor
053 to 057	Paper Lag Jams: Main Machine
053	Separation Sensor
054	Skew Correction Sensor

0

Code No	Meaning
055	Interval Sensor
056	Registration Sensor
057	Exit Sensor
058	Invert/Switchback Sensor
059	Lower Invert Sensor

## D074/D075, M044 Jam Displays

Code No.,	Meaning
А	1 st Paper Feed Sensor
А	2nd Paper Feed Sensor
А	1 st Transport Sensor
А	2nd Transport Sensor
А	Vertical Transport Sensor
А	Bank Exit Sensor
А	Main Relay Sensor 1
В	Main Relay Sensor 3
В	Relay Sensor 1 (LCT)
В	Relay Sensor 2 (LCT)
В	Registration Sensor
B1	Main Relay Sensor 2
В6	Transfer Timing Sensor
С	Transport Thermistor
D2/D3	Fusing Exit Sensor
D2/D3	Feed-out Entrance Sensor

Code No.,	Meaning
D4	Exit JG Sensor
D4	Exit Sensor
D5	Paper Exit Relay Sensor
D5,E	Duplex Invert Sensor
E	Purge Relay Sensor
E	Purged Paper Sensor
U	1 st Transport Sensor (LCT)
U	2nd Transport Sensor (LCT)
U	3rd Transport Sensor (LCT)
U	1 st Relay Sensor: Lower (LCT)
U	1 st Relay Sensor: Upper (LCT)
U	2nd Transport Sensor (LCT)
U	3rd Transport Sensor (LCT)
U	Exit Sensor (LCT)
U,V	4th Transport Sensor (LCT)
U2	1 st Paper Feed Sensor (LCT)
U4	2nd Paper Feed Sensor (LCT)
U6	3rd Paper Feed Sensor (LCT)
٧	4th Paper Feed Sensor (LCT)
Z3	Duplex Transport Sensor 1
Z3	Duplex Transport Sensor 2
Z3	Duplex Transport Sensor 3
Z4	Duplex Transport Sensor 6
Z4	Duplex Transport Sensor 7

Code No.,	Meaning
Kc1 to 9	Transport Sensor 1: Late Jam
Kc1 to 9	Transport Sensor 1: Lag Jam
Kc1 to 9	Transport Sensor 2: Late Jam
Kc1 to 9	Transport Sensor 2: Lag Jam
Kc1 to 9	Transport Sensor 3: Late Jam
Kc1 to 9	Transport Sensor 3: Lag Jam
Kc1 to 9	Transport Sensor 4: Late Jam
Kc1 to 9	Transport Sensor 4: Lag Jam
Kc1 to 9	Transport Sensor 5: Late Jam
Kc1 to 9	Transport Sensor 5: Lag Jam
Kc1 to 9	Transport Sensor 6: Late Jam
Kc1 to 9	Transport Sensor 6: Lag Jam
Kc1 to 9	Transport Sensor 7: Late Jam
Kc1 to 9	Transport Sensor 7: Lag Jam
Kc1 to 9	Transport Sensor 8: Late Jam
Kc1 to 9	Transport Sensor 8: Lag Jam
Kc1 to 9	Main Machine Data Corrupt
L1 to 5	Entrance: Late Jam
L1 to 5	Entrance: Lag Jam
L1 to 5	Proof Tray Exit: Late Jam
L1 to 5	Proof Tray Exit: Lag Jam
L1 to 5	Relay Path: Late Jam
L1 to 5	Relay Path: Lag Jam
L1 to 5	Straight-through Paper Path Exit: Late Error
L1 to 5	Straight-through Paper Path Exit: Lag Jam

Code No.,	Meaning
L6	Stack Tray Exit: Late Jam
L6	Stack Tray Exit: Lag Jam
L6	Shift JG Motor
L6	Proof Tray JG Motor
L6	Shift Motor
L6	Front Jogger Fence Motor
L6	Rear Jogger Fence Motor
L6	Main Jogger Fence Retraction Motor
L6	Main Jogger Rear Fence Retraction Motor
L6	Sub Jogger Motor
L6	LE Stopper Motor
L6	Tray Lift Motor
L6	Main Machine Data Corrupt
Mc1 to 2	Entrance: Late Jam
Mc1 to 2	Entrance: Lag Jam
Mc1 to 2	Main Machine Data Corrupt
Mc10	Stacker Jam
Mc3 to 4	Central Transport Path: Late Jam
Mc3 to 4	Central Transport Path: Lag Jam
Mc3 to 4	Transport Exit: Late Jam
Mc3 to 4	Transport Exit: Lag Jam
Mc5	Before Pre-punch Unit Jam
Mc5	Punch Motor Jam
Mc5 to 6	Binder Unit TE Jam
Мсб	After Pre-punch Unit Jam

Code No.,	Meaning
Mc7 to 8	Binder Unit LE Jam
Mc7 to 8	Ring Jam: Wrong Ring Type
Mc7 to 8	Binder Unit Jam
Mc7 to 8	Shutter Motor Jam
Mc7 to 8	Alignment Pin Motor Jam
Mc7 to 8	Pre-Punch Jogger Jam
Mc7 to 8	Alignment Pin Jam
Mc7 to 8	Clamp Motor Jam
Mc7 to 8	50/100 Clamp Adjust Motor Jam
Mc9	Output Belt 1 Jam
Mc9	Output Belt 2 Jam
Mc9	Output Belt Rotation Motor Jam
N1 to 5	Entrance Sensor: Late Jam
N1 to 5	Entrance Sensor: Lag Jam
N1 to 5	Top Tray Exit: Lag Jam
N1 to 5	Top Tray Exit: Lag Jam
N1 to 5	Horizontal Path Exit: Late Jam
N1 to 5	Horizontal Path Exit: Lag Jam
N1 to 5	Top Tray Path Jam
N1 to 5	Entrance/Top Tray JG Motor Jam
N1 to 5	Entrance/Fold JG Motor Jam
N1 to 5	Main Machine Data Corrupt
N6 to 22	1st Stopper: Late Jam
N6 to 22	1st Stopper: Lage Jam
N6 to 22	2nd Stopper: Late Jam

Code No.,	Meaning
N6 to 22	2nd Stopper: Lag Jam
N6 to 22	3rd Stopper: Late Jam
N6 to 22	3rd Stopper: Lag Jam
N6 to 22	Skew Correction Jam
N6 to 22	1st Stopper Motor Jam
N6 to 22	2nd Stopper Motor Jam
N6 to 22	3rd Stopper Motor Jam
N6 to 22	Dynamic Roller Lift Motor Jam
N6 to 22	Registration Roller Release Motor Jam
N6 to 22	Fold Plate Motor Jam
N6 to 22	Jogger Fence Motor Jam
N6 to 22	Positioning Roller Motor Jam
N6 to 22	FM2 Direct Send Motor Error
N6 to 22	FM6 Pawl Motor
Q1	1 st Feed Sensor: Late Jam
Q1	1 st Feed Sensor: Lag Jam
Q1	1 st Lift Motor Drive Mechanism
Q1	1 st Pick-up Motor Drive Mechanism
Q2	2nd Feed Sensor: Late Jam
Q2	2nd Feed Sensor: Lag Jam
Q2	2nd Lift Motor Drive Mechanism
Q2	2nd Pick-up Motor Drive Mechanism
Q3 to 4	1 st Transport Sensor: Late Jam
Q3 to 4	1 st Transport Sensor: Lag Jam
Q3 to 4	2nd Transport Sensor: Late Jam

Code No.,	Meaning
Q3 to 4	2nd Transport Sensor: Lag Jam
Q3 to 4	1st Tray Transport Sensor: Late Jam
Q3 to 4	1 st Transport Sensor: Lag Error
Q3 to 4	2nd Tray Transport Sensor: Late Jam
Q3 to 4	2nd Transport Sensor: Lag Error
Q3 to 4	Vertical Exit Sensor: Late Jam
Q3 to 4	Vertical Exit Sensor: Lag Error
Q3 to 4	Entrance Sensor: Late Error
Q3 to 4	Entrance Sensor: Lag Error
Q3 to 4	Exit Sensor: Late Error
Q3 to 4	Exit Sensor: Lag Error
Rb1 to 5	Entrance: Late Jam
Rb1 to 5	Entrance: Lag Jam
Rb1 to 5	Proof Tray Exit: Late Jam
Rb1 to 5	Proof Tray Exit: Lag Jam
Rb1 to 5	Shift Tray Exit: Late Jam
Rb1 to 5	Shift Tray Exit: Lag Jam
Rb1 to 5	Paper Transport Path
Rb1 to 5	Shift Tray Operation Mechanism
Rb1 to 5	Shift Tray Drive Mechanism
Rb1 to 5	Punch Drive Mechanism
Rb1 to 5	For Debugging ( Error cause unknown)
Rb1 to 5	Main Machine Data Corrupt
Rb10 to 17	Stapler Exit: Lag Jam
Rb10 to 17	Output

Code No.,	Meaning
Rb10 to 17	Booklet Stapler: Late Jam
Rb10 to 17	Booklet Stapler: Lag Jam
Rb10 to 17	Booklet Stapler Exit: Late Jam
Rb10 to 17	Booklet Stapler Exit: Lag Jam
Rb10 to 17	Jogger Operation Mechanism
Rb10 to 17	Stapler Drive Mechanism
Rb10 to 17	Output Drive Mechanism
Rb10 to 17	Jogger Fences
Rb10 to 17	Stacking Mechanism
Rb10 to 17	Booklet Stapling Mechanism
Rb10 to 17	Booklet Folding Mechanism
Rb6 to 9	Stapler Exit: Late Jam
Rb6 to 9	Pre-stack Tray: Late Jam
Rb6 to 9	Pre-Stack Tray: Lag Jam
Rb6 to 9	Pre-stack Drive Mechanism
Rt1 to 2	Entrance Sensor: Late Jam
Rt1 to 2	Entrance Sensor: Lag Jam
Rt1 to 2	Skew Sensor: Late Jam
Rt1 to 2	Skew Sensor: Lag Jam
Rt1 to 2	Exit Sensor: Late Jam
Rt1 to 2	Exit Sensor: Lag Jam
Rt1 to 2	Trimming Blade Motor Lock
Rt1 to 2	Cut Position Motor
Rt1 to 2	Press Roller
Rt1 to 2	Press/Stopper Roller

Code No.,	Meaning
Rt1 to 2	Tray Motor

MEMO

## Pro C651EX/Pro C751EX/Pro C751 Machine Code: D074/D075/M044

# **Appendices**

# **TABLE OF CONTENTS**

- 4		_		- •
I. Ap	pendix:	Spe	ecitico	ations

Main Specifications	3
General Specifications: Copier and Printer	3
Weight Distribution	7
Copy Specifications	8
Scanner Specifications (D074/D075)	10
Local Storage Specifications	13
Main Unit	13
System Function Specifications	15
ARDF	23
Main Machine Options	24
Peripheral Specifications	25
LCIT RT5060 (D516)	25
Multi-Bypass Tray BY5010 (D517)	26
Decurler Unit DU5000 Unit (D544)	27
Multi-Folding Unit FD5010 (D521)	28
Booklet Finisher SR5040/5030 (D512/D513)	35
2. Appendix: Service Program Mode Tables	
Group 1000	41
Group 2000	77
Group 3000	136
Group 4000	166
Group 5000	180
Group 6000	293
Group 7000	335
Group 8000	373

# 1. Appendix: Specifications

## **Main Specifications**

### General Specifications: Copier and Printer

Configuration	Console
Image Writing System	Laser
Color Copy Process	4-drum dry, electrostatic transfer with transfer belt
Engine Speed	Calculated for A4/LT LEF (uncoated). See below.

Machine	Th: .l	Thickness Range (g/m²)		ppm	
Macnine	Inickness	Range (g/m²)	B/W	FC	
	Thick 1	52.3 to 63.0	65	65	
	Thick 2	63.1 to 80.0	65	65	
	Thick 3	80.1 to 105.0	65	65	
D074	Thick 4	105.1 to 163.0	65	65	
	Thick 5	163.1 to 220.0	65	65	
	Thick 6	220.1 to 256.0	45	45	
	Thick 7	256.1 to 300.0	45	45	
	Thick 1	52.3 to 63.0	75	75	
	Thick 2	63.1 to 80.0	75	75	
	Thick 3	80.1 to 105.0	75	75	
D075/M044	Thick 4	105.1 to 163.0	75	75	
	Thick 5	163.1 to 220.0	75	75	
	Thick 6	220.1 to 256.0	52	52	
	Thick 7	256.1 to 300.0	52	52	

First Print	B/W Less than 11		1 sec. (A4/LT LEF)		
	FC	Less than 1	l sec. (A4/LT LEF)		
Resolution	Reading	600 dpi			
	Writing	1200 x 480	00 dpi (Main Scan x Sub	Scan)	
Gradation	Reading 256 Steps				
			2bit (Copy Printing) 2-bit, 600 dpi/4-bit (Print	bit (Copy Printing) -bit, 600 dpi/4-bit (Print Jobs)	
Warm-up Time	Less than 300 sec.				
Max. Printable Area (W x L)	323 x 480 mm (12.7 x 18.9 in.)				
Paper Capacity (80 g/m²)	Feed Sta	tion	Sheets/Tray	Total	
	Main 1st Tray		1000 + 1000	2000	
	Main 2nd Tray		500	500	
	LCIT 1st Tray		1000	1000	
	LCIT 2nd Tray  LCIT 3rd Tray  Bypass (on LCIT)		2000	2000	
			1000	1000	
			500	500	
			Total (80 g/m²)	7,000	
Paper	Refer to "Paper Type, Size, Thickness Table" below.				

Paper Thickness/Type	Thickness	Туре
Main 1st Tray	52.3 – 300 g/m <sup>2</sup> 14 lb. Bond – 110 lb. Cover	Normal, Recycled, Used, Letterhead, Punched
Main 2nd Tray	52.3 – 256 g/m <sup>2</sup> 14 lb. Bond – 95 lb. Cover	Normal, Recycled, Used, Letterhead, Punched, Index
LCIT 1st Tray	52.3 – 256 g/m <sup>2</sup> 14 lb. Bond – 95 lb. Cover	Normal, Recycled, Used, Letterhead, Punched, Gloss, Matte, Index, OHP, Trace, Envelopes

RTB 47 Note added to these specs

LCIT 2nd Tray	52.3 – 300 g/m² 14 lb. Bond – 110 lb. Cover	Normal, Recycled, Used, Letterhead, Punched, Gloss, Matte, Labels, Index, OHP, Trace, Envelopes
LCIT 3rd Tray	52.3 – 256 g/m <sup>2</sup> 14 lb. Bond – 95 lb. Cover	Normal, Recycled, Used, Letterhead, Punched, Gloss, Matte, Index, OHP, Trace, Envelopes
Bypass	52.3 – 216 g/m <sup>2</sup> 14 lb. Bond – 81 lb. Cover	Normal, Recycled, Used, Letterhead, Punched, Index, OHP, Trace
Main (Duplex)	60 – 256 g/m <sup>2</sup> 16 lb. Bond – 95 lb. Cover	

Paper Size		
Main 1st Tray (Tandem)	A4 LEF, LT L	EF (Fixed)
Main 1st Tray (Tandem – A3 Kit)	Std.	A3 SEF, B4 SEF, A4 SEF/LEF, DLT SEF, LG SEF, LT SEF/LEF
	Custom	Min.: 210 x 210mm Max.: 305 x 439mm
Main 2nd Tray	Std.	13"x 18" SEF; SRA3 SEF, 12 x 18" SEF, SRA4 SEF/LEF; A3 SEF, A4 SEF/LEF, A5 SEF/LEF, B4 SEF, B5 SEF/LEF; DLT SEF, LG SEF, 8.5"x13" SEF, LT SEF/LEF, 8.25 x 14" SEF, 8.25 x 13" SEF, 8 x 13" SEF, Executive SEF/LEF, HLT SEF/LEF, Line Slider 1 LEF, Line Slider 2 SEF; 8-Kai SEF, 16-Kai SEF/LEF; 11"x15" SEF, 11"x14" SEF, 10"x15" SEF
	Custom	Width: 139.7 to 330.2mm Length: 139.7 to 487.7 mm


LCIT	Std.	13"x19.2" SEF, 13"x19"SEF, 12.6"x19.2"SEF, 12.6"x18.5" SEF, 13"x 18" SEF, SRA3 SEF, 12"x18" SEF, SRA4 SEF/LEF		
		A3 SEF, A4 SEF/LEF, A5 SEF/LEF, A6 SEF, B4 SEF, B5 SEF/LEF, B6 SEF		
		DLT SEF, LG SEF, 8.5"x13" SEF, LT SEF/LEF, 8.25"x14" SEF, 8.25"x 13" SEF,		
		8" x 13" SEF, 8"x10.5" LT SEF/LEF, 8"x10" SEF/LEF, Executive SEF/LEF, HLT SEF/LEF,		
		Line Slider 1 SEF/LEF, Line Slider 2 SEF		
		8-Kai SEF, 16-Kai SEF/LEF,		
		11"x15" SEF, 11"x14" SEF, 10"x"15" SEF, 10x 14" SEF		
	Custom	Width: 100 to 330.2mm		
		Length: 139.7 to 487.7mm		
Bypass (on LCIT)	Std.	Same as LCIT		
	Custom	Width: 100 to 330.2mm		
		Length: 139.7 to 630mm		
Duplex Paper Sizes	A5 SEF, HL	A5 SEF, HLT SEF to 13"x19.2"		
Paper Size Adjustment				
Main 1st Tray (Tandem)	Fixed (A4 LEF or LT LEF)			
Main 2nd Tray	Universal Tray			
LCIT	Universal Tray			
Bypass (on LCIT)	Universal Tray			
Paper Output Capacity				
Finisher D512 (Booklet-Stapler)	Shift Tray	2500 Sheets		
	Proof Tray	250 Sheets		
Finisher D513 (Corner Stapler)	Shift Tray	3000 Sheets		
	Proof Tray	250 Sheets		
High Capacity Stacker (D515)	Stacker	5000 Sheets		

	Proof Tray	25	O Sheets	
Ring Binder (D519)	11 Booklets (100 pages each)			
Multi Folding Unit (D521)	Varies with folding method			
Trimmer Unit (D520)	25 Booklets (A3/DLT 20 pages each)			
Power Source	North America		208V to 240V, 16A, 50/60 Hz	
	Europe/Asia		220 to 240V 16A, 50/60 Hz	
Power Consumption (Max.)	Less than 4000W RTB 35 Explanation is added			
Energy Star	Compliant			
Sleep Mode	Less than 30W			
Memory				
D074/D075	2.5 GB (2 GB + 512 MB)			
M044	1.5 GB (1 GB + 512 MB)			
HDD	320 GB			
Dimensions				
D074/D075	1320 x 910 x 1230 mm (52 x 35.8 x 48.4 in.) *1			
M044	1320 x 910 x 1218 mm (52 x 35.8 x 47.9 in.) *1			
Weight				
D074/D075	Less than 580 kg (1,276 lb.)			
M044	Less than 550 kg (1,210 lb.)			

<sup>\*1:</sup> The rear boxes can be removed. With the controller box and cooling box removed, the main body will fit through a space (narrow door or elevator door) about 750 mm (30 in.) wide.

## **Weight Distribution**

The main machine is heavy. Apply these numbers as reference points because the distribution of weight will differ, depending on how the machine is leveled at the four corners (a, b, c, d) in the illustration below.



Location	Weight (kg)
a: Rear Left	144.3
b: Rear Right	155.0
c: Front Right	134.7
d: Front Left	127.2

No.	Location	Weight (kg)
1	d+c	261.9
2	a+b	299.3
3	b+c	289.7
4	a+d	271.5
5	a+b+c+d	561.2

# Copy Specifications

Original Scan Method	Horizontal flatbed, ADF
Original Orientation	Left rear corner

Original Size (Max.)	12" x 17"			
Maximum Weight (Exposure Glass)	5 kg (2.3 lb.)			
Original Scales	Left Scale	Е	NA	
		SEF	LEF	Inch
		А3	A4	11
		В4	B5	10
		A4	A5	8.5
		В5		8
		A5		5.5
	Rear Scale	E	U/AP	NA
		SEF	LEF	Inch
		А3	A4	17
		В4	B5	14
				11
		A4	A5	10
		B5		8.5
		A5		8
				5.5
Original Type	Book, Sheet, C	bject		
Paper Size Detection				
Main	12 x 18" SEF, A3 SEF, B4 SEF, A4 SEF/LEF, A5 SEF/ LEF, DLT SEF, LT SEF/LEF, F (8 x 13")SEF, HLT SEF/LEF, B5 SEF/LEF			
LCIT	12 x 18" SEF, A3 SEF, B4 SEF, A4 SEF/LEF, A5 SEF/ LEF, DLT SEF, LT SEF/LEF, F (8 x 13")SEF, HLT SEF/LEF, B5 SEF/LEF			

Bypass (on LCIT)	12 x 18" SEF, A3 SEF, B4 SEF, A4 SEF/LEF, A5 SEF/ LEF, DLT SEF, LT SEF/LEF, F (8 x 13")SEF, HLT SEF/LEF, B5 SEF/LEF		
Paper Counter	1 to 9999 Sheets		
Enlarge/Reduction Rates			
NA	Enlarge	1:1, 1.21, 1.29, 1.55, 2.00, 4.00	
	Reduce	1: 0.93, 0.85, 0.78, 0.73, 0.65, 0.50, 0.25	
EU/AP	Enlarge	1:1, 1.15, 1.22, 1.41, 2.00, 4.00	
	Reduce	1: 0.93, 0.82, 0.75, 0.71, 0.65, 0.50, 0.25	
Zoom Rate	25% to 40% (1% steps)		

## Scanner Specifications (D074/D075)

#### General

Scanning Method	Flatbed		
Scan Direction	Main Scan Surface		
Scan Range	Same as copy specification		
Gradation	256 Levels		
Compatible Interfaces	Ethernet (100Bases-TX/10Base-T), USB 2.0 Type A, SD Memory Card Slot		
RAM	2.5GB		
Magnification Range	Copy 600 dpi 25 – 400%		
	Scan-to-file 100 – 600 dpi 600 – 1200 dpi		
Scanning Color Modes	B/W, FC, Auto Color selectable		
Multiple Output	B/W 1-bit/8-bit		

	FC	RGB for each color (sRGB)	
Max. Area	Main Scan	297 mm (11.7 in.)	
	Sub Scan	432 mm (17 in.)	
Drop-out Color	Supported (Selectable)		

#### **TWAIN**

Scan Area	Main Scan (Width)	297 mm (11.7 in.)	
	Sub Scan (Length)	432 mm (1 <i>7</i> in.)	
Resolution	Main: 600 dpi (100 – 1200 dpi/1 dpi specified)		
Supported Interfaces	Ethernet (100Base-TX/10Base-T)		
Drivers	Network TWAIN, WIA		
Image Memory Area	Not provided		
TWAIN Compatible OS	Windows 2000, Windows XP, Windows Server 2003, Windows Vista, Windows Server 2008, Windows 7		
TWAIN First Read Function	Supported		

#### **Scan-to-Document**

Scan Area	Main Scan (Width)		297 mm (11.7 in.)
	Sub Scan (Length)		432 mm (17 in.)
Resolution	600 dpi (Base), 400,		300, 200, 150 dpi
Supported Interfaces	Ethernet (100Base-TX/10Base-T)		
ADF Throughput	B/W More than 75 sheets/min. at 200 dpi (A4 LEF with MH Compression		• •
	FC More than 75 JPEG compres		sheets/min. at 200 dpi (A4 LEF with ssion)

Performance	B/W More than 77 sheets/min. at 200 dpi (A4 LEF MH Compression		
	FC	More than 77 sheets/min. at 200 dpi (A4 LEF with JPEG compression)	
Mixed Original	Supported		
Scan-to-PC	SMB, FTP, NCP Sending		
Scan-to-Email	POP before SMTP/SMTP with Authentication, S/MIME		
Distribution Addresses	2000 (LDAP compatible)		
Mail Protocol	POP, SMTP, IMAP4		
Blank Original Detection	Supported		

## **EFI Fiery Scanner**

Scan Area	Main Sco	an (Width)	297 mm (11.7 in.)	
	Sub Scar	(Length)	432 mm (17 in.)	
Resolution	600 dpi	600 dpi		
Grayscale	B/W: 1-l	B/W: 1-bit/8-bit Selectable		
ADF Throughput	B/W	B/W More than 75 sheets/min. at 200 dpi (1-bit A4 LEF, MH Compression)		
	FC More than 75 sheets/min. at 200 dpi (24-bit / LEF JPEG Compression)		•	
Interfaces	10/100/Gigabit Ethernet			
File Formats	TIFF (Multi/Single), JPEG, PDF (Multi/Single)			
Scanning Adjustment	Supported			
Brightness Adjustment	Supporte	Supported		
Original Type	Selectable			
Scan Operation	From MFP operation panel			
TWAIN Driver	Network TWAIN, EFI supported drivers			

Supported Functions	Scan-to-EFI Controller HDD, Scan-to-Email, Scan-to-Mailbox, Scan-to-Hold Queue, Scan-to-FTP, Scan-to-PC (SMB)
Blank Original Detection	Supported

## Local Storage Specifications

Documents	Scanned Original Data, Print Data, Copy Data, Document Backup for Each Type	
Document Handling	Paper Output (Includes Test Output, Password Output, File Merge Output), Client PC Sending	
Interfaces	10/100/Gigabit Ethernet	
Storage Capacity	15000 Pages or 3000 Documents (Copy Application Only)	
	Note:	
	<ul> <li>Storage capacity can be adjusted with and SP code setting to released unused areas on the HDD.</li> </ul>	
	<ul> <li>Document size is limited to 5000 pages for the Copy application and 3000 pages for other applications.</li> </ul>	

## Main Unit

## **Engine**

Configuration	Console Type with Dry Toner Fusing	
Exposure	3-Line CCD Elements, 4 Lens Groups, Xenon Lamp and Reflection Plate, 600 dpi	
Image Writing	Laser Raster System, 1200 x 4800 dpi, PWM, 1/48 dot	
Drive System		
Drum	Traction Motor + Serration Linkage	
Development	Gear and Belt Reduction + Tribol and Coupling Linkage	
Drum Cleaning	Gear & Belt Reduction + Coupling Linkage	

Image Transfer	Large Aperture Gear Reduction	
Paper Transfer/ITB Cleaning	Reduction Gear + Coupling	
Fusing	Reduction Gear + Coupling	
Paper Exit	Reduction Gear + Coupling	
Used Toner Collection	Gear and Belt Reduction + Coupling	
Quenching Around Drums		
Method	4 Drums (YCMK)	
Quenching Method	NC Roller	
Drum Drive	Traction Reduction Motor + Perforated Shaft	
Drums	60 mm dia.	
Drum Cleaning Method	Counter-Blade	
Assist Functions	Dry Drum Lubrication, Quenching Assist with PCL (Photoconductor Lamp)	
Development	Circulating Dry Toner	
Transfer & Separation		
Image Transfer	Belt Transfer System with Roller-Driven ITB	
Paper Transfer	PTR Bias Transfer (Image from ITB to Paper)	
Paper Separation Method	AC Charge	
Paper Transport	Belt Assisted by Suction Fans	
ITB Cleaning	Counter-Blade, Lubricant Brush Roller (Zinc Stearate Lubricant)	
PTR Cleaning	Counter-Blade, Lubricant Brush Roller (Zinc Stearate Lubricant)	
Paper Feed, Transport, Exit		
Feed and Separation	FRR System	
1 st Tray	Tandem (Fixed Size)	
2nd Tray	Universal Tray	
Paper Registration System		

Main Scan	Paper shift based on CIS readings	
Sub Scan	Registration roller buckle adjustment with registration gate, transfer timing roller speed timing adjustment	
Invert/Duplex		
Duplexing Method	Interleave	
Cooling System	Heat Sink Roller	
Fusing		
Fusing Method	Dry Belt (Oil-less)	
Temperature Control	Non-contact Sensors, Contact Thermistors	
Cleaning Method	Cleaning Web	
Fusing Unit Configuration	Fusing/Exit Unit, Removable	
Toner Supply	Dry Toner Pump + Sub Hopper Augur	
Operation Panel	LCD with Touch Panel	
Engine Control	Dual CPU	
Process Control	Potential Sensors, ID Sensors, TD Sensors	

# System Function Specifications

## **Printer/Scanner**

Paper Capacity Detection	
1 st Tray	5-Step (including Near-End)
2nd Tray	5-Step (including Near-End)
LCIT Trays (1, 2, 3)	5-Step (including Near-End)
Bypass (on LCIT)	4-Step (including Near-End)
Limitless Paper Supply	Supported
Tray Overflow Detection	All Trays

Duplexing			
Paper Size	A5 SEF/HLT SEF to 13"x19.2"		
Paper Weight	60.0 to 256 g/m² (16 lb. Bond to 95 lb. Cover)		
Paper Type	Normal, Recycled, Coated Paper		
Double-Feed Detection	Provided		
Stapling (Finisher D512/D513)			
Stack Thickness	2 to 100 Sheets		
Paper Size	B5 to A3/DLT		
Paper Thickness	64 to 90 g/m <sup>2</sup> (2 to 100 Sheets		
Paper Type	Normal, Recycled, Coated,		
Staple Positions (D512)	Corner Stapling: Rear, Rear Diagonal, Front Flat Staples: 2 Locations Booklet Staples: 2 Locations		
Staple Positions (D513)	Corner Stapling: Rear, Rear Diagonal, Front Flat Stapling: 2 Locations Note: Finisher D513 does not support booklet stapling.		
Staple Out Detection	Yes		
Paper Thickness Settings (g/m²)	Thick 1 52.3 to 63.0		
	Thick 2 63.1 to 80.0		
	Thick 3 80.1 to 105.0		
	Thick 4 105.1 to 163.0		
	Thick 5 163.1 to 220.0		
	Thick 6 220.1 to 256.0		
	Thick 7 256.1 to 300.0		
	<b>Note</b> : Only Thick 1, 4, 5 are available for the Bypass Unit (on top of the LCIT). One can be selected with a key on the Bypass Unit.		

Paper Remaining Display	Yes	
Original on Exposure Glass Alert	Yes	
User Code Settings	500 for registration (8 alphanumeric characters)	
Energy Save		
Auto Energy Save Mode	Yes	
Auto Power Save	Yes	
Auto Off	Yes	
Weekly Timer	Yes	
Counter	Electronic Counter, Mechanical Counter	
Anti-Condensation Heaters	<ul> <li>Scanner Unit (Service Option)</li> <li>Transfer Unit (Switch)</li> <li>Paper Bank (Switch)</li> </ul>	
@Remote Function	Supported (Basil, Cumin-N, UZ-A1)	
GW SDK	Applications Available	
ID Chip for Parts	Toner Bottle, Fusing Unit	
Utilities	Windsor     Acacia     @Remote     Email Detection for TX/RX	

## Copying

ACS (Auto Color Selection)	Provided
Full Color Mode	Yes
Black & White Mode	Yes
Single Color Mode	Main machine colors: 12 Colors + B&W Registered colors: 15 (displayed in SP mode only)


2-Color Mode	Black + Mono	Black + Mono Colors		
	Note: Display	Note: Display switch with SP code.		
ADF Originals	Mixed Sizes A	Mixed Sizes Allowed		
	Thin Paper No	Thin Paper Not Allowed		
	Allows Single	Allows Single/Double-Sided Originals in same Batch		
	B/W, Color i	n Sa	me Stack Allowed	
	Blank Origina	ls N	ot Detected	
	Non-Standard	d Or	iginal Sizes Allowed	
	APS Detection	1		
Copy Modes (Selectable)	Text	Text		
	Photo	Photo		
	Generation	Generation		
	Pale	Pale  Map  Highlight Pen  Inkjet Output  Density		
	Мар			
	Highlight Pen			
	Inkjet Output			
	Density			
Enlarge/Reduction Rates				
NA	Enlarge	1 :	1, 1.21, 1.29, 1.55, 2.00, 4.00	
	Reduce	1 :	0.93, 0.85, 0.78, 0.73, 0.65, 0.50, 0.25	
EU/AP	Enlarge	1 :	1, 1.15, 1.22, 1.41, 2.00, 4.00	
	Reduce	1 :	0.93, 0.82, 0.75, 0.71, 0.65, 0.50, 0.25	
Zoom Rate	25% to 400%	(1%	Steps)	
Stamp	Fixed (Provide	ed)	8 (One Color)	
	User Defined		5 (One Color)	

Finisher (D512/D513)

Paper Punch	
NA	3-Hole, 2-Hole for LG (Switchable)
EU/AP	2-Hole, 4-Hole for Northern Europe (Switchable)
Scandinavia	4-Hole

## Multi Folding Unit (D521)

Folds	
FM1: Z-Folding	1 Sheet
FM2: Half Fold	3 Sheets Allowed (64 to 80 g/m²)
FM3: Letter Fold-out	
FM4: Letter Fold-in	
FM5: Double Parallel Fold	Only 1 sheet allowed
FM6: Gate Fold	



## **Original Size Detection**

Paper/Size		NA		EU/AP	
Paper	Size	Book Mode	ADF	Book Mode	ADF
A3 SEF	297x420 mm	X	0	0	0
B4 SEF	257x364 mm	X	Х	0	0
A4 SEF	210x297 mm	Х	0	0	0
A4 LEF	297x210 mm	X	0	0	0
B5 SEF	182x257 mm	Х	Х	0	0
B5 LEF	257x182 mm	Х	Х	0	0
A5 SEF	148x210 mm	Х	Х	Δ	0
A5 LEF	210x148 mm	Х	Х	Х	0
B6 SEF	128x182 mm	Х	Х	Х	0
B6 LEF	182x128 mm	Х	Х	Х	0
DLT SEF	11"x17"	0	00	Х	<b>O</b> 5
LG SEF	8.5"x14"	0	02	Х	Х
LT SEF	8.5"x11"	0	<b>3</b>	Х	<b>©</b> 6
LT LEF	11"x8.5"	0	<b>(4)</b>	Х	00
HLT SEF	5.5"x8.5"	Х	0	Х	Х
HLT LEF	8.5"x5.5"	Х	0	Х	Х
F SEF	8"x13"	Х	Х	<b>A</b>	<b>A</b>
Foolscap SEF	8.5"x13"	Х	●2	<b>A</b>	<b>A</b>
Folio SEF	8.25"x13"	Х	Х	<b>A</b>	<b>A</b>
Folio SEF	11"x15"	Х	●①	Х	X
Folio SEF	10"x14"	Х	0	Х	Х

1

Paper/Size		NA		EU/AP	
Paper	Size	Book Mode	ADF	Book Mode	ADF
Folio SEF	10"x8"	X	●3	X	Х
8-Kai SEF	267x390 mm	X	Х	0	●⑤
16-Kai SEF	195x267 mm	X	Х	0	●⑥
16-Kai LEF	267x195 mm	X	Х	0	●⑦
US EXE SEF	7.25"x10.5"	X	0	Х	X
US EXE LEF	10.5"x7.25W	Х	•4	Х	Х

#### Key

O and $lacktriangle$	Sizes can be switched between the two settings where you see matching numbers. The default is O.
<b>A</b>	Detected as one size: F SEF 8"x13".
Δ	For sizes smaller than B5, one of two SP values for SP4303 can be selected: "A5" and "Unknown Document Size". Default: "Unknown Document Size"
Х	Size cannot be detected.

#### Size Detection Switching with SP4303

4303	Min Size for APS
	Sets the minimum size of the original that the will be detected by APS (Auto Paper Select – with original width sensors) of the exposure glass of the flatbed scanner.
	[0 to 2/1]
	[*0: Unknown Document Size]
	[1 A5-Lengthwise (HLT Lengthwise]
	[2 A5 Sideways HLT Sideways]

#### Size Detection Switching with SP4305

**Note**: For Europe, Asia, and Oceania, original size detection in book mode the "A B" system and SP mode setting are used for the "Kai" sizes.

8-Kai SEF	Switch to A3, B4 SEF
-----------	----------------------

16-Kai SEF	Switch to A4, A5, B5 SEF	
16-Kai LEF	Switch to A4, A5, B5 LEF (However, no switching for individual sizes)	

4305	8K/16K Detection
	This SP enables the machine to recognize 8K/16K size paper automatically.
	[*0: Normal]
	[1: A4-Sideways LT-Lengthways]
	[2: A4-Lengthwise LT-Sideways]
	[3: 8KAI, 16 KAI]
	• A3, B4: 8-Kai SEF
	• A4, B4, A5 SEF: 16-Kai SEF
	• A4, B4, A5 LEF: 16-Kai LEF

## **GW Controller**

	I		
CPU Device	LV Dothan Pentium N	И 1.4 GHz	
Chip Set	GMCH, ICH6-M		
ASIC	Veena, Whistle	Veena, Whistle	
Main Memory			
	Capacity	2.5 GB	
	Configuration	2 GB DIMM + 0.5 GB DIMM	
BIOS ROM	1 MB		
NAND Flash Memory	128 MB		
EEPROM	1 KB		
NVRAM	512 KB		
TPM	Trusted Platform Mode		
RTC	Real Time Clock		
SD Card I/F	SD Card Slots 1, 2		

HDD I/F	SATA I/F Connectors x2
	HDD Power Connector x1
Network	RJ45 I/F Connector x1, 10Base-T/100Base-TX

## ARDF

Original Size	Simplex: A3/11" x 17" – B6/5.5" x 8.5"  Duplex: A3/11" x 17" – B5/5.5" x 8.5"
Original Weight	Simplex: 40 to 128 g/m <sup>2</sup> (11 to 34 lb.)  Duplex: 52 to 128 g/m <sup>2</sup> (14 to 34 lb.)
Table Capacity (A4 SEF, LT SEF)	500 sheets: 69g/m <sup>2</sup> (150 sheets: 80g/m <sup>2</sup> , 20 lb. Bond)
Speed	426.5 mm/s
Original Standard Position	Rear left corner
Separation	Feed belt and separation roller
Original Transport	Roller transport
Original Feed Order	From top original
Reproduction Range	66 to 400%
Power Source	DC 24 V from the main machine
Power Consumption	Less than 65 W
Rated Voltage of Output Connector	Max. DC 24 V
Permissible voltage fluctuation	±10%
Dimensions (w x d x h)	680 x 565 x 180 mm (26.8" x 22.3" x 7.1")
Weight	19.5 kg (43.0 lb.)

RTB 27 Specification corrected

## Main Machine Options

## A3/DLT Tray Kit B331 (Option)

Paper Size	A3 SEF, B4 SEF, 11"x17" SEF, 8½"x14" SEF, A4 SEF, A4 LEF, 8½"x11" SEF, 11"x8½" LEF, 305 mm x 439 mm
Paper Weight	$52.3 \text{ to } 300 \text{ g/m}^2$
Tray Capacity	1,000 sheets
Paper Level Detection	5-Step: 100%, 75%, 50%, 25%, End

1

# **Peripheral Specifications**

## LCIT RT5060 (D516)

Operating Environment	Ranges of temperature and humidity: Same as main machine.			
Service Life	Expected: 5 Years or 55,000K sheets			
	Paper Feed		550 mm/s	
	Standard		352.8	mm/s
Speed	70%		246.9	6 mm/s
	50%		176.4	mm/s
Paper Feed System:	Tray 3, 4, 5	FRI	R-CF	
Air Assist	Air assist fans for se	epara	tion, all	trays
T. C. ''	Tray 3, 5	1,0	)00 she	ets (Thickness: 0.11 mm)
Tray Capacity:	Tray 4	2,000 sheets (Thickness: 0.11 mm)		ets (Thickness: 0.11 mm)
	Tray 3, 5	Tray 3, 5 5 Step: 900, 625, 375, 75, tray end		0, 625, 375, 75, tray end
Paper Level Detection:	Tray 4 5 S		5 Step: 1750, 1250, 750, 75, tray end	
	Accuracy ±3		30 sheets (Tray 3, 4, 5)	
Bypass Tray (Option)	The Multi-Bypass T	The Multi-Bypass Tray (B833) can be installed on this LCIT (D516).		an be installed on this LCIT (D516).
	Tray 3	52.3 to 256 g/m <sup>2</sup>		56 g/m <sup>2</sup>
Paper Weight	Tray 4	52	.3 to 30	00 g/m <sup>2</sup>
	Tray 5	52	.3 to 25	56 g/m <sup>2</sup>
Paper Size	Tray 3,4,5	A5	(LEF) H	ILT (LEF) to 13 x 19.2 in.
	Range	Ler	ngth	139.7 to 487.7 mm
		Wi	dth	100 to 330.2 mm
Paper Size Switching	Side fence, end fer	nce ac	djustmer	nt.
Paper Size Detection	Automatic			

RTB 47 Note added to these specs

Heater (Option)	Anti-condensation heaters: 36W (18W x 2)						
Size (w x d x h)	865 x 730 x	1218mm (34 x 29	2 x 48 in.)				
Level	Less than 5 m	m deviation at fron	t/back, left/r	ight			
Weight	Less than 180	) kg (396 lb.)					
Power Source	DC 24 V ±10% (from main machine) AC 200V to 240V (from main machine)						
Power Consumption:	Less than 150 W						
I/F Connection	Serial connection to main frame						
T I Cl	Feed possible from all Tray. Requires installation of tab sheet fence.			et fence.			
Tab Sheet	Note: Only A4 LEF, 81/2" x 11" LEF tab sheets can be fed.						
Option	The Multi-Bypass Tray (D517)						
						System	
N. t. I.	Mode	Stand-alone	А	В	С		
Noise Level	Operation	< 73 dB	< 78 dB	< 80 dB	< 83 dB		
	Standby		< 64 dB	< 70 dB	< 78 dB		

## Multi-Bypass Tray BY5010 (D517)

This option is installed on top of the LCIT (D516).

Operating Environment	Temperature and humidity ranges: Same as main machine.		
Service Life	Expected: 5 Years or 60,000K sheets		
	Paper Feed	550 mm/s	
Speed	Standard	352.8 mm/s	
	70%	246.96 mm/s	
	50%	176.4 mm/s	
Paper Feed System	FRR-CF		
Tray Capacity	500 sheets (Paper thickness: 0.11 mm)		

Paper Weight	52.3 to 216 g	$52.3 \text{ to } 216 \text{ g/m}^2$				
Paper Size	A5 (LEF) HLT	A5 (LEF) HLT (LEF) to 13 x 19.2 in.				
	Range	Length	139.7 to 630	mm		
		Width	100 to 330.2	! mm		
Paper Size Switching	Operator adju	ustable side fe	nces accommodo	ate different pap	er sizes	
Paper Size Detection	Automatic (sta	ındard sizes d	only)			
Heater	None					
Down and the Land	4-Step: 500, 250, 50, paper end					
Paper Level Detection	Accuracy	Accuracy ±5		50 sheets		
Weight	Less than 18 k	g (39.6 lb)				
Power Source	24V±10 DC (from main machine)					
Power Consumption	Less than 50 \	Less than 50 W				
Size (w x d x h)	685 x 561 x	685 x 561 x 209 mm (27 x 22 x 8.2 in.)				
Tab Sheets	A4 LEF, 8½" >	(11" LEF (req	uires attachment	of tab fence)		
			System			
	Mode	Alone	А	В	С	
Noise Level	Operation	< 73 dB	< 78 dB	< 80 dB	< 83 dB	
	Standby		< 64 dB	< 70 dB	< 78 dB	

## Decurler Unit DU5000 Unit (D544)

#### General


Curl Correction	Front curl, back curl (switching possible)
Speed	160 to 380 mm/s
Operating Environment	Temperature and humidity ranges: Same as main machine.
Service Life	Expected: 5 Years or 60,000K sheets

Paper Weight	52.0 g/m <sup>2</sup> to 300g/m <sup>2</sup>
Paper Size	100 x 139.7 to 330.2 x 630 mm
Paper Types	Normal (includes color paper), recycled paper, cloth paper, matte paper, letterhead, coarse paper, tab sheets, labels, envelopes, film, OHP, trace paper, punched paper
Power Supply	Main machine
Power Consumption	Less than 30 W
Size (w x d x h)	54.5 x 482.7 x 188.7 mm (2 x 19 x 7.5 in.)
Weight	4.8 kg (10.5 lb.)

## Multi-Folding Unit FD5010 (D521)

#### General

Operating Environment	Temperature and humidity ranges: Same as main machine.		
Service Life	Expected: 5 years or 60,000 K (A4 LEF)		
Paper Weight	40 to 300 g/m <sup>2</sup>		
Speed	Straight-Through	100 to 700 mm/s	
	Folding	169 to 700 mm/s	
Straight-Through Feed	Size	Postcard to 13x19.2"	
		Used paper: A3, A4, B4, B5	
	Туре	OHP: A4, B5	
		Tap paper: A4 LEF, LT LEF	
Folding Methods	6 methods (FM1 to FM6)		



FM1: Z-Folding FM2: Half Fold FM3: Letter Fold-out FM4: Letter Fold-in FM5: Double Parallel Fold

FM6: Gate Fold

d454v900

Paper Sizes (Straight Through)		Postcard to 13 x 19.2 in.
Paper Sizes & Weight (Folding)	FM1	A3, B4, DLT, LG, A4, LT, 12x18", 8-kai
	FM2	A3, B4, DLT, LG, A4, B5, LT 12x18", 12.6x18.5", 12.6x19.2", 13x18", 13x19", 13x19.2", 226x310 mm, 310x432 mm, SRA3, SRA4, 8-kai (64 to 105 g/m²)
	FM3	
	FM4	A3, B4, DLT, LG, A4, LT, B5, 12x18", 8-kai
	FM5	(64 to 80 g/m²)
	FM6	
Multiple Folding	FM1	Not allowed
	FM2	Max. 3 (64 to 80 g/m <sup>2</sup> only)
	FM3	Max. 3 (64 to 80 g/m <sup>2</sup> only)
	FM4	Max. 3 (64 to 80 g/m <sup>2</sup> , B4, A4, LT, B5 only)
	FM5	
	FM6 Not allowed	

No Fold	350 mm/sec. to to		machine.		
FM1	700 mm/sec. to top tray (paper < 355.6 mm long) 450 mm/sec. to top tray (paper < 355.6 mm long)				
	To downstream: Same as main machine.				
	1 Sheet: Same as m	nain machine			
	2-3 Sheets: 454 mi				
FM2	700 mm/sec. to to	·	er <355.6 m	nm long)	
	350 mm/sec. to to			-	
	250 mm/sec. to to	p tray (pape	er < 279.4	mm long)	
	1 Sheet: Same as m	nain machine	 e		
FM3	2-3 Sheets: 454 mi	m/sec. to to	p tray		
FM4	350 mm/sec. to to	p tray (pape	er < 420 mr	m long)	
	250 mm/sec. to to	p tray (pape	er < 420 mr	m long)	
	1 Sheet: Same as n	nain machine	Э		
FM5	350 mm/sec. to to	p tray (pape	er < 420 mr	m long)	
	250 mm/sec. to to	p tray (pape	er < 420 mr	m long)	
	1 Sheet: Same as n	nain machine	e as far as	3rd Stopper. At 3rd sto	pper feeds 50 mm at
FM6	100 mm/sec.				
17410	350 mm/sec. to to	p tray (pape	er < 420 mr	m long)	
	250 mm/sec. to to	p tray (pape	er < 420 mr	m long)	
Power Supply		NA	AC 120V	60 Hz, 2.0A	
		EU	AC 220 t	o 240V, 50/60 Hz 1.	2A
Power Consur	nption	270 W			
Size (w x d x l	n)	470 x 1000 x 730 mm (18.5 x 39.4 x 28.7 in.)			
Level		Less than 5 mm deviation at front/back, left/right			
Weight		92 kg (20	3 lb)		
Noise Level (c	IB A)	Mode		Alone	System
		No Folding	9	< 72 dB	


Folding < 72 dB < 76 dB		Foldina	< 72 dB	< 76 dB
-------------------------	--	---------	---------	---------

## **Tray Capacity**


The capacity of the tray on top of the unit for folded paper is determined by these variables:

- Folding Methods (FM1 to FM6)
- Paper size
- Paper weight


#### Folding Mode FM1




Size	Weight (Standard) 64 to 80 g/m <sup>2</sup>	Weight (Heavy) 64 to 80 g/m <sup>2</sup>
8-kai	35	20
12x18"	35	20
A3 SEF	35	20
DLT	35	20
B4 SEF	35	20
LG SEF	35	20
A4 SEF	30	20
LT SEF	30	20



Size	Weight (Standard) 64 to 80 g/m <sup>2</sup>	Weight (Heavy) 64 to 80 g/m <sup>2</sup>
13x19.2"	40	25
13x19"	40	25
12.6x19.2"	40	25
12.6x18.5"	40	25
13x18"	40	25
SRA3 (320x450 mm)	40	25
SRA4 (225x320 mm)	40	25
226x310 mm	40	25
310x432 mm	40	25
8-kai	40	25
12x18"	40	25
A3 SEF	40	25
DLT	40	25
B4 SEF	40	25
LG SEF	40	25
A4 SEF	50	50
LT SEF	50	50
B5 SEF	50	50






Size	Weight (Standard) 64 to 80 g/m <sup>2</sup>	Weight (Heavy) 64 to 80 g/m <sup>2</sup>
8-kai	40	20
12x18"	40	20
A3 SEF 40 20		20
DLT	40	20
B4 SEF	40	20
LG SEF	40	20
A4 SEF	50	40
LT SEF	50	40


1

Size	Weight (Standard) 64 to 80 g/m <sup>2</sup>	Weight (Heavy) 64 to 80 g/m <sup>2</sup>
B5 SEF	50	40

## Folding Mode FM5



Size	Weight (Standard) 64 to 80 g/m <sup>2</sup>	Weight (Heavy) 64 to 80 g/m <sup>2</sup>
8-kai	30	20
12x18"	30	20
A3 SEF	A3 SEF 30 20	
DLT	30	20
B4 SEF	30	20
LG SEF	30	20
A4 SEF	30	30
LT SEF	30	30
B5 SEF	30	30



Size	Weight (Standard) 64 to 80 g/m <sup>2</sup>	Weight (Heavy) 64 to 80 g/m <sup>2</sup>
8-kai	50	20
12x18"	50	20
A3 SEF	3 SEF 50 20	
DLT	50	20
B4 SEF	50	20
LG SEF	50	20
A4 SEF	30	30
LT SEF	30	30
B5 SEF	30	30

## Booklet Finisher SR5040/5030 (D512/D513)

#### General

Operating Environment	Temperate	Temperature and humidity ranges: Same as main machine.			
Service Life	Expected:	Expected: Five years or 60,000K			
Size (w x h x d)	996 x 73	0 x 1125 m	ım (39.2 x 28.7 x 44.	3 in.)	
Weight	Finisher D	Finisher D512 (Booklet Stapling) 130 kg (286 ib.)			
	Finisher D	Finisher D513 (Corner Stapling Only) 112 kg (246.4 lb.)			
	NA	AC 120V 50/60 Hz, 2.5A			
Power Supply	EU	AC 220 to 240V, 50/60 Hz 1.2A			
Power Consumption	250 W	250 W			
Level	Less than	Less than 5 mm deviation at front/back, left/right			
Noise Level (dB A)	Mode		Alone	System	
	Shift		< 76 dB		

Staple < 78 dB < 83 dB	
------------------------	--

## **Shift Tray**

	Unfolded Paper	3000	D513: A4 LEF, B5 LEF, LT LEF	
		2500	D512: A4 LEF, B5 LEF, LT LEF	
		1500	A3, A4 SEF, B4, B5 SEF, LT, LG, LT SEF, SRA4, 226x310 mm	
Capacity		1000	12x18", SRA3, 13x18", 12.6x1.5", 12.6x19.2", 13x19", 13x19.2", 310x432 mm	
		500	A5 LEF, HLT LEF	
		100	A5 SEF, HLT SEF	
	Z-Folded Paper	30		
D 6:	Unfolded Paper	A5 to 13x19.2"		
Paper Size	Z-Folded Paper	A3, B4, A	4 SEF, DLT, LG LT SEF, 12x18", 8-kai	
Paper Weight	Unfolded Paper	40 to 300 g/m <sup>2</sup>		
	Z-Folded Paper	64 to 105 g/m <sup>2</sup>		

## **Proof Tray**

Capacity	Unfolded Paper	250	A4, LT or smaller	
		50	B4, LG or larger	
	Z-Folded Paper	20	A4, LT or smaller	
		30	B4, LG or larger	
Paper Size	Unfolded Paper	A6 SEF to 13x19.2", Postcard SEF		
raper Size	Z-Folded Paper	A3, B4, A4 SEF, DLT, LG, LT SEF, 12x18", 8-kai		
Paper Weight	Unfolded Paper	52 to 216 g/m <sup>2</sup>		

Z-Folded Paper 6	64 to 105 g/m <sup>2</sup>
------------------	----------------------------

## **Corner Stapling**

	Unfolded Dones	2 to 100	A4, B5, LT (80g/m <sup>2</sup> )	
	Unfolded Paper	2 to 50	A3, B4, DLT, LG	
		10		
		Co	ombined Stack	
		Z-Folded	Unfolded	
		1	1 to 90	
		2	0 to 80	
Stack Size (80 g/m²)		3	0 to 70	
	Z-Folded Paper	4	0 to 60	
		5	0 to 50	
		6	0 to 40	
		7	0 to 30	
		8	0 to 20	
		9	0 to 10	
		10	0	
Paper Size	Unfolded Paper	B5 to A3, DLT to	o LT	
	Z-Folded Paper	A3, B4, DLT		
Paper Weight	Unfolded Paper	64 to 80 g/m <sup>2</sup>		
	Z-Folded Paper	64 to 105 g/m <sup>2</sup>		
Stapling Positions	1 Staple: Rear, Rear diagonal, or Front 2 Staples: Front/Rear			
Staple Supply	Cartridge with 5000-staple capacity			
Tray Capacity After Stapling				

	Pages	Stacks	Size
	20 to 100	125 to 25*1	
	20 to 100	50 to 30*2	A4 LEF, B5 LEF, LT LEF
	10 to 19	200 to 105	A4 LEF, B3 LEF, L1 LEF
No Folding	2 to 9	150	
	10 to 100	150 to 15	A A CEE DE CEE LE CEE
	2 to 9	150	A4 SEF, B5 SEF, LT SEF
	10 to 50	150 to 30	A2 D4 DIT IC
	2 to 9	150	A3, B4, DLT, LG

**<sup>\*1</sup>**: D512

**<sup>\*2</sup>**: D513

	Pages	Stacks	Size
	2 to 50	30	A3/A4 LEF
No Folding, Mixed Sizes			B4/B5 LEF
	2 10 30	30	DLT/LT LEF
			8-Kai/16-Kai
	Pages	Stacks	Size
Z-Folded, Mixed with	1 to 10	30 to 3	A3 Z-fold/A4
Unfolded			B4 Z-fold/B5
			DLT Z-fold/LT
			8-Kai/16-Kai
Staple Trimming	Hopper Capacity		15,000 staples
	Hopper Full Alert		Photo-sensor
	Trimming Disposal		Alert, operator

D512 RTB 3

## **Booklet Stapling**

New information added to the specifications

Stack Size	20	64 to 80 g	g/m <sup>2</sup>	
	15	80 to 90 g	g/m <sup>2</sup>	
Paper Size	SRA3 (3	20x450 mr	12.6x19.2", 12.6x1 n), 12x18", A3, B4, S 310 x 432 mm, A4,	SRA4 (320 x 225
Paper Weight	64 to 90	$g/m^2$		
Stapling Positions	2 staples	2 staples, 2 fixed locations		
Staple Supply	2 cartrid	2 cartridges, 5000 staples each		
	Po	ıges	Stacks	Size
	2	to 5	30	
Tray Capacity After Stapling	6 t	o 10	15	All sizes
	11	to 15	10	All sizes
	16	to 20	5	

## Punch Unit PU5000 (D449) (Option)

This punch unit is not pre-installed in the finisher. The punch unit must be installed.

Punching	NA	2/3 hole selectable
	EU/AP	2/4 hole selectable
	Scandinavia	4 hole
Skew Correction	Yes	
Paper Registration	Yes	

	Holes	Edge	Size
		SEF	A6 to A3, HLT to DLT
	2 Holes	LEF	A5 to A4, HLT to LT
	NIA 0 11 1	SEF	A6 to A3, HLT to DLT
	NA 2 Holes	LEF	A5 to A4, HLT to LT
Paper Size	2 11-1	SEF	A3, B4, DLT
	3 Holes	LEF	A4, B5, LT
	EU 4 Holes	SEF	A3, B4, DLT
		LEF	A4, B5, LT
	Scn 4 Holes	SEF	B6 to A3, HLT to DLT
		LEF	A5 to A4, HLT to LT
	Holes	Weight	
	2 Holes		
D \A/-: - l. 4	NA 2 Holes	$52 \text{ to } 209 \text{ g/m}^2$	
Paper Weight	3 Holes		
	EU 4 Holes	$52 \text{ to } 209 \text{ g/m}^2$	
	Scn 4 Holes		

# 2. Appendix: Service Program Mode Tables

# Group 1000

1001	Lead Edge Reg		
	Adjusts the printing leading edge registration using the trimming area pattern SP2109-3 (Pattern No. 14)		
	Setting	Weight	Default
1	Thick 1	52.3 - 63.0 g/m <sup>2</sup>	[-3 to 3/0/0.1 mm]
2	Thick 2	63.1 - 80.0 g/m <sup>2</sup>	
3	Thick 3	80.1 - 105.0 g/m <sup>2</sup>	
4	Thick 4	105.1 - 163.0 g/m <sup>2</sup>	
5	Thick 5	163.1 - 220.0 g/m <sup>2</sup>	
6	Thick 6	220.1 - 256.0 g/m <sup>2</sup>	
7	Thick 7	256.1 - 300.0 g/m <sup>2</sup>	

1002	Fine Adj LEdge		
	Fine adjusts leading edge registration for thick paper trace paper and thick paper (Thick 2, Thick 3)		
	Setting	Weight	Default
1	Trace		[-9 to 0/0/0.1 mm]
2	Thick 2	63.1 - 80.0 g/m <sup>2</sup>	
3	Thick 3	80.1 - 105.0 g/m <sup>2</sup>	

1003	Side-to-Side Reg
	Adjusts printing side-to-side registration for each feed station, using the test pattern printed with SP2109-3 (Pattern No. 14) These SP's should be adjusted after replacing the laser synchronization detector or the laser optical unit.

1	Tray1	[-3 to +3/0/0.1 mm]
2	Tray2	
3	Dupx Tray	
4	A3LCT Tray3	
5	A3LCT Tray4	
6	A3LCT Tray5	
7	Bypass Tray	

1004	Reg Buckle Adj	
	Adjusts the registration motor timing. This timing determines the amount of paper buckle at registration. (A higher setting causes more buckling.)	
1	Tray1 & Tray2	[-5to+5/0/1 mm]
2	Dupx Tray	
3	A3LCT & Bypass Tray	

1005	Reg Buckle Adj(Thick)		
	Adjusts the registration motor timing for thick paper only. This timing determines the amount of paper buckle at registration. (A higher setting causes more buckling.)		
	Setting	Weight	Default
1	Thick 5	163.1 - 220.0 g/m <sup>2</sup>	[-5 to +5/1/1 mm]
2	Thick 6	220.1 - 256.0 g/m <sup>2</sup>	
3	Thick 7	256.1 - 300.0 g/m <sup>2</sup>	

1006	Fine Adj Transfer Tmg Roller Spd
	Fine adjusts the speed of the transfer timing roller for the paper type and weight. The transfer timing roller drives the transfer timing rollers that feed paper from the registration unit to the PTR unit.
	If the paper is late, the machine speeds the rollers up.
	If the paper is early, the machine slows the rollers down.

	Thickness	Weight (g/m2)	
	1	52.3 - 63.0 g/m <sup>2</sup>	
	2	63.1 - 80.0 g/m <sup>2</sup>	
	3	80.1 - 105.0 g/m <sup>2</sup>	
	4	105.1 - 163.0 g/m <sup>2</sup>	
	5	163.1 - 220.0 g/m <sup>2</sup>	
	6	220.1 - 256.0 g/m <sup>2</sup>	
	7	256.1 - 300.0 g/m <sup>2</sup>	
1 to 7	Plain: Weight 1 to	7	[-3 to +3/*/0.1%]
8 to 13	Matte: Weight 2 t	o 7	
14 to 19	Glossy: Weight 2 to 7 Envelope: Weight 5 to 7		The default settings (*) are displayed
20 to 22			to the right of "Initial" on the screen.
23	ОНР		

1007	Fine Adj Invert	Changes the speed of the exit relay motor to adjust the speed of the invert entrance rollers. The invert entrance rollers are the first rollers in the paper path below the exit junction where paper is fed into the vertical path in the left drawer for inverting and duplexing.		
	rollers. The inv			
	Thickness Weight (g/m2)			
	1	52.3 - 63.0 g/m <sup>2</sup>		
	2	63.1 - 80.0 g/m <sup>2</sup>		
	3	80.1 - 105.0 g/m <sup>2</sup>		
	4	105.1 - 163.0 g/m <sup>2</sup>		
	5	163.1 - 220.0 g/m <sup>2</sup>		
	6	220.1 - 256.0 g/m <sup>2</sup>		
	7	256.1 - 300.0 g/m <sup>2</sup>		

1 to 7	Plain: Weight 1 to 7	[-3 to +3/*/0.1%]
8 to 13	Matte: Weight 2 to 7	The default settings (*) are displayed to the right of "Initial" on
14 to 19	Glossy: Weight 2 to 7	the screen.

1008	Fine Adj Exit/Inve	Fine Adj Exit/Invert Roll Spd		
	invert exit rollers.	Changes the speed of the invert/exit motor to adjust the speed of the first pair of nvert exit rollers. The invert exit rollers are the first rollers in the vertical paper path above the invert junction gate on the far side of the left drawer where paper starts to exit the machine.		
	Thickness	Weight (g/m2)		
	1	52.3 - 63.0 g/m <sup>2</sup>		
	2	63.1 - 80.0 g/m <sup>2</sup>		
	3	80.1 - 105.0 g/m <sup>2</sup>		
	4	105.1 - 163.0 g/m <sup>2</sup>		
	5	163.1 - 220.0 g/m <sup>2</sup>		
	6	220.1 - 256.0 g/m <sup>2</sup>		
	7	256.1 - 300.0 g/m <sup>2</sup>		
1 to 7	Plain: Weight 1 to	7	[-3 to +3/*/0.1%]	
8 to 13	Matte: Weight 2	to 7	The default settings (*) are displayed to the right of "Initial" on	
14 to 19	Glossy: Weight 2 to 7		the screen.	

1009	Fine Adj Duplex/Invert Roll Spd		
	Changes the speed of the duplex/invert motor to adjust the speed of the duplex invert rollers. The duplex invert rollers feed the paper up into the first set of rollers in the duplex tray.		
	Thickness Weight (g/m2)		
	1	52.3 - 63.0 g/m <sup>2</sup>	
	2	63.1 - 80.0 g/m <sup>2</sup>	
	3	80.1 - 105.0 g/m <sup>2</sup>	

	7	256.1 - 300.0 g/m <sup>2</sup>	
1 to 7	Plain:Weight 1	to 7	[-3 to +3/*/0.1%]
8 to 13	Matte:Weight 2	2 to 7	The default settings (*) are displayed to the right of "Initial" on
14 to 19	Glossy:Weight 2 7		the screen.

1010	Fine Adj Mtr Speed: High	
	Fine adjusts the speed of the motors for high speed mode (352.8 mm/s).	
1 to 4	K, C, M, Y Drum Motor [-3 to +3/0/0.1%]	
5 to 8	K, C, M, Y Dev Motor	
9 to 012	K, C, M, Y Drum CL(leaning) Mtr	
13	ITB Motor	
15	PTR Motor	[-5 to +5/0/0.1%]
29	Fusing Motor	
43	Paper Ejection Motor	
56	Paper Feed Motor	[-5 to +5/0.5/0.1%]

1011	Fine Adj Mtr Speed: Middle		
	Fine adjusts the speed of the motors for middle speed mode (246.96 mm/s).		
1 to 4	K, C, M, Y Drum Motor [-3 to +3/0/0.1%]		
5 to 8	K, C, M, Y Dev Motor		
9 to 012	K, C, M, Y Drum CL(leaning)		
13	ITB Motor		
15	PTR Motor	[-5 to +5/0/0.1%]	
29	Fusing Motor		

43	Paper Ejection Motor	
56	Paper Feed Motor	[-5 to +5/0.5/0.1%]

1012	Fine Adj Mtr Speed: Low	
	Fine adjusts the speed of the motors for low speed mode (246.96 mm/s).	
1 to 4	K, C, M, Y Drum Motor [-3 to +3/0.2/0.1%]	
5 to 8	K, C, M, Y Dev Motor	
9 to 012	K, C, M, Y Drum CL Mtr	
13	ITB Motor	
15	PTR Motor	[-5 to +5/0/0.1%]
29	Fusing Motor	
43	Paper Ejection Motor	
56	Paper Feed Motor	[-5 to +5/0.5/0.1%]

1013	Fine Adj Exit Moto	Fine Adj Exit Motor Speed	
	Fine adjusts the speed of exit motor for the type of weight of the paper. The exit motor drives the drives the rollers in the paper cooling unit, the second pair of invert exit rollers, and the exit rollers.		
	Thickness	Weight (g/m2)	
	1	52.3 - 63.0 g/m <sup>2</sup>	
	2	63.1 - 80.0 g/m <sup>2</sup>	
	3	80.1 - 105.0 g/m <sup>2</sup>	
	4	105.1 - 163.0 g/m <sup>2</sup>	
	5	163.1 - 220.0 g/m <sup>2</sup>	
	6	220.1 - 256.0 g/m <sup>2</sup>	
	7	256.1 - 300.0 g/m <sup>2</sup>	
1 to 7	Plain:Weight 1 to	7	[-5 to +5/0/0.1%]

8 to 13	Matte: Weight 2 to 7	
14 to 19	Glossy: Weight 2 to 7	
20 to 22 Envelope: Weight 5 to 7		
23	OHP	

1020	Adjust Air DUTY	
	Adjusts the strength of the air flow of the fans in the LCIT. The side and front fans are used to assist paper separation by blowing air across the surface of the first sheet in the stack of paper in the tray.	
1	Suction Air	[0 to 100/100/5%]
2	Side Air	
3	Front Air	

1021	Skew Detect	
	This SP switches skew detection off/on for each paper feed station in the system and the duplex tray.	
1	Tray1	[0 to 1/1/1] 1: ON, 0: OFF
2	Tray2	
3	Dupx Tray	
4	A3LCT Tray3	
5	A3LCT Tray4	
6	A3LCT Tray5	
7	Bypass Tray	

1022	PTR Trans Lift Timing
	Sets the timing for opening and closing the nip of the bias roller and PTR (Paper Transfer Roller). When thick paper is fed the PTR separation motor raises the bias roller away from the PTR so the paper can feed easily into the gap between the rollers. This operation minimizes the "shock jitter" effect with thick paper sizes.

1	Contact	[-30 to +30/0/1 ms]	
2	Separate	[-150 to +20/-70/1 ms]	RTB 4e (D074, ver 1.60:04) Default changed to -120

1023	Shock Jitter Canceling Mode
	Switches the shock jitter mode off and on. When the machine is in shock-jitter mode, the PTR separation motor opens the nip between the bias roller above the paper and the paper transfer roller below to allow thick paper to feed between these rollers.
	[0 to 1/1/1] 1: ON, 0: OFF

1101	Reload Permit Setting	
	Sets the temperature where the fusing motor starts to rotate.	
1	Pre-rotation Start Temp.	[0 to 200/0/1 deg]
2	Reload Target Temp.:Center	[0 to 200/165/1 deg]
3	Reload Target Temp.:Press	[0 to 200/90/1 deg]
4	Temp.:Delta:Cold:Center	[0 to 200/5/1 deg]
5	Temp.:Delta:Cold:End	[0 to 200/5/1 deg]
6	Temp.:Delta:Cold:Press:Center	[0 to 200/20/1 deg]
7	Rotation Time:Cold	[0 to 500/280/1 deg]
8	Temp.:Delta:Warm:Center	[0 to 200/5/1 deg]
9	Temp.:Delta:Warm:End	[0 to 200/5/1 deg]
10	Temp.:Delta:Warm:Press:Center	[0 to 200/10/1 deg]
11	Rotation Time:Warm	[0 to 200/15/1 deg]
12	Temp.:Delta:Hot:Center	[0 to 200/5/1 deg]
13	Temp.:Delta:Hot:End	[0 to 200/5/1 deg]
14	Temp.:Delta:Hot:Press:Center	[0 to 200/20/1 deg]
15	Rotation Time:Hot	[0 to 100/0/1 deg]
16	Temp Diff at Press Roller Ends: Cool	[0 to 200/20/1 deg]

17	Temp Diff at Press Roller Ends: Warm	[0 to 200/20/1 deg]
18	Temp Diff at Press Roller Ends: Hot	[0 to 200/20/1 deg]
20	Roll Core Temp Judgment	
	[0 to 1/1/1] 0: Metal Core Temp Detection On 1: Metal Core Tempt Detection Off	
21	Roll Core Temp	[0 to 120/30/1 deg]

1102	Feed Permit Setting	
	Adjusts the start timing of paper feed. Once the machine grants permission for the start timing, it checks the temperature once again to determine the actual start timing.	
1	P Feed Permit Time	[0 to 500/180/1 sec]
10	Temp Diff Heating Roller: Lower 1	[0 to 60/15/1 deg]
10	Temp Diff Heating Roller: Upper 1	[0 to 60/60/1 deg]
10	Temp Diff Press Roller: Lower 1	[0 to 60/15/1 deg]
10	Temp Diff Press Roller: Upper 1	[0 to 60/20/1 deg]
10	Rotation Time Before Judgment: 1	[0 to 100/0/1 sec]
10	Temp Diff Heating Roller: Lower 2	[0 to 60/10/1 deg]
10	7 Temp Diff Heating Roller: Upper 2	[0 to 60/60/1 deg]
10	Temp Diff Press Roller: Lower 2	[0 to 60/10/1 deg]
10	7 Temp Diff Press Roller: Upper 2	[0 to 60/15/1 deg]
11	Rotation Time Before Judgment:2	[0 to 100/3/1 sec]
11	Temp Diff Heating Roller: Lower 3	[0 to 60/5/1 deg]
11:	Temp Diff Heating Roller: Upper 3	[0 to 60/60/1 deg]
11:	Temp Diff Press Roller: Lower 3	[0 to 60/10/1 deg]
11.	Temp Diff Press Roller: Upper 3	[0 to 60/10/1 deg]

Rotation Time Before Judgment:3		[0 to 100/4/1 sec]
Temp Diff Heat	ing Roller: Lower 4	[0 to 60/20/1 deg]
Temp Diff Heating Roller: Upper 4		[0 to 60/20/1 deg]
Temp Diff Press Roller: Lower 4		[0 to 60/20/1 deg]
Temp Diff Press	Roller: Upper 4	[0 to 60/60/1 deg]
Rotation Time B	efore Judgment:4	[0 to 100/0/1 sec]
Temp Diff Heat	ing Roller: Lower 5	[0 to 60/15/1 deg]
Temp Diff Heat	ing Roller: Upper 5	
Temp Diff Press	Roller: Lower 5	[0 to 60/20/1 deg]
Temp Diff Press	Roller: Upper 5	[0 to 60/60/1 deg]
Rotation Time B	efore Judgment:5	[0 to 100/0/1 sec]
Temp Diff Heat	ing Roller: Lower 6	[0 to 60/5/1 deg]
Temp Diff Heating Roller: Upper 6		[0 to 60/10/1 deg]
Temp Diff Press Roller: Lower 6		[0 to 60/10/1 deg]
Temp Diff Press Roller: Upper 6		[0 to 60/60/1 deg]
Rotation Time B	efore Judgment:6	[0 to 100/5/1 sec]
Thickness	Weight (g/m²)	
1	52.3 - 63.0 g/m <sup>2</sup>	
2	63.1 - 80.0 g/m <sup>2</sup>	
3	80.1 - 105.0 g/m <sup>2</sup>	
4	105.1 - 163.0 g/m <sup>2</sup>	
5	163.1 - 220.0 g/m <sup>2</sup>	
6	220.1 - 256.0 g/m <sup>2</sup>	
7	256.1 - 300.0 g/m <sup>2</sup>	
Normal: Full Siz	ze: Category 1	[0 to 100/50/ 1 deg]
Normal: Full Siz	ze: Category 2	[0 to 100/50/ 1 deg]
	Temp Diff Heating Temp Diff Press Rotation Time Bottom Diff Press Temp Diff Press Rotation Time Bottom Diff Press Temp Diff Press Rotation Time Bottom Diff Press Rotation Time Bottom Diff Press Rotation Time Bottom Diff Press Temp Diff Press Temp Diff Press Rotation Time Bottom Diff Pr	Temp Diff Heating Roller: Lower 4  Temp Diff Press Roller: Lower 4  Temp Diff Press Roller: Upper 4  Rotation Time Before Judgment:4  Temp Diff Heating Roller: Lower 5  Temp Diff Heating Roller: Upper 5  Temp Diff Press Roller: Lower 5  Temp Diff Press Roller: Upper 5  Rotation Time Before Judgment:5  Temp Diff Press Roller: Upper 5  Rotation Time Before Judgment:5  Temp Diff Heating Roller: Lower 6  Temp Diff Press Roller: Upper 6  Temp Diff Press Roller: Upper 6  Rotation Time Before Judgment:6  Thickness Weight (g/m²)  1 52.3 - 63.0 g/m²  2 63.1 - 80.0 g/m²  3 80.1 - 105.0 g/m²  4 105.1 - 163.0 g/m²  5 163.1 - 220.0 g/m²  6 220.1 - 256.0 g/m²

152	Normal: Full Size: Category 3	[0 to 100/25/1 deg]
153	Normal: Full Size: Category 4	[0 to 100/25/ 1 deg]
154	Normal: Full Size: Category 5	[0 to 100/30/ 1 deg]
155	Normal: Full Size: Category 1	
156	Normal: Full Size: Category 2	
157	Normal: Full Size: Category 3	
158	Normal: Full Size: Category 4	
159	Normal: Full Size: Category 5	
160	Output Priority: Full Size: Category 1	[0 to 200/50/1 deg]
161	Output Priority: Full Size: Category 2	[0 to 200/50 deg]
162	Output Priority: Full Size: Category 3	[0 to 200/35 deg]
163	Output Priority: Full Size: Category 4	[0 to 200/30/ deg]
164	Output Priority: Full Size: Category 5	
165	Output Priority: Full Size: Category 1	
166	Output Priority: Full Size: Category 2	
167	Output Priority: Full Size: Category 3	
168	Output Priority: Full Size: Category 4	
169	Output Priority: Full Size: Category 5	
201 to 207	Normal: Uncoated Thick 1 to 7	
209 to 214	Normal: Matte Thick 2 to 7	[] 4- 4 /* /] 4 ]
216 to 221	Normal: Glossy Thick 2 to 7	[1 to 6/*/1 step] The default settings are
222 to 228	Output Priority: Uncoated Thick 1 to 5	displayed to the right of "Initial" on the screen.
230 to 235	Output Priority: Matte Thick 2 to 7	initial on the screen.
237 to 242	Output Priority: Glossy Thick 2 to 5	
	-	<del></del>

1106	Fusing Temp. Display
------	----------------------

	Displays the present fusing temperature at different locations on the heating roller, pressure roller, hot roller, and hot roller core.
1	Heating Roller Center
2	Heating Roller Ends
4	Heating Roller Rear
5	Pressure Roller Center
6	Pressure Roller Ends
7	Hot Roller
8	Hot Roller Core

1107	Standby Target Temp. Setting	
	Sets the target standby temperature for the modes listed below.	
1	Standby: Center [0 to 200/175/1 deg[	
2	Standby: Press	[0 to 200/90/1 deg]
3	Preheat: Center [0 to 200/175/1 deg]	
4	Preheat: Press [Oto 200/90/1 deg]	
5	Low Power: Center [0 to 200/100/1 deg]	
6	Low Power: Press [0 to 200/90/1 deg]	
7	Print Ready: Center [0 to 200/165/1 deg]	
8	Print Ready: Press	[0 to 200/90/1 deg]

1108	After Reload/Job Target Temp.		
	Sets the target temperature for immediately after reload temperature has been achieved or paper has been fed. "Center" is the center of the heating roller, and "Press" is the pressure roller.		
1	Center [0 to 200/165/1 deg]		
2	Press [0 to 200/90/1 deg]		

1111	Environment Correction: Fusing		
	Sets the threshold for fusing temperature correction to compensate for ambient conditions.		
1	Temp.: Threshold: Low [0 to 100/17/1 deg]		
2	Temp.: Threshold: High	[0 to 100/30/1 deg]	
3	Low Temp. Correction	[0 to 100/10/1 deg]	
4	High Temp. Correction	[0 to 100/5/1 deg]	
5	Job Low Temp. Correction	[0 to 100/15/0.1 deg]	
6	Job High Temp. Correction	[0 to 100/0/0.1 deg]	
7	Job Low Temp. Correction: Sp.	[0 to 100/15/0.1 deg]	
8	Job High Temp. Correction: Sp.	[0 to 100/0/0.1 deg]	

1114	Heat Storage Status		
	Sets the threshold for fusing temperature correction to compensate for heat accumulated on the pressure roller.		
1	Temp.: Threshold: Press [0 to 200/60/1 deg]		
2	Temp.: Threshold: Atmosphere	[0 to 200/60/1 deg]	

1115	Target Temp. Correction		
	Corrects the temperature based on the difference in the target temperatures of the center and end of the hot roller.		
1	Temp.: Delta: Heat: End [-100 to +100/5/1 deg]		
2	Temp.: Delta: Press: End	[-100 to +100/0/1 deg]	
3	Temp.: Delta Sub	[0 to +100/3/1 deg]	
5	Temp.: Delta Heat End: Reload	[-100 to +100/5/1 deg]	
6	Temp.: Delta Heat End: Prefeed	[-100 to +100/5/1 deg]	
7	Temp.: Delta Heat Full Size: Reload	[-100 to +100/-10/1 deg]	
8	Temp.: Delta Heat Full Size: Prefeed	[-100 to +100/-15/1 deg]	

1116	Skew Correction Level Setting	
	Sets the amount of skew correction for paper fed from each paper source.	
1	Tray1 [1.6 to 7.5/3/0.1 mm]	
2	Tray2	
3	Dupx Tray	
4	A3LCT Tray3	
5	A3LCT Tray4	
6	A3LCT Tray5	
7	Bypass Tray	

1117	Time Control	
	Adjust the amount of time for timeout.	
1	Control Time 1	[0 to 1000/100/1 sec]
2	Control Time2	[0 to 1000/400/1 sec]
3	Temp:A:Center l	[-20 to 20/0/1 deg]
4	Temp: A: End 1	
5	Temp:A:Center2	
6	Temp: A: End 3	
7	Temp:B:Center1	
8	Temp: B: End 1	
9	Temp:B:Center2	
10	Temp: B: End 2	[-20 to +29/-5/1 deg]
11	Temp.: C: Center 1	[-20 to +29/0/1 deg]
12	Temp.: C: End 1	[-20 to +29/-5/1 deg]
13	Temp.: C: Center 2	[-20 to +29/0/1 deg]
14	Temp.: C: End 1	[-20 to +29/-5/1 deg]

15	Temp.: D: Center 1	[-20 to +29/0/1 deg]
16	Temp.: D: End 1	
17	Temp.: D: Center 2	
18	Temp.: D: End 2	[-20 to +29/-3/1 deg]
101 to 107	Category 1: Weight 1 to 7	[1 to 4/*/1 step]
111 to 117	Category 2: Weight 1 to 7	
121 to 127	Category 3: Weight 1 to 7	The default settings are displayed to the
131 to 137	Category 4: Weight 1 to 7	right of "Initial" on the screen.
141 to 147	Category 5: Weight 1 to 7	

1118	Norm Paper: Init Temp Calc		
	Adjusts the start timing from the standard trigger time for operation mode and paper type.		
1	Start Time: Nor	mal Speed	[0 to 5/0/0.1 sec]
2	Start Time: Med	dium Speed	[0 to 5/1/0.1 sec]
3	Start Time: Low	Speed	[0 to 5/3.5/0.1 sec]
4	Continuous Tim	e: Normal Speed	[0 to 50/10/0/1 sec]
5	Continuous Time: Medium Speed		
6	Continuous Tim	e: Low Speed	
	Thickness	Weight (g/m2)	
	1	52.3 - 63.0 g/m <sup>2</sup>	
	2	63.1 - 80.0 g/m <sup>2</sup>	
	3	80.1 - 105.0 g/m <sup>2</sup>	
	4	105.1 - 163.0 g/m <sup>2</sup>	
	5	163.1 - 220.0 g/m <sup>2</sup>	
	6	220.1 - 256.0 g/m <sup>2</sup>	

	7	256.1 - 300.0 g/m <sup>2</sup>	
11	Added Temp: Thickness 1		[0 to 30/5/1 deg]
12	Added Temp: Thickness 2		[0 to 30/5/1 deg]
13	Added Temp: T	hickness 3	[0 to 30/10/1 deg]
14	Added Temp: Thickness 4		[0 to 30/10/1 deg]
15	Added Temp: Thickness 5		[0 to 30/15/1 deg]
16	Added Temp: Thickness 6		
17	Added Temp: Thickness 7		

1119	Norm Paper: Init Temp: Calc2		
	Adjusts fusing temperature for the core temperature of the hot roller.		
1	Continuous Time: Normal: Spd [0 to 50/10/1 sec]		
2	Continuous Time: Medium: Spd [0 to 50/11/1 sec]		
3	Continuous Time: Low: Spd	[0 to 50/13.5/1 sec]	
11	Added Temp: Thickness 1 [0 to30/10/1 deg]		
12	Added Temp: Thickness 2		
13	Added Temp: Thickness 3		
14	Added Temp: Thickness 4		
15	Added Temp: Thickness 5 [0 to 30/20/1 deg]		
16	Added Temp: Thickness 6		
17	Added Temp: Thickness 7		

1121	Switch: Rotation Start/Stop		
	Sets the time interval for the shift from reload temperature to standby temperature.		
1	Time:After Reload [0 to 999/300/1 sec]		
2	Time:After Recovery	[0 to 100/10/1 sec]	
3	Time:After Job	[0 to 100/30/1 sec]	

4	Press Temp.:After Reload	[0 to 160/160/1 deg]
5	End Uniform Start Temp.:B4	[0 to 250/210/1 deg]
6	End Uniform Start Temp.:A4	
7	End Uniform Start Temp.:A5	
8	Overshoot Prevent Temp.	[0 to 250/215/1 deg]
9	Overshoot Prevent Time	[0 to 100/20/1 sec]

1122	Standby Rotation Setting	
	Sets the interval between fusing roller idle rotations during standby. Idling the rollers helps to maintain and even fusing temperature.	
1	1 Rotation Interval [0 to 240/0/1 min]	
2	Rotation Time	[0 to 60/0/0.1 sec]

1123	Rotation Speed Setting	
	Sets the speed for the rotation fusing rollers during idling before paper starts to feed.	
	Rotation Speed [0 to 1/1/1]	

1124	CPM Down Setting	
	Sets the temperature differential used to calculate CPM down for low and high temperatures. Also, sets the interval for temperature checks for CPM down.	
1	Low: Down Temp.	[-50 to 0/-8/1deg]
2	Low: Up Temp.	[-50 to 0/-6/1deg]
3	Low:1st CPM	[10 to 100/70/5%]
4	Low :2nd CPM	[10 to 100/50/5%]
5	Low :3rd CPM	[10 to 100/30/5%]
6	High: 1 st CPM	[10 to 100/75/5%]
7	High:2nd CPM	[10 to 100/50/5%]
8	High:3rd CPM	[10 to 100/25/5%]

12	High: 1st CPM Down Temp.:A4	[100 to 250/210/1deg]
13	High:2nd CPM Down Temp.:A4	[100 to 250/215/1deg]
14	High:3rd CPM Down Temp.:A4	[100 to 250/220/1deg]
15	High: 1 st CPM Down Temp.: A5	[100 to 250/220/1deg]
16	High:2nd CPM Down Temp.:A5	[100 to 250/215/1deg]
17	High:3rd CPM Down Temp.:A5	[100 to 250/220/1deg]
18	Judging Interval	[1 to 250/10/1sec]
20	Judging Interval: Normal Speed	[0 to 200/15/1sec]
21	Judging Interval: Medium Speed	
22	Judging Interval: Low Speed	
101	High: 1st CPM Down Timing: Category 1	[100 to 250/215/1
102	High: 2nd CPM Down Timing: Category 2	[100 to 250/217/1
103	High: 3rd CPM Down Timing: Category 3	[100 to 250/225/1
111	High: 1st CPM Down Timing: Category 1	[100 to 250/215/1
112	High: 2nd CPM Down Timing: Category 2	[100 to 250/217/1
113	High: 3rd CPM Down Timing: Category 3	[100 to 250/225/1
121	High: 1st CPM Down Timing: Category 1	[100 to 250/215/1
122	High: 2nd CPM Down Timing: Category 2	[100 to 250/217/1
123	High: 3rd CPM Down Timing: Category 3	[100 to 250/225/1
131	High: 1st CPM Down Timing: Category 1	[100 to 250/215/1
132	High: 2nd CPM Down Timing: Category 2	[100 to 250/217/1
133	High: 3rd CPM Down Timing: Category 3	[100 to 250/225/1
141	High: 1st CPM Down Timing: Category 1	[100 to 250/215/1
142	High: 2nd CPM Down Timing: Category 2	[100 to 250/217/1
143	High: 3rd CPM Down Timing: Category 3	[100 to 250/225/1

1131	Continuous Print Mode Switch	
	Sets the permission for paper to feed.	
	Feed Permit Condition	
	[0 to 1/0/1 Step	
	0: Fusing Quality Mode	
	1: Productivity Mode	

1132	Maximum Duty Switch		
	Switches maximum fixed duty level and power control.		
1	Control Method Switch		
	[0 to 1/1/1 step]		
	0: Fixed Duty		
	1: Power Control		
3	Manual Offset		
	[0 to 4/4/1 step]		
	0: -400 W 1: -300 W 2: -200 W 3: -100 W 4: 0		
11	AC Voltage Value	[0 to 300/0/1]	
12	Judgment Voltage		

1141	Fusing SC Issue Time Info	
	Displays the time when an SC code was issued.	
1	SC Number	[0 to 999/0/1 Step]
2	SC Cause	[0 to 9/0/1 Step]
101	Htg Roller: Ctr Varied Op Temp. 1	[-5 to 280/0/1 deg]
103	Htg Roller: Ctr Compensate Temp. 1	
104	Htg Roller: Ends Varied Op Temp. 1	
106	Htg Roller: Ends Compensate Temp. 1	
107	Htg Roller Rear Temp. 1	

108	Press Roller: Ctr Varied Op Temp. 1
110	Press Roller: Ctr Compensate Temp. 1
111	Press Roller: Ends Temp. 1
112	Hot Roller: Surface Varied Op Temp. 1
114	Hot Roller: Surface Compensate Temp. 1
115	Hot Roller: Roll Core Temp. 1
151	Htg Roller: Ctr Varied Op Temp. 2
153	Htg Roller: Ctr Compensate Temp. 2
154	Htg Roller: Ends Varied Op Temp. 2
156	Htg Roller: Ends Compensate Temp. 2
157	Htg Roller Rear Temp. 2
158	Press Roller: Ctr Varied Op Temp. 2
160	Press Roller: Ctr Compensate Temp. 2
161	Press Roller: Ends Temp. 2
162	Hot Roller: Surface Varied Op Temp. 2
164	Hot Roller: Surface Compensate Temp. 2
165	Hot Roller: Roll Core Temp. 2
201	Htg Roller: Ctr Varied Op Temp. 3
202	Htg Roller: Ctr Detect Temp. 3
203	Htg Roller: Ctr Compensate Temp. 3
204	Htg Roller: Ends Varied Op Temp. 3
206	Htg Roller: Ends Compensate Temp. 3
207	Htg Roller Rear Temp. 3
208	Press Roller: Ctr Varied Op Temp. 3
210	Press Roller: Ctr Compensate Temp. 3
211	Press Roller: Ends Temp. 3

212	Hot Roller: Surface Varied Op Temp. 3	
214	Hot Roller: Surface Compensate Temp. 3	
215	Hot Roller: Roll Core Temp. 3	

Fusing Jam Detection	
This SP displays the SC code that was issued if a fusing unit jam error occurs three times in succession. This is a fatal SC error. The machine is shut down and cannot be used until the problem has been corrected.	
SC Display	
[0 to 1/0/1 Step]	
0: OFF	
1: On	

1151	Pressure Setting	
	Switches on the mode that adjusts the length of time pressure is increased on the fusing roller by the pressure roller. The setting is adjusted with the "position" settings that determine the length of time that the pressure is increased (the longer the time the more pressure).	
1	Pressure Change ON/OFF [0 to 1/1410/1 Step]	
11	Pressure Position 1	[0 to 1000/1410/10 ms]
12	Pressure Position 2	[0 to 1000/0/10 ms]
13	Pressure Position 3	[0 to 1000/30/10 ms]

1152	Fusing Nip Band Check	
	Checks and adjusts the nip of the hot roller and pressure roller.	
1	Execute	

	Use a sheet of OHP to execute this SP. Feed the sheet through fusing unit and between the hot roller and pressure roller. The sheet will stop and remain between the rollers for 30 s and is then feed out. Use a scale to measure the width of the band on the sheet.	
[0 to 1/1/1]		
0: ON		
	1: OFF	
2	Pre-idling Time	[0 to 999/30/1 sec]
3	Stop Time	[0 to 255/120/1 sec]
4	Pressure Position	[0 to 3/2/1]
10	Target Temp: Center	[0 to 200/160/1 deg]
11	Target Temp: Press Roller	[0 to 200/100/1 deg]

1153	Press Roller Cooling Fan	
	Sets the temperature at which the pressure roller cooling fan starts to operate. The pressure roller cooling fan is the large blower fan at the front of the left drawer under the fusing unit.	
001	Startup Difference	[-50 to +50/5/1 deg]
002	Paper Difference	
003	After Paper Difference	

1154	Standby Rotation	
	Sets the start time and duration of hot roller rotation in the standby (Ready) mode.	
1	Rotation Start Temp	[0 to 150/120/1 deg]
2	Rotation Time	[0 to 255/30/1 sec]

1155	Job Cancel	
	Sets the temperature to trigger "Job cancel" during a job.	
1	Press Roller Temp	[100 to 200/200/1 deg]

1161 Fusing Cleaning Web
--------------------------

Determines the operation cycles of the take-up roller which pulls fabric off the web supply roller in the fusing belt cleaning unt.
Duplex Take up Cycle Adj.
[-75 to 0/0/10 %]

1190	Manual New Unit Set	
	Sets the machine to access the fusing unit ID chip information for PM parts management.	
1	Fusing Belt	[0 to 1/1/0]
2	Hot Roller	
3	Pressure Roller	
4	Pressure Roller Bearings	

1206	Paper Shift Setting
	Selects edge shift operation.
	Shift Mode Selection
	[0 to 2/1/1]
	O: Shift
	1: Shift Off (Folding Mode)
	2: Shift: Off

1302	Dbl-Feed Detect	
1	Tray 1	
2	Tray 2	
3	A3LCT Tray3	[0 to 1 / 1 / 1]
4	A3LCT Tray4	0:OFF 1:ON
5	A3LCT Tray5	
6	Bypass Tray	

1303	After Dbl-Feed Det Op Set
------	---------------------------

1	Tray 1	
2	Tray 2	
3	A3LCT Tray3	[0 to 1 / 1 / 1] 0:JAM
4	A3LCT Tray4	1:Purge Tray
5	A3LCT Tray5	,
6	Bypass Tray	

1304	Dbl-Feed Detect Threshold Adj	
	Adjusts the threshold for the translucence of the paper to trigger a double-feed detection based on the type of paper.	
1	Plain	[0 to 100/30/1 %]
2	Translucent	
3	OHP	[0 to 100/5/1 %]

1305	Dbl-Feed Comp Std Value		
	Displays the threshold values for paper that triggered a double-feed detection by paper feed station for the past 5 feeds.		
1 to 5	Tray1:LAST1 to 5		
6 to 9	Tray2:LAST to 5		
11 to 15	A3LCT Tray3:LAST to 5		
16 to 20	A3LCT Tray4:LAST to 5		
21 to 25	A3LCT Tray5:LAST to 5		
26 to 30	Bypass Tray:LAST to 5		

1306	Dbl-Feed Det Light Adj Result	
	Adjusts the strength of the light emitted from the double-feed sensor LED. The double feed sensors are a pair. The sensor below emits an LED, and the sensor above receives the light.	
1	Normal Paper [0 to 94/0/1 mA]	

2	Translucent	
3	OHP	

1310	Dbl-Feed Detect Function		
	Toggles double-feed detection alert on and off.		
1	Disabled Display (0:Off 1:On)	[0 to 1/0/1]	

1401	Paper Pass Time 1:Custom Paper	
1402	Paper Pass Time 1:Average	
1	Fusing Unit	[0 to 999/0/1 ms]
2	Fusing Unit	
3	Fusing Unit	
4	Tray l	
5	Tray l	
6	Tray l	
7	Tray2	
8	Tray2	
9	Tray2	
10	A3LCT Tray3	
11	A3LCT Tray3	
12	A3LCT Tray3	
13	A3LCT Tray4	
14	A3LCT Tray4	
15	A3LCT Tray4	
16	A3LCT Tray5	
17	A3LCT Tray5	
18	A3LCT Tray5	

19	Bypass Tray	
20	Bypass Tray	
21	Bypass Tray	

1403	Paper Pass Time 1:Max/Min Diff	
1	Fusing Unit	[0 to 999/0/1 ms]
2	Fusing Unit	
3	Fusing Unit	

1404	Paper Pass Time 1:Target Var	
1	Tray1	[0 to 999/0/1 ms]
2	Tray1	
3	Tray1	
4	Tray2	
5	Tray2	
6	Tray2	
7	A3LCT Tray3	
8	A3LCT Tray3	
9	A3LCT Tray3	
10	A3LCT Tray4	
11	A3LCT Tray4	
12	A3LCT Tray4	
13	A3LCT Tray5	
14	A3LCT Tray5	
15	A3LCT Tray5	
16	Bypass Tray	
17	Bypass Tray	

## RTB 22 SP1501 added

18	Bypass Tray	
----	-------------	--

1902	Cleaning Web Setting			
	This SP controls the operation of the fusing cleaning unit inside the fusing unit. The cleaning unit employs a web suspended between a supply roller and take-up roller. Between these rollers, a web contact roller keeps the web pressed against the fusing belt to take-up paper dust, toner, etc. from the surface of the belt.			
1	Web Consumption	[0 to 107	7/0/1]	
2	Fusing Web Motor Operation Time	[3.6 to 1	30/16.2/0.1sec]	
	Changes the amount of time that the web motor operates to pull fresh fabric from the supply roller.			
3	Web Motor Rotation Time [0.3 to 3.5/2.8/0.1sec]		.5/2.8/0.1sec]	
4	Web Near End Setting [50 to 100/81/1%]		00/81/1%]	
	Changes the web consumption ratio at which web near end is displayed.			
5	Web End Recording		[0 to 1/0/1]	
6	Web Near End/End Clear		[Execute]	
7	Correction Coeff. <b>DFU</b>		[0 to 2/1.19/0.01]	
8	Take up Rotations After Jam		[0 to 30/10/1]	
10	Sequence for Each Reload		[0 to 30/3.5/0.1 sec]	
11	Rotations After Cold Start		[0 to 30/10/1]	
12	Fixed Operation Time 1		[40 to 70/48/1%]	
13	Fixed Operation Time 2		[71 to 120/62/1%]	
14	Operation Intervals: Med Speed	Operation Intervals: Med Speed		
15	Operation Intervals: Low Speed		[3.6 to 130/32.4/0.1 sec]	
16	Operation Frequency		[1 to 1000/250/1]	
19	Web Counter Clear Recording		[0 to 1/0/1]	

1903	Web Drive Time
------	----------------

	Records and stores for display information about fusing cleaning unit web consumtion.	
1	Web: Total Page Counter	[0 to 999 999 999/0/1sec]
2	Web: Total Motor Rotation Time	[0 to 25.5/0/0.1 sec]
3	Operation Interval Count	[0 to 130/0/0.1sec]
4	Total Operation Rotations	[0 to 999 999 999/3/1Cycle]

1906	De-curler Setting	
	Selects the paper path in the decurl unit (upper or lower) for the paper depending on the paper feed source.	
1	Tray 1: Paper Path Selection	[0 to 5/3/1]
2	Tray2: Paper Path Selection	0: Lower Pass Def
3	A3LCT Tray3: Paper Path Selection	1: Lower Pass 1
4	A3LCT Tray4: Paper Path Selection	2: Lower Pass 2 3: Upper Pass Def
5	A3LCT Tray5: Paper Path Selection	4: Upper Pass 1
6	Bypass Tray: Paper Path Selection	5: Upper Pass 2

1909	Force Send to Purge Tray	
	Forces paper to drop into the purged paper path. Used for testing.	
1	Purge 1 (0: Off, 1: On)	[0 to 1/1/1]

19	10	Paper Bank Temp/Humidity	
		Displays the current temperature and humidity readings for the paper trays inside the main machine.	
	1	Temperature Reading	
	2	Humidity Reading	

1912	CIS LED Power Adjustment
------	--------------------------

Adjust the power level of the CIS that is used to adjust paper registration in the paper registration unit inside the right drawer.

[EXECUTE]

1913	CIS LED Adj. Result Display <b>DFU</b>	
	Displays the result of the adjustment to adjust the level of the CIS LED power (done with SP1912).	
	PWM Duty	

## 1914 CIS P Pass Pixel Display **DFU**

1916	CIS LED Power Magnification	
1	Variable Magnification	[1 to 5/1.52/0.01]
2	Variable Magnification	[1 to 5/2.01/0.01]
3	Variable Magnification	[1 to 5/3.53/0.01]

1917	Side-to-Side Reg Disable	
	Used to disable side-to-side registration in the paper registration unit for a selected paper feed source.	
1	Tray1	[0 to 1/0/1]
2	Tray2	
3	Dupx Tray	
4	A3 LCT Tray3	
5	A3 LCT Tray4	
6	A3 LCT Tray5	
7	Bypass Tray	

1920	LCT Tray Fan Duty Adjustment	
	These SP codes adjust the force of the air blown by the fans during paper separation in the LCIT trays.	

1	A3LCT Tray3	[10 to 100/70/10%]
2	A3LCT Tray4	
3	A3LCT Tray5	

1921	LCT Fan Start Time Setting	
	These SP codes adjust the start timing of the fans during paper separation with the LCIT.	
1	A3LCT Tray3	[1 to 10/3/1 sec]
2	A3LCT Tray4	
3	A3LCT Tray5	

1922	LCT Tray Fan ON/OFF	
	These SP codes adjust the start timing of the fans used for paper separation in the LCIT trays.	
1	A3LCT Tray3	[0 to 2/0/1]
2	A3LCT Tray4	0: Auto Select 1: Force ON 2: Force OFF
3	A3LCT Tray5	

1923	LCT Pickup Assist ON/OFF		
	These SP codes switch the air assist function in the LCIT paper trays off/on.		
1	Tray1	[0 to 2/0/1]	
2	Tray2	0 : AUTO	
3	A3LCT Tray3	1 : ON	
4	A3LCT Tray4	2 : OFF	
5	A3LCT Tray5		
6	Tray6		

1927	De-curl Default: Lower Path
------	-----------------------------

Selects the default position of the decurl roller for the lower path.
[-3 to 3/0/0.1 mm]

1928	De-curl Default: Upper Path	
	Selects the default position of the decurl roller for the upper path.	
	[-3 to 3/0/0.1 mm]	

1929	De-curl Line Speed Adj: Default	
	[-2.5 to +12.5/1/0.5%]	

193	De-curl Line Speed Adjust:Pos. 1	
	[-2.5 to +12.5/4/0.5%]	

1931	De-curl Line Speed Adj:Pos.2
	[-2.5 to +12.5/5/0.5%]

1932	Buffer Pass Unit		
	Sets the length of time for the fans to operate in the unit after the unit returns to standby mode.		
1	Stand-by Setting [0 to 60/1/1 min]		
2	Fan drive Setting [0 to 4/2/1]		
	0: Fan On for All Paper Weights		
		1: Fan On from Paper Weight 3	
	2: Fan On from Paper Weight 4		
	3: Fan On from Paper Weight 5		
	4: Fan Off from All Paper Weights		

1945	Set Cooling Operation		
1	Low Noise Op Switch Temp [0 to 50/20/1]		
2 Normal Op Switch Temp		[0 to 50/35/1]	

	3	High Temp Op Switch Temp	[0 to 50/38/1]
	4	Fan Low Temp Op Temp	[5 to 35/22/1]
	5	Pump Low Temp Op Temp	
	6	Fan Op Off: Y Thermistor	[30 to 50/43/1]
2	7	Fan Op Off Time	[0 to 60/10/1]
	8	Duplex Exhaust Fan: Front: HS	[0 to 100/45/1]
	9	Duplex Exhaust Fan: Front: NS	[0 to 100/90/1]
	10	Duplex Exhaust Fan: Rear: HS	[0 to 100/45/1]
	11	Duplex Exhaust Fan: Rear: NS	[0 to 100/90/1]
	12	Machine Stop Counter	[0 to 999 999/0/1]
	13	Pressure Roller Fan Strength	[0 to 1/1/1] RTB 4b (D074, ver 1.56.1:04) Changed 0: Half Speed 1: Normal Speed
	14	Stop Temperature	
RTB 4c (D074	15 , ver 1.58:04	Recovery Temperature	

SP1945-016 to -018 added

i <u>o -o io added</u>	added		
1950	Image Pos: Sub: Side1		
1951	Image Pos: Sub: Side2		
1952	Image Pos: Main: Side1		
1953	Image Pos: Main: Side 2		
1 to 100	Custom Paper 001 to 100 [-3 to 3/0/0.1 mm]		

1955	Skew Detect	
1 to 100	Custom Paper 001 to 100	[0 to 1/1/1] 0: OFF 1: ON

1956	Dbl-Feed Detect		
1 to 100	Custom Paper 001 to 100	[0 to 1/1/1] 0: OFF 1: ON	

1957	Side-to-Side Reg Disable
. , . ,	olde to olde keg blodble

1 to 100	Custom Paper 001 to 100		[0 to 1/1/1] 0: OFF 1: ON	
1958 Sub Scan Reg Correction Setting				
1 to 100	Custom Paper 001 to 100		[0 to 1/1/1] 0: OFF 1: ON	
1959	Line Speed Adjust: Default Pos			
1 to 100	Custom Paper 001 to 100	[-2.	.5 to +12.5/1/0.5%]	
1960	Line Speed Adjust:Pos. 1			
1 to 100	Custom Paper 1 to 100	[-2.	.5 to +12.5/4/0.5%]	
1961	Line Speed Adjust:Pos.2			
1 to 100	<u> </u>			
1962	Color Paper Adjustment	Color Paper Adjustment		
1 to 100			[ 1 to 5 / 1.52 / 0.01 ]	
1963 Trans Timing Roll Spd:Fine Adj				
1 to 100	Custom Paper 001 to 100		[-3 to 3 / 0 / 0.1%]	
1964 Exit Motor Spd:Fine Adj				
1 to 100	Custom Paper 001 to 100		[-5 to 5 / 0 / 0.1 %]	
1965 Invert Entrance Spd:Fine Adj				
1 to 100 Custom Paper 001 to 100			[-3 to 3 / 0 / 0.1 %]	
1966 Invert Exit Spd:Fine Adj				
1 to 100			[-3 to 3 / 0 / 0.1 %]	
1075	LCT Tray Fan Duty Adjustment			
1975	1973 ECT Hay Fall Doly Adjustment			

1 to 100	Custom Paper 001 to 100	[ 10 to 100 / 70 / 10%]		
1976	LCT Tray Fan ON/OFF	CT Tray Fan ON/OFF		
		[0 to 1/0/1]		
1 to 100	Custom Paper 001 to 100	0:OFF		
		1:ON		
1977	LCT Pickup Assist ON/OFF			
	,	[0 to 1 / 0 / 1]		
1 to 100	Custom Paper 001 to 100	0:OFF		
	'	1:ON		
		·		
1984	Htg Roller Temp Setting	Htg Roller Temp Setting		
	[100 to 200/*/1 deg]			
	The default settings are displayed to the right of "Initial" on the screen.			
101 to 12	Custom Paper 001 to 100	Custom Paper 001 to 100		
1985	Press Roller Temp Setting	Press Roller Temp Setting		
	[50 to 200/*/1 deg]			
	The default settings are displayed to the right of "Initial" on the screen.			
101 to 12	Custom Paper 001 to 100			
1986	Process Speed			
	[0 to 2/*/1]			
	The default settings are displayed to the right of "Initial" on the screen.			
101 to 12	Custom Paper 001 to 100			
1987	Fusing Mtr Rotation Correct	Fusing Mtr Rotation Correct		
101 to 12	Custom Paper 001 to 100			

[-10 to +10/*/0.1%]	
The default settings (*) are displayed to the right of "Initial" on the screen.	

1988	CPM Adjustment	
101 to 125	Custom Paper 001 to 100	
	[1 to 100/*/1%] The default settings (*) are displayed to the right of "Initial" on the screen.	

1989	Nip Width Setting	
101 to 125	Custom Paper 001 to 100	
	[1 to 3/2/1] The default settings (*) are displayed to the right of "Initial" on the screen.	

1991	Over N-Temp:CPM Down		
	These SP codes set the threshold for triggering CPM down mode based and weight.		CPM down mode based on media
	Thickness		
	1	52.3 - 63.0 g/m <sup>2</sup>	
	2	63.1 - 80.0 g/m <sup>2</sup>	
	3	80.1 - 105.0 g/m <sup>2</sup>	
	4	105.1 - 163.0 g/m <sup>2</sup>	
	5	163.1 - 220.0 g/m <sup>2</sup>	
	6	220.1 - 256.0 g/m <sup>2</sup>	
	7	256.1 - 300.0 g/m <sup>2</sup>	
101 to 107	Plain: Weight 1 to	7	[0 to 3/0/1 step]
109 to 114	Matte: Weight 2 to 7 Glossy: Weight 2 to 7 Envelope: Weight 5 to 7		0: No CPM Down
016 to 021			1: CPM Down 1
122 to 124			2: CPM Down 2

Z

125 OHP 3: CPM Down 3		
-----------------------	--	--

1992	Web Feed Interval			
	This SP sets the web feed intervals for different types of paper and weigh			
	Thickness	Weight (g/m2)		
	1	52.3 - 63.0 g/m <sup>2</sup>		
	2	63.1 - 80.0 g/m <sup>2</sup>		
	3	80.1 - 105.0 g/m <sup>2</sup>		
	4	105.1 - 163.0 g/m <sup>2</sup>		
	5	163.1 - 220.0 g/m <sup>2</sup>		
	6	220.1 - 256.0 g/m <sup>2</sup>		
	7	256.1 - 300.0 g/m <sup>2</sup>		
101 to 107	Plain: Weight 1 to	7	[-3 to +3/*/0.1%]	
109 to 114	Matte: Weight 2 t	to 7		
016 to 021	Glossy: Weight 2 to 7  Envelope: Weight 5 to 7  OHP		The default settings (*) are	
122 to 124			displayed to the right of "Initial" on the screen.	
125				

## Group 2000

2101	Reg Col Interval		
	These SPs are used to adjust main registration (RGATE).		
1 to 4	Main Scan Dot: K, C, M, Y	[-512 to 511/0/1 dot]	
6 to 9	Main/Sub Scan: K, C, M, Y	[-47 to 47/0/1 sub-dot]	
11	Main phase initial value: K	[0 to 1000/0/1 us]	
12	Main phase initial value: C		
13	Main phase initial value: M		
14	Main phase initial value: Y		
21	Main beam pitch adj: K	[1107 to 1620/1438/1 um]	
22	Main beam pitch adj: C		
23	Main beam pitch adj: M		
24 Main beam pitch adj: Y			
36 to 39	SubScan Line: K, C, M, Y	[-4096 to 4095/0/1 line]	
41 Main cor revision dot: C		[-512 to 511/0/1 dot]	
42	Main cor revision dot: M		
43	Main cor revision dot: Y		
45	Main cor revision subdot: C	[-47 to 47/0/1 sub-dot]	
46	Main cor revision subdot: M		
47	Main cor revision subdot: Y		
49	Sub cor revision line: C	[-4096 to 4095/0/1 line]	
50	Sub cor revision line: M		
51	Sub cor revision line: Y		
60	Main Left Mag.: Subdot: C		
61	Main Right Mag.: Subdot: C		

62	Main Left Mag.: Subdot: M	
63	Main Right Mag.: Subdot: M	
64	Main Left Mag.: Subdot: Y	
65	Main Right Mag.: Subdot: Y	

2102	Print Magnification Adjustment	
	Adjusts the value for the standard speed of the rate of magnification for K in the main scan direction.	
1	Main Mag.: K	[0 to 255/132/1]
4	Main Mag.: C	
7	Main Mag.: M	
10	Main Mag.: Y	
16	Main Mag.: subdot: K	[-15264 to 15264/0/1 sub-dot]
19	Main Mag.: subdot: C	
22	Main Mag.: subdot: M	
25	Main Mag.: subdot: Y	
31	Main Paper Int. Mag: Subdot: K	
32	Main Paper Int. Mag: Subdot: C	
33	Main Paper Int. Mag: Subdot: M	
34	Main Paper Int. Mag: Subdot: Y	
40	Mag settting & Adjustment	[-1 to 1/0/0.001%]
41	Face Main Mag set & Adj	[-0.8 to 0.8/00.025%]
42	Face Sub Mag set & Adj	
43	Verso Main Mag set & Adj	
44	Verso Sub Mag set & Adj	

2103	Erase Margin Adjustment
------	-------------------------

	Adjusts the white space at the leading and trailing edge, left and right edge of the paper.	
1	Lead Edge Width	[0 to 9/4/0.1 mm]
2	Trail. Edge Width	
3	Left	[0 to 9/2/0.1 mm]
4	Right	

2104	Skew Adjustment		
	These SPs adjust skew.		
2	Manual C	[-50 to 50/0/1 pulse]	
3	Manual M		
4	Manual Y		
6	Accumulation present value K		
7	Accumulation present value C		
8	Accumulation present value M		
9	Accumulation present value Y		
11	Accumulation MUSIC value C		
12	Accumulation MUSIC value M		
13	Accumulation MUSIC value Y		
20	Phase pattern K	[1 to 4/1/1]	
21	Phase pattern C		
22	Phase pattern M		
23	Phase pattern Y		
30	Clear Revision K	[0 to 1/0/1]	
31	Clear Revision C		
32	Clear Revision M		
33	Clear Revision Y		

40	Manual K CE	[-10 to 10/0/1 pulse]
41	Manual K User	

2105	Main Beam Pitch Adj	
	Adjusts the value of the beam pitch adjustment for black in the main scan direction.	
	Revision <color> <no.>ch(annel)</no.></color>	
1 to 160	[-10 to 10/*/0.1 um]	
	The default settings (*) are displayed to the right of "Initial" on the screen.	

2106	Trapezoid Adj	
	Trapezoid adjustment for black.	
	Revision <color kcmy=""> <no.>ch(annel)</no.></color>	
1 to 160	[-48 to 48/*/ subdot]	
	The default settings (*) are displayed to the right of "Initial" on the screen.	

2107	Image Parameter	
	These SP codes adjust image parameters.	
1	Shading Correction Flag [0 to 1/1/1]	
2	Image Gamma Flag	
3	Jaggy Revision	[0 to 1/0/1]
4	Fatten slanted line	
5	Dot Stabilize Revision	
6	Bow Skew Revision [0 to 1/1/1]	
7	Sub Mag Adj Revision K1	
8	Sub Mag Adj Revision K2	
9	Sub Mag Adj Revision W1	
10	Sub Mag Adj Revision W2	
11	Sub Mag Adj Rev 600dpi W1	[0 to 1/0/1]

12	trapezoid Adj ON/OFF	[0 to 1/1/1]
13	Sub Mag Adj Mirror K	[0 to 1/0/1]
14	Sub Mag Adj Mirror C	
15	Sub Mag Adj Mirror M	
16	Sub Mag Adj Mirror Y	
18	Sub Mag Adj Revision K3	
19	Sub Mag Adj Revision Gray	
20	Sub Scan Revision 1spl	
21	Sub Mag Adj Parameter Change	
22	2 PWM Phase Selection [0 to 2/1/1]	

2108	Image Parameter	
1	K/C Writing Unit	[0 to 1/0/1]
2	Y/M Writing Unit	

2109	Test Pattern	
	Allows you to select a test pattern.	
3	Pattern Selection	
	Allows you to select 1 of 27 patterns to print [0 to 27/0/1]	
	0:Copy Image Data	14: Trimming Area
	1:Vertical Line 1 dot	15: Hound's Tooth Check 1 Vertical
	2:Vertical Line 2dot	16: Hound's Tooth Check 2 Vertical
	3:Horizontal Line 1 dot	17:Band Horizontal
	4:Horizontal Line 2dot	18:Band Vertical
	5:Grid Vertical Line	19:Checker Flag Pattern
	6:Grid Horizontal Linie	20:Grayscale Vertical Margin

	7:Grid Pattern Small	21:Grayscale Horizontal Margin
	8:Grid Pattern Large	22:Step Pattern 1dot
	9:Argyle Pattern Small	23:Step Pattern 2dot
	10:Argyle Pattern Large	24:Stripe Pattern 1dot
	11:Independent Pattern 1dot	25:Stripe Pattern 2dot
	12:Independent Pattern 2dot	26:Full Dot Pattern
	13:Independent Pattern 4dot	27:None
5	Color Selection	[1 to 5/1/1 step] 1: Full Color 2: Cyan 3: Magenta 4: Yellow 5: Black
6	Density: K	[0 to 15/15/1 step]
7	Density: C	
8	Density: M	
9	Density: Y	

2111	Forced Line Position Adj	
	Executes forced color matching for Mode a, b, c, d	
1	Mode a	[0 to 1/0/1]
2	Mode b	
3	Mode c	
4	Mode d	

2112	TM/P-Sensor Test
	These SP codes are used to test the TM sensors (Toner Mark or MUSIC sensors) and P-sensor (ID sensor), and check for damage on the surface of the image transfer belt (ITB).

1	Execute	[0 to 1/0/1]
10	General	[0 to 9999/0/1]
11	Error Code: P	[0 to 999999/0/1]
15	Error Code: Front	
16	Error Code: Center	
17	Error Code: Rear	
20	Threshold Setting	[0 to 5.5/1.9/0.01 V]
21	Judge Val: Min 2	[0 to 5.5/2.5/0.01 V]
22	Judge Val: Output Chg Amplitude High	[0 to 5.5/1/0.01 V]
23	Judge Val: Output Chg Amplitude Low	
24	Judge Val: Ave Chg Amplitude High	[0 to 5.5/0.5/0.01 V]
25	Judge Val: Ave Chg Amplitude Low	

2113	Adjust LR Density Difference	
	Adjusts in the main scan direction the amount of laser light to create the image for each color so the density is uniform on the left and right sides of the image.	
1	K	[-5 to +5/0/1]
2	С	
3	М	
4	Y	

2121	Erase Margin Adj	
1	Leading Edge	[0 to 6 / 0 / 0.1 mm]
2	Trailing Edge	[0 to 6 / 0 / 0.1 mm]

2122	Erase Margin Adj Leading Edge	
	Adjusts and enlarges margin at the trailing edge. A user setting.	

1 to 100	Custom Paper 001 to 100	[-3 to 6 / 0 / 0.1 mm]
101	Plain: Weight 1	[-3 to 6 / 0.5 / 0.1 mm]
102 to 107	Plain: Weight 2 to 7	
109 to 114	Glossy: Weight 2 to 7	
116 to 121	Matte: Weight 2 to 7	[-3 to 6 / 0 / 0.1 mm]
122 to 124	Envelope: Weight 5 to 7	
125	OHP	

2123	Erase Margin Adj Trailing Edge	
	Adjusts and enlarges margin at the trailing edge. A user setting.	
1 to 100	Custom Paper 001 to 100	[-3 to +6/0/0.1 mm]
101 to 107	Plain: Weight 1 to 7	
109 to 114	Glossy: Weight 2 to 7	
116 to 121	Matte: Weight 2 to 7	
122 to 124	Envelope: Weight 5 to 7	
125	OHP	

2130	Sub Mag Adj Parameter K	
2131	Sub Mag Adj Parameter C	
2132	Sub Mag Adj Parameter M	
2133	Sub Mag Adj Parameter Y	
	These SP modes adjust the magnification parameters in the sub scan direction for each color.	
1	Interval:0.025 Percent	[0 to 255/19/1]
2	Mag Reciprocal:0.025 Percent	[0 to 8191/3990/1]
3	Interval:0.05 Percent	[0 to 255/53/1]
4	Mag Reciprocal:0.05 Percent	[0 to 8191/1961/1]

5	Interval:0.075 Percent	[0 to 255/19/1]
6	Mag Reciprocal:0.075 Percent	[0 to 8191/1349/1]
7	Interval:0.1 Percent	[0 to 255/53/1]
8	Mag Reciprocal:0.1 Percent	[0 to 8191/1007/1]
9	Interval:0.125 Percent	[0 to 255/47/1]
10	Mag Reciprocal:0.125 Percent	[0 to 8191/799/1]
11	Interval:0.15 Percent	[0 to 255/29/1]
12	Mag Reciprocal:0.15 Percent	[0 to 8191/667/1]
13	Interval:0.175 Percent	[0 to 255/13/1]
14	Mag Reciprocal:0.175 Percent	[0 to 8191/572/1]
15	Interval:0.2 Percent	[0 to 255/29/1]
16	Mag Reciprocal:0.2 Percent	[0 to 8191/493/1]
17	Interval:0.225 Percent	[0 to 255/23/1]
18	Mag Reciprocal:0.225 Percent	[0 to 8191/437/1]
19	Interval:0.25 Percent	[0 to 255/19/1]
20	Mag Reciprocal:0.25 Percent	[0 to 8191/3991/1]
21	Interval:0.275 Percent	[0 to 255/19/1]
22	Mag Reciprocal:0.275 Percent	[0 to 8191/361/1]
23	Interval:0.3 Percent	[0 to 255/19/1]
24	Mag Reciprocal:0.3 Percent	[0 to 8191/323/1]
25	Interval:0.325 Percent	[0 to 255/17/1]
26	Mag Reciprocal:0.325 Percent	[0 to 8191/306/1]
27	Interval:0.35 Percent	[0 to 255/17/1]
28	Mag Reciprocal:0.35 Percent	[0 to 8191/289/1]
29	Interval:0.375 Percent	[0 to 255/14/1]
30	Mag Reciprocal:0.375 Percent	[0 to 8191/266/1]

31	Interval:0.4 Percent	[0 to 255/11/1]
32	Mag Reciprocal:0.4 Percent	[0 to 8191/253/1]
33	Interval:0.425 Percent	[0 to 255/21/1]
34	Mag Reciprocal:0.425 Percent	[0 to 8191/231/1]
35	Interval:0.45 Percent	[0 to 255/22/1]
36	Mag Reciprocal:0.45 Percent	[0 to 8191/220/1]
37	Interval:0.475 Percent	[0 to 255/21/1]
38	Mag Reciprocal:0.475 Percent	[0 to 8191/210/1]
39	Interval:0.5 Percent	[0 to 255/18/1]
40	Mag Reciprocal:0.5 Percent	[0 to 8191/198/1]
41	Interval:0.525 Percent	[0 to 255/19/1]
42	Mag Reciprocal:0.525 Percent	[0 to 8191/190/1]
43	Interval:0.55 Percent	[0 to 255/13/1]
44	Mag Reciprocal:0.55 Percent	[0 to 8191/182/1]
45	Interval:0.575 Percent	[0 to 255/11/1]
46	Mag Reciprocal:0.575 Percent	[0 to 8191/176/1]
47	Interval:0.6 Percent	[0 to 255/15/1]
48	Mag Reciprocal:0.6 Percent	[0 to 8191/165/1]
49	Interval:0.625 Percent	[0 to 255/16/1]
50	Mag Reciprocal:0.625 Percent	[0 to 8191/160/1]
51	Interval:0.65 Percent	[0 to 255/14/1]
52	Mag Reciprocal:0.65 Percent	[0 to 8191/154/1]
53	Interval:0.675 Percent	[0 to 255/15/1]
54	Mag Reciprocal:0.675 Percent	[0 to 8191/150/1]
55	Interval:0.7 Percent	[0 to 255/13/1]
56	Mag Reciprocal:0.7 Percent	[0 to 8191/143/1]

57	Interval:0.725 Percent	[0 to 255/14/1]
58	Mag Reciprocal:0.725 Percent	[0 to 8191/140/1]
59	Interval:0.75 Percent	[0 to 255/7/1]
60	Mag Reciprocal:0.75 Percent	[0 to 8191/133/1]
61	Interval:0.775 Percent	[0 to 255/13/1]
62	Mag Reciprocal:0.775 Percent	[0 to 8191/130/1]
63	Interval:0.8 Percent	[0 to 255/14/1]
64	Mag Reciprocal:0.8 Percent	[0 to 8191/126/1]

2141	P-Sensor Test (Average)	
	These SP codes test the belt background data, ID sensor, reflectivity of the belt and averages them for different areas of the image transfer belt. (The "P-sensor" is the ID sensor.)	
1	Average	[0 to 5.5/0/0.01V]
5	Average: Front	
6	Average: Center	
7	Average: Rear	

2142	P-Sensor Test (Maximum)	
	These SP codes test the belt background data, ID sensor, reflectivity of the belt and determine the maximum value at different areas of the image transfer belt. (The "Psensor" is the ID sensor.)	
1	Maximum	[0 to 5.5/0/0.01V]
5	Maximum: Front	
6	Maximum :Center	
7	Maximum: Rear	

2143	P-Sensor Test (Minimum)	
------	-------------------------	--

	These SP codes test the belt background data, ID sensor, reflectivity of the belt and determine the minimum value at different areas of the image transfer belt. (The "P-sensor" is the ID sensor.)	
1	Minimum	[0 to 5.5/0/0.01V]
5	Minimum: Front	
6	Minimum: Center	
7	Minimum: Rear	

2144	P-Sensor Test (Maximum 2)	
	These SP codes test the belt background data, ID sensor, reflectivity of the belt and determine the simple maximum value at different areas of the image transfer belt. (The "Psensor" is the ID sensor.)	
1	Maximum 2	[0 to 5.5/0/0.01V]
5	Maximum 2: Front	
6	Maximum 2: Center	
7	Maximum 2: Rear	

2145	Sensor Test (Minimum 2)	
	These SP codes test the belt background data, ID sensor, reflectivity of the belt and determine the simple minimum value at different areas of the image transfer belt. (The "Psensor" is the ID sensor.)	
1	Minimum 2	[0 to 5.5/0/0.01V]
5	Minimum 2:Front	
6	Minimum 2:Center	
7	Minimum 2:Rear	

2146	TM Sensor Test
	This SP sets the number of tests done to check the belt background data, TM sensor, and front edge of the belt. ("TM sensor" means "MUSIC sensor". Here, it refers to the front MUSIC sensor.)

5	Number of Edge Detection: Front	[0 to 16/0/0.1]
6	Number of Edge Detection: Center	
7	Number of Edge Detection: Rear	

2150	Area Mag. Correction	
	Fine adjusts the image color (YMCK) in the main scan direction. Adjustment is done in units of 1/48 dots.	
001 to 056	Area <no.> <color> [-4095 to +4095/0/1 Subdot]</color></no.>	
	<no.> 0 to 13 <color> Bk, C, M, Y</color></no.>	

2151	Bow Skew Setting	
	Defines the initial setting for each area of the MUSIC pattern for Bow Skew testing and adjustment.	
1	Initial Setting Area 0 K	[0 to 24/0/1]
2 to 11	Initial Setting Area <range>K</range>	[0 to 65535/0/1]
12	Initial Setting Area 81 to 85 K	[0 to 1023/0/1]
13	Initial Setting Area OC	[0 to 24/0/1]
14 to 23	Initial Setting Area <range> C</range>	[0 to 65535/0/1]
24	Initial Setting Area 81 to 85 C	[0 to 1023/0/1]
25	Initial Setting Area 0 M	[0 to 24/0/1]
26 to 35	Initial Setting Area <range>M</range>	[0 to 65535/0/1]
36	Initial Setting Area 81 to 85 M	[0 to 1023/0/1]
37	Initial Setting Area 0 Y	[0 to 24/0/1]
38 to 47	Initial Setting Area <range>Y</range>	[0 to 65535/0/1]
48	Initial Setting Area 81 to 85 Y	[0 to 1023/0/1]
61	Initial Setting Area 0 C	[0 to 24/0/1]
62 to 71	Initial Setting Area <range>C</range>	[0 to 65535/0/1]

72	Initial Setting Area 81 to 85 C	[0 to 1023/0/1]
73	Initial Setting Area 0 M	[0 to 24/0/1]
74 to 83	Initial Setting Area <range>M</range>	[0 to 65535/0/1]
84	Initial Setting Area 81 to 85 M	[0 to 1023/0/1]
85	Initial Setting Area 0 Y	[0 to 24/0/1]
86 to 95	Initial Setting Area <range>Y</range>	[0 to 65535/0/1]
96	Initial Setting Area 81 to 85 Y	[0 to 1023/0/1]

2152	Shading Coeff	
	Sets the adjust coefficient for exposure shading for each color in each area of the MUSIC pattern.	
1 to 128	<area/> <front 0="" 30="" no.="" to=""><color kcmy=""></color></front>	[0.875 to 1.165/1/0.001]

2153	MUSIC Settings	
	These SP codes set up the MUSIC settings.	
1	Auto Execute	[0 to 1/1/1]
2	During ProCon	0: OFF, 1: ON
3	Initialization	
4	During Data In	
5	Writing	
6	MUSIC Temp Intervals	[0 to 1/0/1]
24	Assign Page Interval	[10 to 999/100/1 page]
29	MUSIC Density Lvl	[0 to 15/15/1]
30	Clear Main Slip	[0 to 1/0/1]
31	Clear Sub Slip	
40	Decision Temp: Change K	[0 to 99.9/1.5/0.1 deg]
41	Decision Temp: Change K2	[0 to 99.9/3/0.1 deg]

44	Decision Temp: Change M	[0 to 99.9/1.5/ 0.1deg]
45	Decision Temp: Change M2	[0 to 99.9/3/0.1 deg]
50	Decision Temp: Change Y	[0 to 99.9/1.5/0.1 deg]
51	Decision Temp: Change Y2	[0 to 99.9/3/0.1 deg]
52	Decision Temp: ITB FB Sensor	[0 to 99.9/1.5/0.1 deg]
53	Decision Temp: ITB FB Sensor2	[0 to 99.9/3/0.1 deg]

2154	MUSIC Setting:2	
	Feeds back the MUSIC setting adjustments.	
	Feed Back mode	[0 to 1 /1/1]

2155	MUSIC Setting: 3	
	Filter QF for the MUSIC settings.	
13	Filter QF	[0 to 3 /3/1]
20	BeforeFilter:a1	[-131071 to 131071/125869/1]
21	BeforeFilter:a2	[-131071 to 131071/-60488/1]
22	BeforeFilter:b0	[-131071 to 131071/39/1]
23	BeforeFilter:b1	[-131071 to 131071/77/1]
24	BeforeFilter:b2	[-131071 to 131071/39/1]
25	AfterFilter:a1	[-131071 to 131071/128596/1]
26	AfterFilter:a2	[-131071 to 131071/-63398/1]
27	AfterFilter:b0	[-131071 to 131071/84/1]
28	AfterFilter:b1	[-131071 to 131071/168/1]
29	AfterFilter:b2	[-131071 to131071/84/1]
50	Main Offset Left: C	[-2000 to 2000/0/0.1 um]
51	Main Offset Center: C	
52	Main Offset Right: C	

53	Main Offset Left: M	
54	Main Offset Center: M	
55	Main Offset Right: M	
56	Main Offset Left: Y	
57	Main Offset Center: Y	
58	Main Offset Right: Y	
62	Sub Offset Left: C	
63	Sub Offset Center: C	
64	Sub Offset Right: C	
65	Sub Offset Left: M	
66	Sub Offset Center: M	
67	Sub Offset Right: M	
68	Sub Offset Left: Y	
69	Sub Offset Center: Y	
70	Sub Offset Right: Y	
80	Skew Remainder Std Speed: C	[-2000 to 2000/0/0.001um]
81	Skew Remainder Mid Speed: C	[-2000 to 2000/32.657/0.001um]
82	Skew Remainder Low Speed: C	[-2000 to 2000/54.429/0.001um]
83	Skew Remainder Std Speed: Y	[-2000 to 2000/0/0.001um]
84	Skew Remainder Mid Speed: Y	[-2000 to2000/32.657/0.001um]
85	Skew Remainder Low Speed: Y	[-2000 to 2000/54.429/0.001um]
90	Bow Skew Upper Limit	[0 to 24/24/1 line]
91	Bow Skew Lower Limit	[0 to 24/1/1 line]

2156	MUSIC Threshold Setting	
1	ch 0: 1st	[0.5 to 3/1.5/0.1 V]

2	ch 0: 2nd	
3	ch 0: 3rd	
4	ch 0: 4th	
5	ch 1: 1st	
6	ch 1: 2nd	
7	ch 1: 3rd	
8	ch 1: 4th	
9	ch 2: 1st	
10	ch 2: 2nd	
11	ch 2: 3rd	
12	ch 2: 4th	

2180	MUSIC Monitor	
	Lens temperature monitor.	
1	Lens Temp: K	[0 to 99.9/0/0.1 deg]
3	Lens Temp: M	
10	Previous Temp: K	
12	Previous Temp: M	
15	Previous Temp: Main Y	
16	Previous Temp: ITB FB Sensor	

2181	Alignment Result	
	These SP codes report the results of color registration alignment.	
1	General	[0 to 9999999/0/1]
2	Difference Main Left: C	[-2000 to 2000/0/0.001 um]
3	Difference Main Center: C	
4	Difference Main Right: C	

5	Difference Main Left: M	
6	Difference Main Center: M	
7	Difference Main Right: M	
8	Difference Main Left: Y	
9	Difference Main Center: Y	
10	Difference Main Right: Y	
14	Difference Sub Left: C	
15	Difference Sub Center: C	
16	Difference Sub Right: C	
17	Difference Sub Left: M	
18	Difference Sub Center: M	
19	Difference Sub Right: M	
20	Difference Sub Left: Y	
21	Difference Sub Center: Y	
22	Difference Sub Right: Y	
26	MUSIC Sub Scan Revision: C	[-4096 to 4095/0/1 line]
27	MUSIC Sub Scan Revision: M	
28	MUSIC Sub Scan Revision: Y	
30	BowSkew Revision Left: C	[-2000 to 2000/0/0.001 um]
31	BowSkew Revision Center: C	
32	BowSkew Revision Right: C	
33	BowSkew Revision Left: M	
34	BowSkew Revision Center: M	
35	BowSkew Revision Right: M	
36	BowSkew Revision Left: Y	
37	BowSkew Revision Center: Y	

38	BowSkew Revision Right: Y
42	Skew Amt: C
43	Skew Amt: M
44	Skew Amt: Y

2183	Main Scan Length Detection		
	These SP codes set and execute the standard speed of 2-dot measurement for each color.		
1	Execute : K	[0 to 1/0/1]	
4	Execute : C		
7	Execute : M		
10	Execute : Y		

2184	Main Scan Length Target	
	These SP codes retrieve the results of 2-dot measurement for each color and display the counts.	
1	Execute: K	[0 to 1/0/1]
2	Execute: C	
3	Execute: M	
4	Execute: Y	
6	Count Value: K	[0 to 300000/266835/1]
7	Count Value: C	
8	Count Value: M	
9	Count Value: Y	

2185	Main Scan Length Detection	
	This SP selects 2-point measurement.	
1	Mode Selection	[0 to 2/2/1]

0: OFF 1:ON 2:ALL ON	
----------------------	--

2190	Line Position Adj. Setting	
	This SP selects the amount of magnification in the main scan direction for the color registration method.	
1	Partial Mag: K [0 to 1/1/1]	
2	Partial Mag: C	
3	Partial Mag: M	
4	4 Partial Mag: Y	
6	Left Right Mag: C	
7	Left Right Mag: M	
8		
12		

2191	Polygon Mirror Face Detection	
	Selects polygon mirror facet measurement method.	
1	Mode Selection	[0 to 1/1/1] 0:OFF 1:ON

2192	LD Control	
1	LD On : K	[0 to 40 / 0 / 1] K:LD1 to 40:ON/OFF
2	LD On : C	[0 to 40 / 0 / 1] C:LD1 to 40:ON/OFF
3	LD On : M	[ 0 to 40 / 0 / 1] M : LD1 to 40 : ON/OFF
4 LD On : Y		[ 0 to 40 / 0 / 1] Y : LD1 to 40 : ON/OFF

2193	PD Control			
------	------------	--	--	--

1 Monitor PD Output: K		Monitor PD Output: K	[0 to 1023 / - / 1]
2 Monitor PD Output: C		Monitor PD Output: C	[0 to 1023 / - / 1]
3 Monitor PD Output: M		Monitor PD Output: M	[0 to 1023 / - / 1]
	4	Monitor PD Output: Y	[ 0 to 1023 / - / 1]

2194	MUSIC Execution Result	
7	Execution Result	[0 to 1/0/1]
8	N umber of Execution	[0 to 999999/0/1 times]
9	N umber of Failure	
10	Error Result: M	[0 to 9/0/1]
11	Error Result: C	
12	Error Result: Y	

2197	MUSIC Start Time	
1	1 MUSIC Start Time (EDT) [10 to 40/20/10 ms]	
2	TM Sensor Position	[50 to 500/155/0.1 mm]

2198	Music A/D Interval	
	ADC Trigger Counter	[7.5 to 20/10/0.1 us]

2199	Music Error Time Setting	
	Error Detection Counter	[0.1 to 9.9/2.5/0.1 sec]

2201	Set DC C	Set DC Charge	
These SP codes set the DC bias. However, these settings are enabled only when SP3-600-001 is selected and enabled as the method to control process control electropotential.		-001 is selected and enabled as the method to control process control electrical	
1	1 K [-999 to -250/-560/1 V\		
2 C			

3	М	
4	Υ	

2202	Set AC (Fixed) Charge		
	This SP setting determines the fixed electrical potential setting when AC electrical potential adjustment is off.		
1	AC Bias :K	[0 to 3/2.2/0.01 kV]	
2	AC Bias :C		
3	AC Bias :M		
4	AC Bias :Y		

2204	Set AC Environ Corr		
	Sets the target value for the AC electrical potential charge adjustment.		
1 to 4	Norm:LL:Target:K, C, M, Y	[2.5 to 3.5/2.15/0.01 mA]	
6 to 9	Norm:ML:Target: K, C, M, Y	[1.5 to 2.1/3/0.01 mA]	
11 to 14	Norm:MM:Target:K, C, M, Y	[1.5 to 3/2.05/0.01 mA]	
16 to 19	Norm:MH:Target: K, C, M, Y		
21 to 24	Norm:HH:Target:K, C, M, Y		
26 to 29	Mid:LL:Target:K, C, M, Y	[1.2 to 2.8/1.78/0.01 mA	
31 to 34	Mid:ML:Target:K, C, M, Y	[1.2 to 2.8/1.74/ 0.01 mA	
36 to 39	Mid:MM:Target:K, C, M, Y	[1.2 to 2.8/1.7/0.01 mA	
41 to 44	Mid:MH:Target:K, C		
46 to 47	Mid:HH:Target: M, Y		
48 to 49	Mid:HH:Target:M, Y		
51 to 54	Low:LL:Target:K, C, M, Y	[1 to 2.5/1.56/ 0.01 mA	
56 to 59	Low:ML:Target:K, C, M, Y	[1 to 2.5/1.53/ 0.01 mA	
61 to 64	Low:MM:Target:K, C, M, Y	[1 to 2.5/1.5/0.01 mA]	

66 to 69	Low:MH:Target:K, C, M, Y	
71 to 72	Low:HH:Target:K, C	
73 to 74	Low:HH:Target:M, Y	

2205	Adj/Display AC Charge			
	Switches the AC electrical potential setting on/off.			
1	Select [0 to 1/0/1]			
2	Temp Threshold 1	[0 to 50/3/1 deg]		
3	Temp Threshold 2	[0 to 50/1/1 deg]		
4	Execution Interval	[0 to 200/10/5]		
5	Previous Temp:BW	[0 to 50/0/1 deg]		
6	Previous Temp:Col			

2208	Chg AC Adj.: Execute		
	Touch [EXECUTE] to force execute the AC electrical potential adjustment.		
1	Execute AC Reduction	[EXECUTE]	

2209	Chg AC Adj: Result		
	Displays the result of the AC electrical potential adjustment.		
1	Chg AC Adj:Result	[0 to 9999/100/1] [1111] denotes successful adjustment.	

2211	Set LD Power		
	These SP codes set the LD power level for each laser unit. These settings take effect only when SP3600-001 is selected and set to "0" (ON).		
1	K [80 to 170/100/1 %]		
2	С		
3	М		

4 Y	
-----	--

2212	Set Dev DC		
	These SP codes set the DC bias for each color. These settings take effect only when SP3600-001 is selected and set to "0" (ON).		
1	K	[-900 to 0/-450/1 V]	
2	С		
3	М		
4	Y		

2220	Chg Roll Cleaning Timing		
	This SP sets the operation timing of the charge roller cleaning roller.		
	Execution Timing [0 to 2/2/1]		
	0: No Operation		
	1: Power On & Distance		
	2: Distance		

2221	Chg Roll Cleaning Timing		
	These SP codes set up the parameters for the operation of the charge roller cleaning roller.		
1	Execution Interval: K [0 to 999 999/100 000/100 cm]		
2	Execution Interval: C		
3	Execution Interval: M		
4	Execution Interval: Y		
5	Distance: K	[0 to 999 999/0/1 cm]	
6	Distance: C		
7	Distance: M		
8	Distance: Y		
9	Delay at Power On: K	[0 to 999 999/5000/100 cm]	

10	Delay at Power On: C	
11	1 Delay at Power On: M	
12	Delay at Power On: Y	
13	Delay at Power On: Y	

2222	Chg Roll Cleaning Execute		
	This SP triggers forced manual cleaning of the charge roller with the charge roller cleaning roller. Cleaning can be done for charge roller independently or all at once together.		
1	All	All [EXECUTE]	
2	K		
3	С		
4	М		
5	Y		

2224	Set QL Power		
	Sets the power level of the quenching lamps which eliminate residual charge on th		
1	Norm Image	[0 to 100/80/1%]	
2	Norm Margin		
3	Mid Image	[0 to 100/56/1%]	
4	Mid Margin		
5	Low Image	[0 to 100/40/1%]	
6	Low Margin		

2225	Cleaning Speed: Col		
	These SP codes adjust the speed of the cleaning brush rollers relative to the speed of the drums.		
1	Norm	0.1 to 1/0.38/0.01]	
2	Mid	[0.1 to 1/0.56/0.01]	

3	Low	[0.1 to 1/0.54/0.01]
4	Period of Revs 1	[0 to 150 000/5000/1m]
5	Period of Temp	[0 to 50/34/1deg]
6	Distance Coefficient 1	[0.5 to 2/0.9/0.1]
7	Post Switching Coefficient	[0.5 to 2/1.25/0.1]
8	Period of Revs2	[0 to 150000/15000/1m]
9	Period of Revs3	[0 to 150000/40000/1m]
10	Distance Coefficient2	[0.5 to 2/1/0.1]
11	Distance Coefficient3	
12	Special Mode Selection: K	[0 to 1/0/1]
13	Special Mode Selection: C	
14	Special Mode Selection: M	
15	Special Mode Selection: Y	
16	Special Mode Coefficient1	[0.5 to 2/0.9/0.1]
17	Special Mode Coefficient2	[0.5 to 2/1.2/0.1]
18	Special Mode Coefficient3	

2301	Current Value: FC		
1	Side 1:ITB K	[0 to 70/0/0.1 uA]	
2	Side 1:ITB C		
3	Side 1:ITB M		
4	Side 1:ITB Y		
7	Side 1:PTR	[-400 to 0/0/1 uA]	
8	Side1:SepDC	[0 to 10/0/0.1 uA]	
9	Side1:SepAC	[8 to 12/10/0.1 uA]	
11	Side2:ITB K	[0 to 70/0/0.1 uA]	

12	Side2:ITB C	
13	Side2:ITB M	
14	Side2:ITB Y	
17	Side2:PTR	[-400 to 0/0/1 uA]
18	Side2:SepDC	[0 to 10/0/0.1 uA]
19	Side2:SepAC	[8 to 12/10/0.1 kV]

2302	Current Value: BK		
1	Side 1:ITB K	[0 to 70/0/0.1uA]	
7	Side 1:PTR	[-400 to 0/0/1uA]	
8	Side 1:SepDC	[0 to 10/0/0.1uA]	
9	Side 1:SepAC	[8 to 12/10/0.1kV]	
11	Side2:ITB K	[0 to 70/0/0.1uA]	
17	Side2:PTR	[-400 to 0/0/1uA]	
18	Side2:SepDC	[0 to 10/0/0.1uA]	
19	Side2:SepAC	[8 to 12/10/0.1kV]	

2310	Force Apply Lubricant		
	These SP codes control the forced application of lubricant to the ITB and display the histories of executed cleanings.		
1	1 Belt Cleaning [0 to 1/0/1]		
2	Operation Time Setting	[0 to 600/300/10sec]	
3	Success App Date: History 1	[0 to 991 231/0/1]	
4	Success App Date: History 2		
5	Success App Date: History 3		
6	Success App Date: History 4		
7	Success App Date: History 5		

2311	Current R Division		
11	ITB K	[0 to 6/3/1]	
12	ITB C		
13	ITB M		
14	ITB Y		
17	PTR		

2312	Measured Voltage		
1	ITB K	[0 to 7/0/0.01 kV]	
2	ITB C		
3	ITB M		
4	ITB Y		
7	PTR	[0 to 12/0/0.01 kV]	
13	Meas ITB	[0 to 6/3/0.01 kV]	
14	Meas PTR		

2	2313	Execute VItg Meas		
	1	FC	EC [EXECUTE] then displays "Completed".	
	2	BW		

2315	Set:Int VItg Meas		
1	Execute Interval	[0 to 20000/200/1 Sheet]	
2	Counter:FC	[0 to 20000/0/1 Sheet]	
3	Counter:BW		

2321	Set:R Thresh:LLL	
1	R Thresh 1:ITB	[0 to 10/0.8/0.01 kV]

2	R Thresh2:ITB	[0 to 10/1.15/0.01 kV]
3	R Thresh3:ITB	[0 to 10/1.5/0.01 kV]
4	R Thresh4:ITB	[0 to 10/3/0.01 kV]
5	R Thresh5:ITB	[0 to 10/6.5/0.01 kV]
6	R Thresh 1:PTR	[0 to 10/1.8/0.01 kV]
7	R Thresh2:PTR	[0 to 10/2.48/0.01 kV]
8	R Thresh3:PTR	[0 to 10/3.5/0.01 kV]
9	R Thresh4:PTR	[0 to 10/4.8/0.01 kV]
10	R Thresh5:PTR	[0 to 10/7/0.01 kV]

2322	Set:R Thresh:LL	
1	R Thresh 1:ITB	[0 to 10/0.8/0.01 kV]
2	R Thresh2:ITB	[0 to 10/1.15/0.01 kV]
3	R Thresh3:ITB	[0 to 10/1.5/0.01 kV]
4	R Thresh4:ITB	[0 to 10/3/0.01 kV]
5	R Thresh5:ITB	[0 to 10/6.5/0.01 kV]
6	R Thresh 1:PTR	[0 to 10/1.5/0.01 kV]
7	R Thresh2:PTR	[0 to 10/1.95/0.01 kV]
8	R Thresh3:PTR	[0 to 10/2.65/0.01 kV]
9	R Thresh4:PTR	[0 to 10/3.8/0.01 kV]
10	R Thresh5:PTR	[0 to 10/6/0.01 kV]

2323	Set:R Thresh:ML	
1	R Thresh 1:ITB	[0 to 10/0.8/0.01 kV]
2	R Thresh2:ITB	[0 to 10/1.15/0.01 kV]
3	R Thresh3:ITB	[0 to 10/1.5/0.01 kV]
4	R Thresh4:ITB	[0 to 10/3/0.01 kV]

5	R Thresh5:ITB	[0 to 10/6.5/0.01 kV]
6	R Thresh 1:PTR	[0 to 10/1.2/0.01 kV]
7	R Thresh2:PTR	[0 to 10/1.55/0.01 kV]
8	R Thresh3:PTR	[0 to 10/2.05/0.01 kV]
9	R Thresh4:PTR	[0 to 10/2.9/0.01 kV]
10	R Thresh5:PTR	[0 to 10/5/0.01 kV]

2324	Set:R Thresh:MM	
1	R Thresh 1:ITB	[0 to 10/0.8/0.01 kV]
2	R Thresh2:ITB	[0 to 10/1.15/0.01 kV]
3	R Thresh3:ITB	[0 to 10/1.5/0.01 kV]
4	R Thresh4:ITB	[0 to 10/3/0.01 kV]
5	R Thresh5:ITB	[0 to 10/6.5/0.01 kV]
6	R Thresh 1:PTR	[0 to 10/0.9/0.01 kV]
7	R Thresh2:PTR	[0 to 10/0.65/0.01 kV]
8	R Thresh3:PTR	[0 to 10/1.45/0.01 kV]
9	R Thresh4:PTR	[0 to 10/2/0.01 kV]
10	R Thresh5:PTR	[0 to 10/4/0.01 kV]

2325	Set:R Thresh:MH	
1	R Thresh 1:ITB	[0 to 10/0.8/0.01 kV]
2	R Thresh2:ITB	[0 to 10/1.15/0.01 kV]
3	R Thresh3:ITB	[0 to 10/1.5/0.01 kV]
4	R Thresh4:ITB	[0 to 10/3/0.01 kV]
5	R Thresh5:ITB	[0 to 10/6.5/0.01 kV]
6	R Thresh 1:PTR	[0 to 10/0.5/0.01 kV]
7	R Thresh2:PTR	[0 to 10/6.5/0.01 kV]

8	R Thresh3:PTR	[0 to 10/0.8/0.01 kV]
9	R Thresh4:PTR	[0 to 10/1.2/0.01 kV]
10	R Thresh5:PTR	[0 to 10/2.5/0.01 kV]

2326	Set:R Thresh:HH	
1	R Thresh 1:ITB	[0 to 10/0.8/0.01 kV]
2	R Thresh2:ITB	[0 to 10/1.15/0.01 kV]
3	R Thresh3:ITB	[0 to 10/1.5/0.01 kV]
4	R Thresh4:ITB	[0 to 10/3/0.01 kV]
5	R Thresh5:ITB	[0 to 10/6.5/0.01 kV]
6	R Thresh 1:PTR	[0 to 10/0.4/0.01 kV]
7	R Thresh2:PTR	[0 to 10/0.52/0.01 kV]
8	R Thresh3:PTR	[0 to 10/0.65/0.01 kV]
9	R Thresh4:PTR	[0 to 10/0.95/0.01 kV]
10	R Thresh5:PTR	[0 to 10/2.4/0.01 kV]

2401	Set: ITB K: Standard	
5	FC	[0 to 70/33/0.1 uA]
15	ВК	[0 to 70/34/0.1 uA]
21	Non Image	[0 to 70/5/0.1 uA]

2411	Set:ITB K:Eng Spd Coeff (100%)	
5	100%:FC	[10 to 200/100/1 %]
15	100%:BK	
21	100%:Non Image	

2412	Set:ITB K:Eng Spd Coeff (70%)
------	-------------------------------

5	70%:FC	[10 to 200/70/1%]
15	70%:BK	
21	70%:Non Image	

2413	Set:ITB K:Eng Spd Coeff (50%)	
5	50%:FC	[10 to 200/50/1%]
15	50%:BK	
21	50%:Non Image	

2427	Set:ITB K:Env Coeff	
1	LLL:Bk:Side1	[10 to 200/100/1%\
2	LLL:Bk:Side2	
3	LLL:FC:Side1	
4	LLL:FC:Side2	
5	LLL:Non Image	
11	LL:Bk:Side1	
12	LL:Bk:Side2	
13	LL:FC:Side 1	
14	LL:FC:Side2	
15	LL:Non Image	
21	ML:Bk:Side1	
22	ML:Bk:Side2	
23	ML:FC:Side1	
24	ML:FC:Side2	
25	ML:Non Image	
31	MM:Bk:Side1	
32	MM:Bk:Side2	

33	MM:FC:Side1	
34	MM:FC:Side2	
35	MM:Non Image	
41	MH:Bk:Side1	
42	MH:Bk:Side2	
43	MH:FC:Side1	
44	MH:FC:Side2	
45	MH:Non Image	
51	HH:Bk:Side1	
52	HH:Bk:Side2	
53	HH:FC:Side1	
54	HH:FC:Side2	
55	HH:Non Image	

2428 Set:ITB K:Env Coeff		
1	LLL:FC:Side1	[10 to 200/100/1%]
2	LLL:FC:Side2	
3	LLL:Non Image	
11	LL:FC:Side1	
12	LL:FC:Side2	
13	LL:Non Image	
21	ML:FC:Side1	
22	ML:FC:Side2	
23	ML:Non Image	
31	MM:FC:Side1	
32	MM:FC:Side2	

33	MM:Non Image	
41	MH:FC:Side1	
42	MH:FC:Side2	
43	MH:Non Image	
51	HH:FC:Side1	
52	HH:FC:Side2	
53	HH:Non Image	

2431	Set:ITB K:R Coeff	
	R-2	[50 to 250/170/1 %]

2432	Set:ITB K:R Coeff	
	R-1	[50 to 250/152/1%]

2433	Set:ITB K:R Coeff	
	RO	[50 to 250/136/1%]

2434	Set:ITB K:R Coeff	
	R+1	[50 to 250/124/1%]

2435	Set:ITB K:R Coeff	
	R+2	[50 to 250/116/1%[

2436	Set:ITB K:R Coeff	
	R+3	[50 to 250/136/51%]

	2451	Set:ITB C:Standard	
5 FC [0 to 70/34/0.1uA]		[0 to 70/34/0.1uA]	
	21	Non Image	[0 to 70/5/0.1uA]

2501	Set:ITB M:Standard	
5	FC	[0 to 70/36/0.1 uA]
21	Non Image	[0 to 70/5/0.1 uA]

2551	Set:ITB Y:Standard	
5	FC	[0 to 70/38/0.1 uA]
21	Non Image	[0 to 70/5/0.1 uA]

2661	Set:ITB Col:Eng Spd Coeff	
5	100%:FC [10 to 200/100/1 %]	
21	100%:Non Image	

2662	Set:ITB Col:Eng Spd Coeff	
5	70%:FC	[10 to 200/70/1 %
21	70%:Non Image	

2663	Set:ITB Col:Eng Spd Coeff	
5	50%:FC	[10 to 200/50/1 %]
21	50%:Non Image	

2665	Set:SepDC:Standard	
21	Non Image	[0 to 10/1/0.1 uA]

2666	Set:SepDC:Eng Spd Coeff	
1	100%	[10 to 200/100/1 %]
2	70%	[10 to 200/70/1 %]
3	50%	[10 to 200/50/1 %]

2667	Set:SepAC:Standard
------	--------------------

Non Image	[8 to 12/8.4/0.1 kV]
-----------	----------------------

2668	Set:SepAC:Eng Spd Coeff	
1	:100%	[10 to 200/100/1%]
2	:70%	[10 to 200/93/1%]
3	:50%	[10 to 200/88/1%]

2669	Set:SepDC:Env Coeff	
1	LLL:Bk:Side1	[10 to 200/100/1%]
2	LLL:Bk:Side2	
3	LLL:FC:Side1	
4	LLL:FC:Side2	
11	LL:Bk:Side1	
12	LL:Bk:Side2	
13	LL:FC:Side 1	
14	LL:FC:Side2	
21	ML:Bk:Side 1	
22	ML:Bk:Side2	
23	ML:FC:Side1	
24	ML:FC:Side2	
31	MM:Bk:Side1	
32	MM:Bk:Side2	
33	MM:FC:Side1	
34	MM:FC:Side2	
41	MH:Bk:Side1	
42	MH:Bk:Side2	
43	MH:FC:Side1	

44	MH:FC:Side2	
51	HH:Bk:Side1	
52	HH:Bk:Side2	
53	HH:FC:Side1	
54	HH:FC:Side2	

2670	70 Set:SepAC:Env Coeff	
1	LLL:Bk:Side1	[10 to 200/100/1%]
2	LLL:Bk:Side2	
3	LLL:FC:Side1	
4	LLL:FC:Side2	
11	LL:Bk:Side1	
12	LL:Bk:Side2	
13	LL:FC:Side1	
14	LL:FC:Side2	
21	ML:Bk:Side1	
22	ML:Bk:Side2	
23	ML:FC:Side1	
24	ML:FC:Side2	
31	MM:Bk:Side1	
32	MM:Bk:Side2	
33	MM:FC:Side1	
34	MM:FC:Side2	
41	MH:Bk:Side1	
42	MH:Bk:Side2	
43	MH:FC:Side1	

44	MH:FC:Side2	
51	HH:Bk:Side1	
52	HH:Bk:Side2	
53	HH:FC:Side1	
54	HH:FC:Side2	

2677	Set:Sep:L Edge Length	
1	Side 1	[-10 to 30/5/1 mm]
2	Side2	

2678	Set:Sep:T Edge Length	
1	Side 1	[-10 to +30/0/1 mm]
2	Side2	

2681	Set:ITB Col:R Coeff	
	R-2	[50 to 250/170/1%]

2682	Set:ITB Col:R Coeff	
	R-1	[50 to 250/152/1%]

2683	Set:ITB Col:R Coeff	
	RO	[50 to 250/136/1%]

2684	Set:ITB Col:R Coeff	
	RO	[50 to 250/124/1%]

2685	Set:ITB Col:R Coeff	
	R+2	[50 to 250/116/1%]

2686	Set:ITB Col:R Coeff	
	R+3	[50 to 250/106/1%]

2690	Set:PTR:Standard	
	Non Image	[0 to /0.83/1%]

2691	Set:PTR:R Coeff	
1	R-2	[50 to 300/225/1]
2	R-1	[50 to 300/185/1]
3	RO	[50 to 300/160/1]
4	R+1	[50 to 300/140/1]
5	R+2	[50 to 300/125/1]
6	R+3	[50 to 300/115/1]

2692	Set:RTR:Eng Spd Coeff		
1	100%	100% [10 to 200/100/1%]	
2	70%	[10 to 200/70/1%]	
3	50%	[10 to 200/50/1%]	

2693	Set:PTR:Env Coeff	
1	LLL:Bk:Side 1	[10 to 200/110/1 %]
2	LLL:Bk:Side2	[10 to 200/115/1 %]
3	LLL:FC:Side 1	[10 to 200/110/1 %]
4	LLL:FC:Side2	[10 to 200/115/1 %]
5	LLL:Non Image	[10 to 200/110/1 %]
11	LL:Bk:Side 1	[10 to 200/107/1 %]
12	LL:Bk:Side2	[10 to 200/112/1 %]

13	LL:FC:Side 1	[10 to 200/107/1 %]
14	LL:FC:Side2	[10 to 200/112/1 %]
15	LL:Non Image	[10 to 200/107/1 %]
21	ML:Bk:Side1	[10 to 200/105/1 %]
22	ML:Bk:Side2	[10 to 200/110/1 %]
23	ML:FC:Side1	[10 to 200/105/1 %]
24	ML:FC:Side2	[10 to 200/110/1 %]
25	ML:Non Image	[10 to 200/105/1 %]
31	MM:Bk:Side1	[10 to 200/100/1 %]
32	MM:Bk:Side2	[10 to 200/105/1 %]
33	MM:FC:Side1	[10 to 200/100/1 %]
34	MM:FC:Side2	[10 to 200/105/1 %]
35	MM:Non Image	[10 to 200/100/1 %]
41	MH:Bk:Side1	[10 to 200/90/1 %]
42	MH:Bk:Side2	[10 to 200/95/1 %]
43	MH:FC:Side1	[10 to 200/90/1 %]
44	MH:FC:Side2	[10 to 200/95/1 %]
45	MH:Non Image	[10 to 200/90/1 %]
51	HH:Bk:Side1	[10 to 200/85/1 %]
52	HH:Bk:Side2	[10 to 200/90/1 %]
53	HH:FC:Side1	[10 to 200/85/1 %]
54	HH:FC:Side2	[10 to 200/90/1 %]
55	HH:Non Image	[10 to 200/85/1 %]

2757	Paper Size:Coeff	
1	Weight 1:1st	[50 to 600/105/1]

2	Weight 2:1st	[50 to 600/110/1]
3	Weight 3:1st	[50 to 600/120/1]
4	Weight 4:1st	[50 to 600/135/1]
5	Weight 5:1st	[50 to 600/155/1]
6	Weight 6:1st	[50 to 600/190/1]
7	Weight 7:1st	[50 to 600/240/1]
11	Weight 1:2nd	[50 to 600/110/1]
12	Weight 2:2nd	[50 to 600/120/1]
13	Weight 3:2nd	[50 to 600/135/1]
14	Weight 4:2nd	[50 to 600/155/1]
15	Weight 5:2nd	[50 to 600/190/1]
16	Weight 6:2nd	[50 to 600/240/1]
17	Weight 7:2nd	[50 to 600/290/1]

2800	Set Paper Texture Mode	
1	Custom Paper 001	[0 to 1/0/1 Step]

2801	PTR AC Bias: Bk: 1st		
2802	PTR AC Bias: Bk: 2nd		
2803	PTR AC Bias: FC: 1st		
2804	PTR AC Bias: FC: 2nd		
1 to 100	Custom Paper 001 to 100	[0 to 12/8/0.1 kV]	

2805	PTR Bias	
1	AC	[0 to 12/8/0.1 kV]
2	DC	[-100 to -10/-25/0.1 kV]

2806	Set: PTR AC: Env Coeff	
1	LLL:Bk: Side 1	[10 to 200/110/1 %]
2	LLL:Bk:Side2	[10 to 200/105/1 %]
3	LLL:FC:Side 1	[10 to 200/110/1 %]
4	LLL:FC:Side2	[10 to 200/115/1 %]
5	LLL:Non Image	[10 to 200/115/1 %]
11	LL:Bk:Side 1	[10 to 200/107/1 %]
12	LL:Bk:Side2	[10 to 200/112/1 %]
13	LL:FC:Side1	[10 to 200/107/1 %]
14	LL:FC:Side2	[10 to 200/112/1 %]
15	LL:Non Image	[10 to 200/115/1 %]
21	ML:Bk:Side 1	[10 to 200/105/1 %]
22	ML:Bk:Side2	[10 to 200/110/1 %]
23	ML:FC:Side1	[10 to 200/105/1 %]
24	ML:FC:Side2	[10 to 200/110/1 %]
25	ML:Non Image	[10 to 200/105/1 %]
31	MM:Bk:Side1	[10 to 200/100/1 %]
32	MM:Bk:Side2	[10 to 200/105/1 %]
33	MM:FC:Side1	[10 to 200/100/1 %]
34	MM:FC:Side2	[10 to 200/105/1 %]
35	MM:Non Image	[10 to 200/110/1 %]
41	MH:Bk:Side1	[10 to 200/90/1 %]
42	MH:Bk:Side2	[10 to 200/95/1 %]
43	MH:FC:Side1	[10 to 200/90/1 %]
44	MH:FC:Side2	[10 to 200/90/1 %]
45	MH:Non Image	[10 to 200/115/1 %]

51	HH:Bk:Side1	[10 to 200/85/1 %]
52	HH:Bk:Side2	[10 to 200/90/1 %]
53	HH:FC:Side1	[10 to 200/85/1 %]
54	HH:FC:Side2	[10 to 200/90/1 %]
55	HH:Non Image	[10 to 200/115/1 %]

2807	Set: PTR AC: Eng Spd Coeff	
1	100% [10 to 200/100/1%]	
2	70% [10 to 200/70/1%]	
3	50% [10 to 200/50/1%]	

2808	AC Size Coeff	
1	Thresh1 [ 100 to 330 / 297 / 1 mm]	
2	Thresh2 [ 100 to 330 / 257 / 1 mm]	
3	Thresh3 [ 100 to 330 / 210 / 1 mm]	
4	Thresh4 [ 100 to 330 / 129 / 1 mm]	

1 to 7	Size1: Side1: Weight1 to 7	
11 to 17	Size1 : Side2 : Weight1 to 7	
21 to 27	Size2 : Side1 : Weight1 to 7	
31 to 37	Size2 : Side2 : Weight1 to 7	
41 to 47	Size3 : Side1 : Weight1 to 7	[50 to 300 / 100 / 1 %]
51 to 57	Size3 : Side2 : Weight1 to 7	[30 10 300 / 100 / 1 %]
61 to 67	Size4 : Side1 : Weight1 to 7	
71 to 77	Size4 : Side2 : Weight1 to 7	
81 to 87	Size5 : Side1 : Weight1 to 7	
91 to 97	Size5 : Side2 : Weight1 to 7	

2810	AC Size Coeff : R-1	
1 to 7	Size1: Side1: Weight1 to 7	
11 to 17	Size1 : Side2 : Weight1 to 7	
21 to 27	Size2 : Side1 : Weight1 to 7	
31 to 37	Size2 : Side2 : Weight1 to 7	
41 to 47	Size3 : Side1 : Weight1 to 7	[50, 200 / 100 / 1 %]
51 to 57	Size3 : Side2 : Weight1 to 7	[50 to 300 / 100 / 1 %]
61 to 67	Size4 : Side1 : Weight1 to 7	
71 to 77	Size4 : Side2 : Weight1 to 7	
81 to 87	Size5 : Side1 : Weight1 to 7	
91 to 97	Size5 : Side2 : Weight1 to 7	

2811	AC Size Coeff : R-0
------	---------------------

1 to 7	Size1 : Side1 : Weight1 to 7	
11 to 17	Size1 : Side2 : Weight1 to 7	
21 to 27	Size2 : Side1 : Weight1 to 7	
31 to 37	Size2 : Side2 : Weight1 to 7	
41 to 47	Size3 : Side1 : Weight1 to 7	[ 50 to 300 / 100 / 1 %]
51 to 57	Size3 : Side2 : Weight1 to 7	[3010300710071%]
61 to 67	Size4 : Side1 : Weight1 to 7	
71 to 77	Size4 : Side2 : Weight1 to 7	
81 to 87	Size5 : Side1 : Weight1 to 7	
91 to 97	Size5 : Side2 : Weight1 to 7	

2812	AC Size Coeff : R + 1	
1 to 7	Size1 : Side1 : Weight1 to 7	
11 to 17	Size1 : Side2 : Weight1 to 7	
21 to 27	Size2 : Side1 : Weight1 to 7	
31 to 37	Size2 : Side2 : Weight1 to 7	
41 to 47	Size3 : Side1 : Weight1 to 7	[504-200/100/19]
51 to 57	Size3 : Side2 : Weight1 to 7	[50 to 300 / 100 / 1 %]
61 to 67	Size4 : Side1 : Weight1 to 7	
71 to 77	Size4 : Side2 : Weight1 to 7	
81 to 87	Size5 : Side1 : Weight1 to 7	
91 to 97	Size5 : Side2 : Weight1 to 7	

2813	AC Size Coeff : R + 2
------	-----------------------

1 to 7	Size1 : Side1 : Weight1 to 7	
11 to 17	Size1 : Side2 : Weight1 to 7	
21 to 27	Size2 : Side1 : Weight1 to 7	
31 to 37	Size2 : Side2 : Weight1 to 7	
41 to 47	Size3 : Side1 : Weight1 to 7	[50 to 300 / 100 / 1 %]
51 to 57	Size3 : Side2 : Weight1 to 7	[3010300710071%]
61 to 67	Size4 : Side1 : Weight1 to 7	
71 to 77	Size4 : Side2 : Weight1 to 7	
81 to 87	Size5 : Side1 : Weight1 to 7	
91 to 97	Size5 : Side2 : Weight1 to 7	

2814	AC Size Coeff : R + 3	
1 to 7	Size1 : Side1 : Weight1 to 7	
11 to 17	Size1 : Side2 : Weight1 to 7	
21 to 27	Size2 : Side1 : Weight1 to 7	
31 to 37	Size2 : Side2 : Weight1 to 7	
41 to 47	Size3 : Side1 : Weight1 to 7	[50 to 300 / 100 / 1 %]
51 to 57	Size3 : Side2 : Weight1 to 7	
61 to 67	Size4 : Side1 : Weight1 to 7	
71 to 77	Size4 : Side2 : Weight1 to 7	
81 to 87	Size5 : Side1 : Weight1 to 7	
91 to 97	Size5 : Side2 : Weight1 to 7	

2815	LEdge Coeff AC: Bk	
1 to 100	Custom Paper 001 to 100	[0 to 250/100/1%]

2816	LEdge Coeff AC: FC
------	--------------------

		I				
1 to 1	00	Custom Paper 001 to 100 [0 to 250/100/1%]			/1%]	
2817		LEdge Length AC: BK				
1 to 1	00	Custom Paper 0	01 to 100 [0 to 30/5/1 mm]			nm]
0010			2.50			
2818		LEdge Length AC		_		_
1 to 1	00	Custom Paper 0	01 to 100	[0 to 30/	5/1 n	nm]
2819		TEdge Coeff AC	: Bk			
1 to 1	00	Custom Paper 0	01 to 100	[0 to 250	/100	/1 %]
0000		TE   0 " 10				
2820		TEdge Coeff AC	: FC			
1 to 1	00	Custom Paper 0	01 to 100	[0 to 250	/100	/1 %]
2821		TEdge Length AG	 ∩: Bk			
	00				1	
1 to 1		Custom Paper 0	0116100	00100	/ 0/ 1	mmj
2822		TEdge Length A	C: FC			
1 to 1	00	Custom Paper 0	01 to 100	[0 to 100	[0 to 100/8/1 mm]	
0000	1.0	DT C ACI				
2823		CPT: Sep AC 1st				. 0
1	We	eight 1	[8 to 12/8/1 0.01	kV]	1	52.3 - 63.0 g/m <sup>2</sup>
2	We	eight 2			2	63.1 - 80.0 g/m <sup>2</sup>
3	We	eight 3			3	80.1 - 105.0 g/m <sup>2</sup>
4	We	eight 4	jht 4		4	105.1 - 163.0 g/m <sup>2</sup>
5 Weight 5				5	163.1 - 220.0 g/m <sup>2</sup>	
6	6 Weight 6				6	220.1 - 256.0 g/m <sup>2</sup>
7 Weight 7				7	256.1 - 300.0 g/m <sup>2</sup>	

2824	AC PT: Sep AC 2nd			
1	Weight 1	[8 to 12/8/1 0.01 kV]	1	52.3 - 63.0 g/m <sup>2</sup>
2	Weight 2		2	63.1 - 80.0 g/m <sup>2</sup>
3	Weight 3		3	80.1 - 105.0 g/m <sup>2</sup>
4	Weight 4		4	105.1 - 163.0 g/m <sup>2</sup>
5	Weight 5		5	163.1 - 220.0 g/m <sup>2</sup>
6	Weight 6		6	220.1 - 256.0 g/m <sup>2</sup>
7	Weight 7		7	256.1 - 300.0 g/m <sup>2</sup>

28	30	AC Transcription Power Pack	RTB 4 (D074, ver 1.63:04) Default changed to 1	
		AC Transcription Power Pack	[0 to 1/0/1 step] 0:OFF 1:ON	

2840	SepDC:1st			
2841	SepDC:2nd			
2842	SepAC: 1st			
2843	SepAC: 2nd			
1 to 77	<pre><paper type="">: Weight<no.></no.></paper></pre>			
		The default settings (*) are displayed to the right of "Initial" on the screen.		
	Paper Type:	Plain, Glossy, Matte, Transparency, Translucent, Envelope		
	Weight (g/m²):	1 52.3 - 63.0		
		2 63.1 - 80.0		
		3 80.1 - 105.0		
		4 105.1 - 163.0 5 163.1 - 220.0		
		6	220.1 - 256.0	
		7	256.1 - 300.0	

2844		SepDC:LEdge:Coeff			
2845		SepDC:TEdge:Coeff			
2846		SepAC:LEdge:Coeff			
2847		SepAC:TEdge:Coeff			
	1 to 77	<paper type="">: Weight<no.></no.></paper>	[50 to 200/*/1%]		
			The default settings (*) are displayed to the right of "Initial" on the screen.		
		Paper Type:	Plain, Glossy, Matte, Transparency, Translucent, Envelope		
		Weight (g/m²):	1 52.3 - 63.0		
			2 63.1 - 80.0		
			3 80.1 - 105.0		
			4 105.1 - 163.0		
			5 163.1 - 220.0		
			6	220.1 - 256.0	
			7	256.1 - 300.0	

2850	PTR Bias:Bk		
1 to 77	<paper type="">: Weight<no.></no.></paper>	[-400 to 0/-40/1 uA]	
	Paper Type:	Plain, Glossy, Matte, Transparency, Translucent, Envelope	
	Weight (g/m²):	1 52.3 - 63.0	
		2	63.1 - 80.0
		3	80.1 - 105.0
		4	105.1 - 163.0
		5	163.1 - 220.0
		6	220.1 - 256.0

2851	PTR Bias: FC			
1 to 77	<paper type="">: Weight<no.></no.></paper>	[-400 to 0/-70/1 uA]		
	Paper Type:	Plain, Glossy, Matte, Transparency, Translucent, Envelope		
	Weight (g/m²):	1 52.3 - 63.0		
		2	63.1 - 80.0	
		3	80.1 - 105.0	
		4	105.1 - 163.0	
		5	163.1 - 220.0	
		6	220.1 - 256.0	
		7	256.1 - 300.0	

2852	LEdge Coeff:Bk			
2853	LEdge Coeff:FC			
1 to 77	<paper type="">: Weight<no.></no.></paper>	[5 to 300/*/1%] The default settings (*) are displayed to the right of "Initial" on the screen.		
	Paper Type:	Plain, Glossy, Matte, Transparency, Translucent, Envelope		
	Weight (g/m²):	1 52.3 - 63.0		
		2	63.1 - 80.0	
		3 80.1 - 105.0		
		4 105.1 - 163.0		
		5 163.1 - 220.0		
		6	220.1 - 256.0	
		7	256.1 - 300.0	

2854	LEdge Length:Bk		
2855	LEdge Length:FC		
1 to 77	<paper type="">: Weight<no.></no.></paper>	[0 to 30/*/1 mm]  The default settings (*) are displayed to the right of "Initial" on the screen.	
	Paper Type:	Plain, Glossy, Matte, Transparency, Translucent, Envelope	
	Weight (g/m²):	1	52.3 - 63.0
		2 63.1 - 80.0	
		3 80.1 - 105.0	
		4 105.1 - 163.0	
		5 163.1 - 220.0	
		6 220.1 - 256.0	
		7	256.1 - 300.0

2856		TEdge Coeff:Bk		
2857		TEdge Coeff:FC		
	1 to 77	<pre><paper type="">: Weight<no.> [5 to 300/100/1%]</no.></paper></pre>		0/100/1%]
		Paper Type:		ossy, Matte, Transparency, ent, Envelope
		Weight (g/m²):	1	52.3 - 63.0
			2	63.1 - 80.0
			3	80.1 - 105.0
			4	105.1 - 163.0
			5	163.1 - 220.0
			6	220.1 - 256.0
			7	256.1 - 300.0

TEdge Length:Bk		
TEdge Length:FC		
<paper type="">: Weight<no.> [0 to 100/8/1 mm]</no.></paper>		/8/1 mm]
Paper Type:		ossy, Matte, Transparency, nt, Envelope
Weight (g/m²):	1	52.3 - 63.0
	2	63.1 - 80.0
	3	80.1 - 105.0
	4	105.1 - 163.0
	5	163.1 - 220.0
	6	220.1 - 256.0
	7	256.1 - 300.0
	TEdge Length:FC <paper type="">: Weight<no.>  Paper Type:</no.></paper>	TEdge Length:FC <paper type="">: Weight<no.>  [0 to 100]  Paper Type:  Plain, Gla Transluce  Weight (g/m²):  1  2  3  4  5  6</no.></paper>

2880	PTR Speed Control: 100%		
2881	PTR Speed Control:70%		
2882	PTR Speed Control:50%		
	Weight (g/m²):	1	52.3 - 63.0
		2	63.1 - 80.0
		3 80.1 - 105.0	
		4 105.1 - 163.0	
	5 163.1 - 220.0		163.1 - 220.0
		6 220.1 - 256.0	
		7 256.1 - 300.0	
1	Plain: Weight 1	[-0.5 to 0.5/0/0.1 %]	
2	Plain: Weight 2	[-0.5 to 0.5/-0.1/0.1 %]	
3	Plain: Weight 3	[-0.5 to 0.5/-0.2/0.1 %]	

4	Plain: Weight 4	[-0.5 to 0.5/-0.3/0.1 %]
5	Plain: Weight 5	[-0.5 to 0.5/-0.4/0.1 %]
6	Plain: Weight 6	[-0.5 to 0.5/-0.5/0.1 %]
7	Plain: Weight 7	[-0.5 to 0.5/-0.5/0.1 %]
12	Glossy: Weight 2	[-0.5 to 0.5/-0.3/0.1 %]
13	Glossy: Weight 3	[-0.5 to 0.5/-0.3/0.1 %]
14	Glossy: Weight 4	[-0.5 to 0.5/-0.3/0.1 %]
15	Glossy: Weight 5	[-0.5 to 0.5/-0.4/0.1 %]
16	Glossy: Weight 6	[-0.5 to 0.5/-0.5/0.1 %]
17	Glossy: Weight 7	[-0.5 to 0.5/-0.5/0.1 %]

2883	PTR Speed Control	
1	Env Coeff: LLL [-0.5 to 0.5/0.2/0.1%]	
2	Env Coeff: LL	[-0.5 to 0.5/0.1/0.1%]
3	Env Coeff: ML	[-0.5 to 0.5/0/0.1%]
4	Env Coeff: MM	[-0.5 to 0.5/0/0.1%]
5	Env Coeff: MH	[-0.5 to 0.5/-0.1/0.1%]
6	Env Coeff: HH	[-0.5 to 0.5/-0.2/0.1%]

2904	Prevent Blade Bending		
	Do this SP to create a pattern on the drum at prescribed intervals to prevent the cleaning blade from bending.		
1	Pattern Create Interval [0 to 200/0/1 Page]		
2	Pattern Light Intensity [0 to 15/5/1]		
3	Op Pg Count Display	[0 to 200/0/1 Page]	
4	Set Operation Temp	[0 to 50/40/1 deg]	

2905	Non-stop Used Tnr Bottle Replacement		
	Do this SP to set the upper limit for level of used toner in the used toner bottle to trigger a bottle full alert.		
1	Savings Time Threshold Value [0 to 999/300/1 sec.]		
2	Discharge Time Threshold Value	[0 to 999/180/1 sec.]	
3	Savings Time Count	[0 to 999/0/1 sec.]	
4	Discharge Time Count		

2906	Stop Time Reverse Ctrl		
	The SP code sets the stop/reverse action of the ITB driver motor.		
1	Set Rev Execute: ImgTrans	[0 to 1/0/1]	
2	Set Rev Execute: PaperTrans	0:OFF 1:ON	
3	Set Rev Execute Interval	[1 to 500/30/1 m]	
4	Assign Execution	[0 to 1/0/1] 0:OFF 1:ON	
5	Set Execute Interval	[1 to 500/250/1 m]	
6	Op Time Setting: ImgTrans	[10 to 500/30/10 msec]	
7	Op Time Setting: PaperTrans		

2907	ACS Switch Set		
	This SP sets the threshold for the number of continuous black prints to ACS switching.		
	Bk image count	[0 to 10/5/1 sheet]	

2909	ITB Lift		
	This SP affects the operation of ITB Lift Motor 2, the motor that lifts the right end of the ITB against the bottom of the K drum.		
	Lift ITB [0 to 1/0/1] 0: ON Lift operation on, 1: OFF no lift.		

2912	Encoder Sn:Adj Light		
------	----------------------	--	--

SP2912-2 RTB 139

	This SP adjusts the strength of the LED beam of the ITB feed-back sensors (main sensor and sub sensor).		
1	Adj Light Amt	[0 to 1/0/1]	
2	Light Amt Adj: Pass/Fail	[0 to 9/0/1]	
3	Vref_Disp: Main Setting	[0 to 2.45/0/0.01 V]	
4	Vref_Disp: Sub Setting		
5	Analog Out: Main: After F Adj	[0 to 5/0/0.01 V]	
6	Analog Out: Sub: After F Adj		

2913	Encoder Sn:Output Disp	
	This SP displays the averaged values for the analog output from the ITB feed-back sensors.	
1	Analog: Ave: Main	[0 to 255/0/0.01 V\
2	Analog: Max: Main	
3	Analog: Min: Main	
4	Analog: Ave: Sub	
5	Analog: Max: Sub	
6	Analog: Min: Sub	

2914	Encoder Sn:Get 1stPhase	
	These SP codes reset and initialize the ITB feed-back sensors.	
1	Get Phases: Execute All	[EXECUTE]
2	352.80 Line Speed: Execute	
3	246.96 Line Speed: Execute	
4	176.40 Line Speed: Execute	
5	352.80 Phase Disp/Set	[0 to 65 535/0/1]
6	246.96 Phase Disp/Set	
8	176.40 Phase Disp/Set	

2915	2915 Encoder Sn Ctrl Condition  These SP codes enables the scaled feed-back control and displays information about SC499. SC499 is issued when the ITB sensor that reads the encoded film strip on the front edge of the image transfer belt does not operate correctly. (The TDCU constantly monitors operation of the ITB with transfer feed-back control.)	
1	Scale FB Control Enable	[0 to 1/1/1]
2	SC499 Occurrences	[0 to 3/0/1]
3	MUSIC Executions After SC499	[0 to 1/0/1]

2916	Fail Predict Banner Disp	
	This SP switches the banner display on the operation panel for the failure prediction feature. Default: Off	
1	Code 01	[0 to 1/0/1]
2	Code 02	*0: Banner Disable (Code <b>No.</b> )
3	Code 03	1: Banner Enable (Code <b>No</b> .)
4	Code 04	Where <b>No.</b> = 01, 02, 03, 04, 05, 99
5	Code 05	
6	Code 99	

2920	Steering Control Roller		
	This SP must be executed after replacing the ITB. This SP initializes the position of the new belt on the rollers.		
1	Initialize Belt Position	[0 to 1/0/1]	
2	Stable Position of Steering Roller	[-200 to 200/0/1 step]	
3	Control ON/OFF	[0 to 1/1/1]	
4	MUSIC Belt Init: On/Off	[0 to 1/1/1]	
5	LED PWM of Belt Position Sensor	[0 to 80/70/0.1%]	
6	Threshold for Control Rock	[0 to 1000/30/1]	
7	Threshold for Sensor Error	[0 to 1/0.1/0.01 V]	

8	Threshold for PWM Control	[0 to 2/0.3/0.01 V]	
9	Sum of Sensor Output	[0 to 10/0/0.01 V]	
10	Ratio of Sensor Output	[-1 to 1/0/0.001]	

2949	Process Interval	
	This SP codes extends the ti	ime between the end of a job and when the machine shifts to
	Additional Time	[0 to 10/0/1 sec]

2950	Face Main Mag set & Adj Face Sub Mag set & Adj		
2951			
2952	Verso Main Mag set & Adj  Verso Sub Mag set & Adj		
2953			
	These SP codes set or adjust the magnification rate for Face (Recto right or odd numbered pages) and Verso (reverse or left pages even numbered pages) in the ma scan and sub scan directions.		
1 to 100	Custom Paper 001 to 100	[-08 to 0.8/0/0.025%]	

2970	PTR Bias:Bk	
1 to 100	Custom Paper 001 to 100	[-400 to 0/-34/1 uA]

2971	PTR Bias:FC	
1 to 100	Custom Paper 001 to 100	[-400 to 0/-52/1 uA]

2972 LEdge Coeff:Bk		LEdge Coeff:Bk	
	2973	LEdge Coeff:FC	
	1 to 100	Custom Paper 001 to 100	[50 to 300/100/1%]

2974	LEdge Length:Bk	
2975	LEdge Length:FC	

_		10 00/5/10 0
1 to 100	Custom Paper 001 to 100	[0 to 30/5/1 mm]
2976	TEdge Coeff:Bk	
2977	TEdge Coeff:FC	
1 to 100	Custom Paper 001 to 100	[5 to 300/100/1%]
	,	
2978	TEdge Length:Bk	
2979	TEdge Length:FC	
1 to 100	Custom Paper 001 to 100	[0 to 100/8/1 mm]
2981	PTR Speed Control	
1 to 100	Custom Paper 001 to 100	[-1 to +1/0/0.1 %]
2988	PT Gap Adjustment	
1 to 100	'	) to 3/0/1]
	0	:Auto 1:No 2:Weak 3:Strong
2990	ITB Bias:K:BK	
1 to 100	Custom Paper 001 to 100	[0 to 70/34/0.1 uA]
2991	ITB Bias:K:FC	
1 to 100	Custom Paper 001 to 100	[0 to 70/33/0.1 uA]
2992	ITB Bias:C:FC	
		[0 + 70 /24 /0 1
1 to 100	Custom Paper 001 to 100	[0 to 70/34/0.1 uA]
2993	ITB Bias:M:FC	
1 to 100	Custom Paper 001 to 100	[0 to 70/36/0.1 uA]
2994	ITB Bias:Y:FC	

1 to 100	Custom Paper 001 to 100	[0 to 70/38/0.1 uA]
2995	2nd Bias Coeff:BK	
2996	2nd Bias Coeff:FC	
1 to 100	Custom Paper 001 to 100	[50 to 150/100/1%]

## Z

## **Group 3000**

3011	Manual ProCon :Exe	
	Executes process control.	
1	Normal ProCon	[0 to 1/0/1]
2	Density Adjustment	
3	ACC RunTime ProCon	
4	Full MUSIC	
5	Normal MUSIC	

3012	ProCon OK?	
	Confirms that the previous execution manual process control ended successfully,.	
1	History:Last	[0 to 999 99 999/0/1
2	History:Last 2	
3	History:Last 3	
4	History:Last 4	
5	History:Last 5	
6	History:Last 6	
7	History:Last 7	
8	History:Last 8	
9	History:Last 9	
10	History:Last 10	

3020	Process Setup :Exe
	Execute this SP at installation after all the PCDU units, toner bottles, and developer for each unit have been installed. This SP code confirms that developer/toner is in the PCDU, initializes drum cleaning, initializes the TD sensor, and executes process control to initialize toner density for each color.

Execute: ALL	[0 to 1/0/1]
--------------	--------------

3024	Developer Fill :Exe	
	Fills the PCDU with developer/toner from the developer pack. This SP must be executed at installation for all PCDU units and after developer has been replaced in a PCDU.	
1	Execute: K	[0 to 1/0/1]
2	Execute: C	
3	Execute: M	
4	Execute: Y	
11	Drive Time Upper Limit	[0 to 255/30/1 sec]

3025	Dev Fill OK?	
	Displays the results of developer/toner filling executed with SP3024.	
	From Left: YMCK	[0 to 9999/0/1] Successful return: "1111"

3030	Init TD Sensor :Exe	
	These SP codes initialize the TD sensors mounted on the side of each PCDU. Adjustment of the Vt target settings is also possible. (Vt is the current output of the TD sensor.)	
1	Execute: ALL	[0 to 1/0/1]
2	Execute: COL	
3	Execute: K	
4	Execute: C	
5	Execute: M	
6	Execute: Y	
20	Agitatiton Time	[3 to 20/30/1]sec]
21	Initial TC	[1 to 15/7/0.1 wt%]
31	Vt Target:K	[0 to 5/2.7/0.01 V]

32	Vt Target:C	
33	Vt Target:M	
34	Vt Target:Y	

3031	TD Sens Init OK?	
	Displays the results of TD sensor initialization with SP3030.	
	From Left: YMCK	[0 to 9 999/0/1]
		Successful return: "1111"

3032	Cleaning Setup :Exe	
	Execute this SP at installation and after replacement of the cleaning unit.	
1	Execute: ALL	[0 to 1/0/1]
2	Execute: COL	
3	Execute: K	
4	Execute: C	
5	Execute: M	
6	Execute: Y	
21	A3 Page Cover	[0 to 100/6/1 Sheet]

3050	Force Tnr Supply :Exe		
	Force supplies toner to the sub hoppers of the selected color. You can also specify the amount of toner to be supplied.		
1	Execute: ALL	[0 to 1/0/1]	
2	Execute: COL		
3	Execute: K		
4	Execute: C		
5	Execute: M		
6	Execute: Y		

21	Supply Quantity: K	[0 to 5/1/0.1 wt%]
22	Supply Quantity: C	
23	Supply Quantity: M	
24	Supply Quantity: Y	

3051	Manual Toner Fill :Exe	
	Executes toner filling of all sub hoppers.	
	Execute:ALL	[0 to 1/0/1]

3070	M Pot.Sens Check :Exe	
	This SP checks the condition of each of the four potential sensors after installation at the factory. Use in the field to check the condition of the sensors.	
	All Colors	[EXECUTE]

3071	Pot.Sens Chk :Disp	
	Displays the results of the potential sensor check executed with SP3070.  • Vd is the reading of the unexposed surface of the drum by the potential sensor  • Vr is residual voltage, the slight trace of voltage that remains on the drum after the QL quenches the surface of the drum.	
1	Vd:K	[0 to 999/0/1 V]
2	Vd:C	
3	Vd:M	
4	Vd:Y	
11	Vr:K	
12	Vr:C	
13	Vr:M	
14	Vr:Y	
21	Voffset:K	

22	Voffset:C	
23	Voffset:M	
24	Voffset:Y	

3072	TD. Sens Check :Exe	
	Checks the condition of the TD sensors attached to the side of each PCDU. Executed at the factory after assembly. Use in the field to check the condition of the TD sensors.	
1	All Colors	[EXECUTE]

3073	TD.Sens Chk :Disp	
	Displays the results of the TD sensor check executed with SP3072.	
1	Vt:K	[0 to 1/0/0.01 V]
2	Vt:C	[0 to 5/0/0.01 V]
3	Vt:M	
4	Vt:Y	

31	100	TE Detect :Set	
		This SP switches the operation of the TE sensor off and on.	
		ON/OFF [0 to 1/0/1]	

3101	Toner Sta	Toner Status :Disp	
	Displays the amount of toner remaining for each color. Uses a descending 10-step scale: 10: Full, 2: Almost near-toner end, 1: Almost toner-end, 0: Toner end		
1	K	[0 to 10/10/1]	
2	С		
3	М		
4	Y		

3102	Toner Remains :Disp	
------	---------------------	--

	Sets the toner remain display to show the amount toner remaining as a percentage.		
1	% Remains:K	[0 to 100/0/1 %]	
2	% Remains:C		
3	% Remains:M		
4	% Remains:Y		
11	mg Remains:K	[0 to 999 999/0/0.1 mg]	
12	mg Remains:C		
13	mg Remains:M		
14	mg Remains:Y		
21	Tnr mg(NewBtl):K	[100 to 999 999/1 386 000/0.1 mg]	
22	Tnr mg(NewBtl):C		
23	Tnr mg(NewBtl):M		
24	Tnr mg(NewBtl):Y		
31	ImgArea:K	[0 to 999 999/0/1 cm <sup>2</sup> ]	
32	ImgArea:C		
33	ImgArea:M		
34	ImgArea:Y		
41	TnrRemainsCoef:K	[0 to 2.55/1.1/0.1]	
42	TnrRemainsCoef:C	[0 to 2.55/1.13/0.1]	
43	TnrRemainsCoef:M	[0 to 2.55/1.05/0.1]	
44	TnrRemainsCoef:Y	[0 to 2.55/1.06/0.1]	
51	Feed Counter:K	[0 to 999 999/0/1 msec]	
52	Feed Counter:C		
53	Feed Counter:M		
54	Feed Counter:Y		

3110	TNE Detect (Lvl1) Set		
	This setting determines whether Step 1 for toner near-end is displayed, and allows you to select the percentage to trigger the display.		
1	OFF/ON	[0 to 1/10/1]	
11	Disp Timing:K	[10 to 100/10/1%]	SP3110-11 to -14 RTB 108: Default changed
12	Disp Timing:C		
13	Disp Timing:M		
14	Disp Timing:Y		

3120	TNE Detect(Lvl2) :Set		
	This setting determines whether Step 2 for toner near-end is displayed, and allows you to select the percentage to trigger the display.		
1	Set Cnt	[0 to 255/30/1 Counts]	
11	Cnt:K	[0 to 255/0/1 Counts]	
12	Cnt:C		
13	Cnt:M		
14	Cnt:Y		

3130	TE Detect :Set	
	This SP code allows you to set how long the machine can continue to operated after the toner near-end alert appears. This can be set to limit the number of prints by number of sheets, pixel count, or paper feed count.	
1	Set Sheets(Min)	[0 to 50/10/1 sheets]
2	Set Sheets(Max)	[0 to 5000/1000/1 sheets]
11	Page Cnt:K	[0 to 5000/0/1 sheets]
12	Page Cnt:C	
13	Page Cnt:M	
14	Page Cnt:Y	

21	Set Pxl Cnt	[0 to 1 000 000/15000/1 cm <sup>2</sup> ]
31	Pxl Cnt:K	$[0 \text{ to } 1  000  000/0/1 \text{ cm}^2]$
32	Pxl Cnt:C	
33	Pxl Cnt:M	
34	Pxl Cnt:Y	
41	Set Feed Cnt	[0 to 99 999 999/0/1 msec]
51	Feed Cnt:K	
52	Feed Cnt:C	
53	Feed Cnt:M	
54	Feed Cnt:Y	

3150	TE Sensor :Set	
	This SP sets up how the machine s	amples for toner-end sensor readings.
1	Sampling Count	[4 to 20/10/1 Count]
2	Judge: P	[0.2 to 0.8/0.6/0.1]

3152	Toner Pump CL :Set		
	This SP setting sets up on the toner pump clutch operates. (The toner pump clutch engages the toner pump to pump toner into the sub hopper.)		
1	On Time	[0 to 5000/400/1 msec]	
2	Off Time		
3	Recovery Times (Upper Limit)	[0 to 255/140/1 counts]	
10	Stop Timing :Set	[0 to 2000/0/1 counts]	
11	Cnt:K		
12	Cnt:C		
13	Cnt:M		
14	Cnt:Y		

3200	Tnr Density	
	Displays the toner density by wt% for each color.	
1	К	[0 to 25.5/0/0.1 wt%]
2	С	
3	М	
4	Y	

3201	Tnr Density	
	This SP sets the upper limit and lower limit of the range (wt%) for toner density control.	
1	Upper TC	[1 to 15/9.5/0.1 wt%]
2	Lower TC	[1 to 15/4/0.1 wt%]

3210	TD.Sens:Vt :Disp		
	This SP code displays the TD sensor outputs for all the items below.		
1-4	Current: K, C, M, Y	[0 to 5.5/0/0.01 V]	
2	Current: C		
3	Current: M		
4	Current: Y		

3220	Vtcnt: Disp/Set	
	These SP codes display and allow setting of the current electrical potential of the TD sensors for each color. Vcnt is the gain value is calculated during TD sensor initialization. It is used to adjust the TD sensor output (Vt). A large gain increases Vt, and a small gain decreases Vt. Vcnt is also used to calibrate the TD sensor output (Vt) during TD sensor initialization.	
1	Current: K	[2 to 5/3.72/0.01V]
2	Current: C	
3	Current: M	
4	Current: Y	

11	Initial: K	
12	Initial: C	
13	Initial: M	
14	Initial: Y	

3230	Vtref :Disp/Set	
	These SP codes display and allow settings of the target reference voltage of the TD sensor.  (Vtref is the control reference voltage.)	
1	Current: K	[0 to 5/2.7/0.01V]
2	Current: C	
3	Current: M	
4	Current: Y	
11	Initial: K	[0 to 5/0/0.01V]
12	Initial: C	
13	Initial: M	
14	Initial: Y	

3231	Vtref Limits :Set	
	This SP sets the upper limit for the target voltage of Vtref (control reference voltage).	
1	Upper:K	[0 to 5/4/0.01V]
2	Upper:C	
3	Upper:M	
4	Upper:Y	
11	Lower:K	[0 to 5/2/0.01V]
12	Lower:C	
13	Lower:M	
14	Lower:Y	

3250	ImgArea :Disp	
	Displays the amount of image surface area of the most recent page for the selected color.	
1	ImgArea:K	[0 to 9 999/0/1 cm <sup>2</sup> ]
2	ImgArea:C	
3	ImgArea:M	
4	ImgArea:Y	

3251	Dot Coverage : Disp	
	These SP codes display the percentage of the total area on the sheet used by the image for the most recent print, DC average, and total page information.	
1	DotCoverage:K	[0 to 100/0/0.01%]
2	DotCoverage:C	
3	DotCoverage:M	
4	DotCoverage:Y	
11	DC Avg.:S:K	[0 to 100/5/0.01%]
12	DC Avg.:S:C	
13	DC Avg.:S:M	
14	DC Avg.:S:Y	
21	DC Avg.:M:K	
22	DC Avg.:M:C	
23	DC Avg.:M:M	
24	DC Avg.:M:Y	
31	DC Avg.:L:K	
32	DC Avg.:L:C	
33	DC Avg.:L:M	
34	DC Avg.:L:Y	

41	TotalPage:S:Set	[1 to 255/50/1 sheets]
42	TotalPage:M:Set	[1 to 65 535/100/1 sheets]
43	TotalPage:L:Set	[1 to 65 535/1/1 sheets]

3260	Temp/Humid (PCU)		
	These SP codes display the temperature and humidity readings for the present conditions around the PCDUs.		
1	Temperature	[0 to 100/0/1 deg]	
2	Relative Humidity	[0 to 100/0/1 %RH]	
3	Absolute Humidity	[0 to 63/0/0.01 g/m3]	
4	Environ:Recent	[0 to 9/0/1]	

3261	Temp/Humid(Body)		
	These SP codes display the temperature and humidity readings for the present conditions in the main machine.		
1	Temperature	[0 to 100/0/1 deg]	
2	Relative Humidity	[0 to 100/0/1 %rH]	
3	Absolute Humidity	[0 to 63/0/0.01 g/m <sup>3</sup> ]	
4	Environ: Recent	[0 to 9/0/1]	

3262	Env Set: PCU	
	Force executes an immediate reading of temperature/humidity conditions around the PCDUs.	
1	Force Settings	[0 to 6/0/1]
		0:Sensor Detect
		1:LLL 2:LL 3:ML 4:MM 5:MH 6:HH

3263 Env Set:Body
-------------------

	Force executes an immediate reading of temperature/humidity conditions inside the machine.	
1	Force Settings	[0 to 6/0/1]
		0:Sensor Detect
		1:LLL 2:LL 3:ML 4:MM 5:MH 6:HH

3264	Env Thresh:PCU	
	These SP codes set the thresholds for humidity readings around the PCDUs.	
1	Abs Humid: 1	[0 to 100/0/0.01 g/m3]
2	Abs Humid:2	[0 to 100/5/0.01 g/m3]
3	Abs Humid:3	[0 to 100/10/0.01 g/m3]
4	Abs Humid:4	[0 to 100/18/0.01 g/m3]
5	Abs Humid:5	[0 to 100/25/0.01 g/m3]

3265	Env Thresh:Body		
	These SP codes set the thresholds for humidity readings inside the main machine.		
1	Abs Humid: 1	[0 to 100/2.5/0.01 g/m3]	
2	Abs Humid:2	[0 to 100/5/0.01 g/m3]	
3	Abs Humid:3	[0 to 100/8.4/0.01 g/m3]	
4	Abs Humid:4	[0 to 100/15/0.01 g/m3]	
5	Abs Humid:5	[0 to 100/25/0.01 g/m3]	

3300	ID Pattern :Disp	
	Displays the amount of toner on the drum at the ID sensor pattern created between sheets. M/A is the mass per area, or mass/unit area (mg/cm²). This is calculated based on the ID sensor output value (Vsp). M/A is calculated for each grade of color.	
1	M/A(Latest):K	[0 to 1/0/0.001 mg/cm2]
2	M/A(Latest):C	
3	M/A(Latest):M	

4	M/A(Latest):Y	
11	M/A(Target):K	[0 to 1/0.229/0.001 mg/cm2]
12	M/A(Target):C	[0 to 1/0.472/0.001 mg/cm2]
13	M/A(Target):M	[0 to 1/0.52/0.001 mg/cm2]
14	M/A(Target):Y	[0 to 1/0.472/0.001 mg/cm2]

3301	ID Pattern :Set  These SP codes set up how ID sensor patterns are created on the drum between sheets of paper. As shown below, the intervals can be set up as prints, page counts, fluctuations in M/A, feed counts, and so on.	
1	Create Intrvl:K	[0 to 200/10/1 pages]
2	Create Intrvl:C	
3	Create Intrvl:M	
4	Create Intrvl:Y	
11	Page Cnt:K	[0 to 200/0/1 pages]
12	Page Cnt:C	
13	Page Cnt:M	
14	Page Cnt:Y	
21	M/A UppErr:K	[0 to 1/0.4/ mg/cm2]
22	M/A UppErr:Col	[0 to 2/0.80/0.001 mg/cm2]
23	M/A LowErr:K	[0 to 1/0.1/0.001 mg/cm2]
24	M/A LowErr:Col	[0 to 1/0.2/0.10 mg/cm2]
31	Feed Cnt :Set	[0 to 9 999 999/5000/1 msec]
41	Feed Cnt :K	[0 to 9 999 999/3330/1 msec]
42	Feed Cnt :C	[0 to 9 999 999/261/1 msec]
43	Feed Cnt :M	[0 to 9 999 999/1594/1 msec]
44	Feed Cnt :Y	[0 to 9 999 999/637/1 msec]

51	Vsg Detect Intrvl	[0 to 200/10/1 pages]
61	Vsg Page Cnt	[0 to 200/0/1 pages]
70	Voffset reg	[0 to 99/3/1 times\
71	Voffset dif	[0 to 99/0/ 1 times\
72	Voffset TM(Front)	
73	Voffset TM(Center)	
74	Voffset TM(Rear)	

3310	ID Sens: Offset	
	Displays the amount of voltage used to light the ID sensor LED to create the ID sensor pattern on the drum.	
1	Offset Reg	[0 to 5.5/0/0.01V]
11	V_Offset Dif	
21	V_Offset TM Front	
22	V_Offset TM Center	
23	V_Offset TM Rear	

3311	ID.Sens :Vmin	
	Displays the Vmin output for black used in the gradation pattern.	
	Vmin_K	[0 to 5/0/0.01 V]

3320	Vsg Adj: Execute	
	ALL	[0 to 1/1/1]

|--|

Adjusts Vsg for B&W and the TM sensors. Vsg is the voltage measurement of the reflectivity of the bare transfer belt (ITB). There are three TM sensors mounted on the sensor array above the ITB. The front and rear sensors are MUSIC sensors. The middle sensor is also a MUSIC sensor but it also functions as the ID sensor. Throughout the service manuals these sensors are referred to as the rear MUSIC sensor, (middle) ID/ MUSIC sensor, and front MUSIC sensor. [0 to 5.5/3.84/0.01 V] 1 Vsg reg 11 Vsg dif [0 to 5.5/0/0.01 V] Vsg TM(Front) [0 to 5.5/3.83/0.01 V] 41 [0 to 5.5/3.84/0.01 V] Vsg TM(Center) 42 [0 to 5.5/3,82/0.01 V] Vsg TM(Rear)

3322	Adjusted Ifsg	
	Displays the reading of the ID sensor LED where the current was adjusted.	
1	Adjusted Ifsg	[0 to 50/7.2/0.1 mA]
11	Adjusted Ifsg	[0 to 50/6.4/0.1 mA]
21	Adjusted Ifsg	[0 to 50/6.2/0.1 mA]
22	Adjusted Ifsg	[0 to 50/7.2/0.1 mA]
23	Adjusted Ifsg	[0 to 50/6.6/0.1 mA]

3323	Vsg Adj OK?	
	These SP display a history of the results of Vsg adjustments.	
1	Latest	[0 to 999/0/1]
2	Latest 1	
3	Latest 2	
4	Latest 3	
5	Latest 4	
6	Latest 5	
7	Latest 6	

8	Latest 7	
9	Latest 8	
10	Latest 9	

3330	ID.Sens Coef :Disp	
1	K2(Latest)	[0 to 5/3.24/0.0001]
2	K5(Latest)	[0 to 5/2.56/0.0001]

3400	Toner Supply Type		
	These SP codes set the method of toner supply.		
	0: Fixed method		
	3: DANC (with Vtref correction)		
	4: DANC (without Vtref correction)		
	Note: DANC (Divided Area Noise Control)		
1	К	0:FIXED 3:DANC (Vt_ref Fixed) 4:DANC (Vt_ref Control)	
2	С	Default: 4	
3	М		
4	Υ		

3440	Fixed Supply Mode		
	This SP sets the toner supply rate for the Fixed Supply Mode.		
1	Fixed Rate : K		
2	Fixed Rate : C	[0 to 100 / 5 / 1 %]	
3	Fixed Rate : M		
4	Fixed Rate : Y		

3500	ImgQltyAdj :ON/OFF	
	These SP codes switch off and on the process control and MUSIC functions.	

1	ALL	[0 to 1/0/1]
2	ProCon	
3	MUSIC	
4	Init TD Sensor	

3520	ImgQltyAdj :Interval		
	This SP determines the interval for quality adjustment		
1	During Job	[0 to 100/30/1 Pages]	
2	During Stand-by	[0 to 100/10/1 min.]	

3521	Drum Stop Time :Disp		
	These SP codes display the last time the drums were used.		
1	Year	Year [0 to 99/0/1 year]	
2	Month [1 to 12/1/1 month]		
3	Day [1 to 31/1/1 day]		
4	Hour [0 to 23/0/1 hour]		
5	Minute [0 to 59/0/1 minute]		

3522	Drum Stop Environ :Disp	
	These SP codes display the temperature and humidity around the drum when last used.	
1	Temperature	[-1280 to 1270/0/0.1 deg]
2	Rel Humidity	[0 to 1000/0/0.1 %RH]
3	Abs Humidity	[0 to 1000/0/0.1 g/m3]

3529	ProCon Interval Control :Set		
	These SP codes are used to determine when process control executes automatically.		
1	Gamma Corr	[0 to 1/1/1] 0:ON 1:OFF	

2	Environ Corr	
3	Abs Hum Threshold	[0 to 99/4.3/0.1 g/m3]
4	Max Cnt Threshhold	[0 to 99/2/1 counts]
5	Exe Cnt	[0 to 255/0/1 counts]
6	Page Cnt: BW	[0 to 5000/0/1 sheets]
7	Page Cnt: FC	[0 to 5000/0/1 sheets]

3530	Power ON ProCon :Set	
	These SP codes set the conditions that trigger automatic execution of process control when the machine is switched on for a cold start.	
1	Non-use Time Setting	[0 to 1440/360/1 minute]
2	Temperature Range	[0 to 99/10/1 deg]
3	Relative Humidity Range	[0 to 99/50/1 %RH]
4	Absolute Humidity Range	[0 to 99/6/1 g/m3]
5	Interval:BW	[0 to 5000/0/1 sheets]
6	Interval:FC	
7	Page Cnt:BW	
8	Page Cnt:FC	

3531	Non-useTime Procon :Set	
	These SP codes set the conditions that trigger automatic execution of process control while the machine remains idle in standby mode.	
1	Non-use Time Setting	[0 to 1440/360/1 minute]
2	Temperature Range	[0 to 99/10/1 deg]
3	Relative Humidity Range	[0 to 99/50/1 %RH]
4	Absolute Humidity Range	[0 to 99/6/1 g/m3]
5	Maximum Execution Number	[0 to 99/10/1 times]

3532	Jobln Procon :Set	
	These SP codes set the conditions that trigger automatic execution of process control when the machine receives a new job.	
1	Non-use Time Setting	[0 to 1440/60/1 minute]
2	Temperature Range	[0 to 99/3/1 deg]
3	Relative Humidity Range	[0 to 99/10/1 %RH]
4	Absolute Humidity Range	[0 to 99/3/1 g/m3]

3533	Interrupt ProCon :Set	
	These SP codes set the conditions that trigger automatic execution of process control while the machine is printing.	
1	Interval: Set: BW	[0 to 5000/500/1 sheets]
2	Interval: Disp: BW	[0 to 5000/0/1 sheets]
3	Corr(Short): BW	[0 to 1/0/5/0.01]
4	Corr(Mid): BW	[0 to 1/1/0.01]
11	Interval: Set: FC	[0 to 5000/500/1 sheets]
12	Interval: Disp: FC	[0 to 5000/0/1 sheets]
13	Corr(Short): FC	[0 to 1/0.5/0.01]
14	Corr(Mid): FC	[0 to 1/1/0.01]

3534	JobEnd ProCon :Set	
	These SP codes set the conditions that trigger automatic execution of process control at job end.	
1	Interval: Set: BW	[0 to 5000/1000/1 sheets]
2	Interval: Disp: BW	[0 to 5000/0/1 sheets]
3	Corr(Short): BW	[0 to 1/0.75/0.01]
4	Corr(Mid): BW	[0 to 1/1/0.01]
11	Interval: Set: FC	[0 to 1000/1000/1 sheets]

12	Interval: Disp: FC	[0 to 5000/0/1 sheets]
13	Corr(Short): FC	[0 to 1/0.75/0.01]
14	Corr(Mid): FC	[0 to 1/1/0.01]

3539	Dev Agitating Time :Set	
	These SP codes set up the parameters that determine how the developer/toner is agitated in the development units.	
1	Time	[0 to 3000/0/1 sec]
10	ON/OFF(by RelHum)	[0 to 1/1/1] 0:ON 1:OFF
30	ON/OFF(by Non-use Time)	[0 to 1/0/1] 0:ON 1:OFF
50	ON/OFF(by Non-use Time)	[0 to 1/1/1] 0:ON 1:OFF

3554	Set Expel Dev Mode	
	These SP codes set the parameters for the expel toner function.	
1	Set Expel Dev Mode	[0 to 1/0/1] 0:ON 1:OFF
2	Execution Threshold Value: Run	[0 to 255/75/1 sec]
3	Execution Threshold Value: End	[0 to 255/15/1 sec]
4	Calculated Value: Half-Speed	[0 to 655.35/0.67/0.01 sec]
11	Required Expel Time: K	[0 to 655.35/0.00/0.01 sec]
12	Required Expel Time: C	
13	Required Expel Time: M	
14	Required Expel Time: Y	

3600	Select ProCon	
	These SP codes select the potential control method.	
1	Potential Control	[0 to 1/1/1] 0:FIXED 1:CONTROL
2	LD Control	

3	TC Adj. Mode	[0 to 3/2/1]
		0:Do Not Execute
		1:1st Power On
		2: 1st Power On & Job End
4	ACC Before ProCon	[0 to 3/2/1]
		0:Not Execute
		1:Process Control
		2:TC Control
5	TC Adj. Times	[1 to 10/5/1]
10	Active Potential Control	[0 to 1/1/1] 0:ON 1:OFF
20	Exe. Mode Select	[0 to 9/3/1]

3610	Chrg AC Control	
	These SP codes the AC control value that has been selected for potential AC control.	
1	Std Speed: K	[0 to 3/2.2/0.01 kV]
2	Std Speed: C	
3	Std Speed: M	
4	Std Speed: Y	

3611	Chrg DC Control		
	These SP codes display the DC drum charge bias determined for process control for the color and speed.		
	Mode Speed		
		Med.	246.96 mm/s
		Low	176.4 mm/s
		Std.	352.8 mm/s
1	Std Speed: K	[300 to 1000	0/450/1 -V]
2	Std Speed: C		

3	Std Speed: M	[300 to 1000/550/1 -V]
4	Std Speed: Y	
11	Mid Speed: K	[300 to 1000/450/1 -V]
12	Mid Speed: C	
13	Mid Speed: M	[300 to 1000/550/1 -V]
14	Mid Speed: Y	
21	Low Speed: K	[300 to 1000/450/1 -V]
22	Low Speed: C	
23	Low Speed: M	[300 to 1000/550/1 -V]
24	Low Speed: Y	

3612	Dev DC Control		
	These SP codes display the DC development charge bias determined for process control for the color and speed		
		Mode Speed	
		Med.	246.96 mm/s
		Low	176.4 mm/s
		Std.	352.8 mm/s
1	Std Speed: K	[200 to 800 <sub>/</sub>	/350/1 -V]
2	Std Speed: C		
3	Std Speed: M	[300 to 1000	0/450/1 -V]
4	Std Speed: Y		
11	Mid Speed: K	[300 to 1000	0/350/1 -V]
12	Mid Speed: C		
13	Mid Speed: M	[300 to 1000	)/450/1 -V]
14	Mid Speed: Y		

21	Low Speed: K	[300 to 1000/350/1 -V]
22	Low Speed: C	
23	Low Speed: M	[300 to 1000/450/1 -V]
24	Low Speed: Y	

3613	LD Power Control	
	These SP codes display the LD power determined for process control for standard speed (352.8 mm/s),	
1	Std Speed: K	[60 to 180/107/1 %]
2	Std Speed: C	[60 to 180/88/1 %]
3	Std Speed: M	[60 to 180/110/1 %]
4	Std Speed: Y	[60 to 180/107/1 %]

3620	ProCon Target M/A	
	These SP codes set Beta Coverage for each color.	
1	Maximum M/A:K	[0.25 to 0.75/0.45/0.001 mg/cm2]
2	Maximum M/A:C	
3	Maximum M/A:M	
4	Maximum M/A:Y	
11	Maximum M/A Adj.:K	[-5 to 5/0/1]
12	Maximum M/A Adj.:C	
13	Maximum M/A Adj.:M	
14	Maximum M/A Adj.:Y	
21	Maximum M/A Corr:K	[-0.15 to 0.15/0.000/0.001 mg/cm2]
22	Maximum M/A Corr:C	[-0.15 to 0.15/0.012/0.001 mg/cm2]
23	Maximum M/A Corr:M	
24	Maximum M/A Corr:Y	

3622	Dev Pot :Set	
	These SP codes display the background potential.	
1	К	[0 to 800/0/1 V]
2	С	
3	М	
4	Υ	
51	UpperLimit:K	[400 to 800/625/1 V]
52	UpperLimit:C	
53	UpperLimit:M	
54	UpperLimit:Y	
61	LowerLimit (K)	[0 to 400/200/1 V]
62	LowerLimit (C)	
63	LowerLimit (M)	
64	LowerLimit (Y)	

3623	LD Power Set	
	These SP codes set background potential for the four colors. The default is 100 V. If this setting is set too large, the carrier will not adhere.	
51	Line Width Adj.:K	[20 to 120/60/1 um]
52	Line Width Adj.:C	
53	Line Width Adj.:M	
54	Line Width Adj.:Y	
61	Line Width Adj.:K	[-5 to 5/0/1]-
62	Line Width Adj.:C	
63	Line Width Adj.:M	
64	Line Width Adj.:Y	

3624	TC Adj. Mode	
	These SP codes set the parameters for the range (upper and lower limits) for target gamma adjustment for process control toner density adjustment.	
1	Target(Upp Limit)	[0 to 1/0.15/0.01 mg/cm2/-kV]
2	Target(Lwr Limit)	[-1 to 0/-0.1/0.01 mg/cm2/-kV]
3	Maximum Counts	[1 to 50/5/1]
5	Force Consume Threshold	[1 to 6/1.9/0.01 mg/cm2/-kV]
6	Consume Pattern Area	[10 to 2550/250/10 cm2]
7	Consume(Upp Limit)	[0 to 16/8/1 times]
8	Force Supply Threshold	[0 to 1/1/0.65/0.01 mg/cm2/-kV]
9	Supply(Upp Limit)	[1 to 50/5/1 g]
10	Supply(Lwr Limit)	[1 to 50/1/1 g]

3630	Dev gamma :Disp/Set	
	These SP codes display information about the most recent development gamma settings.	
1	Current:K	[0.1 to 6/0.1/0.1 mg/cm2/-kV]
2	Current:C	
3	Current:M	
4	Current:Y	
11	Target:K	[0.5 to 2.55/0.5/.5 mg/cm2/-kV]
12	Target:C	
13	Target:M	
14	Target:Y	
21	Initial:K	[0.5 to 2.55/1.25/0.01 mg/cm2/-kV]
22	Initial:C	
23	Initial:M	

24	Initial:Y	
31	Env Cor.(ON/OFF)	[0 to 1/0/1]
32	TC Cor.(ON/OFF)	
41	Environ Corr:K	[-1 to 1/1/0.01 mg/cm2/-kV]
42	Environ Corr:Col	
51	TnrDensity Corr:K	[-1 to 1/0/0.01 mg/cm2/-kV]
52	TnrDensity Corr:C	
53	TnrDensity Corr:M	
54	TnrDensity Corr:Y	
61	TnrDensity:K	[0 to 25.5/0/0.1 wt%]
62	TnrDensity:C	
63	TnrDensity:M	
64	TnrDensity:Y	
71	Environ Corr1:K	[-1 to 1/-0.10/0.01 mg/cm2/-kV]
72	Environ Corr2:K	[-1 to 1/-0.05/0.01 mg/cm2/-kV]
73	Environ Corr3:K	[-1 to 1/0/0.01 mg/cm2/-kV]
74	Environ Corr4:K	[-1 to 1/0.05/0.01 mg/cm2/-kV]
75	Environ Corr5:K	[-1 to 1/0.1/0.01 mg/cm2/-kV]
76	Environ Corró:K	[-1 to 1/0.15/0.01 mg/cm2/-kV]
77	Environ Corr7:K	[-1 to 1/0.1/0.01 mg/cm2/-kV]
78	Environ Corr8:K	
81	Environ Corr1:Col	[-1 to 1/-0.10/0.01 mg/cm2/-kV]
82	Environ Corr2:Col	[-1 to 1/-0.05/0.01 mg/cm2/-kV]
83	Environ Corr3:Col	[-1 to 1/0/0.01 mg/cm2/-kV]
84	Environ Corr4:Col	[-1 to 1/0.05/0.01 mg/cm2/-kV]
85	Environ Corr5:Col	[-1 to 1/0.10/0.01 mg/cm2/-kV]

86	Environ Corró:Col	[-1 to 1/0.15/0.01 mg/cm2/-kV]
87	Environ Corr7:Col	[-1 to 1/0/0.01 mg/cm2/-kV]
88	Environ Corr8:Col	[-1 to 1/0/0.01 mg/cm2/-kV]
90	TC-Gamma	[0.1 to 0.25/0.12/0.01]
91	TC Corr Threshold:K	[7 to 12/9/0.1 wt%]
92	TC Corr Threshold:C	
93	TC Corr Threshold:M	
94	TC Corr Threshold:Y	

3631	Vk :Disp	Vk :Disp		
	These SP codes display the most recent development start voltages. Vk is the development start voltage. (One for each color.)			
1	К	K [-300 to +300/0/1 -V]		
2	С			
3	М			
4	Υ			

3641	Vd(700) :Disp		
	These SP codes display the values for OPC drum charge potential around the drum for:  • Averaged values for each color (with offset exposure)  • Maximum and minimum values  • Correction coefficients		
1	Average:K	[0 to 999/0/1 -V]	
2	Average:C		
3	Average:M		
4	Average:Y		
11	Max:K		
12	Max:C		

13	Max:M	
14	Max:Y	
21	Min:K	
22	Min:C	
23	Min:M	
24	Min:Y	
31	Corr Coef:K	[0.8 to 1.2/0.97/0.01]
32	Corr Coef:C	
33	Corr Coef:M	
34	Corr Coef:Y	

3642	Vr :Disp <b>DFU</b>	
	These SP codes display the residual potential for each drum. (Vr is the residual voltage, the slight trace of voltage that may remain after the drum is quenched by the QL.)	
1	K	[0 to 999/0/1]
2	С	
3	М	
4	Y	

3649	Pattern Pot: VI Disp		
	These SP codes display the value of the drum potential after maximum laser exposure by reading the white patches of the potential sensor patterns of KCMY.		
1	VI (P5): K		
2	VI (P5): C		
3	VI (P5): M		
4	VI (P5): Y		

3650	APC Set
------	---------

1 Interval [0 to 200/50/1 pages]	
----------------------------------	--

3820	Tnr Refresh Mode		
	These SP modes set the parameters for  Image area threshold value.  Amount of coverage  Maximum between patterns  Maximum job end pattern	r operation of the toner refresh mode:	
1	Img Area Thresh:K	[0 to 25.5/2/0.1 %]	
2	Img Area Thresh:C		
3	Img Area Thresh:M		
4	Img Area Thresh:Y		
11	K Amount	[0 to 65535/0/1 mm]	
12	C Amount		
13	M Amount		
14	Y Amount		
21	Max Between Pattern	[0 to 255/40/1 mm]	
22	Max Job End Pattern	[0 to 1000/100/1 mm]	

## **Group 4000**



 $\bullet$  These SP codes are for the D074/D075 only. They are unavailable for the M044.

4008	Sub Scan Magnification Adj	
	Adjusts the sub-scan magnification by changing the scanner motor speed.	
	[-1 to +1/0/0.1%]	

4010	Sub Scan Registration Adj		
	Adjusts the leading edge registration by changing the scanning start timing in the sub-scan direction.		
	[-3 to +3/0/0.1 mm]	RTB 121: Manual corrected	

4011	Main Scan Reg	
	Adjusts the side-to-side registration by changing the scanning start timing in the main scan direction.	
	Note: This adjustment is done for the ADF with SP6006 (ADF Reg. Adj.).	
	[-25 to +2.5/0/0.1 mm]	

4012	Set Scale Mask		
	These settings adjust the margins (erase margins) of the scanned area on the sheet. The leading, trailing, right, and left margins can be set independently.		
1	Book:Sub LEdge	[0 to 3/0/0.1 mm]	
2	Book:Sub TEdge		
3	Book:Main:LEdge		
4	Book:Main:TEdge		
5	ADF:Sub:LEdge		
7	ADF:Main:LEdge		
8	ADF:Main:TEdge		

4013	Scanner Free run	
	Performs the scanner free run with the exposure lamp on or off for full-color, full size (A3 or DLT).	
1	1 Book mode :Lamp Off [0 to 1/0/1]	
2	2 Book mode :Lamp On	

4014 Scan <b>DFU</b>		
	Touch [Execute] to execute one scanning operation with the scanner at the home position	
[0 to 1/4/1]		

4020	Dust Check	
	This feature checks the ADF exposure glass for dust that can cause black lines in copies. If dust is detected, a message is displayed, but the process does not stop.	
1	Dust Detect:On/Off	[0 to 1/0/1]
	Issues a warning if there is dust on the narrow scanning glass of the ADF when the original size is detected before a job starts. This function can detect dust on the white plate above to scanning glass, as well as dust on the glass. Sensitivity of the level of detection is adjusted with SP4020-002.  Note: Always clean the ADF scanning glass and the white plate above the scanning glass before you switch this setting on.	
2	Dust Detect:Lvl	[0 to 8/4/1]
	Adjusts the sensitivity for dust detection on the ADF scanning glass. This SP is available after SP4020-001 is switched on.	
	0: Off. No dust warning.	
	0> 4: Lower > Normal sensitivity	
	4> 8: Normal > High sensitivity	
	<ul> <li>If you see black streaks in copies when no warning has been issued, raise the setting to increase the level of sensitivity.</li> <li>If warnings are issued when you see no black streaks in copies, lower the setting.</li> <li>Dust that triggers a warning could move be removed from the glass by the originals in the feed path. If the dust is removed by passing originals, this is not detected and the warning remains on.</li> </ul>	

3	Dust Reject:Lvl	[0 to 4/0/1]
	Sets the level for vertical line correct exposure glass).	ion (the black vertical lines caused by dust on the ADF
	0: No vertical line correction.	
	1-4: Enables and sets the level for vertical line correction.	
	If you select a higher number, this can decrease unwanted lines caused by dust but can also erase thin vertical lines of the original.	

4301	Operation Check APS Sensor	
	[0 to 255/0/1]	

4303	Min Size for APS	
	Sets the minimum size of the original that the will be detected by APS (Auto Paper Select – with original width sensors) of the exposure glass of the flatbed scanner.	
	[0 to 2/0/1]	
	0: Unknown Document Size	
	1: A5 SEF (HLT SEF)	
	2: A5 LEF (HLT LEF)	

4305	8K/16K Detection	
	This SP enables the machine to recognize 8K/16K size paper automatically.	
	[0 to 3/0/1]	
	[0: Normal	
	1: A4 for LEF, LT for SEF	
	2: LT for LEF, A4 for SEF	
	3: 8KAI, 16 KAI	

4400	Org Edge Mask	
	This SP sets the mask area to remove shadows when scanning originals from the exposure glass in Book mode.	
	Note: "LE" denotes "leading edge" and "TE" denotes "trailing edge".	
1	Book:Sub:LEdge	[0 to 3/0/0.1 mm]

2	Book:Sub:TEdge	
3	Book:Main:LEdge	
4	Book:Main:Tedge	
5	ADF:Sub:LEdge	
7	ADF:Main:LEdge	
8	ADF:Main:TEdge	

4417	IPU Te	est Pattern		
	Use th	nis SP to select the IPU test pattern	to print.	
		Test Pattern [0 to 24/0/1]		
	0	Scanned Image	13	Grid Pattern CMYK
	1	Gradation Main Scan A	14	Color Patch CMYK
	2	Gradation Main Scan B	15	Gray Pattern (1)
	3	Gradation Main Scan C	16	Gray Pattern (2)
	4	Gradation Main Scan D	17	Gray Pattern (3)
	5	Gradation Sub Scan 1	18	Shading Pattern
	6	Grid Pattern	19	Thin Line Pattern
	7	Slant Grid Pattern	20	Scanned + Grid Pattern
	8	Gradation RGBCMYK	21	Scanned + Grayscale
	9	UCR Pattern	22	Scanned + Color Patch
	10	Color Patch 16 (1)	23	Scanned + Slant Grid C
	11	Color Patch 16 (2)	24	Scanned + Slant Grid D
	12	Color Patch 16 64		

4450	Scan Image Pass Selection	
	These SP codes switch the operation of black reduction and shading correction off/on.	
1	Black Subtraction ON/OFF [0 to 1/1/1]	

	Switches the black reduction function in scanner data off/on.		in scanner data off/on.
	2	SH ON/OFF	[0 to 1/1/1]
Switches shading reduction function in scanner data off/on.		in scanner data off/on.	

4460	Digital AE <b>DFU</b>	
	These SP codes set parameters for the AE function.	
1	Low Limit Value [0 to 1023/364/1]	
	This setting determines the lower limit for level of background to be skipped for the AE function. The higher the setting, the more background will be ignored.	
2	Background level	[512 to 1535/972/1]
	This setting determines the level	of background to be output for the AE function.

4490	FL Correction ON/OFF	
1	RED	[0 to 1/0/1]
2	GREEN	
3	BLUE	

4501	ACC Target Den <b>Not Used</b>	
	This SP sets the target density for the ACC adjustment for machines connected with the Copier Connection Kit.	
1	Copy:K:Text	[0 to 10/5/1]
2	Copy:C:Text	
3	Copy:M:Text	
4	Copy:Y:Text	
5	Copy:K:Photo	
6	Copy:C:Photo	
7	Copy:M:Photo	

8	Copy:Y:Photo	
---	--------------	--

4505	ACC Cor:Bright Not Used	
	Sets correction for bright areas for ACC correction.	
1	Master:K	[-128 to +127/0/1]
2	Master:C	
3	Master:M	
4	Master:Y	
5	Slave:K	
6	Slave:C	
7	Slave:M	
8	Slave:Y	

4506	ACC Cor:Dark <b>Not Used</b>	
	Sets correction for dark areas for ACC correction.	
1	Master:K	[-128 to +127/0/1]
2	Master:C	
3	Master:M	
4	Master:Y	
5	Slave:K	
6	Slave:C	
7	Slave:M	
8	Slave:Y	

4540	Print Coverage	
	This SP corrects printer coverage of 12 hues (RY, YR, YG, etc. x 4 Colors (K, C, M, Y) for a total of 48 parameters.	

1 st	<x>Phase<y></y></x>	[0 to 255/0/1]
2nd	<x>Phase<y></y></x>	[-256 to +255/0/1]
3rd	<x>Phase<y></y></x>	
4th	<x>Phase<y></y></x>	
055	BLACK G	[-256 to +255/8/1]
056	BLACK B	[-256 to +255/4/1]

4550	Scan Apli:Txt/Print		
4551	Scan Apli:Txt		
4552	Scan Apli:Txt Dropout		
4553	Scan Apli:Txt/Photo		
4554	Scan Apli:Photo		
4565	Scan Apli:GrayScale		
4570	Scan Apli:Col Txt/Photo		
4571	MTF: O(Off) 1-15 (Weak-Strong)		
4572	Scan Apli:AutoCol		
	These SP code share common parameters (see below).		
5	MTF: 0(Off) 1-15 (Weak-Strong) [0 to 15/8/1]		
	Sets the MTF level (Modulation Transfer Function) designed to improve image contrast. Set higher for stronger effect, lower for weaker effect.		
6	Smoothing: 0(x1) 1-7 (Weak-Strong)	[0 to 7/4/1]	
	Use to remove "jaggies" if they appear. Set higher for smoother.		
7	Brightness: 1-255 [1 to 255/128/1]		
	Set higher for darker, set lower for lighter.		
8	3 Contrast: 1-255 [1 to 255/128/1]		
	Set higher for more contrast, set lower for less contrast.		

9	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	[0 to 7/0/1]
	Use to remove individual dots in the background if the more background.	ey appear. Set higher for removal of

4600	SBU Version Display	
	These SP codes display the readings of four ID codes read during automatic adjustment of the SBU every time the machine is turned on. An incorrect ID reading issues SC144.	
1	SBU_ID	[0 to 255/0/1]
	Displays the ID code (1-byte hexadecimal) read for the SBU.	
2	GASBU-N_ID	[0 to 255/0/1]
	Displays the ID code (1-byte hexadecimal) read for the GASBU-N.	
3	VSP_F_ID	[0 to 255/0/1]
	Displays the ID code (1-byte hexadecimal) read for the VSP5100_F.	
4	VSP_L_ID	[0 to 255/0/1]
	Displays the ID code (1-byte hexadecimal) read for the VSP5100	

### 4602 Scanner Memory Access DFU

4609	Gray Balance Adj Value R <b>DFU</b>	
4610	Gray Balance Adj Value G <b>DFU</b>	
4611	Gray Balance Adj Value B <b>DFU</b>	
	These SP codes display the reference voltages stored in NVRAM at the factory for Red, Green, and Blue before the machine was shipped. The SBU acquires these settings every time the machine is switched on.	
1	Book Scan [0 to 1023 / 512 / 1 Step]	
2	DF Scan [0 to 255 / 97 / 1 Step]	

4623	Black Level Adj Value <b>DFU</b>		
4624	Black Level Adj Value <b>DFU</b>		
4625	Black Level Adj Value <b>DFU</b>		
4628	Analog Gain Adj Value <b>DFU</b>		
4629	Analog Gain Adj Value <b>DFU</b>		
4630	Analog Gain Adj Value <b>DFU</b>		
4631	Digital Gain Adj Value <b>DFU</b>		
	When switched on, this SP displays the current range for the E (EVEN) or O (ODD) in the ASCI on the SBU after white level adjustment every time the machine is switched on.		
4632	Digital Gain Adj Value <b>DFU</b>		
	When switched on, this SP displays the current range for E (EVEN) or O (ODD) gain of GREEN or B/W in the ASCI on the SBU after white level adjustment every time the machine is switched on.		
4633	Digital Gain Adj Value <b>DFU</b>		
	When switched on, this SP displays the current range for E (EVEN) or O (ODD) gain of GREEN or B/W in the ASCI on the SBU after white level adjustment every time the machine is switched on.		
4635	SSCG Noise Cancel <b>DFU</b>		
	Switches SSCG noise cancellation on/off. 0: Off, 1: On		
1	Correction ON/OFF	[0 to 1/1/1]	
2	Adj ON/OFF		
I		j	

4636	SSCG Correction <b>DFU</b>
4637	SSCG Correction Adj Value <b>DFU</b>
4638	SSCG Correction Adj Value <b>DFU</b>

4639	SSCG Correction Adj Value <b>DFU</b>			
4640	SSCG Noise Size <b>DFU</b>			
4646	Scan Adjust Error <b>DFU</b>			
4647	Scanner Hardware Error <b>DFU</b>			
4654	Black Level Adj Value <b>DFU</b>			
4655	Black Level Adj Value <b>DFU</b>			
4656	Black Level Adj Value <b>DFU</b>			
4658	Analog Gain Adj Value <b>DFU</b>			
4659	Analog Gain Adj Value <b>DFU</b>			
4660	Analog Gain Adj Value <b>DFU</b>			
4661	Digital Gain Adj Value <b>DFU</b>			
4662	Digital Gain Adj Value <b>DFU</b>			
4663	Digital Gain Adj Value <b>DFU</b>			
4673	Black Level Adj Value <b>DFU</b>			
4674	Black Level Adj Value <b>DFU</b>			
4675	Black Level Adj Value <b>DFU</b>			
4677	Analog Gain Adj Value <b>DFU</b>			

4678	Analog Gain Adj Value <b>DFU</b>

## 4679 Analog Gain Adj Value **DFU**

4680	Digital Gain Adj Value <b>DFU</b>
4681	Digital Gain Adj Value <b>DFU</b>
4682	Digital Gain Adj Value <b>DFU</b>
	When switched on, these SP codes display the settings done at the factory for Red (Green, Blue) O (ODD) and E (EVEN) gain in the ASIC on the SBU after white level adjustment every time the machine is switched on.

4690	White Level Peak Data R: FE <b>DFU</b>
4691	White Level Peak Data: G: FE <b>DFU</b>
4692	White Level Peak Data: B: FE <b>DFU</b>
	When switched on, these SP codes display E (EVEN) or O (ODD) for the white level peak Red (Green, Blue) data after white level detection (AGC) after the machine is switched on.

4693	Black Level Data R: FE <b>DFU</b>
4694	Black Level Data G: FE <b>DFU</b>
4695	Black Level Data B: FE <b>DFU</b>
	When switched on, these SP codes display E (EVEN) or O (ODD) for the black level check done in the SBU for RED after the machine is switched on.

4699	SBU Test Pattern: F			
	Selec	Selects the scan test pattern.		
1	Selec	ct Test Pattern	[0 to 4 / 0 / 1]	
	0	Normal Image Output		
	1	Fixed Value Output		
	2	Main Scan Gradation		
	3	Sub Scan Gradation		

	4	Grid Pattern	
2	2 Set Output Level		[0 to 1023/682/1]
3	Selec	t Test Pattern	[0 to 4 / 0 / 1]
	0	Normal Image Output	
	1	Fixed Value Output	
	2 Main Scan Gradation		
	3	Sub Scan Gradation	
	4	Grid Pattern	
4	Set Output Level		[0 to 1023/682/1]

4802	Scanner Free run	
	This SP sets the scanner in the free run mode for testing. The free run can be set with the exposure lamp off or on.	
1	DF mode :Lamp Off	[0 to 1/0/1]
2	DF mode :Lamp On	

4804	Home Position Operation	[0 to 1/0/1]	
	Touch [Execute] to do the home position operation once.		

4805	Scanner Carriage Retraction Operation	
	[0 to 1/0/1]	

4901	Background Erase Settings	
20	Org Density High Mode (Light) [-128 to 127/0/1 step]	
22	Org Density High Mode (Light)	
22	Org Density High Mode (Light)	

4902	Disp ACC Data				
------	---------------	--	--	--	--

	This SP outputs the final data read at the end of ACC execution. A zero is returned if there was an error reading the data.		
1	R_DATA1	Photo C Patch Level 1 (8-bit)	[0 to 255/0/1]
2	G_DATA1	Photo M Patch Level 1 (8-bit)	
3	B_DATA1	Photo Y Patch Level 1 (8-bit)	
4	R_DATA2	Photo C Patch Level 17 (8-bit)	
5	G_DATA2	Photo M Patch Level 17 (8-bit)	
6	B_DATA2	Photo Y Patch Level 17 (8-bit)	

lect Gradation Level
s SP changes the threshold parameters of error diffusion. to 255/0/1]

4918	Man Gamma Adj <b>DFU</b>	
1	Offset:Highlight	[0 to 30/15/1]
2	Offset:Middle	
3	Offset:Shadow	
4	Offset:IDmax	
5	Option:Highlight	[0 to 255/0/1]
6	Option:Middle	[0 to 12/0/1]
7	Option:Shadow	[0 to 255/0/1]
8	Option:IDmax	

4954	Read/Restore Std <b>DFU</b>		
	Use this SP to calibrate the scanner gamma on each machine connected with the Copier Connection Kit.		
1	Read New Chart [0 to 1/0/1]		
2	Recall Prev Chart		

3	Read Std Chart	
4	Set Std Chart	

4991	IPU Image Path Selection	
	Use this SP to use the 10-key pad to enter the number to determine the image path.	
	IPU [0 to 11/2/1]	
	O DFID input RGB images (upper 8 bits)	
	1 Synchronous RGB images in DFID	
	2 Data with shading correction on	
	3 Data with shading correction off	
	4 Data before black offset correction	
	5 Data after black offset correction	
	6 Shading data	
	7	Test pattern data (grayscale)
	8	RGB image after line interval correction
	9 RGB image after dot correction and pre-gamma	
	10 RGB image after vertiial line correction	
	11 RGB image after scanner gamma correction	

4993	High Light Correction <b>DFU</b>
4994	Adj Txt/Photo Recognition Level <b>DFU</b>
4996	White Paper Detection Level <b>DFU</b>

# **Group 5000**

5024	mm/inch Display Selection	CTL
	[0 to 1/0/1] 0: Europe/Asia (mm) 1: North America (inch)	
5051	Refill Toner Panel Display	CTL
	Switches refill toner display off and on.	
	[0 to 1/0/1] 0:ON 1:OFF	

5045	Accounting Counter	CTL		
	Selects the counting method.			
	Note: When the A3/DLT double count function is switched page is counted as 2 When SP5104-1 is switched ON, the items below cannot be set.			
	Counter method			
	[0 to 6/ * / -]			
1	Note:			
	For the D074/D075 the default is "0 Developments"			
For M044 the default is 1: Prints				
	0: Developments			
	1: Prints			
	2: Coverage			
	There are 5 counters for this selection: (1) Color Total, (2) (3, (5) B&W Total.	Color 1, (3) Color 2, (4) Color		
	Color 1, 2, 3 total the counts for KCMY.			
<ul> <li>Color 1 totals 0 to 5% coverage, Color 2 5% to 20% coverage, Color 3 m</li> <li>20% coverage.</li> </ul>				
	Color 1 and Color 2 can be adjusted with SP7855.			
	3: Not used			
	4: Not used			

#### 5: Developer (A3/DLT & Larger)

There are four counters for this selection: (1) Color (YMC) Development, (2) Black Development, (3) Color (YMC) (A3/DLT&Larger), (4) Black Development (A3/DLT&Larger).

- The number of prints for the colors used are counted.
- When four colors are used for four-color printing, the count is done "Color (YMC)
   Development: +3", and "Black Development: +1"
- The A3/DLT&Larger counts are done only for paper larger than A3 (wider than 420 mm)

#### 6: Prints (A3/DLT & Larger)

	Display IP Address	CTL	
	Switches the banner display of the IP address off and on. (Default: *Off)		
	[OFF] ON		
5055	For example, if this SP is switched on, the IP address will be displayed below "Ready" while the printer is in standby mode:		
	Ready		
	169.254.187.055		

	5056	Coverage Counter Display	CTL
		This SP switches the counter list for the system administrator on/off.	
		[0 to 1/0/1] 0: On 1: Off	

5062	Parts Replacement Banner		CTL
	[0 to 1/0/1] 0: Display Off, 1: Display On This SP codes switches the replacement parts banner on and off. Def OFF.	ault: Display	
	Notes:		
1 to 118	<ul> <li>This selection has no effect on the system alarm warnings.</li> </ul>		
	<ul> <li>Switching this SP on enables SP7624.</li> </ul>		
	<ul> <li>The setting of SP5066 affects what is displayed in the banner.</li> </ul>		
	<ul> <li>Related SP codes are SP5066-1, SP7624, and SP5067</li> </ul>		

5113 Optional Counter Type **Japan Only** 

5066		PM Parts Display	CTL
3000		[0 to 1/0/1] 0:No Display 1:Display	
5067		Switching of Print Application	CTL
1 to 1	118	[0 to 1/0/1]	
	Se	et Bypass Paper Size Display	CTL
3071		nis SP determines whether long paper can be fed from the bypass tray. elected only paper up to 432 mm can be used.  1 to 1 / 0 / 1] 0: Disable 1: Enable	Even if "1" is
5104	A3	/DLT Double Count : SSP	CTL
	Spe	ecifies whether the counter is double clicked for A3/DLT size prints.	
	Wł	nen you have to change this SP, ask your supervisor.	
	No	te: This SP cannot be changed if "5" or "6" is selected for SP5045.	
1	[0 1	to 2 / 0 / 1 /step]	
	0:1	NO (Normal count)	
	1:`	YES (Double count)	
	2: `	YES except By-pass (Normal count for unknown size)	

CTL

### Default Optional Counter Type [0 to 12/0/1]Selects the type of counter: 0: None 1: Key Card (RK3, 4) Japan Only 2: Key Card Down 3: Pre-paid Card 4: Coin Rack 5: MF Key Card 11: Exp Key Card (Add) 12: Exp Key Card (Deduct) External Optional Counter Type Enables the SDK application. This lets you select a number for the external device for user access control. Note: "SDK" refers to software on an SD card. 2 [0 to 3/0/1] 0: None 1: Expansion Device 1 2: Expansion Device 2 3: Expansion Device 3

5114	Optional Card IF	CTI	
	This SP code enables the interface for an optional counting device.  [0 to 8/0/1] Only settings that can be enabled for machines outside Japan are here.		
	0: Disabled		
	1: Key Cards (RK2, 3, 4)		
	2: Decrementing keycard		
	11: Incrementing key cards for use outside Japan		
	12: Decrementing key cards for use outside Japan		

	Disable Copying	CTL
	Temporarily denies access to the machine.	
5118	[0 to 1/0/1]	
	0: Release for normal operation	
	1: Prohibit access to machine	

5120	Mode Clear Count Removal	CTL
	For a machine that has a counting device, this SP sets the next action when a stops because the card is removed, the card is expired, or if the paper supply Japan Only	. , .
	[0 to 2/0/1 step]	
	0: Yes	
	1: Stand-by	
	2: No	

5121	Counter Up Timing	CTL
	Determines whether the optional key counter counts up at paper feed-in or at p	aper exit.
	[0 to 1/1/1]	
	0: Feed count	
	1: No feed count	

5126	Set F-size Document
	[0 to 2/0/1] 0:Foolscap 8.5x13 1:Folio 8.25x13 3:F 8 x 13

5127	APS Off Mode	CTL
	This SP can be used to switch APS (Auto Paper Select) off while a coin lock or possessed to the machine.	ore-paid
	[0 to 1/0/1] 0: On 1: Off	

5128	Code Mode With Key/Card Option Japan Only	CTL
5131	Paper Size Type Selection	

Selects the paper size type (for originals and copy paper). (Only needs to be adjusted if the optional printer controller is installed)

[0 to 2/1]

0: DOM (Japan)

1: NA (North America)

2: EU (Europe)

After changing the value, turn the main power switch off and on.

5150	Bypass Length setting	CTL
	[0 to 1 / 0 / 1 /-]	
	0: OFF: Enables up to the standard 480mm	
	1: ON: Enables up to 630mm	
	<ul> <li>Purpose. To switch the paper feeding control for paper sizes larg often used standard paper sizes(487.7mm in sub-scan direction)</li> </ul>	
	Basic Control.	
	<target direction)="" paper="" size(sub-scan=""></target>	
Paper sizes (Lp) of 487.7mm - 630mm.		
1	<target feed="" tray=""></target>	
	Multi By-pass Tray ONLY	
	Notes:	
	<ul> <li>Paper must be set one sheet at a time on the feed tray because the can not support these paper sizes.</li> </ul>	e end-fence
	Automatic duplexing must be disabled	
	Only face-up stacking is possible	
	The purge function for jams will be disabled	
	Side-to-side registration correction will be disabled	

5162	App. Switch Method	CTL
	Determines if the application screen changes with a hardware switch or a so	ftware switch.
	[0 to 1/0/1] 0: Soft Key Set 1: Hard Key Set	

5169	CE Login	CTL
------	----------	-----

This SP enables and disables the CE log in mode. With this SP enabled, the machine is in the CE (Customer Engineer/Service Technician) login mode.

In the CE login mode:

- The machine power can be turned off and on in the SP mode, and it will remain in the SP mode after power is restored.
- This SP is automatically reset to "0" (disabled) after the service technician closes the SP mode with the [Exit] soft button or after the log out timer expires.

Note: The Auto Logout Timer is in the "System Settings" of User Tools.

[0 to 1/0/1]

0: Disable, 1: Enable

0: CE login mode disabled.

1: CE login mode enabled.

5185	TCRU: Set Machine
	This SP code sets up the machine for the TCRU program. <b>Default</b> : OFF
	[0 to 1/0/1] 0:OFF 1:ON
	Note: The machine must be cycled on after changing this SP setting.

51	186	RK4
	This setting determines whether jam removal operation is enabled or disabled for RK4	
		[0 to 1/0/1] 0: Disable 1: Enable

5188	Copy NV Version DFU	C	TL
	This SP displays the NVRAM version to determine whether the Ninitialized. Used during debugging.	NVRAM has been	

5190	Unit Life Target Change	CTL	
		rmines whether counter reference values for the PM counter are set in the just mode or super operator adjust mode. The settings are used for display.	
[0 to 1/0/1] 0:Enable 1:Disable			

This SP selects the controller type. This setting needs to be done if an external controller is installed in the machine. [0 to 6/0/1]

0: No external controller installed

- 1: EFI controller
- 2: Ratio controller
- 3: Egret controller
- 4: GJ
- 5: Creo
- 6: QX-100

5195	Limitless Switch	CTL
	This SP selects the paper feed mode by switching between "pro" "tray priority (1). This SP operates only if the operator has select	
	O: <b>Productivity priority</b> . Switches from the current feed tray to the the machine detects the priority tray, even if paper still remains	' '
	1: <b>Tray priority</b> . Switches the feed tray only after the paper in the of paper.	e tray current tray runs out

5199	Paper Exit After Staple End	CTL
	This SP determines whether a machine that normally cannot cor staple supply runs can continue to operate.	ntinue to output paper if
	[0 to 1 / 0 / 1]	
	0: OFF. Paper cannot exit if no staples are available.	
	1: ON. Paper can exit with no staples.	

	5212	Page Numbering	CTL	
		This program adjusts the position of the second side page numbers.		
<ul> <li>A "– value" moves the page number positions to the position).</li> </ul>		<ul> <li>A "- value" moves the page number positions to the left ec position).</li> </ul>	lge or leading edge (high	
		<ul> <li>A "+ value" moves the page number positions to the right e position).</li> </ul>	edge or trailing edge (low	

3	Duplex Printout Right/Left Position
	[-10 to +10/0/1 mm] -10 (left, +10 (right)
4	Duplex Printout High/Low Position
	[-10 to +10/0/1 mm] -10 (left, +10 (right)

5227	Page Numbering	CTI	
220	Change Page No. Display		
	This SP code switches the job page number entry display on/off so you can enter a starting page number.  [0 to 1/0/1] 0: Disable 1: Enable		
221	Allow Page No. Entry		
	This SP code restricts the number of digits that can be entered in the job page number entry display. The default is 9 digits.  [2 to 9/9/1]		
222	Zero Surplus Setting		
	This SP code determines whether initial zeros numbers.  [0 to 1/0/1]  0: Do not suppress "0"	are displayed for one and two digit	
	1: Suppress "O"		

	Set Time	CTL			
	Sets the time clock for the local time. This setting is done at the factory before delivery.  The setting is GMT expressed in minutes.				
	[-1440 to 1440/1 min.]				
	AS: +480 (Hong Kong)				
5302	CH: +480 (Peking)				
	EU: +60 (Paris)				
	JA: +540 (Tokyo)				
	KO: +540 (Korea)				
	NA: -300 (NY)				
	TW: +480 (Taipei)				

5307	Summer Tir	me	CTL	
	Lets you set the machine to adjust its date and time automatically with the change to Daylight Savings time in the spring, and back to normal time in the fall. This SP lets you set these items:			
	• Day o	and time to go forward automatically in April		
	• Day o	and time to go back automatically in October		
	Set the	e length of time to go forward and back automatically		
	• The se	ettings for 2 and 3 are done with 8-digit numbers		
	Digits Meaning			
	1st, 2nd Month. 4: April, 10: October (for months 1 to 9, the first digit of 0 input, so the eight-digit setting for 2 or 3 becomes a seven-digit set			
	3rd Day of the week. 0: Sunday, 1: Monday			
	The number of the week for the day selected at the 3rd digit. If "0" is selected for "Sunday", for example, and the selected Sunday is the the 2nd week, then input a "2" for this digit.			
	5th, 6th	The time when the change occurs (24-hour as hex code).  Example: 00:00 (Midnight) = 00, 01:00 (1 a.m.) = 01, and	l so on.	
	7th	The number of hours to change the time. 1 hour: 1		

	8th	If the time change is not a whole number (1.5 hours for example), digit 8 should be 3 (30 minutes).
		Setting
	1	Enables/disables the settings for 2 and 3.
		0: Disable
		1: Enable
	3	Rule Set (Start)
		The start of summer time.
		Rule Set (End)
	4	The end of summer time.

5401	Access Control <b>DFU</b>	СТІ	
	These SP's store settings that limit uses access to SDK (Software Development Kit) application data.		
103	Default Document ACL		
104	Authentication Time		
	This SP sets the length of time allowed for au [1 to $255 / 0 / 1$ ] (0 = 60 sec. standard)	thentication.	
162	Extend Certification Detail		
200	SDK1 Unique ID		
201	SDK1 Certification Method		
210	SDK2 Unique ID		
211	SDK2 Certification Method	"SDK" is the "Software Development Kit".	
220	SDK3 Unique ID	This data can be converted from SAS (VAS) when installed or uninstalled. DFU	
221	SDK3 Certification Method		
230	SDK Certification Device		
240	Detail Option		

	User Code Count Clear	CTL
5404	Clears the counts for the user codes assigned by the key operator to restimachine. Press [Execute] to clear.	rict the use of the

<i>5 4</i> 11	LDAP Certification	CTL	
5411	This SP sets up LDAP certification.		
4	Easy Certification		
	When set to "1" does easy authentication according to the SP setting. [0 to $1\/\ 1\/\ 1$ ]		
5	Password Null Not Permit		
	This SP is referenced only when SP5411-4 is set to "1" (On).  [0 to 1/1/1]  0: Password NULL not permitted.  1: Password NULL permitted		
6	Detail Options		
	(7) 0000 0000 (0)		

5413	Lockout Setting	CTL
1	Lockout On/Off Switches on/off the lock on the local address book account.  [0 to 1/0/1]  0: Off 1: On	
2	Lockout Threshold  Sets a limit on the frequency of lockouts for account lockouts.  [1 to 10/5/1]	

	Cancellation On/Off
	Determines whether the system waits the prescribed time for input of a correct user ID and password after an account lockout has occurred.
3	[0 to 1/0/1]
	0: Off (no wait time, lockout not cancelled)
	1: On (system waits, cancels lockout if correct user ID and password are entered.
	Cancellation Time
4	Determines the length of time that the system waits for correct input of the user ID and password after a lockout has occurred. This setting is used only if SP5413-3 is set to "1" (on).
	[1 to 999/60/1 min.]

5414	Access Mitigation	CTL	
1	Mitigation On/Off		
	Switches on/off masking of continuously us	sed IDs and passwords that are identical.	
	[0 to 1/0/1]		
	0: Off		
	1: On		
2	Mitigation Time		
	Sets the length of time for excluding continuous access for identical user IDs and passwords.		
	[0 to 60/15/1 min.]		

5415	Password Attack		
1	Permissible Number		
	Sets the number of attempts to attack the system with random passwords to gain illegal access to the system.  [0 to 100/30/1 attempt]		
2	Detect Time		
	Sets the time limit to stop a password attack once such an attack has been detected. [1 to 10/5/1 sec.]		

5416	Access Information		
1	Access User Max Number		
	Limits the number of users used by the access exclusion and password attack detection functions.  [50 to 200/200/1 users]		
2	Access Password Max Number		
	Limits the number of passwords used by the access exclusion and password attack detection functions.  [50 to 200/200/1 passwords]		
3	Monitor Interval		
	Sets the processing time interval for referencing user ID and password [1 to 10/3/1 sec.]	information.	

5417	Access Attack	CTL
1	Access Permissible Number	
	Sets a limit on access attempts when an excessive number of attempt for MFP features.  [0 to 500/100/1]	s are detected
2	Attack Detect Time	
	Sets the length of time for monitoring the frequency of access to MFP [10 to 30/10/1 sec.]	features.
3	Productivity Fall Wait	
	Sets the wait time to slow down the speed of certification when an exof access attempts have been detected.  [0 to 9/3/1 sec.]	ccessive number
4	Attack Max Number	
	Sets a limit on the number of requests received for certification in ord the certification speed when an excessive number of access attempts detected.  [50 to 200/200/1 attempt]	

5420	User Authentication			CTL	
	These settings should be done with the System Administrator.  Note: These functions are enabled only after the user access feature has been enabled.				
1	Сору				
	Determines whether certification is required before a user can use the copy applications.  [0 to 1/0/1]  0: On				
	1: Off	or Security Setting			
2		Security Setting			
		applications refer to this SP setting to	limit th	e colors used.	
	Bit	Mode	Bit	Mode	
	0	B&W Mode	4	Auto Color	
	1	Single Color	5		
	2	2-Color	6		
	3	Full Color	7		
11	Document Server  Determines whether certification is required before a user can use the document server.  [0 to 1/0/1]  0: On  1: Off				
31	Scanner  Determines whether certification is required before a user can use the scan applications.  [0 to 1/0/1]  0: On  1: Off				

41	Printer  Determines whether certification is required before a user can use the printer applications.  [0 to 1/0/1]  0: On  1: Off		
51	SDK1	[0 1 / 0 / 1] 0. ON 1. OFF	
61	SDK2	[0 or 1/0/1] 0: ON. 1: OFF  Determines whether certification is required before a user can use	
71	SDK3	the SDK application.	

5430	Auth Dialog Message Change	
1	Message Change On/Off	
	[0 to 1 / 0 / 1]	
2	Message Text Download	
	Touch [EXECUTE].	
3	Message Text ID	

5431	External Auth User Preset	CTL
10	Tag	
11	Entry	
12	Group	
20	Mail	
32	Folder	
33	Protect Code	
34	SMTP Auth	
35	LDAP Auth	
36	SMB FTP Folder Auth	
37	Acnt Acl	

38	Document Acl
40	Cert Crypt

E 40 1	Authentication Error Code	CTL		
5481	These SP codes determine how the authentication failures are displayed.			
1	System Log Disp			
	Determines whether an error code appears in the system log after a user failure occurs.  [0 to 1/0/1]  0: Off	r authentication		
	1: On			
2	Panel Disp			
	Determines whether an error code appears on the operation panel after authentication failure occurs.  [0 to 1/1/1]  1: On	a user		
	0: Off			

5490	MF Keycard <b>Japan Only</b>	CTL	
1	Job Permit Setting		
	Sets up operation of the machine with a keycar	d.	
	<ul><li>[0 to 1/0/1]</li><li>0: Disabled. Cancels operation if no code is input.</li></ul>		
	1: Enabled. Allows operation if another code is input and decrements the counter once for use of the entered code.		
2	Count Mode Setting		

5501	PM Alarm	CTL
1	PM Alarm Level	

	[0 to 9999 / 0 / 1 step]
	0: Alarm off
	1 to 9999: Alarm goes off when Value (1 to 9999) > PM counter
2 Original Count Alarm	
	[0 to 1/0/1]
	0: No alarm sounds
	1: Alarm sounds after the number of originals passing through the ARDF > 10,000

	Jam Alarm	CTL
	Sets the alarm to sound for the specified jam level (document misfeeds are	e not included).
	[0 to 3 / 3 / 1 step]	
5504	0: Zero (Off)	
	1: Low (2.5K jams)	
	2: Medium (3K jams)	
	3: High (6K jams)	

	Error Alarm	CTL
5505	Sets the error alarm level.	
	[0 to 255 / 35 / 1 Step] (1 Step is 100 m)	

5507	Supply Alarm	CTL
1	1 Paper Supply Alarm	
	Switches the control call on/off for the paper supply.	
	[0 to 1/0/1]	
	0: Off, 1: On	
0: No alarm.		
	1: Sets the alarm to sound for the specified number transfer sheets for each paper size (A3, A4, B4, B5, DLT, LG, LT, HLT)	
2	2 Staple Supply Alarm	

	This SP determines whether the machine issues a supply alarm when the finisher runs out of staples.		
	[0 to 1/0/1]		
3	Toner Supply Alarm		
	Switches the control call on/	off for the toner end.	
	[0 to 1/0/1]		
	0: Off, 1: On		
	If you select "1" the alarm w	ill sound when the main machine detects toner end.	
6	Waste Toner Bottle Supply A	larm	
	This SP determines whether the [0 to 1/0/0] 0: No, 1: Yes	ne machine issues a supply alarm when the toner bottle is full.	
080	Toner Call Timing		
	This SP switches the toner sup	oply call for @Remote.	
	[0 to 1 / 0 / 1]  0: Toner replacement. Triggers the alarm when toner should be replaced with new toner		
	1: Toner near-end. The alarm triggers at toner-end or toner near-end.		
	Note: The "Interval nn" SP's below specify the paper control call interval for the referenced paper sizes.		
132	Interval: A3	[250 to 10000/1000/1 Step]	
133	Interval: A4		
134	Interval: A5		
141	Interval: B4		
142	Interval: B5		
160	0 Interval: DLT		
164	Interval: LG		
166	Interval: LT		
172	72 Interval: HLT		

5508	CC Call	CTL
------	---------	-----

1	Jam Remains	Enables/disables initiating a call.	
2	Continuous Jams	[0 to 1/1/1] 0: Disable, 1: Enable	
3	Continuous Door Open		
11	Jam Detection: Time Length		
	Sets the length of time to determine the length of an unattended paper jam.  [3 to 30/10/1]  This setting is enabled only when SP5508-4 is enabled (set to 1).		
12	2 Jam Detection: Continuous Count		
	Sets the number of continuous paper jams required to initiate a call.  [2 to 10/5/1]  This setting is enabled only when SP5508-4 is enabled (set to 1).		
13	Door Open: Time Length		
	Sets the length of time the remains opens to determine when to initiate a call.  [3 to 30/10/1]  This setting is enabled only when SP5508-4 is enabled (set to 1).		

5513	Parts Alarm Level Count		
	This SP sets the level for the alarm to sound for the PM parts listed under SP7617-1.		
1	Normal	[1 to 9 999/300/1 step]	
2	DF		

5514	Parts Alarm Level	CTL
	These SP codes determine how the parts alarm operates.	
1	1 Normal	
Turns on or off the parts replacement alarm for the number of paper.  [0 or 1 / 1 / -] 0: OFF, 1: ON		
2	2 DF	

Turns on or off the parts replacement alarm for the number of scanned originals. [0 or 1 / 0 / -] 0: OFF, 1: ON

	SC/Alarm Setting	CTL	
5515	Determines whether an SC call is issued when an SC error occurs while either CSS (Japan) or @Remote is enabled:		
3313	[0 to 1/1/1]		
	1: An SC call is issued when an SC error occurs.		
	0: An SC call is not issued when an SC error occurs.		
1	SC Call		
	Determines whether an SC call is issued when an SC error occurs while either @Remote is enabled:	CSS or	
	[0 to 1/1/1]		
	1: An SC call is issued when an SC error occurs.		
	0: An SC call is not issued when an SC error occurs.		
2	2 Service Parts Near End Call		
3	3 Service Parts End Call		
4	User Call		
6	Communication Test Call		
7	Machine Information Notice		
8	8 Alarm Notice		
10	0 Supply Automatic Ordering Call		
11	Supply Management Report Call		
12	Jam/Door Open Call		

5516 Individual PM Part Alarm Call		CTL	
1	Disable/Enable Setting (0:Not Sound 1:Send)	[0 to 1/0/1]	
4	Percent Yield for Triggering	[1 to 255/75/1]	

5517	Failure Prediction	CTL
	An imminent failure warning is issued whenever the machine issues a report at the number of printed pages prescribed by SP8581-1 (Total Counter). The number of pages can also be set with SP5517-2 below.	
1	Alarm On/Off Setting	
	Enables or disables the notification alarm for the @Remote.	
	[0 or 1 / 0 / 1]	
	0: Off, 1: On	
2	Alarm Interval	
	Specifies the alarm interval for the @Remote.	
	[0 to 1000 / <b>10</b> / 100 sheets/step]	

5610	Base Gamma Ctrl Pt:Execute	CTL
4	Get Factory Default	[0 to 1/0/1]
5	Set Factory Default	[0 to 1/100/1]
6	Restore Original Value	

5611	Toner Color in 2C	CTL
1	B-C	[0 to 128/100/1]
2	B-M	
3	G-C	
4	G-Y	
5	R-M	[0 to 128/0/1]
6	R-Y	

	Color Mode Display Selection	5618
--	------------------------------	------

2

This SP switches the color display for the operation panel LCD.

[0 or 1 / 1 / -]

0: Domestic Japan

1: Overseas (Outside Japan)

5711	Custom Setting Paper: Data Set	CTL
	The Paper Library must be installed when the machine is installed. These files (library.mqp and user.mqp) are available from the Firmware Download Center. A new function has been added to allow customers to backup the Saved Paper Library data onto an SD card with DOS (Data Overwrite Security). The files are located in the MQP folder and copied to the /mnt/usb3/mqp folder in flash memory.	
1	Standard Paper Data Upload	
	Basic paper data upload from SD card to main machine.	
2	Custom Paper Data Upload	
	Custom paper data upload from SD card to main machine.	
102	Custom Paper Data Download	
	Custom paper data download from main machine to SD card.	
201	Standard Paper Data Ver. (Flash)	
	This SP displays the version of Library.mqp (Paper Library) on the Flash ROM	
202	Standard Paper Data Ver. (SD Card)	
	This SP displays the version of Library.map (Paper Library) on the SD card.	

5715	Custom Paper: Thick		CTL
5716	Custom Paper: Thin		CTL
	This SP checks the type of machine to determine whether these paper sizes are supported. (These SP codes may appear even if the machine does not support these paper types.)		
1 to 100	ID1 to ID100		

5717	Custom Paper UP/Web Info. 1: P-Type	CTL
------	-------------------------------------	-----

5718	Custom Paper UP/Web Info.	CTL	
5719	Custom Paper UP/Web Info.	CTL	
5720	Custom Paper UP/Web Info. 4: Color		CTL
	This SP checks the type of machine to determine whether these paper sizes are supported. (These SP codes may appear even if the machine does not support these paper types.)		
1 to 100	ID1 to ID100		

5721	Custom Paper: Size Code		CTL
5722	Custom Paper: Width (M-Scan 0.1 mm)		CTL
5723	Custom Paper: (S-Scan 0.1 mm)		CTL
5724	Custom Paper: MQP Version		CTL
5725	Custom Paper: Data Type		CTL
	This SP checks the type of machine to determine whether these paper sizes are supported. (These SP codes may appear even if the machine does not support these paper types.)		
001 to 100	ID1 to ID100		

5731	Counter Effect Japan Only	CTL
	Change MK1 Cnt (Paper -> Combine)	

5789	Custom Paper Value Initialize		
	This SP clears the user paper settings selected by the user.  O: Clears all user paper settings.		
	1: Clears user paper settings 1		
1	Custom Paper	[0 to 100/0/1]	

5792	MCS Debug SW <b>DFU</b>
5793	ECS Debug SW <b>DFU</b>
	S .

	Memory Clear					
5801	Resets NVRAM data to the default settings. Before executing any of these SP's, print an SMC Report.					
1	All Clear					
	Initializes items 2 to 22 below.					
2	Engine					
	Initializes all registration settings for the engine and copy process settings.					
3	SCS/SRM					
	Initializes default system settings, SCS (System Control Service) settings, operation display coordinates, and ROM update information.					
4	IMH Memory Clr					
	Initializes the image file system. (IMH: Image Memory Handler)					
5	MCS					
	Initializes the automatic delete time setting for stored documents.					
	(MCS: Memory Control Service)					
6	Copier Application					
	Initializes all main machine application settings.					
8	Printer Application					
	Initializes the printer defaults, programs registered, the printer SP bit switches, and the printer CSS counter.					
9	Scanner Application					
	Initializes the defaults for the scanner and all the scanner SP modes.					
10	Web Service					
	Deletes the Netfile (NFA) management files and thumbnails, and initializes the Job login ID.					
	Netfiles: Jobs to be printed from the document server using a PC and the Desk Top Binder software					
11	NCS					

	Initializes the system defaults and intersection settings (IP addresses also), the Smart Net Monitor for Admin settings, Web Status Monitor settings, and the TELNET settings.  (NCS: Network Control Service)
14	Clear DCS Setting
	Initializes the DCS (Delivery Control Service) settings.
15	Clear UCS Setting
	Initializes the UCS (User Information Control Service) settings.
16	MIRS Setting
	Initializes the MIRS (Machine Information Report Service) settings.
17	CCS
	Initializes the CCS (Certification and Charge-control Service) settings.
18	SRM Memory Clr
	Initializes information in non-volatile RAM.
19	LCS Memory Clr
	Initializes information in non-volatile RAM.
20	Web Uapli
	Initializes the web user application settings.
21	ECS
	Initializes the ECS settings.

5803	Input Check			
5803-1	Trio2 s1 PB Reading			
	Bit	Component	0	1

	0	Not Used		
	1	Mechanical Counter	Unconnected	
	2	Paper Set SW	Set	Not Set
Dan E d 1	3	Width Sensor SW5	ON	OFF
Paper Feed 1	4	Width Sensor SW4	ON	OFF
	5	Width Sensor SW3	ON	OFF
	6	Width Sensor SW2	ON	OFF
	7	Width Sensor SW1	ON	OFF

5803-2	Trio2 s1 PC		Reading	
	Bit	Component	0	1
	0	2nd Tray Upper Limit Sensor	Normal	Overload
	1	1st Tray Upper Limit Sensor	Normal	Overload
	2	2nd Tray Feed Sensor	Paper Present	Paper Out
Paper Feed 2	3	2nd Tray Transport Sensor	Paper Present	Paper Out
	4	1st Tray Feed Sensor	Paper Present	Paper Out
	5	1st Tray Transport Sensor	Paper Present	Paper Out
	6	Vertical Transport Sensor	Paper Present	Paper Out
	7	Main Relay Sensor 1	Paper Present	Paper Out

5803-3	Trio2 s1 PD		Read	ing
	Bit	Component	0	1

	0	Purged Paper Sensor	No Paper	Paper Present
	1	2nd Tray Paper End Sensor	Paper Present	No Paper
	2	1st Tray Paper End Sensor	Paper Present	No Paper
Paper Feed 3	3	Lower Limit Sensor	Home Position	Down
	4	Paper Height Sensor 4	LOW	HIGH
	5	Paper Height Sensor 3	LOW	HIGH
	6	Paper Height Sensor 2	LOW	HIGH
	7	Paper Height Sensor 1	LOW	HIGH

5803-4		Trio2 s1 PH	Reading	
	Bit	Component	0	1
	0	Not Used		
	1	Left Tandem Set Sensor	Set	Not Set
	2	Left Tray Paper Sensor	Paper Present	No Paper
	3	Not Used		
Paper Feed 4	4	Right Tandem Set Sensor	Set	Not Set
	5	Right Tray Paper Sensor	No Paper	Paper Present
	6	Fusing Lamps ON2 Detect	OFF	ON
	7	Fusing Relays ON2 Detect	OFF	ON

5803-5		Trio2 s1 PI	Reading	
	Bit	Component	0	1

	0	2nd Tray Lift Motor Paper Height Sensor 1	ON	OFF
	1	2nd Tray Lift Motor Paper Height Sensor 2	ON	OFF
	2	Rear Side Fence Closed Sensor	LOW	HIGH
Paper Feed 5	3	Rear Side Fence Open Sensor	LOW	HIGH
	4	Front Side Fence Closed Sensor	LOW	HIGH
	5	Front Side Fence Open Sensor	LOW	HIGH
	6	Rear Fence Return Sensor	Out	In
	7	Rear Fence HP Sensotr	Not Home	Home

5803-6	Trio2 s2 PD		Reading	I
	Bit	Component	0	1
	0	Duplex Trans Sensor 1	Paper Present	No Paper
	1	Duplex Trans Sensor 2	Paper Present	
	2	Duplex Trans Sensor 3	Paper Present	
D	3	Duplex Trans Sensor 6	Paper Present	
Paper Feed 6	4	Duplex Trans Sensor 7	Paper Present	
	5	Not Used		
	6	Not Used		
	7	Not Used		

5803-7		Trio2 s2 PF	Reading	ı
	Bit	Component	0	1

Paper Feed 7	0	LCT Relay Sensor 2	Paper Present	No Paper
	1	LCT Relay Sensor 1	Paper Present	No Paper
	2	Main Relays Sensor 3	Paper Present	No Paper
	3	Main Relay Sensor 2	Paper Present	No Paper
	4	Bank Exit Sensor	Paper Present	No Paper
	5	Reg. Timing Sensor	Paper Present	No Paper
	6	Shift Unit HP Sensor	Not HP	At HP
	7	Gate Retract HP Sensor	Not HP	At HP

5803-8	Trio2 s3 PB		Reading	
	Bit	Component	0	1
	0	Transfer Timing Sensor	Paper Present	No Paper
	1	PTB Sensor	Paper Present	No Paper
	2	Fusing Belt Paper Sensor	Paper Present	No Paper
Paper Feed	3	Hot Roller Paper Sensor	Paper Present	No Paper
8	4	Fusing Exit Sensor	Paper Present	No Paper
	5	Exit Unit Entrance Sensor	Paper Present	No Paper
	6	Exit JG Sensor	Paper Present	No Paper
	7	Exit Relay Sensor	Paper Present	No Paper

5803-9	Trio2 s3 PC		Reading		
	Bit	Component	0	1	

	0	Exit Sensor	Paper Present	No Paper
	1	Invert/Duplex Sensor	Paper Present	No Paper
	2	Purge Relay Sensor	Paper Present	No Paper
Paper Feed	3	Pressure Roller Cam Position Sensor B	OFF	Malfunction
	4	Pressure Roller Cam Position Sensor A	UP	НР
	5	Web End Sensor	Normal	End
	6	Decurler Limit Sensor	Normal	Over Limit
	7	Decurler HP Sensor	At HP	Not HP

5803-11	Trio2 s1 PF		Reading	
	Bit	Component	0	1
	0	Not Used		
	1	2nd Tray Lift Motor	Normal	Error
	2	Bank Exit Motor	Normal	Error
Motor Error	3	Vertical Transport Motor	Normal	Error
Detect 1	4	2nd Grip Motor	Normal	Error
	5	1st Tray Transport Motor	Normal	Error
	6	2nd Paper Feed Motor	Normal	Error
	7	1st Tray Feed Motor	Normal	Error

5803-12	Trio2 s2 PG		Reading	
	Bit	Component	0	1

	0	Not Used		
	1	Not Used		
	'	1101 Osed		
Motor Error Detect 2	2	Registration Timing Motor	Normal	Error
	3	Shift Roller Motor	Normal	Error
	4	Shift Unit Motor	Normal	Error
	5	Registration Gate Motor	Normal	Error
	6	Registration Entrance Motor	Normal	Error
	7	Duplex Transport Motor 3	Normal	Error

5803-13	Trio2 s3 PH		Reading	
	Bit	Component	0	1
	0	Decurl Motor	Normal	Error
	1	Decurler Paper Transport Motor	Normal	Error
	2	Fusing Motor: Lock	Normal	Error
Motor Error	3	Pressure Roller Lift Motor	Normal	Error
Detect 3	4	Invert/Duplex Motor	Normal	Error
	5	Invert/Exit Motor	Normal	Error
	6	Exit Relay Motor	Normal	Error
	7	Duplex Transport Motor 1	Normal	Error

5803-14	Trio2 m1 PA		Reading		
	Bit	Component	0	1	

Motor Error Detect 4	0	Not Used		
	1	Paper Cooling Intake Fan: Lock	Error	Normal
	2	Not Used		
	3	Toner Supply Cooling Fan	Error	Normal
	4	Ozone Exhaust Fan (Y): Lock	Error	Normal
	5	Ozone Exhaust Fan (M): Lock	Error	Normal
	6	Ozone Exhaust Fan (C): Lock	Error	Normal
	7	Ozone Exhaust Fan (K): Lock	Error	Normal

5803-15	Trio2 m1 P2		Reading	
	Bit	Component	0	1
	0	Exit Exhaust Fan: Front: Lock	Error	Normal
	1	CIS Cleaning Fan: Lock	Error	Normal
	2	Exit Exhaust Fan: Rear: Lock	Error	Normal
Motor Error	3	Duplex Exhaust Fan: Rear: Lock	Error	Normal
Detect 5	4	Duplex Exhaust Fan: Front: Lock	Error	Normal
	5	Fusing Unit Exhaust Fan: Lock	Error	Normal
	6	Cooling Box Emission Exhaust Fan: Lock	Error	Normal
	7	Fusing Unit Transport Exhaust Fan: Lock	Error	Normal

5803-16		Trio2 m2 PI		ding	
	Bit	Component	0	1	

	0	Pressure Roller Fan: Lock	Error	Normal
	1	ITB Cleaning Fan: Lock	Error	Normal
Motor Error Detect ó	2	Not Used		
	3	ITB Intake Fan: Lock	Error	
	4	Controller Box Intake Fan 2: Lock	Error	Normal
	5	Controller Box Intake Fan 1: Lock	Error	Normal
	6	Cooling Box Heat Fan: Lock	Error	Normal
	7	Cooling Box Ozone Exhaust Fan: Lock	Error	Normal

5803-17	Trio2 m2 P3		Reading	
	Bit	Component	0	1
	0	ITB Intake Fan: Lock	Normal	Error
	1	Ozone Collection Fan	Error	Error
	2	Fusing Exit Exhaust Fan	Error	Error
Motor Error	3	Development Unit Cooling Fan 3: Lock	Error	Error
Detect 7	4	Development Unit Cooling Fan 2: Lock	Error	Error
	5	Development Unit Cooling Fan 1: Lock	Error	Error
	6	Heat Sink Exhaust Fan: Lock	Error	Error
	7	Heat Sink Intake Fan: Lock	Error	Error

5803-18		Trio2 m3 PA	Reading	
	Bit	Component	0	1

	0	Transfer Timing Motor: Lock	Normal	Error
	1	PTR/ITB Cleaning Motor: Lock	Normal	Error
	2	PTR Separation Motor: Lock	Normal	Error
Motor Error Detect 8	3	Not Used		
	4	Drum Motor (Y): Lock	Normal	Error
	5	Drum Motor (M): Lock	Normal	Error
	6	Drum Motor (C): Lock	Normal	Error
	7	Drum Motor (K): Lock	Normal	Error

5803-19	Trio2 m3 PB		Reading	
	Bit	Component	0	1
	0	Development Motor (Y): Lock	Normal	Error
	1	Development Motor (M): Lock	Normal	Error
	2	Development Motor (C): Lock	Normal	Error
Motor Error	3	Development Motor (K): Lock	Normal	Error
Detect 9	4	Drum Cleaning Motor (Y): Lock	Normal	Error
	5	Drum Cleaning Motor (M): Lock	Normal	Error
	6	Drum Cleaning Motor (C): Lock	Normal	Error
	7	Drum Cleaning Motor (K): Lock	Normal	Error

5803-20	Trio2 m3 PC		Reading	
	Bit	Component	0	1

Motor Error Detect 10	0	Belt Cleaning Exhaust Fan: Lock	Error	Normal
	1	Not Used		
	2	ITB AC Detection: Lock	Normal	Error
	3	Drive Exhaust Fan: Lock	Error	Normal
	4	Used Toner Bottle Motor: Lock	Normal	Error
	5	Toner Supply Motor: Lock	Normal	Error
	6	Used Toner Transport Motor: Lock	Normal	Error
	7	Stray Toner Intake Fan: Lock	Error	Normal

5803-21	Trio2 m1 PB		Reading	
	Bit	Component	0	1
	0	Toner Bottle Detection Sensor (Y)	Unlock	Lock
	1	Toner Bottle Detection Sensor (M)	Unlock	Lock
	2	Toner Bottle Detection Sensor (C)	Unlock	Lock
Toner Supply	3	Toner Bottle Detection Sensor (K)	Unlock	Lock
System	4	Toner End Sensor (Y)	No Toner	Toner
	5	Toner End Sensor (M)	No Toner	Toner
	6	Toner End Sensor (C)	No Toner	Toner
	7	Toner End Sensor (K)	No Toner	Toner

5803-22		Trio2 m1 PH	Reading	
	Bit	Component	0	1

_	0	CB Power Pack (Y/M): Y	Normal	Error
	1	CB Power Pack (Y/M): M	Normal	Error
	2	CB Power Pack (C/K): C	Normal	Error
High Voltage	3	CB Power Pack (C/K): K	Normal	Error
Error 1	4	Dev. Bias Check: Y	Normal	Error
	5	Dev. Bias Check: M	Normal	Error
	6	Dev. Bias Check: C	Normal	Error
	7	Dev. Bias Check: K	Normal	Error

5803-23	Trio2 m2 PA		Reading	
	Bit	Component	0	1
	0	Fusing Lamps ON 1 Check	OFF	ON
	1	Fusing Relays ON 1 Check	OFF	ON
	2	Separation Power Pack	Error	Normal
High Voltage	3	AC Transfer Power Pack	Error	Normal
Error 2	4	CB Power Pack (Y/M): Y	Error	Normal
	5	CB Power Pack (Y/M): M	Error	Normal
	6	CB Power Pack (C/K): C	Error	Normal
	7	CB Power Pack (C/K): K	Error	Normal

5803-24		Trio2 s2 Pl	Reading	
	Bit	Component	0	1

	0	Not Used		
	1	Not Used		
	2	Pressure Roller Thermistor: Front	Error	Normal
Fusing Error	3	Heating Roller Thermistor: Rear	Error	Normal
Detection	4	Hot Roller NC Sensor	Error	Normal
	5	Pressure Roller NC Sensor	Error	Normal
	6	Heating Roller NC Sensor: End	Error	Normal
	7	Heating Roller NC Sensor: Center	Error	Normal

5803-25		Trio2 m2 PF		ding
	Bit	Component	0	1
	0	O Used Toner Exhaust Fan: Lock		Normal
	1	Cooling Box Drive Exhaust Fan: Lock	Error	Normal
	2	2nd Lift Sensor 1 (K) Sensor	Up	Down
Used Toner	3	3 2nd Lift Sensor 2 (K) Sensor		Up
System	4	Used Toner Bottle Full Sensor	OFF	ON
	5	Used Toner Bottle Near-Full Sensor	OFF	ON
	6	Used Toner Bottle Door Sensor	Closed	Open
	7	Used Toner Bottle Set Sensor	Set	Not Set

5803-26		Trio2 m2 PG		Reading	
	Bit	Component	0	1	

	0	Not Used		
	1	Web Unit Set Sensor	Set	Not Set
	2	Right Drawer Set Sensor: Left	Set	Not Set
Set Detect 1	3	Right Drawer Set Sensor: Right	Set	Not Set
Sel Delect 1	4	Left Drawer Set Sensor 1	Set	Not Set
	5	Left Drawer Set Sensor 2	Set	Not Set
	6	Belt Cleaning Unit Set Switch	Set	Not Set
	7	Belt Cleaning Unit Cover Set Switch	Set	Not Set

5803-27		Trio2 s2 PH		Reading	
	Bit	Component	0	1	
	0	Key Counter Feedback	Not Present	Present	
	1	1 Key Counter Set		Not Set	
	2	Key Card Set	Set	Not Set	
Set Detect 2	3	Decurler Unit Set Switch	Set	Not Set	
	4	Exit Motor: Lock	Normal	Error	
	5	Not Used			
	6	Not Used			
	7	Transfer Timing Motor: Lock	Normal	Error	

5803-28		Trio2 m2 P8		Reading	
	Bit	Component	0	1	

	0	Not Used		
	1	Not Used		
	2	Not Used		
C 1 D 1 1 1 2	3	Cleaning Unit Set SW (Y)	IN	OUT
Set Detect 3	4	Cleaning Unit Set SW (M)	IN	OUT
	5	Cleaning Unit Set SW (C)	IN	OUT
6		Cleaning Unit Set SW (K)	IN	OUT
	7	Not Used		

5803-29		Trio2 m2 PC	Reading	
	Bit	Component	0	1
	0	24V Line Check: Fusing Motor, Decurler Motors)	Normal	Error
	1	24V Line Check: IOB	Normal	Error
	2	12V Line Check: IOB	Normal	Error
Power	3	24V Interlock Check: IOB	Normal	Error
Supply	4	24V Line Check: DRB, LDB	Normal	Error
	5	24V Line Check: Paper Bank Motors	Normal	Error
	6	5V Line Check: DRB	Normal	Error
	7	VS_Door Open Check	Closed	Open

5803-30	AD Value Display
Dbl-Feed Receptor	O to FFFFh

5803-31	Count Display	
CIS (Detect)	O to FFFFh	

5803-32	Count Display
---------	---------------

Used Toner Lock Sensor (Main)	0 to FFFFh (Cycles)

5803-33	Count Display	
Used Toner Bottle Lock Sensor	0 to FFFFh (Cycles)	

5803-34		TDCU Command Data Display	Reading	
	Bit	Component	0	1
	0	ITB Unit Set Switch	Set	Not Set
	1	Belt Centering Roller HP Sensor	LOW	HIGH
	2	1 st Lift Motor Sensor	LOW	HIGH
lmage	3	PTR Separation Sensor	LOW	HIGH
Transfer Unit	4	Rear Overrun Sensor	Error	Normal
	5	Front Overrun Sensor	Error	Normal
	6	Not Used		
	7	Not Used		

5803-35	TDCU Command Data Temperature Display
	O to FFFFh
ITB Thermistor	Temp.: Hexadecimal Data
	Example: Hex. Data/100 = C°

5803-82		LCT-CPU-Port1	Reading	9
	Bit	Component	0	1

	0	Not Used		
	1	Not Used		
	2	Not Used		
LCT	3	Not Used		
LCI	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	LCT Exit Roller HP Sensor	Not Detected	Detected

5803-83	LCT-CPU-Port7		Reading	
	Bit	Component	0	1
	0	Not Used		
	1	Not Used		
	2	Not Used		
LCT	3	Not Used		
ICI	4	Not Used		
	5	Not Used		
	6	LCT Front Door SW	Closed	Open
	7	Not Used		

5803-84	LCT-CPU-Port9		Reading	
	Bit	Component	0	1

	0	SW002-1	ON	OFF
	1	SW002-2	ON	OFF
	2	SW002-3	ON	OFF
LICT	3	SW002-4	ON	OFF
LICI	4	SW002-5	ON	OFF
	5	SW002-6	ON	OFF
	6	SW002-7	ON	OFF
	7	SW002-8	ON	OFF

5803-85		LCT-elO1-PortB	Reading		
	Bit	Component 0		1	
	0	3rd Tray Paper Height Sensor 1	Not Detected	Detected	
	1	3rd Tray Paper Height Sensor 2	Not Detected	Detected	
	2	3rd Tray Paper Height Sensor 3	Not Detected	Detected	
LCT	3	3rd Tray Paper Height Sensor 4	Not Detected	Detected	
LCT	4	3rd Tray Paper Size Sensor 1	Not Detected	Detected	
	5	3rd Tray Paper Size Sensor 2	Not Detected	Detected	
	6	3rd Tray Paper Size Sensor 3	Not Detected	Detected	
	7	3rd Tray Paper Length Sensor	Not Detected	Detected	

5803-86		LCT-eIO1-PortC	Readi	ng
	Bit	Component	0	1

LCT	0	3rd Tray Unit Set SW	Set	Not Set
	1	3rd Tray Paper End Sensor	Paper Present	No Paper
	2	3rd Tray Upper Limit Sensor	At Limit	Not Limit
	3	3rd Tray Feed Sensor	Paper Present	No Paper
	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	3rd Tray Set SW	Set	Not Set

5803-87	LCT-eIO1-PortD		Reading	
	Bit	Component	0	1
	0	Not Used		
	1	Not Used		
	2	Not Used		
LCT	3	Not Used		
LCI	4	LCT Exit Sensor	Paper Present	No Paper
	5	3rd Tray Vertical Transport Sensor 2	Paper Present	No Paper
	6	3rd Tray Vertical Transport Sensor 1	Paper Present	No Paper
	7	3rd Tray Transport Sensor	Paper Present	No Paper

5803-88		LCT-eIO2-PortB	Readin	g
	Bit	Component	0	1

	0	4th Tray Paper Height Sensor 1	Not Detected	Detected
	1	4th Tray Paper Height Sensor 2	Not Detected	Detected
	2	4th Tray Paper Height Sensor 3	Not Detected	Detected
LCT	3	4th Tray Paper Height Sensor 4	Not Detected	Detected
LCT	4	4th Tray Paper Size Sensor 1	Not Detected	Detected
	5	4th Tray Paper Size Sensor 2	Not Detected	Detected
	6	4th Tray Paper Size Sensor 3	Not Detected	Detected
	7	4th Tray Paper Length Sensor	Not Detected	Detected

5803-89	LCT-eIO2-PortC		Reading	
	Bit	Component	0	1
	0	4th Tray Unit Set SW	Set	Not Set
	1	4th Tray Paper End Sensor	Paper Present	No Paper
	2	4th Tray Upper Limit Sensor	At Limit	Not Limit
LCT	3	4th Tray Feed Sensor	Paper Present	No Paper
LCT	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	4th Tray Set SW	Set	Not Set

5803-90		**	Reading	
	Bit	Component	0	1

LCT	0	Not Used		
	1	Not Used		
	2	Not Used		
	3	Not Used		
	4	Not Used		
	5	Not Used		
	6	4th Tray Vertical Transport Sensor	Paper Present	No Paper
	7	4th Tray Transport Sensor	Paper Present	No Paper

5803-91	LCT-eIO3-PortB		Reading	
	Bit	Component	0	1
	0	5th Tray Paper Height Sensor 1	Not Detected	Detected
	1	5th Tray Paper Height Sensor 2	Not Detected	Detected
	2	5th Tray Paper Height Sensor 3	Not Detected	Detected
LCT	3	5th Tray Paper Height Sensor 4	Not Detected	Detected
LCI	4	5th Tray Paper Size Sensor 1	Not Detected	Detected
	5	5th Tray Paper Size Sensor 2	Not Detected	Detected
	6	5th Tray Paper Size Sensor 3	Not Detected	Detected
	7	5th Tray Paper Length Sensor	Not Detected	Detected

5803-92		LCT-eIO3-PortC	Reading	
	Bit	Component	0	1

	0	6th Tray Unit Set SW	Set	Not Set
	1	6th Tray Paper End Sensor	Paper Present	No Paper
	2	6th Tray Upper Limit Sensor	At Limit	Not Limit
LCT	3	6th Tray Feed Sensor	Paper Present	No Paper
LCI	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	6th Tray Set SW	Set	Not Set

5803-93		**	Reading	
	Bit	Component	0	1
	0	Not Used		
	1	Not Used		
	2	Not Used		
* *	3	Not Used		
	4	Not Used		
	5	Not Used		
	6	6th Tray Vertical Transport Sensor	Paper Present	No Paper
	7	6th Tray Transport Sensor	Paper Present	No Paper

5803-94	LCT-elO4-PortB		Reading	
	Bit	Component	0	1

LCT	0	7th Tray Paper Height Sensor 1	Not Detect	Detect
	1	7th Tray Paper Height Sensor 2	Not Detect	Detect
	2	7th Tray Paper Size Sensor 1	Detect	Not Detect
	3	7th Tray Paper Size Sensor 2	Detect	Not Detect
	4	7th Tray Paper Size Sensor 3	Detect	Not Detect
	5	7th Tray Paper Size Sensor 4	Detect	Not Detect
	6	7th Tray Paper Size Sensor 5	Detect	Not Detect
	7	7th Tray Paper Length Sensor	Detect	Not Detect

5803-95		LCT-eIO4-PortC	Reading	
	Bit	Component	0	1
	0	7th Tray Lower Limit Sensor	At Low Limit	Not Low Limit
	1	7th Tray Paper End Sensor	Paper Present	No Paper
	2	7th Tray Upper Limit Sensor 1	At Upper Limit	Not Upper Limit
LCT	3	7th Tray Feed Sensor	Paper Present	No Paper
	4	Not Used		
	5	7th Tray Lift SW	ON	OFF
	6	Bypass Slide Sensor	Closed	Open
	7	Bypass Set Sensor	Set	Not Set

5803-96		**	Reading		
	Bit	Component	0	1	

	0	Not Used		
	1	Not Used		
	2	Not Used		
**	3	7th Tray Upper Limit Sensor 2	At Upper Limit	Not Upper Limit
	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	7th Tray Transport Sensor 7	Paper Present	No Paper

5803-140	CTB_H8S-PORT9		Readi	Reading	
	Bit	Component	0	1	
	0	Not Used			
	1	Not Used			
	2	Exhaust Fan 4	Normal (Drive)	Error (Stop)	
Buffer Pass Unit	3	Exhaust Fan 3	Normal (Drive)	Error (Stop)	
Buffer Pass Unif	4	Not Used			
	5	Not Used			
	6	Intake Fan 4	Normal (Drive)	Error (Stop)	
	7	Intake Fan 3	Normal (Drive)	Error (Stop)	

5803-141	**		Reading	
	Bit	Component	0	1

Buffer Pass	0	Front Door Interlock SW	Closed	Open
	1	Not Used		
	2	Not Used		
	3	Not Used		
Unit	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	Not Used		

5803-142	**		Reading	
	Bit	Component	0	1
	0	Transport Motor 2	Normal (Drive)	Error (Stop)
	1	Transport Motor 1	Normal (Drive)	Error (Stop)
	2	Not Used		
רו ה וויי	3	Not Used		
Buffer Pass Unit	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	Not Used		

5803-143	**		Reading	
	Bit	Component	0	1

	0	Not Used		
	1	Not Used		
	2	Exhaust Fan 2	Normal (Drive)	Error (Stop)
D	3	Exhaust Fan 1	Normal (Drive)	Error (Stop)
Buffer Pass Unit	4	Not Used		
	5	Not Used		
	6	Intake Fan 2	Normal (Drive)	Error (Stop)
	7	Intake Fan 1	Normal (Drive)	Error (Stop)

5803-144	**		Reading	
	Bit	Component	0	1
	0	Transport Sensor 6	Paper Present	No Paper
	1	Transport Sensor 3	Paper Present	No Paper
	2	Transport Sensor 7	Paper Present	No Paper
Buffer Pass Unit	3	Transport Sensor 2	Paper Present	No Paper
bullet rass Offit	4	Transport Sensor 8	Paper Present	No Paper
	5	Transport Sensor 1	Paper Present	No Paper
	6	Not Used		
	7	Not Used		

5803-145	**		Reading	
	Bit	Component	0	1

	0	Not Used		
	1	Not Used		
	2	24V Line Check	24V ON	24V OFF
D	3	24V_INT Line Check	24V_INT ON	24V_INT OFF
Buffer Pass Unit	4	Transport Unit (Drawer)	Set	Not Set
	5	Not Used		
	6	Transport Sensor 5	Paper Present	No Paper
	7	Transport Sensor 4	Paper Present	No Paper

5803-200	HP Sensor		Readi	ng
	Bit	Component	0	1
	0	Scanner HP Sensor	Home	Not Home
	1	Not Used		
	2	Not Used		
HP Sensor	3	Not Used		
Hr Sensor	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	Not Used		

5803-202	**		Readi	ng	
	Bit	Component	0	1	

	0	Scanner Exhaust Fan	Normal (Drive)	Error (Stop)
	1	Lamp Regulator Cooling Fan	Normal (Drive)	Error (Stop)
	2	Not Used		
Scan Fan Lock	3	Not Used		
Signal	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	Not Used		

5804	Output Check	
1	Feed Mtr 1 (Std Speed)	
2	Feed Mtr 1 (Med Speed)	
3	Feed Mtr 1 (Low Speed)	
4	Feed Mtr 2 (Std Speed)	
5	Feed Mtr 2 (Med Speed)	
6	Feed Mtr 2 (Low Speed)	
7	Bypass Grip Mtr 1 (Std Speed)	
8	Bypass Grip Mtr 1 (Med Speed)	
9	Bypass Grip Mtr 1 (Low Speed)	
10	Bypass Grip Mtr 2 (Std Speed)	
11	Bypass Grip Mtr 2 (Med Speed)	
12	Bypass Grip Mtr 2 (Low Speed)	
13	Bypass V-Transport (Std Speed)	
14	Bypass V-Transport (Med Speed)	
15	Bypass V-Transport (Low Speed)	
16	Bank Exit Mtr (Hi1:Std Speed)	

17	Bank Exit Mtr (Hi1:Med Speed)	
18	Bank Exit Mtr (Hi1:Low Speed)	
19	Bank Exit Mtr (Nor:Std Speed)	
20	Bank Exit Mtr (Nor:Med Speed)	
21	Bank Exit Mtr (Nor:Low Speed)	
22	Bank Exit Mtr (Slow Down:Std Speed)	
23	Bank Exit Mtr (Slow Down:Med Speed)	
24	Bank Exit Mtr (Slow Down:Low Speed)	
25	Registration Entrance Mtr (Hi1:Std Speed)	
26	Registration Entrance Mtr (Hi1:Med Speed)	
27	Registration Entrance Mtr (Hi1:Low Speed)	
28	Registration Entrance Mtr (Nor:Std Speed)	
29	Registration Entrance Mtr (Nor:Med Speed)	
30	Registration Entrance Mtr (Nor:Low Speed)	
31	Registration Entrance Mtr (Slow Down:Std Speed)	
32	Registration Entrance Mtr (Slow Down:Med Speed)	
33	Registration Entrance Mtr (Slow Down:Low Speed)	
34	Registration Timing Mtr (Hil:Std Speed)	
35	Registration Timing Mtr (Hil:Med Speed)	
36	Registration Timing Mtr (Hil:Low Speed)	
37	Registration Timing Mtr (Nor:Std Speed)	
38	Registration Timing Mtr (Nor:Med Speed)	
39	Registration Timing Mtr (Nor:Low Speed)	
40	Reg Tmg Mtr (Slow Dn:Std Spd)	
41	Reg Tmg Mtr (Slow Dn:Med Spd)	
42	Reg Tmg Mtr (Slow Dn:Low Spd)	

43	Shift Roller Motor (Std Speed)	
44	Shift Roller Motor (Med Speed)	
45	Shift Roller Motor (Low Speed)	
46	Unit Shift Motor (HP)	
47	Unit Shift Motor (Drive)	
48	Gate Retract Motor (HP)	
49	Gate Retract Motor (Drive)	
50	1 st Tray: Bottom Plate (Lift: Drive)	
51	1st Tray: Bottom Plate (Lift: HP)	
52	2nd Tray: Bottom Plate (Lift: Drive)	
53	2nd Tray: Bottom Plate (Lift: HP)	
54	Rear Fence Motor (Fws: 1s)	
55	Rear Fence Motor (Rev: 1s)	
58	CIS Cleaning Fan	
59	Paper Exit Cooling Fan 4	
60	Paper Exit Cooling Fan 5	
61	Paper Exit Cooling Fan 6	
62	Paper Exit Cooling Fan 6	
63	1st Tray: Pickup SOL	
64	1st Tray: Rev SOL	
65	2nd Tray: Pickup SOL	
66	2nd Tray: Rev SOL	
67	Relay SOL 1	
68	Relay SOL 1	
69	LCT Relay SOL	
70	Exit JG SOL	

71	Inverter JG SOL	
72	Exit/Inverter JG SOL	
73	Lock SOL	
74	Connect SOL	
75	Rear Side Fence SOL	
76	Front Side Fence SOL	
77	Bank LED: 1st Tray	
78	Bank LED: 2nd Tray	
80	Polygon Motor: KC	
81	Polygon Motor: MY	
90	Used Toner Bottle Motor	
91	Toner Supply Motor	
100	Bk DrumMotor: HighSpeed	
101	C DrumMotor: HighSpeed	
102	M DrumMotor: HighSpeed	
103	Y DrumMotor: HighSpeed	
104	Bk DevelopmentMotor: HighSpeed	
105	C DevelopmentMotor: HighSpeed	
106	M DevelopmentMotor: HighSpeed	
107	Y DevelopmentMotor: HighSpeed	
108	Bk CleaningMotor: HighSpeed	
109	C CleaningMotor: HighSpeed	
110	M CleaningMotor: HighSpeed	
111	Y Cleaning Motor: High Speed	
112	ITB Motor: HighSpeed	
113	PRT Motor: HighSpeed	

114	Fusing Motor: HighSpeed	
115	Paper Ejection Motor: HighSpeed	
116	Bk DrumMotor: MiddleSpeed	
117	C DrumMotor: MiddleSpeed	
118	M DrumMotor: MiddleSpeed	
119	Y DrumMotor: MiddleSpeed	
120	Bk DevelopmentMotor: MiddleSpeed	
121	C DevelopmentMotor: MiddleSpeed	
122	M DevelopmentMotor: MiddleSpeed	
123	Y DevelopmentMotor: MiddleSpeed	
124	Bk CleaningMotor: MiddleSpeed	
125	C CleaningMotor: MiddleSpeed	
126	M CleaningMotor: MiddleSpeed	
127	Y Cleaning Motor: Middle Speed	
128	ITB Motor: MiddleSpeed	
129	PRT Motor: MiddleSpeed	
130	Fusing Motor: MiddleSpeed	
131	Paper Ejection Motor: MiddleSpeed	
132	Bk DrumMotor: LowSpeed	
133	C DrumMotor: LowSpeed	
134	M DrumMotor: LowSpeed	
135	Y DrumMotor: LowSpeed	
136	Bk DevelopmentMotor: LowSpeed	
137	C DevelopmentMotor: LowSpeed	
138	M DevelopmentMotor: LowSpeed	
139	Y DevelopmentMotor: LowSpeed	

140	Bk CleaningMotor: LowSpeed	
141	C CleaningMotor: LowSpeed	
142	M CleaningMotor: LowSpeed	
143	Y Cleaning Motor: Low Speed	
144	ITB Motor: LowSpeed	
145	PRT Motor: LowSpeed	
146	Fusing Motor: LowSpeed	
147	Paper Ejection Motor: LowSpeed	
148	Toner Discharge Motor	
149	Transfer Timing Motor (Std Speed)	
150	Transfer Timing Motor (Med Speed)	
151	Transfer Timing Motor (Low Speed)	
161	Exit/Relay Mtr (Hi2: Std Speed)	
162	Exit/Relay Mtr (Hi2: Med Speed)	
163	Exit/Relay Mtr (Hi2: Low Speed)	
164	Exit/Relay Mtr (Nor: Std Speed)	
165	Exit/Relay Mtr (Nor: Med Speed)	
166	Exit/Relay Mtr (Nor: Low Speed)	
167	Exit/Inverter Mtr (Fwd: Hi2: Std Speed)	
168	Exit/Inverter Mtr (Fwd: Hi2: Med Speed)	
169	Exit/Inverter Mtr (Fwd:Hi2:Low Speed)	
170	Exit/Inverter Mtr (Fwd:Nor:Std Speed)	
171	Exit/Inverter Mtr (Fwd:Nor:Med Speed)	
172	Exit/Inverter Mtr (Fwd:Nor:Low Speed)	
173	Exit/Inverter Mtr (Rev:Hi2:Std Speed)	
174	Exit/Inverter Mtr (Rev:Hi2:Med Speed)	

175	Exit/Inverter Mtr (Rev:Hi2:Low Speed)	
176	Exit/Inverter Mtr (Rev:Nor:Std Speed)	
177	Exit/Inverter Mtr (Rev:Nor:Med Speed)	
178	Exit/Inverter Mtr (Rev:Nor:Low Speed)	
179	Duplex/Inverter Mtr (Fwd:Hi2:Std Speed)	
180	Duplex/Inverter Mtr (Fwd:Hi2:Med Speed)	
181	Duplex/Inverter Mtr (Fwd:Hi2:Low Speed)	
182	Duplex/Inverter Mtr (Fwd:Nor:Std Speed)	
183	Duplex/Inverter Mtr (Fwd:Nor:Med Speed)	
184	Duplex/Inverter Mtr (Fwd:Nor:Low Speed)	
185	Duplex/Inverter Mtr (Rev:Hi1:Std Speed)	
186	Duplex/Inverter Mtr (Rev:Hi1:Med Speed)	
187	Duplex/Inverter Mtr (Rev:Hi1:Low Speed)	
188	Dup Trans Mtr1 (Std Speed)	
189	Dup Trans Mtr1 (Med Speed)	
190	Dup Trans Mtr1 (Low Speed)	
194	Dup Trans Mtr3 (Std Speed)	
195	Dup Trans Mtr3 (Med Speed)	
196	Dup Trans Mtr3 (Low Speed)	
200	Scananer fanmotor	
202	Scananer Lamp	
203	Scanner Motor	
209	De-curler Unit Move: Lower Default	
210	De-curler Unit Move: Upper Default	
211	De-curl Trans Mtr (Std Speed)	
212	De-curl Trans Mtr (Med Speed)	

213	De-curl Trans Mtr (Low Speed)	
214	De-curl Trans Mtr (Reverse)	
217	A3 LCT 3rd Tray: Pickup SOL	
218	A3 LCT 4th Tray: Pickup SOL	
219	A3 LCT 5th Tray: Pickup SOL	
220	Bypass Pickup SOL	
221	A3 LCT: 3rd Tray Feed Mtr (Std Speed)	
222	A3 LCT: 3rd Tray Feed Mtr (Med Speed)	
223	A3 LCT: 4th Tray Feed Mtr (Std Speed)	
224	A3 LCT: 4th Tray Feed Mtr (Med Speed)	
225	A3 LCT: 5th Tray Feed Mtr (Std Speed)	
226	A3 LCT: 5th Tray Feed Mtr (Med Speed)	
227	Bypass: Feed Mtr (Std Speed)	
228	Bypass: Feed Mtr (Med Speed)	
229	A3 LCT: 3rd Tray Grip Mtr (Std Speed)	
230	A3 LCT: 3rd Tray Grip Mtr (Med Speed)	
231	A3 LCT: 4th Tray Grip Mtr (Std Speed)	
232	A3 LCT: 4th Tray Grip Mtr (Med Speed)	
233	A3 LCT: 5th Tray Grip Mtr (Std Speed)	
234	A3 LCT: 5th Tray Grip Mtr (Med Speed)	
235	Bypass: Transport Mtr (Std Speed)	
236	Bypass: Transport Mtr (Med Speed)	
237	A3 LCT: 3rd Transport Mtr (Std Speed)	
238	A3 LCT: 3rd Transport Mtr (Med Speed)	
239	A3 LCT: 4th Transport Mtr (Std Speed)	
240	A3 LCT: 4th Transport Mtr (Med Speed)	
2-10		

241	A3 LCT: 5th Transport Mtr (Std Speed)	
242	A3 LCT: 5th Transport Mtr (Med Speed)	
243	Bypass: Transport Mtr (Std Speed)	
244	Bypass: Transport Mtr (Med Speed)	
245	A3 LCT: Exit Mtr (Std Speed)	
246	A3 LCT: Exit Mtr (Med Speed)	
247	A3 LCT: Exit Roller Retract Mtr	
248	A3 LCT: 3rd Tray Front Fan	
249	A3 LCT: 3rd Tray Rear Fan	
250	A3 LCT: 4th Tray Front Fan	
251	A3 LCT: 4th Tray Rear Fan	
252	A3 LCT: 5th Tray Front Fan	
253	A3 LCT: 5th Tray Rear Fan	

5805	Output Check	
4	Heat Sink Suction Fan NS	
5	Heat Sink Suction Fan HS	
6	Heat Sink Exhaust Fan NS	
7	Heat Sink Exhaust Fan HS	
8	Paper Fan NS	
9	9 Paper Fan HS	
10	Fuse Exit Fan NS	
11	Fuse Exit Fan HS	
12	Back box Fan NS	
13	Back Box Fan HS	
14	Trans. Fuse Fan	

15	Belt Cleaning Fan NS	
16	Belt Cleaning Fan HS	
17	Press Roller Fan	
18	Press Roller Suction Fan NS	
19	Opt. Suction Fan HS	
22	PCB Box Suction Fan1 NS	
24	PCB Box Suction Fan2 NS	
25	PCB Box Suction Fan2 HS	
27	PCB Box Exhaust Fan 1	
28	PCB Box Exhaust Fan2	
29	Ozone Fan: Y	
30	Ozone Fan: M	
31	Ozone Fan: C	
32	Ozone Fan:K	
33	Ozone Collection Fan	
34	Back Box Ozone Fan NS	
35	Back Box Ozone Fan HS	
37	P-sensor Fan	
38	PT Fan: Front	
39	PT Fan: Center	
40	PT Fan: Rear	
41	Developer Liquid Cooling Fan 1 NS	
43	Developer Liquid Cooling Fan NS	
45	Developer Liquid Cooling Fan 3 NS	
47	Developer Liquid Cooling Pump NS	
48	PSU Fan	

50	Buffer Pass Unit:Feed Motor 1
51	Buffer Pass Unit:Feed Motor 2
52	Buffer Pass Unit:Cool Fan 1-2
53	Buffer Pass Unit:Exhaust Fan 1-2
54	Buffer Pass Unit:Cool Fan 3-4
55	Buffer Pass Unit:Exhaust Fan 3-4
60	Toner Bottle Motor (K)
61	Toner Bottle Motor (C)
62	Toner Bottle Motor (M)
63	Toner Bottle Motor (Y)
65	Toner Pump CL (K)
66	Toner Pump CL (C)
67	Toner Pump CL (M)
68	Toner Pump CL (Y)
70	Toner Supply Clutch (K)
71	Toner Supply Clutch (C)
72	Toner Supply Clutch (M)
73	Toner Supply Clutch (Y)
75	Charge Roller Cleaner Lift SOL (K)
76	Charge Roller Cleaner Lift SOL (C)
77	Charge Roller Cleaner Lift SOL (M)
78	Charge Roller Cleaner Lift SOL (Y)
80	QL (K)
81	QL (C)
82	QL (M)
83	QL (Y)

90	ITB Lift Motor (K)	
91	ITB Lift Motor (YMC)	
92	PTR Lift Motor (Fwd: 1 sec.)	
93	PTR Lift Motor (Rev: 1 sec.)	
94	Steering Motor (HP)	
100	Web Motor	
101	Press Roller Lift Motor (HP)	
102	Press Roller Lift Motor (Up)	
110	Dbl-Feed Sensor (Emitter)	
111	CIS LED (Duty 50% Fixed)	
120	Charge DC Voltage (K)	
121	Charge DC Voltage (C)	
122	Charge DC Voltage (M)	
123	Charge DC Voltage (Y)	
124	Charge AC Voltage (K)	
125	Charge AC Voltage (C)	
126	Charge AC Voltage (M)	
127	Charge AC Voltage (Y)	
128	Development Bias (K)	
129	Development Bias (C)	
130	Development Bias (M)	
131	Development Bias (Y)	
132	Primary Transfer (K)	
133	Primary Transfer (C)	
134	Primary Transfer (M)	
135	Primary Transfer (Y)	

136	Secondary Transfer (+)	
137	Secondary Transfer (-)	
138	Secondary Transfer (AC)	
139	Secondary Transfer (DC)	
140	Separation AC	
141	Separation DC	
150	RFID ON/OFF:K	
151	RFID ON/OFF:C	
152	RFID ON/OFF:M	
153	RFID ON/OFF:Y	
154	RFID COM ON/OFF:K	
155	RFID COM ON/OFF:C	
156	RFID COM ON/OFF:M	
157	RFID COM ON/OFF:Y	
158	Dup Exhaust Fan Front NS	
159	Dup Exhaust Fan Front HS	
160	Dup Exhaust Fan Rear NS	
161	Dup Exhaust Fan Rear HS	
162	Exit Exhaust Fan Front NS	
163	Exit Exhaust Fan Front HS	
164	Exit Exhaust Fan Rear NS	
165	Exit Exhaust Fan Rear HS	

5806	RFID CONT.READING
	This SP is used for validation and testing of the RFIDs. After one of these SP codes is switched ON, a communication count will run until switched OFF.

1	TIMES	[0 to 65535/0/1 times]
2	NOT 0	[0 to 65535/0/1 times]
3	RET.	[0 to 65535/0/1 times]
4	EXE.ALL	[0 to 1/0/1]
5	EXE.K	[0 to 1/0/1]
6	EXE.M	[0 to 1/0/1]
7	EXE.C	[0 to 1/1/1]
8	EXE.Y	[0 to 1/0/1]

5807	07 Area Selection <b>DFU</b>	
Sets the machine for the geographical area where it will be used.		
	[1 to 3/2/1] 1:DOM (Japan) 2:NA 3:EU	

5810	SC Reset
	When the machine issues a "Level A" SC code, this indicates a serious problem in the fusing unit (SC542 to SC546, for example).
	As soon as the Level A SC code is issued, the machine is disabled immediately.
	The operator cannot reset the SC because the machine requires servicing immediately.
	The machine cannot be used until the machine has been service.
	Touch [EXECUTE] to release the machine for servicing.

5811	Machine Serial <b>DFU</b>	
	This SP presents the screen used to enter the 11-digit number of the machine. The allowed entries are "A" to "Z" and "O" to "9". The setting is done at the factory, and should not be changed in the field.	
2	Display	
4	Set: BCU	[0 to 255/1/1]
5	Set: Novita	[0 to 255/0/1]

	Service Tel. No. Setting		
5812	Use these SP modes to input service and support telephone numbers. Enter the number and press  Press the [./*] key to input a pause. Press the "Clear modes" key to delete the telephone number.		
1	Service Service representative telephone number.		
2	Facsimile Fax number of service representative		
3	Supply Supplier of consumables		
4	Operation	Operation support	

5816	Remote Service CTL			
	I/F Setting			
	Turns the remote diagnostics off and on.			
1	[0 to 2/2/1]			
	O: Remote diagnostics off.			
	1: Serial (CSS or @Remote) remote diagnostics on.			
	2: Network remote diagnostics on for @Remote			
	CE Call			
2	Lets the operator engineer start or end of the remote machine check with CSS to do this, push the center report key	or @Remote;		
	Function Flag			
	Enables and disables remote diagnosis over the @Remote network.			
3	[0 to 1/0/1]			
	0: Disables remote diagnosis over the network.			
	1: Enables remote diagnosis over the network.			
	Communication Test Call			
4	This SP issues a test call from a GW machine to determine whether it can communicate successfully with the call center after it has been set up for NRS. Successful return will be in the range 0 to 99.			

	Device Information Call
5	Controls if the item for initial setting of the screen for the NRS device-information notification-call is shown.  [0 to 1/1]
	0: Enabled. Item initial setting not shown.
	1: Disable. Item for initial setting shown.
	SSI Disable
7	Controls if RCG (Remote Communication Gate) confirmation is done by SSL during an RCG send for the @Remote over a network intersection.  [0 to 1/0/1]
	0: Yes. SSL not used.
	1: No. SSL used.
	RCG Connect Timeout
8	Sets the length of time (seconds) for the time-out when the RCG (Remote Communication Gate) connects during a call via the @Remote network.  [1 to 90/30/1 sec.]
	RCG Write to Timeout
9	Sets the length of time (seconds) for the time-out when sent data is written to the RCG during a call over the @Remote network.
	[0 to 100/60/1 sec.]
	RCG Read Timeout
10	Sets the length of time (seconds) for the timeout when sent data is written from the RCG during a call over the @Remote network.
	[0 to 100/60/1 sec.]
	Port 80 Enable
	Controls if permission is given to get access to the SOAP method over Port 80 on the @Remote network.
11	[0 to 1/0/1]
	0: No. Access denied
	1: Yes. Access granted.

	RFU Timing
13	This SP determines how the machine receives forum (RFU: @Remote Forum Updates) updates.
	[0 to 1 / 1/1]
	0: All forum updates
	1: Energy status update only
	RCG – C Registed
21	This SP displays the Embedded RC Gate installation end flag.
	1: Installation completed
	2: Installation not completed
	Connect Type (N/M)
23	This SP displays and selects the Embedded RC Gate connection method.
20	0: Internet connection
	1: Dial-up connection
61	Cert. Expire Timing <b>DFU</b>
01	Proximity of the expiration of the certification.
	Use Proxy
62	This SP setting determines if the proxy server is used when the machine communicates with the service center.
	Proxy Host
63	This is the address of the HTTP proxy server used to effect communication between Embedded RC Gate-M and the Gateway. The length of the address is limited to 127 characters (characters beyond the 127th character are ignored).
	Proxy Port Number
64	This is the port number of the HTTP proxy used to effect communication between Embedded RC Gate-N and the Gateway.
	[0 to 0xffff/0/1]
	Proxy User name
65	This is the user name used for certification of the HTTP proxy. The length of the name is limited to 31 characters (characters beyond the 31st character are ignored).

Proxy Password

This is the certification password of the HTTP proxy. The length of the password is limited to 31 characters (characters beyond the 31st character are ignored).

**Note**: The proxy number, user name, and password comprise proprietary operator information required by the service technician to do the necessary settings for Embedded RC Gate-N. To prevent unauthorized access this information, these SP settings do not appear in the SMC report.

66

	Displays the state of the certification update used for Embedded RC Gate. If Embedded			
	RC Gat	e has not been set up, These SP settings are done automatically as soon as ded RC Gate is set up.		
	0	The certification used by Embedded RC Gate is set correctly.		
	1	The certification request (SetAuthKey) for update has been received from the CTL URL and certification is presently being updated.		
	2	The certification update is completed and the CTL URL is being notified of the successful update.		
	3	The certification update failed, and the CTL URL is being notified of the failed update.		
	4	The period of the certification has expired and new request for an update is being sent to the CTL URL.		
	11	A rescue update for certification has been issued and a rescue certification setting is in progress for the rescue CTL connection.		
67	12	The rescue certification setting is completed and the CTL URL is being notified of the certification update request.		
	13	The notification of the request for certification update has completed successfully, and the system is waiting for the certification update request fro the rescue CTL URL.		
	14	The notification of the certification request has been received from the rescue CTL URL, and the certification is being stored.		
-	15	The certification has been s to red, and the CTL URL is being notified of the successful completion of this event.		
	16	The storing of the certification has failed, and the CTL URL is being notified of the failure of this event.		
	17	The certification update request has been received from the CTL URL, the CTURL was notified of the results of the update after it was completed, but a certification error has been received, and the rescue certification is being recorded.		
	18	The rescue certification of No. 17 has been recorded, and the CTL URL is being notified of the failure of the certification update.		

	CERT: Error			
	Displays a number code that describes the reason for the notification requesting the certification update.			
	0	Normal. No request for certification update in progress.		
	1	Certification update in progress due to expiration of certification.		
68	2	SSL error has been issued after the certification has expired.		
	3	There has been a shift from a common to individual certification.		
	4	There has been a common certification without ID2.		
	5	No certification has been issued.		
	6	CTL URL does not exist.		
69	CERT: Up ID			
09	The ID of the request for certification.			
83	Firm Up Status			
03	Displays the status of the firmware update.			
	Firm Up User Check			
85	This SP setting determines if the operator can check the previous version of the firmware before the firmware update execution. If the option to check the previous version is selected, a notification is sent to the system manager and the firmware update is done with the firmware files from the URL.			
	Firmware Size			
86	Allows the service technician to check the size of the firmware data files during the firmware update execution.			
0.7	CERT: Macro Version			
87	Displays the macro version of the @Remote certification			
0.0	CERT: PAC Version			
88	Displays	the PAC version of the @Remote certification.		

	CERT: ID2 Code
	Displays ID2 for the @Remote certification. Spaces are displayed as underscores (_).  Asterisks (****) indicate that no @Remote certification exists.
	CERT: Subject
	Displays the common name of the @Remote certification subject. CN = the following 17 bytes. Spaces are displayed as underscores (_). Asterisks (****) indicate that no DESS exists.
	CERT: Serial No.
	Displays serial number for the @Remote certification. Asterisks (****) indicate that no DESS exists.
	CERT: Issuer
	Displays the common name of the issuer of the @Remote certification. CN = the following 30 bytes. Asterisks (****) indicate that no DESS exists.
	CERT: Valid Start
	Displays the start time of the period for which the current @Remote certification is enabled.
	CERT: Valid End
	Displays the end time of the period for which the current @Remote certification is enabled.
95 -	Server CN Check <b>DFU</b>
	This is a design debugging tool. Not used.
96	GW Host <b>DFU</b>
1	This is a design debugging tool. Not used.
97	GW URL Path <b>DFU</b>
	This is a design debugging tool. Not used.
99	Debug Rescue G/WURL <b>DFU</b>
	This is a design debugging tool. Not used.

100	Specific	Gateway Host <b>DFU</b>		
100	This is a design debugging tool. Not used.			
101	Specific	Gateway URL Path <b>DFU</b>		
101	This is a	design debugging tool. Not used.		
	Selection	n Country <b>DFU</b>		
	Used only for Embedded RC Gate-M to select a country name. Once the number/country is selected, the following settings are checked:			
	• Acc	cess point telephone number		
150	• Dia	l-up user name		
	• Mo	dem parameters set for the country		
	[0 to 10,	/*/1]		
	*: 0: Japan, 1: USA, 3: UK			
	0:Japan, 1:USA, 2:Canada, 3:UK, 4:Germany, 5:France, 6:Italy, 7:Netherlands, 8:Belgium, 9:Luxembourg, 10:Spain			
	Line Type Automatic Judgement <b>DFU</b>			
	Used only for Embedded RC Gate-M to determine whether the dial-up line is for manual rotary or push-button tone dialing.			
151	<ul> <li>The status of the execution of this SP (dialing in progress, success, failure) is written to SP5816-152.</li> </ul>			
		e check succeeds, the number (dial or push number) written to SP5816-153 be used		
	• If th	e check succeeds, the number of the carrier line written to SP816-154 can be d.		
	Line Type	e Judgement Result <b>DFU</b>		
152	Used only for Embedded RC Gate-M to display the status of the execution of SP5816-151 identify the type of line.			
	0	Success		
	1	Currently dialing		
	2	Line abnormal		
	3	Could not confirm external line carrier with automatic detection.		

	4	Line disconnected	
	5	Power supply insufficient	
	6	Line determination not supported	
	7	Error due to fax transmission in progress.	
	8	Other error	
	9	Line type identification still in progress. Please wait.	
	Selection	n Dial/Push <b>DFU</b>	
153	Used only for Embedded RC Gate-M to set the telephone number of the dial-up access point of the line checked with SP5816-151. If a number is entered, use that number. If a number is not displayed, use the pre-set value for that country.		
	Outside Line Outgoing Number <b>DFU</b>		
154	Used only for Embedded RC Gate-M to set the number of the PSTN number to dial out where Embedded RC Gate-M is used with a PBX system. If a number is set here, the number will be replaced by the number returned by the successful execution of SP5816-151.		
	Dial Up User Name <b>DFU</b>		
156	This is the user name for dialing at the access point where Embedded RC Gate-M is used.		
	<b>Note</b> : Numbers with spaces or # marks appear enclosed with quotation marks in the user name.		
	Dial Up Password <b>DFU</b>		
157	This is the password for dialing at the access point where Embedded RC Gate-M is used.  Note: Numbers with spaces or # marks appear enclosed with quotation marks in the user name.		
	Local Pho	one Number <b>DFU</b>	
161	This is the number of the local line where Embedded RC Gate-M is connected. This is the line used to communicate with the Call Center.		

162	Connection Timing Adjustment Incoming <b>DFU</b>
	When the Call Center calls out to the access point where Embedded RC Gate-M is used the ID tone (*#1#) is sent repeatedly. This SP sets the amount of time to elapse for ID tone output.
	[0 to 24/1/1 pause count]
	1 pause count = 2 sec.
	Access Point <b>DFU</b>
163	This is the dial-up telephone line number of the access point connected to Embedded RC Gate-M. If a number is entered here that number is used. If no number is entered here then the pre-set country setting is used.
	Line Connecting <b>DFU</b>
164	This SP code should be set for the customer using Embedded RC Gate-M, depending of the line usage (whether line is shared with a fax or not).
	[0 to 1/0/1]  0: Line shared with facsimile
	1: Line not shared with facsimile
	Modem Serial No. <b>DFU</b>
173	This SP code displays the serial number of the Embedded RC Gate-M (modem).
174	Retransmission Limit <b>DFU</b>
174	Use this SP to manually send a registration update request to Embedded RC Gate-M.
	FAX TX Priority <b>DFU</b>
18 <i>7</i>	This SP is used with SP5816-164 for users who are using a line shared with a facsimile unit.
	[0 to 1/0/1]
	0: Disabled. Embedded RC Gate-M continues to operate if a fax transmission starts on the same line.
	1: Enabled. Fax transmissions have priority. Embedded RC Gate-M will shut down whe a fax transmission begins.

	Manual Polling		
200	Executes manual polling. Embedded RC Gate periodically polls the @Remote Gateway by HTTPS. This is called "center polling". Use this SP at any time to poll the @Remote supply center.		
	Regist: Status		
	Displays a number that indicates the status of the @Remote service device.		
	0	Neither the @Remote device nor Embedded RC Gate device are set.	
201	1	The Embedded RC Gate device is being set. Only Box registration is completed.  In this status the Basil unit cannot answer a polling request.	
	2	The Embedded RC Gate device is set. In this status the Basil unit cannot answer a polling request.	
	3	The @Remote device is being set. In this status the Embedded RC Gate device cannot be set.	
	4	The @Remote module has not started.	
202	Letter Number		
202	Allows entry of the number of the request needed for the Embedded RC Gate device.		
203	Confirm Execute		
203	Execu	tes the inquiry request to the @Remote CTL URL.	

	Confirm Result			
	Displays a number that indicates the result of the inquiry executed with SP5816 203.			
	0	Succeeded		
	1	Inquiry number error		
	2	Registration in progress		
	3	Proxy error (proxy enabled)		
204	4	Proxy error (proxy disabled)		
	5	Proxy error (Illegal user name or password)		
	6	Communication error		
	7	Certification update error		
	8	Other error		
	9	Inquiry executing		
	Confir	m Place		
205	Displays the result of the notification sent to the device from the CTL URL in answer to the inquiry request. Displayed only when the result is registered at the CTL URL.			
05:	Registe	er Execute		
206	Execut	tes Embedded RC Gate Registration.		

	Register Result		
	Displays a number that indicates the registration result.		
	0	Succeeded	
	2	Registration in progress	
	3	Proxy error (proxy enabled)	
207	4	Proxy error (proxy disabled)	
	5	Proxy error (Illegal user name or password)	
	6	Communication error	
	7	Certification update error	
	8	Other error	
	9	Registration executing	

	Error Code						
	Displays a number that describes the error code that was issued when either SP5816 204 or SP5816 207 was executed.						
	Cause	Code	Meaning				
		-11001	Chat parameter error				
	Illegal Modem Parameter	-11002	Chat execution error				
		-11003	Unexpected error				
		-12002	Inquiry, registration attempted without acquiring device status.				
	Operation Error, Incorrect Setting	-12003	Attempted registration without execution of an inquiry and no previous registration.				
		-12004	Attempted setting with illegal entries for certification and ID2.				
208	Error Caused by Response from CTL URL	-2385	Attempted dial up overseas without the correct international prefix for the telephone number.				
		-2387	Not supported at the Service Center				
		-2389	Database out of service				
		-2390	Program out of service				
		-2391	Two registrations for same device				
		-2392	Parameter error				
		-2393	Basil not managed				
		-2394	Device not managed				
		-2395	Box ID for Basil is illegal				
		-2396	Device ID for Basil is illegal				
		-2397	Incorrect ID2 format				
		-2398	Incorrect request number format				
209	Instl Clear						

	Releases a machine from its embedded RCG setup.	
250	CommLog Print	
	Prints the communication log.	

582	Remote Service Address	CTL
	This SP sets the IP address for RCG (Remote Communication Gate) for processing the @Remote service center.	ng calls to

	NVRAM Data Upload	CTL
Uploads the UP and SP mode data (except for counters and the serial NVRAM on the control board to an SD card inserted in Slot 2.		mber) from
5824	1. Remove the SD card slot cover on the back of the machine.	
<ul><li>2. Insert a blank SD card in Slot 2.</li><li>3. Open this SP and touch [EXECUTE].</li></ul>		
	4. When you see "Completed", remove the SD card from Slot 2.	

	NVRAM Data Download	CTL		
	Downloads the content of an SD card in Slot 2 to the NVRAM on the control board.			
5825	<ul> <li>Remove the SD card slot cover on the back of the machine.</li> </ul>			
0020	Insert a blank SD card in Slot 2.			
	Open this SP and touch [EXECUTE].			
	When you see "Completed", remove the SD card from Slot 2.			

5828	Network Setting CT	
1	IPv4 Address (Ethernet/IEEE 802.11)	
	This SP allows you to check and reset the IPv4 address for Ethernet and wireless LAN (802.11): aaa.bbb.ccc.ddd	
2	IPv4 Subnet Mask (Ethernet/IEEE 802.11)	
	This SP allows you to check and reset the IPv4 subnet mask for Ethernet and wireless LAN (802.11): aaa.bbb.ccc.ddd	
3	IPv4 default Gateway (Ethernet/IEEE 802.11)	

	This SP allows you to check and reset the IPv4 default gateway used by the network			
	for Ethernet and wireless LAN (802.11): aaa.bbb.ccc.ddd			
6	DHCP (Ethernet/IEEE 802.11)			
	This SP code allows you check and change the setting that determines whether the IP address is used with DHCP on an Ethernet or wireless (802.11) LAN network.  [0 to 1 / 1 / 1]			
	0: Not used (manual setting)			
	1: Used			
21	Active IPv4 Address			
21				
	This SP allows you to check the IPv4 address that was used when the machine started up with DHCP.			
22	Active IPv4 Subnet Mask			
	This SP allows you to check the IPv4 subnet mask setting that was used when the machine started up with DHCP.			
23	Active IPv4 Gateway Address			
	This SP allows you to check the IPv4 default gateway setting that was used when the machine started up with DHCP.			
50	1284 Compatibility (Centro)			
	Enables and disables bi-directional communication on the parallel connection between the machine and a computer.			
	[0 to 1 / 1 / 1]			
	0:Off, 1: On			
52	ECP (Centro)			
	Disables and enables the ECP feature (1284 Mode) for data transfer.			
	[0 to 1 / 1 / 1]			
	0: Disabled, 1: Enabled			
65	Job Spool			
	Switches job spooling on and off.			
	[0 to 1/0/1]			
	0: No spooling 1: Spooling enabled			

66	Job Spool Clear: Start Time			
	This SP determines whether the job interrupted at power off is resumed at the next power on. This SP operates only when SP5828065 is set to 1.			
	-	/1/1]		
		umes printing spoo	oled j	og.
	0: Cle	ars spooled job.		
69	Spooli	ing (Protocol)		
		P8etermines wheth a8-bit setting.	ier jo	b spooling is enabled or disabled for each pro to col.
	O LPR	R	4	BMLinks (Japan Only)
	1 FTF	(Not Used)	5	DIPRINT
	2 IPP		6	Reserved (Not Used)
	3 SM	1B	7	Reserved (Not Used)
90	TELNE	T (0:OFF 1:ON)		
	Disabl	es or enables Telno	et op	eration. If this SP is disabled, the Telnet port is closed.
	[0 to 1/1/1]			
	0: Disable			
	1: Ena	ble		
91	Web (0:OFF 1:ON)			
	Disabl	es or enables the \	Web	operation.
	[0 to 1	[0 to 1/1/1]		
	0: Disable			
	1: Enable			
145	Active IPv6 Link Local Address			
	This is the IPv6 local address referenced on the Ethernet or wireless LAN (802.11b) in the format:			
	"Link-L	ocal address" + "P	refix	Length"
	The IPv6 address consists of a total 128 bits configured in 8 blocks of 16 bits each. These notations can be abbreviated. See "Note: IPV6 Addresses " below this table.			
147	Active IPv6 Stateless Address 1			

149	Active IPv6 Stateless Address 2
151	Active IPv6 Stateless Address 3
153	Active IPv6 Stateless Address 4
155	Active IPv6 Stateless Address 5
	SP codes 147 to 155 are the IPv6 stateless addresses (1 to 5) referenced on the Ethernet or wireless LAN (802.11b) in the format:
	"Stateless Address" + "Prefix Length"
	The IPv6 address consists of a total 128 bits configured in 8 blocks of 16 bits each.
156	IPvó Manual Address
	This SP is the IPv6 manually set address referenced on the Ethernet or wireless LAN (802.11b) in the format:
	"Manual Set Address" + "Prefix Length"
	The IPv6 address consists of a total 128 bits configured in 8 blocks of 16 bits each.  These notations can be abbreviated. See "Note: IPV6 Addresses" below this table.
158	IPv6 Gateway Address
	This SP is the IPv6 gateway address referenced on the Ethernet or wireless LAN (802.11b). The IPv6 address consists of a total 128 bits configured in 8 blocks of 16 bits each. These notations can be abbreviated. See "Note: IPV6 Addresses " below this table.
161	IPv6 Stateless Auto Setting
	Sets the machine to reference the stateless auto setting for Ethernet and wireless LAN operation.
	[0 to 1 / 1 / 1]
	0: Disable
	1: Enable
·	

Ethernet and the Wireless LAN (802.11b) reference the IPV6 "Link-Local address + Prefix Length". The IPV6 address consists of 128 bits divided into 8 blocks of 16 bits:

aaaa:bbbb:cccc:dddd:eeee:ffff:gggg:hhhh:

The prefix length is inserted at the 17th byte (Prefix Range: 0x0 to 0x80). The initial setting is 0x40(64). For example, the data:

2001123456789012abcdef012345678940h

is expressed:

2001:1234:5678:9012:abcd:ef01:2345:6789: prefixlen 64

However, the actual IPV6 address display is abbreviated according to the following rules.

# Rules for Abbreviating IPV6 Addresses

- The IPV6 address is expressed in hexadecimal delmited by colons (:) with the following characters: 0123456789abcdefABCDEF
- 2. A colon is inserted as a delimiter every 4th hexadecimal character.

fe80:0000:0000:0000:0207:40ff:0000:340e

3. The notations can be abbreviated by eliminating zeros where the MSB and digits following the MSB are zero. The example in "2" above, then, becomes:

fe80:0:0:0207:40ff:0:340e

4. Sections where only zeros exist can be abbreviated with double colons (::). This abbreviation can be done also where succeeding sections contain only zeros (but this can be done only at one point in the address). The example in "2" and "3" above then becomes: fe80::207:40ff:0:340e (only the first null sets zero digits are abbreviated as "::")

-or-

fe80:0:0:0:207:40ff::340e (only the last null set before "340e" is abbreviated as "::")

	Web Item visible
	Displays or does not display the Web system items.
236	[0 x 0000 to 0 x ffff / 0 x ffff] 0: Not displayed, 1: Displayed
	bit0: Net RICOH
	bit1: Consumable Supplier
	bit2-15: Reserved (all)
	Web shopping link visible
237	Displays or does not display the link to Net RICOH on the top page and link page of the web system.
	[0 to 1 / 1 / 1]
	0: Not display, 1:Display

	Web supplies Link visible		
238	Displays or does not display the link to Consumable Supplier on the top page and link page of the web system.		
	[0 to 1 / 1 / 1]		
	0: Not display, 1:Display		
	Web Link 1 Name		
239	This SP confirms or changes the URL1 name on the link page of the web system. The maximum characters for the URL name are 31 characters.		
	Web Link1 URL		
This SP confirms or changes the link to URL1 on the link page of the we maximum characters for the URL are 127 characters.		, ,	
	Web Link 1 Visible		
241	Displays or does not display the link to URL1 on the top page of the web system.  [0 to 1 / 1 / 1]  0: Not display, 1:Display		
242	Web Link2 Name	Same as "-239"	
243	Web Link2 URL	Same as "-240"	
244	Web Link2 visible Same as "-241"		

	Initial Setting Clear
5831	This SP clears all the User Tools settings and restores them to their factory default settings.

	HDD		CTL
5832	Enter the SP number for the partition to initialize, then press #. When the execution ends, turn the machine power off and on.		
1	HDD Formatting (All)		
2	HDD Formatting (IMH)		
3	HDD Formatting (Thumbnail)		

4	HDD Formatting (Job Log)
5	HDD Formatting (Printer Fonts)
6	HDD Formatting (User Info)
7	Mail RX Data
8	Mail TX Data
9	HDD Formatting (Data for Design)
10	HDD Formatting (Log)
11	HDD Formatting (Ridoc I/F) (for Ridoc DesktopBinder)

5840	IEEE 802.11		CTL	
Channel MAX  Sets the maximum range of the bandwidth for the wireless LAN. This bandwidth setting varies for different countries.				
			vidth setting	
	[1 to 14/14/1]			
	Channel MIN			
7	Sets the minimum range of the bandwidth for operation of the wireless LAN. This bandwidth setting varies for different countries.  [1 to 14/1/1]			
	Transmission Speed			
	0 x FF to Auto [Default]	0 x 0A – 6M Fix		
	0 x 11 – 55M Fix	0 x 07 – 11M Fix		
8	0 x 10 – 48M Fix	0 x 05 – 5.5M Fix		
	0 x 0F – 36M Fix	0 x 08 – 1M Fix		
	0 x 0E – 18M Fix	0 x 13 – 0 x FE (reserved)		
	0 x 0D – 12M Fix	0 x 12 – 72M (reserved)		
	0 x 0B – 9M Fix	0 x 09 – 22M (reserved)		

	WEP Key Select
	Determines how the initiator (SBP-2) handles subsequent login requests.
	[00 to 11/00/1]
11	<b>Note:</b> There are four settings (binary numbers): 00, 01, 10, 11. These settings are possible only after the wireless LAN card has been installed.
	00: 1 st key. If the initiator receives another login request while logging in, the request is refused.
	01, 10, 11: 2nd, 3rd, 4th keys are "Reserved".
42	Fragment Thresh
	Adjusts the fragment threshold for the IEEE802.11 card.
	[256 to 2346 / 2346 / 1]
	This SP is displayed only when the IEEE802.11 card is installed.
43	11g CTS to Self
	Determines whether the CTS self function is turned on or off.
	[0 to 1 / 1 / 1] 0: Off, 1: On
	This SP is displayed only when the IEEE802.11 card is installed.
44	1 1g Slot Time
	Selects the slot time for IEEE802.11.
	[0 to 1 / 0 / 1] 0: 20 µm, 1: 9 µm
	This SP is displayed only when the IEEE802.11 card is installed.
45	WPA Debug Lvl
	Selects the debug level for WPA authentication application.
	[1 to 3 / 3 / 1] 1: Info, 2: warning, 3: error
	This SP is displayed only when the IEEE802.11 card is installed.
(	CTI

	Supply Name Setting	CTL	
	5841	Use the soft keyboard of this SP to enter the names and numbers of consumable the names that appear on the display when [Inquiry] is pressed on the User Too	

5842 GWWS Analysis <b>DFU</b>	CTL
-------------------------------	-----

	Setting 1		
	This is a debugging tool. It sets the debugging output mode of each Net File process. Bit SW 0011 1111	Bit	Groups
		0	System & other groups (LSB)
		1	Capture related
1		2	Certification related
		3	Address book related
		4	Machine management related
		5	Output related (printing, delivery)
		6	Repository related
	Setting 2	Bit	
	This SP codes sets the optional setting for message log time stamp. Bit 7 is the 5682 message log where the following are set:	0-6	Not Used
2		7	Message log 1: mm:ss:ms 0: mm:ss (time)

5844	USB	CTL
1	Transfer Rate	
	Sets the speed for USB data transmission. [Full Speed], [Auto Change]	
2	Vendor ID <b>DFU</b>	
	Sets the vendor ID: Initial Setting: 0x05A Ricoh Company [0x0000 to 0xFFFF/1]	
3	Product ID <b>DFU</b>	
	Sets the product ID.  [0x0000 to 0xFFFF/1]	
4	Device Release Number <b>DFU</b>	

Sets the device release number of the BCD (binary coded decimal) display. [0000 to 9999/100/1] Enter as a decimal number. NCS converts the number to hexadecimal number recognized as the BCD. Fixed USB Port This SP standardizes for common use the model name and serial number for USB PnP (Plug & Play). It determines whether the driver requires re-installation. [0 to 2 / 0 / 4]0: Off 1: Level 1 2: Level 2 PnP Model Name This SP sets the model name to be used by the USB PnP when "Function Enable (Level 2) is set so the USB Serial No. can have a common name (SP5844-5). Default: Laser Printer (up to 20 characters allowed). 7 PnP Serial Number This SP sets the serial number to be used by the USB PnP when "Function Enable (Level 2) is set so the USB Serial No. can have a common name (SP5844-5). Default: None (up to 12 characters allowed for entry). • Make sure that this entry is the same as the serial number in use. · At initialization the serial number generated from the model name is used, not the setting of this SP code. • At times other than initialization, the value set for this SP code is used. 100 Notify Unsupport

This SP determines whether an alert message appears on the control panel when a a USB device (unsupported device) that cannot use an A-connector is connected.

[0 to 1/1/1]

0: Function enable

1: Function disable

- An unsupported device is a device that cannot use the functions of the USB device. For example, a USB mouse cannot be used even if it connected.
- If the PictBridge option is not mounted, even if a digital camera is connected it cannot be used because it is an unsupported device.

	Delivery Server Setting			CTL
5845	Provides items for delivery server settings.			
1	FTP Port No.	[0 to 655	535 / 3670 / 1]	
1	Sets the FTP port number used when im	age files c	re sent to the Scan Router	Server.
	IP Address (Primary)	Range: 0	00.000.000.000 to 255	.255.255.255
2	Use this SP to set the Scan Router Server address. The IP address under the transfer tab can be referenced by the initial system setting.			transfer tab can
	Delivery Error Display Time		[0 to 999 / 300 / 1]	
6	Use this setting to determine the length of time the prompt message is displayed when a test error occurs during document transfer with the NetFile application and an external device.			
8	IP Address (Secondary) Range: 000.000.000 to 255.255.255		5.255.255.255	
	Specifies the IP address assigned to the computer designated to function as the secondary delivery server of Scan Router. This SP allows only the setting of the IP address without reference to the DNS setting.		•	
9	Delivery Server Model		[0 to 4/0/1]	
	Allows changing the model of the deliv	ery server	registered by the I/O dev	vice.
	0: Unknown			
	1: SG1 Provided			
	2: SG1 Package			
	3: SG2 Provided			
	4: SG2 Package			

	Delivery Svr Capability
	Changes the capability of the registered that the I/O device registered.
	[0 to 255 / 0 / 1]
	(7) [0000 0000] (1)
	Bit $7 = 1$ Comment information exists
	Bit6 = 1 Direct specification of mail address possible
10	Bit5 = 1 Mail RX confirmation setting possible
	Bit4 = 1 Address book automatic update function exists
	Bit3 = 1 Fax RX delivery function exists
	Bit2 = 1 Sender password function exists
	Bit1 = 1 Function to link MK-1 user and Sender exists
	BitO = 1 Sender specification required (if set to 1, Bit6 is set to "0")
	Delivery Svr.Capability (Ext)
11	These settings are for future use. They will let you increase the number of registered devices (in addition to those registered for SP5845-10).
	There are eight bits (Bit 0 to Bit 7). All are unused at this time.
13	Server Scheme (Primary)
14	Server Port Number (Primary)
15	Server URL Path (Primary)
16	Server Scheme (Secondary)
17	Server Port Number (Secondary)
18	Server URL Path (Secondary)
22	Rapid Sending Control

Switches instant transmission off/on.

[0 to 1/1/1]

0: Off. Instant transmission not possible with network setting errors.

1: On. Instant transmission possible with network setting errors.

# Note:

- The machine will continue to transmit over the network, even if the network settings are incorrect. (This causes multiple errors, of course.)
- With this SP off, the machine will stop communicating with the network if the settings are wrong. This reduces the amount of spurious network traffic caused by errors due to incorrect settings.

5846	UCS Setting	CTL
	UCS (User Control Service) is the software that manages user codes and the for scan-to-email and scan-to-folder.	e address books
	Machine ID (for Delivery Server)	
	Displays the unique device ID in use by the delivery server directory. The voldisplayed and cannot be changed.	alue is only
	This ID is created from the NIC MAC or IEEE 1394 EUI.	
1	The ID is displayed as either 6-byle or 8-byte binary.	
	6-byte	
	%02X.%02X.%02X.%02X.%02X	
	8-byte	
	%02X.%02X.%02X.%02X.%02X.%02X	
	Machine ID Clear (Delivery Server)	
2	Clears the unique ID of the device used as the name in the file transfer direct SP if the connection of the device to the delivery server is unstable. After clear ID will be established again automatically by cycling the machine off and contact the stable in the stabl	earing the ID, the
	Maximum Entries	
	Changes the maximum number of entries that UCS can handle.	
3	[2000 to 20000/2000/1]	
	If a value smaller than the present value is set, the UCS managed data is cl data (excluding user code information) is displayed.	eared, and the

	Delivery Server Retry Timer
6	Sets the interval for retry attempts when the delivery server fails to acquire the delivery server address book.
	[0 to 255/0/1 sec.]
	0: No retries
	Delivery Server Retry Times
7	Sets the number of retry attempts when the delivery server fails to acquire the delivery server address book.  [0 to 255/0/1]
	Delivery Server Maximum Entries
8	Lets you set the maximum number of account entries and information about the users of the delivery server controlled by UCS.
	[2000 to 20000/2000/1]
	LDAP Search Timeout
10	Sets the length of the time-out for the search of the LDAP server.
	[1 to 255/60/1]
	WSD Maximum Entries
20	WSD (Web Services on Devices) is the Microsoft standard for connectivity to web-service enabled devices.
	[50 to 250/250/1]
	Default: 250
	Folder Auth Change
21	This SP determines whether the user login information (Login User name and Password) or address (destination setting in the address book for Scan-to-SMB) is used to permit folder access. The machine must be cycled off/on for this setting to take effect if it is changed.
	[0 to 1 / 0 / 1]
	0: Uses operator login information (initial value of main machine)
	1: Uses address authorization information

## Addr Book Migration (SD -> HDD)

This SP moves the address book data from an SD card to the HDD. You must turn the machine power off and on after executing this SP.

- 1. Turn the machine off.
- 2. Install the HDD.
- 3. Insert the SD card with the address book data in SD card Slot C3.
- 4. Turn the machine on.
- 5. Do SP5846-40.

40

- 6. Turn the machine off.
- 7. Remove the SD card from SD card Slot C3.
- 8. Turn the machine on.

## Notes:

- Executing this SP overwrites any address book data already on the HDD with the data from the SD card.
- We recommend that you back up all directory information to an SD card with SP5846-51 before you execute this SP.
- After the address book data is copied to HDD, all the address book data is deleted from the source SD card. If the operation fails, the data is not erased from the SD card.

#### Fill Addr Acl Info.

This SP must be executed immediately after installation of an HDD unit in a basic machine that previously had no HDD. The first time the machine is powered on with the new HDD installed, the system automatically takes the address book from the NVRAM and writes it to the new HDD. However, the new address book on the HDD can be accessed only by the system administrator at this stage. Executing this SP by the service technician immediately after power on grants full address book access to all users.

# **Procedure**

41

- 1. Turn the machine off.
- 2. Install the new HDD.
- 3. Turn the machine on.
- 4. The address book and its initial data are created on the HDD automatically. However, at this point the address book can be accessed by only the system administrator or key operator.
- 5. Enter the SP mode and do SP5846-41. After this SP executes successfully, any user can access the address book.

	Addr Book Media
	This SP displays the media where the address book currently in use is stored.
	[0 to 30 / 0 / 1]
	0: Unconfirmed
43	1: SD Slot 1
	2: SD Slot 2
	4: USB Flash ROM
	20: HDD
	30: Nothing
46	Initialize All Settings & Address Book
40	Initializes all settings and the address book.
	Initialize Local Addr Book
47	Clears all of the address information from the local address book of a machine managed with UCS.
	Initialize Delivery Addr Book
48	Push [Execute] to delete all items (this does not include user codes) in the delivery address book that is controlled by UCS.
	Initialize LDAP Addr Book
49	Push [Execute] to delete all items (this does not include user codes) in the LDAP address book that is controlled by UCS.
	Initialize All Addr Book
50	Clears everything (including user codes) in the directory information managed by UCS.  However, the accounts and passwords of the system administrators are not deleted.
<i>E</i> 1	Backup All Addr Book
51	Uploads all directory information to the SD card.
52	Restore All Addr Book
J2	Downloads all directory information from the SD card.

	Clear Backup Info.			
53	Deletes the address book uploaded from the SD card in the slot. Deletes only the files uploaded for that machine. This feature does not work if the card is write-protected.			
	<b>Note</b> : After you do this SP, go out of the SP mode, turn the power off. Do not remove the SD card until the Power LED stops flashing.			
	Search	Option		
	This SP uses bit switches to set up the fuzzy search options for the UCS local address book.			
	Bit	Meaning		
	0	Checks both upper/lower case characters		
	1			
60	2	Japan Only		
	3			
	4	Not Used		
	5	Not Used		
	6	Not Used		
	7	Not Used		
	Complexity Option 1			
	Use this SP to set the conditions for password entry to access the local address book.  Specifically, this SP limits the password entry to upper case and sets the length of the password.			
62	[0 to 32/0/1]			
	Note:			
	This SP does not normally require adjustment.			
		is enabled only after the system administrator has set up a group password policy to access to the address book.		

# Complexity Option 2

Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to lower case and defines the length of the password.

63 [0 to 32/0/1]

#### Note:

This SP does not normally require adjustment.

This SP is enabled only after the system administrator has set up a group password policy to control access to the address book.

# Complexity Option 3

Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to numbers and defines the length of the password.

64 [0 to 32/0/1]

## Note:

This SP does not normally require adjustment.

This SP is enabled only after the system administrator has set up a group password policy to control access to the address book.

# Complexity Option 4

Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to symbols and defines the length of the password.

65 [0 to 32/0/1]

#### Note:

This SP does not normally require adjustment.

This SP is enabled only after the system administrator has set up a group password policy to control access to the address book.

# FTP Auth. Port Settings

Sets the FTP port to get the delivery server address book that is used in the individual authorization mode.

[0 to 65535/3671/1]

0.4	Encryption Stat	
94	Shows the status of the encryption function of the address book on the LDAP server.	

	Rep. Resolution Reduction			CTL			
	These SP's change the default settings of image data sent externally by the Net File page reference function. [0 to 2/1]						
5847	Note:						
	"NetFile" refers to jobs to be printed from the document server with a PC and the DeskTopBinder software.						
	This SP is available only after the File Format Converter (B609) has been installed.						
1	Rate for Copy Color	[0 to 5/2/1]	0: 1x				
2	Rate for Copy B&W Text	[0 to 6/0/1]	1: 1/2	x			
3	Rate for Copy B&W Other	[0 to 5/2/1]	2: 1/3				
4	Rate for Printer Color		3: 1/4x 4: 1/6x				
5	Rate for Printer B&W		5: 1/8				
7	Rate for Printer B&W 1200 dpi	x1					
	Note: "6:" above (2/3x) applies to 3, 5, 6 or	nly.					
	Network Quality Default for JPEG						
21	Sets the default value for the quality of JPEG images sent as NetFile pages. This function is available only with the MLB (Media Link Board) option installed.  [5 to 95/50/1]						

5848	Web Service	CTL	
	5847 2 sets the 4-bit switch assignment for the access control setting. Setting of 5848 1 has no effect on access and delivery from Scan Router. 5847 100 sets the maximum size of images that can be downloaded. The default is equal to 1 gigabyte.		
2	Acc. Ctrl.: Repository (only Lower 4 Bits)	000: No access control 001: Denies access to eskTop Binder.	

3	Acc. Ctrl.: Doc. Svr. Print (Lower 4 Bits)				
4	Acc. Ctrl.: User Directory (Lower 4 Bits)				
9	Acc. Ctrl.: Job Control (Lower 4 Bits)		Switches access control on and off.		
11	Acc. Ctrl: Device Management (Lower 4 Bits)		0000: OFF, 0001: ON		
21	Acc. Ctrl: Delivery (Lower 4 Bits)				
22	Acc. Ctrl: User Administration (Lower 4 Bits)				
99	Repository: Download Image Setting <b>DFU</b>				
	This is a bit-switch setting. Only the lower 4 bits are enabled/disabled.  Set to "0" (disabled) or "1" (enabled) as needed for image download.  (1) Mac OS  (2) Windows OS  (3) OS other than Mac or Windows  Note: This SP is used primarily by designers.				
100	Repository: Download Image Max. Size	[1 to 204	48 /2048 /1 K]		

210	Setting: Log Type: Job 1 <b>DFU</b>	
210	[0 to 0xFFFFFFF/0/1]	
211	Setting: Log Type: Job 2 <b>DFU</b>	
211	[0 to 0xFFFFFFF/0/1]	
212	Setting: Log Type: Access <b>DFU</b>	
212	[0 to 0xFFFFFFF/0/1]	
213	Setting: Primary Srv <b>DFU</b>	
214	Setting: Secondary Srv <b>DFU</b>	
215	Setting: Start Time <b>DFU</b>	Note: These SP's are for display only; they cannot be changed.
213	[0 to 0xFFFFFFF/0/1]	cannot be changed.
216	Setting: Interval Time <b>DFU</b>	
210	[1 to 100/1/1]	
	Setting: Timing <b>DFU</b>	
217	[0 to 2/0/1]	
	0: Transmission off	
	1: Transmission 1 by 1	
	2: Periodic transmission	

5849	Installation Date	CTL	
3049	Displays or prints the installation date of the machine.		
	Display		
1	Displays the installation date. The installation date is set automatically done at the installation site.	after test copies are	

	Switch to Print
	Determines whether the installation date or total count is printed on the total counter printout.
2	[0 to 1/0/1]
	0: Off. No Print
	1: On. Print
2	Total Counter
3	Displays the total count starting from the installation date (SP5849-1).

	5851	Bluetooth Not Used
		Sets the operation mode for the Bluetooth Unit. Press either key.
		[0 to 1/0/1]
		[O:Public] [1: Private]

	5853	Stamp Data Download	CTL
		Push [Execute] to download the fixed stamp data from the machine RON disk so that these stamps can be used by the system. The customer will not these stamps ("Confidential", "Secret", etc.) until this SP has been executed.	
Note:			
This SP must always be executed after the HDD has been reformatted or repl		d or replaced.	
		Always switch the machine off and on after executing this SP.	

5856	Remote ROM Update	CTL
	When set to "1" allows reception of firmware data via the local port (IEEE a remote ROM update. This setting is reset to zero after the machine is cyclon.	
	[0 to 1 / 0 / 1] 0: Not allowed	
	1: Allowed	

	5857	Save Debug Log	CTL	
--	------	----------------	-----	--

Switches on the debug log feature. The debug log cannot be captured until	
is switched on.  [0 to 1/0/1]  0: OFF  1: ON	l this feature
Target (2: HDD 3: SD Card)	
Selects the destination where the debugging information generated by the a selected by SP5858 will be s to red if an error is generated  [2 to 3 /2/1]  2: HDD  3: SD Card	event
Save to HDD	
Specifies the decimal key number of the log to be written to the hard disk.	
Save to SD Card	
Specifies the decimal key number of the log to be written to the SD Card.	
Copy HDD to SD Card (Latest 4 MB)	
Takes the most recent 4 MB of the log written to the hard disk and copies the Card. A unique file name is generated to avoid overwriting existing file name Card. Up to 4MB can be copied to an SD Card. 4 MB segments can be copied to each SD Card.	nes on the SD
Copy HDD to SD Card Latest 4 MB Any Key)	
Takes the log of the specified key from the log on the hard disk and copies Card. A unique file name is generated to avoid overwriting existing file nam Card. Up to 4 MB can be copied to an SD Card. 4 MB segments can be co one to each SD Card. This SP does not execute if there is no log on the HDI specified.	nes on the SD opied one by
Erase HDD Debug Data	
Erases all debug logs on the HDD	

	Erase SD Card Debug Data
12	Erases all debug logs on the SD Card. If the card contains only debugging files generated by an event specified by SP5858, the files are erased when SP5857-10 or -11 is executed.
	to enable this SP, the machine must be cycled off and on.
13	Free Space on SD Card
13	Displays the amount of space available on the SD card.
	Copy SD to SD (Latest 4MB)
14	Copies the last 4MB of the log (written directly to the card from shared memory) on to an SD card.
	Copy SD to SD (Latest 4MB Any Key)
15	This SP copies the log on an SD card (the file that contains the information written directly from shared memory) to a log specified by key number.
16	Make HDD Debug
10	This SP creates a 32 MB file to store a log on the HDD.
17	Make SD Debug
17	This SP creates a 4 MB file to store a log on an SD card.

	Debug Save When	CTL	
5858	These SP's select the content of the debugging information to be saved to the destination selected by SP5857-2. SP58583 stores one SC error specified by number.		
	Engine SC Error (0:OFF 1:ON)		
1	Stores SC codes generated by main machine engine errors.  [0 to 1/0/1]		
	Controller SC Error (0:OFF 1:ON		
2	Stores SC codes generated by CTL controller errors.  [0 to 1/0/1]		
3	Any SC Error		
3	0:OFF 1:ON		

	Jam (0:OFF 1:ON
4	Stores jam errors. [0 to 1/0/1]

5859	Debug Save Key No.	CTL
	These SP's allow you to set up to 10 keys for log files for functions that use memory on the controller board.	
	[-9999999 to 9999999 / 0 / 1]	
1 to 10 Key 1 to Key 10		

5860	SMTP/POP3/IMAP4	CTL
	Partial Mail Receive Timeout	
20	[1 to 168/72/1]  Sets the amount of time to wait before saving a mail that breaks up during received mail is discarded if the remaining portion of the mail is not received prescribed time.	
	MDN Response RFC2298Compliance	
21	Determines whether RFC2298 compliance is switched on for MDN reply mo [0 to 1/1/1]  0: No  1: Yes	ail.
	SMTP Auth. From Field Replacement	
22	Determines whether the FROM item of the mail header is switched to the val after the SMTP server is validated.  [0 to 1/0/1]  0: No. "From" item not switched.	idated account
	1: Yes. "From" item switched.	

	SMTP Auth Direct Sending
25	Occasionally, all SMTP certifications may fail with SP5860-6 set to "2" to enable encryption during SMTP certification for the SMTP server. This can occur if the SMTP server does not meet RFC standards. In such cases you can use this SP to set the SMTP certification method directly. However, this SP can be used only after SP5860-3 has been set to "1" (On).
	BitO: LOGIN
	Bit1: PLAIN
	Bit2: CRAM_MD5
	Bit3: DIGEST_MD5
	Bit4 to Bit 7: Not Used
	S/MIME:MIME Header Specification
	This SP determines the standard type of header for e-mails sent with S/MIME.
26	[0 to 1 / 0 / 1]
	0: Microsoft Outlook Express
	1: Internet Draft
	2: RFC

5866	Email Report	CTL	
	Report Validity		
	Disables and re-enables the email notification feature.		
1	[0 to 1/0/1]		
	0: Enable		
	1: Disable		
	Add Date Field		
5	This SP adds the current date to the date field of an email alert that informs the an error has occurred.	operator that	
5	[0 to 1/0/1]		
	0: Date not added		
	1: Date added		

	5870	Common Key Ir	nfo Writing	CTL
		Writes to flash ROM the common proof for validating the device for @Remote specifications.		
	1	Writing	Note: These SP's are for future use and currently are not used.	
	3	Initialize	Trole. These or sale for future use and currently are not used.	

5873	SD Card Appli Mov	е	CTL
36/3	Moves an application from one SD card to another		
1	Move Exec	Executes the move from one SD card to another.	
2	Undo Exec	This is an undo function. It cancels the previous execution.	

5875	SC Auto Reboot	CTL
1 Reboot Setting		
	Determines whether the machine reboots automatically when an SC error occ [0 to 1/0/1]	urs.
1: The machine does not reboot when an SC error occurs. However, the reboo occur for Type "A" SC codes.  0: The machine reboots automatically when the machine issues an SC error and SC error code. If the same SC occurs again, the machine does not reboot.		ot does not
		nd logs the
2	2 Reboot Type  Selects the reboot method after an SC error occurs.  [0 to 1/0/1]  0: Manual reboot by operator or technician  1: Automatic reboot	

	Option Setup	CTL
5878	Press [Execute] to initialize the Data Overwrite Security and HDD Encryption option.  Both options are available on SD cards.	
1	Data Overwrite Security	

CTI

This SP enables the Data Overwrite Security option.

Note:

Before execution the SD card must be in SD Card Slot 1 (option slot).

The SD card must reside in Slot 1 after execution.

HDD Encryption

This SP enables the HDD Encryption option.

Note:

Before execution the SD card must be in SD Card Slot 1 (option slot).

The SD card can be removed after execution.

5881	Fixed Phrase Block Erasing	CTL
	Press [EXECUTE] to erase fixed phrases supplied by SKB.	

Set WIM Function

	Sel Wilvi	TOTICHOTI		CIL
5885			now access to the Web Image Monitor document server is s where "1" enables and "0" disables.	controlled.
20	DocSvr Acc Ctrl			
	Allows or	disallows	the functions of web image monitor.	
	0: OFF, 1	: ON		
			(7) 0000 0000 (0)	
	LSB	Obit	Denies all access to document server	
		1 bit	Denies all access to User Tools	
		2bit	Denies access to printing	
		3bit	Denies access to fax	
		4bit	Denis access to scan-to-email	
		5bit	Denies access data downloading functions	
		6bit	Denies access to data delete functions	
	MSB	7bit	Forbid guest user	

50	DocSvr Forr	nat	
	Selects the o	display type for the document box list.	
	[0 to 2 / 0 / 1]		
	0: Thumbna	il, 1: Icon, 2: Details	
51	DocSvr Trar	ns	
		nber of documents to be displayed in the document box list.	
	[5 to 20 / 1	0/1]	
100	Set Signatur	re	
		rmines whether a signature is attached to scanned documents queued for a Web Image Monitor.	
	[0 to 2 / 0	/ 1]	
	0: Set indivi	dually	
		elects signature on the send screen when documents are sent via email. as the option of selecting or not selecting a signature.	
	1: Signature	e required. A signature must be selected for sending.	
	2: No signa	ture. No signature requird.	
101	O1 Set Encryption		
	Determines whether the scanned documents with the WIM are encrypted when they are transmitted by an e-mail.		
	[0 to 1 / 0 / 1]		
	0: Not encr	ypted, 1:Encryption	
200	Detect Mem	ı Leak	
	This SP dete	rmines how Web Image Monitor memory leaks are handled. A "1" setting function.	
		(7) 0000 0000 (0)	
	Bit O	Displays memory status at session timeouts.	
	Bit 1	Displays memory status at the start/end of PF handler only.	
	Bit2-7	Not used	
201	DocSvr Time	eout	

This SP sets the length of time for session timeout. The default is 30 min. The time can be reduced to shorten the time between memory leak detections. [1 to 255 / 30 / 1 min.]

5887	SD Get Counter	CTL
	After you touch [EXECUTE] this SP sends a text file to an SD card inserted in SD 2. The file is stored in a folder created in the root directory of the SD card calle SD_COUNTER. The file is saved as a text file (*.txt) prefixed with the number of machine.	d
	Insert the SD card in SD card Slot 1 (lower slot).	
	Select SP5887 then touch [EXECUTE].	
	Touch [EXECUTE] in the message when you are prompted.	

5888	Personal Information Protect	CTL
	Selects the protection level for logs.	
	[0 to 1 / 0 / 1}	
	0: No authentication, No protection for logs	
	1: No authentication, Protected logs (only an administrator can see the logs)	

5893	SDK Application Counter	CTL
	The machine stores up to six registered names in the SDK application.	
	<ul> <li>This SP has been implemented for all machines using Engine 08S and late</li> </ul>	er.
	This SP is not needed if there are no SDK applications loaded.	
1 to 6	SDK1 to SDK-6	

5894	External Mech Count Setting	
	This SP switches the operation mode of the external counter	
	Mech Counter Switch Setting	[0 to 2/22/1]

5898	HDD Pages
------	-----------

2

[0 to 2/0/1]
0: Standard
1: Extension A
2: Extension B

5907	Plug & Play Maker/Model Name	CTL	
	Selects the brand name and the production name for Windows Plug & Play. This information is stored in the NVRAM. If the NVRAM is defective, these names should be registered again.		
	After selecting, press the "Original Type" key and "#" key at the same time.		
	When the setting is completed, the beeper sounds five times.		

5913	Switchover Permission Time
	Sets the length of time to elapse before allowing another application to take control of the display when the application currently controlling the display is not operating because a key has not been pressed.  [3 to 30/3/1 s]

5959	Paper Size
	Tray 1 (tandem tray) and the LCT do not have automatic paper size detection. Use these SP codes to set the paper size for Tray 1 and the optional LCT when it is installed.
	1st Tray (Tandem)
1	The following paper sizes can be set. If the A3 DLT kit is not installed, you can only use settings 0 and 1
	[0 to 1/0/1]
	0: A4
	1: 8.5x11

	1st Tray (A3 Kit)		
	The 1st Tray accepts the paper sizes below after the A3 Kit has been installed.		
	0: A4 5: 11x17		
2	1: 8.5x11	6: 8.5x14 SEF	
	2: A3 SEF	7: 8.5x11 SEF	
	3: B4 SEF	8: Custom	
	4:A4 SEF		

5960	A3 Tray Custom Paper Size Set	
	Sets the custom paper size for the A3/DLT option installed in Tray 1.	
1	Width (Main Scan)	[210 to 305/297/0.1]
2	Length (Sub Scan)	[210 to 439/210/0.1]

5965	Dehum-Heat on
	Sets the anti-condensation heaters to remain on at all times. Normally, the heaters switch on only after the machine has been switched off.
	[0 to 1/0/1] 0:OFF/1:ON

5967	Copy Server: Set Function	CTL
	Disables and enables the document server. This is a security measure that data from being left in the temporary file sector of the HDD. After changin switch the main switch off and on to enable the new setting.	
	[0 to 1/0/1] 0: Enable 1: Disable	

5974	Cherry Server	CTL
	Selects which version of the Scan Router application program, "Light" or (Professional)", is installed.	"Full
	[0 to 1 / 0 / 1 /step]  O: Light version  1: Full version	

5985	Device Setting		CTL
	The NIC and USB support features are built into the CTL controller. Use this SP to enable and disable these features. In order to use the NIC and USB functions built into the controller board, these SP's must be set to "1".		
	[0 to 2/0/1]		
	0: Disable 1: Enable 2: Enable for	@Remote	
001	On Board NIC		
002	On Board USB		

5987	Mech. Counter
	This SP switches the mechanical counter on and off.
	0: OFF / 1: ON

5990	SP Print Mode (SMC Printout)		CTL
1	All (Data List)		
2	SP (Mode Data List)		
3	User Program		
4	Logging Data		
5	Diagnostic Report		
6	Non-Default	Prints all of the system parameter lists for the item selected.  Input the number for the item that you want to pri and then press [1]: "Execute" on the touch panel	, .
7	NIB Summary		•
8	Capture Log		
21	Copier User Program		
22	Scanner SP		
23	Scanner User Program		
24	SDK/J Summary		
25	SDK/J Application Info.		

# **Group 6000**

6006	ADF Reg Adj	D0704/D075	
1	ADF Main Reg Adj:Front	[-3 to 3/0/0.1 mm]	
	Adjusts the side-to-side registration for the fron	t in ADF mode.	
2	ADF Main Reg Adj:Rear	[-4 to 4/0/0.1 mm]	
	Adjusts the side-to-side registration for the bac	k in ADF mode.	
3	ADF Sub Reg Adj	[-29 to 29/0/1 step]	
	Adjusts the vertical registration for the front in ADF mode.		
5	ADF Buckle Adj: Front	[-16 to 23/0/1 step]	
	Adjusts the roller timing at the skew correction sensor/entrance roller. A higher setting causes more buckling.		
6	ADF Buckle Adj: Rear	[-20 to 20/0/1 step]	
	These settings adjust the erase margin for the trailing edges for the rear.		
7	Rear Edge Rail Width (0.5mm/step)	[-20 to 20/-3/1 step]	
	This SP is used to eliminate shadows that may appear at the trailing edge of copies.		

6007	ADF Input Check		D0704/D075
1	ADF Group 1	[0 to 0xFF/0]	
2	ADF Group 2		
3	ADF Group 3		
	Open SP mode SP6007.		
	Select the SP number that corresponds to the component you wish to check. (Refer to the table below.)		
	<ol><li>Press On then press Off to test the selected item. You cannot exit and close this display until you click Off to switch off the output check currently executing.</li></ol>		
	Description	Re	eading
	Description	0	1

2	Original Tray B5 Detect Sensor Original Tray A4 Detect Sensor	No paper	Paper detected
	Original Tray A4 Detect Sensor		
		No paper	Paper detected
3	Original Tray LG Detect Sensor	No paper	Paper detected
4	Original Width Sensor 1	No paper	Paper detected
5	Original Width Sensor 2	No paper	Paper detected
6	Original Width Sensor 3	No paper	Paper detected
7	Original Width Sensor 4	No paper	Paper detected
8	Original Width Sensor 5	No paper	Paper detected
9	Original Set Sensor	No paper	Paper detected
10	Separation Sensor	No paper	Paper detected
11	Skew Correction Sensor	No paper	Paper detected
12	Entrance Sensor	No paper	Paper detected
13	Registration Sensor	No paper	Paper detected
14	Exit Sensor	No paper	Paper detected
15	Cover Sensor	Open	Close
16	ADF Position Sensor	Open	Close
18	Pick-up Roller HP Sensor	Not HP	HP
20	APS Start Sensor	Not Start	Start
21	Bottom Plate HP Sensor	Not HP	HP
22	Bottom Plate Position Sensor	Incorrect Position	Correct Position

6008	Output Check	D0704/D075
	Turns on the selected ARDF motor (forward o running, or you will a solenoid click. This concorrectly.	-
1	ADF Feed Motor (Fwd)	[0 to 1/0/1]
2	ADF Feed Motor (Rev)	

	ADF Exit Motor (Fwd)	
5   1	ADF Upper Inverter Motor (Fwd)	
6	ADF Upper Inverter Motor (Rev)	
7	ADF Lower Inverter Motor (Fwd)	
8	ADF Lower Inverter Motor (Rev)	
9	ADF Pick-up Motor (Fwd)	
10	ADF Bottom Plate Lift Motor (Fwd)	
11	ADF Upper Inverter SOL	
12	ADF Lower Inverter SOL	

6009	ADF Free Run		D0704/D075
	This SP does an ADF free run	in duplex origin	al mode.
1	Simplex	[0 to 1/0/1]	
2	Duplex		

6016	ADF Priority Org Size Setting	D0704/D075
	ADF Original Size Detection Priority. Allows s original size detection.	election of alternate settings for automatic
	[0 to 255/0/1]	

6017	ADF Adjust	D0704/D075
	Adjusts magnification for the ARDF by changing scanning speed.	
	[-1 to 1/0/0.1%]	

If the original is small (B6, A5, HLT), the delay sensor detects the leading edge of the sheet and delays the original at the entrance roller for the prescribed number of pulses to buckle the leading edge and correct skew.

[0 to 1/1]

0: Delay skew correction only for small originals

1: Delay skew correction for all originals, regardless of size. (May reduce the scanning speed of the ADF)

[0 to 1/0/1] 0:Buckle Correction OFF 1:Buckle Correction ON

6200	Adjust Booklet Staple Position	
	This SP corrects the stapling p by the Booklet Finisher (D513	position of the booklet stapler when paper is staple and folded 3)
1	A3 SEF	[-2 to 2/0/0.2 mm]
2	B4 SEF	
3	A4 SEF	
4	B5 SEF	
5	12x18	
6	13x19	
7	DLT SEF	
8	LG SEF	<b>⊕</b> ← → ⊖ b132s923
9	LT SEF	
11	Other	

6201	Adjust Booklet Fold Position	
	This SP corrects the folding position when paper is stapled and folded by the Booklet Finisher (D513)	
1	A3 SEF	[-2 to 2/0/0.2 mm]
		+ : Shifts staple position toward crease
		- : Shifts staple position away from crease.

2	B4 SEF	
3	A4 SEF	
4	B5 SEF	
5	12x18	<del></del>
6	13x19	$\Theta$ $\Theta$
7	DLT SEF	
8	LG SEF	b132s924
9	LT SEF	
11	Other	

6202	Fine Adj Booklet Jogger Fence Position	
	This SP adjusts the distance between the jogger fences and the sides of the stack on the finisher stapling tray in the Booklet Finisher. The adjustment is done perpendicular to the direction of paper feed.	
1	A3 SEF	[-0.5 to 0.5/0/0.1 mm]
2	B4 SEF	+ : Shifts staple position toward crease
3	A4 SEF	- : Shifts staple position away from crease.
4	B5 SEF	
5	12x18	
6	13x19	
7	DLT SEF	
8	LG SEF	
9	LT SEF	
11	Other	

|--|

2

This SP sets the number of times the folding rollers are driven forward and reverse to sharpen the crease of a folded booklet before it exits the folding unit. When set at the default (0):

- The folding blade pushes the center of the stack into the nip of the folding roller.
- The folding rollers rotated ccw to crease the booklet, reverse cw, then rotate ccw again crease the booklet fold twice before feeding to the folding unit exit rollers.

[-1 to 9/0/ step]

6205	Booklet Stapler Jog Pawl Adj	ust
1	A3 SEF	[-3 to 3/0/0.2 mm]
2	B4 SEF	
3	A4 SEF	
4	B5 SEF	
5	12x18	
6	13x19	
7	DLT SEF	
8	LG SEF	
9	LT SEF	
11	Other	

6208	Staple Position Adjustment	
1	A3 SEF	[-1 to 1/0/0.5 mm] + : Shifts staple position toward crease - : Shifts staple position away from crease.
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	B5 SEF	
6	B5 LEF	

7	DLT SEF	
8	LG SEF	
9	LT SEF	
10	LT LEF	
11	8-Kai SEF	
12	16-Kai SEF	
13	16-Kai LEF	
14	Other	

6209	Punch Position Adjustment : Sub Scan	
	Adjusts the punch hole position	ons in the direction of paper feed.
1	2-Hole EU/JPN	[-3.5 to 3.5/0/0.5 mm]
2	3-Hole NA	
3	4-Hole EU	
4	4-Hole Scandinavia	
5	2-Hole Scandinavia	

6210	Punch Position Adjustment : Main Scan	
	This SP adjusts the punch position (front-to-back) in the main scan direction.	
1	2-Hole EU/JPN	[-3 to 3/0/0.5 mm]
2	3-Hole NA	
3	4-Hole EU	
4	4-Hole Scandinavia	
5	2-Hole NA	

6211	End Bind Jogger Adjustment	
1	A3 SEF	[-1 to 1/0/0.5 mm]

2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	B5 SEF	
6	B5 LEF	
7	DLT SEF	
8	LG SEF	
9	LT SEF	
10	LT LEF	
11	8-Kai SEF	
12	16-Kai SEF	
13	16-Kai LEF	
14	Other	

6212	Adjust Output Jog Position	
		petween the output jogger fences and the sides of the stack ttached to the side of the machine jogs sheets as they exit the
1	A3 SEF	[0 to 2/2/0.1 mm]
2	B4 SEF	
3	A4 SEF	[0 to 5/5/0.1 mm]
4	A4 LEF	
5	A5 SEF	
6	A5 LEF	
7	B5 SEF	[0 to 2/2/0.1 mm]
8	B5 LEF	
9	DLT SEF	[0 to 5/5/0.1 mm]

10	LG SEF	
11	LT SEF	[0 to 2/2/0.1 mm]
12	LT LEF	[0 to 5/5/0.1 mm]
13	HLT SEF	
14	HLT LEF	

6213	Pre Stack Adjustment	
	default:Normally with standa the 6th sheet feeds, the 6th sh stapling tray together. <b>Note</b> :	this setting or switch it off when feeding thick or slick paper.
	In the settings below "mo	ai" means "sheets".
1	A3 SEF	[0 to 2/2/1 mai]
2	B4 SEF	
3	A4 SEF	[0 to 5/5/1 mai]
4	A4 LEF	
5	B5 SEF	
6	B5 LEF	
7	DLT SEF	[0 to 2/2/1 mai]
8	LG SEF	
9	LT SEF	[0 to 5/5/1 mai]
10	LT LEF	
11	8-Kai SEF	[0 to 2/2/1 mai]
12	16-Kai SEF	[0 to 5/5/1 mai]
13	16-Kai LEF	
14	Other	

6214	Adj Leading Edge Stopper Press	
1	A3 SEF	[-2.5 to 2.5/0/0.5 mm]
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	B5 SEF	
6	B5 LEF	
7	DLT SEF	
8	LG SEF	
9	LT SEF	
10	LT LEF	
11	8-Kai SEF	
12	16-Kai SEF	
13	16-Kai LEF	
15	Other	

6215	Staple Jogging Repeat Setting
	Touch [1:+1 Time] to have the jogger fences press against the sides of the stack on the staple tray one more time to align the stack for corner stapling.  [0:Default] [1:+1 Time]

6216	Staple Tray Jog Off/On	
	[0 to 6/0/1]	
	0:Yes, 1:No, 2:-10, 3:-5, 4:+5, 5:+10	

6218	Finisher Input Check
	[0 to 1/0/1]
1	Finisher Entrance Sensor

2	Pre-stack Paper Sensor
3	Pre-stack Roller HP Sensor
4	Proof Tray JG HP Sensor
5	Stack JG HP Sensor
6	Proof Tray Exit Sensor
7	Proof Tray Full Sensor
8	Punch Vertical Registration Sn
9	Punch Side-to-Side Regist Sn
10	Punch Blade HP Sensor
11	Punch Unit HP Sensor
12	Punch Switch
13	Punch Hopper Full Sensor
14	Punch Set Sensor
15	Stack Plate HP Sensor: Front
16	Stack Plate HP Sensor: Center
17	Stack Plate HP Sensor: Rear
18	Corner Stapler HP Sensor
19	Stapler Rotation HP Sn: Front
20	Stapler Rotation HP Sn: Rear
21	Bottom Fence HP Sensor
22	Jogger Fence HP Sensor: Front
23	Jogger Fence HP Sensor: Rear
24	Positioning Roller HP Sensor
25	Top Fence HP Sensor
26	Stack Feed-out Belt HP Sensor
27	Stapling Tray Paper Sensor

28	Corner Stapler HP Sensor
29	Staple End Sensor
30	Self-Limit Sensor
31	Stpl Trimmings Hopper Set Sn
32	Stpl Trimmings Hopper Full Sn
33	Stapling Tray Entrance Sensor
34	Stack Transport Unit HP Sensor
35	Stack JG HP Sensor
36	Bklet Top Fence HP Sensor
37	Bklet Stplr Clamp Roller HP Sn
38	Fold Plate Cam HP Sensor
39	Fold Plate HP Sensor
40	Bklet Side Fence HP Sn: Front
41	Bklet Side Fence HP Sn: Rear
42	Bklet Stplr Bottom Fence HP Sn
43	Fold Unit Entrance Sensor
44	Bklet Stapler Exit Sensor
45	Bklet Stapler HP Sensor
46	Bklet Stplr Stpl End Sn: Front
47	Bklet Stplr Stpl End Sn: Rear
48	Bklet Tray Full Sensor Upper
49	Bklet Tray Full Sensor Lower
50	Shift Tray Exit Sensor: Long
51	Shift Tray Exit Sensor: Short
52	Exit Guide HP Sensor
53	Drag Roller HP Sensor

54	Shift Tray Upper Limit Switch
55	Shift Tray HP Sensor: Front
56	Shift Tray HP Sensor: Rear
57	Paper Height Sensor: Staple
58	Paper Height Sensor: Shift
59	Paper Height Sensor: Z-Fold
60	Paper Height Sensor: TE
61	Shift Tray Full Sensor: 2500
62	Shift Tray Full Sensor: 1500
63	Shift Tray Full Sensor: 1000
64	Shift Tray Full Sensor: 500
65	Shift Tray Emergency Stop Sw
66	Shift Tray Jogger HP Sensor
67	Shift Jog Fence Retract HP Sn
68	Shift Tray Jogger HP Sensor
69	Front Door Switch
70	Punch Type 1
71	Punch Type 2
72	Staple Tray Set Sensor
73	Sub Board Set Sensor
74	Reserved

6219	Finisher Output Check
	[0 to 1/0/1]
1	Entrance Motor
2	Registration Motor

3	Proof Tray Vertical Trans Mt
4	Pre-stack Release Motor
5	Pre-stack Motor
6	Shift JG Motor
7	Stapler JG Motor
8	Proof Tray Exit Motor
9	Horizontal Transport Motor
10	Punch Movement Motor
11	Punch Switch Motor
12	Punch Drive Motor
13	Stapling Tray Entrance Motor
14	Stack Plate Motor: Front
15	Stack Plate Motor: Center
16	Stack Plate Motor: Rear
17	Punch S-to-S Regist: CIS Lamp
18	Stapler Rotation Motor
19	Stapler Movement Motor
20	Bottom Fence Lift Motor
21	Front Jogger Fence Motor
22	Rear Jogger Fence Motor
23	Positioning Roller Rotation Mt
24	Positioning Roller Motor
25	Stack Feed-out Belt Motor
26	Top Fence Motor
27	Shutter Solenoid
28	Booklet Stapler Motor

29	Stack Transport Motor
30	Stack JG Motor
31	Stack Transport Motor
32	Reserved
33	Bklet Stplr Clamp Roller Motor
34	Bklet Stplr Bottom Fence Motor
35	Bklet Stplr Side Fence Motor
36	Bklet Stplr Top Fence Motor
37	Bklet Stplr Mt
38	Fold Roller Motor
39	Fold Plate Motor
40	Shift Tray Exit Motor
41	Shift Motor
42	Drag Drive Motor
43	Drag Roller Motor
44	Exit Guide Motor
45	Shift Tray Lift Motor
46	Shift Tray Jogger Fence Motor
47	Shift Tray Jog Fence Retra Mt

6220	Finisher Free Run 1	
	Packing Mode	[0 to 1/0/1]

6221	Punch Skew Correction	
	Skew Correction(0:On, 1:Off)	[0 to 1/0/1]

6222	Registration Buckle Adjustment
------	--------------------------------

1	A4 LEF	[-2 to 2/0/0.5 mm]
2	A5 SEF	
3	A5 LEF	
4	B5 LEF	
5	LT LEF	
6	HLT SEF	
7	HLT LEF	
8	Other	

	6223	Exit Guide Plate Close Timing Adj
[0 to 1/0/1] 0:Default 1:Thin Paper		[0 to 1/0/1] 0:Default 1:Thin Paper

6224 Exit Paper Tray Lowering Adj	
	[0 to 2/0/1]
	0: Default
	1: Thin Paper
	2: Thick Paper

6309	Input Check: Folder	
1	Entrance Sensor	[0 to 1/0/1]
2	Entrance JG HP Sensor	
4	Registration Sensor	
5	Dynamic Roller HP Sensor	
6	Registration Roller HP Sensor	
7	Fold Plate HP Sensor	
8	Jogger Fence HP Sensor	
10	1st Stopper Paper Sensor	
11	1st Stopper HP Sensor	

12	2nd Stopper Paper Sensor	
13	2nd Stopper HP Sensor	
14	3rd Stopper Paper Sensor	
15	3rd Stopper HP Sensor	
16	Direct-Send JG HP Sensor	
17	FM6 Pawl HP Sensor	
18	Top Tray Paper Path Sensor	
19	Top Tray Exit Sensor	
20	Horizontal Path Exit Sensor	
21	Top Tray Full Sensor (E)	
23	Front Door Switch (SW1)	
24	Horizontal Path Paper Sensor	
25	Vertical Path Paper Sensor	
26	Bypass Entrance Paper Sensor	
27	Bypass Exit Paper Sensor	

6310	Output Check: Folder	
1	Horizontal Transport Motor	[0 to 1/0/1]
2	Top Tray Transport Motor	
3	Top Tray Exit Motor	
4	Dynamic Roller Transport Motor	
5	Registration Roller Transport Motor	
7	Entrance JG Motor	
8	1st Stopper Motor	
9	2nd Stopper Motor	
10	3rd Stopper Motor	

11	Dynamic Roller Lift Motor	
12	Registration Roller Release Motor	
13	Fold Plate Motor	
14	Jogger Fence Motor	
16	5 Direct-Send JG Motor	
17	7 FM6 Pawl Motor	
18	3 1st Fold Motor	
19	2nd Fold Motor	
20	Crease Motor	
21	Bypass JG Solenoid	
22	2 Exit JG Solenoid	
23	3 Top Tray JG Solenoid	
24	4 LE Stop Pawl Solenoid	
25	5 Reverse JG Solenoid	
26	6 Horizontal Exit Motor	

6311	Folder Free Run (D521)
1	Free Run 1
	System free run. A4 LEF at 90 ppm, with simulated staple mode.
2	Free Run 2
	Free run for durability testing. All motors and solenoids operate to simulate full staple mode run for durability testing.
3	Free Run 3
	Shipping free run. Simulates standby conditions during shipping.
4	Free Run 4
	Shift free run. A4 LEF at 90 ppm with simulated output jogging with the shift jogger unit mounted on the side of the finisher.

6324	Jogger Fence Position Adjust (D521)	
1	A3 SEF	[-2 to 2/0/0.5 mm]
2	B4 SEF	
3	A4 SEF	
4	DLT SEF	
5	LG SEF	
6	LT SEF	
7	12x18	
8	8-Kai	
9	B5T	
19	Other	

6325	Registration Buckle Adjust (D521)	
1	A3 SEF	[-4 to 2/0/1 mm]
2	B4 SEF	
3	A4 SEF	
4	DLT SEF	
5	LG SEF	
6	LT SEF	
7	12x18	
8	8-Kai	
9	B5T	
19	Other	

6326	Registration Buckle Adjust Select (D521)
------	--

2

[0 to 1/0/1]

0: Buckle Control ON

1: Buckle Control OFF

6400	Cvr Inserter Input Check	
1	1st Paper Feed Sensor	[0 to 1/0/1]
2	2nd Paper Feed Sensor	
3	1 st Transport Roller	
4	2nd Transport Roller	
5	1st Vertical Transport Sensor	
6	2nd Vertical Transport Sensor	
7	Output Sensor	
8	Entrance Sensor	
9	Exit Sensor	
10	1 st Pick-up Roller HP Sensor	
11	2nd Pick-up Roller HP Sensor	
12	1 st Upper Limit Sensor	
13	2nd Upper Limit Sensor	
14	1 st Lower Limit Sensor	
15	2nd Lower Limit Sensor	
16	1st Paper Near End Sensor	
17	2nd Paper Near End Sensor	
18	1st Paper End Sensor	
19	2nd Paper End Sensor	
20	1st Paper Length Sensor	
21	2nd Paper Length Sensor	

22	1st Paper Width Sensor 1	
23	1st Paper Width Sensor 2	
24	1st Paper Width Sensor 3	
25	1st Paper Width Sensor 4	
26	1st Paper Width Sensor 5	
27	2nd Paper Width Sensor 1	
28	2nd Paper Width Sensor 2	
29	2nd Paper Width Sensor 3	
30	2nd Paper Width Sensor 4	
31	2nd Paper Width Sensor 5	
32	1st Feed Cover Sensor	
33	2nd Feed Cover Sensor	
34	Cover Vertical Transport Switch	
35	Front Door Open Switch	

6401	Cvr Inserter Output Check	
1	OFF (Stop)	[0 to 1/0/1]
2	1 st Pick-up Motor	
3	2nd Pick-up Motor	
4	1 st Paper Feed Motor	
5	2nd Paper Feed Motor	
6	1 st Transport Motor	
7	2nd Transport Motor	
8	Vertical Transport Motor	
9	Horizontal Transport Motor	

6500
------

1	A4 LEF	[-2 to 2/0/0.1 mm]
2	LT LEF	

6501	Paddle Pos Adjustment (D519)
	[-3 to 3/0/0.1 mm]

6502	Adj Binding Position 1 (D519)	
1	1 A4 LEF [-2 to 2/0/0.1 mm]	
2	LT LEF	

6503	Adj Binding Position 2 (D519)	
1	1 A4 LEF [-2 to 2/0/0.1 mm] 2 LT LEF	
2		

6504 Adj Jog: Punching (D519)		
1	1 A4 LEF [-4 to 4/0/0.1 mm]	
2	LT LEF	

6505	Adj Jog: Paddle (D519)	
	[-3 to 3/0/0.1 mm]	

6506 Adj Jog: Binding 1 (D519)		Adj Jog: Binding 1 (D519)	
	1	A4 LEF [-2 to 2/0/0.1mm]	
	2	LT LEF	

6507 Adj Jog: Binding 2 (D519)		Adj Jog: Binding 2 (D519)	
	1	1 A4 LEF [-2 to 2/0/0.1mm]	
	2	LT LEF	

6508	Input Check: Ring Binder (D519)	
1	Entrance Sensor	[0 to 1/0/1]
2	Transport Sensor	
3	Exit Sensor	
4	Punch Process Reference Sensor	
5	Binder Delivery Base Sensor	
6	Path JG HP Sensor	
7	Paper Jog HP Sensor	
8	Jog Roller Lift HP Sensor	
9	Punch HP Sensor	
10	Punch Encoder Sensor	
11	Unit Detect Sensor	
12	Punch Size A4/LT Sensor	
13	Punch Type Sensor	
14	Full Sensor	
15	Punchout Box Sensor	
16	Output Belt 1 HP Sensor	
17	Output Belt 2 HP Sensor	
18	Output Belt Rotation HP Sensor	
19	Output Unit Entrance Sensor	
20	Booklet Pass Sensor	
21	Stack HP Sensor	
22	Stack Height Sensor 1	
24	Stacker Paper Detect Sensor	
25	Tray Detect Sensor	
26	Obstacle Detect Sensor	

27	Book Position Sensor
28	Binder Unit Sensor
29	Width Align HP Sensor 1
30	Paddle Roller HP Sensor
31	Clamp HP Sensor
32	Alignment Pin HP Sensor
33	Shutter HP Sensor
34	50-Sheet Detect Sensor
35	Paper Thickness Sensor
37	Paper LE Detect Sensor
38	Alignment Pin Top Edge Sensor
39	Width Align HP Sensor 2
40	De-curler Motor HP Sensor
41	Shutter Motor HP Sensor
42	Roller Lift Motor HP Sensor
43	Binder HP Sensor
44	Bind Timing Sensor
45	Ring Replace HP Sensor
46	Ring Replace Timing Sensor
47	Ring Supply Detect Sensor
48	Cartridge Reversed Sensor
49	Ring Near-End Sensor
50	Ring 50/100 Sensor
51	Ring A4/LT Sensor

	Output Check: Ring Binder (D519)	6509	
--	----------------------------------	------	--

1	Entrance Motor	[0 to 1/0/1]
2	Transport Motor	
3	Exit Motor	
4	Path JG Motor	
5	Jog Roller Motor	
6	Side Jogger Motor	
7	After-Punch Output Motor	
8	Jog Roller Lift Motor	
9	Hole Clear Motor	
10	Top Fence SOL	
11	Output Belt 1 Motor	
12	Output Belt 2 Motor	
13	Output Belt Rotation Motor	
14	Output Tray Lift Motor	
15	De-curler Motor	
16	Shutter Motor	
17	Paddle Roller Motor	
18	Alignment Pin Motor	
19	Paddle Roller Lift Motor	
20	Width Align Motor 1	
21	Clamp Motor	
22	Width Align Motor 2	
23	Roller Motor	
24	Roller Lift Motor	
25	Main Lift Motor	
26	50/100 Adjustment Motor	

6600	Stacker Input Check (D515)	
1	Entrance Sensor	[0 to 1/0/1]
2	Shift Tray Exit Sensor	
3	Proof Tray Exit Sensor	
4	Exit Sensor	
5	Transport Sensor	
6	Proof Tray Full Sensor	
7	Shift Tray JG HP Sensor	
8	Proof Tray JG HP Sensor	
9	Shift Roller HP Sensor	
11	Front Jogger Fence HP Sensor	
12	Rear Jogger Fence HP Sensor	
13	Jog Fence Retraction HP Sensor	
14	LE Stopper HP Sensor	
15	Paper Height Sensor	
16	Shift Tray Paper Sensor	
17	Tray Full Sensor 1: 25%	
18	Tray Full Sensor 2: 50%	
19	Tray Full Sensor 3: 75%	
20	Tray Full Sensor 4: 100%	
21	Tray Low Limit Sensor	
22	Roll Away Cart Set SW	
23	Tray Guard Sensor 1	
24	Tray Guard Sensor 2	
25	Sub Jogger HP Sensor	
26	Down Button	

27	Jam Button	
28	Top Door SW	
29	Front Door SW	

6601	Stacker Output Check (D515)	
1	Stop	[0 to 1/0/1]
2	Entrance Motor	
3	Proof Tray Exit Motor	
4	Shift Exit Motor	
5	Transport Motor	
6	Shift JG Motor	
7	Proof Tray JG Motor	
8	Shift Motor	
9	Front Jogger Fence Motor	
10	Rear Jogger Fence Motor	
11	Jogger Fence Retraction Motor	
13	LE Stopper Motor	
14	Sub Jogger Motor	
15	Tray Lift Motor	
16	Front Door Lock SOL	
17	Fan Motor	
18	Tray Full LED	
19	Jog In Progress LED	
20	Tray Lift LED	
21	Error LED	

|--|

1	A3 SEF	[-2 to 2/0/0.1 mm]
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	A5 SEF	
6	A5 LEF	
7	B5 SEF	
8	B5 LEF	
9	DLT SEF	
10	LG SEF	
11	LT SEF	
12	LT LEF	
13	HLT SEF	
14	HLT LEF	
15	Other	

6603	LE Stopper Adjust: Stacker (D515)	
1	A3 SEF	[-2 to 2/0/0.1 mm]
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	A5 SEF	
6	A5 LEF	
7	B5 SEF	
8	B5 LEF	
9	DLT SEF	

10	LG SEF	
11	LT SEF	
12	LT LEF	
13	HLT SEF	
14	HLT LEF	
15	Other	

6604	SubJog Fence Adjust: Stacker (D515)	
1	A3 SEF	[-2 to 2/0/0.1 mm]
2	B4 SEF	
9	DLT SEF	
10	LG SEF	
15	Other	

6612	Stacker Fan Setting
	[0 to 1/0/1] 0:ON 1:OFF

6650	SHINJIKO Input Check	Trimmer Unit TR5040 (D520)
1	Entrance Sensor	[0 to 1/0/1]
2	Stopper Sensor	
3	Exit Sensor	
4	Booklet Sensor 1	
5	Booklet Sensor 2	
6	Booklet Sensor 3	
7	Trimming Blade HP Sensor	
8	Cut Posion HP Sensor	
9	Press Roller HP Sensor	

10	Press Stopper HP Sensor	
11	Scrap Hopper Full HP Sensor	
12	Scrap Hopper HP Sensor	
13	Door Switch	

6651	SHINJIKO Output Check	Trimmer Unit TR5040 (D520)
1	Entrance Motor	[0 to 1/0/1]
2	Exit Motor	
3	Press Roller Motor	
4	Cut Position Motor	
5	Press Stopper Motor	
6	Tray Motor	
7	Trimming Blade Motor	

6721	Adjust Booklet Staple Position (D512)	
1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	B5 SEF	
5	12x18	[ ] - 1 / 0 / 0 2]
6	13x19	[-1 to 1 / 0 / 0.2 mm]
7	DLT	
8	LG	
9	LT SEF	
10	Other	

6722	Adjust Booklet Fold Position (D512)
------	-------------------------------------

1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	B5 SEF	
5	12x18	[-1 to 1 / 0 / 0.2 mm]
6	13x19	[-1 10 1 / 0 / 0.2 11111]
7	DLT	
8	LG	
9	LT SEF	
10	Other	

6723	Adjust Staple Position (D512/D513)	
1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	B5 SEF	
6	B5 LEF	
7	DLT	[ ] , ] /0 /0 [ ]
8	LG	[-1 to 1 / 0 / 0.5 mm]
9	LT SEF	
10	LT LEF	
11	8kai SEF	
12	16kai SEF	
13	16kai LEF	
14	Other	

6724	Adj Punch Posi Sub Scan (D512/D513)	
1	2-Hole EU/JPN	
2	3-Hole NA	
3	4-Hole EU	[-4 to 4 / 0 / 0.5 mm]
4	4-Hole Scandinavia	
5	2-Hole NA	

6725	Adj Punch Posi Main Scan (D512/D513)	
1	2-Hole EU/JPN	
2	3-Hole NA	
3	4-Hole EU	[ -2 to 2 / 0 / 0.5 mm]
4	4-Hole Scandinavia	
5	2-Hole NA	

6726	Fine Adj Booklet Jogger Fence Position (D512)	
1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	B5 SEF	
5	12x18	[05,05/0/01]
6	13x19	[ -0.5 to 0.5 / 0 / 0.1 mm]
7	DLT	
8	LG	
9	LT SEF	
10	Other	

6728	Booklet Stapler Jog Pawl Adjust (D512)
------	--

1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	B5 SEF	
5	12x18	[ -2 to 2 / 0 / 0.2 mm]
6	13x19	[-2 10 2 / 0 / 0.2 mm]
7	DLT	
8	LG	
9	LT SEF	
10	Other	

6729	End Bin Jogger Adjustment (D512/D513)	
1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	B5 SEF	
6	B5 LEF	
7	DLT	[1, 1/0/05]
8	LG	[-1 to 1 / 0 / 0.5 mm]
9	LT SEF	
10	LT LEF	
11	8kai SEF	
12	16kai SEF	
13	16kai LEF	
14	Other	

6730	Adjust Output Jog Position (D512,	/D513)
1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	A5 SEF	
6	A5 LEF	
7	B5 SEF	
8	B5 LEF	[-1 to 1 / 0 / 0.1 mm]
9	DLT	
10	LG	
11	LT SEF	
12	LT LEF	
13	HLT SEF	
14	HLT LEF	
15	Other	

6731	Adj Leading Edge Stopper Press (D512/D513)
------	--

1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	B5 SEF	
6	B5 LEF	
7	DLT	[ 25 to 25 / 0 / 05]
8	LG	[ -2.5 to 2.5 / 0 / 0.5 mm]
9	LT SEF	
10	LT LEF	
11	8kai SEF	
12	1 6kai SEF	
13	1 ókai LEF	
14	Other	

6733	Registration Buckle Adjustment (D512/D513)	
1	A4 LEF	
2	A5 SEF	
3	A5 LEF	
4	B5 LEF	[ 1, 1 /0 /05 ]
5	LT LEF	[-1 to 1 / 0 / 0.5 mm]
6	HLT SEF	
7	HLT LEF	
8	Other	

Jog Position Adjust Stacker (D515)	
------------------------------------	--

1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	A5 SEF	
6	A5 LEF	
7	B5 SEF	
8	B5 LEF	[-1 to 1 / 0 / 0.1 mm]
9	DLT	
10	LG	
11	LT SEF	
12	LT LEF	
13	HLT SEF	
14	HLT LEF	
15	Other	

6741	LE Stopper Adjust Stacker (D515)
------	----------------------------------

_	40.055	
1	A3 SEF	
2	B4 SEF	
3	A4 SEF	
4	A4 LEF	
5	A5 SEF	
6	A5 LEF	
7	B5 SEF	
8	B5 LEF	[-1 to 1 / 0 / 0.1 mm]
9	DLT	
10	LG	
11	LT SEF	
12	LT LEF	
13	HLT SEF	
14	HLT LEF	
15	Other	

6742	Sub Jog Adjust Stacker (D515)	
1	A3 SEF	
2	B4 SEF	
9	DLT	[-1 to 1 / 0 / 0.1 mm]
10	LG	
15	Other	

6746	Stack Full Setting (D515)
------	---------------------------

		[0 to 3 / 0 / 1]
		0:100%
1	-	1:75%
		2:50%
		3:25%

6752	FM2 Equal 1/2:FineAdjFld(D521	)
1 to 100	Custom Paper 001 to 100	
101	A3 SEF	
102	B4 SEF	
103	A4 SEF	
104	DLT SEF	
105	LG SEF	[ 44- 4 / 0 / 0 2]
106	LT SEF	[-4 to 4 / 0 / 0.2 mm]
107	12x18	
108	8kai	
109	B5 SEF	
110	13x19	
111	Other	

6753	FM3 Equal 3rds:Fine Adj 1st (D521)	
		н

1 to 100	Custom Paper 001 to 100	
101	B4 SEF	
102	A4 SEF	
103	LG SEF	[ -4 to 4 / 0 / 0.2 mm]
104	LT SEF	
107	B5 SEF	
108	Other	

6754	FM3 Equal 3rds:Fine Adj 2nd (D521)	
1 to 100	Custom Paper 001 to 100	
101	B4 SEF	
102	A4 SEF	
103	LG SEF	[-4 to 4 / 0 / 0.2 mm]
104	LT SEF	
107	B5 SEF	
108	Other	

6755	FM4 3rds 1 Flap:Fine Adj 1st (D521)
------	-------------------------------------

1 to 100	Custom Paper 001 to 100	
101	A3 SEF	
102	B4 SEF	
103	A4 SEF	
104	DLT SEF	
105	LG SEF	[-4 to 4 / 0 / 0.2 mm]
106	LT SEF	
107	12x18	
108	8kai	
109	B5 SEF	
110	Other	

6756	FM4 3rds 1 Flap:Fine Adj 2nd (D3	521)
1 to 100	Custom Paper 001 to 100	
101	A3 SEF	
102	B4 SEF	
103	A4 SEF	
104	DLT SEF	
105	LG SEF	[-4 to 4 / 0 / 0.2 mm]
106	LT SEF	
107	12x18	
108	8kai	
109	B5 SEF	
110	Other	

6762	Top Tray Full Set: Enable
	[0 to 1 /0/1]

6763	Top Tray Full Set: Limit Output
	[0 to 250/0/1]

6800	Sheet Conversion <b>DFU</b>	C	CTL
	[1 to 3/3/1]		
	This SP code enables punch operation in Z-fo disabled in Z-fold mode, but this feature can machine calculates one sheet of paper as thi	be enabled by the service technician. The	
	[1 to 3 / 3 / 1]		
	1: 1 sheet		
	2: 2 sheets		
	3: 3 sheets		
i .			

Ring Binding Thick Paper <b>DFU</b>	CTL
Selects the count type for binding the thick paper thick paper as three sheets of plain paper by def	
1: 1 sheet	
2: 2 sheets	
	Selects the count type for binding the thick paper thick paper as three sheets of plain paper by def [1 to 3 / 3 / 1]  1: 1 sheet

6830	Extra Staples <b>DFU</b>	CTL
	More than the standard number of corner staples can be loaded. This SP recognizes the maximum number of staples (This Setting + Standard Number).  • If the number of the maximum for staples is increased, and the mechanical warranty of the unit can be guaranteed, then the setting can take effect without changing the controller software.	
	before changing the setting to increa	I performance can be guaranteed is required se the staple load for more than the maximum in this setting without quality assurance could
1	0 to 50 (Initial: 0) [0 to 50 / 0 / 1]	

	0 to 50 (Initial: 0)
2	[0 to 50 / 0 / 1]

6890	Punch Function Enabled (Z-Fold)	CTL
	Permission for punching thick (tab) paper is forbidden and it is up to the stechnician to pass this on to the customer.	service
	[0 or 1/0/-]	
	0: Simultaneous use forbidden	
	1: Simultaneous use allowed	

6900	ADF Bottom Plate Lift Setting	D0704/D075	
	This SP setting determines whether the bottom plate lift motor of the of the ADF switches on when the original is set in the ADF original tray, or when the [Start] key is pressed.		
	The ADF bottom plate lift motor raises the bottom plate that pushes up the original tray and raises it to the optimum feed position.		
	[0 to 1 /0/1]		
	0: At Original Set		
	1: At Start		

## **Group 7000**

		- '				
7001	Е	ngin	ngine Drive Distance Counter			
	[(	0 to	to 99 999 999/0/1 m]			
7401	Т	otal	SC Counter			CTL
7401			ays the total number of SCs logged.			
		Jispic	ays the lold homber of 3cs logged.			
7403			SC History			CTL
			Displays the latest 10 SC codes.			
	1 to	10	Latest to Latest 9th			
7404			SC991 History			CTL
			Displays the most recent occurrences of SC	991.		
	1 to	10	Latest to Latest 9th			
7502		Total Paper Jam Counter			CTL	
		Displays the total number of copy jams.				
		I				
7503		Tot	al Original Jam Counter			CTL
	Displays the total number of copy jams.					
7504		Paper Jam Total by Location			CTL	
	1	At Power On				
	3	1st Paper Feed Sensor: Late Error				
	4	2nd Paper Feed Sensor: Late Error				
	5	3rd Paper Feed Sensor: Late Error				
	6	4th Paper Feed Sensor: Late Error				

7	5th Paper Feed Sensor: Late Error	
8	6th Paper Feed Sensor: Late Error	
9	1 st Transport Sensor: Late Error	
10	2nd Transport Sensor: Late Error	
11	3rd Transport Sensor: Late Error	
12	4th Transport Sensor: Late Error	
13	5th Transport Sensor: Late Error	
14	6th Transport Sensor: Late Error	
15	Vertical Transport Sensor: Late Error	
16	Bank Exit Sensor (Simplex): Late Error	
17	Bank Exit Sensor (Duplex): Late Error	
18	Main Relay Sensor 1: Late Error	
19	Main Relay Sensor 2: Late Error	
20	Main Relay Sensor 3: Late Error	
21	3rd Vertical Trans Sn (Upper): Late Error	
22	3rd Vertical Trans Sn (Lower): Late Error	
23	4th Vertical Trans Sn: Late Error	
24	5th Vertical Trans Sn: Late Error	
25	LCT Exit Sensor: Late Error	
26	LCT Relay Sensor 1: Late Error	
27	LCT Relay Sensor 2: Late Error	
28	Registration Sensor (Main): Late Error	
29	Registration Sensor (LCT): Late Error	
30	Paper Late Jam	
31	Transfer Timing Sensor: Late Error	
32	PTB Jam Sensor: Late Error	

33	Fusing Exit Sensor: Late Error
34	Feed-out Entrance Sensor: Late Error
35	Exit Junction Gate Sensor: Late Error
36	Exit Sensor: Late Error
38	Exit Relay Sensor (2nd Pass) : Late Error
39	Exit Relay Sensor (Duplex) : Late Error
40	Duplex Invert Sn (1st Pass) : Late Error
41	Duplex Invert Sensor (2nd Pass): Late Error
42	Duplex Transport Sensor 1: Late Error
43	Duplex Transport Sensor 2: Late Error
44	Duplex Transport Sensor 3: Late Error
45	Duplex Transport Sensor 6: Late Error
46	Duplex Transport Sensor 7: Late Error
53	1st Paper Feed Sensor
54	2nd Paper Feed Sensor
55	4th Paper Feed Sensor
56	5th Paper Feed Sensor
57	6th Paper Feed Sensor
58	7th Paper Feed Sensor (LCT)
59	1 st Transport Sensor: Lag Error
60	2nd Transport Sensor: Lag Error
61	3rd Transport Sensor: Lag Error
62	4th Transport Sensor: Lag Error
63	5th Transport Sensor: Lag Error
64	6th Transport Sensor: Lag Error
65	Vertical Transport Sensor: Lag Error

, .		
66	Bank Exit Sensor: Lag Error	
68	Main Relay Sensor 1: Lag Error	
69	Main Relay Sensor 2: Lag Error	
70	Main Relay Sensor 3: Lag Error	
71	3rd Vertical Trans Sn (Upper) : Lag Error	
72	3rd Vertical Trans Sn (Lower) : Lag Error	
73	4th Vertical Trans Sn: Lag Error	
74	5th Vertical Trans Sn: Lag Error	
75	LCT Exit Sensor: Lag Error	
76	LCT Relay Sensor 1: Lag Error	
77	LCT Relay Sensor 2: Lag Error	
78	Registration Sensor: Lag Error	
80	Sub Scan Registration Correction: Lag Error	
81	Transfer Timing Sensor: Lag Error	
82	PTB Jam Sensor: Lag Error	
83	Fusing Exit Sensor: Lag Error	
84	Feed-out Entrance Sensor: Lag Error	
85	Exit Junction Gate Sensor: Lag Error	
86	Exit Sensor: Lag Error	
87	Exit Relay Sensor (1 st Pass) : Lag Error	
89	Exit Relay Sensor (Duplex) : Lag Error	
90	Duplex Invert Sn (1st Pass): Lag Error	
91	Duplex Invert Sn (2nd Pass): Lag Error	
92	Duplex Transport Sensor 1: Lag Error	
93	Duplex Transport Sensor 2: Lag Error	
94	Duplex Transport Sensor 3: Lag Error	

95	Duplex Transport Sensor 6: Lag Error
96	Duplex Transport Sensor 7: Lag Error
97	Over Skew
98	Over Shift
99	Double-Feed
101	Entrance: Late Error (D512/D513)
102	Entrance: Lag Error (D512/D513)
103	Proof Tray Exit: Late Error (D512/D513)
104	Proof Tray Exit: Lag Error (D512/D513)
105	Shift Tray Exit: Late Error (D512/D513)
106	Shift Tray Exit: Lag Error (D512/D513)
107	Staple Tray Exit: Late Error (D512/D513)
108	Staple Tray Exit: Lag Error (D512/D513)
109	Pre-Stack: Tray Late Error (D512/D513)
110	Pre-Stack: Tray Lag Error (D512/D513)
111	Output (D512/D513)
112	Booklet Stapler: Late Error (D512/D513)
113	Booklet Stapler: Lag Error (D512/D513)
114	Booklet Stapler Exit: Late Error (D512/D513)
115	Booklet Stapler Exit: Lag Error (D512/D513)
116	Paper Path (D512/D513)
117	Shift Tray Lift Drive Train (D512/D513)
118	Jogger Fence Drive Train (D512/D513)
119	Shift Drive Train (D512/D513)
120	Stapler Drive Train (D512/D513)
121	Stack Output Drive Train (D512/D513)

122	Punch Drive Train (D512/D513)
123	Jogger System (D512/D513)
124	Pre-Stacker Drive Train (D512/D513)
125	Booklet Path (D512/D513)
126	Booklet Stapling System (D512/D513)
127	Folding System (D512/D513)
128	For Debugging: Cause Unknown) (D512/D513)
129	Main Machine Setting Incorrect (D512/D513)
150	1st Feed Sensor: Late Error (D518)
151	1st Feed Sensor: Lag Error (D518)
152	2nd Feed Sensor: Late Error (D518)
153	2nd Feed Sensor: Lag Error (D518)
154	1st Transport Sensor: Late Error (D518)
155	1st Transport Sensor: Lag Error (D518)
156	2nd Transport Sensor: Late Error (D518)
157	2nd Transport Sensor: Lag Error (D518)
158	1st Ver. Transport Sn: Late Error (D518)
159	1st Ver.Transport Sn: Lag Error (D518)
160	2nd Ver.Transport Sn: Late Error (D518)
161	2nd Ver.Transport Sn: Lag Error (D518)
162	Vertical Exit Sensor: Late Error (D518)
163	Vertical Exit Sensor: Lag Error (D518)
164	Entrance Sensor: Late Error (D518)
165	Entrance Sensor: Lag Error (D518)
166	Interposer Exit Sensor: Late Error (D518)
167	Interposer Exit Sensor: Lag Error (D518)

168	1st Lift Motor Drive Train (D518)	
169	2nd Lift Motor Drive Train (D518)	
170	1st Pick-up Motor Drive Train (D518)	
171	2nd Pick-up Motor Drive Train (D518)	
198	Plockmatic Jam	
199	GBC Punch Unit Jam	
200	Entrance Sensor: Late Error (D520)	
201	Entrance Sensor: Lag Error (D520)	
202	Skew Sensor: Late Error (D520)	
203	03 Skew Sensor: Lag Error (D520)	
204	Exit Sensor: Late Error (D520)	
205	Exit Sensor: Lag Error (D520)	
206	Trimming Blade Motor Lock (D520)	
207	Cut Position Motor (D520)	
208	Press Roller (D520)	
209	Stopper/Press Roller (D520)	
210	Tray Motor (D520)	
250	Entrance: Late Jam (D521)	
251	Entrance: Lag Jam (D521)	
252	Top Tray Exit: Late Jam (D521)	
253	Top Tray Exit: Lag Jam (D521)	
254	Straight-Through Exit: Late Jam (D521)	
255	Straight-Through Exit: Lag Jam (D521)	

7505	Original Jam Total By Location	CTL
1	At Power On	

3	Separation Sn Late	
4	Skew Correction Sn: Late	
5	Interval Sn: Late	
6	Registration Sn: Lag	
7	Exit Sn: Lag	
8	Inverter Switch Sn: Lag	
9	Low Inverter Sn: Lag	
53	Separation Sn: Lag	
54	Skew Correction Sn: Lag	
55	Interval Sn: Lag	
56	Registration Sn: Late	
57	Exit Sn: Late	
58	Inverter Switch Sn: Late	
59	Low Inverter Sn: Late	

7506	Jam Count by Pap	er Size	CTL
	Displays the total	Displays the total number of jams by paper size.	
5	A4 LEF		
6	A5 LEF		
14	B5 LEF		
38	LT LEF		
44	HLT LEF		
132	A3 SEF		
133	A4 SEF		
134	A5 SEF		
141	B4 SEF		

142	B5 SEF	
160	DLT SEF	
164	LG SEF	
166	LT SEF	
172	HLT SEF	
255	Others	

7507	Plotter Jam History	
1	Latest	
2	Latest 1	
3	Latest 2	
4	Latest 3	Displays the following items for the last 10 copy paper jams:  1) Jam code  2) Paper size
5	Latest 4	
6	Latest 5	3) Total count when jam occurred
7	Latest 6	4) Date of jam.  The "jam codes" are listed in the SMC report under SP7504.
8	Latest 7	The Jam couct are used in the office report under 017 304.
9	Latest 8	
10	Latest 9	

7508
------

1	Original Latest	
2	Latest 1	
3	Latest 2	
4	Latest 3	Displays the following items for the Latest 10 original jams:  1) Jam code
5	Latest 4	2) Paper size
6	Latest 5	3) Total count when jam occurred
7	Latest 6	4) Date of jam.  The "jam codes" are listed in the SMC report under SP7504.
8	Latest 7	The Julii codes are listed in the SMC report under SF7 304.
9	Latest 8	
10	Latest 9	

7509	Paper Jam Total By Location
1	1st Stopper: Late Jam (D521)
2	1st Stopper: Lag Jam (D521)
3	2nd Stopper: Late Jam (D521)
4	2nd Stopper: Lag Jam (D521)
5	3rd Stopper: Late Jam (D521)
6	3rd Stopper: Lag Jam (D521)
7	Skew Correction Jam (D521)
8	Top Tray Transport Jam(D521)
9	Entrance/Top Tray JG Motor Error (D521)
10	Entrance/Fold JG Motor Error (D521)
11	1st Stopper Motor Error (D521)
12	2nd Stopper Motor Error (D521)
13	3rd Stopper Motor Error (D521)
14	Dynamic Roller Transport Motor Error (D521)

15	Registration Roller Release Motor Error (D521)
16	Fold Plate Motor Error (D521)
17	Jogger Fence Motor Jam (D521)
18	Positioning Roller Motor Jam (D521)
19	FM2 Direct Send JG Motor Jam (D521)
20	FM6 Pawl Motor (D521)
21	Main Machine Setting Incorrect for D521
45	Entrance Sensor: Late Error (D515)
46	Entrance Sensor: Lag Error (D515)
47	Proof Tray Exit: Late Error (D515)
48	Proof Tray Exit: Lag Error (D515)
49	Stack Tray Exit: Late Error (D515)
50	Stack Tray Exit Sensor: Lag Error (D515)
51	Transport Sensor: Lag Error (D515)
52	Transport Sensor: Late Error (D515)
53	Exit Sensor: Late Error (D515)
54	Exit Sensor: Lag Error (D515)
55	Shift JG Motor (D515)
56	Proof Tray JG Motor (D515)
57	Shift Roller Motor (D515)
58	Main Jogger Front Motor (D515)
59	Main Jogger Rear Motor (D515)
60	Main Jogger Fence Retraction (D515)
61	Main Jogger Fence Retraction (D515)
62	Sub Jogger Motor (D515)
63	LE Stopper Motor (D515)

64	Tray Lift Motor (D515)
65	Main Machine Setting Incorrect for D515
95	Entrance: Late Jam (D519)
96	Entrance: Lag Jam (D519)
97	Relay: Late Jam (D519)
98	Relay: Lag Jam (D519)
99	Exit: Late Error (D519)
100	Exit: Lag Error (D519)
101	Pre-punch Unit Jam (D519)
102	After Punch Unit Jam (D519)
103	Binder Unit TE Jam (D519)
104	Binder Unit LE Jam (D519)
105	Ring Jam: Wrong Ring Type (D519)
106	Binder Unit Jam (D519)
107	Output Belt 1 HP Jam (D519)
108	Output Belt 2 HP Jam (D519)
109	Stacker Jam (D519)
110	Punch Motor Jam (D519)
111	Shutter Motor Jam (D519)
112	Alignment Pin Motor Jam (D519)
113	Pre-Punch Jogger Jam (D519)
114	Alignment Pin Jam (D519)
115	Clamp Motor Jam (D519)
116	50/100 Clamp Adjust Motor Jam (D519)
117	Output Belt Rotation Motor Jam (D519)
118	Main Machine Setting Incorrect for D519

145	Relay Sensor 1: Late Error (D548)
146	Relay Sensor 1: Lag Error (D548)
147	Relay Sensor 2: Late Error (D548)
148	Relay Sensor 2: Lag Error (D548)
149	Relay Sensor 3: Late Error (D548)
150	Relay Sensor 3: Lag Error (D548)
151	Relay Sensor 4: Late Error (D548)
152	Relay Sensor 4: Lag Error (D548)
153	Relay Sensor 5: Late Error (D548)
154	Relay Sensor 5: Lag Error (D548)
155	Relay Sensor 6: Late Error (D548)
156	Relay Sensor 6: Lag Error (D548)
157	Relay Sensor 7: Late Error (D548)
158	Relay Sensor 7: Lag Error (D548)
159	Relay Sensor 8: Late Error (D548)
160	Relay Sensor 8: Lag Error (D548)
161	Main Machine Setting Incorrect for Fan Option
245	Finisher No Exiting Response

7617	Parts PM Counter Display	СТІ
1	Normal	Japan Only
2	DF	Japan Only

7618	PM Parts Counter Reset (Japan Only)	CTL
1	Normal	
	Push [Execute] to clear the parts replacement alarm counter for the main machine.	
2	DF	

Z

Push [Execute] to clear the parts replacement alarm counter for the ADF.

7621	PM Counter
7622	Reset
7623	Standard Value
7624	Part Replacement Operation ON/OFF
1	#K_Development Unit
2	K_Developer
3	K_Dev Filter
4	#C_Development Unit
5	C_Developer
6	C_Dev Filter
7	#M_Development Unit
8	M_Developer
9	M_Dev Filter
10	#Y_Development Unit
11	Y_Developer
12	Y_Dev Filter
13	#K_Drum Cleaning Unit
14	K_Cleaning Blade
15	K_Lubricant Brush
16	K_Lubricant Bar
17	K_Lubricant Blade
18	K_Joint
19	K_Gears
20	#C_Drum Cleaning Unit

21	C_Cleaning Blade	
22	C_Lubricant Brush	
23	C_Lubricant Bar	
24	C_Lubricant Blade	
25	C_Joint	
26	C_Gears	
27	#M_Drum Cleaning Unit	
28	M_Cleaning Blade	
29	M_Lubricant Brush	
30	M_Lubricant Bar	
31	M_Lubricant Blade	
32	M_Joint	
33	M_Gears	
34	#Y_Drum Cleaning Unit	
35	Y_Cleaning Blade	
36	Y_Lubricant Brush	
37	Y_Lubricant Bar	
38	Y_Lubricant Blade	
39	Y_Joint	
40	Y_Gears	
41	#K_Charge Unit	
42	#C_Charge Unit	
43	#M_Charge Unit	
44	#Y_Charge Unit	
45	#K_Drum Unit	
46	K_Drum	

47	#C_Drum Unit
48	C_Drum
49	#M_Drum Unit
50	M_Drum
51	#Y_Drum Unit
52	Y_Drum
53	#Image Transfer Unit
54	ITB
55	#ITB Cleaning Unit
56	ITB Cleaning Blade
57	ITB Brush Roller
58	ITB Lubricant Bar
59	ITB Lubricant Blade
60	#Paper Transfer Unit
61	PTU Cleaning Blade
62	PTU Lubricant Bar
63	Separation PP
64	PTR
65	#Fusing Unit
66	Fusing Belt
67	Hot Roller
68	Pressure Roller
69	Pressure Roller Bearings
70	#Fusing Cleaning Unit
71	Cleaning Web
72	Web Pressure Roller

73	Web Roller Stopper	
74	#Main Unit Filters	
75	Dust Filter: Rear Upper Right	
76	Dust Filter: Rear Upper Left	
77	Dust Filter: Rear Lower Right	
78	Dust Filter: Rear Lower Left	
79	Dust Filter: Controller Box	
80	Ozone Filter 1	
81	Ozone Filter 2	
82	#ADF	
83	ADF Transport Belt	
84	ADF Feed Belt	
85	ADF Separation Roller	
86	ADF Pick-up Roller	
87	#1st Feed Rollers	
88	1 st Pick-up Roller	
89	1st Feed Roller	
90	1st Separation Roller	
91	#2nd Feed Rollers	
92	2nd Pick-up Roller	
93	2nd Feed Roller	
94	2nd Separation Roller	
95	#3rd Feed Rollers	
96	3rd Pick-up Roller (D516)	
97	3rd Feed Roller (D516)	
98	3rd Separation Roller (D516)	

99	#4th Feed Rollers	
100	4th Pick-up Roller (D516)	
101	4th Feed Roller (D516)	
102	4th Separation Roller (D516)	
103	#5th Feed Rollers	
104	5th Pick-up Roller (D516)	
105	5th Feed Roller (D516)	
106	5th Separation Roller (D516)	
107	#6th Feed Rollers	
108	Bypass Pick-up Roller	
109	Bypass Feed Roller	
110	Bypass Reverse Roller	
111	#(D518) 1st Feed Rollers	
112	1st Pick-up Roller (D518)	
113	1st Feed Belt (D518)	
114	1st Reverse Roller (D518)	
115	#(D518) 2nd Feed Rollers	
116	2nd Pick-up Roller (D518)	
117	2nd Feed Belt (D518)	
118	2nd Reverse Roller (D518)	

7625	Pg Count History:Latest 1	
7626	Pg Count History: Latest 2	
1	#K_Development Unit	[0 to 99 999 999/0/1]
2	K_Developer	
3	K_Dev Filter	

4	#C_Development Unit	
5	C_Developer	
6	C_Dev Filter	
7	#M_Development Unit	
8	M_Developer	
9	M_Dev Filter	
10	#Y_Development Unit	
11	Y_Developer	
12	Y_Dev Filter	
13	#K_Drum Cleaning Unit	
14	K_Cleaning Blade	
15	K_Lubricant Brush	
16	K_Lubricant Bar	
17	K_Lubricant Blade	
18	K_Joint	
19	K_Gears	
20	#C_Drum Cleaning Unit	
21	C_Cleaning Blade	
22	C_Lubricant Brush	
23	C_Lubricant Bar	
24	C_Lubricant Blade	
25	C_Joint	
26	C_Gears	
27	#M_Drum Cleaning Unit	
28	M_Cleaning Blade	
29	M_Lubricant Brush	

30	M_Lubricant Bar	
31	M_Lubricant Blade	
32	M_Joint	
33	M_Gears	
34	#Y_Drum Cleaning Unit	
35	Y_Cleaning Blade	
36	Y_Lubricant Brush	
37	Y_Lubricant Bar	
38	Y_Lubricant Blade	
39	Y_Joint	
40	Y_Gears	
41	#K_Charge Unit	
42	#C_Charge Unit	
43	#M_Charge Unit	
44	#Y_Charge Unit	
45	#K_Drum Unit	
46	K_Drum	
47	#C_Drum Unit	
48	C_Drum	
49	#M_Drum Unit	
50	M_Drum	
51	#Y_Drum Unit	
52	Y_Drum	
53	#Image Transfer Unit	
54	ITB	
55	#ITB Cleaning Unit	

56	ITB Cleaning Blade	
57	ITB Brush Roller	
58	ITB Lubricant Bar	
59	ITB Lubricant Blade	
60	#Paper Transfer Unit	
61	PTU Cleaning Blade	
62	PTU Lubricant Bar	
63	Separation PP	
64	PTR	
65	#Fusing Unit	
66	Fusing Belt	
67	Hot Roller	
68	Pressure Roller	
69	Pressure Roller Bearings	
70	#Fusing Cleaning Unit	
71	Cleaning Web	
72	Web Pressure Roller	
73	Web Roller Stopper	
74	#Main Unit Filters	
75	Dust Filter: Rear Upper Right	
76	Dust Filter: Rear Upper Left	
77	Dust Filter: Rear Lower Right	
78	Dust Filter: Rear Lower Left	
79	Dust Filter: Controller Box	
80	Ozone Filter 1	
81	Ozone Filter 2	

82	#ADF	
83	ADF Transport Belt	
84	ADF Feed Belt	
85	ADF Separation Roller	
86	ADF Pick-up Roller	
87	#1st Feed Rollers	
88	1 st Pick-up Roller	
89	1 st Feed Roller	
90	1st Separation Roller	
91	#2nd Feed Rollers	
92	2nd Pick-up Roller	
93	2nd Feed Roller	
94	2nd Separation Roller	
95	#3rd Feed Rollers	
96	3rd Pick-up Roller (D516)	
97	3rd Feed Roller (D516)	
98	3rd Separation Roller (D516)	
99	#4th Feed Rollers	
100	4th Pick-up Roller (D516)	
101	4th Feed Roller (D516)	
102	4th Separation Roller (D516)	
103	#5th Feed Rollers	
104	5th Pick-up Roller (D516)	
105	5th Feed Roller (D516)	
106	5th Separation Roller (D516)	
107	#6th Feed Rollers	

108	Bypass Pick-up Roller	
109	Bypass Feed Roller	
110	Bypass Reverse Roller	
111	#(D518) 1st Feed Rollers	
112	1st Pick-up Roller (D518)	
113	1st Feed Belt (D518)	
114	1st Reverse Roller (D518)	
115	#(D518) 2nd Feed Rollers	
116	2nd Pick-up Roller (D518)	
117	2nd Feed Belt (D518)	
118	2nd Reverse Roller (D518)	

7628	Clear PM Counter	
	Clears PM Counters.	
1	Clear Exceeded Counts	
	Do this SP to clear all PM counts that have exceeded their limits.	
2	Reset All Counts	
	Do this SP to clear all PM counts, including those that have not exceeded their limits.	

7801	ROM No./Firmware Version	
	Displays the serial number and the ROM version for each unit or peripheral.	

7803	PM Counter Display	CTL	
	Displays the PM count since the last PM.		

7804	PM Counter Reset	CTL
	Touch [EXECUTE] to reset the PM count.	

7807	SC/Jam Counter Reset	CTL
	Touch [EXECUTE\ to reset the SC and jam counters.	
7826	MF Error Counter (Japan Only)	CTL
	Displays the number of counts requested of the card/key counter.	
1	Error Total	
	A request for the count total failed at power on. This error will occur installed but disconnected.	if the device is
2	Error Staple	
	The request for a staple count failed at power on. This error will occur if the device is installed but disconnected.	
7827	MF Error Counter Clear (Japan Only)	CTL
	Press Execute to reset to 0 the values of SP7826.	
7832	Self-Diagnostic Result Display	CTL
	Push [#] to display a list of error codes. Nothing is displayed if no errors have occurred.	
7835	ACC Counter	CTL
	No information is available at this time.	
1	Copy ACC	
2	Printer ACC	
7836	Total Memory Size	CTL
	Displays the contents of the memory on the controller board.	
7852	ADF Exposure Glass	

	Displays the count for the number of times the machine has detected dust on the ARDF scanning glass at the beginning of copy jobs. This SP operates only after SP4020 1 has been turned on	
1	Dust Counter	[0 to 65 535/0/1]
2	Clear Counter	

7855	Coverage Range <b>DFU</b>	
1	Coverage Range 1	[1 to 200/5/1%]
2	Coverage Range 2	[1 to 200/20/1%]
	<ul> <li>Note:</li> <li>If Coverage Range 1 is less than Coverage Range 2, coverage is controlled by the firmware.</li> <li>If Coverage Range 1 is greater than or equal to Range 2, the value cannot be entered.</li> </ul>	

7901	Assert Info. <b>DFU</b>	CTL
1	File Name	
002	Number of Lines	Used for debugging.
003	Locations	

7931	Toner Bottle Bk	
7932	Toner Bottle M	
7933	Toner Bottle C	
7934	Toner Bottle Y	
1	Machine Serial ID	[0 to 255/0/1]
2	Cartridge Ver	[0 to 255/0/1]
3	Brand ID	[0 to 255/0/1]
4	Area ID	[0 to 255/0/1]
5	Product ID	[0 to 255/0/1]

6	Color ID	[0 to 255/0/1]
7	Maintenance ID	[0 to 255/0/1]
8	New Product Information	[0 to 255/0/1]
9	Recycle Counter	[0 to 255/0/1]
10	Date	[0 to 1/100/1]
11	SerialNo.	[0 to 1/0/1]
12	Toner Remaining	[0 to 100/0/1]
13	EDP Code	[0 to 1/0/1]
14	End History	[0 to 1/0/1]
15	Refill Information	[0 to 1/0/1]
16	Attachment: Total Counter	[0 to 99999999/0/1]
17	Attachment: Color Counter	[0 to 99999999/0/1]
18	End: Total Counter	[0 to 99999999/0/1]
19	End: Color Counter	[0 to 99999999/0/1]
20	Attachment Date	[0 to 1/0/1]
21	End Date	[0 to 1/0/1]

7935	Toner Bottle Log 1: Bk	
7936	Toner Bottle Log 1: M	
7937	Toner Bottle Log 1: C	
7938	Toner Bottle Log 1: Y	
1	SerialNo.	[0 to 1/0/1]
2	Attachment Date	[0 to 1/0/1]
3	Attachment: Total Counter	[0 to 99999999/0/1]
4	Refill Information	[0 to 1/0/1]
11	SerialNo.	[0 to 1/0/1]

12	Attachment Date	[0 to 1/0/1]
13	Attachment: Total Counter	[0 to 99999999/0/1]
14	Refill Information	[0 to 1/0/1]
21	SerialNo.	[0 to 1/0/1]
22	Attachment Date	[0 to 1/0/1]
23	Attachment: Total Counter	[0 to 99999999/0/1]
24	Refill Information	[0 to 1/0/1]
31	SerialNo.	[0 to 1/0/1]
32	Attachment Date	[0 to 1/0/1]
33	Attachment: Total Counter	[0 to 99999999/0/1]
34	Refill Information	[0 to 1/0/1]
41	SerialNo.	[0 to 1/0/1]
42	Attachment Date	[0 to 1/0/1]
43	Attachment: Total Counter	[0 to 99999999/0/1]
44	Refill Information	[0 to 1/0/1]

7940	Drive Distance: End Std Value	
7942	Drive Distance % Counter	
7944	Drive Distance Counter	
1	#K_Development Unit	[0 to 99 999 999/99 999 999/1 m]
2	K_Developer	
3	K_Dev Filter	
4	#C_Development Unit	
5	C_Developer	
6	C_Dev Filter	
7	#M_Development Unit	

8	M_Developer	
9	M_Dev Filter	
10	#Y_Development Unit	
11	Y_Developer	
12	Y_Dev Filter	
13	#K_Drum Cleaning Unit	
14	K_Cleaning Blade	
15	K_Lubricant Brush	
16	K_Lubricant Bar	
17	K_Lubricant Blade	
18	K_Joint	
19	K_Gears	
20	#C_Drum Cleaning Unit	
21	C_Cleaning Blade	
22	C_Lubricant Brush	
23	C_Lubricant Bar	
24	C_Lubricant Blade	
25	C_Joint	
26	C_Gears	
27	#M_Drum Cleaning Unit	
28	M_Cleaning Blade	
29	M_Lubricant Brush	
30	M_Lubricant Bar	
31	M_Lubricant Blade	
32	M_Joint	
33	M_Gears	

34	#Y_Drum Cleaning Unit
35	Y_Cleaning Blade
36	Y_Lubricant Brush
37	Y_Lubricant Bar
38	Y_Lubricant Blade
39	Y_Joint
40	Y_Gears
41	#K_Charge Unit
42	#C_Charge Unit
43	#M_Charge Unit
44	#Y_Charge Unit
45	#K_Drum Unit
46	K_Drum
47	#C_Drum Unit
48	C_Drum
49	#M_Drum Unit
50	M_Drum
51	#Y_Drum Unit
52	Y_Drum
53	#Image Transfer Unit
54	ITB
55	#ITB Cleaning Unit
56	ITB Cleaning Blade
57	ITB Brush Roller
58	ITB Lubricant Bar
59	ITB Lubricant Blade

60	#Paper Transfer Unit	
61	PTU Cleaning Blade	
62	PTU Lubricant Bar	
63	Separation PP	
64	PTR	
65	#Fusing Unit	
66	Fusing Belt	
67	Hot Roller	
68	Pressure Roller	
69	Pressure Roller Bearings	
70	#Fusing Cleaning Unit	
71	Cleaning Web	
72	Web Pressure Roller	
73	Web Roller Stopper	

7954	Pg Counter(%)	
	This SP displays the current usage (listed as percent of usage) of the components listed below: Current Usage/Standard Usage Service Life x 100	
1	#K_Development Unit	[0 to 255/0/1]
2	K_Developer	
3	K_Dev Filter	
4	#C_Development Unit	
5	C_Developer	
6	C_Dev Filter	
7	#M_Development Unit	
8	M_Developer	

9	M_Dev Filter	
10	#Y_Development Unit	
11	Y_Developer	
12	Y_Dev Filter	
13	#K_Drum Cleaning Unit	
14	K_Cleaning Blade	
15	K_Lubricant Brush	
16	K_Lubricant Bar	
17	K_Lubricant Blade	
18	K_Joint	
19	K_Gears	
20	#C_Drum Cleaning Unit	
21	C_Cleaning Blade	
22	C_Lubricant Brush	
23	C_Lubricant Bar	
24	C_Lubricant Blade	
25	C_Joint	
26	C_Gears	
27	#M_Drum Cleaning Unit	
28	M_Cleaning Blade	
29	M_Lubricant Brush	
30	M_Lubricant Bar	
31	M_Lubricant Blade	
32	M_Joint	
33	M_Gears	
34	#Y_Drum Cleaning Unit	

35	Y_Cleaning Blade	
36	Y_Lubricant Brush	
37	Y_Lubricant Bar	
38	Y_Lubricant Blade	
39	Y_Joint	
40	Y_Gears	
41	#K_Charge Unit	
42	#C_Charge Unit	
43	#M_Charge Unit	
44	#Y_Charge Unit	
45	#K_Drum Unit	
46	K_Drum	
47	#C_Drum Unit	
48	C_Drum	
49	#M_Drum Unit	
50	M_Drum	
51	#Y_Drum Unit	
52	Y_Drum	
53	#Image Transfer Unit	
54	ITB	
55	#ITB Cleaning Unit	
56	ITB Cleaning Blade	
57	ITB Brush Roller	
58	ITB Lubricant Bar	
59	ITB Lubricant Blade	
60	#Paper Transfer Unit	

61	PTU Cleaning Blade	
62	PTU Lubricant Bar	
63	Separation PP	1
64	PTR	
65	#Fusing Unit	
66	Fusing Belt	
67	Hot Roller	
68	Pressure Roller	
69	Pressure Roller Bearings	
70	#Fusing Cleaning Unit	
71	Cleaning Web	
72	Web Pressure Roller	
73	Web Roller Stopper	
74	#Main Unit Filters	
75	Dust Filter: Rear Upper Right	
76	Dust Filter: Rear Upper Left	
77	Dust Filter: Rear Lower Right	
78	Dust Filter: Rear Lower Left	
79	Dust Filter: Controller Box	
80	Ozone Filter 1	
81	Ozone Filter 2	
82	#ADF	
83	ADF Transport Belt	
84	ADF Feed Belt	
85	ADF Separation Roller	
86	ADF Pick-up Roller	

87	#1st Feed Rollers	
88	1st Pick-up Roller	
89	1st Feed Roller	
90	1st Separation Roller	
91	#2nd Feed Rollers	
92	2nd Pick-up Roller	
93	2nd Feed Roller	
94	2nd Separation Roller	
95	#3rd Feed Rollers	
96	3rd Pick-up Roller (D516)	
97	3rd Feed Roller (D516)	
98	3rd Separation Roller (D516)	
99	#4th Feed Rollers	
100	4th Pick-up Roller (D516)	
101	4th Feed Roller (D516)	
102	4th Separation Roller (D516)	
103	#5th Feed Rollers	
104	5th Pick-up Roller (D516)	
105	5th Feed Roller (D516)	
106	5th Separation Roller (D516)	
107	#6th Feed Rollers	
108	Bypass Pick-up Roller	
109	Bypass Feed Roller	
110	Bypass Reverse Roller	
111	#(D518) 1st Feed Rollers	
112	1st Pick-up Roller (D518)	

113	1st Feed Belt (D518)
114	1st Reverse Roller (D518)
115	#(D518) 2nd Feed Rollers
116	2nd Pick-up Roller (D518)
117	2nd Feed Belt (D518)
118	2nd Reverse Roller (D518)

7960	Motor Drive Information	
1	K_Drum Ave. Torque	[0 to 65 535/0/1]
2	K_Drum Max. Torque	
3	K_Drum Min. Torque	
4	C_Drum Ave. Torque	
5	C_Drum Max. Torque	
6	C_Drum Min. Torque	
7	M_Drum Ave. Torque	
8	M_Drum Max. Torque	
9	M_Drum Min. Torque	
10	Y_Drum Ave. Torque	
11	Y_Drum Max. Torque	
12	Y_Drum Min. Torque	
13	ITB Drive Ave. Torque	
14	ITB Drive Max. Torque	
15	ITB Drive Min. Torque	
16	PTR Drive Ave. Torque	
17	PTR Drive Max. Torque	
18	PTR Drive Min. Torque	

19	Transfer Timing Ave. Torque	
20	Transfer Timing Max. Torque	
21	Transfer Timing Min. Torque	
22	Fusing Drive Ave. Torque	
23	Fusing Drive Max. Torque	
24	Fusing Drive Min. Torque	
25	K_Drum Ave. Revolutions	
26	C_Drum Ave. Revolutions	
27	M_Drum Ave. Revolutions	
28	Y_Drum Ave. Revolutions	
29	ITB Mtr Ave. Revolutions	
30	PTR Mtr Ave. Revolutions	
31	ITB Timing Mtr Ave. Revolutions	
32	ITU FB Sensor: Main Ave.	
33	ITU FB Sensor: Sub Ave.	

7963	Operation Env. Log: PCU: Bk	
	This SP displays the distance traveled by the K PCDU drum so the engine can acclimate operation for the ambient temperature and humidity.	
1	Temp<=5: 0<=Hum<30	[0 to 99 999 999/0/1 m]
2	Temp<=5: 30<=Hum<55	
3	Temp<=5: 55<=Hum<80	
4	Temp<=5: 80<=Hum<100	
5	5 <temp<=15: 0<="Hum&lt;30&lt;/td"><td></td></temp<=15:>	
6	5 <temp<=15: 30<="Hum&lt;55&lt;/td"><td></td></temp<=15:>	
7	5 <temp<=15: 55<="Hum&lt;80&lt;/td"><td></td></temp<=15:>	

8	5 <temp<=15: 80<="Hum&lt;100&lt;/th"></temp<=15:>
9	15<=Temp<25: 0<=Hum<30
10	15<=Temp<25: 30<=Hum<55
11	15<=Temp<25: 55<=Hum<80
12	15<=Temp<25: 80<=Hum<100
13	25<=Temp<30: 0<=Hum<30
14	25<=Temp<30: 30<=Hum<55
15	25<=Temp<30: 55<=Hum<80
16	25<=Temp<30: 80<=Hum<100
17	30<=Temp: 0<=Hum<30
18	30<=Temp: 30<=Hum<55
19	30<=Temp: 55<=Hum<80
20	30<=Temp: 80<=Hum<100

7	7964	Operation Env. Log Clear
		Touch [EXECUTE\ to clear the ambient temperature log.

7987	Drum Motor Error Counter	
	Drum motor lock condition counts for the four drum motors.	
1	Drum Motor K	[0 to 3/0/1]
2	Drum Motor C	
3	Drum Motor M	
4	Drum Motor Y	

7988	Drum Motor Error Counter Clear	
	Clears the motor lock condition counts for the four drum motors.	
1	Drum Motor K	

2	Drum Motor C
3	Drum Motor M
4	Drum Motor Y

7989	Trimmer Unit Counter	
	Displays the count for the number of cuts performed by the trimmer unit cutting blade.	
	[0 to 99 999 999/100/1	

# **Group 8000**

These new SP counters are provided for MFP, LP, and Wide Format machines that employ GW Architecture. These SP codes have been created in response to requests by customers, sales personnel and customer engineers, and R&D staff for a standardized set of counters that can be used to log more detailed information about machine operation.

These SP codes are absolutely essential to provide more detailed counters and job logs to match similar features that are being developed by competitors.

### Current Status of the SP8xxx Counters

Many of these counters are provided for features that are currently not available, such as sending color faxes, and so on. However, here are some Group 8 codes that when used in combination with others, can provide useful information.

SP Numbers	What They Do
SP8211 to SP8216	The number of pages scanned to the document server.
SP8401 to SP8406	The number of pages printed from the document server
SP8691 to SP8696	The number of pages sent from the document server

Specifically, the following questions can be answered:

- How is the document server actually being used?
- What application is using the document server most frequently?
- What data in the document server is being reused?

#### **Group 8 Service Table Keys**

Many of the SPs in this group are prefixed with a letter that indicates the mode of operation (the mode of operation is referred to as an 'application'). Before reading the Group 8 Service Table, make sure that you understand what these prefixes mean.

Prefixes	Meaning	
T:	Total: (Grand Total).	Grand total of items counted for all applications (C, F, P, etc.).
C:	Copy application.	
P:	Print application.	Totals (pages, jobs, etc.) executed for each application when the job was not stored on the document server
S:	Scan application.	

Prefixes	Meaning	
L:	Local storage (document server)	Totals (jobs, pages, etc.) for the document server. The L: counters work differently case by case. Sometimes, they count jobs/pages stored on the document server; this can be in document server mode (from the document server window), or from another mode, such as from a printer driver or by pressing the Store File button in the Copy mode window. Sometimes, they include occasions when the user uses a file that is already on the document server. Each counter will be discussed case by case.
O:	Other applications (external network applications, for example)	Refers to network applications such as Web Image Monitor. Utilities developed with the SDK (Software Development Kit) will also be counted with this group in the future.

The Group 8 SP codes are limited to 17 characters, forced by the necessity of displaying them on the small LCDs of printers and faxes that also use these SPs.

# 

• The C (Copy application) and S (Scan application) functions appear in the SP code displays for the D074/D075 only. They do not appear in the M044 SP code displays.

Read over the list of abbreviations below and refer to it again if you see the name of an SP that you do not understand.

Abbreviation	What It Means	
/	"By", e.g. "T:Jobs/Apl" = Total Jobs "by" Application	
>	More (2> "2 or more", 4> "4 or more"	
AddBook	Address Book	
Apl	Application	
B/W	Black & White	
Bk	Black	
С	Cyan	
ColCr	Color Create	
ColMode	Color Mode	

Abbreviation	What It Means	
Comb	Combine	
Comp	Compression	
Deliv	Delivery	
DesApl	Designated Application. The application (Copy, Fax, Scan, Print) used to store the job on the document server, for example.	
Dev Counter	Development Count, no. of pages developed.	
Dup, Duplex	Duplex, printing on both sides	
Emul	Emulation	
FC	Full Color	
FIN	Post-print processing, i.e. finishing (punching, stapling, etc.)	
Full Bleed	No Margins	
GenCopy	Generation Copy Mode	
GPC	Get Print Counter. For jobs 10 pages or less, this counter does not count up. For jobs larger than 10 pages, this counter counts up by the number that is in excess of 10 (e.g., for an 11-page job, the counter counts up 11-10=1)	
IFax	Internet Fax	
ImgEdt	Image Edit performed on the original with the copier GUI, e.g. border removal, adding stamps, page numbers, etc.	
K	Black (YMCK)	
LS	Local Storage. Refers to the document server.	
LSize	Large (paper) Size	
Mag	Magnification	
МС	One color (monochrome)	
NRS	New Remote Service, which allows a service center to monitor machines remotely. "NRS" is used overseas, "CSS" is used in Japan.	
Org	Original for scanning	
OrgJam	Original Jam	

Abbreviation	What It Means	
Palm 2	Print Job Manager/Desk Top Editor: A pair of utilities that allows print jobs to be distributed evenly among the printers on the network, and allows files to moved around, combined, and converted to different formats.	
PC	Personal Computer	
PGS	Pages. A page is the total scanned surface of the original. Duplex pages count as two pages, and A3 simplex count as two pages if the A3/DLT counter SP is switched ON.	
PJob	Print Jobs	
Ppr	Paper	
PrtJam	Printer (plotter) Jam	
PrtPGS	Print Pages	
R	Red (Toner Remaining). Applies to the wide format model A2 only. This machine is under development and currently not available.	
Rez	Resolution	
SC	Service Code (Error SC code displayed)	
Scn	Scan	
Sim, Simplex	Simplex, printing on 1 side.	
S-to-Email	Scan-to-E-mail	
SMC	SMC report printed with SP5990. All of the Group 8 counters are recorded in the SMC report.	
Svr	Server	
TonEnd	Toner End	
TonSave	Toner Save	
TXJob	Send, Transmission	
YMC	Yellow, Magenta, Cyan	
YMCK	Yellow, Magenta, Cyan, BlacK	

Note: All of the Group 8 SPs are reset with SP5801 1 Memory All Clear, or the Counter Reset SP7808.

8001	T:Total Jobs	These SPs count the number of times each application is used to do
8002	C:Total Jobs	a job.
8004	P:Total Jobs	[0 to 9999999/ 1]  Note: The L: counter is the total number of times the other
8005	S:Total Jobs	applications are used to send a job to the document server, plus the number of times a file already on the document server is used.
8006	L:Total Jobs	

These SPs reveal the number of times an application is used, not the number of pages processed.

- When an application is opened for image input or output, this counts as one job.
- Interrupted jobs (paper jams, etc.) are counted, even though they do not finish.
- Only jobs executed by the customer are counted. Jobs executed by the customer engineer using the SP modes are not counted.
- When using secure printing (when a password is required to start the print job), the job is counted
  at the time when either "Delete Data" or "Specify Output" is specified.
- When a copy job on the document server is printed, SP8022 also increments, and when a print job stored on the document server is printed, SP8024 also increments.
- When an original is both copied and stored on the document server, the C: and L: counters both increment.
- When a print job is stored on the document server, only the L: counter increments.
- When the user presses the Document Server button to store the job on the document server, only
  the L: counter increments.
- When the user enters document server mode and prints data stored on the document server, only
  the L: counter increments.
- When an image received from Palm 2 is received and stored, the L: counter increments.

8011	T:Jobs/LS	
8012	C:Jobs/LS	These SPs count the number of jobs stored to the document server by
8014	P:Jobs/LS	each application, to reveal how local storage is being used for input.
8015	S:Jobs/LS	[Oto9999999/ 1] The L: counter counts the number of jobs stored from within the documen server mode screen at the operation panel.
8016	L:Jobs/LS	
8017	O:Jobs/LS	

• When a scan job is sent to the document server, the S: counter increments. When you enter document server mode and then scan an original, the L: counter increments.

- When a print job is sent to the document server, the P: counter increments.
- When a network application sends data to the document server, the O: counter increments.
- When an image from Palm 2 is stored on the document server, the O: counter increments.

8021	T:Pjob/LS	
8022	C:Pjob/LS	These SPs reveal how files printed from the document server were stored
8024	P:Pjob/LS	on the document server originally. [0 to 9999999/1]
8025	S:Pjob/LS	The L: counter counts the number of jobs stored from within the document server mode screen at the operation panel.
8026	L:Pjob/LS	
8027	O:Pjob/LS	

- When a copy job stored on the document server is printed with another application, the C: counter increments.
- When an application like DeskTopBinder merges a copy job that was stored on the document server with a print job that was stored on the document server, the C: and P: counters both increment.
- When a job already on the document server is printed with another application, the L: counter increments.
- When a scanner job stored on the document server is printed with another application, the S: counter increments. If the original was scanned from within document server mode, then the L: counter increments.
- When images stored on the document server by a network application (including Palm 2), are printed with another application, the O: counter increments.
- When a copy job stored on the document server is printed with a network application (Web Image Monitor, for example), the C: counter increments.

8031	T:Pjob/DesApl	
8032	C:Pjob/DesApl	These SPs reveal what applications were used to output documents
8034	P:Pjob/DesApl	from the document server.
8035	S:Pjob/DesApl	[0 to 9999999/ 1] The L: counter counts the number of jobs printed from within the document server mode screen at the operation panel.
8036	L:Pjob/DesApl	
8037	O:Pjob/DesApl	

- When documents already stored on the document server are printed, the count for the application that started the print job is incremented.
- When the print job is started from a network application (Desk Top Binder, Web Image Monitor, etc.) the L: counter increments.

8041	T:TX Jobs/LS	These SPs count the applications that stored files on the document	
8042	C:TX Jobs/LS	server that were later accessed for transmission over the telephone line or over a network (attached to an e-mail, or as a fax image by	
8044	P:TX Jobs/LS	I-Fax).	
8045	S:TX Jobs/LS	[0 to 9999999/1]	
8046	L:TX Jobs/LS	Note: Jobs merged for sending are counted separately.  The L: counter counts the number of jobs scanned from within the	
8047	O:TX Jobs/LS	document server mode screen at the operation panel.	

- When a stored copy job is sent from the document server, the C: counter increments.
- When images stored on the document server by a network application or Palm2 are sent as an email, the O: counter increments.

8051	T:TX Jobs/DesApl	
8052	C:TX Jobs/DesApl	These SPs count the applications used to send files from the document server over the telephone line or over a
8054	P:TX Jobs/DesApl	network (attached to an e-mail, or as a fax image by I-Fax). Jobs merged for sending are counted separately.
8055	S:TX Jobs/DesApl	[0 to 9999999/1]  The L: counter counts the number of jobs sent from within the document server mode screen at the operation panel.
8056	L:TX Jobs/DesApl	
8057	O:TX Jobs/DesApl	

• If the send is started from Desk Top Binder or Web Image Monitor, for example, then the O: counter increments.

8061	T:FIN Jobs	[0 to 9999999/ 1]
	These SPs total the finishing methods. The finishing method is specified by the application.	
	C:FIN Jobs	[0 to 9999999/ 1]
8062	These SPs total finishing methods for copy jobs only. The finishing method is spe by the application.	

	P:FIN Jobs	[0 to 9999999/1]	
8064	These SPs total finishing methods for print jobs only. The finishing method is specified by the application.		
	S:FIN Jobs	[0 to 9999999/ 1]	
8065	These SPs total finishing methods for scan jobs only. The finishing method is specified by the application.		
		res for scan jobs are not available at this time.  [0 to 9999999/1]	
8066	These SPs total finish	ing methods for jobs output from within the document server mode on panel. The finishing method is specified from the print window	
	O:FIN Jobs	[0 to 9999999/ 1]	
8067	These SPs total finishing methods for jobs executed by an external application, over network. The finishing method is specified by the application.		
806x 1	Sort	Number of jobs started in Sort mode. When a stored copy job is set for Sort and then stored on the document server, the L: counter increments. (See SP8066 1)	
806x 2	Stack	Number of jobs started out of Sort mode.	
806x 3	Staple	Number of jobs started in Staple mode.	
806x 4	Booklet	Number of jobs started in Booklet mode. If the machine is in staple mode, the Staple counter also increments.	
806x 5	Z-Fold	Number of jobs started in any mode other than the Booklet mode and set for Z-folding. (Multi Fold Unit)	
806x 6	Punch	Number of jobs started in Punch mode. When Punch is set for a print job, the P: counter increments. (See SP8064 6.)	
806x 7	Other	Reserved. Not used.	
806x 8	Inside Fold	Half-Fold (FM2) (Multi Fold Unit)	
806x 9	Three-IN-Fold	Letter Fold-in (FM4) (Multi Fold Unit)	
806x 10	Three-OUT-Fold	Letter Fold-out (FM3) (Multi Fold Unit)	
806x 11	Four Fold	Double Parallel Fold (FM5) (Multi Fold Unit)	

806x 12	KANNON-Fold	Gate Fold (FM6) (Multi Fold Unit D394)
806x 13	Perfect-Bind	Perfect Binder <b>Not Used</b>
806x 14	Ring-Bind	Ring Binder

	T:Jobs/PGS [0 to 9999999/ 1]					
8071	These SPs count the number of jobs broken down by the number of pages in the job, regardless of which application was used.					
	C:Jobs/PGS	[0 to 9999999/1]				
8072	These SPs count of pages in the job.	and calcula	te the number of	copy jobs by size based on the number of		
	P:Jobs/PGS	[0 to 999	9999/1]			
8074	These SPs count of pages in the job.	These SPs count and calculate the number of print jobs by size based on the number of pages in the job.				
	S:Jobs/PGS	[0 to 999	9999/1]			
8075	These SPs count of pages in the job.	These SPs count and calculate the number of scan jobs by size based on the number of pages in the job.				
	L:Jobs/PGS	[0 to 9999999/ 1]				
8076	These SPs count and calculate the number of jobs printed from within the document server mode window at the operation panel, by the number of pages in the job.					
	O:Jobs/PGS	[0 to 999	9999/1]			
8077	These SPs count and calculate the number of "Other" application jobs (Web Ima Monitor, Palm 2, etc.) by size based on the number of pages in the job.					
807x 1	1 Page		807x 8	21 to 50 Pages		
807x 2	2 Pages		807x 9	51 to 100 Pages		
807x 3	3 Pages		807x 10	101 to 300 Pages		
807x 4	4 Pages		807x 11	301 to 500 Pages		
807x 5	5 Pages		807x 12	501 to 700 Pages		
807x 6	6 to 10 Pages		807x 13	701 to 1000 Pages		

- For example: When a copy job stored on the document server is printed in document server mode, the appropriate L: counter (SP8076 0xx) increments.
- Interrupted jobs (paper jam, etc.) are counted, even though they do not finish.
- If a job is paused and re-started, it counts as one job.
- If the finisher runs out of staples during a print and staple job, then the job is counted at the time the
  error occurs.
- For copy jobs (SP 8072) and scan jobs (SP 8075), the total is calculated by multiplying the number of sets of copies by the number of pages scanned. (One duplex page counts as 2.)
- The first test print and subsequent test prints to adjust settings are added to the number of pages of the copy job (SP 8072).
- When printing the first page of a job from within the document server screen, the page is counted.

	T:S-to-Email Jobs		[0 to 9999999/ 1]	
8131	These SPs count the total number of jobs scanned and attached to an e-mail, regardles whether the document server was used or not.			
	S:S-to-Email Jobs	S:S-to-Email Jobs		
8135	These SPs count the number of jobs scanned and attached to an e-mail, without storing to original on the document server.		attached to an e-mail, without storing the	
1	B/W Count for the number of job		s with black-and-white.	
2	Color	Count for the number of jobs with color.		
3	ACS	Count for the number of jobs	s using ACS mode.	

- These counters count jobs, not pages.
- If the job is stored on the document server, after the job is stored it is determined to be color or black-and-white then counted.
- If the job is cancelled during scanning, or if the job is cancelled while the document is waiting to be sent, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- If several jobs are combined for sending to the Scan Router, Scan-to-Email, or Scan-to-PC, or if
  one job is sent to more than one destination. each send is counted separately. For example, if the
  same document is sent by Scan-to-Email as well as Scan-to-PC, then it is counted twice (once for
  Scan-to-Email and once for Scan-to-PC).

8141	T:Deliv Jobs/Svr		[0 to 9999999/ 1]
0141	These SPs count the total number of jobs scanned and sent to a Scan Router server.		nd sent to a Scan Router server.
1	B/W	Count for the number of jobs	with black-and-white.
2	Color	Count for the number of jobs	with color.
3	ACS Count for the number of jobs		using ACS mode.
	S:Deliv Jobs/Svr		
8145	These SPs count the number of jobs scanned in scanner mode and sent to a Scan Router server.		
1	B/W Count for the number of jobs		with black-and-white.
2	Color	Count for the number of jobs with color.	
3	ACS	Count for the number of jobs using ACS mode.	

- These counters count jobs, not pages.
- The jobs are counted even though the arrival and reception of the jobs at the Scan Router server cannot be confirmed.
- If even one color image is mixed with black-and-white images, then the job is counted as a "Color" job.
- If the job is cancelled during scanning, or if the job is cancelled while the document is waiting to be delivered, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- Even if several files are combined for sending, the transmission counts as one job.

	T:Deliv Jobs/PC		[0 to 9999999/1]
8151	These SPs count the total number of jobs scanned and sent to a folder on a PC (Scan-to-PC).  Note: At the present time, 8151 and 8155 perform identical counts.		
1	B/W	Count for the number of jobs with black-and-white.	
2	Color	Count for the number of jobs with color.	
3	ACS	Count for the number of jobs	using ACS mode.

8155	S:Deliv Jobs/PC		
These SPs count the total number of jobs scanned and sent with Scan-to-PC.		the total number of jobs scanned and sent with Scan-to-PC.	
1	B/W	Count for the number of jobs with black-and-white.	
2	Color Count for the number of jobs with color.		
3	ACS Count for the number of jobs using ACS mode.		

- These counters count jobs, not pages.
- If the job is cancelled during scanning, it is not counted.
- If the job is cancelled while it is waiting to be sent, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- Even if several files are combined for sending, the transmission counts as one job.

8171	T: Deliv Jobs/WSD	
8175	S: Deliv Jobs/WSD	
8181	T: Scan to Media Jobs	
8185	S: Scan to Media Jobs	
1	B/W	
2	Color	
3	ACS	

8191	T:Total Scan PGS	
8192	C:Total Scan PGS	These SPs count the pages scanned by each application that uses the scanner to scan images.
8195	S:Total Scan PGS	[0 to 9999999/1]
8196	L:Total Scan PGS	

- SP 8191 to 8196 count the number of scanned sides of pages, not the number of physical pages.
- These counters do not count reading user stamp data, or reading color charts to adjust color.
- Previews done with a scanner driver are not counted.
- A count is done only after all images of a job have been scanned.
- Scans made in SP mode are not counted.

## **Examples**

- If 3 B5 pages and 1 A3 page are scanned with the scanner application but not stored, the S: count is 4.
- If both sides of 3 A4 sheets are copied and stored to the document server using the Store File button in the Copy mode window, the C: count is 6 and the L: count is 6.
- If both sides of 3 A4 sheets are copied but not stored, the C: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

	T:LSize Scan PGS	[0 to 9999999/1]		
8201	This SP counts the total number of large pages input with the scanner for scan and copy jobs.			
	Note: These counters are displayed in the SMC Report, and in the User Tools display.			
	S:LSize Scan PGS	[0 to 9999999/1]		
8205	This SP counts the total number of large pages input with the scanner for scan jobs only  Note: These counters are displayed in the SMC Report, and in the User Tools display			

8211	T:Scan PGS/LS	These SPs count the number of pages scanned into the
8212	C:Scan PGS/LS	document server .   [0 to 9999999
8215	S:Scan PGS/LS	The L: counter counts the number of pages stored from within
8216	L:Scan PGS/LS	the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen

- Reading user stamp data is not counted.
- If a job is cancelled, the pages output as far as the cancellation are counted.
- If the scanner application scans and stores 3 B5 sheets and 1 A4 sheet, the S: count is 4.
- If pages are copied but not stored on the document server, these counters do not change.
- If both sides of 3 A4 sheets are copied and stored to the document server, the C: count is 6 and the L: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

		ADF Org Feeds	
;	8221	[0 to 9999999/ 0 / 1]	
		These SPs count the number of pages fed through the ADF for front and back side scanning.	

1	Front	Number of front sides fed for scanning:  With an ADF that can scan both sides simultaneously, the Front side count is the same as the number of pages fed for either simplex or duplex scanning.  With an ADF that cannot scan both sides simultaneously, the Front side count is the same as the number of pages fed for duplex front side scanning. (The front side is determined by which side the user loads face up.)
2 Back as the number of pages fed for duplex scanning. With an ADF that cannot scan both sides simultaneous		With an ADF that can scan both sides simultaneously, the Back count is the same

- When 1 sheet is fed for duplex scanning the Front count is 1 and the Back count is 1.
- If a jam occurs during the job, recovery processing is not counted to avoid double counting. Also, the pages are not counted if the jam occurs before the first sheet is output.

	Scan PGS/Mode			
8231	[0 to 9999999/ 0 / 1]			
	These SPs count the number of pages scanned by each ADF mode to determine the work load on the ADF.			
1	Large Volume  Selectable. Large copy jobs that cannot be loaded in the ADF at one time.			
2	SADF	Selectable. Feeding pages one by one through the ADF.		
3	Mixed Size Selectable. Select "Mixed Sizes" on the operation panel.			
4	Custom Size	Selectable. Originals of non-standard size.		
5	Platen  Book mode. Raising the ADF and placing the original directly on the platen.			
6	Mixed 1side/2side			

- If the scan mode is changed during the job, for example, if the user switches from ADF to Platen mode, the count is done for the last selected mode.
- If the user selects "Mixed Sizes" for copying in the platen mode, the Mixed Size count is enabled.
- In the SADF mode if the user copies 1 page in platen mode and then copies 2 pages with SADF, the Platen count is 1 and the SADF count is 3.

	T:Scan PGS/Org			[0 to 9999999/1]		
8241	These SPs count the total number of scanned pages by original type for all jobs, regardless of which application was used.					
00.40	C:Scan PGS/Org	C:Scan PGS/Org			[0 to 9999999/1]	
8242	These SPs count the number	er of pages scar	nned by origin	nal type for Copy jol	bs.	
00.45	S:Scan PGS/Org			[0 to 9999999/ 1	]	
8245	These SPs count the number	er of pages scar	nned by origin	nal type for Scan job	os.	
	L:Scan PGS/Org			[0 to 9999999/ 1]		
8246	These SPs count the number of pages scanned and stored from within the document serv mode screen at the operation panel, and with the Store File button from within the Copy mode screen					
			8242	8245	8246	
824x 1: Text		Yes	Yes	Yes	Yes	
824x 2: Text/Photo		Yes	Yes	Yes	Yes	
824x 3: Photo		Yes	Yes	Yes	Yes	
824x 4: GenCopy, Pale		Yes	Yes	Yes	Yes	
824x 5: Map		Yes	Yes	Yes	Yes	

<sup>•</sup> If the scan mode is changed during the job, for example, if the user switches from ADF to Platen mode, the count is done for the last selected mode.

8251	T:Scan PGS/ImgEdt	These SPs show how many times Image Edit features have been selected at the operation panel for each	
8252	C:Scan PGS/ImgEdt	application. Some examples of these editing features	
8255	S:Scan PGS/ImgEdt	are:	
8256	L:Scan PGS/ImgEdt	Erase> Border	
0200	E.ocaii i ooy iiiigEai	Erase> Center	
	O:Scan PGS/ImgEdt	Image Repeat	
		Centering	
		Positive/Negative	
8257		[0 to 9999999/ 1]	
		Note: The count totals the number of times the edit features have been used. A detailed breakdown of exactly which features have been used is not given.	

• The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen.

	T:Scn PGS/ColCr	[0 to 9999999/ 1]	
8261	These SPs count the total number of scanned pages by the color processing mode used.		
	C:Scn PGS/ColCr	[0 to 9999999/1]	
These SPs count the number of pages by the color processin jobs only.		color processing mode used for Copy	
8265	S: Scn PGS/ColCr [0 to 9999999/1]		
8266	L: Scn PGS/TWAIN	[0 to 9999999/ 1]	
8261 1	Color Conversion		
8261 2	Color Erase		
8261 3	Background		
8261 4	Other		

• These counters are enabled only for MFP machines that support color. The wide format machines do not support the "Background" or "Other" counters.

8281	T:Scan PGS/TWAIN	These SPs count the number of pages scanned using a	
		TWAIN driver. These counters reveal how the TWAIN driver is used for delivery functions.	
8285	S:Scan PGS/TWAIN	[0 to 9999999/1] Note: At the present time, these counters perform identical counts.	

8291	T:Scan PGS/Stamp	These SPs count the number of pages stamped with the stamp in the ADF unit.
8295	S:Scan PGS/Stamp	[O to 9999999/ 1]  The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen

	T:Scan PGS/Size	[0 to 9999999/1]		
8301	These SPs count by size the total number of pages scanned by all applications.  Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-441].			
	C:Scan PGS/Size	[0 to 9999999/1]		
		al number of pages scanned by the Copy compare original page size (scanning) and output ].		
	S:Scan PGS/Size	[0 to 9999999/1]		
8305	These SPs count by size the total number of pages scanned by the Scan application. Use these totals to compare original page size (scanning) and output page size [SP 8-445].			
	L:Scan PGS/Size	[0 to 9999999/ 1]		
8306 the document server mode button from within the Cop		otal number of pages scanned and stored from within reen at the operation panel, and with the Store File mode screen. Use these totals to compare original put page size [SP 8-446].		

830x 1	A3
830x 2	A4
830x 3	A5
830x 4	B4
830x 5	B5
830x 6	DLT
830x 7	LG
830x 8	LT
830x 9	HLT
830x 10	Full Bleed
830x 254	Other (Standard)
830x 255	Other (Custom)

	T:Scan PGS/Rez		[0 to 9999999/1]
8311	These SPs count by resolution setting the total number of pages scanned by applications that can specify resolution settings.		
	S:Scan PGS/Rez		[0 to 9999999/ 1]
8315	These SPs count by resolution setting the total number of pages scanned by applications that can specify resolution settings.  Note: At the present time, 8311 and 8315 perform identical counts.		s.
831x 1	1200dpi to 599dpi		
831x 2	600dpi to 1199dpi		
831x3	400dpi to 599dpi		
831x 4	200dpi to 399dpi		
831x 5	to 199dpi		

- Copy resolution settings are fixed so they are not counted.
- The Fax application does not allow finely-adjusted resolution settings so no count is done for the Fax application.

8381	T:Total PrtPGS	These SPs count the number of pages printed by
8382	C:Total PrtPGS	the customer. The counter for the application used for storing the pages increments.
8384	P:Total PrtPGS	[0 to 9999999/1]
8385	S:Total PrtPGS	The L: counter counts the number of pages stored from within the document server mode
8386	L:Total PrtPGS	screen at the operation panel. Pages stored with the Store File button from within the Copy mode
8387	O:Total PrtPGS	screen go to the C: counter.

- When the A3/DLT double count function is switched on with SP5104, 1 A3/DLT page is counted as 2.
- When several documents are merged for a print job, the number of pages stored are counted for the application that stored them.
- These counters are used primarily to calculate charges on use of the machine, so the following pages are not counted as printed pages:
- Blank pages in a duplex printing job.
- Blank pages inserted as document covers, chapter title sheets, and slip sheets.
- Reports printed to confirm counts.
- All reports done in the service mode (service summaries, engine maintenance reports, etc.)
- Test prints for machine image adjustment.
- Error notification reports.
- Partially printed pages as the result of a copier jam.

	LSize PrtPGS [0 to 9999999/1]	
8391	These SPs count pages printed on paper sizes A3/DLT and larger.	
	Note: In addition to being displayed in the SMC I displayed in the User Tools display on the copy m	

8401	T:PrtPGS/LS	These SPs count the number of pages printed from the
8402	C:PrtPGS/LS	document server. The counter for the application used to print
8404	P:PrtPGS/LS	the pages is incremented.  The L: counter counts the number of jobs stored from within the
8405	S:PrtPGS/LS	document server mode screen at the operation panel.
8406	L:PrtPGS/LS	[0 to 9999999/ 1]

• Print jobs done with Web Image Monitor and Desk Top Binder are added to the L: count.

8411	Prints/Duplex	This SP counts the amount of paper (front/back counted as 1 page) used for duplex printing. Last pages printed only on one side are not counted.
		[0 to 9999999/ 1]

	T:PrtPGS/Dup Comb		[0 to 9999999/ 1]	
8421	These SPs count by binding and combine processed for printing. This is the total for		, and n-Up settings the number of pages	
	C:PrtPGS/Dup Comb		[0 to 9999999/ 1]	
8422	These SPs count by binding processed for printing by th		and n-Up settings the number of pages cation.	
	P:PrtPGS/Dup Comb		[0 to 9999999/ 1]	
8424	These SPs count by binding processed for printing by th		and n-Up settings the number of pages cation.	
	S:PrtPGS/Dup Comb		[0 to 9999999/ 1]	
8425	These SPs count by binding processed for printing by th		and n-Up settings the number of pages ication.	
	L:PrtPGS/Dup Comb		[0 to 9999999/ 1]	
8426	, ,		and n-Up settings the number of pages ument server mode window at the operation	
	O:PrtPGS/Dup Comb		[0 to 9999999/ 1]	
8427	These SPs count by binding processed for printing by C		and n-Up settings the number of pages	
842x 1	Simplex> Duplex			
842x 2	Duplex> Duplex			
842x 3	Book> Duplex			
842x 4	Simplex Combine			
842x 5	Duplex Combine			

842x 6	2>	2 pages on 1 side (2-Up)	
842x 7	4>	4 pages on 1 side (4-Up)	
842x 8	6>	6 pages on 1 side (6-Up)	
842x 9	8>	8 pages on 1 side (8-Up)	
842x 10	9>	9 pages on 1 side (9-Up)	
842x 11	16>	16 pages on 1 side (16-Up)	
842x 12	Booklet		
842x 13	Magazine		

- These counts (SP8421 to SP8427) are especially useful for customers who need to improve their compliance with ISO standards for the reduction of paper consumption.
- Pages that are only partially printed with the n-Up functions are counted as 1 page.
- Here is a summary of how the counters work for Booklet and Magazine modes:

Booklet			Magazine	
Original Pages	Count		Original Pages	Count
1	1		1	1
2	2		2	2
3	2		3	2
4	2		4	2
5	3		5	4
6	4		6	4
7	4		7	4
8	4		8	4

		T:PrtPGS/ImgEdt	[0 to 9999999/ 1]
	8431	These SPs count the total number of p	ages output with the three features below, used.

	C:PrtPGS/ImgEdt	[[	0 to 9999999 / 1]
8432	, 0		ges output with the three features below with the
	P:PrtPGS/ImgEdt	[0	0 to 9999999/ 1]
8434	These SPs count the total numb	er of pag	ges output with the three features below with the
	L:PrtPGS/ImgEdt	[0	0 to 9999999/ 1]
8436	These SPs count the total number of pages output from within the window t the operation panel with the three features below.		,
	O:PrtPGS/ImgEdt	[0 to 9999999/ 1]	
8437	These SPs count the total numb Other applications.	er of pag	ges output with the three features below with
843x 1	Cover/Slip Sheet	Total number of covers or slip sheets inserted. The count for a cover printed on both sides counts 2.	
843x 2	Series/Book	The number of pages printed in series (one side) or printed as a book with booklet right/left pagination.	
843x 3	User Stamp	The number of pages printed where stamps were applied, including page numbering and date stamping.	

8441	T:PrtPGS/Ppr Size	[0 to 9999999/1]		
0441	These SPs count by print paper size the number of pages printed by all applications.			
	C:PrtPGS/Ppr Size	[0 to 9999999/1]		
These SPs count by print paper size the number of pages printed by the copapplication.		mber of pages printed by the copy		
	P:PrtPGS/Ppr Size	[0 to 9999999/ 1]		
8444	These SPs count by print paper size the number of pages printed by the printer application.			
	S:PrtPGS/Ppr Size	[0 to 9999999/ 1]		
8445	These SPs count by print paper size the number of pages printed by the scanner application.			

	L:PrtPGS/Ppr Size		[0 to 9999999/ 1]
8446	These SPs count by print paper size the number of pages printed from within the document server mode window at the operation panel.		
	O:PrtPGS/Ppr Size		[0 to 9999999/ 1]
8447	These SPs count by print p applications.	aper size the nu	mber of pages printed by Other
844x 1	A3		
844x 2	A4		
844x 3	A5		
844x 4	B4		
844x 5	B5		
844x 6	DLT		
844x 7	LG		
844x 8	LT		
844x 9	НІТ		
844x 10	Full Bleed		
844x 254	Other (Standard)		
844x 255	Other (Custom)		

• These counters do not distinguish between LEF and SEF.

0.451	PrtPGS/Ppr Tray		[0 to 9999999/ 1]
8451	These SPs count the number of sheets fed from each		n paper feed station.
1	Bypass Tray		
2	Tray 1 Copier		
3	Tray 2 Copier		
4	Tray 3	Paper Tray Unit (Op	tion)
5	Tray 4	Paper Tray Unit (Op	tion)

6	Tray 5	LCT (Option)
7	Tray 6	Currently not used.
8	Tray 7	Currently not used.
9	Tray 8	
10	Tray 9	
11	Tray 10	
12	Tray 11	
13	Tray 12	
14	Tray 13	
15	Tray 14	
16	Tray 15	

	T:PrtPGS/Ppr Type	[0 to 9999999/1]		
	These SPs count by paper type the number pages printed by all applications.  These counters are not the same as the PM counter. The PM counter is based on feed			
8461	timing to accurately measure the service life of the feed rollers. However, these counts are based on output timing.			
	Blank sheets (covers, chapter covers, slip shee	ets) are also counted.		
	During duplex printing, pages printed on both sides count as 1, and a page printed on one side counts as 1.			
8462	C:PrtPGS/Ppr Type	[0 to 9999999/ 1]		
8402	These SPs count by paper type the number pages printed by the copy application.			
0.44.4	P:PrtPGS/Ppr Type	[0 to 9999999/ 1]		
8464	These SPs count by paper type the number pages printed by the printer application.			
	L:PrtPGS/Ppr Type	[0 to 9999999/ 1]		
8466	These SPs count by paper type the number pages printed from within the document server mode window at the operation panel.			
846x 1	846x 1 Normal			

846x 2	Recycled
846x 3	Special
846x 4	Thick
846x 5	Normal (Back)
846x 6	Thick (Back)
846x 7	OHP
846x 8	Other

8471	PrtPGS/Mag	[0 to 9999999/ 1]
	These SPs count by magnification rate the number of pages printed.	
1	to 49%	
2	50% to 99%	
3	100%	
4	101% to 200%	
5	201% to	

- Counts are done for magnification adjusted for pages, not only on the operation panel but performed remotely with an external network application capable of performing magnification adjustment as well.
- Magnification adjustments done with printer drivers with PC applications such as Excel are also counted.
- Magnification adjustments done for adjustments after they have been stored on the document server are not counted.
- Magnification adjustments performed automatically during Auto Reduce/Enlarge copying are counted.
- The magnification rates of blank cover sheets, slip sheets, etc. are automatically assigned a rate of 100%.

	8481	T:PrtPGS/TonSave	These SPs count the number of pages printed with the Toner Save feature switched on.	
	8484		Note: These SPs return the same results as this SP is limited to the Print application.	
			[0 to 9999999/ 1]	

8491	T:PrtPGS/Col Mode [0 to 9999999/1]		
	These SPs count by color mode the total number of pages output by the Copy, document server, and Fax applications.		
8492	C:PrtPGS/Col Mode		[0 to 9999999/1]
0492	These SPs count by color mode the total output by the Copy application only		
	L:PrtPGS/Col Mode		[0 to 9999999/ 1]
8496	These SPs count by color mode the total output from within the document server mode window at the operation panel.		
8497	O:PrtPGS/Col Mode		[0 to 9999999/ 1]
849x 1	B/W		
849x 2	Single Color	Color MFP/2-colo	or MFP machines only.
849x 3	Two Color	Color MFP/2-color MFP machines only.	
849x 4	Full Color	Color MFP machines only	

# Notes for SP8491 to SP8496

- These SPs apply to the Copy, document server, and Fax applications only. They do not apply to the Print application.
- When the ACS feature is used to select the color settings automatically, the results of the ACS execute is used to increment the appropriate counter.
- If a color stamp is selected for printing on a monochrome document, the count is for B/W.
- If the output is black and white even if color print mode was selected, the pages count as Full Color.
- The color mode selected for a document stored on the document server is counted. (The color selection cannot be changed once the document is stored on the document server.)

0.501	T:PrtPGS/Col Mode		[0 to 9999999/ 1]	
8501	These SPs count by color mode the total number of pages printed.			
0504	P:PrtPGS/Col Mode		[0 to 9999999/1]	
8504	These SPs count by color mode the number of pages printed with the Print application.			
8507	O:PrtPGS/Col Mode		[0 to 9999999/ 1]	
	These SPs count by color mode the number of pa		ges printed with the other applications.	
1	B/W			
2	Mono Color	Color MFP and 2-Co	olor MFP machines only.	
3	Full Color	Color MFP and Color LP machines only.		
4	Single Color	B081/D082 only		
5	Two Color	B081/D082 only		

• At the present time, 8501 and 8504 perform identical counts, because they are both limited to the Print application.

8511	T:PrtPGS/Emul	[0 to 9999999/ 1]
	These SPs count by printer emulation mode the total number of pages printed.	
8514	P:PrtPGS/Emul	[0 to 9999999/1]
	These SPs count by printer emulation mode the total number of pages printed.	

851x 1	RPCS	
851x 2	RPDL	
851x 3	PS3	
851x 4	R98	
851x 5	R16	
851x 6	GL/GL2	
851x7	R55	
851x 8	RTIFF	
851x 9	PDF	
851x 10	PCL5e/5c	
851x 11	PCL XL	
851x 12	IPDL-C	
851x 13	BM-Links	Japan Only
851x 14	Other	
851x 15	IPDS	

- SP8511 and SP8514 return the same results as they are both limited to the Print application.
- Print jobs output to the document server are not counted.

8521	T:PrtPGS/FIN	[0 to 9999999/ 1]	
	These SPs count by finishing mode the total number of pages printed by all applications.		
	C:PrtPGS/FIN	[0 to 9999999/ 1]	
8522	These SPs count by finishing mode the total number of pages printed by the Copy application.		
	P:PrtPGS/FIN	[0 to 9999999/ 1]	
8524	These SPs count by finishing mode the total number of pages printed by the Print application.		

	S:PrtPGS/FIN		[0 to 9999999/ 1]	
8525	These SPs count by finishing mode the total number of pages printed by the Scanner application.			
	L:PrtPGS/FIN		[0 to 9999999/ 1]	
8526	These SPs count by finishing mode the total number of pages printed from within the document server mode window at the operation panel.			
852x 1	Sort			
852x 2	Stack			
852x 3	Staple			
852x 4	Booklet			
852x 5	Z-Fold			
852x 6	Punch			
852x 7	Other			
806x 8	Inside Fold	Inside Fold Half-Fold (FM2) (Multi Fold Unit)		
806x 9	Three-IN-Fold	Letter Fold-in (FM4) (Multi Fold Unit)		
806x 10	Three-OUT-Fold	Three-OUT-Fold Letter Fold-out (FM3) (Multi Fold Unit)		
806x 11	Four Fold	Double Parallel Fold (FM5) (Multi Fold Unit)		
806x 12	KANNON-Fold	Gate Fold (FM6) (Multi Fold Unit)		
806x 13	Perfect-Bind	Perfect Binder Not Used		
806x 14	Ring-Bind	g-Bind Ring Binder		

## Note:

- If stapling is selected for finishing and the stack is too large for stapling, the unstapled pages are still counted.
- The counts for staple finishing are based on output to the staple tray, so jam recoveries are counted.

8531	Staples	This SP counts the amount of staples used by the machine.		
	8331	Staples	[0 to 9999999/ 1]	

8551	T: PrtBooks/FIN	
8552	O: PrtBooks/FIN	
8554	P: PrtBooks/FIN	
8556	L: PrtBooks/FIN	
1	Perfect-Bind	Not Used
2	Ring-Bind	

	T:Counter	[0 to 9999999/ 1]	
8581	These SPs count the total output broken down by color output, regardless of the application used. In addition to being displayed in the SMC Report, these counters are also displayed in the User Tools display on the copy machine.  Note: These SPs are supported by color MFP and LP machines only.		
1	Total		
2	Total: Full Color		
3	B&W/Single Color		
4	Development: CMY		
5	Development: K		
6	Copy: Color		
7	Copy: B/W		
8	Print: Color		
9	Print: B/W		
10	Total: Color		
11	Total: B/W		
12	Full Color: A3		
13	Full Color: B4 JIS or smaller		
14	Full Color Print		
15	Mono Color Print		

16	Full Color GPC	
17	Twin Color Mode Print	
18	Full Color Print (Twin)	
19	Mono Color Print (Twin)	
20	Full Color Total (CV)	
21	Mono Color Total (CV)	
22	Full Color Print (CV)	
28	Development: CMY (A3)	
29	Development: K (A3)	
30	Total: Color (A3)	
31	Total: B/W (A3)	

	C:Counter	[0 to 9999999/1]	
8582	These SPs count the total output broken down by color output for the Copy application only.		
	Note: These SPs are supported l	by color copy MFP machines only.	
	These counters are displayed in the SMC Report, and in the User Tools display on the copy machine.		
1	B/W		
2	Single Color		
3	Two Color		
4	Full Color		

		P:Counter		[0 to 9999999/ 1]
858	34	These SPs count the total output broken down by color output for the Print application only. These counters are displayed in the SMC Report, and in the User Tools display on the copy machine.		
		Note: These SPs are supported by color MFP and LP machines only.		
	1	B/W		

2	Mono Color	
3	Full Color	
4	Single Color	
5	Two Color	

	L:Counter		[0 to 9	9999999/1]
8586	These SPs count the total output broken down by color for output from within the document server mode window at the operation panel. These counters are displayed in the SMC Report, and in the User Tools display on the copy machine.			
Note: These SPs are supported only by color copy MFP machinapplication installed.		P machines only with the fax		
	MFP Co		or	Replaced:
1	B/W	Yes		
2	Single Color	Yes		
3	Two Color	Yes		
4	Single Color	Yes		

	O:Counter		[0 to 9999999/ 1]
8591	These SPs count the totals for A3/DLT paper use, number of duplex pages printed, and the number of staples used. These totals are for Other (O:) applications only.		
1	A3/DLT		
2	Duplex		

8601	Coverage Counter		
1	B/W		
2	Color		
11	B/W Printing Pages		
12	Color Printing Pages		
21	Coverage Counter 1		

22	Coverage Counter 2	
23	Coverage Counter 3	

8617	SDK Apli Counter
1	SDK-1
2	SDK-2
3	SDK-3
4	SDK-4
5	SDK-5
6	SDK-6

8621	Func Use Counter <b>DFU</b>
1 to 64	Function 001 to Function 064

	T:S-to-Email PGS		[0 to 9999999/1]	
8651	·	unt by color mode the total number of pages attached to an e-mail for both the cument server applications.		
1	B/W			
2	Color	Supported by Color MFP mad	chines only.	
	S:S-to-Email PGS		[0 to 9999999/1]	
8655	These SPs count by color mode the total number of pages attached to an e-mail for Scan application only.			
1	B/W			
2	Color	Supported by Color MFP machines only.		

## Notes

- The count for B/W and Color pages is done after the document is stored on the HDD. If the job is cancelled before it is stored, the pages are not counted.
- If Scan-to-Email is used to send a 10-page document to 5 addresses, the count is 10 (the pages are sent to the same SMTP server together).

- If Scan-to-PC is used to send a 10-page document to 5 folders, the count is 50 (the document is sent to each destination of the SMB/FTP server).
- Due to restrictions on some devices, if Scan-to-Email is used to send a 10-page document to a large number of destinations, the count may be divided and counted separately. For example, if a 10-page document is sent to 200 addresses, the count is 10 for the first 100 destinations and the count is also 10 for the second 100 destinations, for a total of 20.).

8661		T:Deliv PGS/Svr		[0 to 9999999/ 1]
			t by color mode the total number of pages sent to a Scan Router server and LS applications.	
	1	B/W		
	2	Color	Supported by Color MFP ma	chines only.
		S:Deliv PGS/Svr		[0 to 9999999/1]
8665		These SPs count by color mode the total number of pages sent to a Scan Rout by the Scan application.		r of pages sent to a Scan Router server
	1	B/W		
	2	Color	Supported by Color MFP machines only.	

## Notes

- The B/W and Color counts are done after the document is stored on the HDD of the Scan Router server.
- If the job is canceled before storage on the Scan Router server finishes, the counts are not done.
- The count is executed even if regardless of confirmation of the arrival at the Scan Router server.

8671		T:Deliv PGS/PC		[0 to 9999999/ 1]
		These SPs count by color mode the total number of pages sent to a folder on a PC (Scan-to-PC) with the Scan and LS applications.		
1	1	B/W		
	2	Color Supported by Color M		P machines only.
S:Deliv PGS/PC [0 to 99999		[0 to 9999999/1]		
8675	These SPs count by color mode the total number of pages sent with Scan-to-Scan application.		r of pages sent with Scan-to-PC with the	
	1	B/W		

2	Color	Supported by Color MFP machines only.
8691	T:TX PGS/LS	These SPs count the number of pages sent from the document
8692	C:TX PGS/LS	server. The counter for the application that was used to store the pages is incremented.
8694	P:TX PGS/LS	[0 to 9999999/1]
8695	S:TX PGS/LS	The L: counter counts the number of pages stored from within the document server mode screen at the operation panel. Pages
8696	L:TX PGS/LS	stored with the Store File button from within the Copy mode screen go to the C: counter.

## Notes

- Print jobs done with Web Image Monitor and Desk Top Binder are added to the count.
- If several documents are merged for sending, the number of pages stored are counted for the application that stored them

	TX PGS/Port		[0 to 9999999/1]
These SPs count the number of pages sent by the physical port used to send them example, if a 3-page original is sent to 4 destinations via ISDN G4, the count for (G3, G4) is 12.			
1	PSTN-1		
2	PSTN-2		
3	PSTN-3		
4	ISDN (G3,G4)		
5	Network		

	T:Scan PGS/Comp		[0 to 9999999/ 1]
These SPs count the number of compressed pages scanned into the docum counted by the formats slisted below.		es scanned into the document server,	
1	JPEG/JPEG2000		
2	TIFF (Multi/Single)		
3	PDF		
4	Other		

ſ			
	5	PDF/Comp	
		' '	

	S:Scan PGS/Comp		[0 to 9999999/1]
8715	These SPs count the number of compressed pages scanned by the scan applicat counted by the formats slisted below.		
1	JPEG/JPEG2000		
2	TIFF (Multi/Single)		
3	PDF		
4	Other		
5	PDF/Comp		

8721	T: Deliv PGS/WSD		
8725	S: Deliv PGS/WSD		
8731	T: Scan PGS/Media		
8735	S: Scan PGS/Media		
1	B/W		
2	Color		

	RX PGS/Port		[0 to 9999999/ 1]
8741	These SPs count the number of pages received by the physical port used to receive them.		
1	PSTN-1		
2	PSTN-2		
3	PSTN-3		
4	ISDN (G3,G4)		
5	Network		

	Dev Counter		[0 to 9999999/ 1]
8771	These SPs count the frequency of use (number of rotations of the development rollers) for black and other color toners.		
Note: For machines that do not support color, the Black toner count is the same as to Total count.			
1	Total	All toners (YMCK)	
2	К	Black toner	
3	Υ	Yellow toner	
4	М	Magenta toner	
5	С	Cyan toner	
6	R	Red toner (Wide Format A2 machines only)	

	Toner Use Count: Color		[0 to 65 535]
These SPs count the frequency of use (number of rotations of the development for black and other color toners.		of rotations of the development rollers)	
1	ВК	Black toner	
2	Υ	Yellow toner	
3	М	Magenta toner	
4	С	Cyan toner	

8791	LS Memory Remain
	This SP displays the percent of space available on the document server for storing documents.
	[0 to 100/1]

	Toner Remain [0 to 100/1]					
8801		This SP displays the percent of toner remaining for each color. This SP allows the user to check the toner supply at any time.				
	Note: This precise method of measuring remaining toner supply (1% steps) is better than other machines in the market that can only measure in increments of 10 (10% steps).					
1	K	Black. Supported by B/W, Color, Wide Format A2, Wide Format Roll machines.		Color, Wide Format A2, Wide Format		
2	Υ	Yellow				
3	М	Magenta	Color machines only.			
4	С	Cyan				

8851	Toner Coverage 0-10%		[0 to 65 535]
0031	These SPs count the percentage of dot coverage		for black other color toners.
11	0-2%: BK		
12	0-2%: Y		
13	0-2%: M		
14	0-2%: C		
21	3-4%: BK		
22	3-4%: Y		
23	3-4%: M		
24	3-4%: C		
31	5-7%: BK		
32	5-7%: Y		
33	5-7%: M		
34	5-7%: C		
41	8-10%: BK		
42	8-10%: Y		

43	8-10%: M	
44	8-10%: C	

8861	Toner Coveraç	ge 11-20%	[0 to 65 535]
0001	These SPs count the percentage of dot coverage for black other color toners.		
0.071	Toner Coverage 21-30%		[0 to 65 535]
8871	These SPs count the percentage of dot coverage for black other color toners.		
0001	Toner Coverage 31 -%		[0 to 65 535]
8881	These SPs count the percentage of dot coverage for black ot		ge for black other color toners.
8891	Pages: Current	Toner	[0 to 65 535]
0091	These SPs count the number of pages for the current set toner.		
8901	Page/Toner_Prev1 <b>DFU</b>		
8911	Page/Toner_Prev2 <b>DFU</b>		
1	1 BK Black toner		
2	Υ	Yellow toner	
3	М	Magenta toner	
4	С	Cyan toner	

8921	Cvr Cnt/Total	
1	Coverage (%): BK	
2	Coverage (%): Y	
3	Coverage (%): M	
4	Coverage (%): C	
11	Coverage/P: BK	
12	Coverage/P: Y	
13	Coverage/P: M	
14	Coverage/P: C	

	Machine Status		[0 to 9999999/ 1]
8941	These SPs count the amount of time the machine spends in each operation mode. The SPs are useful for customers who need to investigate machine operation for improve their compliance with ISO Standards.		
1			n time. Does not include time while ng data to HDD (while engine is not
2	Standby Time	Engine not operating. Includes time while controller saves data to HDD. Does not include time spent in Energy Save, Low Power, or Off modes.	
3	Energy Save Time	Includes time while the machine is performing background printing.	
4	Low Power Time		Energy Save mode with Engine on. nile machine is performing background
5	Off Mode Time	Includes time while machine is performing background printing. Does not include time machine remains powered off with the power switches.	
6	SC	Total down time due to S	
7	PrtJam Total down time		due to paper jams during printing.
8	OrgJam Total down time due to original jams during scannin		due to original jams during scanning.
9	Supply PM Unit End Total down time due to toner end.		due to toner end.

AddBook Register		AddBook Register	
	8951	These SPs count the number of events when the machine manages data registration.	

1	User Code User code registrations.		
2	Mail Address	ail Address Mail address registrations.	
3	Fax Destination	Fax destination registrations.	
4	Group	Group destination registrations.	[0 to 9999999/ 1]
5	Transfer Request	Fax relay destination registrations for relay TX.	
6	6 F-Code F-Code box registrations.		
7	7 Copy Program Copy application registrations with the Program (job settings) feature.		
8	Fax Program  Fax application registrations with the Program (job settings) feature.		
9	Printer Program	Printer application registrations with the Program (job settings) feature.	[0 to 255 / 255]
10	Scanner application registrations with the Program (job settings) feature.		

8999	Admin Counter List	
1	Total	
2	Copy: Full Color	
3	Copy: BW	
4	Copy: Single Color	
5	Copy: Two Color	
6	Printer: Full Color	
7	Printer: BW	
8	Printer: Single Color	
9	Printer: Two Color	
10	Fax Print: BW	

11	Fax Print: Single Color	
12	A3/DLT	
13	Duplex	
14	Coverage: Color (%)	
15	Coverage: BW (%)	
16	Coverage: Color Print Page	
17	Coverage: BW Print Page	
20	Full Color: GPC	
101	Transmission Total: Color	
102	Transmission Total: BW	
103	Fax Transmission	
104	Scanner Transmission: Color	
105	Scanner Transmission: BW	

MEMO

MEMO

