


Pro C900s

Operating Instructions Copy/Document Server Reference





- 1 Placing Originals
- 2 Basic Copying
- 3 Color Copying
- 4 Advanced Copying
- 5 Document Server
- **6** Appendix

Introduction

This manual contains detailed instructions and notes on the operation and use of this machine. For your safety and benefit, read this manual carefully before using the machine. Keep this manual in a handy place for quick reference.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Do not copy or print any item for which reproduction is prohibited by law.

Copying or printing the following items is generally prohibited by local law:

bank notes, revenue stamps, bonds, stock certificates, bank drafts, checks, passports, driver's licenses.

The preceding list is meant as a guide only and is not inclusive. We assume no responsibility for its completeness or accuracy. If you have any questions concerning the legality of copying or printing certain items, consult with your legal advisor.

The color samples in this manual may differ slightly from the colors of actual copies.

Colors on color keys or the color circle may differ slightly from the colors of actual copies.

This machine is equipped with a function that prevents making counterfeit bank bills. Due to this function the original images similar to bank bills may not be copied properly.

Notes:

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Depending on which country you are in, your machine may include certain options as standard. For details, please contact your local dealer.

Caution:

Use of controls or adjustments or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

Notes:

Two kinds of size notation are employed in this manual. With this machine refer to the inch version.

Manuals for This Machine

Refer to the manuals that are relevant to what you want to do with the machine.

- Media differ according to manual.
- The printed and electronic versions of a manual have the same contents.
- Adobe Acrobat Reader/Adobe Reader must be installed in order to view the manuals as PDF files.
- A Web browser must be installed in order to view the html manuals.

About This Machine

Be sure to read the Safety Information in this manual before using the machine.

This manual provides an introduction to the functions of the machine. It also explains the control panel, preparation procedures for using the machine, how to enter text, and how to install the CD-ROMs provided.

Troubleshooting

Provides a guide to solving common problems, and explains how to replace paper, toner, staples, and other consumables.

Copy/ Document Server Reference

Explains Copier and Document Server functions and operations. Also refer to this manual for explanations on how to place originals.

Scanner Reference

Explains Scanner functions and operations.

Network Guide

Explains how to configure and operate the machine in a network environment.

General Settings Guide

Explains User Tools settings, and Address Book procedures such as registering user codes. Also refer to this manual for explanations on how to connect the machine.

Security Reference

This manual is for administrators of the machine. It explains security functions that you can use to prevent unauthorized use of the machine, data tampering, or information leakage. For enhanced security, we recommend that you first make the following settings:

- Install the Device Certificate.
- Enable SSL (Secure Sockets Layer) Encryption.
- Change the user name and password of the administrator using Web Image Monitor.

For details, see "Setting Up the Machine", Security Reference.

Be sure to read this manual when setting the enhanced security functions, or user and administrator authentication.

Information

Contains general notes on the machine, and information about the trademarks of product names used in the manuals.



• In addition to the above, manuals are also provided for the Printer function.

What You Can Do with This Machine < Color Functions/Color Adjustments>

This section introduces the machine's color functions that you are likely to use most often.

Color Copying


You can switch the color copy mode depending on the type of originals used and the desired finish.

You can also erase or convert a certain color in the original, or add a background color to the whole page.

See p.109 "Selecting a Color Mode".

Primary Colors

Colors can be created by combining the three primary colors: yellow, magenta, and cyan. Black can be made by combining yellow, magenta and cyan, however, as there might be some slight differences, "black" will be expressed using a black toner.




Full Color

Copies using four colors: yellow, magenta, cyan, and black.



Black & White

Copies in black and white even if the original is colored.




BAS163S

Convert Colors

Copies by changing a certain color in the original to another color.


See p.110 "Convert Colors".



Erase Specified Color

Copies by erasing a certain color in the original.


See p.111 "Erase Color".



Color Background

Copies by adding a color to the whole page.


See p.113 "Color Background".



Stamping on Copies

Copies with the date, page numbers, etc.

The stamp color can be yellow, red, cyan, magenta, green, blue, and black.



BAT170S

Printed inserts types:

Preset Stamp

See p.140 "Preset Stamp".

User Stamp

See p.143 "User Stamp".

Date Stamp

See p.148 "Date Stamp".

Page Numbering

See p.151 "Page Numbering".

Stamp Text

See p.157 "Stamp Text".


Adjusting Colors

You can adjust the color tone of copies.

Color Balance

Adjusts the overall color tone of copies.


See p.114 "Color Balance".



Adjust Color

Adjusts the specific colors (yellow, red, magenta, blue, cyan and green) by mixing them with adjacent colors in the color circle.

See p.117 "Color Adjustment".



Adjusting Image Qualities


You can adjust image qualities.

See p.118 "Image Adjustment".

Sharp/Soft

Adjusts the outline of an image.


See p.119 "Sharp / Soft".



Contrast


Adjusts the shades of an image.

See p.120 "Contrast".



Background Density

Adjusts the background density of an image. See p.120 "Background Density".



BAT175S

What You Can Do with This Machine

This section introduces the machine's copier functions that you are likely to use most often.

Functions differ depending on machine type and options.


See p.21 "Functions Requiring Optional Configurations".

Reducing/Enlarging Originals by Specifying the Paper Size

The machine automatically detects the original size, and then selects an appropriate reproduction ratio based on the paper size you select.

Auto Reduce/Enlarge

See p.69 "Auto Reduce/Enlarge".



BAS033


Saving Paper

The Duplex and Combine functions allow you to save paper.


Duplex

Copies two 1-sided pages or one 2-sided page onto a 2-sided page.

See p.72 "Duplex".




8AS034S




One-Sided Combine

Combines up to eight pages of originals onto one side of a sheet.

See p.75 "One-Sided Combine".







Two-Sided Combine

Combines up to 16 pages of originals onto two sides of one sheet.


See p.79 "Two-Sided Combine".





Copying onto Various Types of Paper

You can copy onto various types of paper such as tab stock, envelopes, and thick paper.



See p.48 "Copying onto Tab Stock".

See p.52 "Copying from the Multi Bypass Tray".

See p.64 "Copying from the Wide Large Capacity Tray (Wide LCT)".


Creating a Booklet or Magazine

Copies two or more originals in page order.


Booklet

Make copies in page order for a folded booklet.

See p.183 "Booklet/Magazine".



- 1. Open to left
- 2. Open to right




- 1. Open to left
- 2. Open to right


Magazine

Copies two or more originals to make copies in page order when they are folded and stacked.

See p.183 "Booklet/Magazine".



- 1. Open to left
- 2. Open to right



- 1. Open to left
- 2. Open to right


Copying Originals Such as Books

Copies bound originals onto one side or both sides of a sheet.


Series Copies

Separately copies the front and back of a 2-sided original or the two facing pages of a bound original onto two sheets.

See p.181 "Series Copies".



BAS1035




13

Book → 2 Sided

Copies a two-page spread original onto one sheet with one page per side.


See p. 183 "Booklet/Magazine".



Front & Back → 2 Sided

Copies each two-page spread original as it is onto both sides of a sheet.

See p. 183 "Booklet/Magazine".



Registering the Initial Display's Default Functions

You can configure the settings of the initial screen so that the default display contains the functions you use most often.

For example: if the default selection is the Duplex function, but the function you use most frequently is 1-sided copying, you can change the default selection to 1-sided copying instead. For details, see "Registering the Initial Display's Default Functions".

You can also store frequently used copy job settings in the machine memory and recall them for future use. For details, see "Registering Frequently Used Function".

See p.102 "Registering Frequently Used Functions".

See p.106 "Registering the Initial Display's Default Functions".

TABLE OF CONTENTS

Manuals for This Machine	1
What You Can Do with This Machine < Color Functions/Color Adjustments>	3
Color Copying	3
Stamping on Copies	5
Adjusting Colors	6
Adjusting Image Qualities	7
What You Can Do with This Machine	9
Reducing/Enlarging Originals by Specifying the Paper Size	9
Saving Paper	9
Copying onto Various Types of Paper	11
Creating a Booklet or Magazine	11
Copying Originals Such as Books	13
Registering the Initial Display's Default Functions	14
How to Read This Manual	20
Symbols	20
Names of Major Options	20
Functions Requiring Optional Configurations	21
Display	22
Simplified Display	23
1. Placing Originals	
Originals	25
Sizes and Weights of Recommended Originals	25
Sizes Detectable with Auto Paper Select	26
Missing Image Area	28
Placing Originals	30
Original Orientation	30
Reverse Orientation	
Left Original Beeper	33
Placing Originals on the Exposure Glass	
Placing Originals in the ADF	34
Batch Mode	
SADF Mode	36
Mixed Sizes Mode	37

Thin Mode	38
Specifying Original Sizes	39
2. Basic Copying	
Basic Procedure	43
Interrupt Copy	44
Copy Face Up	45
Auto Start	47
Job Preset	47
Copying onto Tab Stock	48
Copying from the Multi Bypass Tray	52
Copying onto Regular Size Paper	55
Copying onto Custom Size Paper	56
Copying onto Thin Paper	58
Copying onto Thick Paper	58
Loading Tab Stock in the Multi Bypass Tray (Tray 7)	59
Copying onto Envelopes	61
Copying from the Wide Large Capacity Tray (Wide LCT)	64
Loading Tab Stock in the Wide LCT	64
Loading Envelopes in the Wide LCT	65
Reducing or Enlarging Originals	66
Preset Reduce/Enlarge	66
Zoom	67
Auto Reduce/Enlarge	69
Duplex/Combined Copying	72
Duplex	72
One-Sided Combine	75
Two-Sided Combine	79
Finishing	83
Sort	83
Stack	87
Staple	88
Punch	90
Z-fold	93

Storing Data in the Document Server	95
Managing Jobs	97
Job List Screen	97
Checking Jobs in the Job List	98
Changing the Order of Jobs	99
Holding Jobs	99
Deleting Jobs	100
Checking the Job History	101
Registering Frequently Used Functions	102
Registering Functions in a Program	102
Changing a Stored Program	103
Recalling a Stored Program	104
Deleting a Stored Program	104
Registering the Initial Display's Default Functions	106
3. Color Copying	
Color Functions	
Selecting a Color Mode	109
Convert Colors	110
Erase Color	111
Color Background	113
Adjusting Color and Image Quality	114
Color Balance	114
Color Balance Program	115
Color Adjustment	117
Image Adjustment	118
User Color	121
4. Advanced Copying	
Adjusting Copy Image Density	127
Auto Image Density	127
Manual Image Density	127
Combined Auto and Manual Image Density	128
Selecting the Original Type	129
Selecting Copy Paper	131

Auto Paper Select	132
Manual Paper Select	133
Advanced Reduce/Enlarge Copying	134
Size Magnification	134
Directional Magnification (%)	135
Directional Size Magnification (inch)	137
Create Margin	139
Stamps	140
Preset Stamp	140
User Stamp	143
Date Stamp	148
Page Numbering	151
Stamp Text	157
Advanced Copier Functions	160
Scan Position	160
Margin Adjustment	161
Erase Center / Border	163
Erase Inside	169
Erase Outside	171
Image Repeat	173
Double Copies	176
Centering	177
Positive/Negative	179
Mirror Image	179
3 Edges Full Bleed	180
Series Copies	181
Booklet/Magazine	183
Creep Adjustment	187
Mix 1 & 2 Sided	188
Covers	190
Designate	192
Chapters	194
Designation Sheet Copy	196

Insert Sheet	197
Slip Sheet	198
5. Document Server	
Relationship between Document Server and Other Functions	201
Document Server Display	202
Simplified Display	203
Preview Display	204
Using the Document Server	206
Storing Data	206
Changing the User Name of a Stored Document	210
Changing the File Name of a Stored Document	211
Changing the Password of a Stored Document	212
Checking the Details of a Stored Document	212
Searching for Stored Documents	213
Printing Stored Documents	215
Editing a Stored Document	220
Deleting a Stored Document	222
Displaying Stored Documents with Web Image Monitor	223
Downloading Stored Documents with Web Image Monitor	223
6. Appendix	
Specifications	225
Function Compatibility	227
Supplementary Information	231
User Tools Menu (Copier/Document Server Features)	241
INDEX	249

How to Read This Manual



- For proper use of this product, be sure to read About This Machine first.
- Supplementary information about the copier mode is described in "Supplementary Information".

Reference

• p.231 "Supplementary Information"

Symbols

This manual uses the following symbols:

Indicates points to pay attention to when using the machine, and explanations of likely causes of paper misfeeds, damage to originals, or loss of data. Be sure to read these explanations.



Indicates supplementary explanations of the machine's functions, and instructions on resolving user errors.

■ Reference

This symbol is located at the end of sections. It indicates where you can find further relevant information.

[]

Indicates the names of keys on the machine's display or control panels.

Names of Major Options

Major options of this machine are referred to as follows in this manual:

- LCIT RT5020 → Wide Large Capacity Tray (Wide LCT)
- Finisher SR5000 → Finisher
- Booklet Finisher BK5000 → Booklet Finisher

Functions Requiring Optional Configurations

Certain functions require special machine configuration and extra options as follows:

Shift Sort: Finisher Stack: Finisher Staple: Finisher

Staple (Center): Finisher and Booklet Finisher

Punch: Finisher and punch unit Z-fold: Finisher and Z-folding unit

Copying onto tab stock: Tab sheet holder

Copying from the bypass tray: Multi bypass tray (Tray 7)




• The tab sheet holder is required when copying onto tab stock from the paper trays.

Display

The function items displayed serve as selector keys. You can select or specify an item by lightly pressing them.

When you select or specify an item on the display panel, it is highlighted like formula. Keys appearing as cannot be used.

Initial copy display



- 1. Use this area to specify the original type, color mode, image density level, and other settings.
- 2. Displays operational status and messages.
- You can register up to two frequently used reduce/enlarge ratios other than the preset ratios under Reproduction Ratio in User Tools. For details, see "Copier/Document Server Features", General Settings Guide.
- 4. Displays the numbers of originals scanned, copies set, and copies made.
- 5. Press the key to confirm the current settings.
- 6. Displays Sort, Stack, Staple, Punch, and Z-fold functions.
- 7. Displays available functions. Press a function to display its menu. A clip mark indicates the currently selected functions.




• The illustration is an example of the panel display when the optional Finisher, the wide large capacity tray (Wide LCT) and the Z-folding unit are installed.

Simplified Display

This section explains how to switch to the simplified display.

When you press the [Simplified Display] key, the screen changes from the initial display to the simplified display.

Letters and keys are displayed at a larger size, making operations easier.



Example of a simplified display



1. [Key Color]

Press to increase screen contrast by changing the color of the keys. This is available only for the simplified display.



- To return to the initial display, press the [Simplified Display] key again.
- Certain keys do not appear on the simplified display.

1. Placing Originals

This chapter describes the types of originals you can set and how to place originals.

Originals

This section describes the types of originals that can be placed, paper sizes that are automatically detected, and missing image area.



As the color of markers or highlighters is difficult to reproduce, the copy might not come out depending
on the color or a different color might be copied.

Sizes and Weights of Recommended Originals

The following describes recommended paper sizes and non-recommended originals for the ADF (Auto Document Feeder):

Metric version

Original location	Original size	Original weight
Exposure glass	Up to A3	-
ADF	One-sided originals: A3 - A5 - A5	52 - 128 g/m ²
	Two-sided originals: A3□ - A5□□	52 - 105 g/m ²
	Thin Paper mode: A3□ - A5□□	40 - 128 g/m ²

Inch version

Original location	Original size	Original weight
Exposure glass	Up to 11 × 17	-
ADF	One-sided originals: $11 \times 17 \square - 5^1/2 \times 8^1/2 \square \square$	14 - 34 lb.
	Two-sided originals: $11 \times 17 \square - 5^1/_2 \times 8^1/_2 \square \square$	14 - 28 lb.
	Thin Paper mode: 11 × 17 - 5 1/2 × 8 1/2 0	10 - 34 lb.



• About 100 originals can be placed in the ADF.

Non-compatible originals for the ADF

Placing unsuitable originals in the ADF can cause paper misfeeds or black lines, or result in damage to the originals.

Place the following types of originals on the exposure glass instead.

- Originals other than those specified on "Sizes and Weights of Recommended Originals"
- Stapled or clipped originals
- Perforated or torn originals
- Curled, folded, or creased originals
- Pasted originals
- Originals with any kind of coating, such as thermal fax paper, art paper, aluminum foil, carbon paper, or conductive paper
- · Originals with perforated lines
- · Originals with indexes, tags, or other projecting parts
- Sticky originals such as translucent paper
- Thin or highly flexible originals
- Thick originals such as postcards
- Bound originals such as books
- Transparent originals such as OHP transparencies or translucent paper
- · Originals that are still wet with ink or correction fluid



• The original might become dirty if it is written with a pencil or a similar tool.

Sizes Detectable with Auto Paper Select

This section describes sizes detectable by the exposure glass and ADF.

Metric version

Size Original location	A3□	B4□	A4 D □	B5 JIS □□	A5D	A5□	B6 JIS □□	11×1 7 □	8 ¹ / ₂ ×11	8 ¹ / ₂ ×13
Exposur e glass	0	0	0	0	0	×	×	×	×	O*1
ADF	0	0	0	0	0	0	0	0	0	O*1

O: Detectable size ×: Undetectable size

*1 Default is $8^1/_2 \times 13$. If you want to switch the detectable size from $8^1/_2 \times 13$ to 8×13 or $8^1/_4 \times 13$, contact your service representative.


Inch version

Size Original location	11×1 7	8 ¹ / ₂ ×14 □	8 ¹ / ₂ ×11 □□		5 ¹ / ₂ ×8 ¹ / ₂ □	2×13	11×1 5	10×1 4	8×10
Exposure glass	0	0	0	0	x	x	×	×	×
ADF	0	0	0	0	0	0	0	0	0

Size Original location	A3₽	B4 JIS	A4 ₽ □	B5 JIS □□
Exposure glass	×	0	×	0
ADF	0	×	0	×

O: Detectable size ×: Undetectable size

Exposure glass



27

ADF

Horizontal size

Maximum scanning area

297 x 432 mm

11 x 17 inches

U Note

• When you copy custom size originals, make sure you specify the size of the originals. If not, the image may not be copied properly. For details about custom size originals, see "Custom sizes".

■ Reference

• p.40 "Custom sizes"

Sizes difficult to detect


It is difficult for the machine to detect the sizes of the following originals, so select the paper size manually:

- · Originals with indexes, tags, or other projecting parts
- Transparent originals such as OHP transparencies or translucent paper
- Dark originals with a lot of text and drawings
- Originals which partially contain a solid image
- Originals which have solid images at their edges

Missing Image Area

Even if you place originals in the ADF or on the exposure glass correctly, margin of a few millimeters on all four sides of the original might not be copied.

1



- 1. 2.0 ± 2.0 mm (0.08 ± 0.08 inch)
- 2. 2.0 ± 2.0 mm (0.08 ± 0.08 inch)
- 3. 2.0 ± 2.0 mm (0.08 ± 0.08 inch)
- 4. 4.0 ± 1.0 mm (0.16 ± 0.04 inch)



• The total missing vertical image area (1+3) is less than 4.0 mm (0.16 inch).

1

Placing Originals

This section describes the procedure for placing originals on the exposure glass and in the ADF.

Take care to place originals after any correction fluid and ink has completely dried. Not taking this precaution could cause marks on the exposure glass that will be copied onto paper.



• For original sizes you can place on the exposure glass and in the ADF, see "Originals".


■ Reference

• p.25 "Originals"

Original Orientation

You can specify the original orientation if necessary.

When using the exposure glass, place the original face down. When using the ADF, place it faces up.



1. ADF

2. Exposure glass


When you cannot place the original as the above, you may not make copies as you want with particular functions. If this happens, change the orientation by selecting the unreadable orientation.

- Select this mode when the original orientation is the same as the copy paper orientation.
 Unreadable orientation


Select this mode when you want to copy A3 $^{\circ}$, B4 JIS $^{\circ}$ or 11 × 17 $^{\circ}$ size originals. The machine rotates the copy image by 90° and you can make copies as you want.

This is useful for copying large originals with the Staple, Duplex, Combine or Stamp functions.


For example, to copy A3D or 11 \times 17D originals with the Staple function selected:



1. Press [Special Original].



2. Select the original orientation, and then press [OK].



31






• It is recommended that you use this function together with the Auto Paper Select or Auto Reduce / Enlarge function.


Reverse Orientation

This function rotates the copy image by 180° (1819 or 1979).

This is useful for copying torn originals. For example, if the left side of the original is damaged and is difficult to set, position it as shown below.



1. Press [Special Original].



2. Press [Reverse Orientation].

3. Select the original orientation, and then press [OK].



- It is recommended that you use this function together with the Auto Paper Select or Auto Reduce / Enlarge function.
- Copy results may differ depending on the combination of selected functions.

Left Original Beeper

The beeper sounds and an error message is displayed when you leave your originals on the exposure glass after copying.

You can change the beeper setting under Alert Sound: Original left on Exposure Glass in User Tools. For details, see "Copier/Document Server Features", General Settings Guide.

Placing Originals on the Exposure Glass

Place originals on the exposure glass.




- Do not lift the ADF forcefully. Otherwise, the cover of the ADF might open or be damaged.
- 1. Lift the ADF.

Be sure to lift the ADF by more than 30 degrees. Otherwise, the size of the original might not be detected correctly.

Place the original face down on the exposure glass. The original should be aligned to the rear left corner.

Start with the first page to be copied.



- 1. Positioning mark
- 2. Scales

3. Lower the ADF.



You can specify the way in which copies are delivered when copying an original placed on the
exposure glass under Copy Eject Face Method in Glass Mode in User Tools. For details, see "Copier/
Document Server Features", General Settings Guide.

Placing Originals in the ADF

Place originals in the ADF.

Be sure not to block the sensor or load the original untidily. Doing so may cause the machine to detect the size of the original incorrectly or display a paper misfeed message. Also, be sure not to place originals or other objects on the top cover. Doing so may cause a malfunction.

Settings should be made in the following situations:

When placing originals consisting of more than 100 pages:

See "Batch Mode".

When placing originals one by one:

See "SADF Mode".

When copying originals of various sizes:

See "Mixed Sizes Mode".

When copying thin paper originals:

See "Thin Mode".


When placing custom size originals:

See "Custom sizes".

- 1. Adjust the document guides to the original size.
- 2. Set the aligned originals face up into the ADF.

Do not stack originals beyond the limit mark.

The first page should be on the top.



- 1. Limit mark
- 2. Document guide



- Straighten curls in the originals before placing them on the ADF.
- To prevent multiple sheets from being fed at once, fan the original before placing it on the ADF.
- Set the original squarely.

■ Reference

- p.35 "Batch Mode"
- p.36 "SADF Mode"
- p.37 "Mixed Sizes Mode"
- p.38 "Thin Mode"
- p.40 "Custom sizes"

Batch Mode


In Batch mode, the machine copies an original of more than 100 pages as one document, even if it is placed on the ADF in parts.



• Place special originals, such as translucent paper, one by one.

٦

1. Press [Special Original].



- 2. Select [Batch] and then press [OK].
- 3. Place the first part of the original, and then press the [Start] key.
- 4. After the first part of the original has been fed, place the next part, then press the [Start] key.




- To copy subsequent originals in this mode, repeat step 4.
- Press the [#] key after all originals have been scanned.

SADF Mode


In SADF mode, even when an original is placed page by page in the ADF, each page is automatically fed when placed.

1. Press [Special Original].



- 2. Press [SADF] and then press [OK].
- 3. Place one page of an original, and then press the [Start] key.
- 4. When the machine instructs you to place another original, place the next page.

 The second and subsequent pages will be fed automatically without pressing the [Start] key.





- Press the [#] key after all originals have been scanned.
- In SADF mode, an original must be set within a specified time after the previous original has been fed.
 You can adjust this time under SADF Auto Reset in User Tools. For details, see "Copier/Document Server Features", General Settings Guide.

Mixed Sizes Mode

When placing different size originals of the same width in the ADF together, the machine automatically checks the size of the originals and makes copies.

• When placing originals of different sizes in the ADF and making copies without using the Mixed Sizes mode, paper might become jammed or parts of the original image might not be copied.

The sizes of the originals that can be placed in this mode are follows:


Metric version

Inch version


$$11 \times 17 \square$$
, $8^{1}/_{2} \times 14 \square$, $8^{1}/_{2} \times 11 \square$

You can place originals of two different sizes at a time.

1. Press [Special Original].



- 2. Select [Mixed Sizes] and then press [OK].
- 3. Align the rear and left edges of the originals as shown in the illustration.



- 1. Place the originals into the ADF
- 2. Vertical size
- 4. Adjust the document guides to the widest original size.
- 5. Place originals in the ADF.
- 6. Press the [Start] key.



• For details about weights of paper that can be used with this mode and other relevant information, see "Supplementary Information".


■ Reference

• p.231 "Supplementary Information"

Thin Mode

When copying thin paper originals, select Thin mode.

1. Press [Special Original].



- 2. Press [Thin Paper] and then press [OK].
- 3. Place the original, and then press the [Start] key.


Specifying Original Sizes

Specify the size of the originals.

Regular sizes


Select the size of the originals from the regular sizes.

1. Press [Special Original].



2. Press [Original Size].

3. Press [Regular Size].




- 4. Select the size of original, and then press [OK] twice.
- 5. Place the originals, and then press the [Start] key.

Custom sizes

When placing custom size originals in the ADF, specify the size of the originals.




- Paper that has a vertical length of 128 297 mm (5.1 11.6 inches) and a horizontal length of 128 432 mm (5.1 17 inches) can be placed with this function.
- 1. Press [Special Original].



- 2. Press [Original Size].
- 3. Press [Custom Size].

4. Enter the horizontal size with the number keys, and then press [#].



- 5. Enter the vertical size with the number keys, and then press [#].
- 6. Press [OK] twice.
- 7. Place the originals, and then press the [Start] key.



• To change the value you entered, press the item you want to change, and then enter a new value.

2. Basic Copying

This chapter describes the basic procedure for making copies.

Basic Procedure

This section describes the basic procedure for making copies.



- When User Code Authentication is set, enter your user code (up to eight digits) with the number keys so that the machine accepts copy jobs. For details about Administrator Tools, see "System Settings", General Settings Guide.
- When Basic Authentication, Windows Authentication, LDAP Authentication, or Integration Server
 Authentication is set, enter your login user name and password so that the machine accepts copy
 jobs. Ask the administrator for the login user name and password. For details, see "When the
 Authentication Screen is Displayed", About This Machine.
- To copy onto paper other than plain paper, specify the paper type under Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
- 1. Make sure "Ready" appears on the screen.

If any other function is displayed, press the [Copy] key on the left side of the control panel.

Initial copy screen



2. Make sure no previous settings remain.

When there are previous settings remaining, press the [Clear Modes] key.

- 3. Place the originals.
- 4. Make desired settings.
- 5. Enter the number of copies with the number keys.

The maximum copy quantity that can be set is 9999.

6. Press the [Start] key.

The machine starts copying.

When placing originals on the exposure glass, press the [#] key after all originals are scanned.

7. When the copy job is finished, press the [Clear Modes] key to clear the settings.




- Always log off when you have finished using the machine to prevent unauthorized users from using the machine.
- To stop the machine during a multi-copy run, press the [Stop] key.
- To cancel all copy functions and return the machine to the default condition, press the [Clear Modes] key.
- To clear entered values, press the [Clear] key or [Cancel] on the screen.
- To confirm settings, press [Check Modes].
- You can change the maximum copy quantity under Max. Copy Quantity in User Tools. For details about Max. Copy Quantity, see "Copier/Document Server Features", General Settings Guide.

Interrupt Copy

Use this function if you want to interrupt a long copy job to make urgently needed copies.

1. Press the [Interrupt] key.



The interrupt key indicator lights. The machine stops scanning.



- 2. Remove the originals that were being copied.
- 3. Place the originals you want to copy.
- 4. Press the [Start] key.

The machine starts making copies.

- 5. When copying is complete, remove the originals and copies.
- 6. Press the [Interrupt] key again.

The interrupt key indicator goes off.

7. Replace the originals that you were copying, and then press the [Start] key. Following the instructions on the display.




 The previous copy job settings are restored. Simply press the [Start] key to continue copying from where it left off.

Copy Face Up


Copies are delivered in opposite order to the default order setting.

1 Sided originals




BAS023S


2 Sided originals



- 1. Face down (same order as original)
- 2. Face up (reverse order of original)
- 1. Press [Output/ Customize Function/ Finisher].



- 2. Press [Output/ Cstmz.].
- 3. Press [Rvrse Ejct: FaceUp/Dn].



4. Place the originals, and then press the [Start] key.



• For details about the default delivery order setting, see "Supplementary Information".



• p.231 "Supplementary Information"

Auto Start

If you make settings and scan originals while the machine is busy, your copies will be made once the machine is ready.

- 1. Make your settings while "Select print mode, then press the Start key." and "Scanning originals can be started." are displayed alternately.
- 2. Place the original.
- 3. Press the [Start] key.

The machine scans the original.


Copying starts automatically once the machine is ready.

Job Preset

You can make settings for the next copy job during copying.

If a long copy job is in progress and you do not want to wait for it to finish, you can use this function to set up the next copy job in advance. When the current copy job is finished, the next job will start automatically.

1. Press [New Job] when "Copying..." appears.



- 2. Be sure message "Ready" appears, and then make settings for the next copy job.
- 3. Place the originals, and then press the [Start] key.

All originals are scanned.

After the current copy job, the next copy job starts automatically.



• Preset copy jobs are registered under job numbers in the Reserv. Screen.


You can confirm and delete preset jobs. For details about the procedures, see "Managing Jobs".

Reference

• p.97 "Managing Jobs"


Copying onto Tab Stock

You can copy onto tab stock.




Mportant (


 Before using this function, set the tray for tab stock and set the position of the index tab under Paper Type in Tray Paper Settings. For details about Paper Type, see "Tray Paper Settings", General Settings Guide.




- 1. Original width
- 2. Index width
- Specify the size of tab stock under Paper Size in Tray Paper Settings. The sizes that can be used are A4, 8¹/₂ × 11, and 8¹/₂ × 14. For details about Tray Paper Size, see "System Settings", General Settings Guide.
- Tab stock can be loaded in Tray 2, the Wide Large Capacity Tray (Wide LCT), and the Multi Bypass
 Tray (Tray 7).
- Set tab stock copy side down in Tray 2.
- Set tab stock copy side up in the Wide Large Capacity Tray (Wide LCT) or the Multi Bypass Tray (Tray 7).
- When setting tab stock, always use the tab sheet holder.



- Set tab stock so that it will be fed from the side without the tab first.
- When loading tab stock in Tray 2, adjust the back fence position so that the tab sheet holder will fit the tab stock.



Tab stock is fed starting from the top tab.



- 1. Originals
- 2. Tab Stock
- 3. Copies

1. Select the paper tray where the tab stock is loaded.



2. Place the originals, and then press the [Start] key.



- Check the position of the index tab to avoid cropping the image.
- Align the image you want to copy by checking the position of the index tab. If the image extends beyond the index tab, the backs of sheets may get soiled with toner.
- To copy onto tab stock from the multi bypass tray, see "Loading Tab Stock in the Multi Bypass Tray (Tray 7)".
- When a paper jam has occurred, check the order of originals and tab stock, and then restart copying.

Reference


• p.59 "Loading Tab Stock in the Multi Bypass Tray (Tray 7)"

Surplus tab stock auto eject

When copying onto tab stock but not using all the tab stock for each copy, remaining sheets of tab stock are automatically ejected.

Before using this function, specify the number of sheets of tab stock (Number of Tabs) in one set. For details, see "Items of Tray Paper Settings", General Settings Guide.

For example, if you use three of five tabs that form a set in a tray and insert slip sheets using the Designate function, the unused 4th and 5th tab sheets are automatically ejected when the first copy is complete.





• If you set [Number of Tabs] to [Off], surplus tab stock sheets for each copy are not ejected.


Copying from the Multi Bypass Tray

The multi bypass tray allows you to copy non-standard paper.

Use the multi bypass tray to copy onto paper that cannot be loaded in the paper trays.


Mportant !

- Paper that has a vertical length of 139.7 330.2 mm (5.5 13 inches) and a horizontal length of 182 - 487.7 mm (7.17 - 19.2 inches) can be copied from the multi bypass tray.
- The machine can automatically detect the following sizes as regular size copy paper:
 - Metric version:
 A3□, B4 JIS□, A4□□, B5 JIS□, A5□, 12 × 18□, 11 × 17□, 8¹/₂ × 11□
 8 × 13□, 5¹/₂ × 8¹/₂□
 - Inch version: 12 × 18□, 11 × 17□, 8¹/₂ × 11□□, 5¹/₂ × 8¹/₂□, 8 × 13□, A3□, B4 JIS□ A4□, B5 JIS□, A5□
- If you want to use the size of paper other than the above, be sure to specify the size.
- The maximum number of sheets you can load at the same time depends on paper type. Load only as much paper as can be held between the paper guides on the multi bypass tray.
- While pinching the release lever, push the side fences out until there is space between them
 and the paper you are loading.
- 2. Place paper face up in the multi bypass tray (Tray 7).




3. Adjust the side fences again to ensure they properly fit the paper size.


4. Set the end fence.



To remove the end fence, slide it to the right by pressing the stopper down.



5. Press the elevator switch on the multi bypass tray (Tray 7).



The green lamp of the elevator switch is blinking while the original table is going up and down, and keeps lit when it stops.


Press the elevator switch to move down the original table if you want to either add paper or remove jammed ones.

- 6. Select the multi bypass tray (Tray 7) on the control panel.
- 7. Press the [#] key.

- 8. Select the size and type of the paper.
- 9. Press [OK].
- 10. Place the originals, and then press the [Start] key.
- 11. When the copy job is finished, press the [Clear Modes] key to clear the settings.



- Load only as much paper as can be held between the guides on the multi bypass tray. Overloading
 the multi bypass tray can result in misfeeds and skewed images.
- To support A4 \square , $8^{1}/_{2} \times 11\square$ or larger paper sizes, pull out the extender.



1. Extender

- To prevent multiple sheets from being fed at once, fan paper before placing it on the tray.
- When the Sort function is selected, press the [#] key after all originals have been scanned.
- When the Panel Key Sound is turned off, it will not sound if you insert paper into the multi bypass tray. For details about Panel Key Sound, see "System Settings", General Settings Guide.
- Printing on special paper such as thick paper may be slower than printing on plain paper.
- If you place originals on the exposure glass and want the copies to be delivered face down, select Face Down for Copy Eject Face Method in Glass Mode.
- For details about Copy Eject Face Method in Glass Mode, see "Copier/Document Server Features", General Settings Guide.
- If you select Tab Stock, you cannot have copies delivered face up.
- If you use paper larger than 458 mm, 18.1 inches in size, you cannot have copies delivered face down.
- Depending on the environment where the machine is being used, you might at times hear a rustling noise from paper moving through the machine. This noise does not indicate a malfunction.
- For standard paper sizes that can be used with the multi bypass tray, see "Supplementary Information".

Reference


• p.106 "Registering the Initial Display's Default Functions"

• p.231 "Supplementary Information"


Copying onto Regular Size Paper

Makes copies onto regular size paper from the multi bypass tray.

- 1. While pinching the release lever, push the side fences out until there is space between them and the paper you are loading.
- 2. Place paper face up in the multi bypass tray (Tray 7), and then set the side fences to the paper size.
- 3. Set the end fence, and then press the elevator switch on the multi bypass tray (Tray 7).
- 4. Select the multi bypass tray (Tray 7) on the control panel.
- 5. Press the [#] key.
- 6. Press [Select Regular Size].



7. Select the paper size.




- 8. Press [OK] twice.
- 9. Place the originals, and then press the [Start] key.


Copying onto Custom Size Paper

Makes copies onto custom size paper from the multi bypass tray.

- 1. While pinching the release lever, push the side fences out until there is space between them and the paper you are loading.
- 2. Place paper face up in the multi bypass tray (Tray 7), and then set the side fences to the paper size.
- 3. Set the end fence, and then press the elevator switch on the multi bypass tray (Tray 7).
- 4. Select the multi bypass tray (Tray 7) on the control panel.
- 5. Press the [#] key.
- 6. Press [Program Custom Size].



7. Enter the horizontal size with the number keys, and then press [#].



- 8. Enter the vertical size with the number keys, and then press [#].
- 9. Press [OK].
- 10. Place the originals, and then press the [Start] key.




• To change the value you entered, press the item you want to change, and then enter a new value.

Registering a custom size

Register a custom paper size.

- 1. Press [Program Custom Size].
- 2. Enter the horizontal size with the number keys, and then press [#].
- 3. Enter the vertical size with the number keys, and then press [#].
- 4. Press [Program].




The confirmation screen appears.

- 5. Press [Exit].
- 6. Press [OK].

Recalling the registered custom size

Recalls the registered paper size.

1. Press [Recall].




The registered size is displayed.

Copying onto Thin Paper

When copying onto thin paper, select the type and size of paper.

1. Select the paper type [Thin Paper] in Special Paper.



- 2. Specify the paper size, and then press [OK].
- 3. Place the originals, and then press the [Start] key.



- Printing on thin paper may be slower than printing on plain paper.
- To prevent multiple sheets from being fed at once, fan paper before placing it on the tray.


Copying onto Thick Paper

When copying onto thick paper, select the type and size of paper.

1. Select the paper type [Thick Paper 1] or [Thick Paper 2] in Special Paper.

Select [Thick Paper 1] when paper weight is between 127.0 g/m 2 (33.8 lb.) and 156.0 g/m 2 (40.4 lb.).

Select [Thick Paper 2] when paper weight is between $157.0 \, \text{g/m}^2$ (41.8 lb.) and $220.0 \, \text{g/m}^2$ (58.5 lb.).



- 2. Specify the paper size, and then press [OK].
- 3. Place the originals, and then press the [Start] key.



- Printing on thick paper may be slower than printing on plain paper.
- To prevent multiple sheets from being fed at once, fan paper before placing it on the tray.


Loading Tab Stock in the Multi Bypass Tray (Tray 7)

Loading tab stock in the multi bypass tray.




· Before using this function, set the tray for tab stock and set the position of the index tab under Paper Type in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.

Tab stock is fed starting from the top tab.




- 1. Originals
- 2. Tab Stock
- 3. Copies
- 1. While pinching the release lever, push the side fences out until there is space between them and the paper you are loading.


2. Set the tab stock face up in the multi bypass tray (Tray 7), and fit the side fences to the tab stock.



3. Attach the back fence to the end fence.



4. Set the end fence.



- 5. Press the elevator switch on the multi bypass tray (Tray 7).
- 6. Select the multi bypass tray (Tray 7) on the control panel.
- 7. Press the [#] key.
- 8. Select the paper size.
- 9. Press [OK] twice.

10. Place originals, and then press the [Start] key.



• For details about how to load tab stock in paper trays, see "Copying onto Tab Stock".


Reference

• p.48 "Copying onto Tab Stock"


Copying onto Envelopes

When copying onto envelopes, specify the paper type and paper size.

- Before using this function, specify the paper thickness under Paper Type in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
- Place envelopes in the multi bypass tray (Tray 7), and then set the side fences to the envelope size.
- 2. Set the end fence.
- 3. Press the elevator switch on the multi bypass tray (Tray 7).
- 4. Select the multi bypass tray (Tray 7) on the control panel.
- 5. Press the [#] key.
- 6. Press [Program Custom Size].




7. Specify the envelope size, and then press [OK].




8. Place the originals, and then press the [Start] key.



- When placing an original on the exposure glass, place the original with the bottom line aligned to the left scale.
- When placing an original in the ADF, place the original with the bottom line inserted in the ADF.
- To load envelopes in the Multi Bypass Tray (Tray 7), place them with the side you want to copy faceup. Be sure to unfold the flaps and position them opposite to the paper feed direction.



• When entering the horizontal size for envelopes, including the opened-out flap in the measurement.



1. Vertical size

2. Horizontal size

- You can load up to 10 envelopes (80 95 g/m², 24 lb.) in the multi bypass tray at the same time, without compressing them. Check the envelopes are not damp. Load only as much envelopes as can be held between the paper guides on the multi bypass tray.
- Check there is no air in the envelopes before loading.
- To get better print quality, it is recommended that you set the right, left, top, and bottom print margin, to at least 15 mm (0.6 inch) each.
- You cannot print envelopes with the Duplex function.
- Load only one size and type of envelope at a time.
- Before loading envelopes, flatten leading edges (the side going into the machine) by pressing a pencil
 or ruler across them.
- Before loading envelopes, check they are rectangular in shape.
- For details about supported envelope types, see "Envelopes", About This Machine.

Copying from the Wide Large Capacity Tray (Wide LCT)

The Wide LCT allows you to copy non-standard paper.

Use the Wide LCT to copy onto adhesive labels, thick paper such as envelopes, and tab stock.

☆ Important

- Special paper such as adhesive labels and thick paper must be loaded in the Wide LCT. Specify the
 paper type in Tray Paper Settings in advance. For details, see "Tray Paper Settings", General Settings
 Guide.
- To copy onto custom size paper, load it in the Wide LCT and specify the size of the paper in Tray
 Paper Settings in advance. For the procedure for specifying the type of paper loaded in the Wide
 LCT, see "Tray Paper Settings", General Settings Guide.
- For the procedure for loading paper in the Wide LCT, see "Changing the Paper Size in the Wide Large Capacity Tray", Troubleshooting.



 If you select Thick Paper 2, Thick Paper 3, Coated Paper 1, Coated Paper 2, or Coated Paper 3 for Paper Type in Tray Paper Settings, air is blown out automatically to fan the paper loaded in the Wide LCT.

Loading Tab Stock in the Wide LCT

Loading tab stock in the Wide LCT.

- When setting tab stock, always use the tab sheet fence.
- Before using this function, set the position of the index tab before copying. For details, see "Copying onto Tab Stock".
- 1. Select the Wide LCT.
- 2. Place the originals, and then press the [Start] key.

U Note

 For the procedure to load tab stock in the Wide LCT, see "Changing the Paper Size in the Wide Large Capacity Tray", Troubleshooting.

Reference


• p.48 "Copying onto Tab Stock"

2

Loading Envelopes in the Wide LCT

Loading envelopes in the Wide LCT.

To load envelopes in the Wide LCT, place them with the side you want to copy face-up. Be sure to unfold the flaps and position them opposite to the paper feed direction.



Before you can use this function, you must specify the size of your envelope in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.

- 1. Select the Wide LCT.
- 2. Place the originals, and then press the [Start] key.



- For the procedure to load envelopes in the Wide LCT, see "Changing the Paper Size in the Wide Large Capacity Tray", Troubleshooting.
- For details about supported envelope types, see "Envelopes", About This Machine.

Reducing or Enlarging Originals

This section describes methods of reducing or enlarging images by specifying a reproduction ratio, or a paper size.

In addition to the functions described in this section, advanced reduce/enlarge copy functions are also available. For details about these functions, see "Advanced Reduce/Enlarge Copying".


Reference

• p.134 "Advanced Reduce/Enlarge Copying"

Preset Reduce/Enlarge


This function allows you to reduce or enlarge images by selecting a preset ratio.

You can register up to two frequently used reproduction ratios other than the preset Reduce/Enlarge ratios.



Base Point

The base point of Reduce/Enlarge differs depending on how the original is scanned. When the original is placed on the exposure glass, the upper left corner will be the base point. When it is placed in the ADF, the upper right corner will be the base point.



1. Base point when placed on the exposure glass


2. Base point when placed in the ADF

1. Press [Reduce / Enlarge].



To select a preset ratio on the initial display, press the shortcut reduce/enlarge key.

2. Select a ratio, and then press [OK].




3. Place the originals, and then press the [Start] key.



 You can change reproduction ratios shown on the initial display under Reproduction Ratio in User Tools. For details about Reproduction Ratio, see "Copier/Document Server Features", General Settings Guide.

Zoom


You can specify the reproduction ratio in increments of 1%.




Specifying the ratio with [-] and [+]

Specify a ratio using [-] and [+].

1. Press [Reduce / Enlarge].



- 2. Select a preset ratio which is close to the desired ratio.
- 3. Adjust the ratio with [-] and [+].



Pressing [—] or [+] changes the ratio in increments of 1%. Pressing and holding down [—] or [+] changes it in increments of 10%.

- 4. Press [OK].
- 5. Place the originals, and then press the [Start] key.



• To change the value you specified, readjust it with [-] and [+].


Entering the ratio with the number keys

Enter a ratio using the number keys.

1. Press [Reduce / Enlarge].



- 2. Press [Number keys].
- 3. Enter the desired ratio with the number keys, and then press [#].




- 4. Press [OK] twice.
- 5. Place the originals, and then press the [Start] key.



• To change the value you entered, press [Change], and then enter a new value.

Auto Reduce/Enlarge

The machine automatically detects the original size and then selects an appropriate reproduction ratio based on the paper size you select.




BAS033S



 If you select a reproduction ratio after pressing [Auto Reduce / Enlarge], [Auto Reduce / Enlarge] is canceled and the image cannot be rotated automatically.

This is useful to copy different size originals to the same size paper.

If the orientation in which your original is placed is different from that of the paper you are copying onto, the machine rotates the original image by 90 degrees and fits it on the copy paper (Rotate Copy). For example, to reduce A3 (11 × 17) \Box originals to fit onto A4 (8 $^1/_2$ × 11) \Box paper, select a paper tray containing A4 (8 $^1/_2$ × 11) \Box paper, and then press [Auto Reduce / Enlarge]. The image is automatically rotated.



For details about Rotate Copy, see "Rotate Copy".

The original sizes and orientations you can use with this function are as follows:

Metric version


Original location	Original size and orientation
Exposure glass	A3C, B4 JISC, A4CC, B5 JISCC, A5C, 8 ¹ / ₂ × 13C

Original location	Original size and orientation
ADF	A3D, B4 JISD, A4DD, B5 JISDD, A5DD, B6 JISDD, 11 $\times 17D$, $8^{1}/_{2} \times 11DD$, $8^{1}/_{2} \times 13D$

Inch version

Original location	Original size and orientation		
Exposure glass	11 × 17 °, 8 1/2 × 14 °, 8 1/2 × 11 °°, 5 1/2 × 8 1/2 °, B4 JIS °, B5 JIS °		
ADF	11 × 17 □, 8 1/2 × 14 □, 8 1/2 × 11 □ □, 5 1/2 × 8 1/2 □ □, 8 × 13 □, 11 × 15 □, 10 × 14 □, 10 × 8 □, A3 □, A4 □ □		

1. Press [Auto Reduce / Enlarge].



- 2. Select the paper size.
- 3. Place the originals, and then press the [Start] key.

■ Reference

• p.132 "Rotate Copy"

Duplex/Combined Copying

This section describes how to make duplex or combined copies.

Duplex


Copies two 1-sided pages or one 2-sided page onto a 2-sided page.



• The paper weight that can be used with this function is $60 - 220 \text{ g/m}^2 (16 - 58.6 \text{ lb.})$.

1 Sided → 2 Sided


Copies two 1-sided pages on one 2-sided page.



BAS034S

2 Sided → 2 Sided


Copies one 2-sided page on one 2-sided page.




Original orientation and completed copies

The resulting copy image will differ according to the orientation in which you place your originals $(\square \text{ or } \square)$.

The table shows the orientation of images on the front and back of copies, not the orientation of delivery.




1. Press [Dup./ Combine/ Series].



2. Make sure that [Duplex] is selected. If [Duplex] is not selected, press [Duplex].

Select [1 Sided → 2 Sided] or [2 Sided → 2 Sided].



To change the original or copy orientation, press [Orientation].

- 4. Press [OK].
- 5. Place the originals, and then press the [Start] key.



- · When placing an original on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set so that the first page is on the top.
- When placing originals on the exposure glass, or in the ADF using Batch mode, press the [#] key after all the originals have been scanned.
- You can specify the margins under Edit in User Tools. For details about Edit, see "Copier/Document Server Features", General Settings Guide.
- For standard paper sizes that can be used with the Duplex function, see "Supplementary Information".


■ Reference

- p.30 "Original Orientation"
- p.74 "Originals and copy orientation"
- p.231 "Supplementary Information"

Originals and copy orientation


You can select the orientation of originals and copies.

• Top to Top




Top to Bottom





- 1. Press [Orientation].
- 2. Select orientation ([Top to Top]/[Top to Bottom]), and then press [OK].





 The default setting is [Top to Top]. You can change the default orientation under Original Orientation in Duplex Mode and Copy Orientation in Duplex Mode in User Tools. For details, see "Copier/ Document Server Features", General Settings Guide.


One-Sided Combine

Combine several pages onto one side of a sheet.

There are six types of One-Sided Combine.

1 Sided 2 Pages → Combine 1 Side


Copies two 1-sided originals to one side of a sheet.



BAS038S


1 Sided 4 Pages → Combine 1 Side

Copies four 1-sided originals to one side of a sheet.




1 Sided 8 Pages → Combine 1 Side

Copies eight 1-sided originals to one side of a sheet.




2 Sided 1 Page → Combine 1 Side

Copies one 2-sided original to one side of a sheet.




2 Sided 2 Pages → Combine 1 Side

Copies two 2-sided originals to one side of a sheet.




2 Sided 4 Pages → Combine 1 Side

Copies four 2-sided originals to one side of a sheet.




Orientation of the original and image position of combine

Portrait (\Box) originals




Landscape (□) originals




Placing originals (originals placed in the ADF)

• Originals read from left to right




• Originals read from top to bottom



1. Press [Dup./ Combine/ Series].



- 2. Press [Combine].
- 3. Select [1 Sided] or [2 Sided] for Original, and then press [Combine 1 Side] for Copy.



- 4. Select the number of originals to combine.
- 5. Select the paper size.
- 6. Press [OK].
- 7. Place the originals, and then press the [Start] key.



- When placing originals on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set the first page on top.
- When placing originals on the exposure glass or in the ADF using the Batch function, press the [#] key after all the originals have been scanned.
- If you selected [2 Sided] for Original, you can change the orientation. See "Originals and copy orientation".
- You can change the initial settings for 1-Sided Combine under Edit in User Tools. For details, see "Copier/Document Server Feature", General Settings Guide.

■ Reference

• p.74 "Originals and copy orientation"


Two-Sided Combine

Combines various pages of originals onto two sides of one sheet.

There are six types of Two-Sided Combine.


1 Sided 4 Pages → Combine 2 Sides

Copies four 1-sided originals to one sheet with two pages per side.



1 Sided 8 Pages → Combine 2 Sides


Copies eight 1-sided originals to one sheet with four pages per side.



- 1. Front
- 2. Back

1 Sided 16 Pages → Combine 2 Sides


Copies 16 1-sided originals to one sheet with eight pages per side.



- 1. Front
- 2. Back


2 Sided 2 Pages → Combine 2 Sides

Copies two 2-sided originals to one sheet with two pages per side.



2 Sided 4 Pages → Combine 2 Sides


Copies four 2-sided originals to one sheet with four pages per side.



- 1. Front
- 2. Back


2 Sided 8 Pages → Combine 2 Sides

Copies eight 2-sided originals to one sheet with eight pages per side.




BAT052S

- 1. Front
- 2. Back
- 1. Press [Dup./ Combine/ Series].



2. Press [Combine].

3. Select [1 Sided] or [2 Sided] for Original, and then press [Combine 2 Sides] for Copy.



- 4. Press [Orientation].
- 5. Select orientation ([Top to Top]/[Top to Bottom]), and then press [OK].
- 6. Select the number of originals to combine.
- 7. Select the paper size.
- 8. Press [OK].
- 9. Place the originals, and then press the [Start] key.



- When placing originals on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set the first page on top.
- When placing originals on the exposure glass, or in the ADF using the Batch function, press the [#] key after all the originals have been scanned.
- You can change the initial settings for 2-Sided Combine under Edit in User Tools. For details, see "Copier/Document Server Features", General Settings Guide.

Finishing

You can sort, staple, punch, and fold your copies.



 Depending on your model and which options are installed on it, some of these functions might not be available. For details, see "Functions Requiring Optional Configurations".

■ Reference

• p.21 "Functions Requiring Optional Configurations"


Sort

The machine assembles copies as sets in sequential order.

Sort/Shift Sort


Copies are assembled as sets in sequential order.

To use Shift Sort, the optional finisher is required. Each time the copies of one set or a job are delivered, the next copy is shifted to separate each set or job.



BAS053S

1. Press [Sort/ Stack].



- 2. Enter the number of copies with the number keys.
- 3. Place the originals.

To confirm the type of finishing, press the [Sample Copy] key.

4. Press the [Start] key.



- When placing an original on the exposure glass, start with the first page to be copied. When placing
 originals in the ADF, set so the first page is on the top.
- When placing originals on the exposure glass, or in the ADF using Batch mode, press the [#] key after all the originals have been scanned.
- You can change the settings for Sort under Input/Output in User Tools. For details, see "Copier/Document Server Features", General Settings Guide.


Sample Copy

Use this function to check the copy settings before making a long copy run.



- This function can be used only when the Sort function is selected.
- 1. Select Sort and any other necessary functions, and then place the originals.
- 2. Press the [Sample Copy] key.

One copy set is delivered as a sample.



One copy set is delivered as a sample.

3. If the sample is acceptable, press [Continue].

The number of copies made is the number specified, minus one for the proof copy.




• If you press [Suspend] after checking the results, return to step 1 to adjust the copy settings as necessary. You can change the settings. However, depending on the combination of functions, you may not be able to change some settings.

Changing the number of sets

You can change the number of copy sets during copying.



- This function can only be used when the Sort function is selected.
- 1. While "Copying..." is displayed, press the [Stop] key.
- 2. Press [Change Quantity].
- 3. Enter the number of copy sets with the number keys, and then press the [#] key.



4. Press [Continue].

Copying starts again.



• The number of sets you can enter in step 3 differs depending on when the [Stop] key is pressed.

When memory is full

If the amount of data of the scanned originals exceeds the capacity of memory, scanning is interrupted.

1. Press the [Start] key.

All scanned pages are copied, and data stored in memory are cleared.


2. Remove the copies, and then continue copying following the instructions on the display.



- The number of pages that can be stored in memory is about 2000 pages of A4 size originals. It depends on the type of originals or memory settings.
- In Sort mode, you can complete scanning and copying by copying the scanned pages stored in memory until it becomes full, and then scanning and copying the remained originals.

Shift tray off in sort/stack


1. Press [Output/ Customize Function/ Finisher].



- 2. Make sure [Output/ Cstmz.] is selected, and then press [Sort/ Stack Shift Tray Off].
- 3. Place originals, and then press the [Start] key.


Insert separation sheet

Use this function to have separation sheets inserted between sets or jobs.




Important

- Before using this function, select the tray for separation sheet under Separation Sheet Tray in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
- 1. Press [Output/ Customize Function/ Finisher].



2. Press [Output/ Cstmz.].

3. Press [Insert Separation Sheet Per 1 set(s)] or [Insert Separation Sheet Per Job].




4. Place the originals, and then press the [Start] key.



When [Per Set] is selected, you can enter the number of sets between which separation sheets are
inserted with the number keys.


Stack

Groups together copies of each page in a multi-page original.



If a finisher is installed, each time the copies of one page are delivered, the next copy is shifted when delivered so you can separate each job by page.

1. Press [Output/ Customize Function/ Finisher].



2. Press [Finisher].


- 3. Press [Stack].
- 4. Press [OK].
- 5. Enter the number of copies with the number keys.
- 6. Place the originals, and then press the [Start] key.



- When placing an original on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set so the first page is on the top.
- When placing originals on the exposure glass, or in the ADF using the Batch mode, press the [#] key after all the originals have been scanned.

Staple

Each copy set can be stapled together.



BAS0565

• If you select staple without having the stapler cartridge for saddle stitch set in the booklet finisher, a paper misfeed might occur. Be sure to set the stapler cartridge.

Original orientation and stapling position


Place all the originals in the ADF in the orientation in which they can be read normally. When placing the original on the exposure glass, keep the same orientation, but set the original facing downwards.

The relationship between the orientation in which you place the original and the staple positions is as follows:

Exposure glass ADF position position RR + RR			Original location		Stapling
Index Top Right 2 Top 2 Left 2 Bottom 1 Slant Top Left 2 Bottom 1 Slan				ADF	position *1
and the state of t	B'R	Top Left 1		R -	R
and the state of t				R -	→ ®R
Hand Booklet Linisher Bayes	R/R	ant		R -	
Booklet Elanguage Parking Park		SIS		R -	→ (R)*2
Hand Booklet Elisible Linisher	Boffom 1	om 1		R -	→ R
Booklet Flishisher		Bott	n	R -	التعنيان ال
Hand and the state of the state	Left 2	ft 2		R -	• R *2
Booklet Finisher		Le	8	[R] -	_
Booklet Finisher	Top 2	p 2		R -	
Booklet Finisher Booklet Finisher		욘	Pa	R -	→ (PR) *2
Booklet Finisher	Right 2	ht 2		R -	R
Booklet Finisher		Rig	Sal	R -	
Booklet Finisher		Right 1	R	R -	→ R
Finisher by R R		Top R	A	R -	R
	Finisher	nter		R -	→ (PR)
	L'B.	Cer		B -	- Po

- BQG028
- * 1 The above table shows staple positioning. The orientation of the paper does not indicate orientation of delivery.
- *2 You cannot staple at this position when copying onto A3 or B4 JIS size paper.
- *3 If you want to staple at this position on A3 or B4 JIS size paper, select unreadable orientation in Original Orientation and then select Top 2.

1. Press [Output/ Customize Function/ Finisher].



- 2. Press [Finisher].
- 3. Select the staple position.
- 4. Press [OK].
- 5. Enter the number of copies with the number keys.
- 6. Place the originals, and then press the [Start] key.



- When placing an original on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set so that the first page is on the top.
- When placing originals on the exposure glass, or in the ADF using Batch mode, press the [#] key after all the originals have been scanned.
- If you specify Staple: Center, you must specify the Magazine function. For details about Magazine, see "Booklet/Magazine".
- You can change the staple positions shown on the initial display under Input/Output in User Tools. For details, see "Copier/Document Server Features", General Settings Guide.
- For details about the number of sheets that can be stapled together, and the number of stapled copies that can be stacked on each tray, see "Supplementary Information".

Reference

- p.183 "Booklet/Magazine"
- p.231 "Supplementary Information"


Punch

You can make punch holes in copies.




• You cannot use the multi bypass tray with this function.

2 holes




3 holes



Original orientation and punch hole position


Place all the originals in the ADF in the orientation in which they can be read normally. When placing the original on the exposure glass, keep the same orientation, but set the original facing downwards.

The relationship between the orientation in which you place the original and the punch hole positions is as follows:



BCU035

1. Press [Output/ Customize Function/ Finisher].




- 2. Press [Finisher].
- 3. Select one of the punch hole positions.
- 4. Enter the number of copies with the number keys.
- 5. Place the originals, and then press the [Start] key.



- When placing an original on the exposure glass, start with the first page to be copied. When placing
 originals in the ADF, set so that the first page is on the top.
- You can change the punch hole positions shown on the initial display under Input/Output in User Tools. You can select 2 hole or 3 hole. For details, see "Copier/Document Server Features", General Settings Guide.

Z-fold

Makes two parallel folds, one of which faces in and the other facing out.



BAS061S




• You cannot use Punch with this function.

Original orientation and Z-fold position


Place all the originals in the ADF in the orientation in which they can be read normally. When placing the original on the exposure glass, keep the same orientation, but set the original facing downwards.

The relationship between the orientation in which you place the original and the Z-fold positions is as follows:



BAT062

1. Select the folding direction.



2. Place the originals, and then press the [Start] key.



- You can specify the fold-back position in 1 mm (0.1 inch) increments under Z-fold Position in User Tools. For details about Z-fold Position, see "Tray Paper Settings", General Settings Guide.
- For details about the standard paper sizes that can be Z-folded, and the number of Z-folded copies that can be stacked on each tray, see "Supplementary Information".

Reference


• p.231 "Supplementary Information"

Using the Z-fold support tray

When using the Z-fold function together with the Staple function, attach the Z-fold support tray to the upper tray or the shift tray of the finisher.

Finisher Shift Tray

Fit the hooks of the Z-fold support tray into the holes in the shift tray.



U Note

Remove the Z-fold support tray when delivering copies to the shift tray without using the Z-fold function.
 If you leave the Z-fold support tray in place, prints are not stacked properly.

2

Storing Data in the Document Server


The Document Server enables you to store documents being read with the copy feature on the hard disk of this machine. Thus you can print them later applying necessary conditions.



- Machine failure can result in data loss. Important data stored on the hard disk should be backed up.
 The manufacturer shall not be responsible for any damage that might result from the loss of data.
- 1. Press [Store File].



2. Enter a file name, user name, or password if necessary.



- 3. Press [OK].
- 4. Place the originals.
- 5. Make the scanning settings for the original.
- 6. Press the [Start] key.

Stores scanned originals in memory and makes one set of copies.



• To stop scanning, press the [Stop] key. To resume a paused scanning job, press [Continue] in the confirmation display. To delete scanned images and cancel the job, press [Stop]. The originals placed in the ADF will be ejected.

- When placing an original on the exposure glass, press the [#] key after all the originals have been scanned.
- Data stored in the Document Server is set to be deleted after three days (72 hours) by the factory
 default. You can specify the period after which the stored data is deleted automatically under Auto
 Delete File in Document Server in User Tools. For details about changing settings, see "System
 Settings", General Settings Guide.
- To check if the document has been stored, press the [Document Server] key.
- If you want to store another document, do so after copying is complete.
- For details about the Document Server, see "Using the Document Server".
- For details about printing stored documents, see "Printing Stored Documents".
- For details about setting user name, file name, and password, see "Storing Data".
- Depending on the security setting, Access Privileges may appear instead of User Name. For details about Access Privileges, consult the administrator.
- For details about how to enter text, see "Entering Text", About This Machine.

Reference

- p.206 "Using the Document Server"
- p.206 "Storing Data"
- p.215 "Printing Stored Documents"

2

Managing Jobs

Jobs printed using Copy, Document Server, or Printer mode are temporarily stored in the machine, and then executed in order. The Job List function allows you to manage these jobs.

For example, you can cancel incorrect job settings or print an urgent document.



- You cannot use the Job List function when Interrupt Copy is active.
- Documents printed using the scanner function is not displayed in the job list.
- You can specify the time interval between print jobs under Time Interval between Printing Jobs in User
 Tools. For details about this setting, see "System Settings", General Settings Guide. To print jobs
 continuously without intervals, press [Start Printing] in the right side of the control screen. [Start Printing]
 appears only when [Job Order] is selected.


Job List Screen

This section explains displays and icons that appear in the Job List screen.

The Job List screen varies depending on whether Job Order is selected with Print Priority for the System Settings. For details about the setting procedure, see "System Settings", General Settings Guide.


When [Job Order] is not selected:

The job list is displayed for each of the functions.



When [Job Order] is selected:

The job list is displayed for all functions in the order of print jobs.




- 1. Switches between job lists for each function.
- 2. Switches between [Current / Waiting Job List] and [Job History].
- 3. Displays reserved job numbers.
- 4. Displays the function used to print jobs.
 - D: Job printed using copy function
 - a: Job printed using printer function
 - D: Job printed using Document Server function
 - : Job printed using DeskTopBinder
 - : Job printed using Web Image Monitor

Checking Jobs in the Job List

You can check the contents of jobs in the job list.

- 1. Press [Job List].
- 2. Select the job whose contents you want to check.
- 3. Press [Details], and then check the contents.




4. Press [Exit].


Changing the Order of Jobs

You can change the order of jobs in the job list.

- 1. Press [Job List].
- 2. Select the job whose order you want to change.
- 3. Press [Change Order].



4. Change the order using [Top], [Previous], or [Next].




5. Press [OK].

Holding Jobs

You can hold jobs that are queued or currently printing.

- 1. Press [Job List].
- 2. Select the job you want to hold.

3. Press [Suspend Printing].



The selected job and the jobs that follow it are suspended. "Suspended" is displayed at the left of the jobs in the job list that are suspended.




- To resume the suspended jobs, press [Resume Printing].
- This function is available only if [Job Order] is specified.

Deleting Jobs

You can delete a job that is queued or currently printing.

- 1. Press [Job List].
- Select the job you want to delete.To delete two or more print jobs, select them.
- 3. Press [Delete Reservation].



4. Press [OK].

Checking the Job History

You can view the history and contents of completed print jobs.

- 1. Press [Job List].
- 2. Press [Job History].

A list of completed print jobs appears.

- 3. Select the job whose contents you want to check.
- 4. Press [Details], and then check the contents.
- 5. Press [Exit].

Registering Frequently Used Functions

You can store frequently used copy job settings in the machine memory and recall them for future use.

You can store up to 25 programs.



- When a specified program is registered as the default, its values become the default settings, which
 are displayed without pressing the [Program] key, when modes are cleared or reset, and after the
 operation switch is turned on. See "Registering the Initial Display's Default Functions".
- Paper settings are stored based on paper size. So if you place more than one paper tray of the same size, the paper tray prioritized under Tray Paper Settings will be selected first. For details, see "Tray Paper Settings", General Settings Guide.
- Programs are not deleted by turning the power off or by pressing the [Clear Modes] key.


Reference

• p. 106 "Registering the Initial Display's Default Functions"


Registering Functions in a Program

You can register functions in a program.

- 1. Edit the copy settings so all functions you want to store in a program are selected.
- 2. Press the [Program] key.




3. Press [Program].



- 4. Press the program number you want to store.
- 5. Enter the program name with the letter keys on the display panel.

You can enter up to 40 characters.



6. Press [OK].

The screen returns to the program screen, showing the program number followed by the program name. The screen returns to the initial copy display after a short time.



• Program numbers with ♦ against them already have settings made for them.

Changing a Stored Program

Changes program settings.

- 1. Check the program settings.
- 2. Specify the contents of a program.
- 3. Press the [Program] key.
- 4. Press [Program].
- 5. Press the program number you want to change.

- 6. Press [Yes].
- 7. Enter the program name.

You can enter up to 40 characters.

8. Press [OK].

The screen returns to the program screen, showing the program number followed by the program name. The screen returns to the initial copy display after a short time.




- To check the contents of a program, recall the program.
- When it is overwritten, the previous program is deleted.

Recalling a Stored Program

Recalls a stored program to make copies using the stored settings.

- 1. Press the [Program] key.
- 2. Press [Recall].



3. Press the program number you want to recall.

The stored settings are displayed.




- Only programs with $\ \ \ \ \$ against them contain a program.

Deleting a Stored Program

Erases the contents of a program.

1. Press the [Program] key.

2. Press [Delete].



- 3. Press the program number you want to delete.
- 4. Press [Yes].

The program is deleted, and the display returns to the initial copy display.


Registering the Initial Display's Default Functions

You can configure the settings of the initial screen so that the default display contains the functions you use most often.

For example: if the default selection is the Duplex function, but the function you use most frequently is 1-sided copying, you can change the default selection to 1-sided copying instead.


The settings you can program as defaults are Color Mode, Paper Tray, Original Type, Density, Special Original, Original Orientation, Cover/Slip Sheet, Edit / Color, Dup./ Combine/ Series, Reduce / Enlarge, Output/ Customize Function/ Finisher, and the number of copies.

- 1. Specify scan settings and any other settings you require on the initial display.
- 2. Press the [Program] key.




bqoo

3. Press [Program as Defaults].



9

4. Press [Program].



5. When a confirmation dialog appears, press [Yes].

The current settings are programmed as defaults. The screen returns to the initial display.



- To restore the factory default settings on the initial display, press [Restore Factory Defaults].
- The default settings can be programmed separately for the normal screen and simplified display screens.

3. Color Copying

This chapter describes how to make color copies and adjust color and image quality.

Color Functions

This section describes functions that are used for color copying.

Selecting a Color Mode

Select a color mode that suits your originals and copying requirements.

For color images, see "What You Can Do with This Machine <Color Functions/Color Adjustments>".

The following three color modes are available:

Auto Color Select

Judges the color of the original automatically, and copies either in full color or black and white.

Full Color

Copies by overlaying yellow, magenta, cyan and black.

Black & White

Copies in black regardless of the color of the original.

1. Select a color mode.



2. Place the originals, and then press the [Start] key.



- To use a user color, you need to register it beforehand. For details, see "User Color".
- When copied using the registered color, the original will be copied lighter than the registered color.
- For examples of what you can do with the color functions, see "What You Can Do with This Machine <Color Functions/Color Adjustments>".

- p.3 "What You Can Do with This Machine <Color Functions/Color Adjustments>"
- p.121 "User Color"

Convert Colors


Copies by changing a certain color in the original to another color.



- Up to four colors can be converted at the same time.
- To use this function, [Full Color] must be selected.
- If any other color mode is selected, you cannot select [Convert Color].
- 1. Press [Full Color].




2. Press [Edit / Color].



3. Press [Color], and then press [Convert Color].

4. Select any one item from [Conversion 1] to [Conversion 4].



- 5. Selects the color to be converted.
- 6. Selects the new color.

You can adjust the density of the color in four steps.

To select user color, press [User Color], and then select the color.

To change more than two colors, repeat steps 4 to 6.

- 7. After selecting all colors to be converted, press [OK] three times.
- 8. Place the originals, and then press the [Start] key.



- The width of the color to be converted can be adjusted in five levels. When the width of the color is set to [Wider] under Color Sensitivity in User Tools and red has been specified, colors close to orange and purple will be converted. You can change the setting. For details about Color Sensitivity, see "Copier/Document Server Features", General Settings Guide.
- To change the converted color, press from [Conversion 1] to [Conversion 4], and then make the selection again.
- The full color counter will advance by "1".
- For examples of what you can do with the color functions, see "What You Can Do with This Machine <Color Functions/Color Adjustments>".

Reference


• p.3 "What You Can Do with This Machine < Color Functions/Color Adjustments>"

Erase Color

Copies by erasing a certain color in the image of the original.

1. Select a color mode.

2. Press [Edit / Color].



- 3. Press [Color], and then press [Erase Color].
- 4. Select the color to be erased.



Up to four colors can be erased at the same time.

- 5. After selecting all colors to be erased, press [OK] twice.
- 6. Place the originals, and then press the [Start] key.



- The width of the color to be converted can be adjusted in five levels. When the width of the color is set to [Wider] under Color Sensitivity in User Tools and red has been specified, colors close to orange and purple will be converted. You can change the setting. For details about Color Sensitivity, see "Copier/Document Server Features", General Settings Guide.
- To cancel the selection, press the selected (highlighted) key.
- When the Full Color Copy is selected, the full color counter will advance by "1". When the Black & White is selected, the mono-color counter will advance by "1".
- For examples of what you can do with the color functions, see "What You Can Do with This Machine <Color Functions/Color Adjustments>".

Reference


• p.3 "What You Can Do with This Machine <Color Functions/Color Adjustments>"

Color Background

Copies by adding a color in the whole page.



- Since the Color Background function overprints the entire original, the color of the image may change.
- 1. Select a color mode.
- 2. Press [Edit / Color].



- 3. Press [Color], and then press [Color Background].
- 4. Select the background color, and then press [OK] twice.



You can adjust the density of the color in four steps.

To select user color, press [User Color], and then select the color.

5. Place the originals, and then press the [Start] key.



- To cancel the selection, press the selected (highlighted) key.
- When the Full Color is selected, the full color counter will advance by "1". When the Black & White is selected, the mono-color counter will advance by "1".

Adjusting Color and Image Quality

This section describes how to adjust color balance and image quality. Also explains how to register user colors.

Color Balance

Adjusts the overall color tone when the copy is reddish or bluish.

1. Press [Edit / Color].



- 2. Press [Color], and then press [Adjust Color].
- 3. Press [Color Balance].
- 4. Adjust the color balance by pressing [Lighter] or [Darker].



5. Press [OK] twice.



- The adjusted settings will be deleted and the initial values will be reset, when Auto Clear has been performed, when the [Clear Modes] key has been pressed or when the power has been turned off.
- For explanations about and examples of what you can do with the color adjustment function, see
 "What You Can Do with This Machine <Color Functions/Color Adjustments>".





• p.3 "What You Can Do with This Machine < Color Functions/Color Adjustments>"

Color Balance Program

You can store the color balance setting as a color balance program and recall it when you want to use it. You can store up to three programs.




If you want to change the registered settings, register them one more time. In this case, the previously
registered settings will be overwritten.

Registering the adjusted color balance

Register adjusted color balance settings so that you can use them later.

- 1. Press [Edit / Color].
- 2. Press [Color], and then press [Adjust Color].
- 3. Adjust the color balance.
- 4. Press [Program Color Balance].



- 5. Press [Program].
- 6. Select a program number (1-3).

The color balance setting will be registered in the selected number.

7. Press [OK] twice.



- If you select the program number key where \circ is displayed, the previously registered settings will be overwritten.
- For details about how to adjust the color balance, see "Color Balance".



• p.114 "Color Balance"

Changing the color balance

Changes the settings stored in color balance programs.

- 1. Press [Edit / Color].
- 2. Press [Color], and then press [Adjust Color].
- 3. Press [Color Balance], and then press [Program Color Balance].



4. Select the program number (1-3) to be changed.

The programmed color balance appears.

- 5. Change the registered settings.
- 6. Press [Program Color Balance].
- 7. Press [Program], and then press the program number to be overwritten.
- 8. Press [Yes].

The program is overwritten.

9. Press [OK] twice.

Recalling the color balance

Applies settings registered in color balance programs to the copy job.

- 1. Press [Edit / Color].
- 2. Press [Color], and then press [Adjust Color].
- 3. Press [Color Balance], and then press [Program Color Balance].
- 4. Select the program number you want to use.
- 5. Press [OK] twice.





• The adjusted settings will be deleted and the initial values will be reset, when Auto Clear has been performed, when the [Clear Modes] key has been pressed, or when the power has been turned off.

Deleting the color balance

Deletes the settings stored in color balance programs.

- 1. Press [Edit / Color].
- 2. Press [Color], and then press [Adjust Color].
- 3. Press [Color Balance], and then press [Program Color Balance].
- 4. Press [Delete], and then select the program number you want to delete.
- 5. Press [Yes].
- 6. Press [OK] twice.


Color Adjustment

Adjusts the specific colors (yellow, red, magenta, blue, cyan and green) by mixing them with adjacent colors in the color circle.

You can adjust up to three colors from yellow, red, magenta, blue, cyan, or green.




- This function is not available if Black & White is selected.
- 1. Press [Edit / Color].



- 2. Press [Color], and then press [Adjust Color].
- 3. Press [Adjust Color].
- 4. Select the colors you want to adjust.

You can select up to three colors.



- 5. Adjust the color tastes using [←] or [→].
- 6. Press [OK] twice.



- The adjusted settings will be deleted and the initial values will be reset, when Auto Clear has been performed, when the [Clear Modes] key has been pressed or when the power has been turned off.
- For explanations about and examples of what you can do with the color adjustment function, see "What You Can Do with This Machine <Color Functions/Color Adjustments>".

Reference

• p.3 "What You Can Do with This Machine <Color Functions/Color Adjustments>"

Image Adjustment

Adjusts image qualities.

The following five types of image adjustments are available:

Sharp/Soft

Adjusts the outline of an image.

Contrast

Adjusts the shades of an image.

Background Density

Adjusts the background density of an image.

Adjust U.C.R.


Adjusts the amount of black toner to express vividly the black areas in an image.

Text/Photo Sensitivity

Adjusts the standard level in judging the image in the text and photo part when using "Text / Photo".



1. Press [Edit / Color].



- 2. Press [Color], and then press [Adjust Color].
- 3. Press [Copy Quality].
- 4. Adjust the settings.
- 5. Press [OK] twice.



- [Sharp / Soft], [Contrast], and [Background Density] can each be adjusted, however, their
 adjustments can affect the level of other adjustment functions.
- The adjusted settings will be deleted and the initial values will be reset, when Auto Clear has been
 performed, when the [Clear Modes] key has been pressed or when the power has been turned off.
- For types and examples of the image adjustment functions, see "What You Can Do with This Machine <Color Functions/Color Adjustments>".


Reference

• p.3 "What You Can Do with This Machine < Color Functions/Color Adjustments>"

Sharp / Soft

Adjusts the outline of an image.

1. Adjust the image quality by pressing [Soft] or [Sharp].




2. Press [OK].

Contrast

Adjusts the shades of an image.

1. Adjust the image quality by pressing [Low] or [High].




2. Press [OK].

Background Density

Adjusts the background density of an image.

1. Adjust the image quality by pressing [Lighter] or [Darker].



2. Press [OK].



- Adjustments should be made lighter when copying dark textured originals, such as newspaper or recycled paper.
- Adjustments should be made darker when darkening the color of markers or highlighters. However, as the color of highlighters is difficult to reproduce, the copy might not come out depending on the color or a different color might be copied.

Adjust U.C.R.

Adjusts the amount of black toner to express vividly the black areas in an image.

1. Adjust the image quality by pressing [Lighter] or [Darker].




2. Press [OK].

Text / Photo Sensitivity

Adjusts the standard level in judging the image in the text and photo part when using "Text / Photo".

1. Adjust the image quality by pressing [Text] or [Photo].



2. Press [OK].



• Specify the original type to Text when parts of the texts are faded or are not clear. Set it to Photo when the outline of photos becomes dark.

User Color

You can register user colors made by adjusting the density of yellow, magenta, cyan, and black. You can also name the colors you register, and print out a list of user colors.

You can create colors by:

- Adjusting the density of primary colors based on a chosen basic color.
- Directly specifying the density of primary colors using the number keys.



- When copying using user colors, the fine shades might vary depending on the condition of the machine.
- In order to correctly reproduce originals, the values, which have been input, are corrected inside the machine, and copies are made using the best suitable values. Therefore, there might be slight color differences when copying using Text and when using Photo.
- Up to 15 colors can be registered.
- Sample prints of user colors can be made on an A4D, $8^{1}/_{2} \times 11D$, A3D, or $11 \times 17D$ size paper.
- When printing a list of user colors, the full color counter will advance by "1".
- For explanations about and examples of what you can do with the color adjustment function, see
 "What You Can Do with This Machine <Color Functions/Color Adjustments>".


Reference

• p.3 "What You Can Do with This Machine < Color Functions/Color Adjustments>"

Adjusting colors based on the selected color


Creates colors by adjusting the density of primary colors based on a chosen basic color.

1. Press [Edit / Color].




- 2. Press [Color], and then press [User Color].
- 3. Press [Program], and then select the number (01-15) for the color you want to register.
- 4. Select the color to be used as base color from the basic and user colors.

The density of primary colors for the selected color is displayed.



To select user color, press [User Color], and then select the color.

5. Select the color whose density is to be specified, and then specify the density in percentages using [+] or [-].



You can also specify the density by pressing [Adjust with Number Keys].

- 6. Check the settings, and then press [OK].
- 7. Press [OK] twice.




 Selecting a user color key that is indicated by a solid line will change (overwrite) the contents of that color.

Creating colors by specifying the density of primary colors with number keys


Creates colors by directly specifying the density of primary colors using the number keys.

- 1. Press [Edit / Color].
- 2. Press [Color], and then press [User Color].
- 3. Press [Program], and then select the number (01-15) for the color you want to register.

4. Press [Custom Setting].



- 5. Select the color whose density is to be specified.
- 6. Enter the density using the number keys, and then press [#].



Repeat steps 5-6 if you want to specify the density of multiple colors.

You can also specify the density by pressing [Adjust with [+] [-]].

- 7. Check the settings, and then press [OK].
- 8. Press [OK] twice.



• Selecting a user color key that is indicated by a solid line will change (overwrite) the contents of that color.

Changing the user color name

Changes the user color.

- 1. Press [Edit / Color].
- 2. Press [Color], and then press [User Color].
- 3. Press [Program], and then select the number (01-15) for the color you want to rename.
- 4. Select the color you want to rename.
- 5. Press [Change Name].

- 6. Enter the name of the color (up to 16 characters), and then press [OK].
- 7. Press [OK] three times.

Deleting user colors

Deletes user colors.




- You can not delete colors registered in the program or user colors that are currently being used.
- 1. Press [Edit / Color].
- 2. Press [Color], and then press [User Color].
- 3. Press [Delete].
- 4. Select the number of the user color you want to delete.
- 5. Press [Yes].
- 6. Press [OK] twice.

Printing a list of user colors

Prints a list of user colors.

- 1. Press [Edit / Color].
- 2. Press [Color], and then press [User Color].
- 3. Check the copy paper, and then press [Print Sample of User Color].



The list of user colors is output.



• The list will be copied on a A4D, $8^1/_2 \times 11D$, A3D, or $11 \times 17D$ sheet.

4. Advanced Copying

This chapter describes the procedure for making copies in various modes.

Adjusting Copy Image Density

There are three types of adjustment available.

Auto image density

The machine automatically adjusts the image density by scanning the densities of originals. Dark texture originals (such as newspaper or recycled paper) will be copied so that background will not be reproduced.

Manual image density

You can adjust the density of the overall original in nine steps.

Combined auto and manual image density


Adjusts the density of an image only for dark texture originals.

Auto Image Density

The machine automatically adjusts the image density by scanning the densities of originals. Dark texture originals (such as newspaper or recycled paper) will be copied so that background will not be reproduced.


1. Make sure that [Auto Density] is selected.

If [Auto Density] is not selected, press [Auto Density].



Manual Image Density

You can adjust the density of the overall original in nine steps.




2. Press [◀] or [▶] to adjust the image density. The density indicator "▽" moves.

Combined Auto and Manual Image Density

Adjusts the density of an image only for dark texture originals.

Make sure [Auto Density] is selected.
 If [Auto Density] is not selected, press [Auto Density].



2. Press [◀] or [▶] to adjust the density. The density indicator "▽" moves.

Selecting the Original Type

Select an original type that is suitable for your originals.

There are eight original types available:

Text

For originals that contain mainly text or printed characters.

Photo

For Photographs or pictures.

- Glossy Photo: Use when copying developed photographs
- Printed Photo: Use when copying photographs or pictures that are printed on paper (e.g. magazines)
- Copied Photo: Use when copying copies or originals generated by color copiers

Text/Photo

For originals that contain both text and photographs or pictures.

Generation Copy

For originals that are copied. The copy image can be reproduced sharply and clearly.

Pale

For originals that have lighter lines written in pencil, or faintly copied slips.

Map

For map originals.


Highlight Pen

For originals marked with a highlighter pen.


Inkjet Output

For originals that are printed by inkjet. Specify the color balance that is closest to that of the original. There are three settings available.

1. Select the original type.



• To select [Generation Copy], [Pale], [Map], [Highlight Pen], or [Inkjet Output], select [Others] first.



- You can change the settings for original types shown on the initial display under General Features in User Tools. For details, see "Copier/Document Server Features", General Settings Guide.
- You can select whether or not to display the keys for the original on the initial display under Original
 Type Display in User Tools. For details about Original Type Display, see "Copier/Document Server
 Features", General Settings Guide.

Selecting Copy Paper

Select paper you want to copy onto.

There are two ways to select copy paper:

Auto Paper Select

The machine selects a suitable size of copy paper automatically based on the detected original size and the reproduction ratio you select.

Manual Paper Select

Select the tray containing the paper you want to copy onto: a paper tray, the multi bypass tray or the Wide LCT.

See the following table for original sizes and orientations that can be used with Auto Paper Select (when copying at a ratio of 100%):

Metric version

Original location	Original size and orientation				
Exposure glass	A3 ⁻ , B4 JIS ⁻ , A4 ⁻ , B5 JIS ⁻ , A5 ⁻ , 8 ¹ / ₂ × 13 ⁻				
ADF	A30, B4 JISO, A400, B5 JISOO, A500, B6 JISOO, 11 × 170, 8 ¹ / ₂ × 1100, 8 ¹ / ₂ × 130				

Inch version

Original location	Original size and orientation			
Exposure glass	11×17□, 8¹/ ₂ × 14□, 8¹/ ₂ × 11□□, 5¹/ ₂ × 8¹/ ₂ □, B4 JIS□, B5 JIS□□			
ADF	$11 \times 17^{\square}$, $8^{1}/_{2} \times 14^{\square}$, $8^{1}/_{2} \times 11^{\square}$, $5^{1}/_{2} \times 8^{1}/_{2}$, $8 \times 13^{\square}$, $11 \times 15^{\square}$, $10 \times 14^{\square}$, $10 \times 8^{\square}$, A3 $^{\square}$, A4 $^{\square}$			



 Only the paper trays set to [No Display] or [Recycled Paper] in Paper Type and also set to [Yes] in Apply Auto Paper Select under Tray Paper Settings can be selected in Auto Paper Select mode. For details, see "Tray Paper Settings", General Settings Guide.

Reference

• p.28 "Sizes difficult to detect"

Auto Paper Select

The machine selects a suitable size of copy paper automatically based on the detected original size and the reproduction ratio you select.


1. Make sure that [Auto Paper Select] is selected.

Trays with a key mark (will not be automatically selected.



Rotate Copy

If the orientation in which your original is placed is different from that of the paper you are copying onto, the machine rotates the original image by 90° to fit it on the paper.



You cannot use Rotate Copy when enlarging onto A3, B4 JIS or 11 × 17, $8^1/_2$ × 14 size paper. In this case, place your original in the \square orientation.

	Original size and orientation			Copy paper size and orientation	
You cannot rotate:	$8^{1}/_{2} \times 11$, or $5^{1}/_{2} \times 8$	BATOSES	When enlarging to →	$8^{1}/_{2} \times 14$, or 11×17	BATOS3S

	Original size and orientation			Copy paper size and orientation	
However, you can use:	$8^{1}/_{2} \times 11$, or $5^{1}/_{2} \times 8$ $1/_{2}$	R	When enlarging to →	$8^{1}/_{2} \times 14$, or 11×17	R



- This function works when Auto Paper Select or Auto Reduce / Enlarge is selected. See "Auto Paper Select" and "Auto Reduce/Enlarge".
- The default setting for Auto Tray Switching is [On]. You cannot use the Rotate Copy if this setting is changed to [Off]. For details about Auto Tray Switching, see "Copier/Document Server Features", General Settings Guide.
- Depending on the settings for the Punch, Staple or Z-fold functions, you may not be able to use the Rotated Copy function.

Reference


- p.69 "Auto Reduce/Enlarge"
- p.88 "Staple"
- p.90 "Punch"
- p.93 "Z-fold"
- p.132 "Auto Paper Select"

Manual Paper Select

Select the tray containing the paper you want to copy onto: a paper tray, the multi bypass tray or the wide large capacity tray (Wide LCT).

1. Select the tray you want to use.

The indicator corresponding to the selected paper tray is highlighted.



Advanced Reduce/Enlarge Copying

This section describes the advanced functions for reducing or enlarging images.


For details about the basic reduce/enlarge copy functions, see "Reducing or Enlarging Images".



• p.66 "Reducing or Enlarging Originals"


Size Magnification

This function calculates a reproduction ratio based on the lengths of the original and copy.



Measure and specify the lengths of the original and copy by comparing "A" with "a".


1. Press [Reduce / Enlarge].



2. Press [Size Magnification].



3. Enter the length of the original with the number keys, and then press [#].



You can enter sizes between 1 to 999 mm (0.1 to 99.9 inches) in increments of 1 mm (0.1 inch).

- 4. Enter the length of the copy with the number keys, and then press [#].
- 5. Press [OK] twice.




• To change the value you entered, press the key you want to change, and then enter a new value.

Directional Magnification (%)

Specify the horizontal and vertical reproduction ratios, individually.

Copies can be reduced or enlarged at different reproduction ratios horizontally and vertically.




a: Horizontal ratio


b: Vertical ratio

Specifying the ratio with [-] and [+]

Specify a ratio using [-] and [+].



- 2. Press [Direct. Mag. %].
- 3. Press [[+] [-] keys].
- 4. Press [Horizontal].
- 5. Adjust the ratio using [-] and [+].



Pressing [—] or [+] changes the ratio in increments of 1%. Pressing and holding down [—] or [+] changes it in increments of 10%.

- 6. Press [Vertical].
- 7. Adjust the ratio with [-] and [+].
- 8. Press [OK] twice.




• To change the value you entered, readjust it with [-] and [+].

Entering the ratio with the number keys


Enter a ratio using the number keys.



1. Press [Reduce / Enlarge].



- 2. Press [Direct. Mag. %].
- 3. Press [Horizontal].



- 4. Enter the desired ratio with the number keys, and then press [#].
- 5. Press [Vertical].
- 6. Enter the desired ratio with the number keys, and then press [#].
- 7. Press [OK] twice.
- 8. Place the originals, and then press the [Start] key.




• To change the value you entered, press the key you want to change, and then enter a new value.

Directional Size Magnification (inch)

Specify the horizontal and vertical lengths of the original and copy image.

Copies can be reduced or enlarged at different reproduction ratios horizontally and vertically.




- 1. Horizontal original size: A mm (inch)
- 2. Vertical original size: B mm (inch)
- 3. Horizontal copy size: a mm (inch)
- 4. Vertical copy size: b mm (inch)

Measure and specify the lengths of the original and copy by comparing "A" with "a" and "B" with "b".

1. Press [Reduce / Enlarge].



- 2. Press [Dir. Size Mag. Inch].
- 3. Enter the horizontal size of the original with the number keys, and then press [#].



You can enter sizes between 1 to 999 mm (0.1 to 99.9 inches) in increments of 1 mm (0.1 inch).

4. Enter the horizontal size of the copy with the number keys, and then press [#].

- 5. Enter the vertical size of the original with the number keys, and then press [#].
- 6. Enter the vertical size of the copy with the number keys, and then press [#].
- 7. Press [OK] twice.




• To change the value you entered, press the key you want to change, and then enter a new value.

Create Margin

Reduces the image to 93% of its original size and places the reduced image at the center. By combining it with the Reduce/Enlarge functions, you can further increase a margin.

1. Press [Create Margin].



2. Select the reproduction ratio, if necessary.



• You can change the ratio for Create Margin under Reproduction Ratio in User Tools. For details about Reproduction Ratio, see "Copier/Document Server Features", General Settings Guide.


Stamps

Copies with the date, page numbers, etc.

The stamp color can be yellow, red, cyan, magenta, green, blue, and black.

Preset Stamp

Messages are stamped on copies.




• Only one message can be stamped at a time.

The following eight messages are available for Preset Stamp:

"COPY", "URGENT", "PRIORITY", "For Your Info.", "PRELIMINARY", "For Internal Use Only", "CONFIDENTIAL", "DRAFT"

Stamp position and original orientation

The stamp positions differ according to the orientation in which you place the originals.



BAT072S

1. Press [Stamp].




2. Press [Preset Stamp].

3. Select the desired message.

You can change the color, position, size, and density of the stamp.

4. Press [All Pages] or [1st Page Only] to select the print page.



- 5. After making all settings, press [OK].
- 6. Press [OK].



- When the Full Color is selected, the full color counter will advance by "1".
- The default stamp color is black.
- You can change the settings for Preset Stamp under Stamp in User Tools. Depending on the setting, density may change. For details about Stamp, see "Copier/Document Server Features", General Settings Guide.

■ Reference

• p.30 "Original Orientation"

Changing the stamp color

Changes the stamp color.


- 1. Press [Stamp Color] under Stamp Color.
- 2. Select the stamp color, and then press [OK].

Changing the stamp position, size and density

Changes the stamp position, size and density.

1. Press [Change] under Position / Size / Density.


2. Select the stamp position, size, and density, and then press [OK].



User Stamp

Copies a scanned image as a stamp.

Letters or images you use frequently can be registered.




€ Important

- You have to register a user stamp before using this function.
- Only one message can be stamped each time.


Stamp position and original orientation

The user stamp positions differ according to the orientation in which you place the originals.



BAT074S


1. Press [Stamp].



- 2. Press [User Stamp].
- 3. Select the stamp you require.

You can change the stamp color and position.

4. Press [All Pages] or [1st Page Only] to select the print page.



- 5. After making all settings, press [OK].
- 6. Press [OK].



- When the Full Color is selected, the full color counter will advance by "1".
- The default user stamp color is black.
- You can change the settings for User Stamp under Stamp in User Tools. For details about Stamp, see "Copier/Document Server Features", General Settings Guide.

■ Reference

- p.30 "Original Orientation"
- p.146 "Registering the user stamp"

Changing the user stamp color


Changes the stamp color.

- 1. Press [Stamp Color] under Stamp Color.
- 2. Select the stamp color, and then press [OK].

Changing the user stamp position

Changes the stamp position.

1. Press [Change] under Stamp Position.




Registering the user stamp


Scans an image that is used as a user stamp.

The range of stamp images is 10 - 297 mm (0.4 - 11.7 inches) high and 10 - 432 mm (0.4 - 17.0 inches) wide. However, if the value exceeds the maximum value of the area (5,000 mm², 7.75 inch²), it is corrected within the range of the area automatically.


Up to five frequently used images can be stored in memory.



- 1. Base point
- 2. Exposure glass
- 1. Press the [User Tools] key.



2. Press [Copier / Document Server Features].



- 3. Press [Stamp].
- 4. Press [User Stamp].
- 5. Press [Program / Delete Stamp].
- 6. Press [Program], and then press the stamp number you want to program.
- 7. Enter the user stamp name (up to ten characters) with the letter keys, and then press [OK].
- 8. Enter the horizontal size of the stamp with the number keys, and then press [#].
- 9. Enter the vertical size of the stamp with the number keys, and then press [#].
- 10. Place the original for user stamp on the exposure glass, and then press [Start Scanning]. The original will be scanned, and the stamp will be registered.
- 11. Press [Exit].
- 12. Press [Exit].

The display returns to the User Tools/Inquiry screen.

13. Press [Exit].

Exits settings and gets ready to copy.




- Stamp numbers with $\stackrel{•}{\Rightarrow}$ already have settings in them. Stamp numbers that are not registered yet are marked with "Not Programmed".
- If the stamp number is already being used, the machine will ask you if you want to overwrite it. Press [Yes] or [Stop].
- You cannot restore the overwritten stamp.
- Originals cannot be scanned from the ADF when programming the user stamp.
- For details about how to enter text, see "Entering Text", About This Machine.

Deleting the user stamp

Deletes an image registered as a user stamp.

You cannot restore a deleted stamp.

1. Press the [User Tools] key.



BOGOO

2. Press [Copier / Document Server Features].



- 3. Press [Stamp].
- 4. Press [User Stamp].
- 5. Press [Program / Delete Stamp].
- 6. Press [Delete], and then press the stamp number you want to delete.
- 7. Select [Yes], and then press [Exit].
- 8. Press [Exit].


The display returns to the User Tools/Inquiry screen.

9. Press [Exit].

Exits settings and gets ready to copy.

Date Stamp

Use this function to print dates on your copies.




You can select from the following styles:


- MM/DD/YYYY
- MM.DD.YYYY
- DD/MM/YYYY
- DD.MM.YYYY
- YYYY.MM.DD

Stamp position and original orientation

The date stamp positions differ according to the orientation in which you place the originals.



BAT077S



- 2. Press [Date Stamp].
- 3. Select the stamp format.

You can change the color, style and position of the date.

4. Press [All Pages] or [1st Page Only] to select the print page.



- 5. After making all settings, press [OK].
- 6. Press [OK].



- The default color is Black.
- You can change the settings for Date Stamp under Stamp in User Tools. For details about Stamp, see "Copier/Document Server Features", General Settings Guide.

Reference

• p.30 "Original Orientation"

Changing the date stamp color


Changes the stamp color.

- 1. Press [Stamp Color] under Stamp Color.
- 2. Select the stamp color, and then press [OK].

Changing the format of date

Changes the format of date.


- 1. Press [Change Format] under Current Date.
- 2. Select the date format, and then press [OK].



Changing the date stamp position


Changes the stamp position.

- 1. Press [Change] under Stamp Position.
- 2. Select the stamp position, and then press [OK].



Page Numbering

Use this function to print page numbers on your copies.




There are six types of page numbering.

- P1,P2...
- 1/5,2/5...
- -1-,-2-...
- P.1,P.2...
- 1, 2...
- 1-1,1-2...


Stamp position and original orientation

The page stamp positions differ according to the orientation in which you place the originals.




BAT079S

1. Press [Stamp].



- 2. Press [Page Numbering].
- 3. Select the page numbering format.



You can change the stamp color, position, pages to be stamped, and numbering.

- 4. After making all settings, press [OK].
- 5. Press [OK].



- The default color is black.
- You can change the settings for Page Numbering under Stamp in User Tools. For details about Stamp,
 see "Copier/Document Server Features", General Settings Guide.
- You can change the stamp position if Combine or Duplex is specified for use with this function under Duplex Back Page Stamping Position or Page Numbering in Combine in User Tools. For details about these settings, see "Copier/Document Server Features", General Settings Guide.

Changing the stamp color


Changes the stamp color.

- 1. Press [Stamp Color] under Stamp Color.
- 2. Select the stamp color, and then press [OK].

Changing the stamp position

Changes the stamp position.


- 1. Press [Change] under Stamp Position.
- 2. Select the stamp position, and then press [OK].



Specifying the first printing page and start number ("P1,P2...", "-1-,-2-...", "P.1,P.2...", "1,2...")

Specify the first printing page and start number.


The example below shows when the first printing page is "2" and the start number is "3".



In the following procedure, "P1, P2..." is selected, but the procedure is the same regardless of the format you select.

1. Press [Change] under Change Numbering.

Press [First Printing Page], enter the original sheet number from which to start printing, and then press [#].



- 3. Press [First Printing Number], enter the number of page from which to start numbering with the number keys, and then press [#].
- 4. Press [Last Number], enter the number of the page at which to stop numbering with the number keys, and then press [#].

If you want to number all pages to the end, press [to the End].

To change the number entered, press [Clear] and then enter a new number.

- 5. After making all settings, press [OK].
- 6. Press [OK] twice.



- The last number is the last page number to print. For example, if Total Pages is ten, when you want to print up to seven pages and do not want to print from page 8 on, enter "7" for Last Number. Normally, you do not need to enter the number.
- You can set a value from 1 to 9999 for [First Printing Page], [First Printing Number], and [Last Number].

Specifying the first printing page and start number ("1/5,2/5...")

Specify the first printing page and start number.

1. Press [Change] under Change Numbering.



- 3. Press [First Printing Number], enter the number of page from which to start numbering with the number keys, and then press [#].
- 4. Press [Last Number], enter the number of page at which to stop numbering with the number keys, and then press [#].

If you want to number all pages to the end, press [to the End].

5. Press [Total Pages], enter the total number of original pages with the number keys, and then press [#].

To change the number entered, press [Clear] and then enter a new number.

- 6. After making all settings, press [OK].
- 7. Press [OK] twice.



- The last number is the last page number to print. For example, if Total Pages is ten, when you want to print up to seven pages and do not want to print from page 8 on, enter "7" for Last Number. Normally, you do not need to enter the number.
- You can set a value from 1 to 9999 for [First Printing Page], [First Printing Number], [Last Number], and [Total Pages].

Specifying the first printing page and start number ("1-1,1-2...")

Specify the first printing page and start number.

1. Press [Change] under Change Numbering.

2. Press [First Printing Page], enter the original sheet number from which to start printing, and then press [#].




- 3. Press [First Chapter No.], enter the chapter number from which to start numbering with the number keys, and then press [#].
- 4. Press [First Printing Number], enter the page number from which to start printing with the number keys, and then press [#].
- 5. When page designation is complete, press [OK].
- 6. Press [OK] twice.



- You can set a value from 1 to 9999 for [First Printing Page], [First Printing Number], and [First Chapter No.].
- To change the value you entered, press [Clear], and then enter the new value.


Stamp Text

You can stamp text on copies up to 64 letters.



Stamp position and original orientation

The stamp positions differ according to the orientation in which you place the originals.




BAT083S

1. Press [Stamp].



- 2. Press [Stamp Text].
- 3. Press [Change Text].
- 4. Enter stamp text, and then press [OK].



You can change the stamp color and position.

- 5. Press [All Pages] or [1st Page Only] to select the print page.
- 6. After making all settings, press [OK].
- 7. Press [OK].



- The default color is black.
- When the Full Color is selected, the full color counter will advance by "1".
- If the main power is turned off, the text is cleared. To save the typed text, you can register them in a program. For details about Program, see "Registering Frequently Used Functions".
- You can change the settings for Stamp Text under Stamp in User Tools. For details about Stamp, see "Copier/Document Server Features", General Settings Guide.

■ Reference

• p.102 "Registering Frequently Used Functions"

Changing the stamp color


Changes the stamp color.

- 1. Press [Stamp Color] under Stamp Color.
- 2. Select the stamp color, and then press [OK].

Changing the stamp position

Changes the stamp position, size and density.

- 1. Press [Change] under Stamp Position.
- 2. Select the stamp position, and then press [OK].




Advanced Copier Functions

This section describes the machine's advanced copy functions.


Scan Position

You can move the scanning position of originals.



1. Point from which the machine begins scanning


You can move the scanning position up to 30 mm (1.2 inches) in 1 mm (0.1 inch) increments upward, downward, to left and to right.




BAT0858

- 1. Top: 0 30 mm, 0 1.2 inches
- 2. Right: 0 30 mm, 0 1.2 inches
- 3. Bottom: 0 30 mm, 0 1.2 inches
- 4. Left: 0 30 mm, 0 1.2 inches

1. Press [Edit / Color].



- 2. Press [Scan Position].
- 3. Specify the scanning position for the front side of the original.



4. Specify the scanning position for the back side of the original. Then press [OK].


If you don't need to set the scanned position of the back side of the original, press [OK].




- To change the value you entered, press [←], [→], [↓] or [↑], or press [Clear], and then specify a new value.
- Press $[\, \downarrow \,]$ and $[\, \uparrow \,]$ to set the top or bottom position. Press $[\, \leftarrow \,]$ and $[\, \rightarrow \,]$ to set the left or right position.
- The scanning position for the back side of the original is valid only when you are copying 2-sided originals.

Margin Adjustment


Copies originals leaving a binding margin.



1. Press [Edit / Color].



- 2. Make sure that [Margin Adj.] is selected. If [Margin Adj.] is not selected, press [Margin Adj.].
- 3. Specify a binding margin for the front side pages.



4. Specify a binding margin for the back side pages. Then press [OK].

If you do not need to specify the margins for the back side pages, press [OK].



- To change the value you entered, press [←], [→], [↓] or [↑], or press [Clear], and then specify a new value.
- Press $[\, \downarrow \,]$ and $[\, \uparrow \,]$ to set the top or bottom position. Press $[\, \leftarrow \,]$ and $[\, \rightarrow \,]$ to set the left or right position.
- You can set the binding margin up to 30 mm (1.2 inches) in 1 mm (0.1 inch) increments.
- Margin on the back side of the page is valid when 1 Sided → 2 Sided or Combine 2 Sides is selected.

You can change the settings for Margin Adjustment under Edit in User Tools. For details about Edit,
 see "Copier/Document Server Features", General Settings Guide.


Erase Center / Border

This function erases the center and/or all four sides of the original image.

This function has the following three types:


Erase Border

Erases the edge margin of the original image.




Erase Center

Erases the center margin of the original image.




Erase Center/Border

Erases both the center and edge margins of the original image.





• The relationship between the original orientation and the erased part is as follows:




- 1. Erased part
- 2. 0 432 mm (0 17 inches)
- To erase the image on the back side of the original, press [2 Sided Setting] and then [Back]. Erasing the image on the back side is valid when you copy 2-Sided originals.
- The erase width is set to 10 mm (0.4 inch) as a default. You can change this setting under Edit in User Tools. For details about Edit, see "Copier/Document Server Features", General Settings Guide.


Erase Border (same width)

Erases the edge margin of the original image.

1. Press [Edit / Color].



- 2. Press [Erase].
- 3. Press [Erase Center / Border].
- 4. Press [Erase Border].
- 5. Press [Same Width].
- 6. Specify an erase border width with [+] and [-].



Pressing [+] or [-] changes the width in increments of 1 mm (0.1 inch). Pressing and holding down the relevant key changes the width in increments of 10 mm (1 inch).


7. Press [OK] twice.




• To change the value you entered, press [+] and [-], and then specify a new value.

Erase Border (different width)

Erases the edge margins of the original image.



- 2. Press [Erase].
- 3. Press [Erase Center / Border].
- 4. Press [Erase Border].
- 5. Press [Different Width].
- 6. Press the key you want to change and specify an erase width with [+] and [-].



7. Press [OK] twice.



• To change the value you entered, press [+] and [-], and then specify a new value.


Erase Center

Erases the center margin of the original image.

1. Press [Edit / Color].



- 2. Press [Erase].
- 3. Press [Erase Center / Border].
- 4. Press [Erase Center].
- 5. Specify the erase width with [+] and [-].



6. Press [OK] twice.




• To change the value you entered, press [+] and [-], and then specify a new value.


Erase Center / Border (same width)

Erases both the center and edge margins of the original image.

1. Press [Edit / Color].



- 2. Press [Erase].
- 3. Press [Erase Center / Border].
- 4. Press [Erase Center / Border].
- 5. Press [Same Width].
- 6. Press [Center], and then specify the erase width with [+] and [-].



- 7. Press [Border], and then specify the erase width with [+] and [-].
- 8. Press [OK] twice.




• To change the value you entered, press [+] and [-], and then specify a new value.

Erase Center / Border (different width)


Erases both the center and edge margins of the original image.

4

1. Press [Edit / Color].



- 2. Press [Erase].
- 3. Press [Erase Center / Border].
- 4. Press [Erase Center / Border].
- 5. Press [Different Width].
- 6. Press the key you want to change and specify an erase width with [+] and [-].




7. Press [OK] twice.




- To change the value you entered, press [+] and [-], and then specify a new value.

Erase Inside

Use this function to copy the original while erasing a specified area.




To specify the area you want to erase, you have to define the value of X1, Y1, X2, and Y2 on the original. Measure the area you want to specify before entering the area settings.



X1, X2: 0 - 432 mm (0 - 17 inches)


Y1, Y2: 0 - 432 mm (0 - 17 inches)

1. Press [Edit / Color].



- 2. Press [Erase].
- 3. Select one of the areas from [Erase Inside 1] to [Erase Inside 5].

4. Enter the length of [X1] with the number keys, and then press [#].



- 5. Enter the length of [Y1] with the number keys, and then press [#].
- 6. Enter the length of [X2] with the number keys, and then press [#].
- 7. Enter the length of [Y2] with the number keys, and then press [#].

 If you want to erase the image on the back side of the original, press [2 Sided Setting] and then [Back].


 Erasing the image on the back side is valid when you copy 2-Sided originals.
- 8. Press [OK].
- 9. To specify multiple areas, select areas 1 to 5, and then repeat steps 3 to 8.
- 10. Press [OK].




- To change the value you entered, press the key you want to change, and then enter a new value.
- You can specify up to five areas.

Erase Outside

Use this function to copy the original while erasing outside of a specified area.




To specify the area you want to erase, you have to define the value of X1, Y1, X2, and Y2 on the original. Measure the area you want to specify before entering the area settings.




X1, X2: 0 - 432 mm (0 - 17 inches)

Y1, Y2: 0 - 432 mm (0 - 17 inches)

1. Press [Edit / Color].



- 2. Press [Erase].
- 3. Press [Erase Outside].
- 4. Enter the length of [X1] with the number keys, and then press [#].



- 5. Enter the length of [Y1] with the number keys, and then press [#].
- 6. Enter the length of [X2] with the number keys, and then press [#].
- 7. Enter the length of [Y2] with the number keys, and then press [#].

 If you want to erase the image on the back side of the original, press [2 Sided Setting] and then [Back].

4

Erasing the image on the back side is valid when you copy 2-Sided originals.


8. Press [OK] twice.



• To change the value you entered, press the key you want to change, and then enter a new value.

Image Repeat

The original image is copied repeatedly.



There are two ways to specify an image to be repeated.

Whole Area Repeat

Repeatedly copies the entire image.

Specified Area Repeat

Repeatedly copies a specified area of the image.



• You can change the settings for Image Repeat under Edit in User Tools. For details about Edit, see "Copier/Document Server Features", General Settings Guide.

Whole Area Repeat

Repeatedly copies the entire image.

The number of repeated images depends on the original size, paper size, and reproduction ratio. For example, see the following table:


Original: A5 \square /Copy paper: A4 \square , Original: A5 \square /Copy paper A4 \square , Original: $5^1/_2 \times 8^1/_2 \square$ /Copy paper: $8^1/_2 \times 11^\square$, or Original: $5^1/_2 \times 8^1/_2 \square$ /Copy paper: $8^1/_2 \times 11^\square$

4 repeats (71 %)	16 repeats (35 %)
BATORS	BATO96S

Original: A5 \square /Copy paper: A4 \square , Original: A5 \square /Copy paper A4 \square , Original: $5^1/_2 \times 8^1/_2 \square$ /Copy paper: $8^1/_2 \times 11 \square$, or Original: $5^1/_2 \times 8^1/_2 \square$ /Copy paper: $8^1/_2 \times 11 \square$

2 repeats (100 %)	8 repeats (50 %)	32 repeats (25 %)
BATORES	BAT087S	BATORES

- 1. Select the size of copy paper and the reproduction ratio.
- 2. Press [Edit / Color].



- 3. Press [Edit Image].
- 4. Press [Image Repeat].
- 5. Make sure that [Whole Area] is selected, and then press [OK].
- 6. Press [OK].


Specified Area Repeat

Repeatedly copies a specified portion of the image.



- You cannot use this function from the ADF.
- If Margin Adjustment is selected, cancel the setting.

To specify the area you want to repeat, you have to define the value of X1, Y1, X2, and Y2 on the original. Measure the area you want to specify before entering the area settings.



1. Set the original on the exposure glass


X1: 0 - 412 mm (0 - 16.2 inches)

X2: 20 - 432 mm (0.8 - 17.0 inches)


Y1: 0 - 277 mm (0 - 10.8 inches),

Y2: 20 - 297 mm (0.8 - 11.6 inches).

- 1. Select the size of copy paper and the reproduction ratio.
- 2. Press [Edit / Color].




- 3. Press [Edit Image].
- 4. Press [Image Repeat].
- 5. Press [Specified Area].



- 7. Enter the length of [Y1] with the number keys, and then press [#].
- 8. Enter the length of [X2] with the number keys, and then press [#].
- 9. Enter the length of [Y2] with the number keys, and then press [#].
- 10. Press [OK] twice.

Double Copies

One original image is copied twice on one sheet.



• Originals with a size of A5, B6 JIS, and $5^1/_2 \times 8^1/_2$ cannot be detected properly on the exposure glass. Be sure to select the copy paper manually or place the originals in the ADF.

See the following table for original and copy paper sizes when using a 100 % ratio:

Metric version

Original size and Orientation	Copy paper size and Orientation
A5 🗗	A4 🖵
B6 JIS □	B5 JIS □
A4 🕽	A3 🗗
A5 🖸	A4 🗗
B5 JIS □	B4 JIS □
B6 JIS □	B5 JIS □


BCY008

Inch version

Original size and Orientation	Copy paper size and Orientation
$5^{1/2} \times 8^{1/2} \square$	8 ¹ /2 × 11 □
5 ¹ / ₂ × 8 ¹ / ₂ \Box	8 ¹ / ₂ × 11 □
8¹/2 × 11	11 × 17 🖵

RAT100

1. Press [Edit / Color].




- 2. Press [Edit Image].
- 3. Press [Double Copies].
- 4. Press [OK].
- 5. Select the paper size.



• You can change the settings for Double Copies under Edit in User Tools. For details about Edit, see "Copier/Document Server Features", General Settings Guide.

Centering

You can make copies with the image moved to the center of the copy paper.



The original sizes and orientations you can use with this function are as follows:


Metric version

Original location	Original size and orientation
Exposure glass	A3\$\operatorname{\operatorname{D}}, A4\$\operatorname{D}\$, A5\$\overatorname{D}\$, 8\$^1/2 \times 13\$\operatorname{D}\$
ADF	A3D, B4 JISD, A4DD, B5 JISDD, A5DD, B6 JISDD, 11 × 17D, $8^{1}/_{2}$ × 11DD, $8^{1}/_{2}$ × 13D

Inch version

Original location	Original size and orientation
Exposure glass	$11 \times 17^{\Box}$, $8^{1}/_{2} \times 14^{\Box}$, $8^{1}/_{2} \times 11^{\Box}$, $5^{1}/_{2} \times 8^{1}/_{2}^{\Box}$
ADF	$11 \times 17^{\Box}$, $11 \times 15^{\Box}$, $10 \times 14^{\Box}$, $10 \times 13^{\Box}$, $8^{1}/_{2} \times 14^{\Box}$, $8^{1}/_{2} \times 11^{\Box}$, $5^{1}/_{2} \times 8^{1}/_{2}$, $8 \times 13^{\Box}$, A3 \Box , A4 \Box

- 1. Select the paper size.
- 2. Press [Edit / Color].



- 3. Press [Edit Image].
- 4. Press [Centering].


4

5. Press [OK].


Positive/Negative

Copies an image inverted.

If your original is black and white, copy images are inverted. If your original is color, the density, darkness and brightness of each color will be reversed and inverted to complimentary colors.




1. Press [Edit / Color].



- 2. Press [Edit Image].
- 3. Press [Positive / Negative].
- 4. Press [OK].

Mirror Image


Copies by reversing the image from left to right, as reflected in a mirror.



BAS101S

Important

- If Margin Adjustment is selected, cancel the setting.
- 1. Press [Edit / Color].




- 2. Press [Edit Image].
- 3. Press [Mirror Image].
- 4. Press [OK].

3 Edges Full Bleed

You can make full image copy by cutting down the margin of top, bottom, and right sides.

This function is useful for originals full of image.




BAS1028

/



1. Press [Edit / Color].



- 2. Press [Edit Image].
- 3. Press [3 Edges Full Bleed].
- 4. Press [OK].



• Do not attempt Duplex printing with this function. The paper will jam if you do.

Series Copies

Separately copies the front and back of a 2-sided original or the two facing pages of a bound original onto two sheets.



• You cannot use the Book \rightarrow 1 Sided function from the ADF.

The following table shows the paper sizes for Book \rightarrow 1 Sided when the reproduction ratio is 100%:

Metric version

Original	Paper for 1-sided copy	
A3□ 7	A4 □ × 2 sheets	
B4 JIS⊡	B5 JIS × 2 sheets	
A4 □	A5 × 2 sheets	

BAT140S

Inch version


Original	Paper for 1-sided copy
11 × 17 □	$8^{1}/_{2} \times 11 \square \times 2$ sheets
8 ¹ / ₂ × 11 □	$5^{1/2} \times 8^{1/2} \square \times 2$ sheets

BAT102S

There are two types of Series Copies.


Book → 1 Sided

You can make 1-sided copies from two facing pages of a bound original (book).




2 Sided → 1 Sided

You can make 1-sided copies from 2-sided originals.




1. Press [Dup./ Combine/ Series].



2. Press [Series].

3. Select [2 Sided \rightarrow 1 Sided] or [Book \rightarrow 1 Sided], and then press [OK].



If you specified [2 Sided → 1 Sided], you can specify the orientation.



• Press the [#] key after all originals have been scanned.



• p.74 "Originals and copy orientation"

Booklet/Magazine

Copies two or more originals in page order.

The following table shows the paper sizes for Book \rightarrow 2 Sided when the reproduction ratio is 100%:

Metric version

Original	Paper	
A3 □	A4 🖟 (2-sided)	
B4 JIS□	B5 JIS ☐ (2-sided)	
A4 □	A5 (2-sided)	

BAT134S

Inch version


Original	Paper	
11 × 17 □	$8^{1}/_{2} \times 11 \square$ (2-sided)	
8 ¹ / ₂ × 11 □	5 ¹ / ₂ ×8 ¹ / ₂ (2-sided)	

BAT1018

There are six types of Booklet/Magazine.

1 Sided → Booklet


Make copies in page order for a folded booklet as shown.



- 1. Open to left
- 2. Open to right

2 Sided → Booklet


Make 2-sided originals to copies in page order for a folded booklet as shown.



- 1. Open to left
- 2. Open to right

1 Sided → Magazine

Copies two or more originals to make copies in page order when they are folded and stacked.




- 1. Open to left
- 2. Open to right

4

2 Sided → Magazine


Copies two or more originals of 2-sided to make copies in page order when they are folded and stacked.



- 1. Open to left
- 2. Open to right


Book → 2 Sided

Copies a two-page spread original onto one sheet with one page per side.




Front & Back → 2 Sided

Copies each two-page spread original as it is onto both sides of a sheet.



How to fold and unfold copies to make a booklet


Fold a copy along the centerline, and open.




- 1. Open to left
- 2. Open to right

How to fold and unfold copies to make a magazine

Fold and stack copies to make a magazine, and open.




- 1. Open to left
- 2. Open to right
- 1. Press [Dup./ Combine/ Series].



2. Press [Book].

3. Select a book type separately for the original ([1 Sided] or [2 Sided]) and copy ([Booklet] or [Magazine]), or select a book type from [Book → 2 Sided] and [Front&Back → 2 Sided].



If you specified [2 Sided] for the original, [Book \rightarrow 2 sided], or [Front&Back \rightarrow 2 sided], you can specify the orientation of originals or copies.

- 4. Select the paper size.
- 5. Press [OK].



- When placing originals on the exposure glass, or in the ADF using Batch mode, press the [#] key after all the originals have been scanned.
- The machine sets the reproduction ratio automatically to meet the paper size.
- The default setting for the orientation of Booklet and Magazine is [Open to Left]. You can change the
 default under Orientation: Booklet, Magazine in User Tools. For details, see "Copier/Document
 Server Features", General Settings Guide.

Reference


• p.74 "Originals and copy orientation"

Creep Adjustment

When Magazine is selected, you can specify the creep value.

When folding stacked paper, the thickness of the paper causes creep (progressive image loss) between the most inner and most outer pages. The machine compensates for creep by progressively shifting the copy image.

For example, when folding 15 sheets, the creep value will be 2 mm (0.1 inch), meaning there will be a 2 mm (0.1 inch) gap in the center of the image printed on the outermost sheet.



- 2. Press [Book].
- 3. Select [1 Sided] or [2 Sided] for the original.
- 4. Press [Magazine].
- 5. Press [Creep Adjust.].
- 6. Specify the creep value with [+] and [-].




7. Press [OK] twice.




- You can adjust the creep value between 0 to 99 mm (0 to 3.9 inches) in 1 mm (0.1 inch) steps.
- To change the value you entered, press [+] and [-], and then specify a new value.

Mix 1 & 2 Sided


You can copy two types of originals, 1-sided and 2-sided, onto one or both sides of a sheet in one copy job.



1. Press [Dup./ Combine/ Series].



- 2. Press [Mix 1&2 Sid.].
- 3. Select [1 Sided] or [2 Sided] for the original.



If you select [2 Sided], you can select the orientation.

- 4. Select [1 Sided] or [2 Sided] for the copy.
- 5. Place the originals, and then press the [Start] key.
- 6. If you specify [2 Sided] for either the originals or copies, press [Change Setting] if the number of originals that you want to scan is odd, or if you want to change the settings for the next originals.

Place the next originals, and then repeat steps 3 to 5.

- When placing originals on the exposure glass, or in the ADF using Batch mode, press the [#] key after all the originals have been scanned.
- When making two or more copies with the ADF, specify Batch mode. For details about Batch mode, see "Batch Mode".
- If you specified [2 Sided] for the originals or copies, you can specify the orientation.

■ Reference

• p.35 "Batch Mode"

Covers

You can use this function to create cover sheets by adding additional pages of different paper, or copying existing pages onto different paper.


- Before using this function, select the trays for covers under Front Cover Sheet tray and Back Cover Sheet tray in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
- If you have selected Interposer for Front Cover Sheet tray or Back Cover Sheet tray in Tray Paper Settings, you cannot copy onto the cover sheets.
- When selecting [Copy], select whether the front and back covers are copied 1-sided or 2-sided.

The Covers function includes Front Cover and Back Cover.

Front Cover


This function copies the first page of an original onto paper that has been specified for covers, or places a cover sheet before the first copy page.

Copy



Blank







Back Cover

This function copies the last page of an original onto paper that has been specified for covers, or places a cover sheet after the last copy page.

Copy




• Blank



1. Press [Cover/ Slip Sheet].





- 3. Select [Copy] or [Blank] for the back cover, and then press [OK].
- 4. Select the main sheet tray that contains the paper to copy the originals.
- 5. After making all settings, press [OK] twice.




- The back cover sheet should be the same size and orientation as the main sheets.
- You can use paper of different size and orientation than the main sheets as the front cover sheet.
- When stapling copies with the front cover whose size and orientation is different from the main sheets, the front cover sheet should be the same width in paper feed direction as the main sheets. For example, when the main sheet is A5D, you can staple the copies with the front cover sheet of A4D, but you cannot staple them with that of A4D.
- When you specify both front and back covers, the first and last pages of your original are copied on
 paper specified for use as a cover, or cover sheets are inserted before the first copy and after the last
 copy.
- You can make a combined copy on the front cover sheet. For details about Front Cover Copy in Combine, see "Copier/Document Server Features", General Settings Guide.
- For details about the interposer, see "Loading Paper", Troubleshooting.


Designate

Use this function to have certain pages of your original copied onto designation sheets or to insert a designation sheet for each page specified.


Copy




• Blank



- Before using this function, select the tray for designation sheets under Designation Sheet 1 Tray or Designation Sheet 2 Tray in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
- If you have selected Interposer for Designation Sheet 1 Tray or Designation Sheet 2 Tray in Tray Paper Settings, you cannot copy onto the designation sheets.
- 1. Press [Cover/ Slip Sheet].



- 2. Press [Designate / Chapter].
- 3. Select [Designate: Copy] or [Designate: Blank].



To select pages 21 to 40 (chapter), press [21-40].

- 5. Select the designation sheet tray that contains the paper for the designation sheets.
- 6. Enter the page location of the first page of the chapter with the number keys, and then press the [#] key.
- 7. To specify another page location, repeat steps 4 to 7.


 Up to 100 locations can be specified.
- 8. Select the main sheet tray that contains the paper to copy the originals.
- 9. After making all settings, press [OK] twice.



- To change the value you entered, press the key you want to change, and then enter a new value.
- For details about the interposer, see "Loading Paper", Troubleshooting.
- When placing the designation sheets in the multi bypass tray, it should be the same size and orientation as the main sheets.

Chapters


The page locations you specify with this function will appear on the front of copy sheets.




BAS120S



- Before selecting this function, press [Dup./ Combine/ Series] and then select [1 Sided → 2 Sided] or [Combine].
- This function can be used only when you use the Duplex (1 Sided → 2 Sided) or Combine function.
- 1. Press [Cover/ Slip Sheet].



- 2. Press [Designate / Chapter].
- 3. Press [Chapter].
- 4. Press the key to select the chapter number.



To select chapters 21 to 40, press [21-40].

5. Enter the page location of the first page of the chapter with the number keys, and then press the [#] key.

Up to 100 locations can be specified.


- 6. To specify another page location, repeat steps 4 to 5.
- 7. Select the main sheet tray that contains the paper to copy the originals.
- 8. After making all settings, press [OK] twice.




• To change the value you entered, press the key you want to change, and then enter a new value.

Designation Sheet Copy


You can copy designated pages onto designation sheets.



- Mportant !
 - Before using this function, select the tray for designation sheets under Designation Sheet 1 Tray or Designation Sheet 2 Tray in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
 - 1. Press [Cover/ Slip Sheet].



- 2. Press [Designate / Chapter].
- 3. Press [Designation Sheet Copy].
- 4. Enter the sheet number of the first original with the number keys.



- 5. Press [Page to Page].
- 6. Enter the sheet number of the last original with the number keys.


- 7. Select the designation sheet tray that contains the paper for the designation sheets, and then press the [#] key.
- 8. To specify another page location, repeat step 4 to 7. Up to 100 locations can be specified.
- 9. Select the main sheet tray that contains the sheet to copy the originals.
- 10. After making all settings, press [OK] twice.



- · When this function is combined with Duplex, the first page of the designated pages is copied on the front side of a designation sheet.
- The designation sheets should be the same size and orientation as the main sheet.
- To change the value you entered, press the key you want to change, and then enter a new value.


Insert Sheet

You can insert a blank designation sheet before or after a specified page.




Mportant !


- Before using this function, select the tray for slip sheets under Designation Sheet 1 Tray or Designation Sheet 2 Tray in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
- 1. Press [Cover/ Slip Sheet].



- 2. Press [Designate / Chapter].
- 3. Press [Insert Sheet].
- 4. Press the key to select the chapter number.



- 5. Select the designation sheet tray that contains the paper for the designation sheets.
- 6. Select [Before] to insert slip sheets before the desired page. Select [After] to insert slip sheets after the desired page. Enter the page number with the number keys.
- 7. Press [Number of Sheets], and enter the number of sheets you want to insert with the number keys, and the press the [#] key.



- 8. To specify another location where to insert sheets, repeat steps 4 to 7.
- 9. Select the main sheet tray that contains the paper to copy the originals.
- 10. After making all settings, press [OK] twice.




- The designation sheets should be the same size and orientation as the main sheets.
- To change the value you entered, press the key you want to change, and then enter a new value.
- For details about the interposer, see "Loading Paper", Troubleshooting.


Slip Sheet

Every time an original page changes, a slip sheet is inserted. You can also print on the inserted slip sheet.


Since a slip sheet is inserted for every page, you can protect printed surfaces.




Copy




Blank



- If [1 Sided → 2 Sided] is set, cancel the setting.
- Before using this function, select the tray for slip sheets under Slip Sheet tray in Tray Paper Settings. For details, see "Tray Paper Settings", General Settings Guide.
- 1. Press [Cover/ Slip Sheet].





3. Select the main sheet tray that contains the paper to copy the originals.



• The slip sheets should be the same size and orientation as the copy paper.

5. Document Server

The Document Server enables you to store documents on the hard disk of this machine. Thus you can print them later applying necessary conditions.

Relationship between Document Server and Other Functions

State of the Document Server varies depending on the function used.

Copier functions

- Storing method: Copy/Document Server
- List display: Available
- Printing: Available
- Transmission: Unavailable

Printer functions

- · Storing method: Personal computer
- List display: Available
- · Printing: Available
- Transmission: Unavailable

Scanner functions

- Storing method: Scanner
- List display: Unavailable

When documents are stored with the scanner feature, you can confirm them from the scanner feature screen. For details, see "Displaying the List of Stored Files", Scanner Reference.


- Printing: Unavailable
- Transmission: Available

The data can be transferred by the scanner feature. For details, see "Sending a Stored File", Scanner Reference.

Document Server Display

Explains the screens and icons displayed in the Document Server function.

Document Server initial display



- 1. Displays operational status and messages.
- 2. Displays the title of the current screen.
- 3. Displays the numbers of originals stored into the memory, copies set, and copies made.
- 4. Displays keys for the operation.
- 5. Displays an icon that indicates the function and color mode used to stored the document.
- 6. Displays keys for switching the display between list and thumbnails.

The following icons appear in the list of the Document Server to indicate the function and color mode used to store a document.

Function	Copier	Printer
Icons	D .	<u> </u>
Color icons	Full color	Black and white
Icons	ஃ	À

5

Thumbnail screen

In thumbnail view, miniature images of the stored documents are displayed. This is useful for checking a document's content.






• All the stored documents may not be displayed depending on the security function specified.

Simplified Display

This section explains how to switch to the simplified display.

When you press the [Simplified Display] key, the screen changes from the initial display to the simplified display.

Letters and keys are displayed at a larger size, making operations easier.



Simplified Document Server Screen



BQG011S

1. [Key Color]

Press to increase screen contrast by changing the color of the keys. This is available only for the simplified display.




- To return to the initial display, press the [Simplified Display] key again.
- Certain keys do not appear on the simplified display.

Preview Display

This section explains the items that appear on the preview display and how to preview stored documents.

To preview stored documents, select the documents you want to preview on the Document Server initial display, and then press [Preview]. The preview display denotes the screen that allows confirming contents of the scanned documents.

Preview Display



1. [←][→][↑][↓]

Moves the display area in the direction indicated by the arrow.

2. [Zoom Out], [Zoom In]

Scales the displayed page down or up.

3. [Exit]

Closes the preview display.

4. Display File

Displays the file name.

If you have selected two or more files for preview, press [Switch] to switch between them.

5. Display Page

Displays the number of the currently displayed page, total number of pages, and page size.

6. [Switch]

Flips the page of the selected file.

7. Display Position

Indicates the location of the displayed preview image when the image is enlarged.



- When the preview is already selected from another function, the preview screen function may become
 unusable.
- The preview display is also not available when the paper size is larger than A3.

Using the Document Server

Following describes how to use the Document Server.

Storing Data

Following describes the procedure for storing documents on the Document Server.



- Data stored in the machine might be lost if some kind of failure occurs. The manufacturer shall not be responsible for any damage resulting from loss of data.
- Be careful not to let anyone know your password, especially when entering a password or recording it. Keep any record of your password in a secure place.
- Avoid using a single number or consecutive numbers for a password such as "0000" or "1234", since the numbers like this are easy to guess, so using them will not provide a worthwhile level of security.
- A document accessed with a correct password remains selected even after operations are complete, and it can be accessed by other users. After the operation, be sure to press the [Clear Modes] key to cancel the document selection.
- The user name registered to a stored document in the Document Server is to identify the document creator and type. It is not to protect confidential documents from others.
- When scanning by the scanner, make sure that all other operations are ended.

File Name

A document name such as "COPY0001" and "COPY0002" is automatically attached to the scanned document. You can change the document name.


User Name

You can register a user name to identify the user or user group that stored the documents. To assign it, select the user name registered in the Address Book, or enter the name directly.


Password

To prevent unauthorized printing, you can set a password for any stored document. A protected document can only be accessed if its password is entered. If a password is set for the documents, the key icon appears next to the documents.

1. Press the [Document Server] key.



2. Press [Scan Original].



3. Enter a user name, file name, and password, if necessary.

When not changing a file name, the name will be automatically set.

- 4. Set the original.
- 5. Specify the original scanning conditions.
- 6. Press the [Start] key.

The original is scanned. The document is saved in the Document Server.



- Enter the password in the range of four and eight digits.
- To stop scanning, press the [Stop] key. To restart a paused scanning job, press [Continue] in the
 confirmation display. To delete saved images and cancel the job, press [Stop]. The original placed
 in the ADF will be ejected.
- If a password is set, the key icon appears on the left side of the file name.
- After scanning, a list of stored documents will be displayed. If the list does not appear, press [Finish Scanning].
- Data stored in the Document Server is set to be deleted after three days (72 hours) by the factory
 default. You can specify the period after which the stored data is deleted automatically under Auto
 Delete File in Document Server in User Tools. See "System Settings", General Settings Guide.

- If you do not want stored documents to be automatically deleted, select [Off] in Auto Delete File in
 Document Server before storing a document. If you select [On] later, data stored after will be
 automatically deleted.
- When storing another document in the Document Server after storing a document from the copy feature, be sure that its copy is completed.
- Depending on the security setting, [Access Privileges] may appear instead of [User Name]. For details
 about specifying [Access Privileges], consult the administrator.
- For details about how to enter text, see "Entering Text", About This Machine.

Specifying a User Name

You can specify a user name for the stored file.

- 1. Press [Scan Original].
- 2. Press [User Name].



A list of user names appears.

Select a user name, and then press [OK].


The user names shown are names that were registered in the Address Book. To specify a name not shown in the display, press [Manual Entry], and then enter a user name.

Specifying a File Name

You can change the name of a stored document.

1. Press [Scan Original].

2. Press [File Name].



The soft keyboard appears.

3. Press [Delete All] to delete the document name to be automatically set.

Pressing [Backspace] allows you to delete up to any desired position.

4. Enter a document name, and then press [OK].





You can enter up to 20 characters for a document name. In the list, however, up to 16 characters are
displayed as the document name. If above limits are exceeded, the list will display up to 15 characters
for the document name.

Specifying a Password

You can specify a password for the stored document.

- 1. Press [Scan Original].
- 2. Press [Password].






You can use four to eight digits for the password.

4. For double-check, enter the password again, and then press [OK].

Changing the User Name of a Stored Document

You can change the user name for a stored document.


1. Select the document whose user name you want to change.



If a password is set, enter it, and then press [OK].

2. Press [Edit File].

3. Press [Change User Name].



- 4. Enter a new user name, and then press [OK].
- 5. Press [OK].




- To cancel the selection, press the selected (highlighted) key.
- Depending on the security setting, [Access Privileges] may appear instead of [User Name]. For details
 about specifying [Access Privileges], consult the administrator.
- For details about how to enter text, see "Entering Text", About This Machine.

Changing the File Name of a Stored Document

You can change the file name of a stored document.

- Select the document whose name you want to change.
 If a password is set, enter it, and then press [OK].
- 2. Press [Edit File].
- Press [Change File Name].



- 4. Enter a new file name, and then press [OK].
- 5. Press [OK].




- To cancel the selection, press the selected (highlighted) key.
- Depending on the security setting, [Access Privileges] may appear instead of [User Name]. For details
 about specifying [Access Privileges], consult the administrator.
- For details about how to enter text, see "Entering Text", About This Machine.

Changing the Password of a Stored Document

You can change the password of a stored document.

- Select the document whose password you want to change.
 If a password is set, enter it, and then press [OK].
- 2. Press [Edit File].
- 3. Press [Change Password].



- 4. Enter a new password, and then press [OK].
- 5. For double-check, enter the password again and then press [OK].
- 6. Press [OK].




- To cancel the selection, press the selected (highlighted) key.
- Depending on the security setting, [Access Privileges] may appear instead of [User Name]. For details
 about specifying [Access Privileges], consult the administrator.
- For details about how to enter text, see "Entering Text", About This Machine.

Checking the Details of a Stored Document

You can confirm the details of a stored document.


1. Select the document whose details are to be displayed.



If a password is set, enter it, and then press [OK].

2. Press [Details].

Details of the document will be displayed.





- If you have selected two or more documents, press [▲] or [▼] to view their information.
- To chancel the selection, press the selected (highlighted) key.
- Pressing [Exit] restores the document selection screen.

Searching for Stored Documents

Searches for stored documents by user name or file name.

You can rearrange the currently chronologically ordered documents in any desired order.

Searching by file name

Searches for stored documents by file name.

Searching by user name

Searches for stored documents by user name.




- DeskTopBinder Lite enables searching and reordering of stored documents from computers.
- For details about DeskTopBinder Lite, see Instruction Manual and Help of DeskTopBinder Lite.


Searching by file name

Searches for stored documents by file name.

1. Press [File Name].



2. Enter the document name to be searched, and then press [OK].



Document names that match completely from the starting character will be searched and displayed on the screen.




• Pressing [Display All] displays all stored documents.

Searching by user name

Searches for stored documents by user name.

1. Press [User Name].



- 2. When specifying a registered user name, select it.
- 3. When the user name is not registered, press [Manual Entry], and then enter it from the input screen to be displayed. Then press [OK].
- 4. Press [OK].

User names that match completely from the starting character will be searched and displayed on the screen.



• Pressing [Display All] displays all stored documents.

Printing Stored Documents

Prints stored documents.

Web Image Monitor allows you to print documents stored in the Document Server from your computer.

1. Select a document to be printed.


If a password is set, enter it, and then press [OK].

2. When printing two or more documents at a time, repeat step 1.

Up to 30 documents can be printed.

3. When specifying printing conditions, press [To Printing Screen].

The printing condition screen will appear. The user name, file name, and printing order of the document will be displayed.



4. Enter the number of print copies with the number keys.

The maximum quantity that can be set is 9999.

5. Press the [Start] key.

Printing will be started.



- You can search the target document using [User Name] or [File Name] situated in the left side of the screen
- You can sort the documents by user name, file name, or creation date. Press the item to be used for the sorting on the top of the list.
- Some of the selected documents may not be printed due to the difference in the size or resolution.
- When changing the printing order, cancel the highlight and then specify the order correctly.
- Pressing the [Clear Modes] key cancels every selection.
- Pressing [Order] displays the selected documents in the printing order.
- The copy and printer features hold the specified printing conditions after the operation is over and apply them at the next printing.
- When two or more documents are specified, the printing conditions are stored on the first document but not on the succeeding documents.
- Following settings are available for the printing conditions. For respective printing results, see "Basic Copying" and "Advanced Copying".
 - Paper tray
 - The number of prints
 - 2 Sided / Book (2 Sided Copy, Booklet, Magazine)
 - Edit / Stamp
 - · Cover / Slip Sheet
 - Finishing (Sort, Staple, Punch, Z-fold)
- When printing two or more copies while selecting the sort function, you can confirm the finish by printing only one copy.

- When printing two or more documents at a time, you can print them as a single continuous document
 by specifying the order of their printing.
- When printing two or more documents at a time, the printing conditions set for the first document are applied to all the remaining documents.
- When two or more documents are selected, press [▲] [▼] to confirm the user name, document name
 and printing order of the document.
- Pressing [File List] restores the document selection screen.
- You can change the maximum print quantity under Max. Copy Quantity in User Tools. For details about Max. Copy Quantity, see "Copier/Document Server Features", General Settings Guide.
- Web Image Monitor allows you to print a document stored in the Document Server from your computer. For the Web Image Monitor starting procedure, see "Displaying Stored Documents with Web Image Monitor".




p.223 "Displaying Stored Documents with Web Image Monitor"

Sample Print

When the number of sets is massive, you can print a single set in advance to check the printing order and the printing conditions of the selected documents.



- This function can be used only when the Sort function is selected in the printing conditions.
- 1. Select the document to be printed.



If a password is set, enter it, and then press [OK].

2. Press the [Sample Copy] key.

Only one set will be printed.

3. Press [Continue].

Printing will be resumed.






• To cancel the printing, press [Suspend]. The print screen will appear, enabling to set another item.

Printing the first page

In order to confirm the print results, you can print the first page alone of the document selected on the Select File screen.

When two or more documents are selected, the first page of the respective documents is printed.

- Select the document to be printed.
 If a password is set, enter it, and then press [OK].
- 2. Press [Print Specified Page].
- 3. Press [1st Page].



4. Press the [Start] key.

Printing a specified page

You can print the specified page alone of the document selected on the Select File screen.

- Select the document to be printed.
 If a password is set, enter it, and then press [OK].
- 2. Press [Print Specified Page].
- 3. Press [Specified Page].

4. Specify the page to be printed with the number keys, and then press [#].



5. Press the [Start] key.



• To change the value you entered, press the key you want to change, and then enter a new value.

Printing a specified range

You can print the pages in the specified range alone of the document selected on the Select File screen.

- Select the document to be printed.
 If a password is set, enter it, and then press [OK].
- 2. Press [Print Specified Page].
- 3. Press [Specify Range].
- 4. Specify the printing start page with the number keys, and then press [#].



- 5. Specify the printing end page with the number keys, and then press [#].
- 6. Press the [Start] key.



• To change the value you entered, press the key you want to change, and then enter a new value.

Editing a Stored Document

Edits a stored document.

Combining Stored Documents

You can combine two or more documents stored in the Document Server.



- · You cannot recover the original documents from the combined document.
- You cannot combine files if they are currently being used by another function.
- 1. Select the documents you want to combine.

If a password is set, enter it, and then press [OK].

The documents are combined in the order of being selected.

- 2. Press [Edit File].
- 3. Press [Combine Files].
- 4. Enter the new document name.
- 5. Press [OK].



- You can combine up to 30 documents.
- The print settings for the document selected first are stored.
- If you do not set the document name in step 5, the name of the document selected first will be the name of the combined document.

Inserting a Stored Document

You can insert a document into documents already stored in the Document Server.

- You cannot recover the original document from the new document.
- You cannot insert documents into a document that is currently being used by another function.
- 1. Select the documents to be inserted in.

If a password is set, enter it, and then press [OK].

- 2. Press [Edit File].
- 3. Press [Insert File].
- 4. Select the document you want to insert into.

- 5. Enter the page number to insert the document using the number keys.
- 6. Press [Before Specify Page] or [After Specify Page].
- 7. Press [OK].

Deleting Pages

Follow the procedure below to delete pages from a document store in the Document Server.

Mportant !

- To check the page numbers, print the file.
- Select the document containing the pages you want to delete.

If a password is set, enter it, and then press [OK].

- 2. Press [Edit File].
- 3. Press [Delete Pages].
- 4. Enter the number of the page you want to delete using the number keys.
- 5. If you want to delete a series of pages, press [Page to Page], and then enter the number of the last page you want to delete.
- 6. Press [OK].
- 7. Press [Yes] in the confirmation dialog box.



- If you want to delete only one page in step 5, proceed to step 6.
- If you enter every page in step 6, the whole document is deleted.

Copying Documents

You can copy documents that are store in the Document Server.



- You cannot copy a selected document that is currently being used by another function.
- Select the document you want to copy.
 If a password is set, enter it, and then press [OK].
- 2. Press [Edit File].
- 3. Press [Duplicate File].
- 4. Press [Yes] in the confirmation dialog box.



• If you select No in Step 4, the selected document is not copied.

5


- If you press [Stop Duplicating] while copying, the selected document is not copied. However, if you select multiple documents, some of them might be copied.
- The "~" mark is added to the beginning of the copied document's name.

Deleting a Stored Document

Deletes a stored document.



- The Document Server can store up to 3000 documents. As the number of stored documents reaches 3000, storing of a new document becomes unavailable. Thus, you should delete unnecessary documents as much as practicable.
- Select the document to be deleted.
 If a password is set, enter it, and then press [OK].
- 2. Press [Delete File].



3. Press [Yes].



- You can delete all documents stored in the Document Server under Delete All Files in Document Server
 in User Tools. For details about Delete All Files in Document Server, see "System Settings", General
 Settings Guide.
- Web Image Monitor allows you to print a document stored in the Document Server from your computer.
- It is also possible to select two or more documents and delete them.
- You can search the target document using [File Name] or [User Name] situated in the left side of the screen.
- You can sort the documents by user name, file name, or creation date. Press the item to be used for the sorting on the top of the list.
- When you could not identify the target document from the document name, print the first page alone
 of the document in order to confirm the print results.

- To chancel the selection, press the selected (highlighted) key.
- For details about how to start Web Image Monitor, see "Displaying Stored Documents with Web Image Monitor".

■ Reference

p.223 "Displaying Stored Documents with Web Image Monitor"

Displaying Stored Documents with Web Image Monitor

You can display stored documents in the Document Server on the computer screen with Web Image Monitor.

- 1. Start a Web browser.
- 2. Enter "http://(IPv4 address, IPv6 address or host name of this machine)/" in the address bar.

When entering an IPv4 address, do not begin segments with zeros.

For example: If the address is "192.168.001.010", you must enter it as "192.168.1.10" to connect to the machine.

The top page of Web Image Monitor will be displayed.

3. Click [Document Server].

The list of documents in the Document Server will be displayed.

4. Click of the document you want to confirm.

Information of the document will be displayed.

5. Confirm contents of the document.



- You can change the format of the list. Click the 🖽 (Thumbnails), 🍱 (Icons), or 🔳 (Details).
- When you want to enlarge the preview display, click [Enlarge Image].

Downloading Stored Documents with Web Image Monitor

You can download documents stored in the Document Server under the scanner function to the computer with Web Image Monitor.

- 1. Start a Web browser.
- Enter "http://(IPv4 address, IPv6 address or host name of this machine)/" in the address bar.

When entering an IPv4 address, do not begin segments with zeros.

For example: If the address is "192.168.001.010", you must enter it as "192.168.1.10" to connect to the machine.

Top page of Web Image Monitor will be displayed.

3. Click [Document Server].

The list of documents in the Document Server will be displayed.

- 4. Click of the document you want to download.
- 5. Select [PDF] or [Multi-page TIFF] for the file format.

The data will be downloaded.

6. Click [OK].



• You can change the format of the list. Click the 🖽 (Thumbnails), 🎹 (Icons), or 🔳 (Details).

5

6. Appendix

This chapter describes the copy machine's specifications and the function compatibility.

Specifications

This section describes the specifications for the copier functions of this machine.

First copy time [*]	Less than 13.5 seconds
Continuous copy speed	90 copies per minutes (B&W/Color, A4/LTD)
Copy originals	Separate sheets, books, tridimensional objects
Maximum original size	A3□(297 mm × 420 mm), 11 × 17□
Copy size	SRA3 \square -A5 \square , 12 × 18 \square -5 $^{1}/_{2}$ × 8 $^{1}/_{2}$ \square
Paper thickness	Paper tray 1, 2: 60-220 g/m ² Paper tray 3, 4: 60-300 g/m ² Wide LCT: 60-300 g/m ² Multi bypass tray: 60-216 g/m ²
Missing image area	Top: 3-6.0 mm Bottom: 0-4.0 mm Left / Right: 0-4.0 mm
Reproduction Ratio	1:1 100-% Enlarge: 121%, 129%, 155%, 200%, 400% Reduce: 93%, 85%, 78%, 73%, 65%, 50%, 25% Zoom: 25%-400%
Resolution	Scan: 600dpi Print: 1200dpi
Paper feed method and capacity	Paper tray 1: 1,000 × 2 sheets Paper tray 2: 500 sheets Paper tray 3, 4: 2,000 × 2 sheets Wide LCT: 2,000 × 2 sheets Multi bypass tray: 500 sheets

Maximum number of copies	1-9999 copies
--------------------------	---------------

 $^{^{*\,1}}$ When copying A4D original in black & white using 100% magnification, Tray 1, the exposure glass.

0

Function Compatibility


The combination chart given below shows which modes can be used together.


Blank: These modes can be used together.

•: These modes cannot be used together. The first mode selected will be the mode you are working in.

×: These modes cannot be used together. The second mode selected will be the mode you are working in.

The following shows the combinations of functions:





The following combinations are not possible.

^{*1} Covers with 2 Sided → 1 Sided

- *2 Back covers when copying with Auto Paper Select. Possible when printing a stored document.
- *3 2 Sided → 1 Sided with Covers or Slip Sheet
- *4 Combine, Slip Sheet and Document Server
- *5 Book → 2 Sided with Slip Sheet
- *6 Book → 2 Sided with Document Server
- *7 The following combinations are not possible:
 - Left Punch with Right/Top/Center Staple
 - Top Punch with Bottom/2/Center Staple
 - Right Punch with Left/Top/Center Staple
- *8 The following combinations are not possible:
 - Right/Top/Center Staple with Right Fold
 - Bottom Fold with Front/2/Center/Left Top 1 Slant Staple
- *9 The following combinations are not possible:
 - Right Fold with Right/Top Punch
 - Bottom Fold with Right/Top Punch

b

Supplementary Information


Describes the detailed specifications of the respective functions.

Batch mode

You cannot switch between 1-sided and 2-sided originals during copying.

Mixed Sizes mode

- Since small originals may not be correctly aligned with the original guide, the copy image may
 be slanted.
- Copying speed and scanning speed will be reduced.
- When using this function with 1 Sided → 2 Sided mode, always ensure that the originals of each size are in even numbers. If you have an odd number of originals, insert blank sheets to adjust the total.



Copy Face Up

- Copies are delivered face down (in the same order as the original) if Thin Paper, Plain Paper, Middle Thick, or Thick Paper 1 is specified.
- Copies are delivered face up (in reverse order of the original) if Thick Paper 2 or Thick Paper 3
 is specified.
- Tab stock is delivered face down regardless of its paper weight.

Multi Bypass Tray Copy

• The following paper sizes can be selected as the standard sizes:

SRA3D, A3D, B4 JISD, A4DD, B5 JISDD, A5D,
$$12 \times 18D$$
, $11 \times 17D$, $11 \times 15D$, $11 \times 14D$, $10 \times 15D$, $10 \times 14D$, $8^{1}/_{2} \times 14D$, $8^{1}/_{2} \times 13D$, $8^{1}/_{2} \times 11DD$, $8^{1}/_{4} \times 14D$, $8^{1}/_{4} \times 13D$, $8 \times 13D$, $8 \times 10D$, $7^{1}/_{4} \times 10^{1}/_{2}DD$, $5^{1}/_{2} \times 8^{1}/_{2}D$

Preset Reduce/Enlarge

- You can select one of 12 preset ratios (5 enlargement ratios, 7 reduction ratios).
- The following shows the relation between the original and paper sizes at respective scaling factors.
 - Metric version

6

```
400% (Area ratio 16 times): -
200% (Area ratio 4 times): A5 \rightarrow A3, A6 \rightarrow A4, B6 JIS \rightarrow B4 JIS
141% (Area ratio 2 times): A4 \rightarrow A3, A5 \rightarrow A4, A6 \rightarrow A5, B5 JIS \rightarrow B4 JIS, B6 JIS \rightarrow B5
JIS
122%: F → A3, A4 → B4 JIS
115%: B4 IIS → A3
93%: -
82%: F → A4. B4 JIS → A4
75%: B4 IIS → F4. B4 IIS → F
71% (Area ratio 1/2 times): A3 \rightarrow A4, A4 \rightarrow A5
65%: A3 → F
50% (Area ratio ^{1}/_{4} times): A3 \rightarrow A5, F \rightarrow A5
25%: -
```

Inch version

```
400% (Area ratio 16 times): -
200% (Area ratio 4 times): 5^{1}/_{2} \times 8^{1}/_{2} \rightarrow 11 \times 17
155% (Area ratio 2 times): 5^{1}/_{2} \times 8^{1}/_{2} \rightarrow 8^{1}/_{2} \times 14
129\%: 8^{1}/_{2} \times 11 \rightarrow 11 \times 17
121\%: 8^{1}/_{2} \times 14 \rightarrow 11 \times 17
93%: -
85%: F \rightarrow 8^{1}/_{2} \times 11
78%: 8^{1}/_{2} \times 14 \rightarrow 8^{1}/_{2} \times 11
73%: 11 × 15 \rightarrow 8<sup>1</sup>/<sub>2</sub> × 11
65%: 11 × 17 \rightarrow 8<sup>1</sup>/<sub>2</sub> × 11
50% (Area ratio ^{1}/_{4} times): 11 \times 17 \rightarrow 5^{1}/_{2} \times 8^{1}/_{2}
25%: -
```

 You can select a ratio regardless of the size of an original or copy paper. With some ratios, parts of the image might not be copied or margins will appear on copies.

Zoom

- The reproduction ratios you can specify are 25-400%.
- You can select a ratio regardless of the size of an original or copy paper. With some ratios, parts of the image might not be copied or margins will appear on copies.

Auto Reduce/Enlarge


• The machine selects reproduction ratios of between 25-400%.

Duplex

- You cannot use the following copy paper with this function:
 - Paper smaller than A5, $5^{1}/_{2} \times 8^{1}/_{2}$
 - Label paper (adhesive labels)
 - Paper thicker than 220 g/m², 58.6 lb.
 - Paper thinner than 60 g/m², 16 lb.
 - Cardstock
 - Tab stock
 - Envelope
- When an odd number of originals are placed in the ADF, the back of the last page of copied paper is blank.
- During copying, the image is shifted to allow for the binding margin.
- Front and back image quality of copies may differ.

Combine

- In this mode, the machine selects the reproduction ratio automatically. This reproduction ratio depends on copy paper sizes and the number of originals.
- The reproduction ratios selectable by the machine are 25-400%.
- If the calculated ratio is under the minimum ratio, it is automatically adjusted to within available range. However, with some ratios, parts of the image might not be copied.
- You cannot use custom size paper.
- If the orientation of originals is different from that of the copy paper, the machine will automatically rotate the image by 90° to make copies properly.
- If the number of originals placed is less than the number specified for combining, the last page segment is left blank as shown.



Sort

- The number of copies that can be placed on the tray is as follows. When the number of copies
 exceeds capacity, remove copies from the tray. (paper weight: 80 g/m², 20 lb.)
 - Finisher (Upper Tray)

A4, $8^{1}/_{2} \times 11$ or smaller: 500 sheets

B4 JIS,
$$8^{1}/_{2} \times 14$$
 or larger: 250 sheets

• Finisher (Shift Tray)

A4
$$\mathbb{D}$$
, B5 JIS \mathbb{D} , 8 $^{1}/_{2} \times 11\mathbb{D}$: 3000 sheets

A3D, B4 JISD, A4D, B5 JISD,
$$11 \times 17D$$
, $8^{1}/_{2} \times 14D$, $8^{1}/_{2} \times 11D$: 1500 sheets

A5
$$\Box$$
, 5 $^{1}/_{2} \times 8^{1}/_{2}\Box$: 500 sheets

A5
$$\Box$$
, 5 $^{1}/_{2} \times 8^{1}/_{2}\Box$: 100 sheets

• When using the Staple functions, the capacity may be reduced.

Stack

Paper sizes and orientations that can be used with the Shift Stack are as follows:

A4DD, B5 JISDD, A5DD,
$$8^{1}/_{2} \times 11D$$

Staple

- The following type of paper cannot be stapled:
 - Postcard
 - Label paper (adhesive labels)
 - Curled paper
 - · Paper of low stiffness
 - · Paper of mixed sizes
- You can specify how the machine responds if its memory becomes full during copying, or if the number of copies exceeds the capacity of the stapler:
 - · Divides the copies into the number of sheets that can be stapled
 - · Cancels the stapling job
- To specify Left 2, Top 2, or Slant together with 2 Originals or 8 Originals of Combine 1 Side, or 4 Originals or 16 Originals of Combine 2 Sides: specify □ paper for □ orientation originals and specify □ paper for □ orientation originals.
- To specify Left 2, Top 2, or Slant together with Double Copies: specify □ paper for □ orientation originals and specify □ paper for □ orientation originals.
- Even if you place different size originals in the ADF, appropriate size of copy paper can be
 automatically selected and stapled using the Mixed Sizes mode and Auto Paper Select function.
 Load the paper you want to use in the paper trays beforehand. Paper sizes that can be stapled
 when using the Mixed Sizes mode are as follows:
 - A3□ and A4□
 - B4 IIS□ and B5 IIS□
 - $11 \times 17 \square$ and $8^{1}/_{2} \times 11 \square$

- Paper sizes and orientation that can be used in the Staple function and the stapler capacity are as follows: (paper weight: 80 g/m², 20 lb.)
 - Finisher
 A3D, B4 JISD, 11 × 17D, 8¹/₂ × 14D: 50 sheets
 A4DD, B5 JISDD, 8¹/₂ × 11DD: 100 sheets
 - Booklet Finisher
 A3D, B4 JISD, 11 × 17D, 8¹/₂ × 14D, A4DD, B5 JISDD, 8¹/₂ × 11DD: 15 sheets
- When stapling B4JIS \square , $8^{1}/_{2} \times 14\square$ or larger paper sizes, be sure to extend the paper support plate of the finisher tray.
- When the number of copies exceeds tray capacity, copying stops. If this happens, remove the copies from the shift tray, and then resume copying. The tray capacity for the stapled sheets is as follows: (paper weight: 80 g/m², 20 lb.)

A4 \square D, B5 JIS \square D, $8^1/_2 \times 11$ DD: 10 to 100-leaf binding...200 to 30 copies, 2 to 9-leaf binding...150 copies

A3 \square , B4 JIS \square , 11 × 17 \square , 8 $^1/_2$ × 14 \square : 10 to 50-leaf binding...150 to 30 copies, 2 to 9-leaf binding...150 copies

In the Mixed Sizes mode: 2 to 50-leaf binding...30 copies

- You cannot change stapling positions during copying.
- When the original image is rotated, the staple orientation changes by 90°.
- The maximum original image size that can be rotated is as follows: Metric version: A4, Inch version: $8^{1}/_{2} \times 11$
- When using Slant, Left 2, or Top 2 with the Combine, Double Copies or Auto Reduce / Enlarge function, "Blank part will appear. Check orientation." message may appear depending on the orientation of originals and paper you placed. In this case, change the paper orientation.
- When Top or Bottom is selected and the paper with the same orientation as the original is not loaded, the image is rotated and the paper with the same size and the different orientation is selected.
- When Left 2, or Top 2 is selected, the following settings are useful to rotate images appropriately:
 - Auto Reduce / Enlarge or Auto Paper Select
 - Replace Auto Tray Switching with With Image Rotation in User Tools.
- If you select Center for the Booklet or Magazine function, the machine staples the paper, and folds it like a book, then delivers the paper folded.

Punch

- You cannot punch on thick paper heavier than 157 g/m² (41.7 lb.).
- When using Punch and Combine, Double Copies, or Auto Reduce/Enlarge, the message "Blank part will appear. Check orientation." may appear because of the orientation of the original and the copy paper. If this occurs, change the orientation of the copy paper.

- Since punch holes are made in each copy, the punch hole positions vary slightly.
- Punchable paper sizes are as follows:
 - 2 and 4 holes type (2 holes)

$$\Box$$
: SRA3 to A5, 13 × 19.2 to $5^{1}/_{2}$ × $8^{1}/_{2}$

$$\square$$
: A4 to B5 JIS, $8^{1}/_{2} \times 11$, $7^{1}/_{4} \times 10^{1}/_{2}$

• 2 and 4 holes type (4 holes)

$$\square$$
: A4, B5 JIS, $8^1/_2 \times 11$

• 2 and 3 holes type (2 holes)

$$\square$$
: SRA3 to A5, 13 × 19.2 to $5^{1}/_{2}$ × $8^{1}/_{2}$

$$\square$$
: A4 to B5 JIS, $8^{1}/_{2} \times 11$, $7^{1}/_{4} \times 10^{1}/_{2}$

• 2 and 3 holes type (3 holes)

$$\square$$
: A4, B5 JIS, $8^1/_2 \times 11$

• 4 holes type

$$\square$$
: SRA3 to A5, 13 × 19.2 to $5^{1}/_{2}$ × $8^{1}/_{2}$

$$\square$$
: A4 to B5 JIS, $8^{1}/_{2} \times 11$, $7^{1}/_{4} \times 10^{1}/_{2}$

Z-fold

- You cannot use the following paper with this function:
 - Special paper
 - Letterhead
 - Thick paper
 - Thin paper
 - Tab stock
 - Label paper (adhesive labels)
 - Cardstock
- Paper sizes that can be Z-folded are as follows:

A3D, B4 JISD, A4D,
$$12 \times 18D$$
, $11 \times 17D$, $8^{1}/_{2} \times 14D$, $8^{1}/_{2} \times 11D$


- The number of Z-folded copies that can be stacked on the finisher trays is as follows (paper weight: 80 g/m², 20 lb.). When the number of copies exceeds capacity, remove them from the trays.
 - Finisher (Upper Tray, Shift Tray): 30 sheets
 - Finisher shift tray, stapled paper: 10 sheets
- Depending on the Z-fold settings, you may not be able to use Rotate Copy.

6


Even if you place different size originals in the ADF, appropriate size of copy paper can be
automatically selected and Z-folded using the Mixed Sizes mode and Auto Paper Select function.
Load the paper you want to use in the paper trays beforehand. Paper sizes that can be Z-folded
when using the Mixed Sizes mode are as follows (the larger size paper is Z-folded):

A3□ and A4□
B4 JIS□ and B5 JIS□

 $11 \times 17 \square$ and $8^1/_2 \times 11 \square$



- The paper sizes that can be stapled after being Z-folded are A3□, B4 JIS□, and 11 × 17□.
- The number of Z-folded copies that can be stapled is as follows (paper weight: 80 g/m², 20 lb.):
 - 10 Z-folded sheets, 9 Z-folded sheets and 0 to 10 unfolded sheets, 8 Z-folded sheets and 0 to 20 unfolded sheets, 7 Z-folded sheets and 0 to 30 unfolded sheets, 6 Z-folded sheets and 0 to 40 unfolded sheets, 5 Z-folded sheets and 0 to 40 unfolded sheets, 4 Z-folded sheets and 0 to 60 unfolded sheets, 3 Z-folded sheets and 0 to 70 unfolded sheets, 2 Z-folded sheets and 0 to 80 unfolded sheets, 1 Z-folded sheets and 0 to 90 unfolded sheets
- When using this function with 1 Sided → 2 Sided and Mixed Sizes modes, always ensure that
 the originals of each size are in even numbers. If you have an odd number of originals, insert
 blank sheets to adjust the total.



- Depending on the Z-fold settings, you may not be able to use Rotate Copy.
- Even if you have selected Face Up for Copy Eject Face Method in Glass Mode in User Tools, the copies will be delivered face down.
- You cannot specify Punch with Z-fold.

Size Magnification

- If the calculated ratio is over the maximum or under the minimum ratio, it is automatically adjusted
 to within available range. However, with some ratios, parts of the image might not be copied
 or margins will appear on copies.
- The machine selects reproduction ratios of between 25-400%.

Directional Size Magnification

- The reproduction ratios you can specify are 25-400%.
- When entering a percentage ratio, you can specify any value in the permitted range, regardless
 of original or copy paper size. However, depending on settings and other conditions, part of
 the image may not be copied, or margins will appear on copies.
- When entering a size in mm (inch), if the calculated ratio is over the maximum or under the
 minimum ratio, it is automatically adjusted to within available range. However, with some ratios,
 parts of the image might not be copied or margins will appear on copies.

Preset Stamp

• Depending on paper size, if you change the stamp size, parts of the stamp might not be printed.

Date Stamp

- When Date Stamp is used Combine, Magazine, or Booklet function, the date stamp is printed as follows:
 - With the Combine function



2000

• With the Magazine or Booklet function




BCU046

Page Numbering


- When Page Numbering is used with Combine, Magazine, or Booklet function, page numbers are printed as follows:
 - Per Original is selected in Page Numbering in Combine:
 With 1 Sided/2 Sided using the Combine function

6







With the Magazine or Booklet function



Per Copy is selected in Page Numbering in Combine:
 With 1 Sided/2 Sided using the Combine function



• If you combine this function with the Duplex (Top to Top) function and select [P1,P2...] or [1/5,2/5...], page numbers on the back are printed as follows:



- 1. Front
- 2. Back

Stamp Text

• Depending on the stamp position, parts of the text might not be copied.

Margin Adjustment

- If you set a binding margin that is too wide, part of the image may not be copied.
- When making copies in Combine mode, the binding margin is added to the copies after the combination is finished.

Erase

• The width of the erased margin varies depending on the reproduction ratio.

Image Repeat

 Depending on the paper size, ratio, and orientation, parts of repeated images may not be copied.

Centering

 Though the original is set to a different orientation from the paper loaded, the machine will not rotate the image by 90° (Rotate copy).

Booklet/Magazine

- The machine sets the reproduction ratio automatically to meet the paper size and copies the originals together onto the paper.
- The reproduction ratios selectable by the machine are 25-400%.
- If the calculated ratio is under the minimum ratio, it is automatically adjusted to within available range. However, with some ratios, parts of the image might not be copied.
- If the orientation of originals is different from that of the copy paper, the machine will automatically rotate the image by 90° to make copies properly.
- You cannot copy with originals different in size and orientation.
- If the number of originals scanned is less than a multiple of 4, the last page is copied blank.
- In Magazine mode, the copying may take some time after scanning originals.

Covers

- If Blank mode is selected, the cover will not be counted as a copy.
- The settings made under Front Cover Sheet Tray and Back Cover Sheet Tray in User Tools
 determine whether or not the front and back covers are duplex printed.
 - At Mode Selected... Settings made in Cover Sheet Tray will take priority.
 - Full Time... Settings made in Paper Type will take priority.

Designate

When Combine (1 Sided → 2 Sided) has been selected, specified pages will always be copied
on the front of copies in the same way as in Chapters mode.

Slip Sheet

• If you do not copy onto slip sheets, they are excluded from the number of copies counted.

User Tools Menu (Copier/Document Server Features)

This section describes items that can be specified on the Copier/Document Server Features screen. The Copier/Document Server Features screen can be displayed by pressing the [User Tools] key. For details about how to set up these items, see General Settings Guide.

General Features

ltem	Description
Auto Image Density Priority	You can set whether Auto Image Density is "On" or "Off" when the machine is turned on, reset, or modes are cleared.
Original Type Priority	You can select the original type effective when the power is turned on, or modes cleared.
Original Photo Type Priority	When you select "Text / Photo" or "Photo" in "Original Type Priority", you can change the settings of the selected original type.
Original Orientation in Duplex Mode	Set the original orientation when making two-sided copies.
Copy Orientation in Duplex Mode	Set the copy orientation when making two-sided copies.
Reserve Job Mode	You can set whether to reset the mode to the initial state or return to the mode in use before the reserved operation was started when you return to the initial screen after reserved copying finishes.
Reservation Screen Auto- off Timer	You can set the time required until the display is switched to the reserved first job display after reservation is set.
	If you select "Yes", use the numbers keys to enter the time (10-99 seconds). The default setting is 15 seconds.
Max. Copy Quantity	The maximum copy quantity can be set between 1 and 9999.
Manual Original Counter Reset	You can set whether to enable the document counter reset key.
Auto Tray Switching	If you load paper of the same size in two or more trays, the machine automatically shifts to the other when the first tray runs out of paper (when Auto Paper Select is selected.) This function is called "Auto Tray Switching". This setting specifies whether to use Auto Tray Switching or not.

ltem	Description
Dark Background	You can set whether "Dark Background" can be selected as an original type.
Panel Features Default	You can set which items will appear as the function buttons on the basic display.
Image Adjustment Priority	You can set the items, to be preferentially displayed, to the function buttons on the basic display.
Paper Display	You can choose to have the available paper trays and sizes shown on the initial display.
Original Type Display	You can have the original types shown on the initial display.
Alert Sound: Original left on Exposure Glass	The beeper (key tone) sounds if you forget to remove originals after copying.
Job End Call	Choose whether or not the beeper sounds when copying is complete.
Switch Original Counter Display	Specify the original counter display.
Customize Function: Copier	You can assign up to four frequently-used functions to Copy Function keys.
Customize Function: Document Server Storage	You can assign up to four frequently-used functions for scanning documents on the Document Server Storage keys.

Reproduction Ratio

ltem	Description
Shortcut Reduce/Enlarge	You can register up to two frequently used Reduce/Enlarge ratios other than the fixed Reduce/Enlarge ratio and have them shown on the initial display. You can also change registered Reduce/Enlarge ratios.
Reproduction Ratio	Specify the enlargement and reduction ratios that appear if [Reduce / Enlarge] is pressed on the copier screen.
Reduce/Enlarge Ratio Priority	You can set the ratio that has priority when [Reduce / Enlarge] is pressed.
Ratio for Create Margin	You can set a Reduce/Enlarge ratio when registering Create Margin in a shortcut key.

Edit

ltem	Description
Front Margin: Left / Right	Specify left and right margins on the front side of copies in Margin Adjustment mode.
Back Margin: Left / Right	Specify left and right margins on the back side of copies in Margin Adjustment mode.
Front Margin: Top / Bottom	Specify top and bottom margins on the front side of copies in Margin Adjustment mode.
Back Margin: Top / Bottom	Specify top and bottom margins on the back side of copies in Margin Adjustment mode.
1 Sided → 2 Sided Auto Margin: TtoT	In 1 sided to 2 sided Duplex mode, you can specify the margins on the back side.
1 Sided → 2 Sided Auto Margin: TtoB	In 1 sided to 2 sided Duplex mode, you can specify the margins on the back side.
Creep Setting for Magazine	Specify the creep binding margin width.
Erase Border Width	Specify the width of erased border margins with this function.
Erase Original Shadow in Combine	In Combine mode, you can specify whether to erase a 3 mm, 0.1 inch boundary margin around all four edges of each original.
Erase Center Width	Specify the width of the erased center margins with this function.
Front Cover Copy in Combine	You can make a combined copy on the front cover sheet when you select Front Cover mode.
Copy Order in Combine	You can set the copy order in Combine mode to Left to Right or Top to Bottom.
Orientation: Booklet, Magazine	Select the opening orientation of copies made using Booklet or Magazine mode.
Image Repeat Separation Line	You can select a separation line and color using the Image Repeat function from: None, Solid, Broken A, Broken B, or Crop Marks.
Double Copies Separation Line	You can select a separation line and color using the Double Copies function from: None, Solid, Broken A, Broken B, or Crop Marks.

ltem	Description
Separation Line in Combine	You can select a separation line and color using the Combine function from: None, Solid, Broken A, Broken B, or Crop Marks.
Copy on Designating Page in Combine	Specify whether to make a combined copy on the inserted slip sheets in Desig./Chapter mode.
Copy Back Cover	When copying the back cover, you can specify whether to have the back cover outside (outside page) or inside (inside page).
Double Copies Position	You can select the copy position of bottom or left page according to top or right page as the original image position.

Stamp

Item	Description		
Preset Stamp			
Stamp Language	You can select the language of the message printed in Stamp mode.		
Stamp Priority	You can select the stamp type given priority when [Preset Stamp] is pressed.		
Stamp Format	Specify how each of stamps is printed.		
Stamp Color	Sets the stamp print color.		
User Stamp	User Stamp		
Program / Delete Stamp	You can register, change, or delete user stamps.		
Stamp Format: 1 to 5	Specify how each of registered User Stamps 1 to 5 is printed.		
Stamp Color: 1 to 5	Sets the color registered in User Stamp color (1 to 5).		
Date Stamp			
Format	You can select the date format for Date Stamp mode.		
Font	You can select the Date Stamp font.		
Size	You can set the Date Stamp size.		
Superimpose	You can have the Date Stamp printed in white when it overlaps black parts of the image.		

ltem	Description	
Stamp Color	Set the selected priority color when printing the date.	
Stamp Setting	Specify how Date Stamp is printed.	
Page Numbering		
Stamp Format	You can select the page number format given priority when [Page Numbering] is pressed.	
Font	You can select the page number printed in Page Numbering mode.	
Size	You can set the size of the stamp printed in Page Numbering mode.	
Duplex Back Page Stamping Position	You can set the position of the duplex back page number printed in Duplex mode.	
Page Numbering in Combine	You can set page numbering when using the Combine function and the Page Numbering function together.	
Stamp on Designating Slip Sheet	You can select to print the page number onto slip sheets when using the Designate function set to [Copy] and the Page Numbering function together.	
Stamp Position	Specify how each of stamps is printed.	
Superimpose	You can have page numbers printed in white when they overlap black parts of the image.	
Stamp Color	Sets the selected priority color when printing the page number.	
Page Numbering Initial Letter	You can select the page numbering initial letter between "P1, P2/P.1, P.2" and "S1, S2/S.1, S.2".	
Stamp Text		
Font	You can select the Stamp Text font.	
Size	You can set the Stamp Text size.	
Superimpose	You can have the Stamp Text printed in white when it overlaps black parts of the image.	
Stamp Color	Sets the selected priority color when printing the text.	
Stamp Setting	Specify how Date Stamp is printed.	

Input / Output

ltem	Description
SADF Auto Reset	In SADF mode, an original must be set within a specified time after the previous original has been fed. You can adjust this time from 3 to 99 seconds in increments of 1 second.
Copy Eject Face Method in Glass Mode	You can specify the way in which copies are delivered when copying an original placed on the exposure glass.
Memory Full Auto Scan Restart	When memory becomes full while scanning originals, the machine can make copies of scanned originals first, and then automatically proceed scanning remaining originals.
Sort / Stack Shift Tray Setting	You can specify whether to shift the Shift Tray in sort mode or stack mode.
Insert Separation Sheet	You can specify the number of copy pages for inserting the separation sheet from 1 to 999 pages in increments of 1 page.
Letterhead Setting	If you select [Yes] in this function, the machine rotates images correctly.
Staple Position	Specify which Top 2 staples or Bottom shown on the initial display with priority.
Punch Type	Specify which punch type (2 holes or 3 holes) has priority to be shown on the initial display.
Finisher: Staple Position	Specify the stapling position. The optional finisher, or the booklet finisher is required to use this function.
Finisher: Punch Type	Specify the punch type. The optional finisher and multi-hole punch unit are required to use this function.
Simplified Screen: Finishing Types	You can select which key is displayed with higher priority for "Finishing Types" on the Simplified Screen.

Adjust Color Image

	Item	Description
"	round Density of Full Color/Two	The background density is adjusted to skip the texture and copy. You can adjust the background density up to 5 levels when in Full Color.

ltem	Description
Color Sensitivity	You can adjust the color specified to convert in "Convert Color" and the color specified for "Erase Color", in 5 levels.
A.C.S. Sensitivity	This 5-step setting determines the level of the standard used for discriminating between black & white originals and full color originals when "Auto Color Select" is selected.
A.C.S. Priority	This setting determines the copy priority between "Black & White" and "Full Color" when "Auto Color Select" is selected.
Inkjet Output Type	When copying inkjet paper documents, specify the final image quality appropriate to the color of the document.

Administrator Tools

ltem	Description
Menu Protect	You can prevent unauthenticated users from changing the user tools.

INDEX

Chapters		Changing the user color name124
ADF	2	Chapters194
ADF. 25, 26, 34 Adjust color. 6, 117 Adjust Color Image. 246 Adjust U.C.R. 118, 121 Adjusting color. 114 Adjusting colors. 6, 117 Adjusting colors. 116 Adjusting colors based on the selected color. 122 Adjusting colors based on the selected color. 122 Adjusting mage qualities. 7, 118, 120 Adjusting image qualities. 7, 127 Adjusting image qualities. 7, 128 Administrator Tools. 247 Auto color select. 109 Auto Paper Select. 131, 132 Auto Paper Select. 26 Auto Reduce/Enlarge. 9, 69, 232 Auto Start. 27 B Back cover. 190 Background density. 7, 118, 120 Copying onto thick paper. 111 Black and white. 3, 109 Booklet. 183 Booklet/Magazine. 11, 13, 183, 240 Border erase. 163 Befault settings. 106	3 eages full bleed180	Checking the contents of jobs98
Adjust color. 6, 117 Adjust Color Image. 246 Adjust U.C.R. 118, 121 Adjusting color. 114 Adjusting colors based on the selected color. 226 Adjusting copy image density. 127 Adjusting image qualities. 77 Adjusting image qualities. 77 Adjusting image quality. 114 Adjusting image quality. 114 Adjusting mage quality. 114 Adjusting image quality. 115 Convert colors. 3, 110 Copy Face Up. 45, 231 Auto color select. 109 Auto image density. 127 Copying from the multi bypass tray. 52 Auto Paper Select. 26 Auto Reduce/Enlarge. 9, 69, 232 Auto Start. 27 B Back cover. 190 Background density. 7, 118, 120 Base point of Reduce/Enlarge. 66 Basic procedure. 43 Batch. 35, 231 Binding margin. 161 Black and white. 3, 109 Booklet/Magazine. 11, 13, 183, 240 Border erase. 163 C Color backaground. 3, 113 Color background. 3, 113 Color background. 3, 114 Color balance. 6, 114 Color balance. 6, 114 Color balance. 6, 114 Color balance. 6, 114 Color backaground. 3, 113 Color balance. 6, 114 Color backaground into program. 115 Color functions. 109 Combine. 72, 233 Combined auto and manual image density. 128 Copying control on and manual image density. 128 Copying from the wild and manual image density. 128 Copying from the multi bypass tray. 52 Copying from the multi bypass tray. 52 Copying onto the bypass tray. 52 Copying onto thick paper. 64 Copying onto thick paper. 58 Copying originals such as books. 13 Copying originals such as	<u>A</u>	Checking the details of a stored document212
Adjust color	ADF25, 26, 34	Checking the job history101
Adjust Color Image. 246 Adjust U.C.R. 118, 121 Adjusting color. 114 Adjusting colors. 6 Adjusting colors based on the selected color. 6 Adjusting copy image density. 127 Adjusting image qualities. 7 Adjusting image quality. 114 Adjusting image quality. 114 Administrator Tools. 247 Auto color select. 109 Auto image density. 127 Auto paper select. 109 Auto Reduce/Enlarge. 9, 69, 232 Auto Start. 247 Basck cover. 190 Background density. 7, 118, 120 Base point of Reduce/Enlarge. 66 Basic procedure. 43 Batch. 35, 231 Binding margin. 161 Black and white. 3, 109 Booklet. 183 Booklet. 183 Booklet. 183 Booklet. 183 Border erase. 163 Date stamp. 5, 148, 238 <tr< td=""><td></td><td></td></tr<>		
Adjust U.C.R. 118, 121 Color balance program. 115 Adjusting colors. .6 Adjusting colors based on the selected color. .6 Adjusting copy image density. 122 Combine. .7, 118, 120 Adjusting image qualities. .7 Convert colors. .3, 110 Adjusting image quality. .114 Copy Face Up. .45, 231 Administrator Tools. .247 Copying. .43 Auto color select. .109 Copying from the multi bypass tray. .52 Auto mage density. .127 Copying from the Wide LCT. .64 Auto paper select. .131, 132 Copying onto envelopes. .61 Auto Reduce/Enlarge. .96, 92, 322 Copying onto tab stock. .48 Auto Start. .47 Copying onto tab stock. .48 Back cover. .190 Copying onto various types of paper. .11 Basic procedure. .43 Copying originals of various sizes. .37 Copying originals such as books. .13 .13 Back and white. .30 .10 .10 .10 .10 .10 .10	•	Color balance6, 114
Adjusting colors	•	
Adjusting colors	•	Color functions109
Adjusting colors based on the selected color	, -	
122		Combined auto and manual image density128
Adjusting image qualities.		
Adjusting image quality 114 Copy Face Up 45, 231 Administrator Tools 247 Copying 43 Auto color select 109 Copying from the multi bypass tray 52 Auto image density 127 Copying from the Wide LCT 64 Auto paper select 26 Copying onto envelopes 61 Auto Reduce/Enlarge 9, 69, 232 Copying onto tab stock 48 Auto Start 47 Copying onto thick paper 58 Auto Start 47 Copying onto various types of paper 11 Copying originals of various sizes 37 Copying originals such as books 13 Back cover 190 Covers 190, 240 Basic procedure 66 Create margin 139 Basic procedure 43 Creep adjustment 187 Batch 35, 231 Custom size originals 40 Black and white 3, 109 3 Booklet 183 Date 151 Border erase 163 Date 5, 148, 238 Date stamp 5, 148, 238 <td< td=""><td>Adjusting copy image density127</td><td>Convert colors3, 110</td></td<>	Adjusting copy image density127	Convert colors3, 110
Administrator Tools. 247 Copying. 43 Auto color select. 109 Copying from the multi bypass tray. 52 Auto image density. 127 Copying from the Wide LCT. 64 Auto paper select. 26 Copying onto envelopes. 61 Auto Reduce/Enlarge. 9, 69, 232 Copying onto tab stock. 48 Auto Start. 47 Copying onto various types of paper. 11 Copying onto various types of various sizes. 37 Copying originals of various sizes. 37 Copying originals such as books. 13 Covers. 190, 240 Basic procedure. 43 Basic procedure. 43 Batch. 35, 231 Binding margin. 161 Black and white. 3, 109 Booklet. 183 Booklet. 183 Border erase. 163 Date. 5, 148, 238 Default settings. 106	Adjusting image qualities7	Copier functions160, 201
Auto color select. 109 Copying from the multi bypass tray. .52 Auto image density. .127 Copying from the Wide LCT. .64 Auto paper select. .131, 132 Copying onto envelopes. .61 Auto Paper Select. .26 Copying onto tab stock. .48 Auto Reduce/Enlarge. .9, 69, 232 Copying onto thick paper. .58 Auto Start. .47 Copying onto various types of paper. .11 Back cover. .190 Copying originals of various sizes. .37 Covers. .190, 240 Covers. .190, 240 Basic procedure. .43 Create margin. .13 Basic procedure. .43 Creating colors by specifying the density. .123 Batch. .35, 231 Custom size originals. .40 Black and white. .3, 109 Docklet/Magazine. .11, 13, 183, 240 Date. .151 Border erase. .163 Date format. .151 Date stamp. .5, 148, 238 Default settings. .106	Adjusting image quality114	Copy Face Up45, 231
Auto image density	Administrator Tools247	Copying43
Auto paper select. 131, 132 Copying onto envelopes. 61 Auto Paper Select. 26 Copying onto tab stock. 48 Auto Reduce/Enlarge. 9, 69, 232 Copying onto thick paper. 58 Auto Start. 47 Copying onto various types of paper. 11 Copying originals of various sizes. 37 Copying originals such as books. 13 Copying originals such as books	Auto color select109	Copying from the multi bypass tray52
Auto Paper Select. 26 Copying onto tab stock. 48 Auto Reduce/Enlarge. 9, 69, 232 Copying onto thick paper. 58 Auto Start. 47 Copying onto various types of paper. 11 Base Deck cover. 190 Copying originals of various sizes. 37 Copying originals such as books. 13 Create margin. 139 Creating colors by specifying the density. 123 Creep adjustment. 187 Custom size originals. 40 Custom size paper. 56 Date. 151 Date. 151 Date format. 151 Date stamp. 5, 148, 238 Default settings. 106	Auto image density127	Copying from the Wide LCT64
Auto Reduce/Enlarge 9, 69, 232 Copying onto thick paper 58 Auto Start 47 Copying onto various types of paper 11 B Copying onto various sizes 37 Copying originals of various sizes 37 Copying originals such as books 13 Covers 190, 240 Base point of Reduce/Enlarge 66 Basic procedure 43 Batch 35, 231 Creep adjustment 187 Custom size originals 40 Custom size paper 56 Black and white 3, 109 Booklet 183 Booklet/Magazine 11, 13, 183, 240 Date 151 Date stamp 5, 148, 238 Default settings 106	Auto paper select131, 132	Copying onto envelopes61
Auto Start	Auto Paper Select26	Copying onto tab stock48
Copying originals of various sizes	Auto Reduce/Enlarge9, 69, 232	Copying onto thick paper58
Back cover 190 Background density 7, 118, 120 Base point of Reduce/Enlarge 66 Basic procedure 43 Batch 35, 231 Binding margin 161 Black and white 3, 109 Booklet 183 Booklet/Magazine 11, 13, 183, 240 Border erase 163 Date format 151 Date stamp 5, 148, 238 Default settings 106	Auto Start47	Copying onto various types of paper11
Back cover	В	Copying originals of various sizes37
Background density		Copying originals such as books13
Base point of Reduce/Enlarge 66 Basic procedure 43 Batch 35, 231 Binding margin 161 Black and white 3, 109 Booklet 183 Border erase 163 Date format 151 Date stamp 5, 148, 238 Default settings 106		Covers190, 240
Basic procedure 43 Creep adjustment 187 Batch 35, 231 Custom size originals 40 Binding margin 161 Custom size paper 56 Black and white 3, 109 Booklet 183 Booklet/Magazine 11, 13, 183, 240 Date 151 Border erase 163 Date format 151 Date stamp 5, 148, 238 Default settings 106		Create margin139
Batch 35, 231 Custom size originals 40 Binding margin 161 Custom size paper 56 Black and white 183 D Booklet 183 D D Booklet/Magazine 11, 13, 183, 240 Date 151 Border erase 163 Date format 151 Date stamp 5, 148, 238 Default settings 106		Creating colors by specifying the density123
Binding margin	·	Creep adjustment187
Black and white		Custom size originals40
Booklet		Custom size paper56
Booklet/Magazine 11, 13, 183, 240 Date 151 Border erase 163 Date format 151 Date stamp 5, 148, 238 Default settings 106		D
Border erase 163 Date format 151 C Date stamp 5, 148, 238 Default settings 106		D
Date stamp		
Default settings106	Border erase163	
1/2	C	·
	Center erase	
Contain a 177 240		
Cl		
Changing the color balance		
Cl. : d. ft.		-
Cl. : d. L. (.		
Character the ender state		_
Changing the password212 Delivery order45		Delivery order45

Displaying stored documents.	Designate192, 240	G
Derectable original sizes		General Features 241
Heading Directional size magnification 238 Heading 238 Directional size magnification (inch) 237 Displaying stored documents 223 Document Server 95, 201 Document Server display 202 Double copies 176 Downloading stored documents 223 Image density 125 Image density 126 Image density 127 Image density 128 Image position of Combine 77 244 Initial display 14, 22, 106, 203 Inkjet output 173, 246 Initial display 14, 22, 106, 203 Inkjet output 189 Interrupt Copy 189 Interrupt		
Directional size magnification (inch)		Generalion copy129
Displays Stored documents 223 How to read this manual 204 100 205 206 207 20	_	Н
Displaying stored documents.	Directional size magnification (inch)137	Highlight pen129
Displaying stored documents. 223 Document Server 95, 201 Document server display. 202 Double copies 176 Downloading stored documents 223 Image position of Combine. 75 Image position of Combine. 78 Image position of Combine. 78 Image position of Combine. 79 Image position of	Display22	3 3 1
Document Server display	Displaying stored documents223	- 1
Double copies	Document Server95, 201	I
Downloading stored documents	Document server display202	
Duplex	Double copies176	Image density127
Edit	Downloading stored documents223	Image position of Combine75
Edit	Duplex9, 72, 233	Image repeat173, 240
Inkjet output.	F	Initial display14, 22, 106, 202
Enlarging originals		Inkjet output129
Enlarging originals by specifying the paper size		Input / Output246
Envelopes		Insert separation sheet86
Interrupt Copy.		Insert sheet197
Erase 163, 240 Erase border 164, 165, 167, 168 Erase center 166, 167, 168 Erase center/border 163, 168 Erase color 111 Erase inside 169 Erase outside 171 Erase specified color 3 Exposure glass 25, 26, 33 Left Original Beeper 33 Loading envelopes in the Wide LCT 63 Loading tab stock in the Wide LCT 64 M Magazine 11, 13, 183, 183 First printing number 154, 155, 156 Managing jobs 97 First printing page 154, 155, 156 Manual image density 127 Folding copies to make a booklet 183 Manual paper select 133 Folding copies to make a magazine 183 Manual paper select 133 Folding copies to make a magazine 183 Manual sor this machine 126 Front cover 190 Margin adjustment 161, 233 Full color 3, 109 Mirror image 173 <td< td=""><td></td><td>Interrupt Copy44</td></td<>		Interrupt Copy44
Erase border 164, 165, 167, 168 Erase center 166, 167, 168 Erase center/border 163, 168 Erase color 111 Erase inside 169 Erase outside 171 Erase specified color 3 Exposure glass 25, 26, 33 Left Original Beeper 33 Loading envelopes in the Wide LCT 64 Loading tab stock in the Wide LCT 64 Face up 45 Finishing 83 Magazine 11, 13, 183, 187 First printing number 154, 155, 156 Managing jobs 97 First printing page 154, 155, 156 Manual image density 127 Folding copies to make a booklet 183 Manual paper select 133 Folding copies to make a magazine 183 Manuals for this machine 129 Front cover 190 Margin adjustment 161, 236 Full color 3, 109 Mirror image 176 Mix 1 & 2 sided 186	•	Invert179
Erase center. 166, 167, 168 Job List screen. 97 Erase center/border. 163, 168 Job Order. 97 Erase color. 111 Job Preset. 47 Erase inside. 169 L Erase outside. 171 L Erase specified color. 3 Left Original Beeper. 33 Exposure glass. 25, 26, 33 Left Original Beeper. 33 Loading envelopes in the Wide LCT. 64 Loading tab stock in the Wide LCT. 64 Loading tab stock in the Wide LCT. 64 M Magazine. 11, 13, 183, 183 First printing number. 154, 155, 156 Managing jobs. 97 First printing page. 154, 155, 156 Manual image density. 127 Folding copies to make a booklet. 183 Manual paper select. 133 Folding copies to make a magazine. 183 Manual sfor this machine. 129 Front cover. 190 Margin adjustment. 161, 236 Full color. 3, 109 Mirror image. <		1
Erase center/border 163, 168 Job Order 97 Erase color 111 Job Preset 47 Erase inside 169 L Erase specified color 3 Left Original Beeper 33 Exposure glass 25, 26, 33 Left Original Beeper 33 Face down 45 Loading envelopes in the Wide LCT 64 Face up 45 M Magazine 11, 13, 183, 183 First printing number 154, 155, 156 Managing jobs 97 First printing page 154, 155, 156 Manual image density 127 Folding copies to make a booklet 183 Manual paper select 133 Folding copies to make a magazine 183 Manual sport this machine 126 Front cover 190 Margin adjustment 161, 239 Full color 3, 109 Mirror image 179 Function compatibility 227 Missing image area 28 Mix 1 & 2 sided 183		
Erase color. 111 Job Preset 47 Erase inside 169 L L Erase outside 171 L Last number 154, 153 Exposure glass 25, 26, 33 Left Original Beeper 33 Face down 45 Loading envelopes in the Wide LCT 62 Face up 45 M M Finishing 83 Magazine 11, 13, 183, 183 First printing number 154, 155, 156 Managing jobs 97 First printing page 154, 155, 156 Manual image density 127 Folding copies to make a booklet 183 Manual paper select 133 Folding copies to make a magazine 183 Manuals for this machine 129 Frequently used functions 14, 102 Map 129 Front cover 190 Margin adjustment 161, 239 Full color 3, 109 Mirror image 179 Function compatibility 227 Missing image area 28 Mix 1 & 2 sided 186		
Erase inside 169 Erase outside 171 Erase specified color 3 Exposure glass 25, 26, 33 Left Original Beeper 3 Loading envelopes in the Wide LCT 64 Loading tab stock in the Wide LCT 64 Face up 45 Finishing 83 Magazine 11, 13, 183, 183 First printing number 154, 155, 156 Manual image density 97 First printing page 154, 155, 156 Manual image density 127 Folding copies to make a booklet 183 Manual paper select 133 Folding copies to make a magazine 183 Manuals for this machine 129 Front cover 190 Margin adjustment 161, 236 Full color 3, 109 Mirror image 179 Function compatibility 227 Missing image area 26 Mix 1 & 2 sided 188		
Erase outside		Job Preset47
Erase specified color. 3 Last number. 154, 153 Exposure glass. 25, 26, 33 Left Original Beeper. 33 Ferman State of State		L
Exposure glass		Last number 154 155
Loading envelopes in the Wide LCT	•	
Loading tab stock in the Wide LCT	Exposure glass25, 26, 35	
Face down	F	-
Finishing	Face down45	
Finishing 83 Magazine 11, 13, 183, 183 First printing number 154, 155, 156 Managing jobs 97 First printing page 154, 155, 156 Manual image density 127 Folding copies to make a booklet 183 Manual paper select 133 Folding copies to make a magazine 183 Manuals for this machine 129 Frequently used functions 14, 102 Map 129 Front cover 190 Margin adjustment 161, 239 Full color 3, 109 Mirror image 179 Function compatibility 227 Missing image area 28 Mix 1 & 2 sided 188	Face up45	M
First printing number	·	Magazine11, 13, 183, 187
First printing page 154, 155, 156 Manual image density 127 Folding copies to make a booklet 183 Manual paper select 133 Folding copies to make a magazine 183 Manuals for this machine 129 Frequently used functions 14, 102 Map 129 Front cover 190 Margin adjustment 161, 239 Full color 3, 109 Mirror image 179 Function compatibility 227 Missing image area 28 Mix 1 & 2 sided 188		Managing jobs97
Folding copies to make a booklet		Manual image density127
Folding copies to make a magazine		,
Frequently used functions 14, 102 Map 129 Front cover 190 Margin adjustment 161, 239 Full color 3, 109 Mirror image 179 Function compatibility 227 Missing image area 28 Mix 1 & 2 sided 188		Manuals for this machine1
Front cover		Map129
Full color	• •	Margin adjustment161, 239
Function compatibility		Mirror image179
Mix 1 & 2 sided188	•	•
	,	Mix 1 & 2 sided188
		Mixed sizes231

Mixed Sizes37	R	
Multi bypass tray52, 55, 56	D. III. a sat	
Multi bypass tray copy231	Readable orientation	
N	Recalling a stored program	
	Recalling the color balance	
Names of major options	Recalling the registered custom size	
New job	Recommended originals	
Non-compatible originals26	Reduce/Enlarge Reducing originals	
0	Reducing originals by specifying the p	
One-Sided Combine9, 75		
Options21	Registering a custom size	
Original orientation 30, 32, 140, 143, 148, 151	Registering functions	
Original orientation and completed copies72	Registering the color balance	
Original size25	Registering the default functions	106
Original type129	Registering the user stamp	146
Original weight25	Regular size originals	
Originals25	Regular size paper	55
Originals and copy orientation74	Repeat	173
P	Reproduction Ratio	242
<u>-</u>	Rotate copy	132
Page numbering	S	
Pale129		
Photo	SADF	
Placing originals	Sample copy	
Placing originals in the ADF34	Sample Print	
Placing originals of different sizes37	Saving paper	
Placing originals on the exposure glass33	Scan position	
Positive/Negative	Scanner functions	
Preset Reduce/Enlarge	Searching by file name	
Preset stamp	Searching by user name	
Preview display204	Searching for stored documents	
Primary colors	Selecting a color mode	
Printer functions	Selecting a preset ratio	
Printing a list of user colors	Selecting copy paper	
Printing a specified page218	Series copies	
Printing a specified range219, 220	Sharp/SoftShift Sort	
Printing stored documents	Shift stack	
Printing the first page	Shift tray off in sort/stack	
Program	Simplified display	
Programming defaults	Size magnification	
Punch	Sizes difficult to detect	
Punch hole positions90	Slip shoot	

Sort83, 233
Specifications225
Specified area repeat173, 174
Specifying a file name208
Specifying a password209
Specifying a reproduction ratio
Specifying a user name208
Specifying original sizes39
Specifying the reproduction ratio135, 136
Stack21, 83, 87, 234
Stamp140, 244
Stamp color142, 145, 150, 153, 159
Stamp density142
Stamp position140, 142, 143, 145, 148, 151,
154, 159
Stamp size
Stamp text
Stamping on copies5
Staple21, 83, 88, 234
Staple (Center)21
Stapling position88
Storing data206
Storing data in the Document Server95
Supplementary information231
Symbols20
Т
Tab stock11, 21, 48, 59, 64
Text
Text/Photo
Text/Photo sensitivity
Thick paper
Thin mode
-1
Thin Paper
Two-Sided Combine9, 79
U
Unreadable orientation30, 32
User color121
User stamp5, 143, 147
w
Web Image Monitor223
What you can do with this machine3, 9

85
173
64
3, 93, 236
3, 93, 236

In accordance with IEC 60417, this machine uses the following symbols for the main power switch:

- means POWER ON.
- **U** means STAND BY.

Trademarks

Windows® is a registered trademark of Microsoft Corporation in the United States and/or other countries.

Adobe, Acrobat, Acrobat Reader, PostScript, and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

