Model PE-MF2 Machine Code: M018/M019 Copiers SERVICE MANUAL

> November 2008 Subject to change

Safety Notices

Important Safety Notices

Prevention of Physical Injury

- 1. Before disassembling or assembling parts of the machine and peripherals, make sure that the machine power cord is unplugged.
- 2. The wall outlet should be near the machine and easily accessible.
- 3. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
- 4. The machine drives some of its components when it completes the warm-up period. Be careful to keep hands away from the mechanical and electrical components as the machine starts operation.
- The inside and the metal parts of the fusing unit become extremely hot while the machine is operating. Be careful to avoid touching those components with your bare hands.

Health Safety Conditions

Toner is non-toxic, but if you get either of them in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

Observance of Electrical Safety Standards

The machine and its peripherals must be serviced by a customer service representative who has completed the training course on those models.

Safety and Ecological Notes for Disposal

- Do not incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.
- 2. Dispose of used toner, the maintenance unit which includes developer or the organic photoconductor in accordance with local regulations. (These are non-toxic supplies.)
- 3. Dispose of replaced parts in accordance with local regulations.

WARNING

• To prevent a fire or explosion, keep the machine away from flammable liquids, gases, and aerosols. A fire or an explosion might occur.

• The Controller board on the MF model contains a lithium battery. The danger of explosion exists if a battery of this type is incorrectly replaced. Replace only with the same or an equivalent type recommended by the manufacturer. Discard batteries in accordance with the manufacturer's instructions and local regulations.

Laser Safety

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

WARNING

• Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

AWARNING

WARNING:

Turn off the main switch before attempting any of the procedures in the Laser Optics Housing Unit section. Laser beams can seriously damage your eyes.

CAUTION MARKING:



Symbols, Abbreviations and Trademarks

This manual uses several symbols and abbreviations. The meaning of those symbols and abbreviations are as follows:

	See or Refer to
$\langle \overline{\mathcal{O}} \rangle$	Clip ring
Ĩ	Screw
Ē	Connector
£	Clamp
C	E-ring
SEF	Short Edge Feed
LEF	Long Edge Feed





Short Edge Feed (SEF)

Long Edge Feed (LEF)

Trademarks

Microsoft[®], Windows[®], and MS-DOS[®] are registered trademarks of Microsoft Corporation in the United States and /or other countries.

PostScript[®] is a registered trademark of Adobe Systems, Incorporated.

 $\mathsf{PCL}^{\circledast}$ is a registered trademark of Hewlett-Packard Company.

Ethernet[®] is a registered trademark of Xerox Corporation.

PowerPC[®] is a registered trademark of International Business Machines Corporation.

Other product names used herein are for identification purposes only and may be trademarks of their respective companies. We disclaim any and all rights involved with those marks.

TABLE OF CONTENTS

Safety Notices	1
Important Safety Notices	1
Laser Safety	2
Symbols, Abbreviations and Trademarks	3
Trademarks	3
1. Product Information	
Specifications	9
Machine Overview	
Component Layout	
Paper Path	12
Drive Layout	
Machine Configuration	
Guidance for Those Who are Familiar with Predecessor Products.	
2. Installation	
Installation Requirements	
Environment	
Machine level	
Machine Space Requirement	
Power Requirements	
Installation Procedure	
3. Preventive Maintenance	
Preventive Maintenance	
4. Replacement and Adjustment	
Before You Start	
Special Tools	
Exterior Covers	
Rear Cover	
Operation Panel	
Right Cover	
Left Cover	
Front Cover Unit	
Laser Optics	
Caution Decal Location	

Laser Optics Housing Unit	
AIO Cartridge	
AIO Cartridge (All In One Cartridge)	
Black AIO Motor	
Color AIO Motor	
Image Transfer	40
Image Transfer Belt Unit	
ITB (Image Transfer Belt) Cleaning Unit	41
Agitator Motor	
ITB (Image Transfer Belt) Contact Motor	
ITB (Image Transfer Belt) Contact Sensor	45
TM (Toner Mark) Sensor Base	
Waste Toner Bottle Set Sensor	47
Waste Toner Overflow Sensor	
Paper Transfer	
Transfer Unit	
Transfer Roller	
Registration Roller	
Registration Sensor	53
Registration Clutch	53
Image Fusing	
Fusing Unit	
Fusing Lamp	
Transport/Fusing Motor	
Paper Feed	
Paper Feed Clutch	
Paper Feed Roller	
Separation Pad	60
Paper End Sensor	61
Paper Exit	63
Paper Exit Roller	63
Paper Exit Sensor	64
Electrical Components	

Controller Board	66
EGB (Engine Board)	68
FCU	70
Interlock Switches	70
Fusing Fan Motor	71
LSU Fan Motor	72
ID Chip Board	73
PSU	73
High Voltage Power Supply Board	75
Temperature/Humidity Sensor	76
Duplex Motor	76
Speaker	
EEPROM	
ADF	80
ADF Unit	80
Original Tray	
ADF Feed Unit	
ADF Separation Pad	
ADF Front Cover	83
ADF Rear Cover	83
ADF Cover	
ADF Motor	
Original Set Sensor	86
ADF Cover Open Sensor	
ADF Feed Sensor	
ADF Drive Board	
Scanner	
Scanner Unit	
Scanner Top Cover	
Scanner Carriage Unit	
Exposure Lamp	
Lamp Stabilizer Board	
Scanner Motor	

5. System Maintenance Reference

Service Program
Overview
Configuration Page Information100
Overview100
Firmware Updating101
Checking the Machine Firmware Version101
Updating the Controller Firmware
Updating Failure
Updating the Engine Firmware
Boot Loader Firmware
6. Troubleshooting
Troubleshooting Guide
Image Problems
Overview
Checking a Sample Printout112
INDEX

1. Product Information

Specifications

See "Appendices" for the following information:

- "General Specifications"
- "Supported Paper Sizes"

Machine Overview

Component Layout

Engine



1



1. Feed Sensor5. Exit Roller2. Feed Roller5. Exit Roller3. Separation Roller6. Original Set Sensor4. Pick-up Roller7. DF Exposure Glass

Scanner



Paper Path

Engine



m018v107

- 1. Paper path from tray 1
- 2. Duplex path
- 3. By-pass tray
- 4. Paper path from tray 2 (optional)



ADF

1. Original path

Drive Layout



1. Color AIO Motor	5. Registration Clutch
2. Black AIO Motor	6. Paper Feed Clutch
3. Duplex Motor	7. Agitator Motor
4. Transport/Fusing Motor	8. ITB (Image Transfer Belt) Contact Motor

• Color AIO Motor:

This drives the color AIOs (Cyan, Magenta and Yellow)

• Black AIO Motor:

This drives the black AIO and the ITB (Image Transfer Belt).

• Duplex Motor:

This drives the paper exit roller and the duplex roller.

• Transport/Fusing Motor:

This drives the fusing unit, paper feed roller, registration roller and paper exit roller via the paper feed clutch, registration clutch and gears.

• Registration Clutch:

This transfers drive from the transport/ fusing motor to the registration roller.

• Paper Feed Clutch:

This transfers drive from the transport/ fusing motor to the paper feed roller.

• Agitator Motor:

This moves the agitators in the waste toner bottle.

• ITB Contact Motor:

This moves the ITB into contact with and away from the color OPCs.

1

Machine Configuration

[MF2b]







M018v501

Models	Duplex Unit	Optional Memory	Optional Tray (G849)	DDST (GDI)	PCL PS	Fax
PE-MF2b (M018)	Auto	N	500x1	Y	N	Y
PE-MF2c (M019)	Auto	Y	500x1	N	Y	Y

Guidance for Those Who are Familiar with Predecessor Products

The M018/M019 series models are similar to the G181/G183/G184 series. If you have experience with those products, the following information will be of help when you read this manual.

Different Points from Previous Products

	M018/M019	G181/G183/G184
Print Cartridge (AIO)	Longer life Print Cartridge (AIO)	-
Operation Panel	Four separated menu keys and user tool button	One menu key and no user tool button

Installation Requirements



- 1. Temperature Range: 10°C to 32°C (50°F to 89.6°F)
- 2. Humidity Range: 15% to 80% RH
- 3. Ambient Illumination: Less than 2,000 lux (do not expose to direct sunlight)
- 4. Ventilation: 3 times/hr/person
- 5. Do not put the machine in areas that get sudden temperature changes. This includes:
 - Areas directly exposed to cool air from an air conditioner
 - Areas directly exposed to heat from a heater.
- 6. Do not put the machine in areas that get exposed to corrosive gas.
- 7. Do not install the machine at locations over 2,500 m (8,125 ft.) above sea level.
- 8. Put the machine on a strong, level base. (Inclination on any side must be no more than 5 mm.)
- 9. Do not put the machine in areas with strong vibrations.

Machine level

Front to back: Within 5 mm (0.2") of level Right to left: Within 5 mm (0.2") of level

2

Machine Space Requirement

Put the machine near the power source with these clearances:



Left side: Over 20 cm (7.9") Rear: Over 20 cm (7.9")

Right side: Over 10 cm (4")

Front: Over 70 cm (27.5")

Top: Over 24 cm (9.5")

Power Requirements

- Make sure that the plug is tightly in the outlet.
- Avoid multi-wiring.
- Make sure that you ground the machine.

Input voltage level	120 V, 60 Hz: More than 11 A (for North America) 220 V to 240 V, 50 Hz/60 Hz: More than 6 A (for Europe/ Asia)	
Permitted voltage fluctuation: 10%		
Do not set anything on the power cord.		

Installation Procedure

Refer to the Quick Installation Guide for details about installing the machine.

2. Installation

Preventive Maintenance

See "Appendices" for the "User Replaceable Items".

3. Preventive Maintenance

4. Replacement and Adjustment

Before You Start

- If there are printer jobs in the machine, print out all jobs in the printer buffer.
- Turn off the main power switch and unplug the machine before you do the procedures in this section.

Special Tools

- PC: Windows 2000/XP/Vista, Windows Server 2003/2003 R2, or Mac OS X.
- USB cable or Crossover cable

Exterior Covers

• Turn off the main power switch and unplug the machine before you do the procedures in this section.

Rear Cover



1. Rear tray cover [A]



2. Rear cover [B] (x 2)

Operation Panel



m018r512

1. Open the top cover [A].



2. Open the front cover [B].

3. Front harness cover [C] (🖉 x 1)



- m018r523

Right Cover

- 1. Rear cover (🖝 p.25)
- 2. Operation panel (🖝 p.26)



3. Right cover [A] (🕅 x 4)

Note

• Top front screw: M3x8, others: M4x10

Left Cover

1. Rear cover (🖝 p.25)

27

2. Operation panel (🖝 p.26)



m018r525

3. Left cover [A] (x 3, hook at arrow mark)

Note

• Top front screw: M3x8, others: M4x10

Front Cover Unit

- 1. Rear cover (🖝 p.25)
- 2. Operation panel (🖝 p.26)
- 3. Transfer unit (🖝 p.50)
- 4. Right cover (🖝 p.27)



m018r526

m018r527

5. Cover link gear unit [A] (\mathscr{F} x 2)



- 6. Release the belt [B]
- 7. Front cover unit [C] (🖗 x 4)

Laser Optics

WARNING

• Turn off the main power switch and unplug the machine before beginning any of the procedures in this section. Laser beams can cause serious eye injury.

Caution Decal Location

Caution decals are attached as shown below.







• Be sure to turn off the main power switch and disconnect the power plug from the power outlet before beginning any disassembly or adjustment of the laser unit. This printer uses a class IIIb laser beam with a wavelength of 780 nm and an output of 7 mW. The laser can cause serious eye injury.

Laser Optics Housing Unit

- 1. Rear cover (p.25)
- 2. Controller box cover (p.66 "Controller Board")
- 3. Remove the controller bracket (r p.68 "EGB (Engine Board)")

4



m018r510

4. Disconnect the three harnesses from CN301, 302 and 303 on the EGB (IIII x 3).



m018r512

5. Open the top cover [A].



6. Lift up the hook [B] of the harness guide at the rear-left frame and slide the harness guide to the right.



m018r515

- 7. Remove the springs [D] (left side and right side).
- 8. Stoppers [C] (x 2 each; left side and right side)



9. Remove the laser optics housing unit [E] from the top cover and place it on the main body.

Note

• Always use two hands when carrying the laser optics housing unit. Be sure not to drop the laser optics housing unit.





- 10. Take out the harnesses [F] (🛱 x 1).
- 11. Pull out the harnesses from the rear side.



m018r519

12. Remove the laser optics housing unit.

After replacing the laser optics housing unit

Comportant 1

• Do the following step 4 with the front cover of the machine open.

m018r517



- 1. Open the front cover and turn on the machine.
- Look for the lot number [A] attached to the new laser optics housing unit. Then look for this lot number on the information sheet (this sheet will be released separately, and will contain lists of input data for each lot number)

Input the data for this lot number from the information sheets with steps 3 to 7 below.

- 3. Open the front cover and turn on the machine.
- Input the setting values for the laser optics housing unit ("User Tools" > "Maintenance Mode" > "Engine Maintenance" > "LSU Adjustment").
- 5. Close the front cover.
- 6. Execute "Color Registration" in the "Engine Maintenance" menu.
- Adjust the registration settings for each tray and for the front and rear sides of the paper with the "Engine Maintenance" menu if necessary.

RTB 13 Steps were added after step 6.
4

AIO Cartridge

AIO Cartridge (All In One Cartridge)

1. Open the top cover.



2. AIO cartridge [A]

Black AIO Motor

1. Left cover (🖝 p.27)



m018r531

m018r532

2. Disconnect the fusing connector [A] and remove the fusing relay harness [B] (hooks).



m018r533

3. Fusing harness guide [C] (🖉 x 2)



- 4. Disconnect the connectors shown by arrows in the above picture and release all harnesses on the harness guide [D].
- 5. Harness guide [D] (P x 4)
- 6. Interlock switch base (🖝 Interlock Switches)
- 7. Controller bracket (
 p.66 "Controller Board")
- 8. Disconnect the connector (CN305) on the EGB.



9. LSU fan motor base [E] (🌶 x 2, 📫 x 1)



m018r536

10. Drive unit [F] (🖗 x 4)



m018r537

- 11. Drive unit guide [G] (x 3)
- 12. Black AIO gear [H] (snap ring x 1)



13. Black AIO motor [I] (x 3)

Color AIO Motor

1. Drive unit (🖝 p.35 "Black AIO Motor")



m018r537a

- 2. Drive unit guide [A] (🖗 x 3)
- 3. Color AIO gears [B] (ring stopper x 1 each)







4

m018r538

4. Color AIO motor [C] (🖗 x 3)

Image Transfer

Image Transfer Belt Unit

- 1. Remove all the AIO cartridges (🖝 p.35).
- 2. Transfer unit (🖝 p.50)



3. Pull out the waste toner bottle [A].



m018r529a

m018r691

- 4. Release the hook [B] under the guide plate.
- 5. Move the guide plate [C] underneath the fusing unit to the left, and then remove it.



6. Pull out the image transfer belt unit [D] ($\mathscr{P} \times 2$).

After replacing the image transfer belt unit

🔂 Important

- Do the following step 2 with the front cover of the machine open.
- 1. Open the front cover and turn on the machine.
- 2. Execute "Reset Transfer Unit Life Counter" with the "Engine Maintenance" menu.
- 3. Close the front cover.
- 4. Execute "Trans. Belt Adjust" with the "Engine Maintenance" menu.
- 5. Adjust the registration settings for each tray and for the front and rear sides of the paper with the "Engine Maintenance" menu if necessary.

ITB (Image Transfer Belt) Cleaning Unit

Note

- The ITB cleaning unit contains waste toner. When removing the ITB cleaning unit, put it on a sheet of paper.
- 1. Image transfer belt unit (🖝 p.40)



- 2. Left handle [A] (hook, bushing x 1)
- 3. Right handle [B] (hook, bushing x 1)





m018r571

4. ITB cleaning unit [C] (𝔅 x 2)

Agitator Motor

1. Right cover (🖝 p.27)



2. Motor bracket [A] (🎘 x 2)



m018r542

3. Agitator motor assembly [B] (🎘 x 1, 💷 x 1)



4. Agitator motor [C] (x 2)

ITB (Image Transfer Belt) Contact Motor

1. Agitator motor (🖝 p.42)



- 2. Release the wire [A].
- 3. ITB contact motor assembly [B] (P x 1, 🕬 x 1)



4. ITB contact motor [C] (x 2)

ITB (Image Transfer Belt) Contact Sensor

- 1. Right cover (🖝 p.27)
- 2. High voltage power supply board (🖝 p.75)





3. ITB contact sensor assembly [A] (𝒫 x 1, 🕮 x 1)





4. ITB contact sensor [B] (hooks)

TM (Toner Mark) Sensor Base

- 1. Open the top cover.
- 2. Remove all AIO cartridges (🖝 p.35).
- 3. Slide the ITB unit to the front side or remove it.
- 4. Rear cover (🖝 p.27)
- 5. Controller box cover (🖝 p.66 "Controller Board")
- 6. Controller bracket (🖝 p.68 "EGB (Engine Board)")



m018r689

7. Disconnect CN306 on the EGB (🛱 x 1).



- 8. Harness cover [A] (hook)
- 9. TM sensor base [B]

Waste Toner Bottle Set Sensor

- 1. Remove all AIO cartridges. (🖝 p.35)
- 2. Image transfer belt unit (🖝 p.40)
- 3. EGB (🖝 p.68)



4. Remove two screws [A] for the waste toner sensor base.



5. Waste toner sensor base [B]



m018r609

m018r610

- 6. Remove the mylar fixing three hooks of the waste toner bottle set sensor.
- 7. Waste toner bottle set sensor [C] (hooks, x 1)

Note

• When reinstalling the waste toner bottle set sensor, connect it to the white connector of the harness.

Waste Toner Overflow Sensor

- 1. Remove all AIO cartridges. (🖝 p.35)
- 2. Image transfer belt unit (🖝 p.40)
- 3. EGB (🖝 p.68)
- 4. Waste toner sensor base (🖝 p.47 "Waste Toner Bottle Set Sensor")



- 5. Remove the mylar fixing three hooks of the waste toner bottle set sensor.
- 6. Waste toner overflow sensor [A] (hooks, 📬 x 1)

Note

• When reinstalling the waste toner overflow sensor, connect it to the black connector of the harness.

Paper Transfer

Transfer Unit

1. Open the front cover.



m018r549

- 2. Release the locks [A].
- 3. Transfer unit [B]

Transfer Roller

1. Transfer Unit (🖝 p.50)



1.

Release the two hooks [A] at both sides of the transfer unit.



2. Open the transfer roller unit [B] and remove it.



m018r554

3. Transfer roller assembly [C] ($\mathscr{P} \times 2$)



- 4. Release the holder [D] at the left side of the transfer roller unit (hook).
- 5. Transfer roller [E]

51

Registration Roller

- 1. Transfer unit (🖝 p.50)
- 2. Transfer roller unit (🖝 p.50)



m018r557

- 3. Tension springs [A] (both sides)
- 4. Registration idle roller [B] (C x 2, gear x 1, bushing x 2)
- 5. Registration roller [C] (C x 2, gear x 2, bushing x 2)

Reassembling the registration roller unit



m018r559

When installing the tension spring, make sure that the tension spring correctly hooks onto the bushing of the registration idle roller as shown above [A].

4

Registration Sensor

- 1. Rear cover (🖝 p.25)
- 2. Right Cover (🖝 p.27)



m018r560





4. Registration sensor [B] (hooks)

Registration Clutch

- 1. Rear cover (🖝 p.25)
- 2. Left cover (🖝 p.27)
- 3. Transport/Fusing motor (🖝 p.57)



m018d592

4. Registration clutch [A] (🕅 x 1)

Image Fusing

- Make sure that the fusing unit is cool before you touch it. The fusing unit can be very hot.
- Make sure to restore the insulators, shields, etc after you service the fusing unit.

Fusing Unit

- 1. Open the front cover.
- 2. Rear cover (🖝 p.25)
- 3. Right cover (🖝 p.27)
- 4. Left cover (🖝 p.27)





5. Disconnect the connectors [A] (hook) [B].

Note

• The sponge [C] clamps the harness. Install this sponge in the same position after reinstalling the fusing unit.



6. Fusing unit [D] (🖉 x 2)

Fusing Lamp

1. Fusing unit (🖝 p.55)



2. Fusing front cover [A] (X 4)



3. Fusing lamp [B] (x 2, ground cable x 1)

When Reinstalling the Fusing Lamp



m018r585

The terminal [A], which shows the voltage and power ratings, must be placed at the left side of the fusing unit (fusing cable side).

Transport/Fusing Motor

- 1. Rear cover (🖝 p.25)
- 2. Left cover (🖝 p.27)



m018r587

- 3. Disconnect the fusing connector [A] (hook).
- 4. Fusing harness guide [B] (\mathscr{F} x 2)
- 5. Duplex timing belt [C]



B018r590

6. Transport/Fusing motor assembly [D] (x 3, 🕬 x 3, ground plate x 1)



7. Transport/Fusing motor [E] (🖗 x 3)

Paper Feed

Paper Feed Clutch

- 1. Rear cover (🖝 p.25)
- 2. Left cover (🖝 p.27)





- 3. Disconnect the fusing relay harness [A] (hook).
- 4. Paper feed clutch [B] (∅ x 1, 🕬 x 1)

Paper Feed Roller

- 1. Remove all the AIO cartridges.
- 2. Remove the waste toner bottle.
- 3. Rear cover (🖝 p.25)
- 4. Left cover (🖝 p.27)
- 5. Paper feed clutch (🖝 p.59)
- 6. Close the top cover and front cover.
- 7. Pull out the tray.



8. Stand the machine with the rear side facing the table.





m018r601

m018r598

9. Slide the paper feed shaft [A] to the left side ($\textcircled{0} \times 2$).



m018r600

10. Paper feed roller [B] (hook)

Separation Pad

1. Pull out the tray.



- 2. Push down the bottom plate [A].
- 3. Separation pad [B] (hooks, spring x 1)



Note

• When reinstalling the separation pad, make sure that the mylar [C] is not placed under the separation pad. The right side image above shows incorrect installation.

Paper End Sensor

- 1. Rear cover (🖝 p.25)
- 2. Right cover (🖝 p.27)
- 3. High voltage power supply board (
 p.75)



m018r546

m018r566

4. Paper end sensor assembly [A] (💷 x 1)



m018r567

5. Paper end sensor [B] (hooks)

Paper Exit

Paper Exit Roller

1. Operation panel (🖝 p.26)



- 2. Remove the bushing [A] (🕅 x 1)
- 3. Move the bushing [B] to the left side ((0×1)).
- 4. Paper exit roller [B]



5. Remove the four exit guides [D], gear [E] ($\mathbb{C} \times 1$) and bushing [F].



When reinstalling the paper exit roller

4

m018r688

Make sure that the ground wire [A] from the discharge sheet touches the ground plate [B] on the machine after reinstalling the paper exit roller.

Paper Exit Sensor

- 1. Rear cover (🖝 p.25)
- 2. Right cover (🖝 p.27)



3. Right bracket [A] (* x 3: M3x8, * x 1 [B]: M4x10)





m018d595

4

4. Mylar [C]



- This mylar is necessary for reinstalling the paper exit sensor.
- 5. Paper exit sensor [D] (hooks, 💷 x 1)

Electrical Components

Controller Board

Main Controller Board

1. Rear cover (🖝 p.25)



2. Controller box cover [A] (x 7)



m018r611

3. Interface bracket [B] (🖉 x 2)



4. Main controller board [C] (flat cable x 1, all 🕬 s, 🖗 x 6)

Note

• The photo above left shows the PE-MF2c (M019), and the photo above right shows the PE-MF2b (M018).

PDL Board (M019 only)

- 1. Rear cover (🖝 p.25)
- 2. Controller box cover (see "p.66 "Main Controller Board "" above)
- 3. Interface bracket (see "p.66 "Main Controller Board "" above)



m018r612a

4. PDL board [A] (* x 4)

EGB (Engine Board)

- 1. Rear cover (🖝 p.25)
- 2. Controller box cover (🖝 p.66 "Controller Board")



3. Controller bracket [A] (P x 3, ground cable x 1, all 🕬s, flat cable x 1)



m018r617

4. EGB [B] (🖗 x 6, all 🕮 s)



m018r615a

5. EEPROM [C]

When installing the new EGB

1. Remove the EEPROM from the old EGB.





2. Install it on the new EGB with the mark [A] pointing to the left side of the board after you replace the

- EGB.
- 3. Replace the EEPROM if the EEPROM on the old EGB is defective.

ACAUTION

- Keep the EEPROM away from any objects that can cause static electricity. Static electricity can damage EEPROM data.
- Make sure that the EEPROM is correctly installed on the EGB. ٠

FCU

- 1. Rear cover (🖝 p.25)
- 2. Controller box cover (🖝 p.66 "Controller Board")
- 3. Controller bracket (🖝 p.68 "EGB (Engine Board)")



m018r618

4. FCU [A] (🖉 x 4)

Interlock Switches

- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Left cover (🖝 p.27)



- 4. Remove the spring [A].
- 5. Interlock switch base [B] (🎤 x 4, all 🕬s)


• Remove all the connectors after the interlock switch base has been removed.



6. Two interlock switches [C] at the outside of the base and one interlock switch [D] at the inside of the base (hooks)

Fusing Fan Motor

- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Left cover (🖝 p.27)
- 4. Interlock switch base (p.70 "Interlock Switches")



m018r622

5. Fusing fan base [A] (🖗 x 2, 💷 x 1)



6. Fusing fan motor [B] (hooks, 🕬 x 1)

• Install the fusing fan motor with its decal facing the outside of the machine.

LSU Fan Motor

- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Left cover (🖝 p.27)



m018r625

m018r622

4. LSU fan motor [A] (hooks, 🕬 x 1)

• Install the LSU fan motor with its decal facing the outside of the machine.

ID Chip Board

- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Left cover (🖝 p.27)
- 4. Controller bracket (🖝 p.66 "Controller Board")
- 5. Disconnect the connector (CN305) on the EGB.
- 6. Interlock switch base (🖝 p.70 "Interlock Switches")
- 7. Fusing fan base (🖝 p.71 "Fusing Fan Motor")
- 8. Drive unit (🖝 p.35 "Black AIO Motor")
- 9. Take the harnesses aside around the LSU fan base [A].
- 10. LSU fan base [A] (🖉 x 2, 💷 x 1)



11. ID Chip Board [B] (🖉 x 3)

PSU

- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Left cover (🖝 p.27)
- 4. Drive unit (🖝 p.35 "Black AIO Motor")
- 5. LSU fan base (🖝 p.72 "LSU Fan Motor")



- 6. PSU guide [A] (🕅 x 3)
- 7. Power cord bracket [B] (🖗 x 2)
- 8. Ground cable [C] (🖗 x 1)





m018r629

9. Power switch assembly [D] (washer screw [a] x 2, \mathscr{F} x 1, 🗊 x 2)



10. PSU assembly [E] (🎘 x 4, all 💷s)



11. PSU [F] (🖉 x 4)

Comportant 🗋

- There are two types of PSUs for this model. Do not install a wrong PSU in the machine.
- PSU has yellow [a] on the transistor is for NA models and PSU has green [b] on the transistor is for EU models.

Fuse

There is the removable fuse on the PSU.

Fuse No.	Rating
FU101: NA	15 A, 125V
FU101: EU, ASIA	6.3A, 250V

- Use a correct rating fuse for the fuse replacement. Never use a wrong rating fuse. If do so, the machine may be damaged.
- Never try direct connection of PSU circuit without a fuse.

High Voltage Power Supply Board

- 1. Remove all AIO cartridges.
- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Right cover (🖝 p.27)

4. Replacement and Adjustment



Temperature/Humidity Sensor

- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Right cover (🖝 p.27)



m018r683

4. Temperature/Humidity sensor [A] (♂ x 1, 🕬 x 1)

Duplex Motor

- 1. Operation panel (🖝 p.26)
- 2. Rear cover (🖝 p.25)
- 3. Left cover (🖝 p.27)



m018r587a

- 4. Disconnect the fusing connector [A]
- 5. Duplex timing belt [B]
- 6. Left bracket [C] (8 x 4)



7. Duplex motor [D] (🖗 x 2, 💷 x 1)

Speaker

- 1. Rear cover (🖝 p.25)
- 2. Controller box cover (🖝 p.66 "Controller Board")



3. Speaker [A] (🖉 x 2, 💷 x 1)

EEPROM

Vote

 Replacement and Reinstallation procedures for the EEPROM are included in the "EGB (Engine Board)" replacement procedure. Refer to "EGB (Engine Board)" for details.

When replacing an old EEPROM with a new EEPROM, EEPROM setting is required. Follow the EEPROM setting procedure described below.

Replacement Procedure

🔁 Important

- Do the following steps 1 to 9 with the front cover of the machine open. After completing these steps, turn off the machine.
- 1. Open the front cover and turn on the machine.

Note

- The machine may issue an error code (because the cover is open), but continue this procedure.
- Enter the following keys consecutively in order to enter "Engine Maintenance" in the "Maintenance Mode Menu".
- 3. Select "Init Engine EEPROM" item and execute it to initialize the EEPROM.
- 4. Press the "Clear/Stop" key to exit the "Engine Maintenance" menu.
- 5. Select the "Serial No." item, and then input a serial number.

Note

• Ask your supervisor about how to access the serial number input display.

- 6. Exit the serial number input display, and then enter "Engine Maintenance" again.
- 7. Select "Destination", and then select a destination.
- 8. Select "Model", and then select a model.
- 9. Select "PnP Name", and then select a plug and play name.
- 10. Select "LSU Adjustment", and then input the LSU (laser optics housing unit) setting values.
- 11. Turn off the machine.
- 12. Turn on the machine with the front cover open.
- 13. Enter "Engine Maintenance" in the "Maintenance Mode Menu" again.
- 14. Close the front cover.
- 15. Select "Trans. Belt Adjust", and then execute "Trans. Belt Adjust" to adjust the ITB (Image Transfer Belt) unit.
- 16. Select "Fuser SC Detect", and then select "ON" or "OFF" for the consecutive fusing jam detection.

🕗 Note 📃

- The default setting is "OFF". Select "ON" only if the customer wants to use this feature.
- 17. Select "Registration", and then adjust the registration for each direction (vertical and horizontal direction) and tray if necessary.
- 18. Select "2nd Transfer Fuser Temp", and then adjust the transfer roller bias and the temperature reduction of the fusing unit for each paper type and for the front and back sides. The default settings for normal operation are all '0'.
- 19. Exit "Engine Maintenance".

ADF

ADF Unit



m018r672

1. Stand left cover [A]



m018r690

2. Disconnect the ADF harness [B] and power cord [C].





3. Open the ADF unit [D]





m018r675

- 4. Release the three hooks of the right hinge [E]
- 5. Lift the ADF unit.

Original Tray

1. Open the ADF cover.

4. Replacement and Adjustment



m018r659

m018r658

- 2. Release the front tab [A].
- 3. Original tray [B]

4

ADF Feed Unit

1. Open the ADF cover.





- 2. Release the lock lever [A]
- 3. ADF feed unit [B]

ADF Separation Pad

- 1. Open the ADF cover.
- 2. ADF feed unit (🖝 p.82)



m018r660



m018r661

3. ADF separation pad [A] (hook x 2, spring x 1)

ADF Front Cover

- 1. ADF unit (🖝 p.80)
- 2. Original Tray (🖝 p.81)
- 3. ADF feed unit (🖝 p.82)



4. ADF front cover [A] (x 1)

ADF Rear Cover

- 1. ADF unit (🖝 p.80)
- 2. Original Tray (🖝 p.81)
- 3. ADF feed unit (🖝 p.82)



4. ADF rear cover [A] (🖉 x 2)

ADF Cover

- 1. ADF unit (p.80)
- 2. ADF front cover (🖝 p.83)
- 3. ADF rear cover (🖝 p.83)



4. ADF top cover [A] (two tabs)

ADF Motor

- 1. ADF unit (🖝 p.80)
- 2. Original Tray (🖝 p.81)

4

- 3. ADF feed unit (🖝 p.82)
- 4. ADF front cover (🖝 p.83)
- 5. ADF rear cover (🖝 p.83)



m018r667

6. ADF drive unit [A] (🖗 x 4, all 🕬 s)



m018r668

7. ADF motor assembly [B] (\$\vec{P} x 2)



8. ADF motor [C] (🖉 x 2)

Original Set Sensor

- 1. ADF unit (🖝 p.80)
- 2. ADF feed unit (🖝 p.82)
- 3. ADF motor assembly (🖝 p.84)



m018r670

- 4. Feed roller holder [A] (🖉 x 1)
- 5. Upper guide [B] (🖉 x 2)



6. Original set sensor [C] (hooks)

ADF Cover Open Sensor

- 1. Original tray (🖝 p.81)
- 2. ADF rear cover (🖝 p.83)



m018r679

3. ADF cover open sensor (x 1, 💷 x 1)

ADF Feed Sensor

- 1. ADF unit (🖝 p.80)
- 2. ADF feed unit (🖝 p.82)



m018r680

3. Sensor cover [A] (🖉 x 2)



11018

4. ADF feed sensor [B] (hooks)

ADF Drive Board

- 1. Original tray (🖝 p.81)
- 2. ADF rear cover (🖝 p.83)



3. ADF drive board [A] (all 🕬s, hooks)

Scanner

Scanner Unit

1. Controller box cover (🖝 p.66 "Controller Board")



m018r633

- 2. Disconnect the flat cable [A].
- 3. Stand left cover [B] and right cover [C] (1 hook each)



m018r634

- 4. Disconnect the scanner harness, power cord and ground cable (and the ADF harness and power cord if the ADF is installed in the scanner unit) ($\mathscr{F} \times 1$).
- 5. Open the top cover of the machine.



- 6. Remove the stepped screw [D].



- 7. Push the lock button [E] and slide the scanner unit to the rear side.
- 8. ADF unit (🖝 p.80)



m018r637

9. Scanner unit

Scanner Top Cover

1. Scanner unit (🖝 p.90)





m018r639

m018r638

- 2. Turn over the scanner unit.
- 3. Scanner front cover [A] (tabs x 3)



4. Remove the six screws at the bottom of the scanner base [B].

4



5. Scanner top cover [C]

Scanner Carriage Unit

- 1. Scanner unit (🖝 p.90)
- 2. Scanner top cover (🖝 p.92)



m018r642

3. Slide the scanner carriage unit [A] to the right side.



4. Remove the timing belt tension spring [B]



5. Remove the flat cable [C] from the scanner carriage unit.



6. Bar holder [D] (🖗 x 1)

4



7. Carriage bar [E] and scanner carriage unit [F]

Exposure Lamp

1. Scanner carriage unit (🖝 p.93)



2. Carriage top cover [A] (🖗 x 2, 🕬 x 1)



3. Exposure lamp [B] (hooks)

When reinstalling the exposure lamp



m018r649

Wire the lamp cords as shown above. Otherwise, the top cover pinches the lamp cords and damages them when reinstalling the top cover on the scanner carriage unit.

Lamp Stabilizer Board

1. Scanner carriage unit (🖝 p.93)



m018r650

2. Carriage bottom cover [A] (*P* x 2)



m018r651

3. Lamp stabilizer [B] (💷 x 1)

Scanner Motor

1. Scanner carriage unit (🖝 p.93)



2. Scanner motor [A] (🖗 x 3)



- 3. Carriage rail [B] (🖗 x 2)
- 4. Ground plate [C] (double-sided tape)
- 5. Scanner motor

5. System Maintenance Reference

Service Program

See "Appendices" for "Service Menu".

Overview

There is an LCD on these models. To execute the service program, access the "Maintenance Mode Menu" or "Fax Service Menu" with special key assignments. For details, refer to the "Service Menu" section.

Configuration Page Information

Overview

The configuration page and maintenance page have information about the machine's status. Print this sheet as shown below. Check the configuration page or maintenance page when doing machine maintenance.

To Print the Configuration Page/ Maintenance Page

- 1. Turn on the machine.
- 2. Press the "User Tools" key.
- 3. Press the "▲" or "▼" key to select "Reports Print", and then press the "OK" key.
- Press the "▲" or "▼" key to select "Configuration Page" or "Maintenance Page", and then press the "OK" key.
- 5. The configuration page or maintenance page is printed.

Firmware Updating

• Do not turn off the main power of the machine during the firmware updating. If doing so, the engine board or controller board may be damaged.

Checking the Machine Firmware Version

- 1. Turn the machine on.
- 2. Press "User/Tools" key and select "Report Print" with the "Up" or "Down" key.
- 3. Press "OK" and select "Maintenance Page" with the "Up" or "Down" key.
- 4. Press "OK" to display the "Firmware version (Controller)" and "Engine FW version"

Updating the Controller Firmware

Using the following procedure to update the controller firmware. Be sure to print the configuration page both before and after the update. Comparing pre- and post-update configuration pages allows you to check whether or not the update was successful.

Follow the procedure carefully, and note that it will vary in parts depending on which version of the firmware is currently installed.

Preparation

1. Download the firmware file on you PC.

			Z		
[Manual]	readme.txt	setting.ini	UpdateTool.e	vxxx.brn	
_					

m018s505	,
----------	---

- 2. Unzip the firmware file.
 - The firmware file contains the manual folder and other updating applications as show above.

Updating Procedure

- The update may take a while to complete. Do not turn off the power during the update.
- Turn off the power only when the machine beeps and "Firmware Update Done Please Reboot" appears on the control panel display.

🔁 Important

- When using a computer running on a Windows operating system, you must have an account that has Manage Printers permission. Log on as an Administrators or Power Users group member to acquire this permission.
- The following procedure is based on Windows XP as an example.
- 1. Disconnect the telephone line cable from the machine.
- 2. Turn on the machine.
- 3. Press any menu key on the machine's control panel.
- 4. Press the [▲] [▼] keys to select [Reports Print], and then press the [OK] key.
- 5. Press the [▲] [▼] keys to select [Configuration Page], and then press the [OK] key.

The configuration page is printed out. Take note of the current firmware version (shown under "Firmware Version" on the configuration page).

SP C220S/C221SF/C222SF F/W Update Tool	[A]
F/W Update (USB) F/W Update (NET)	[A]
MFP IP · · ·	
Close	
Never turn off the power before the "Firmware Update / Done Please Reboot" message appears on the control panel display.	

6. Double-click the [UpdateTool.exe] icon to launch the firmware update tool [A].



- For a USB connection, click [F/W Update (USB)] [A]. For a network connection, enter the machine's IP address in [MFP IP] [B], and then click [F/W Update (NET)] [C].
- 8. Check the control panel display for messages and the update's current percentage of completion.

Note

- The Update may take a while to complete. Do not turn off the power during the update.
- Turn off the power only when the machine beeps and "Firmware Update Done Please Reboot" appears on the control panel display.
- Wait until the machine beeps once and "Firmware Update Done Please Reboot" appears on the control panel display.
 - Click [Close] to the update tool.
- 10. Turn off the power, and turn it back on.
 - After you turn the power back on, "Initializing" appears on the control panel display.
- 11. Wait until the initial screen appears on the control panel display.
 - If the initial screen does not appear after more than one minute, the update is not complete. In this case, see "Updating Failure".
- 12. Repeat Steps 3 to 5 to print the configuration page again.

Take note of the new firmware version (shown under "Firmware Version" on the configuration page).

13. Reconnect the telephone line cable to the machine.

Note

- The update's percentage of completion might not be displayed, depending on which version of the firmware is currently installed.
- In addition to printing a configuration page, you can check the machine's firmware version by accessing the machine using a web browser. For details, see "Checking Machine Status", in the User Guide.
- Depending on how it is configured, the machine might start up in fax mode following the firmware update.

Messages that appear in the update tool window

Message	Cause/ Solutions
Can't open ROM file. Please check ROM file.	The firmware file (*.brn/*.dwn) or setting file (*.ini) is not stored in the same folder as the update tool.
	• Make sure that the firmware file (*.brn/*.dwn) and setting file (*.ini) are stored in the same folder as the update tool.
	• Also, make sure that you do not modify the setting file.
	The path to the location of the update tool is too long.
	• Make sure that the path to the update tool is not too long. For convenience, save the update tool in a subfolder directly under your computer's C: drive.
	The USB cable is not connected.
	 Make sure the USB connection between the machine and computer is secure.
	 If this message persists, try another USB cable.
Fail to open USB port.	The USB printer driver is not installed in your computer.
	 Install the USB printer driver in your computer.
	The machine is turned off or an error has occurred.
	• Turn off the power, turn it back on, and then perform the update again.
	 If this message reappears after you turn the power back on, see "Error and Status Messages on the Screen" in the User Guide.

Message	Cause/ Solutions
Net Connection : FAIL(X)*1	The IP address specified for either the machine or your computer is invalid.
	Check that both IP addresses are valid.
	The [F/W Update (USB)] or [F/W Update (NET)] button was clicked when the update was already in progress.
	• Clicking the [F/W Update (USB)] or [F/W Update (NET)] button during the update process does not interfere with any ongoing update.
	 Ignore this error message and complete the update using the procedure shown in this manual.
	The machine is turned off or an error has occurred.
	• Turn off the power, turn it back on, and then perform the update again.
	 If this message reappears after you turn the power back on, see "Error and Status Messages on the Screen" in the User Guide.
	The machine is being operated through the operation panel.
	 Cancel any operations being performed through the operation panel.
	 Put the machine into standby mode, and then perform the update again.
Net Server : Connecting	Your computer is searching the network for the machine.
	• Wait a while until the machine is found.
Net Upload : End of data	Firmware has been transferred to the machine successfully.
	• Follow the instructions in this manual to complete the update.
LICE Lineard Frank States	Firmware has been transferred to the machine successfully.
USB Upload : End of data	• Follow the instructions in this manual to complete the update.

Message	Cause/ Solutions
USB Upload : FAIL	The [F/W Update (USB)] or [F/W Update (NET)] button was clicked when the update was already in progress.
	 Clicking the [F/W Update (USB)] or [F/W Update (NET)] button during the update process does not interfere with any ongoing update.
	 Ignore this error message and complete the update using the procedure shown in this manual.
	The machine is being operated through the operation panel.
	 Cancel any operations being performed through the operation panel.
	• Put the machine into standby mode, and then perform the update again.

* 1: "X" indicates an error code.

Updating Failure

If the initial screen does not appear and the message below remains on the operation panel display for more than one minute following firmware update, a power failure or similar interruption prevented the update from completing.

If this happens, use the following procedure to recover from the failure and complete the update.

Coloritant 🔁

- To recover the machine following a failed update, the machine must be connected to a computer by USB.
- When using a computer running on a Windows operating system, you must have an account that has Manage Printers permission. Log on as an Administrator or Power Users group member to acquire this permission.
- 1. If you performed the update through a network connection, disconnect the network cable, and then connect the machine to your computer using a USB cable.
- 2. While "Initializing" is shown on the operation panel display, double-click the [UpdateTool.exe] icon to launch the firmware update tool.
- 3. Click [F/W Update (USB)].
- 4. Wait until "Please Download FW Again Now!" appears on the operation panel display.

Make sure that you keep the power of the machine turned on.
- 5. Click [F/W Update (USB)] again.
- Check the operation panel display for messages and the update's current percentage of completion.
 The update may take a while to complete. Do not turn off the power during the update.

Turn off the power only when the machine beeps and "Firmware Update Done Please Reboot." appears on the operation panel display.

7. Wait until the machine beeps once and "Firmware Update Done Please Reboot." appears on the operation panel display.

Click [Close] to close the update tool.

8. Turn off the power, and then turn it back on.

After you turn the power back on, "Initializing" appears on the operation panel display.

- 9. Wait until the initial screen appears on the operation panel display.
- 10. Press any menu key on the machine's operation panel.
- 11. Press the [▲] [▼] keys to select [Reports Print], and then press the [OK] key.
- Press the [▲] [▼] keys to select [Configuration Page] and then press the [OK] key.
 Take note of the new firmware version (shown under "Firmware Version" on the configuration page).
- 13. Reconnect the telephone line cable to the machine.

Note

- The update's percentage of completion might not be displayed, depending on which version of the firmware is currently installed.
- In addition to printing a configuration page, you can check the machine's firmware version by accessing the machine using a web browser. For details, see "Checking Machine Status" in the User Guide.
- Depending on how it is configured, the machine might start up in fax mode following the firmware update.

Updating the Engine Firmware

- 1. Make a folder in your computer.
- 2. Save the files (".bin", ".fwu", ".ini" and ".exe") in the folder.

	_
🛋 🛋 🔚 🔀	
EFHeader.bin per_p1_eng10 setting.ini UpdateTool.e	
Zolo F/W Upload Tool (Ver. 0.3)	×
F/W Update (USB) Eng. F/W Update (USB)	
F/W Update (NET) Eng. F/W Update (NET)	
MFP IP 10 . 1 . 14 . 69	1
Close	1
USB UPIDAD : CUMPLETED	
	m018s517

- 3. Click the exe file to execute the updating program.
- 4. Click "Eng. F/W Update (USB or NET)" to send the engine firmware from PC to MF printer.
 - The "F/W Update (USB or NET)" buttons are for designer use only. Do not use these buttons.
- 5. The machine makes a beep sound when starting the firmware update.
- 6. The image above is displayed at the PC and "Firmware update" and "Updating" are displayed on the operation panel.
- 7. Then, you can close this window at your PC.

- Do not turn off the machine until "Done Please reboot" is displayed in the operation panel. Otherwise, the controller board will be damaged.
- If "Done Please reboot" does not appear, the download failed. Try again. You can also switch from an Ethernet connection to a USB connection and see if that works. If you still cannot download the firmware, it may be necessary to change the EGB and/or the controller board.
- If power failed during the download, try again. If you still cannot download the firmware, it may be necessary to change the EGB and/or the controller board.

Boot Loader Firmware

This is also listed on the configuration page, but this firmware is not updated in the field.

6. Troubleshooting

Troubleshooting Guide

See "Appendices" for the following information:

- Error Messages
- Service Call Conditions

Image Problems

Overview

Image problems may appear at regular intervals that depend on the circumference of certain components. The following diagram shows the possible symptoms (black or white dots at regular intervals).



- Abnormal image at 24-mm intervals: Paper feed roller
- Abnormal image at 25.5-mm intervals: Image transfer belt unit
- Colored spots at 27-mm intervals: Print cartridge (Development roller)
- Abnormal image at 30-mm intervals: Charge roller
- Abnormal image at 38-mm intervals: Registration roller
- Abnormal image at 60-mm intervals: Transfer roller
- Colored spots at 76-mm intervals: Print cartridge (OPC drum)
- Abnormal image at 110-mm intervals: Fusing unit (Pressure roller)
- Abnormal image at 115.5-mm intervals: Fusing unit (Heat roller)

Checking a Sample Printout

Print out a mono-color pattern (all K, C, M, or Y), which will clarify if the cause is a problem with one of the AIOs, the image transfer belt, image transfer roller, or the fusing unit. A sample page is provided with the printer driver's CD. You can print the sample page from the printer driver's CD. Before printing, you have to adjust the printer driver settings to make the problem become obvious. For details about adjusting the settings, refer to "Printer Driver Setting for Printing a Sample" described below.

- Occurs with 1-3 colors: AIO unit(s) failure
- Occurs with all four colors: Image transfer belt, transfer roller or fusing unit failure

	1
g	165c502

Printer Driver Setting for Printing a Sample

1. Click "Properties" on the printer driver.

Resolution	Fint Quality Waterman 600 dpi Gradation: Speed	Ks Color	C Automatic C Manual Use ICM	Advanced
Toner Saving	⊂ On © Off			

- 2. Click the "Print Quality" tab.
- 3. Check "Manual" in the color setting.
- 4. Click "Advanced...".

Text Color Profile:	Graphics Color Profile:	Photo Color Profile:
Lolor Profile:		
1011		
Dithering:	Dithering:	Dithering:
Text	Photographic	Photographic
16%		Bastara Dafaulta

g165c510

- 5. Select "Off" from the pull-down menu in "Color Profile" in the "Text" area.
- 6. Select "Off" from the pull-down menu in "Color Profile" in the "Graphics" area.
- 7. Select "Off" from the pull-down menu in "Color Profile" in the "Photo" area.

Model PE-MF2 Machine Code: M018/M019

Appendices

January, 2009 Subject to change

TABLE OF CONTENTS

General Specifications	
Engine	3
Option	9
Supported Paper Sizes	10
2. Appendix: Preventive Maintenance	
Preventive Maintenance	13
User Replaceable Items	13
3. Appendix: Troubleshooting Guide	
Error Messages	15
Overview	15
Error Messages List	15
Fax Error Code	
Service Call Conditions	23
Summary	23
Engine SC	23
Controller SC	
4. Appendix: SP Mode Tables	
Service Menu	
Overview	
Maintenance Mode Menu	
Fax Service Test Menu	46
5. Appendix: Machine Swap	
Exchange and Replace Procedure	
Instruction	
Cleaning Points after Machine Arrival at Depot	

General Specifications

Engine

PE-MF2b: M018, PE- MF2c: M019

Туре			Desktop	
			Flatbed with CCD array image-sensor	
Technology			Laser beam scanning and electro-photographic printing	
			Mono-component toner development	
			4-drum tandem method	
			600 × 600 dpi Speed (1bit)	
Resolution (dpi, b	it/pixel)		600 × 600 dpi Standard (2bits)	
			600 × 600 dpi Fine (4bits)	
Printing Speed	General Paper A4/LT		BW/FC: 20ppm (LT:21ppm)	
First Print Speed	Mono		14.0 sec or less	
(A4/LT, SEF, Std. Tray)	F/C		14.0 sec or less	
Duplex Printing/ Copying	A4, LT, B5, LG, Exe		Auto	
Dimensions (W x D x H)			420 x 493 x 476 mm	
Weight			30 kg *Includes consumables.	

		Std Tray	250 sheets (80 g/m ²)
	Standard	Bypass tray	1 sheet
Input capacity	Op. Paper Tray	Paper Feed Unit	500 sheets (80 g/m ²) x 1
	Max	·	Up to 751 sheets
Output capacity	Standard Tray	Face down	Up to 150 sheets (A4/LT or 80g/m ² , 20lb)
			A4, B5, A5, B6, A6, Legal, Letter, HLT, Executive, Foolscap, Folio
	Standard	Tray	Custom size:
			Min. 90mm x 148mm (3.6" x 5.92"),
			Max. 216mm x 356mm (8.64" x 14.24")
Input Paper Size Bypass Tr Op. Pape			A4, B5, A5, B6, A6, Legal, Letter, HLT, Executive, Foolscap, Folio
		у	Custom size:
			Min. 90mm x 148mm (3.6" x 5.92"),
			Max. 216mm x 356mm (8.64" x 14.24")
		[.] Tray	A4, Letter
	Std. Tray		Plain Paper, Recycle Paper, Application Paper, Envelope, Glossy, Thick Paper, Label
Media Type		Bypass Tray	Plain Paper, Recycle Paper, Application Paper, Envelope, Glossy, Thick Paper, Label
	Oı Ur		Plain Paper, Recycle Paper
	Standard Tray		60-160g/m ² (16-40lb)
Paper Weiaht	Bypass tray		60-160g/m ² (16-40lb)
1	Op. Pape Tray	er Paper Feed Unit	60-105g/m ² (16-28lb)

	Capacity		35 sheets (80g/m ² , 20lb)	
ADF	Original size	2	Letter/A4: Width 139.7-215.9 mm (5.5" - 8.5"), Length: 139.7-355.6 mm (5.5" - 14")	
	Original weight		52 - 105 g/m ² (14 - 28lbs.)	
Rating Power	NA version		120V, 60Hz	
Spec.	EU version		220 to 240V, 50/60Hz	
Power Consumption EU ver		Max.	1300W or less	
	NA version	Energy Saver	PE-MF2b 20 W or less PE-MF2c 25 W or less	
		Max	1300W or less	
	EU version	Energy Saver	PE-MF2b 20 W or less PE-MF2c 25 W or less	
Warm-up Time			48 sec or less (from power on)	
Energy Save	e Sleep Mode		48 sec (Uses approx 15W)	
Mode	Low Power Mode		10 sec (Uses approx 100W)	

Copier

l st copy speed	Platen/ADF	B&W: Less than 30 sec. FC: Less than 30 sec.
	Platen	A4 (210 x 297mm) / Letter (215.9 x 279.4mm)
Maximum original size	ADF	A4 (210 x 297mm) / Letter (215.9 x 279.4mm)/ Legal (215.9 x 355.6mm)

	Single Document Multiple Copy	Platen	B/W: 20 cpm (A4), 21 cpm (LT) FC: 20 cpm (A4), 21 cpm (LT)	
Copy Speed		ADF	B/W: 20 cpm, FC: 20 cpm (A4), B/W: 21 cpm, FC: 21 cpm (LT)	
	Multiple Document Single Copy	ADF	B/W: 20 cpm, FC: 10 cpm	
Multiple copy			Up to 99	
Peopletion (Hy))		Scanning	600 x 600 dpi (Flatbed), 600 x 300 dpi (ADF)	
Resolution (FI X V)		Printing	600 x 600 dpi	
Grayscale			256 levels	
Reduction / Enlargement		Fix	NA: 50, 65, 78, 93, 129, 155, 200, 400% EU: 50, 71, 82, 93, 122, 141, 200, 400%	
		Custom	25 – 400% in 1% steps	
Image density adjus	tment		Yes, Manual only: 5 levels	
Copy mode			Text/Photo/Mixed	
Memory copy			Yes	
Auto-duplex copy			No	
Interrupt copy			No	
Combine copy			2 in 1, 4 in 1 (Only ADF)	
APS/AMS			No/No	
Auto Tray Switch			No	
Directional Magnific	Directional Magnification		No	
Directional Size Ma	gnification		No	
Photo Mode			Yes	
Auto Start			No	

User Program	No
Electronic Sorting	Standard (collation, ADF only)
Image Rotation	No
Series Copy	No

Scanner

Scanning Device	•	CCD array image-sensor	
Develoption		Scanner: 1200 x 1200 dpi	
Kesolution		Driver: Max. 19200 x 19200 dpi (interpolated)	
Gray scale		256 levels	
Scan modes/ sp 300dpi, USB2.0	eed (A4,)	 ADF: B/W: less than 5 sec. / Gray Scale: less than 5 sec. / Color: less than 10 sec Platen B/W: less than 5 sec. / Gray Scale: less than 5 sec. / Color: less than 10 sec 	
Maximum	Platen	Width max: Up to 216mm, Length max: Up to 297mm	
original size ADF		Width max: Up to 216mm, Length max: Up to 356mm	
Scan Depth		48bit color processing (input), 24bit color processing (output)	
PC Interface		USB2.0, 10/100Base-TX	
TWAIN Complin	nent	TWAIN, WIA	
Scanner utilities o Drivers	and	TWAIN Driver, Scanner utility (PageManager)	

Fax

Circuit	PSTN/ PABX
Compatibility:	ITU-T Group 3

Coding system:	MH/MR/MMR
Modem speed:	Automatic Fallback: 33600 bps
Document size:	Platen: A4/ LT/ LG Width max: 216 mm (8.5"), Length max: 297 mm (11.7") ADF: A4/ LT/ DLT Width: 139.7-215.9mm (5.5" - 8.5") Length: 139.7-355.6 mm (5.5" - 14")
Scanning width:	Max. 210 mm (8.3")
Printing width:	Max. 208 mm (8.2")
Gray scale:	256 levels
Polling type:	Standard, Sequential
Contrast control:	Normal/Light/Dark (manual setting)
Resolution:	8 x 3.85/ 8 x 7.7 lines/mm 200 x 100/ 200 x 200 dpi
Scanning Speed	Less than 5 sec. (A4 SEF, 200 dpi)
Modem Speed	Automatic Fallback: 33600, 31200, 28800, 26400, 24000, 21600, 19200, 16800, 14400, 12000, 9600, 7200, 4800, 2400bps
Transmission Speed	Approx. 3 sec *ITU No.1 chart, Compression: MMR, Resolution: Standard, Speed: 33.6kbps
SAF Memory	100 pages (ITU No.1 chart, Compression: MMR, Resolution: Standard)
Memory Backup	1 hour
One-touch dial:	20 (10 x 2)
Broadcasting:	100 stations
Communication source:	Public switched telephone network
PC Fax utility:	Not available
Automatic re-dial	5/4/3/2 times after 5 minutes (Default 5 times)
Auto Answer	1-99 rings (Default 2 rings)

Option

Paper Feed Unit

	Paper Size	A4,Letter
	Paper Weight	60-105g/m ² (16-28lb)
Paper Tray	Paper capacity	500 sheets x 1 tray
	Dimensions (W x D x H)	400 x 450 x 127mm/16 x 18 x 5.08 inch
	Weight	6 kg/13.2 lb

Supported Paper Sizes

А	Supported and the size is molded in the tray. Need to select paper size by operation panel/driver.
В	Supported but size is not molded in the tray. Need to select paper size by operation panel/driver.
С	Need to input paper size by operation panel and driver.
Ν	Not supported.

Туре		SEF/ LEF	Size	Input Tray			
				Standard Tray	Option PFU	Bypass Tray	Auto. Dup.
	A 4	SEF	210x297	А	А	В	Y
	A4	LEF	297x210	Ν	Ν	Ν	Ν
	B5	SEF	182x257	А	Ν	В	Y
		LEF	257x182	Ν	Ν	Ν	Ν
Digin Danor	A5	SEF	148x210	А	Ν	В	Ν
riain raper		LEF	210x148	Ν	Ν	Ν	Ν
	Вб	SEF	128x182	В	Ν	В	N
		LEF	182x128	Ν	Ν	Ν	Ν
		SEF	105x148	В	Ν	В	Ν
Ao	AU	LEF	148x105	Ν	Ν	Ν	Ν

Туре		SEF/ LEF	Input Tray				
			Size	Standard Tray	Option PFU	Bypass Tray	Auto. Dup.
	DLT	SEF	11" x 17"	Ν	Ν	Ν	Ν
	Legal	SEF	8 1/2″x14″	А	Ν	В	Y
	lattar	SEF	81/2″x11″	А	А	В	Y
	Lellel	LEF	11″x 8 1/2″	Ν	Ν	Ν	Ν
	Half Letter	SEF	5 1/2″ x 8 1/2″	С	Ν	С	Ν
Plain Paper		SEF	7 1/4″x10 1/2″	А	Ν	В	Y
	Executive	LEF	10 1/2″x7 1/4″	Ν	Ν	Ν	Ν
	F	SEF	8″ x 13″	В	N	В	N
	Foolscap	SEF	81/2″×13″	В	N	В	Ν
	Folio	SEF	81/4″×13″	В	N	В	Ν
	8 Kai	SEF	267 x 390	Ν	Ν	Ν	Ν
Plain Paper	16 Kai	SEF	195 x 267	С	N	С	Ν
		LEF	267 x 195	Ν	N	Ν	Ν
	Com10	SEF	4 1/8″ x 9 1/2″	С	Ν	С	Ν
Envelope	Monarch	SEF	3 7/8″ x 7 1/2″	С	Ν	С	Ν
Lintelope	C6	SEF	114 x 162	С	N	С	N
	C5	SEF	162 x 229	С	N	С	N
	DL Env	SEF	110 x 220	С	Ν	С	Ν

		CEE /		Input Tray			
Тур	e	LEF	Size	Standard Tray	Option PFU	Bypass Tray	Auto. Dup.
		Width	90-216mm (3.6″x 8.5″)	С	Ν	С	N
Custom		Length	148 – 356mm (5.8″x 14.24″)	С	И	С	Ν

Preventive Maintenance

User Replaceable Items

ltem	Yield
Print Cartridge (AIO)	Starter: Approx. 1.0 k prints/cartridge Short: Approx. 2.5 k prints/cartridge Long: 6.5 k for BK, 6.0 k for CMY (prints/cartridge)
Waste Toner Bottle	Approx. 25 k prints/ bottle (See condition 5)

Condition:

- 1. An A4 (8.5"x11")/ 5% chart was used to measure the above yield except the Print Cartridge (AIO).
- 2. The yield was measured at standard temperature and humidity.
- 3. The expected yield measurement for the Print Cartridge (AIO) is based on the ISO 19798 (ISO chart, continuous prints).
- 4. These yield values may change depending on the circumstances and printing conditions.
- 5. Waste Toner Bottle yield was measured for 3P/J when the printer is used 50% for color and 50% for black-and-white

2. Appendix: Preventive Maintenance

Error Messages

Overview

The error codes will be displayed on the LCD if the machine has a problem. These can be recovered by a customer.

Error Messages List

	Cover Open
000	The front or top cover is open.
	1. Close the front or top cover.
	2. Replace the interlock switches or actuator mechanism.

010	AIO Set Error (Black)
011	AIO Set Error (Magenta)
012	AIO Set Error (Cyan)
013	AIO Set Error (Yellow)
	Black AIO not setDefective connection of the ID chip terminal on the black AIO
	 Install the AIO (black, magenta, cyan or yellow). Reinstall or replace the AIO (black, magenta, cyan or yellow).

3. Appendix: Troubleshooting Guide

	Waste Toner Bottle Set Error
	Waste toner bottle not set
	 Disconnected or defective harness of the waste toner bottle set sensor
014	Defective waste toner bottle set sensor
	1. Install the waste toner bottle.
	2. Check or replace the harness of the waste toner bottle set sensor.
	3. Replace the waste toner bottle set sensor.

Tray/Paper Selection Error

- No paper in the tray or tray not set in the machine
- Paper size requested by the job does not match the paper in the tray
 - 1. Install the tray or put the correct size paper in the tray.
 - 2. Check the paper setting in the user menu mode.

	Paper Selection Error: Feed and Exit
031	• Paper size requested by the job does not match the paper in the tray
	Selection error for the paper feed and paper exit location in duplex mode
	Check the paper feed and exit location in the user menu mode.

	Jam Error: No Feed from Tray 1
050	• Paper slipped
	Remove the paper jam at tray 1.

	Jam Error: No Feed from Optional Tray
052	• Paper slipped
	Remove the paper jam at the optional tray (Tray 2).

055	Inner Jam Error: Registration/ Paper Exit
	A sheet of paper stays at the registration sensor or paper exit sensor.Paper slipped
	Paper double feed
	Remove the paper jam at the registration sensor or paper exit sensor.

	Paper Exit Jam Error: Paper Exit/ Fusing Unit
056	A sheet of paper stays at the paper exit sensor or winds around the rollers in the fusing unit.
	 Paper slipped
	 A sheet of paper is wound around the rollers in the fusing unit
	Remove the paper jam at the paper exit sensor or in the fusing unit.

	Printing Error: No Paper
070	No paper in the tray
	Put paper in the tray.

080	Toner Near End: Black AIO
081	Toner End: Black AIO
	Black toner near-end or end
	Replace the black AIO.

082	Toner Near End: Magenta AIO
083	Toner End: Magenta AlO
	 Magenta toner near-end or end
	Replace the magenta AIO.

084	Toner Near End: Cyan AlO
085	Toner End: Cyan AIO

	Cyan toner near-end or end	
	Replace the Cyan AIO.	
086	Toner Near End: Yellow AIO	

087	Toner End: Yellow AIO
	Yellow toner near-end or end
	Replace the yellow AIO.

089 Waste Toner Bottle: Full • Waste toner bottle near-full or full Replace the waste toner bottle.	088	Waste Toner Bottle: Near Full
Waste toner bottle near-full or full Replace the waste toner bottle.	089	Waste Toner Bottle: Full
Replace the waste toner bottle.		Waste toner bottle near-full or full
		Replace the waste toner bottle.

999	Color Registration (MUSIC) Error
	Color registration (MUSIC) failure
	This error is not displayed even if this error occurs. It is just logged. This error is automatically recovered after the color registration (MUSIC) has been done successfully.

Fax Error Code

This section describes the dial, transmission (TX), and reception (RX) error codes that are printed on the TX Report/Activity Report.

Basic error code structure

Error codes consist of six hexadecimal digits (0-5).

Digit 5 (far left)	TX or RX	
TX:	1ххххх	
RX:	2 xxxxx	

Digit 4	Coding (MH/MR/MMR)
MH:	x1xxxx
MR:	х2хххх
MMR:	хЗхххх

Digit 3	MODEM mode
V27ter nonECM:	xx1xxx
V29 nonECM:	xx 2 xxx
V17 nonECM:	ххЗххх
V33 nonECM:	xx 4 xxx
V34:	хх5ххх
V27ter ECM:	xx 9 xxx
V29 ECM:	xxaxxx
V17 ECM:	xxbxxx

Digit 2	MODEM speed
2400:	xxx1xx
4800:	xxx 2 xx
7200:	ххх3хх
9600:	xxx 4 xx
12000:	xxx 5 xx
14400:	ххх б хх
16800:	ххх7хх
19200:	xxx 8 xx
21600:	xxx 9 xx
24000:	xxx a xx
26400:	xxxbxx

Digit 2	MODEM speed	
28800:	xxx c xx	
31200:	xxxdxx	
33600:	xxxexx	

Error code table

Error Type		Error Description	Error Code
General		STOP	xxxx01
		RX T1 Time Out	Not logged in activity report
Local Mechanical error		Scanner Error during TX	1xxx11
		Memory Full during RX	2xxx14
TX Job Error		TX Job Lost	1xxx18
		TX Job deleted	1xxx19
		Connection Fail	xxxx21
Dial failure		Dial Fail	xxxx22
		Redial All Failed	xxxx23

Error Type		Error Description	Error Code
		TX T1 Time Out	xxxx31
		V8 negotiation Fail	xxxx32
		Retry Out	xxxx40
		Too many FTT	xxxx41
		Too many CRP	xxxx42
		T2 Time Out	xxxx43
Comm. Error	Comm. Error 1. Phase-B Error	DCN received	xxxx44
		Command Rec Error	xxxx45
		Resp Rec Error	xxxx46
		Invalid Command/Response RX	xxxx47
	Remoter No RX capability	xxxx48	
		T1 time out after EOM	xxxx49
		T2 Time Out	xxxx50
	2. Phase-C Error	Image Data not ready	xxxx51
	Phase-C Time Out	xxxx52	

3. Appendix: Troubleshooting Guide

Error Type		Error Description	Error Code
		Retry Out	хххх60
		T2 Time Out	xxxx61
		DCN received	хххх62
		Too many CRP	хххх63
		Too many PPR	xxxx64
	3. Phase-D Error	RNR time Out	хххх65
		RTN/PIN Received, EOR/ERR/DCN	ххххбб
		Invalid Command/Response RX	хххх67
		Command Rec Error	хххх68
		Resp Rec Error	хххх69
	4. Phase-E Error	Time Out	xxxx70
		modem hang-up	xxxx80
		V34 abort received	xxxx81
5. Other general Comm Error	5. Other general	V34 t1 timeout, control channel error	xxxx82
	V34 t1 timeout, primary channel error	xxxx83	
	data not sent until guard timer expire	xxxx84	

3

Service Call Conditions

Summary

This machine issues an SC (Service Call) code if an error occurs on the machine. The error code can be seen on the operation panel.

Make sure that you understand the following points;

- 1. All SCs are logged.
- 2. At first, always turn the main switch off and on if an SC code is issued.
- 3. First, disconnect then reconnect the connectors before you replace the PCBs, if the problem concerns electrical circuit boards.
- 4. First, check the mechanical load before you replace motors or sensors, if the problem concerns a motor lock.
- 5. Fusing related SCs: To prevent damage to the machine, the main machine cannot be operated until the fusing related SC has been reset by a service representative.
 - Enter the engine maintenance mode.
 - Press "O.K" in "Fuser SC Reset" with engine maintenance mode, and then turn the main power switch off and on.

Engine SC

SC 1xx (Other Error)

	Serial Number Error
	The serial number stored in the memory (EGB) is not correct.
195	EEPROM defective
	EGB replaced without original EEPROM
	1. Check the serial number.
	2. If the stored serial number is incorrect, contact your supervisor.

SC 2xx (Laser Optics Error)

202	Polygon motor error 1: ON timeout
	The polygon mirror motor does not reach the targeted operating speed within 5 sec. after turning on or changing speed
	Polygon motor error 2: OFF timeout
203	The polygon mirror motor does not leave the READY status within 3 sec. after the polygon motor switched off.
	Polygon motor error 3: XSCRDY signal error
	The SCRDY_N signal remains HIGH for 200 ms while the LD unit is firing.
	 Polygon motor/driver board harness loose or disconnected
	 Polygon motor/driver board defective
204	Laser optics unit defective
	IPU (EGB) defective
	1. Replace the interface harness of the laser optics unit.
	2. Replace the laser optics unit.
	3. Replace the EGB (Engine Board).

220	Laser Synchronizing Detection Error: [K]/[Y]			
	The laser synchronizing detection signal for LDB [K]/[Y] is not output after the LDB unit has turned on while the polygon motor is rotating normally.			
	Laser Synchronizing Detection Error: [M]/[C]			
The laser synchronizing detection signal for LDB [M]/[C] is not output after the LD turned on while the polygon motor is rotating normally.				
	• Disconnected cable from the laser synchronizing detection unit or defective connection			
222	Defective laser synchronizing detector			
	Defective LDB			
	Defective EGB			
	1. Check the connectors.			
	2. Replace the laser optics unit.			
	3. Replace the EGB.			

	LD error	
	The IPU (EGB) detects a problem at the LD unit.	
240	Worn-out LD	
	 Disconnected or broken harness of the LD. 	
	1. Replace the laser optics unit.	

SC 3xx (Charge Error)

	High voltage power output error			
	The measured voltage is not correct when the EGB measures each charge output (charge, development, image transfer belt unit, and transfer unit).			
300	Disconnected or defective high voltage harness			
300	Detective high voltage power supply			
	Defective EGB			
	1. Check or replace the harnesses.			
	2. Replace the high voltage power supply board			
	3. Replace the EGB.			

	Black drum motor error			
396	The LOCK signal error is detected when the EGB monitors the black drum motor state. (This monitoring is done immediately after power-on, when the motor starts rotating, and immediatel after the motor stops.)			
	• Disconnected or defective motor harness.			
	 Motor slips due to excessive load 			
	1. Check the harness from the black drum motor. Replace it if necessary.			

Color	drum	motor	error
			~ ~ .

The LOCK signal error is detected when the EGB monitors the color drum motor state. (This monitoring is done immediately after power-on, when the motor starts rotating, and immediately after the motor stops.)

- Disconnected or defective motor harness.
- Motor slips due to excessive load
 - 1. Check the harness from the color drum motor. Replace it if necessary.

SC 4xx (Image Transfer and Transfer Error)

ITB (Image Transfer Belt) Unit: Home Position Error

The ITB contact sensor does not detect the home position of the ITB for 5 seconds after the ITB unit initialization has been done.

ITB (Image Transfer Belt) Unit: Contact Position Error

The ITB contact sensor does not detect the contact position of the ITB for 5 seconds after the ITB unit has moved to the contact position.

ITB (Image Transfer Belt) Unit: No-contact Position Error

445

The ITB contact sensor does not detect the home position of the ITB for 5 seconds after the ITB unit has moved to no-contact position.

- Defective ITB contact motor
- Defective ITB contact sensor
- Defective ITB unit
 - 1. Replace the ITB contact motor.
 - 2. Replace the ITB contact sensor.
 - 3. Replace the ITB unit.
| 480 | Agitator Motor Error |
|-----|--|
| | The agitator motor error is detected twice for 10 msec during the initialization at power-on or after the cover is closed. |
| | Disconnected or defective harness |
| | Defective agitator motor |
| | 1. Check or replace the harness. |
| | 2. Replace the agitator motor. |

490	ITB (Image Transfer Belt) Unit Set Error	
	The TM sensor does not detect the reflection from the ITB.	
	No ITB unit in the machine	
	Dirty TM sensor	
	1. Check the installation of the ITB unit.	
	2. Clean the TM sensor.	

SC 5xx (Motor and Fusing Error)

	Transport/Fusing Motor Error
500	The LOCK signal error is detected when the EGB monitors the transport/fusing motor state. (This monitoring is done immediately after power-on, when the motor starts rotating, and immediately after the motor stops.)
	• Disconnected or defective motor harness.
	 Motor slips due to excessive load
	1. Check the harness from the transport/fusing motor. Replace it if necessary.

	LSU Fan Motor Error
530	A LOCK signal is not detected for more than ten seconds while the motor START signal is on and if this error occurs twice consecutively, this SC is issued.
	Disconnected or defective motor harness.
	Defective LSU fan motor
	1. Check or replace the motor harness.
	2. Replace the LSU fan motor.

Fusing Fan Motor Error

A LOCK signal is not detected for more than ten seconds while the motor START signal is on and if this error occurs twice consecutively, this SC is issued.

- Disconnected or defective motor harness.
 - Defective LSU fan motor
 - 1. Check or replace the motor harness.
 - 2. Replace the fusing fan motor.

541	Thermistor Error
	The thermistor output is less than 0°C for 7 seconds.
	Disconnected thermistor
	Defective harness connection
	1. Check the harness connection of the thermistor.
	2. Replace the fusing unit.
	€ Important
	• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

	Print Ready Temperature Error
	• The heating roller temperature increase during a set time is not correct.
	 The fusing temperature does not reach the print ready temperature within a set time after the fusing lamp has turned on.
	Defective thermistor
	 Incorrect power supply input at the main power socket
542	Defective fusing lamp
	1. Check the voltage of the wall outlet.
	2. Replace the fusing unit
	3. Replace the fusing lamp.
	€ Important
	• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

	High Temperature Detection Error
	This SC is issued if one of following conditions occurs:
	• The thermistor (center) detects 255°C or thermistor (end) detects 245°C.
	• The thermistor (center) detects a 3°C increment or more for five seconds at 220°C or more or the thermistor (end) detects a 4°C increment or more for five seconds at 210°C or more.
543	Defective I/O control (EGB)
	Defective EGB
	1. Replace the EGB
	(2) Important
	• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

3. Appendix: Troubleshooting Guide

Heating Lamp Full-Power Error

The fusing lamp is fully-powered for a certain time while the fusing unit stays in the stand-by mode and is not rotating.

- Deformed thermistor
- Thermistor not in the correct position
- Defective fusing lamp
 - 1. Replace the fusing unit.
 - 2. Replace the fusing lamp.

🔁 Important

• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

Zero Cross Error

The zero cross signal is not detected for three seconds even though the fusing lamp relay is on after turning on the main power or closing the front door.

- 547 Defective fusing lamp relay
 - 1. Turn the main power switch off and on.

🚼 Important

• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

	Low Temperature Error
	The center thermistor detects 100°C or less for 4 seconds.
	Defective fusing lamp
_ / _	Defective thermistor
548	1. Replace the fusing unit.
	2. Replace the fusing lamp.
	⇔Important
	• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

Zero Cross Frequency Error The detection error occurs ten times consecutively in ten zero cross signal detections. This error is defined when the detected zero cross signal is 17 or less/27 or more for 0.2 seconds. • Defective fusing lamp relay • Unstable input power source 1. Check the power supply source. 2. Replace the fusing unit. Important • Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated			
 The detection error occurs ten times consecutively in ten zero cross signal detections. This error is defined when the detected zero cross signal is 17 or less/27 or more for 0.2 seconds. Defective fusing lamp relay Unstable input power source Check the power supply source. Replace the fusing unit. Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated 			Zero Cross Frequency Error
 Defective fusing lamp relay Unstable input power source Check the power supply source. Replace the fusing unit. Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated 			The detection error occurs ten times consecutively in ten zero cross signal detections. This error is defined when the detected zero cross signal is 17 or less/27 or more for 0.2 seconds.
 557 Unstable input power source Check the power supply source. Replace the fusing unit. Important Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated 			Defective fusing lamp relay
 Check the power supply source. Replace the fusing unit. Important Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated 		557	Unstable input power source
 2. Replace the fusing unit. Important Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated 			1. Check the power supply source.
 Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated 			2. Replace the fusing unit.
• Execute "Engine Maintenance Menu" to recover the machine after completing the recover procedure. Otherwise, the machine continues to issue this SC code and cannot be operated			☆Important
			• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

	Consecutive Fusing Jam
	The paper jam counter for the fusing unit reaches 3. The paper jam counter is cleared if the paper is fed correctly.
	This SC is activated only when this function is enabled with "Engine Maintenance" (default "OFF").
	Defective fusing unit
559	Defective fusing control
	1. Clear this SC to send a command after a jam removal.
	2. Turn off this function after a jam removal.
	☆Important
	• Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated.

SC 6xx (Communication and Other Error)

	EEPROM Error
	An unexpected value exists in the initialization flag of the EEPROM
	EEPROM not initialized
669	Defective EEPROM
	1. Initialize the EEPROM.
	2. Replace the EEPROM.
	3. Replace the EGB.

690	GAVD Communication Error
	The ID of the GAVD is not identified during initialization.
	The chip ID of the GAVD cannot be detected by the machine at power-on.
	Defective EGB
	1. Replace the EGB.

Controller SC

SC8xx

819	Service Cycle Power
	 Incorrect combination of EGB and controller board. An unexpected error occurs in the EEPROM on the controller board.
	Controller board defective
	1. Install the correct EGB and controller boards for this machine.
	2. Replace the controller board

823	USB/ Network Device Error
	An interface error in the USB connection or NIB connection occurs.
	Controller board detective
	1. Replace the controller board.

824	EEPROM Error
	An EEPROM check error at power-on occurs.
	Controller board detective
	1. Replace the controller board.

On-Board Memory Check Error
An on-board memory check error at power-on occurs.
Controller board detective
1. Replace the controller board.

	ROM Checksum Error	
828	A ROM checksum error at power-on occurs.	
	1. Replace the controller board.	

3. Appendix: Troubleshooting Guide

Service Menu

Overview

This model has several service menus. Each service menu has several adjustment items. This section explains how to enter each service menu and what you can do in each service menu.

Each menu is classified into two "Modes" depending on how you enter the service menus.

- "Menu Mode" can be executed by pushing a sequence of keys.
- "Special Mode" can be executed if you press certain keys at the same time as you turn the power on.

Each menu is classified as follows:

Menu Mode		
Maintenance Mode Menu	This is a menu for maintenance and service.	
Special Mode		
Fax Service Test Menu	This is a menu for checking the fax mode.	

Maintenance Mode Menu

Additional Maintenance Mode Information

Selecting an Item

To select an item, press the "Up" or "Down" key.

Going into the Next Level/ Returning to the Previous Level

- To go into the next level of an item, select an item then press the "OK" key.
- To return to the previous level of an item, press the "Return" key.

Exiting the Maintenance Mode Menu

To exit the maintenance mode menu, press the "Clear/Stop" or "Return" key until the "Ready" display appears.

Menu List

Display Info		
Model Name		Displays the Model Name, Depends on Engine Firmware Settings
	CTL FW Ver.	Displays the Firmware Version
	FAX FW Ver.	Displays the PDL Firmware Version.
rvv ver.	MCTL FW Ver.	Displays the Engine Firmware Version
	PDL FW Ver.	Displays the PDL Firmware Version.
	Printer Counter	Displays the following counters of the printer engine. Total Page/ Color Image/ Black Image
	Scanner Counter	Displays the sum total of scanner counters for each mode. Total Page/ Black Page/ Color Page / ADF Used
Counter	Jam Counter	Displays the number of paper jams at each location. Total/ ADF/ Printer Output Bin/ Internal/ Tray1 / Tray2/ Duplex
	Coverage 1/ Coverage 2	Coverage 1: [0 to 100 / 5 / 1/step] Coverage 2: [0 to 100 / 20 / 1/step] Changes the thresholds for each coverage counter.

Print Reports		
G3 Protocol dump list	G3 protocol dump of the latest communication is printed. Off (Default)/ Error/ On	

Engine Maintenance		
	Text	Determines the maximum amount of ink/toner you can use in any area of your text. This is where you are controlling exactly how much ink will be used during printing. [200 to 400 / 250 (Default)/ 10/step] Setting 0: Off
Toner Limit	Graphic	Determines the maximum amount of ink/toner you can use in any area of your graphic. This is where you are controlling exactly how much ink will be used during printing. [200 to 400 / 250 (Default)/ 10/step] Setting 0: Off
	Image	Determines the maximum amount of ink/toner you can use in any area of your image. This is where you are controlling exactly how much ink will be used during printing. [200 to 400 / 250 (Default)/ 10/step] Setting 0: Off
P. P. Name	NA Model: RICOH/ EU Model: RICOH/	'nul' NRG/ LANIER
N, Italie	ASIA Model: RICOH/ LANIER China Model: RICOH	
Destination	Sets the destination and updates the engine setting. JPN/ NA (Default)/ EU/ ASIA/ China	

Engine Maintenance			
	2nd Transfer Front	Adjusts the transfer roller current, based on the default value.	
		[-15 to 15 / 0 (Default) / 1 µA/step]	
	2nd Transfer Back	Adjusts the transfer roller current, based on the default value.	
		[-15 to 15 / 0 (Default) / 1 µA/step]	
2nd Transfer Fuser Temp.	Fuser Temperature	Adjusts the temperature of the fusing unit, based on the default value.	
		[-30 to 0 / 0 (Default) / 2°C/step]	
	Media Type	Plain Paper (90-105 g/m ²)/ Plain Paper/ Thick Paper (1405-110 g/m ²)/ Thin Paper (60-75 g/ ²)/ Thick Paper (Post Card)/ Envelop/ Cardstock/ Bond paper/ Label Paper/ Prepunched/ Preprinted/ Letterhead/ Color/ Recycled	
	Horiz. Tray 1	Adjusts the horizontal registration for tray 1. If the machine settings are reset to the factory defaults, this value does not change.	
		[-15 to 15 / 0 (Default) / 4 mm/step]	
	Vert.Tray 1	Adjusts the vertical registration for tray 1. If the machine settings are reset to the factory defaults, this value does not change.	
Pagistration		[-15 to 15 / 0 (Default) / 0.24 mm/step]	
Registration	Horiz.Tray2	Adjusts the horizontal registration for tray 2. If the machine settings are reset to the factory defaults, this value does not change.	
		[-15 to 15 / 0 (Detault) / 4 mm/step]	
	Vert.Tray2	Adjusts the vertical registration for tray 2. If the machine settings are reset to the factory defaults, this value does not change.	
		[-15 to 15 / 0 (Default) / 0.3 mm/step]	

Engine Maintenance		
	Horiz.Bypass	Adjusts the horizontal registration for the bypass tray. If the machine settings are reset to the factory defaults, this value does not change. [-15 to 15 / 0 (Default) / 4 mm/step]
	Vert.Bypass	Adjusts the vertical registration for the bypass tray. If the machine settings are reset to the factory defaults, this value does not change. [-15 to 15 / 0 (Default) / 0.3 mm/step]
Registration	Horiz.Dup.Back	Adjusts the horizontal registration for the back side in duplex mode. If the machine settings are reset to the factory defaults, this value does not change. [-15 to 15 / 0 (Default) / 4 mm/step]
	Vert.Dup.Back	Adjusts the vertical registration for the back side in duplex mode. If the machine settings are reset to the factory defaults, this value does not change. [-15 to 15 / 0 (Default) / 0.3 mm/step]
Reset Count	Resets counters to factory defaults.	
Clear Count	Clears the Scanner and Jam Counters.	
Replace Fuser	Resets the maintenance counter for the fusing unit. This item appears only when the fusing unit life is almost expired or has ex	
Init Engine EEPROM	This clears all counters except "Full Color" and "Black and White" in the total counter. When you execute "Init Engine EEPROM", the engine EEPROM is initialized. Turn the machine power off/on after you change this setting.	
Model	Displays only 1: MF2b 2: MF2c Displays the current model in a dropdown list. Do not change this setting (Designed for Factory Use).	

Engine Maintenance			
	00* – 7F		
Brand ID	Displays the current b	orand ID number.	
	Do not change this se	atting (Designed for Factory Use).	
LSU Adjustment	Input 160 bytes	Character: alphanumeric "0-9", "a-f", "A-F", only valid data can be input.	
	sennig.	Input length: 160 bytes	
Trans. Belt Adjust	When you execute "Trans. Belt Adjust", the transfer belt adjustment is done. This calibrates the motor speed to match the length of the new transfer belt.		
Fuser SC Detect	On/Off*	If On, the engine detects SC559. If Off, the engine does not detect "Fusing SC Reset".	
	The engine will do color registration and density tuning automatically.		
Color Registration	The machine will warm up automatically after this setting is changed.		
Reset Transfer Unit Life Counter	Resets the transfer unit life counter.		
Fuser SC Reset	This button is for resetting an SC related with the fusing errors.		
	This adjusts the M/A of toner.		
Special Mode	[0 to 0x7F]		
	0x00 : Normal (Default: no reduction)		
	0x06: 20% reduction		
	0x07: 10% reduction		

Scan Maintenance		
Mono Compression	Sets the monochrome compression type for scanning.	
Setting	MH (Default)/ MR/ MMR	

Scan Maintenance		
	ADF Main Reg.	Adjusts the ADF Scan main-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 mm/step]
	ADF Sub Reg.	Adjusts the ADF Scan sub-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 mm/step]
kegist Adjust	Flatbed Main Reg.	Adjusts the Flatbed Scan main-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 mm/step]
	Flatbed Sub Reg.	Adjusts the Flatbed Scan sub-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 mm/step]
Size Adjust	ADF Main Reg.	Adjusts the ADF Scan main-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step]
	ADF Sub Reg.	Adjusts the ADF Scan sub-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step]
	Flatbed Main Reg.	Adjusts the Flatbed Scan main-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step]
	Flatbed Sub Reg.	Adjusts the Flatbed Scan sub-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step]

Fax Maintenance		
Modem Settings	RX Level	Sets the reception level. [-43 dBm (Default)/ -33 dBm/ -26 dBm / -16 dBm]
	TX Level	Sets the transmission level. [O dBm/ -1 dBm/ -2 dBm/ -3 dBm/ -4 dBm / -5 dBm/ -6 dBm/ -7 dBm/ -8 dBm/ -9 dBm / -10 dBm/ -11 dBm/ -12 dBm/ -13 dBm / -14 dBm/ -15 dBm]
	Cable Equalizer	These selectors are used to improve the pass-band characteristics of analogue signals on the telephone line. [OKm (Default)/ 1.8Km/ 3.6Km/ 7.2Km]

Fax Maintenance		
Protocol Definition	Training Retries	This sets the number of training retries to be repeated before automatic fallback. [1 Time/ 2 Times (Default)/ 3 Times/ 4 Times]
	Encoding	Sets the compression method for Tx/Rx. [MMR+MR+MH (Default)/ MR+MH/ MH]
Protocol Definition Timer	TO Timer	Timeout for response from the called station in automatic sending mode [35 Sec/ 45 Sec/ 55 Sec (Default)/ 60 Sec/ 90 Sec/ 140 Sec]
	T1 Timer	Set the time length for the T1 timer. [40 Sec (Default)/ 50 Sec]
	T4 Timer	Set the time length for the T4 timer. [3 Sec (Default/ 4.5 Sec]

Fax Maintenance		
	Silence Detection Time	Silence (No tone) detection time (Rx mode : FAX/ TAD Only) After the line is connected via the external telephone, the
		machine can detect silence (no tone) for the time length specified by this setting.
		[30 sec (Default)]
		CNG tone detection time (RX mode : FAX / TEL, FAX / TAD Only)
	CNG Tone Detection Time	After the line is connected via the external telephone, the machine can detect a CNG signal for the time length specified by this setting.
		[5 Sec (Default)/ 10 Sec]
RX Settings		Number of CNG cycles to be detected
	CNG Cycles	This setting is only effective for FAX/TAD mode.
		[1.5 Cycle (Default)/ 2.0 Cycle]
	Tone Sound	Determines the period when tones from the line are monitored.
	Monitoring	[No Monitoring/ Up To Phase B (Default)/ All TX Phases]
	Stop/Clear key	Pressing the Stop/Clear key can stop the current receiving operation. Received data is lost.
		[Not Functional (Default)/ Functional]
	Off-Hook Level	Sets the off-hook detection threshold.
		[10V (Default)/ 15V/ 20V/ 25V]
TX Settings	Redial Interval	Sets the redial interval when Tx fails.
		[5 Min/ 6 Min]
	Redialings	Sets the number of redials when Tx fails.
		[2 times/ 3 Times/ 4 Times/ 5 Times]

Fax Maintenance		
Overseas Comm Mode Settings	Overseas Comm Mode	This sets the machine to ignore a DIS signal sent from the called station once in a sending operation. [Off (Default)/ Ignore DIS Once]
	Minimum Time Length	If this setting is set to "On", the machine detects the CNG signal after the line is connected. If it is set to "Off", the machine detects the CNG signal as long as the line is connected.
Dial Pulse Setting	Dial Pulse Type	 Ihis sets the number of pulses that are generated during dialing. N: Dialing '0' generates 10 pulses Dialing '9' generates 9 pulses. N+1: Dialing '0' generates 1 pulses Dialing '9'
		generates 10 pulses.
		 10-N: Dialing '0' generates 10 pulses Dialing '9' generates 1 pulse.
	Tone Signal Transmission Time Length	Sets the tone signal transmission time length [100 ms (Default)]
	Minimum Pause In Tone Dialing	Sets the minimum pause during tone dialing
		[100 ms (Default)/ 150 ms/ 200 ms]
Tone Signal Settings	Attenuator For Pseudo Ring Backtone To the Line	Sets the attenuator for pseudo ringback tone to the line [0 to 15 / 10 (Default)/ 1 dB/step]
	DTMF Level	Sets the transmission level of DTMF tones.
		[-12 dBu / -11 dBu/ -10 dBu/ -8 dBu/ -6 dBu]
	DTMF Delta	Sets the level difference between high band frequency signals and low band frequency signals when sending DTMF tones. [2 dBu/ 3 dBu]

Fax Maintenance		
	Wait Time	The machine starts dialing after the specified interval without detection of a dial tone when
		Dial tone detection is set to "No detection".
		[3.5 Sec (Default)/ 7.0 Sec/ 10.5 Sec
1 Dial Tone		/ 14.0 Sec]
Detection	Timeout Length	This setting sets the time-out length for the 1 st dial tone detection. The machine waits for a dial tone for the specified time and disconnects itself from the line when no dial tone is input. [10 Sec (Default)/ 15 Sec/ 20 Sec/ 30 Sec]
		DFU
	BT Setting	[Off/ On]
		BT: Busy tone
		DFU
BT (Busy Tone) Detection	BT Frequency	[300-550 Hz/ 300-650 Hz/ 325-525 Hz/ 340-550 Hz/ 350-500 Hz/ 350-550 Hz/ 375-475 Hz/ 380-520 Hz]
	BT Level	DFU
		[-35 dB/ -36 dB/ -37 dB/ -38 dB/ -39 dB]
		DFU
	BT Cadence	[0.10/ 0.15/ 0.20/ 0.25/ 0.30/ 0.35/ 0.40/ 0.45/ 0.50/ 0.75]
Comm Settings	RTN Rate	The machine checks the actual data reconstruction errors and then transmits an RTN depending on the decoding error rate that is set by this setting (Number of lines containing an error per page / Total number of lines per page). [10%/ 15%]
	V34 Modem	DFU
		[Permitted (Default)/ Prohibited]
	V17 Modem	DFU
		[Permitted (Default)/ Prohibited]

Fax Maintenance		
V34 Settings	Equalizer	These selectors set the equalizer's training level to be applied if training fails due to poor line connection. [Automatic (Default)/ 4 Points/ 16 Points]
	Redialing	Resend when a communication error occurs. [Disabled (Default)/ Not Disabled]
	First TX Speed	Sets the first transmission speed choice, before fallback. [2400 Bps/ 4800 Bps/ 7200 Bps/ 9600 Bps / 12000 Bps/ 14400 Bps/ 16800 Bps/ 19200 Bps/ 21600 Bps/ 24000 Bps/ 26400 Bps/ 28800 Bps/ 31200 Bps/ 33600 Bps (Default)]
	Symbol Rate	This setting limits the transmission speed range in V.34 mode by masking the desired symbol rate(s). [Not Used (Default)/ 3429 Sym/Sec / 3200 Sym/Sec/ 3000 Sym/Sec / 2800 Sym/Sec/ 2400 Sym/Sec]

Note

- The "Reseller Default" menu can be entered directly at power-on. If you want to enter this mode directly, try the following procedure.
- Turn on the machine while pressing the "Copy" key.

"Overall Ringings w/TAD" (FAX/TAD mode) can now be changed. (F/w ver 1.11)

Fax Service Test Menu

Entering the Fax Service Test Menu

Turn on the machine while pressing the "Fax" key.

Selecting an Item

To select the item, press the "Up" or "Down" key.

Going into the Next Level/ Returning to the Previous Level

• To go into the next level of an item, select an item then press the "OK" key.

RTB 2b

• To return to the previous level of an item, press the "Return" key.

Exiting the Maintenance Mode Menu

To exit the maintenance mode menu, press the "Clear/Stop" or "Return" key until the "Ready" display appears.

Menu List

Fax Test		
Off-Hook Test	On Hook	Executes the on hook test.
	Off Hook	Executes the off hook test
CED Test		Executes the CED test.
CNG Test	1100 Hz	Executes the CNG test
ANSam		Executes the ANSam test.
Ring Tone Test		Executes the ring tone test.
	Tone [0] to [9]	Executes the DTMF tone 0 to 9 test.
DTMF Test	Tone [*]	Executes the DTMF tone * test.
	Tone [#]	Executes the DTMF tone # test.
	Tone Stop	Executes the Stop DTMF tone test.

	[V34] 33600 bps	Generates the [V34] 33600 bps signal.
	[V34] 28800 bps	Generates the [V34] 28800 bps signal.
	[V17] 14400 bps	Generates the [V17] 14400 bps signal.
	[V17] 12000 bps	Generates the [V17] 12000 bps signal.
	[V17] 9600 bps	Generates the [V17] 9600 bps signal.
	[V17] 7200 bps	Generates the [V17] 7200 bps signal.
Modem Test	[V29] 9600 bps	Generates the [V29] 9600 bps signal.
	[V29] 7200 bps	Generates the [V29] 7200 bps signal.
	[V27] 4800 bps	Generates the [V27] 4800 bps signal.
	[V27] 2400 bps	Generates the [V27] 2400 bps signal.
	[V21] 300 bps	Generates the [V21] 300 bps signal.
	Signal Stop	Generates the Stop signal.

5. Appendix: Machine Swap

Exchange and Replace Procedure

If the machine exchange and replacement is required, arrange to send a machine without the four print cartridges (AIO) to the customer site.

Instruction

Instruct the customer to do the following procedure.

Before the substitute machine gets to the customer site

- Save the customer settings by using a web browser. For details, refer to the "User Guide".
- Clear customer settings in the problem machine.

When the substitute machine gets to the customer site

- 1. Remove the four print cartridges (AIO) from the problem machine.
- 2. Install the four print cartridges (AIO) into the substitute machine.
- 3. Restore the customer settings by using a web browser.
- 4. Send back the problem machine to the repair center.

Cleaning Points after Machine Arrival at Depot

1. Open the front cover.



m018r549

- 2. Release the locks [A].
- 3. Transfer unit [B]









m018r691b

- 5. Release the hook [A] under the guide plate.
- 6. Move the guide plate [B] underneath the fusing unit to the left, and then remove it.



7. Pull out the image transfer belt unit [A] (\mathscr{P} x 2).



8. Clean inside the machine, especially around the circled area [A].



- 9. Clean the circled area at the waste toner bottle [A] and circled area [B] at image transfer belt unit.
- 10. Reassemble the machine.

MEMO