


Scan and Fax Manager Barcode Plug-in

Administrator's Guide

The Scan and Fax Manager Barcode Plug-in is Scan and Fax Manager (SFM) plug-in filters that read barcodes in documents scanned by a multifunction device (MFP) and save the data obtained from the barcodes as the bibliographical information of a document. Use of this plug-in in conjunction with each SFM distribution service allows you to identify and distribute documents efficiently, managing them according to their barcodes.



BTPO

Fig. 1: Scan and Fax Manager Barcode Plug-in Workflow

Note

- This plug-in is displayed as "Barcode Separator/Index" on the SFM server, in AdminTool, and on the MFP control panel.
- This manual explains the configuration procedures for the Barcode Plug-in. For details about Administrator Settings and Service/Filter Settings, see *Scan and Fax Manager Administrator's Guide*.

Introduction

This manual contains detailed instructions and notes on the operation and use of this product. For your safety and benefit, read this manual carefully before using the product. Keep this manual in a handy place for quick reference.

Important

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW:
 - THE SUPPLIER SHALL NOT BE LIABLE FOR THE RESULT OF OPERATION OF THIS SOFTWARE OR THE USE OF THIS DOCUMENT.
 - THE SUPPLIER SHALL NOT BE LIABLE TO YOU FOR DAMAGES OR LOSS OF ANY DOCUMENT OR DATA PRODUCED BY USING THIS SOFTWARE.
 - THE SUPPLIER SHALL NOT BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL OR INDIRECT DAMAGES (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION OR LOSS OF BUSINESS INFORMATION, AND THE LIKE) CAUSED BY FAILURE OF THIS SOFTWARE OR LOSS OF DOCUMENTS OR DATA, NOR FOR ANY OTHER DAMAGES ARISING OUT OF THE USE OF THIS SOFTWARE, IF THE SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.
- Some illustrations or explanations in this guide may differ from your product due to improvement or change in the product.
- The contents of this document are subject to change without notice.
- No part of this document may be duplicated, replicated, reproduced in any form, modified or quoted without prior consent of the supplier.
- It is possible that any document or data stored in the computer will be damaged or lost by user error during operation or software error. Be sure to back up of all important data beforehand. Important documents and data should always be copied or backed up. Documents and data can be lost because of malfunction or human error. Furthermore, the customer is responsible for protection measures against computer viruses, worms, and other harmful software.
- Do not remove or insert any disk while operating this software.

Before You Begin

Abbreviations

The following abbreviations are used in this guide.

Product / Name	Abbreviation
Scan and Fax Manager	SFM
Multifunctional Device	MFP, Device
Scan and Fax Manager Barcode Plug-in	Barcode Plug-in

Supported File Formats

The Barcode Plug-in supports the following file formats.

File Formats
TIFF
TIFF-F
DCX
BMP
JPEG
PNG
GIF

↓ Note

- Barcodes included in PDF files and files created in other applications cannot be recognized. If data that cannot be recognized is scanned, a processing error occurs and the job stops regardless of the Error Handling setting (See P.11).

Supported Barcodes

The following table shows the barcode formats that the Barcode Plug-in can read.

Linear Barcodes	2D Barcodes
Code39 Standard ASCII	PDF417
Code39 Extended ASCII	DataMatrix
Code128	QR
EAN 8	
EAN 13	
Interleaved 2 of 5	
Code 2 of 5	
Codabar(NW7)	
GSI(EAN)-128	

Cautions on Orientation of Originals

- The Barcode Plug-in does not adapt to variation in original orientation. For this reason, be sure to set the original in the correct orientation. For details about setting originals, see *Operating Instructions* supplied with the MFP.
- Depending on the setting made for the orientation of originals, the position of the barcode on the actual original might not correspond to the barcode position or the coordinates of the scan area.

Features of the Barcode Plug-in

If you scan a multiple-page document using multiple-page settings, all pages of the scan job will be saved together as a single file. If you scan a multiple-page document using single-page settings, each page of the scan job will be saved as a separate file.


- Only the barcode on the first page of the first section of a document is read. The barcodes on the following pages or in other sections are not read. However, if [**Continue Recognition Even When 1st Page Has No Barcode**] is enabled in the General Settings tab, the barcodes on the following pages or in other sections can also be read.
- By selecting a preset format, you can specify (delimiter) what data is obtained from barcodes.
- Data obtained from barcodes by delimiting can be saved as custom SFM bibliographical information.
- Saved bibliographical information can be utilized by other SFM services.
- Tag names required for saving data as bibliographical information can be specified.
- The job-splitting function allows you to use barcodes to save large, multiple-page documents as separate files.

Splitting Multiple-Page Documents into Separate Files

Normally, when you scan a multiple-page document, it is saved as a large, single file containing multiple pages. However, using the job-splitting function of the Barcode Plug-in, you can save a multiple-page document as separate files containing fewer pages. When you apply the job-splitting function, the document is split into separate files each time a common barcode is read.

Example

In this example, a nine-page document features a common barcode printed in the upper right corner of three of the nine pages. When scanned, the document is split each time the common barcode is read, so the document is saved as three separate files.



BTP011S

Adding the Barcode Plug-in

Step 1: Login to AdminTool

For details, see "3. Login and Logout" and "5. Server Management", *RICOH Streamline NX Administrator's Guide*.

Step 2: Add a Profile

1. Click **[Profile]**.



Fig. 5: AdminTool Home Page

2. Click **[Create]**.
The Profile Properties screen appears.
If you are adding the Barcode Plug-in to an existing profile, proceed to P.6 "Step 3: Add a Group".
3. Enter the profile name and screen title.
Note
 - The profile name can contain up to 128 characters.
 - The screen title can contain up to 50 characters.
 - For details about profile settings, see *Scan and Fax Manager Administrator's Guide*.
4. Click **[OK]**.

Step 3: Add a Group

1. In the Profile List, double-click the profile name you want to add the Barcode Plug-in to.

The Group/Project screen appears.



Fig. 6: Group/Project screen

- Note**
 - If you are adding the Barcode Plug-in to an existing group, click the group you require, and then proceed to P.6 "Step 4: Add a Project".
2. Click **[Group]** (top left).
The Group Properties screen appears.
3. Enter the group name.
Note
 - The group name can contain up to 128 characters.
4. Make sure the status of "Display" is **[On]**.
5. Click **[OK]** to save the settings.
The group appears as a tab on the Group/Project screen.
Note
 - For details about group settings, see *Scan and Fax Manager Administrator's Guide*.

Step 4: Add a Project

1. Drag the **[Project]** button (below the **[Group]** button) to the Group/Project screen.
The Project Properties screen appears.
Note
 - If you are adding the Barcode Plug-in to an existing project, click the desired project, and then proceed to P.7 "Step 5: Add a Service and Filter/Create a Delivery Flow".
2. Enter the project name.
Note
 - For details about project settings, see *Scan and Fax Manager Administrator's Guide*.
3. Click **[OK]**.
A new project button appears.

Step 5: Add a Service and Filter/Create a Delivery Flow

1. Double-click the project button.
The Project Configuration screen appears.
2. Under "New Filter(s)", drag "Barcode Separator/Index" to the Delivery Flow Editor screen.






Fig. 7: Delivery Flow Editor screen

Note

- To automatically align Service(s) and Filter(s), click the [] button (below the [] button).
 - For details about creating a delivery flow, see *Scan and Fax Manager Administrator's Guide*.
3. Under "New Service(s)", drag the service you require to the Delivery Flow Editor screen.
 4. Double-click the lower half of the Service/Filter icon added to the Flow.

The Properties screen appears.

Note

- There are three levels at which you can configure the properties for services: the System Level, Profile Level, and Project Level. This example procedure explains how to configure the properties at the Project Level. For details about how to specify the properties in other levels, see *Scan and Fax Manager Administrator's Guide*.
 - For details about how to specify the properties of the Barcode Plug-in, see P.8 "Configuring the Barcode Plug-in".
 - The contents of each setting vary depending on the Service/Filters. For details, see *Scan and Fax Manager Administrator's Guide*. If you are using the optional Service/Filter plug-in, see the Administrator's Guide of each plug-in.
5. Change the settings as necessary.
 6. Click [Apply], and then [OK] to return to the Group/Project screen.

Step 6: Configure the MFP(s)


For details, see "6. Configuration", *RICOH Streamline NX Administrator's Guide*.

Configuring the Barcode Plug-in

Use Barcode Plug-in properties to configure the plug-in's barcode read settings. The values of each setting are registered for each barcode. The Barcode Configuration screen contains details of the read settings registered for each barcode.

Barcode Configuration Screen

You can use this screen to register barcode read settings, and to change or delete previously registered barcode read settings.



BTP014S

Fig. 9: Barcode Configuration screen

Note

- Settings on the screen that are marked with an asterisk (*) must be specified.

A. Display Name

Enter a display name for this filter.

Note

- The display name can contain up to 30 characters.

B. Add/Edit/Delete

Add: Register new items of barcode data to be read.

Edit: Change previously registered barcode read settings.

Delete: Remove previously registered barcode read settings.

C. Barcode Configuration Table

Lists registered settings for each barcode. To change or delete a setting, select its check box and then click [Edit] or [Delete].

The table shows the following barcode read settings:

- Barcode Batch Separation
- Delete Sheet
- Selection Method
- Barcode Position
- Barcode Type
- Tag Name

General Settings Tab

This tab contains the settings for registering new barcode information or changing the information of previously registered barcodes.




Fig. 10: General Settings screen

↓ Note

- Settings on the screen that are marked with an asterisk (*) must be specified.
- When the job-splitting function is applied, the settings specified on the General Settings screen are reflected in the job-splitting barcode.

A. Use barcode to perform batch separation

Select this check box to perform batch separation (job-splitting) by barcode marker. The following two check boxes are available when this check box is selected:

- Perform batch separation when the barcode data match
- Do not include the barcode sheet in the separated document

Perform batch separation when the barcode data match

Select this check box to read matching barcodes as a job-splitting markers. When this box is selected, the "Barcode data" box becomes available. When reading a barcode, the machine will attempt to match the value (character string) you enter in the "Barcode data" text box with the string registered for the barcode. If a match occurs, the job will be split at the place of the barcode.

Do not include the barcode sheet in the separated document

Select this check box to omit pages that feature a job-splitting marker barcode from the saved scan file.

B. Continue Recognition Even When 1st Page Has No Barcode

- If the check box is selected:

The barcodes on the pages after the first page and the barcodes in the second section and after will be recognized, even if there is no barcode on the first page.
- If the check box is not selected:

The barcodes on the pages after the first page and the barcodes in the second section and after will not be recognized, even if there is no barcode on the first page.

The LastResult_Barcode values recorded in the metadata are as follows, depending on the [Continue Recognition Even When 1st Page Has No Barcode] setting:

	Barcode on the first page	No barcode on the first page
If the check box is selected	Success	Success
If the check box is not selected	Success	Error

C. Selection Method

Barcodes can be recognized according to a specified uniqueness criterion (Selection Method). Select one of the following three settings for the Selection Method:

- Do not Specify
- Barcode Number
- Coordinates

Do not Specify

Select this if you do not want barcodes to be recognized by a specified uniqueness criterion.

Barcode Number

Select this method if you want barcodes to be recognized according to their numbers. When you select this method, if multiple barcodes appear on the same page, they will be numbered according to the numbering rule.

Note

- If you select "Barcode Number" as the Selection Method, you must then specify the relevant barcode number. Enter single-byte digits between 1 and 99 in the "Position" box to specify the barcode number.

Reference

- For details about the barcode numbering rule, see P.12 "Rules of Barcode Numbering".

Coordinates

Select this method if you want barcodes to be recognized according to their position (expressed as X, Y coordinates).

Note

- If you select "Coordinates" as the Selection Method, you must then specify the relevant coordinates. Determine the coordinates as follows: using the upper-left corner of the image as the base point, measure the horizontal (X) and vertical (Y) distance from the base point to the approximate center of the barcode you want recognized. These distances are the coordinates of your barcode. Enter the coordinates in the order of X, Y in the "Position" box. You can select "mm" or "inch" as the units for the coordinates.

Reference

- For details about the coordinates of barcode, see P.13 "Rules of Coordinate Measuring".

D. Barcode Type

Specify one of the following as the barcode type:

- Do not Specify
- Code39 Standard ASCII
- Code39 Extended ASCII
- Code128
- EAN 8
- EAN 13
- Interleaved 2 of 5
- Code 2 of 5
- Codabar(NW7)
- GS1(EAN)-128
- PDF417
- DataMatrix
- QR

E. Data Format

Specify one of the following as the barcode data format:

- Non-delimiter Type
- Delimiter Type
- Digit Type

Delimiter Type

Select this option if the barcode's data format uses arbitrary delimiters to split the data into files. If you select this format, the "Delimiter Rules" field will appear highlighted. Data obtained from barcodes is split into multiple files based on the delimiter entered in the Plug-in "Delimiter Rules" field.

Digit Type

Select this option if the barcode's data format uses the number of characters the data is to be split into as delimiters. If you select this format, the "Delimiter Rules" field will appear highlighted. Data obtained from barcodes is split into multiple files based on the number of digits entered in the "Delimiter Rules" field. Use commas without spaces to separate the digits you enter in this field. For example, if the barcode data is "123xx789yyy", specify "3,2,3,3" to split the data into units of "123", "xx", "789", and "yyy". Asterisk "*" can also be used when entering the number of digits. An asterisk means "all subsequent character strings".

Note

- Select "Non-delimiter Type" if the barcode data is are not delimited.

F. Character Encoding

Specify one of the following as the character code of the barcode data:

- UTF-8
- Windows Shift_JIS
- JIS
- Latin 1
- ASCII

↓ Note

- Be sure to specify the character code that is used in the barcode.

G. Error Handling

Specify one of the following as the plug-in's response in the event of a processing error.

- Stop the job when barcode filter fails
- Ignore error and continue the job

Stop the job when barcode filter fails

If a barcode cannot be read or if its data cannot be decoded or split, an error will be reported and the job will be cancelled.

Ignore error and continue the job

If a barcode cannot be read or if its data cannot be decoded or split, the error will be ignored and the job will continue. However, the data decoded from the barcode is not added as bibliographical information. All barcode reading errors and data decoding/splitting failures are recorded in a warning log.

H. Tag Name

Specify a tag name to be used for new bibliographical information.

If the tag name is for custom bibliographical information added to SFM, the prefix "P0001_" is added to the string entered in this box, and a single underscore "_" followed by a number is added after the string. (Suffixes are determined according to order and range between 1 and 99.)

Example

Bibliographical information names added to documents for which the "Tag name" is "DOC" are as follows:

- P0001_DOC_01
- P0001_DOC_02
- P0001_DOC_03

:

↓ Note

- If a tag name is not specified, the default character string "bcData" is used.
- Curly brackets ({ }) cannot be used for tag names.
- Do not use any tag name more than once.

Procedure

1. Click [**Home**], and then click the [**Profile**] shortcut.
The Profile screen appears.
2. Select the group you require, and then double-click the project you require.
The Delivery Flow screen appears.
3. Double-click the lower half of the "Barcode Separator/Index" icon in the Delivery Flow.
The Properties screen appears.
4. Change the settings as necessary.
5. Click [**Apply**], and then [**OK**] to return to the Group/Project screen.


Rules of Barcode Numbering

When the Selection Method in General Settings is set to "Barcode Number," the following barcode numbering rules are applied:

- The upper-left corner of the scanned image becomes the base (0, 0) coordinate.
- Sequence is determined based on the coordinates of the upper-left corner of each barcode.
- X-coordinates are compared and sequenced in order from the lowest value X-coordinate.
- If the values of two X-coordinates are equal, the data with the lower Y-coordinate value is sequenced first.
- Depending on the number of specified barcode types, the barcodes are numbered as follows:
 - When specifying only one barcode type
Only the specified barcode type is numbered.
 - When specifying multiple barcode types
All of the specified barcode types are numbered.
 - When you do not specify any type of barcode
All barcodes are numbered.

Example of Barcode Numbering

The following illustration shows how barcodes are numbered when there are four barcodes on one page.



BTP012S

Rules of Coordinate Measuring

If the Selection Method in General Settings is set to "Coordinate," the following coordinate measurement rules are applied:

- The upper-left corner of the original becomes the base (0, 0) coordinate.
- The X/Y-direction length through the approximate center of the barcode is measured.


Example of Coordinate Measuring

The following illustration shows how the coordinates of the upper-right barcode are measured when there are four barcodes on one page.

A = Measure as the x-coordinate

B = Measure as the y-coordinate

C = Target barcode



BTP013S