

TotalFlow MR

Operating Instructions Setup Guide

- 1 Before Setting Up
- 2 Installation
- 3 Start-up/Shutdown

Introduction

Important

To the maximum extent permitted by applicable laws, in no event will the manufacturer be liable for any damages whatsoever arising out of failures of this product, losses of documents or data, or the use of this product and operation manuals provided with it.

Make sure that you always copy or have backups of important documents or data. Documents or data might be erased due to your operational errors or malfunctions of the machine. Also, you are responsible for taking protective measures against computer viruses, worms, and other harmful software.

In no event will the manufacturer be responsible for any documents created by you using this product or any results from the data executed by you.

Do not remove or insert any disk or license keys (dongles) while operating this application.

Cautions Regarding this Guide

- Some illustrations or explanations in this guide may differ from your application due to improvement or change in the application.
- The contents of this document are subject to change without notice.
- No part of this document may be duplicated, replicated, reproduced in any form, modified or quoted without prior consent of the manufacturer.

Guides for this Application

The following guides are available for this application:

Instruction Manuals

The following two types of instruction manuals are included:

• Setup Guide (This guide, Printed/HTML/PDF)

This guide explains the setup and startup procedures, and the settings required before you can use this application.

User's Guide (HTML/PDF)

This guide explains the functions and basic operations of this application.

To help you better understand the basic operations of this application, this guide also includes practice lessons using sample files.

Help

Help uses explanatory balloons to explain each of the settings, their values, and how to configure them. In this guide, this type of help is referred to as "on-screen balloon help".



- A Web browser must be installed in order to view the HTML manuals.
 Recommended browser:
 - Internet Explorer 6 SP3 or later
- Adobe® Acrobat® Reader®/Adobe Reader must be installed in order to view the manuals as PDF files.

How to Read the Documentation

Before Using this Application

This manual contains detailed instructions and notes on the operation and use of this application. To ensure correct operation, read this manual carefully and completely before using this application. Keep this manual in a handy place for quick reference.

How to Use the Manuals and Help

Use the instruction manuals (Setup Guide and User's Guide) and Help files (balloon help) according to your needs.

To learn about the functions and basic operations of this application:

See the instruction manuals.

To learn about configuring on-screen settings, correct entry, etc.

See the on-screen balloon help.

Symbols

The following symbols are used in this manual to help you to identify content quickly.

This symbol indicates points to pay attention to when using the application. Be sure to read these explanations.

U Note

This symbol indicates supplementary information that you may find helpful, but not essential to completing a task.

Reference

This symbol indicates where you can find further relevant information.

[]

This symbol indicates the names of screens, menus, settings, and buttons.

Displaying the instruction manuals (Setup Guide and User's Guide)

Use the following procedures to display the instruction manuals (HTML/PDF).

The descriptions in the HTML and PDF formats of instruction manuals are the same.


Displaying the HTML manuals

Start this application, and then select [TotalFlow MR Help] on the [Help] menu.




Displaying the PDF manuals

Click [Start], point to [All Programs] > [TotalFlow MR], and then click either [Setup Guide] or [User's Guide].



Displaying balloon help

When you click the **D** button, help for that item will appear inside a balloon. Clicking **D** Find more within the balloon displays the related page in the HTML manual.



Trademarks

Adobe, Acrobat, the Adobe PDF logo, AIR, Distiller, Flash, and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Microsoft[®], Windows[®], Windows Server[®], Windows Vista[®], Excel[®], PowerPoint[®], and Internet Explorer[®] are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

The proper names of the Windows operating systems are as follows:

• The product names of Windows XP are as follows:

Microsoft® Windows® XP Professional

Microsoft® Windows® XP Home Edition

• The product names of Windows Vista are as follows:

Microsoft® Windows Vista® Ultimate

Microsoft® Windows Vista® Business

Microsoft® Windows Vista® Home Premium

Microsoft® Windows Vista® Home Basic

Microsoft® Windows Vista® Enterprise

• The product names of Windows 7 are as follows:

Microsoft® Windows® 7 Ultimate

Microsoft® Windows® 7 Professional

Microsoft® Windows® 7 Home Premium

Microsoft® Windows® 7 Enterprise

• The product names of Windows Server 2003 are as follows:

Microsoft® Windows Server® 2003 Standard Edition

Microsoft® Windows Server® 2003 Enterprise Edition

• The product names of Windows Server 2003 R2 are as follows:

Microsoft® Windows Server® 2003 R2 Standard Edition

Microsoft® Windows Server® 2003 R2 Enterprise Edition

• The product names of Windows Server 2008 are as follows:

Microsoft® Windows Server® 2008 Standard

Microsoft® Windows Server® 2008 Enterprise

• The product names of Windows Server 2008 R2 are as follows:

Microsoft® Windows Server® 2008 R2 Standard

Microsoft® Windows Server® 2008 R2 Enterprise

The proper name of Internet Explorer 6 is Microsoft Internet Explorer 6.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

TABLE OF CONTENTS

Introduction	1
Important	1
Cautions Regarding this Guide	1
Guides for this Application	2
How to Read the Documentation	3
Before Using this Application	3
How to Use the Manuals and Help	3
Trademarks	6
1. Before Setting Up	
Setup Flow	9
Computer Requirements	10
2. Installation	
Installing the Main Application and Related Programs	13
Installing the Main Application	13
Installing the TotalFlow PDF driver	16
Installing Adobe AIR	17
Uninstallation	19
Uninstalling the Main Application	19
Uninstalling Adobe AIR	
Uninstalling the TotalFlow PDF Driver Manually	20
3. Start-up/Shutdown	
Start-up	21
Preparation	21
Start-up Procedure	21
Shut Down	24
INDEX	

1. Before Setting Up

This chapter explains the setup flow and computer requirements of this application.

Read this chapter thoroughly before setting up this application.

Setup Flow

Set up this application in the following order:

Step 1	Check the operation environment.	p.10 "Computer Requirements"
Step 2	Install the necessary application. 1. Main application 2. TotalFlow PDF driver 3. Adobe AIR® Note • When installing the application for the first time, you can install all the necessary application sequentially in a series of steps. • After the application has been installed, you can install these software applications individually as needed.	p.13 "Installing the Main Application and Related Programs"
Step 3	Start the main application and configure the necessary settings. 1. Insert the license key (dongle) (referred to as "dongle" below). 2. Start the main application. 3. Register printers.	p.21 "Start- up"

Computer Requirements

To run this application, your computer must meet the following requirements. Before setup, check that all the requirements are met.

ltem	Requirements
Computer	CPU: 3 GHz or higher recommended (minimum 2 GHz)
	Main memory: 3 GB or higher recommended (minimum 2 GB)
Hard Disk	Program area: 500 MB
	Free space of at least 10 GB is recommended.
USB Port	Required for connecting the dongle included with this application
	• USB 1.1/2.0
Display	1280 x 1024 pixels or greater recommended (minimum 1024 x 768 pixels)
Operating System	Windows XP Home Edition / Professional SP3 (32bit) / Windows XP Professional SP2 (64bit)
	Windows Vista Home Basic / Home Premium / Business / Enterprise / Ultimate SP2
	Windows 7 Home Premium / Professional / Enterprise / Ultimate SP1
	Windows Server 2003 Standard Edition / Enterprise Edition SP2
	Windows Server 2003 R2 Standard Edition / Enterprise Edition SP2
	Windows Server 2008 Standard / Enterprise SP2
	Windows Server 2008 R2 Standard / Enterprise SP1
	↓ Note
	• Under a 64-bit operating system, this application can be used only in 32-bit mode.
Supported Languages	Dutch, English, French, German, Italian, Spanish
Network	 Ethernet LAN adapter (at least 100 Mbps, wired LAN recommended) TCP/IP protocol (IPv4)

ltem	Requirements		
Associated Application	When using the following types of files, install the necessary supplemental application before setting up this application.		
	Microsoft Office (Word/Excel/PowerPoint) files		
	 Acrobat 8 Standard / Professional (Adobe PDF must be installed.) 		
	 Acrobat 9 Standard / Pro (Adobe PDF must be installed.) 		
	 Acrobat X Standard / Pro (Adobe PDF must be installed.) 		
	 Microsoft Office Word^{*1} 2003 SP3 / 2007 SP2 / 2007 SP3 / 2010 / 2010 SP1 		
	 Microsoft Office Excel^{*1} 2003 SP3 / 2007 SP2 / 2007 SP3 / 2010 / 2010 SP1 		
	 Microsoft Office PowerPoint^{*1} 2003 SP3 / 2007 SP2 / 2007 SP3 / 2010 / 2010 SP1 		
	PS/EPS files		
	 Acrobat 8 Standard / Professional (Acrobat Distiller[®] must be installed.) 		
	 Acrobat 9 Standard / Pro (Acrobat Distiller must be installed.) 		
	 Acrobat X Standard / Pro (Acrobat Distiller must be installed.) 		
Compatible printers and scanners	For details about printers and scanners that are compatible with this application, see Readme.		
	To view the Readme file, click the [Start] button to display the [All Programs] menu. Point to [TotalFlowMR] on the menu, and then click [Readme]. The procedure for viewing the file differs according to the operating system you are using.		

^{* 1} Only the 32-bit version is supported.

2. Installation

This chapter explains how to install and uninstall the main application and the related programs included with this application.

Installing the Main Application and Related Programs

To use this application, you must install the following application and related programs:

Main application

Basic application for this application.

• TotalFlow PDF driver

TotalFlow PDF driver is required if you want to use Microsoft Office (Word/Excel/PowerPoint) documents with this application. When Microsoft Office documents are loaded into this application, this driver converts the documents to PDF format.

Adobe AIR

Adobe AIR is a Flash®-based runtime environment for desktop applications. This program is required for running this application.

Important

- If Adobe Acrobat (not included) is required for your workflow, make sure it is installed before you
 install this application.
- To change the display language of this application after it has been installed, you must uninstall this
 application, and then reinstall it.

Installing the Main Application



• To install this application, you must use an account that has administrator privileges. Make sure you log on with such an account you begin the installation.

Use the following procedure to install the main application.


1. Insert this application's installation media into the computer.

If the Autoplay window opens, select [Install or run program].

If the user account control screen appears, do one of the following according to the level of your account's permissions:


• If your account has administrator permissions, click [Allow].

- If your account has general user permissions only, enter the password for an administrator account, and then click [Yes].
- 2. On the setup screen, click [TotalFlow MR].



- 3. Select the language for the interface, and then click [OK].
- 4. Click [Next].
- 5. Select "I accept the terms of the Software License Agreement.", and then click [Next].

 If you do not accept the license agreement, installation will not continue.
- 6. Enter [User name] and [Company name], and then click [Next].
- 7. Specify the folder where the main application is to be installed, and the folder where the data created by this application is to be stored, and then click [Next].



Set the access privileges of the data folder so that all users of this application can access the data folder. For details about setting access privileges, see the Windows Help files.

You can specify removable disks and network folders as the data folder.

8. Enter the port number of Tomcat, and then click [Next].

Normally, leave the port number as "8080", the default value.

If "8080" is already in use with another application, enter an unused port number.

Contact the system administrator for details about the port number.



9. Check the settings, and then click [Next].

Installation starts.

New installation

When installation of the main application finishes, the setup screen for the TotalFlow PDF driver will appear. Continue installing the driver.

• Overwrite installation/update

When file copying finishes, the setup completion screen will appear. Click [Close]. The installation will end. To install the TotalFlow PDF driver, you must use the Windows [Start] menu.

If a window prompting you to restart the computer appears, click [Yes] to restart the computer.

Reference

 For details about installing the TotalFlow PDF driver, see p. 16 "Installing the TotalFlow PDF driver".

Installing the TotalFlow PDF driver




- To install this application, you must use an account that has administrator privileges. Make sure you
 log on with such an account you begin the installation.
- You can install the TotalFlow PDF driver only if Adobe Acrobat is already installed on the computer.

Use one of the following procedures to install the TotalFlow PDF driver.

To install the TotalFlow PDF driver immediately after the main application (New installation):

1. On the setup screen of the TotalFlow PDF driver, select the [Set up now] check box, and then click [Next].



2. When the installation finishes, click [OK].

The Adobe AIR setup screen appears. Continue with the installation.



• For details about installing Adobe Air, see p.17 "Installing Adobe AIR".

To install the TotalFlow PDF driver separately using the Windows [Start] menu:

- 1. Click [Start], select [All Programs], and then select [TotalFlow MR].
- 2. Select [TotalFlow PDF Driver Setup].
- 3. Select [OK].
- 4. When the installation finishes, click [OK].

Precautions after installing the TotalFlow PDF driver

• Do not change the name of the TotalFlow PDF driver.

- Check if the settings on the [Adobe PDF settings] tab in the [TotalFlow PDF Document Properties]
 window are specified as below. If the settings are as follows, do not change the settings. You can
 use the application with the current settings. If the settings are other than the following, change them
 to the below settings. Otherwise, Microsoft Office files cannot be imported into this application.
 - [Adobe PDF Security]: None
 - [Adobe PDF Output Folder]: My Documents*.pdf
 - [View Adobe PDF results]: Not selected
 - [Delete log files for successful jobs]: Selected
- If you have to upgrade or downgrade your version of Adobe Acrobat, you must also reinstall the
 TotalFlow PDF driver. To do this, first delete the TotalFlow PDF driver manually, then upgrade (or
 downgrade) Adobe Acrobat, and then reinstall the TotalFlow PDF driver from the Windows [Start]
 menu.
- If you uninstall Adobe Acrobat, the TotalFlow PDF driver will not function and you will have to delete it manually.



 For details about deleting the TotalFlow PDF driver, see p.20 "Uninstalling the TotalFlow PDF Driver Manually".

Installing Adobe AIR



To install this application, you must use an account that has administrator privileges. Make sure log
on with such an account before you begin the installation.

Use the following procedure to install Adobe AIR.

To install Adobe AIR immediately after the main application (New installation):

- 1. On the setup screen of Adobe AIR, click [Next].
- 2. Click [I Agree].
- 3. When the installation finishes, click [Finish].

The application's setup completion screen appears. Click [Close].

If a window prompting you to restart the computer appears, click [Yes] to restart the computer.

To install Adobe Air separately using the installation media:

1. Insert this application's installation media into the computer.

If the Autoplay window opens, select [Install or run program].

If the user account control screen appears, do one of the following according to the level of your account's permissions:

- If your account has administrator permissions, click [Allow].
- If your account has general user permissions only, enter the password for an administrator account, and then click [Yes].
- 2. On the setup screen, click [Adobe AIR].
- 3. Click [I Agree].
- 4. When the installation finishes, click [Finish].

Uninstallation

This section explains the procedures for uninstalling the main application and Adobe AIR.




- The TotalFlow PDF driver is uninstalled together with the main application.
- If you want to delete the TotalFlow PDF driver only, see p.20 "Uninstalling the TotalFlow PDF Driver Manually".

Uninstalling the Main Application

The following uninstallation procedure is explained using Windows 7 as an example. The procedure will vary slightly on other operating systems, but the basic procedure will be the same for all.

- 1. Click [Start], and then select [Uninstall a program] in [Control Panel].
- 2. Right-click [TotalFlow MR], and then click [Uninstall/Change].
- 3. On the [Uninstall] screen, continue as follows:
 - To uninstall this application completely:
 Select the [Delete data folder at the same time] check box.
 - If you plan to reinstall this application and reuse the data (job file) after uninstallation: Clear the [Delete data folder at the same time] check box.



- 4. Click [Yes].
- 5. Click [Close].

Uninstalling Adobe AIR



Do not uninstall Adobe AIR if it is in use with any other applications. If you do, those applications
will not function properly.

The following uninstallation procedure is explained using Windows 7 as an example. The procedure will vary slightly on other operating systems, but the basic procedure will be the same for all.

- 1. Click [Start], and then select [Uninstall a program] in [Control Panel].
- 2. Select [Adobe AIR], and then click [Uninstall].
- In the confirmation dialog box, click [Uninstall].
 Uninstallation starts.

Uninstalling the TotalFlow PDF Driver Manually

The following uninstallation procedure is explained using Windows 7 as an example. The procedure will vary slightly on other operating systems, but the basic procedure will be the same for all.

- 1. Click [Start], and then select [Display devices and printers].
- 2. Select [TotalFlow PDF], and then click [Delete the device].
- 3. In the confirmation dialog box, click [Yes].

This deletes TotalFlow PDF Driver.

3

3. Start-up/Shutdown

This chapter explains how to start up and shut down this application.

Start-up

This section explains the necessary preparations and the procedure for start-up.

Preparation

Make the following preparations before starting this application:

- Before starting this application for the first time, you must register a printer. Check that both the
 computer and printer you want to use are properly connected to the network. For details about
 printers that are compatible with this application, see Readme. For details about how to connect the
 printer to a network, see the printer's documentation.
- To output jobs via TotalFlow PM, you must first set up TotalFlow PM. For details, see the TotalFlow PM documentation.
- If the Windows firewall is enabled, the following programs will be blocked and this application
 might not function correctly. In this case, register them as a firewall exception. For details about
 registering exceptions, see the Windows Help.
 - {Installation path of this application}\svc\jre\bin\java.exe
 - {Installation path of this application}\svc\bin\TwainAccessor.exe

If you selected the default installation path when you installed this application, {Installation path of this application} refers to the following folder:

C:\Program Files\TotalFlow MR\

Start-up Procedure

Use the following procedure to start this application.

 Insert the license key (dongle) included with this application into a USB port on the computer.




- The dongle is required to confirm the license for this application. If you try to start this
 application without inserting the dongle, an error message will appear and the program will
 not start.
- Leave the dongle inserted as long as this application is running. If you remove the dongle
 while this application is running, the application will become unusable.

- 2. Click the [Start] button, select [All programs], and then select [TotalFlow MR].
- 3. Select [TotalFlow MR].

If a printer was not registered the first time this application was started, the [Printer Management] screen will appear. Proceed to step 4.


This application starts only if a printer has already been registered.

4. On the [Printer Management] screen, click [Add].



On the [Add/Edit Custom Printer Settings] screen, select [Data output mode:], and then specify each setting.

For details about a specific setting, see the on-screen balloon help.



- 6. Click [OK].
- 7. On the [Printer Management] screen, click [Close].

The application starts.



• When this application has started, you can add other printers. For details about registering printers, see User's Guide.

ರ

• To scan documents, you must first register a scanner. For details about registering scanners, see User's Guide.

Shut Down

Use the following procedure to shut down this application.

1. On the [File] menu, select [Exit].

The screen closes.



• While using the Hot folder function, do not remove the dongle. To remove the dongle, quit this application first. You can remove the dongle by disconnecting it from the USB port.

3

INDEX


A	
Adobe AIR	
Installing	
UninstallingAssociated applications	
B	
Balloon help	1
C	4
Computer	
Computer requirements	10
D	
Delete data folder at the same time	19
Display	10
н	
Hard disk	
<u>I</u>	
Installation	13
Adobe AIR	
TotalFlow PDF driver	
Instruction manuals	
HTML manuals PDF manuals	
	4
L	
Languages	10
N	
Network	10
0	
Operating environment	10
Operating system	10
P	
Port number	15
S	
Setup	9
Shut-down	
Start-up	21
Symbols	2

1	
TotalFlow PDF Driver Installing Uninstalling	
Trademarks	6
U	
Uninstallation	19
Adobe AIR	19
TotalFlow PDF Driver	20
USB port	1 C

MEMO

MEMO

MEMO



GB EN US EN AU

