Fax Option Type M19/M20 Machine Code: D3BV/D3BT

Field Service Manual

May, 2016

Important Safety Notices

Important Safety Notices

WARNING

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Always use caution when installing or modifying telephone lines.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use a telephone or cellular phone to report a gas leak in the vicinity of the leak.

- Before installing the fax unit, switch off the main switch, and disconnect the power cord.
- The fax unit contains a lithium battery. The danger of explosion exists if a battery of this type is incorrectly replaced. Replace only with the same or an equivalent type recommended by the manufacturer.
- Discard batteries in accordance with the manufacturer's instructions and local regulations.

Note for Australia


Unit must be connected to Telecommunication Network through a line cord that meets the requirements of ACA Technical Standard TS008.

Symbols and Abbreviations

Conventions Used in this Manual

This manual uses several symbols and abbreviations. The meaning of those symbols and abbreviations are as follows:

Symbol	What it means
Ŵ	Clip ring
€) ^m	Screw
S.	Connector
ş	Clamp
B	E-ring
65 ³	Flat Flexible Cable
\bigcirc	Timing Belt
SEF	Short Edge Feed [A]
LEF	Long Edge Feed [B]
К	Black
С	Cyan
м	Magenta
Y	Yellow
B/W, BW	Black and White
FC	Full color



Cautions, Notes, etc.

The following headings provide special information:

WARNING

• Failure to obey warning information could result in serious injury or death.

• Obey these guidelines to ensure safe operation and prevent minor injuries.

Coloritant 🖸

- Obey these guidelines to avoid problems such as misfeeds, damage to originals, loss of valuable data and to prevent damage to the machine.
- Always obey these guidelines to avoid serious problems such as misfeeds, damage to originals, loss of valuable data and to prevent damage to the machine. Bold is added for emphasis.

Note

• This document provides tips and advice about how to best service the machine.

TABLE OF CONTENTS

Important Safety Notices	1
Important Safety Notices	1
Note for Australia	1
Symbols and Abbreviations	2
Conventions Used in this Manual	
Cautions, Notes, etc	3
1. Installation	
Fax Option Type M20 (D3BT-01, -02, -03)	9
Accessory Check	
Installation Procedure	
Fax Stamp Installation	15
Adding Fax Application Icons to the Home Screen	17
Registering Function Keys	
Function Priority Setting	20
Notes for Connecting the Telephone Line	21
Reasons why the Fax Board may be damaged	
Fax Option Type M19 (D3BV-01, -02, -03)	22
Accessory Check	22
Installation Procedure	23
Fax Stamp Installation	27
Adding Fax Application Icons to the Home Screen	
Registering the Function key	
Function Priority Setting	
Notes for Connecting the Telephone Line	
Reasons why the Fax Board may be damaged	
G3 Interface Unit Type M20 (D3BT-07, -08, -12)	
Accessory Check	
Installation Procedure	
Single G3 Board	
Double G3 Boards	40
Notes for Connecting the Telephone Line	47
Reasons why the Fax Board may be damaged	
G3 Interface Unit Type M19 (D3BV-07, -08, -12)	

Accessory Check	
Installation Procedure	
Single G3 Board	
Double G3 Boards	54
Notes for Connecting the Telephone Line	61
Reasons why the Fax Board may be damaged	61
Fax Unit Options	
Fax Memory Unit Type M19 64MB (D3BZ)	
Accessory Check	62
For MP C4504/C5504/C6004 models	63
For MP C3004/C3504 models	
Handset HS3020 (D739)	
Fax Connection Unit	73
Accessory Check	
Installation Procedure	73
Order of installation	74
Installing the fax connection unit	74
Registering the client machine(s)	76
Registering the remote machine	76
Configuring the Remote Reception Settings	76
2. Replacement and Adjustment	
FCU	
SRAM Data Transfer Procedure	
For MP C4504/5504/6004 models	80
For MP C3004/3504 models	
3. Troubleshooting	
Error Codes	
Error Codes	
Fax Connection Unit Error Codes	
Fax Connection Unit Error Code List	
MACHINE_ERR_01	
 MACHINE_ERR_02	
 MACHINE_ERR_03	

MACHINE_ERR_04	
MACHINE_ERR_05	
MACHINE_ERR_06	
MACHINE_ERR_07	
MACHINE_ERR_08	
IFAX Troubleshooting	
IFAX Troubleshooting	
IP-Fax Troubleshooting	
IP-Fax Transmission	
Cannot send by IP Address/Host Name	
Cannot send via VoIP Gateway	
Cannot send by Alias Fax number	
IP-Fax Reception	
Cannot receive via IP Address/Host Name	
Cannot receive by VoIP Gateway	
Cannot receive by Alias Fax number	
4. Service Tables	
Cautions	
Service Program Tables	
Service Program Tables SP1-XXX (BIT Switches)	
<u> </u>	
SP1-XXX (BIT Switches)	
SP1-XXX (BIT Switches) SP2-XXX (RAM)	
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set)	
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions)	
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions) SP5-XXX (RAM Clear) SP6-XXX (Reports)	
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions) SP5-XXX (RAM Clear)	
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions) SP5-XXX (RAM Clear) SP6-XXX (Reports) SP7-XXX (Tests)	
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions) SP5-XXX (RAM Clear) SP6-XXX (Reports) SP7-XXX (Tests) Bit Switches – 1	126
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions) SP5-XXX (RAM Clear) SP6-XXX (Reports) SP7-XXX (Tests) Bit Switches – 1 System Switches	126
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions) SP5-XXX (RAM Clear) SP6-XXX (Reports) SP7-XXX (Tests) Bit Switches – 1 System Switches Bit Switches – 2	126
SP1-XXX (BIT Switches) SP2-XXX (RAM) SP3-XXX (Machine Set) SP4-XXX (ROM Versions) SP5-XXX (RAM Clear) SP6-XXX (Reports) SP7-XXX (Tests) Bit Switches – 1 System Switches Bit Switches – 2 I-Fax Switches	126

Bit Switches – 4	
G3 Switches	
Bit Switches – 5	
G3-2 and G3-3 Switches	
G4 Internal Switches	
G4 Parameter Switches	
Bit Switches – 6	
IP Fax Switches	
NCU Parameters	
NCU Parameters	
Dedicated Transmission Parameters	
Programming Procedure	
Parameters	
Fax Parameters	
E-mail Parameters	
Service RAM Addresses	
Service RAM Addresses	
5. Detailed Section Descriptions	
Overview	
Overview	239
Boards	
FCU	241
SG3 Board	242
Video Data Path	
Transmission	
Memory Transmission and Parallel Memory Transmission	
Immediate Transmission	
JBIG Transmission	
Adjustments	
Reception	
Fax Communication Features	
Multi-port	
Document Server	

Internet Mail Communication	
Mail Transmission	
Mail Reception	251
Handling Mail Reception Errors	
Secure Internet Reception	
Transfer Request: Request By Mail	
E-Mail Options (Sub TX Mode)	254
IP-Fax	258
What is IP-FAX?	
T.38 Packet Format	258
UDP Related Switches	
Settings	

6. Specifications

General Specifications	259
FCU	259
Capabilities of Programmable Items	261
Capabilities of Programmable Items	261
IFAX Specifications	262
IFAX Specifications	262
IP-FAX Specifications	264
IP-FAX Specifications	264
Fax Unit Configuration	265
G3 Interface Unit Type M19 (for MP C3004/C3504)	265
G3 Interface Unit Type M20 (for MP C4504/C5504/C6004)	266


Fax Option Type M20 (D3BT-01, -02, -03)

This fax option is for MP C4504/C5504/C6004 models only.

Accessory Check

Check the quantity and condition of the accessories against the following list.


No.	Description	Q'ty	Remarks
1	FCU	1	
2	Ferrite Core	1	For NA, this ferrite core is attached to the telephone cable [4].
3	Screw: M3x6	4	
4	Telephone Cable with ferrite core	1	NA only
5	Serial number decal	1	
-	FCC Decal	1	NA only
-	EMC Address Decal	1	EU only
-	Telephone Jack Cap	1	TWN only




Installation Procedure

CAUTION

- Before installing this fax unit, print out all data in the printer buffer. Turn the main power to OFF and disconnect the power cord and the network cable.
- 1. Remove the I/F cover [A].




2. Remove the rear cover [A].



3. Remove the controller box cover [A].


Red circle: remove

Blue circle: loosen




d238m0614

4. Remove the "TEL" [A] and "LINE1" [B] covers using a screwdriver.




5. Switch the battery jumper switch [A] to the "ON" position.



Note


- If the battery jumper switch is not in the correct position, SC820 will occur.
- 6. Install the FCU [A] on the controller board.

Make sure that both connectors [B] are connected.




d238m0705

• Insert the tabs [A] of the FCU bracket into the cutouts on the left of the controller box.



d238m0707



- 7. Reinstall the rear cover and controller box cover.
- 8. Attach the handset support bracket and handset bracket to the machine. To install the handset, connect the handset cord with the ferrite core to the "TEL" jack.

Note

• For details about installation, refer to page 68 "Handset HS3020 (D739)".

Taiwan only: Install the telephone jack cap in the "TEL" jack if the handset is not installed on the machine.


9. Make one loop with the telephone cord, and then attach the ferrite core [A] (this step is not needed for NA).





10. Connect the telephone cord to the "LINE 1" jack.

11. Attach the clamps [A] to the rear cover of the optional paper feed unit, and then hold the telephone line with the clamps as shown below.



d163z0001

- 12. Attach the serial number decal under the machine serial number decal on the rear cover of the machine.
- 13. Attach the FCC decal to the rear cover of the machine (NA only).
- 14. Insert the power plug into the outlet. Turn ON the main power of the machine.


Vote

- Make sure that the outlet is grounded.
- "SRAM formatted" is displayed on the operation panel after the main power is turned ON. Turn the main power OFF and then ON again for normal use.
- 15. Make sure that the date and time are correctly set.
- 16. Execute SP3-102-000 in the fax SP mode and enter the serial number for the fax unit.
- 17. Enter the correct country code with SP1101-016(SYS OF): Country/area code for functional setting.


Fax Stamp Installation

This procedure is only for machines with ARDF DF3090.

1. Open the ARDF original cover and stamp holder [A].




2. Install the fax stamp [A] provided with the machine.



3. Close the holder.

Make sure that the holder is pushed into the position where the marks on the holder and the exterior cover face each other. If not, jam detection (JO01) will occur.



- 4. Close the ARDF.
- 5. As an operation test, place an original on the ARDF tray, and send it with the memory sending/fax stamp function ON.
 - Set the sending time to a time when nobody uses the machine (such as 11 PM).

• Check if the fax stamp is marked on the trailing edge of the original.

Adding Fax Application Icons to the Home Screen

The fax application icon is normally added automatically. However, if it is missing from the Home screen, add it as follows:

1. Press the [Application List] key [A].



2. Press and hold the Fax application from the app list.



d238m0744


3. Drag and position the application on the home screen.



Registering Function Keys


By registering a fax application to a function key on the Home screen, you can open the application from any page. Specify the setting as required.

Function Keys 1, 2, and 3 are from the left, as shown:



Allocate an application to a function key as follows:

- 1. Login as the machine administrator
- 2. Press "User Tools" icon > "Screen Features".
- 3. Press [Screen Device Settings].



d238m0988e

4. Press [Function Key Settings].

上 Сору			Cyan		Logout	
< 😵 Screen	Device Settings					
Screen S	Startup Mode					
Screen S	5D Card Slot					
Operatio	on Panel USB Slot					
Server S	iettings					
Function	I Priority					
Function	I Key Settings					
		5	合			

d238m0994e

5. Select the key to register.

To disable a function key, deselect the corresponding function key check box.

Сору	Scanner		Toner Cartrid	ge is almost empty.	Logout	
Function Ke	ey Settings					
Function Ke	y					
Function Ke	y 1					
Function Ke	y 2					
Function Ke	y 3					
		€	合			

d238m0992e

6. Press [Allocated Function], and then select the fax application.

In [Display Name], you can change the name of the icon on the Home screen (using up to 64 characters).

Сору			Toner Cartridge is almost empty.	 Logout	_(
Function K	ey 1				
Allocated F	unction				
Display Na Copy	me				
		€			
		ر.	<u> </u>	1238m0	aa

Function Priority Setting

You can specify whether the fax application appears on the operation panel just after turning the power on or just after the system is reset automatically.

- 1. Login as the machine administrator
- 2. Press "User Tools" icon > "Screen Features".
- 3. Press [Screen Device Settings].

Screen Fea			
	orwarding to Machine		
DEVICE			
Sound	1		
O Displa	зу		
E Stora	ge		
PERSONAL			
Secur	ity		
🔺 Langu	age & input		
SYSTEM			
③ Scree	n Device Settings Infor	rmation	
	n Device Settings		

d238m0988e

4. Press [Function Priority].

2	Сору	Scanner		Cyan	Log	jout	C
<	Screen Device	Settings					
	Screen Startu	ip Mode					
	Screen SD Ca	rd Slot					
	Operation Par	nel USB Slot					
	Server Setting	gs					
	Function Prior	ity					
	Function Key	Settings					
			Ś	谷			
					d238	m098	9e

5. Select the fax application.

Сору	Scanner		Toner Cartridge is	s almost empty.		Logout	
Function 1	Priority						
Home							0
Cloud Fax							
Connector							
Copier (Classic)						
Сору							
Document Ser	ver						
Fax							
Fax (Classic)							
ID Card Copy							
		ر ه	合				
					d2	38m099	90e

Notes for Connecting the Telephone Line

Checking the following before connecting the telephone line:

If a phone line dedicated to business phones is connected to the MFP, the fax board may be damaged. Make sure that the connecting phone line is for fax.

Reasons why the Fax Board may be damaged

Business phones have various functions. To operate those functions, a high current is supplied to a business phone line. This may damage components on the Fax board.


Fax Option Type M19 (D3BV-01, -02, -03)

This fax option is for C3004/C3504 models only.

Accessory Check

Check the quantity and condition of the accessories against the following list.

No.	Description	Q'ty	Remarks
1	Shield	1	
2	FCU	1	
3	Speaker Bracket	1	
4	Ferrite Core	1	For NA, this ferrite core is attached to the telephone cable [4].
5	Serial Number Decal	1	
6	Clamp	2	
7	FCU Screw: M3x6	4	
8	Screw	2	Not used for this machine
9	Telephone Cable with ferrite core	1	NA only
-	FCC Decal	1	NA only
-	EMC Address Decal	1	EU Only
-	Telephone Jack Cap	1	TWN only



Installation Procedure

ACAUTION

- Before installing this fax unit, print out all data in the printer buffer. Turn the main power to OFF and disconnect the power cord and the network cable.
- 1. Remove the I/F cover [A].




@ x3

d238m0709


2. Remove the interface slot cover [A] (\Im x 2).




3. Remove the "TEL" [A] and "LINE1" [B] covers on the interface slot cover using a screwdriver.



4. Switch the battery jumper switch [A] to the "ON" position.



5. Connect the speaker bracket [A] to the FCU [B].



6. Attach the shield [A], FCU [B], and speaker bracket [C] together.




7. Insert the FCU [A] completely into the interface slot.



d238m0713

8. Reattach the interface slot cover [A].

Blue circle: Use supplied screws (for the FCU)



- 9. Reinstall the I/F cover (🞯 x 3).
- 10. Attach the handset support bracket and handset bracket to the machine. To install the handset, connect the handset cord with the ferrite core to the "TEL" jack.

Vote

• For details about installation, refer to page 68 "Handset HS3020 (D739)".

Taiwan only: Install the telephone jack cap in the "TEL" jack if the handset is not installed on the machine.


11. Make one loop with the telephone cord, and then attach the ferrite core [A] (this step is not needed for NA).



d238m0916

12. Connect the telephone cord to the "LINE 1" jack.

13. Attach the clamps [A] to the rear cover of the optional paper feed unit, and then hold the telephone line with the clamps as shown below.



d163z0001

- 14. Attach the serial number decal under the machine serial number decal on the rear cover of the machine.
- 15. Attach the FCC decal to the rear cover of the machine (NA only).
- 16. Insert the power plug into the outlet. Turn ON the main power of the machine.


Vote

- Make sure that the outlet is grounded.
- "SRAM formatted" is displayed on the operation panel after the main power is turned ON. Turn the main power OFF and then ON again for normal use.
- 17. Make sure that the date and time are correctly set.
- 18. Execute SP3-102-000 in the fax SP mode and enter the serial number for the fax unit.
- 19. Enter the correct country code with SP1101-016(SYS OF): Country/area code for functional setting.


Fax Stamp Installation

This procedure is needed only for machines with ARDF DF3090.

1. Open the ARDF original cover and stamp holder [A].




2. Install the fax stamp [A] provided with the machine.



3. Close the holder.

Make sure that the holder is pushed into the position where the marks on the holder and the exterior cover face each other. If not, jam detection (JO01) will occur.



- 4. Close the ARDF.
- 5. As an operation test, place the original on ARDF tray, and send it with the memory sending/fax stamp function ON.
 - Set the sending time to a time when nobody uses the machine (such as 11 PM).

• Check if the fax stamp is marked on the trailing edge of the original.

Adding Fax Application Icons to the Home Screen

The fax application icon is normally added automatically. However, if it is missing from the Home screen, add it as follows:

1. Press the [Application List] key [A].



2. Press and hold the Fax application from the app list.



d238m0744


3. Drag and position the application on the home screen.



Registering the Function key


By registering a fax application to a function key on the Home screen, you can open the application from any page. Specify the setting as required.

Function Keys 1, 2, and 3 are from the left, as shown:



Allocate an application to a function key as follows:

- 1. Login as the machine administrator
- 2. Press "User Tools" icon > "Screen Features".
- 3. Press [Screen Device Settings].



d238m0988e

4. Press [Function Key Settings].

Сору			Cyan		Logout	
Creen D	evice Settings					
Screen St	artup Mode					
Screen SE	Card Slot					
Operation	Panel USB Slot					
Server Se	ttings					
Function I	Priority					
Function I	Key Settings					
		∽	合			

d238m0994e

5. Select the key to register.

To disable a function key, deselect the corresponding function key check box.

Сору	Scanner		Toner Cartrid	ge is almost empty.	Logout	
Function Ke	ey Settings					
Function Ke	y				×	
Function Ke	y 1					
Function Ke	y 2					
Function Ke	y 3					
		€	合			

d238m0992e

6. Press [Allocated Function], and then select the fax application.

In [Display Name], you can change the name of the icon on the Home screen (using up to 64 characters).

Сору			Toner Cartridge is almost empty.	 Logout	(
Function R	(ey 1				
Allocated Copy	Function				
Display Na Copy	me				
		€			
				1238m0	993

Function Priority Setting

You can specify whether the fax application appears on the operation panel just after turning the power on or just after the system is reset automatically.

- 1. Login as the machine administrator
- 2. Press "User Tools" icon > "Screen Features".
- 3. Press [Screen Device Settings].

			Cyan		Logout	C
(°¢	Screen Featur	res				
	- TOILIO	warang to Machine				
	DEVICE					
	H Sound					
	O Display					
	Storage					
	PERSONAL					
	Security					
	🔺 Languag	je & input				
	SYSTEM					
	③ Screen I	Device Settings Info	rmation			
	🗖 Screen I	Device Settings				
•			শ্চ 🌈	*		

d238m0988e

4. Press [Function Priority].

2	Сору	Scanner		Cyan		Logout	
(Screen Devi	ce Settings					
	Screen Start	tup Mode					
	Screen SD C	ard Slot					
	Operation Pa	anel USB Slot					
	Server Setti	ngs					
	Function Pri	ority					
	Function Key	/ Settings					
			€	谷			
					d	238m098	39e

5. Select the fax application.

Сору	Scanner		Toner Cartridge is	almost empty.		Logout	
Function F	Priority						
Home							0
Cloud Fax							
Connector							
Copier (Classic)							
Сору							
Document Serv	ver						
Fax							
Fax (Classic)							
ID Card Copy							
		ر	谷				
					d2:	38m099	90e

Notes for Connecting the Telephone Line

Checking the following before connecting the telephone line:

If a phone line dedicated to business phones is connected to the MFP, the fax board may be damaged. Make sure that the connecting phone line is for fax.

Reasons why the Fax Board may be damaged

Business phones have various functions. To operate those functions, a high current is supplied to a business phone line. This may damage components on the Fax board.

G3 Interface Unit Type M20 (D3BT-07, -08, -12)

This G3 interface unit option is for Fax Option Type M20.

Accessory Check

Check the quantity and condition of the accessories against the following list.

No.	Description	Q'ty	Remarks
1	SG3 Interface Unit	1	
2	FFC	1	
3	Ferrite Core	1	
4	Screw: M3x6	3	
5	Telephone Cable	1	NA only
6	FFC Holder	1	
-	FCC Decal	1	NA only
-	EMC Address Decal	1	EU only



Installation Procedure


• Before installing this fax unit, print out all data in the printer buffer. Turn the main power to OFF and disconnect the power cord and the network cable.

An additional two SG3 boards can be added for this model. Follow the procedures for installing a single SG3 board or double SG3 board as required.

Single G3 Board


Preparation

- If Fax Option Type M20 is not installed in the machine, install the Fax Option Type M20 first (page 9 "Fax Option Type M20 (D3BT-01, -02, -03)").
- 1. Remove the I/F cover [A].



1


2. Remove the rear cover [A].



3. Remove the controller box cover [A].

Red circle: remove

Blue circle: loosen



d238m0614

4. Remove the "LINE2" [A] cover using a screwdriver.




- A
 Image: Constrained and the second sec
- 5. Install the SG3 interface unit [A].

• Insert the tab [B] of the SG3 interface unit bracket in the cutout [C] on the top of the controller box.




d238m0724

• Insert the tab [D] of the controller box in the cutout [E] of the SG3 interface unit.



6. Connect the FFC [A] to the FCU.




• Release the connector lock [B] and connect the FFC, and then lock the FFC.




d238m0717b

- 7. Attach the other end of the flat cable to the connector [A] on the CCU interface unit.
 - Make sure that the blue tapes of the flat cable face outward.




d238m0726




8. Attach the FFC Holder [A] to secure the FFC.

- 9. Reinstall the controller box cover, rear cover and I/F cover.
- 10. Make two loops with the telephone cord, and then attach the ferrite core [A].



11. Connect the telephone cord to the "LINE 2" jack.

12. Attach the clamps [A] to the rear cover of the optional paper feed unit, and then hold the telephone line with the clamps as shown below.




d163z0001

- 13. Insert the power plug into the outlet. Turn ON the main power of the machine.
- 14. Enter the service mode. Set Bit 1 of Communication Switch 16 to "1" (SP1-104-023).
- 15. Exit the service mode.
- 16. Turn OFF then ON the main power.
- 17. Print out the system parameter list. Check that "G3" is displayed as an option.
- 18. Set up and program the items required for PSTN-2 communications.


Double G3 Boards

Preparation

 If the Fax Option Type M20 is not installed in the machine, install the Fax Option Type M20 first (page 9 "Fax Option Type M20 (D3BT-01, -02, -03)"). 1. Remove the I/F cover [A].




2. Remove the rear cover [A].




3. Remove the controller box cover [A].

Red circle: remove Blue circle: loosen




d238m0614


4. Remove the "LINE2" [A] and "LINE3" [B] covers using a screwdriver.



5. Remove the CCU I/F board and SG3 board [A] from the SG3 interface unit. Repeat the same procedure for the second SG3 interface unit.



- 6. Remove the SG3 board [A] from one of the CCU I/F and SG3 board assemblies removed in step 5.
- 7. Attach the SG3 board removed in step 6 to the other CCU I/F and SG3 board assembly [B].



d1672004


- 8. Attach the boards (CCU I/F board and two SG3 boards) to the SG3 interface unit bracket.
 - Use two screws from the eight screws removed in step 5



@P x8

d238m0742

9. Install the SG3 interface unit [A].





 Insert the tab [B] of the SG3 interface unit bracket in the cutout [C] on the top of the controller box.



d238m0724

• Insert the tab [D] of the controller box in the cutout [E] of the SG3 interface unit.






10. Connect the FFC [A] to the FCU.

• Release the connector lock [B] and connect the FFC, and then lock the FFC.




d238m0717b

- 11. Attach the other end of the flat cable to the connector [A] on the CCU interface unit.
 - Make sure that the blue tapes of the flat cable face outward.




d238m0726b




12. Attach the FFC Holder [A] to secure the FFC.

- 13. Reinstall the controller box cover, rear cover and I/F cover.
- 14. Make two loops with the telephone cord for each telephone line (LINE2, LINE3). Attach the ferrite core [A] to each telephone line.



15. Connect the telephone cords to the "LINE2" and "LINE3" jacks.

16. Attach the clamps [A] to the rear cover of the optional paper feed unit, and then hold the telephone lines with the clamps as shown below.



d163z0001

- 17. Insert the power plug into the outlet. Turn ON the main power of the machine.
- 18. Enter the service mode. Set Bit 1 of Communication Switch 16 to "1" (SP1-104-023).
- 19. Set Bit 3 of Communication Switch 16 to "1" (SP1-104-023).
- 20. Exit the service mode.
- 21. Turn ON then OFF the main power.
- 22. Print out the system parameter list. Check that "G3" is displayed as an option.
- 23. Set up and program the items required for PSTN-2 communications.

Notes for Connecting the Telephone Line

Checking the following before connecting the telephone line:

If a phone line dedicated to business phones is connected to the MFP, the fax board may be damaged. Make sure that the connecting phone line is for fax.

Reasons why the Fax Board may be damaged

Business phones have various functions. To operate those functions, a high current is supplied to a business phone line. This may damage components on the Fax board.

47


G3 Interface Unit Type M19 (D3BV-07, -08, -12)

This G3 interface unit option is for Fax Option Type M19.

Accessory Check

Check the quantity and condition of the accessories against the following list.

No.	Description	Q'ty	Remarks
1	SG3 Interface Unit	1	
2	Telephone Cable	1	NA only
3	Ferrite Core	1	
4	FFC	1	
5	FFC Holder	1	
6	Screw: M3x6	3	
-	EMC Address Decal	1	EU only
-	FCC Decal	1	NA only



Installation Procedure


• Before installing this fax unit, print out all data in the printer buffer. Turn the main power to OFF and disconnect the power cord and the network cable.

An additional two SG3 boards can be added for this model. Follow the procedures for installing a single SG3 board or double SG3 board as required.


Single G3 Board

Preparation

- If the Fax Option Type M19 is not installed in the machine, install the Fax Option Type M19 first (page 22 "Fax Option Type M19 (D3BV-01, -02, -03)").
- 1. Remove the I/F cover [A].




2. Remove the rear cover [A].



3. Remove the controller box cover [A].

Red circle: remove

Blue circle: loosen




4. Remove the "LINE2" [A] cover using a screwdriver.




d238m0721

5. Connect the FFC [A] to the FCU.




- Release the connector lock [B] and connect the FFC, and then lock the FFC.
- Connect the folded side [C] as shown below.




d238m0717

- 6. Install the SG3 interface unit [A].
 - Insert the tab [C] of the controller box into the cutout [B] of the SG3 interface unit.




• Insert the tab [D] of the controller box into the cutout of the SG3 interface unit [E].




d238m0719

7. Take the FFC [A] out and connect the CCU interface board connector [B].




d238m0720

8. Secure the FFC [B] with the supplied clamp [A]. Make sure that there is no FFC deflection.




d238m0738

- 9. Reinstall the controller box cover, rear cover and I/F cover.
- 10. Make two loops with the telephone cord, and then attach the ferrite core [A].



11. Connect the telephone cord to the "LINE 2" jack.

12. Attach the clamps [A] to the rear cover of the optional paper feed unit, and then hold the telephone line with the clamps as shown below.




d163z0001

- 13. Insert the power plug into the outlet. Turn ON the main power of the machine.
- 14. Enter the service mode. Set Bit 1 of Communication Switch 16 to "1" (SP1-104-023).
- 15. Exit the service mode.
- 16. Turn OFF then ON the main power.
- 17. Print out the system parameter list. Check that "G3" is displayed as an option.
- 18. Set up and program the items required for PSTN-2 communications.


Double G3 Boards

Preparation

 If the Fax Option Type M19 is not installed in the machine, install the Fax Option Type M19 first. (page 22 "Fax Option Type M19 (D3BV-01, -02, -03)") 1. Remove the I/F cover [A].




2. Remove the rear cover [A].



3. Remove the controller box cover [A].


Red circle: remove

Blue circle: loosen




d238m0614

4. Remove the "LINE2" [A] and "LINE3" [B] covers using a screwdriver.



d1632002a


5. Remove the CCU I/F board and SG3 board [A] from the SG3 interface unit. Repeat the same procedure for the second SG3 interface unit.



@P x6


6. Remove the SG3 board [A] from one of the CCU I/F and SG3 board assemblies removed in step 5.

7. Attach the SG3 board removed in step 6 to the other CCU I/F and SG3 board assembly [B].




d1672004

- 8. Attach the boards (CCU I/F board and two SG3 boards) to the SG3 interface unit bracket.
 - Use two screws from the six screws removed in step 5.




9. Connect the FFC [A] to the FCU.



<∞x1


d238m0716

- Release the connector lock [B] and connect the FFC, and then lock the FFC.
- Connect the folded side [C] as shown below.




d238m0717

- 10. Install the SG3 interface unit [A].
 - Insert the tab [C] of the controller box into the cutout [B] of the SG3 interface unit.




• Insert the tab [D] of the controller box into the cutout of the SG3 interface unit [E].




d238m0719

11. Take the FFC [A] out and connect the CCU interface board connector [B].




d238m0720b

Secure the FFC [B] with a supplied clamp [A].
 Make sure that there is no FFC deflection.




d238m0738

- 13. Reinstall the controller box cover, rear cover and I/F cover.
- 14. Make two loops with the telephone cord for each telephone line (LINE2, LINE3). Attach the ferrite core [A] to each telephone line.



15. Connect the telephone cords to the "LINE2" and "LINE3" jacks.

16. Attach the clamps [A] to the rear cover of the optional paper feed unit, and then hold the telephone lines with the clamps as shown below.



d163z0001

- 17. Insert the power plug into the outlet. Turn ON the main power of the machine.
- 18. Enter the service mode. Set Bit 1 of Communication Switch 16 to "1" (SP1-104-023).
- 19. Set Bit 3 of Communication Switch 16 to "1" (SP1-104-023).
- 20. Exit the service mode.
- 21. Turn ON then OFF the main power.
- 22. Print out the system parameter list. Check that "G3" is displayed as an option.
- 23. Set up and program the items required for PSTN-2 communications.

Notes for Connecting the Telephone Line

Checking the following before connecting the telephone line:

If a phone line dedicated to business phones is connected to the MFP, the fax board may be damaged. Make sure that the connecting phone line is for fax.

Reasons why the Fax Board may be damaged

Business phones have various functions. To operate those functions, a high current is supplied to a business phone line. This may damage components on the Fax board.


Fax Unit Options

Fax Memory Unit Type M19 64MB (D3BZ)

Accessory Check


Check the quantity and condition of the accessories against the following list.

No.	Description	Q'ty	Remarks
1	Bracket	1	For MP C4504/C5504/C6004
2	Memory unit	1	
3	Screws M3x6	2	For MP C4504/C5504/C6004
4	Screws	1	For MP C4504/C5504/C6004
5	Clamp	1	For MP C3004/C3504



For MP C4504/C5504/C6004 models


1. Attach the memory unit [A] to the bracket [B].




@P x2

d238m0730

2. Remove the I/F cover [A].




3. Remove the rear cover [A].



4. Remove the controller box cover [A].

Red circle: remove

Blue circle: loosen



d238m0614

5. To attach the memory unit [A], remove the two screws of the FCU.




- Image: Constraint of the second sec
- 6. Connect the memory unit connector [A] to the FCU [B].

7. Secure the bracket [A].

Red circle: Use screws removed in the previous step.


Blue circle: Use supplied screws.



8. Re-assemble the machine.


Note

• To install the G3 interface unit with this option, install the FFC before attaching the bracket. Otherwise, the bracket blocks the FFC connector [A].



For MP C3004/C3504 models

1. Remove the fax option unit [A] (page 22 "Fax Option Type M19 (D3BV-01, -02, -03)").





d238m0713b

2. Separate the shield [A], FCU [B], and speaker bracket [C].




3. Attach the supplied clamp [B] to the speaker Bracket [A].






4. Attach the memory unit [B] to the FCU connector [A]

5. Re-assemble the shield [A], FCU [B], and speaker bracket [C].



• Make sure that the clamp [B] is pressing the memory unit [A] and holding it in place.



- 6. Reinstall the FCU in the interface slot.
- 7. Re-assemble the machine.

Handset HS3020 (D739)

The optional handset is available for NA only.

1. Open the front cover [A].



d1462004

- [A]
- 2. Remove the paper exit tray [A].



3. Remove the upper left cover [A] (🕬×1).

Slide the cover in the direction of the blue arrow.



d1462008

4. Remove the left rear cover [A] (🕅×2).



d1462010

5. Remove the scanner front cover [A] (\mathfrak{O}^{*} ×2).



6. Remove the scanner left cover [A] (x 3).



d1462303

7. Make two holes in the scanner left cover.




d1463050

1

- 8. Reattach the scanner left cover (🞯 x 3).
- 9. Re-assemble the machine.
- 10. Attach the bracket [A] enclosed with the fax unit (🞯 x 2: M3 x 12) as shown.

For machines with the single pass ADF, the bracket can be attached slanted using the hole [B].



11. Attach the cradle [A] to the handset bracket (\Im x 2).



12. Make two loops with the telephone cord, and then attach the ferrite core [A] to the cable.



d1463054

13. Connect the cable to the "TEL" jack on the left side of the controller box.

Fax Connection Unit

Fax Connection Unit Type M19 (D3BD-01, -02, -03) is for MP C3004/C3504 Fax Connection Unit Type M20 (D3BC-01, -02, -03) is for MP C4504/C5504/C6004

Accessory Check

Check the quantity and condition of the accessories against the following list.

No.	Description	Q'ty	Remarks
1	Fax Connection Unit SD card	1	



d595i900b

Installation Procedure

This unit allows a machine without the fax unit installed (client machine) to send and receive faxes via a machine with the fax unit installed (remote machine).

Requirements

- Up to six machines can be registered as the client machines.
- Machines that already have a fax unit installed cannot be used as client machines.
- Only one machine can be registered as the remote machine.
- Firmware for this unit: "aics" (software number: D1655759 for Type M3/ D1665759 for Type M4)
- Remote Fax transmission is possible using a G3 line.
- The Remote Fax function does not support User Code Authentication. Disable the User Code Authentication on the remote machine.
- Use this function to check the contents of a file that is stored in memory and not yet sent. Also, use this function to cancel a transmission from the client machine.

Order of installation

- 1. Install the Fax Connection Unit in the remote machine (fax unit already installed).
- 2. Install the Fax Connection Unit in the client machine (no fax unit is installed).
- 3. Register the client machine on the remote machine.

🔁 Important

- Do not register the remote machine before the client machine is registered on the remote machine. Otherwise, the remote machine cannot be registered.
- 4. Register the remote machine in the client machine.

Installing the fax connection unit

Vote

- Before starting this procedure, connect the network cable to the target machine(s), and then configure the network settings.
- When installing more than one SD card, perform the merge operation. For details about how to merge, refer to "Card Appli Move" in the field service manual for the main frame.
- 1. Remove the SD card slot covers [A] [B].

MP C4504/C5504/C6004



@P x1

d238m0638

MP C3004/3504:



- 2. Insert the Fax Connection Unit SD card into SD card slot 1 [A: Upper Slot].
 - Type M19 is for MP C3004/3504.
 - Type M20 is for MP C4504/C5504/C6004.

MP C4504/C5504/C6004:



d238m0639

MP C3004/3504:



- 3. Reattach the SD-card slot cover (🖤 x 1).
- 4. Turn ON the main power.
- Make sure that the machine can recognize the option (See 'Self-Diagnosis Report' and check whether the aics (D1655759 for Type M3/ D1665759 for Type M4) is listed in [Loading Program].)

1

Registering the client machine(s)

🕗 Note

- Before starting this procedure, connect the network cable to the target machine(s), and then configure the network settings.
- 1. On the remote machine, press the [User Tools/Counter] key on the operation panel.
- 2. Press [System Settings].
- 3. Press [Administrator Tools].
- 4. Press [Program/Change/Delete Remote machine].
- 5. Enter the IP address or host name of the client machines.

Note

- Up to six machines can be registered as the client machines.
- 6. Press [OK] to set after "connection test".
- 7. Press the [User Tools/Counter] key on the operation panel to terminate System Settings.

Registering the remote machine

Vote

- Only one machine can be registered as the remote machine.
- Before starting this procedure, connect the network cable to the target machine(s), and then configure the network settings.
- 1. On the client machine, press the [User Tools/Counter] key on the operation panel
- 2. Press [System Settings].
- 3. Press [Administrator Tools].
- 4. Press [Program/Change/Delete Remote machine].
- 5. Enter the IP address or host name of the remote machine.
- 6. Press [OK] to set after "connection test".
- 7. Press [Exit].

Configuring the Remote Reception Settings

Perform the following procedure to enable the client machine(s) to receive faxes via the remote machine. You can forward or route received documents per line or to a specific sender.

Vote

- Before starting this procedure, connect the network cable to the target machine(s), and then configure the network settings.
- By performing procedures #1-3 above, the client machines can send faxes via the remote machine. The procedures shown below are necessary to enable the client machines to receive faxes.

This procedure is performed on the remote machine.

Using "Remote Reception Setting per Line"

- 1. Press [Facsimile Features].
- 2. Press [Remote Reception Setting per Line] in [Reception Settings].
- 3. Enter an IP address or a host name of the client-side machine to connect.
- 4. Press [Set], and [Exit] to exit from the setting.

Using "Remote Reception per Sender"

- 1. Press [Facsimile Features].
- 2. Press [Program Special Sender] in [Reception Settings].
- 3. Select the Special Sender.


Program Special Sender				
Select destination to program	or change.			
Program / Change D)elete		Initi	al Set Up
001 Tokyo branch	Full Agree	002 Head office of Osaka	Full Agree	
003 branch	Part.Agree	004 XNot Programmed	Full Agree	
005 XNot Programmed	Full Agree	006 XNot Programmed	Part.Agree	1/2
007 XNot Programmed	Full Agree	008 XNot Programmed	Full Agree	
009 XNot Programmed	Full Agree	010 XNot Programmed	Full Agree	▼ Next

d1661001

4. Press [Remote Reception Setting per Sender].

Program / Change	Cancel OK				
Check contents, then press [OK].	Check contents, then press [OK].				
Own Name and Fax Number 1	Conditions: Full Agreement Partial Agreement				
Authorized Reception per Sender Off	Print 2 Sided per Sender Same as Basic Settings				
RX File Print Oty per Sender Same as Basic Settings	Memory Lock RX per Sender Same as Basic Settings				
Forwarding per Sender Same as Basic Settings	Paper Tray per Sender Same as Basic Settings				
Remote Reception Setting per Sender On					
Remote Machine: XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	*****				
	d1661002				

5. Press [On] and [Remote machine].




- 6. Enter an IP address or a host name of the client machine to connect.
- 7. Press [OK] to exit from the setting.

2. Replacement and Adjustment

FCU

• When removing the FFC, lift the lever [A] to release the lock.



d238m1212

SRAM Data Transfer Procedure


When you replace the FCU board, transfer the SRAM data from the old FCU board to the new FCU board. Do the following procedure to back up the SRAM data.




• The following data can be transferred: TTI, RTI, CSI, Fax bit switch settings, RAM address settings, NCU parameter settings.

For MP C4504/5504/6004 models

1. Remove the controller cover [A].




2. Remove the rear cover [A].



3. Remove the controller box cover [A].


Red circle: remove Blue circle: loosen

2




d238m0614

4. Disconnect the FFC [A] if connected.




d238m1201

5. Remove the FCU board [A].




6. Change the orientation of the battery jumper switch [A] on the removed FCU board, and then attach the battery jumper switch [B] on the FCU board to switch to the Restore mode.

The battery jumper switch [B] is supplied with the new FCU board.




7. Switch the battery jumper switch [A] of the new fax unit to the "ON" position before installing.




- Note
 - If the battery jumper switch is not in the correct position, SC820 will occur.
- 8. Install the new fax unit (@x 3).
- 9. Attach the flat cable [A] to CN603 of the new fax unit.

Make sure that the blue tape of the flat cable faces outward.



10. Attach the removed FCU board [A] to the center frame of the controller box (⁽³⁾ x 1). Then attach the flat cable to CN603 of the removed FCU board.

Make sure that the blue tape of the flat cable faces outward.



- Keep the removed FCU board away from the metal frames. Otherwise, the removed FCU board may have a short circuit.
- 11. Turn ON the main power.

SRAM data transmission starts. When the transmission is completed, you will hear a beeper sound.

Note

- The beeper sound is at the same volume as the speaker sound.
- The beeper sounds even if the speaker sound is turned off.
- If the beeper does not sound, repeat main power OFF/ON until the beeper sounds, and then perform the transmission procedure. If the data cannot be transmitted, repeat transmission 2 or 3 times.

- If the beeper does not sound after turning the main power OFF/ON 3 times, you need to input the settings stored in SRAM memory manually.
- 12. When "Ready" is displayed on the display panel, turn the main power OFF. Disconnect the flat cable from the removed FCU board.
- 13. Remove the removed FCU board (^(C) x 1).
- 14. Remove the bracket from the center frame of the controller box (🖤 x 1).
- 15. Disconnect the flat cable from the new FCU board.
- 16. Re-assemble the machine.
- 17. Turn ON the main power. Execute SP6-101 to print the system parameter list.
- 18. Check the system parameter list to make sure that the data is transferred correctly.
- Set the correct date and time with the User Tools: User Tools > System Settings > Timer Setting > Set Date/Time.

Note

• If any of the SRAM data was not transferred, input those settings manually.

For MP C3004/3504 models


Preparation

 Remove the G3 Unit and disconnect the FFC connection. (See the installation of "G3 Interface Unit Type M19"page 48)

Check "LINE2" to see if the 3G unit is installed.



1. Remove the controller box cover [A].



2. Remove the interface slot cover [A] ($\Im^{*}x$ 2).




d238m0561b

3. Pull out the FCU [A] from the interface slot.




d238m1202

4. Switch the battery jumper switch [A] of the new fax unit to the "ON" position before installing.




Vote

- If the battery jumper switch is not in the correct position, SC820 will occur.
- 5. Replace the installed FCU board [A] with a new FCU board [B].




6. Change the orientation of the battery jumper switch [A] on the removed FCU board, and then attach the battery jumper switch [B] on the FCU board to switch to the Restore mode. The battery jumper switch [B] is supplied with the new FCU board.

2




- 7. Reinstall the new fax unit, and then the slot cover ($\Im^{x} x 2$).
- 8. Remove the rear cover [A].



9. Remove the controller box cover [A]. Red circle: remove Blue circle: loosen


2



d238m0614


10. Attach the flat cable [A] to CN603 of the new fax unit.

- When inserting the cable, make sure that it is not slanted.
- Make sure that the blue tapes of the flat cable face outward.



11. Attach the removed FCU board [A] to the center frame of the controller box (^(W)x 1). Then attach the flat cable to CN603 of the removed FCU board.

Make sure that the blue tape of the flat cable faces outward.



- Keep the removed FCU board away from the metal frames. Otherwise, the removed FCU board may have a short circuit.
- 12. Turn ON the main power.

SRAM data transmission starts. When the transmission is completed, you will hear a beeper sound.

Note

- The beeper sound is at the same volume as the speaker sound.
- The beeper sounds even if the speaker sound is turned off.
- If the beeper does not sound, repeat main power OFF/ON until the beeper sounds, and then perform the transmission procedure. If the data cannot be transmitted, repeat transmission 2 or 3 times.
- 13. When "Ready" is displayed on the display panel, turn OFF the main power. Disconnect the flat cable from the removed FCU board.
- 14. Remove the removed FCU board ($\Im^{*}x$ 1).
- 15. Remove the bracket from the center frame of the controller box (🖤 x 1).
- 16. Disconnect the flat cable from the new FCU board.
- 17. Re-assemble the machine.
- 18. Turn ON the main power. Execute SP6-101 to print the system parameter list.
- 19. Check the system parameter list to make sure that the data is transferred correctly.
- Set the correct date and time with the User Tools: User Tools > System Settings > Timer Setting > Set Date/Time.

3. Troubleshooting

Error Codes

Error Codes

If an error code is displayed, retry communication. If the same problem occurs, try to fix the problem as suggested below.

Vote

• Error codes appear in the error code display and on the service report.

Code	Meaning	Suggested Cause/Action
0-00	DIS/NSF not detected within 40 s of Start being pressed	 Check the connection. The other party may be incompatible. Replace the FCU. Check for DIS/NSF with an oscilloscope. If the RX signal is weak, there may be a bad connection.
0-01	DCN received unexpectedly	 The other party is out of paper or has a paper jam. The other party pressed the Stop button during communication.
0-03	Incompatible modem at the other end	The other party is incompatible.

Code	Meaning	Suggested Cause/Action
0-04	CFR or FTT not received after	Check the connection.
	modem training	 Try changing the TX level and/or cable equalizer settings.
		• Replace the FCU.
		 The other machine may be defective. Try sending to another machine.
		 If the RX signal is weak or defective, there may be a bad connection.
		Reference:
		• TX level: NCU Parameter 01 (PSTN)
		• Cable equalizer: G3 Switch 07 (PSTN)
		 Dedicated TX parameters in Service Program Mode
0-05	Modem training fails even G3	Check the connection.
	shifts down to 2400 bps.	 Try adjusting the TX level and/or cable equalizer.
		• Replace the FCU.
		Check for line problems.
		Reference:
		See error code 0-04.
0-06	ne other terminal did not reply to	Check the connection.
	DCS	 Try adjusting the TX level and/or cable equalizer settings.
		• Replace the FCU.
		 The other end may be defective or incompatible; try sending to another machine.
		Check for line problems.
		Reference:
		See error code 0-04.

З

Code	Meaning	Suggested Cause/Action
0-07	No post-message response from the other end after a page was sent	 Check the connection. Replace the FCU. The other party is out of paper or has a paper jam. The other party may have disconnected the call. Check for a bad line. The other machine may be defective. Try sending to another machine.
0-08	The other end sent RTN or PIN after receiving a page, because there were too many errors	 Check the connection. Replace the FCU. The other end may have jammed, or run out of paper or memory space. Try adjusting the TX level and/or cable equalizer settings. The other end may have a defective modem/FCU; try sending to another machine. Check for line problems and noise. Reference: TX level: NCU Parameter 01 (PSTN) Cable equalizer: G3 Switch 07 (PSTN) Dedicated TX parameters in Service Program Mode
0-14	Non-standard post message response code received	 Incompatible or defective remote terminal; try sending to another machine. Noisy line; resend. Try adjusting the TX level and/or cable equalizer settings. Replace the FCU. Reference: See error code 0-08.

Code	Meaning	Suggested Cause/Action
0-15	The other terminal is not capable of specific functions.	 The other party is unable to accepting the following functions, or the other party's memory is full. Confidential RX Transfer function SEP/SUB/PWD/SID
0-16	CFR or FTT not detected after modem training in confidential or transfer mode	 Check the connection. Replace the FCU. Try adjusting the TX level and/or cable equalizer settings. The other machine may have disconnected, or it may be defective. Try sending to another machine. If the ax signal level is too low, there may be a line problem. Reference: See error code 0-08.
0-17	Communication was interrupted by pressing the Stop key	If the Stop key was not pressed and this error keeps occurring, replace the operation panel or the operation panel drive board.
0-20	Facsimile data not received within 6 s of retraining	 Check the connection. Replace the FCU. Check for line problems. Try calling another fax machine. Try adjusting the reconstruction time for the first line and/or RX cable equalizer setting. Reference: Reconstruction time - G3 Switch 0A, Bit 6 Rx cable equalizer - G3 Switch 07 (PSTN)

Code	Meaning	Suggested Cause/Action
0-21	EOL signal (end-of-line) from the other end not received within 5 s of the previous EOL signal	 Check the connection between the FCU and line. Check for line noise or other line problems. Replace the FCU. The remote machine may be defective or may have been disconnected. Reference: Maximum interval between EOLs and between ECM frames - G3 Bit Switch 0A, Bit 4
0-22	The signal from the other end was interrupted for more than the acceptable modem carrier drop time (default: 200 ms)	 Check the connection. Replace the FCU. The remote machine may be defective. Check for line noise or other line problems. Try adjusting the acceptable modem carrier drop time. Reference: Acceptable modem carrier drop time: G3 Switch 0A, Bits 0 and 1
0-23	Too many errors during reception	 Check the connection. Replace the FCU. The remote machine may be defective. Check for line noise or other line problems. Try asking the other party to adjust their TX level. Try adjusting the RX cable equalizer setting and/or RX error criteria. Reference: Rx cable equalizer: G3 Switch 07 (PSTN) Rx error criteria: Communication Switch 02, Bits 0 and 1
0-29	Data block format failure in ECM reception	 Check for line noise or other line problems. Check the FCU - NCU connectors. Replace the NCU or FCU.

Code	Meaning	Suggested Cause/Action
0-30	The other terminal did not reply to NSS(A) in Al short protocol mode	 Check the connection. Try adjusting the TX level and/or cable equalizer settings. The other terminal may not be compatible. Reference: Dedicated TX parameters - Section 4
0-32	The other terminal sent a DCS, which contained functions that the receiving machine cannot handle.	Check the protocol dump list.Ask the other party to contact the manufacturer.
0-33	The data reception (not ECM) is not completed within 10 minutes.	 Check the connection. The other terminal may have a defective modem/FCU.
0-52	Polarity changed during communication	Check the connection. Retry communication.
0-55	FCU does not detect the SG3.	FCU firmware or board defective.SG3 firmware or board defective.
0-56	The stored message data exceeds the capacity of the mailbox in the SG3.	SG3 firmware or board defective.
0-70	The communication mode specified in CM/JM was not available	• The other terminal did not have a compatible communication mode (e.g., the other terminal was a V.34 data modem and not a fax modem.)
	(V.8 calling and called terminal)	 A polling TX file was not ready at the other terminal when polling RX was initiated from the calling terminal.
0-74	The calling terminal fell back to T. 30 mode, because it could not detect ANSam after sending Cl.	 The calling terminal could not detect ANSam due to noise, etc. ANSam was too short to detect. Check the connection. and condition. Try making a call to another V.8/V.34 fax.

Code	Meaning	Suggested Cause/Action
0-75	The called terminal fell back to T. 30 mode, because it could not detect a CM in response to ANSam (ANSam timeout).	 The terminal could not detect ANSam. Check the connection. and condition. Try receiving a call from another V.8/V.34 fax.
0-76	The calling terminal fell back to T. 30 mode, because it could not detect a JM in response to CM (CM timeout).	 The called terminal could not detect a CM due to noise, etc. Check the connection. and condition. Try making a call to another V.8/V.34 fax.
0-77	The called terminal fell back to T. 30 mode, because it could not detect a CJ in response to JM (JM timeout).	 The calling terminal could not detect a JM due to noise, etc. A network that has narrow bandwidth cannot pass JM to the other end. Check the connection. and condition. Try receiving a call from another V.8/V.34 fax.
0-79	The called terminal detected CI while waiting for a V.21 signal.	 Check for line noise or other line problems. If this error occurs, the called terminal falls back to T.30 mode.
0-80	The line was disconnected due to a timeout in V.34 phase 2 – line probing.	 The guard timer expired while starting these phases. Serious noise, narrow bandwidth, or low signal level can cause these errors.
0-81	The line was disconnected due to a timeout in V.34 phase 3 – equalizer training.	 If these errors happen at the transmitting terminal: Try making a call later. Try using V.17 or a slower modem using
0-82	The line was disconnected due to a timeout in the V.34 phase 4 – control channel start-up.	dedicated TX parameters.Try increasing the TX level.Try adjusting the TX cable equalizer setting.
0-83	The line was disconnected due to a timeout in the V.34 control channel restart sequence.	 If these errors happen at the receiving terminal: Try adjusting the RX cable equalizer setting. Try increasing the TX level. Try using V.17 or a slower modem if the same error is frequent when receiving from multiple senders.

Code	Meaning	Suggested Cause/Action
0-84	The line was disconnected due to abnormal signaling in V.34 phase 4 – control channel start-up.	 The signal did not stop within 10 s. Turn off the main power switch, and then turn it back on. If the same error is frequent, replace the FCU.
0-85	The line was disconnected due to abnormal signaling in V.34 control channel restart.	 The signal did not stop within 10 s. Turn off the main power switch, and then turn it back on. If the same error is frequent, replace the FCU.
0-86	The line was disconnected because the other terminal requested a data rate using MPh that was not available in the currently selected symbol rate.	The other terminal was incompatible.Ask the other party to contact the manufacturer.
0-87	The control channel started after an unsuccessful primary channel.	 The receiving terminal restarted the control channel because data reception in the primary channel was not successful. This does not result in an error communication.
0-88	The line was disconnected because PPR was transmitted/ received 9 (default) times within the same ECM frame.	Try using a lower data rate at the start.Try adjusting the cable equalizer setting.
2-11	Only one V.21 connection flag was received	Replace the FCU.
2-12	Modem clock irregularity	Replace the FCU.
2-13	Modem initialization error	 Turn off the machine, and then turn it back on. Update the modem ROM. Replace the FCU.
2-22	Counter overflow error of JBIG chip	If error occurs frequently, change the settings for resolution, paper size, and compression type.
2-23	JBIG compression or reconstruction error	Turn off the machine, and then turn it back on.
2-24	JBIG ASIC error	• Turn off the machine, and then turn it back on.

З

Code	Meaning	Suggested Cause/Action
2-25	JBIG data reconstruction error (BIH error)	JBIG data errorCheck the sender's JBIG function.
2-26	JBIG data reconstruction error (Float marker error)	• Update the FCU ROM.
2-27	JBIG data reconstruction error (End marker error)	
2-28	JBIG data reconstruction error (Timeout)	
2-29	JBIG trailing edge maker error	FCU defectiveCheck the destination device.
2-50	The machine resets itself for a fatal FCU system error	 If this is frequent, update the ROM, or replace the FCU.
2-51	The machine resets itself because of a fatal communication error	 If this is frequent, update the ROM, or replace the FCU.
2-53	Snd msg() in the manual task is an error because the mailbox for the operation task is full.	 The user did the same operation many times, and this gave too much load to the machine.
4-01	Line current was cut	Check the line connector.Check for line problems.Replace the FCU.
4-10	Communication failed because of an ID Code mismatch (Closed Network) or Tel. No./CSI mismatch (Protection against Wrong Connections)	 Get the ID Codes the same and/or the CSIs programmed correctly, and then resend. The machine at the other end may be defective.
5-00	Data reconstruction not possible	Replace the FCU.
5-10	DCR timer expired	Replace the FCU.
5-20	Storage impossible because of a lack of memory	Temporary memory shortage.Test the SAF memory.
5-21	Memory overflow	

Code	Meaning	Suggested Cause/Action
5-23	Print data error when printing a substitute RX or confidential RX message	Test the SAF memory.Ask the other end to resend the message.
5-25	SAF file access error	 Replace an SD card or HDD. Replace the FCU.
6-00	G3 ECM - T1 time out during reception of facsimile data	Try adjusting the RX cable equalizer.Replace the FCU.
6-01	G3 ECM - no V.21 signal was received	
6-02	G3 ECM - EOR was received	
6-04	G3 ECM - RTC not detected	 Check the connection. Check for a bad line or defective remote terminal. Replace the FCU.
6-05	G3 ECM - facsimile data frame not received within 18 s of CFR, but there was no line fail	 Check the connection. Check for a bad line or defective remote terminal. Replace the FCU. Try adjusting the RX cable equalizer Reference: RX cable equalizer - G3 Switch 07 (PSTN)
6-06	G3 ECM - coding/decoding error	Defective FCU.The other terminal may be defective.
6-08	G3 ECM - PIP/PIN received in reply to PPS.NULL	The other end pressed Stop during communication.The other terminal may be defective.
6-09	G3 ECM - ERR received	 Check for a noisy line. Adjust the TX levels of the communicating machines. See code 6-05.

Code	Meaning	Suggested Cause/Action
6-10	G3 ECM - error frames still received at the other end after all communication attempts at 2400 bps	 Check for line noise. Adjust the TX level (use NCU parameter 01 or the dedicated TX parameter for that address). Check the connection. Defective remote terminal.
6-21	V.21 flag detected during high speed modem communication	 The other terminal may be defective or incompatible.
6-22	The machine resets the sequence because of an abnormal handshake in the V.34 control channel	 Check for line noise. If the same error occurs frequently, replace the FCU. Defective remote terminal.
6-99	V.21 signal not stopped within 6 s	Replace the FCU.
13-17	SIP user name registration error	 Double registration of the SIP user name. Capacity for user-name registration in the SIP server is not sufficient.
13-18	SIP server access error	Incorrect initial setting for the SIP server.Defective SIP server.
13-24	SIP authentication error	 Registered password in the device does not match the password in the SIP server.
13-25	Network I/F setting error	IPV4 is not active in the active protocol setting.IP address of the device is not registered.
13-26	Network I/F setting error at power on	 Active protocol setting does not match the I/F setting for SIP server. IP address of the device is not registered.
13-27	IP address setting error	• IP address of the device is not registered.
14-00	SMTP Send Error	 Error occurred during sending to the SMTP server. Occurs for any error other than 14-01 to 16. For example, the mail address of the system administrator is not registered.

Code	Meaning	Suggested Cause/Action
14-01	SMTP Connection Failed	 Failed to connect to the SMTP server (timeout) because the server could not be found. The PC is not ready to transfer files. SMTP server not functioning correctly. The DNS IP address is not registered. Network not operating correctly. Destination folder selection not correct.
14-02	No Service by SMTP Service (421)	 SMTP server operating incorrectly or the destination for direct SMTP sending is not correct. Contact the system administrator and check that the SMTP server has the correct settings and operates correctly. Contact the system administrator for direct SMTP sending and check the sending destination.
14-03	Access to SMTP Server Denied (450)	 Failed to access the SMTP server because the access is denied. SMTP server operating incorrectly. Contact the system administrator to determine if there is a problem with the SMTP server and to check that the SMTP server settings are correct. Folder send destination is incorrect. Contact the system administrator to determine that the SMTP server settings and path to the server are correct. Device settings incorrect. Confirm that the user name and password settings are correct. Direct SMTP destination incorrect. Contact the system administrator to determine if there is a problem at the destination and that the settings at the destination are correct.
14-04	Access to SMTP Server Denied (550)	SMTP server operating incorrectlyDirect SMTP sending not operating correctly

Code	Meaning	Suggested Cause/Action
14-05	SMTP Server HDD Full (452)	 Failed to access the SMTP server because the HDD on the server is full.
		 Insufficient free space on the HDD of the SMTP server. Contact the system administrator and check the amount of space remaining on the SMTP server HDD.
		 Insufficient free space on the HDD where the destination folder is located. Contact the system administrator and check the amount of space remaining on the HDD where the target folder is located.
		 Insufficient free space on the HDD at the target destination for SMTP direct sending. Contact the system administrator. Check the amount of space remaining on the target HDD or check if the mail size setting is the default value (2MB).
		 Check the size of the original data. For example, if the original has too many pages, the data size can be too big to send.
14-06	User Not Found on SMTP Server (551)	• The designated user does not exist.
		 The designated user does not exist on the SMTP server.
		 The designated address is not for use with direct SMTP sending.
14-07	Data Send to SMTP Server Failed (4XX)	 Failed to access the SMTP server because the transmission failed.
		• PC not operating correctly.
		SMTP server operating incorrectly
		Network not operating correctly.
		Destination folder setting incorrect.
		• Direct SMTP sending not operating correctly.

Code	Meaning	Suggested Cause/Action
14-08	Data Send to SMTP Server Failed (5XX)	 Failed to access the SMTP server because the transmission failed. SMTP server operating incorrectly Destination folder setting incorrect. Direct SMTP sending not operating correctly. Software application error.
14-09	Authorization Failed for Sending to SMTP Server	POP-Before-SMTP or SMTP authorization failed.Incorrect setting for file transfer
14-10	Addresses Exceeded	• Number of broadcast addresses exceeded the limit for the SMTP server.
14-11	Buffer Full	 The send buffer is full so the transmission could not be completed. Buffer is full due to using Scan-to-Email while the buffer is being used send mail at the same time.
14-12	Data Size Too Large	 Transmission was cancelled because the detected size of the file was too large.
14-13	Send Cancelled	 Processing is interrupted because the user pressed Stop.
14-14	Security Locked File Error	• Update the software because of the defective software.
14-15	Mail Data Error	 The transmitting a mail is interrupted via DCS due to the incorrect data. Update the software because of the defective software.
14-16	Maximum Division Number Error	 When a mail is divided for the mail transmission and the division number of a mail are more than the specified number, the mail transmission is interrupted. Update the software because of the defective software.
14-17	Incorrect Ticket	 Update the software because of the defective software.

Code	Meaning	Suggested Cause/Action
14-18	Access to MCS File Error	 The access to MCS file is denied due to the no permission of access. Update the software because of the defective software.
14-20	SMTP Authentication error	Make sure the administrator's e-mail address is same as the SMTP authentication address or POP before SMTP address.
14-21	Transmission error of S/MIME	Register the correct user certificate and device certificate.
14-30	MCS File Creation Failed	 Failed to create the MCS file because: The number of files created with other applications on the Document Server has exceeded the limit. HDD is full or not operating correctly. Software error.
14-31	UFS File Creation Failed	 UFS file could not be created: Not enough space in UFS area to handle both Scan-to-Email and IFAX transmission. HDD full or not operating correctly. Software error.
14-32	Cancelled the Mail Due to Error Detected by NFAX	• Error detected with NFAX and send was cancelled due to a software error.
14-33	No Mail Address For the Machine	 Neither the mail address of the machine nor the mail address of the network administrator is registered.
14-34	Address designated in the domain for SMTP sending does not exist	 Operational error in normal mail sending or direct SMTP sending. Check the address selected in the address book for SMTP sending. Check the domain selection.

Code	Meaning	Suggested Cause/Action
14-50	Mail Job Task Error	 Due to an FCU mail job task error, the send was cancelled: Address book was being edited during creation of the notification mail. Software error.
14-51	UCS Destination Download Error	 Not even one return notification can be downloaded: The address book was being edited. The number for the specified destination does not exist (it was deleted or edited after the job was created).
14-60	Send Cancel Failed	• The cancel operation by the user failed to cancel the send operation.
14-61	Notification Mail Send Failed for All Destinations	• All addresses for return notification mail failed.
14-62	Transmission Error due to the existence of zero line page	• When the 0 line page exists in received pages with G3 communication, the transmission is interrupted.
14-63	Fax Communication Unit: Transmission Error	 Check the followings. Name of SMTP server Port number of SMTP DNS setting Server name (FTP) Path name (computer name and shared folder name at SMTP/ NCP) Active protocol setting (Netware/ NCP) NW flame type (NCP) Log-on mode (NDS tree/ bindery)
-		 Check the SMTP server. Check if the SMTP server works normally and is connected to the network. Check if the settings of the SMTP are correct.

Code	Meaning	Suggested Cause/Action
-		 Check the DNS server. Check if the DNS server works normally and is connected to the network. Check if the settings of the DNS server are correct.
-		Check the network.Check if the LAN works normally.Check if the no firewall exists.
-		 Check the destination folder for the data transfer. Check if the destination folder works normally. Check if the settings of the destination folder are correct.
-		 Ask an administrator of the direct SMTP server in which the data is supposed to be transferred. Check if the destination SMTP server works normally. Check if the settings of the destination SMTP server are correct.
15-01	POP3/IMAP4 Server Not Registered	 At startup, the system detected that the IP address of the POP3/IMAP4 server has not been registered in the machine.
15-02	POP3/IMAP4 Mail Account Information Not Registered	 The POP3/IMAP4 mail account has not been registered.
15-03	Mail Address Not Registered	• The mail address has not been registered.
15-10	DCS Mail Receive Error	• Error other than 15-11 to 15-18.
15-11	Connection Error	 The DNS or POP3/IMAP4 server could not be found: The IP address for DNS or POP3/IMAP4 server is not stored in the machine. The DNS IP address is not registered. Network not operating correctly.

Code	Meaning	Suggested Cause/Action
15-12	Authorization Error	 POP3/IMAP4 send authorization failed: Incorrect IFAX user name or password. Another device, such as the PC, attempted access. POP3/IMAP4 settings incorrect.
15-13	Receive Buffer Full	 Occurs only during manual reception. Transmission cannot be received due to insufficient buffer space. The buffer is being used for mail send or Scan-to-Email.
15-14	Mail Header Format Error	• The mail header is not standard format. For example, the Date line description is incorrect.
15-15	Mail Divide Error	• The e-mail is not in standard format. There is no boundary between parts of the e-mail, including the header.
15-16	Mail Size Receive Error	• The mail cannot be received because it is too large.
15-17	Receive Timeout	 May occur during manual receiving only because the network is not operating correctly.
15-18	Incomplete Mail Received	• Only one portion of the mail was received.
15-31	Final Destination for Transfer Request Reception Format Error	• The format of the final destination for the transfer request was incorrect.
15-39	Send/Delivery Destination Error	 The transmission cannot be delivered to the final destination: Destination file format is incorrect. Could not create the destination for the file transmission.
15-41	SMTP Receive Error	 Reception rejected because the transaction exceeded the limit for the "Auth. E-mail RX" setting.
15-42	Off Ramp Gateway Error	• The delivery destination address was specified with Off Ramp Gateway OFF.

Code	Meaning	Suggested Cause/Action
15-43	Address Format Error	 Format error in the address of the Off Ramp Gateway.
15-44	Addresses Over	• The number of addresses for the Off Ramp Gateway exceeded the limit of 30.
15-61	Attachment File Format Error	• The attached file is not TIFF format.
15-62	TIFF File Compatibility Error	 Could not receive transmission due to: Resolution error Image of resolution greater than 200 dpi without extended memory. Resolution is not supported.
		 Page size error The page size was larger than A3. Compression error File was compressed with other than MH, MR, or MMR.
15-63	TIFF Parameter Error	 The TIFF file sent as the attachment could not be received because the TIFF header is incorrect: The TIFF file attachment is a type not supported. The TIFF file attachment is corrupted. Software error.
15-64	TIFF Decompression Error	 The file received as an attachment caused the TIFF decompression error: The TIFF format of the attachment is corrupted. Software error.
15-71	Not Binary Image Data	 The file could not be received because the attachment was not binary image data.
15-73	MDN Status Error	 The disposition line in the header of the Return Receipt could not be found, or there is a problem with the firmware.
15-74	MDN Message ID Error	 Could not find the Original Message ID line in the header of the Return Receipt, or there is a problem with the firmware.

Code	Meaning	Suggested Cause/Action
15-80	Mail Job Task Read Error	 Could not receive the transmission because the destination buffer is full and the destination could not be created (this error may occur when receiving a transfer request or a request for notification of reception).
15-81	Repeated Destination Registration Error	• Could not repeat receive the transmission because the destination buffer is full and the destination could not be created (this error may occur when receiving a transfer request or a request for notification of reception).
15-91	Send Registration Error	Could not receive the file for transfer to the final destination:
		• The format of the final destination or the transfer destination is incorrect.
		 Destinations are full so the final and transfer destinations could not be created.
15-92	Memory Overflow	 Transmission could not be received because memory overflowed during the transaction.
15-93	Memory Access Error	 Transaction could not complete due to a malfunction of SAF memory.
15-94	Incorrect ID Code	 The machine rejected an incoming e-mail for transfer request, because the ID code in the incoming e-mail did not match the ID code registered in the machine.
15-95	Transfer Station Function	 The machine rejected an incoming e-mail for transfer because the transfer function was unavailable.
16-00	No IP address registered	 The machine does not get an IP address because the DNS server has not been registered for the remote machine or IP address of the remote machine has not been registered. Register the DNS server for the remote machine or configure an IP address of the remote machine.

Code	Meaning	Suggested Cause/Action
22-00	Original length exceeded the maximum scan length	 Divide the original into more than one page. Check the resolution used for scanning. Lower the scan resolution if possible. Add optional page memory.
22-01	Memory overflow while receiving	 Wait for the files in the queue to be sent. Delete unnecessary files from memory. Transfer the substitute reception files to another fax machine, if the machine's printer is busy or out of order. Add an optional SAF memory card or hard disk.
22-02	TX or RX job stalled due to line disconnection at the other end	 The job started normally but did not finish normally; data may or may not have been received fully. Restart the machine.
22-04	The machine cannot store received data in the SAF	Update the ROMReplace the FCU.
22-05	No G3 parameter confirmation answer	• Defective FCU board or firmware.
23-00	Data read timeout during construction	 Restart the machine. Replace the FCU.
25-00	The machine software resets itself after a fatal transmission error occurred	Update the ROMReplace the FCU.
F0-xx	V.34 modem error	Replace the FCU.
F6-xx	SG3 modem error	 Update the SG3 modem ROM. Replace the SG3 board. Check for line noise or other line problems. Try communicating another V.8/V.34 fax.

Fax Connection Unit Error Codes

Fax Connection Unit Error Code List

MACHINE_ERR_01

Error Code	Possible Causes	Troubleshooting Procedures	
01(1)	IPv4/IPv6 not enabled	Enable IPv4 and IPv6	
01(3)	"Cancel" is pressed by user.	-	
01(4)	A false connection ID is being used.	Check that the network is established.	
01(5)	Network is disconnected because of no response within a specified time.		
01(14)	 Either this machine or the machine at the other end has entered SP or Initial settings. An established connection exists. 	 Exit SP or initial settings. Wait until the connection has finished. 	

MACHINE_ERR_02

Error Code	Possible Causes	Troubleshooting Procedures
02(5)	 Wrong IP address/host name was used. The main power of the other machine at destination is OFF. LAN cable is disconnected. Network is rebooting. 	 Enter the correct IP address/host name Turn ON the main power. Connect the LAN cable Wait until rebooting has finished.

MACHINE_ERR_03

Error Code	Possible Causes	Troubleshoo	ting Procedures
	f	Configure the user for client and remo follows:	authentication setting te machines as
		Client Machine	Remote Machine
03		OFF	OFF
		ON	OFF
		ON	ON

MACHINE_ERR_04

Error Code	Possible Causes	Troubleshooting Procedures
04	Although the same user is registered on the remote machine and client machine, the user name and login password do not match.	 Register the same user to both the remote machine and client machine. Make sure to match the username and login password.

MACHINE_ERR_05

Error Code	Possible Causes	Troubleshooting Procedures
05	An unauthorized user tried to connect.	Authorize the user to use fax connection.

MACHINE_ERR_06

Error Code	Possible Causes	Troubleshooting Procedures
06	Timeout error on the node authentication	Adjust the value of SP5-741-001 to prolong the timeout for node authentication.

MACHINE_ERR_07

Error Code	Possible Causes	Troubleshooting Procedures
07	Multiple destinations are set in the client machine.	On the client machine, execute SP5-801-021 to clear AICS memory

MACHINE_ERR_08

Error Code	Possible Causes	Troubleshooting Procedures
08(1)	 A client machine connects to another client machine. The client machine is not registered on the remote machine as destinations. 	 Connect to the remote machine. Register the client machine to the remote machine as a destination.
08(2)	 A remote machine connects to another Remote Machine. The wrong remote machine is registered on the client machine. 	 Connect to the client machine. Check the remote machine registered on the client machine.

IFAX Troubleshooting

IFAX Troubleshooting

Use the following procedures to determine whether the machine or another part of the network is causing the problem.

Communication Route	ltem	Troubleshooting Procedures
General LAN	1. Connection with the LAN	 Check that the LAN cable is connected to the machine. Check that the LEDs on the hub are lit.
	2. LAN activity	Check that other devices connected to the LAN can communicate through the LAN.
Between IFAX and PC	1. Network settings on the PC	 Check the network settings on the PC. Check with the network administrator for the IP address. (Is the IP address registered in the TCP/IP properties in the network setup correct?)
	2. Check that PC can connect with the machine	Use the "ping" command on the PC to contact the machine. At the MS-DOS prompt, type ping then the IP address of the machine, then press Enter.
	3. LAN settings in the machine	 Check the LAN parameters Check if there is an IP address conflict with other PCs. Use the "Network" function in the User Tools. If there is an IP address conflict, inform the administrator.

Communication Route	ltem	Troubleshooting Procedures
Between machine and e-mail server	1. LAN settings in the machine	 Check the LAN parameters Check if there is an IP address conflict with other PCs. Use the "Network" function in the User Tools. If there is an IP address conflict, inform the administrator.
	2. E-mail account on the server	 Make sure that the machine can log into the e-mail server. Check that the account and password stored in the server are the same as in the machine. Ask the administrator to check.
	3. E-mail server	Make sure that the client devices which have an account in the server can send/receive e-mail. Ask the administrator to check. Send a test e-mail with the machine's own number as the destination. The machine receives the returned e-mail if the communication is performed successfully.

Communication Route	ltem	Troubleshooting Procedures
Between e-mail server and internet	1. E-mail account on the Server	 Make sure that the PC can log into the e-mail server. Check that the account and password stored in the server are the same as in the machine. Ask the administrator to check.
	2. E-mail server	Make sure that the client devices which have an account in the server can send/receive e-mail. Ask the administrator to check. Send a test e-mail with the machine's own number as the destination. The machine receives the returned e-mail if the communication is performed successfully.
	3. Destination e-mail address	 Make sure that the e-mail address is actually used. Check that the e-mail address contains no incorrect characters such as spaces.
	4. Router settings	 Use the "ping" command to contact the router. Check that other devices connected to the router can sent data over the router. Ask the administrator of the server to check.
	5. Error message by e- mail from the network of the destination.	 Check whether e-mail can be sent to another address on the same network, using the application e-mail software. Check the error e-mail message. Inform the administrator of the LAN.

IP-Fax Troubleshooting

IP-Fax Transmission

Cannot send by IP Address/Host Name

	Check Point	Troubleshooting Procedures
1	LAN cable connected?	Check the LAN cable connection.
2	Specified IP address/hostname correct?	Check the IP address/host name.
3	Firewall/NAT installed?	The firewall cannot be breached. Send by another method (Fax, Internet Fax)
4	Transmission sent manually?	Manual sending not supported.
5	IP address of local machine registered?	Register the IP address.
6	Remote terminal port number setting other than 1720 (when using H.323) or 5060 (when using SIP)?	Send by specifying the port number.
7	Specified port number correct?	Confirm the port number of the remote fax.
8	DNS server registered when host name specified?	Contact the network administrator.
9	Remote fax a T.38 terminal?	Check whether the remote fax is a T38 terminal.
10	Remote fax switched off or busy?	Check that the remote fax is ON.
11	Network bandwidth too narrow?	Request the network administrator to increa the bandwidth.
		Raise the delay level. (IPFAX SW 01 Bit 0 to 3)
		IP-Fax bandwidth is the same as the DCS speed. Set IP-Fax SW00 Bit 6 to 1.
12	Remote fax cancelled transmission?	Check whether the remote fax cancelled th transmission.

Cannot send via VoIP Gateway

	Check Point	Troubleshooting Procedures
1	LAN cable connected?	Check the LAN cable connection.
2	VoIP Gateway T.38 standard?	Contact the network administrator.
3	VoIP Gateway installed correctly?	Contact the network administrator.
4	VoIP Gateway power switched on?	Contact the network administrator.
5	Is the IP address/host name of the specified Gateway correct?	Check the IP address/host name.
6	Number of the specified fax correct?	Check the remote fax number.
7	Firewall/NAT installed?	The firewall cannot be breached. Send by another method (Fax, Internet Fax)
8	Transmission sent manually?	Manual sending not supported.
9	IP address of local fax registered?	Register the IP address.
10	DNS registered when host name specified?	Contact the network administrator.
11	Remote fax a G3 fax?	Check that the remote fax is a G3 fax.
12	G3 fax connected to VoIP gateway?	Check that G3 fax is connected.
13	Remote G3 fax turned ON?	Check that G3 fax is ON.
14	Network bandwidth too narrow?	Request the network administrator to increase the bandwidth.
		Raise the network delay level. (IPFAX SW 01 Bit 0 to 3)
		IP-Fax bandwidth is the same as the DCS speed. Set IP-Fax SW00 Bit 6 to 1.

Cannot send by Alias Fax number.

	Check Point	Troubleshooting Procedures
1	LAN cable connected?	Check the LAN cable connection.

2	Number of specified Alias fax correct?	Confirm the Alias of the remote fax. Error Code: 13-14
3	Firewall/NAT installed?	The firewall cannot be breached. Send by another method (Fax, Internet Fax)
4	Transmission sent manually?	Manual sending not supported.
5	Gatekeeper/SIP server installed correctly?	Contact the network administrator.
6	Gatekeeper/SIP server power turned ON?	Contact the network administrator.
7	IP address/host name of Gatekeeper/SIP server correct?	Check the IP address/host name.
8	DNS server registered when Gatekeeper/SIP server host name specified?	Contact the network administrator.
9	Enable H.323/Enable SIP SW is set to on?	Check the settings.
		See User Parameter SW 34 Bit 0/SW 34 Bit 1
10	IP address of local fax registered?	Register the IP address of the local fax.
11	Alias number of local fax registered?	Register the Alias number of the local fax.
12	Remote fax registered in Gatekeeper?	Contact the network administrator.
13	Remote fax a T.38 terminal?	Check whether the remote fax is a T38 terminal.
14	Remote fax switched off or busy?	Contact the network administrator.
15	Network bandwidth too narrow?	Request the system administrator to increase the bandwidth.
		Raise the delay level.
		(IPFAX SW 01 Bit 0 to 3)
		Lower the modem transmission baud rate. (IPFAX SW 05)
16	Remote fax cancelled transmission?	Check whether the remote fax cancelled the transmission.

IP-Fax Reception

Cannot receive via IP Address/Host Name.

	Check Point	Troubleshooting Procedures
1	LAN cable connected?	Check the LAN cable connection.
2	Firewall/NAT installed?	The firewall cannot be breached. Send by another method (Fax, Internet Fax)
3	IP address of local fax registered?	Register the IP address.
4	Port number specified at remote sender fax (if required)?	Request the sender to specify the port number.
5	Specified port number correct (if required)?	Request the sender to check the port number.
6	DNS server registered when host name specified on sender side?	Contact the network administrator. Note The sender machine displays this error code if the sender fax is a Ricoh model.
7	Network bandwidth too narrow?	Request the system administrator to increase the bandwidth.
		Lower the start modem reception baud rate on the receiving side. (IPFAX SW06)
8	Remote fax cancelled transmission?	Check whether the remote fax cancelled the transmission.

Cannot receive by VoIP Gateway.

	Check Point	Troubleshooting Procedures
1	LAN cable connected?	Check the LAN cable connection.
2	Firewall/NAT installed?	The firewall cannot be breached. Send by another method (Fax, Internet Fax)
3	VoIP Gateway installed correctly?	Contact the network administrator.

3. Troubleshooting

4	VoIP Gateway power turned ON?	Contact the network administrator.
5	IP address/host name of specified VoIP Gateway correct on sender's side?	Request the remote fax to check the IP address/ host name.
6	DNS server registered when host name specified on sender side?	Contact the network administrator.
7	Network bandwidth too narrow?	Request the network administrator to increase the bandwidth.
8	G3 fax connected?	Check that G3 fax is connected.
9	G3 fax power turned ON?	Check that G3 fax is ON.

Cannot receive by Alias Fax number.

	Check Point	Troubleshooting Procedures
1	LAN cable connected?	Check the LAN cable connection.
2	Firewall/NAT installed?	The firewall cannot be breached. Send by another method (Fax, Internet Fax)
3	Gatekeeper/SIP server installed correctly?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.
4	Power to Gatekeeper/SIP server turned ON?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.
5	IP address/host name of Gatekeeper/SIP server correct on the sender's side?	Request the sender to check the IP address/host name. Note • The sender machine displays this error code when the sender fax is a Ricoh model.

6	DNS server registered when Gatekeeper/SIP server host name specified on sender's side?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.
7	Enable H.323/Enable SIP SW set to on?	Request the sender to check the settings. User Parameter SW 34 Bit 0/SW 34 Bit 1 Note • Only if the remote sender fax is a Ricoh fax.
8	Local fax IP address registered?	Register the IP address.
9	Local fax Alias number registered?	Register the Alias number.
10	Network bandwidth too narrow?	Request the system administrator to increase the bandwidth.
		Lower the start modem reception baud rate on the receiving side. (IPFAX SW06)
11	Remote fax cancelled transmission?	Check whether the remote fax cancelled the transmission.
12	Local fax registered in Gatekeeper/SIP server?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.

3. Troubleshooting

4. Service Tables

Cautions

Coloritant 🔁

• Never turn off the main power switch when the power LED is lit or flashing. To avoid damaging the hard disk or memory, press the operation power switch to switch the power off, wait for the power LED to go off, and then switch the main power switch off.

-		_
	Note	
v	14010	

• The main power LED lights or flashes while the platen cover or ARDF is open, while the main machine is communicating with a facsimile or the network server, or while the machine is accessing the hard disk or memory for reading or writing data.

Service Program Tables

SP1-XXX (BIT Switches)

1	Mode No.		Function
101	System Switch		
	001 – 032	00 – 1 F	Change the bit switches for system settings for the fax option
			"page 136 "Bit Switches – 1"" : "System Switches"
102	Ifax Switch		
	001 – 016	00 – 0F	Change the bit switches for internet fax settings for the fax option
			"page 150 "Bit Switches – 2"" : "I-Fax Switches"
103	Printer Switch		
	001 – 016	00 – 0F	Change the bit switches for printer settings for the fax option
			"page 150 "Bit Switches – 2"": "Printer Switches"
104	Communication	Switch	
	001 – 032	00 – 1F	Change the bit switches for communication settings for the fax option
			"page 165 "Bit Switches – 3"" : "Communication Switches"
105	G3-1 Switch		
	001 – 016	00 – 0F	Change the bit switches for the protocol settings of the standard G3 board
			"page 175 "Bit Switches – 4"" : "G3 Switches"
106	06 G3-2 Switch		·
	001 – 016	00 – 0F	Change the bit switches for the protocol settings of the optional G3 board
			"page 185 "Bit Switches – 5"" : "G3-2 and G3-3 Switches"

107	G3-3 Switch		
	001 – 016	00 – 0F	Change the bit switches for the protocol settings of the optional G3 board
			"page 185 "Bit Switches – 5"": "G3-2 and G3-3 Switches"
108	G4 Internal Switch		
	001 – 032	00 – 1 F	Not used (Do not change the bit switches)
109	G4 Parameter S	witch	
	001 – 016	00 – 0F	Not used (Do not change the bit switches)
111	IP fax Switch		
	001 – 016	00 – 0F	Change the bit switches for optional IP fax parameters "page 193" : "IP Fax Switches"

SP2-XXX (RAM)

2	Mode No.		Function
101	RAM Read/Write		
	001		Change RAM data for the fax board directly.
			"page 226 "Service RAM Addresses""
102	Memory Dum	p	
	001	G3-1 Memory Dump	Print out RAM data for the fax board.
			"page 226 "Service RAM Addresses""
	002	G3-2 Memory Dump	Print out RAM data for the optional SG3 board.
	003	G3-3 Memory Dump	Print out RAM data for the optional SG3 board.
	004	G4 Memory Dump	Not used
103	03 G3-1 NCU Parameters		
	001 – 023	CC, 01 – 22	NCU parameter settings for the standard G3 board. "page 202 "NCU Parameters""

104	G3-2 NCU Parameters		
	001 – 023	CC, 01 – 22	NCU parameter settings for the optional G3 board. "page 202 "NCU Parameters""
105	G3-3 NCU Parameters		
	001 – 023	CC, 01 – 22	NCU parameter settings for the optional G3 board. "page 202 "NCU Parameters""

SP3-XXX (Machine Set)

3	Mode No.		Function
101	Service Statio	on	
	001	Fax Number	Enter the fax number of the service station.
	002	Select Line	Select the line type.
102	Serial Number		
	000		Enter the fax unit's serial number.
103	PSTN-1 Port Settings		
	001	Select Line	Select the line type setting for the G3-1 line. If the machine is installed on a PABX line, select "PABX", "PABX (GND)" or "PABX (FLASH)".
	002	PSTN Access Number	Enter the PSTN access number for the G3-1 line.
	003	Memory Lock Disabled	Not used

104	PSTN-2 Port S	ettings	
	001	Select Line	Select the line setting for the G3-2 line. If the machine is installed on a PABX line, select "PABX", "PABX (GND)" or "PABX (FLASH)".
	002	PSTN Access Number	Enter the PSTN access number for the G3-2 line.
	003	Memory Lock Disabled	Not used
	004	Transmission Disabled	If you turn this SP on, the machine does not send any fax messages on the G3-2 line.
105	PSTN-3 Port S	ettings	
	001	Select Line	Select the line setting for the G3-3 line. If the machine is installed on a PABX line, select "PABX", "PABX (GND)" or "PABX (FLASH)".
	002	PSTN Access Number	Enter the PSTN access number for the G3-3 line.
	003	Memory Lock Disabled	Not used
	004	Transmission Disabled	If you turn this SP on, the machine does not send any fax messages on the G3-3 line.
106	ISDN Port Settings		
	001	Select Line	Not used (Do not change the settings.)
	002	PSTN Access Number	
	003	Memory Lock Disabled	
	004	Transmission Disabled	

107	IPFAX Port Set		
	001	H323 Port	Sets the H323 port number.
	002	SIP Port	Sets the SIP port number.
	003	RAS Port	Sets the RAS port number.
	004	Gatekeeper port	Sets the Gatekeeper port number.
	005	T.38 Port	Sets the T.38 port number.
	006	SIP Server Port	Sets the SIP port number.
	007	IPFAX Protocol Priority	Select "H323" or "SIP".
201	FAX SW		
	001 – 032	00 – 1F	

SP4-XXX (ROM Versions)

4	Mode No.		Function
101	001	FCU ROM Version	Displays the FCU ROM version.
102	001	Error Codes	Displays the latest 64 fax error codes.
103	001	G3-1 ROM Version	Displays the G3-1 modem version.
104	001	G3-2 ROM Version	Displays the G3-2 modem version.
105	001	G3-3 ROM Version	Displays the G3-3 modem version.
106	001	G4 ROM Version	Not used (Do not change the settings.)

SP5-XXX (RAM Clear)

5	Mode No.	Function
101	Initialize SRAM (except Secure)	
	000 Initializes the bit switches and user parameters, user data in the SRAM, files in the SAF memory, and clock.	

102	Erase All Files	
	000	Erases all files stored in the SAF memory.
103	D3 Reset Bit Switches (except Secure)	
	000	Resets the bit switches and user parameters.
104	Factory Setting	
	000	Resets the bit switches and user parameters, user data in the SRAM and files in the SAF memory.
105	Reset All Bit Switches	
	000	Resets all the current bit switch settings.
106	06 Reset Security Bit Switches	
	000	Resets only the security bit switches. If you select automatic output/ display for the user parameter switches, the security settings are initialized.

SP6-XXX (Reports)

6	Mode No.		Function
101	System Parameter List		
	000	-	Touch the "ON" button to print the system parameter list.
102	Service Monitor Report		
	000	-	Touch the "ON" button to print the service monitor report.

103	G3 Protocol Dump List		
	001	G3 All Communications	Prints the protocol dump list of all communications for all G3 lines.
	002	G3-1 (All Communications)	Prints the protocol dump list of all communications for the G3-1 line.
	003	G3-1 (1 Communication)	Prints the protocol dump list of the last communication for the G3-1 line.
	004	G3-2 (All Communications)	Prints the protocol dump list of all communications for the G3-2 line.
	005	G3-2 (1 Communication)	Prints the protocol dump list of the last communication for the G3-2 line.
	006	G3-3 (All Communications)	Prints the protocol dump list of all communications for the G3-3 line.
	007	G3-3 (1 Communication)	Prints the protocol dump list of the last communication for the G3-3 line.
104	G4 Protoco	ol Dump List	
	001	Dch + Bch 1	Not used (Do not change the settings.)
	002	Dch	-
	003	Bch 1 Link Layer	
	004	Dch Link Layer	
	005	Dch +Bch 2	
	006	Bch 2 Link Layer	

105	All Files print out		
	000	-	Prints out all the user files in the SAF memory, including confidential messages.
			◆Note
			 Do not use this function, unless the customer is having trouble printing confidential messages or recovering files stored using the memory lock feature.
106	Journal Pri	nt out	
	001	All Journals	The machine prints all the communication records on the report.
	002	Specified Date	The machine prints all communication records after the specified date.
107	Log List Print out		
	001	All log files	These log print out functions are for designer use
	002	Printer	only.
	003	SC/TRAP Stored	
	004	Decompression	
	005	Scanner	
	006	JOB/SAF	
	007	Reconstruction	
	008	JBIG	
	009	Fax Driver	
	010	G3CCU	
	011	Fax Job	
	012	сси	
	013	Scanner Condition	

108	IP Protocol Dump List		
	001	All Communications	Prints the protocol dump list of all communications for the IP fax line.
	002	1 Communication	Prints the protocol dump list of the last communication for the IP fax line.

SP7-XXX (Tests)

4. Service Tables

These are the test modes for PTT approval.

7	Function	
101	G3-1 Modem Tests	
102	G3-1 DTMF Tests	
103	Ringer Test	
104	G3-1 V34 (S2400baud)	
105	G3-1 V34 (S2800baud)	
106	G3-1 V34 (S3000baud)	
107	G3-1 V34 (S3200baud)	
108	G3-1 V34 (S3429baud)	
109	Recorded Message Test	
110	G3-2 Modem Tests	
111	G3-2 DTMF Tests	
112	G3-2 V34 (S2400baud)	
113	G3-2 V34 (S2800baud)	
114	G3-2 V34 (S3000baud)	
115	G3-2 V34 (S3200baud)	
116	G3-2 V34 (S3429baud)	
117	G3-3 Modem Tests	

118	G3-3 DTMF Tests
119	G3-3 V34 (S2400baud)
120	G3-3 V34 (S2800baud)
121	G3-3 V34 (S3000baud)
122	G3-3 V34 (S3200baud)
123	G3-3 V34 (S3429baud)
124	IG3-1 Modem Tests - Not used
125	IG3-1 DTMF Tests - Not used
126	IG3-1 V34 (S2400baud) - Not used
127	IG3-1 V34 (S2800baud) - Not used
128	IG3-1 V34 (S3000baud) - Not used
129	IG3-1 V34 (S3200baud) - Not used
130	IG3-1 V34 (S3429baud) - Not used
131	IG3-2 Modem Tests - Not used
132	IG3-2 DTMF Tests - Not used
133	IG3-2 V34 (S2400baud) - Not used
134	IG3-2 V34 (S2800baud) - Not used
135	IG3-2 V34 (S3000baud) - Not used
136	IG3-2 V34 (S3200baud) - Not used
137	IG3-2 V34 (S3429baud) - Not used

Bit Switches – 1

C Important

• Do not adjust a bit switch or use a setting that is described as "Not used", as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

Default settings for bit switches are not listed in this manual. Refer to the System Parameter List printed by the machine.

System Switches

System Switch 00 (SP No. 1-101-001)		
No	Function	Comments
0	Dedicated transmission parameter programming O: Disabled 1: Enabled	Set this bit to 1 before changing any dedicated transmission parameters. This setting is automatically reset to "0" after turning off and on.
1	Not used	Do not change this setting.
2	Technical data printout on the journal O: Disabled 1: Enabled	1: Instead of the personal name, the following data are listed in the journal for each G3 communication.

	Example:			
		L0100 03 04 6) (7) (8)		
	(1): EQM value (Line quality data)	(1): EQM value (Line quality data). A larger number means more errors.		
	(2): Symbol rate (V.34 only)(3): Final modem type used(4): Starting data rate (for example, 288 means 28.8 kbps)			
	(5): Final data rate			
	(6): RX level (see below for how to	pread the RX level)		
	(7): Total number of error lines tha	t occurred during non-ECM reception.		
	(8): Total number of burst error line	es that occurred during non-ECM reception.		
	Note			
	• EQM and RX level are fixed a	at "FFFF" in TX mode.		
	• The seventh and eighth numb reception records.	ers are fixed at "00" for transmission records and ECM		
	RX level calculation			
	Example:			
	L0100 03 04 6) (7) (8)			
	The four-digit hexadecimal value (N) after "L" indicates the RX level.			
	The high byte is given first, followed by the low byte. Divide the decimal value of N get the RX level.			
	In the above example, the decima	l value of N (= 0100 [H]) is 256.		
	So, the actual RX level is 256/-16 = -16 dB			
3	Not used	Do not change this setting.		
4	Line error mark print	When "1" is selected, a line error mark is printed on		
	0: OFF, 1: ON (print)	the printout if a line error occurs during reception. This shows error locations when ECM is turned off.		
5	G3 communication parameter	This is a fault-finding aid. The LCD shows the key		
	display	parameters (see "G3 Communication Parameters"		
	0: Disabled	below this table). This is normally disabled because it		
	1: Enabled	cancels the CSI display for the user.		
		Be sure to reset this bit to "0" after testing.		

4. Service	Tables
------------	--------

6	Protocol dump list output after each communication 0: Off 1: On	This is only used for communication troubleshooting. It shows the content of the transmitted facsimile protocol signals. Always reset this bit to 0 after finishing testing. If system switch 09 bit 6 is at "1", the list is only printed if there was an error during the communication.
7	Not used	Do not change the setting.

G3 Communication Parameters

Modem rate	336: 33600 bps 168: 16800 bps
	312: 31200 bps 144: 14400 bps
	288: 28800 bps 120: 12000 bps
	264: 26400 bps 96: 9600 bps
	240: 24000 bps 72: 7200 bps
	216: 21600 bps 48: 4800 bps
	192: 19200 bps 24: 2400 bps
Resolution	S: Standard (8 x 3.85 dots/mm)
	D: Detail (8 x 7.7 dots/mm)
	F: Fine (8 x 15.4 dots/mm)
	SF: Superfine (16 x 15.4 dots/mm)
	21: Standard (200 x 100 dpi)
	22: Detail (200 x 200 dpi)
	44: Superfine (400 x 400 dpi)
Compression mode	MMR: MMR compression
	MR: MR compression
	MH: MH compression
	JBO: JBIG compression (Optional mode)
	JBB: JBIG compression (Basic mode)
Communication mode	ECM: With ECM
	NML: With no ECM

Width and reduction	A4: A4 (8.3"), no reduction
	B4: B4 (10.1"), no reduction
	A3: A3 (11.7"), no reduction
I/O rate	0: 0 ms/line
	5:5 ms/line
	10: 10 ms/line
	20: 20 ms/line
	25: 2.5 ms/line
	40: 40 ms/line
	♦ Note
	• "40" is displayed while receiving a fax message using AI short protocol.

System Switch 01 - Not used (Do not change the factory settings.)

	System Switch 02 (SP No. 1-101-003)		
No	Function	Comments	
0-1	Not used	Do not change these settings.	
2	Forced reset after transmission stalls 0: Off 1: On	With this setting on, the machine resets itself automatically if a transmission stalls and fails to complete the job.	
3	Not used	Do not change these settings.	
4	File retention time O: Depends on User Parameter 24 [18(H)] 1: No limit	1: A file that had a communication error will not be erased unless the communication is successful.	
5-7	-	Do not change this setting	

System Switch 03 - Not used (Do not change the factory settings.)

System Switch 04 (SP No. 1-101-005)		
No	Function	Comments

0-2	Not used	Do not change these settings.
3	Printing dedicated TX parameters on Quick/Speed Dial Lists O: Disabled 1: Enabled	 Each Quick/Speed dial number on the list is printed with the dedicated TX parameters (10 bytes each). The first 10 bytes of data are the programmed dedicated TX parameters; 34 bytes of data are printed (the other 24 bytes have no use for service technicians).
4-7	Not used	Do not change these settings.

 System Switch 05 - Not used (Do not change the factory settings.)

 System Switch 06 - Not used (Do not change the factory settings.)

 System Switch 07 - Not used (Do not change the factory settings.)

 System Switch 08 - Not used (Do not change the factory settings.)

	System Switch 09 (SP No. 1-101-010)		
No	Function	Comments	
0	Addition of image data from confidential transmissions on the transmission result report O: Disabled 1: Enabled	If this feature is enabled, the top half of the first page of confidential messages will be printed on transmission result reports.	
1	Print timing of communication reports on the Journal when no image data was exchanged. O: After DCS/NSS communication (default), 1: After polling	0: The Journal is printed only when image data is sent. 1: The Journal is printed when any data is sent.	
2	Automatic error report printout 0: Disabled 1: Enabled	0: Error reports will not be printed. 1: Error reports will be printed automatically after failed communications.	
3	Printing of the error code on the error report 0: No 1: Yes	1: Error codes are printed on the error reports. This can be used for detecting an error which occurs rarely.	

4	Not used	Do not change this setting.
5	Power failure report O: Disabled 1: Enabled (default)	1: A power failure report will be automatically printed after the power is turned ON if a fax message disappeared from the memory when the power was turned off last.
		NOTE: If "0" is selected, no reports are printed and no one may recognize that fax data is gone due to a power failure.
6	Conditions for printing the protocol dump list	This switch becomes effective only when system switch 00 bit 6 is set to 1.
	0: Print for all communications 1: Print only when there is a communication error	 Set this bit to 1 when you wish to print a protocol dump list only for communications with errors. NOTE: The memory size is limited. Use this bit switch only when some log reports are necessary.
7	Not used	Do not change this setting.

	System Switch OA (SP No. 1-101-011)		
No	Function	Comments	
0	Automatic port selection O: Disabled, 1: Enabled	When "1" is selected, a suitable port is automatically selected if the selected port is not used. NOTE: This bit is useful if all communication lines at a customer site are not the same quality	
1-3	Not used	Do not change these settings.	
4	Dialing on the ten-key pad when the external telephone is off-hook O: Disabled 1: Enabled	 O: Prevents dialing from the ten-key pad while the external telephone is off-hook. Use this setting when the external telephone is not by the machine, or if a wireless telephone is connected as an external telephone. 1: The user can dial on the machine's ten-key pad when the handset is off-hook. 	
5	On hook dial 0: Disabled 1: Enabled	0: On hook dial is disabled.	
6-7	Not used	Do not change these settings	

System Switch OB - Not used (Do not change the factory settings.)

System Switch OC - Not used (Do not change the factory settings.)

System Switch OD - Not used (Do not change the factory settings.)

System Switch OE (SP No. 1-101-015)		
No	Function	Comments
0-1	Not used	Do not change the settings.
2	Enable/disable for direct sending selection O: Direct sending off 1: Direct sending on	Direct sending cannot operate when the capture function is on during sending. Setting this switch to "1" enables direct sending without capture. Setting this switch to "0" masks the direct sending function on the operation panel so direct sending with ScanRouter cannot be selected.
3	Action when the external handset goes off-hook O: Manual TX and RX operation 1: Memory TX and RX operation (the display remains the same)	 0: Manual TX is possible while the external handset is off-hook. However, manual TX during handset off-hook may not be sent to a correct direction. Manual TX is not possible. 1: The display stays in standby mode even when the external handset is used, so that other people can use the machine for memory TX operation. Note that manual TX and RX are not possible with this setting.
4-7	Not used	Do not change these settings.

System Switch OF (SP No. 1-101-016)		
No	Function	Comments

0 to	Country/area code for functional settings (Hex)		This country/area code determines the factory settings of bit switches and RAM addresses.
7	00: France	12: Asia	However, it has no effect on the NCU parameter settings and communication
	01: Germany	13: Japan	parameter RAM addresses.
	02: UK	14: Hong Kong	Cross reference NCU country code:
	03: Italy	15: South Africa	SP No. 2-103-001 for G3-1
	04: Austria	16: Australia	SP No. 2-104-001 for G3-2
	05: Belgium	17: New Zealand	SP No. 2-105-001 for G3-3
	06: Denmark	18: Singapore	
	07: Finland	19: Malaysia	
	08: Ireland	1A: China	
	09: Norway	1B: Taiwan	
	0A: Sweden	1C: Korea	
	OB: Switz.	1D: Brazil	
	OC: Portugal	20: Turkey	
	0D: Holland	21: Greece	
	OE: Spain	22: Hungary	
	OF: Israel	23: Czech	
	10:	24: Poland	
	11: USA		

System Switch 10 (SP No. 1-101-017)			
No	Function	Comments	
0-7	Threshold memory level for parallel memory transmission	Threshold = N x 128 KB + 256 KB N can be between 00 - FF(H) Default setting: 02(H) = 512 KB	

	System Switch 11 (SP No. 1-101-018)				
No	Function	Comments			
0	TTI printing position O: Superimposed on the page data 1: Printed before the data leading edge	Change this bit to 1 if the TTI overprints information that the customer considers to be important (G3 transmissions). NOTE: If "1" is selected, it is possible that sent data is printed on two sheets of paper.			
1-2	Not used	Do not change these settings.			
3	TTI used for broadcasting O: The TTIs selected for each Quick/ Speed dial are used 1: The same TTI is used for all destinations	1: The TTI (TTI_1 or TTI_2) which is selected for all destinations during broadcasting.			
4-7	Not used	Do not change these settings.			

System Switch 12 (SP No. 1-101-019)				
No	Function	Comments		
0-7	TTI printing position in the main scan direction	TTI: 08 to 92 (BCD) mm Input even numbers only.		
		This setting determines the print start position for the TTI from the left edge of the paper. If the TTI is moved too far to the right, it may overwrite the file number which is on the top right of the page. On an A4 page, if the TTI is moved over by more than 50 mm, it may overwrite the page number.		

System Switch 13 - Not used (do not change these settings)

System Switch 14 - Not used (do not change these settings)

System Switch 15 (SP No. 1-101-022)			
No	Function	Comments	
0	Not used	Do not change the settings.	

1	Going automa 0: Enal 1: Disa	atically bled	Energy Saver mode	 1: The machine will restart from the Energy Saver mode quickly, because the +5V power supply is active even in the Energy Saver mode. The LED of the operation switch is flashing instead of entering Energy Saver mode. Use this setting if an external telephone has to be used when the machine is in the Energy Saver mode.
2-3	Not use	ed		Do not change these settings.
4-5	Interval for preventing the machine from entering Energy Saver mode if there is a pending transmission file.		nergy Saver mode if	If there is a file waiting for transmission, the machine does not go to Energy Saver mode during the selected period.
	Bit 5	Bit 4	Setting	After transmitting the file, if there is no file waiting for transmission, the machine goes to the Energy Saver
	0	0	1 min	mode.
	0	1	30 min	
	1	0	1 hour	
	1	1	24 hours	
6-7	Not used			Do not change

System Switch 16 (SP No. 1-101-023)				
No	Function	Comments		
0	Parallel Broadcasting O: Disabled 1: Enabled	 1: The machine sends messages simultaneously using all available ports during broadcasting. NOTE: If a customer wants to keep a line available for fax reception or other reasons, select "0" (Disable). 		
1	Priority setting for the G3 line. 0: PSTN-1 > PSTN-2 or 3 1: PSTN-2 or 3 > PSTN-1	This function allows the user to select the default G3 line type. The optional SG3 units are required to use the PSTN-2 or 3 setting.		
2-7	Not used	Do not change these settings.		

System Switch 17 - Not used (do not change these settings)

System Switch 18 - Not used (do not change these set
--

	System Switch 19 (SP No. 1-101-026)				
No	Function	Comments			
0-5	Not used	Do not change the settings.			
6	Extended scanner page memory after memory option is installed O: Disabled 1: Enabled	 O: After installing the memory expansion option, the scanner page memory is extended to 4 MB from 2 MB. 1: If this bit is set to 1 after installing the memory expansion option, the scanner page memory is extended to 12 MB. But the SAF memory decreases to 18 MB. 			
7*	Special Original mode O: Disabled 1: Enabled	1: If the customer frequently wishes to transmit a form or letterhead which has a colored or printed background, change this bit to "1". "Original 1" and "Original 2" can be selected in addition to the "Text", "Text/Photo" and "Photo" modes.			

	System Switch 1A (SP No. 1-101-027)				
No	Function	Comments			
0 to 7	LS RX memory capacity threshold setting 00-FF (0-1020 Kbyte: Hex)	Sets the value to x4KB. When the amount of available memory drops below this setting, RX documents are printed to conserve memory. Initial setting 0x80 (512 KB) Note • If a customer wants available memory size to be larger, decrease this threshold.			

System Switch 1B - Not used (do not change these settings)

System Switch 1C - Not used (do not change these settings)

System Switch 1D (SP No. 1-101-030)

No	Function	Comments
0	RTI/CSI/CPS code display O: Enable 1: Disable	0: RTI, CSI, CPS codes are displayed on the top line of the LCD panel during communication. 1: Codes are switched off (no display)
1-7	Not used	Do not change these settings.

System Switch 1E (SP No. 1-101-031)			
No	Function	Comments	
0	Communication after the Journal data storage area has become full O: Impossible 1: Possible	 0: When this switch is on and the journal history becomes full, the next report prints. If the journal history is not deleted, the next transmission cannot be received. This prevents overwriting communication records before the machine can print them. 1: If the buffer memory of the communication records for the Journal is full, fax communications are still possible. But the machine will overwrite the oldest communication records. 	
		 Note This setting is effective only when Automatic Journal printout is enabled but the machine cannot print the report (e.g., no paper). 	
J *	Action when the SAF memory has become full during scanning O: The current page is erased. 1: The entire file is erased.	 0: If the SAF memory becomes full during scanning for a memory transmission, the successfully scanned pages are transmitted. 1: If the SAF memory becomes full during scanning for a memory transmission, the file is erased and no pages are transmitted. Note This setting is effective only when Automatic Journal printout is enabled but the machine cannot print the report (e.g., no paper). 	
2	RTI/CSI display priority 0: RTI 1: CSI	This bit determines which identifier, RTI or CSI, is displayed on the LCD while the machine is communicating in G3 non-standard mode.	

1 101 021) c. ~ . L 1E CONL

3	File No. printing O: Enabled 1: Disabled	1: File numbers are not printed on any reports. NOTE: The file numbers may not be printed in the sequential order. If a customer does not like this numbering, select "0".
4	Action when authorized reception is enabled but authorized RTIs/CSIs are not yet programmed O: All fax reception is disabled 1: Faxes can be received if the sender has an RTI or CSI	 0: If the user has stored no acceptable sender RTIs or CSIs, the user can select "ON" in the authorized reception setting but the setting becomes invalid ("OFF"). The machine will not be able to receive any fax messages. If the customer wishes to receive messages from any sender that includes an RTI or CSI, and to block messages from senders that do not include an RTI or CSI, change this bit to "O", then enable Authorized Reception. Otherwise, keep this bit at "1 (default setting)".
5-7	Not used	Do not change the settings

	System Switch 1F (SP No. 1-101-032)		
No	Function	Comments	
0	Not used	Do not change the settings.	
1	Report printout after an original jam during SAF storage or if the SAF memory fills up O: Enabled 1: Disabled	0: When an original jams, or the SAF memory overflows during scanning, a report will be printed. Change this bit to "1" if the customer does not want to have a report in these cases. Memory TX – Memory storage report Parallel memory TX – Transmission result report	
2	Not used	Do not change the settings.	
3	Received fax print start timing (G3 reception) O: After receiving each page 1: After receiving all pages	 0: The machine prints each page immediately after the machine receives it. 1: The machine prints the complete message after the machine receives all the pages in the memory. 	
4-6	Not used	Do not change the factory settings.	

7	Action when a fax SC has occurred 0: Automatic reset 1: Fax unit stops	 0: When the fax unit detects a fax SC code other than SC1201 and SC1207, the fax unit automatically resets itself. 1: When the fax unit detects any fax SC code, the fax unit stops.
		Reference: For fax SC codes, see "Troubleshooting".

Bit Switches – 2

C Important

• Do not adjust a bit switch or use a setting that is described as "Not used", as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

Default settings for bit switches are not listed in this manual. Refer to the System Parameter List printed by the machine.

I-Fax Switches

I-fax Switch 00 (SP No. 1-102-001)		
No	Function	Comments
Origin	al Width of TX Attachment File	This setting sets the maximum size of the original that the destination can receive. (Bits 3 to 6 are reserved for future use or not used.)
0	A4	-
1	В4	
2	A3	
3-6	Reserved	
7	Not used	
	0: Off (not selected), 1: On (selected)	
	 If more than one of these three bits is set to "1", the larger size has priority. For example, if both Bit 2 and Bit 1 are set to "1" then the maximum size is "A3" (Bit 2). When mail is sent, there is no negotiation with the receiving machine at the destination, so the sending machine cannot make a selection for the receiving capabilities (original width setting) of the receiving machine. The original width selected with this switch is used as the RX machine's original width setting, and the original is reduced to this size before sending. The default is A4. If the width selected with this switch is higher than the receiving machine can accept, the machine detects this and this causes an error. 	

I-fax Switch 01 (SP No. 1-102-002)

No	Function	Comments
Origina	al Line Resolution of TX Attachment File	These settings set the maximum resolution of the original that the destination can receive.
0	200x100 Standard	0: Not selected
1	200x200 Detail	1: Selected
2	200x400 Fine	If more than one of these three bits is set to "1", the higher resolution has priority. For example, if both Bit
3	300 x 300 Reserve	O and Bit 2 are set to "1" Then The Resolution is set "Bit 2 200 x 400.
4	400 x 400 Super Fine	bii 2 200 x 400.
5	600 x 600 Reserve	
6	Reserve	
7	mm/inch	
	 This setting selects mm/inch conversion for mail transmission. O: Off (No conversion), 1: On (Conversion) When on (set to "1"), the machine converts millimeters to inches for sending mail. There is no switch for converting inches to millimeters. Unlike G3 fax transmissions which can negotiate between sender and receiver to determine the setting, mail cannot negotiate between terminals; the mm/inch selection is determined by the sender fax. When this switch is Off (0): Images scanned in inches are sent in inches. Images received in inches are transmitted in inches. Images received in mm are transmitted in mm. When this switch is On (1): Images scanned in inches are sent in inches. Images scanned in inches are sent in inches. Images scanned in mm are converted to inches. 	

I-fax Switch 02 (SP No. 1-102-003)		
No	No Function Comments	

2X Text Mail Header Processing This setting determines whether the header information is printed with text e-mails when they are received. D: Prints only text mail. : Prints mail header information attached to text mail. When a text mail is received with this switch On (1), the "From" address and "Subject"
re received.): Prints only text mail. : Prints mail header information attached to text mail.
: Prints mail header information attached to text mail.
When a text mail is received with this switch On (1), the "From" address and "Subject"
iddress are printed as header information.
Vhen a mail with only binary data is received (a TIFF-F file, for example), this setting is gnored and no header is printed.
Dutput from Attached Document at E-mail TX Error
his setting determines whether only the first page or all pages of an e-mail attachment are printed at the sending station when a transmission error occurs. This allows the customer to ee which documents have not reached their intended destinations if sent to the wrong e-mail addresses, for example.
): Prints 1 st page only.
: Prints all pages.
ext String for Return Receipt
his setting determines the text string output for the Return Receipt that confirms the
ori ee id): : :

	00: "Dispatched"	
	Sends from PC mail a request for a Return Receipt. Receives the Return Receipt with "dispatched" in the 2nd part:	
	Disposition: Automatic-action/MDN-send automatically; dispatched	
	The "dispatched" string is included in the Subject string.	
	01: "Displayed"	
	Sends from PC mail a request for a Return Receipt. Receives the Return Receipt with "displayed" in the 2nd part:	
	Disposition: Automatic-action/MDN-send automatically; displayed	
	The "displayed" string is included in the Subject string.	
	10: Reserved	
	11: Reserved	
	A mail requesting a Return Receipt sent from an IFAX with this switch set to "00" (for "dispatched") received by Microsoft Outlook 2000 may cause an error. If any setting other than "displayed" (01) causes a problem, change the setting to "01" to enable normal sending of the Return Receipt.	
4	Media accept feature	
	This setting adds or does not add the media accept feature to the answer mail to confirm a reception.	
	0: Does not add the media accept feature to the answer mail	
	1: Adds the media accept feature to the answer mail.	
	Use this bit switch if a problem occurs when the machine receives an answer mail, which contains the media accept feature field.	
5-6	Not Used	
7	Image Resolution of RX Text Mail	
7	Image Resolution of RX Text Mail This setting determines the image resolution of the received mail.	
7		
7	This setting determines the image resolution of the received mail.	

I-fax Switch 03 - Not used (do not change these settings)

I-fax Switch 04 (SP No. 1-102-005)		
No	Function	Comments
0	Subject for Delivery TX/Memory Transfer This setting determines whether the RTI/CSI registered on this machine or the RTI/CSI of the originator is used in the subject lines of transferred documents.	
	0: Puts the RTI/CSI of the originator in the Subject line. If this is used, either the RTI or CSI is used. Only one of these can be received for use in the subject line.	
	1: Puts the RTI/CSI registered on this r	nachine in the Subject line.
	When this switch is used to transfer and deliver mail to a PC, the information in the Subject line that indicates where the transmission originated can be used to determine automatically the destination folder for each e-mail.	
1	Subject corresponding to mail post da	Itabase
	0: Standard subject	
	1: Mail post database subject	
	The standard subject is replaced by the mail post database subject in the following three cases:	
	1) When the service technician sets the service (software) switch.	
	2) When memory sending or delivery specified by F code is applied by the SMTP server	
	3) With relay broadcasting (1st stage without the Schmidt 4 function).	
	♦ Note	
 This switch does not apply for condition 3) when the RX system is set up fo sending, delivery by F-code, sending with SMTP RX and when operators of (to prevent problems when receiving transmissions). 		ding with SMTP RX and when operators are using FOL
2-7	Not Used	

	I-fax Switch 05 (SP No. 1-102-006)		
No Function Comments		Comments	

0	Mail Addresses of SMTP Broadcast Recipients
	Determines whether the e-mail addresses of the destinations that receive transmissions broadcasted using SMTP protocol are recorded in the Journal.
	For example:
	"1st destination + Total number of destinations: 9" in the Journal indicates a broadcast to 9 destinations.
	0: Not recorded
	1: Recorded
1	IFAXTX Retries
	Determines whether the machine retries sending IFAX when connection and transmission fails due to errors.
	0: Disabled
	1: Enabled
2-7	Not Used

I-fax Switch 06 - Not used	(do not change the settings)
----------------------------	------------------------------

I-fax Switch 07 - Not used	(do not change the settings)
----------------------------	------------------------------

I-fax Switch 08 (SP No. 1-102-009)				
No	Function Comments			
0-7	Memory Threshold for POP Mail Reception			
	This setting determines the amount of SAF (Store and Forward) memory. (SAF stores fax messages to send later for transmission to more than one location, and also holds incoming messages if they cannot be printed.) When the amount of SAF memory available falls below this setting, mail can no longer be received; received mail is then stored on the mail server.			
	00-FF (0 to 1024 KB: HEX)			
	The hexadecimal number you enter is multiplied by 4 KB to determine the amount of memory.			

	I-fax Switch 09 (SP No. 1-102-010)		
No	Function	Comments	
0-3	Not used	Do not change the settings	

4-7	Restrict TX Retries	This setting determines the number of retries when connection and transmission fails due to errors.
		01-F (1-15 Hex)

I-fax Switch OA - Not used (do not change the settings)

I-fax Switch OB - Not used (do not change the settings)

I-fax Switch OC - Not used (do not change the settings)

I-fax Switch OD (SP No. 1-102-014				o. 1-102-014)
No	Function		inction	Comments
0-1	Not used			Do not change the settings
2-3		signature v n of the ser	when sending mail nd results	In response to IEEE2600.1.
	Bit 2	Bit 3	Setting	
	0	0	No sign	
	0	1	No setting	
	1	0	Individual setting	
	1	1	Always sign	
4-5	Select the signature when sending mail.		when sending mail.	In response to IEEE2600.1.
	Bit 5	Bit 4	Setting	
	0	0	No sign	
	0	1	No setting	
	1	0	Individual setting	
	1	1 1 Always sign		
6-7	Not used			Do not change the settings.

I-fax Switch OE - Not used (do not change the settings)

	I-fax Switch OF (SP No. 1-102-016)				
No	Function Comments				
0	Delivery Method for SMTP RX Files				
	This setting determines whether files received with SMTP protocol are delivered or output immediately.				
	0: Off. Files received via SMTP are or	utput immediately without delivery.			
	1: On. Files received via SMTP are delivered immediately to their destinations.				
1	Set to select the signature when receiving SMTP mail.				
	0: No sign				
	1: Always sign				
2	Set to encrypt the data when receiving SMTP mail.				
	0: No encryption				
	1: Encryption				
3-7	Not used				

Printer Switches

	Printer Switch 00 (SP No. 1-103-001)			
No	Function	Comments		
0	Select page separation marks O: Off 1: On	 0: If a 2 page RX transmission is split, [*] is printed in the bottom right corner of the 1st page and only a [2] is printed in the upper right corner of the 2nd page. 1: If a 2 page RX transmission is split into two pages, for example, [*] [2] is printed in the bottom right corner of the 1st page and only a [2] is printed in the upper right corner of the 2nd page. Wote This helps the user to identify pages that have been split because the size of the paper is smaller than the size of the document received. (When A5 is used to print an A4 size document, for example.) 		

1	Repetition of data when the received page is longer than the printer paper 0: Off 1: On	 Default. 10 mm of the trailing edge of the previous page are repeated at the top of the next page. The next page continues from where the previous page stopped without any repeated text.
2	Prints the date and time on received fax messages O: Disabled 1: Enabled	 This switch is only effective when user parameter 02 - bit 2 (printing the received date and time on received fax messages) is enabled. 1: The machine prints the received and printed date and time at the bottom of each received page.
3-7	Not used	Do not change the settings.

Printer Switch 01 (SP No. 1-103-002)				01 (SP No. 1-103-002)
No	Function			Comments
0-2	Not used			Do not change the settings.
3-4	Maximum print width used in the setup protocol			These bits are only effective when bit 7 of printer switch 01 is "1".
	Bit 4	Bit 3	Setting	
	0	0	Not used	
	0	1	A3	
	1	0	B4	
	1	1	A4	
5-6	Not used			Do not change the settings.
7	Received message width restriction in the protocol signal to the sender 0: Disabled			O: The machine informs the transmitting machine of the print width depending on the paper size available from the paper feed stations.
	1: Enabled			Refer to the table on the next page for how the machine chooses the paper width used in the setup protocol (NSF/DIS).
				1: The machine informs the transmitting machine of the fixed paper width which is specified by bits 3 and 4 above.

Available Paper Size	Printer width used in the Protocol (NSF/DIS)
A4 or 8.5" x 11"	297 mm width
В5	256 mm width
A5 or 8.5" x 5.5"	216 mm width
No paper available (Paper end)	216 mm width

Relationship between available paper sizes and printer width used in the setup protocol

	Printer Switch 02 (SP No. 1-103-003)			
No	Function	Comments		
0*	1 st paper feed station usage for fax printing	0: The paper feed station can be used to print fax messages and reports.		
	0: Enabled 1: Disabled	1: The specified paper feed station will not be used for printing fax messages and reports.		
1*	2nd paper feed station usage for fax printing O: Enabled 1: Disabled	 Note Do not disable usage for a paper feed station which has been specified by User Parameter Switch OF (15), or which is used for the Specified Cassette Selection feature. 		
2*	3rd paper feed station usage for fax printing 0: Enabled 1: Disabled			
3*	4th paper feed station usage for fax printing 0: Enabled 1: Disabled			
4*	LCT usage for fax printing O: Enabled 1: Disabled			
5-7	Not used	Do not change the settings.		

	Printer Switch 03 (SP No. 1-103-004)			
No	Function	Comments		
0*	Length reduction of received data 0: Disabled	0: Incoming pages are printed without length reduction.		
	1: Enabled	(Page separation threshold: Printer Switch 03, bits 4 to 7)		
		1: Incoming page length is reduced when printing.		
		(Maximum reducible length: Printer Switches 04, bits 0 to 4)		
1-3	Not used	Do not change the settings		
4 to	Page separation setting when sub scan compression is forbidden	Page separation threshold (with reduction disabled with switch 03-0 above).		
7	00-0F (0-15 mm: Hex) Default: 6 mm	For example, if this setting is set to "10", and A4 is the selected paper size:		
		If the received document is 10 mm or less longer than A4, then the 10 mm are cut and only 1 page prints.		
		If the received document is 10 mm longer than A4, then the document is split into 2 pages.		

Printer Switch 04 (SP No. 1-103-005)				
No	Function	Comments		

0	Maximum reducible length when length reduction is enabled with switch 03-0 above.							
to	[Maximum reducible length] = [Paper length] + (N x 5mm)							
4	"N" is the decimal value of the binary setting of bits 0 to 4.							
	Bit 4	Bit 3	Bit 1	Bit O	Setting			
	0	0	0	0	0	0 mm		
	0	0	0	0	1	5 mm		
	0	0	1	0	0	20 mm		
	1	1	1	1	1	155 mm		
	For A5 sidewa	For A5 sideways and B5 sideways paper						
	[Maximum reducible length] = [Paper length] + 0.75 x (N x 5mm)							
5	Length of the duplicated image on the next page, when page separation has taken place.							
6	Bi	t 6	E	Bit 5	Set	ting		
	(C		0	4 r	nm		
	0 1 10 mm					mm		
	1		0		15 mm			
	1			1		Not used		
7	Not used.		Do not c	hange the setting	•			

Printer Switch 05 - Not used (do not change the settings)

	Printer Switch 06 (SP No. 1-103-007)					
No	Function	Comments				
0*	Printing while a paper cassette is pulled out, when the Just Size Printing feature is enabled. O: Printing will not start	Reference: Just size printing on/off – User switch 05, bit 5				
	1: Printing will start if another cassette has a suitable size of paper, based on the paper size selection priority tables.					

4

Printer Switch 07 (SP No. 1-103-008)				
No	No Function Comments			
0-3	Not used.	Do not change the settings.		
4	Receiver name printed on the transmission result report Selects the printing target on the transmission report. 0: All receivers 0: All receivers 1: Printing only receivers which have received transmission.			
5-7	Not used.	Do not change the settings.		

Printer Switch 08 - Not used (do not change the settings)
Printer Switch 09 - Not used (do not change the settings)
Printer Switch OA - Not used (do not change the settings)
Printer Switch OB - Not used (do not change the settings)
Printer Switch OC - Not used (do not change the settings)

Printer Switch OE (SP No. 1-103-015)					
No	Function	Comments			
0*	Paper size selection priority O: Width 1: Length	0: A paper size that has the same width as the received data is selected first.1: A paper size which has enough length to print all the received lines without reduction is selected first.			
1*	Paper size selected for printing A4 width fax data 0: 8.5" x 11" size 1: A4 size	This switch determines which paper size is selected for printing A4 width fax data, when the machine has both A4 and 8.5" x 11" size paper.			

2	Page separation O: Enabled 1: Disabled			 If all paper sizes in the machine require page separation to print a received fax message, the machine does not print the message (Substitute Reception is used). After a larger size of paper is set in a cassette, the machine automatically prints the fax message.
3-4	Bit 4 Bit 3 Setting		ple image on reports	"Same size" means the sample image is printed
			Setting	at 100%, even if page separation occurs. User Parameter Switch 19 (13H) bit 4 must be
	0	0	The upper half only	set to "0" to enable this switch.
	0	1	50% reduction (sub-scan only)	Refer to "Detailed Descriptions" for more details.
	1	0	Same size	
	1	1	Not used	
5-6	Not use	ed		Do not change the settings.
7	Equalizing the reduction ratio among separated pages (Page Separation) O: Enabled 1: Disabled			O: When page separation has taken place, all the pages are reduced with the same reduction ratio.
				1: Only the last page is reduced to fit the selected paper size when page separation has taken place. Other pages are printed without reduction.

Printer Switch OF (SP No. 1-103-016)					
No	No Function Comments				

0-1*	Smoothing feature			(0, 0) (0, 1): Disable smoothing if the
	Bit 1	Bit O	Setting	machine receives halftone images from other manufacturers fax machines frequently.
	0	0	Disabled	
	0	1	Disabled	
	1	0	Enabled	
	1	1	Not used	
2*	Duplex printing O: Disabled 1: Enabled			1: The machine always prints received fax messages in duplex printing mode:
3	Binding direction for Duplex printing O: Left binding 1: Top binding			0: Sets the binding for the left edge of the stack.1: Sets the binding for the top of the stack.
4-7	Not used			Do not change the settings.

Bit Switches – 3

C Important

 Do not adjust a bit switch or use a setting that is described as "Not used", as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

Default settings for bit switches are not listed in this manual. Refer to the System Parameter List printed by the machine.

		Co	mmunication Switch 00 (SP	No. 1-104-001)
No		F	unction	Comments
0-1	Compression modes available in receive mode			These bits determine the compression
	Bit 1	Bit O	Modes	capabilities to be declared in phase B (handshaking) of the T.30 protocol.
	0	0	MH only	
	0	1	MH/MR	
	1	0	MH/MR/MMR	
	1	1	MH/MR/MMR/JBIG	
2-3	Compressi	on modes a	vailable in transmit mode	These bits determine the compression
	Bit 3	Bit 2	Modes	capabilities to be used in the transmission and to be declared in phase
	0	0	MH only	B (handshaking) of the T.30 protocol.
	0	1	MH/MR	
	1	0	MH/MR/MMR	
	1	1	MH/MR/MMR/JBIG	
4	Not used			Do not change the settings.
5	JBIG compression method: Reception 0: Only basic supported			Change the setting when communication problems occur using JBIG compression.
	1: Basic an	nd optional	both supported	

Communication Switches

6	JBIG compression method: Transmission 0: Basic mode priority 1: Optional mode priority	Change the setting when communication problems occur using JBIG compression.
7	Closed network (reception) O: Disabled 1: Enabled	1: Reception will not go ahead if the polling ID code of the remote terminal does not match the polling ID code of the local terminal. This function is only available in NSF/NSS mode.

Communication Sw			Communication S	Switch 01 (SP No. 1-104-002)
No	Function		tion	Comments
0	ECM 0: Off 1: On			If this bit is set to 0, ECM is switched off for all communications. In addition, V.8 protocol and JBIG compression are switched off automatically.
1	Not used	l		Do not change the setting.
2-3	Wrong c method	onnection	prevention	(0, 1): The machine will disconnect the line without sending a fax message, if the last 8 digits of the
	Bit 3	Bit 2	Setting	received CSI do not match the last 8 digits of the dialed telephone number. This does not work when
	0	0	None	manually dialed.
	0	1	8 digit CSI	(1,0): The same as above, except that only the last 4 digits are compared.
	1	0	4 digit CSI	(1,1): The machine will disconnect the line without
	1	1	CSI/RTI	sending a fax message, if the other end does not identify itself with an RTI or CSI.
ahead. Note • This function does		(0,0): Nothing is checked; transmission will always go ahead.		
			♦ Note	
			• This function does not work when dialing is done from the external telephone.	
4-5	Not used			Do not change the setting.

			e page length	The setting determined by these bits is informed to the transmitting terminal in the pre-message protocol
	exchange (in the DIS/NSF trames).			
	0	0	No limit	
	1	0	A4 (297 mm)	
	1	1	Not used	

	Communication Switch 02 (SP No. 1-104-003)		
No	Function		Comments
0	G3 Burst error threshold 0: Low 1: High	received pag will send a ne threshold val	ore consecutive error lines in the than the threshold, the machine egative response. The Low and High ues depend on the sub-scan ad are as follows.
		100 dpi	6(L) →12(H)
		200 dpi	12(L) →24(H)
		300 dpi	18(L) →36(H)
		400 dpi	24(L) →48(H)
1	Acceptable total error line ratio 0: 5% 1: 10%		e ratio for a page exceeds the atio, RTN will be sent to the other
2	Treatment of pages received with errors during G3 reception	0: Pages rece	eived with errors are not printed.
	0: Deleted from memory without printing 1: Printed		

3	Hang-up decision when a negative code (RTN or PIN) is received during G3 immediate transmission 0: No hang-up, 1: Hang-up	 0: The next page will be sent even if RTN or PIN is received. 1: The machine will send DCN and hang up if it receives RTN or PIN. This bit is ignored for memory transmissions or if ECM is being used.
4-7	Not used	Do not change these settings.

Communication Switch 03 (SP No. 1-104-004)		
No	Function	Comments
0-7	Maximum number of page retransmissions in a G3 memory transmission	00 - FF (Hex) times. This setting is not used if ECM is switched on. Default setting - 03(H)

	Communication Switch 04 (SP No. 1-104-005)		
No	Function	Comments	
0	Remote mode switch (TEL mode) O: Disable 1: Enable (Active)	Set this bit to ON when you wish to switch TEL mode to FAX mode remotely.	
1	Remote mode switch (FAX mode) O: Disable 1: Enable (Active)	Set this bit to ON when you wish to turn on the remote mode switch after automatic reception with FAX mode.	
2	Remote mode switch (AUTO mode) O: Disable 1: Enable (Active)	Set this bit to ON when you wish to turn on the remote mode switch after automatic reception with AUTO mode.	
3-7	Not used	Do not change the settings.	

Communication Switch 05 (SP No. 1-104-006)			
No Function Comments			
0-3	Remote mode switch number 00-09 (0-9:HEX)	Enter the number to switch between TEL/FAX modes using the external phone.	

4-7	Not used	Do not change the settings.
-----	----------	-----------------------------

Communication Switch 06 - Not used (do not change the settings)

Communication Switch 07 - Not used (do not change the settings)

Communication Switch 08 - Not used (do not change the settings)

	Communication Switch 09 (SP No. 1-104-009)			
No	No Function Comments			
0-7	Minimum interval between automatic dialing attempts	This value is the minimum time that the machine waits before it dials the next destination.		

Communication Switch OA (SP No. 1-104-011)			
No	Function	Comments	
0	Point of resumption of memory transmission upon redialing	0: The transmission begins from the page where transmission failed the previous time.	
	0: From the error page 1: From page 1	1: Transmission begins from the first page, using normal memory transmission.	
1-7	Not used	Do not change these settings.	

	Communication Switch OB (SP No. 1-104-012)			
No	Function	Comments		
0-3	Not used	Do not change these settings.		
4	Printout of the message when acting as a Transfer Station O: Disabled, 1: Enabled	When the machine is acting as a Transfer Station, this bit determines whether the machine prints the fax message coming in from the Requesting Terminal.		
5-7	Not used	Do not change the settings.		

Communication Switch OC - Not used (do not change the settings)

Communication Switch OD (SP No. 1-104-014)

No	Function	Comments
0-7	The available memory threshold, below which ringing detection (and therefore reception into memory) is disabled	00 to FF (Hex), unit = 4 Kbytes (e.g., 06(H) = 24 Kbytes) One page is about 24 Kbytes. The machine refers to this setting before each fax reception. If the amount of remaining memory is below this threshold, the machine cannot receive any fax messages. If this setting is kept at 0, the machine will detect ringing signals and go into receive mode even if there is no memory available. This will result in communication failure.

Communication Switch OE (SP No. 1-104-015)		
No	No Function Comments	
0-7	Minimum interval between automatic dialing attempts	06 to FF (Hex), unit = 2 s (e.g., 06(H) = 12 s) This value is the minimum time that the machine waits before it dials the next destination.

Communication Switch OF – Not used (do not change the settings.)

	Communication Switch 10 (SP No. 1-104-017)		
No	Function	Comments	
0-7	Memory transmission: Maximum number of dialing attempts to the same destination	01 – FE (Hex) times	

Communication Switch 11 – Not used (do not change the settings.)

	Communication Switch 12 (SP No. 1-104-019)		
No	No Function Comments		

0-7	Memory transmission: Interval	01 – FF (Hex) minutes
	between dialing attempts to the same destination	
	same destination	

Communication Switch 13 – Not used (do not change the settings.)

No		Fu	nction	Comments
0	Inch-to-mm conversion during transmission 0: Disabled, 1: Enabled		Ū.	0: In immediate transmission, data scanned in inch format are transmitted without conversion.
				In memory transmission, data stored in the SAF memory in mm format are transmitted without conversion.
				Note: When storing the scanned data into SAF memory, the fax unit always converts the data into mm format.
				1: The machine converts the scanned data or stored data in the SAF memory to the format which was specified in the set-up protocol (DIS/NSF) before transmission.
1-5	Not used			Do not change the factory settings.
6-7		e unit of reso s are receive	lution in which fax ed	For the best performance, do not change the factory settings.
	Bit 7	Bit 6	Unit	The setting determined by these bits is informed to the transmitting terminal in the pre-
	0	0	mm	message protocol exchange (in the DIS/NSF
	0	1	inch	frames).
	1	0	mm and inch	
	1	1	Not used	

Communication Switch 14 (SP No. 1-104-021)

Communication Switch 15 – Not used (do not change the settings)

Communication Switch 16 (SP No. 1-104-023)		
No Function Comments		Comments

0	Not used	Do not change the settings.
1	Optional G3 unit (G3-2) 0: Not installed 1: Installed	Change this bit to 1 when installing the first optional G3 unit.
2	Not used	
3	Select PSTN connection 0: Off 1: On	 This switch enables the G3-2. O: Off, no connection 1: Recognizes and enables G3-2. This switch can be used only after G3-2 has been installed.
4-7	Not used	Do not change the settings.

	Communication Switch 17 (SP No. 1-104-024)		
No	Function	Comments	
0	SEP reception O: Disabled 1: Enabled	O: Polling transmission to another maker's machine using the SEP (Selective Polling) signal is disabled.	
1	SUB reception O: Disabled 1: Enabled	0: Confidential reception to another maker's machine using the SUB (Sub-address) signal is disabled.	
2	PWD reception O: Disabled 1: Enabled	0: Disables features that require PWD (Password) signal reception.	
3-4	Not used	Do not change the settings.	
5	PSTN dial-in routing setting 0: OFF 1: ON	1: The machine sets multiple PSTN dial-in numbers in the PSTN dial-in line and transfers received data from each PSTN dial-in number to each address.	
6	Not used	Do not change the settings.	

4

Г

7	Action when there is no box with an F-code that matches the received SUB code	Change this setting when the customer requires.
	0: Disconnect the line	
	1: Receive the message	
	(using normal reception mode)	

	Communication Switch 18 (SP No. 1-104-025)		
No	Function	Comments	
0-4	Not used	Do not change the settings.	
5	IP-Fax dial-in routing selection 0: Off 1: On	1: Transfers received data to each IP-Fax dial-in number. IP-Fax dial-in number is a 4-digit number.	
6	PSTN 2 dial-in routing 0: Off 1: On	Enables or disables dial-in routing for the PSTN 2 connection.	
7	PSTN 3 dial-in routing 0: Off 1: On	Enables or disables dial-in routing for the PSTN 3 connection.	

Communication Switch 19 - Not used (do not change the settings)

Communication Switch 1A - Not used (do not change the settings)

	Communication Switch 1B (SP No. 1-104-028)		
No Function Comments		Comments	
0-7	Extension access code (0 to 7) to turn V.8 protocol On/Off	If the PABX does not support V.8/V.34 protocol procedure, set this bit to "1" to disable V.8.	
	0: On	Example: If "0" is the PSTN access code, set bit 0 to 1.	
	1: Off	When the machine detects "O" as the first dialed number, it automatically disables V.8 protocol. (Alternatively, if "3" is the PSTN access code, set bit 3 to 1.)	

	Communication Switch 1C (SP No. 1-104-029)		
No	Function	Comments	
0-1	Extension access code (8 and 9) to turn V.8 protocol On/Off 0: On 1: Off	Refer to communication switch 1B. Example: If "8" is the PSTN access code, set bit 0 to 1. When the machine detects "8" as the first dialed number, it automatically disables V.8 protocol. (If "9" is the PSTN access code, use bit 1.)	
2-7	Not used	Do not change the settings.	

Communication	Switch	1
_		_

Communication Switch 1D - Not used (do not change the settings)	
Communication Switch 1E - Not used (do not change the settings)	
Communication Switch 1F - Not used (do not change the settings)	

Bit Switches – 4

Comportant [

• Do not adjust a bit switch or use a setting that is described as "Not used", as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

Default settings for bit switches are not listed in this manual. Refer to the System Parameter List printed by the machine.

	G3 Switch 00 (SP No. 1-105-001)				
No			Function	Comments	
0 1	Monitor speaker during communication (TX and RX)			(0, 0): The monitor speaker is disabled all through the communication.	
	Bit 1	Bit O	Setting	(0, 1): The monitor speaker is on up to phase B in the T.30 protocol.	
	0	0	Disabled	(1, 0): Used for testing. The monitor speaker is on	
	0	1	Up to Phase B	all through the communication. Make sure that you reset these bits after testing.	
	1	0	All the time		
	1	1	Not used		
2	 2 Monitor speaker during memory transmission 0: Disabled 1: Enabled 			1: The monitor speaker is enabled during memory transmission.	
3-5	Not used			Do not change the settings.	
6	Dedicated G3 line mode selection 0: Off 1: On (Dedicated)			Set this bit to 1 when you wish to dedicate a line for G3.	
7	Not us	ed		Do not change this setting.	

G3 Switches

	G3 Switch 01 (SP No. 1-105-002)				
No	Function	Comments			

0-3	Not used	Do not change the settings.
4	DIS frame length 0: 10 bytes 1: 4 bytes	1: The bytes in the DIS frame after the 4th byte will not be transmitted (set to 1 if there are communication problems with PC-based faxes which cannot receive the extended DIS frames).
5	Not used	Do not change the setting.
6	Forbid CED/ANsam output 0: Off 1: On (Forbid output)	Do not change this setting (Default: 0: Off), unless communication problem is caused by a CED or ANSam transmission.
7	Not used	Do not change this setting.

	G3 Switch 02 (SP No. 1-105-003)				
No	Function	Comments			
0	G3 protocol mode used 0: Standard and non-standard 1: Standard only	Change this bit to 1 only when the other end can only communicate with machines that send T.30-standard frames only. 1: Disables NSF/NSS signals (these are used in non- standard mode communication)			
1-6	Not used	Do not change the settings.			
7	Short preamble 0: Disabled 1: Enabled	Refer to Appendix B in the Group 3 Facsimile Manual for details about Short Preamble.			

	G3 Switch 03 (SP No. 1-105-004)				
No	Function	Comments			
0	DIS detection number (Echo countermeasure)	O: The machine will hang up if it receives the same DIS frame twice.			
	0: 1 1: 2	1: Before sending DCS, the machine will wait for the second DIS which is caused by echo on the line.			
1	Not Used	Do not change the settings.			
2	Not Used	Do not change the settings.			

3	ECM frame size 0: 256 bytes 1: 64 bytes	Keep this bit at "0" in most cases.
4	CTC transmission conditions O: After one PPR signal received 1: After four PPR signals received (ITU-T standard)	0: When using ECM in non-standard (NSF/NSS) mode, the machine sends a CTC to drop back the modem rate after receiving a PPR, if the following condition is met in communications at 14.4, 12.0, 9.6, and 7.2 kbps. √NTransmit≤NRe send NTransmit- Number of transmitted frames NResend- Number of transmitted frames NResend- Number of frames to be retransmitted 1: When using ECM, the machine sends a CTC to drop back the modem rate after receiving four PPRs. PPR, CTC: These are ECM protocol signals. This bit is not effective in V.34 communications.
5	Modem rate used for the next page after receiving a negative code (RTN or PIN) O: No change 1: Fallback	1: The machine's TX modem rate will fall back before sending the next page if a negative code is received. This bit is ignored if ECM is being used.
6	Not used	Do not change the settings
7	Select detection of reverse polarity in ringing 0: Off 1: On	This switch is used to prevent reverse polarity in ringing on the phone line (applied to PSTN-G3 ringing). Do not change this setting 0: No detection 1: Detection (Japan and Korea only)

	G3 Switch 04 (SP No. 1-105-005)				
No	Function	Comments			
0-3	Training error detection threshold	0 - F (Hex); 0 - 15 bits			
		If the number of error bits in the received TCF is below this threshold, the machine informs the sender that training has succeeded.			
4-7	Not used	Do not change the settings.			

	G3 Switch 05 (SP					No. 1-105-006)
No	Function					Comments
0-3	Initial TX modem rate (kbps))		These bits set the initial starting modem rate for
	Bit 3	Bit 2	Bit 1	Bit O	kbps	transmission. Use the dedicated transmission parameters if
	0	0	0	1	2.4	you need to change this for specific receivers.
	0	0	1	0	4.8	If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled
	0	0	1	1	7.2	manually.
	0	1	0	0	9.6	Cross reference
	0	1	0	1	12.0	V.8 protocol on/off - G3 switch 03, bit 2
	0	1	1	0	14.4	
	0	1	1	1	16.8	
	1	0	0	0	19.2	
	1	0	0	1	21.6	
	1	0	1	0	24.0	
	1	0	1	1	26.4	
	1	1	0	0	28.8	
	1	1	0	1	31.2	
	1	1	1	0	33.6	
	Other se	ttings - No	ot used	<u> </u>	<u> </u>	
4-5	Initial ma	odem type	e for 9.6 k	c or 7.2 kl	ops.	These bits set the initial modem type for 9.6 and
	Bit 5	Bit 4		Setting		7.2 kbps, if the initial modem rate is set at these speeds.
	0	0		V.29		
	0 1 V.17					
	1 0 V.34					
	1	1		Not use	d	
6-7	Not used					Do not change the settings.

	G3 Switch 06 (SP No. 1-105-007)					
No	Function					Comments
0-3	Initial RX	modem re	ate(kbps)			These bits set the initial starting modem rate
	Bit 3	Bit 2	Bit 1	Bit O	kbps	for reception. Use a lower setting if high speeds pose
	0	0	0	1	2.4	problems during reception.
	0	0	1	0	4.8	If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled
	0	0	1	1	7.2	manually.
	0	1	0	0	9.6	Cross reference
	0	1	0	1	12.0	V.8 protocol on/off - G3 switch 03, bit2
	0	1	1	0	14.4	
	0	1	1	1	16.8	
	1	0	0	0	19.2	
	1	0	0	1	21.6	
	1	0	1	0	24.0	
	1	0	1	1	26.4	
	1	1	0	0	28.8]
	1	1	0	1	31.2	
	1	1	1	0	33.6	
	Other se	ttings - No	ot used			

4-7 Modem types available for reception

The setting of these bits is used to inform the transmitting terminal of the available modem type for the machine in receive mode.

If V.34 is not selected, V.8 protocol must be disabled manually.

Cross reference

V.8 protocol on/off - G3 switch 03, bit 2

Bit 7	Bit 6	Bit 5	Bit 4	Турез			
0	0	0	1	V.27ter			
0	0	1	0	V.27ter, V.29			
0	0	1	1	V.27ter, V.29, V.33			
0	1	0	0	V.27ter, V.29, V.17			
0	1	0	1	V.27ter, V.29, V.17, V.34			
Other set	Other settings - Not used						

Other settings - Not used

	G3 Switch 07 (SP No. 1-105-008)					
No		Fu	nction	Comments		
0-1	PSTN cat (TX mode	ole equalize : Internal)	er	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone		
	Bit 1	Bit O	Setting	exchange.		
	0	0	None	Use the dedicated transmission parameters for specific receivers.		
	0	1	Low	' Also, try using the cable equalizer if one or		
	1	0	Medium	more of the following symptoms occurs.		
1 1	High	Communication error Modem rate fallback occurs frequently.				
				 Note This setting is not effective in V.34 communications. 		

2-3	PSTN cable e (RX mode: Int	•		Use a higher setting if there is signal loss at higher frequencies because of the length of
	Bit 3	Bit 2	Setting	wire between the modem and the telephone exchange.
	0	0	None	Also, try using the cable equalizer if one or more of the following symptoms occurs.
	0	1	Low	Communication error with error codes such as
	1	0	Medium	0-20, 0-23, etc.
	1	1	High	Modem rate fallback occurs frequently.
				• This setting is not effective in V.34 communications.
4	PSTN cable e	•		Keep this bit at "1".
	(V.8/V.17 RX mode: External) O: Disabled			
	1: Enabled			
5	Not used			Do not change the settings.
6	Parameter se	lection for dia	tone	0: This uses the fixed table in the ROM for dial tone detection.
	0: Normal po	arameter		1: This uses the specific parameter adjusted
	1: Specific po			with SRAM (69ECBEH - 69ECDEH). Select this if the dial tone cannot be detected when the "Normal parameter: 0" is selected.
7	Not used			Do not change the settings.

G3 Switch 08 - Not used (do not change the settings)

G3 Switch 09 - Not used (do not change the settings)

G3 Switch 0A (SP No. 1-105-011)						
No	No Function Comments					

0-1		um allow data rece	able carrier drop during ption	These bits set the acceptable modem carrier drop time.
	Bit 1 Bit 0 Value (ms)		Value (ms)	Try a longer setting if error code 0-22 is frequent.
	0	0	200	
	0	1	400	
	1	0	800	
	1	1	Not used	
2			on of high-speed RX if t while receiving	This switch setting determines if high-speed receiving ends if the carrier signal is lost when receiving during non-ECM mode
3	Not use	ed		Do not change the settings
4	Maximum allowable frame interval during image data reception. 0: 5 s 1: 13 s			This bit set the maximum interval between EOL (end-of-line) signals and the maximum interval between ECM frames from the other end. Try using a longer setting if error code 0-21 is frequent.
5	Not use	ed		Do not change the settings.
6	Reconstruction time for the first line in receive mode 0: 6 s 1: 12 s			When the sending terminal is controlled by a computer, there may be a delay in receiving page data after the local machine accepts set- up data and sends CFR. This is outside the T.30 recommendation. But, if this delay occurs, set this bit to 1 to give the sending machine more time to send data. Refer to error code 0-20.
				ITU-T T.30 recommendation: The first line should come within 5 s of CFR.
7	Not use	ed		Do not change the settings.

G3 Switch OB Not used (do not change the settings).

	G3 Switch 0E (SP No. 1-105-013)				
No	Function	Comments			
0-1	Not used	Do not change these settings.			
4-5	Select detection of DTMF/DP detection when using remote switch.	This setting determines how to detect the signals from the handset when remote switch is active.			
	00: DTMF+PSTN (Simultaneous detection)				
	01: DTMF				
	10: DP (10 PPPS)				
	11: DP (20 PPS)				

G3 Switch 0D Not used (do not change the settings).

	G3 Switch 0E (SP No. 1-105-015)					
No	Function Comments					
0-7	e may not be able to automatically switch the 3-second					
5		3000-2250ms: 3000-50xNms 3000 – 50 x Nms OF (3000 ms) <= N <= FF (2250 ms)				
	Low order bit	00-0E(3000-3700ms: 3000+50xNms 3000 – 50 x Nms OF (3000 ms) <= N <= OF (3700 ms)				

	G3 Switch 0F (SP No. 1-105-016)					
No	Function	Comments				
0	Alarm when an error occurred in Phase C or later	If the customer wants to hear an alarm after each error communication, change this bit to "1".				
	0: Disabled					
	1: Enabled					

1	Alarm when the handset is off- hook at the end of communication 0: Disabled 1: Enabled	If the customer wants to hear an alarm if the handset is off-hook at the end of fax communication, change this bit to "1".
2-3	Not used	Do not change these settings.
4	Manual calibration setting 0: Off 1: On	1: manually calibrates for communication with a line whose current change occurs such as an optical fiber line.
5-7	Not used	Do not change the settings.

Bit Switches – 5

Coloritant []

• Do not adjust a bit switch or use a setting that is described as "Not used", as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

Default settings for bit switches are not listed in this manual. Refer to the System Parameter List printed by the machine.

G3-2 and G3-3 Switches

These switches require an optional G3 interface unit.

G3-3 switches are the same as for G3-2 switches.

			G3-2 Switch 00	(SP No. 1-106-001)
No		F	Function	Comments
0 1	Monitor speaker during communication (TX and RX)			(0, 0): The monitor speaker is disabled all through the communication.
	Bit 1 Bit 0 Setting		Setting	(0, 1): The monitor speaker is on up to phase B in the T.30 protocol.
	0	0	Disable	(1, 0): Used for testing. The monitor speaker is on
	0	1	Up to Phase B	all through the communication. Make sure that you reset these bits after testing.
	1	1 0 All the time		
	1 1 Not used		Not used	
2	transmi	•	during memory abled	1: The monitor speaker is enabled during memory transmission.
3-7	Not use	ed		Do not change the settings.

G3-2 Switch 01 (SP No. 1-106-002) No Function Comments 0-3 Not used Do not change the settings.

4	DIS frame length 0: 10 bytes 1: 4 bytes	1: The bytes in the DIS frame after the 4th byte will not be transmitted (set to 1 if there are communication problems with PC-based faxes which cannot receive the extended DIS frames).
5	Not used	Do not change the setting.
6	Forbid CED/ANSam output 0: Off 1: On (Forbid output)	Do not change this setting (Default: 0: Off), unless communication problem is caused by a CED or ANSam transmission.
7	Not used	Do not change the setting.

	G3-2 Switch 02 (SP No. 1-106-003)					
No	Function	Comments				
0	G3 protocol mode used O: Standard and non-standard 1: Standard only	Change this bit to 1 only when the other end can only communicate with machines that send T.30-standard frames only. 1: Disables NSF/NSS signals (these are used in non- standard mode communication)				
1-4	Not used	Do not change the settings.				
5	AI modem rate selection 0: OFF, 1: ON	Selects if the AI modem rate is ON or OFF.				
6	Not used	Do not change the settings.				
7	Short preamble 0: Disabled 1: Enabled	Refer to Appendix B in the Group 3 Facsimile Manual for details about Short Preamble.				

	G3-2 Switch 03 (SP No. 1-106-004)					
No	Function	Comments				
0	DIS detection number (Echo countermeasure) O: 1 1: 2	0: The machine will hang up if it receives the same DIS frame twice.1: Before sending DCS, the machine will wait for the second DIS which is caused by echo on the line.				
1	Not Used	Do not change the settings.				

2	Not Used	Do not change the settings.
3	ECM frame size 0: 256 bytes 1: 64 bytes	Keep this bit at "O" in most cases.
4	CTC transmission conditions O: After one PPR signal received 1: After four PPR signals received (ITU-T standard)	0: When using ECM in non-standard (NSF/NSS) mode, the machine sends a CTC to drop back the modem rate after receiving a PPR, if the following condition is met in communications at 14.4, 12.0, 9.6, and 7.2 kbps. √NTransmit≤NRe send Ntransmit = Number of transmitted frames Nresend = Number of transmitted frames Nresend = Number of frames to be retransmitted 1: When using ECM, the machine sends a CTC to drop back the modem rate after receiving four PPRs. PPR, CTC: These are ECM protocol signals. This bit is not effective in V.34 communications.
5	Modem rate used for the next page after receiving a negative code (RTN or PIN) 0: No change 1: Fallback	1: The machine's TX modem rate will fall back before sending the next page if a negative code is received. This bit is ignored if ECM is being used.
6	Not used	Do not change the settings
7	Select detection of reverse polarity in ringing 0: Off 1: On	This switch is used to prevent reverse polarity in ringing on the phone line (applied to PSTN-G3 ringing). Do not change this settingO: No detection1: Detection (Japan and Korea only)

	G3-2 Switch 04 (SP No. 1-106-005)					
No	Function	Comments				
0-3	Training error detection threshold	0 - F (Hex); 0 - 15 bits				
		If the number of error bits in the received TCF is below this threshold, the machine informs the sender that training has succeeded.				

r

4-7	7 Not used					change the settings.
			G	3-2 Swite	:h 05 (SP	No. 1-106-006)
No			Function			Comments
0-3	Initial TX	modem r	ate (kbps)		These bits set the initial starting modem rate for
	Bit 3	Bit 2	Bit 1	Bit O	kbps	transmission. Use the dedicated transmission parameters if
	0	0	0	1	2.4	you need to change this for specific receivers.
	0	0	1	0	4.8	If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled
	0	0	1	1	7.2	manually.
	0	1	0	0	9.6	Cross reference
	0	1	0	1	12.0	V.8 protocol on/off - G3 switch 03, bit 2
	0	1	1	0	14.4	-
	0	1	1	1	16.8	
	1	0	0	0	19.2	
	1	0	0	1	21.6	_
	1	0	1	0	24.0	_
	1	0	1	1	26.4	
	1	1	0	0	28.8	
	1	1	0	1	31.2	_
	Other se	ttings - N	ot used			
4-5	Initial mo	odem type	e for 9.6	k or 7.2 k	bps.	These bits set the initial modem type for 9.6 and
	Bit 5	Bit 4		Setting		7.2 kbps, if the initial modem rate is set at these speeds.
	0	0		V.29		
	0	1		V.17		
	1	0		V.34		
	1	1		Not use	d	1

6-7	Not used	Do not change the settings.

Γ

			G3	-2 Switch	lo. 1-106-007)	
No			Function		Comments	
0-3	Initial RX	modem re	ate(kbps)			These bits set the initial starting modem rate
	Bit 3	Bit 2	Bit 1	Bit O	kbps	for reception. Use a lower setting if high speeds pose
	0	0	0	1	2.4	problems during reception.
	0	0	1	0	4.8	If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled
	0	0	1	1	7.2	manually.
	0	1	0	0	9.6	Cross reference
	0	1	0	1	12.0	V.8 protocol on/off - G3 switch 03, bit2
	0	1	1	0	14.4	
	0	1	1	1	16.8	
	1	0	0	0	19.2	
	1	0	0	1	21.6	
	1	0	1	0	24.0	
	1	0	1	1	26.4	
	1	1	0	0	28.8	
	1	1	0	1	31.2	
	Other se	ttings - No	ot used			

4-7 Modem types available for reception

The setting of these bits is used to inform the transmitting terminal of the available modem type for the machine in receive mode.

If V.34 is not selected, V.8 protocol must be disabled manually.

Cross reference

V.8 protocol on/off - G3 switch 03, bit 2

Bit 7	Bit 6	Bit 5	Bit 4	Types
0	0	0	1	V.27ter
0	0	1	0	V.27ter
0	0	1	1	V.27ter
0	1	0	0	V.27ter
0	1	0	1	V.27ter
	Natural			

Other settings - Not used

		G3-2	Switch 07 (SP	No. 1-106-008)
No		Function		Comments
0-1	PSTN cable e (TX mode: Inte			Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone
	Bit 1	Bit O	Setting	exchange.
	0 0 None	Use the dedicated transmission parameters for specific receivers.		
	0	0 1 Low	Low	Also, try using the cable equalizer if one or
	1	0	Medium	more of the following symptoms occurs.
	1	1 1 High	Communication error Modem rate fallback occurs frequently.	
		↓ Note		
				• This setting is not effective in V.34 communications.

2-3	PSTN cable ed (RX mode: Inte			Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone
	Bit 3	Bit 2	Setting	exchange.
	0	0	None	Also, try using the cable equalizer if one or more of the following symptoms occurs.
	0	1	Low	Communication error with error codes such as
	1 0 Medium 1 1 High		Medium	0-20, 0-23, etc.
			High	Modem rate fallback occurs frequently.
				• This setting is not effective in V.34 communications.
4	PSTN cable ea	qualizer		Keep this bit at "1".
	(V.8/V.17 RX	mode: Externa	I)	
	0: Disabled			
	1: Enabled			
5-7	Not used			Do not change the settings.

G3-2 Switch 08 - Not used (do not change the settings)	
G3-2 Switch 09 - Not used (do not change the settings)	

	G3-2 Switch 0A (SP No. 1-106-011)						
No		Fur	nction	Comments			
0-1		allowable ta reception	carrier drop during n	These bits set the acceptable modem carrier drop time.			
	Bit 1	Bit O	Value (ms)	Try a longer setting if error code 0-22 is frequent.			
	0	0	200				
	0	1	400				
	1	0	800				
	1	1	Not used				
2-3	Not used			Do not change the settings			

-	i	
4	Maximum allowable frame interval during image data reception. 0: 5 s 1: 13 s	This bit set the maximum interval between EOL (end-of-line) signals and the maximum interval between ECM frames from the other end. Try using a longer setting if error code 0-21 is frequent.
5	Not used	Do not change the settings.
6	Reconstruction time for the first line in receive mode 0: 6 s 1: 12 s	When the sending terminal is controlled by a computer, there may be a delay in receiving page data after the local machine accepts set- up data and sends CFR. This is outside the T.30 recommendation. But, if this delay occurs, set this bit to 1 to give the sending machine more time to send data. Refer to error code 0-20. ITU-T T.30 recommendation: The first line should come within 5 s of CFR.
7	Not used	Do not change the settings.

G3-2 Switch OB- Not used (do not change the settings)
G3-2 Switch OC- Not used (do not change the settings)
G3-2 Switch OE- Not used (do not change the settings)
G3-2 Switch OF- Not used (do not change the settings)

G4 Internal Switches

The G4 internal switches (SW00 to 1F) are displayed but do not change these settings.

G4 Parameter Switches

The G4 parameter switches (SW00 to 0F) are displayed but do not change these settings.

Bit Switches – 6

C Important

 Do not adjust a bit switch or use a setting that is described as "Not used", as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

Default settings for bit switches are not listed in this manual. Refer to the System Parameter List printed by the machine.

IP Fax Switches

	IP Fax Switch 00 (SP No. 1-111-001)				
No.	Function	Comments			
0	Not used	Do not change this setting.			
1	IP Fax Transport 0: TCP, 1: UDP	Selects TCP or UDP protocol for IP-Fax			
2	IP Fax single port selection 0: OFF, 1: ON (enable)	Selects single data port.			
3	IP Fax double ports (single data port) selection 0: OFF, 1: ON (enable)	Selects whether IP-Fax uses a double port.			
4	IP Fax Gatekeeper 0: OFF, 1: ON (enable)	Enables/disables the gatekeeper for IP-Fax.			
5	IP Fax T30 bit signal reverse O: LSB first, 1: MSB first	Reverses the T30 bit signal.			
6	IP Fax max bit rate setting O: Not affected, 1: Affected	When "0" is selected, the max bit rate does not affect the value of the DIS/DCS. When "1" is selected, the max bit rate affects the value of the DIS/DCS.			

	IP Fax received telephone number confirmation	When "0" is selected, fax data is received without checking the telephone number.
7	0: No confirmation, 1: Confirmation	When "1" is selected, fax data is received only when confirming that the telephone number from the sender matches the registered telephone number in this machine. If this confirmation fails, the line is disconnected.

IP Fax Switch 01 (SP No. 1-111-002)						
No.	Function			Comments		
	IP Fax delay l	evel setting				
	Selects the ac	ceptable delay	level.			
	Level 0 is the	highest quality				
	Default is "00	00" (level 0).				
0-3	Bit 3	Bit 2	Bit 1	Bit O		
	0	0	0	0	Level O	
	0	0	0	1	Level 1	
	0	0	1	0	Level 2	
	0	0	1	1	Level 3	
	IP Fax preamble wait time setting			Selects the preamble wait time.		
				[00 to 0f]		
4-7				There are 16 values in this 4-bit binary switch combination.		
				Waiting time: set value level x 100 ms		
				Max: Of (1500 ms) Min: 00 (No wait time)		
					0" (00H).	

IP Fax Switch 02 (SP No. 1-111-003)					
No.	No. Function Comments				

0	IP Fax bit signal reverse setting O: Maker code setting 1: Internal bit switch setting	When "0" is selected, the bit signal reverse method is decided by the maker code. When "1" is selected, the bit signal reverse method is decided by the internal bit switch. When communicating between IP Fax devices, LSB first is selected.)
1	IP Fax transmission speed setting O: Modem speed 1: No limitation	Selects the transmit speed for IP Fax communication.
2	SIP transport setting O: TCP 1: UDP	This bit switch sets the transport that has priority for receiving IP Fax data. This function is activated only when the sender has both TCP and UDP.
3	CCM connection 0: No CCM connection 1: CCM connection	When "1" is selected, only the connection call message with H.323 or no tunneled H.245 is transmitted via CCM.
4	Message reception selection from non- registered SIP server O: Answer 1: Not answer	 0: This answers the INVITE message from the SIP server not registered for the machine. 1: This does not receive the INVITE message from the SIP server not registered for the machine and send a refusal message.
5	ECM communication setting 0: No limit for image compression 1: Limit for image compression	 0: This does not limit the type of the image compression with ECM communication. 1: When the other end machine is Ciscco, this permits the image compression other than JBIG or MMR with ECM communication.
6-7	Not used	Do not change these settings.

IP Fax Switch 03 (SP No. 1-111-004)				
No.	Comments			
0	Effective field limitation for G3 standard function information 0: OFF, 1: 4byte (DIS)	Limits the effective field for standard G3 function information.		

1	Switching between G3 standard and G3 non standard O: Enable switching 1: G3 standard only	Enables/disables switching between G3 standard and G3 non-standard.
2	Not used	Do not change this setting.
3	ECM frame size selection at transmitting 0: 256byte, 1: 64byte	Selects the ECM frame size for sending.
4	DIS detection times for echo prevention 0: 1 time, 1: 2 times	Sets the number of times for DIS to detect echoes.
5	CTC transmission selection O: PPRx1 1: PPRx4	When "O" is selected, the transmission condition is decided by error frame numbers. When "1" is selected, the transmission condition is based on the ITU-T method.
6	Shift down setting at receiving negative code 0: OFF, 1: ON	Selects whether to shift down when negative codes are received.
7	Not used	Do not change this setting.

IP Fax Switch 04 (SP No. 1-1111-005)				
No.	No. Function Comments			
0-3	-3 TCF error threshold Sets the TCF error threshold level. [00 to 0f] The default is "1111" (0fH).			
4-7	4-7 Not used Do not change these settings.			

IP Fax Switch 05 (SP No. 1-111-006)			
No.	Function	Comments	

	Modem bit rate setting for transmission (kbps)			ansmissior	Sets the modem bit rate for transmission.	
	Bit 3	Bit 2	Bit 1	Bit O	kbps	The default is "0110" (14.4K bps).
	0	0	0	1	2.4	
0.2	0	0	1	1	4.8	
0-3	0	0	1	1	7.2	
	0	1	0	0	9.6	
	0	1	0	1	12.0	
	0	1	1	0	14.4	
	Modem setting for transmission			on	Sets the modem type for transmission.	
	Bit 5	5	Bit 4	1	ypes	The default is "00" (V29).
4-5	0		0		V29	
4-5	0		1		V17	
	1		0	N	ot used	
	1		1	N	ot used	
6-7	Not used				Do not change these settings.	

IP Fax Switch 06 (SP No. 1-111-007)					
No.	No. Function Comments				
0-3	0-3 Modem bit rate setting for reception Sets the modem bit rate for reception. The default is "0110" (14.4K bps).				

	Modem setting for reception					
	Sets the modem type for reception. The default is "0100" (V27ter, V29, V17).					
	Bit 7	Bit 6	Bit 5	Bit 4	Types	
	0	0	0	1	V.27ter	
4-7	0	0	1	0	V.27ter, V.29	
	0	0	1	1	V.27ter, V.29, V.33	
	0	1	0	0	V.27ter, V.29, V.17/V.33	
	Other settings - Not used					

	IP Fax Switch 07 (SP No. 1-111-008)				
No.	Function	Comments			
0	TSI information 0: Not added, 1: Added	Adds or does not add TSI information to NSS(S).			
1	DCN transmission setting at T1 timeout 0: Not transmitted 1: Transmitted	Transmits or does not transmit DCN at T1 timeout.			
2	Not used	Do not change this setting.			
3	Hang up setting at DIS reception disabled	Sets whether the machine disconnects after DIS reception.			
	0: No hang up 1: Hang up after transmitting DCN				
4	Number of times for training 0: 1 time, 1: 2 times	Selects the number of times training is done at the same bit rate.			
5	Space CSI transmission setting at no CSI registration 0: Not transmitted 1: Transmitted	When "0" is selected, frame data is enabled. When "1" is selected, the transmitted data is all spaces.			
6-7	Not used	Do not change these settings.			

	IP Fax Switch 08 (SP No. 1-111-009)					
No.	Function			Comments		
0-1	T1 timer adjustment			Adjusts the T1 timer.		
	Bit 1	Bit O		The default is "00" (35 seconds).		
	0	0	35 s			
	0	1	40 s			
	1	0	50 s			
	1	1	60 s			
2-3	T4 timer adjustment			Adjust the T4 timer.		
-	Bit 3	Bit 2		The default is "00" (3 seconds).		
	0	0	3 s			
	0	1	3.5 s			
	1	0	4 s			
	1	1	5 s			
4-5	T0 timer adju	stment		Adjusts the fail safe timer. This timer sets the		
	Bit 5	Bit 4		 interval between "setup" data transmission and T. 38 phase decision. If your destination return is 		
	0	0	75 s	late on the network or G3 fax return is late, adjust the longer interval timer.		
	0	1	120 s	The default is "00" (75 seconds).		
	1	0	180 s			
	1	1	240 s			
6-7	Not used	1	1	Do not change these settings.		

IP Fax Switch 09 (SP No. 1-111-010)					
No.	No. Function Comments				

0				Selects the connection type (IPV4 or IPV6) to connect to the SIP server.
1	Network I/F setting for Fax communication 0: Same setting as SIP server connection 1: Automatic setting			 0: The I/F setting for fax communication follows the setting for SIP server connection. 1: The negotiation between the SIP server and the device decides whether IPv4 or IPv6 is used for the I/F setting for fax communication.
2	Record-route setting O: Disable 1: Enable			0: Disables the record-route function of the SIP server. 1: Enables the record-route function of the SIP server.
3-4	re-INVITE transmission delay timer setting			This changes the interval for transmit re-INVITE after receiving the ACK message transmitted by T 38 device.
	Bit 4	Bit 3		So device.
	0	0	No delay	
	0	1	l sec	
	1	0	2 sec	
	1	1	3 sec	
5	SIP-IPFAX: Adding vender information selection 0: Declare T38VendorInfo=RICOH 1: Not declare T38VendorInfo=RICOH		=ricoh	0: Use this setting normally. 1: This setting is used only when a customer wants to connect the machine with SIP server + VOIP- GW provided by AVAYA Inc.
6-7	Not used.			Do not change these settings.

IP Fax Switch OA - Not used (do not change the settings)
IP Fax Switch OB - Not used (do not change the settings)
IP Fax Switch OC - Not used (do not change the settings)
IP Fax Switch OD - Not used (do not change the settings)

IP Fax Switch OE (SP No. 1-111-013)

No.	Function	Comments
0-1	SIP: IP-FAX port mode (UDP) 00: 3 port mode 01: 2 port mode 10: 1 port mode	Switch the port mode for IP-FAX (T38 transport: UDP) at SIP call control.
2-3	SIP: IP-FAX port mode (TCP) 00: 3 port mode 01: 2 port mode 10: 1 port mode	Switch the port mode for IP-FAX (T38 transport: TCP) at SIP call control.
4-7	Not used.	Do not change these settings.

NCU Parameters

NCU Parameters

The following tables give the RAM addresses and the parameter calculation units that the machine uses for ringing signal detection and automatic dialing. The factory settings for each country are also given. Most of these must be changed by RAM read/write (SP2-102), but some can be changed using NCU Parameter programming (SP2-103, 104 and 105); if SP2-103, 104 and 105 can be used, this will be indicated in the Remarks column. The RAM is programmed in hex code unless (BCD) is included in the Unit column.

Vote

- The following addresses describe settings for the standard NCU.
- Change the fourth digit from "5" to "6" (e.g. 680500 to 680600) for the settings for the first optional G3 interface unit and from "5" to "7" (e.g. 680700) for the settings for the second optional G3 interface unit.

Address	Function						
680500	Country/Area code for NCU parameters						
	Use the Hex value to program the country/area code directly into this address, or use the decimal value to program it using SP2-103-001						
	Country /Area	Decimal	Hex	Country /Area	Decimal	Hex	
	France	00	00	Asia	18	12	
	Germany	01	01	Japan	19	13	
	UK	02	02	Hong Kong	20	14	
	Italy	03	03	South Africa	21	15	
	Austria	04	04	Australia	22	16	
	Belgium	05	05	New Zealand	26	17	
	Denmark	06	06	Singapore	24	18	
	Finland	07	07	Malaysia	25	19	
	Ireland	08	08	China	26	1A	
	Norway	09	09	Taiwan	27	1B	
	Sweden	10	0A	Korea	28	1C	
	Switzerland	11	OB	Brazil	29	1D	
	Portugal	12	0C	Turkey	32	20	
	Holland	13	OD	Greece	33	21	
	Spain	14	OE	Hungary	34	22	
	Israel	15	OF	Czech	35	23	
	USA	17	11	Poland	36	24	

Address	Function	Unit	Remarks
680501	Line current detection time	20 ms	Line current detection is
680502	Line current wait time		disabled. Line current is not detected if
680503	Line current drop detect time		680501 contains FF.
680504	PSTN dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is
680505	PSTN dial tone frequency upper limit (low byte)	-	disabled.
680506	PSTN dial tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is
680507	PSTN dial tone frequency lower limit (low byte)	-	disabled.
680508	PSTN dial tone detection time	20 ms	If 680508 contains FF (H), the machine pauses for the pause time (address 68050D / 68050E). Italy: See Note 2.
680509	PSTN dial tone reset time (LOW)		
68050A	PSTN dial tone reset time (HIGH)		
68050B	PSTN dial tone continuous tone time		
68050C	PSTN dial tone permissible drop time		
68050D	PSTN wait interval (LOW)		-
68050E	PSTN wait interval (HIGH)		
68050F	PSTN ring-back tone detection time	20 ms	Detection is disabled if this contains FF.
680510	PSTN ring-back tone off detection time	20 ms	-
680511	PSTN detection time for silent period after ring-back tone detected (LOW)	20 ms	-
680512	PSTN detection time for silent period after ring-back tone detected (HIGH)	20 ms	-

Address	Function	Unit	Remarks	
680513	PSTN busy tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is disabled.	
680514	PSTN busy tone frequency upper limit (low byte)			
680515	PSTN busy tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is	
680516	PSTN busy tone frequency lower limit (low byte)		disabled.	
680517	PABX dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is	
680518	PABX dial tone frequency upper limit (low byte)		disabled.	
680519	680519 PABX dial tone frequency lower limit (high byte)		If both addresses contain FF (H), tone detection is	
68051A	PABX dial tone frequency lower limit (low byte)		disabled.	
68051B	PABX dial tone detection time	20 ms	If 68051B contains FF, the	
68051C	PABX dial tone reset time (LOW)		machine pauses for the pause time (680520 /	
68051D	PABX dial tone reset time (HIGH)		680521).	
68051E	PABX dial tone continuous tone time	_		
68051F	PABX dial tone permissible drop time	_		
680520	PABX wait interval (LOW)	-	-	
680521	PABX wait interval (HIGH)			
680522	PABX ringback tone detection time	20 ms	If both addresses contain FF	
680523	PABX ringback tone off detection time	20 ms	(H), tone detection is disabled.	

Address	Function	Unit	Remarks	
680524	PABX detection time for silent period after ringback tone detected (LOW)	20 ms	If both addresses contain FF (H), tone detection is	
680525	PABX detection time for silent period after ringback tone detected (HIGH)	20 ms	disabled.	
680526	PABX busy tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is	
680527	PABX busy tone frequency upper limit (low byte)		disabled.	
680528	680528 PABX busy tone frequency lower limit (high byte)		If both addresses contain FF (H), tone detection is	
680529	PABX busy tone frequency lower limit (low byte)		disabled.	
68052A	Busy tone ON time: range 1	20 ms	-	
68052B	Busy tone OFF time: range 1			
68052C	Busy tone ON time: range 2			
68052D	Busy tone OFF time: range 2	-		
68052E	Busy tone ON time: range 3	-		
68052F	052F Busy tone OFF time: range 3			
680530	Busy tone ON time: range 4			
680531	Busy tone OFF time: range 4			
680532	Busy tone continuous tone detection time			

Address	Function	Unit	Remarks		
680533	Busy tone signal state time tolerance for all ranges, and number of cycles required for detection (a setting of 4 cycles means that ON-OFF-ON or OFF-ON-OFF must be detected twice).				
	Tolerance (±)				
	Bit 1: 0, Bit 0: 0 = 75% Bits 2 and 3 must always be kept at 0.				
	Bit 1: 0, Bit 0: 0 = 50% Bits 2 and 3 must	t always be kept	at 0.		
	Bit 1: 0, Bit 0: 0 = 25%				
	Bit 1: 0, Bit 0: 0 = 12.5%				
	Bits 7, 6, 5, 4 - number of cycles require	d for cadence de	etection		
680534	International dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is disabled.		
680535	International dial tone frequency upper limit (low byte)				
680536	International dial tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is disabled.		
680537	International dial tone frequency lower limit (low byte)				
680538	International dial tone detection time	20 ms	If 680538 contains FF, the machine pauses for the pause time (68053D / 68053E). Belgium: See Note 2.		
680539	International dial tone reset time (LOW)				
68053A	International dial tone reset time (HIGH)				
68053B	International dial tone continuous tone time				
68053C	International dial tone permissible drop time				
68053D	International dial wait interval (LOW)		-		
68053E	International dial wait interval (HIGH)				

Address	Function	Unit	Remarks
68053F	Country dial tone upper frequency limit (HIGH)	Hz (BCD)	If both addresses contain FF (H), tone detection is disabled. If both addresses contain FF (H), tone detection is
680540	Country dial tone upper frequency limit (LOW)		
680541	Country dial tone lower frequency limit (HIGH)		
680542	Country dial tone lower frequency limit (LOW)		disabled.
680543	Country dial tone detection time	20 ms	If 680543 contains FF, the
680544	Country dial tone reset time (LOW)		machine pauses for the pause time (680548 /
680545	Country dial tone reset time (HIGH)		680549).
680546	Country dial tone continuous tone time	-	-
680547	Country dial tone permissible drop time	20 ms	-
680548	Country dial wait interval (LOW)		
680549	Country dial wait interval (HIGH)	~	
68054A	Time between opening or closing the DO relay and opening the OHDI relay	1 ms	See Notes 3, 6 and 8. SP2-103-012 (parameter 11).
68054B	Break time for pulse dialing	l ms	See Note 3. SP2-103-013 (parameter 12).
68054C	Make time for pulse dialing	l ms	See Note 3. SP2-103-014 (parameter 13).
68054D	Time between final OHDI relay closure and DO relay opening or closing	1 ms	See Notes 3, 6 and 8. SP2-103-015 (parameter 14). This parameter is only valid in Europe.

Address	Function	Unit	Remarks
68054E	Minimum pause between dialed digits (pulse dial mode)	20 ms	See Note 3 and 8. SP2-103-016 (parameter 15).
68054F	Time waited when a pause is entered at the operation panel		SP2-103-017 (parameter 16). See Note 3.
680550	DTMF tone on time	l ms	SP2-103-018 (parameter 17).
680551	DTMF tone off time		SP2-103-019 (parameter 18).
680552	Tone attenuation level of DTMF signals while dialing	-N x 0.5 –3.5 dBm	SP2-103-020 (parameter 19). See Note 5.
680553	Tone attenuation value difference between high frequency tone and low frequency tone in DTMF signals	-dBm x 0.5	SP2-103-021 (parameter 20). The setting must be less than –5dBm, and should not exceed the setting at 680552h above. See Note 5.
680554	PSTN: DTMF tone attenuation level after dialing	-N x 0.5 –3.5 dBm	SP2-103-022 (parameter 21). See Note 5.
680555	ISDN: DTMF tone attenuation level after dialing	-dBm x 0.5	See Note 5
680556	Not used	-	Do not change the settings.
680557	Time between 68054Dh (NCU parameter 14) and 68054Eh (NCU parameter 15)	1 ms	This parameter takes effect when the country code is set to France.
680558	Not used	-	Do not change the setting.
680559	Grounding time (ground start mode)	20 ms	The Gs relay is closed for this interval.
68055A	Break time (flash start mode)	1 ms	The OHDI relay is open for this interval.

Address	Function	Unit	Remarks
68055B	International dial access code (High)	BCD	For a code of 100:
68055C	International dial access code (Low)		68055B - F1
			68055C - 00
68055D	PSTN access pause time	20 ms	This time is waited for each pause input after the PSTN access code. If this address contains FF [H], the pause time stored in address 68054F is used.
			Do not set a number more than 7 in the UK.
68055E	Progress tone detection level, and cadence detection enable flags	Bit 7: 0, Bit 6: 0, Bit 5: 0 = -25.0 dBm	
		Bit 7: 0, Bit 6: 0, Bit 5: 1 = -35.0 dBm	
		Bit 7: 0, Bit 6: 1, Bit 5: 0 = -30.0 dBm	
		Bit 7: 1, Bit 6: 0, Bit 5: 0 = -40.0 dBm	
		Bit 7: 1, Bit 6: 1, Bit 5: 0 = -49.0 dBm	
		Bits 2, 0 - See Note 2.	
68055F To 680564	Not used	-	Do not change the settings.
680565	Long distance call prefix (HIGH)	BCD	For a code of 0:
680566	Long distance call prefix (LOW)	BCD	680565 – FF 680566 - FF
680567	Not used	-	Do not change the settings.
to			
680571			

Address	Function	Unit	Remarks
680572	Acceptable ringing signal frequency: range 1, upper limit	1000/ N (Hz).	SP2-103-003 (parameter 02).
680573	Acceptable ringing signal frequency: range 1, lower limit		SP2-103-004 (parameter 03).
680574	Acceptable ringing signal frequency: range 2, upper limit		SP2-103-005 (parameter 04).
680575	Acceptable ringing signal frequency: range 2, lower limit		SP2-103-006 (parameter 05).
680576	Number of rings until a call is detected	1	SP2-103-007 (parameter 06).
			The setting must not be zero.
680577	Minimum required length of the first ring	20 ms	See Note 4. SP2-103-008 (parameter 07).
680578	Minimum required length of the second and subsequent rings	20 ms	SP2-103-009 (parameter 08).
680579	Ringing signal detection reset time (LOW)	20 ms	SP2-103-010 (parameter 09).
68057A	Ringing signal detection reset time (HIGH)		SP2-103-011 (parameter 10).
68057B to 680580	Not used	-	Do not change the settings.
680581	Interval between dialing the last digit and switching the Oh relay over to the external telephone when dialing from the operation panel in handset mode.	20 ms	Factory setting: 500 ms

Address	Function	Unit	Remarks
680582	Bits 0 and 1 - Handset off-hook detectio Bit 1:0, Bit 0: 0 = 200 ms Bit 1:0, Bit 0: 1 = 800 ms Other Not used Bits 2 and 3 - Handset on-hook detectio Bit 3: 0, Bit 2: 0 = 200 ms Bit 3: 0, Bit 2: 1 = 800 ms Other Not used Bits 4 to 7 - Not used		-
680583 To 6805A0	Not used	-	Do not change the settings.
6805A1	Acceptable CED detection frequency upper limit (high byte)	BCD (Hz)	If both addresses contain FF (H), tone detection is
6805A2	Acceptable CED detection frequency upper limit (low byte)		disabled.
6805A3	Acceptable CED detection frequency lower limit (high byte)	BCD (Hz)	If both addresses contain FF (H), tone detection is disabled.
6805A4	Acceptable CED detection frequency lower limit (low byte)		
6805A5	CED detection time	20 ms ± 20 ms	Factory setting: 200 ms
6805A6	Acceptable CNG detection frequency upper limit (high byte)	BCD (Hz)	If both addresses contain FF (H), tone detection is disabled.
6805A7	Acceptable CNG detection frequency upper limit (low byte)		
6805A8	Acceptable CNG detection frequency lower limit (high byte)	BCD (Hz)	If both addresses contain FF (H), tone detection is
6805A9	Acceptable CNG detection frequency lower limit (low byte)		disabled.
6805AA	Not used	-	Do not change the setting.

Address	Function	Unit	Remarks
6805AB	CNG on time	20 ms	Factory setting: 500 ms
6805AC	CNG off time	20 ms	Factory setting: 3000 ms
6805AD	Number of CNG cycles required for detection	-	The data is coded in the same way as address 680533.
6805AE	Not used	-	Do not change the settings.
6805AF	Acceptable AI short protocol tone (800Hz) detection frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF (H), tone detection is disabled.
6805B0	Acceptable AI short protocol tone (800Hz) detection frequency upper limit (low byte)	-	
6805B1	Acceptable AI short protocol tone (800Hz) detection frequency lower limit (high byte)	Hz(BCD)	If both addresses contain FF (H), tone detection is disabled.
6805B2	Acceptable AI short protocol tone (800Hz) detection frequency lower limit (low byte)	-	
6805B3	Detection time for 800 Hz Al short protocol tone	20 ms	Factory setting: 360 ms
6805B4	PSTN: TX level from the modem	-N – 3 dBm	SP2-103-002 (parameter 01).
6805B5	PSTN: 1100 Hz tone transmission level	- N 6805B4 - 0.5N 6805B5 –3.5 (dB) See Note 7.	
6805B6	PSTN: 2100 Hz tone transmission level	- N6805B4 - 0.5N 6805B6 –3 (dB) See Note 7.	
6805B7	PABX: TX level from the modem	- dBm	
6805B8	PABX: 1100 Hz tone transmission level	- N 6805B7 - 0	D.5N 6805B8 (dB)
6805B9	PABX: 2100 Hz tone transmission level	- N 6805B7 - 0	D.5N 6805B9 (dB)

Address	Function	Unit	Remarks	
6805BD	Modem turn-on level (incoming signal detection level)	-37-0.5N (dBm)		
6805BE to 6805C6	Not used	-	Do not change the settings.	
6805C7	Bits 0 to 3 – Not used			
	Bit 4 = V.34 protocol dump 0: Simple, 1: Detailed (default)			
	Bits 5 to 7 – Not used.			
6805C8 to 6805D9	Not used	-	Do not change the settings.	
6805DA	T.30 T1 timer	1 s		
6805E0 bit	Maximum wait time for post message	0: 12 s	1: Maximum wait time for	
3		1: 30 s	post message (EOP/EOM/ MPS) can be changed to 30 s.	
			Change this bit to "1" if communication errors occur frequently during V.17 reception.	
6805E3	Bits 0 and 1 – DCV (TIP/RING) Voltage	1		
	Bit 1:0, Bit 0: 0 = 3.1 V			
	Bit 1:0, Bit 0: 1 = 3.2 V			
	Bit 1:1, Bit 0: 0 = 3.35 V			
	Bit 1:1, Bit 0: 1 = 3.5 V			
	Bits 2 and 3 – MINI (minimum loop elec	tric current)		
	Bit 2:0, Bit 3: 0 = 10 mA			
	Bit 2:0, Bit 2: 1 = 12 mA			
	Bit 2:1, Bit 3:0 = 14 mA			
	Bit 2:1, Bit 3: 1 = 16 mA			
	Bits 6 and 7 – ACIM (AC impedance)			
	Bit 7:0, Bit 6: 0 Bit 5:0, Bit 4: 0= 600			
	Bit 7:0, Bit 6: 0 Bit 5:1, Bit 4: 0= TBR21			

Address	Function	Unit	Remarks
6805E4	Bit 0 – OHS (on hook speed)		
	0: OHS=0		
	1: OHS=1		
	Bit 1 – SQ (spark quench)		
	0: SQ=00		
	1: SQ=11		
	Bit 2 – RZ (call signal Impedance)		
	O: RZ=O (high)		
	1: RZ=1 (low)		
	Bit 3 – RT (call signal detection level)		
	O: RT=O (low)		
	1: RT=1 (high)		
	Bit 4 – ILIM (DC limitation)		
	O: ILIM=O (CTR 21)		
	1: ILIM=1 (other than CTR 21)		
	Bit 5 –FILTER		
	0: FILTER=0 (around 5Hz)		
	1: FILTER=1 (around 200Hz)		
	Bits 6 to 7 – Calibration in off hook state		
	Bit 6:0, Bit 7: 0 = off hook to ACAL:128	ms, off hook to N	ICAL: 1000 ms
	Bit 6:1, Bit 7:0 = off hook to ACAL:128	ms, off hook to N	ICAL: 500 ms
	Bit 6:0, Bit 7: 1 = off hook to ACAL:128	ms (no MCAL)	
	Bit 6:1, Bit 7: 1 = off hook to ACAL:8 ms	(no MCAL)	
6805E5	Bits 0 to 6 – Not used		
	Bits 7 – Energy saving for DSP, COMBLE	K, SiDAA	
	0: Does not save energy		
	1: Saves energy		

NOTES

- 1. If a setting is not required, store FF in the address.
- 2. Italy and Belgium only

RAM address 68055E: the lower four bits have the following meaning.

Bit 2 - 1: International dial tone cadence detection enabled (Belgium)

Bit 1 - Not used

Bit 0 - 1: PSTN dial tone cadence detection enabled (Italy)

If bit 0 or bit 2 is set to 1, the functions of the following RAM addresses are changed.

680508 (if bit 0 = 1) or 680538 (if bit 2 = 1): tolerance for on or off state duration (%), and number of cycles required for detection, coded as in address 680533.

68050B (if bit 0 = 1) or 68053B (if bit 2 = 1): on time, hex code (unit = 20 ms)

68050C (if bit 0 = 1) or 68053C (if bit 2 = 1): off time, hex code (unit = 20 ms)

- 3. Pulse dial parameters (addresses 68054A to 68054F) are the values for 10 pps. If 20 pps is used, the machine automatically compensates.
- 4. The first ring may not be detected until 1 to 2.5 wavelengths after the time specified by this parameter.
- 5. The calculated level must be between 0 and 10.

The attenuation levels calculated from RAM data are:

High frequency tone:

- 0.5 x N₆₈₀₅₅₂/₆₈₀₅₅₄-3.5 dBm
- - 0.5 x N₆₈₀₅₅₅ dBm

Low frequency tone:

- 0.5 x (N₆₈₀₅₅₂/₆₈₀₅₅₄ + N₆₈₀₅₅₃) 3.5 dBm
- 0.5 x (N₆₈₀₅₅₅ + N₆₈₀₅₅₃) dBm

• Note

- N₆₈₀₅₅₂, for example, means the value stored in address 680552(H)
- 6. 68054A: Europe Between Ds opening and Di opening, France Between Ds closing and Di opening

68054D: Europe - Between Ds closing and Di closing, France - Between Ds opening and Di closing

- Tone signals which frequency is lower than 1500Hz (e.g., 800Hz tone for AI short protocol) refer to the setting at 6805B5h. Tones which frequency is higher than 1500Hz refer to the setting at 6805B6h.
- 8. 68054A, 68054D, 68054E: The actual inter-digit pause (pulse dial mode) is the sum of the period specified by the RAM addresses 68054A, 68054D, and 68054E.

Dedicated Transmission Parameters

There are two sets of transmission parameters: Fax and E-mail

Each Quick Dial Key and Speed Dial Code has eight bytes of programmable parameters allocated to it. If transmissions to a particular machine often experience problems, store that terminal's fax number as a Quick Dial or Speed Dial, and adjust the parameters allocated to that number.

The programming procedure will be explained first. Then, the eight bytes will be described.

Programming Procedure

- 1. Set the bit 0 of System Bit Switch 00 to 1.
- Enter Address Book Management mode ([User Tools]> System Settings> Key Operator> Address Book Management).
- 3. Select the address book that you want to program.
- For the fax parameter, select "Fax Dest.", for the E-mail parameter, select "E-mail", then press "Start". Make sure that the LED of the Start button lights green.
- 5. The settings for the switch 00 are now displayed. Press the bit number that you wish to change.
- 6. To scroll through the parameter switches, either:
- Select the next switch: press "Next" or Select the previous switch: "Prev." until the correct switch is displayed. Then go back to step 6.
- 8. After the setting is changed, press "OK".
- 9. After finishing, reset bit 0 of System Bit Switch 00 to 0.

Parameters

Fax Parameters

The initial settings of the following fax parameters are all FF (H) - all the parameters are disabled.

Switch 00

FUNCTION AND COMMENTS

ITU-TT1 time (for PSTN G3 mode)

If the connection time to a particular terminal is longer than the NCU parameter setting, adjust this byte. The T1 time is the value stored in this byte (in hex code), multiplied by 1 second.

Range:

0 to 120 s (00h to 78h)

FFh - The local NCU parameter factory setting is used.

Do not program a value between 79h and FEh.

Switch 01

No			FU	NCTIO	N	COMMENTS	
0-4	TX lev	el				If communication with a particular remote	
	Bit4	Bit3	Bit2	Bit 1	BitO		terminal often contains errors, the signal level may be inappropriate. Adjust the TX
	0	0	0	0	0	0	level for communications with that terminal until the results are better.
	0	0	0	0	1	-1	If the setting is "Disabled", the NCU
	0	0	0	1	0	-2	parameter 01 setting is used.
	0	0	0	1	1	-3	Note Do not use settings other than listed
	0	0	1	0	0	-4	on the left.
	\checkmark	Ŷ	Ŷ	↓	Ŷ	Ŷ	
	0	1	1	1	1	-15	
	1	1	1	1	1	Disabled	

5-7	Cable equalizer	Use a higher setting if there is signal loss
	Bit 7: 0, Bit 6: 0, Bit 5: 0 = None	at higher frequencies because of the length of wire between the modem and
	Bit 7: 0, Bit 6: 0, Bit 5: 1 = Low	the telephone exchange when calling the
	Bit 7: 0, Bit 6: 1, Bit 5: 0 = Medium	number stored in this Quick/Speed Dial.
	Bit 7: 0, Bit 6: 1, Bit 5: 1 = High	Also, try using the cable equalizer if one
	Bit 7: 1, Bit 6: 1, Bit 5: 1 = Disabled	or more of the following symptoms occurs.
		Communication error with error codes such as 0-20, 0-23, etc.
		Modem rate fallback occurs frequently.
		♦ Note
		 Do not use settings other than listed on the left.
		If the setting is "Disabled", the bit switch setting is used.

Switc	h 02	
No	FUNCTION	COMMENTS

0-3	Initial	TX mod	em rate			If training with a particular remote terminal always
	Bit3	Bit2	Bit 1	BitO	bps	takes too long, the initial modem rate may be too high. Reduce the initial TX modem rate using these
	0	0	0	0	Not used	bits.
	0	0	0	1	2400	For the settings 14.4 or kbps slower, Switch 04 bit 4 must be changed to 0.
	0	0	1	0	4800	♦ Note
	0	0	1	1	7200	• Do not use settings other than listed on the left. If the setting is "Disabled", the bit switch
	0	1	0	0	9600	setting is used.
	0	1	0	1	12000	
	0	1	1	0	14400	
	0	1	1	1	16800	
	1	0	0	0	19200	
	1	0	0	1	21600	
	1	0	1	0	24000	
	1	0	1	1	26400	
	1	1	0	0	28800	
	1	1	0	1	31200	
	1	1	1	0	33600	
	1	1	1	1	Disabled	
	Other	settings	: Not us	ed	· ·	
4-7	Not us	sed				Do not change the settings.

Switch 03			
No	FUNCTION	COMMENTS	

0-1	Inch-mm conversion before TX Bit 1: 0, Bit 0: 0 = Inch-mm conversion available Bit 1: 0, Bit 0: 1 = Inch only Bit 1: 1, Bit 0: 0 = Not used Bit 1: 1, Bit 0: 1 = Disabled	If "inch only" is selected on the machine uses inch-based resolutions for scanning, the printed copy may be slightly distorted at the other end if that machine uses mm-based resolutions. If the setting is "Inch-mm conversion available ", Inch-mm conversion become effective to the special senders. If the setting is "Disabled", the bit switch setting is used.
2-3	DIS/NSF detection method Bit 3: 0, Bit 2: 0 = First DIS or NSF Bit 3: 0, Bit 2: 1 = Second DIS or NSF Bit 3: 1, Bit 2: 0 = Not used Bit 3: 1, Bit 2: 1 = Disabled	(0, 1): Use this setting if echoes on the line are interfering with the set-up protocol at the start of transmission. The machine will then wait for the second DIS or NSF before sending DCS or NSS.If the setting is "Disabled", the bit switch setting is used.
4	V.8 protocol O: Off 1: Disabled	If transmissions to a specific destination always end at a lower modem rate (14,400 bps or lower), disable V.8 protocol so as not to use V.34 protocol. O: V.34 communication will not be possible. If the setting is "Disabled", the bit switch setting is used.
5	Compression modes available in transmit mode 0: MH only 1: Disabled	This bit determines the capabilities that are informed to the other terminal during transmission. If the setting is "Disabled", the bit switch setting is used.
6-7	ECM during transmission Bit 7: 0, Bit 6: 0 = Off Bit 7: 0, Bit 6: 1 = On Bit 7: 1, Bit 6: 0 = Not used Bit 7: 1, Bit 6: 1 = Disabled	 For example, if ECM is switched on but is not wanted when sending to a particular terminal, use the (0, 0) setting. Note V.8/V.34 protocol and JBIG compression are automatically disabled if ECM is disabled. If the setting is "Disabled", the bit switch setting is used.

Switch 04 - Not used (do not change the settings)	
Switch 05 - Not used (do not change the settings)	

Switch 06 - Not used (do not change the settings)
Switch 07 - Not used (do not change the settings)
Switch 08 - Not used (do not change the settings)
Switch 09 - Not used (do not change the settings)

E-mail Parameters

The initial settings of the following e-mail parameters are all "0" (all parameters disabled).

Switch 00			
No	FUNCTION	COMMENTS	
0	MH Compression mode for e-mail attachments 0 : Off 1: On	Switches MH compression on and off for files attached to e- mails for sending.	
1	MR Compression mode for e-mail attachments 0 : Off 1: On	Switches MR compression on and off for files attached to e- mails for sending.	
2	MMR Compression mode for e-mail attachments 0 : Off 1: On	Switches MMR compression on and off for files attached to e-mails for sending.	
3-6	Not used	Do not change these settings.	
7	Designates the bits to reference for compression method of e-mail attachments 0 : Registered (Bit 0 to 6) 1: No registration.	The "0" selection (default) references the settings for Bits 00, 01, 02 above. The "1" selection ignores the selections of Bits 00, 01, 02.	

Switch 01

No	FUNCTION	COMMENTS
0	Original width of e-mail attachment: A4 0 : Off 1: On	Sets the original width of the e-mail attachment as A4.
1	Original width of e-mail attachment: B4 0 : Off 1: On	Sets the original width of the e-mail attachment as B4.
2	Original width of e-mail attachment: A3 0 : Off 1: On	Sets the original width of the e-mail attachment as A3.
3-6	Not used	Do not change these settings.
7	Designates the bits to reference for original size of e-mail attachments 0 : Registered (Bit 0 to 6) 1: No registration.	The "0" selection (default) references the settings for Bits 00, 01, 02 above. The "1" selection ignores the selections of Bits 00, 01, 02.

Switch O	2	
No	FUNCTION	COMMENTS
0	Line resolution of e-mail attachment: 200 x 100 0 : Off 1: On	Sets the line resolution of the e-mail attachment as 200 x100.
1	Line resolution of e-mail attachment: 200 x 200 0 : Off 1: On	Sets the line resolution of the e-mail attachment as 200 x 200.

2	Line resolution of e-mail attachment: 200 x 400 0 : Off 1: On	Sets the line resolution of the e-mail attachment as 200 x 400.
3	Not used	Do not change these settings.
4	Line resolution of e-mail attachment: 400 x 400 0 : Off 1: On	Sets the line resolution of the e-mail attachment as 400 x 400.
5-6	Not used	Do not change these settings.
7	Designates the bits to reference for original size of e-mail attachments 0 : Registered (Bit 0 to 6) 1: No registration.	The "0" selection (default) references the settings for Bits 00, 01, 02, 04 above. The "1" selection ignores the selections of Bits 00, 01, 02, 04.

Switch 03 - Not used (do not change the settings)

Switch 04		
No FUNCTION		COMMENTS
0	Full mode address selection O: Full mode address 1: No full mode (simple mode)	 If the other ends have the addresses, which have the full mode function flag ("0"), this machine determines them as full mode standard machines. This machine attaches the "demand of reception confirmation" to a message when transmitting. This machine updates the reception capability to the address book when receiving.
1-7	Not used	Do not change these settings.

Switch 0	5	
No	FUNCTION	COMMENTS

0	Directr transmission selection to SMTP server 0: ON 1: OFF	Allows or does not allow the direct transmission to SMTP server.
1-7	Not used	Do not change these settings.

Switch 06 - Not used (do not change the settings)	
Switch 07 - Not used (do not change the settings)	
Switch 08 - Not used (do not change the settings)	
Switch 09 - Not used (do not change the settings)	

Service RAM Addresses

Service RAM Addresses

🔁 Important

• Do not change the settings that are marked as "Not used" or "Read only."

680001 to 680004(H) - ROM version (Read only)

680001(H) - Revision number (BCD)

680002(H) - Year (BCD)

680003(H) - Month (BCD)

680004(H) - Day (BCD)

680006 to 680015(H) - Machine's serial number (16 digits - ASCII)

680016(H) - Language code

0: Japanese, 1: UK English, 2: US English, 3: French, 4: German, 5: Spanish, 6: Italian, 7: Dutch, 8: Swedish, 9: Norwegian, 10: Danish, 11: Finnish, 12: Czech, 13: Hungarian, 14: Polish, 15: Portuguese, 16: Russian, 17: Traditional Chinese, 18: Simplified Chinese, 19: Korean

680018(H) - Total program checksum (low)

680019(H) - Total program checksum (high)

680020 to 68003F(H) - System bit switches

680050 to 68005F(H) - Printer bit switches

680060 to 68007F(H) - Communication bit switches

680080 to 68008F(H) - G3 bit switches

680090 to 68009F(H) - G3-2 bit switches: Not used

6800A0 to 6800AF(H) - G3-3 bit switches: Not used

6800D0(H) - User parameter switch 00 (SWUER_00): Not used

6800D1(H) - User parameter switch 01 (SWUSR_01): Not used

6800D2(H) - User parameter switch 02 (SWUSR_02)

Bit O: Forwarding mark printing on forwarded messages O: Disabled, 1: Enabled

Bit 1: Center mark printing on received copies

(This switch is not printed on the user parameter list.)

0: Disabled, 1: Enabled

Bit 2: Reception time printing

(This switch is not printed on the user parameter list.)

Bit 3: TSI print on received messages 0: Disabled, 1: Enabled Bit 4: Checkered mark printing (This switch is not printed on the user parameter list.) 0: Disabled, 1: Enabled Bit 5: Not used Bit 6: Not used Bit 7: Not used 6800D3(H) - User parameter switch 03 (SWUSR_03: Automatic report printout) Bit 0: Transmission result report (memory transmissions) 0: Off, 1: On Bit 1: Not used Bit 2: Memory storage report 0: Off, 1: On Bit 3: Polling reserve report (polling reception) 0: Off, 1: On Bit 4: Polling result report (polling reception) 0: Off, 1: On Bit 5: Transmission result report (immediate transmissions) 0: Off, 1: On Bit 6: Not used Bit 7: Journal 0: Off, 1: On 6800D4(H) - User parameter switch 04 (SWUSR_04: Automatic report printout) Bit 0: Not used Bit 1: Automatic communication failure report and transfer result report output 0: Off, 1: On Bits 2 to 3: Not used Bit 4: Indicates the parties 0: Not indicated, 1: Indicated Bit 5: Include sender's name on reports 0: Off, 1: On Bit 6: Not used Bit 7: Inclusion of a sample image on reports 0: Off, 1: On 6800D5(H) - User parameter switch 05 (SWUSR_05) Bit O: Substitute reception when the base copier is in an SC condition 0: Enabled, 1: Disabled Bits 1 and 2: Condition for substitute RX when the machine cannot print messages (Paper end, toner end, jam, and during night mode)

0: Disabled, 1: Enabled

- Bit 2: 0, Bit 1: 0 = The machine receives all the fax messages.
- Bit 2: 0, Bit 1: 1 = The machine receives the fax messages with RTI or CSI.
- Bit 2: 1, Bit 1: 0 = The machine receives the fax messages with the same ID code.

Bit 2: 1, Bit 1: 1 = The machine does not receive anything. Bit 3: Not used Bit 4: Not used Bit 5: Just size printing 0: Off, 1: On Bit 6: Not used Bit 7: Add paper display when a cassette is empty 0: Off, 1: On 6800D6(H) - User parameter switch 06 (SWUSR_06) Bit O: Bit 1: V8 protocol (G3-1: Super G3) 0: Off, 1: On Bit 2: V8 protocol (G3-2: Super G3) 0: Off, 1: On Bit 3: V8 protocol (G3-3: Super G3) 0: Off, 1: On 6800D7(H) - User parameter switch 07 (SWUSR_07) Bit O Ringing O: Off, 1: On Bit1: Automatic answering message 0: Off, 1: On Bit 2: Parallel memory transmission 0: Off, 1: On Bits 3 and 4: Not used Bit 5: Remote control 0: Off, 1: On Bits 6 and 7: Not used 6800D8(H) - User parameter switch 08 (SWUSR_08) Bits 0 and 1: Not used. Bit 2: Authorized reception 0: Only faxes from senders whose RTIs/CSIs are specified for this feature are accepted. 1: Only faxes from senders whose RTIs/CSIs are not specified for this feature are accepted. Bits 3 to 7: Not used. 6800D9(H) - User parameter switch 09 (SWUSR_09): Not used 6800DA(H) - User parameter switch 10 (SWUSR_OA) Bits 0 to 2: Not used Bit 3: Page reduction 0: Off, 1: On Bits 4 and 5: Not used Bit 6: Use both e-mail notification and printed reports to confirm the transmission results 0: Off, 1: On Bit 7: Not used 6800DB(H) - User parameter switch 11 (SWUSR_OB) Bits 0 and 1: Not used

Bit 2: White original detection 0: Off, 1: On (alarm and alert message on the LCD)

Bit 3: Receive rejection for 1300 Hz transmission 0: Off (receive), 1: On (not receive)

Bit 5: Not used

Bit 6: Printout of messages received while acting as a forwarding station 0: Off, 1: On

Bit 7: Not used

6800DC(H) - User parameter switch 12 (SWUSR_OC): Not used

6800DD(H) - User parameter switch 13 (SWUSR_0D): Not used

6800DE(H) - User parameter switch 14 (SWUSR_OE)

Bit 0: Message printout while the machine is in Night Printing mode 0: On, 1: Off

Bit 1: Maximum document length detection 0: Double letter, 1: Longer than double-letter (well log) – up to 1,200 mm

Bit 2: Not used

Bit 3: Fax mode settings, such as resolution, before a mode key (Copy/Fax/Printer/Scanner) is pressed 0: Not cleared, 1: Cleared

Bits 4 to 6: Not used

Bit 7: Not used

6800DF(H) - User parameter switch 15 (SWUSR_OF)

(This switch is not printed on the user parameter list.)

Bits 0, 1 and 2: Cassette for fax printout

Bit 2: 0, Bit 1: 0, Bit 0: 1 = 1st paper feed station

Bit 2: 0, Bit 1: 1, Bit 0: 0 = 2nd paper feed station

Bit 2: 0, Bit 1: 1, Bit 0: 1 = 3rd paper feed station

Bit 2: 1, Bit 1: 0, Bit 0: 0 = 4th paper feed station

Bit 2: 1, Bit 1: 0, Bit 0: 1 = LCT

Other settings Not used

Bits 3 and 4: Not used

Bit 5: Using the cassette specified by bits 0, 1 and 2 above only 0: On, 1: Off

Bits 6 and 7: Not used

6800E0(H) – User parameter switch 16 (SWUSR_10)

(This switch is not printed on the user parameter list.)

Bits 0 and 1: Not used

Bit 2: Paper size selection priority for an A4 size fax message when A4/LT size paper is not available. 0: A3 has priority, 1: B4 has priority

Bits 3 to 7: Not used

229

6800E1(H) – User parameter switch 17 (SWUSR_11)

Bit 0: Not used

Bit 1: Not used

Bit 2: Inclusion of the "Add" button when a sequence of Quick/Speed dials is selected for broadcasting 0: Not needed, 1: Needed

Bits 3 to 6: Not used

Bit 7: Press "Start" key without an original when using the on hook dial or the external telephone,

0: displays "Cannot detect original size". 1: Receives fax messages.

6800E2(H) - User parameter switch 18 (SWUSR_12)

Bit 0: TTI date 0: Off, 1: On

Bit 1: TTI sender 0: Off, 1: On

Bit 2: TTI file number 0: Off, 1: On

Bit 3: TTI page number 0: Off, 1: On

Bits 4 to 6: Not used

Bit 7: Japan only

6800E3(H) - User parameter switch 19 (SWUSR_13)

Bit 0: Not used

Bit 1: Journal format

O: The Journal is separated into transmissions and receptions

1: The Journal is separated into G3-1, G3-2, and G3-3 communications

Bit 2: Not used

Bit 3: 90° image rotation during B5 portrait TX (This switch is not printed on the user parameter list.) 0: Off, 1: On

Bit 4: Reduction of sample images on reports to 50% in the main scan and sub-scan directions. (This switch is not printed on the user parameter list.) O: Technician adjustment (printer switch OE bits 3 and 4), 1: 50% reduction

Bit 5: Use of A5 size paper for reports (This switch is not printed on the user parameter list.) 0: Off, 1: On

Bits 6 and 7: Not used

6800E4(H) - User parameter switch 20 (SWUSR_14)

Bit 0: Automatic printing of the LAN fax result report 0: Off, 1: On Bit 1: Not used.

Bits 2 to 5: Store documents in memory, which could not be printed from PC fax (LAN fax) driver

Bit 5	Bit 4	Bit 3	Bit 2	Setting
0	0	0	0	0 min.

0	0	0	1	1 min.
\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
1	1	1	0	14 min.
1	1	1	1	15 min.

Bits 6 and 7: Not used.

6800E5(H) - User parameter switch 21 (SWUSR_15)

Bit O: Print results of sending reception notice request message O: Disabled (print only when error occurs), 1: Enabled

Bit 1: Respond to e-mail reception acknowledgment request 0: Disabled, 1: Enabled

Bit 2: Not used

Bit 3: File format for forwarded folders 0: TIFF, 1: PDF

- Bit 4: Transmit Journal by E-mail 0: Disabled, 1: Enabled
- Bit 5: Not used

Bit 6: Network error display 0: Displayed, 1: Not displayed

Bit 7: Transmit error mail notification 0: Enabled, 1: Disabled

6800E6(H) - User parameter switch 22 (SWUSR_16)

(This switch is not printed on the user parameter list.)

Bit O: Dial tone detection (PSTN 1) O: Disabled, 1: Enabled

Bits 1 to 7: Not used

6800E7(H) - User parameter switch 23 (SWUSR_17): Not used

6800E8(H) - User parameter switch 24 (SWUSR_18): Not used

6800E9(H) - User parameter switch 25 (SWUSR_19)

Bit 0: Not used

Bit 1: Reception mode switch timer 0: Off, 1: On (switching Fax or Fax/Tel)

- Bit 2: Mode priority switch 0: Fax first, 1: Tel first
- Bit 3: Dial in function (Japan Only)
- Bit 4: Do not Change this Bit.

Bits 5 to 7: Not used

6800EA(H) and 6800EB(H) - User parameter switches 26 and 27 (SWUSR_1A and 1B): Not used

6800EC(H) - User parameter switch 28(SWUSR_1C): Not used

6800ED(H) - User parameter switch 29(SWUSR_1D): Not used

6800EE(H) and 6800EF(H) - User parameter switches 30 and 31 (SWUSR_1E and 1F): Not used

6800F0(H) - User parameter switch 32 (SWUSR_20)

Bit 0: Quotation priority for a destination when there is no destination of the specified type

0: Paper output priority = Priority order: 1. IP-fax destination, 2. Fax Number, 3. E-mail address, 4. Folder

1: Electric putout order = Priority order: 1. E-mail address, 2. Folder, 3. IP-fax destination, 4. Fax number

Bits 1 to 7: Not used

6800F1(H) - User parameter switch 33 (SWUSR_21): Not used

6800F2(H) - User parameter switch 34 (SWUSR_22)

Bit 0: Gatekeeper server used with IP-Fax 0: Disabled, 1: Enabled

Bit 1: SIP server used with IP-Fax O: Disabled, 1: Enabled

Bits 2 to 7: Not used

6800F3(H) - User parameter switch 35 (SWUSR_23)

Redial interval when sending a backup file

6800F4(H) - User parameter switch 36 (SWUSR_24)

Maximum number of redials when sending a backup file

6800F5(H) - User parameter switch 37 (SWUSR_25)

Bit 0: Whether to stop sending a backup file if the destination folder becomes full while the machine is sending or waiting to send a fax or the backup file. 0: No, • 1: Yes

Bit 2 and 3: Backup file is printed along with the TX communication failure report when a backup file transmission failure occurs. 00: Do not print, 01: Print first page only, 10: Print whole file

Bit 4: Display the sender's information in the file name of documents that are forwarded to folder destinations. 0: Disabled, 1: Enabled

Bit 5: Limit the file names of documents that are forwarded to folder destinations to plain characters only. 0: Disabled, 1: Enabled

Bit 6: When using the remote fax function, the sub-machine beeps to let you know when it has printed a received document (If you specify "On", the machine will beep according to the setting of [Panel Key Sound] under [System Settings].) 0: On, 1: Off

Bit 7: Not used

6800F6(H) - User parameter switch 38 (SWUSR_26)

Maximum number of transmissions the machine attempts before determining that a fax cannot be forwarded from a sender (including special senders) to a folder destination

6800F7(H) - User parameter switch 39 (SWUSR_27)

Interval (in minutes) between resend attempts after failing to forward a fax from a sender (including special senders) to a folder destination

6800F8(H) - User parameter switch 40 (SWUSR_28)

Bit 0: When memory space is insufficient, the machine prints and then deletes the oldest faxes, creating memory space for storage of new faxes. 0: Disabled, 1: Enabled

Bit 1 to 7: Not used

6800FD(H) - User parameter switch 45 (SWUSR_2D)

Bit 0 and 1:

Bit 2: File format for files transmitted to e-mail addresses and folders registered as forwarding, destinations of backup file transmission, receivers for Personal Box, or end receivers for Transfer Box. 0: PDF 1: PDF/A

Bit 3:

Bit 4 to 7: Not used

680100 to 68010F(H) - G4 Parameter Switches - Not used

680110 to 68012F(H) - G4 Internal Switches - Not used

680130 to 68016F(H) - Service Switches

680170 to 68017F(H) - IFAX Switches

680180 to 68018F(H) - IP-FAX Switches

680190 to 6801A3(H) - PSTN-1 RTI (Max. 20 characters - ASCII) - See the following note.

6801A4 to 6801B7(H) - PSTN-2 RTI (Max. 20 characters - ASCII)

6801B8 to 6801CB(H) - PSTN-3 RTI (Max. 20 characters - ASCII)

6801CF to 68020E(H) - TTI 1 (Max. 64 characters - ASCII) - See the following note.

68020F to 68024E(H) - TTI 2

- 68024F to 68028E(H) TTI 3
- 68028F to 6802CE(H) TTI 4
- 6802CF to 68030E(H) TTI 5
- 68030F to 68034E(H) TTI 6
- 68034F to 68038E(H) TTI 7
- 68038F to 6803CE(H) TTI 8

6803CF to 68040E(H) - TTI 9

68040F to 68044E(H) - TTI 10

• Note

 If the number of characters is less than the maximum (20 for RTI, 32 for TTI), add a stop code (00[H]) after the last character.

68044F(H)

Printing format for TTI 1

0: DOM (Japan), 1:EXP (Export)

680450(H)

Printing format for TTI 2

0: DOM, 1: EXP

680451(H)

Printing format for TTI 3

0: DOM, 1:EXP

680452(H)

Printing format for TTI 4

0: DOM, 1:EXP

680453(H)

Printing format for TTI 5

0: DOM, 1:EXP

680454(H)

Printing format for TTI 6

0: DOM, 1:EXP

680455(H)

Printing format for TTI 7

0: DOM, 1:EXP

680456(H)

Printing format for TTI 8

0: DOM, 1:EXP

680457(H)

Printing format for TTI 9

0: DOM, 1:EXP

680458(H)

Printing format for TTI 10

0: DOM, 1: EXP

680459 to 68046C(H) - PSTN-1 CSI (Max. 20 characters - ASCII)

68046D to 680480(H) - PSTN-2 CSI (Max.20 characters - ASCII)

680481 to 680494(H) - PSTN-3 CSI (Max.20 characters - ASCII)

680495(H) - Number of PSTN-1 CSI characters (Hex)

680496(H) - Number of PSTN-2 CSI characters (Hex)

680497(H) - Number of PSTN-3 CSI characters (Hex)

- 6804C6(H) Memory Lock ID (BCD)
- 6804D2 to 6804D9(H) Last power off time (Read only)
- 6804D2(H) 01(H) 24-hour clock, 00(H) 12-hour clock (AM), 02(H) 12-hour clock (PM)
- 6804D3(H) Year (BCD)
- 6804D4(H) Month (BCD)
- 6804D5(H) Day (BCD)
- 6804D6 (H) Hour
- 6804D7 (H) Minute
- 6804D8(H) Second
- 6804D8 (H) 00: Monday, 01: Tuesday, 02: Wednesday, ///, 06: Sunday
- 6804E6(H) Optional equipment (Read only Do not change the settings)
- Bit 0: Page Memory 0: Not installed, 1: Installed
- Bit 1: SAF Memory (4M) 0: Not installed, 1: Installed
- Bit 2: SAF Memory 0: Not installed, 1: Installed
- Bits 3 to 7; Not used
- 6804E7(H) Optional equipment (Read only Do not change the settings)
- Bits 0 to 3: Not used
- Bit 4: G3-2 0: Not installed, 1: Installed
- Bit 5: G3-3 0: Not installed, 1: Installed
- Bit 6 and 7: Not used
- 6804EE(H) Machine code (Check ram 3)
- 680500(H) Start address of G3 table for G3-1
- 680600(H) Start address of G3 table for G3-2
- 680700(H) Start address of G3 table for G3-3
- 680800 to 68081F(H) Service station's fax number (SP3-101)
- 680820 to 680829(H) Own fax PABX extension number Not used
- 68082A to 680833(H) Own fax number (PSTN) Not used
- 680834 to 680847(H) Own fax number (ISDN G4) Not used
- 680848 to 680853(H) The first subscriber number (ISDN G3) Not used
- 680854 to 68085F(H) The second subscriber number (ISDN G3) Not used
- 680860 to 68086B(H) The first subscriber number (ISDN G4) Not used
- 68086C to 680877(H) The second subscriber number (ISDN G4) Not used
- 6808A0 to 6808B7(H) G4TID registered information (Max.24 characters ASCII)

6808B8 to 6808CB(H) - ISDN CSI (Max.20 characters - ASCII)

6808CC(H) - Number of ISDN CSI characters (Hex)

6808D1 to 6808D4(H) - ISDN G3 sub address registered information

6808D5 to 6808D8(H) - G4 sub address registered information

6808DE to 6808E2 - Option G3 board (G3-2) ROM information (Read only)

- 6808DE(H) Suffix (BCD)
- 6808DF(H) Version (BCD)
- 6808E0(H) Year (BCD)
- 6808E1(H) Month (BCD)
- 6808E2(H) Day (BCD)

6808E3 to 6808E7 - Option G3 board (G3-3) ROM information (Read only)

- 6808E3(H) Suffix (BCD)
- 6808E4(H) Version (BCD)
- 6808E5(H) Year (BCD)
- 6808E6(H) Month (BCD)
- 6808E7(H) Day (BCD)
- 6808E8(H) G3-1 Modem ROM version (Read only)
- 6808EA(H) G3-2 Modem ROM version (Read only)
- 6808EC(H) G3-3 Modem ROM version (Read only)
- 6808F8(H) Number of multiple sets print (Read only)
- 68094E(H) Time for economy transmission (Not used)
- 68094F(H) Time for economy transmission (Not used)
- 68096A(H) Transmission monitor volume 00 07(H)
- **68096B(H)** Reception monitor volume 00 07(H)
- 68096C(H) On-hook monitor volume 00 07(H)
- 68096D(H) Dialing monitor volume 00 07(H)
- 68096E(H) Buzzer volume 00 07(H)
- 68096F(H) Beeper volume 00 07(H)
- 680980(H) Machine code (Check ram 4)
- 680982(H) Machine serial number (ASCII)
- 687178 to 68717B(H) Transmission counter (Max.24 characters ASCII)
- 68717C to 68717F(H) Reception counter (Max.24 characters ASCII)
- 6871E8 to 6871EB(H) Mail transmission counter (Max.24 characters ASCII)

- 6871EC to 6871EF(H) Mai reception counter (Max.24 characters ASCII)
- 6A6DEE(H) to 6A70ED(H) SIP server address (Read only)
- 6A6DEE(H) Proxy server Main (Max. 128 characters ASCII)
- 6A6E6E(H) Proxy server Sub (Max. 128 characters ASCII)
- 6A6EEE(H) Redirect server Main (Max. 128 characters ASCII)
- 6A6F6E(H) Redirect server Sub (Max. 128 characters ASCII)
- 6A6FEE(H) Registrar server Main (Max. 128 characters ASCII)
- 6A706E(H) Registrar server Sub (Max. 128 characters ASCII)
- 6A70EE(H) Gatekeeper server address Main (Max. 128 characters ASCII)
- 6A716E(H) Gatekeeper server address Sub (Max. 128 characters ASCII)
- 6A71EE(H) Alias Number (Max. 128 characters ASCII)
- 6A726E(H) SIP user name (Max. 128 characters ASCII)
- 6A72EE(H) SIP digest authentication password (Max. 128 characters ASCII)
- 6A736E(H) Gateway address information (Max. 7100 characters ASCII)
- 6A8F2A(H) NGN initial setting method 0: Simple, 1: Manual
- 6A8F2B(H) SIP digest authentication user name (Max. 128 characters ASCII)
- 6A8FAB(H) NGN-SIP domain name (Max. 64 characters ASCII)
- 6A8FEB(H) NGN-home gateway address (Max. 128 characters ASCII)
- 6A906C(H) Stand-by port number for H.323 connection
- 6A906E(H) Stand-by port number for SIP connection
- 6A9070(H) RAS port number
- 6A9072(H) Gatekeeper port number
- 6A9074(H) Port number of data waiting for T.38
- 6A9076(H) Port number of SIP server
- 6A9078(H) Priority for SIP and H.323 0: H.323, 1: SIP
- 6A9079(H) SIP function O: Disabled, 1: Enabled
- 6A907A(H) H.323 function 0: Disabled, 1: Enabled
- 6A907B(H) SIP digest authentication function 0: Disabled, 1: Enabled
- 6B3AE4(H) 6B3B04 (H) Dial tone detection parameter (Max. 11 x 3 lines)
- This initializes following order. [0x04, 0x40, 0x03, 0x60, 0x64, 0x64, 0x01,0x64, 0x04, 0xc8, 0x00]
- 6B3AE4(H) Dial tone detection frequency Upper limit (High)
- Defaults: NA: 06, EU: 06, ASIA: 06

6B3AE5(H) - Dial tone detection frequency - Upper Limit (Low)

Defaults: NA: 50, EU: 50, ASIA: 50

6B3AE6(H) - Dial tone detection frequency - Lower Limit (High)

Defaults: NA: 03, EU: 02, ASIA: 02

6B3AE7(H) - Dial tone detection frequency - Lower Limit (Low)

Defaults: NA: 60, EU: 90, ASIA: 90

6B3AE8(H) - Dial tone detection waiting time (20 ms)

Defaults: NA: 64, EU 64, ASIA: 64

6B3AE9 to 6B3AEA - Dial tone detection monitoring time (20 ms)

Defaults

Area	6B35A9	6B35AA
NA	F4	01
EU	F4	01
ASIA	F4	01

6B3AEB(H) - Dial tone detect judge time (20 ms)

Defaults: NA: 64, EU: 1B, ASIA: 32


6B3AEC(H) - Dial tone disconnect permission time (20 ms)

Defaults: NA: 11, EU: OF, ASIA: 11

5. Detailed Section Descriptions

Overview

Overview



Together with the controller board, the FCU controls all the fax communications and fax features. The FCU also contains the ROM, SRAM and NCU circuits.

Fax Options

• Extra G3 Interface option


This provides one more analog line interface. This allows full dual access. Two extra G3 interface options can be installed.

• Memory Expansion

This expands the SAF memory and the page memory (used for image rotation); without this expansion, the page memory is not big enough for image rotation at 400 dpi, so transmission at 400 dpi is not possible.

Boards

FCU



The FCU (Facsimile Control Unit) controls fax communications, the video interface to the base copier's engine, and all the fax options.

FACE3.5 (Fax Application Control Engine)

- CPU
- Data compression and reconstruction (DCR)
- DMA control
- Clock generation
- DRAM backup control

Modem (FAME2)

• V.34, V33, V17, V.29, V.27ter, V.21, and V.8

DRAM

- The 16 MB of DRAM is shared as follows.
 - SAF memory: 4MB
 - Working memory: 4MB
 - Page memory: 8MB

• The SAF memory is backed up by a rechargeable battery.

ROM

• 4MB flash ROMs for system software storage

SRAM

• The 512 KB SRAM for system and user parameter storage is backed up by a lithium battery.


Memory Back-up

- A rechargeable battery backs up the SAF memory (DRAM) for 12 hours.
- A lithium battery backs up the system parameters and programmed items in the SRAM, in case the base copier's main switch is turned off.

Switches

ltem	Description
SW1	Switches the SRAM backup battery on/off.

SG3 Board



b766d903a

5

The SG3 board allows up to three simultaneous communications when used in combination with the FCU and optional G3 boards. The NCU is on the same board as the common SG-3 board. This makes the total board structure smaller. But, the specifications of the SG3 board do not change.

NCCP (New Communication Control Processor)

- Controls the SG3 board.
- CPU (RU30)
- DPRAM (Dual Port RAM): Handshaking with the FCU is done through this block.
- DMA controller
- JBIG
- DSP V34 modem (RL5T892): Includes the DTMF Receiver function
- DCR for MH, MR, MMR, and JBIG compression and decompression

FROM

• 1 Mbyte flash ROM for SG3 software storage and modem software storage

SDRAM

• 4Mbyte DRAM shared between ECM buffer, line buffer, and working memory

AFE (Analog Front End)

• Analog processing


CODEC (COder-DECoder)

• A/D & D/A conversions for modem

REG

• Generates +3.3 V from the +5V from the FCU

Video Data Path



Memory Transmission and Parallel Memory Transmission

The base copier's scanner scans the original at the selected resolution in inch format. The IPU processes the data and transfers it to the FCU.

Vote

• When scanning a fax original, the IPU uses the MTF, independent dot erase and thresholding parameter settings programmed in the fax unit's scanner bit switches, not the copier's SP modes.

5

Then, the FCU converts the data to mm format, and compresses the data in MMR or raw format to store it in the SAF memory. If image rotation will be done, the image is rotated in page memory before compression.

At the time of transmission, the FCU decompresses the stored data, then re-compresses and/or reduces the data if necessary for transmission. The NCU transmits the data to the line.

Immediate Transmission

The base copier's scanner scans the original at the resolution agreed with the receiving terminal. The IPU video processes the data and transfers it to the FCU.

Vote

• When scanning a fax original, the IPU uses the MTF, independent dot erase and thresholding parameter settings programmed in the fax unit's scanner bit switches, not the copier's SP modes.

Then the FCU stores the data in page memory, and compresses the data for transmission. The NCU transmits the data to the line.

JBIG Transmission

Memory transmission

If the receiver has JBIG compression, the data goes from the DCR to the QM-Coder. Then the NCU transmits the data to the line. When an optional G3 unit (SG3) is installed and PSTN2 is selected as the line type, JBIG compression is available, but only for the PSTN-2 line.


Immediate transmission

If the receiver has JBIG compression, the data goes from the page memory to the QM-Coder. Then the NCU transmits the data to the line. When an optional G3 unit (SG3) is installed and PSTN2 is selected as the line type, JBIG compression is available, but only for the PSTN-2 line.

Adjustments

• Priority for the line used for G3 transmissions (PSTN 1/PSTN 2 or 3): System switch 16 bit 1

Reception



First, the FCU stores the incoming data from either an analog line to the SAF memory. (The data goes to the FACE3 at the same time, and is checked for error lines/frames.)

The FCU then decompresses the data and transfers it to page memory. If image rotation will be done, the image is rotated in the page memory. The data is transferred to the IPU.

If the optional G3 unit is installed, the line that the message comes in on depends on the telephone number dialed by the other party (the optional G3 unit has a different telephone number from the main fax board).

JBIG Reception

When data compressed with JBIG comes in on PSTN-1 (the standard analog line), the data is sent to the QM-CODER for decompression. Then the data is stored in the page memory, and transferred to the IPU.

When data compressed with JBIG comes in on PSTN-2 (optional extra analog line), the data is sent to the QM-CODER on the SG3 board for decompression.


Fax Communication Features

Multi-port

When the optional extra G3 Interface Unit is installed, communication can take place at the same time through the two or three lines at once.

Option	Available Line Type	Available protocol Combinations
Standard only	PSTN	G3
Extra G3 Interface Unit (single)	PSTN + PSTN	G3 + G3
Extra G3 Interface Unit (double)	PSTN + PSTN +PSTN	G3 + G3 +G3

Document Server



d629d104

The base copier's scanner scans the original at the selected resolution. The IPU video processes the data and transfers it to the controller board.

Then the controller stores the data in the page memory for the copier function, and compresses the data in MMR (by software) to store it in the HDD. If image rotation will be done, the image is rotated in the page memory before compression.

For transmission, the stored image data is transferred to the FCU. The FCU decompresses the image data, then recompresses and/or reduces the data if necessary for transmission. The NCU transmits the data to the line.

The documents can be stored in the HDD (Document Server) from the fax application. The stored documents in the document sever can be used for the fax transmission in many times. More than one document and the scanned document can be combined into one file and then the file can be transmitted.

- When using the document server, the SAF memory is not used.
- The document is compressed with MMR and stored.
- Up to 9,000 pages can be stored (1 file: Up to 1,000 pages) from the fax application.
- Only stored documents from the fax application can be transmitted.
- Scanned documents are given a name automatically, such as "FAXOO1". But it is possible to change the file name, user name and password.
- Up to 30 files can be selected at once.

Vote

- The compression method of the fax application is different from the copy application. The storing time is longer than the copier storing.
- When selecting "Print 1 st page", the stored document will be reduced to A4 size.

Internet Mail Communication

Mail Transmission

T.37 simple and full modes

This machine supports T.37 full mode. (ITU-T Recommendation, RFC2532). The difference between T.37 simple mode and full mode is as follows.

Function	T.37 Simple Mode	T.37 Full Mode
Resolution	200 x 100	200 x100
	200 x 200	200 x 200
		200 x 400
		400 x 400 (if available)
RX Paper Width	A4	A4, B4, A3

Function	T.37 Simple Mode	T.37 Full Mode
RX Data Compression Method	МН	MH (default), MR, MMR,
Signals	Image data transmission only	Image data transmission, exchange of capability information between the two terminals, and acknowledgement of receipt of fax messages

Data Formats

The scanned data is converted into a TIFF-F formatted file.

The fields of the e-mail and their contents are as follows:

Field	Content
From	Mail address of the sender
Reply To	Destination requested for reply
То	Mail address of the destination
Всс	Backup mail address
Subject	From CSI or RTI (Fax Message No. xxxx)
Content Type	Multipart/mixed Attached files: image/tiff
Content Transfer Encoding	Base 64, 7-bit, 8-bit, Quoted Printable
Message Body	MIME-converted TIFF-F (MIME standards specify how files are attached to e-mail messages)

Direct SMTP Transmission

Internet Fax documents can be sent directly to their destinations without going through the SMTP server. (Internet Faxes normally transmit via the SMTP server.)

For example:

e-mail address:	gts@ricoh.co.jp
SMTP server address:	gts.abcd.com

In this case, this feature destination e-mail address (gts@ricoh.co.jp) is read as the SMTP server address "gts.abcd.com", and the transmissions bypass the SMTP server. This leads to decrease the server load and to reduce the time lag during transferring the mail.

- Requirements for destination server:
 - Supports with Internet FAX (as a destination of Internet FAX)
 - Can receive mails (as a destination of mail)
 - Is installed in the same LAN as this machine
 - Supports with the SMTP mail reception, and the reception protocol is set to SMTP

Note

- Set the port number for [SMTP server] to "25" to enable this feature.
- If the sender server sends an Internet FAX or a mail using this feature, the SMTP authentication is disabled even if the server sets it.
- Using this feature, error notification mail will not be sent even if the mail is not properly received.
- Also, error mail will not be sent even if the mail is not sent properly.
- This feature refers to A records (not supported with MX records).

Selectable Options

These options are available for selection:

- With the default settings, the scan resolution can be either standard or detail. Inch-mm conversion before TX depends on IFAX SW01 Bit 7. Detail resolution will be used if Super Fine resolution is selected, unless Fine resolution is enabled with IFAX SW01.
- The requirements for originals (document size, scan width, and memory capacity) are the same as for G3 fax memory TX.
- The default compression is TIFF-F format.
- IFAX SW00: Acceptable paper widths for sending
- IFAX SW09: Maximum number of attempts to the same destination

Secure Internet Transmission

- SMTP Authentication:
 - User Tools> System Settings> File Transfer> SMTP Authentication
- POP Before SMTP:
 - User Tools> System Settings> File Transfer> POP Before SMTP

Mail Reception

Three Types

This machine supports three types of e-mail reception:

- POP3 (Post Office Protocol Ver. 3.)
- IMAP4 (Internet Messaging Access Protocol)
- SMTP (Simple Mail Transfer Protocol)

Vote

 For details: Core Technology Manual – Facsimile Processes – Faxing from a PC – Internet/LAN Fax Boards – Mail Reception

POP3/IMAP4 Mail Reception Procedure

The machine automatically picks up e-mail from the server at an interval which is adjustable in the range 2 to 1440 min. in 1-minute steps:

• User Tools> System Settings> File Transfer> E-mail Reception Interval

SMTP Reception

- 1. The IFAX must be registered as an SMTP server in the MX record of the DNS server, and the address of the received mail must specify the IFAX.
- 2. To enable SMTP reception: User Tools> System Settings> File Transfer> Reception Protocol
 - Even if the MX record on the DNS server includes the IFAX, mail cannot be received with SMTP until SMTP reception is enabled:
 - However, if SMTP reception is selected and the machine is not registered in the MX record of the DNS server, then either IMAP4 or POP3 is used, depending on the setting: User Tools> System Settings> File Transfer> Reception Protocol

🕗 Note

- An error will be issued and error mail will be sent to the mail source when the reception protocol is not set to SMTP even If you configure to enable SMTP reception in the DNS server.
- If the received mail contains error, the reception operation is stopped, the mail is discarded and error report is output. Error mail is also sent to the mail source.
- When a mail is received from SMTP server during sending a mail in the machine, the SMTP server will give a "Busy" response. The SMTP server will usually try to send the mail again later until the time-out is reached.
- This feature cannot be used with the POP server.

Mail Delivery Conditions: Transferring Mail Received With SMTP

- 1. The machine must be set up for SMTP mail delivery:
 - User Tools> Facsimile Features> Reception Settings> SMTP RX File Delivery Settings

- If the user wishes to limit this feature so that the machine will only deliver mail from designated senders, the machine's "Auth. E-mail RX" feature must be set (User Tools> Facsimile Features> Reception Settings> SMTP RX File Delivery Settings).
- If the "SMTP RX File Delivery Setting" is set to "Off" to prohibit SMTP receiving, and if there is mail designated for delivery, then the machine responds with an error. (User Tools> Facsimile Features> Reception Settings> SMTP RX File Delivery Settings)
- 4. If the quick dial, speed dial, or group dial entry is incorrect, the mail transmission is lost, and the IFAX issues an error to the SMTP server and outputs an error report.

Auth. E-mail RX

In order to limit access to mail delivery with IFAX, the addresses of senders must be limited using the Access Limit Entry. Only one entry can be registered.

1. Access Limit Entry

For example, to limit access to @IFAX.ricoh.co.jp:

gts@IFAX.ricoh.co.jp	Matches and is delivered.
gts@IFAX.abcde.co.jp	Does not match and is not delivered.
IFAX@ricoh.co.jp	Does not match and is not delivered.

2. Conditions

- The length of the Access Limit Entry is limited to 127 characters.
- If the Access Limit Entry address and the mail address of the incoming mail do not match, the incoming mail is discarded and not delivered, and the SMTP server responds with an error. However, in this case an error report is not output.
- If the Access Limit Entry address is not registered, and if the incoming mail specifies a delivery destination, then the mail is delivered unconditionally.

Handling Mail Reception Errors

Abnormal files

When an error of this type occurs, the machine stops receiving and commands the server to erase the message. Then the machine prints an error report and sends information about the error by email to the sender address (specified in the "From" or "Reply-to" field of the message). If there is an incomplete received message in the machine memory, it will be erased.

The machine prints an error message when it fails to send the receive error notification after a certain number of attempts.

The following types of files are judged to be abnormal if one or more of the following are detected:

1. Unsupported MIME headers.

Supported types of MIME header

Header	Supported Types
Content-Type	Multipart/mixed, text/plain, message/rfc822 lmage/tiff
Charset	US-ASCII, ISO 8859 X. Other types cannot be handled, and some garbage may appear in the data.
Content-Transfer- Encoding	Base 64, 7-bit, 8-bit, Quoted Printable

- 2. MIME decoding errors
- 3. File format not recognized as TIFF-F format
- 4. Resolution, document size, or compression type cannot be accepted

Remaining SAF capacity error

The machine calls the server but does not receive e-mail if the remaining SAF capacity is less than a certain value (the value depends on IFAX Switch 08. The e-mail will be received when the SAF capacity increases (for example, after substitute reception files have been printed). The error handling method for this type of error is the same as for "Abnormal files".

If the capacity of the SAF memory drops to zero during reception, the machine operates in the same way as when receiving an abnormal file (refer to "Abnormal files" above).

Secure Internet Reception

To enable password encryption and higher level security: User Tools> System Settings> File Transfer> POP3/IMAP4 Settings> Encryption (set to "On")

Transfer Request: Request By Mail

For details: Core Technology Manual – Facsimile Processes – Faxing from a PC – Internet/LAN Fax Boards – Transfer Request

Field	Content
From	E-mail address of the requesting terminal
То	Destination address (Transfer Station address)
Всс	Backup mail address
Subject	From TSI (Fax Message No. xxxx)

The fields of the e-mail and their contents are as follows:

Field	Content
Content-Type	Multipart/mixed Text/Plain (for a text part), image/tiff (for attached files)
Content-Transfer-Encoding	Base 64, 7-Bit, 8-bit, Quoted Printable
Mail body (text part)	RELAY-ID-: xxxx (xxxx: 4 digits for an ID code) RELAY: #01#*X#**01
Message body	MIME-converted TIFF-F.

E-Mail Options (Sub TX Mode)

The following features are available as options for mail sending: entering a subject, designating the level of importance, confirming reception of the mail.

Subject and Level of Importance

You can enter a subject message with: TX Mode> Subject

The Subject entry for the mail being sent is limited to 128 characters. The subject can also be prefixed with a "Confidential", "Urgent", "Please phone" or "Copy to corres. Section" notation.

- How the Subject Differs According to Mail Type -

Mail Type	Item 1		Item 2	Item 3
Subject Entry		Entry Condition		
		1. "CSI" ("RTI")		Fax Message No.
No Subject		2. "RTI"	CSI not registered	+
Entry		3. "CSI"	RTI not registered	File No.
		4. None	CSI, RTI not registered	

Mail Type	Item 1		ltem 2	Item 3	
		1. "CSI" ("RTI")		Normal:	
				Return Receipt (dispatched).	
Confirmation of Reception	From	2. "RTI"	CSI not registered	You can select "displayed" with IFAX SW02 Bits 2 and 3.	
		3. "CSI"	RTI not registered	Error:	
		4. None	CSI, RTI not registered	Return Receipt (processed/error)	
Mail	From	RTI or CSI of the station designated for delivery	Mail delivery		
delivery, memory transfer,		RTI or CSI of sender	Mail sending from G3 memory	Fax Message No. + File	
SMTP receiving and delivery		Mail address of sender	Memory sending	- Number	
convery		Mail address of sender	SMTP receiving and delivery (Off Ramp Gateway)		
Mail error notification		Error Message No. xxxx From CSI (RTI)			

Items 1, 2, and 3 in the table above are in the Subject.

- Subjects Displayed on the PC -

Sender .	Date		Subject 🔺
Substation 2	04/25/2002	1,513	Parts List
Substation 2	04/26/2002	1,147	Specifications
Amain Station	05/09/2002	33,551	@ [Urgent] Memo 2041
		21,624,288	3
			-
			b766d907

E-mail Messages

After entering the subject, you can enter a message with: TX Mode> Text

An e-mail message (up to 5 lines) can be pre-registered with: User Tools> System Settings> File Transfer> Program/Change/Delete E-mail Message - Limitations on Entries -

ltem	Maximum
Number of Lines	5 lines
Line Length	80 characters
Name Length	20 characters

Message Disposition Notification (MDN)

For details: Core Technology Manual – Facsimile Processes – Faxing from a PC – Internet/LAN Fax Boards – E-mail Options

The network system administrator can confirm whether a sent mail has been received correctly or not. This confirmation is done in four steps.

- Send request for confirmation of mail reception. To enable or disable this request (known as MDN): TX Mode> Reception Notice
- 2. Mail reception (receive confirmation request)
- 3. Send confirmation of mail reception
- 4. Receive confirmation of mail reception

The other party's machine will not respond to the request unless the two conditions below are met:

- The other party's machine must be set up to respond to the confirmation request.
- The other party's machine must support MDN (Message Disposition Notification).
- Setting up the Receiving Party -

The receiving party will respond to the confirmation request if:

- 1. The "Disposition Notification To" field is in the received mail header (automatically inserted in the 4th line in the upper table on the previous page, if MDN is enabled), and
- Sending the disposition notification must be enabled (User Parameter Setting SW21 (15 [H]) Bit 1 for this model). The content of the response is as follows:

Normal reception:	"Return Receipt (dispatched)" in the Subject line
IFAX SW02 (Bit 2, 3)	"Return Receipt (displayed)" in the Subject line
Error:	"Return Receipt (processed/error)" in the Subject line

Handling Reports

- Sending a Request for a Return Receipt by Mail -

After the mail sender transmits a request for a return receipt, the mail sender's journal is annotated with two hyphens (--) in the Result column and a "Q" in the Mode column.

- Mail Receipt (Request for Receipt Confirmation) and Sending Mail Receipt Response -

After the mail receiver sends a response to the request for a return receipt, the mail receiver's journal is annotated with two hyphens (--) in the Result column and an "A" in the Mode column.

- Receiving the Return Receipt Mail -
 - After the mail sender receives a return receipt, the information in the mail sender's journal about the receipt request is replaced, i.e. the journal is annotated with "OK" in the Result column.
 - When the return receipt reports an error, the journal is annotated with an "E" in the Result column.
 - The arrival of the return receipt is not recorded in the journal as a separate communication. Its arrival is only reported by the presence of "OK" or "E" in the Result column.
 - If the mail address used by the sender specifies a mailing list (i.e., a Group destination; the machine sends the mail to more than one location. See "How to set up Mail Delivery"), the Result column of the Journal is updated every time a return receipt is received. For example, if the mailing list was to 5 destinations, the Result column indicates the result of the communication with the 5th destination only. The results of the communications to the first 4 destinations are not shown.

Exceptions:

If one of the communications had an error, the Result column will indicate E, even if subsequent communications were OK.

If two of the communications had an error, the Journal will indicate the destination for the first error only.

- Report Sample -

DATE	TIME	ADDRESS MODE TIME	PAGE	RESULT
MAY. 5	10:15	fuser_01@domlg. ricoh. co. Mail SM 0'09"	2	
	10:16	fuser_01@dom1g. ricoh. co. Mail SMQ 0'05"	1	
	10:17	s_tadashi@domlg. ricoh. co. Mail SMQ 0'09"	2	OK
	10:19	m_masataka@dom1g. ricoh. co. Mail SMA 0'05"	1	

b771d506

257

IP-Fax

What is IP-FAX?

For details: Core Technology Manual – Facsimile Processes – Faxing from a PC – Internet/LAN Fax Boards – IP-FAX

T.38 Packet Format

TCP is selected by default for this machine, but you can change this to UDP with IPFAX SW 00 Bit 1.

UDP Related Switches

	IP-Fax Switch 01							
No.	Function					Comments		
0-3	Select IP FAX Delay Level					Raise the level by selecting a higher setting if		
	Bit 3	Bit 2	Bit 1	Bit O	Level	too many transmission errors are occurring on the network.		
	0	0	0	0	0	If TCP/UDP is enabled on the network, raise		
	0	0	0	1	1	this setting on the T.30 machine. Increasing the delay time allows the recovery of more lost		
	0	0	1	0	2	packets.		
	0	0	1	1	3	If only UDP is enabled, increase the number of redundant packets.		
						Level 1~2: 3 Redundant packets		
						Level 3: 4 Redundant packets		

Settings

User parameter switch 34 (22[H]), bit 0

IP-Fax Gate Keeper usage, 0: No, 1: Yes

IP Fax Switches: Various IP-FAX settings (see the bit switch table)

General Specifications

FCU

Туре:	Desktop type transceiver
Circuit:	PSTN (max. 3ch.)
	PABX
Connection:	Direct couple
Original Size:	Book (Face down)
	Maximum Length: 432 mm [17 ins]
	Maximum Width: 297 mm [11.7 ins]
	ARDF (Face up)
	(Single-sided document)
	Length: 128 - 1200 mm [5.0 - 47.2 ins]
	Width: 105 - 297 mm [4.1 - 11.7 inch]
	(Double-sided document)
	Length: 128 - 432 mm [5.0 - 17 inch]
	Width: 105 - 297 mm [4.1 - 11.7 inch]
Scanning Method:	Flat bed, with CCD
Resolution:	G3
	8 x 3.85 lines/mm (Standard)
	8 x 7.7 lines/mm (Detail)
	8 x 15.4 line/mm (Fine) See Note1
	16 x15.4 line/mm (Super Fine) See Note 1
	200 x 100 dpi (Standard)
	200 x 200 dpi (Detail)
	400 x 400 dpi (Super Fine) See Note 1
	♦ Note
	Optional Expansion Memory required

Transmission Time:	G3: 3 s at 28800 bps; Measured with G3 ECM using memory for an ITU-T #1 test document (Slerexe letter) at standard resolution		
Data Compression:	MH, MR, MMR, JBIG		
Protocol:	Group 3 with ECM		
Modulation:	V.34, V.33, V.17 (TCM), V.29 (QAM), V.27ter (PHM), V.8, V.21 (FSK)		
Data Rate:	G3: 33600/31200/28800/26400/24000/21600/ 19200/16800/14400/12000/9600/7200/4800/2400 bps Automatic fallback		
I/O Rate:	With ECM: 0 ms/line Without ECM: 2.5, 5, 10, 20, or 40 ms/line		
Memory Capacity:	SAF Standard: 4 MB With optional Expansion Memory: 28 MB (4 MB+ 24 MB) Page Memory Standard: 8 MB (Print: 4 MB + Scanner: 4 MB) With optional Expansion Memory: 16 MB (8 MB + 8 MB) (Print 8 MB + Scanner: 8 MB)		

Capabilities of Programmable Items

Capabilities of Programmable Items

The following table shows the capabilities of each programmable items.

ltem	Standard
Quick Dial	2000
Groups	100
Destination per Group	500
Destinations dialed from the ten-key pad overall	500
Programs	100
Auto Document	6
Communication records for Journal stored in the memory	200
Specific Senders	30

The following table shows how the capabilities of the document memory will change after the Expansion Memory are installed.

	Without the Expansion Memory	With the Expansion Memory
Memory Transmission file	800	800
Maximum number of page for memory transmission	1000	1000
Memory capacity for memory transmission (Note1)	320	2240



• Measured using an ITU-T #1 test document (Slerexe letter) at the standard resolution, the auto image density mode and the Text mode.

IFAX Specifications

IFAX Specifications

	1		
Connectivity:	Local area network		
	Ethernet 100base-Tx/10base-T		
	Gigabit Ethernet 1000 Base-T		
	IEEE802.11a/g, g (wireless LAN),		
	200 × 100 dpi (Standard resolution), 200 × 200 dpi (Detail resolution), 200 × 400 dpi (Fine resolution)* 1, 400 × 400 dpi (Super Fine resolution)* 1		
Resolution:	♦ Note		
	 To use 200 × 400 dpi and 400 × 400 dpi, IFAX SW01 Bit 2 and/or bit 4 must be set to "1". 		
	1 s (through a LAN to the server)		
	Condition: ITU-T #1 test document (Selerexe Letter)		
	MTF correction: OFF		
- - .	TTI: None		
Transmission Time:	Resolution: 200 x 100 dpi		
	Communication speed: 10 Mbps		
	Correspondent device: E-mail server		
	Line conditions: No terminal access		
	Maximum Original Size: A3/DLT.		
Document Size:	♦ Note		
	 To use B4 and A3 width, IFAX SW00 Bit 1 (B4) and/or Bit 2 (A3) must be set to "1". 		
E-mail File Format:	Single/multi-part		
	MIME conversion		
	Image: TIFF-F (MH, MR, MMR)		

Protocol:	Transmission: SMTP, TCP/IP		
	Reception: POP3, SMTP, IMAP4, TCP/IP		
Data Rate:	1000 Mbps (1000 Base-T) 100 Mbps (100base-Tx) 10 Mbps (10base-T)		
Authentication Method:	SMTP-AUTH POP before SMTP A-POP		
Remark:	The machine must be set up as an e-mail client before installation. Any client PCs connected to the machine through a LAN must also be e-mail clients, or some features will not work (e.g. Autorouting).		


IP-FAX Specifications

IP-FAX Specifications

Local Area Network	
Ethernet/10base-T, 100base-TX	
Gigabit Ethernet/1000 Base-T	
IEEE802.11a/g, g (wireless LAN)	
8 x 3.85 lines/mm, 200x100dpi (standard character),	
8 x 7.7lines/mm, 200x200dpi (detail character),	
8 x 15.4lines/mm (fine character: optional expansion memory required),	
16 x 15.4lines/mm, 400x400dpi (super fine character: optional expansion memory required)	
A3 or 11" x 17" (DLT)	
Custom: 297mm x 1200mm (11.7" x 47.3")	
297mm x 1200mm (11.7" x 47.3")	
Recommended: T.38 Annex protocol, TCP, UDP/IP communication, SIP (RFC 3261 compliant), H.323 v2	
IP-Fax compatible machines	
Specify IP address and send faxes to an IP-Fax compatible fax through a network.	
Also capable of sending faxes from a G3 fax connected to a telephone line via a VoIP gateway.	
Receive faxes sent from an IP-Fax compatible fax through a network.	
Also capable of receiving faxes from a G3 fax connected to a telephone line via a VoIP gateway.	

Fax Unit Configuration


G3 Interface Unit Type M19 (for MP C3004/C3504)




d1673010

Component	Code	No.	Remarks
FCU	D3BV	1	
GWFCU I/F		5	Included with the fax unit
Expansion Memory	D3BZ	2	Optional
SG3 Board	- D3BV	3	
CCU I/F Board		4	Included with optional G3 unit

G3 Interface Unit Type M20 (for MP C4504/C5504/C6004)





d1673010

Component	Code	No.	Remarks
FCU	- D3BT	3	Included with the fax unit
GWFCU I/F		5	Included with the rax unit
Expansion Memory	D3BZ	4	Optional
SG3 Board	- D3BT	2	Included with optional C2 unit
CCU I/F Board		1	Included with optional G3 unit

MEMO

MEMO