Model K-C3 Printer/Scanner Unit Machine Code: B867 SERVICE MANUAL

Safety Notices

riangleImportant Safety Notices

Prevention of Physical Injury

- 1. Before disassembling or assembling parts of the copier and peripherals, make sure that the power cord is unplugged.
- 2. The wall outlet should be near the copier and easily accessible.
- 3. Note that some components of the copier and the paper tray unit are supplied with electrical voltage even if the main power switch is turned off.
- 4. If a job has started before the copier completes the warm-up or initializing period, keep hands away from the mechanical and electrical components because the starts making copies as soon as the warm-up period is completed.
- 5. The inside and the metal parts of the fusing unit become extremely hot while the copier is operating. Be careful to avoid touching those components with your bare hands.

Health Safety Conditions

Toner and developer are non-toxic, but if you get either of them in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

Observance of Electrical Safety Standards

The copier and its peripherals must be installed and maintained by a customer service representative who has completed the training course on those models.

Safety and Ecological Notes for Disposal

- 1. Do not incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.
- Dispose of used toner, developer, and organic photoconductors in accordance with local regulations. (These are non-toxic supplies.)
- 3. Dispose of replaced parts in accordance with local regulations.

Laser Safety

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.



• Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

MARNING FOR LASER UNIT

WARNING: Turn off the main switch before attempting any of the procedures in the Laser Unit section. Laser beams can seriously damage your eyes.

CAUTION MARKING:





Symbols and Abbreviations

Conventions Used in this Manual

This manual uses several symbols.

Symbol	What it means	
•	Refer to section number	
F	Screw	
	Connector	
0	E-ring	
⟨\(\)\(\)	Clip ring	
Ş	Clamp	





Short Edge Feed (SEF)

Long Edge Feed (LEF)

Cautions, Notes, etc.

The following headings provide special information:

⚠ WARNING

• Failure to obey warning information could result in serious injury or death.

ACAUTION

• Obey these guidelines to ensure safe operation and prevent minor injuries.

Mportant 🕽

- Obey these guidelines to avoid problems such as misfeeds, damage to originals, loss of valuable data and to prevent damage to the machine.
- Always obey these guidelines to avoid serious problems such as misfeeds, damage to originals, loss
 of valuable data and to prevent damage to the machine. bold is added for emphasis.



• This information provides tips and advice about how to best service the machine.

TABLE OF CONTENTS

Safety Notices	1
△ Important Safety Notices	1
Laser Safety	2
Symbols and Abbreviations	3
Conventions Used in this Manual	3
Cautions, Notes, etc	3
1. Installation	
Controller Box and Printer/Scanner	
Accessory Check	9
Installing Expansion Component	1C
Installing Panels and Keys	14
Settings	15
Controller Options	16
Overview	16
PostScript3 Installation	17
Java VM Option Installation	17
Wireless LAN (IEEE 802.11b) Installation	18
IEEE 1284 Installation	20
Bluetooth Installation	21
USB Host Installation	23
Remote Communication Gate Installation	24
2. Replacement and Adjustment	
Main Board	
Precautions	27
Controller Board	27
3. Troubleshooting	
Service Call Conditions	31
Service Call Conditions	31
GW SC Code Descriptions	32
4. Service Tables	
Service Program Mode	49
Enabling and Disabling Service Program Mode	49
GW SP Mode Tables	50

SP4-XXX (Mode)	50
SP5-XXX (Mode)	53
SP7-XXX (Data Log)	92
SP8-XXX (History)	96
Printer Service Mode	116
Service Mode Table	116
SP Modes Related to Printer Controller	116
Scanner Service Mode	117
Scanner Program Mode Table	117
Using SP Mode	118
Memory Clear	118
Serial Number Input (SP5-811)	119
SMC Print (SP5-990)	120
Counter-Each Paper Jam (SP7-504)	120
Original Jam History Display (SP7-508)	121
Firmware Update Procedure	122
NVRAM Data Upload/Download	128
Power-on Self Test	129
5. Detailed Section Descriptions	
Overview	
Controller Functions	133
Paper Source Selection	133
Auto Continue	134
Paper Output Tray	135
Duplex Printing	135
Scanner Functions	136
Image processing for scanner mode	136
Network Interface	137
LED Indicators	137
IEEE 802.11b (Wireless LAN)	138
Specifications	138
Transmission Modes	139
Security Features	140

Wireless LAN Troubleshooting Notes	141
Bluetooth	143
Specifications	143
Bluetooth Profiles	143
Bluetooth Security Features	144
USB	145
Specifications	145
USB 1.1/2.0	145
USB connectors	145
Pin Assignment	146
6. Specifications	
General Specifications	
Printer	149
Scanner	150
Software Accessories	151
Printer	151
SCANNER	152
Machine Configuration	153
System Components	153

Controller Box and Printer/Scanner

When you install the printer/scanner option, the GW controller box must also be installed. This procedure shows the installation procedure for the GW controller box and printer/scanner option.

Accessory Check

	No.	Description	Q'ty
	1	Installation procedure	1
	2	Controller box	1
	3	Operation panel	1
Controller Box	4	Expansion decal	1
Controller Box	5	Screw M3 x 8	1
	6	Tapping screw M3 x 6	6
	7	Ground cable	1
	8	Clamp	1
	1	Installation procedure	1
	2	Dummy cover-fax	1
	3	Dummy key top	1
	4	Printer/Scanner key panel	2
Printer Scanner	5	SD card	1
	6	RAM DIMM	1
	7	Ferrite core	1
	8	Operating instructions	1
	9	FCC label	1


9

Installing Expansion Component


ACAUTION

• Unplug the machine power cord before starting the following procedure.


Step 1-Controller Box



- 1. Remove the rear cover [A] (\mathscr{F} x 6).
- 2. Remove the slot cover [B] (x 1).
- 3. Remove one screw [C] from the BICU.




4. For B268/B269 model only, remove the GDI controller box [D] ($\hat{\mathscr{F}} \times 7$).




- 5. Connect the controller box [E] to the BICU. Make sure that the BICU is not damaged [F] and that the three openings [G][H][I] hold the controller box.
- 6. Fasten the screws ($\mbox{\ensuremath{\not{\not}}}\xspace$ x 7 [including the screw [C]).
- 7. Remove the FCU cover [J] (\$\beta x 3).


Step 2-Printer/Scanner




- 1. Remove the controller-box cover [A] (\mathscr{F} x 7).
- 2. Install the RAM DIMM [B].
- 3. Remove the SD-card cover [C] $(\mathscr{F} \times 1)$.
- 4. Install the SD card [D] in the lowest slot.
- 5. Install the SD-card cover.



6. Attach the ferrite core [E] to the network cable [F]. The end of the ferrite core must be about 8 cm (3.2") from the end of the cable [G].




7. Install the ground cable [H] as shown, and then clamp the cable (\mathscr{E} x 2, $\overset{\hookrightarrow}{\hookrightarrow}$ x 1).



8. Release the clamps [I], and then bind the harness [J] with the clamp [K].

- 9. Attach the clamp [K] to the controller box.
- 10. If you do not install the FCU, reinstall the FCU bracket (which has been removed in Step 1), to the controller box.




11. Attach the FCC label [L] at the right-hand side of the USB connector on the controller box (for the USA model only).

Step 4-Reassembling

- 1. Reassemble the controller box.
- 2. Install the rear cover.


Step 5-Panel

Installing Panels and Keys



- 1. Remove the front upper left cover [A] (\mathscr{F} x 3).
- 2. Install the optional operational panel [B] (X 1, \mathscr{F} x 4 [including the three screws removed in step 1]).

Step 6-Printer/Scanner Keys



- Remove the dummy cover (from the basic operation panel) and install the printer/scanner key panel
 [A].
- 2. Install the dummy fax cover [B].

Settings

Step 9-Printer/Scanner Model Settings


- 1. Turn the main switch on.
- 2. Start the SP mode.
- 3. Select SP5-985-001 (NIC setting) and change the setting value to "1" (ON).
- 4. Select SP5-985-002 (USB setting) and change the setting value to "1" (ON).
- 5. Turn the main switch off and on.
- 6. Start the SP mode.
- 7. Select SP5-801-001 and initialize the all SP data.
- 8. Exit the SP mode, and then start the UP mode.
- Select the "@Remote Service" ("User Tool" > "System Settings > Administrator Tools" > "Extended Security" > @Remote Service") and select "Prohibit".
- 10. Exit the UP mode, and then start the SP mode.
- 11. Select SP5-870-003 and execute initialization for @Remote.
- 12. Select SP5-907-001 and specifies the "Plug & Play".
- 13. Select SP5-870-001 and execute writing certification for @Remote.
- 14. Select SP5-302-002 and specify the time zone.
- 15. Select SP5-307-001, 003, and 004 and specify the daylight-saving time settings.
- 16. Exit the SP mode.
- 17. Turn the main switch off and on.
- 18. Start the UP mode.
- 19. Specifies the date and time with "Set Date" or "Set Time" (User Tool" > "System Settings" > "Set Date" or "Set Time").

15

Controller Options

Overview

This machine has I/F card slots and SD card slots for optional I/F connections and applications.



b867i503

I/F Card Slot


- Slot [A] is used for one of the optional I/F connections: (IEEE1284, IEEE802.11 (Wireless LAN), Bluetooth or Embedded RCG-M).
- Slot [B] is used for the USB Host.

SD Card Slot

- Slot [1] is used for optional printer/scanner application only.
- Slot [2] is used for PostScript3.
- Slot [3] is used for the Java VM Option or service use.

PostScript3 Installation

Installation Procedure




- 1. Remove the SD card slot cover [A] (x 1).
- 2. Install the PostScript3 SD card into the slot 2 [B].
- 3. Reinstall the SD card slot cover [A] (F x 1).
- 4. Turn on the main power switch.
- 5. Print out the configuration page (User Tools/ Counter > Printer Features > List/ Test Print), and then check that this device is detected.
- 6. Attach the "Adobe PostScript3" decal to the front cover of the machine.

Java VM Option Installation

Installation Procedure

SD card slot 3 is basically used only for service maintenance. Do not leave an SD card in slot 3 after installing an application.



b867i505



- 1. Remove the slot cover [A] from the SD card slot 3 (\mathscr{F} x 1).
- 2. Turn the SD-card label face to the rear of the machine. Then push it slowly into slot 3 [B] until you hear a click.
- 3. Turn on the main power switch.
- 4. Follow the vendor's installation procedure.
- 5. After installing, turn off the main power switch
- 6. Remove the SD card from slot 3.
- 7. Attach the slot cover [A] (Fx 1).


Wireless LAN (IEEE 802.11b) Installation

Component Check

No.	Description	Q'ty
1	Wireless Adapter	1
2	Wireless LAN Card	1
3	LAN Card Cover	4

4	Caution Sheet	1
5	Label	1

Installation Procedure



- 1. Remove the interface cover [A] (x 2).
- 2. Install the Wireless adaptor to the slot A [B] (x 2).
- 3. Install the Wireless LAN card to the wireless adaptor.
- 4. Attach the antenna cap to the wireless LAN card.
- 5. Turn on the main power switch.
- 6. Print out the configuration page (User Tools/Counter > Printer Features > List/Test Print), and then check that this device is detected.

If reception is poor, you may need to move the machine:

- Make sure that the machine is not located near an appliance or any type of equipment that could generate a strong magnetic field.
- Position the machine as close as possible to the access point.

SP Mode Settings for IEEE 802.11b Wireless LAN

The following SP commands can be set for IEEE 802.11b


SP No.	Name	Function
5840 004	SSID	Used to confirm the current SSID setting.
5840 006	Channel MAX	Sets the maximum range of the channel settings for the country.
5840 007	Channel MIN	Sets the minimum range of the channel settings allowed for your country.
5840 011	WEP Key Select	Used to select the WEP key (Default: 00).
5840 018	SSID Check	Used to check the SSID.
5840 020	WEP Mode	Used to display the maximum length of the string that can be used for the WEP Key entry.

IEEE 1284 Installation

Component Check

No.	Description	Q'ty
1	IEEE1284 Interface Ass'y	1
2	UL Sheet	1
3	Caution Sheet	1

Installation Procedure



- 1. Remove the interface cover [A] (F x 2).
- 2. Install the IEEE 1284 board in interface slot A [B] ($\ensuremath{\widehat{\mathcal{F}}} \times 2$).
- 3. Turn on the main power switch.
- 4. Print out the configuration page (User Tools/Counter > Printer Features > List/Test Print), and then check that this device is detected.


Bluetooth Installation

Component Check

No.	Description	Q'ty
1	Wireless Adapter	1
2	Bluetooth Card	1
3	Bluetooth Card Adapter	1
4	Bluetooth Card Cover	1

5	UL/FCC Sheet	1
6	Caution Sheet	1

Installation Procedure




- 1. Remove the interface cover [A] (F x 2).
- 2. Install the Wireless adaptor in interface slot A [B] (\mathscr{F} x 2).
- 3. Select an appropriate FCC label from the FCC sheet, and then attach the FCC label to the non-label side of the Bluetooth card.
- 4. Install the Bluetooth card in the wireless adaptor.
- 5. Attach the antenna cap to the Bluetooth card.
- 6. Turn on the main power switch.
- 7. Print out the configuration page (User Tools/ Counter > Printer Features > List/ Test Print), and then check that this device is detected.

USB Host Installation

Component Check

No.	Description	Q'ty
1	USB Host Interface Ass'y	1
2	USB Cable	1
3	Ferrite Core	1
4	Clamp	1
5	UL Sheet	1

Installation Procedure



b867i507

- 1. Remove the interface cover [A] (\mathscr{F} x 2).
- 2. Install the USB host board in the interface slot B [B] ($\hat{\mathbb{F}} \times 2$).
- 3. Turn on the main power switch.

- 4. Print out the configuration page (User Tools/ Counter > Printer Features > List/ Test Print), and then check that this device is detected.
- 5. Exit the User Tools mode.


Remote Communication Gate Installation

This option requires the printer/scanner application and DIMM 256 MB.

Component Check


No.	Description	Q'ty
1	Remote Comm. Gate Interface Ass'y	1
2	Cover	1
3	Screw	3

Installation Procedure



- 1. Remove the interface cover [A] (\mathscr{F} x 2).
- 2. Install the modern board into interface slot A [B] ($\mathscr{F} \times 2$).

- 3. Confirm the following SP settings before starting installation flow.
 - SP5-985-001 ("On Board NIC" is set to "0: OFF".)
 - SP5-816-150 (To Select the country)
 - SP5-816-154 (To set an outside connection telephone number)
 - SP5-816-161 (To set a telephone number)
- 4. Follow the Installation flow as shown below with SP mode.



2. Replacement and Adjustment

Main Board

Precautions


ACAUTION

- Turn off the main power switch and unplug the machine before starting replacement.
- Before turning off the main power switch, check that no mechanical component is operating.
 Mechanical components may stop out of their home positions if you turn off the main power switch while they are operating. The component may be damaged if you try to remove it when it is not in the home position.


Controller Board

Preparation


- Before replacing the controller board, be sure to print out SMC or save the NVRAM data.
- Saving from the Controller NVRAM to an SD card ("NVRAM Data Upload/Download [SP5-824/825]" in the chapter "Service Tables" of the this manual)




1. Remove the rear cover [A] ($\hat{\mathbb{F}}$ x 6)



2. Remove the FCU cover [B] (\mathscr{F} x 3).




- 3. Remove the SD-card cover [C] (${\hat{\mathbb{F}}}$ x 1), and then remove all SD cards in the SD slots.
- 4. Remove the controller-box cover [E] (\mathscr{F} x 7).
- 5. Remove the RAM DIMM [F] if it has been installed.
- 6. Remove the two I/F covers [G] (or I/F options if they have been installed).



b867r904

7. Remove the controller board with the rails [H] ($\hat{F} \times 5$).




b867r905

- 8. Release the hooks [I], and then pull out the rails [J].
- 9. Controller board



• When replacing the controller board, remove the NVRAMs from the board. Install the NVRAMs to the new board.

When replacing the NVRAM on the controller board



- 1. When you replace the NVRAMs [A], make sure that the NVRAMs are correctly installed.
- 2. The mark [B] on the NVRAM should be directed to the right side (seem from the back side of the machine).
- 3. Reassemble the machine.
- 4. Copy the old NVRAM data to the new NVRAM with SP5-825 or input the SMC data in the machine. (For details, refer to the "NVRAM Data Upload/Download [SP5-824/825]" in the chapter "Service Tables" of the this manual)

3. Troubleshooting

Service Call Conditions

Service Call Conditions

There are four levels of service call conditions.

Level	Definition	Reset Procedure	
A	To prevent damage to the machine, the main machine cannot be operated until the SC has been reset by a service representative (see the note below).	Enter SP mode, and then turn the main power switch off and on.	
В	If the SC was caused by incorrect sensor detection, the SC can be reset by turning the main power switch off and on.	Turn the main power switch off and on.	
С	The main machine can be operated as usual, excluding the unit related to the service call.	Turn the main power switch off and on.	
D	The SC history is updated. The machine can be operated as usual.	The SC will not be displayed. Only the SC history is updated.	



- If the problem concerns electrical circuit boards, first disconnect then reconnect the connectors before replacing the PCBs.
- If the problem concerns a motor lock, first check the mechanical load before replacing motors or sensors.

Important

- Do not try to use the operation panel during an automatic reboot.
- If the Remote Service System is used, the SC code is sent immediately to the Service Center

ACAUTION

Never turn off the main power switch when the power LED is lit or flashing. To avoid damaging the
hard disk or memory, press the operation switch to switch the power off, wait for the power LED to
go off, and then switch the main power switch off.

GW SC Code Descriptions

SC6xx

No. Definition	1	Symptom	Possible Cause/Countermeasure
		CSS communication error	
630	D	The machine tries to communicate with one of the terminals of a relevant service center. → An error signal returns.	Communication error on the public telephone network (logged only; the machine can still operate)
		MF accounting device error 1	
632	С	The machine sends a data frame. → No normal end signal returns. → This symptom happens three times.	Defective or broken line between machine and device
		MF accounting device error 2	
633	С	The machine is communicating with the accounting device. → The break signal returns.	Defective or broken line between machine and device
	С	MF accounting device error 3	
634		A backup RAM error is reported from the accounting device.	Defective accounting device controller Defective battery in the accounting
			device
	С	MF accounting device error 4	
635		C A battery voltage error is reported from	Defective accounting device controller
		the accounting device.	Defective battery in the accounting device
636	SD Card Error		
	В	Expanded authentication module error	
-001		There is no expanded authentication module in the machine.	Install the correct SD card or the file of the expanded authentication module.

No. Definition	1	Symptom	Possible Cause/Countermeasure
		The SD card or the file of the expanded authentication module is broken. There is no DESS module in the machine.	2. Install the DESS module.
		Version error	
-002	В	The version of the expanded authentication module is not correct.	Install the correct file of the expanded authentication module.
650	Com	munication error of the remote service mode	em (Embedded RCG-M)
		Authentication error	
-001	С	The authentication for the Embedded RCG-M fails at a dial up connection.	1. Check and set the correct user name (SP5816-156) and password (SP5816-157).
-004	С	Incorrect modem setting	
		Dial up fails due to the incorrect modem setting.	Check and set the correct AT command (SP5819-160).
		Communication line error	
-005	С	The supplied voltage is not sufficient due to the defective communication line or defective connection.	Consult with the user's local telephone company.
	С	Incorrect network setting	
-011		Both the NIC and Embedded RCG-M are activated at the same time.	1. Disable the NIC with SP5985-1.
		Modem board error	
-012	С	The modem board does not work properly even though the setting of the modem board is installed with a dial up connection.	 Install the modem board. Check and reset the modem board setting with SP5816. Replace the modem board.
651	Incorrect dial up connection		
-001	D	Program parameter error	

No. Definition	ı	Symptom	Possible Cause/Countermeasure	
		The unexpected error occurs when the modem (Embedded RCG-M) tries to call the center with a dial up connection.	Software bug.	
-002	D	Program execution error		
-002		Same as SC651-001.	Software bug.	
		Engine startup error		
670	В	Just after the main power is turned on or the machine is recovering from auto off mode, the engine ready signal assertion fails. Just after the main power is turned on, the engine does not respond.	 Poor connection between the BICU and controller board Defective BICU Defective controller board 	
		Controller-to-operation panel communication error at startup		
672	В	After powering on the machine, communication between the controller and operation panel does not begin, or the communication is interrupted after a normal startup.	 Controller stalled Controller board installed incorrectly Defective controller board Operation panel connector loose or defective Poor connection of DIMM and optional boards on the controller board Check the setting of SP5875-001. If the setting is set to "1 (OFF)", change it to "0 (ON)". 	

SC8xx

No. Definition		Symptom	Possible Cause/Countermeasure
818	В	Watchdog error	

			56
		While the system program is running,	Defective controller board
		no other programs can run (due to a bus hold or endless loop).	Reinstall the system program.
		bus note of chalcus toopy.	Replace the controller board.
819	Kernel stop		
		Process error	
		System completely down	Defective RAM DIMM
			Defective SD card in slot 1 (lowest slot)
			Defective controller
[0696e]	В		Software error
[00706]			Check and/or replace the RAM DIMM.
			Check and/or replace the SD card in slot 1 (lowest slot).
			3. Replace the controller.
	В		See NOTE at the end of the SC table.
		VM full error	
		B Unexpected system memory size	Defective RAM DIMM
			Defective SD card in slot 1 (lowest slot)
			Defective controller
[0766d]			Software error
			Check and/or replace the RAM DIMM.
			Check and/or replace the SD card in slot 1 (lowest slot).
			3. Replace the controller.
			See NOTE at the end of the SC table.
		Cache error	
[4361]	В	Cache error in the CPU	Defective CPU
			Replace the controller board.
[]	В	The others	

		Error in OS	 Defective memory Defective flash memory Defective CPU Replace the controller board. 		
	Self-Diagnostic Error: CPU				
		[0001-0015] [000A-000D]: Detailed	error code		
	В	During the boot monitor program and self-diagnostic, any exception or cut-in are not supposed to happen. If these happen, it is defined as SC.	 Defective CPU device Defective boot monitor program or self-diagnostic program Replace the controller board. Reinstall the system firmware. 		
		[00FF]: Detailed error code			
	В	Cache access error in the CPU	 Defective CPU Defective local bus 1. Turn the main power switch off and on. 2. Reinstall the system program. 3. Replace the controller board. 		
820		[0601, 0602, 0605, 0606, 0607, 0609]: Detailed error code			
	В	Exceptional command does not operate even though it is executed on purpose.	Defective CPU devices Replace the controller board.		
		[060A-060E]: Detailed error code			
	В	Cut-in command does not operate when it is executed.	 Defective CPU devices Defective ASIC devices Replace the controller board. 		
		[0610]: Detailed error code			
	В	Timer cut-in does not operate even though it is set.	Defective CPU devices Replace the controller board.		
	_	[0612]: Detailed error code			
	В	Cut-in in ASIC occurs.	Defective ASIC		

			 Defective devices in which ASIC detects cut-in. 1. Replace the controller board. 	
		[06FF]: Detailed error code	·	
	В	The pipeline clock frequency rate is different from the prescribed value.	 Defective CPU devices Mode bit data error, which is used for initializing CPU. Replace the controller board. 	
		[0702]: Detailed error code		
	В	The result when the program is executed in the command cache is different from desirable value.	 Insufficient CPU cache Insufficient memory process speed Replace the controller board. Replace the RAM DIMM. 	
		[0709, 070A]: Detailed error code		
	В	Even you write the data in the only cache of memory, the data is actually written in another area (not cache) of memory.	 Defective CPU devices Incorrect SPD Boot mode setting error Replace the controller board. Replace the RAM DIMM. 	
	В	[0801, 0804, 0807, 0808, 0809, 80A]: Detailed error code		
		An error occurs when checking the TLB.	Defective CPU devices Replace the controller board.	
		[4002-4005]: Detailed error code		
	В	The calculation error in the CPU occurs.	Defective CPU1. Replace the CPU.	
821	Self-	Diagnostic Error: ASIC		
		ASIC error		
[OBOO]	В	The write-&-verify check error has occurred in the ASIC.	Defective controller board Replace the controller.	

	В	ASIC not detected		
[OBO6]		The ASIC of the I/O is not detected.	 ASIC (controller board defective) Poor connection between North Bridge and PCI I/F. Replace controller board. 	
		SHM register check error	·	
[OB10]	С	Failed to initialize or could not read connection bus. Data in SHM register incorrect.	Defective bus connectionDefective SHMReplace controller board.	
[0D05]	В	The CPU checks if the ASIC timer works properly compared with the CPU timer. If the ASIC timer does not function in the specified range, this SC code is displayed.	 System firmware problem Defective RAM-DIMM Defective controller Reinstall the controller system firmware. Replace the RAM-DIMM. Replace the controller board. 	
822	Self-I	Diagnostic Error: HDD		
		[3003]: Timeout error/ [3004]: Command error		
[3003]	С	When the main switch is turned on or starting the self-diagnostic, the HDD stays busy for the specified time or more.	 Loose connection Defective HDD Defective controller 1. Check that the HDD is correctly connected to the controller. 2. Replace the HDD. 3. Replace the controller. 	
823	Self-	diagnostic Error: NIB		
		MAC address check sum error		
[6101]	С	The result of the MAC address check sum does not match the check sum stored in ROM.	Defective controller1. Replace the controller.	

[6104]	С	PHY IC error		
		The PHY IC on the controller cannot be correctly recognized.	Same as SC823-[6101]	
		PHY IC loop-back error		
[6105]	С	An error occurred during the loop-back test for the PHY IC on the controller.	Same as SC823-[6101]	
		Self-diagnostic Error: NVRAM		
824	В	The controller cannot recognize the standard NVRAM installed or detects that the NVRAM is defective.	 NVRAM damaged or abnormal Backup battery has discharged NVRAM socket damaged Replace the NVRAM. 	
		Self-diagnostic Error: RTC/Optional N	VRAM	
		[1501]: Clock error		
826	В	 An RTC device is recognized, and the difference between the RTC device and the CPU exceeds the defined limit. No RTC device is recognized. 	 RTC defective NVRAM without RTC installed Backup battery discharged Replace the NVRAM with another NVRAM with an RTC device. 	
	В	[15FF]: RTC not detected		
		The RTC device is not detected.	 NVRAM without RTC installed Backup battery discharged Replace the NVRAM with another NVRAM with an RTC device. 	
827	Self-	diagnostic Error: RAM		
		Verification error		
[0201]	В	Error is detected during a write/verify check for the standard RAM (SDRAM DIMM).	 Loose connection Defective SDRAM DIMM Defective controller Replace the SDRAM DIMM. Replace the controller. 	

[0202]	В	Resident memory error		
		The SPD values in all RAM DIMM are incorrect or unreadable.	 Defective RAM DIMM Defective SPD ROM on RAM DIMM Defective 12C bus Replace the RAM DIMM. 	
828	Self-	diagnostic Error: ROM		
		Boost lap code error		
[0101]	В	The boot monitor and OS program stored in the ROM DIMM is checked. If the check sum of the program is incorrect, this SC code is displayed.	 Defective ROM DIMM Defective controller Replace the ROM DIMM. Replace the controller. 	
		ROMFS error		
[0104]	В	All areas of the ROM DIMM are checked. If the check sum of all programs stored in the ROM DIMM is incorrect, this SC code is displayed.	Defective ROM DIMM Replace the ROM DIMM.	
829	Self-	diagnostic Error: Optional RAM		
		Verification error (Slot 1)		
[0401]	С	The data stored in the RAM in Slot 1 does not match the data when reading.	 Not specified RAM DIMM installed Defective RAM DIMM Replace the RAM DIMM. Replace the controller board. 	
		Composition error (Slot 1)		
[0402]	С	The result of checking the composition data of the RAM in Slot 1 on the controller is incorrect.	 Not specified RAM DIMM installed Defective RAM DIMM Replace the RAM DIMM. Replace the controller board. 	
838	В	Self-diagnostic Error: Clock Generator		

		A verify error occurred when setting data was read from the clock generator via the I2C bus.	 Defective clock generator Defective I2C bus Defective I2C port on the CPU Replace the controller board. 		
		IEEE1394 I/F abnormal			
851	С	The IEEE1394 interface cannot be used, due to a driver error.	IEEE1394 interface board defectiveDefective controller board		
		Wireless card startup error			
853	С	The machine starts up. → The IEEE802 11b card connection board is recognized. → The wireless LAN card or bluetooth card is not recognized.	Loose connection between the wireless card and the connection board		
		Wireless card access error			
854	С	The machine has been reading the data from the card. → The machine loses access to the card; the wireless LAN card or bluetooth card connection board is still recognized.	Loose connection between the wireless card and the connection board		
855	С	Wireless card error			
633		Some illegal data is found in the card.	Defective wireless card		
		Wireless card connection board error			
856	С	An error is detected in the wireless LAN card or bluetooth card connection board.	Defective wireless card connection board		
		USB I/F Error			
857	С	USB interface error is detected.	 Defective controller 1. Check the USB connections, and make sure that they are securely connected. 2. Replace the controller board. 		
860	С	HDD startup error at main power on			

			No formatted HDD	
		HDD is connected but a driver error is detected.	Label name input during formatting is corrupted.	
		The driver does not respond with the	Defective HDD	
		status of the HDD within 30 s.	1. Reformat the HDD.	
			2. Replace the HDD.	
		HDD reboot error		
			Loose connection	
			Defective cables	
			Defective HDD	
861	В	The HDD does not become ready	Defective controller	
		within 30 seconds after the power is supplied to the HDD.	Check the connection between the HDD and controller.	
			2. Check and replace the cables.	
			3. Replace the HDD.	
			4. Replace the controller.	
	В	HDD read error		
			Bad sector detected during operation of the HDD	
			Defective HDD	
		The data stored in the HDD cannot be	Defective controller	
863			1. Reformat the HDD.	
		read correctly.	Replace the HDD when SC863 occurs more than ten times or it takes more than twenty seconds to get ready condition.	
			3. Replace the controller board.	
		HD data CRC error		
864	В	While reading data from the HDD or storing data in the HDD, data transmission fails.	Defective HDD	
865	В	HD access error		

		An error other than SC863 and SC864 is detected while operating the HDD.	Defective HDD
		SD card authentication error	
866	С	A digital license error of an SD card application is detected.	SD card data has corrupted. Store correct data in the SD card.
		SD card error	
867	В	An application SD card is removed from the boot slot while an application is activated.	An application SD card is ejected.
		SD card access error	
		(-13 to -3: File system error, other numb	per: Device error)
			SD card not inserted correctly SD card defective
			Controller board defective
868	В	An error report is sent from the SD card reader.	For a file system error, format the SD card on PC.
			For a device error, turn the main switch off and on.
			3. Remove and re-install the SD card.
			4. Replace the SD card.
			5. Replace the controller.
		Address book data error	
870	С	The address book in the hard disk is accessed. → An error is detected in the address book data; address book data is not read; or data is not written into the address book	 Data corruption Defective hard disk Defective controller software Replace the hard disk (the user codes
		 To recover from the error, do any of the following countermeasures: Format the address book by using SP5-846-050 (all data in the address book–including the user 	and counters are recovered when the main switch is turned on if those data are stored in Smart Device Monitor for Admin).

		codes and counters-is initialized).		
		HDD received mail data error		
			Defective HDD	
872	С	An error is detected in the received mail	 Power failure during an access to the HDD 	
		data partition of the HDD at machine initialization.	 Initialize the HDD partition (SP5-832-007). 	
			2. Replace the HDD.	
		HDD sent mail data error		
			Defective HDD	
873	С	An error is detected in the sent mail data	 Power failure during an access to the HDD 	
		partition of the HDD at machine initialization.	 Initialize the HDD partition (SP5-832-008). 	
			2. Replace the HDD.	
		Delete All error 1: HDD		
	В	An error is detected while the all data of the HDD or NVRAM are formatted physically by the Data Overwrite Security Unit (B735).	 Not installed Data Overwrite Security Unit (SD card) 	
874			Defective HDD	
			 Install the Data Overwrite Security Unit (B735). 	
			2. Replace the HDD.	
		Delete All error 2: Data area		
875	В	An error is detected while the all data of the HDD or NVRAM are formatted logically by the Data Overwrite Security Unit (B735).	The logical format for HDD fails.1. Turn the main switch off/on and try the operation again.	
876	Log Data Error			
		Log Data Error 1		
-001	В	An error was detected in the handling of the log data at power on or during machine operation. This can be caused	Damaged log data file in the HDD1. Initialize the HDD with SP5832-004.	

		by switching the machine off while it is operating.	
		Log Data Error 2	
-002	В	Same as -001	An encryption module not installedDisable the log encryption setting.Install the encryption module
		Log Data Error 3	
-003	В	Same as -001	 Invalid encryption key log due to defective NVRAM data 1. Initialize the HDD with SP5832-004.
			2. Disable the log encryption setting.
		Log Data Error 4	
-004	В	Same as -001	Unusual encryption function log due to the defective NVRAM data
			1. Initialize the HDD with SP5832-004.
		Log Data Error 5	
-005	В	B Same as -001	 Installed NVRAM or HDD, which is used in other machine
			 Reinstall the previous NVRAM or HDD.
			2. Initialize the HDD with SP5832-004.
		Log Data Error 99	
-099	В	Same as -001	Other than above causes
		Same as -00 I	1. Ask your supervisor.
		HDD Data Overwrite Security SD card &	error
877	С		• Defective SD card (B735)
		The all delete cannot be executed even though the Data Overwrite Security Unit (B735) is installed and activated.	 Not installed SD card (B735) Replace the NVRAM and then install the new SD card (B735).
			Check and reinstall the SD card (B735).

		File Format Converter (MLB) error	
880	В	A request to get access to the MLB was not answered within the specified time.	MLB defective

SC9xx

		Electronic total counter error		
900	В	The value of the total counter is out of the normal range.	Defective NVRAM	
		Printer error		
920	С	An application error that stops the machine operation is detected.	 Defective software 1. Unexpected hardware resource (e.g., memory shortage) 	
		Printer font error		
921	С	A necessary font is not found in the SD card when the printer application starts.	 A necessary font is not found in the SD card. The SD card data is corrupted. 1. Check that the SD card stores correct data. 	
		Software performance error		
990	В	The software attempted to perform an unexpected operation. NOTE: When this error occurs, the file name, address, and data will be stored in NVRAM. This information can be checked by using SP7-403. See the data and the situation in which this SC occurs. Then report the data and conditions to your technical control center.	 Software defective Internal parameter incorrect Insufficient working memory 	
		Software continuity error		
991	D	The software attempted to perform an unexpected operation. However,	Logged only; the machine can continue to operate	

		unlike SC990, the process can keep on running.		
		Undefined error		
992	В	An error not controlled by the system occurred (the error does not come under any other SC code).	Defective software program	
		Application function selection error		
	С	The application selected by a key press on the operation panel does not start or ends abnormally.	Software for that application is defective	
997			 An option required by the application (RAM, DIMM, board) is not installed. 	
			 Too complicated nest of the fax group address 	
			 As for the fax operation problem, simplify the nest of the fax group address. 	
	В	Application start error		
		After switching the machine on, the application does not start within 60 s. (No applications start or end normally.)	Software for that application is defective	
998			 An option required by the application (RAM, DIMM, board) is not installed. 	
			 Check the setting of SP5875-001. If the setting is set to "1 (OFF)", change it to "0 (OFF)". 	

4. Service Tables

Service Program Mode

CAUTION

- Before accessing the service menu, do the following:
- Confirm that there is no print data in the printer buffer (the 'Data In' LED must not be lit or blinking).
- If there is some data in the buffer, wait until all data has been printed.

ACAUTION

• Never turn off the main power switch when the power LED is lit or flashing. To avoid damaging the hard disk or memory, press the operation power switch to switch the power off, wait for the power LED to go off, and then switch the main power switch off.



The main power LED (※①) lights or flashes while the platen cover or ARDF is open; while the main
unit is communicating with a facsimile or the network server; or while the machine is accessing the
memory for reading or writing data.

Enabling and Disabling Service Program Mode

Entering the SP Mode

\$	1.	Press the Clear Mode key.	
107	2.	Use the keypad to enter "107".	
(C/O)	3.	Hold down Clear/Stop for at least 3 seconds.	
	4.	Enter the Service Mode.	
Printer SP		Select "Printer SP" to enter printer SP mode.	
Scanner SP		Select "Scanner SP" to enter scanner SP mode.	

Exiting the Service Mode

Press the cancel key to exit from the service mode.

GW SP Mode Tables

The tables in this section list the service programs (SPs).

The following codes are used:

- Asterisk (*): The settings are saved in the NVRAM. Most of them return to the default values when you
 execute SP 5801 2.
 - CTL indicates that the data is contained in the NVRAM on the controller board.
- The DFU menu is for design or factory use only. You must not change the settings.
- Brackets ([]): The brackets enclose the setting rage, default value, and minimum step (with unit) as follows: [Minimum to Maximum / **Default** / Step].
- SSP: Consult your supervisor before you use this program.

SP4-XXX (Mode)

4921*	[Image Adj Selection]	
	Сору	[0 to 10 / 0 / 1]
001	Selects which mode the settings from SP4-922 to SP4-932 are used for. 0 = None, 1 = Text 1, 2 = Text 2, 3 = Photo 1, 4 = Photo 2, 5 = Photo 3, 6 = Special 1, 7 = Special 2, 8 = Special 3, 9 = Special 4, 10 = Special 5	
	Fax	[0 to 5 / 0 / 1]
002	Selects which mode the settings from SP4-922 to SP4-932 are used for. 0 = None, 1 = Text 1, 2 = Text 2, 3 = Photo 1, 4 = Photo 2, 5 = Special 1	
	Scanner	[0 to 4 / 0 / 1]
003	Selects which mode the settings from SP4-922 to SP4-932 are used for. 0 = None, 1 = Text 1, 2 = Text 2, 3= Photo 1, 4 = Photo 2	

	[Scanner Gamma]	
4922*	Selects "text" or "photo" as the priority output mode. This setting is applied to all image processing modes of SP4-921.	
001	Copy [0=System default/ 1=Text/ 2=Photo]	

4

	[Notch Selection]	
	Selects the value of the center ID adjustment notch for the ID adjustment LEDs.	
• Normally the center notch is 3 (range 1-5). If -1 is selected, each notch (becomes lighter). If +1 is selected, each notch shifts up (becomes dark		
	This setting is applied to all image processing modes of SP4-921.	
001	Сору	
002	Fax	[-1 = Light / 0 = Normal / +1 = Dark]
003	Scanner	

	[Texture Removal]		
4926*	Adjusts the texture removal level that is used with error diffusion. 0: The default value for each mode is used. Text 1, Photo 2, Special 2, and Special 5 have a default of 3 and Photo 1-3 have a default of 1.		
	1: No removal applied.		
	2 to 5: Removal applied at the level specified here. The higher the setting (level), the less clear the image will become (more texture removal). This setting is only applied to the originals in SP4-921.		
001	Сору		
002	Fax	[0 to 6 / 0 / 1/step]	
003	Scanner		

	[Line Width Correction]	
4927*	Adjusts the line width correction algorithm. Positive settings produce thicker lines; negative settings produce thinner lines. This setting is only applied to the originals in SP4-921.	
001	Сору	
002	Fax	[-2 to 2 / 0 / 1/step]
003	Scanner	

4928*	[Independent Dot Erase]		
	Selects the dot erase level. Higher settings provide greater erasure. This setting is only applied to the originals in SP4-921.		
001	Сору		
002	Fax	[-2 to 2 / 0 / 1/step]	
003	Scanner		

	4929*	[Positive/Negative]	[0 = No, 1 = Yes]
Inverts white and black. This setting is only applied to		Inverts white and black. This setting	g is only applied to the originals in SP4-921.
	001	Сору	
	002	Fax	

4930*	[Sharpness-Edge]	[-2 to 2 / 0 / 1/step]
4730	Adjust the clarity. This setting is only applied to the originals in SP4-921.	
001	Сору	
002	Fax Scanner	
003		

4931*	[Sharpness-Solid]	[-2 to 2 / 0 / 1/step]
4731	Adjust the clarity. This setting is on	ly applied to the originals in SP4-921.
001	Сору	
002	Fax Scanner	
003		

4932*	[Sharpness-Low ID]	[-2 to 2 / 0 / 1/step]		
Adjust the clarity. This setting is only applied to the originals in SP4-921.		ly applied to the originals in SP4-921.		
001	Сору			
002	Fax			

003 Scanner

SP5-XXX (Mode)

	5001	[All Indicators On]	
OO1 All LEDs turn on. The LCDs turn on or off with "ON" or "OFF" key.		All LEDs turn on. The LCDs turn on or off with "ON" or "OFF" key.	

Selects whether mm or inches are used in the display.

Note

After selecting the number, you must turn the main power switch off and on.

Europe/Asia model: [0: mm / 1: inch]

American model: [0: mm / 1: inch]

Slects the counting display if the meter charge mode is enabled with SP5-930-001.

Note

You can change the setting only one time.

[0 to 2/0/1/step]
0: 1 counter (Total)
1: 2 counters (Total and Prints)
2: 2 counters GPC

5051	[Refill Toner Displ] Refill Toner Detection Display			
3031	Enables or disables the toner refill detection display.			
001	Refill Toner	CTL	[0 or 1 / 0 /-] 0: ON, 1: OFF	

5055	[Display IP address]		
001	Display IP address	CTL	Displays or does not display the IP address on the LCD. [0 or 1 / 0 / -]

0: No, 1: Yess

5056	[Coverage Counter]			
001	Coverage Counter	CTL	Displays or does not display the coverage counter on the LCD. [0 or 1 / 0 / -] 0: Not display, 1: Display	

5104*	[A3 Double Count] SSP			
5104"		A3 Double Count	CTL	[0 = No / 1 = Yes / 2 = No Unclear]
	001	Selects whether the machine counts twice for each sheet of A3/11"x 17". If this is set to "Yes", the total (mechanical) counter and the current user counter will both increment by two for each A3/11" x 17" sheet.		

5112	[Non-Std. Paper Set] Non-Standard Paper Set	
001	Determines whether a non-standard paper size can be input for the universal cassette trays (Tray 2, Tray 3) [0 or 1 / 0 / -]	
001	0: No	
	1: Yes. If "1" is selected, the customer will be able to input a non-standard paper size using the UP mode.	

5113	[Optional Counter Type]		
			This program specifies the counter type.
			0: None
			1: Key card (RK 3, 4)
001	Optional Counter Type 1	CTL	2: Key card (down)
			3 to 10: Japan only
			11: Exp. key card (Add)
			12: Exp. key card (Deduct)
			This program specifies the external counter type.
002	Optional Counter Type 2	CTL	0: None
			1: Expansion device 1

			2: Expansion device 2
			3: Expansion device 3
5114	[MF Key Card Ext.]	CTL	[0: Not installed/ 1: Installed (scanning accounting)]
001	Japan use		
5118	[Disable Copying]	CTL	[0: Not disabled/ 1: Disabled]
001	This program disables copying.		
5120*	[Clr For Cnt Remove]	CTL	[0=Yes / 1=Standby only / 2=No]
001	Determines under which conditions the copy job settings are reset when the key counter is removed. With 0, the settings are cleared if the counter is removed at the end of a job or midway through a job. With 1, they are only cleared if the counter is removed at the end of a job. With 2, they are not cleared at all, under either condition. With duplex copies, the job settings are always preserved, regardless of the setting of this SP mode.		
5121*	[Counter Up Timing]	CTL	[0 = Feed In / 1 = Exit]
3121	[Counter of Inning]		
001	Selects whether the key cour	ter increm	ents at time of paper feed-in or at time of paper exit.
5127	[APS Mode]	CTL	[0: Not disabled/ 1: Disabled]

5150	[By-pass Long Paper]	CTL	[0 = Feed In / 1 = Exit]
001		sub scar	rom the by-pass tray is used or not. nning paper from the by-pass tray is limited to 600 SP to 1260 mm.

001

This program disables the APS.

		[Fax Printing Cnt Off]			
516	57	Enables or disables the automatic print out without an accounting device. This SP is use when the receiving fax is accounted by an external accounting device.			
	001	Fax Printing Counter Off	CTL	[0 or 1 / 0 / –] 0: Automatic printing	

	1: No automatic printing	
--	--------------------------	--

	[CE Login]		
5169	If you change the printer bit switches, you must 'log in' to service mode with this SP before you go into the printer SP mode.		
001	CE Login	CTL	[0 or 1 / 0 / -] 0: Disabled 1: Enabled

5188	[Copy NV Version]		
001	Copy NV Version	CTL	Displays the NVRAM version in the controller board.

	[Set Time]				
	Adjusts the RTC (real time clock) time setting for the local time zone.				
	Examples: For Japan (+9 GMT), enter 540 (9 hours x 60 min.)				
	DOM: +540 (Tokyo)				
5302	302 NA :-300 (New York)				
	EU :+ 60 (Paris)				
	CH :+480 (Peking)				
	TW :+480 (Taipei)				
	AS :+480 (Hong Kong)				
002	Time Difference	CTL #	[-1440 to 1440 / Area / 1 min./step]		

5307	[Summer Time]	
001	ON/OFF - Enables or disables the summer time r	[0 or 1 / NA, EU, ASIA / 1 /step] 0: Disabled 1: Enabled NA and EUR: 1, ASIA: 0

	Note				
	Make sure that both SP5- activated even if this SP is		nd -4 are correctly set. Otherwise, this SP is not ".		
	Start	-	-		
	Specifies the start setting for the	e summe	r time mode.		
	There are 8 digits in this SP. For months 1 to 9, the "0" cannot be input in the first digit, so the eight-digit setting for -2 or -3 becomes a seven-digit setting.				
	1st and 2nd digits: The month.	[1 to 12]		
	3rd digit: The week of the mon	th. [1 to	5]		
003	4th digit: The day of the week.	[0 to 6 =	= Sunday to Saturday]		
003	5th and 6th digits: The hour. [C	00 to 23]			
	7th digit: The length of the adv	anced tir	ne. [0 to 9 / 1 hour /step]		
	8th digit: The length of the advanced time. [0 to 5 / 10 minutes /step]				
	For example: 3500010 (EU default)				
	The timer is advanced by 1 hour at am 0:00 on the 5th Sunday in March				
	The digits are counted from the left.				
	Make sure that SP5-307-1 is set to "1".				
	End	-	-		
	Specifies the end setting for the summer time mode.				
	There are 8 digits in this SP.				
	1st and 2nd digits: The month. [1 to 12]				
004	3rd digit: The week of the month. [0 to 5]				
004	4th digit: The day of the week. [0 to 6 = Sunday to Saturday]				
	5th and 6th digits: The hour. [00 to 23]				
	The 7th and 8th digits must be	set to "O	0".		
	The digits are counted fro	m the lef	t.		
	Make sure that SP5-307-	-1 is set to	o "l".		

5401	[Access Control]					
3401	When installin	g the SDI	K application, SAS (VAS) adjusts the following settings. DFU			
006	С	CTL	SSP: These SPs are not disclosed due to the security protection.			

016	DS	CTL	
026	F	CTL	
036	S	CTL	
046	P	CTL	
076	SDK 1	CTL	
086	SDK 2	CTL	
096	SDK 3	CTL	
200	SDK1 Unique ID	CTL	This ID is overwritten by SAS (VAS) when you install or uninstall the SDK application.
201	SDK1 Certification Method	CTL	[0 to 255 / 0 / 1 /step] DFU
210	SDK2 Unique ID	CTL	DFU
211	SDK2 Certification Method	CTL	[0 to 255 / 0 / 1 /step] DFU
220	SDK3 Unique ID	CTL	DFU
221	SDK3 Certification Method	CTL	[0 to 255 / 0 / 1 /step] DFU

5404	[User Code Clear]
001	Clears the counts for the user codes assigned by the key operator to restrict the use of the machine. Press [Execute] to clear.

5501	[PM Alarm Interval]	CTL	-
001	D	[0 to 9999 / 0 / 1 /step]	
001 Printout		0: Alarm	off

		1 to 9999: Alarm goes off when the PM counter reaches the specified value (1 to 9999) x 1000.
002	ADF	[0 or 1 / 1 / -] 0: No alarm sounds 1: Alarm sounds after the number of originals passing through the A(R)DF ≥ 10,000

5504	[Jam Alarm]	CTL	-	
	Sets the alarm to sound fo	r the specif	ied jam level (document misfeeds are not included).	
001 [0 to 3 / 3 / 1 /step]				
	0: Zero (Off), 1: Low (2.5K jams), 2: Medium (3K jams), 3: High (6K jams)			

5505*	[Error Alarm]
001	Sets the error alarm level. The error alarm counter counts "1" when any SC is detected. However, the error alarm counter decreases by "1" when any SC is not detected during specified sheets of copies (for example, default 1500 sheets).
	The error alarm occurs when the SC error alarm counter reaches "5".
	[0 to 255 / 15 / 100 copies per step]

5507	[Supply Alarm]	CTL	-		
001	Paper Size	0 : Off, 1:	On,		
003	Toner	0 : Off, 1:	0 : Off, 1: On,		
128	Interval :Others				
132	Interval :A3	[250 to 10000 / 1000 / 1 /step]			
133	Interval :A4				
134	Interval :A5				
141	Interval :B4				
142	Interval :B5				
160	Interval :DLT				

164	Interval :LG
166	Interval :LT
172	Interval :HLT

5508*	[Auto Call Setting]	CTL	-		
001*	Jam Remains	0:	Disable, 1: Enable		
001	Enables/disables initiating a call	l for an	unattended paper jam.		
002*	Frequent Jams	0:	Disable, 1: Enable		
002	Enables/disables initiating a call	l for co	nsecutive paper jams.		
003*	Door Open	0:	Disable, 1: Enable		
003	Enables/disables initiating a call	l when	the front door remains open.		
	Jam Remains: Time	[0	3 to 30 / 10 / 1 minute /step]		
011*	Sets the time a jam must remain before it becomes an "unattended paper jam". This setting is enabled only when SP5508 004 is set to 1.				
	Freq Jam: # of Time	[0	2 to 10 / 5 / 1 /step]		
012*	Sets the number of consecutive paper jams required to initiate a call. This setting is enabled only when SP5508 004 is set to 1.				
	Door Open: Time	[0	3 to 30 / 10 / 1 minute/step]		
013*	Sets the length of time the door remains open before the machine initiates a call.				
	This setting is enabled only when SP5508 004 is set to 1.				
	Jam Remains: Mode	0:	Automatic Call		
021*		1:	Audible Warning at Machine		
	Determines what happens when a paper jam is left unattended.				
	Freq Jam: Mode	0:	Automatic Call		
022*	Troq yanni maas	1:	Audible Warning at Machine		
	Determines what happens when a paper jam happens continually.				
023*	Door Open: Mode	0:	OFF, 1: ON		
023	Determines what happens if the door remains open (15 min.).				

Displays a warning if set to ON. Pressing the call button will contact the service center.

	[SC/Alarm Setting]	CTL	-	
5515			pe set to issue an SC call when an SC error occurs. issued when an SC error occurs.	
001	SC Call			
002	Service Parts Near End	-		
003	Service Parts End	<u> </u>		
004	User Call	[0 or 1 / 1 / -] 0: Off, 1: On		
006	Communication Test			
007	Machine Information			
008	Alarm Notice			
010	Supply Automatic Order	[0 1 /0 / 10 0 W 1 0		
011	Supply Management Report	[0 or 1 / 0 / -] 0: Off, 1: On		
012	Jam/Door Open Call	[0 or 1 /	1 / -] 0: Off, 1: On	

5801	[Memory Clear] Before executing any of these SP codes, print an SMC Report.			
	All Clear			
001	Initializes items SP5801-002 to -014 below. Turn the main power switch off and on after executing this SP.			
003	SCS	-	-	
003	Clears the system settings.			
004	IMH	-	-	
004	Clears IMH data. DFU			
005	MCS	-	-	
	Clears MCS data. DFU			
006	Copier	-	-	

	Clears the copy application settings.			
007	Fax	-	-	
007	Clears the fax application s	ettings.		
008	Printer	-	-	
008	Clears the printer application	n settings.		
009	Scanner	-	-	
009	Clears the scanner applicat	ion settings		
	GWWS	-	-	
010	Delete the netfile application ID.	ı managem	ent files and thumbnails, and initializes the job login	
	NCS	-	-	
011	Initializes the system default and interface settings (IP address also), SmartNetMonitor for Admin, WebStatusMonitor settings, and the TELNET settings.			
	The name of Apple talk is not cleared only if this SP is executed. Turns off and on after executing this SP.			
	R-FAX	-	-	
012	Initializes the job login ID, SmartNetMonitor for Admin, job history, and local storage file numbers.			
014	Clear DCS Setting	-	-	
014	Initializes the DCS (Delivery Control Service) settings.			
015	Clear UCS Setting	-	-	
013	Initializes the UCS (User Information Control Service) settings.			
016	MIRS Setting	-	-	
010	Initializes the MIRS (Machir	ne Informati	on Report Service) settings.	
017	CCS	-	-	
017	Initializes the CCS (Certifica	ition and C	harge-control Service) settings.	
018	SRM Memory Clr	-	-	

	Initializes the SRM (System Resource Manager) settings.		
010	LCS	-	-
019	Initializes the LCS (Log Count Service) settings.		

5811*	[Machine Serial] Machine Se	erial Numb	per
001	Set	-	("Serial Number Input")

5812	[Service TEL]		
	Telephone	CTL	-
001	Sets the telephone number for a service representative. This number is printed on the Counter List, which can be printed with the user's "Counter" menu. This can be up to 20 characters (both numbers and alphabetic characters can be input).		
	Facsimile	CTL	-
002	Sets the fax or telephone number for a service representative. This number is printed on the Counter List.		
	This can be up to 20 charac	cters (both i	numbers and alphabetic characters can be input).

5816	[NRS Function]	CTL	-
		Selects the	e remote service setting.
		[0 to 2 /	2 / 1 /step]
001	I/F Setting	0: Remote	e service off
		1: CSS re	mote service on
		2: @Remo	ote service on
		Performs t	he CE Call at the start or end of the service.
		[0 or 1 /	0 / 1 /step]
002		0: Start of	the service, 1: End of the service
002		UNote	
		• This "2".	SP is activated only when SP 5816-001 is set to
000	F .: FI	Enables o	r disables the remote service function.
003	003 Function Flag		0 / 1 /step]

		0: Disabled, 1: Enabled	
007	SSL Disable	Uses or does not use the RCG certification by SSL when calling the RCG. [0 or 1 / 0 / 1 /step] 0: Uses the RCG certification 1: Does no use the RCG certification	
008	RCG Connect Timeout Specifies the connect timeout interval when calling the RC [1 to 90 / 10 / 1 second/step]		
009	RCG Write Timeout	Specifies the write timeout interval when calling the RCG. [1 to 100 / 60 / 1 second/step]	
010	RCG Read Timeout Specifies the read timeout interval when calling the RCG [1 to 100 / 60 / 1 second/step]		
011	Port 80	Enables/disables access via port 80 to the SOAP method. [O or 1 / 0 / -] O: Disabled, 1: Enabled	
	Function Flag		
021	This SP displays the embedded RCG installation end flag. 1: Installation completed 2: Installation not completed		
	Install Status		
022	This SP displays the RCG device installation status. 0: RCG device not registered 1: RCG device registered 2: Device registered		
	Connect Mode (N/M)		
023	This SP displays and selects the embedded RCG connection method. O: Internet connection 1: Dial-up connection		
061	NotiTime ExpTime DFU		

	Proximity of the expiration of the certification.
062	HTTP Proxy Use
	This SP setting determines if the proxy server is used when the machine communicates with the service center.
	HTTP Proxy Host
063	This SP sets the address of the proxy server used for communication between embedded RCG-N and the gateway. Use this SP to set up or display the customer proxy server address. The address is necessary to set up embedded RCG-N.
	 Note The address display is limited to 127 characters. Characters beyond the 127th character are ignored.
	This address is customer information and is not printed in the SMC report.
	HTTP Proxy Port Number
064	This SP sets the port number of the proxy server used for communication between embedded RCG N and the gateway. This setting is necessary to set up embedded RCG-N.
	Note This part number is sustance information and is not printed in the SMC report
	This port number is customer information and is not printed in the SMC report.
	HTTP Proxy Aut Usr
	This SP sets the HTTP proxy authentication user name.
065	Note
	 The length of the name is limited to 31 characters. Any character beyond the 31st character is ignored.
	 This name is customer information and is not printed in the SMC report.
	HTTP Proxy Aut Pass
	This SP sets the HTTP proxy authentication password.
066	Note
000	• The length of the password is limited to 31 characters. Any character beyond the 31st character is ignored.
	This name is customer information and is not printed in the SMC report.
067	Cer Updt Cond

	Displ	ays the status of the certification update.		
	0	The certification used by embedded RCG is set correctly.		
	1	The certification request (setAuthKey) for update has been received from the GW URL and certification is presently being updated.		
	2	The certification update is completed and the GW URL is being notified of the successful update.		
	3	The certification update failed, and the GW URL is being notified of the failed update.		
	4	The period of the certification has expired and a new request for an update is being sent to the GW URL.		
	11	A rescue update for certification has been issued and a rescue certification setting is in progress for the rescue GW connection.		
	12	The rescue certification setting is completed and the GW URL is being notified of the certification update request.		
	13	The notification of the request for certification update has been completed successfully, and the system is waiting for the certification update request from the rescue GW URL		
	14	The notification of the certification request has been received from the rescue GW controller, and the certification is being stored.		
	15	The certification has been stored, and the GW URL is being notified of the successful completion of this event.		
	16	The storing of the certification has failed, and the GW URL is being notified of the failure of this event.		
	17	The certification update request has been received from the GW URL, the GW URL was notified of the results of the update after it was completed, but a certification error has been received, and the rescue certification is being recorded.		
	18	The rescue certification of No. 17 has been recorded, and the GW URL is being notified of the failure of the certification update.		
068	Cer Abnml Cause			
	Displays a number code that describes the reason for the request for update of the certification.			
	0	Normal. There is no request for certification update in progress.		
	Cer A	The rescue certification of No. 17 has been recorded, and the GW URL is being notified of the failure of the certification update. Abnml Cause ays a number code that describes the reason for the request for update of the ication.		

	1	Request for certification update in progress. The current certification has expired.		
	2	An SSL error notification has been issued (after the certification has expired).		
	3	Notification of shift from a common authentication to an individual certification.		
	4	Notification of a common certification without ID2.		
	5	Notification that no certification was issued.		
	6	Notification that GW URL does not exist.		
069	Cert:	Updtt ReqID		
009	The II	O of the request for certification.		
002	Firm l	Jpdating		
083	Displays the status of the firmware update.			
004	Firm UpFlg No HDD			
084	This s	etting determines if the firmware can be updated, even without the HDD installed.		
085	Firm l	Jp Usr Conf		
	befor select	P setting determines if the operator can confirm the previous version of the firmware e the firmware update execution. If the option to confirm the previous version is ted, a notification is sent to the system manager and the firmware update is done with mware files from the URL.		
	Firmv	vare Size		
086	Allows the service technician to confirm the size of the firmware data files during the firmware update execution.			
	CERT	: Macro Version		
087	Displays the macro version of the @Remote certification.			
088	CERT: PAC Version			
000	Displ	ays the PAC version of the @Remote certification.		
	CERT	: ID2 Code		
089		ays ID2 for the @Remote certification. Spaces are displayed as underscores (_). isks (*) indicate that no @Remote certification exists.		
090	CERT	: Subject		

CERT: Serial Number Displays serial number for the @Remote certification. Asterisks (*) indicate that no DESS exists. CERT: Issuer Displays the common name of the issuer of the @Remote certification. CN = the following 30 bytes. Asterisks (*) indicate that no DESS exists. CERT: St ExpTime Displays the start time of the period for which the current @Remote certification is enabled. CERT: End ExpTime Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-154 SP5816-154 SP5816-154 SP5816-155 Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. The current progress, success, or failure of this execution can be displayed with SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		Displays the common name of the @Remote certification subject. CN = the following 17 bytes. Spaces are displayed as underscores (_). Asterisks (*) indicate that no DESS exists.
Displays send number for the @Remote certification. Asterisks () indicate that no DESS exists. CERT: Issuer Displays the common name of the issuer of the @Remote certification. CN = the following 30 bytes. Asterisks (*) indicate that no DESS exists. CERT: St ExpTime Displays the start time of the period for which the current @Remote certification is enabled. CERT: End ExpTime Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M. **SP5816-153** SP5816-154** SP5816-154** SP5816-161* 0: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. **The current progress, success, or failure of this execution can be displayed with SP5816 152. **If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		CERT: Serial Number
Displays the common name of the issuer of the @Remote certification. CN = the following 30 bytes. Asterisks (*) indicate that no DESS exists. CERT: St ExpTime Displays the start time of the period for which the current @Remote certification is enabled. CERT: End ExpTime Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. The current progress, success, or failure of this execution can be displayed with SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.	091	
Displays the common name of the issuer of the @Remote certification. CN = the following 30 bytes. Asterisks (*) indicate that no DESS exists. CERT: St ExpTime Displays the start time of the period for which the current @Remote certification is enabled. Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 D: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. The current progress, success, or failure of this execution can be displayed with SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		CERT: Issuer
Displays the start time of the period for which the current @Remote certification is enabled. CERT: End ExpTime Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.	092	
Displays the start time of the period for which the current @Remote certification is enabled. CERT: End ExpTime Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. The current progress, success, or failure of this execution can be displayed with SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.	003	CERT: St ExpTime
Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 D: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France G: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. The current progress, success, or failure of this execution can be displayed with SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.	093	Displays the start time of the period for which the current @Remote certification is enabled.
Displays the end time of the period for which the current @Remote certification is enabled. Ins Country Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: • SP5816-153 • SP5816-154 • SP5816-161 0: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.	004	CERT: End ExpTime
Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.	094	Displays the end time of the period for which the current @Remote certification is enabled.
machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. The current progress, success, or failure of this execution can be displayed with SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		Ins Country
SP5816-154 SP5816-161 O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		machine. After selecting the country, you must also set the following SP codes for embedded
SP5816-161 O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.	150	• SP5816-153
O: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France 6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		• SP5816-154
6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		• SP5816-161
Aut Line Detect Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		0: Japan, 1: USA, 2: Canada, 3: UK, 4: Germany, 5: France
Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		6: Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain
Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		Aut Line Detect
dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. • The current progress, success, or failure of this execution can be displayed with SP5816 152. • If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.		Press [Execute].
 SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line. 	151	dial-up or push type, so embedded RCG-M can automatically distinguish the number that
SP5816 154 will display the telephone number for the connection to the outside line.		
152 Line Detect Rst		
	152	Line Detect Rst

Displays a number to show the result of the execution of SP5816 151. Here is a list of what the numbers mean.

- 0: Success
- 1: In progress (no result yet). Please wait.
- 2: Line abnormal
- 3: Cannot detect dial tone automatically
- 4: Line is disconnected
- 5: Insufficient electrical power supply
- 6: Line classification not supported
- 7: Error because fax transmission in progress ioctl() occurred.
- 8: Other error occurred
- 9: Line classification still in progress. Please wait.

Dial/Push Select

This SP displays the classification (tone or pulse) of the telephone line to the access point for embedded RCG-M. The number displayed (0 or 1) is the result of the execution of SP5816 151. However, this setting can also be changed manually.

[0 to 1 / 0 / 1 / step]

153 0: Tone Dialing Phone

1: Pulse Dialing Phone

Inside Japan "2" may also be displayed:

- 0: Tone Dialing Phone
- 1: Pulse Dialing Phone 10PPS
- 2: Pulse Dialing Phone 20PPS

Outline Phone

The SP sets the number that switches to PSTN for the outside connection for embedded RCG-M in a system that employs a PBX (internal line).

154

- If the execution of SP5816-151 has succeeded and embedded RCG-M has connected to the external line, this SP display is completely blank.
- If embedded RCG-M has connected to an **internal** line, then the number of the connection to the external line is displayed.
- If embedded RCG-M has connected to an external line, a comma is displayed with the number. The comma is inserted for a 2 sec. pause.
- The number setting for the external line can be entered manually (including commas).

	Remove Service: PPP Recognition Timeout
155	SSP: Sets the length of the timeout for the embedded RCG-M connection to its access point. The timeout is the time from when the modem sends the ATD to when it receives the result code. [1 to 65536 / 60 / 1 / step]
	Dial Up User
156	Use this SP to set a user name for access to remote dial up. Follow these rules when setting a user name: • Name length: Up to 32 characters • Spaces and # allowed but the entire entry must be enclosed by double quotation
	marks (").
	Dial Up Password
157	Use this SP to set a password for access to remote dial up. Follow these rules when setting a user name:
	 Name length: Up to 32 characters Spaces and # allowed but the entire entry must be enclosed by double quotation marks (").
	Phone Number
161	Use this SP to set the telephone number of the line where embedded RCG-M is connected. This number is transmitted to and used by the Call Center to return calls. Limit: 24 numbers (numbers only)
	Ans Timing Adj
162	When the Call Center calls out to a embedded RCG-M modem, it sends a repeating ID tone (*#1#). This SP sets the time the line remains open to send these ID tones after the number of the embedded RCG-M modem is dialed up and connected.
	[0 to 24/1/1/step] The actual amount of time is this setting + 2 sec. For example, if you set "2" the line will remain open for 4 sec.
	Access Point
163	This is the number of the dial-up access point for embedded RCG-M. If no setting is done for this SP code, then a preset value (determined by the country selected) is used. Default: 0

	Allowed: Up to 16 alphanumeric characters
	Comm Line
	This SP sets the connection conditions for the customer. This setting dedicates the line to embedded RCG-M only, or sets the line for sharing between embedded RCG-M and a fax unit.
17.4	[0 or 1 / 0 / -]
164	0: Line shared by embedded RCG-M/Fax 1: Line dedicated to embedded RCG-M only
	Note
	If this setting is changed, the copier must be cycled off and on.
	 SP5816 187 determines whether the off-hook button can be used to interrupt an embedded RCG-M transmission in progress to open the line for fax transaction.
	Modem Serial Number
173	This SP displays the serial number registered for the embedded RCG-M.
	Lmt Resend Cncl
174	Normally, it is best to allow unlimited time for certification and ID2 update requests, and for the notification that the certification has been completed. However, embedded RCG-M generates charges based on transmission time for the customer, so a limit is placed upon the time allowed for these transactions.
	If these transactions cannot be completed within the allowed time, do this SP to cancel the time restriction.
	FAX TX Priority
	This SP determines whether pushing the off-hook button will interrupt an embedded RCG-M transmission in progress to open the line for fax transaction. This SP can be used only if SP5816-164 is set to "0".
	[0 or 1/0/-]
187	O: Disable. Setting the fax unit off-hook does not interrupt a fax transaction in progress. If the off-hook button is pushed during a embedded RCG-M transmission, the button must be pushed again to set the fax unit on-hook after the embedded RCG-M transmission has completed.
	1: Enable. When embedded RCG-M shares a line with a fax unit, setting the fax unit off-hook will interrupt a embedded RCG-M transmission in progress and open the line for a fax transaction.

200	Polling Man Exc
200	Executes the polling test.
	Instl: Condition
	Displays a number that indicates the status of the @Remote service device.
	0: Neither the registered device by the external RCG nor embedded RCG device is set.
201	1: The embedded RCG device is being set. Only Box registration is completed. In this status the this unit cannot answer a polling request from the external RCG.
	2: The embedded RCG device is set. In this status the external RCG unit cannot answer a polling request.
	3: The registered device by the external RCG is being set. In this status the embedded RCG device cannot be set.
	4: The registered module by the external RCG has not started.
202	Instl: ID#
202	Allows entry of the number of the request needed for the embedded RCG.
202	Instl: Reference
203	Executes the inquiry request to the @Remote GateWay URL.
	Instl: Ref Rslt
	Displays a number that indicates the result of the inquiry executed with SP5816-203.
	0: Succeeded
	1: Inquiry number error
	2: Registration in progress
204	3: Proxy error (proxy enabled)
	4: Proxy error (proxy disabled)
	5: Proxy error (Illegal user name or password)
	6: Communication error
	7: Certification update error
	8: Other error
	9: Inquiry executing
205	Instl: Ref Section

	Displays the result of the notification sent to the device from the GW URL in answer to the inquiry request. Displayed only when the result is registered at the GW URL.					
206	Instl: Rgstltn					
200	Executes Embedded RCG Registration.					
	Instl: Rgstltn Rst					
	Displays a number th	at indicates	s the registration result.			
	0: Succeeded					
	2: Registration in pro	gress				
	3: Proxy error (proxy	enabled)				
207	4: Proxy error (proxy	disabled)				
	5: Proxy error (Illega	l user name	e or password)			
	6: Communication er	ror				
	7: Certification update error					
	8: Other error					
	9: Registration executing					
	Instl Error Code					
	Displays a number that describes the error code that was issued when either SP5816 204 or SP5816 207 was executed.					
	Cause	Code	Meaning			
		-11001	Chat parameter error			
	Illegal Modem Parameter	-11002	Chat execution error			
		-11003	Unexpected error			
208		-12002	Inquiry, registration attempted without acquiring device status.			
	Operation Error, Incorrect Setting	-12003	Attempted registration without execution of an inquiry and no previous registration.			
	-12004		Attempted setting with illegal entries for certification and ID2.			
	Error Caused by Response from GW URL	-2385	Attempted dial up overseas without the correct international prefix for the telephone number.			

		-2387	Not supported at the Service Center	
		-2389	Database out of service	
		-2390	Program out of service	
			Two registrations for same device	
		-2392	Parameter error	
			External RCG not managed	
			Device not managed	
			Box ID for external RCG is illegal	
			Device ID for external RCG is illegal	
			Incorrect ID2 format	
		-2398	Incorrect request number format	
209	Instl Clear			
209	Releases a machine from its embedded RCG setup.		pedded RCG setup.	
250	Print Com Log			
230	Prints the communication log.			

5821	[NRS Address]	
001	CSS-PI Device	Sets the PI device code. After you change this setting, you must turn the machine off and on.
002	RCG IP Address	Sets the IP address of the RCG (Remote Communication Gate) destination for call processing at the remote service center. [00000000h to FFFFFFFFh/1]

5824	NVRAM Upload
001	("NVRAM Upload")

|--|

001 ("NVRAM Download")

5828	[Network Setting]	CTL		
		Enables or disables 1284 Compatibility.		
050	1284 Compatibility (Centro)	[0 or 1 / 1 / 1 / step]		
		0: Disabled, 1: Enabled		
		Enables or disables ECP Compatibility.		
		[0 or 1 / 1 / 1 / step]		
052	ECP (Centro)	0: Disabled, 1: Enabled		
		NOTE: This SP is activated only when SP5-828-50 is set to "1".		
		Enables/disables Job Spooling.		
065	Job Spooling	[0 or 1 / 0 / 1 / step]		
		0: Disabled, 1: Enabled		
	Job Spooling Clear: Start Time	Treatment of the job when a spooled job exists at power		
066		on.		
		0: ON (Data is cleared)		
		1: OFF (Automatically printed)		
	Job Spooling (Protocol)	Validates or invalidates the job spooling function for each protocol.		
		0: Validates		
		1: Invalidates		
		bitO: LPR		
040		bit1: FTP		
069		bit2: IPP		
		bit3: SMB		
		bit4: BMLinkS		
		bit5: DIPRINT		
		bitó: (Reserved)		
		bit7: (Reserved)		
090	TELNET (0: OFF 1: ON)	Enables or disables the Telnet protocol.		
070	TELINET (O. OTT T. OTN)	[0 or 1 / 1 / -]		

		0: Disable, 1: Enable			
		Enables or disables the Web operation.			
091	Web (0: OFF 1: ON)	[0 or 1 / 1 / -]			
		0: Disable, 1: Enable			
	Active IPv6 Link				
145	This is the IPv6 local address link referenced on the Ethernet or wireless LAN (802.11b) in the format:				
	"Link Local Address" + "Prefix	Length"			
	The IPv6 address consists of a	total of 128 bits configured in 8 blocks of 16 bits each.			
147	Active IPv6 Status Address 1				
149	Active IPv6 Status Address 2	These SPs are the IPv6 status addresses (1 to 5) referenced on the Ethernet or wireless LAN (802.11b) in the format:			
151	Active IPv6 Status Address 3	"Status Address" + "Prefix Length"			
153	Active IPv6 Status Address 4	The IPv6 address consists of a total of 128 bits configured in 8 blocks of 16 bits each.			
155	Active IPv6 Status Address 5				
	IPv6 Manual Setting Address				
156	This SP is the IPv6 manually set address referenced on Ethernet or wireless LAN (802.11b) in the format:				
	"Manual Set Address" + "Prefix Length"				
	The IPv6 address consists of a total of 128 bits configured in 8 blocks of 16 bits each.				
	IPv6 Gateway Address				
158	This SP is the IPv6 gateway address referenced on Ethernet or wireless LAN (802.11b). The IPv6 address consists of a total of 128 bits configured in 8 blocks of 16 bits each.				

5840	[IEEE 802.11b]				
	Channel MAX	CTL	[1 to 11 or 13 / 11 or 13 / 1 /step] Europe: 1 to 13, default: 13 NA/ Asia: 1 to 11, default: 11		
006	The number of channels availe	the maximum number of channels available for data transmission via wireless LA number of channels available varies according to location. The default settings ar he maximum end of the range for each area. Adjust the upper 4 bits to set the maximum of channels. DFU			

	₩Note					
	Do not change the setting.					
		CTL	[1 to 11 or 13 / 1 / 1 /step]			
	Channel MIN		Europe: 1 to 13			
			NA/ Asia: 1 to 11			
007	Sets the minimum number of channels available for data transmission via the wireless LAN. The number of channels available varies according to location. The default settings are set for the minimum end of the range for each area. Adjust the lower 4 bits to set the minimum number of channels. DFU ••• Note					
	Do not change the setting.					
			[00 to 11 / 00 / 1 binary]			
			00: Key #1			
	WEP Key Select	CTL	01: Key #2 (Reserved)			
011			10: Key #3 (Reserved)			
			11: Key #4 (Reserved)			
	Selects the WEP key.					

5842	[GWWS Analysis] DFU			
	Setting 1	CTL		
		Bit	Groups	
		0	System & other groups (LSB)	
001	This is a debugging tool. It sets the debugging output mode of each Net File process. Default: Bit SW 1000 0000	1	Capture related	
		2	Certification related	
		3	Address book related	
		4	Machine management related	
		5	Output related (printing, delivery)	
		6	Repository related	
		7	Debug log output	

002	Setting 2	CTL	
	Default: Bit SW 0000 0000	Bit	Groups
		0-6	Not used
		7	Log time stamp setting 0: Date/Hour/Minute/Second
			1: Minute/Second/Msecond

5844	[USB]				
	Transfer Rate	CTL			
001	Sets the speed for USB data transmission. [Full Speed] [Auto Change]				
	Vendor ID	CTL			
002	Sets the vendor ID: Initial Setting: 0x05A Ricoh Company [0x0000 to 0xFFFF/1] DFU				
	Product ID	CTL			
003	Sets the product ID. [0x0000 to 0xFFFF/1] DFU				
	Device Release No.	CTL			
004	Sets the device release number of the BCD (binary coded decimal) display. [0000 to 9999/1] DFU Enter as a decimal number. NCS converts the number to hexadecimal number recognized as the BCD.				

5045	5845	[Delivery Server Setting]	CTL	-
Provides items for delivery server settings.				
	001	FTP Port Num	[0 to	65535 / 3670 / 1 /step]
	001	Sets the FTP port number used when image files to the Scan Router Server.		

	Srv IP (Primary)	Range: 000.000.000	.000 to 255.255.255		
002	Use this SP to set the Scan Router Server address. The IP address under the transfer tab can be referenced by the initial system setting.				
	Retry Interval	[60 to 999 / 300 / 1 second /step]			
003	Specifies the interval time for send SMTP/FTP/NCP/SMB server after		data to the deliver server or		
	Number of Retries	[0 to 99 / 3 / 1 time/	'step]		
004	Specifies the retry times for sending FTP/NCP/SMB server after sendi		a to the deliver server or SMTP/		
	Delivery Error Display Time	[0 to 999 / 300 / 1 s	second /step]		
006	Use this setting to determine the length of time the prompt message is displayed when a test error occurs during document transfer with the NetFile application and an external device.				
	Srv IP (Secondary)	Range: 000.000.000.000 to 255.255.255.255			
008	Specifies the IP address assigned to the computer designated to function as the secondar delivery server of Scan Router. This SP allows only the setting of the IP address without reference to the DNS setting.				
	Delivery Server Model	[0 to 4 / 0 / 1 /step]			
009	Allows changing the model of the 0: Unknown, 1: SG1 Provided, 2: 3: SG2 Provided, 4: SG2 Packag	SG1 Package,	ed by the I/O device.		
	Delivery Svr Capability	[0 to 255 / 0 / 1 /st	ep]		
	Bit7 = 1 Comment information exit	rs			
	Bit6 = 1 Direct specification of ma	il address possible			
	Bit5 = 1 Mail RX confirmation setti				
010	Bit4 = 1 Address book automatic u	Changes the capability of the server that is registered as an			
	Bit3 = 1 Fax RX delivery function e	I/O device.			
	Bit2 = 1 Sender password function	n exists			
	Bit1 = 1 Function to link MK-1 use				

	BitO = 1 Sender specification required (if set to 1, Bit6 is set to "O")					
	Delivery Svr Capability (Ext)	ep]				
	Changes the capability of the server that is registered as an I/O device.					
011	Bit7 = 1 Address book usage limit	ation (Limitation for each	n authorized user)			
	Bit6 = 1 RDH authorization link					
	Bit5 to 0: Not used					
013	Svr Schm (Primary)	-				
	Specifies the scheme of the primar	y delivery server.				
014	Svr Port Num (Pri)	-				
014	Specifies the port number of the p	rimary delivery server.				
015	Srv URL Path (Pri)	-				
013	Specifies the URL path of the primary delivery server.					
017	Svr Schm (Sec)	-				
016	Specifies the scheme of the secondary delivery server.					
017	Svr Port Num (Sec)	-				
017	Specifies the port number of the secondary delivery server.					
010	Srv URL Path (Sec)	-				
018	Specifies the URL path of the seco	ndary delivery server.				
019	CapSvr Schm	-				
019	Specifies the scheme of the capture server.					
020	CapSvr Port Num	-				
020	Specifies the port number of the capture server.					
001	CapSrv URL Path	-				
021	Specifies the URL path of the s capture server.					
000	Rapid-fire Send	[O or 1 / 1 / -]				
022	Rapid-life delid	0: Disable, 1: Enable				

Enables or disables the prevention function for the continuous data sending.

5846	[UCS Settings]	CTL	-			
	Machine ID (Delivery Server)	Machine ID (Delivery Server) Displays ID				
001	Displays the unique device ID in use by the delivery server directory. The value is only displayed and cannot be changed. This ID is created from the NIC MAC or IEEE 1394 EUI. The ID is displayed as either 6-byle or 8-byte binary.					
	Machine ID Clear (Delivery S	Server)		Clears ID		
002	this SP if the connection of the	e device to	o the delivery se	n the file transfer directory. Execute erver is unstable. After clearing the cycling the machine off and on.		
	Maximum Entries		[150 to 999]	/ 150 / 1 /step]		
003	Changes the maximum numb	er of entri	es that UCS ca	n handle.		
	If a value smaller than the predata (excluding user code in			S managed data is cleared, and the		
	Delivery Server Retry Timer			[0 to 255 / 0 / 1 /step]		
006	Sets the interval for retry attempts when the delivery server fails to acquire the delivery server address book.					
	Delivery Server Retry Times			[0 to 255 / 0 / 1 /step]		
007	Sets the number of retry attempts when the delivery server fails to acquire the delivery server address book.					
	Delivery Server Maximum En	tries	[200 to 999 / 200 / 1/step]			
008	Sets the maximum number account entries of the delivery server user information managed by UCS.					
010	LDAP Search Timeout			[1 to 255 / 60 / 1 /step]		
010	Sets the length of the timeout for the search of the LDAP server.					
	[AddrB Acl Info] Address Book Access Control List Information					
041	This SP must be executed immediately after installation of an HDD unit in a basic machine that previously had no HDD. The first time the machine is powered on with the new HDD installed, the system automatically takes the address book from the NVRAM and writes it onto the new HDD. However, the new address book on the HDD can be accessed only					

	1 .1 . 1			
	1 -	stage. Executing this SP by the service technician sfull address book access to all users.		
	Addr B Mig (SD \rightarrow SD)	[0 to 10 / 0 / 1 /step]		
		0: Not decided yet		
		1: Slot 1 to 10: Slot 10		
042	This SP copies an address book d	ata in a SD card to another SD card.		
	Select the destination slot where ye "Execute" key.	ou want to move an address book data, and then press		
	You can check where an address	book data is in with SP5-846-043.		
0.40	Addr B Media	-		
043	Displays the slot number where ar	address book data is in.		
047	Initialize Local Addr Book	Clears the local address book information, including the user code.		
048	Initialize Delivery Addr Book	Clears the distribution address book information, except the user code.		
049	Initialize LDAP Addr Book	Clears the LDAP address book information, except the user code.		
050	Initialize All Addr Book	Clears all directory information managed by UCS, including all user codes.		
030		Turn the main power switch off and on after executing this SP.		
051	Backup All Addr Book	Uploads all directory information to the SD card.		
052	Restore All Addr Book	Downloads all directory information from the SD card.		
	Clear Backup Info			
	Deletes the address book data from the SD card in the service slot.			
	Deletes only the files that were uploaded from this machine.			
053	This feature does not work if the card is write-protected.			
	Note			
	After you do this SP, go out of the SP mode, and then turn the power off. Do not remove the SD card until the Power LED stops flashing.			
060	Search Option			

This SP uses bit switches to set up the fuzzy search options for the UCS local address book. BitO: Checks both upper/lower case characters Bit1: Japan only Bit2 to 7: Not used Compl Opt1 Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to upper case and sets the length of the password. 062 [0 to 32 / 0 / 1 /step] **U** Note • This SP does not normally require adjustment. This SP is enabled only after the system administrator has set up a group password policy to control access to the address book. Compl Opt2 Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to lower case and defines the length of the password. 063 [0 to 32 / **0** / 1 /step] Note • This SP does not normally require adjustment. • This SP is enabled only after the system administrator has set up a group password policy to control access to the address book. Compl Opt3 Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to numbers and defines the length of the password. 064 [0 to 32 / **0** / 1 /step] **Note** • This SP does not normally require adjustment. • This SP is enabled only after the system administrator has set up a group password policy to control access to the address book. Compl Opt4 065

Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to **symbols** and defines the length of the password.

[0 to 32 / **0** / 1 /step]

U Note

- This SP does not normally require adjustment.
- This SP is enabled only after the system administrator has set up a group password policy to control access to the address book.

091	FTP Auth Port Setting	Specifies the FTP port for getting a distribution server address book that is used in the identification mode. [0 to 65535 / 3671 / 1 / step]
094	Encryption Stat	Shows the status of the encryption function for the address book data.

	[Web Service]	CTL	-
5848	SP5848-1 sets the 4-bit switch ass has no effect on access and delive ac: Access Control	for the access control setting. Setting of 0001 Scan Router.	
004	ac: UD (only Lower 4 bits)		
007	ac: Log Fax (Lower 4 bits)		
009	ac: Job Ctrl (Lower 4 bits)		es access control on and off. No access control
		: Denies access to DeskTop Binder.	
022	ac: Uadmin (Lower 4bits)		
210	Log Type: Job 1		
211	Log Type: Job2		
212	Log Type: Access	Display	vs the log server settings.
213	Primary Srv	These can be adjusted with the Web Image M	
214	Secondary Srv		
215	Start Time		

216	Interval Time	Specifies the transmit interval. [1 to 1000 / 1 / 1 hour/step] This SP is activated only when SP5848-217 is set to "2 (Transmit periodically)".
217	Timing	Selects the transmit timing. [0 to 2 / 0 / 1/step] 0: No Transmit, 1: Transmit one by one 2: Transmit periodically

5849	[Installation Dat	e]	CTL	
3649	Displays or prints the installation date of the machine.			
001	Display The "Counter Clear Day" has been changed to "Installation Date" "Inst. Date".			" has been changed to "Installation Date" or
002	Print	Determines whether the installation date is printed on the printout for the total counter. [0 or 1/1/1/step] 0: No Print, 1: Print		
003	Total Counter	Displays the total counter when the installation date is registered to the machine.		

5851	[Bluetooth]		CTL	
001	Mode	Sets the operation O:Public, 1: Privo		for the Bluetooth Unit. Press either key.

	[Remote ROM Update]				
Allows the technician to upgrade the firmware using a parallel cable w remote ROM.		he firmware using a parallel cable when updating the			
002	Local Port	CTL	[0 or 1 / 0 / 1/step] 0: Disallow 1: Allow		

5857	[Debug Log Save]	CTL	-
------	------------------	-----	---

	On/Off	0: OFF, 1: ON			
001	Switches the debug log feature of feature is switched on.	e debug log feature on and off. The debug log cannot be captured until this vitched on.			
006	Save to SD Card				
000	Specifies the debug log number	for saving to an SD card.			
	Erase SD Debug				
012	Erases SD debug logs in the SD	card.			
	Turn off and on after executing t	his SP.			
013	Dsply-SD Space				
013	Displays the remaining space in the SD card.				
	SD to SD Latest (Latest 4 MB)				
014	Saves the debug log (latest 4 MB) in memory to the SD card.				
014	A unique file name is generated to avoid overwriting existing file names on the SD card. Up to 4MB can be copied to the SD card. 4 MB segments can be copied one by one to the SD card.				
	SD to SD Any (Latest 4 MB Any	Key)			
015	Saves the specified debug log (with SP5-857-006) in memory to the SD card.				
015	A unique file name is generated to avoid overwriting existing file names on the SD c Up to 4MB can be copied to the SD card. 4 MB segments can be copied one by or the SD card.				
017	Make SD Debug				
017	Executes the making of a file (4MB) for saving debug logs.				

	[Debug Log Save: SC]	CTL	-
5858	These SPs select the content of the debugging information to be saved to the destination selected by SP5857-2. SP5858-3 stores one SC specified by number. Refer to the chapter "Trouble Shooting" for a list of SC error codes.		
001		Turns the save function on/off for SC codes generated by copier engine errors. [0 or 1 / 0 / 1 / step]	

		0: OFF, 1: ON	
	G	Turns the save function on/off for SC codes generated by GW controller errors.	
002	Controller SC	[0 or 1 / 0 / 1 / step]	
		0: OFF, 1: ON	
003	Any SC	[0 to 65535 / 0 / 1 /step]	
		Turns the save function on/off for jam errors.	
004	Jam	[0 or 1 / 0 / 1 / step]	
		0: OFF, 1: ON	

5859	[Debug Log Save Key]	CTL	-	
001	Key 1			
002	Key 2			
003	Key 3			
004	Key 4			
005	Key 5	These SPs allow you to set up to 10 keys for log files for functions that use common memory on the controller boo		
006	Кеу б	[-9999999 to 9999999 / 0 / -]		
007	Key 7			
008	Key 8	_		
009	Key 9			
010	Key 10			

5860	[SMTP/POP3/IMAP4]	CTL	-	
Partial Mail Receive Timeout		[1 to 168 / 72 / 1 hour/step]		
020			-	ail that breaks up during reception. The on of the mail is not received during this
001	MDN Response RFC2298 Compliance [0 to 1 / 1 / -]			
021	Determines whether RFC2298	3 complia	nce is sw	ritched on for MDN reply mail.

	0: No, 1: Yes			
	SMTP Auth. From Field Replacement	[0 to 1 / 0 / -]		
022	Determines whether the FROM item of the mail I after the SMTP server is validated. O: No. "From" item not switched. 1: Yes. "From"			
	SMTP Auth. Direct Setting	[0 or 1 / 0 / –]		
	Selects the authentication method for SMPT.			
	Bit switch:			
	Bit 0: LOGIN			
025	Bit 1: PLAIN			
023	Bit 2: CRAM MD5			
	Bit 3: DIGEST MD5			
	Bit 4 to 7: Not used			
	Note			
	This SP is activated only when SMTP author	rization is enabled by UP mode.		

5866	[E-mail Report]		
Report Validity - [0 or 1 / 0 / -] 0: Enabled, 1: Disabled Enables or disables the E-mail alert function. Add Date Field CTL [0 or 1 / 0 / -] 0: Not add, 1: Add			
	Adds or does not add the date field to the header of the alert mail.		

5869	[RAM Disk Setting]		
Mail Function	GWINIT	[0 or 1 / 0 / -] 0: ON, 1: OFF	
	Turns on or off the e-mail fund	ction.	
000	PDL Storage	GWINIT	[0 to 255 / 4 / 1 /step]
Specifies the RAM disk storage size for PDL.		DL.	

5870	[Common Key Info Writing]		
001	Writing	CTL	Writes to flash ROM the common proof for validating the device for @Remote specifications.
003	Initialize	CTL	Formats the common proof area of the flash ROM.

5873	[SD Card Appli Move]	
001	Move Exec	This SP copies the application programs from the original SD card in SD card slot 3 to an SD card in SD card slot 2.
002	Undo Exec	This SP copies back the application programs from an SD card in the SD Card Slot 3 to the original SD card in the SD card slot 2. Use this menu when you have mistakenly copied some programs by using "Move Exec" (SP5873-1).

5875	[SC Auto Reboot]		
001	Reboot Mode	CTL	Enables or disables the automatic reboot function when an SC error occurs. [0 or 1 / 0 / -] 0: The machine reboots automatically when the machine issues an SC error and logs the SC error code. If the same SC occurs again, the machine does not reboot. 1: The machine does not reboot when an SC error occurs. The reboot is not executed for Type A, B or C SC
			Selects the reboot method for SC.
002	Reboot Method	CTL	[0 or 1 / 0 / -] 0: Manual reboot, 1: Automatic reboot

5878	[Option Setup]		
001	Option Setup	-	Enables the Data Overwrite Security unit. Press "EXECUTE" on the operation panel. Then turn the machine off and on.

5881	[Delete Fixed Sent]		
001	Delete Fixed Sent	-	Deletes the fixed form sentence.

5886	[Permit ROM Update] DFU	
	This SP determines whether the ROM can be updated.	
001	[0 or 1 / 0 / 1/step]	
	0: Yes, 1: No	

5887	[SD GetCounter] SSP	
001	This SP saves the counter list of the machine to an SD card in the slot 3.	
001	The folder of "SD_COUNTER" must be made in an SD card for this SP.	

5913	[Switch Permission]
	Print Application Timer
002	Sets the length of time to elapse before allowing another application to take control of the display when the application currently controlling the display is not operating because a key has not been pressed.
	[3 to 30 / 3 / 1 second/step]

	[Device Setting]		
5985	The NIC and USB support features are built into the GW controller. Use this SP to en and disable these features. In order to use the NIC and USB functions built into the conboard, these SP codes must be set to "1".		
001	On Board NIC [0 to 2 / 0 / 1 /step] O: Disable, 1: Enable, 2: Function limitation		

		When the "Function limitation" is set, "On board NIC" is limited only for the @Remote or LDAP/NT authentication.
		Note
		Other network applications than @Remote or LDAP/NT authentication are not available when this SP is set to "2". Even if you can change the initial settings of those network applications, settings may not actually work.
002	On Board USB	[0 or 1 / 0 / 1/step] 0: Disable, 1: Enable

	[SP Print Mode] SMC Print			
5990	In the SP mode, press Copy Window to move to the copy screen, select the paper single then press Start. Select A4/LT (Sideways) or larger to ensure that all the information press SP Window to return to the SP mode, select the desired print, and press "EXEC			
001	All (Data List)			
002	SP (Mode Data List)			
003	User Program Data			
004	Logging Data			
005	Diagnostic Report			
006	Non-Default (Prints only SPs set to values other than defaults.)			
007	NIB Summary			
021	Copier User Program			
022	Scanner SP			
023	Scanner User Program			

5998	Memory Clear	
OO1 See the section "Memory Clear" in this chapter.		

SP7-XXX (Data Log)

7401*	[Counter-SC Total]	CTL	[0 to 9999 / 0 / 1/step]
001	Displays how many times SC codes are generated.		

7403	[SC History]		
001	Latest		
002	Latest 1		
003	Latest 2		
004	Latest 3		Logs the SC codes detected. The 10 most recently detected SC Codes are
005	Latest 4	CTL	displayed on the screen.
006	Latest 5		L: Asset line
007	Latest 6		V: Assert location F: Assert file
008	Latest 7		
009	Latest 8		
010	Latest 9		

<i>7</i> 502*	[Counter-Paper Jam]	[0 to 9999 / 0 / 1/step]			
7502 1	Displays the total number of p	Displays the total number of paper jams.			

7503*	[Counter-Orgn Jam]	[0 to 9999 / 0 / 1/step]	
7503	1 Displays the total number of a	Displays the total number of original jams,	

	[Paper Jam/Loc]	[0 to 9999 / 0 / 1/step]	
7504* Displays the total number of the paper jams classified by timing and		s classified by timing and location.	

7505*	[Original Jam/Loc]	[0 to 9999 / 0 / 1/step]
-------	--------------------	---------------------------------

Displays the total number of the original jams on the ADF/ARDF that have occurred at a certain timing or at a certain location.

■ "Original Jam History Display (SP7-508)", in this chapter.

7506	[Paper Jam/ Size] Jam Counter: Paper Size		
7506 5	A4 LEF		
7506 6	A5 LEF		
7506 14	B5 LEF		
7506 38	LT LEF		
7506 44	HLT LEF		
7506 132	A3 SEF		
7506 133	A4 SEF	СТІ	Displays the number of jams according to the paper size. [0 to 9999 / 0 / 1 sheet/step]
7506 134	A5 SEF		
7506 141	B4 SEF		
7506 142	B5 SEF		
7506 160	DLT SEF		
7506 164	LG SEF		
7506 166	LT SEF		
7506 172	HLT SEF		
7506 255	Others		

7507*	[Disply-P Jam Hist] Display: Paper Jam History		
7507 1	Last	Displays the copy jam history (the most recent 10 jams)	
7507 2	Latest 1	Sample Display:	
7507 3	Latest 2	CODE:007 SIZE:05h TOTAL:0000334	
7507 4	Latest 3		
73074	Luiesi 3		
7507 5	Latest 4	DATE:DEC 1 09:44/06 2005	
		where:	

7507 6	Lates	t 5					
7507 7	Latest 6		CODE is the SP7504-*** number (see above.)				
7507 8	B Latest 7		SIZE is the ASAP paper size code in hex. TOTAL is the total jam error count (SP7003) DATE is the date the jams occurred.				
7507 9	Latest 8						
7507 10	Lates	t 9					
Size	Code		Size	Code	Size	Code	
A4 (S)	05	A3 (L)	84	DLT (L)	A0	
A5 (S))	06	A4 (L)	85	LG (L)	A4	
B5 (S)) OE		A5 (L)	86	LT (L)	A6	
LT (S)		26	B4 (L)	8D	HLT (L)	AC	
HLT (S)	2C	B5 (L)	8E	Others	FF	

	[Disply-O Jam Hist] Display: Original Jam History					
	Displays the original jam history of the transfer unit in groups of 10, starting with the most recent 10 jams. Display contents are as follows:					
7508*	CODE is the SP7-505-*** r	number.				
	SIZE is the paper size code i	n hex. (See "Paper Size Hex Codes" below.)				
	TOTAL is the total jam error count (SP7-003)					
	DATE is the date the previous jam occurred					
1*	Latest					
2*	Latest 1					
3*	Latest 2	Sample Display:				
4*	Latest 3	CODE: 007 SIZE: 05h TOTAL: 0000334				
5*	Latest 4					
6*	Latest 5	DATE: Mon Mar 15 11:44:50 2000				
7*	Latest 6					
8*	Latest 7					

9*	Latest 8	
10*	Latest 9	

7801	[Memory/ Version/ PN]	
7801	Displays the part number and version of all ROMs in the machine.	
7801 255	Memory/ Version/ PN	

7803	[PM Counter]				
7803	Displays the PM counter for each PM part.				
7803 1	Paper	CTL	[0 to 99999999 / 0 / 1/step]		

7804	[PM Count. Reset]			
7604	rt.			
7804 1	Paper	CTL	This clears the counter of SP7803-1.	

7807	7	[Reset-SC/Jam Counters]	
78		Resets the SC, paper, original, and total jam counters. When the program ends normally, the message "Completed" is displayed. SP 7807 1 does not reset the following logs: SP 7507 (Display-Paper Jam History) and SP 7508 (Display-Original Jam History).	

7826	[MF Error Counter] Japan Only		
7620	Displays the number of counts requested of the card/key counter.		
001	Error Total	A request for the count total failed at power on. This error will occur if the device is installed but disconnected.	
002	Error Staple	The request for a staple count failed at power on. This error will occur if the device is installed but disconnected.	

7827	[MF Error Counter Clear]	
7627	Press Execute to reset to 0 the values of SP7826. Japan Only	

7832*	[Display-Self-Diag]	
7832 1	Displays the SC codes and the number of their occurrences. Each number is in the range of 0 to 9999.	

7836	[Resident Memory]
7630	Displays the contents of the memory on the controller board.

7901	[Assert Info]		
	Records the location where SP is used for problem and	•	lem is detected in the program. The data stored in this
7901 1	File Name	-	-
7901 2	Number of Lines	-	-
7901 3	Location	-	-

7992*	992* Reset-Info Count	
7992 5	Reset-ID Er Count	
79923	Clears the ID sensor error counter (SP7-991-005).	

SP8-XXX (History)

Most of the SPs in this group are prefixed with a letter that indicates the mode of operation (the mode of operation is referred to as an "application"). Before reading the Group 8 Service Table, make sure that you understand what these prefixes mean.

Prefixes	What it means		
T:	Total: (Grand Total).	Grand total of the items counted for all applications (C, F, P, etc.)	
C:	Copy application.		
F:	Fax application.	Totals (pages, jobs, etc.) executed for each application	
P:	Print application.	when the job was not stored on the document server.	
S:	Scan application.		

Other applications O: (external network applications, for exa	Refers to network applications such as Web Image Monitor. Utilities developed with the SDK (Software Development Kit) will also be counted with this group in the future.
---	---

The Group 8 SP codes are limited to 17 characters, forced by the necessity of displaying them on the small LCDs of printers and faxes that also use these SPs. Read over the list of abbreviations below and refer to it again if you see the name of an SP that you do not understand.

Key for Abbreviations

Abbreviation	What it means
/	"By", e.g. "T:Jobs/Apl" = Total Jobs "by" Application
>	More (2> "2 or more", 4> "4 or more"
AddBook	Address Book
Apl	Application
B/W	Black & White
Bk	Black
С	Cyan
ColCr	Color Create
ColMode	Color Mode
Comb	Combine
Comp	Compression
Deliv	Delivery
DesApl	Designated Application. The application (Copy, Fax, Scan, Print) used to store the job on the document server, for example.
Dev Counter	Development Count, no. of pages developed.
Dup, Duplex	Duplex, printing on both sides
Emul	Emulation
FC	Full Color
FIN	Post-print processing, i.e. finishing (punching, stapling, etc.)

Abbreviation	What it means
Full Bleed	No Margins
GenCopy	Generation Copy Mode
GPC	Get Print Counter. For jobs 10 pages or less, this counter does not count up. For jobs larger than 10 pages, this counter counts up by the number that is in excess of 10 (e.g., for an 11-page job, the counter counts up 11-10=1)
IFax	Internet Fax
ImgEdt	Image Edit performed on the original with the copier GUI, e.g. border removal, adding stamps, page numbers, etc.
K	Black (YMCK)
LS	Local Storage. Refers to the document server.
LSize	Large (paper) Size
Mag	Magnification
MC	One color (monochrome)
NRS	NRS (@Remote), which allows a service center to monitor machines remotely. "@Remote" is used overseas; "CSS" is used in Japan.
Org	Original for scanning
OrgJam	Original Jam
Palm 2	Print Job Manager/Desk Top Editor: A pair of utilities that allows print jobs to be distributed evenly among the printers on the network, and allows files to moved around, combined, and converted to different formats.
PC	Personal Computer
PGS	Pages. A page is the total scanned surface of the original. Duplex pages count as two pages, and A3 simplex count as two pages if the A3/DLT counter SP is switched ON.
PJob	Print Jobs
Ppr	Paper
PrtJam	Printer (plotter) Jam
PrtPGS	Print Pages

Abbreviation	What it means
R	Red (Toner Remaining). Applies to the wide format model A2 only. This machine is under development and currently not available.
RCG	Remote Communication Gate
Rez	Resolution
SC	Service Code (Error SC code displayed)
Scn	Scan
Sim, Simplex	Simplex, printing on 1 side.
S-to-Email	Scan-to-E-mail
SMC	SMC report printed with SP5990. All of the Group 8 counters are recorded in the SMC report.
Svr	Server
TonEnd	Toner End
TonSave	Toner Save
TXJob	Send, Transmission
YMC	Yellow, Magenta, Cyan
YMCK	Yellow, Magenta, Cyan, Black

U Note

• All of the Group 8 SPs are reset with SP5 801 1 Memory All Clear.

8 191	T:Total Scan PGS	CTL	
8 192	C:Total Scan PGS	CTL	These SPs count the pages scanned by each application that uses the scanner to scan images.
8 193	F:Total Scan PGS	CTL	[0 to 9999999 / 0 / 1]
8 195	S:Total Scan PGS	CTL	

- SP 8 191 to 8 196 count the number of scanned sides of pages, not the number of physical pages.
- These counters do not count reading user stamp data, or reading color charts to adjust color.
- Previews done with a scanner driver are not counted.
- A count is done only after all images of a job have been scanned.

• Scans made in SP mode are not counted.

Examples

- If 3 B5 pages and 1 A3 page are scanned with the scanner application but not stored, the S: count is 4.
- If both sides of 3 A4 sheets are copied and stored to the document server using the Store File button in the Copy mode window, the C: count is 6 and the L: count is 6.
- If both sides of 3 A4 sheets are copied but not stored, the C: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

	T:LSize Scan PGS	CTL	[0 to 9999999 / 0 / 1]			
8 201	These SPs count the total number of large pages input with the scanner for scan and copy jobs. Large size paper (A3/DLT) scanned for fax transmission is not counted. •• Note					
	These counters are displayed in the SMC Report, and in the User Tools display.					
0.000	F:LSize Scan PGS	CTL	[0 to 9999999 / 0 / 1]			
8 203	These SPs count the number of large pages scanned by original type for Fax jobs.					
	S:LSize Scan PGS	CTL	[0 to 9999999 / 0 / 1]			
8 205	These SPs count the total number of large pages input with the scanner for scan jobs only. Large size paper (A3/DLT) scanned for fax transmission are not counted. • Note					
	These counters are displayed in the SMC Report, and in the User Tools display.					

	ADF Org Feeds		CTL	[0 to 9999999 / 0 / 1]	
8 221	These SPs count the number of pages fed through the ADF for front and back side scanning.				
			t can scan both sides simultaneously, the Front side number of pages fed for either simplex or duplex		
		With an ADF/ARDF that cannot scan both sides simultaneously, the Front side count is the same as the number of pages fed for duplex front side scanning. (The front side is determined by which side the user loads face up.)			
002	Back	Number of rear sides fed for scanning:			

- With an ADF/ARDF that can scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex scanning.

 With an ADF/ARDF that cannot scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex rear-side scanning.
 - When 1 sheet is fed for duplex scanning the Front count is 1 and the Back count is 1.
 - If a jam occurs during the job, recovery processing is not counted to avoid double counting. Also, the pages are not counted if the jam occurs before the first sheet is output.

8 281	T:Scan PGS/TWAIN	CTL	These SPs count the number of pages scanned using a
8 285	S:Scan PGS/TWAIN	CTL	TWAIN driver. These counters reveal how the TWAIN driver is used for delivery functions. [0 to 9999999 / 0 / 1] • Note • At the present time, these counters perform identical counts.

8 291	T:Scan PGS/Stamp	CTL	These SPs count the number of pages stamped with the
8 293	F:Scan PGS/Stamp	CTL	stamp in the ADF unit.
8 295	S:Scan PGS/Stamp	CTL	[0 to 9999999 / 0 / 1]

	T:Scan PGS/Size	CTL	[0 to 9999999 / 0 / 1]		
8 301	These SPs count by size the total number of pages scanned by all applications. It these totals to compare original page size (scanning) and output (printing) page [SP 8-441].				
	C:Scan PGS/Size	CTL	[0 to 9999999 / 0 / 1]		
8 302	These SPs count by size the total number of pages scanned by the Copy application. Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-442].				
	F:Scan PGS/Size	CTL	[0 to 9999999 / 0 / 1]		
8 303	These SPs count by size the total number of pages scanned by the Fax application. Use these totals to compare original page size (scanning) and output page size [SP 8-443].				
8 305	S:Scan PGS/Size	CTL	[0 to 9999999 / 0 / 1]		

	_	otal number of pages scanned by the Scan application. Original page size (scanning) and output page size [SP
-001	A3	
002	A4	
003	A5	
004	B4	
005	B5	
006	DLT	
007	LG	
008	LT	
009	HLT	
010	Full Bleed	
-254	Other (Standard)	
-255	Other (Custom)	

8 381	T:Total PrtPGS	CTL	
8 382	C:Total PrtPGS	CTL	The CD countries and a factor of the little of
8 383	F:Total PrtPGS	CTL	These SPs count the number of pages printed by the customer. The counter for the application used for
8 384	P:Total PrtPGS	CTL	storing the pages increments. [0 to 9999999 / 0 / 1]
8 385	S:Total PrtPGS	CTL	[0 10 4444444
8 387	O:Total PrtPGS	CTL	

- When the A3/DLT double count function is switched on with SP5104, 1 A3/DLT page is counted as 2.
- When several documents are merged for a print job, the number of pages stored is counted for the application that stored them.
- These counters are used primarily to calculate charges on use of the machine, so the following pages are not counted as printed pages:
 - Blank pages in a duplex printing job.

- Blank pages inserted as document covers, chapter title sheets, and slip sheets.
- Reports printed to confirm counts.
- All reports done in the service mode (service summaries, engine maintenance reports, etc.)
- Test prints for machine image adjustment.
- Error notification reports.
- Partially printed pages as the result of a copier jam.

	LSize PrtPGS	CTL	[0 to 9999999 / 0 / 1]		
8 391	These SPs count pages printed on paper sizes A3/DLT and larger. Note				
		ldition to being displayed in the SMC Report, these counters are also ayed in the User Tools display on the copy machine.			

8 411	Prints/Duplex	CTL	This SP counts the amount of paper (front/back counted as 1 page) used for duplex printing. Last pages printed only on one side are not counted. [0 to 9999999 / 0 / 1]
-------	---------------	-----	--

	T:PrtPGS/Dup Comb	CTL	[0 to 9999999 / 0 / 1]			
8 421	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing. This is the total for all applications.					
	C:PrtPGS/Dup Comb	CTL	[0 to 9999999 / 0 / 1]			
8 422	These SPs count by binding and combining, and n-Up settings the number of pages processed for printing by the copier application.					
	F:PrtPGS/Dup Comb	CTL	[0 to 9999999 / 0 / 1]			
8 423	These SPs count by binding and combining, and n-Up settings the number of pages processed for printing by the fax application.					
	P:PrtPGS/Dup Comb	CTL	[0 to 9999999 / 0 / 1]			
8 424	These SPs count by binding and combining, and n-Up settings the number of pages processed for printing by the printer application.					
8 425	S:PrtPGS/Dup Comb					

	These SPs count by binding and combining, and n-Up settings the number of pages processed for printing by the scanner application.					
	O:PrtPGS/Dup Comb		CTL	[0 to 9999999 / 0 / 1]		
8 427	These SPs count by bir processed for printing	•		oining, and n-Up settings the number of pages cations		
001	Simplex> Duplex	-				
002	Duplex> Duplex	-				
003	Book> Duplex	-				
004	Simplex Combine	-				
005	Duplex Combine	-				
006	2>	2 pages on 1 side (2-Up)				
007	4>	4 pages on 1 side (4-Up)				
008	6>	6 pag	ges on 1	side (6-Up)		
009	8>	8 pag	ges on 1	side (8-Up)		
010	9>	9 pages on 1 side (9-Up)				
011	16>	16 pages on 1 side (16-Up)				
012	Booklet	-				
013	Magazine	-				

- These counts (SP8-421 to SP8-427) are especially useful for customers who need to improve their compliance with ISO standards for the reduction of paper consumption.
- Pages that are only partially printed with the n-Up functions are counted as 1 page.
- Here is a summary of how the counters work for Booklet and Magazine modes:

Booklet		Magazine	
Original Pages	Count	Original Pages	Count
1	1	1	1
2	2	2	2

3	2	3	2
4	2	4	2
5	3	5	4
6	4	6	4
7	4	7	4
8	4	8	4

8 441	T:PrtPGS/Ppr Size	CTL	[0 to 9999999 / 0 / 1]		
8 44 1	These SPs count by print	paper size th	ne number of pages printed by all applications.		
	C:PrtPGS/Ppr Size	CTL	[0 to 9999999 / 0 / 1]		
8 442	These SPs count by print paper size the number of pages printed by the copy application.				
8 443	F:PrtPGS/Ppr Size	CTL	[0 to 9999999 / 0 / 1]		
0 443	These SPs count by print	paper size the	e number of pages printed by the fax application.		
	P:PrtPGS/Ppr Size	CTL	[0 to 9999999 / 0 / 1]		
8 444	These SPs count by print paper size the number of pages printed by the printer application.				
	S:PrtPGS/Ppr Size	CTL	[0 to 9999999 / 0 / 1]		
8 445	These SPs count by print paper size the number of pages printed by the scanner application.				
8 447	O:PrtPGS/Ppr Size	CTL	[0 to 9999999 / 0 / 1]		
0 44/	These SPs count by print paper size the number of pages printed by Other application				
001	A3				
002	A4				
003	A5				
004	B4				
005	B5				

006	DLT
007	LG
008	LT
009	HLT
010	Full Bleed
254	Other (Standard)
255	Other (Custom)

• These counters do not distinguish between LEF and SEF.

0.451	PrtPGS/Ppr Tray	CTL [0 to 9999999 / 0 / 1]		
8 451	These SPs count the number of sheets fed from each paper feed station.		fed from each paper feed station.	
001	Bypass	Bypass Tray		
002	Tray 1	Copi	er	
003	Tray 2	Copi	er	
004	Tray 3	Paper Tray Unit (Option)		
005	Tray 4	Paper Tray Unit (Option)		
006	Tray 5	Currently not used.		
007	Tray 6	Currently not used.		
008	Tray 7	Currently not used.		
009	Tray 8	Currently not used.		
010	Tray 9	Currently not used.		

	T:PrtPGS/Ppr Type	CTL	[0 to 9999999 / 0 / 1]	
8 461	These counters are not the feed timing to accurately these counts are based or	e same as measure th n output tir		
	Blank sheets (covers, chapter covers, slip sheets) are also counted.			

		During duplex printing, pages printed on both sides count as 1, and a page printed on one side counts as 1.		
		[0 to 9999999 / 0 / 1]		
0 402	These SPs count by paper type the number pages printed by the copy applications and the copy applications are supplied to the copy applications.			er pages printed by the copy application.
8 463		F:PrtPGS/Ppr Type		
0 403		These SPs count by paper type the number pages printed by the fax application.		
8 464		P:PrtPGS/Ppr Type	CTL	[0 to 9999999 / 0 / 1]
0 404		These SPs count by paper type the number pages printed by the printer application.		
	001	Normal		
	002	Recycled		
	003	Special		
	004	Thick		
	005	Normal (Back)		
	006	Thick (Back)		
	007	OHP		
	800	Other		

8 521	T:PrtPGS/FIN	CTL	[0 to 9999999 / 0 / 1]			
0 321	These SPs count by finishing mode the total number of pages printed by all applications.					
	C:PrtPGS/FIN	CTL	[0 to 9999999 / 0 / 1]			
8 522	These SPs count by finishing mode the total number of pages printed by the Copy application.					
	F:PrtPGS/FIN	CTL	[0 to 9999999 / 0 / 1]			
8 523	These SPs count by finishing mode the total number of pages printed by the Fax application. •• Note					
	Print finishing options for received faxes are currently not available.					
8 524	P:PrtPGS/FIN	CTL	[0 to 9999999 / 0 / 1]			

	These SPs count by finishing mode the total number of pages printed by the Print application.				
	S:PrtPGS/FIN	CTL	[0 to 9999999 / 0 / 1]		
8 525	These SPs count by finishing rapplication.	count by finishing mode the total number of pages printed by the Scanner n.			
001	Sort				
002	Stack				
003	Staple				
004	Booklet				
005	Z-Fold				
006	Punch				
007	Other				

U Note

- If stapling is selected for finishing and the stack is too large for stapling, the unstapled pages are still counted.
- The counts for staple finishing are based on output to the staple tray, so jam recoveries are counted.

	T:Counter	CTL	[0 to 9999999 / 0 / 1]
8 581	application used. In addit	utput broken down by color output, regardless of the tion to being displayed in the SMC Report, these counters are arrools display on the copy machine.	
001	Total		

8 591	O:Counter		CTL	[0 to 9999999 / 0 / 1]
8 591 1	A3/DLT		rals for A3/DLT paper use, number of duplex	
8 591 2	Duplex		rinted, and the D:) application	e number of staples used. These totals are for as only.

8 601	Cvg Counter	CTL	[0 to 9999999 / 0 / 1]
8 601 1	Cvg: BW %	Displays the	e total coverage of each mode.

8 601 11 Cvg: BW Pages Displays the number of the printouts in each mode.

0.421	T:FAX TX PGS	CTL	[0 to 9999999 / 0 / 1]		
8 631	This SP counts by color mode the number of pages sent by fax to a te		of pages sent by fax to a telephone number.		
8 633	F:FAX TX PGS	CTL	[0 to 9999999 / 0 / 1]		
0 033	This SP counts by color mode the number of pages sent by fax to a telephone number.				
001	B/W				

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8631 and SP8633 are
 the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.
- Relay, memory, and confidential mailbox transmissions and are counted for each destination.

	T:IFAX TX PGS	CTL	[0 to 9999999 / 0 / 1]
This SP counts by color mode the number of pages sent by fax to as fax images l-Fax.			nber of pages sent by fax to as fax images using
	F:IFAX TX PGS	CTL	[0 to 9999999 / 0 / 1]
This SP counts by color mode the number of Fax.		ber of pages sent by Fax as fax images using I-	
001	B/W		

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8641 and SP8643 are the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.

• Relay, memory, and confidential mailbox transmissions and are counted for each destination.

	T:S-to-Email PGS	CTL	[0 to 9999999 / 0 / 1]	
This SP counts by color mode the total number of pages attached to a the Scan and document server applications.				
	S:S-to-Email PGS	CTL	[0 to 9999999 / 0 / 1]	
8 655	This SP counts by color mode the total number of pages attached to an e-mail for the Scan application only.			
001	B/W			

UNote

- The count for B/W and Color pages is done after the document is stored on the HDD. If the job is cancelled before it is stored, the pages are not counted.
- If Scan-to-Email is used to send a 10-page document to 5 addresses, the count is 10 (the pages are sent to the same SMTP server together).
- If Scan-to-PC is used to send a 10-page document to 5 folders, the count is 50 (the document is sent to each destination of the SMB/FTP server).
- Due to restrictions on some devices, if Scan-to-Email is used to send a 10-page document to a large number of destinations, the count may be divided and counted separately. For example, if a 10-page document is sent to 200 addresses, the count is 10 for the first 100 destinations and the count is also 10 for the second 100 destinations, for a total of 20.).

	T:Deliv PGS/Svr	CTL	[0 to 9999999 / 0 / 1]
These SPs count by color mode the total number of pages by both Scan and LS applications.		tal number of pages sent to a Scan Router server	
	S:Deliv PGS/Svr	CTL	[0 to 9999999 / 0 / 1]
8 665	These SPs count by color mode the total number of pages sent to a Scan Router server by the Scan application.		
001	B/W		

₩Note

- The B/W and Color counts are done after the document is stored on the HDD of the Scan Router server.
- If the job is canceled before storage on the Scan Router server finishes, the count is not done.
- The count is executed even if there is confirmation of the arrival at the Scan Router server.

	T:Deliv PGS/PC	CTL	[0 to 9999999/ 0 / 1]
8 671	These SPs count by color mode the total number of pages sent to a folder on to-PC) with the Scan and LS applications.		
	S:Deliv PGS/PC	CTL	[0 to 9999999 / 0 / 1]
8 675	These SPs count by color mode the total number of pages sent with Scan-to-PC with the Scan application.		
001	B/W		

UNote

- Print jobs done with Web Image Monitor and Desk Top Binder are added to the count.
- If several documents are merged for sending, the number of pages stored are counted for the application that stored them.
- When several documents are sent by a Fax broadcast, the F: count is done for the number of pages sent to each destination.

8 681	T:PCFAX TXPGS	CTL	These SPs count the number of pages sent by PC Fax.
8 683	F:PCFAX TXPGS	CTL	These SPs are provided for the Fax application only, so the counts for SP8-681 and SP8-683 are the same. [0 to 9999999 / 0 / 1]

- This counts pages sent from a PC using a PC fax application, from the PC through the copier to the destination.
- When sending the same message to more than one place using broadcasting, the pages are only counted once. (For example, a 10-page fax is sent to location A and location B. The counter goes up by 10, not 20.)

	TX PGS/Port	CTL	[0 to 9999999 / 0 / 1]		
8 <i>7</i> 01		umber of pages sent by the physical port used to send them. For original is sent to 4 destinations via ISDN G4, the count for ISDI			
8 701 1	PSTN-1	-			
8 701 2	PSTN-2	-			
8 701 3	PSTN-3	-			
8 701 4	ISDN (G3,G4)	-			

0.701.5					
8 701 5	Network	-	-		
8 <i>7</i> 11	T:Scan PGS/Con	np	CTL	[O t	9999999/0/1]
0.71.5	S:Scan PGS/Cor	mp	CTL	[0 t	o 9999999 / 0 / 1]
8 715	These SPs count t	he numb	er of pa	ges s	ent by each compression mode.
-001	JPEG/JPEG2000) -	-		
-002	TIFF M/S (Multi/ Single)	-	-		
003	PDF	-	-		
-004	Other	-	_		
				ì	
8 <i>7</i> 71	Dev Counter		CTL	[O t	9999999 / 0 / 1]
3771	This SP counts the total number of developed images.				
8 771 1	Total	-	-		
		•			
8 <i>7</i> 81	Toner Botol Info.		*BCU [0 to 9999999 / 0 / 1]		
	This SP displays the number of already replaced toner cartridges.				y replaced toner cartridges.
8 781	1 BK	The nur	mber of	black	toner cartridges
	Toner Remain		C1	ΓL	[0 to 100 / 0 / 1]
8 801	This SP displays the percent of toner remaining for each color. This SP allows the user to check the toner supply at any time. • Note				
	 This precise method of measuring remaining toner supply (1% steps) is better than other machines on the market that can only measure in increments of 10 (10% steps). 				
8 801 1	K				
8 851	Cvr Cnt:0-10% *BCU [0 to 9999999 / 0 / 1]				

	These SPs display the number of scanned sheets on which the coverage of each color is from 0% to 10%.
8 851 11	0-2%:Bk
8 851 21	3-4%: Bk
8 851 31	5-7%: Bk
8 851 41	8-10%: Bk

	Cvr Cnt: 11-20%	*BCU	[0 to 9999999 / 0 / 1]		
8 861	This SP displays the number of scanned sheets on which the coverage of each color i from 11% to 20%.				
8 851 1	ВК				

	Cvr Cnt: 21-30% *BCU [0 to 9999999 / 0 / 1]						
8 871	This SP displays the number of scanned sheets on which the coverage of each of from 21% to 30%.						
8 871 1	BK						

	Cvr Cnt: 31%-	*BCU	[0 to 9999999 / 0 / 1]
8 881	ed sheets on which the coverage of each color is		
8 881 1	ВК		

8 891	Page/Toner Bottle *BCU [0 to 9999999 / 0 / 1]					
		er of sheets	output by the scan application.			
8 891 1	ВК					

	Page/Toner k Prev 1	*BCU	[0 to 9999999/ 0 / 1]
8 901	out by the scan application with the previously		
8 901 1	ВК		

	Page/Toner Prev2 *BCU [0 to 9999999 / 0 / 1]						
8 911	This SP displays the number of sheets output by the scan application with the unit replaced before the previously replaced unit (two steps back from the current unit).						
8 911 1	ВК						

8 921	Cvr Cnt/Total	*BCU	[0 to 9999999 / 0 / 1]
8 921 1	Coverage(%): BK	These SPs dis	splay the total coverage percentage of sheets machine.
8 921 11	Covwerage/P: Bk	These SPs dis	splay the total coverage pages output by the

	Machine Status	CTL	[0 to 9999999 / 0 / 1]		
8 941	SPs are useful for custom	e SPs count the amount of time the machine spends in each operation mode. These are useful for customers who need to investigate machine operation for overment of their compliance with ISO Standards.			
8 941 1	Operation Time	0 1	ation time. Does not include time while controller ta to HDD (while engine is not operating).		
8 941 2	Standby Time	Engine not operating. Includes time while controller saves data to HDD. Does not include time spent in Energy Save, Low Power, or Off modes.			
8 941 3	Energy Save Time	Includes time while the machine is performing background printing.			
8 941 4	Low Power Time	Includes time in Energy Save mode with Engine on. Includes time while machine is performing background printing.			
8 941 5	Off Mode Time		e while machine is performing background es not include time machine remains powered off ver switches.		
8 941 6	SC	Total down	time due to SC errors.		
8 941 7	PrtJam	Total down	time due to paper jams during printing.		
8 941 8	OrgJam	Total down	time due to original jams during scanning.		
8 941 9	Spl PM Unit End	Total down	time due to toner end.		

0.000	AdominCounter		CTL	[0 to 9999999 / 0 / 1]		
8 999	Displays the user setting counter for administrator.					
8 999 1	Total	-				
8 999 3	Copy: BW	-				
8 999 7	Printer: BW	-				
8 999 10	FaxP: BW	-				
8 999 12	A3/DLT	-				
8 999 13	Duplex	-				
8 999 15	Cvr: BW %	-				
8 999 17	Cvr: BW Pages	-				
8 999 102	SendTtl: BW	-				
8 999 103	FaxSend	-				
8 999 105	FaxSend: BW	-				

Service Mode Table

SP No.	Description	Function and Setting
1001	BitSw#1 Set	Adjusts bit switch settings. Note: Currently the bit switches are not being used.
1003	Clear Setting	Not used
1004	Print Summary	Prints the service summary sheet (An error log is printed in addition to the configuration page).
1005	Display Version	Displays the version of the controller firmware.

SP Modes Related to Printer Controller

The following SP modes are located in the copier SP mode. Refer to section 5.1 of the main unit service manual.

SP No.	Description	Function and Setting
5104	A3/DLT Double Count	Specifies whether the counter is doubled for A3/DLT. 0: No, 1: Yes If ① is selected, the total counter and the current user code counter count up twice when A3 or DLT paper is used.
5801	Memory All Clear	Resets data for process control and all software counters, and returns all modes and adjustments to their defaults values. section "Memory Clear" in this chapter for details.
5907	Plug & Play	Selects the brand name and the production name for Windows Plug & Play. This information is stored in NVRAM.
7832	Detailed Display of Self-Diagnostics	Displays the controller self-diagnostic result.

4

4

Scanner Service Mode

Scanner Program Mode Table

Service Table Key

Notation	What it means		
[range / default / step]	Example: [-9 to +9 $/$ +3.0 $/$ 0.1 mm step]. The setting can be adjusted in the range ± 9 , value reset to +3.0 after an NVRAM reset, and the value can be changed in 0.1 mm steps with each key press.		
italics	Comments added for your reference.		
*	This value is stored in NVRAM. After a RAM reset, the default value (factory setting) is restored.		
DFU	Denotes "Design or Factory Use". Do not change this value.		

SP1	Mode Number		Function and [Setting]	
1004*	1	Compression Type	Selects the compression type for binary picture processing. [1: MH, 2: MR, 3: MMR]	
1005*	1	Erase Margin	Creates an erase margin for all edges of the scanned image. If the machine has scanned the edge of the original, create a margin. [0 to 5 / 0mm / 1 mm step]	

For the settings of the image quality, see the copier SP-mode table.

Using SP Mode

Memory Clear

GW Machine

The GW machine (the machine with the optional controller box) stores the engine data in the NVRAM on the BICU, and stores the other data in the NVRAM on the optional controller. To distinguish between the engine data and the other data, see SP5-801-003 through 019. This service program (SP5-801) handles the controller data. Any data that is not handled by SP5-801 is the engine data. The data in the BICU NVRAM (engine data) is cleared by SP5-998-001 while the data in the controller NVRAM (controller data) is cleared by SP5-801-xxx (for exceptions, see "").

Machine	Data	NVRAM	Cleared by	Remarks	
	Engine data	BICU	SP5-998-001	Any data other than controller data	
GW	Controller data	Controller	SP5-801-xxx	SCS, IMH, MCS, Copier application, Fax application, Printer application, Scanner application, Web service/ network application, NCS, R-Fax, DCS, UCS	

Exceptions

SP5-998-001 clears most of the settings and counters stored in the NVRAM on the BICU (the values return to their default values). However, the following settings are not cleared:

SP5-807 (Area Selection)

SP5-811-001 (Serial Num Input [Code Set])

SP5-811-003 (Serial Num Input [ID2 Code Display])

SP5-812-001 (Service TEL [Telephone])

SP5-812-002 (Service TEL [Facsimile])

SP5-907 (Plug & Play)

SP7 (Data Log)

SP8 (History)

Use SP5-998-001 after you have replaced the BICU NVRAM or when the BICU NVRAM data is corrupted. When the program ends normally, the message "Completed" is displayed. When you have replaced the

controller NVRAM or when the controller NVRAM data is corrupted, use SP5-801-001. The message is the same as the basic machine.

Memory Clear Procedure

- 1. Print out all SMC data lists ("SMC Print").
- 2. Do SP5-998-001.
- 3. Press the OK key.
- 4. Select "Execute." The messages "Execute?" followed by "Cancel" and "Execute" are displayed.
- 5. Select "Execute."
- 6. When the program has ended normally, the message "Completed" is displayed. If the program has ended abnormally, an error message is displayed.
- 7. Turn the main switch off and on.
- 8. Adjust the printer and scanner registration and magnification (Topy Adjustment" in the chapter "Replacement and Adjustment").
- 9. Refer to the SMC lists, and enter any values that differ from the factory settings. Double-check the values for SP4-901.
- 10. Adjust the standard white level (SP4-428).
- 11. Initialize the TD sensor (SP 2-214).
- 12. Check the copy quality and the paper path.

Serial Number Input (SP5-811)

Specifying Characters

SP5-811-001 specifies the serial number. For the machine with the optional controller, you use the numeric keypad and the optional operation panel.

GW Machine

You can use the numeric keypad to type numbers. In addition, you can use the operation panel to type other characters. When you press the "ABC" key, the letter changes as follows: $A \to B \to C$. To input the same letter two times, for example "AA," you press the "ABC" key, the "Space" key, and the "ABC" key. To switch between uppercase letters and lowercase letters, press the "Shift" key.

Serial numbers are stored in the NVRAM before shipment and are not cleared. You must specify a serial number after you replace the NVRAM.

SMC Print (SP5-990)

SP5-990 outputs machine status lists.

- 1. Select SP5-990.
- 2. Select a menu:
 - GW machine: 001 All (Data List), 002 SP (Mode Data List), 003 User Program, 004 Logging Data, 005 Diagnostic Report, 006 Non-Default, 007 NIB Summary, 008 Net File Log, 021 Copier User Program, 022 Scanner SP, 023 Scanner User Program, 040 Parts Alarm Counter Print, 064 Normal Count Print, 065 User Code Counter, 066 Key Operator Counter, 067 Contact List Print, 069 Heading 1 print, 071 Heading 3 print, 072 Group List Print, 128 ACC Pattern, 129 User Color Pattern, or 160:ACC Pattern Scan



- The output given by the menu "Big Font" is suitable for faxing.
- 3. Press the "Execute" key.
 - GW machine: The machine status list is output.
- 4. To return to the SP mode, press the key.

Counter-Each Paper Jam (SP7-504)

The table lists the menu numbers (the last three digits of SP7-504-XXX) and the paper jam timings and locations.

Code	
001	Paper jam occurs at power on.
010	Paper does not reach the registration sensor (from a paper tray).
011	Paper does not reach the relay sensor.
012	Paper is caught at the relay sensor.
021	Paper does not reach the vertical transport sensor.
022	Paper is caught at the vertical transport sensor.

4

031	Paper does not reach the vertical transport sensor in the optional paper feed unit.
032	Paper is caught at the vertical transport sensor in the optional paper feed unit.
050	Paper does not reach the registration sensor (from the by-pass tray).
060	Paper does not reach the registration sensor during reverse-side printing (for duplex printing).
070	Paper is caught at the registration sensor.
120	Paper is caught at the exit sensor (previous page).
121	Paper does not reach the exit sensor.
122	Paper is caught at the exit sensor.
123	Paper does not reach the duplex inverter sensor (from the registration roller).
125	Paper is caught at the duplex inverter sensor.
126	Paper does not reach the duplex entrance sensor.
127	Paper is caught at the duplex entrance sensor.
128	Paper does not reach the duplex exit sensor.
129	Paper is caught at the duplex exit sensor.
130	Paper does not reach the one-bin tray.
131	Paper is caught at the one-bin tray.

Original Jam History Display (SP7-508)

Viewing the Copy Jam History

You can view the information for the most recent 10 events. The information on older events is deleted automatically.



- The information on jam history is saved in the NVRAM.
- 1. Select SP7-508.
- 2. Select one of the menu items ("Latest 1" through Latest 10").
- 3. Press the OK key. The summary of the jam history is displayed.

4. To view more information, select "Detail."

Jam History Code

Code	Meaning
210	Original does not reach the registration sensor.
211	Original caught at the registration sensor.
212	Original does not reach the original exit sensor.
213	Original caught at the original exit sensor.
214	Original does not reach the original reverse sensor.
215	Original caught at the original reverse sensor.

Firmware Update Procedure

This section illustrates how to update the firmware of the GW machine (the machine with the optional controller box).

To update the firmware for the GW machine, you must have the new version of the firmware downloaded onto an SD (Secure Digital) Card. The SD Card is inserted into the uppermost slot on the right side of the controller box, viewed from the back of the machine.

Before You Begin...

An SD card is a precision device, so always observe the following precautions when handling SD cards:

- Always switch the machine off before inserting an SD card. Never insert the SD card into the slot with the power on.
- When the power is switched on, never remove the SD card from the service slot.
- Never switch the machine off while the firmware is downloading from the SD card.
- Store SD cards in a safe location where they are not exposed high temperature, high humidity, or exposure to direct sunlight.
- Always handle SD cards with care to avoid bending or scratching them. Never drop an SD card or expose it to other shock or vibration.

Keep the following points in mind while you are using the firmware update software:

• "Upload" means to send data from the machine to the SD card, and "download" means to send data from the SD card to the machine.

- To select an item on the LCD screen, press the appropriate key on the operation panel, or press the appropriate number key on the 10-key pad of the operation panel.
- Before starting the firmware update procedure, always make sure that the machine is disconnected from the network to prevent a print job for arriving while the firmware update is in progress.

Firmware Update Procedure



• Before beginning the following, first confirm which firmware version(s) are currently installed in the machine with SP7-801-255.

SD Card Preparation

- 1. Format an SD card with, for example, SD Formatter v1.1.
- 1. Create a "romdata" folder on the card.
- 2. Create the following folders within the "romdata" folder: B245, B268, B276, B277, etc.
- 3. Download the firmware from the server and store the files in the folder with the corresponding model code on the SD card.


Example:

File B2455540B should be stored in the "B245" folder, whereas files B6585902B, B6585903B, and B6585905B should be stored in the "B658" folder.


Firmware Update



• It is strongly recommended to store only B245/B276/B277 files on SD cards used for downloading to B245/B276/B277. With the controller used on this model, a firmware update may sometimes be interrupted if there is software for multiple models stored on the same SD card.




- 1. Turn off the main power switch.
- 1. If the machine is connected to a network, disconnect the network cable from the copier.
- 2. Remove the slot cover [A] (x 1)
- 3. With the label on the SD card facing the rear side of the machine, insert the SD card into the upper slot [B] on the controller box. Slowly push the SD card into the slot so it locks in place.
- Make sure the SD card is locked in place.
 (To remove the SD card, push it in to unlock the spring lock and then release it so it pops out of the slot.)
- 5. Switch the main power switch on. After about 5 seconds, the LCD will display "Please wait..." Then, about 60 seconds later, the LCD will display "Program UpDate Menu P.01" on the first line and the name of the firmware on the second line (e.g. System/Copy).



6. Press the "OK" key to select a module.

• To scroll through the menus, press the Δ or ∇ keys [A].




- b867s503
- To view the firmware version, press the right key. "ROM" is the information on the current firmware. "NEW" is the information on the firmware in the SD card.
- To return to the menu, press the

 key.
- To select the module, press the OK key.
- To scroll through the module name, the serial number, and the version, press the \triangleleft key or \triangleright
- If you wish to install the following firmware simultaneously, press the START key. The scroll keys can be used to confirm that this firmware has been selected (highlighted with a dark background). [Engine, FCU, Scanner, Printer, Printer Font, Security Module]



- Please note that the following firmware cannot be updated simultaneously. The update procedure must be repeated for each individually.
- System/Copy, ServiceCardNetFile, ServiceCardNIB, ServiceCardFAX, ServiceCardWebSystem.




b867s504

- When you have selected a module, the text lines are highlighted, and the "Verify" key and the "Update" key are displayed.
- 7. Select a module and press the "Update" key.



• Do NOT press the "Verify" key.

- 8. The firmware update program starts and the message "Loading" is displayed.
 - The update will begin, and then will take a few minutes to complete. The LCD will initially display, "Updating... ***-----".
 - When the update is completed, the LCD display will change to "Update done" or "Updated /
 Power Off On".




b867s505

9. Check that the message "Update Done" is displayed.

Confirmation

- 1. Turn the main power switch off and on.
 - The LCD will display "Please wait..." for about 60 seconds, after which it will return to the "Program UpDate Menu" screen.
- 2. Repeat Steps 1-8 above until all firmware updates are complete.
- 3. Turn the main power switch off.
- 4. Remove the SD card from the lower slot on the controller by pushing on the card to release the spring lock.



b867s506

If an error occurs, the error code is displayed. For a list of information on error codes, see the following table.

Cod e	Cause	Necessary Action
E20	Physical address mapping error	Insert the SD card correctly.Use another SD card
E22	Decompression error	Store correct data in the SD card.
E23	Update program error	Update controller program. Replace the controller.
E24	SD card access error	Insert the SD card correctly.Use another SD card.
E31	Download data inconsistency*	Insert the SD card that was used when the previous update procedure is interrupted.
E32	Download data inconsistency*	Insert the SD card that stores the correct data.
E33	Version data error	Store the correct data in the SD card.
E34	Locale data error	Store the correct data in the SD card.
E35	Machine model data error	Store the correct data in the SD card.
E36	Module data error	Store the correct data in the SD card.
E40	Engine program error**	Store the correct data in the SD card.Replace BICU.
E42	Operation panel program	 Store the correct data in the SD card. Replace the operation panel board.
E44	Controller program error*	 Store the correct data in the SD card. Replace the controller board.
E50	Authentication error	Store the correct data in the SD card.

^{*}You need to reinstall the program.

If the firmware update program is interrupted (for example, by a power failure), keep the SD card inserted and turn the mains switch off and on. The firmware update program restarts. If you do not do so, the message "Reboot after Card insert" is displayed when you turn the main switch on.

Uploading Content of NVRAM to an SD card

Follow this procedure to upload SP code settings from NVRAM to an SD card.



- This data should always be uploaded to an SD card before the NVRAM is replaced.
- Before switching the machine off, execute SP 5990-1 (SMC Print). You will need a record of the NVRAM settings if the upload fails.
- 2. Turn off the main power of the copier.
- 3. Remove the slot cover 3 (uppermost one) (F x 1).
- 4. Insert the SD card into the service slot 3 (uppermost one), then turn on the main power of the copier.
- 5. Execute SP 5824-1 (NVRAM Data Upload) then press the "Execute" key.
 - When uploading is finished, a file is coped to an NVRAM folder on the SD card. The file is saved to the path and filename:

NVRAM\<serial number>.NV

Here is an example with Serial Number "B0700017":

NVRAM\B0700017.NV

6. In order to prevent an error during the download, be sure to mark the SD card that holds the uploaded (saved) data with the number of the machine from which the data was uploaded (saved).



- NVRAM data from more than one machine can be uploaded (saved) to the same SD card.
- 1. Turn off the main power, and then remove the SD card from the slot 3 (the uppermost one).
- 2. Reassemble the machine.

Downloading an SD Card to NVRAM

Follow this procedure to download (save) SP data from an SD card to the NVRAM in the machine.

- If the SD card with the NVRAM data is damaged, or if the connection between the controller and BICU is defective, the NVRAM data download may fail.
- If the download fails, repeat the download procedure.
- If the second attempt fails, enter the NVRAM data manually using the SMC print you created before
 uploading the NVRAM data. (
 above procedure)
- 1. Turn off the main power of the copier.
- 2. Remove the slot cover 3 (the uppermost one) (F x 1).

- 1. Insert the SD card with the NVRAM data into the service slot 3 (the uppermost one).
- 2. Turn on the main power of the copier.
- 3. Execute SP 5825-1 (NVRAM Data Download) and press the "Execute" key.
- 4. Turn off the main power of the copier, and then remove the SD card from the slot 3 (the uppermost one).
- 5. Reassemble the machine.



 In order for the NVRAM data to download successfully, the serial number of the file on the SD card must match the serial number of the machine. If the serial numbers do not match, the download will fail.

This procedure downloads (saves) the following data to the NVRAM:

- Total Count
- C/O, P/O Count


Power-on Self Test

The controller tests the following devices at power-on. If an error is detected, an error code is stored in the controller board.

- CPU, ASIC and clock
- Flash ROM
- · Resident and optional SDRAM
- NVRAM
- PS fonts (if installed)

5. Detailed Section Descriptions

Overview



This machine uses the GW architecture. To enable printer features, install the printer option SD Card in the controller.

Main components:

- CPU: TOSHIBA TMPR4955BFG-300
- PICCOLO: GW architecture ASIC. It controls all the functions of the controller board.
- Flash ROM: 16 MB Flash ROM for the system program
- SDRAM: On board 64 MB, DIMM 128 MB (resident)
- NVRAM: Stores the controller settings
- LAN interface
- USB 2.0 interface
- SD Card: Printer/Scanner program

5

Optional components:


- PostScript3
- Bluetooth interface
- Wireless LAN interface
- IEEE1284 interface
- USB Host

5

Controller Functions

Paper Source Selection

Tray Priority (Auto Tray Select)



The Tray Priority setting determines the start of the tray search when the user selects "Auto Tray Select" with the driver.

The machine searches for a paper tray with the specified paper size and type.

When no tray contains paper that matches the paper size and type specified by the driver, the controller stops printing until the user loads the correct paper.

The Tray Priority setting can be specified using the Paper Size Setting in the user tools.

(User Tools/ System Settings/ Paper Size Settings)



• The by-pass tray is not part of the tray search.

Tray Lock

If Tray Lock is enabled for a tray, the controller skips the "locked" tray in the tray search process.

The Tray Lock setting can be specified by selecting "No" for the "Apply Auto Paper Select" setting in the Paper Size Setting screen in the user tools.

(User Tools/ System Settings/ Paper Size Settings)




• The by-pass feeder cannot be locked.

Manual Tray Select

If the selected tray does not have the paper size and type specified by the driver, the controller stops printing until the user loads the correct paper.

Auto Continue

If no paper tray matches the paper size and paper type specified by the driver:



When this function is enabled, the machine stops printing and cancels the print job if there is no paper tray which matches the paper size and paper type specified by the driver.

If Auto Continue is enabled, the machine waits for a specified period (0, 1, 5, 10, 15 minutes) for the correct size paper to be set in the tray, then cancels the print job if the interval expires.

The interval can be set via Printer Settings in the user tools.
 (User Tools/ Printer Settings/ System/ Auto Continue)

If Auto Continue is disabled, the machine will not print the job, but will not cancel it, so the job stays in the print queue.

5





• The default setting for Auto Continue is "Off."

Paper Output Tray

The default paper output tray for each application (copy/fax/printer) can be selected using the System Settings menu within User Tools.

(User Tools/System Settings/General Features)

If a print job does not specify an output tray or if the driver specifies the default tray, the default paper output tray is used.

Output Tray Selected

- If an output tray is specified by the driver, it overrides the default tray setting in User Tools.
- If the machine cannot print to the selected output tray, it prints to the default paper output tray.
- If the mailbox unit is installed, paper larger than B4 cannot be output to the standard (internal) tray.
- If paper overflow is detected at the selected output tray, the controller stops printing until the overflow detector indicates that the tray is no longer full.

Sequential Stacking

When the nine-tray mailbox is selected as the output tray and "Printer Default" is specified as the output tray in the driver, the machine automatically sends the output to the top tray (1st tray). When that tray fills up, the machine sends the output to the next tray.

This feature is called "Sequential Stacking."

- If a tray becomes full and the next tray is also full, the machine displays an error and stops printing.
 When the paper in the next tray is removed, the machine automatically resumes printing to the next tray.
- If all trays become full (overflow detected in all trays), the machine displays an error and stops printing.
 This time, all paper in all trays must be removed.

Duplex Printing

Duplex printing is available with all output bin options but not all paper sizes. If a job specifies duplex printing but the paper size to be used cannot be used by the duplex unit, the job will be printed single-sided.

When the by-pass feeder is selected as the paper source, duplex printing is automatically disabled.

Scanner Functions

Image processing for scanner mode


The image processing for scanner mode is done in the IPU chip on the BICU board. The IPU chip chooses the most suitable image processing methods (gamma tables, dither patterns, etc.) depending on the settings made in the driver.

The image compression method can be selected with SP mode (MR/MH/MMR for binary picture processing).

Whether the user selects the image mode using the driver (TWAIN mode) or from the operation panel (Delivery mode), the IPU chip does the image processing using the appropriate image processing methods mentioned above.

Image Data Path

1. Image Store/Image Delivery Mode




The user can select the following modes from the LCD.

Delivery only

After image processing and image compression, all image data for the job are stored in the printer controller RAM using TIFF file or PDF file format (binary picture processing). The type of file format used depends on the user's scanner settings.

When the delivery mode is selected, the controller creates a file which contains the destination and page information, and then the controller sends the file to a server.

2. Twain Mode



After image processing and image compression, the data (TIFF or PDF) is sent to the scanner Twain driver directory on the computer.


5

5

Network Interface

LED Indicators

The LEDs are on the optional controller box.



Description	On	Off
LED1 (Green): Link status	Link success	Link failure
LED2 (Yellow): Data rate	100 Mbps	10 Mbps

IEEE 802.11b (Wireless LAN)

Specifications

The IEEE 802.11b wireless LAN interface card is available as an option for this machine.

A wireless LAN is a flexible data communication system used to extend or replace a wired LAN. Wireless LAN employs radio frequency technology to transmit and receive data over the air and minimize the need for wired connections.

- With wireless LANs, users can access information on a network without looking for a place to plug
 into the network.
- Network managers can set up or expand networks without installing or moving wires.
- Most wireless LANs can be integrated into existing wired networks. Once installed, the network treats
 wireless nodes like any other physically wired network component.
- Flexibility and mobility make wireless LANs both effective extensions of and attractive alternatives to wired networks.

Standard applied:	IEEE802.11b		
	Speed	Distance	
	11 Mbps	140 m (153 yd.)	
Data transmission rates:	5.5 Mbps	200 m (219 yd.)	
	2 Mbps	270 m (295 yd.)	
	1 Mbps	400 m (437 yd.)	
Network protocols:	TCP/IP, Apple Talk, NetBEUI, IPX/SPX		
Bandwidth:	2.4GHz (divided over 14 channels, 2400 to 2497 MHz for each channel)		



The wireless LAN cannot be active at the same time as the Ethernet LAN. The following user tool setting
determines which LAN is active: System Settings - Interface Settings - Network - LAN Type.

LED Indicators

LED	Description	ON	OFF

LED 1 (Green)	Link Status	Linked	No Link
LED 2 (Orange)	Power Distribution	Power On	Power Off

Transmission Modes


Wireless communication has two modes: 1) ad hoc mode, and 2) infrastructure mode.

Ad Hoc Mode

The ad hoc mode allows communication between each device (station) in a simple peer-to-peer network. In this mode, all devices must use the same channel to communicate. In this machine, the default transmission mode is ad hoc mode and the default channel is 11. First, set up the machine in ad hoc mode and program the necessary settings, even if the machine will be used in the infrastructure mode.

To switch between ad hoc and infrastructure modes, use the following user tool: Host Interface Menu - IEEE802.11b - Comm Mode

Infrastructure Mode



The infrastructure mode allows communication between each computer and the printer via an access point equipped with an antenna and wired into the network. This arrangement is used in more complex topologies. The wireless LAN client must use the same SSID (Service Set ID) as the access point in order to communicate.

Security Features

SSID (Service Set ID)

The SSID is used by the access point to recognize the client and allow access to the network. Only clients that share the same SSID with the access point can access the network.



- If the SSID is not set, clients connect to the nearest access point.
- The SSID can be set using the web status monitor or telnet.

Using the SSID in Ad hoc mode

When the SSID is used in ad hoc mode and nothing is set, the machine automatically uses "ASSID" as the SSID. In such a case, "ASSID" must also be set at the client.



SSID in ad hoc mode is sometimes called "Network Name."

Some devices automatically change from ad hoc mode to infrastructure mode when the same SSID is used in ad hoc mode and infrastructure mode. In such a case, to use the device in ad hoc mode, use a specified SSID in infrastructure mode and use "ASSID" in the ad hoc mode.

WEP (Wired Equivalent Privacy):

WEP is a coding system designed to protect wireless data transmission. In order to unlock encoded data, the same WEP key is required on the receiving side. There are 64 bit and 128 bit WEP keys. However, this machine supports only 64 bit WEP.



The WEP key can be set using the Web Status Monitor or Telnet.

MAC Address:

When the infrastructure mode is used, access to the network can also be limited at the access points using the MAC address. This setting may not be available with some types of access points.

5

5

Wireless LAN Troubleshooting Notes

Communication Status

Wireless LAN communication status can be checked with the UP mode "W.LAN Signal" in the Maintenance menu. This can also be checked using the Web Status Monitor or Telnet.

The status is described on a simple number scale.

Status Display	Communication Status
Good	76 ~ 100
Fair	41 ~ 75
Poor	21 ~ 40
Unavailable	0~20




• Communication status can be measured only when the infrastructure mode is being used.

Channel Settings

If a communication error occurs because of electrical noise, interference with other electrical devices, etc., you may have to change the channel settings.

To avoid interference with neighboring channels, it is recommended that you use a channel separated from another in use by 3 channels. For example, if there are problems using channel 11 (default), try using channel 8.



Troubleshooting Procedure

If there are problems using the wireless LAN, check the following.

- 1. Check the LED indicator on the wireless LAN card.
- Check if "IEEE802.11b" is selected in the following user tool: Host Interface menu Network Setup
 LAN Type.
- 3. Check if the channel settings are correct.
- 4. Check if the SSID and WEP are correctly set.

If infrastructure mode is being used,

- 1. Check if the MAC address is properly set.
- 2. Check the communication status.
- 3. If the communication status is poor, bring the machine closer to the access point, or check for any obstructions between the machine and the access point. If the problem cannot be solved, try changing the channel setting.

Bluetooth

Specifications

Bluetooth wireless provides radio links between mobile computers, mobile phones and other portable handheld devices.

Bluetooth contains the following features.

- Cheaper compared to the IEEE802.11b wireless LAN.
- Many protocols for infrared transmission (IrDA) can be used with Bluetooth.
- A Bluetooth device can connect to other Bluetooth devices without any settings.

Standard applied:	Bluetooth 1.1 (Bluetooth Special Interest Group)
Data transfer rates:	1 Mbps
Bandwidth:	2.4GHz Frequency Hopping Spread Spectrum (FHSS)

Piconet:

Bluetooth devices communicate with other Bluetooth devices in the ad hoc mode. This network is called a "Piconet". A Piconet may contain a maximum of 8 Bluetooth devices.

There is one master device and seven slave devices in a Piconet. The master device controls the hopping frequency and timing, as well as storing the ID codes of the slave devices. The master and slave devices can be swapped. Once the master device leaves the Piconet, a slave device becomes the new master.

Machines with the Bluetooth option become potential slave devices to connect to a PC.

FHSS (Frequency Hopping Spread Spectrum):

The Bluetooth device divides 2402 to 2480 MHz into 79 channels of 1 MHz width, and changes the channel 1600 times per second. If other devices in the LAN are using the same radio band, Bluetooth can avoid interference from the other devices.

Bluetooth Profiles

A Bluetooth device will not operate if it is located overly close to another Bluetooth device. However, the Bluetooth device should support the protocols to communicate with each other. There are many types of Bluetooth and service protocols. These are listed below.

Here are 14 profiles for Bluetooth, as follows.

- Generic Access Profile
- Service Discovery Profile
- Cordless Telephony Profile
- Intercom Profile
- Serial Port Profile
- Headset Profile
- Dial-up Networking Profile
- Fax Profile
- LAN Access Profile
- Generic Object Exchange Profile
- Object Push Profile
- File Transfer Profile
- Synchronization Profile
- Hardcopy Cable Replacement Profile

Serial Port Profile (SPP) and Hardcopy Cable Replacement Profile (HCRP) are used for the printer products. SPP is used in place of the serial port, while HCRP is used in place of the parallel port.

Bluetooth Security Features

Public and Private Mode.

A computer can browse Bluetooth devices. The machine's default is public mode. A computer cannot browse the machine if it has been changed to private mode.

PIN Code (Personal Identification Number).

When the PIN code is used, a computer connects to the device that sent the PIN code. The PIN code is a 4 digit number. This machine uses the last four digits of the machine's serial number. It cannot be changed.

USB

Specifications

USB connectivity is provided as an option for this machine.

Interface:	USB 1.1, USB 2.0
Data rates:	480 Mbps (high speed), 12 Mbps (full speed), 1.5 Mbps (low speed)
Daid Tales.	High speed mode is only supported by USB 2.0.

USB 1.1/2.0

USB (Universal Serial Bus) offers simple connectivity for computers, printers, keyboards, and other peripherals. In a USB environment, terminators, device IDs (like SCSI), and DIP switch settings are not necessary.

USB 1.1 provides the following features:

- Plug & Play. As soon as a new device is connected via USB, the operating system recognizes it, and
 the appropriate driver is installed for it automatically if the driver is available. If the driver is not
 available, a message prompts the user for the driver disk for immediate installation.
- Hot swapping (cables can be connected and disconnected while the computer and other devices are switched on)
- No terminator or device ID required
- Data rates of 12 Mbps (full speed), and 1.5 Mbps (low speed)
- Common connectors for different devices
- Bi-directional data communication between device and host computer via a 4-byte header and DEVICE ID.


USB 2.0 is an evolution of the USB 1.1 specification. It uses the same cables, connectors, and software interfaces so the user will see no change. It provides an easy-to-use connection to a wide range of products with a maximum data rate of 480 Mbps (high speed).

Up to 127 devices can be connected and 6 cascade connections are allowed. Power is supplied from the computer and the maximum cable length is 5 m.


USB connectors

USB is a serial protocol and a physical link, which transmits all data on a single pair of wires. Another pair provides power to downstream peripherals. The USB standard specifies two types of connectors, type "A"

connectors for upstream connection to the host system, and type "B" connectors for downstream connection to the USB device.



Pin Assignment



The controller has a type "B" receptacle.

Pin No.	Signal Description	Wiring Assignment
1	Power	Red
2	Data –	White
3	Data +	Green
4	Power GND	White

Remarks about USB

- The machine does not print reports specifically for USB.
- Only one host computer is allowed for the USB connection.
- After starting a job using USB, do not switch the printer off until the job has been completed. When a user cancels a print job, if data transmitted to the printer has not been printed at the time of cancellation, the job will continue to print up to the page where the print job was cancelled

5

5

• When the controller board is replaced, the host computer will recognize the machine as a different device.

Related SP Mode

"USB Settings" in the printer engine service mode. Data rates can be adjusted to full speed fixed (12 Mbps). This switch may be used for troubleshooting if there is a data transfer error using the high speed mode (480 Mbps).

Data rates can also be adjusted using the UP mode "USB Setting" in the Host Interface in the System menu. This mode can be accessed only when the "Enter", "Escape", then "Menu" keys are pressed to enter the UP mode.

6. Specifications

General Specifications

Printer

Printing Speed:	Maximum 20 ppm (A4/LT LEF): B277 model Maximum 16 ppm (A4/LT LEF): B276 model		
Printer Languages:	PCL6/PCL5e PostScript 3 (option) RPCS (Refined Printing Command Stream) - an original Ricoh PDL)		
Resolution:	600 dpi (PCL 6/PCL5e/PS3/RPCS) 300 dpi (PCL6 PCL5e/PS3) 200 dpi (RPCS)		
Resident Fonts:	PCL: 35 Intellifonts 10 True Type fonts PS3: 136 fonts (24 Type 2 fonts, 112 Type 14 fonts)		
Host Interfaces:	USB 2.0 interface Ethernet (100 Base-TX/10 Base-T) (standard) Bi-directional IEEE1284 parallel x 1 (option) IEEE802.11 (Wireless LAN) (option) Bluetooth (option) USB Host (option)		
Network Protocols:	TCP/IP		
Memory:	128 MB		
Supported Paper Size	See the copier service manual.		

Scanner

Standard Scanner Resolution:	Main scan/Sub scan 600 dpi
Available scanning Resolution Range:	Twain Mode: 100 to 600 dpi E-mail/Network Delivery Scanner: 100 dpi, 200 dpi, 300 dpi, 400 dpi, 600 dpi
Scanning Throughput:	25 spm for TWAIN 43 spm for Delivery mode (A4L, ADF mode)
Interface:	Ethernet (100 Base-TX/10 Base-T for TCP/IP), IEEE 802.11b (Wireless LAN), Bluetooth
Compression Method:	Binary: TIFF (MH, MR, MMR)

Software Accessories

Printer

The printer drivers and utility software are provided on one CD-ROM. An auto-run installer allows you to select which components to install.

Printer Drivers

Printer Language	Windows 95/98/ME	Windows NT4.0	Windows 2000/ XP/2003	Macintosh
PCL 6	Yes	Yes	Yes	No
PCL 5e	Yes	Yes	Yes	No
PS3	Yes	Yes	Yes	Yes
RPCS	Yes	Yes	Yes	No



- The printer drivers for Windows NT 4.0 are only for the Intel x86 platform. There is no Windows NT 4.0 printer driver for the PowerPC, Alpha, or MIPS platforms.
- The PS3 drivers are all genuine AdobePS drivers, except for Windows 2000, which uses Microsoft PS. A PPD file for each operating system is provided with the driver.

Utility Software

Software	Description
Agfa Font Manager (Win 95/98/ME, NT4, 2000, XP)	A font management utility with screen fonts for the printer.
SmartNetMonitor for Admin (Win 95/98/ME, NT4, 2000, XP)	A printer management utility for network administrators. NIB setup utilities are also available.
SmartNetMonitor for Client	A printer management utility for client users. Peer-to-peer printing utility and parallel/recovery printing functions are included.

(Win 95/98/ME, NT4, 2000, XP)	
LAN-Fax (Win 95/98/ME, NT4, 2000, XP)	PC LAN FAX driver
Bitmap Installer (Win 95/98/ME, NT4, 2000, XP)	-
Install Manager (Win 95/98/ME, NT4, 2000, XP)	-
Install Manager Configuration (Win 95/98/ME, NT4, 2000, XP)	-
Printer Utility for Mac	This software provides several convenient functions for printing from Macintosh clients.

SCANNER

The scanner driver and utility software are provided on one CD-ROM.

Scanner Driver


• Network Twain Driver for Win95/98/ME/NT3.51/NT4.0/2000

Scanner Utilities

- Scan Router V2 Lite (Cherry-Lite) for Win95/98/ME/NT4.0/2000/XP
- Desk Top Binder V2 Lite (Plumeria-Lite) for Win95/98/ME/NT4.0/2000/XP

Machine Configuration

System Components



Item	Machine Code		Remarks
GW Board	B843	[A]	Required to install the printer/scanner unit
Printer/Scanner unit	B867	[C]	
RAM DIMM	_	[F]	Distributed with the printer/scanner unit
PostScript 3	B896	[B]	-
IEEE 1284	B679	[D]	
Wireless LAN	G813	[D]	One from the four

Bluetooth	B826	[D]	
Embedded RCG-M	B818	[D]	
USB Host	B825	[E]	-

MEMO

MEMO

