Paper Feed Unit TK2000 Machine Code: M406

Field Service Manual

TABLE OF CONTENTS

- D		•		•
1. Proc	luct i	nt	ormai	ior

С	verview	3
	Specifications	3
2	Replacement and Adjustment	
P	aper Feed Tray	5
	Left Cover	5
	Right Cover	6
	Rear Cover	6
	Paper Feed Unit	6
	Paper Feed Roller	8
	Friction Pad	8
	Paper Feed Motor	9
	Paper Feed Gear	9
	Paper Feed Tray Board	10
	Paper Size Detection Switch	10
	Paper End Sensor	10
	Paper Feed Sensor.	11
	Side Fence Adjustment	11


1

1. Product Information

Overview

Specifications





- 1. Grip roller clutch
- 2. Paper feed clutch
- 3. Grip roller
- 4. Paper feed roller
- 5. Friction pad

2

2. Replacement and Adjustment

Paper Feed Tray


Left Cover



$\overline{}$

Right Cover


1. Right cover [A] (*×3)



m1092091

Rear Cover


1. Rear cover [A] (**2, Hook*4)




Paper Feed Unit

- 1. Left cover (page 5)
- 2. Right cover (page 6)

3. Front cover [A] (*×6)




4. Paper feed unit [A] (♠×5,♣×1,♣×1)



Paper Feed Roller

1. Paper feed roller [A]




Friction Pad

1. Friction pad unit (*×2)




m1092096

2. Friction pad [A] (*x1)



Paper Feed Motor


- 1. Paper feed unit (page 6)
- 2. Paper feed motor [A] (*×4, *1)



m1092098


Paper Feed Gear

- 1. Paper feed unit (page 6)
- 2. Remove the gear cover [A], then remove the paper feed gears [B] (C×4, Spring ×1)



Paper Feed Tray Board


- 1. Paper feed unit (page 6)
- 2. Paper feed tray board [A] (♠×4, 🕮×4)



m1092100

Paper Size Detection Switch


- 1. Paper feed unit (page 6)
- 2. Paper size detection switch [A] (**1, Hook*2)



Paper End Sensor

1. Paper feed unit (page 6)


2. Remove the feeler [B], then remove the paper end sensor [A] ([]×1)



m1092102

Paper Feed Sensor

- 1. Paper feed unit (page 6)
- 2. Paper feed sensor [A] (🕮×1)



m1092103


Side Fence Adjustment

For the optional paper tray, you can adjust the side-to-side registration within a range of 2 mm, by changing the position of the Pinion on the side fence.

1. Pull out the tray from the optional tray and then turn it over.



• With the default setting (±0), the pinion is positioned so that the triangle marks are fully aligned.



2. Loosen the screws and lift up the pinion. Adjust the side-to-side registration in the desired direction and then tighten the screws.



m1092138



• The example image shows that the registration is adjusted by 2 mm to the right.