TotalFlow Print Server R-61 (Machine Code:M506)

Field Service Manual

Important Safety Notices

Warnings, Cautions, Notes

In this manual, the following important symbols and notations are used.

WARNING

• A Warning indicates a potentially hazardous situation. Failure to obey a Warning could result in death or serious injury.

• A Caution indicates a potentially hazardous situation. Failure to obey a Caution could result in minor or moderate injury or damage to the machine or other property.

🚼 Important

• Obey these guidelines to avoid problems such as misfeeds, damage to originals, loss of valuable data and to prevent damage to the machine.

Vote

• This information provides tips and advice about how to best service the machine.

General Safety Instructions


For your safety, please read this manual carefully before you use this product. Keep this manual handy for future reference.

Safety Information

Always obey the following safety precautions when using this product.

Safety During Operation

In this manual, the following important symbols and notations are used.



[B]: OFF

[C]: Push ON/Push OFF

[D]: Standby

Switches and Symbols

Where symbols are used on or near switches on machines for Europe and other areas, the meaning of each symbol conforms with IEC60417.

Safety

Prevention of Physical Injury

- 1. Before disassembling or assembling parts of the machine and peripherals, make sure that the machine and peripheral power cords are unplugged.
- 2. The plug should be near the machine and easily accessible.
- 3. Note that some components of the machine and the paper tray unit are supplied with electrical voltage even if the main power switch is turned off.
- 4. Always unplug the power cord from the power source before you move the product. Before you move the machine, arrange the power cord so it will not fall under the machine.
- 5. Disconnect all peripheral units (finisher, LCT, etc.) from the mainframe before you move the machine.
- 6. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
- 7. The machine drives some of its components when it completes the warm-up period. Be careful to keep hands away from the mechanical and electrical components as the machine starts operation.
- 8. The inside and the metal parts of the fusing unit become extremely hot while the machine is operating. Be careful to avoid touching those components with your bare hands.
- 9. To prevent a fire or explosion, keep the machine away from flammable liquids, gases, and aerosols.
- 10. Do not use flammable sprays or solvent in the vicinity of the machine. Also, avoid placing these items in the vicinity of the machine. Doing so could result in fire or electric shock.
- 11. To avoid fire or explosion, never use an organic cleaner near any part that generates heat.
- 12. Clean the floor completely after accidental spillage of silicone oil or other materials to prevent slippery surfaces that could cause accidents leading to hand or leg injuries.
- 13. Never remove any safety device unless it requires replacement. Always replace safety devices immediately.
- 14. Never do any procedure that defeats the function of any safety device.
- 15. Modification or removal of a safety device (fuse, switch, etc.) could lead to a fire and personal injury. Always test the operation of the machine to ensure that it is operating normally and safely after removal and replacement of any safety device.

- 16. For replacements use only the correct fuses or circuit breakers rated for use with the machine. Using replacement devices not designed for use with the machine could lead to a fire and personal injuries.
- 17. For machines installed with the ADF/ARDF: When a thick book or three-dimensional original is placed on the exposure glass and the ARDF cover is lowered, the back side of the ARDF rises up to accommodate the original. Therefore, when closing the ARDF, please be sure to keep your hands away from the hinges at the back of the ARDF.
- 18. When using a vacuum cleaner around the machine, keep others away from the cleaner, especially small children.
- 19. For machines installed with the anti-tip components:

The anti-tip components are necessary for meeting the requirements of IEC60950-1, the international standard for safety. The aim of these components is to prevent the products, which are heavy in weight, from toppling as a result of people running into or leaning onto the products, which can lead to serious accidents such as persons becoming trapped under the product. (U.S.: UL60950-1, Europe: EN60950-1) Therefore, removal of such components must always be with the consent of the customer. Do not remove them at your own judgment.

Health Safety Conditions

- 1. For the machines installed with the ozone filters:
 - Never operate the machine without the ozone filters installed.
 - Always replace the ozone filters with the specified types at the proper intervals.
- The machine, which use high voltage power source, can generate ozone gas. High ozone density is harmful to human health. Therefore, locate the machine in a large well ventilated room that has an air turnover rate of more than 50m³/hr/person.
- Toner and developer are non-toxic, but if you get either of them in your eyes by accident, it may
 cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If
 unsuccessful, get medical attention.

Observance of Electrical Safety Standards

 The machine and its peripherals must be installed and maintained by a customer service representative who has completed the training course on those models with exceptions on some machines where the installation can be handled by the user.

Safety and Ecological Notes for Disposal

1. Do not incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.

- 2. Dispose of used toner, developer, organic photoconductors, and AIO unit in accordance with local regulations. (These are non-toxic supplies.)
- 3. Dispose of replaced parts in accordance with local regulations.
- 4. When keeping used lithium batteries in order to dispose of them later, do not put more than 100 batteries per sealed box. Storing larger numbers or not sealing them apart may lead to chemical reactions and heat build-up.
- 5. The danger of explosion exists if a battery of this type is incorrectly replaced. Replace only with the same or an equivalent type recommended by the manufacturer. Discard used batteries in accordance with the manufacturer's instructions.

Handling Toner

- Work carefully when removing paper jams or replacing toner bottles or cartridges to avoid spilling toner on clothing or the hands.
- If toner is inhaled, immediately gargle with large amounts of cold water and move to a wellventilated location. If there are signs of irritation or other problems, seek medical attention.
- If toner gets on the skin, wash immediately with soap and cold running water.
- If toner gets into the eyes, flush the eyes with cold running water or eye wash. If there are signs of irritation or other problems, seek medical attention.
- If toner is swallowed, drink a large amount of cold water to dilute the ingested toner. If there are signs of any problem, seek medical attention.
- If toner spills on clothing, wash the affected area immediately with soap and cold water. Never use hot water! Hot water can cause toner to set and permanently stain fabric.
- Always store toner and developer supplies such as toner and developer packages, cartridges, bottles (including used toner and empty bottles and cartridges), and AIO unit out of the reach of children.
- Always store fresh toner supplies or empty bottles or cartridges in a cool, dry location that is not exposed to direct sunlight.
- Do not use a vacuum cleaner to remove spilled toner (including used toner). Vacuumed toner may cause a fire or explosion due to sparks or electrical contact inside the cleaner. However, it is possible to use a cleaner designed to be dust explosion-proof. If toner is spilled over the floor, sweep up spilled toner slowly and clean up any remaining toner with a wet cloth.

Handling the development unit cooling system

For the machines installed the development cooling system:

- 1. The development unit cooling system circulates propylene glycol from a sealed tank through hoses that pass behind cooling plates on the sides of each development unit.
- 2. The coolant tank is located at the bottom of the cooling box on the back of the main machine.

- 3. Always obey local laws and regulations if you need to dispose of a tank or the propylene glycol coolant.
- 4. The tank must never be emptied directly into a local drainage system, river, pond, or lake.
- 5. Contact a professional industrial waste disposal organization and ask them to dispose of the tank.

Laser Safety

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

WARNING

• Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

WARNING FOR LASER UNIT

WARNING:

Turn off the main switch before attempting any of the procedures in the Laser Unit section. Laser beams can seriously damage your eyes.



Safety Instructions for the Color Controller

Fuse

The color controller uses a double pole fuse. If this fuse blows, be sure to replace it with an identical fuse.

Batteries

- Always replace a battery with the same type of battery prescribed for use with the color controller unit. Replacing a battery with any type other than the one prescribed for use could cause an explosion.
- 2. Never discard used batteries by mixing them with other batteries or other refuse.

3. Always remove used batteries from the work site and dispose of them in accordance with local laws and regulations regarding the disposal of such items.

TABLE OF CONTENTS

1. Installation

Installation Requirements	7
Environment	7
Machine Level	7
Minimum Space Requirements	7
Power Requirements	8
Installation Flow Chart	
Machine Installation	11
Setting Customer Expectations	
Accessory Check	
Connector/ Front Panel	
Installation Procedure	
Initial Setting	
Initial Setting for Printer	
Initial Startup	19
Test Print	
Network Settings	
General Operations for Servicing	
Power Interlock Switch	
Switching Procedure of Power Interlock	27
Starting the Print Server	
Shutting Down or Restarting the Print Server	
Shutting Down the Print Server	
Restarting the Print Server	
Rebooting the Print Server	
Canceling the Current Print Job	
Test Print	
How to Access Consoles (Operation Screen)	
Overview	
Local Console	40
Remote Console	
Backing up Data/ Restoring Data	43
Automatic Backup for Configuration Data	43

Printing Configuration	
Calibration	
2. Replacement	
Cover Removal	
PCI cover	
Left Cover	48
Right Cover	
Front Cover	
Unit Removal	51
HDD	
HDD (for Operation System)	51
HDD (for Data Storage)	
PSU	54
RDTU Cooling Fan	
RDTU Board	
PIC Board	61
Cooling Fans	64
DIMM	66
7SEG Board	68
USB Dongle	68
Motherboard	69
Removal Procedure	69
Operation Checking after Motherboard Replacement	72
Time Setting	72
Procedures for Re-setting Options	75
Lithium Battery	75
CPU/ CPU Cooling Fan	76
CPU/ CPU Cooling Fan (Left)	77
CPU/ CPU Cooling Fan (Right)	79
DVD Drive	
Power Supply SW Board	
3. Software Maintenance	
Software Maintenance	

Backing up Data/ Restoring Data	
Overview	
Backing up Data	
Operation from the Printer Screen	
Operation from the Console Screen on the Print Server	
Restoring Data	93
Operation from the Printer Screen	
Operation from the Console Screen on the Print Server	96
System Software Installation Procedure	
Backing up Data	
Reinstalling the System Software	
Restoring Data	
Updating System Software	
Update Procedure	
Operation from the Printer Screen	
Operation from the Console Screen on the Print Server	
4. Troubleshooting	
Overview	
LED Error Code	
Overview	
How to Deal with an Error Code	
Diagnostic Code Table	
How to Identify the Location of CPU/DIMM/HDD Errors	
How to Identify the Location of CPU/DIMM/HDD Errors	
CPU	
DIMM	
HDD	
How to Solve When an Error Occurs	
How to Solve When an Error Occurs	
When the Printer SC Occurs	
When the Print Server Error Occurs	
Service Call (SC) Tables	
Service Call Conditions	

Service Call (SC911)	125
Traces	131
Managing Archived Traces	131
Operation from the Printer Screen	131
Operation from the Console Screen on the Print Server	132
Saving Traces	136
Operation from the Printer Screen	136
Operation from the Console Screen on the Print Server	139
Capturing a Print Job	143
Troubles That Related to the Optional IPDS	149
Cannot Exit SP Mode While Establishing a Session with the IPDS Print Server	149
Troubles That Related to External Printing Software	150
Data Cannot Be Sent Properly When Using Prinect	150
5. Detailed Section Descriptions	
Block Diagram and Functions	
Block Diagram	153
Functions	153
Network	153
PIC Board	154
RDTU Board	154
HDD	154
Mother Board	
Digital Display Board	154
USB Dongle	154
DVD Drive	154
USB I/F	155
6. Option	
IPDS	
Activating the IPDS	157
Activation Procedure	
Optional Features for IPDS	164
How to Reactivate	168
RIP Software	

Activating the RIP Software	
Activation Procedure	
How to Reactivate	
7. Specifications	
Specifications	
General Specifications	

1. Installation

Installation Requirements

Environment

- Temperature Range: 10°C to 32°C (50°F to 90°F)
- 2. Humidity Range:

10% to 85% RH

3. Ambient Illumination:

Less than 1,500 lux (do not expose to direct sunlight or strong light)

4. Ambient Dust:

Less than 0.10 mg/m³


- 5. If the place of installation is air-conditioned or heated, do not place the machine where it will be:
 - 1) Subjected to sudden temperature changes
 - 2) Directly exposed to cool air from an air-conditioner
 - 3) Directly exposed to heat from a heater
- 6. Do not place the machine where it will be exposed to corrosive gases.
- 7. Do not install the machine at any location over 3,048 m (10,000 feet) above sea level.
- 8. Place the controller on a strong and level base.
- 9. Do not place the machine where it may be subjected to strong vibrations.
- 10. Do not connect the machine to a power source shared with another electrical appliance.
- 11. The machine can generate an electromagnetic field, which could interfere with radio or television reception.

Machine Level


- 1. Front to back: Within $\pm 5^{\circ}$ (0.2") away from level
- 2. Right to left: Within $\pm 5^{\circ}$ (0.2") away from level

Minimum Space Requirements

Place the machine near the power source, providing clearance as shown.



- 1: Rear (200 mm or more)
- 2: Front (200 mm or more)



1: Printer

2: LCT

You may place the print server [A] on the right side of the large capacity tray or printer as shown in the illustration.


Power Requirements

WARNING

- Insert firmly the plug in the outlet.
- Avoid using an outlet extension plug or cord.
- Ground the machine. Avoid using a 3-pronged adapter in a 2-hole ungrounded outlet.
- Use the supplied AC power cord with this product.
- Input voltage level: 100-240V, 4.8A, 50/60 Hz
- Do not put anything on the AC power cord.

Installation Flow Chart

First install Pro C9110/C9100. (Hereinafter referred to as printer) Then install TotalFlow Print Server R-61. (Hereinafter referred to as print server) Recommended installation steps are as follows:



Machine Installation

Setting Customer Expectations

Before installation, the customer should be informed of the following:

- Some nodes on the network may be unavailable for up to one hour.
- Installation process will take about 80 minutes (with Microcode) / 70 minutes (without Microcode).
- The site administrator should be available during the installation for assistance with network connectivity issues.
- Equipment downtime and impact on the network can be minimized if the site administrator installs a network node for the print server and confirms network connection for the print server installation.
- The site administrator should have a networked computer available during the installation. The
 appropriate software should already be installed. Documentation for the networked computer and
 the network operating software should be available.
- The site administrator should install the user software shipped with the print server (user documentation is also included) onto the networked PCs and Mac OS computers that will print to the print server.

Note


• This guide covers hardware installation and service. It provides general information on connecting the print server to the customer's network. For network setup and configuration information for the network administrator, refer to the instruction manual "Setup Guide".

No.	Description	Q'ty
1	Power Supply Cord	1
2	Giga Ether Cable	1
3	Ferrite Core	4
4	Band	8
5	PCI Cover	1
6	Screw	2
7	EULA	1

Accessory Check

No.	Description	Q'ty
8	Release Note	1
9	Setup Guide	1
10	About the handling of the DVD	1
11	DVD: Operating Instructions	1

Connector/ Front Panel



No.	Name	No.	Name
1	VGA monitor port	10	Main power switch
2	USB port (backup)	11	Power connector
3	USB port (keyboard/mouse)	12	DVD drive
4	USB port (keyboard/mouse)	13	Disc eject button
5	Gigabit Ethernet port (print server to network.)	14	Front USB port

No.	Name	No.	Name
6	Gigabit Ethernet port (printer to print server)	15	Power switch
7	Digital display (7-segment)	16	Power indicator
8	Power interlock switch	17	HDD access indicator
9	Data Transfer Unit Port	18	System error indicator

Installation Procedure

- Use two persons when installing this product. This product is 20 kg or more in weight.
- Turn OFF the print server power switch and printer main power switch, then disconnect the power cords before following procedure.
- 1. Remove the controller cover [A] of the printer. (\mathfrak{V}^* ×2)



m205a0328

2. Remove the Gigabit Ethernet port cover [A]. ($\mathfrak{O}^* \times 1$).





3. Connect the interface cable [A] to the Gigabit Ethernet port of the printer. (🕬 ×1)

- Connect the interface cable which is connected to the printer to the Gigabit Ethernet port (Right) [A] of the print server. (1)
- 5. Connect the interface cable which is connected to a network to the Gigabit Ethernet port (Left) [B] of the print server. (SF×1)




Note

• To disconnect the interface cables, remove the I/O cover [A].




m272z1011

6. Connect the data transfer unit cable to the data transfer unit port [A] [B] of the printer.






 There are two types of data transfer unit cables: A and B. Check [A] part of the data transfer unit cables, and then connect the cable which is described as "A" into the port marked "A". Connect the cable which is described as "B" into the port marked "B".




7. Attach the controller cover [A]. (\mathfrak{O}^{P} ×2)




m205a0326

Note


• Pass the interface cable [B] and the data transfer unit cables [C] through the cut off part of controller cover [A].



m205a0327




8. Attach the ferrite cores [A] on the data transfer unit cables and attach the bands to prevent slipping off the ferrite core as below.



m272z1012

9. Attach the ferrite cores [A] on the end of the data transfer unit cables going to print server and attach the bands to prevent slipping off the ferrite core ad below.





10. Pass the two data transfer unit cables through the openings of the PCI cover [A].



m272z1005



m272z1002

12. Set the power interlock switch [A] to the ON position.



m272z1003

13. Install the PCI cover [A] to the print server. (\mathfrak{P}^* 2)





14. Connect the power cord [A] to the print server.

15. Plug the power cord of the print server to the outlet.

Initial Setting

Initial Setting for Printer

- 1. Turn ON the main power switch on the printer.
- 2. Enter the SP mode.
- 3. Check the following firmware at SP-7-801-255 (ROM No./ Firmware Version).
 - System V1.02 or higher
 - Engine V4.002b:14 or higher
 - TDCU V1.03a:05 or higher
 - Web Support V1.02 or higher
 - Network Support V14.65 or higher
- 4. Set the following SP.
 - "7" (Kurofune) at SP5-193-001 (External Controller Info. Setting)
 - "1" (invalid) at SP5-895-001 (Application invalidation / Printer) (If it is displayed)
- 5. Exit the SP mode.
- 6. Turn OFF the main power switch on the printer.

Initial Startup

The print server has a function to interlock the main power with the printer.


By turning this function on in the print server, the print server's power goes off when the printer is turned off.

When the interlock switch is set to OFF, the interlock function is turned OFF, and when the switch is set to ON, the interlock function is turned ON.

1. Turn ON the main power switch [A] on the print server.



- Do not turn OFF immediately after the main power switch to ON. HDDs and memory might be damaged.
- Do not use the power button [U] to turn the print server ON. Otherwise the print server detects that the printer is OFF, and then the server automatically shutdown by the power interlocking.
- 2. Turn ON the main power switch on the printer.
- 3. Make sure the print server is automatically turned on and the power indicator comes on.
- 4. Make sure "00" is displayed on the digital display [A] at the rear side of the print server.



m272z1006

Note

• If a code other than "00" is displayed, check the Service manual (LED ERROR CODES) for code description.

5. Press the [Home] key on the operation panel of the printer and wait about five minutes until the [TotalFlow] icon appears on the Home screen.


				Ŗ
Copier	Scamer	TotalFlow	Document Server	
Address Book Management				
			m273	z8001

Test Print


1. Press the [TotalFlow] icon to access to the menu screen.




2. Press [User Tools/Adjustment].



3. Press [Print Samples].




4. Press [Color test page].



m273z8004

5. Press [Print].




6. Make sure that the test page is printed normally.

Network Settings


1. Press the [TotalFlow] icon to access to the menu screen.

23

2. Press [User Tools/Adjustment].



3. Press [Ethernet Configuration].



4. Configure the network settings.

Hardware address	00:E0:81:EC:A6:63
Card	Ethernet copper integrated #1
Use DHCP to obtain DNS servers	es
IP address of primary DNS server	
IP address of secondary DNS server	
DHCP timeout	0
Domain name of local host	
	1/3 AProv. V

5. Configure in accordance with network environment, then press [OK].

Ethernet Adapter - Common		Cancel	OK
Hardware address	DHCP Plus and Play	Cancel	OK
Card	Select item, then press [OK].		
Use DHCP to obtain IP address of primer IP address of seconds DHCP times DHCP times DHCP times	Yes No		
Constitution of the			
		1/3 🔺 Pre	V Next
		m	273z8008

6. After completing configuration of the network fields, press [OK].

thernet Adapter - Common	Cancel	OK
 Hardware address 	00:E0:81:EC:A6:63	
Card	Ethernet copper integrated #1	
Use DHCP to obtain DNS servers	Yes	
IP address of primary DNS server		
IP address of secondary DNS server		
DHCP timeout	60	
Domain name of local host		
	1/3	rev. 🔍 🛡 Next
		m273z800

General Operations for Servicing


Power Interlock Switch

The print server has a function to interlock the main power with the printer.

By turning this function, the print server's power goes OFF when the printer is turned off.

When the interlock switch is set to OFF, the interlock function is turned OFF, and when the switch is set to ON, the interlock function is turned ON.

The power interlock switch is located at the rear side of the print server. It is recommended for use in ON.



Switching Procedure of Power Interlock

- 1. Turn OFF the power switch of the print server and the printer.
- 2. Turn OFF the main power switch of the print server.
- 3. Wait for about one minute.

4. Switch the power interlock switch.

C Important

- After the main power switch to OFF the internal voltage left for a while. Therefore, wait for about one minute before switching.
- 5. Turn ON the main power switch of the print server.

Starting the Print Server

🔁 Important

- When the power interlock function is enabled, the print server turns OFF/ON the power in tandem with the printer's operation.
- When the power interlock function is disabled, first turn ON the printer, and then turn ON the print server. Otherwise, the print server will not work correctly.

When the power interlock function is disabled, start the print server in the following procedure:

- 1. Turn ON the main power switch of the printer.
- 2. Turn ON the main power switch (rear side) [A] of the print server.

🔁 Important

Do not turn OFF the main power switch of the print server immediately after turning it ON.
 Doing so may result in damage to the hard disk or memory, leading to malfunctions.



3. Push down the power switch (front side) of the print server.

The power indicator lights up.

The [TotalFlow] icon appears on the home screen of the control panel of the printer.

4. Press the [Home] key on the operation panel of the printer and wait about five minutes until the [TotalFlow] icon appears on the home screen.

				ţ,
Copier	Scamer	TotalFlow	Document Server	
Address Book Management				
			m27	3z8001

Shutting Down or Restarting the Print Server

🔁 Important

- Do not turn OFF the main power switch of the print server when the power indicator is lit.
- If the print server is shut down while another user is editing job properties, the edited data will be lost.

Vote

• If the shutdown sequence of the print server is suspended, the job will be resumed from where it was suspended after the print server restarts.


Shutting Down the Print Server

🔁 Important

- When the power interlock function is enabled, the print server turns OFF/ON the power in tandem with the printer's operation.
- When the power interlock function is enabled, you cannot shut down the print server using the control panel of the printer.
- When the power interlock function is disabled, turn OFF the print server first, and then turn OFF the printer.

If the power interlock switch is OFF, shut down the print server in the following procedure:

- 1. Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon.
- 2. Press [Stop] to suspend the printer operation.




3. Press [User Tools/Adjustment].

Operations	Jobs	Paper Setting	UserTools/Adjustment
Active (0)	Inactive (2)	History (24)	
Status	Job name	Owner	Find
• Retained space	e Test Print - Co	nfialog Service	
• Retained space	• Test Print - In	terPage ddc	Print
			Hold

1

4. Press [Shutdown Computer].



m273z8011

5. Press [OK].

O Not	Ready		Stop Chart
Orera O Shutda Resta Resta Shutd	•	This procedure performs an orderly shutdown of the software and then powers off the computer. Any job that is receiving is terminated. Any job that is printing will be available for reprinting later.Are you sure that you want to shutdown the computer now?	nt are ration
Diek C		Cancel OK	
Re	etore		
Unda	te Code		
Code V(I	version		
			m273z8012

6. To shut down the print server, make sure that the power indicator is turned OFF, and then turn OFF the main power switch of the print server.

C Important

- Do not turn OFF the main power switch of the printer until the power indicator of the print server goes out. Doing so may result in damage to the hard disk or memory, leading to malfunctions. After turning off the main power switch of the print server, wait for two minutes or more before turning it on again.
- 7. Turn OFF the printer.

Restarting the Print Server


When restarting the print server to recover from a problem, try this procedure first. However, this procedure will only restart the print server application software. To reboot the system OS, see the next section "Rebooting the Print Server".

1. Press [Stop] to suspend the printer operation.


			CONTRACTOR OF THE OWNER.
Active (0) In	active (2) 🔪 🛛 H	listory (24)	
tatus	Job name	Owner	Find
Retained space	Test Print - Cor	fialog Service	
• Retained space	Test Print - Int	erPage ddc	

m273z8049

2. Press [User Tools/Adjustment].



3. Press [Restart Software].



m273z8013

4. Press [OK].

O Not	Ready		stop Dbrt
Overs Or Shutck Rest: Rest: Shutch	•	This procedure performs an orderly shutdown of the software then does a restart. Any job that is receiving is terminated. Any job that is printing will be available for reprinting later.Are you sure that you want to restart the software now?	nt ins ration
Disk C		Cancel OK	
R	ectore		
Urd	ate Code		
Code v(1	version		


m273z8014

Rebooting the Print Server

Use this procedure to reboot the system OS.

33

1. Press [Stop] to suspend the printer operation.




2. Press [User Tools/Adjustments].

🔵 Not Ready		an in the second second second	Stop Start
Operations	Jobs	Paper Setting	UserTools/Adjustment
Active (0)	active (2)	History (24)	
Status	Job name	Owner	Find
001 • Retained space	Test Print - Co	nfialog Service	
02 9 Retained space	Test Print - In	terPage ddc	Print
			Hold
			m273z805


1

3. Press [Restart Computer].




m273z8015

4. Press [OK].



Canceling the Current Print Job

 Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon. 2. Press [Jobs].



3. Select the job that you want to cancel.

Ready				Stop Sta
Operations	Jobs	Paper Setting	UserTools/Ad	ljustment
Active (0) Ina	ctive (3) His	story (22)		
Status	Job name	Owner		Find
• Held before print	Printer_test2.pdf			
2 9 Retained space	Test Print - Confi	ialog Service		Print
3 9 Retained space	Test Print - Inter	rPage ddc		Hold
				Delete
			_	
				Actions
				Properties


Test Print

1. Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon.

2. Press [User Tools/Adjustment].

Operations	Jobs		Paper Setting	UserTools/Adjustme	nt
perator Message				·	
CB1A - No output trays	s are available			Details	
Tray Information					
Tray Information		-			
Tray Information	85×110	63.1 - 80.0 gsm	6 🔳	%×11D	63.1 - 80.0 gs
	85×11₽ 11×17₽		6 🗐 A 🗐	%×11₽ %×11₽	
1 💷		80.0 gsm 63.1 - 80.0 gsm 63.1 -			80.0 gs 63.1 -
1 💷	11×17⊡	80.0 gsm 63.1 - 80.0 gsm 63.1 - 80.0 gsm 63.1 -			80.0 gs 63.1 -
1 III 2 III 3 III	11×17⊡ %×11⊡	80.0 gsm 63.1 - 80.0 gsm 63.1 - 80.0 gsm			80.0 gs 63.1 -

3. Press [Print Samples].




4. Select the test page you want to print.



Vote

- You can select the following test pages:
 - Color test page
 - Tray adjustment
 - CMYK colors
 - CMY colors
 - RGB colors
 - Blank page

5. Press [Print].



How to Access Consoles (Operation Screen)

Overview

You can access to the print server from the consoles in the following ways:

• Local Console

By connecting a commercially available monitor, keyboard, and mouse to the print server, you can directly operate the print server with the local console.

• Remote Console

You can operate the print server from a web browser of the client computer. To use the remote console, connect the client computer and print server to a network. To access the print server using the remote console, log in to the print server.

The layout of the console screen is the same even if accessed from either. (Some in remote access, there is a restricted function.)

You can manage such as logging, network and maintenance on the console screen.

perations	Jobs	Configuration	Maintenance			Submit Job	Service ▼	?
	Basic		Input Trays [9]			Preset		
aper	Simplest and m	ost basic printer settings.	Settings to con trays.	figure the paper input			and retrieve setups for ortant printer settings ply restored.	
	Allow to print sample Yes	0			Name	Ricoh		
rinter	Reprint unfinished Yes pages Flip for face up duplex No	Yes	Tray	Tray status		Status Currently loaded		
		No	Tray 1	Enabled		Jobs using this preset	Valid	
	Printer name		Tray 2	Enabled				
_	Printer information		Tray 3	Enabled				
olor	Printer Information	ormation	Tray 4	Enabled		Date/Time		8
agement	details Printer location		Tray 5	Enabled	Н		n the printer or identify	y the
<u>ک</u>	Enter Sleep mode after	2 hours	Tray 6	Enabled			e printer should utilize ent time on every start	
	Wake on network	Yes	Tray 7	Enabled	Ŧ	-		
Stream	traffic		Output Trays [2]		a	Date and time 12/31/2		
	When printer sleeps	DFE sleeps immediately		figure the paper output		Time zone America Deriver Time source Manual		
twork			0					
ist into			Output Trays	Tray Status	_	Extended Feature		
ÇŲ.			Booklet processor tray	Enobled			feature settings allow ins to be installed and	
			Finisher upper tray	Enabled		enabled for a p		
curity						□ 亩 ▶ Ⅱ		
0						Extended feature name	Status	_
							0.000	

1. Hub

This is the main operational menu. Machine details or the configuration screen appear when you click the items.

2. Pod

Indicates each item in a panel.

3. Tab

Appears on the left side of the screen when the [Configuration] hub is open. Each tab has pods.

For more information on display and setting items of the console screen, refer to "Operating Instructions".

Local Console

To use the local console, attach a monitor, keyboard and mouse to the print server.

After print server starts, the console screen is displayed.

Switch to the service authority after the print server starts, because you are logged in automatically with administrator in the local console.

Operations	Jobs Cor	figuration	Maintenance		Submit Job	😳 A	dministrator	
Job Previe	Job Infor_	Active Jobs [0]				Logou		alles!
	and the second se		i=v			User	Preferences	10100
		Status	Job Name	User Name	Size	Copies	Job Type	Action
Job name:		313025	- AN INGINE	oper morne	3420	copies	Jab Type	1 140.004
		nactive Jobs [0]] Stored Jobs [5]	Invalid Jobs [2]	Job Log [21]		Q.][View	*]]□[×
		▶ II i Ø	i≣ v					
	0.00	► II 📋 🔗 Status	Job Name	User Name	Size	Copies	Job Type	Action
	×⊠ ⇔ ⇔ ∕∘ <u>≥≥</u>			User Name	Size	Copies	Job Type	Action
I≤ ≤ Input Tray_ [Ir	/0 > >1			User Name	Size	Copies	Job Type	Action
	/0 > >1			User Name	Size	Copies	Job Type	Action
I≤ ≤ nput Tray_ [Ir	/0 ≥ ≥I			User Name	Size	Copies	Job Type	Action
I< < Input Tray_ Ir Ø	/0 >>I nterposer_ Paper 210.0 x 297.0 mm, A Plain, Weight 2 (63.1 -			User Name	Size	Copies	Job Type	Action
ISIS	70 >> hterposer.			User Name	Size	Copies	Job Type	Action

1. Click [Administrator] and select "Logout" on the console screen.

- 2. After the login screen appears, select "Service" to log in from [User name:].
- 3. Enter the password in [Password:].
- 4. Click [Login].

Note

• The initial password is blank. Set the password after the initial login. For details about how to change the password, see "Operating Instructions".




m273z8026

Console screen appears after login.

Remote Console

- 1. Launch the web browser.
- 2. Enter "http://(IP address or host name of the print server)/" in the address bar.
- 3. Press the [Enter] key.


The login screen appears.



- 4. Select a user to log in from [User name:].
- 5. Enter the password in [Password:].
- 6. Click [Login].

Note

- Customer engineers select "Service" for user name.
- The initial password is blank. Set the password after the initial login. For details about how to change the password, see "Operating Instructions".



Console screen appears after login.

Backing up Data/ Restoring Data

You can use the backed-up data to restore the data after a hard drive failure or to copy the configuration data to another installation of the print server. (page 86 "Backing up Data/ Restoring Data")

Automatic Backup for Configuration Data

To back up the configuration data automatically, insert a writable USB memory into the rear USB port of the print server.

When printing 1,000 sheets or more, it will back up them automatically per 24 hours after booting.



m273z6002


Printing Configuration

- 1. Access to the print server by the local or remote console.
- 2. Click [Maintenance].


Read	У					o C71105	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Operations	Jobs	Configuration	Maintenance		Subm	it Job	🔅 Service	v 2
Job Previ_ Jo	b Infor_ 🛛 🖓 🗆 🗆	Active Jobs [0]				80	L] [View	•][[]X]
► II i ð	v≣.	► II 亩 Ø	i 🗐 🔻					
Job name:		Status	Job Name	User	Name Size	Copies	Job Type	Action_
	800	Inactive Jobs [1		Invalid Jobs [0]	Job Log [20]	@ (C	k] [View	•][] X]
	/0 > >1	Status	Job Name	▲ User	Name Size	Copies	Job Type	Action.
	10 2 21	E Held	Printer_test2.pdf		108.7 K	B 1	PDF	► ŭ
Input Tra. In	terpos. 🛛 🖓							
Tray	Paper							
1 💷 🖓	8.5 x 11.0 in, Plain, Weight 2 (63.1 – 80.0 gsm)	<u>^</u>						
2 🔳 🕞	11.0 x 17.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
3 🔳 🕞	8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
4 🔳 💭	8.5 x 11.0 in, Plain, Weight 2 (63.1 -	Ŧ						

m273z8027

3. Select the type of the configuration data for printing.



4. Select the option items if necessary and click [OK].



Calibration

1

This product is provided with calibration targets using ColorPort. Below shown are two types of calibration targets stored in the folder on the driver CD-ROM provided.

• Folder

Calibration

- File names
 - Calibration_Target_Standard.xml (Standard accuracy target)
 - Calibration_Target_High.xml (High accuracy target)

Before calibrating a printer, import the xml files using ColorPort. For details about how to calibrate a printer, see "Calibrating the Printer", Operating Instructions, and the help in ColorPort.


Cover Removal

PCI cover

1. Remove the outer part of PCI cover [A]. (\mathfrak{V}^* 4)



Remove the data transfer unit cables while pushing the lock behind the connector. (*2)




3. Remove the inner part [A] of the PCI cover [A]. (**5)



Left Cover

1. Slide the left cover backward [A]. (🕅×3)



Right Cover


1. PCI cover (page 47)

2. I/O cover [A] (1 × 3)



• Note

- To disconnect the interface cable, remove the I/O cover.
- 3. Slide the right cover backward [A]. (🕬×2)



Front Cover

- 1. Left cover (page 48)
- 2. Right cover (page 48)

3. Front cover [A] (🕬×6)



Unit Removal

WARNING

• Unplug the power cord from the power source before attempting any of the procedure in this section.

HDD

The print server has three HDDs. One is for operating system [A] and the other two are for data storage [B].



m273z3046

HDD (for Operation System)

- 1. Left cover (page 48)




m273z3003

3. Remove the HDD (for operation system) [A] with the bracket. (**3)



m273z3004

4. HDD [A] (X×4)




Vote

- When replacing the HDD, install the system software from the system software DVD packed with the new HDD.
- When the IPDS is activated, reactivate the IPDS after replacing the HDD. (page 168 "How to Reactivate")


HDD (for Data Storage)

- Be sure to install the system software to reconfigure the system setting, due to these HDDs are RAID O structure. (page 101 "System Software Installation Procedure")
- 1. Left cover (page 48)

2. Release the connectors and clamps from the HDD (for data storage) [A] [B]. (🗺 ×4, 🖗 ×3)




3. Remove the HDD (for data storage) [A] [B] with the bracket. ($\textcircled{\sc storage} \times 6)$



m273z3007

4. HDD (for data storage) (⁽⁾×4)



Note

- When replacing the HDD, install the system software from the system software DVD packed with the new HDD.
- When the IPDS is activated, reactivate the IPDS after replacing the HDD. (page 168 "How to Reactivate")

PSU

- 1. Left cover (page 48)
- 2. Lay down the machine.



m273z3008

2



Note

• All connectors have a locking mechanism on the lower side. Release the connectors by releasing the lock in the figure below of the order.



m273z3010

4. Remove the electrostatic tape [A] on the PSU [B] and the housing.





- Note
 - After installing a new PSU, put the electrostatic tape on as before.


5. Remove the screws of the PSU [A] and the bracket [B]. (🕮×5)



6. Remove the PSU [A] in the following order.



7. Remove the electrostatic tapes [A] on the PSU [B].



Note

• Put the electrostatic tapes on a new PSU as before.


RDTU Cooling Fan

- 1. Left cover (page 48)
- 2. Lay down the machine.




m273z3008

3. Release the ferrite core [A] and the two clamps. (𝒱×1, ☜×2)




4. Remove the RDTU cooling fan [A] with the bracket. (☞×3, ×1, ☞×1)



2

5. RDTU cooling fan [A] (@*×2)



RDTU Board

CAUTION

• Do not touch the terminal part of the RDTU board. Clean with alcohol in case of touching the terminal.




m272z3003

1. Left cover (page 48)

2. Lay down the machine.



3. Remove the USB socket [A] with the USB dongle. (×2)




4. Release the ferrite core [A]. (SXX1)




m272z3002

 Disconnect the connectors on the PIC board, RDTU cooling fan, and RDTU board. Then remove the bracket [A]. (☞×9, ×3, ☞×5)



6. RDTU board [A] (@*×1)



PIC Board


• Do not touch the terminal part of the PIC board. Clean with alcohol in case of touching the terminal.



- 1. Left cover (page 48)
- 2. Lay down the machine.



3. Remove the USB socket [A] with the USB dongle. (SXX2)




m272z3001




4. Release the ferrite core [A]. (SXX1)

 Disconnect the connectors on the PIC board, RDTU cooling fan, and RDTU board. Then remove the bracket [A]. (☞×9, ×3, ☞×5)




6. Remove the PIC board [A] with the bracket. (🞯 ×1)



m272z3006

2

7. PIC board [A] (@*×2)



Cooling Fans

- 1. Left cover (page 48)
- 2. Lay down the machine.




m273z3008





4. Release the ferrite core [A]. (@*×1)

 Disconnect the connectors on the PIC board, RDTU cooling fan, and RDTU board. Then remove the bracket [A]. (☞×9, ×3, ☞×5)




6. Disconnect the connectors from the cooling fans [A]. (\Im ×2)




m273z3025

7. Remove the cooling fans with the bracket [A]. (**5)



8. Cooling fans [A] (each 🕸×2)






• When installation, attach to the bracket so that the fan label is the same direction as the photo.


DIMM

• Do not touch the terminal part of the DIMM. Clean with alcohol in case of touching the terminal.



m273z3028

- 1. PIC board (page 61)
- 2. Open the both sides of the lever, and pull out DIMM (×8) [A] from the sockets.



Note


- When installing, gently slide the DIMM straight down into the socket and push into the slot. Make sure that the levers close securely around the ends of the DIMM.
- DIMMs fit in the socket only one way.

7SEG Board

- 1. PIC board (page 61)
- 2. Remove the 7SEG board [A] with the bracket. (🕮 ×1)




3. 7SEG board [A] (@*4, @**1)



USB Dongle

1. Left cover (page 48)



2. Remove the dongle cover [A] and pull out the USB dongle [B]. (🗊×1)


Motherboard

Coloritant 🖸

 The license key is registered in the USB dongle. At initial startup the serial number of the motherboard is written to the USB dongle to prevent unauthorized use. The print server does not start when the serial number does not match. Therefore, when you replace the motherboard, USB dongle also need to be replaced at the same time (New USB dongle is packed with the motherboard).

Removal Procedure


- 1. 7SEG board (page 68)
- 2. RDTU Board (page 59)
- 3. Cooling fan bracket (page 64 "Cooling Fans")



4. Release the clamps and connectors around the motherboard [A]. (\$×3, \$×10)

Note

• When installing the motherboard, make sure the harness (20 pins) is connected to FPIO1 connector (23 pins) [A] and the harness (10 pins) is connected to CT5 connector (9 pins) [B].



5. Remove the electrostatic tape [A] on the LAN adapter.




m273z3050

Note

- After installing a new motherboard, put the electrostatic tape on as before.
- 6. Motherboard [A]. (@×9)

• Remove the motherboard carefully to prevent the harness and connectors from damage.

2



Vote

- When installing a new motherboard, make sure to remove the CPU cooling fans, CPU and DIMM from the old motherboard and install them on the new motherboard.
- 7. Remove the old USB dongle and install the new one. (page 68 "USB Dongle")

Operation Checking after Motherboard Replacement

- 1. Make sure that the print server is in the following states:
 - Main power is turned OFF
 - Anything not in the DVD drive
 - Connected to the printer
- 2. Turn ON the main power on the rear of the print server, and turn ON the power on the front of the print server.
- 3. Make sure that the print server is standby status.
- Install the system software from the system software DVD. (page 101 "Reinstalling the System Software")
- 5. Print a test page from the operation panel of the printer and make sure whether correctly can be printed. (page 36 "Test Print")

Time Setting

Set the date and time in the BIOS or console of the print server after replacing the motherboard.

Setting date and time in BIOS

In order to set the time in the BIOS screen, connect a monitor and keyboard to the print server.

- 1. After the print server boots, immediately press the [F2] key.
- 2. Select the [Main] tab, and then set [System Date]/[System Time] with the arrow keys and the numeric keypad.

- Select the [Save & Exit] tab with the arrow keys, and press the [F4] key (Save & Exit).
- 4. Select [Yes] in the pop-up screen, and then press the [Enter] key.
- 5. The BIOS screen is closed, and the print server startup sequence is started.

Setting date and time in the console of the print server

- 1. Access to the print server by the local or remote console.
- 2. Click [Stop] to change the status of the printer [Not Ready].

Rea	dy					Stop	Start	Pro C			
Operations	Jobs	Con	nfiguration	Maintenance			-	Submit	Job 【	Service	•
	ob Infor 🛛 🗆		Active Jobs [0]						1 (Q	View •	
Job name:			Status	Job Name		User Nam	ne .	Size	Copies	Job Type	Action_
			Inactive Jobs [1]	Stored Jobs [0]	Invalid Jol	os [0]	Job Log	[20]		View 7 *	
	10 > >1		Status	Job Name Printer_test2pdf		User Nam	he	Size 108.7 KB	Copies	Job Type PDF	Action.
0	nterpos. 🛛 🖾 🗔	_		PTERUM_UPS (2001				1067 NB	1	FUF	
Tray	Paper	-									
1 🛄 💭	8.5 x 11.0 in, Plain, Weight 2 (63.1 – 80.0 gsm)	1									
2 🔲 🖓	11.0 x 17.0 in, Ptain, Weight 2 (63.1 – 80.0 gsm)	H									
3 🔳 🕞	8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)										
4 🔳 D	8.5 x 11.0 in, Plain, Weight 2 (63.1 -	v									

3. Select [Configuration] → [Printer].

4. Click [Date/Time].

Operations	Jobs	Configuration	Maintenance		Submit Job		
	Basic		Input Trays [7]	Interposer Trays _	Preset		
Paper	Simplest and mos	t basic printer settings.	Settings to o	onfigure the paper input trays.	Presets store and retrieve setups for the printer. All important printer settings for a can be simply restored.		
	Output jogging	None	9		Name Ricoh		
Printer	Allow to print sample Yes		Tray	Tray status	Status	Currently loaded	
	Reprint unfinished pages	Yes	Tray 1	IPDS default	Jobs using this preset	Valid	
	Flip for face up duplex Printer name	No	Tray 2	Enabled			
	Printer information		Tray 3	Enabled			
Color	Printer information		Tray 4	Enabled	Date/Time		
Management	details		Tray 5	Enabled		the printer or identify the	
6	Printer location Enter Sleep mode after Wake on network traffic	2 hours	Tray 6	Enabled	method that the	printer should utilize to	
			Tray A	Enabled	obtain the curren	nt time on every startup.	
Data Stream	When printer sleeps	DFE sleeps immediately			Date and time 02/16/2015 14:53:39 PM Time zone US Aleutian Time source Manual		
-			Output Trays [4]				
4000			Settings to configure the paper output trays.		Time source Manual		
Network							
101			Output Trays	Tray Status	Extended Features	[3]	
			Perfect binder tray	Enabled		vature settings allow to be installed and enable	
			Finisher shift tray	IPDS default	for a printer.		
Security			Finisher upper tray	Enabled	Din⊳II		
			Trimmer tray	Enabled	Extended feature name	Status	
-					IPDS	Enabled	
					884289	Disabled	
					884418	Disabled	

111270

5. Set the date and time, and then click [OK].

Operations	Jobs	Configuration	Maintenance		Submit Job	o Ø Service ▼	
	Basic		Input Trays [7]	Interposer Trays _	Preset		8
Paper	Simplest and m	ost basic printer settings.	Settings to co	nfigure the paper input trays.		and retrieve setups for the portant printer settings for restored.	
	Output jogging	None	0		Name	Ricoh	
Printer	Allow to print sample	Yes	Tray	Tray status	Status	Currently loaded	
	Reprint unfinished page Flip for face up duplex	s Yes	Tray 1	IPDS default	Jobs using this preset	: Valid	
101	Printer name	Date/Time			2		
	Printer Information			d that the printer should utilize to o	iotain the		
Color	Printer Information	Current time on	every startup.				
Oprinent	details Printer location				time time	on the printer or identify the	
0	Enter Sleep mode after	Date and time	02/16/2015 🛅 2 🕂 :	54 ÷ 8 ÷ O AM 6	9 PM od that 1	the printer should utilize to	
1000	Wake on network traff	Time zone	US	Aleutian	·	ment time on every startup.	
ata Stream	When printer sleeps	Time source	Manual			6/2015 14:54:08 PM	
-					US	Aleutian	
4000					Man	ual	
_							
Network							
100000000000000000000000000000000000000				OK	Cancel Feature	es [3]	
INSTR			Perfect binder tray	Enabled		feature settings allow	
ÎĤ				Endowed	additional opt	ions to be installed and enal	blei
<u>iài</u>			Enister shift trav	IPOS default			
Security			Finisher shift tray	IPDS default			
Security			Finisher upper tray	Enabled	C ii ► II		
Security						> Status	
Security			Finisher upper tray	Enabled		e Status Enabled	
Security			Finisher upper tray	Enabled	Extended feature name		

6. "Configuration Restart" popup displays to reflect changes and click [Restart].

O Not	Ready				PRCOH Pro CONT	5 	
Operations	Jobs Configuration	M	aintenance		Submit Job	Service V	?
Paper	Basic Simplest and most basic printer set	tings.	Input Trays [7]	Interposer Trays		nd retrieve setups for the stant printer settings for estored.	
Printer	Output jogging None Allow to print sample Yes Reprint unfinished pages Yes Filip for face up duplex No Printer name		P Name Ricch Tray Tray status Status Currently is Jobs using this preset Valid Tray 2 Enabled Valid Valid Valid				
Color Management	Printer information Printer information details Printer location Enter Steep mode after 2 hours	Confi	guration Restart guration changes are pen e next Shutdown or Rest	ding and will be reflected art	method that th	the printer or identify the printer should utilize to enrinter should utilize to int time on every starbup	
Data Stream	Wake on network traffic Yes When printer sleeps DFE sleeps imm	ediat		131 1975.	Date and time 02/16 Time zone US Time source Monus	2015 14:55:22 PM Aleutian	
Network			Perfect binder tray	Tray Status Enabled	additional optio	• [3] eature settings allow ns to be installed and ena	iii sbied
Security			Finisher shift tray Finisher upper tray	IPDS default Enabled	for a printer.		
			Trimmer tray	Enabled	Extended feature name IPOS 884289 884418	Status Enabled Disabled Disabled	Å
						m273z80	093

The print server automatically restarts.

Procedures for Re-setting Options

When the IPDS is activated, reactivate the IPDS after replacing the motherboard. (page 168 "How to Reactivate")

Lithium Battery

- There is danger of explosion if the battery is replaced with the incorrect type. Replace with only the same lithium battery supplied as a spare part.
- Discard the used motherboard battery in accordance with the manufacturer's instructions and local regulations.
- 1. RDTU Board (page 59)

2. Lithium Battery [A]



Vote

• When installing the lithium battery, set as "+" side is visible. Re-configure the system date and time after booting.



CPU/ CPU Cooling Fan


- The CPU cooling fan becomes extremely hot during operation. Since touching the high temperature component risks burns, perform the replacement operations after a temperature inside the machine is sufficiently dropped.
- When replacing the CPU, be sure to replace both the CPU and the CPU cooling fan. When replacing only the CPU, there is a possibility of overheating.
- When replacing the CPU, make sure that the pin of the CPU socket are not bent. When the pin of the CPU socket is bent, it can cause operating failure of the print server.
- Be careful not to damage the motherboard, the CPU, or the CPU socket when replacing the cooling fan.

CPU/ CPU Cooling Fan (Left)

- 1. PIC board (page 61)
- 2. CPU cooling fan (left) [A] (∜×1, ☞×1, ☞×4)




3. Unlock the upper/lower of the CPU socket [A].



m273z3037

4. Open the socket cover [A].




m273z3038

5. Grasp the edges of the CPU [A] and remove from the CPU socket.




Vote

- When installing a new CPU cooling fan, coat properly the thermal compound of accessories between the fan and CPU.
- When installing a CPU, adjust the position of the CPU (marking [A]) and CPU socket (marking [B]) as shown in the figure below.




CPU/ CPU Cooling Fan (Right)

- 1. PIC board (page 61)
- 2. Cooling fan bracket (page 64 "Cooling Fans")
- 3. CPU cooling fan (right) [A] ([®]×2, [™]×1, [™]×4)




4. Open the socket cover [A].



m273z3041

5. Open the socket cover [A].



m273z3042


2



6. Grasp the edges of the CPU [A] and remove from the CPU socket.

Note

- When installing a new CPU cooling fan, coat properly the thermal compound of accessories between the fan and CPU.
- When installing a CPU, adjust the position of the CPU (marking [A]) and CPU socket (marking [B]) as shown in the figure below.



m273z3044

DVD Drive

1. Front cover (page 49)


2. Remove the fixing screws of the DVD drive [A]. (***4)






m273z3014

4. Pull out the DVD drive [A].




Power Supply SW Board

- 1. Front cover (page 49)
- 2. Remove the power supply SW board [A] with the bracket. (${\mathfrak S}^{*} \times 2, \, {\mathfrak S}^{*} \times 1$)



3. Power supply SW board [A] (🕬×2)



m273z3018

Software Maintenance

Operation is required after replacing the HDD (for operating system), HDD (for data storage), and motherboard. Reference to the following:

ltems	HDD (Operation System)	HDD (Data Storage)	Motherboar d	Details
Reinstalling system software installation	Required	Required		Installation of basic OS Initialization for HDD (restructuring of RAID) (page 101 "System Software Installation Procedure")
Updating system software installation	A/N	A/N		Update to the latest Microcode (page 104 "Updating System Software")
Reinstalling optional products	A/N	A/N	A/N	IPDS activation (page 157 "IPDS")
Resetting configuration	A/N	A/N		Restoring or manual setting
Replacing dongle			Required	
Resetting time			Required	Time setting
Reinstalling fonts	A/N	A/N		Reinstalling the customer own fonts other than the pre-installed fonts (Usually user operation)

A/N: As needed

Backing up Data/ Restoring Data

Overview

Backing up and restoring data can be operated from the printer and the console screen.

You can backup following data:

- Configuration data
- User-created ICC profiles

Operating from the console screen can also backup and restore the following data:

- Logs
- Traces
- Jobs

Note

- Fonts cannot be backed up.
- Backup data of TotalFlow Print Server R-60 cannot be restored to R-60A.

Backing up Data

Operation from the Printer Screen

Note

- When performing a backup from the printer, you can back up only the configuration data and user-created ICC profiles.
- When performing a backup from the printer, the destination of the backup is limited to USB memory.
- Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon.

2. Press [Stop] to suspend the printer operation.

Operations	Jobs	Paper Setting	UserTools/Adjustment
Active (0) In	active (2) H	listory (24)	
Status	Job name	Owner	Find
Retained space	Test Print - Con	nfialog Service	
• Retained space	Test Print - Int	terPage ddc	Print
			Hold

3. Press [User Tools/Adjustment].


Not Ready			Stop St
Operations	Jobs	Paper Setting	UserTools/Adjustment
Active (0)	active (2)	History (24)	
Status	Job name	Owner	Find
1 9 Retained space	Test Print - Co	nfialog Service	
2 9 Retained space	Test Print - In	terPage ddc	Print
			Hold
			m273z80

4. Insert a USB memory into the front USB port of the print server.




• It is not recognized in the rear USB ports of the print server.

5. Press [Backup].



m273z8019

6. Press [Backup].



• You can change the file name by pressing [Edit].

Operation from the Console Screen on the Print Server

1. Access to the print server by the local or remote console.

Read	ly			Stoe	Start Pro C	7110S		
Operations	Jobs	Configuration	Maintenance		Submit	Job	Service	• 2
	b Infor_ @ 🗆	Active Jobs [0				0	View •	
Job name:	Job name:		Job Name	User Nam	e Size	Copies	Job Type	Action.
		Inactive Jobs		Invalid Jobs [0]	Job Log [20] ve Size	Copies	Job Type	Action
	10 2 21	E Held	Printer_test2pdf		108.7 KB	1	PDF	► 1
-	terpos 🛛 🖓 🗆 🕬							
0	1-	_						
1 🛄 💭	Paper 8.5 x 11.0 in, Plain, Weight 2 (63.1 – 80.0 gsm)	A						
2 🗐 🖓	11.0 x 17.0 in, Plain, Weight 2 (63.1 – 80.0 gsm)							
3 🔳 🕞	8.5 x 11.0 in, Plain, Weight 2 (63.1 – 80.0 gsm)							
4 🔳 🖓	8.5 x 11.0 in, Plain, Weight 2 (63.1 -							
							m273z	8028


2. Click [Stop] to suspend the printer operation.

3. Click [Maintenance].

O Not	Ready			Stoo	Start			
Operations	Jobs	Configuration	Maintenance		Submit	Job	🔅 Service	•
Job Previ_	Job Infor_ 🛛 🖂 🖂	Active Jobs [0]				0	L][View	•][= ×]
▶ II îî	🤊 iiit	► II 🗃 🖉	i≣v					
Job name:		Status	Job Name	User Name	Size	Copies	Job Type	Action
	3.8.0.0	Inactive Jobs [1]		Invalid Jobs [O] Jo	b Log [20]	Copies	L] [View ·	Action
$ \leq $	10 >>>	Held	Printer_test2pdf	- Ose harre	108.7 KB	1	PDF	•
Input Tra.	Interpos. 🛛 🕬 🗆 🖄							
Tray	Paper	_						
1 💷 🖓	8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)	<u>A</u>						
	11.0 x 17.0 in, Plain, Weight 2 (63.1 -	-						
2 🔳 🕞	80.0 gsm)							
2								

m273z8062

4. Click [Backup] on the [Disk Operations] pod.



- 5. Select the method of backup to perform and click [OK].
 - [Normal] includes configuration data and user-created ICC profiles.
 - [Extended backup] adds logs, trace, or both to [Normal] data.
 - [Extended backup (include Jobs)] adds jobs to [Extended backup] data. It is only available at the local console.

Vote

• Executing [Extended backup (include Jobs)] reboots the print server.


Not Ready			Sta	o Start	Pro C71105		Ӯ
Operations Jobs	Configuration	Maintenance			Submit Job	Service V	?
Shutdown/Restart Use these procedures to restart shut down the DFE and control to Restart Tota/Row Print Sen Restart Printer Controller Shut Down Printer Controller	and property nit software.	VTest Print [12] Use to print configurati masters to verify print sprocedure creates a config ropagate this printer config	quality. uration backup that can b	The caller	e calibration to er adjusting the colo tion procedure is j scourate colors ister] button to h must be sca pration data is	sure optimal print qual or output density. Derformed to make sur Select the [Print begin, A color test ma need by an optical scan then loaded back into t ccepted as the new	e the A
Disk Operations Use these functions to manage data and control unit software Backup	Configur	ation	tended backup	-	the calibration le [Print Calibr Calibration Mar Calibration	procedure over at any stion Master] button. ster	time v
Restore HDD Erase Update Code	☑ Logs ☑ Trace file	es			faces to captur ase software p	re the data needed to roblems.	-
Tools and Logs Use these tools and logs to main printer.	itain the		ОК	Cancel	e Star Save T Configur Trace A	races e Trace	
DFE Hardware Status, Logs., Hibernation Event Status					_		
						m273z8	030

 Specify the destination (USB memory/network/email) of the data and enter the file name. Click [Save].

Operations Jobs	Configurati	on Maint	enance		Submit	Job 🔅 Service 🔻 ያ
hutdown/Restart	8	List/Test Print	t [12]	8	Calibration	8
Use these procedures to restart and shut down the DFE and control unit			int configuration data and tes to verify print quality.	t		ion to ensure optimal print quality the color output density.
Restart TotalFlow Print Server Restart Printer Controller	V				Die 📫 🖬	re is performed to make sure the colors. Select the [Print ton to begin. A color test master
Shut Down Printer Controller	<u>111</u>	Name	Date Modified	Size	•	e scanned by an optical scanning sta is then loaded back into the ally accepted as the new
isk Operations						ation procedure over at any time Calibration Master] button.
Use these functions to manage cont data and control unit software.						n Master
Backup,						
HDD Erase						apture the data needed to are problems.
pols and Logs		File name	000000000000000000000000000000000000000			StartStop
Use these tools and logs to maintail printer.		Files of type	*.*	bag		ave Traces hfigure Trace ace Archive
DFE Hardware Status	Download	File_		Save	Cancel	
Logs Hibernation Event Status						-


Note

- When saving the data to a USB memory, insert it into the front USB port of the print server. It is
 not recognized in the rear USB ports of the print server.
- Clicking [Download File] when accessing from the remote console allows you to save the data to the client PC.



Vote

• When sending email, enter the email address, and enter the message text or subject. Click [Send].



Restoring Data

Operation from the Printer Screen

1. Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon.

2. Press [Stop] to suspend the printer operation.



m273z8049

3. Press [User Tools/Adjustment].

Operations	Jobs	Paper Setting	UserTools/Adjustment
Active (0)	mactive (2)	History (24)	
Status	Job name	Owner	Find
• Retained space	Test Print - Con	nfialog Service	
Retained space	Test Print - Int	terPage ddc	Print


4. Insert a USB memory into the front USB port of the print server.



• It is not recognized in the rear ports of the print server.

5. Press [Restore].

Note




- m273z8022
- 6. Select the data that you want to restore and press [Restore].

○ Not Ready		Stop Ctart
Disk Operations : Restore		Exit
Name	Date Modified	Restore
001 0000000000.bak_bas	12/28/2014, 10:12:10	
002	12/08/2014, 18:03:02	
		m273z8023

• If the backup file contains other than the configuration data and user-created ICC profiles, you can restore only the configuration data and user-created ICC profiles.

7. Confirm the contents and then press [OK].



Operation from the Console Screen on the Print Server

- 1. Access to the print server by the local or remote console.
- 2. Click [Stop] to suspend the printer operation.

Rea	idy			Stoe	Start Pro	C71105		
Operations	Jobs	Configuration	Maintenance		Submi	t Job 🔅 Serv	ice 🔻 <table-cell></table-cell>	
L	Job Infor 🛛 🗆 🖂	Active Jobs [0				Q View		
Job name:	<i>v</i>	Status				Size Copies Job Type Act		
	N 8000	Inactive Jobs	Job Name	Invalid Jobs [0]		Copies Job Typ		
		Held	Printer_test2.pdf		108.7 KB	1 PDF	•	
Input Tra.	Interpos. 🛛 🖓 🗆 🖂	-						
Tray	Paper	-						
1 💷 💭	8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)	·						
2 🔳 🕞	11.0 x 17.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
3 🔳 🕞	8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
4 🔳 🖓	85 x 11.0 in, Plain,	Ŧ						
						m27	3z8028	

3. Click [Maintenance].

O Not R	eady	F		Stor St	rt Pro (7110S		
Operations	Jobs	Configuration	Maintenance		Submit	Job	Service	• 2
	Infor_ @ □ i≣▼	Active Jobs [0]					View -	
Job name:		Status	Job Name	User Name	Size	Copies	Job Type	Action.
		Inactive Jobs [1		Invalid Jobs [O] Job L	.og [20]	2	View •	
	800 ∕•≥≥	Status	Job Name Printer_test2.pdf	User Name	Size 108.7 KB	Copies	Job Type PDF	Action.
Input Tra_ Inte	Paper 85 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
2 🛄 🖓	11.0 x 17.0 in, Plain Weight 2 (63.1 - 80.0 gsm) 8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
4 🔳 🖟	85 x 11.0 in, Plain, Weight 2 (63.1 –	v						

m273z8062

4. Click [Restore] on the [Disk Operations] pod.

Operations	Jobs	Configuration	Maintenance		Submit J	ob 🚯 Service 🔻		
ihutdown/Rest	art		List/Test Print [12]	6	Calibration			
	rocedures to restart the DFE and control u		Use to print configurat masters to verify print			n to ensure optimal print quality he color output density.		
Restart TotalFlow Print Server			Test master		The calibration procedure is performed to make sure the printer prints accurate colors. Select the (Print calibration Master) button to beain. A color test master			
Restart Printer Controller Shut Down Printer Controller			rest master Configuration [5] Logo Lo			e scanned by an optical scannin lata is then loaded back into the		
Disk Operations			Paper catalog		You can start the calibration procedure over a			
			PostScript fonts		by selecting the [Print Calibration Master] butto			
Use these functions to manage configuration data and control unit software.		onnguration	Presets Printer configuration		Print Calibration Master			
10.000 C			PDF [7]		Load Calibration			
	Dackan		PDF - Blank page			· · · · ·		
	Restore_		PDF - CMY colors		Traces Use traces to capture the data needed to diagnose software problems.			
	NUC Brase		PDF - CMYK colors					
	Update Code		PDF - Color test page		diagnose sortware problems.			
			PDF - Profiles		Job Capture			
ools and Logs		8	PDF - RGB colors		StartStop			
	ools and logs to main	tain the	PDF - Tray adjustment			Save Traces		
printer.						Configure Trace Trace Archive		
						ave recare		
D	FE Hardware Status							
-	Logs							
Hib	ernation Event Status							

5. Specify the destination where the backup file is saved and click [Load].

Not Ready				Stop	Start Pro C	
Operations Jobs	Configuration	Maintenanc	e		Submit	Job 🔯 Service 🔻 🔋
Shutdown/Restart Use these procedures to restart and shut down the DFE and control unit s	property 0	Use to print [12]	iguration data and test print quality.			on to ensure optimal print quality the color output density.
			Pata Modflad	577 M	6 Ca	e is performed to make sure the colors. Safect the Print ton to begin. A color test master e scarne by an optical scarning to is then loaded bock into the elly accepted as the new ation procedure over at any time calibration Master] button. In Master
Update Code Tools and Logs Use these tools and logs to maintain printer. DFE Hardware Status Logs Hibernation Event Status			201412311750.bsk_bag *.*	Load	Cancel	StartStop we Traces rifigure Trace ace Archive
						m273z8033

Note

- If you restore the data from a USB memory, insert it into the front USB port of the print server. It is not recognized in the rear USB ports of the print server.
- Clicking [File Upload] when accessing from the remote console allows you to restore the data from the client PC.


Operations	Jobs	Configurat	tion Maintenan	:e	Si	ubmit Job	Service 🔻 🛛
	ocedures to restart		List/Test Print [12]	figuration data and test	Calibration		re optimal print quality
shut down ti	ne DFE and control u	select File	masters to verif	y print quality.	by ac	djusting the color o	utput density.
	TotalFlow Print Sen	10			ių 📭	m colors. Se	formed to make sure th elect the [Print igin. A color test master
	own Printer Controll		Name	Date Modified	Size	e scanne ata is the	d by an optical scanning n loaded back into the
			201412511750.bak_bag	01/03/2015 10:42:12 AM	37.7 MB	ally accept	pted as the new
Disk Operations						tation pro	ocedure over at any time in Master] button.
	inctions to manage (atrol unit software.	conf				n Master	
	Backup						
-	Restore					septure ti	he data needed to
	HDD Erase Update Code					are problem	lerns.
ools and Logs						Start_	Stop_
	iols and logs to mair	ntair	File name	201412311750.bak_bag		ave Trac	es
printer.		Files of type *.*			race		
DF	E Hardware Status	File Uplo				_	
	Logs_	File Opto	ad		Load Cance		

- 6. Select the method of restore to perform and click [OK].
 - [Normal]: includes configuration data and user-created ICC profiles.
 - [Extended restore]: adds logs, trace, or both to [Normal] data.
 - [Partial restore]: select the items. See the following Note.

O Not R	eady				Samole		Start RICOH Pro C/1	105	
Operations	Jobs	Configuration	n	Maintenance				Service	• ?
Shutdown/Rest	List/Test Print [12] Calibration Use to print configuration data and test masters to verify print quality. Use calibration to ensure optimal pri by adjusting the color output density						ality		
Restar Rest Shut (K	Test me Resto	re Configuration This procedure rest	e. For 'Normal' and '			ever been performed o	on this	
Disk Operations Use these functions to manage configuration data and control unit software.				types, the system to nfiguration printer profiles	Normal restore		S Use traces to captu diagnose software j	ine the data needed to problems.	2
	FE Hardware Status Logs ernation Event Statu	-			ок	Cancel	Save	artStop Traces are Trace Archive	
								m273z	7034

Note

• [Partial restore]: select the items for restoring.



System Software Installation Procedure

System software should be installed when:

- You replace the HDD with a new one.
- You update to a more recent version of the BOS.
- You have problem with the system software (e.g. software corruption).

Backing up Data

When reinstalling the system software, the saved configuration and job data are deleted. Before you start system installation, print the configuration (page 44 "Printing Configuration") and back up the data (page 86 "Backing up Data").

Reinstalling the System Software

It takes about 30 minutes to install the system software excluding the set-up time.

Vote

- Before using the printer during installing the system software, disconnect the interface cable connected to the printer.
- Before installing the system software, disconnect any USB memory connecting to the print server. If there is a USB memory connected, errors may occur in installation process.
- Get the installation iso data from the firmware download site for the system software, and barn the data into a blank DVD to create a system software DVD.
 Alternatively, use a system software DVD packed with the new HDD for replacement.
- 2. Turn OFF the interlock switch if the switch is set to ON. (page 27 "Power Interlock Switch")
- 3. Make sure that the print server is turned OFF.
- 4. Disconnect the interface cable which is connected to a network from the print server.


Vote

- This prevents from receiving a print job during the installation.
- 5. Turn ON the power switch [\bigcirc] of the print server.
- 6. Immediately press the disc eject button to open the DVD drive.
- Insert the system software DVD into the tray of the DVD drive by the end of the startup sequence.

🕹 Note

• The installation process begins automatically.

- If a monitor is connected to the print server, the following screen is displayed.
- Make sure that [DFE Master Disk Create] is selected. Pressing [Enter] starts the installation
 process immediately. The machine automatically starts the installation process when there is
 no input for a certain period of time.



8. Make sure that the print server shuts down after completing the writing successfully.

```
Vote
```

- It takes about 10 minutes from power switch ON to shut down.
- 9. Connect the interface cable which is connected to the printer to the print server (if disconnected).
- 10. Turn ON main power switch on the printer.
- 11. Press the power switch [U] located at the front of the print server.
- 12. Immediately press the disc eject button to open the DVD drive.

Note

- Otherwise, the installation process starts again.
- 13. Take the system software DVD out of the tray and close it.

Vote

- After the print server starts, the system software installation process continues.
- The print server reboots twice during the installation process. It takes about 12 minutes to reboot twice.
- 14. Make sure that the print server starts up successfully and is in standby state.
- 15. Connect the interface cable which is connected to a network to the print server.
- 16. Turn ON the power interlock switch if the power interlock switch is disabled in step2.

Restoring Data

Restore the system settings with the backup data after reinstalling the system software. (page 93 "Restoring Data")

Updating System Software

Update Procedure

Updating the system software can be operated from the printer and the console screen. It takes about 10 minutes to complete updating with rebooting the print server.


Operation from the Printer Screen

Note

- When operating from the printer, the updating data is limited to USB memory.
- 1. Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon.
- 2. Press [Stop] to suspend the printer operation.

Operations	Jobs	Paper Setting	UserTools/Adjustment
Active (0)	mactive (2)	listory (24)	
Status	Job name	Owner	Find
Retained space	Test Print - Con	fialog Service	
Retained space	Test Print - Int	erPage ddc	Print
			Hold


3. Press [User Tools/Adjustment].




4. Insert the USB memory which you saved the update data to the front USB port of the print server.

Vote


- It is not recognized in the rear USB ports of the print server.
- 5. Press [Update Code].



6. Select the update file and press [Update].



- The update file is a .kp3 file.
- 7. Check the current and update version of and then press [OK].



The print server automatically reboots after completing the update.

Operation from the Console Screen on the Print Server

1. Access to the print server by the local or remote console.

Read	У			Stoe	Start Pro C	71105	İgg	
Operations	Jobs	Configuration	Maintenance		Submit	Job	🔅 Service	•
	b Infor_ @ 💿	Active Jobs [8	View •	·][= ×]
Job name:		Status	Job Name	User Na	me Size	Copies	Job Type	Action.
		Inactive Jobs		Invalid Jobs [0]	Job Log [20]][View] *	
	10 > >1	Status	Job Name	 User Na 	me Size	Copies	Job Type	Action.
		Held	Printer_test2pdf		108.7 KB	1	PDF	► 1
	terpos 🗟 🗆 🔅	<]						
Ø		_						
1 🛄 💭	Paper 8.5 x 11.0 in, Plain, Weight 2 (63.1 – 80.0 gsm)	A						
2 🗐 🕞	11.0 x 17.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
3 🔳 🕞	8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
4 🔳 💭	8.5 x 11.0 in, Plain, Weight 2 (63.1 -	v						
							m273z	8028


2. Click [Stop] to suspend the printer operation.

3. Click [Maintenance].

O Not	Ready			Stor	Start	C71105	
Operations	Jobs	Configuration	Maintenance		Submit	Job 🔯 Ser	rvice 🔻 👔
Job Previ_ J	Job Infor_ 🛛 🖾 🗆 🖂	Active Jobs [0)]			Q View	- (*][X]
▶ II ū /	🔊 i≣▼	► II ā d	♥ i≣▼				
Job name:		Status	Job Name	User Na	me Size	Copies Job T	ype Action
KK		Inactive Jobs Inactive Jobs Inacti		Invalid Jobs [O]	Job Log [20] me Size 108.7 KB	Copies Job T 1 PDF	ype Action
	Interpos 🛙 🗆 🗆						
Tray	Paper	-					
1 🛄 💭		•					
2 🗐 🖓	11.0 x 17.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)						
3 🔳 🕞	8.5 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)						

З

4. Click [Update Code] on the [Disk Operations] pod.



5. Specify the destination (USB memory/ DVD drive/ network) where the update file is saved, and click [Load].

Operations Jobs	Configuration	Mainter	nance		Submit	Job 🔅 Service 🔻
hutdown/Restart Use these procedures to restart an shut down the DFE and control unit			[12] t configuration data and test verify print quality.	<u></u>		ion to ensure optimal print quality g the color output density.
Restart TotalFlow Print Server Restart Printer Controller Shut Down Printer Controller		002108kp5	12/08/2014 08:49:00 AM	957.41	01, 04 m	re is performed to make sure the colors. Select the [Print ton to begin. A color test master e scanned by an optical scarning it a is then loaded back into the ally accepted as the new
Visk Operations Use these functions to manage con data and control unit software. Backup	<u> <u><u></u></u></u>					ation procedure over at any time Calibration Master] button. n Master
Restore HDD Erase Update Code						capture the data needed to rare problems.
OOLS and Logs Use these tools and logs to mainta printer.		le name les of type	002108kp3 *kp3			Start Stop ave Traces nfigure Trace ace Archive
DFE Hardware Status Logs Hibernation Event Status	File Upload			Load	Cancel	

• Note

- The update file is a .kp3 file.
- When updating the data from a USB memory, insert it into the front USB port of the print server. It is not recognized in the rear USB ports of the print server.
- Clicking [File Upload] when accessing from the remote console allows you to update the data from the client PC.


Operations	Jobs	Configurat	ion Ma	intenance		Submit	Job 🔅 Service 🔻 🕻
	rt ocedures to restart an e DFE and control unit	software.		rint [12] to print configuration data and test ers to verify print quality.	Calib		ion to ensure optimal print quality the color output density.
Resta	TotalFlow Print Server rt Printer Controller wn Printer Controller.	Select File	Name	Date Modified 12/08/2014 08:49:00 AM	Size		re is performed to make sure the colors. Select the (Print ton to begin. A color test master e scanned by an optical scanning sta is then loaded back into the ally accepted as the new
	nctions to manage cor trol unit software.	<u>III</u>					ation procedure over at any time Calibration Master] button. n Master
	Backup Restore HDD Erase Update Code						apture the data needed to are problems.
Tools and Logs	ols and logs to mainta		File name Files of type	002108kp3 *kp3		•	StartStop ave Traces rfigure Trace ace Archive
DF	E Hardware Status	File Uplo	ad		Load	Cancel	

m273z8097

6. Verify the update version and click [OK].

The screen shows the current and new versions.

З



The print server automatically reboots after completing the update.

4. Troubleshooting

Overview

When a problem occurs with the print server, check in the following order:

- Reboot the print server, and check if the print server can start properly. If turned ON the main power of the printer, reboot the print server as well.
- Make sure that the network is functioning.
- Make sure that the print server and its connection with the printer have no problem by printing test pages. (page 36 "Test Print")
- Check that all cables, connectors, and replacements are present, appear undamaged and are correctly installed and connected.
- Check if a newer version of system software for the print server has been released. If so, install it. (page 104 "Updating System Software")
- When the problem is not resolved, reinstall the system software. (page 101 "Reinstalling the System Software")
- When the problem is still not resolved, replace parts of the hardware. (page 51 "Unit Removal")

LED Error Code

Overview

The print server has 7-segment LED to display the self-diagnosis results of the operation system startup.

If the operation system is started without any problems, the LED displays "00".

When the code other than "00" is displayed, there is a possibility that failed to start. When startup failure, check the diagnostic code table to deal.

How to Deal with an Error Code

When an error code is displayed, apply with following procedure. If you do not observe the procedure, the print server may not reboot properly.

Print Server OFF/ON

- 1. Press and hold the power switch of the front side until the print server turns OFF.
- 2. Wait for 30 seconds.
- 3. Press (but do not hold) the power switch.
- 4. Wait for a while and check whether or not the print server reaches standby status.

Diagnostic Code Table

When an error code is displayed again after rebooting the print server, one of the CPU, DIMM, or motherboard might be crashed.

Refer to the following list to identify the crashed part. For details of CPU and DIMM, see page 116 "How to Identify the Location of CPU/DIMM/HDD Errors".

	Description		Replace:			
Code			DIM M	Mother board		
0C-0d	Reserved for future AMI SEC error codes			~		
OE	Microcode not found	~				
OF	Microcode not loaded	~				
50	Memory initialization error. Invalid memory type or incompatible memory speed		4			

			Replace):
Code	Description	CPU	DIM M	Mother board
51	Memory initialization error. SPD reading has failed		~	
52	Memory initialization error. Invalid memory size or memory modules do not match.		~	
53	Memory initialization error. No usable memory detected		~	
54	Unspecified memory initialization error.		~	
55	Memory not installed		~	
56	Invalid CPU type or speed	~		
57	CPU mismatch	~		
58	CPU self-test failed or possible CPU cache error	~		
59	CPU micro-code was not found or micro-code update failed	~		
5A	Internal CPU error	~		
5b	Reset PPI is not available			~
5C-5F	Reserved for future AMI error codes			~
d0	CPU initialization error	~		
d1	North bridge initialization error	~		
d2	South bridge initialization error			~
d3	Some of the architectural protocols are not available	~		
d4	4PCI resource allocation error. Out of resources			~
d5	No space for legacy option ROM			✓
dó	No console output devices were found			✓
d7	No console input devices were found			✓
d8	Invalid password			4
d9	Error loading boot option (Load image returned error)			✓

	Description		Replace:			
Code			DIM M	Mother board		
dA	Boot option failed (Start image returned error)			✓		
db	Flash update failed			✓		
dC	Reset protocol is not available			✓		
EC-EF	Reserved for future AMI error codes			✓		
F8	Recovery PPI was not available			✓		
F9	Recovery capsule was not found			✓		
FA	Invalid recovery capsule			~		
Fb-FF	Reserved for future AMI error codes			4		

Following codes are displayed during startup sequence, so no correspondence needed.

Code	Description
06	Microcode loading
10	PEI Core is started
15	Pre-memory North Bridge initialization is started
19	Pre-memory South Bridge initialization is started
32	CPU post-memory initialization is started
36	CPU post-memory initialization. System Management Mode (SMM) initialization
39	Post-Memory North Bridge initialization (North Bridge module specific)
4F	DXE IPL is started
60	DXE Core is started
61	NVRAM initialization
63	CPU DXE initialization is started
70	South Bridge DXE initialization is started

Code	Description
79	CSM initialization
92	PCI Bus initialization is started
95	PCI Bus Request Resources
96	PCI Bus Assign Resources
99	Super IO Initialization
9A	USB initialization is started
9C	USB Detect
AO	IDE initialization is started
A2	IDE Detect
A8	Setup Verifying Password
Α9	Start of Setup
AA	Reserved for ASL
AE	Legacy Boot event
AF	Exit Boot Services event
b0	Runtime Set Virtual Address MAP Begin
b1	Runtime Set Virtual Address MAP End

How to Identify the Location of CPU/ DIMM/HDD Errors

How to Identify the Location of CPU/DIMM/HDD Errors

This product has two CPUs, eight DIMMs, and three HDDs. When an error occurs in these parts, identify the location of errors in BIOS.


Vote

• In order to access in BIOS screen, connect a monitor and keyboard to the print server.


CPU

1. After the print server boots, immediately press the [F2] key.

Select the [Advanced] tab in the BIOS screen, and then select [CPU Configuration] with the arrow keys.



2. Select [Socket 0 CPU Information] with the arrow keys and check the CPU information.




Note

• When the details are displayed as below, there is no error in the CPU (Socket 0). Check the other CPU information.


Aptio Setup Uti Advanced	lity – Copyright
Socket 0 CPU Information	
Intel(R) Xeon(R) CPU E5-2630 CPU Signature	v2 @ 2.60GHz 306e4
Microcode Patch	416
Max CPU Speed	2600 MHz
Min CPU Speed	1200 MHz
Processor Cores Intel HT.Technology	6
Intel VT-× Technology	Supported Supported
	m273z4006

• [A] to [B] on the list corresponds to the CPU on the motherboard.




DIMM

- 1. After the print server boots, immediately press the [F2] key.
- 2. Select the [Chipset] tab in the BIOS screen, and then select [North Bridge] with the arrow keys.




3. Select [DIMM Information] with the arrow keys and check the DIMM information.




Vote

• If no details of a DIMM are displayed, it is judged that there is an error in the DIMM on the motherboard. [A] to [H] on the list corresponds to the DIMM on the motherboard.



HDD

- 1. After the print server boots, immediately press the [F2] key.
- 2. Select the [Advanced] tab in the BIOS screen, and then select [SATA Configuration] with the arrow keys.



3. Check [SATA Port2] to [SATA Port4] of the list.

	Aptio Se Advanced	tup Utility	– Copyrigh	nt (C)	2012	A
SATA (Configuration					
SATA I			ATAPI Not Pre		ATAPI	
SATA SATA SATA	Port3		ST1000D ST1000D ST1000D	M003-(10006	B
SHIH	POPT5		Not Pre:	sent	73z400	

Vote

- When the details of a SATA port are not displayed, it is judged that the HDD breaks down.
- [A] to [C] on the list corresponds to the HDD.
 [A]: HDD for operation system
 [B]/[C]: HDD for data storage

SATA	Configuration	
SATA	Porto	ATAPI I
SATA	Port1 [A]	Not Preser
SATA	Port2	ST1000DM00
	Ports[B]	ST1000DM00
SATA	Port4 [C]	ST1000DM00
SATA	Ports [U]	Not Preser



m273z4012


How to Solve When an Error Occurs

How to Solve When an Error Occurs

When the Printer SC Occurs

When the printer SC occurs, the SC code is displayed on the operation panel of the printer. For more details about causes and solutions, refer to page 124 "Service Call (SC) Tables".

• Printer Operation Panel



When the Print Server Error Occurs

When the print server error occurs, the same message appears on the operation panel of the printer and console screen of the print server.


Follow the instructions to solve the error.

• Printer Operation Panel



m273z8059

Print Server Console Screen



When a fatal error occurs

You can select the following action from the fatal error dialog:

- 1. Saving the traces to the USB memory
- 2. Restarting the software
- 3. Rebooting the print server
- 4. Shutting down the print server

When selecting "1", you can save the traces to the USB memory into the front USB port of the print server.

96m Feb 16 13 09:04 2003 0000000000 Software has detected a fatal error:		
Abort Source:	10000	
Abort ID:	4	
Abort Name:	POH4:ctt_direct_raster_open	
Additional Data:	RSM Error 3	
Status	Traces have been saved to USB.	
Save Traces, USB.	Device - Control Unit Restart Reboot Shutdown	

m273z8107

Service Call (SC) Tables

This section explains the SC due to Print Server R-60. If the other SC occurs, see the printer's field service manual.

Service Call Conditions

Pattern	Display	How to reset	SC call or SC alarm in customer support system
A	The SC is displayed on the operation panel, and the machine cannot be used (safety-related SC).	Execute CE reset SP mode, and switch main power from OFF to ON.	Occurrence & alarm count ↓ Immediate alarm
В	When a function is selected, the SC is displayed on the operation panel, and the machine cannot be used (down- time mitigation).	Switch main power from OFF to ON.	Occurrence & alarm count ↓ Power OFF → ON ↓ Alarm count and alarm only if recurrence
С	No display on the operation panel, and use is permitted.	Count only logging.	Occurrence ↓ Logging count & alarm count
D	The SC is displayed on the operation panel, and the machine cannot be used (machine-error SC).	Switch main power from OFF to ON.	Occurrence & alarm count ↓ Power OFF → ON ↓ Alarm count and alarm only if recurrence

Service Call (SC911)

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-06	D	Ethernet TCP/IP: Invalid configuration during enable
		Configuration error involved in the communication with the IPDS host system (only occurs when the IPDS installed)
		If rebooting the print server does not solve the problem, replace the motherboard.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-10	D	Internal printing: File system error
		File system error of the internal print (such as file corruption)
		If rebooting the print server does not solve the problem, do the following.
		1. Update to the latest version of the print server system software.
		2. Re-install the system software.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-11	D	Unexpected network condition
		 Unexpected errors for the network environment Motherboard defective The configuration file or device driver corruption If rebooting the print server does not solve the problem, replace the motherboard.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-20	D	Program check - Type 1
SC911-21	D	Program check - Type 2
SC911-22	D	Program check - Type 3
		Programming error
		Reboot the print server.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-24	D	CPU0 Temperature Alert
		CPU0 temperature error by H/W checking
		CPU or CPU cooling fan defective
		Connection error between the CPU and CPU cooling fan
		Exhaust heat port of the housing is blocked
		• Check the connection between the CPU and CPU cooling fan.
		 Check the exhaust heat port and clean it up.
		Replace the CPU and CPU cooling fan.
		Replace the motherboard.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-26	D	CPU1 Temperature Alert
		CPU1 temperature error by H/W checking
		CPU or CPU cooling fan defective
		Connection error between the CPU and CPU cooling fan
		 Exhaust heat port of the housing is blocked
		• Check the connection between the CPU and CPU cooling fan.
		 Check the exhaust heat port and clean it up.
		Replace the CPU and CPU cooling fan.
		Replace the motherboard.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-42	D	Memory configuration has changed.
		This error rarely occurs at the initial startup after the software installation because of memory shortage.
		If rebooting the print server does not solve the problem, replace the DIMM or the motherboard.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-43	D	Invalid features defined
		Invalid features defined
		Turn the main power off and on.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-44	D	Recommended amount of memory not found
		DIMM defective
		If rebooting the print server does not solve the problem, replace the DIMM.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-45	D	Recommended number of processors not found
		CPU or motherboard defective
		If rebooting the print server does not solve the problem, replace the CPU/ CPU cooling fan or motherboard.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-46	D	File read error, hard disk
		System files corruption
		If rebooting the print server does not solve the problem, do the following.
		1. Re-install the system software.
		2. Replace the HDD.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-47	D	File write error, hard disk
		System files corruption
		If rebooting the print server does not solve the problem, do the following.
		1. Re-install the system software.
		2. Replace the HDD.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-48	D	Checksum error on configuration file.
		System files corruption
		If rebooting the print server does not solve the problem, re-install the system software.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-49	D	Hard disk backup to USB storage device failure
		Abnormal termination due to incomplete backup to the USB memory
		If rebooting the print server does not solve the problem, replace the USB memory for backup.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-50	D	Software update failed.
		Abnormal termination due to the system software update file failure
		If rebooting the print server does not solve the problem, re-install the update file.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-51	D	RDTU H/W error
		 RDTU board defective Connection fault
		If rebooting the print server does not solve the problem, replace the RDTU board.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-57	D	License key H/W error
		USB dongle (included a license key) defectiveConnection fault
	 Reboot the print server. Re-insert the USB dongle. Replace the USB dongle. 	

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-58	D	License error
	 License key defective (nonconformity, file corruption and so on) Unauthorized use of USB dongle (used once to another device, falsification, etc.) 	
		If rebooting the print server does not solve the problem, replace the USB dongle.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-60	D	Brand mismatch
		An invalid USB dongle is inserted.
		If rebooting the print server does not solve the problem, replace the USB dongle.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-61	D	Command timeout communicating with the printer.
		No response of command level from the printer.
		Check the printer power is turned on.
		• Check the cable connection between the print server and the printer.
		• Restart the printer and the print server in the correct procedure.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-62	D	Print Engine communication error.
		Connection faultMotherboard (onboard NIC) defective
		 Check the printer power is turned on. Check the cable connection between the print server and the printer. Restart the printer and the print server in the correct procedure. Replace the connection cable or motherboard.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-63	D	A file system access error occurred in the ASCII temporary disk cache.
		System files corruption
		If rebooting the print server does not solve the problem, re-install the system software.

SC No.	Level	Error Name/Error Condition/Major Cause/Solution
SC911-64	D	Page processing timeout
		Time-out error occurs during the page processing for print job.
		If rebooting the print server does not solve the problem, there may be a problem with the job.

Traces

Managing Archived Traces

The print server automatically captures all the data needed to diagnose software problems when it encounters a program check or fatal error. You can also save a trace whenever you find anything unusual.


Trace data includes event logs, printer configuration, software component traces, and optionally captured data. The trace information is saved to an archive file system for using by service representative. In some cases the service representative might need to access this archive.

Saving traces can be operated from the printer and the console screen.

Operation from the Printer Screen

• Note

- When operating from the printer, the destination of the tracing file is limited to USB memory.
- 1. Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon.
- 2. Press [User Tools/Adjustment].



m273z8002

3. Press [Trace Archive].

Operations	Jobs	Paper Setting	UserTools/Adjustment
Shutdown/Restart	📷 Test	Print	Preset
	Pr	int Samples	Load Preset
	📷 Trace	G	Ethernet Adapters
	S	ave Traces	Ethernet Configuration
Disk Operations	Conf	figure Traces	
	Tr	ace Archive	
Code version v0.1.133			

4. Insert the USB memory into the front USB port of the print server.

Note

- It is not recognized in the rear USB ports of the print server.
- 5. Select the file you want to download in the list, and then press [Save and Mark].

0	Ready				Stop Chart
rac	e Archive				Exit
	State	Abort name	Date created	Туре	
01	USB	Manual	12/28/2014. 10:23:44	Manual	Properties
02	Done	Manual	12/28/2014, 06:55:40	Manual	Save and Mark
03	Done	Manual	12/28/2014, 06:51:49	Manual	Mark selected tra
04	Done	Manual	12/27/2014, 10:34:16	Manua I	Mark all traces
05	Done	Manual	12/27/2014, 10:09:08	Manual	
06	Done	C: JTA_Sething	12/27/2014, 09:40:07	Fatal error	
07	Done	MC: handleTray	12/27/2014, 09:23:11	Fatal error	
08	Done	MC: handleTray	12/27/2014, 09:16:32	Fatal error	
09	Done	MC: handleTray	12/27/2014, 09:10:23	Fatal error	
10	Done	MC: handleTray	12/27/2014, 09:03:07	Fatal error	1/2
11	Done	MC: handleTray	12/27/2014, 08:55:09	Fatal error	▲Prev. ▼Next



Operation from the Console Screen on the Print Server

1. Access to the print server by the local or remote console.

4

2. Click [Maintenance].

Ready	/			Stor	Start Pro C	71105	2 10 10 10 10 10 10	
Operations	Jobs	Configuration	Maintenance		Submit	Job	Service	v 2
	Infor_ @ (□)>	Active Jobs [0				0	View -	
Job name:		Status	Status Job Name		me Size	Copies	Job Type	Action.
		Inactive Jobs		Invalid Jobs [O]	Job Log [20]	2 Q	View T*	
		Status			me Size	Copies	Job Type	Action.
	/0 > >1	Held	Printer_test2.pdf		108.7 KB	1	PDF	► ii
0	erpos. 🛛 🗆 🗆 🖂	3]						
Tray	Paper 85 x 11.0 in, Plain,							
1 🛄 💭	Weight 2 (63.1 - 80.0 gsm)	Ê						
2 🔳 고	11.0 x 17.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
3 🔳 🕞	85 x 11.0 in, Plain, Weight 2 (63.1 - 80.0 gsm)							
4 🔳 💭	8.5 x 11.0 in, Plain, Weight 2 (63.1 -	Ŧ						

m273z8027

3. Click [Trace Archive].

Ready	Stoe	Start		
Operations Jobs Configurat	ion Maintenance	Submit Job 🚺 Service 🔻 👔		
Shutdown/Restart	List/Test Print [12]	Calibration		
shut down the DFE and control unit software.	masters to verify print quality.	Use calibration to ensure optimal print quality by adjusting the color output density.		
Restart TotalFlow Print Server		The calibration procedure is performed to make sure the printer prints accurate colors. Select the (Print		
Restart Printer Controller	Test master	Calibration Master] button to begin. A color test master		
Shut Down Printer Controller	v Configuration [5]	is printed which must be scanned by an optical scanning device. Its calibration data is then loaded back into the printer, verified, and finally accepted as the new calibration.		
	Logs			
	Paper catalog	You can start the calibration procedure over at any time		
Disk Operations	PostScript fonts	You can start the calibration proceedure over at any time by selecting the [Print Calibration Master] button. Print Calibration Master		
Use these functions to manage configuration	Presets			
data and control unit software.	Printer configuration			
	T PDF [7]			
Backup	PDF – Blank page	Traces		
Restore	PDF - CMY colors	Use traces to capture the data needed to		
HDD Erase	PDF - CMYK colors	diagnose software problems.		
Update Code	PDF - Color test page	-		
	PDF - Profiles	Job Capture Start_ Stop_		
Tools and Logs	PDF - RG8 colors	Save Traces		
Use these tools and logs to maintain the printer.	PDF – Tray adjustment	Confinera Traca		
		Trace Archive		
DFE Hardware Status				
Logs				
Hibernation Event Status				
		m273z8041		

4. Select the file you want to download in the list, and then click the "Save" icon.


Operations Ja	obs	Configu	ration Main	tenan	ice			🐼 Service 🔻	i i
Shutdown/Restart			List/Test Pri	nt (12	2]	8	Calibration		6
Use these procedure down the DFE and co	ntrol unit s		thut Use to master	print c 's to ve	onfiguration data ar rify print quality.	nd test	Use calibration to ensure by adjusting the color ou		y
Restart TotalFic Restart Print Shut Down Prin		Trace Archive						performed on	this
	State	3 2 0°	Date created	Ci+	Abort name	Description		-	
isk Operations	Downto		12/27/2014 10:34:16 AM					1	
data and control un	Done	Manual	12/27/2014 10:09:08 AM	10.16	Manual	Administrator requi 10:07:12	ested save traces on 12/27/2014,		
Rest	-	Fatal error	12/27/2014 09:40:07 AM	9.17	C: JTA_SetFinishing	Can't set output bir option.	to infoprint.Perfect without bind		_
HDD E Update	0	Fatal error	AM 12/27/2014 09:23:11 AM	17.67	MC: handleinfoSpecO utputTray	Specified item nam [IFBoxTray.faceDov	e includes invalid output tray name in]	i needed to	
ools and Logs	Done	Fatal error	12/27/2014 09:16:32 AM	17.67	MC: handleinfoSpecO utputTray	Specified item nam [IFBoxTray.faceDov	e includes invalid output tray name m]	Stop	
Use these tools and	Done	Fatal error	12/27/2014 09:10:25 AM	17.67	MC: handleinfoSpecO utputTray	Specified item nam [IFBoxTray.faceDov	e includes invalid output tray name in]		٢
DFE Hardw	Done	Fatal error	12/27/2014 09:03:07 AM	17.67	MC: handleinfoSpecO utputTray	Specified item nam [IFBoxTray.faceDov	e includes invalid output tray name m]		-
Lo	-						Close]	
Hibernation	Event Stat	us						_	

5. Select the destinations (USB memory/network/email), and then input a file name. Click [Save].


Ready				Stoo Start	
Operations Jo	bs Configurat	tion Mainte	mance	Subr	mit Job 🔅 Service 🔻 🤗
Shutdown/Restart	to restart and property Archive Traces (5) Traces (5) Traces (5)		[12] nt configuration data and test	Calibration Use call	at to make sure the A
Restart Printe Shut Down Print Disk Operations	State	Name	Date Modified	Size	on over at any time both of the rew over at any time for t
data and control unit Backs Peste HDD E	New				が SL でのトレー 意家しまし a needed to
Tools and Logs Use these tools and L printer.	New	File name Files of type	tr-0000000000-201	141231-095940.tarZ	31, でのトレー 数家しまし ・
DFE Handwe	Done		- Alte	Save	31, でのトレー 観家しまし て
	Vent Status				
					m273z8043

Vote

- When selecting the USB memory, insert the USB memory into the front USB port of the print server. It is not recognized in the rear USB ports of the print server.
- Clicking [Download File] when accessing from the remote console allows you to save the trace log to the client PC.



• When sending email, enter the email address, and inputs the message text or subject. Click [Send].



Saving Traces

Saving traces can be manually operated from the printer and the console screen.

Operation from the Printer Screen

Note

- When operating from the printer, the destination of the tracing file is limited to USB memory.
- 1. Press the [Home] key on the operation panel of the printer and then press the [TotalFlow] icon.

4

2. Press [User Tools/Adjustment].

Operations	Jobs		Paper Setting	UserTools/Adjustm	ent
perator Message				· · · · · · · · · · · · · · · · · · ·	_
CB1A - No output tray	s are available			Details	
Tray Information					
Tray Information	85×11	63.1 - 80.0 ssm	6 🔳	85×111	63.1 - 80.0 ss
	%5×11₽ 11×17₽		6 🗐 A 🗐	%×11₽ %×11₽	80.0 gs
1 💷		80.0 gsm 63.1 - 80.0 gsm 63.1 -			80.0 gs 63.1 -
1 💷	11×17⊡	80.0 gsm 63.1 - 80.0 gsm			80.0 gs 63.1 -

3. Press [Save Traces].

O Ready			Stop Start
Operations	Jobs	Paper Setting	UserTools/Adjustment
O Shutdown/Restart	Test Pr	int	Preset
	Prin	t Samples	Load Preset
	Traces		Ethernet Adapters
	Sav	e Traces	Ethernet Configuration
Disk Operations	Confia	gure Traces	
	Trao	e Archive	
Code version v0.1.133			
			m273z8053



- You can select the tracing items from the [Configure Traces] key.
- 4. Insert the USB memory into the front USB port of the print server.


Note

- It is not recognized in the rear USB ports of the print server.
- 5. If necessary, press [Edit] to describe the situation.

6. Press [OK].



- Note
 - It takes about 20 seconds to save the traces.
- 7. Press [Save].






- You can change the file name by pressing [Edit].
- The tracing file is saved as a .tar file.

Operation from the Console Screen on the Print Server

- 1. Access to the print server by the local or remote console.
- 2. Click [Maintenance].

						1	-	
Operations	Jobs	Configuration	Maintenance		Sub	mit Job	Service	• • 🛛
lob Previ_	lob Infor_ 📓 🔲 🗵	Active Jobs [0]			0	Q View	*][= ×
▶Ⅱ亩	🔊 🗐 🛛	► II 亩	Ø Ⅲ v					
Job name:		Status	Status Job Name User Name			Copie	is Job Type	Action
		Inactive Jobs	[1] Stored Jobs [0]	Invalid Jobs [0]	Job Log [20]		[Q,] [View]	*][=]×
		-		Invalid Jobs [0]		Copie		
	4800 ∕0≥≥1	▶Ⅱ亩	Ø :=•			Copie		Action
KK		Status Ca Held	Job Name		Name Size	Copie	rs Job Type	Action
KK	/0 > >1	Status Ca Held	Job Name		Name Size	Copie	rs Job Type	Action
nput Tra.	/0 > >1	Status Ca Held	Job Name		Name Size	Copie	rs Job Type	Action
nput Tra.	/0 >>I	Status Ca Held	Job Name		Name Size	Copie	rs Job Type	Action
nput Tra		Status	Job Name		Name Size	Copie	rs Job Type	Action
nput Tra.	/0 >> Interpos_ Paper 85 x 110 in, Plain, Weight 2 (631 - Weight 2 (631 -	Status	Job Name		Name Size	Copie	rs Job Type	Action


3. Click [Save Traces].



4. Click [OK].



• You can describe the situation.



m273z8057

4

• Note

- It takes about 20 seconds to save the traces.
- 5. Select the destinations (USB memory/network /email), and then enter the filename. Click [Save].

O Ready	/						Stor		Pro C71105
Operations	Jobs	Configu	ration	Mainte	nance			Subm	it Job 🚯 Service 🔻 🙎
	art rocedures to resta the DFE and contre	rt and property Select File	_	est Print [Use to print	[2] configuration	data and test		Calibration Use call	aration to ensure optimal print idjusting the color output density.
Resta Shut Do Disk Operations	TotalFlow Prints 5 et Printer Control was Printer Control was printer Control unctions to many introl unit softwar Backup		Name		Date Modifie	d	Size	R 1 1	edure is performed to make sure barnet colors. Select the (Print botton to begin A color test sich must be scanned by an optical calibration data is then loaded c, verified, and finally accepted as libration procedure over at any e (Print Calibration Master) button. tion Master
	HDD EraseUpdate Code								to capture the data needed to rtware problems.
Tools and Logs Use these t printer.	ools and logs to n		ile name iles of type	•	tr-00000000 *.*	0000-20141	218-155419.	tarZ	Save Traces
DF	E Hardware Statu	Download Fi	Le				Save	Cancel	
Hbe	mation Event State	ð							
									m273z8058

Note

- When selecting the USB memory, insert a USB memory into the front USB port of the print server. It is not recognized in the rear USB ports of the print server.
- The tracing file is saved as a .tar file.
- Clicking [Download File] when accessing from the remote console allows you to save the traces to the client PC.

Operations	Jobs	Configu	ration	Mainter	ance			Submit	Job 🐼 Service 🔻	
hutdown/Restart			List/T	lest Print [1	2]	<u></u>	Calibra	tion		
Use these process shut down the D	EE and controllin	and properly Select File		Use to print of	configuration data a	and test		Use calibr	ation to ensure optimal print idjusting the color output der	isit)
Restart Total	Flow Print Se	Ŷ					Ci (亩	edure is performed to make curate colors. Select the [Pri	
	inter Controll		Name		Date Modified	Size			button to begin. A color test tich must be scanned by an o	
	minter Contri	III -							calibration data is then loade	d
isk Operations									dibration procedure over at a e [Print Calibration Master] b	ny
Use these function									ation Master	
	GIRT SUTCHO								tion	
в	ackup_									
Ri	estore									
HD	D Erase								to capture the data needed t ftware problems.	0
Upd	ste Code									
ools and Logs		R	le name	1	r-00000000000	-20141218-15541	9.tar.Z		Start Stop	
/ Use these tools	and logs to m	R	les of type	6					Save Traces	
printer.			and an open		4.				Configure Trace Trace Archive	
		Download Fil				Save	Cano	wi l	inace Arctime	
DFE Har	dware Statu	Downtood Pi				Solve	Car		_	
	Logs on Event Status									

• When using the email, enter the email address in the following screen. Also enter the subject and text, and then click [Send].

Not Ready		
Operations Jobs Configurat	tion Maintenance	Submit Job 🚺 Service 🔻 👔
Shutdown/Restart	List/Test Print [12] Use to print configuration data and test masters to verify print quality.	Calibration
	To:Sending file 00000000	Configure Trace_ Trace Archee_
DFE Hardware Status	e	Send Cancel
Logs., Hibernation Event Status.,		m273z8065

Traces

Capturing a Print Job


Job Captures include print data and host communications as well as trace data which described before. Service representatives use this function to diagnose problems.

- 1. Access to the print server by the local or remote console.
- 2. Click [Maintenance].


Onorations	Jobs	Configura	Non.	Maintenance			Submit	Inte I	A Comise	• E
Operations	JODS	Configura	tion	Maintenance			Submit	JOD	Service 🕄	
ob Previ_	lob Infor_ 🛛 🗐 🗔 🗆	Active	Jobs [0]	1				<u>a</u>	View 4	•][= ×
▶ II 亩 /		▶ 1	► II TE Ø ET							
Job name:		Status	Status Job Name User Name		User Name	Size	Copies	Job Type	Action	
		Inactiv	e Jobs [1] Stored Jobs [O]	Invalid Job	os [O] Job L	.og [20]		View 1	·) [D X
	191515	Inactiv	-		Invalid Job	os [O] Job L	.og [20]] [View	·) [D X
	A 12 (O (O) /0 (O (O)	> Status	I T Ø		1	us [O] Job L	.og [20]	Copies] [View Type	Action
 € ≤		► I	I T Ø) ⊞v	1					Actio
KK		Status B He	I T Ø	Job Name	1		Size	Copies	Job Type	Actio
KK	/0 >>>	Status B He	I T Ø	Job Name	1		Size	Copies	Job Type	Actio
nput Tra.	/0 >>>	Status B He	I T Ø	Job Name	1		Size	Copies	Job Type	Actio
nput Tra.	/0 ≥ >I	Status B He	I T Ø	Job Name	1		Size	Copies	Job Type	Actio
nput Tra	/0 >>1	Status	I T Ø	Job Name			Size	Copies	Job Type	Actio
nput Tra.	/0 >>I Interpos. Paper 85 x 110 in Plain, Weight 2 (631 - 80.0 gsm) 110 x 170 in Plain, Weight 2 (631 -	Status	I T Ø	Job Name			Size	Copies	Job Type	Actio

4


3. Click [Start] at [Job Capture].



4. Select the protocol that you send the job in [Start Job Capture].




5. Select the destination (Memory/ Hard disk) to save at "Location".



• Note

- When selecting the "Hard disk", you can set "Forward/Back channel data". The "Forward/ Back channel data" defines whether the trace data is saved in one file or divided files.
- 6. Click [OK].

Note



• During the capturing data, the console screen shows "Tracing". The capturing data often slows down the operation of the print server.



- 7. Send the job that you want to analyze.
- 8. Click [OK] after the problem occurs in the job.

	Aut D	Operator Messa	ges
	Describe the circumstances of this trace.	Input Trays [7]	Paper 210.0 x 297.0 mm Plan
S Y		2 🗐 🖓	Weight 2 (631 - 80.0 gsm) 2970 x 420.0 mm, Plai Weight 2 (631 - 80.0 gsm) 210.0 x 297.0 mm, Plai Weight 2 (631 - 80.0 gsm)
	OK Cancel		210.0 x 297.0 mm, Plair Weiner 2 (651 – 80.0
DFE Hardware Status Logs Hibernation Event Status	PDF - CMY coors PDF - CMYK colors PDF - Color test page PDF - Profiles PDF - Profiles		
	PDF - Hold colors PDF - Tray adjustment		

Note

- You can enter the job details at the save traces screen.
- During the tracing job, the following screen appears:

Collecting_	
Blank page	
	m273z8102

9. Select the destinations (USB memory/network/email), and then enter the filename.

Click [Save].

Ready				Sto		Start	RICOH Pro C71105		▼
Operations Jobs C	Configuration	Mainte	nance				Submit Job	Service 🔻	?
Shutdown/Restart Use these procedures to restart and p down the DFE and control unit software		List/Test Pr	int [18] print configuration of fy print quality.	lata and test maste	8		calibration to ensure opti ting the color output de		9 7
Restart TotalFlow Print Serve Restart Printer Controller Shut Down Printer Controller	Select File	me	Date Modi	fied 5	(ize	1 1	ocedure is performe arate colors. Select t b begin. A color test i by an optical scanni ed back into the print hew calibration.	he (Print Calibratio master is printed v 19 device. Its calibr	on which ration
Disk Operations Use these functions to manage config and control unit software.							calibration procedur nt Calibration Master bration Master		by
Bodup,							es to capture the dat	a needed to diagn	iii iose
Tools and Logs Use these tools and logs to maintain t		name is of type	tr-000000	00000-20150216-	135349.tar	2	Start	Stop	5
DFE Hardware Status	Download File			s	ave	Cancel	Trace Archive,	-]
Logs Hibernation Event Status		PDF - Color PDF - Profile PDF - RGB c PDF - Tray a	es colors						
							r	n273z81	03

Vote

- When selecting the USB memory, insert a USB memory into the front USB port of the print server. It is not recognized in the rear USB ports of the print server.
- Clicking [Download File] when accessing from the remote console allows you to trace data to the client PC.

Operations	Jobs	Configuration	Mainte	enance			Submit Job	Service V	?
Shutdown/Restart		Ð	List/Test Pr	int [18]	9	Calibration			8
	ires to restart and control unit softw			a print configuration dat ify print quality.	a and test masters		alibration to ensure ting the color outpu	optimal print quality it density.	by
	alFlow Print Server Vinter Controller_	_				in (p begin. A color t	rmed to make sure t ect the [Print Calibrat test master is printed	tion I which
	Printer Controller	<u>QQQ</u>	Name	Date Modifie	d Size			anning device. Its call printer, verified, and f	
Disk Operations							nt Calibration M	edure over at any tin aster] button.	ne by
	rs to manage confi oftware.						bration Master_ bration lew Calibration_]	
	Backup_								
н	Restore DD Erase date Code						es to capture the problems.	e data needed to diag	
Tools and Logs			File name	tr-0000000	0000-20150216-135349	itarZ	Start,	Stop	
Use these tools ar	nd logs to maintain	1	Files of type	**		•		frace	
DFE H	ardware Status_	Download	FLe		Save	Cancel			
Hibernat	Logs tion Event Status		PDF - Profit	es					
			PDF - Tray						

- When sending email, enter the email address, and enter the message text or subject. Click [Send].
- The tracing file is saved as a .tar file.

Troubles That Related to the Optional IPDS

Cannot Exit SP Mode While Establishing a Session with the IPDS Print Server

Symptom

When printing from the IPDS host system, the IPDS keeps the session after the print job completes. If the customer engineers enter into the SP mode in this condition, they cannot exit the SP mode until the session is disconnected.

Solution

Do not enter the SP mode during the session of the IPDS is established.

Do one of the following when you cannot exit the SP mode:

- Terminate the session through the IPDS host system such as Infoprint Manager.
- Disconnect the network cable that connects to the print server. (This can terminate the IPDS session)

Troubles That Related to External Printing Software

Data Cannot Be Sent Properly When Using Prinect

Symptom

Data cannot be sent properly when using Prinect.

Solution

- 1. Access to the print server by the local or remote console.
- 2. Click [Configuration] [Data Stream].
- 3. Click the [Basic] pod.



m273z8105

4. Select "APPE" (Not "CPSI") at [PDF jwob processor].




4

4. Troubleshooting

Block Diagram and Functions

Block Diagram



Functions

Network

Cable requirements:

- 10BaseT (Ethernet): Unshielded Twisted Pair (UTP), Category 3 or higher
- 100BaseTX (Fast Ethernet): UTP, Category 5 or higher (4-pair/8-wire, short length)
- 1000BaseT (Gigabit Ethernet): UTP, Category 5e or higher (4-pair/8-wire, short-length)

PIC Board

When the power interlock switch is ON at the print server, it can recognize the power ON/OFF status of the printer.

RDTU Board

Performs as an interface* between the print server and the printer

*Command/Status I/F and Image Data I/F

HDD

The print server has three HDD.

- HDD 1 for operation system
- HDD 2/HDD 3 for data storage with RAIDO
- HDD 4 is not installed. (Future expansion)

Mother Board

- CPU: 2.6GHz × 2
- SDRAM: 4GB (1600MHz DDR3, 240 pin) × 8, Total 32GB.
- Performs a self-diagnosis by BIOS and displays the error code to the digital display board (7segment).

Digital Display Board

Displays the status of the print server by 7-segment

USB Dongle

Stores product information such as a license

The print server cannot be used without USB dongle.

DVD Drive

The DVD drive can read the items below:

- Print data
- File for system updating
- User created ICC profiles

• Font data

Note that these data cannot be written into the DVD, because the DVD drive is read only.

USB I/F

USB I/F are used in the following purpose.

Front USB port

- 1. Reading the following data are saved in the USB memory.
 - Print data
 - File for system updating
 - User created ICC profiles
 - Font data
- 2. Writing the following data to USB memory
 - Tracing data
 - Logging data

USB port (keyboard/mouse)

Attaching a keyboard and mouse

USB port (memory)

Backing up automatically for configuration data

IPDS

Activating the IPDS

Activating the IPDS with the following steps is required to use the IPDS features.

- Go to the certificate site on the internet to generate a license file with the following two items:
 - System Fingerprint: an identifier that is provided for each print server.
 - EID (Entitlement ID): an identifier provided for the customer when they purchase the option.
- 2. Install the license file generated to the print server.

The license file generated is installed in the print server.

Reactivating the IPDS is required when you re-install the system software for troubleshooting or parts replacement. For details, refer to "How to Reactivate". (page 168 "How to Reactivate")

Activation Procedure


🔁 Important

- Make sure that you have the EID (Entitlement ID) issued when the customer purchases this option.
- 1. Access to the print server by the local or remote console.


2. Click [Stop] to suspend the printer operation.


Operations Jobs Configuration Maintenance Submit Job Service Image: Configuration Job Previl Job Infor. Image: Configuration Active Jobs [0] Image: Configuration Image: Configuration <t< th=""><th>Read</th><th>у</th><th></th><th></th><th></th><th>art Pro C</th><th>71105</th><th></th><th></th></t<>	Read	у				art Pro C	71105		
Image: Status Job name User Name Size Copies Job Type Action. Image: Status Job Name User Name Size Copies Job Type Action. Image: Status Job Name User Name Size Copies Job Type Action. Image: Status Job Name User Name Size Copies Job Type Action. Image: Status Job Name User Name Size Copies Job Type Action. Imput Tra. Interpos. Image: Status Job Name User Name Size Copies Job Type Action. Imput Tra. Interpos. Image: Status Job Name User Name Size Copies Job Type Action. Imput Tra. Interpos. Image: Status Job Name User Name Size Copies Job Type Action. Imput Tra. Interpos. Image: Status Job Name User Name Size Copies Job Type Action. Ima	Operations	Jobs	Configuration	Maintenance		Submit	Job 🕴	Service	• 2
Job name: Image: Status				i≣ v			a Q	View][= ×]
Image: Status Job Name User Name Size Copies Job Type Action. Imput Tra. Interpos. Imput Tra. Interpos. Imput Tra. Imput	Job name:		Status	Job Name	User Name	Size	Copies	Job Type	Action
Input Tra. Interpos. Imput Tra. Interpos. Imput Tra. Imput Tra			▶ II 🖬 🖉	i≣ v					
1 Image: State of the state of	Input Tra. Int		C Held	Printer_test2.pdf		108.7 KB			
1 Image: State of the state of	Trav	Paper							
2 IIO x 170 m, Pian, Weight 2 (631 - 800 gsm) 3 III 4 III		Weight 2 (63.1 -	A						
3 Im of the state	2 🗐 🕞	11.0 x 17.0 in, Plain, Weight 2 (63.1 -							
4 🔳 🗋 K5 x 11.0 in, Plain, Weight 2 (63.1 - 🗸	3 🔳 🕞	8.5 x 11.0 in, Plain, Weight 2 (63.1 -							
	4 🔳 💭	8.5 x 11.0 in, Plain, Weight 2 (63.1 -	Ŧ						

- 3. Select [Configuration] [Printer].
- 4. Click "Arrow" (Add) at the [Extended Features] pod.




6





7. Click [OK].

The console screen is in this status, then set from a web browser.



- 8. Start the web browser, and access the website below: https://www.ricohsoftware-entitlements.com
- 9. Select the "EID" at the [Login/Using] field.
- 10. Enter the EID (Entitlement ID) at the [EID] field.

RIC	DH 2.7		
You	user session has expired. Try	r logging on again.	
Customer	ogin		
Login Using:	EID	*	
EID:			
[Login		

m273z7070

11. Put a check mark in "IPDS-Product Feature" and click [OK].

RIC	COH 27			Powered By SafeNet Sentine[EM Welcome Lecou
		84		Change Language
Entitlen	ment Details			
▼ Associ	ated Product and Features			Activate Revoke
-	Product	Start Date	End Date	Quantity
-	PDS-Printer-Fea ture 1.0	05/12/2014	Never expires	117 out of 250
▶ List o	of features associated			
Previou	us Activations (Total 133)			
Previou	us Revocations (Total 1)			
		© 2013 SafeNet, I	nc. All Rights Reserved.	

m273z7071

12. In the [System Fingerprint/Locking] field, enter the "System Fingerprint" that was ahead in step 6 to IPDS pop-up screen, and click [Generate].

RIC	Activate Product(s)			X SafeNet
	EID: 1			Welcome Logos
1	▼ Enter Quantity			Change Language 💌
	Product	Remaining Quantity	Quantity	
Entitien	PDS-Printer-Feature 1.0	117	1	
	Client 4 criteria: Eth	amat åddrace		
	* System Fingerprint/Locking Data:			Activate Revolve
	Generate			v
2	IPOS-Printer-Fea ture 1.0	06/12/2014	Never expires	117 out of 250
► List of f	features associated			
Previous	Activations (Total 133)			
Previous	Revocations (Total 1)			
		© 2013 SafeNet, Inc. All I	Rights Reserved.	
				m273z707

13. Click [Save to File] and save the generated license file.

6

		Lice	ense generated suc	cessfully			- 1	Welco	me Loo
	License Certificate							Change La	nguage
Entitlen	Contact @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@		Customer:	Controller Develo	opment	Password:			
- Associ	Support <u>http://www.rico</u> URL:	hsoftware.com/To	talFlow(Advantage					Activate 1	
_	List of Activations							Acevase	Revoke
2	Product Key	Name	AID		Quantity	Remaining Quantity	•	of 250	
▶ List¢		IPDS-Printer -Feature 1.0			250	116	1		
Previou	Download Urt:								
Previou	License String								
	*8 VetPGNP8hSUIT1mdbjpt/3 MONpUa20103/NWXix49/9b Soccoccoccoccoccoccoccoccoccoccoccoccocc	EatKOCptZ3a3Q# *							

Alternatively, send the license file to the email address you registered.

14. Change the extension of the license file to ".key".

Return to the console screen.

15. Select the destination icon of the saved license file (USB memory/ DVD/network), and select the license file.


16. Click [Load].

O Not	Ready					Sta	so Start	RICOH Pro (71105
Operations	Jobs	Cor	figuration	Maintena	nce		Submit Job	Service V
Paper	Basic Simplest a setting	nd most bi elect File	isic printer	Input Trays	[7] Interpos		Preset	ts store and retrieve setups for per. All important printer for a job can be simply
Printer	Allow to print		Nome Iservrc		- Modelland 2/2015 18:18:04 PM	сла 432 КВ	i i ii	Ricoh Currentiy loaded Valid
Color Management	Printer name Printer Informa details Printer location	194 194						time on the printer or the method that the printer tilize to obtain the current
Data Stream	Enter Sleep mo after Wake on netwo traffic When printer sl							1/23/2015 11:09:36 AM S Aleutian tanual
Network			File name Files of type	lservr *,*	c			atures [1] anded feature settings allow all options to be installed and for a printer.
Security		File Uplo	ad			Load	Cancel	П
				inmmer tray	EU30160		Extended featur	re na. Status
								m273z8077

Note

- When loading from the USB memory, insert a USB memory into the front USB port of the print server. It is not recognized in the rear USB ports of the print server.
- Clicking [File Upload] when accessing from the remote console allows you to upload the license file from the client PC.

17. After activation completion message is displayed, click [OK].



18. Reboot the print server.

Optional Features for IPDS

After activating the IPDS, activate the optional features below:


• Suppress Off Page Errors (8B4289)

This feature allows a user to specify the number of pixels (pels) that are allowed to be outside of the printable area of a page without generating an error to the host system. If activated, a menu item (Suppress Off Page Errors) appears in the IPDS data stream configuration area.

• IPDS 2-pass G4 compression (8B4418)


For IPDS, reinterpret each image using the second of two possible RIDIC values, if the first interpretation fails. Enabling this feature may avoid image processing errors. There are no console menu changes when this feature is activated.

- 1. Access to the print server by the local or remote console.
- 2. Select [Configuration] [Printer].




3. Click "Arrow" (Add) at the [Extended Features] pod.


4. Select the extended features that you want to activate.



6

Enter the following password, and then click [OK].
 2halo: (for 8B4289 (Suppress Off Page Errors))
 2passup: (for 8B4418 (IPDS 2-pass G4 compression))






6. Verify the optinal features at the [Extended Features] pod.

Note

- When the optional feature to [Enabled], click the [▶] button.
- When set to [Disabled], click the [Stop] button.



6

How to Reactivate

When Replaced HDD, or Re-installed the system software

As the System Fingerprint does not change, you can reactivate the IPDS with the same license file as the one used for last activation. If the license file is lost, log in to the certificate site with the same EID as the one used for last activation, and then download the license file again.

When Replaced the Motherboard

As the System Fingerprint changes, you cannot reactivate the IPDS with the same license file as the one used for last activation. Activate the IPDS with a new System Fingerprint and EID.

RIP Software

Activating the RIP Software

Activating the RIP software with the following steps is required to use the RIP features.

- 1. Go to the certificate site on the internet to generate a license file with the following two items:
 - System Fingerprint: an identifier that is provided for each print server.
 - EID (Entitlement ID): an identifier provided for the customer when they purchase the option.
- 2. Install the license file generated to the print server.

The license file generated is installed in the print server.

Reactivating the RIP software is required when you re-install the system software for troubleshooting or parts replacement. For details, refer to "How to Reactivate". (page 168 "How to Reactivate")

Activation Procedure


🔁 Important

- Make sure that you have the EID (Entitlement ID) issued when the customer purchases this option.
- 1. Access to the print server by the local or remote console.

2. Click [Stop] to suspend the printer operation.

Operations Jobs Configuration Maintenance Submit Job I I I III Job Infor IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	Action.
Image: Copies Job Name User Name Size Copies Job Type	
	Action_
I D III D IIII D IIIII D IIIIII D IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	Action.
Input Tra. Interpos.	
Tray Paper	
1 UU 0 85 x 110 in, Pian, A Weight 2 (631 - 800 gem)	
2 III - 11.0 x 17.0 in Plain, Weight 2 (331 - 80.0 gsm)	
5 III - 85 x 110 in, Piain, Weight 2 (631 - 800 gsm)	
4 85 x 110 in Pan, weight 2 (631 - w	

- 3. Select [Configuration] [Printer].
- 4. Click "Arrow" (Add) at the [Extended Features] pod.



6

5. Select the RIP software and click [OK].

RIP model H		
RIP model K		
RIP model S		
		-
	_	

6. Write down the string that is shown at [System Fingerprint].



7. Click [OK].

After this screen is shown, operate from the web browser.



m506a0003

- 8. Start the web browser, and access the website below: https://www.ricohsoftware-entitlements.com
- 9. Select the "EID" at the [Login/Using] field.

6

10. Enter the EID (Entitlement ID) at the [EID] field, and then click [Login].

RIC	ОН	2.7			
Yo	ur user session h	has expired. Try log	gging on again.		
Customer	Login				
Login Using:	EID		•		
EID:					
	Login				

m273z7070

11. Put a check mark in "RIP model *" and click [Activate].

RICOH ₂₇			Powered By SafeNet Sentine/EA Welcome Loop
	¢		Change Language
Entitlement Details			
			Activate
Product	Start Date	End Date	Quantity
RP model H - RJ 1	6205/2016	62/06/2918	158 out of 200
List of features associated			
Previous Activations (Total 42)			
Previous Revocations (Total 0)			
	© 2013 SafeNet, Inc.	AN PARTY PARTY IN	

© 2013 SafeNet, Inc. All Rights Reserved.

m506a0004

12. In the [System Fingerprint/Locking] field, enter the "System Fingerprint" that was obtained in step 6 to RIP model * pop-up screen, and click [Generate].

D: 1000000000000000000000000000000000000	*****				SentinelEN
* Enter Quantity					Welcome Logo
					Change Language 💌
Product	Remaining Quantity		Quantity		
IPDS-Printer-Feature 1.0	117		1		
Client 4 criteria:	Ethamat Addraca				
• System Fingerprint/Locking Data:	*************			_	Activate Revoke
Generate				by .	
IPOS-Printer-Fea ture 1.0	06/12/2014	Never expires		117 out of 250	
atures associated					
tivations (Total 133)					
evocations (Total 1)					
	POS-Printer-Feature 1.0 Planet 1 centeries * System FingerprintLocking Data: Concernate Pos-Printer-Feature trues associated truetions (Total 133)	POS-Prote-Feature 1.0 117	POS-Printer-Feature 1.0 117	POS-Printer-Feature 1.0 117 1 Clines & effects Close lose Close Close Close Close	POS-Printer-Feature 1.0 117 1 Planet 4 cellores Planet 4 defease * System * System Close Program to Close

13. Click [Save to File], select the desired destination icon, and then save the generated license file.

Alternatively, send the license file to the email address you registered.

		Lic	ense generated successfully				Welcome Logout
	License Certificate						Change Language 💌
Entitlen	Contact: 000000000000000000000000000000000000		Customer: Controller De	evelopment	Password:		
Associ	Support <u>http://www.ricol</u> URL:	isoftware.com/To	dalFlow(Advantage				
_	List of Activations						Activate Revoke
2	Product Key	Name	AID	Quantity	Remaining Quantity	of	250
List		IPDS-Printer -Feature 1.0	******	250	116		
eviou	Download Url:						
viou	License String						
	MCNpU2201X3y1wxxx49j9b6	atKOCpfZ3a3Q#	Rt/Ut0Rhe9ap2GUPeHj3mrh3iR2 IPDS-014" version "1.0", no expirat	:OQkvNFWN9Bi tion date, exclus	RP5:H8GmVCoJ sive##AID=e5388	****	
		Append To File	E-mail Close			2	
						_	m273z7073

14. Change the extension of the license file to ".key".

Return to the console screen.

- Select the destination icon of the saved license file (USB memory/ DVD/network), and select the license file.
- 16. Click [Load].

O Not	Ready							Stop Star		RICOH Pro	- C	
Operations	Jobs	Configu	ration	Mair	tenance			Submit .	doL	🐼 Ser	vice 🔻	?
Paper	setting	nd most basic pr elect File	inter	Input 1		Interpose		Treset		tore and ret er. All import for a job can	tant printer	s for A
Printer	Pation to prate)))	lservrc		Date Models 01/22/2015 1		432 KB		۵ ا	Ricoh Currer Valid	ntiy loaded	
Color Management	Printer name Printer informa details Printer location	72							- 12	ime on the p he method t illize to obtai	hat the prin	
Data Stream	Enter Sleep mo after Wake on netwo traffic When printer sl									1/23/2015 11 S anual	:09:36 AM Aleutian	
Network		File	name		lservrc				5	tures [1]		
<u>UQU</u>		File	s of type	(*,*					nded feature (options to) for a printer.	be installed	
Security		File Upload		unmmer		Enabled	Load	Cancel		I		
					uuy	Childhey		Extended f	eature i	na. Statu	5	
										m	273z8(077



- When loading from the USB memory, insert a USB memory into the front USB port of the print server. It is not recognized in the rear USB ports of the print server.
- Clicking [File Upload] when accessing from the remote console allows you to upload the license file from the client PC.
- 17. When you are prompted to restart the system, click [Restart].

in the next !	Shutdown or Restart.	id will be reflecte

How to Reactivate

When HDD is replaced or System Software (BOS) is re-installed:

As the System Fingerprint does not change, you can reactivate the RIP software with the same license file as the one used for last activation. If the license file is lost, log in to the certificate site with the same EID as the one used for last activation, and then download the license file again.

When the Motherboard is replaced:

As the System Fingerprint changes, you cannot reactivate the RIP software with the same license file as the one used for last activation. Activate the RIP software with both of them below.

- the same EID as the one used for the last activation
- a new System Fingerprint.

🖖 Note

The license can be easily activated without the need of a new EID for the defective DFE. The
person in charge of EDI can simply increase the number of avaialbe activations allocated to
the original EID. In other words, a new EID for replacement Motherboards will not be
required.

6. Option

Specifications

General Specifications

ltem	Description	
CPU	Intel Xeon E5-2630v2 2.6GHz ×2	
Memory	32 GB (4 GB ×8)	
HDD	SATA connection 1TB3.5 inch HDD (7,000 rpm) ×3	
DVD Drive	SATA connection DVD-ROM drive	
Interface	Gigabit Ethernet ×2 (100BASE-TX/10BASE-T/1000BASE-T), USB2.0 Type-A ×4 (Front ×1, Rear ×3), USB2.0 Type-B, VGA, RDTU ×2	
Protocol	FTP, LPR, Port 9100, TCP-IPDS, IPP, RHPP, HTTP, Dynamic DNS, SMB, AppleTalk, WSD	
Print Resolution	1,200 dpi (8bit)	
Input Data Streams	 IPDS PostScript Level3 PDF -Version 1.7 TIFF -TIFF AFPC Subset JPEG -AFPC JPEG Subset PDF/VT-1 PDF/X (PDF/X-1a, PDF/X-3, PDF/X-4) PPML –Version 2.2 	
Built-in Fonts	Roman PS Font: 136 fonts	
Power Source	100-240 V, 4.8 A, 50/60 Hz	
Power Consumption	400 W	
Dimensions (W x D x H)	178 × 650 × 444 mm (7.0 × 25.6 × 17.5 inches)	
Weight	Approximately 22 kg (4.41 lbs.)	

MEMO

MEMO

MEMO