


SP 1210N User's Guide



Using this guide

Symbols used in this guide

We use the following icons throughout this User's Guide:



Warnings tell you what to do to prevent possible personal injury.



Electrical Hazard icons alert you to a possible electrical shock.



Hot Surface icons warn you not to touch machine parts that are hot.



Cautions specify procedures you must follow or avoid to prevent possible damage to the printer or other objects.



Improper Setup icons alert you to devices and operations that are not compatible with the printer.



Notes tell you how you should respond to a situation that may arise or give tips about how the operation works with other features.

i

Safety precautions

To use the printer safely


Please keep these instructions for later reference and read them before attempting any maintenance.



WARNING




There are high voltage electrodes inside the printer. Before you clean the inside of the printer, make sure that you have turned off the power switch and unplugged the printer from the AC power outlet.





DO NOT handle the plug with wet hands. Doing this might cause an electrical shock.



Always make sure the plug is fully inserted.

DO NOT use a vacuum cleaner to clean up scattered toner. Doing this might cause the toner dust to ignite inside the vacuum cleaner, potentially starting a fire. Carefully clean the toner dust with a dry, lint-free cloth and dispose of it according to local regulations.

DO NOT use flammable substances, any type of spray or organic solvent/liquids containing alcohol /ammonia to clean the inside or outside of the machine. Doing this may cause a fire or electrical shock. Refer to *Cleaning* on page 65 for how to clean the machine.








After you have just used the printer, some internal parts of the printer will be extremely hot. To prevent injury, when you open the front or back cover (back output tray) of the printer, DO NOT touch the shaded parts shown in the illustration.



Inside the printer (Front View)



Inside the printer (Back View)


Plastic bags are used in the packaging of your machine. To avoid danger of suffocation, keep these bags away from babies and children.

Cleaning the outside of the printer:

- Make sure that you have unplugged the printer from the AC power outlet.
- Use neutral detergents. Cleaning with volatile liquids such as thinner or benzine will damage the outside surface of the printer.
- DO NOT use cleaning materials that contain ammonia.



DO NOT remove or damage the caution labels located on or around the fuser.



CAUTION

Be sure to disconnect the plug from the wall outlet and clean the prongs and the area around the prongs at least once a year.

Allowing dust to build up on the plug constitutes a fire hazard.

Symbols for the main power switch

In accordance with IEC 60417, this machine uses the following symbols for the main power switch:

- means POWER ON.
- means POWER OFF.

Trademarks

The Ricoh logo is a registered trademark of Ricoh Company., Ltd.

Hewlett Packard is a registered trademark and HP LaserJet 6P, 6L, 5P, 5L, 4, 4L 4P, III, IIIP, II, and IIP are trademarks of Hewlett-Packard Company.

Windows Vista is either a registered trademark or a trademark of Microsoft Corporation in the United States and other countries.

Microsoft, Windows and Windows Server are registered trademarks of Microsoft Corporation in the United States and/or other countries.

ENERGY STAR is a U.S. registered mark.

SuSE is a registered trade mark of SuSE Linux AG.

RED HAT is a registered trade mark of Red Hat. Inc.

Mandrake is a registered trade mark of Mandrake Soft SA.

Intel, Intel Xeon and Pentium are trademarks or registered trademarks of Intel Corporation.

AMD, AMD Athlon, AMD Opteron and combinations thereof, are trademarks of Advanced Micro Devices, Inc.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.

All other terms and brand and product names mentioned in this User's Guide are registered trademarks of their respective companies.

Compilation and Publication Notice

Under the supervision of Ricoh Company., Ltd., this manual has been compiled and published, covering the latest product's descriptions and specifications. The contents of this manual and the specifications of this product are subject to change without notice. Ricoh reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.

© 2007 Ricoh Company., Ltd.

Shipment of the Printer

If for any reason you must ship your printer, carefully package the printer to avoid any damage during transit. We recommend that you save and use the original packaging. The printer should also be adequately insured with the carrier.

Table of Contents

'	About this Finter	
	What is in the box?	
	Interface cable	
	Front view	
	Back view	3
	Positioning the printer	∠
	Power supply	
	Environment	∠
2	Printing Methods	5
	About paper	5
	Type and size of paper	5
	Recommended paper	6
	Unprintable area	
	Printing methods	
	Printing on plain paper and transparencies	
	Printing on thick paper, labels and envelopes	
	Duplex printing	
	Guidelines for printing on both sides of the paper Printing on both sides of the paper (manual duplex printing)	
	Printing on both sides of the paper (mandar duplex printing)	∠
3	Driver and Software	25
	Printer driver	2!
	Features in the printer driver	
	Uninstalling the printer driver	
	Printer driver for Windows® 2000/XP/7, Windows Vista® and Windows Server® 2003	
	Software	
	Software for network models	
	Automatic interface selection	38
4	Control Panel	39
-		
	LEDs (Light Emitting Diodes)	
	Service call indications	
	Go button	
	Print a test page	
	Print a Printer Settings page	
	Print Fonts	
	Network default settings	50
5	Routine Maintenance	51
	Replacing the consumable items	52
	Consumables	
	Toner cartridge	53
	Drum unit	
	Cleaning	65

	Cleaning the outside of the printer	65
	Cleaning the inside of the printer	
	Cleaning the corona wire	
6	Troubleshooting	71
	Identifying your problem	71
	Error messages in the Status Monitor	
	Error message printout	
	Paper handling	
	· · · · · · · · · · · · · · · · · · ·	
	Paper jams and how to clear them	
	Improving the print quality	
	Solving print problems Network problems	
Α	Appendix	91
	··	
	Printer specifications	
	Engine	
	Controller	
	Software	
	Control panel	
	Paper handling	
	Media specifications	92
	Supplies	93
	Dimensions / weights	93
	Other	93
	Computer requirements	94
	Important information for choosing your paper	95
	Symbol and character sets	
	How to use Web Based Management (web browser)	98
	Symbol and character sets list	
	Quick reference for bar code control commands	
	Print bar codes or expanded characters	
В	Appendix (for Europe and Other Countries)	107
	Important information: regulations	107
	Radio interference (220 to 240 volt model only)	
	IEC 60825-1:2007 specification (220 to 240 volt model only)	
	Internal laser radiation	
	EU Directive 2002/96/EC and EN50419	
	IMPORTANT - for your safety	
С	Appendix (for USA and Canada)	110
	Important information: regulations	110
	Federal Communications Commission (FCC) Declaration of Conformity (USA only)	
	Industry Canada Qualification Statement (Canada only)	
	International ENERGY STAR® Qualification Statement	111
	Important Information for Australia	
	IMPORTANT-For Your Safety	
	Important safety instructions	
	Important datoty inditablionionionionionionionionionionionionioni	


	Important Information for Some Countries	114
	Important Safety Instructions	
	Laser notices	
	Laser safety (110 to 120 volt model only)	116
	FDA regulations (110 to 120 volt model only)	116
	Internal laser radiation	
	IMPORTANT - for your safety	117
D	Index	118

1

About this Printer

What is in the box?

When you unpack the printer, make sure that you have all of the following parts.



Interface cable

The interface cable is not a standard accessory. Purchase the appropriate cable for the interface you are using.

■ USB cable

Please make sure you use a USB 2.0 interface cable that is no longer than 6 feet (2 meters).


DO NOT connect the interface cable at this time. Connecting the interface cable is done during the printer driver installation process.

When you use a USB cable, make sure you connect it to the USB port of your computer and not to a USB port on a keyboard or non-powered USB hub.

■ Network cable


Use a straight-through Category5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

Front view



- 1 Face-down output tray support flap 2 (support flap 2) 1
- 2 Face-down output tray support flap 1 (support flap 1)
- 3 Control panel
- 4 Manual feed paper guide
- 5 Manual feed slot
- 6 Manual feed slot cover
- 7 Paper tray
- 8 Front cover
- 9 Power switch
- 10 Ventilation hole
- 11 Face-down output tray
- ¹ For details about the support flap 2, see page 88.

Back view



- 1 Back cover (back output tray)
- 2 AC power connector
- 3 Network status LEDs (Light Emitting Diodes)
- 4 10/100BASE-TX port
- 5 USB interface connector

Positioning the printer

Read the following before you use the printer.

Power supply

Use the printer within the recommended power range.

Power source: USA and Canada: AC 110 to 120 V, 50/60 Hz

Europe and Australia: AC 220 to 240 V, 50/60 Hz

The power cord, including extensions, should be no longer than 5 meters (16.5 feet).

Do not share the same power circuit with other high-powered appliances, such as an air conditioner, copier, shredder and so on. If you cannot avoid using the printer with these appliances, we recommend that you use a voltage transformer or a high-frequency noise filter.

Use a voltage regulator if the power source is not stable.

Environment

- Put your printer on a flat, stable surface such as a desk that is free of vibration and shocks.
- Put the printer near an AC power outlet, so that it can be easily unplugged from the AC power outlet if there is an emergency.
- Only use the printer within the following ranges of temperature and humidity:

Temperature: 10 °C to 32.5 °C (50 °F to 90.5 °F)

Humidity: 20% to 80% (without condensation)

- Use the printer in a well-ventilated room.
- DO NOT put the printer where the ventilation hole of the printer is blocked. Keep a gap of roughly 100 mm (4 in.) between the ventilation hole and the wall.
- DO NOT expose the printer to direct sunlight, excessive heat, moisture, or dust.
- DO NOT put the printer near devices that contain magnets or produce magnetic fields.
- DO NOT expose the printer to open/naked flames or salty or corrosive gasses.
- DO NOT put objects on top of the printer.
- DO NOT put the printer near heaters, air conditioners, water, chemicals or refrigerators.
- Keep the printer horizontal when you carry it.

Printing Methods

About paper

Type and size of paper

The printer loads paper from the installed paper tray or the manual feed slot.

The names for the paper trays in the printer driver and this guide are as follows:

Paper tray	Tray 1
Manual feed slot	Manual

When looking at this page on the CD-ROM, you can jump to the page for each printing method by clicking (i) in the table.

Media type	Tray 1	Manual	Choose the media type from the printer driver
Plain paper			Plain Paper
75 g/m ² to 105 g/m ² (20 to 28 lb)	①	(1)	
Recycled paper	(i)	①	Recycled Paper
Bond paper			Bond Paper
Rough paper– 60 g/m ² to		①	
163 g/m ² (16 to 43 lb)			
Thin paper			Thin Paper
60 g/m ² to 75 g/m ² (16 to 20 lb)	①	①	
Thick paper			Thick Paper or Thicker
105 g/m ² to 163 g/m ² (28 to 43 lb)		(1)	Paper
Transparency	(i)	①	Transparencies
	A4 or Letter	A4 or Letter	
Labels		①	Thicker Paper
		A4 or Letter	
Envelopes			Envelopes
		①	Env. Thin
			Env. Thick

	Tray 1	Manual	
Paper size	A4, Letter, Legal ¹ , B5 (ISO), Executive,	Width: 76.2 to 220mm (3 to 8.7 in.)	
	A5, A6, B6 (ISO), Folio, Post Card	Length: 116 to 406.4 mm (4.57 to 16 in.)	
Number of sheets (80 g/m ² / 20 lb)	250 sheets	Single sheet	
Envelope size	N/A	COM10	

Legal size paper is not available in some regions outside the USA and Canada.

Recommended paper

	Europe	USA
Plain paper	Xerox Premier TCF 80 g/m ² Xerox Business 80 g/m ²	Xerox 4200DP 20 lb Hammermill Laser Print (24 lb=90g/m2)
Recycled paper	Xerox Recycled Supreme 80 g/m ²	(No specific brand recommended)
Transparency	3M CG3300	3M CG3300
Labels	Avery laser label L7163	Avery laser labels white #5160
Envelope	Antalis River series (DL)	(No specific brand recommended)

- Before you buy a lot of paper, test a small quantity to make sure that the paper is suitable.
- Use paper that is made for plain-paper copying.
- Use paper that is 75 to 90 g/m² (20 to 24 lb).
- Use neutral paper. Do not use acidic or alkaline paper.
- Use long-grain paper.
- Use paper with a moisture content of approximately 5%.
- This printer can use recycled paper that meets DIN 19309 specifications.

CAUTION

DO NOT use ink jet paper because it may cause a paper jam or damage your printer.

Preprinted paper must use ink that can withstand the temperature of the printer's fusing process (200 degrees centigrade).

If you use bond paper, paper having a rough surface or paper that is wrinkled or creased, the paper may exhibit degraded performance.



If you use paper that is not recommended, a paper jam or misfeed may occur in the printer.

(To help you choose which paper to use with this printer, see Important information for choosing your paper on page 95.)

Types of envelopes

Most envelopes will be suitable for your printer. However, some envelopes may have feed and print quality problems due to the way they have been made. A suitable envelope should have edges with straight, well-creased folds and the leading edge should not be thicker than two pieces of paper. The envelope should lie flat and not be of baggy or flimsy construction. You should buy quality envelopes from a supplier who understands that you will be using the envelopes in a laser printer. Before you print a lot of envelopes, test one to make sure that the print results are what you want.

We does not recommend a particular envelope because envelope manufacturers may change the envelope specifications. You are responsible for the quality and performance of the envelopes you use.

- Do not use damaged, curled, wrinkled, irregularly shaped, extremely shiny or textured envelopes.
- Do not use envelopes with clasps, snaps, tie strings, self-adhesive components, windows, holes, cutouts or perforations.
- Do not use envelopes that are of a baggy construction, not sharply creased, embossed (have raised writing on them) or pre-printed on the inside.
- Do not use envelopes that were previously printed by a laser printer.
- Do not use envelopes that are made of paper that weighs more than the paper weight specifications for the printer.
- Do not use envelopes that have been badly made, with edges that are not straight or consistently square.



If you use any of the types of envelopes listed above, they may damage your printer. This damage is not covered under any our warranty or service agreement.




- Do not put different types of paper in the paper tray at the same time because it may cause paper jams or misfeeds.
- Do not print envelopes using manual duplex printing.
- You must choose the same paper size from your application as the paper or envelope you are using.

Unprintable area


The area of the paper that cannot be printed on is shown in the table below:

Portrait



	A4	Letter	Legal	B5 (ISO)	Executive	A5	A6	B6
1	4.23 mm							
	(0.16 in.)							
2	6.01 mm	6.35 mm	6.35 mm	6.01 mm	6.35 mm	6.01 mm	6.01 mm	6.01 mm
	(0.24 in.)	(0.25 in.)	(0.25 in.)	(0.24 in.)	(0.25 in.)	(0.24 in.)	(0.24 in.)	(0.24 in.)
3	4.23 mm							
	(0.16 in.)							
4	6.01 mm	6.35 mm	6.35 mm	6.01 mm	6.35 mm	6.01 mm	6.01 mm	6.01 mm
	(0.24 in.)	(0.25 in.)	(0.25 in.)	(0.24 in.)	(0.25 in.)	(0.24 in.)	(0.24 in.)	(0.24 in.)

Landscape



	A4	Letter	Legal	B5 (ISO)	Executive	A5	A6	B6
1	4.23 mm							
	(0.16 in.)							
2	5.0 mm	5.08 mm	5.08 mm	5.0 mm	5.08 mm	5.0 mm	5.0 mm	5.0 mm
	(0.19 in.)	(0.2 in.)	(0.2 in.)	(0.19 in.)	(0.2 in.)	(0.19 in.)	(0.19 in.)	(0.19 in.)
3	4.23 mm							
	(0.16 in.)							
4	5.0 mm	5.08 mm	5.08 mm	5.0 mm	5.08 mm	5.0 mm	5.0 mm	5.0 mm
	(0.19 in.)	(0.2 in.)	(0.2 in.)	(0.19 in.)	(0.2 in.)	(0.19 in.)	(0.19 in.)	(0.19 in.)


Printing methods

Printing on plain paper and transparencies


Printing on plain paper and transparencies from the paper tray

(For the recommended paper to use, see *About paper* on page 5.)

1 Pull the paper tray completely out of the printer.




2 While pressing the blue paper-guide release lever, slide the paper guides to fit the paper size. Make sure that the guides are firmly in the slots.





For Legal size paper, press the release button in the bottom of the paper tray and then pull out the back of the paper tray. (Legal size paper is not available in some regions.)



3 Put paper in the tray, and make sure that the paper is below the maximum paper mark (1). The side to be printed on must be face down.




CAUTION

Make sure the paper guides touch the sides of the paper so it will feed properly. If you do not this, it may cause damage to your printer.

4 Put the paper tray firmly back in the printer. Make sure that it is completely inserted into the printer.

5 Lift up the support flap 1 (1) to prevent paper from sliding off the face-down output tray.




6 Choose the following from the printer driver:

 Paper Size
 (1)

 Media Type
 (2)

 Paper Source
 (3)


and any other settings.



Send the print data to the printer.



• The Error LED on the control panel will light up to indicate **No paper** if the power switch is turned on before you put paper or transparencies in the tray. You can clear this error indication by pressing **Go**.



• When printing on transparencies, remove each transparency as soon as it has been printed. Stacking the printed transparencies may cause a paper jam or the transparency to curl.


Printing on plain paper, bond paper or transparencies from the Manual feed slot

(For the recommended paper to use, see *About paper* on page 5.)




The printer automatically turns on the Manual Feed mode when you put paper in the manual feed slot.


1 Lift up the support flap 1 (1) to prevent paper from sliding off the face-down output tray, or remove each page as soon as it comes out of the printer.




2 Open the manual feed slot cover.



3 Using both hands, slide the manual feed slot paper guides to the width of the paper that you are going to use.



4 Using both hands, put one piece of paper or one transparency in the manual feed slot until the front edge of the paper or transparency touches the paper feed roller. When you feel the machine pull in the paper, let go.






- Put the paper into the manual feed slot with the side to be printed face up.
- Make sure that the paper or transparency is straight and in the correct position on the manual feed slot. If
 it is not, the paper or the transparency may not be fed properly, resulting in a skewed printout or a paper
 jam.
- Do not put more than one piece of paper in the manual feed slot at any one time, as it may cause a jam.
- If you put any media (paper, transparency and so on) in the manual feed slot before the printer is in the Ready state, the media may be ejected without being printed on.

5 Choose the following from the printer driver:

Paper Size(1)

Media Type(2)


Paper Source(3) and any other settings.



- 6 Send the print data to the printer.
- 7 After the printed page comes out of the printer, put in the next sheet of paper or transparency as in Step 4 above. Repeat for each page that you want to print.



• The Error LED on the control panel will flash to indicate **No paper** in the manual feed slot until you put a sheet of paper or transparency in the manual feed slot.



• When printing on transparencies, remove each transparency as soon as it has been printed. Stacking the printed transparencies may cause a paper jam or transparency to curl.


Printing on thick paper, labels and envelopes

When the back output tray is pulled down, the printer has a straight paper path from the manual feed slot through to the back of the printer. Use this paper feed and output method when you want to print on thick paper, labels or envelopes. (For the recommended paper to use, see *About paper* on page 5 and *Type and size of paper* on page 5.)




The printer automatically turns on the Manual Feed mode when you put paper in the manual feed slot.


Open the back cover (back output tray).




Open the manual feed slot cover.



3 Using both hands, slide the manual feed slot paper guides to the width of the paper that you are going to use.




4 Using both hands, put one piece of paper or one envelope in the manual feed slot until the front edge of the paper or envelope touches the paper feed roller. When you feel the machine pull in the paper, let go.





- Put the paper into the manual feed slot with the side to be printed face up.
- Make sure that the paper or envelope is straight and in the proper position on the manual feed slot. If it is not, the paper or the envelope may not be fed properly, resulting in a skewed printout or a paper jam.
- Do not put more than one piece of paper in the manual feed slot at any one time, as it may cause a jam.
- If you put any Media (paper, envelope and so on) in the manual feed slot before the printer is in the Ready state, the media may be ejected without being printed on.
- **5** Choose the following from the printer driver:
 - Paper Size(1)
 Media Type(2)
 Paper Source(3)

and any other settings.







- When you use Envelope #10, choose Com-10 for the Paper Size.
- For other envelopes which are not listed in the printer driver, such as Envelope #9 or Envelope C6, choose **User Defined...** (For more information on envelope sizes, see *Paper size* on page 97.)
- 6 Send the print data to the printer.
- 7 After the printed page comes out of the printer, put in the next sheet of paper or envelope as shown in Step 4. Repeat for each page that you want to print.



• The Error LED on the control panel will flash to indicate **No paper** in the manual feed slot until you put a sheet of paper or envelope in the manual feed slot.




• Remove each sheet or envelope as soon as it has been printed. Stacking sheets or envelopes may cause the paper to jam or curl.






• If an envelope is creased after it is printed, turn the next one around 180° when you put it in the manual feed slot, and then in the printer driver choose the **Advanced** tab, select **Page Setting**, and check the **Reverse Print** box. As an alternative you can change the printing direction in your software application.



• If the DL size double flap envelope is creased after printing, choose **DL Long Edge** in **Paper Size**, from the **Basic** tab. Put a new DL size double-flap envelope in the manual feed slot with the longest edge of the envelope in first, then print again.



- If envelopes get smudged during printing set the **Media Type** to **Thick Paper** or **Thicker Paper** to increase the fixing temperature.
- Envelope joints that are sealed by the manufacturer should be secure.
- All sides of the envelope should be properly folded without wrinkles or creases.

Duplex printing

The supplied printer drivers for Windows[®] 2000/XP/XP Professional x64 Edition, Windows Vista[®], Windows Server[®] 2003/Windows Server[®] 2003 x64 Edition all enable duplex printing. For more information about how to choose the settings, see the **Help** text in the printer driver.

Guidelines for printing on both sides of the paper

- If the paper is thin, it may wrinkle.
- If paper is curled, straighten it and then put it back in the paper tray or the manual feed slot.
- If the paper is not feeding properly, it may be curled. Remove the paper and straighten it.
- When you use the manual duplex function, it is possible that there may be paper jams or poor print quality. (If there is a paper jam, see *Paper jams and how to clear them* on page 77. If you have a print quality problem, see *Improving the print quality* on page 83.)




- The screens in this section are from Windows[®] XP. The screens on your computer may vary depending on your operating system.
- Make sure that the paper tray is completely inserted into the printer.
- · You should use plain paper, recycled paper or thin paper. Do not use bond paper.


Printing on both sides of the paper (manual duplex printing)

Manual duplex printing from the paper tray

- 1 In the printer driver choose the **Advanced** tab, click the Duplex icon, and then choose the **Manual Duplex** printing mode, and from the **Basic** tab choose the Paper Source to be **Tray1**.
- Send the data to the printer, then click **OK** on the computer screen.
 The printer will automatically print all the even-numbered pages on one side of the paper first.



3 Remove the printed even-numbered pages from the output tray and put them back in the paper tray with the side to be printed on (blank side) face down. Follow the instructions on the computer screen.



4 The printer will now automatically print all the odd-numbered pages on the other side of the paper.




When you put paper in the paper tray, first empty the tray. Next, put the printed pages in the tray, with the printed side face up. (Do not add the printed pages to the top of a stack of unprinted paper.)

Manual duplex printing from the manual feed slot




You should use plain paper and recycled paper. Do not use bond paper.


- 1 In the printer driver choose the **Advanced** tab, click the Duplex icon, then choose the **Manual Duplex** printing mode, and then from the **Basic** tab choose the **Paper Source** to be **Manual feed**.
- 2 Open the manual feed slot cover.




3 Using both hands, slide the manual feed slot paper guides to the width of the paper that you are going to use.




4 Using both hands put the paper in the manual feed slot with the side that is going to be printed on first facing up. Follow the instructions on the computer screen. Repeat this step until you have printed all the even-numbered pages.





6 Remove the printed even-numbered pages from the output tray, and then put the first of the printed sheets back into the manual feed slot with the side to be printed on (the blank side) face up. Follow the instructions on the computer screen.



6 Repeat Step 6 until you have printed all the odd-numbered pages.

Paper orientation for manual duplex printing

The printer prints the second page first.

If you print 10 pages on 5 sheets of paper, it will print page 2 and then page 1 on the first sheet of paper. It will print page 4 and then page 3 on the second sheet of paper. It will print page 6 and then page 5 on the third sheet of paper, and so on.

When doing manual duplex printing, the paper must be put in the paper tray in the following way:

- For the paper tray:
 - Put the side to be printed on face down with the leading edge (top) of the paper at the front of the tray.
 - To print on the second side, put the paper face up, with the leading edge (top) of the paper at the front of the tray.
 - If letterhead paper is used, put the paper in the tray with the heading face up at the front of the tray.
 - To print on the second side, put the heading face down at the front of the tray.
- For the manual feed slot:
 - Put the side to be printed on face up with the leading edge (top) of the paper in first.
 - To print on the second side, put the paper face down, with the leading edge (top) of the paper in first.
 - If letterhead paper is used, put it in with the heading face down and in first.
 - To print on the second side, put the heading face up and in first.

3

Driver and Software

Printer driver

A printer driver is software that translates data from the format used by a computer to the format that a particular printer needs. Typically, this format is page description language (PDL).

The printer drivers for the supported versions of Windows[®] are on the CD-ROM we have supplied or on our Web site. Install the drivers by following the Quick Setup Guide. The latest printer driver can be downloaded from our Web site.

(If you want to uninstall the printer driver, see *Uninstalling the printer driver* on page 37.)

■ Windows[®] printer driver

	Windows [®] printer driver
Windows [®] 2000 Professional	①
Windows [®] XP Home Edition	①
Windows [®] XP Professional	①
Windows Vista [®]	①
Windows Server [®] 2003	①
Windows [®] XP Professional x64 Edition	①
Windows Server® 2003 x64 Edition	①

¹ You can download the latest printer driver from our Website.

You can change the following printer settings when you print from your computer.

- Paper Size
- Multiple Page
- Orientation
- Copies
- Media Type
- Paper Source
- Resolution
- Toner Save Mode
- Print Setting
- Manual Duplex printing
- Watermark
- Scaling
- Job Spooling
- Quick Print Setup
- Sleep Time
- Macro
- Header-Footer Print
- Density adjustment
- Error Message Printout
- Improve Print Output

Features in the printer driver


(For more information, see the **Help** text in the printer driver.)



- The screens in this section are from Windows® XP. The screens on your computer will vary depending on your operating system.
- If you are using Windows[®] 2000, XP, 7, Windows Vista[®] or Windows Server[®] 2003, you can access the **Printing Preferences** dialog box by clicking **Printing Preferences**... in the **General** tab of the **Printer Properties** dialog box.

Basic tab

You can also change settings by clicking the illustration on the left side of the **Basic** tab.



- 1 Choose the Paper Size, Multiple Page, Orientation, Copies and Media Type (1).
- 2 Choose the Paper Source (2).
- 3 Click **OK** to apply your chosen settings.

 To return to the default settings, click **Default**, then **OK**.

Paper Size

From the drop-down box choose the Paper Size you are using.

Multiple Page

The Multiple Page selection can reduce the image size of a page allowing multiple pages to be printed on one sheet of paper or can enlarge the image size for printing one page on multiple sheets of paper.





Page Order

When N in 1 option is selected, the page order can be selected from the drop-down list.

Border Line

When printing multiple pages on one sheet with the Multiple Page feature you can choose to have a solid border, dash border or no border around each page on the sheet.

Orientation

Orientation selects the position of how your document will be printed (**Portrait** or **Landscape**).







Copies

The copies selection sets the number of copies that will be printed.

Collate

With the Collate check box selected, one complete copy of your document will be printed and then will be repeated for the number of copies you selected. If the Collate check box is not selected, then each page will be printed for all the copies selected before the next page of the document is printed.





Media Type

You can use the following types of media in your printer. For the best print quality, select the type of media that you wish to use.

Plain Paper Thin Paper Thick Paper Thicker Paper Bond Paper Transparencies Envelopes Env. Thick Env. Thin Recycled Paper



- When using ordinary plain paper (72.5 g/m² to 95 g/m² / 19 to 25 lb) choose **Plain Paper**. When using heavier weight paper or rough paper choose **Thick Paper** or **Thicker Paper**. For bond paper, choose **Bond Paper**.
- When you use envelopes, choose **Envelopes**. If the toner is not fixed to the envelope correctly when **Envelopes** has been selected, choose **Env. Thick**. If the envelope is crumpled when **Envelopes** has been selected, choose **Env.Thin**.


Paper Source

You can choose **Auto Select**, **Tray1**, **Manual** and specify separate trays for printing the first page and for printing from the second page onwards.



The printer automatically turns on the Manual Feed mode when you put paper in the manual feed slot.

Advanced tab



Change the tab settings by clicking one of the following icons:

- Print Quality (1)
- Duplex (2)
- Watermark (3)
- Page Setting (4)
- Device Options (5)

Print Quality

■ Resolution

You can change the resolution as follows:

- HQ 1200
- 600 dpi
- 300 dpi

■ Toner Save Mode

You can save running costs by turning on the **Toner Save Mode**, which reduces the print density (print appears lighter).



- We do not recommend **Toner Save Mode** for printing Photo or Greyscale images.
- Toner Save Mode is not available for HQ 1200 resolution.

■ Print Setting

You can manually change the print setting.

General

This is a printing mode for general printing of documents.

Graphics

This is the best mode for printing documents that contain graphics.

Office Document

This is the best mode for printing office documents.

Manual

You can change the settings manually by choosing **Manual** and clicking the **Setting...** button. You can set brightness, contrast and other settings.

Duplex Printing

■ Manual Duplex

Check the **Duplex** box and choose **Manual Duplex**. In this mode, the printer prints all the even numbered pages first. Then the printer driver will stop and show the instructions required to re-install the paper. When you click **OK** the odd numbered pages will be printed. There are six types of manual duplex binding directions available for each orientation.

■ Booklet Printing

When you want to print a booklet, use this function. To make the Booklet, fold the printed pages down the middle, when using the booklet printing function.

■ Binding Offset

If you check the Binding Offset option, you can also specify the offset for binding in inches or millimeters.

Watermark

You can put a logo or text into your documents as a watermark.

You can choose one of the preset watermarks, or you can use a bitmap file or text file that you have created.


When you use a bitmap file as a watermark, you can change the size of the watermark and put it anywhere you like on the page.

When you use text as a watermark, you can change the font, darkness and angle settings.

Page Setting

You can change the print image scaling and choose Mirror/Reverse print options.

Device Options



You can set the following in **Printer Function**:

- Job Spooling
- Quick Print Setup
- Sleep Time
- Macro
- Header-Footer Print
- Density adjustment
- Error Message Printout
- Improve Print Output

■ Job Spooling

The printer keeps the last print job sent to it in memory.

To reprint the last document, press the **Go** button and hold it down for about 4 seconds until all the LEDs light up in order (**Toner**, **Drum**, **Error**, **Ready**), and then release the **Go** button. Within 2 seconds press the **Go** button the number of times you want to reprint. If you don't press the **Go** button within 2 seconds, a single copy will be printed.



If you want to prevent other people from printing your data using the reprint function, uncheck the **Use Reprint** check box in the job spooling settings.

■ Quick Print Setup

This feature allows you to quickly choose driver settings by clicking a tasktray icon.

You can turn the quick print setting on or off. By placing a check in the selection boxes for the following functions you can choose which will be available in the quick print setting.

- · Multiple Page
- · Manual Duplex
- · Toner Save Mode
- Paper Source
- Media Type

■ Sleep Time

When the printer does not receive data for a certain period of time, it enters sleep mode. In sleep mode, the printer acts as though it were turned off. When you choose **Printer Default**, the timeout setting has been set to a specific time set at the factory, this can be altered in the driver. Intelligent Sleep Mode automatically adjusts to the most suitable timeout setting depending on the frequency of your printer use.

While the printer is in sleep mode, the **Ready** LED lights up slightly, but the printer can still receive data. Receiving a print file or document or pressing the **Go** button will automatically wake up the printer to start printing.

To turn sleep mode off, from the **Advanced** tab, click the **Device Options** icon and choose **Sleep Time**. Double-click the word **Sleep Time**, and the Sleep Time Off function will appear. Click **Off** to stop the printer going into sleep mode. The Sleep Time Off function can be hidden by double-clicking the word Sleep Time again. We recommend that you keep sleep mode on for power saving.

■ Macro

You can save a page of a document as a macro to the printer's memory. You can also execute the saved macro (you can use the saved macro as an overlay on any document). This will save time and increase printing speed for often used information such as forms, company logos, letterhead formats or invoices.

■ Header-Footer Print

When this feature is enabled, it will print the date and time on your document from your computer's system clock and the PC login user name or the text you entered. By clicking **Setting**, you can customize the information.

• ID Print

If you select **Login User Name**, your PC login user name will print. If you select **Custom** and enter the text in the **Custom** edit box, the text you entered will print.

■ Density adjustment

Increase or decrease the print density.



The **Density adjustment** is not available when you set the **resolution** to **HQ 1200**.

■ Error Message Printout

You can choose whether the printer reports problems by printing an error page. For details, see *Error message printout* on page 74.

Selections are **Printer Default** (ON), **ON** and **OFF**.

■ Improve Print Output

This feature allows you to improve a print quality problem.

Reduce Paper Curl

If you choose this setting, the paper curl may be reduced.


If you are printing only a few pages, you do not need to choose this setting. We recommend that you change the printer driver setting in **Media Type** to a thin setting.

Improve Toner Fixing

If you choose this setting, the toner fixing on paper may be improved. If this selection does not improve the situation enough, select **Thicker paper** in **Media type** settings.

Tray Settings tab

You can define the paper size for each paper tray and auto detect the serial number in the **Tray Settings** tab as follows.



■ Paper Source Setting (1)

This feature identifies the paper size defined for each paper tray.

Paper Size

This setting allows you to define which paper size is used for the tray and manual feed slot. Highlight the paper source you want to define and then choose the paper size from the pull-down menu. Click **Update** to apply the setting to the paper source.

Default Source

This setting allows you to choose the default paper source that your document will be printed from. Choose the **Default Source** from the pull-down menu and click **Update** to save your setting. The **Auto Select** setting will automatically pull paper from any paper source (tray or manual feed slot) that has a defined paper size that matches your document.

■ Serial No. (2)


By clicking **Auto Detect**, the printer driver will probe the printer and display its serial number. If it fails to receive the information, the screen will display "-----".



The **Auto Detect** function is not available under the following printer conditions:

- · The printer power switch is off.
- The printer is in an error state.
- The printer is in a network shared environment.
- The cable is not connected to the printer correctly.

Support tab



■ Print Settings (1)

This will print the pages that show how the internal settings of the printer have been configured.

■ Print Fonts (2)

This will print the pages that show all the internal fonts of the printer.

■ Check Setting... (3)

You can check the current driver settings.

Uninstalling the printer driver

You can uninstall the printer driver that you have installed with the following steps.



- This is not available if you installed the printer driver from the Windows Add a printer function.
- After uninstalling, we recommend that you restart your computer to remove files that were in use during the uninstall.

Printer driver for Windows $^{(\!R)}$ 2000/XP/7, Windows Vista $^{(\!R)}$ and Windows Server $^{(\!R)}$ 2003

- 1 Click the **Start** button, point to **All Programs** ¹ and then to your printer name.
- Click Uninstall.
- 3 Follow the instructions on the screen.
- ¹ **Programs** for windows[®] 2000 users

Software

Software for network models

BRAdmin Light

BRAdmin Light is a utility for initial setup of Ricoh network connected devices. This utility can search for products on your network, view the status and configure basic network settings, such as IP address. The BRAdmin Light utility is available for Windows[®] 2000/XP/7 and Windows Vista[®] and Windows Server[®] 2003 or greater computers. For installing BRAdmin Light, please see the Quick Setup Guide we provided with the printer.

Automatic interface selection

This printer has an automatic interface selection feature that is turned on by default. This lets it automatically change the interface to USB or Ethernet depending on which interface is receiving data.

Since the default setting is on for the automatic interface selection mode, simply connect the interface cable to the printer. Always turn off both your computer and printer when connecting or disconnecting the cable.




This function takes a few seconds to work.

If only one interface is chosen, the printer will allocate the entire input buffer to that interface.

Control Panel

LEDs (Light Emitting Diodes)

This section refers to three LEDs **Toner**, **Drum** and **Error**, and a dual function **Ready** LED & **Go** button on the control panel.



1 Toner LED

The Toner LED indicates when the Toner is low or at the end of its life.

2 Drum LED

The Drum LED indicates when the Drum is nearing the end of its life.

3 Error LED

The Error LED indicates when the printer is in one of the following states:

No paper / Paper jam / Cover open

4 Ready LED


The Ready LED will flash depending on the printer status.


Go button


Wake-up / Error recovery / Form feed / Job Cancel / Reprint


The LED indications shown in the table below are used in the illustrations in this chapter.

or —	LED is off.
or or —	LED is on.
	The LED is dimmed.
or or or	LED is blinking.










Service call indications

If there is an error that cannot be cleared by the user, the printer will show that a service call is needed by lighting up all the LEDs as shown below.



If you see the service call indication shown above, turn off the power switch, and then turn it back on and try to print again.


If the error remains after switching the printer back on, press the **Go** button and make a note of the LED's that remain lit and report the error status (as shown in the table below) to your dealer or Ricoh Customer Service.

LED indications while pressing the Go button

LEDs	Main PCB failure	Fuser unit failure ¹	Laser unit failure	Main motor failure	High voltage failure
Toner					
Drum					
Error					
Ready					

If this error occurs, turn off the printer power switch, wait a few seconds, and then turn it on again. Leave the printer for 10 minutes with the power on. If the error occurs again, call your dealer or Ricoh Customer Service.

For example, the LED indication below shows a fuser unit failure.



Make a note of the indication, referring to the table on page 44, and report the error status to your dealer or Ricoh Customer Service.



Make sure that the front cover is completely closed before you report a service call.

Go button

The **Go** button has the following functions:

■ Cancel printing

Cancel only the printing job:

While printing press the **Go** button for about 4 seconds until all the LEDs light up. The **Ready** and **Error** LEDs will flash as the job is being canceled.

Cancel all the received jobs:

To delete all jobs, press the **Go** button for about 4 seconds until all the LEDs light up and then release it. Press the **Go** button again. The **Ready** and **Error** LEDs will flash as the job is being canceled.

■ Wake-up

If the printer is in sleep mode, press the **Go** button to wake the printer up and go to the Ready state.

■ Error recovery

If there is an error, the printer will recover automatically from some errors. If an error is not automatically cleared, press the **Go** button to clear the error, and then continue to use the printer.

■ Form feed

If the blue **Ready** LED blinks for a long time, press the **Go** button. The printer will print any data that is left in the printer's memory.

■ Reprint

To reprint the last document, press the **Go** button for about 4 seconds until all the LEDs light up and then release it. Within 2 seconds press the **Go** button the number of times you want to reprint. If you don't press the **Go** button within 2 seconds, a single copy will be printed.

If you want to use the reprint function open the driver's **Properties** dialog box and go to the Advanced tab, select the **Device options** icon and click **Job Spooling** and then check the **Use Reprint** check box. See *Device Options* on page 32.

Print a test page


You can use the **Go** button or the printer driver to print a test page.

Using the Go button

- 1 Turn off the printer.
- Make sure that the front cover is closed and the power cord is plugged in.
- 3 Hold down the **Go** button as you turn on the power switch. Keep the **Go** button pressed down until the **Toner**, **Drum** and **Error** LEDs light up. Release the **Go** button. Make sure that the **Toner**, **Drum** and **Error** LEDs are off.
- 4 Press the **Go** button again. The printer will print a test page.

Using the printer driver

If you are using the Windows ¹ printer driver, click the **Print Test Page** button in the **General** tab of the printer driver.



Print a Printer Settings page


You can print the current settings using the control panel button or printer driver.

Using the Go button

- 1 Make sure that the front cover is closed and the power cord is plugged in.
- Turn on the printer and wait until the printer is in the Ready state.
- 3 Press the **Go** button three times within 2 seconds. The printer will print the current printer settings page.

Using the printer driver

If you are using the Windows[®] printer driver, you can print the current printer settings page by clicking the **Print Settings** button in the **Support** tab.



Print Fonts


You can print a list of the internal fonts using the control panel button or printer driver.

Using the Go button

- 1 Turn off the printer.
- Make sure that the front cover is closed and the power cord is plugged in.
- 3 Hold down the **Go** button as you turn on the power switch. Keep the **Go** button pressed down until the **Toner**, **Drum** and **Error** LEDs light up. Release the **Go** button. Make sure that the **Toner**, **Drum** and **Error** LEDs are off.
- 4 Press the **Go** button twice. The printer will print a list of the internal fonts.

Using the printer driver

If you are using the Windows[®] printer driver, you can print a list of the internal fonts by clicking the **Print Fonts** button in the **Support** tab.



Network default settings

If you want to reset the print server back to its default settings (resetting all information such as the password and IP address information), follow these steps:

Using the Go button

- 1 Turn off the printer.
- Make sure that the front cover is closed and the power cord is plugged in.
- 3 Hold down the **Go** button as you turn on the power switch. Keep the **Go** button pressed down until the **Toner**, **Drum** and **Error** LEDs light up. Release the **Go** button. Make sure that the **Toner**, **Drum** and **Error** LEDs are off.
- 4 Press the **Go** button seven times. Make sure that all the LEDs light up to indicate the print server has been reset to its default settings.

5 Routine Maintenance


You will need to replace certain parts and clean the printer regularly.




WARNING

When you replace certain parts or clean the inside of the printer, remember the following:

- If your clothes are smeared with toner, wipe off the toner with a dry cloth and immediately wash the clothes in cold water to avoid stains.
- Be careful not to inhale toner.
- After you have just used the printer, some internal parts of the printer will be extremely hot. To prevent injury, when you open the front cover or back cover (back output tray) of the printer, DO NOT touch the shaded parts shown in the illustration.






Replacing the consumable items

You will need to replace the consumable items when the machine indicates that the life of the consumable is over.

Consumables



Approx. cartridge yield is declared in accordance with ISO/IEC 19752.

Toner cartridge

The life of the original toner cartridge that came with the printer will be a starter ¹ toner cartridge.


The starter toner cartridge will print approximately 1,000 A4 or Letter-size single-sided pages. Approx. cartridge yield is declared in accordance with ISO/IEC 19752.



- The amount of toner used varies according to what is printed on the page and the print density setting.
- If you change the print density setting for lighter or darker printing, the amount of toner used will change.
- Wait to unpack the toner cartridge until immediately before you put it into the printer.

Toner Low message

The **Toner** LED will turn on for 2 seconds and off for 3 seconds and repeats this pattern.




If the LED shows this message, the printer has nearly run out of toner and will continue to print until it has reached the end of its life. Buy a new toner cartridge and have it ready before you get a **Toner Life End** message. To replace the toner cartridge, see *Replacing the toner cartridge* on page 54.



The **Toner** LED will blink continuously if the toner cartridge is nearly empty.

Toner Life End message

The printer will stop printing until you replace the toner cartridge with a new one.




Replacing the toner cartridge



- To ensure high quality printing, we recommend that you use only genuine toner cartridges. When you want to buy toner cartridges, call your dealer or Ricoh Customer Service.
- We recommend that you clean the printer when you replace the toner cartridge. See *Cleaning* on page 65.
- 1 Make sure that the printer is turned on. Open the front cover.




2 Take out the drum unit and toner cartridge assembly.




We recommend that you put the drum unit and toner cartridge assembly on a piece of disposable paper or cloth in case you accidentally spill or scatter toner.

To prevent damage to the printer from static electricity, DO NOT touch the electrodes shown in the illustration.



Push down the green lock lever and take the toner cartridge out of the drum unit.





WARNING

DO NOT put a toner cartridge into a fire. It could explode, resulting in injuries.

Use neutral detergents.


DO NOT use cleaning materials that contain ammonia, alcohol, any type of spray, or any type of flammable substance to clean the outside or inside of the machine. Doing this may cause a fire or electrical shock.



Handle the toner cartridge carefully. If toner scatters on your hands or clothes, wipe or wash it off with cold water at once.


To avoid print quality problems, DO NOT touch the shaded parts shown in the illustrations.







- Be sure to seal up the toner cartridge tightly in a suitable bag so that toner powder does not spill out of the cartridge.
- Discard the used toner cartridge according to local regulations, keeping it separate from domestic waste. If you have questions, call your local waste disposal office.
- 4 Unpack the new toner cartridge. Hold the cartridge level with both hands and gently rock it from side to side five or six times to spread the toner evenly inside the cartridge.






Wait to unpack the toner cartridge until immediately before you put it in the printer. If toner cartridges are left unpacked for a long time the toner life will be shortened.

If an unpacked drum unit is put in direct sunlight or room light, the unit may be damaged.

Put the toner cartridge in the drum unit immediately after you have removed the protective cover. To prevent any degradation to the print quality, DO NOT touch the shaded parts shown in the illustrations.





CAUTION

For USA and Canada

Ricoh strongly recommends that you do not refill the toner cartridge provided with your printer. We also strongly recommend that you continue to use only genuine Ricoh brand replacement toner cartridges. Use or attempted use of potentially incompatible toner and/or cartridges in the Ricoh machine may cause damage to the machine and/or may result in unsatisfactory print quality. Our warranty coverage does not apply to any problem that is caused by the use of unauthorized third party toner and/or cartridges. To protect your investment and obtain premium performance from the Ricoh machine, we strongly recommend the use of genuine Ricoh supplies.




For UK and other countries


This machines are designed to work with toner of a particular specification and will work to a level of optimum performance when used with genuine Ricoh branded toner cartridges. We cannot guarantee this optimum performance if toner or toner cartridges of other specifications are used. We does not therefore recommend the use of cartridges other than genuine Ricoh branded cartridges with this machine.

If damage is caused to the drum unit or other part of this machine as a result of using other manufacturer's products with this machine, any repairs required as a result may not be covered by the warranty.

Pull off the protective cover.



6 Put the new toner cartridge firmly into the drum unit until you hear it lock into place. If you put it in properly, the lock lever will lift automatically.






CAUTION

Make sure that you put in the toner cartridge properly or it may separate from the drum unit.


7 Clean the primary corona wire inside the drum unit by gently sliding the blue tab from right to left and left to right several times.



CAUTION

Be sure to return the tab to the home position (**A**) (1). If you do not, printed pages may have a vertical stripe.

8 Put the drum unit and toner cartridge assembly back in the printer. Close the front cover.



CAUTION

DO NOT turn off the printer power switch or open the front cover until the Ready LED lights up.

Drum unit


A new drum unit can print approximately 12,000 A4 or Letter size single-sided pages at 1 per/ job.



- There are many factors that determine the actual drum life, such as the temperature, humidity, type of
 paper, type of toner used, number of pages per print job and so on. Under ideal conditions, the average
 drum life is estimated at approximately 12,000 pages. The actual number of pages that your drum will print
 may be significantly less than this estimate. Because we have no control over the many factors that
 determine the actual drum life, we cannot guarantee a minimum number of pages that will be printed by
 your drum.
- For best performance, use only genuine toner. The printer should be used only in a clean, dust-free environment with adequate ventilation.
- Printing with a third-party drum unit may reduce not only the print quality but also the quality and life of the printer itself. Warranty coverage does not apply to problems caused by the use of a third-party drum unit.

Change Drum message

The **Drum** LED will turn on for 2 seconds and off for 3 seconds and repeats this pattern.



If the LED shows the message, it means the drum unit is near the end of its life. We recommend that you replace the drum unit with a new one before there is a noticeable deterioration in the print quality.

Replacing the drum unit



CAUTION

While removing the drum unit, handle it carefully because it may contain toner.


Every time you replace the drum unit, clean the inside of the printer. See Cleaning on page 65.

When you replace the drum unit with a new one, you need to reset the drum counter by completing the following steps:

Make sure that the printer is turned on and the **Drum** LED is blinking. Open the front cover.




Press and hold down the white Go button for about 4 seconds until all the LEDs light up. Once all four LEDs are lit, release the Go button.



Improper Setup

Do not reset the drum counter when you only replace the toner cartridge.


3 Take out the drum unit and toner cartridge assembly.




A CAUTION

We recommend that you put the drum unit and toner cartridge assembly on a piece of disposable paper or cloth in case you accidentally spill or scatter toner.

To prevent damage to the printer from static electricity, DO NOT touch the electrodes shown in the illustration.




4 Push down the green lock lever and take the toner cartridge out of the drum unit.






Handle the toner cartridge carefully. If toner scatters on your hands or clothes, wipe or wash it off with cold water at once.

To avoid print quality problems, DO NOT touch the shaded parts shown in the illustrations.








- Be sure to seal up the drum unit tightly in a suitable bag so that toner powder does not spill out of the unit.
- Discard the used toner cartridge according to local regulations, keeping it separate from domestic waste. If you have questions, call your local waste disposal office.
- Unpack the new drum unit.



CAUTION

Wait to unpack a drum unit until immediately before you put it in the printer. Exposure to direct sunlight or room light may damage the drum unit.


6 Put the toner cartridge firmly into the new drum unit until you hear it lock into place. If you put the cartridge in properly, the green lock lever will lift automatically.



CAUTION

Make sure that you put in the toner cartridge properly, or it may separate from the drum unit.

7 Put the drum unit and toner cartridge assembly back in the printer.



- 8 Close the front cover.
- 9 Make sure that the **Drum** LED is now off.

Cleaning

Clean the outside and inside of the printer regularly with a dry, lint-free cloth. When you replace the toner cartridge or the drum unit, make sure that you clean the inside of the printer. If printed pages are stained with toner, clean the inside of the printer with a dry, lint-free cloth.

Cleaning the outside of the printer




WARNING


Use neutral detergents.

DO NOT use cleaning materials that contain ammonia, alcohol, any type of spray, or any type of flammable substance to clean the outside or inside of the machine. Doing this may cause a fire or electrical shock.


1 Turn off the printer power switch and then unplug the printer.




2 Pull the paper tray completely out of the printer.



3 Wipe the outside of the printer with a dry, lint-free cloth to remove dust.




- 4 Remove anything that is stuck inside the paper tray.
- 6 Wipe the inside of the paper tray with a dry, lint-free cloth to remove dust.




- 6 Put the paper tray back in the printer.
- Plug the printer back in, and then turn on the power switch.

Cleaning the inside of the printer


1 Turn off the printer power switch and then unplug the printer.



2 Open the front cover.



Take out the drum unit and toner cartridge assembly.



HOT SURFACE

After you have just used the printer, some internal parts of the printer will be extremely hot. Wait for the printer to cool down before you touch the internal parts of the printer.




CAUTION


We recommend that you put the drum unit and toner cartridge assembly on a piece of disposable paper or cloth in case you accidentally spill or scatter toner.

Handle the toner cartridge carefully. If toner scatters on your hands or clothes, wipe or wash it off with cold water at once.

To prevent damage to the printer from static electricity, DO NOT touch the electrodes shown in the illustration.



4 Wipe the scanner window with a dry, lint-free cloth.




- 5 Put the drum unit and toner cartridge assembly back in the printer.
- 6 Close the front cover.
- Plug the printer back in, and then turn on the power switch.


Cleaning the corona wire

If you have print quality problems, clean the corona wire as follows:

1 Open the front cover.




2 Take out the drum unit and toner cartridge assembly.




CAUTION

We recommend that you put the drum unit and toner cartridge assembly on a piece of disposable paper or cloth in case you accidentally spill or scatter toner.

To prevent damage to the printer from static electricity, DO NOT touch the electrodes shown in the illustration.




3 Clean the primary corona wire inside the drum unit by gently sliding the blue tab from right to left and left to right several times.



CAUTION

Be sure to return the tab to the home position (A) (1). If you do not, printed pages may have a vertical stripe.

4 Put the drum unit and toner cartridge assembly back in the printer. Close the front cover.



6 Troubleshooting

You can correct most problems by yourself.

Identifying your problem

First, check the following:

- The AC power cord is connected properly and the printer is turned on.
- All of the protective parts have been removed.
- The toner cartridges and drum unit are installed properly.
- The front cover and fuser cover are fully closed.
- Paper is inserted properly in the paper tray.
- The interface cable is securely connected to the printer and the computer.
- The correct driver for the printer has been chosen and is installed.
- The computer is set up to connect to the correct printer port.

Printer does not print:

If you did not solve your problem with the above checks, identify your problem and then go to the page suggested below.

■ Printer LED is blinking

See LEDs (Light Emitting Diodes) on page 39.

■ Status Monitor Error Message appears

See Error messages in the Status Monitor on page 72.

■ Printer printed an Error Message

See Error message printout on page 74.

■ Paper handling

(See Paper handling on page 75 and Paper jams and how to clear them on page 77.)

Pages are printed, but there are problems with:

■ Print quality

(See Improving the print quality on page 83.)

■ Printout is incorrect

(See Solving print problems on page 89.)

Error messages in the Status Monitor

The Status Monitor will report problems with the printer. Take the proper action by referring to the following table.

If you want to turn the status monitor on, follow these steps:

Click the **Start** button, **All Programs** ¹, your printer (e.g Ricoh SP 1210N), and then **Status Monitor**.

¹ **Programs** for Windows® 2000 users

Error message	Action
Cover is Open	■ Close the front cover of the printer.
Memory Full	■ Press the Go button to print the remaining data in the printer memory. Cancel the print job if you want to delete the remaining data in the printer memory. See <i>Go button</i> on page 46.
	■ Reduce the complexity of your document or cut the print resolution.
Print Overrun	■ Press the Go button to print the remaining data in the printer memory. Cancel the print job if you want to delete the remaining data in the printer memory. See <i>Go button</i> on page 46.
	If this does not clear the error, reduce the complexity of your document or cut the print resolution.
	■ Change the following settings in the supplied Windows [®] driver and try again. The best combination of these settings will vary depending on your document:
	Graphics mode ¹
	TrueType mode ¹
	Use Printer TrueType [®] Fonts ¹
	Choose the Advanced tab, click the Print Quality icon, and then choose Manual in Print Setting and click the Setting button.
No Paper Fed Tray 1	■ The paper tray may be out of paper or not properly installed. If it is empty, put a new stack of paper in the paper tray and then press the Go button.
	■ If there is paper in the paper tray, make sure it is straight. If the paper is curled, straighten it before printing. Sometimes it is helpful to remove the paper, turn the stack over and put it back in the paper tray.
	■ Cut the amount of paper in the paper tray, and then try again.
	Make sure you use paper that meets Ricoh's recommended paper specifications. See About paper on page 5.
	■ Load the same size paper that you selected in the current driver setting.
No Paper Fed Manual Slot	■ If the manual feed slot is empty, put a piece of paper in it.
	Make sure you use paper that meets Ricoh's recommended paper specifications. See About paper on page 5.
	■ Load the same size paper that you selected in the current driver setting.

Error message	Action
Paper Jam Tray 1	■ Clear the jammed paper from the indicated area. See Paper jams and how to
Paper Jam Inside	clear them on page 77.
Paper Jam Rear	
Toner Life End	■ See Replacing the toner cartridge on page 54.
Toner Low	Buy a new toner cartridge and have it ready for when the Toner Life End status is indicated.
Cartridge Error	■ Make sure the drum unit and toner cartridge assembly is installed properly.
Fuser Cover is Open	■ Close the fuser cover located behind the back cover of the printer.
Drum Life End Soon	■ The drum unit is near the end of its life. Buy a new drum unit to replace the current one. See <i>Replacing the drum unit</i> on page 61.
Drum Error	■ See Cleaning the corona wire on page 69.
	If your LED's still shows the same error indication after you have cleaned the corona wire, replace the drum unit with a new one. See Replacing the drum unit on page 61.
Service Call	Check the LED indication to identify the error. See Service call indications on page 44.

Error message printout

The printer can also report problems by printing an error message. Use the table below to identify and clear the error message.

Error message	Action
Memory Full	■ Press the Go button to print the remaining data in the printer memory. Cancel the print job if you want to delete the remaining data in the printer memory. See <i>Go button</i> on page 46.
	■ Reduce the complexity of your document or reduce the print resolution.
Print Overrun	■ Press the Go button to print the remaining data in the printer memory. Cancel the print job if you want to delete the remaining data in the printer memory. See <i>Go button</i> on page 46.
	If this does not clear the error, reduce the complexity of your document or reduce the print resolution.
	■ Change the following settings in the supplied Windows [®] driver and try again. The best combination of these settings will vary depending on your document:
	• Graphics mode ¹
	• TrueType mode ¹
	• Use Printer TrueType [®] Fonts ¹
	Choose the Advanced tab, click the Print Quality icon, and then choose Manual in Print Setting and click the Setting button.
Resolution reduced to enable printing	Reduce the complexity of your document before you print to prevent automatic reduction in the resolution.
(The printer has printed the document at a reduced resolution)	

Paper handling


First, make sure that you are using paper that meets Ricoh's recommended paper specifications. (See *About paper* on page 5.)

Problem	Recommendation
The printer does not feed paper.	If there is paper in the paper tray, make sure it is straight. If the paper is curled, straighten it before printing. Sometimes it is helpful to remove the paper. Turn the stack over and put it back in the paper tray.
	■ Reduce the amount of paper in the paper tray, and then try again.
	■ Make sure that manual feed mode is not chosen in the printer driver.
The printer does not feed paper	■ Fan the paper well and put it back in firmly.
from the manual feed slot.	Make sure that you have chosen the manual feed slot in the Paper Source of the printer driver.
The printer does not feed envelopes.	■ The printer can feed envelopes from the manual feed slot. You must set up your application to print on the size of envelopes you are using. This is usually done in the page setup or document setup menu of your software. (See your application manual.)
A paper jam has occurred.	■ Clear the jammed paper. (See <i>Paper jams and how to clear them</i> on page 77.)
The printer does not print.	■ Make sure that the cable is connected to the printer.
	■ Make sure that you have chosen the correct printer driver.
When printing on normal paper, it creases.	■ Change the printer driver setting in Media Type to a thin setting.
The paper slides off the top output tray.	■ Lift up the output tray support flap 1 (1).

Problem Recommendation The paper slides off the back Follow these steps: output tray. Remove the output tray support flap 1 (1) from the top of the printer by first lifting the flap up. Then push the flap to the left or right to release one of the posts (2) on the flap and pull up. 2 Attach the support flap 1 (1) to the back output tray by inserting the posts of the support flap one at a time into the holes of the back output tray.


Paper jams and how to clear them

If a paper jam occurs, the printer will flash the Error LED as shown below.



HOT SURFACE

After you have just used the printer, some internal parts of the printer will be extremely hot. To prevent injury, when you open the front cover or back cover (back output tray) of the printer, DO NOT touch the shaded parts shown in the illustration.






Clear the jammed paper as follows.

If the jammed paper is removed completely by following the steps below, you can install the paper tray first, and then close the front cover. The printer will resume printing automatically.


If the printer does not start printing automatically, press the **Go** button. If the printer still does not start printing, check that all the remaining jammed paper has been removed from the printer. Then try printing again.



- Always remove all paper from the paper tray and straighten the stack when you add new paper. This helps prevent multiple sheets of paper from feeding through the printer at one time and prevents paper jams.
- Please confirm that you have installed both a toner cartridge and a drum unit in the machine. If you have not installed a drum unit or have installed the drum unit improperly, then this may cause a paper jam in your machine.
- 1 Open the front cover.




2 Slowly take out the drum unit and toner cartridge assembly. The jammed paper will be pulled out with the drum unit and toner cartridge assembly.



CAUTION

We recommend that you put the drum unit and toner cartridge assembly on a piece of disposable paper or cloth in case you accidentally spill or scatter toner.

To prevent damage to the printer caused by static electricity, DO NOT touch the electrodes shown in the illustration.




3 Close the front cover.




Do not put the drum unit and toner cartridge assembly back in at this point.


4 Pull the paper tray completely out of the printer.




5 Pull the jammed paper down and out of the printer.




6 Open the back cover (back output tray).



7 Pull the tab toward you to open the fuser cover (1).




8 Pull the jammed paper out of the fuser unit.




HOT SURFACE

After you have just used the printer, some internal parts of the printer will be extremely hot. Wait for the printer to cool down before you touch the internal parts of the printer.



Olose the back cover (back output tray).

10 Push down the green lock lever and take the toner cartridge out of the drum unit. Clear the jammed paper if there is any inside the drum unit.




A CAUTION


Handle the toner cartridge carefully. If toner scatters on your hands or clothes, wipe or wash it off with cold water at once.

To avoid print quality problems, DO NOT touch the shaded parts shown in the illustrations.






11 Put the toner cartridge back into the drum unit until you hear it lock into place. If you put the cartridge in properly, the green lock lever will lift automatically.



12 Open the front cover. Put the drum unit and toner cartridge assembly back in the printer.



- 13 Put the paper tray firmly back in the printer.
- 14 Close the front cover.
- 15 Make sure that the Error LED is now off.

Improving the print quality


If you have a print quality problem, print a test page first (see *Print a test page* on page 47). If the printout looks good, the problem is probably not the printer. Check the interface cable or try the printer on another computer.

This section gives information on the following topics.


Examples of poor print quality	Recommendation
ABCDEFGH	■ Check the printer's environment. Conditions such as humidity, high temperatures, and so on, may cause this print fault. See <i>Positioning the printer</i> on page 4.
abcdefghijk ABCD	■ If the whole page is too light, Toner Save Mode may be on. Turn off Toner Save Mode in the printer Properties tab of the driver.
abcde 01234	■ Put in a new toner cartridge. See Replacing the toner cartridge on page 54.
01234	■ Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
Faint	■ You may clear the problem by wiping the scanner window with a soft cloth. See Cleaning the inside of the printer on page 66.
	Make sure that you use paper that meets our specifications. See About paper on page 5.
ABCDEFGH abcdefghijk ABCD	Check the printer's environment. Conditions such as high temperatures and high humidity can increase the amount of background shading. See <i>Positioning the</i> printer on page 4.
abcde 01234	■ Put in a new toner cartridge. See Replacing the toner cartridge on page 54.
01234	■ Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
Grey background	
B	■ Make sure that you use paper that meets our specifications. Rough-surfaced paper or thick print media may cause this problem. See <i>About paper</i> on page 5.
B	■ Make sure that the media type setting in the driver matches the type of paper you are using. See <i>About paper</i> on page 5.
	■ Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
В	■ The fuser unit may be contaminated. Call Ricoh Customer Service.
Ghost	
	■ Make sure that you use paper that meets our specifications. Rough-surfaced paper may cause the problem. See <i>About paper</i> on page 5.
ABCDEFGH abcdefghijk ABCD	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
abcde 01234	■ The fuser unit may be contaminated. Call Ricoh Customer Service.
Toner specks	

_	
Examples of poor print quality	Recommendation
	Make sure that you use paper that meets our specifications. See About paper on page 5.
	■ Choose Thick paper mode in the printer driver, or use thinner paper than what you are now using.
	■ Check the printer's environment. Conditions such as high humidity can cause hollow print. See <i>Positioning the printer</i> on page 4.
Hollow print	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
	■ Clean the primary corona wire inside the drum unit by sliding the blue tab. Be sure to return the blue tab to the home position (▲). See Cleaning the corona wire on page 69.
	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
	■ The fuser unit may be contaminated. Call Ricoh Customer Service.
All black	
	Make sure that you use paper that meets our specifications. A rough surfaced paper or thick print media can cause problems.
ABCDEFGH abcdefghijk	■ Make sure that you choose the correct media type in the printer driver.
A B Č D a b c d e	■ The problem may disappear by itself. Print multiple pages to clear this problem, especially if the printer has not been used for a long time.
01234	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
White lines across the page	
ADDE FOU	■ Clean the inside of the printer and the primary corona wire in the drum unit. See <i>Cleaning</i> on page 65.
ABCDEFGH abcdefghijk ABCD	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
abcde 01234	
Lines across the page	
	Make sure that a torn piece of paper is not inside the printer covering the scanner window.
ABCDEFGH abcdefghijk ABCD	■ Wipe the scanner window with a soft cloth. See Cleaning the inside of the printer on page 66.
abcde 01234	■ The toner cartridge may be damaged. Put in a new toner cartridge. See Replacing the toner cartridge on page 54.
White lines down the page	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.

Examples of poor print quality



White Spots on black text and graphics at 75 mm (2.95 in.) intervals




Black Spots at 75 mm (2.95 in.) intervals

Recommendation


■ If the problem is not solved after printing a few pages, the drum unit may have glue from a label stuck on the OPC drum surface.

Clean the drum unit as follows:


1 Put the print sample in front of the drum unit, and find the exact position of the poor print.



2 Turn the drum unit gear by hand while looking at the surface of the OPC drum (1).



When you have found the mark on the drum that matches the print sample, wipe the surface of the OPC drum with a dry cotton swab until the dust or glue on the surface comes off.



CAUTION

DO NOT clean the surface of the photosensitive drum with a sharp object.

■ The drum unit may be damaged. Put in a new drum unit. See *Replacing the drum unit* on page 61.

Examples of poor print quality	Recommendation
	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
ABCDEFGH abcdefghijk ABCD	■ The toner cartridge may be damaged. Put in a new toner cartridge. See Replacing the toner cartridge on page 54.
abcde 01234	Make sure that you use paper that meets our specifications. See About paper on page 5.
Black toner marks across the	■ If you use label sheets for laser printers, the glue from the sheets may sometimes stick to the OPC drum surface. Clean the drum unit. See page 85.
page	Do not use paper that has clips or staples because they will scratch the surface of the drum.
	If the unpacked drum unit is in direct sunlight or room light, the unit may be damaged.
	■ Clean the corona wire inside the drum unit by sliding the blue tab. See <i>Cleaning</i> the corona wire on page 69.
ABCDEFGH abcdefghijk	■ Make sure the primary corona wire cleaner is at the home position (▲).
ABCD abcde 01234	■ The drum unit may be damaged. Put in a new drum unit. See <i>Replacing the drum unit</i> on page 61.
	■ The toner cartridge may be damaged. Put in a new toner cartridge. See Replacing the toner cartridge on page 54.
Black lines down the page	■ The fuser unit may be smudged. Call your dealer or Ricoh Customer Service.
Printed pages have toner stains down the page.	
ABCDEFGH ABCDEFGH	Make sure that the paper or other print media is loaded properly in the paper tray and that the guides are not too tight or too loose against the paper stack.
ABCD	■ Set the paper guides correctly. See <i>Printing on plain paper and transparencies</i> from the paper tray on page 9.
abcde 01234	■ If you are using the manual feed slot, see <i>Printing on plain paper, bond paper or transparencies from the Manual feed slot</i> on page 13.
Page skewed	■ The paper tray may be too full. See <i>Printing on plain paper and transparencies from the paper tray</i> on page 9.
	■ Check the paper type and quality. See <i>About paper</i> on page 5.
AROPEGU	■ Check the paper type and quality. High temperatures and high humidity will cause paper to curl. See <i>About paper</i> on page 5.
ABCDEFGH abcdefghijk ABCD abcde 01234	■ If you do not use the printer often, the paper may have been in the paper tray too long. Turn over the stack of paper in the paper tray. Also, fan the paper stack and then rotate the paper 180° in the paper tray.
Curled or wavy	

Examples of poor print quality	Recommendation
ABCDEFGH abcdefghijk ABCD abcde 01234	 Make sure that the paper is loaded properly. See <i>Printing on plain paper and transparencies from the paper tray</i> on page 9. Check the paper type and quality. See <i>About paper</i> on page 5. Turn over the stack of paper in the tray or try rotating the paper 180° in the input tray.
ABCDEFGH abcdefghijk ABCD abcde 01234 Poor fixing	 Choose Improve Toner Fixing mode in the printer driver. See Improve Print Output in Advanced tab on page 30. If this selection does not provide enough improvement, select Thicker paper in Media type settings.

Examples of poor print Recommendation quality ■ Turn the paper over in the paper tray, and print again. (Excluding Letterhead paper) If the problem remains, lift up the support flaps as follows: **ABCDEFGH** 1 Lift up the output tray support flap 1 (1). abcdefghijk ABCD abcde 01234 Curled Lift up the output tray support flap 2 (2). Fold down the output tray support flap 1 (1) and fold down the output tray support flap 2 (2). ■ Choose Reduce Paper Curl mode in the printer driver when you do not use our recommended paper. See Improve Print Output in Advanced tab on page 30.

Solving print problems

Problem	Recommendation
The printer prints unexpectedly or it prints garbage data.	■ Make sure that the printer cable is not too long. We recommend that you use a USB cable that is no longer than 2 meters (6.5 feet).
	■ Make sure that the printer cable is not damaged or broken.
	■ If you are using an interface-switching device, remove it. Connect your computer directly to your printer, and then try again.
	Make sure that you have chosen the correct printer driver with 'Set as Default Printer'.
	Make sure that the printer is not connected to the same port that is also connected to a storage device or scanner. Take away all other devices and connect the port only to the printer.
	■ Turn off the Status Monitor .
The printer cannot print full pages of a document. An error message Memory Full	■ Press the Go button to print the remaining data in the printer memory. Cancel the print job if you want to delete the remaining data in the printer memory. (See <i>Go button</i> on page 46.)
appears.	■ Reduce the complexity of your document or reduce the print resolution.
The printer cannot print full pages of a document. An error message Print Overrun	■ Press the Go button to print the remaining data in the printer memory. Cancel the print job if you want to delete the remaining data in the printer memory. See <i>Go button</i> on page 46.
appears.	If this does not clear the error, reduce the complexity of your document or cut the print resolution.
	■ Change the following settings in the supplied Windows [®] driver and try again. The best combination of these settings will vary depending on your document:
	Graphics mode ¹
	• TrueType mode ¹
	• Use Printer TrueType ¹ Fonts ¹
	Choose the Advanced tab, click the Print Quality icon, and then choose Manual in Print Setting and click the Setting button.
The headers or footers appear when the document displays on the screen but they do not show up when it is printed.	Adjust the top and bottom margins of your document.

Network problems

For problems concerning using your printer on a Network, see the Network User's Guide on the CD-ROM we have supplied. Click **Documentation** on the menu screen.

The Network User's Guide in PDF format will be installed automatically when you install the driver. Click the **Start** button, **All Programs** ¹, your printer, and then User's Guide.

¹ **Programs** for Windows[®] 2000 users

Appendix

Printer specifications

Engine

Model		SP 1210N
Technology		Electrophotographic
Print speed 1	² (A4 size/ Letter size)	Up to 22 ppm (A4 size) ² ,Up to 23 ppm (Letter size) ²
Resolution	Windows [®] 2000/XP/ XP Professional x64 Edition, Windows Vista [®] , Windows [®] 7, Windows Server [®] 2003/ Windows Server [®] 2003 x64 Edition	HQ1200 600 dpi 300 dpi
	DOS	600 dpi

¹ The printing speed may change depending on the type of document you print.

Controller

Model		SP 1210N
Processor		181MHz
Memory		16 MB
Interface		USB ¹ , 10BASE-T/100BASE-TX Ethernet
Network	Protocols	TCP/IP (Standard 10/100BASE-TX Ethernet) ²
Connectivity	Management tool	BRAdmin Light
Emulation	•	PCL6
Resident fonts	PCL	49 scalable fonts, 12 bitmap fonts, 11 bar codes ³

Compatible with USB 2.0 specification

² From standard paper tray.

² See the Network User's Guide locator on the CD-ROM for details on the supported network protocols.

³ Code39, Interleaved 2 of 5, EAN-8, EAN-13, UPC-A, UPC-E, EAN-128, Codabar, FIM (US-PostNet), ISBN, Code128

Software

Model		SP 1210N
Printer driver	Windows [®]	PCL printer driver for Windows [®] 2000/XP/XP Professional x64 Edition, Windows Vista [®] , Windows Server [®] 2003/Windows Server [®] 2003 x64 Edition
Utilities		Interactive Help ¹

¹ Instructional animations for problem solving.

Control panel

Model	SP 1210N
LED	4 LEDs
Button	1 button

Paper handling

Model		SP 1210N
Paper Input ¹	Manual feed slot	1 sheet
	Paper tray	250 sheets
Paper Face-down		100 sheets ²
Output ¹ Face-up		1 sheet
Duplex		Manual Duplex

¹ Calculated with 80 g/m2 (20 lb) paper

Media specifications

Model		SP 1210N
Media types	Manual feed slot	Plain paper, Bond paper, Recycled paper, Thin paper, Thick paper, Envelopes, Labels, Transparencies
	Paper tray	Plain paper, Recycled paper, Thin paper, Transparencies ¹
Media	Manual feed slot	60 to 163 g/m ² (16 to 43 lb)
weights	Paper tray	60 to 105 g/m ² (16 to 28 lb)
Media sizes	Manual feed slot	Width: 76.2 to 220mm (3.0 to 8.66 in.) Length: 116 to 406.4 mm (4.57 to 16 in.)
	Paper tray (Standard)	A4, Letter, Legal ² , B5 (ISO), Executive, A5, A6, B6, Folio

¹ Up to 10 sheets

² For A4, LT size

Legal size paper is not available in some regions outside the USA and Canada.

Supplies

Model		SP 1210N	Order No.
Toner Cartridge Starter cartridge		Approx. 1,000 pages A4/Letter pages ¹	N/A
	Standard cartridge	Approx. 2,600 pages A4/Letter pages ¹	Print Cartridge SP 1200E (for Europe) Print Cartridge SP 1200A (USA and Canada) Print Cartridge SP 1200S (For Asia)
Drum Unit		Approx. 12,000 pages A4/Letter pages (1 page / job)	Drum Unit SP 1200

¹ Approx. cartridge yield is declared in accordance with ISO/IEC 19752.

Dimensions / weights

Model	SP 1210N
Dimensions (W \times D \times H)	$368 \times 361 \times 170.5 \text{ mm}$ (14.5 × 14.2 × 6.7 in.)
Weights	Approx. 5.8 kg (12.8 lb)

Other

Model			SP 1210N
Power consumption		Printing	Average 460 W at 25 °C (77 °F)
		Standby	Average 80 W at 25 °C (77 °F)
		Sleep	Average 7 W
Noise level Sound Pressure		Printing	51 dB (A)
	Standby	30 dB (A)	
Sound power		Printing	LWAd = 6.7 Bell (A)
		Standby	LWAd = 4.5 Bell (A)
Ecology	Power save		Yes
Toner save ¹			Yes

We do not recommend Toner Save Mode for printing Photo or Greyscale images.

Computer requirements

Computer Platform & Operating System Version		Processor Minimum Speed	Minimum RAM	Recommended RAM	Hard Disk Space to install
Windows [®] Operating	Windows [®] 2000 Professional	Intel [®] Pentium [®] II or equivalent	64 MB		
System	Windows® XP Home Edition		128 MB	256 MB	
	Windows [®] XP Professional		120 IVID		
	Windows [®] XP Professional x64 Edition	64-bit (Intel [®] 64 or AMD64) supported CPU	256 MB	512 MB	
	Windows Vista [®]	Intel [®] Pentium [®] 4 or equivalent 64-bit (Intel [®] 64 or AMD64) supported CPU	512 MB	1 GB	50 MB
	Windows Server [®] 2003	Intel [®] Pentium [®] III or equivalent	256 MD	512 MB	
	Windows Server [®] 2003 x64 Edition	64-bit (Intel [®] 64 or AMD64) supported CPU	- 256 MB	S IZ IVID	
Windows [®] 7	Windows [®] 7	Intel [®] Pentium [®] 4 or equivalent 64-bit (Intel [®] 64 or AMD64) supported	1GB (32-bit)	1GB (32-bit)	
		CPU	2GB (64-bit)	2GB (64-bit)	

Important information for choosing your paper

This section gives information to help you choose paper to use with this printer.



If you use paper that is not recommended, a paper jam or misfeed may occur in the printer. (See *Recommended paper* on page 6.)

Before you buy a large quantity of paper

Make sure that the paper is suitable for the printer.

Paper for plain paper copies

Paper is divided by usage, such as paper for printing and paper for copying. The usage is usually written on the paper's package. Check the package to see whether it is suitable for laser printers. Use paper that is suitable for laser printers.

Basis weight

The basis weight of the paper in general use varies in different countries. We recommend that you use paper that weighs 75 to 90 g/m² (20 to 24 lb), although this printer is able to cope with thinner or thicker paper than these weights.

Unit	Europe	USA
g/m ²	80 to 90	75 to 90
lb		20 to 24

Long grain and short grain

The pulp fiber of the paper is aligned during paper manufacturing. Paper can be classified into two types, long grain and short grain.

Long grain paper fibers run in the same direction as the long edge of the paper. Short grain paper fibers run perpendicular to the long edge of the paper. Though most plain paper for copying is long grain, some is short grain. We recommend that you use long grain paper for this printer. Short grain paper is too weak for the paper transport of the printer.

Acid paper and neutralized paper

Paper can be classified as either acid paper or neutralized paper.

Though modern paper manufacture methods started with acid paper, neutralized paper is recently taking the place of acid paper because of environmental issues.

However, many forms of acid paper can be found in recycled paper. We recommend that you use neutralized paper for this printer.

You can use an acid paper check pen to distinguish acid paper from neutral paper.

Print surface

The characteristics of the face side and reverse side of a sheet of paper may vary a little.

Usually, the opening side of the paper ream package is the print side. Follow the indications on the paper package. Typically, the print side is indicated by an arrow.

Moisture content

Moisture content is the amount of water left in the paper after manufacture. It is one of the important characteristics of the paper. This can change greatly depending on the storage environment, although usually paper contains about 5% water by weight. Because paper often absorbs water, the amount of water can sometimes be about 10% in a high humidity environment. When the amount of water increases, the characteristics of the paper changes greatly. The fixing of the toner may become worse. For storage of the paper and during use, we recommend that the humidity of the surrounding environment be between 50% and 60%.

Rough estimate of basis weight

g/m ²	lb	lb		
	Bond	Index		
60	16			
64	17			
75	20			
90	24			
105	28			
120	32			
135	36			
161	43	90		

Paper size

Paper size	mm	in.
Letter		8.5 × 11 in.
Legal		8.5 × 14 in.
Executive		7.25 × 10.5 in.
A4	210 × 297 mm	
A5	148 × 210 mm	
A5 Long Edge	210 × 148 mm	
A6	105 × 148 mm	
Envelope Monarch		3.875 × 7.5 in.
Envelope Com-10		4.12 × 9.5 in.
Envelope DL	110 × 220 mm	
Envelope C5	162 × 229 mm	
B5 (JIS)	182 × 257 mm	
B5 (ISO)	176 × 250 mm	
B6 (ISO)	125 × 176 mm	
Folio		8.5 × 13 in.
Post Card	100 × 148 mm	
A4 Long	210 × 405 mm	
Envelope DL-L	220 × 110 mm	
3×5		3 × 5 in.

Symbol and character sets

For the HP LaserJet emulation modes, you can choose the symbol and character sets using Web Based Management (Web browser) when connected to a network or the control panel buttons.

How to use Web Based Management (web browser)

To use Web Based Management (Web browser), follow the steps below.



We recommend Microsoft Internet Explorer 6.0[®] (or greater) or Firefox[®] 1.0 (or greater). Please also make sure that JavaScript and cookies are always enabled in whichever browser you use. We recommend you upgrade to SafariTM 1.2 or greater to enable JavaScript. To use a web browser, you will need to know the IP address of the print server.

- 1 Start your web browser.
- 2 Type http://printer_ip_address/ into your browser. (Where printer_ip_address is the IP address or the node name)
 - For example:

http://192.168.1.2/ (if the printer's IP address is 192.168.1.2.)



If you have edited the hosts file on your computer or are using a Domain Name System, you can also enter the DNS name of the print server. As the print server supports TCP/IP and NetBIOS, you can also enter the NetBIOS name of the print server. The NetBIOS name can be seen on the printer settings page. The NetBIOS name assigned is the first 15 characters of the node name and by default it will appear as "RNPxxxxxxxxxxx" for a wired network.

- 3 Click Printer Settings.
- 4 Enter a user name and a password.



The login name for the Administrator is "admin" (case sensitive) and the default password is "access".

- 5 Click **OK**.
- 6 Choose the **HP LaserJet** tab and click **Font Setup**. Choose a symbol set you want to use from the **Symbol Set** list box.

Symbol and character sets list

OCR symbol sets

When you choose the OCR-A or OCR-B font, the matching symbol set is always used.

OCR A (00)

OCR B (10)

HP LaserJet mode

ABICOMP Brazil / Portugal (13P)

ABICOMP International (14P)

 Desktop (7J)
 Greek8 (8G)

 HP German (0G)
 HP Spanish (1S)

 ISO Latin1 (0N)
 ISO Latin2 (2N)

 ISO Latin5 (5N)
 ISO Latin6 (6N)

 ISO2 IRV (2U)
 ISO4 UK (1E)

ISO2 IRV (20)

ISO3 ASCII (0U)

ISO10 Swedish (3S)

ISO11 Swedish (0S)

ISO14 JIS ASCII (0K)

ISO15 Italian (0I)

ISO16 Portuguese (4S)

ISO21 German (1G)

ISO25 French (0F)

ISO57 Chinese (2K)

ISO60 Norwegian1 (0D)

ISO61 Norwegian2 (1D)

ISO69 French (1F) ISO84 Portuguese (5S)
ISO85 Spanish (6S) ISO8859 / 7 Latin / Greek (12N)

ISO8859 / 15 Latin (9N) ISO8859 / 15 Latin / Cyrillic (10N)

Legal (1U) Math-8 (8M)
MC Text (12J) MS Publishing (6J)
PC8 (10U) PC8 Bulgarian (13R)

PC8 D/N (11U) PC8 Greek Alternate (437G) (14G)

PC8 Latin / Greek (12G) PC8 PC Nova (27Q)

PC8 Turkish (9T) PC775 (26U)

PC850 Multilingual (12U) PC851 Greece (10G)

PC852 East Europe (17U) PC853 Latin3 (Turkish) (18U)
PC855 Cyrillic (10R) PC857 Latin5 (Turkish) (16U)

PC858 Multilingual Euro (13U) PC860 Portugal (20U)

PC861 Iceland (21U) PC863 Canadian French (23U)

PC865 Nordic (25U) PC866 Cyrillic (3R)

PC869 Greece (11G) PC1004 (9J)
Pi Font (15U) PS Math (5M)
PS Text (10J) Roman8 (8U)

Roman9 (4U) Roman Extension (0E)

Russian-GOST (12R) Symbol (19M)

Quick reference for bar code control commands

The printer can print bar codes in the HP LaserJet emulation modes.

Print bar codes or expanded characters

 Code
 ESC i

 Dec
 27 105

 Hex
 1B 69

Format: ESC i n ... n \

Creates bar codes or expanded characters according to the segment of parameters 'n ... n'. For more information about parameters, see the following Definition of Parameters. This command must end with the '\' code (5CH).

Definition of parameters

This bar code command can have the following parameters in the parameter segment (n ... n). As parameters are effective within the single command syntax ESC i n ... n \, they do not apply in the bar code commands. If certain parameters are not given, they take the preset settings. The last parameter must be the bar code data start ('b' or 'B') or the expanded character data start ('l' or 'L'). Other parameters can be given in any sequence. Each parameter can start with a lower-case or upper-case character, for example, 't0' or 'T0', 's3' or 'S3' and so one.

Bar code mode

n = 't0' or 'T0'	CODE 39 (default)	
n = 't1' or 'T1'	Interleaved 2 of 5	
n = 't3' or 'T3'	FIM (US-Post Net)	
n = 't4' or 'T4'	Post Net (US-Post Net)	
n = 't5' or 'T5'	EAN 8, EAN 13, or UPC A	
n = 't6' or 'T6'	UPC E	
n = 't9' or 'T9'	Codabar	
n = 't12' or 'T12'	Code 128 set A	
n = 't13' or 'T13'	Code 128 set B	
n = 't14' or 'T14'	Code 128 set C	
n = 't130' or 'T130'	ISBN (EAN)	
n = 't131' or 'T131'	ISBN (UPC-E)	
n = 't132' or 'T132'	EAN 128 set A	
n = 't133' or 'T133'	EAN 128 set B	
n = 't134' or 'T134'	EAN 128 set C	

This parameter selects the bar code mode as shown above. When n is 't5' or 'T5' the bar code mode (EAN 8, EAN 13, or UPC A) varies according to the number of characters in the data.

Bar code, expanded character, line block drawing and box drawing

n = 's0' or 'S0' 3: 1 (default)

n = 's1' or 'S1' 2: 1 n = 's3' or 'S3' 2.5: 1

This parameter chooses the bar code style as above. When the EAN 8, EAN 13, UPC-A, Code 128 or EAN 128 bar code mode is chosen, this bar code style parameter is ignored.

Expanded Character

'S'

0 = White

1 = Black

2 = Vertical stripes

3 = Horizontal stripes

4 = Cross hatch

For example 'S' n1 n2

n1 = Background fill pattern

n2 = Foreground fill pattern

If 'S' is followed by only one parameter, the parameter is a foreground fill pattern.

Line block drawing & box drawing

'S'

1 = Black

2 = Vertical stripes

3 = Horizontal stripes

4 = Cross hatch

Bar code

 $n = 'mnnn' or 'Mnnn' (nnn = 0 \sim 32767)$

This parameter shows the bar code width. The unit of 'nnn' is a percentage.

Bar code human readable line ON or OFF

n = 'r0' or 'R0 Human readable line OFF n = 'r1' or 'R1 Human readable line ON

Preset: Human readable line ON

(1) 'T5' or 't5' (2) 'T6' or 't6'

(3) 'T130' or 't130' (4) 'T131' or 't131'

Preset: Human readable line OFF

All others

This parameter shows whether the printer prints the human readable line below the bar code. Human readable characters are always printed with OCR-B font of 10 pitch and all the current character style enhancements are masked. The default setting is determined by the bar code mode selected by 't' or 'T'.

Quiet zone

 $n = \text{'onnn'} \text{ or 'Onnn'} \text{ (nnn = 0 } \sim 32767)$

Quiet zone is the space on both sides of the bar codes. Its width can be shown using the units that are set by the 'u' or 'U' parameter. (For the description of 'u' or 'U' parameter, see the next section.) The default setting of the quiet-zone width is 1 inch.

Bar code, expanded character unit, line block drawing and box drawing

n = 'u0' or 'U0'	mm (preset)
n = 'u1' or 'U1'	1/10
n = 'u2' or 'U2'	1/100
n = 'u3' or 'U3'	1/12
n = 'u4' or 'U4'	1/120
n = 'u5' or 'U5'	1/10 mm
n = 'u6' or 'U6'	1/300
n = 'u7' or 'U7'	1/720

This parameter shows the measurement units of X-axis offset, Y-axis offset, and bar code height.

Bar code, expanded character, line block drawing and box drawing offset in X-axis

n = 'xnnn' or 'Xnnn'

This parameter shows the offset from the left margin in the 'u'- or 'U'-specified unit.

Bar code & expanded character offset in Y-axis

n = 'ynnn' or 'Ynnn'

This parameter shows the downward offset from the current print position in the 'u'- or 'U'-specified unit.

Bar code, expanded character, line block drawing and box drawing height

n = 'hnnn', 'Hnnn', 'dnnn', or 'Dnnn'

1 EAN13, EAN8, UPC-A, ISBN (EAN13, EAN8, UPC-A), ISBN (UPC-E): 22 mm

2 UPC-E: 18 mm

3 Others: 12 mm

Expanded characters → 2.2 mm (preset)

Line block drawing and box drawing → 1 dot

This parameter shows the height of bar codes or expanded characters as shown above. It can start with 'h', 'H', 'd', or 'D'. The height of bar codes is shown in the 'u'- or 'U'-specified unit. The default setting of the bar code height (12 mm, 18 mm or 22 mm) is determined by the bar code mode selected by 't' or 'T'.

Expanded character width, line block drawing and box drawing

n = 'wnnn' or 'Wnnn'

Expanded character → 1.2 mm

Line block drawing and box drawing → 1 dot

This parameter shows the width of expanded characters as shown above.

Expanded character rotation

n = 'a0' or 'A0'	'Upright (preset)
n = 'a1' or 'A1'	'Rotated 90 degrees
n = 'a2' or 'A2'	'Upside down, rotated 180 degrees
n = 'a3' or 'A3'	'Rotated 270 degrees

Bar code data start

n = 'b' or 'B'

Data that follows 'b' or 'B' is read in as bar code data. Bar code data must end with the '\' code (5CH), which also ends this command. The acceptable bar code data is determined by the bar code mode selected by 't' or 'T'.

■ When CODE 39 is chosen with the parameter 't0' or 'T0'

Forty three characters '0' to '9', 'A' to 'Z', '-', '.', '(space)', '\$', '/', '+', and '%' can be accepted as bar code data. Other characters will cause a data error. The number of characters for bar codes is not limited. The bar code data automatically starts and ends with an asterisk '*' (start character and stop character). If the received data has an asterisk '*' at the beginning or end, the asterisk is regarded as a start character or stop character.

■ When Interleaved 2 of 5 is selected with the parameter 't1' or 'T1':

Ten numerical characters '0' to '9' can be accepted as bar code data. Other characters cause a data error. The number of characters for bar codes is not limited. This mode of bar codes needs even characters. If the bar code data has odd characters, '0' is automatically added to the end of the bar code data.

■ When FIM (US-Post Net) is selected with the parameter 't3' or 'T3'

Characters 'A' to 'D' are valid and one digit of data can be printed. Upper-case and lower-case alphabet characters can be accepted.

■ When Post Net (US-Post Net) is selected with the parameter 't4' or 'T4'

Numbers '0' to '9' can be data and it must end with a check digit. '?' can be used instead of the check digit.

■ When EAN 8, EAN 13, or UPC A is selected with the parameter 't5' or 'T5'

Ten numbers '0' to '9' can be accepted as bar code data. The number of characters for bar codes is limited as follows:

EAN 8: Total 8 digits (7 digits + 1 check digit)

EAN 13: Total 13 digits (12 digits + 1 check digit)

UPC A: Total 12 digits (11 digits + 1 check digit)

A number of characters other than those stated above will cause a data error that results in the bar code data being printed as normal print data. If the check digit is not correct, the printer decides the correct check digit automatically so that the correct bar code data will be printed. When EAN13 is selected, adding '+' and a two-digit or five-digit number after the data can create an add-on code.

■ When UPC-E is selected with the parameter 't6' or 'T6':

The numbers '0' to '9' can be accepted as bar code data.

Eight digits ^{1 2} (standard format) The first character must be '0' and the data must end with a check digit.

Total eight digits = '0' plus 6 digits plus 1 check digit.

Six digits ² The first character and the last check digit are removed from the eight digit data.

- 1 '?' can be used instead of a check digit.
- ² Adding '+' and two-digit or five-digit number after the data creates an add-on code.
- When Codebar is chosen with the parameter 't9' or 'T9'

Characters '0' to '9', '-', '.', '\$', '/', '+', ':' can be printed. Characters 'A' to 'D' can be printed as a start-stop code, which can be upper case or lower case. If there is no start-stop code, errors will happen. A check digit cannot be added and using '?' causes errors.

■ When Code 128 Set A, Set B, or Set C is selected with the parameter 't12' or 'T12', 't13' or 'T13', or 't14' or 'T14'

Code 128 sets A, B and C can be individually selected. Set A shows characters Hex 00 to 5F. Set B includes characters Hex 20 to 7F. Set C includes the pairs 00 to 99. Switching is allowed between the code sets by sending %A, %B, or %C. FNC 1, 2, 3, and 4 are produced with %1, %2, %3, and %4. The SHIFT code, %S, allows temporary switching (for one character only) from set A to set B and vice versa. The '%' character can be encoded by sending it twice.

■ When ISBN (EAN) is selected with the parameter 't130' or 'T130'

The same rules apply as for 't5' or 'T5'.

- When ISBN (UPC-E) is selected with the parameter 't131' or 'T131': The same rules apply as for 't6' or 'T6'.
- When EAN 128 set A, set B or set C is selected with the parameter 't132' or 'T132', 't133' or 'T133' or 't134' or 'T134'

The same rules apply as for 't12' or 'T12', 't13' or 'T13', or 't14' or 'T14'.

Box drawing

```
ESC i ... E (or e)
'E' or 'e' is a terminator.
```

Line block drawing

```
ESC i ... V (or v)

'V' or 'v' is a terminator.
```

V OI V IS a terminator.

Expanded character data start

```
n = 'l' \text{ or 'L'}
```

Data that follows 'I' or 'L' is read as expanded character data (or labeling data). Expanded character data must end with the '\' code (5CH), which also ends this command.

Example Program Listings

```
WIDTH "LPT1:",255
'CODE 39
LPRINT CHR$(27); "it0r1s0o0x00y00bCODE39?\";
'Interleaved 2 of 5
LPRINT CHR$(27); "it1r1s0o0x00y20b123456?\";
'FIM
LPRINT CHR$(27); "it3r1o0x00y40bA\";
'Post Net
LPRINT CHR$(27); "it4r1o0x00y60b1234567890?\";
'EAN-8
LPRINT CHR$(27); "it5r1o0x00y70b1234567?\";
'UPC-A
LPRINT CHR$(27); "it5r1o0x50y70b12345678901?\";
'EAN-13
LPRINT CHR$(27); "it5r1o0x100y70b123456789012?\";
'UPC-E
LPRINT CHR$(27); "it6r1o0x150y70b0123456?\";
```

```
'Codabar
LPRINT CHR$(27);"it9rls0o0x00y100bA123456A\";
'Code 128 set A
LPRINT CHR$(27);"it12rlo0x00y120bCODE128A12345?\";
'Code 128 set B
LPRINT CHR$(27);"it13rlo0x00y140bCODE128B12345?\";
'Code 128 set C
LPRINT CHR$(27);"it14rlo0x00y160b";CHR$(1);CHR$(2);"?\";
'ISBN(EAN)
LPRINTCHR$(27);"it130rlo0x00y180b123456789012?+12345\";
'EAN 128 set A
LPRINT CHR$(27);"it132rlo0x00y210b1234567890?\";
LPRINT CHR$(12)
END
```

Appendix (for Europe and Other Countries)

Important information: regulations

Radio interference (220 to 240 volt model only)

This printer follows EN55022 (CISPR Publication 22)/Class B.

IEC 60825-1:2007 specification (220 to 240 volt model only)

This printer is a Class 1 laser product as defined in IEC 60825-1:2007 specifications. The label shown below is attached in countries where it is needed.



This printer has a Class 3B laser diode which produces invisible laser radiation in the laser unit. You should not open the laser unit under any circumstances.



Caution

Use of controls or adjustments or performance of procedures other than those specified in this User's Guide may result in hazardous invisible radiation exposure.

For Finland and Sweden

LUOKAN 1 LASERLAITE KLASS 1 LASER APPARAT



• Varoitus!

Laitteen käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.



Varning

Om apparaten används på annat sätt än i denna Bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.

Internal laser radiation

Maximum radiation power: 10 mW

780 - 800 nm Wave length: Class 3B Laser class:

EU Directive 2002/96/EC and EN50419



(European Union only)

This equipment is marked with the above recycling symbol. It means that at the end of the life of the equipment you must dispose of it separately at an appropriate collection point and not place it in the normal domestic unsorted waste stream. This will benefit the environment for all. (European Union only)

E

IMPORTANT - for your safety

To ensure safe operation, the supplied three-pin plug must be inserted only into a standard three-pin power outlet that is properly grounded through the standard electrical wiring.

Extension cords used with this printer must be three-pin plug type and correctly wired to provide grounding. Incorrectly wired extension cords may cause personal injury and equipment damage.

The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, call a qualified electrician.

This product should be connected to an AC power source within the range indicated on the rating label. DO NOT connect it to a DC power source. If you are not sure, contact a qualified electrician.

Disconnect device

You must install this printer near a power outlet that is easily accessible. In case of an emergency, you must disconnect the power cord from the power outlet to shut off the power completely.

Caution for LAN connection

Connect this product to a LAN connection that is not subjected to overvoltages.

IT power system (For Norway only)

This product is also designed for an IT power system with phase-to-phase voltage 230V.

Wiring information (for UK)

Important

If you need to replace the plug fuse, fit a fuse that is approved by ASTA to BS1362 with the same rating as the original fuse.

Always replace the fuse cover. Never use a plug that does not have a cover.

Warning - This printer must be earthed.

The wires in the mains lead are coloured in line with the following code:

■ Green and Yellow: Earth

■ Blue: Neutral■ Brown: Live

If in any doubt, call a qualified electrician.

Maschinenlärminformations- Verordnung 3. GPSGV (For Germany only)

Der höchste Schalldruckpegel beträgt 70 dB(A) oder weniger gemäß EN ISO 7779.



Appendix (for USA and Canada)

Important information: regulations

Federal Communications Commission (FCC) Declaration of Conformity (USA only)

Responsible Party: Ricoh Americas Corporation

Address: 5 Dedrick Place, West Caldwell, NJ 07006 USA

Telephone number: 973-882-2000

declares, that the products

Product Name: Laser Printer
Model Number: SP 1210N

complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada Qualification Statement (Canada only)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

International ENERGY STAR® Qualification Statement

The purpose of the International ENERGY STAR[®] Program is to promote the development and popularization of energy-efficient office equipment. As an ENERGY STAR[®] Partner, Ricoh Company., Ltd. has determined that this product meets the ENERGY STAR[®] guidelines for energy efficiency.



Important Information for Australia

IMPORTANT-For Your Safety

To ensure safe operation the three-pin plug supplied must be inserted only into a standard three-pin power point which is effectively grounded through the normal household wiring.

Extension cords used with the equipment must be three-conductor and be correctly wired to provide connection to ground. Incorrectly wired extension cords are a major cause of fatalities.

The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, consult a qualified electrician.

Important safety instructions

- 1 Read all of these instructions.
- 2 Save them for later reference.
- 3 Follow all warnings and instructions marked on the product.
- 4 Unplug this product from the wall socket before cleaning the outside of the machine and the scanner glass. DO NOT use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 5 DO NOT use this product near water.
- 6 DO NOT place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
- 7 Slots and openings in the casing at the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heater. This product should never be placed in a built-in installation unless adequate ventilation is provided.
- 8 This product should be connected to an AC power source within the range indicated on the rating label. DO NOT connect it to a DC power source or inverter. If you are not sure, contact a qualified electrician.
- 9 This product is equipped with a 3-wire grounded plug, a plug having a third (grounded) pin. This plug will only fit into a grounded power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, call your electrician to replace your obsolete outlet. DO NOT defeat the purpose of the grounded plug.
- 10 DO NOT place anything on top of the power cord including this machine. DO NOT allow the power cord to be stepped on.
- 11 DO NOT touch a document during printing.
- 12 Never push objects of any kind into this product through cabinet slots, since they may touch dangerous voltage points or short out parts resulting in a risk of fire or electric shock. Never spill liquid of any kind on the product.
- 13 DO NOT attempt to service this product yourself, because opening or removing covers may expose you to dangerous voltage points and/or other risks. Refer all servicing to service personnel.

- 14 Wait until pages have exited the machine before picking them up.
- 15 Unplug this product from the wall outlet and refer servicing to Authorised Service Personnel under the following conditions:
 - When the power cord is damaged or frayed.
 - If liquid has been spilled into the product.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions. Incorrect adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
 - If the product has been dropped or the casing has been damaged.
 - If the product exhibits a distinct change in performance, indicating a need for service.

Important Information for Some Countries

Important Safety Instructions

- 1 Read all of these instructions.
- 2 Save them for later reference.
- 3 Follow all warnings and instructions marked on the product.
- 4 Unplug this product from the wall outlet before cleaning the outside of the machine and the scanner glass. DO NOT use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 5 DO NOT place this product near water.
- 6 DO NOT place this product on an unstable cart, stand, or table. The product may drop, causing serious damage to the product.
- 7 Slots and openings in the casing at the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or on a radiator or heater. This product should never be placed in a built-in installation unless adequate ventilation is provided.
- 8 This product should be connected to an AC power source within the range indicated on the rating label. DO NOT connect it to a DC power source or inverter. If you are not sure, contact a qualified electrician.
- 9 This product is equipped with a 2-wire grounding type plug or a 3-wire grounding type plug (Only for Singapore, Malaysia, Hong Kong and India), a plug having two or three pins. This plug will only fit into only a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. DO NOT defeat the purpose of the grounding-type plug.
- 10 DO NOT place anything on top of the power cord including this machine. DO NOT allow the power cord to be stepped on.
- 11 If an extension cord is used with this product, make sure that the total ampere ratings on the products plugged into the extension cord DO NOT exceed the extension cord ampere rating.
- 12 DO NOT touch a document during printing.
- 13 Never push objects of any kind into this product through cabinet slots, since they may touch dangerous voltage points or short out parts resulting in the risk of fire or electric shock. Never spill liquid of any kind on the product.
- 14 DO NOT attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points and/or other risks, and may void your warranty. Please refer all servicing to our Authorized Service Personnel.
- 15 Unplug this product from the wall outlet and refer servicing to Authorized Service Personnel under the following conditions:
 - If the power cord is damaged or frayed.
 - If the product has been spilled by liquid.
 - If the product has been exposed to rain or water.

- If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions. Incorrect adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- If the product has been dropped or the casing has been damaged.
- If the product exhibits a distinct change in performance, indicating a need for service.
- 16 To protect your product against power surges, we recommend the use of a power protection device (Surge Protector).



WARNING

For protection against the risk of electrical shock, always disconnect all cables from the wall outlet before servicing, modifying or installing the equipment.

Ricoh cannot accept any financial or other responsibilities that may be the result of your use of this information, including direct, special or consequential damages. There are no warranties extended or granted by this document.

Laser notices

Laser safety (110 to 120 volt model only)

This printer is certified as a Class 1 laser product under the U.S. Department of Health and Human Services (DHHS) Radiation Performance Standard according to the Radiation Control for Health and Safety Act of 1968. This means that the printer does not produce hazardous laser radiation.

Since radiation emitted inside the printer is completely confined within protective housings and external covers, the laser beam cannot escape from the machine during any phase of user operation.

FDA regulations (110 to 120 volt model only)

The U.S. Food and Drug Administration (FDA) has implemented regulations for laser products manufactured on and after August 2, 1976. Compliance is mandatory for products marketed in the United States. The following label on the back of the printer indicates compliance with the FDA regulations and must be attached to laser products marketed in the United States.

MANUFACTURED:

RICOH COMPANY LTD, 3-6, Naka-magome 1-Chome Ohta-ku, Tokyo 143-8555, Japan

Complies with FDA performance standards for laser products except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.



Use of controls, adjustments or performance of procedures other than those specified in this User's Guide may result in hazardous invisible radiation exposure.

Internal laser radiation

Maximum radiation power: 10 mW

Wave length: 780 - 800 nm Laser class: Class 3B

IMPORTANT - for your safety

To ensure safe operation, the supplied three-pin plug must be inserted only into a standard three-pin power outlet that is properly grounded through the standard electrical wiring.

Extension cords used with this printer must be three-pin plug type and correctly wired to provide proper grounding. Incorrectly wired extension cords may cause personal injury and equipment damage.

The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, call a qualified electrician.

This product should be connected to an AC power source within the range indicated on the rating label. DO NOT connect it to a DC power source. If you are not sure, contact a qualified electrician.

Disconnect device

You must install this printer near a power outlet that is easily accessible. In case of an emergency, you must disconnect the AC power cord from the AC power outlet to shut off the power completely.

Caution for LAN connection

Connect this product to a LAN connection that is not subjected to overvoltages.

Index

A		J	
Automatic Interface Selection	38	Job cancel	46
В		L	
Bar code control		LEDs	39
BRAdmin Light	38		
С		M	
		Manual feed slot	
Carton contents		manual feed slot	
Cartridge position error		Media specifications	
Character sets		Media type	
Cleaning		Memory	
Computer requirements	94	Memory full	42
Consumables	52		
Control panel	39, 92	N	
Corona wire59,	69, 70		
Cover open	42	Network	38
		Network connectivity	91
D		Network default setting	50
		No paper	42
Device options	32		
Dimensions	93	0	
Domain	98		
Drum error	43	OPC drum	85
Drum life end soon	42		
Drum unit	60	P	
Duplex printing			
		Paper	5, 95
E		Paper handling	92
		Paper jams	
Emulation	91	PCL printer driver	
Envelopes	7, 17	Plain paper	
Error messages		Power supply	
3.1.0	,	Print overrun	
F		Print quality	
•		Print test page	
Fonts	49. 91	Printer driver	
	, , ,	Printer settings	
G		Processor	
Go buttons	46	R	
l e		Reprint	33, 46
Interface	91	S	
		Scanner window	
		Service call	44

SoftwareSpecifications	
Status Monitor	
Symbol	
т	
Toner cartridge	53
Toner life end	41, 54
Toner low Trademarks	41
	٠١
Tray Setting tab	35
Troubleshooting	71
U	
Unprintable area	8
Utilities	92
W	
Watermark	31
Weights	
Windows [®]	27
=	

This machine is approved for use in the country of purchase only.	