

Operating Instructions Software Guide



1	Preparing for Printing
2	Setting Up the Printer Driver
3	Other Print Operations
4	Using Paper Types that have Unique Names
5	Making Printer Settings Using the Control Panel
6	Monitoring and Configuring the Printer
7	Using a Printer Server
8	Special Operations under Windows
9	Mac OS Configuration
10	Appendix

Read this manual carefully before you use this machine and keep it handy for future reference. For safe and correct use, be sure to read the Safety Information before using the machine.

Introduction

This manual contains detailed instructions and notes on the operation and use of this machine. For your safety and benefit, read this manual carefully before using the machine. Keep this manual in a handy place for quick reference.

Do not copy or print any item for which reproduction is prohibited by law.

Copying or printing the following items is generally prohibited by local law:

bank notes, revenue stamps, bonds, stock certificates, bank drafts, checks, passports, driver's licenses.

The preceding list is meant as a guide only and is not inclusive. We assume no responsibility for its completeness or accuracy. If you have any questions concerning the legality of copying or printing certain items, consult with your legal advisor.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

For good print quality, the supplier recommends that you use genuine print cartridges from the supplier.

The supplier shall not be responsible for any damage or expense that might result from the use of parts other than genuine parts from the supplier with your office products.

Trademarks

Microsoft, Windows and Windows NT are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe[®], PostScript[®], Acrobat[®], PageMaker[®] and Adobe Type Manager are registered trademarks of Adobe Systems Incorporated.

 $\mathsf{PCL}^{\circledast}$ is a registered trademark of Hewlett-Packard Company.

Apple, AppleTalk, EtherTalk, Macintosh, Mac OS, and True Type are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

IPS-PRINT Printer Language Emulation Copyright[©] 1999-2000 Oak Technology, Inc., All rights reserved.

NetWare is a registered trademark of Novell, Inc.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

- * The product name of Windows[®] 95 is MicrosoftR Windows[®] 95.
- * The product name of Windows[®] 98 is MicrosoftR Windows[®] 98.
- * The product name of Windows[®] Me is MicrosoftR Windows[®] Millennium Edition (Windows Me).
- * The product names of Windows[®] 2000 are as follows: Microsoft[®] Windows[®] 2000 Professional Microsoft[®] Windows[®] 2000 Server Microsoft[®] Windows[®] 2000 Advanced Server
- * The product names of Windows[®] XP are as follows: Microsoft[®] Windows[®] XP Home Edition Microsoft[®] Windows[®] XP Professional
- * The product names of Windows Server[®] 2003 are as follows: Microsoft[®] Windows Server[®] 2003 Standard Edition Microsoft[®] Windows Server[®] 2003 Enterprise Edition Microsoft[®] Windows Server[®] 2003 Web Edition
- * The product names of Windows Server[®] 2003 R2 are as follows: Microsoft[®] Windows Server[®] 2003 R2 Standard Edition Microsoft[®] Windows Server[®] 2003 R2 Enterprise Edition Microsoft[®] Windows Server[®] 2003 R2 Web Edition
- * The product names of Windows NT[®] 4.0 are as follows: Microsoft[®] Windows NT[®] Workstation 4.0 Microsoft[®] Windows NT[®] Server 4.0

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

TABLE OF CONTENTS

Manuals for This Printer	10
How to Read This Manual	11
Symbols	11
Description for the Specified Model	12
Using Keys	13
1. Preparing for Printing	
Quick Install	15
Confirming the Connection Method	17
Network Connection	17
Local Connection	19
Using the SmartDeviceMonitor Port	21
Installing DeskTopBinder-SmartDeviceMonitor for Client	21
Installing the PCL or RPCS Printer Driver (TCP/IP)	22
Installing the PCL or RPCS Printer Driver (IPP)	23
Installing the PostScript 3 Printer Driver (Windows 95/98/Me - TCP/IP)	25
Installing the PostScript 3 Printer Driver (Windows 95/98/Me - IPP)	26
Installing the PostScript 3 Printer Driver (Windows 2000 - TCP/IP)	28
Installing the PostScript 3 Printer Driver (Windows 2000 - IPP)	29
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2 - TCP/IF 30	')
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2 - IPP)	31
Changing the Port Settings for SmartDeviceMonitor for Client	33
Using the Standard TCP/IP Port	35
Installing the PCL or RPCS Printer Driver	35
Installing the PostScript 3 Printer Driver (Windows 2000)	36
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)	37
Using the LPR Port	39
Installing the PCL or RPCS Printer Driver	39
Installing the PostScript 3 Printer Driver (Windows 2000)	40
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)	41
Using as the Windows Network Printer	43
Installing the PCL or RPCS Printer Driver	43
Installing the PostScript 3 Printer Driver (Windows 95/98/Me)	44

Installing the PostScript 3 Printer Driver (Windows 2000)	45
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)	46
Using as the NetWare Print Server/Remote Printer	48
When using the PostScript 3 Printer Driver	49
Form Feed	50
Banner Page	50
Printing after Resetting the Printer	50
Installing the Printer Driver Using USB	51
Windows Me - USB	51
Windows 2000 - USB	53
Windows XP, Windows Server 2003/2003 R2 - USB	54
Troubleshooting USB	55
Printing with Parallel Connection	56
Installing the PCL or RPCS Printer Driver	56
Installing the PostScript 3 Printer Driver (Windows 95/98/Me)	57
Installing the PostScript 3 Printer Driver (Windows 2000)	58
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)	59
Having Problems Installing the Printer Driver from the CD-ROM	60
Making Option Settings for the Printer	62
Conditions for Bidirectional Communication	62
If Bidirectional Communication is Disabled	63
Memory Capacity and Paper Size	64
2. Setting Up the Printer Driver	
PCL - Accessing the Printer Properties	
Windows 95/98/Me - Accessing the Printer Properties	67
Windows 2000 - Accessing the Printer Properties	68
Windows XP, Windows Server 2003/2003 R2 - Accessing the Printer Properties	69
Windows NT 4.0 - Accessing the Printer Properties	71
RPCS - Accessing the Printer Properties	74
Windows 95/98/Me - Accessing the Printer Properties	74
Windows 2000 - Accessing the Printer Properties	
Windows XP, Windows Server 2003/2003 R2 - Accessing the Printer Properties	77
Windows NT 4.0 - Accessing the Printer Properties	78

PostScript 3 - Setting Up for Printing	81
Windows 95/98/Me - Accessing the Printer Properties	81
Windows 2000 - Accessing the Printer Properties	82
Windows XP, Windows Server 2003/2003 R2 - Accessing the Printer Properties	83
Windows NT 4.0 - Accessing the Printer Properties	85
Mac OS - Setting Up for Printing	87
3. Other Print Operations	
Printing a PDF File Directly	
Printing Method	89
Using Commands	92
Unauthorized Copy Control	94
Using [Data security for copying]	94
Using [Mask type:]	95
Important Notice	97
Sample Print	98
Printing the First Set	99
Printing the Remaining Sets	99
Deleting Sample Print Files	101
Locked Print	102
Sending a Locked Print File	102
Printing a Locked Print File	103
Deleting Locked Print Files	104
Hold Print	106
Hold Print Job to the Printer	106
Printing a Hold Print File	107
Deleting Hold Print Files	108
Stored Print	110
Stored Print Job to the Printer	111
Printing a Stored Print File	111
Deleting Stored Print Files	113
Form Feed	115
Printing from a Selected Tray	115
Canceling a Print Job	116

Windows - Canceling a Print Job	
Mac OS - Canceling a Print Job	
Checking the Error Log	119
Collate	
Spool Printing	121
Setting Spool Printing	121
Viewing or Deleting spooled jobs using Web Image Monitor	122
Cover	123
Slip Sheets	
4. Using Paper Types that have Unique Names	
From Registration of User Paper Types to Use	
Registering Names to Paper Types	
Setting User Paper Types to Trays	
Printing Using Registered Paper Types	
5. Making Printer Settings Using the Control Panel	
Menu Chart	133
Paper Input Menu	139
Changing the Paper Input Menu	139
Paper Input Menu Parameters	140
List/Test Print Menu	143
Printing a Configuration Page	143
Interpreting the Configuration Page	143
List/Test Print Menu Parameters	145
Maintenance Menu	146
Changing the Maintenance Menu	146
Maintenance Menu Parameters	146
System Menu	149
Changing the System Menu	149
System Menu parameters	149
Host Interface Menu	
Changing the Host Interface Menu	
Host Interface Menu Parameters	
PCL Menu	

Changing the PCL Menu	
PCL Menu Parameters	
PS Menu	
Changing the PS Menu	
PS Menu Parameters	
PDF Menu	
Changing the PDF Menu	
PDF Menu Parameters	
Language Menu	
Changing the Language Menu	
Language Menu Parameters	

6. Monitoring and Configuring the Printer

Using Web Image Monitor	171
Displaying Top Page	172
About Menu and Mode	173
Access in the Administrator Mode	175
Displaying Web Image Monitor Help	175
Using SmartDeviceMonitor for Admin	177
Installing SmartDeviceMonitor for Admin	178
Changing the Network Interface Board Configuration	179
Locking the Menus on the Printer's Control Panel	
Changing the Paper Type	
Managing User Information	181
Setting Applicable Functions to New Users	183
Configuring the Energy Saver Mode	183
Setting a Password	184
Checking the Printer Status	185
Changing Names and Comments	185
Viewing and Deleting Spool Print Jobs	187
Using SmartDeviceMonitor for Client	188
Monitoring Printers	188
Checking the Printer Status	188
When Using IPP with SmartDeviceMonitor for Client	

Printer Status Notification by E-Mail	
Auto E-mail Notification	
On-demand E-mail Notification	
Mail authentication	
Sending On-demand E-mail	
Remote Maintenance by telnet	
Using telnet	
access	
autonet	
bonjour(rendezvous)	
devicename	
dhcp	
diprint	
dns	
domainname	
help	
hostname	
ifconfig	
info	
ipp	
ipv6	
lpr	
netware	
passwd	
pathmtu	
prnlog	
route	
set	
show	
slp	
smb	
snmp	
sntp	

spoolsw	
ssdp	
ssh	
status	
syslog	
upnp	
web	
wiconfig	
wins	
SNMP	
Getting Printer Information over the Network	
Current Printer Status	
Printer Configuration	235
Understanding the Displayed Information	
Print Job Information	
Print Log Information	
Configuring the Network Interface Board	239
Message List	
System Log Information	248
7. Using a Printer Server	
Preparing Printer Server	
Printing notification via SmartDeviceMonitor for Client	
Using NetWare	
Setting Up as a Print Server (NetWare 3.x)	
Setting Up as a Print Server (NetWare 4.x, 5/5.1, 6/6.5)	
Using Pure IP in the NetWare 5/5.1 or 6/6.5 Environment	
Setting Up as a Remote Printer (NetWare 3.x)	
Setting Up as a Remote Printer (NetWare 4.x, 5/5.1, 6/6.5)	
8. Special Operations under Windows	
Printing Files Directly from Windows	
Setup	
Using a Host Name Instead of an IPv4 Address	
Printing Commands	

9. Mac OS Configuration

Mac OS	
Installing the PostScript 3 Printer Driver and PPD File	
Setting Up PPD Files	
Using USB Interface	
Setting Up Options	
Installing Adobe Type Manager	
Installing Screen Fonts	
Changing to EtherTalk	
Mac OS X	
Installing the PPD Files	
Setting Up PPD Files	
Setting Up Options	
Using USB Interface	
Using Bonjour (Rendezvous)	
Changing to EtherTalk	
Configuring the Printer	
Using PostScript 3	
Job Type	
User Code	
Paper Size	
Fit to Paper	
Paper Source (Paper Feed)	
Resolution	
Orientation Override	
Duplex Printing	
Toner Saving	
Collate	
Paper Type	
Image Smoothing	
Dithering	
Printer Utility for Mac	
Installing Printer Utility for Mac	

Starting Printer Utility for Mac	
Printer Utility for Mac Functions	
10. Appendix	
Software and Utilities Included on the CD-ROM	
Printer Drivers for This Printer	
SmartDeviceMonitor for Admin	
DeskTopBinder - SmartDeviceMonitor for Client	
Protection Using Encryption	
SSL (Secure Sockets Layer) Encryption	
User Settings for SSL (Secure Sockets Layer)	
Setting the SSL / TLS Encryption Mode	
SNMPv3 Encryption	
Cautions to Take When Using in a network	
Connecting a Dial-up Router to a Network	
Using DHCP	
Configuring the WINS Server	
Using the Dynamic DNS Function	
Installing Font Manager 2000	
Using Adobe PageMaker Version 6.0, 6.5, or 7.0	
When Using Windows Terminal Service/MetaFrame	
Operating Environment	
Supported Printer Drivers	
Limitations	
Copyright Information about Installed Applications	
expat	
JPEG LIBRARY	
NetBSD	
Samba(Ver 2.2.2-1.1)	
RSA BSAFE [®]	
INDEX	

Manuals for This Printer

For particular functions, see the relevant parts of the manual.

Safety Information

Provides information on safe usage of this machine.

To avoid injury and prevent damage to the machine, be sure to read this.

Quick Installation Guide

Contains procedures for removing the printer from its box, connecting it to a computer, and installing its driver.

Hardware Guide

Contains information about paper and procedures such as installing options, replacing consumables, responding to error messages, and resolving jams.

Software Guide (This manual)

Contains procedures for using this machine in a network environment, utilizing the software, and using security functions.

How to Read This Manual

Symbols

The following set of symbols is used in this manual.

WARNING

This symbol indicates a potentially hazardous situation that might result in death or serious injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are described in the Safety Information section.

This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage that does not involve personal injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are described in the Safety Information section.

*The statements above are notes for your safety.

Comportant 🔁

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

Note

This symbol indicates precautions for operation, or actions to take after abnormal operation.

Reference

This symbol indicates a reference.

[]

Keys that appear on the machine's display.

Keys and buttons that appear on the computer's display.

[]

Keys built into the machine's control panel.

Keys on the computer's keyboard.

Description for the Specified Model

In this manual, the following items explain about the printer for the specified models:

 220-240V

This explains about the 220-240 V model printer.

Read if you purchase this model.


120V

This explains about the 120 V model printer.

Read if you purchase this model.


Note

• You can identify the printer's model by checking the label on its inside as shown.



Using Keys

This section describes configuration using the display panel on the initial screen.



1. Display

Shows the current status of the printer and error messages.

2. Power indicator

Is on while the printer power is on.

Is off when the power is turned off or while the printer is in Energy Saver mode.

3. Alert indicator

Blinks or lights up whenever any printer error occur. A message describing the cause of the error also appears on the display.

4. Data In indicator

Blinks while the printer is receiving data from a computer. Is on if there is data to be printed.

5. [Online] key

Press this key to switch the printer between online and offline.

6. [Job Reset] key

When the printer is online, press this key to cancel any ongoing print jobs. See p.116 "Canceling a Print Job".

7. [Form Feed] key

If the printer is offline, press this key to print all the data left in the printer's input buffer. This does not work if the printer is online.

8. [Menu] key

Press this key to make and check the current printer settings.

9. [Escape] key

Press this key to return to the previous condition on the display.

10. [# Enter] key

Press this key to execute menu items selected on the display.

Press this key to clear some errors.

11. [▲] [♥] keys

Press keys to increase or decrease values on the display when making settings.

Keep the key pressed to quicken scrolling, and increase or decrease values on the display in units of 10.

1. Preparing for Printing

Quick Install

Windows 95/98/Me/2000/XP, and Windows Server 2003/2003 R2 users can easily install this software using the CD-ROM provided.

Quick Install sets the TCP/IP port and installs DeskTopBinder and the PCL and/or RPCS driver.

C Important

- To install printer driver under Windows 2000/XP Professional, and Windows Server 2003/2003 R2, you must have an account that has Manage Printers permission. Log on as an Administrator.
- The Quick Install is not available when using this printer under USB connection.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- Select an interface language, and then click [OK].

The default interface language is English.

4. Click [Quick Install].

The software license agreement appears in the License Agreement dialog box.

- 5. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- 6. Select the printer model you want to use in the [Select Printer] dialog box. For network connection via TCP/IP, select the printer whose IP address is displayed in [Connect To]. For parallel connection, select the printer whose printer port is displayed in [Connect To].
- 7. Click [Install].

The printer driver installation starts.

8. Click [Finish].

A message about restarting the computer may appear. Restart the computer to complete installation.

9. Click [Exit] in the first dialog box of the installer, and then take out the CD-ROM.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- To stop installation of the selected software, click [Cancel] before installation is complete.
- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.

- Select a printer to whose IP address is displayed in [Connect To] to install SmartDeviceMonitor for Client when using TCP/IP.
- Download the printer driver from the supplier's web site when using under Windows NT 4.0.
- Quick Install is not available unless bidirectional communication between the printer and computer is enabled via parallel connection.

Reference

- p.62 "Making Option Settings for the Printer"
- p.51 "Installing the Printer Driver Using USB"

Confirming the Connection Method

This printer supports network and local connection.

Before installing the printer driver, check how the printer is connected. Follow the driver installation procedure that is appropriate to the connection method.


Network Connection

This printer can be used as a Windows printing port or network printer.

Using this printer as the Windows printing port

Network connections can be established through Ethernet and IEEE 802.11b.

Available ports are determined based on the combination of Windows operating system version and connection method used.



Windows 95/98

Connection Method	Available Ports	
Ethernet/IEEE 802.11b	SmartDeviceMonitor for Client port	

Windows Me

Connection Method	Available Ports
Ethernet/IEEE 802.11b	SmartDeviceMonitor for Client port

Windows 2000

	Connection Method	Available Ports
Eth	nernet/IEEE 802.11b	SmartDeviceMonitor for Client port
		Standard TCP/IP port
		LPR port

Windows XP

Connection Method	Available Ports
Ethernet/IEEE 802.11b	SmartDeviceMonitor for Client port
	Standard TCP/IP port
	LPR port

Windows Server 2003/2003 R2

Connection Method	Available Ports
Ethernet/IEEE 802.11b	SmartDeviceMonitor for Client port
	Standard TCP/IP port
	LPR port

Windows NT 4.0

Connection Method	Available Ports
Ethernet/IEEE 802.11b	SmartDeviceMonitor for Client port LPR port

Reference


- p.21 "Using the SmartDeviceMonitor Port"
- p.35 "Using the Standard TCP/IP Port"
- p.39 "Using the LPR Port"

Using as a network printer

This printer can be used as the Windows network printer, the NetWare print server, or the NetWare remote printer.

🔂 Important

• In an IPv6 environment, Netware servers cannot be used.



Vote

• See the explanation of how to install the printer driver for each type of network printer.

Reference

- p.43 "Using as the Windows Network Printer"
- p.48 "Using as the NetWare Print Server/Remote Printer"

Local Connection

Local connections can be established via parallel and USB connections.

Windows operating system version determines the available connection methods.

• Windows 95:

Parallel connection

- Windows 98: Parallel connection
- Windows Me: USB and Parallel connections
- Windows 2000:

USB and Parallel connections

• Windows XP:

USB and Parallel connections

- Windows Server 2003/2003 R2: USB and Parallel connections
- Windows NT 4.0:

Parallel connection

Note

• See the explanation of how to install the printer driver for each method of connection.

Reference

- p.51 "Installing the Printer Driver Using USB"
- p.56 "Printing with Parallel Connection"

Using the SmartDeviceMonitor Port

Installing DeskTopBinder-SmartDeviceMonitor for Client

🔂 Important

- To install SmartDeviceMonitor for Client under Windows 2000/XP Professional, Windows Server 2003/2003 R2, and Windows NT 4.0, you must have an account that has Manage Printers permission. Log on as an Administrator.
- Install SmartDeviceMonitor for Client before installing the printer driver when using the SmartDeviceMonitor for Client port.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [DeskTopBinder-SmartDeviceMonitor for Client].
- 5. The DeskTopBinder Lite Setup dialog appears, and then click [Next >].
- 6. The software license agreement appears in the [License Agreement] dialog box. After reading through its contents, click [Yes].
- 7. Click [Full install] or [Custom Install].

[Full install] installs all required applications: DeskTopBinder Lite and SmartDeviceMonitor for Client.

[Custom Install] installs selected applications.

- 8. Follow the instructions on the display and click [Next >] to proceed next step.
- 9. After the installation is completed, select one of the options to restart the computer either now or later, and click [Complete].

Restart the computer to complete installation.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- To stop installation of the selected software, click [Cancel] before installation is complete.

Installing the PCL or RPCS Printer Driver (TCP/IP)

🔁 Important 🗋

- To install this printer driver under Windows 2000/XP Professional, and Windows Server 2003/2003 R2, you must have an account that has Manage Printers permission. Log on as an Administrators or Power Users group member.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- Select an interface language, and then click [OK]. The default interface language is English.
- 4. Click [PCL/RPCS Printer Drivers].
- 5. The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- 6. Select the printer driver you want to use in the [Select Program] dialog box. You can select several printer drivers.
- 7. Click [Next>].
- 8. Select the printer model you want to use.

The printer name can be changed in the [Change settings for 'Printer Name'] box.

9. Double-click the printer name to display the printer settings.

The details shown in [Comment:], [Driver:], and [Port:] vary depending on the operating system, printer model, and port.

- 10. Click [Port:], and then click [Add].
- 11. Click [SmartDeviceMonitor], and then click [OK].
- 12. Click [TCP/IP], and then click [Search].

A list of printers using TCP/IP appears.

13. Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a printer not listed here, click [Specify Address], and then enter the IP address or host name of the printer.

- 14. Check that the port of the selected printer is displayed in [Port:].
- 15. Set a User Code, if necessary.

Up to 8 numeric characters can be entered. No alphabetic characters or symbols are available.

16. Select the [Default Printer] check box to configure the printer as default.

17. Click [Continue].

Installation starts.

18. After the installation is completed, select one of the options to restart the computer either now or later, and then click [Finish].

Restart the computer to complete installation.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- Under Windows 95/98/Me, you cannot add an IPv4 address partially similar to the one already used. For example, if "192.168.0.2" is in use, "192.168.0.2xx" cannot be used. Similarly, if "192.168.0.20" is in use, "192.168.0.2" cannot be used.
- This allows a SmartDeviceMonitor for Admin user to display and check statistics about the number of sheets which each user prints. For details, see SmartDeviceMonitor for Admin Help.
- A message appears if there is a newer version of the printer driver already installed. If there is, you cannot install the printer driver using Auto Run. If you still want to install the printer driver, install using [Add Printer].

Reference

• p.60 "Having Problems Installing the Printer Driver from the CD-ROM"

Installing the PCL or RPCS Printer Driver (IPP)

🚼 Important 🛛

- To install printer driver under Windows 2000/XP Professional, and Windows Server 2003/2003 R2, you must have an account that has Manage Printers permission. Log on as an Administrators or Power Users group member.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [PCL/RPCS Printer Drivers].
- The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- 6. Select a printer driver you want to use in the [Select Program] dialog box. You can select several printer drivers.

7. Select the printer model you want to use.

The printer name can be changed in the [Change settings for 'Printer Name'] box.

8. Double-click the printer name to display the printer settings.

The details shown in [Comment:], [Driver:], and [Port:] vary depending on the operating system, printer model, and port.

- 9. Click [Port:], and then click [Add].
- 10. Click [SmartDeviceMonitor], and then click [OK].
- 11. Click [IPP].
- 12. In the [Printer URL] box, enter "http://printer's address/printer" as the printer's address.

If the server authentification is issued, to enable SSL(a protocol for encrypted communication), enter "https://printer's address/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IPv4 address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http: //printer's address/ipp" as the printer's address.

 Enter a name for identifying the printer in [IPP Port Name]. Use a name different from the one of any existing port.

If a name is not specified here, the address entered in the [Printer URL] box becomes the IPP port name.

14. Click [Detailed Settings] to make necessary settings, and then click [OK].

For information about the settings, see SmartDeviceMonitor for Client Help.

- 15. Click [OK].
- 16. Check that the port of the selected printer is displayed in [Port:].
- 17. Set a User Code, if necessary.

Up to 8 numeric characters can be entered. No alphabetic characters or symbols can be entered.

- 18. Select the [Default Printer] check box to configure the printer as default.
- 19. Click [Continue].

Installation starts.

20. After the installation is completed, select one of the options to restart the computer either now or later, and then click [Finish].

Restart the computer to complete installation.

🕗 Note

 Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.

- This allows a SmartDeviceMonitor for Admin user to display and check the number of sheets each user prints. For details, see SmartDeviceMonitor for Admin Help.
- To stop installation of the selected software, click [Cancel] before installation is complete.
- A message appears if there is a newer version of the printer driver already installed. If there is, you cannot install the printer driver using Auto Run. If you still want to install the printer driver, use [Add Printer].

Reference

• p.60 "Having Problems Installing the Printer Driver from the CD-ROM"

Installing the PostScript 3 Printer Driver (Windows 95/98/Me - TCP/IP)

- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- Select an interface language, and then click [OK]. The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next >].
- 6. Click [Local printer], and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

- 7. Select the name of the printer whose driver you want to install, and then click [Next >].
- 8. In the [Available ports:] box, click [Printer Port], and then click [Next >].
- Change the printer name if you want, and then click [Next >].
 Select the [Yes] check box to configure the printer as default.
- 10. Specify whether or not to print a test page, and then click [Finish].
- On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- 12. Click the icon of the printer you want to use. On the [File] menu, click [Properties].
- 13. On the [Details] tab, click [Add Port...].
- 14. Click [SmartDeviceMonitor] in the [Other] list, and then click [OK].
- 15. Click [TCP/IP], and then click [Search].

A list of printers using TCP/IP appears.

16. Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a printer not listed here, click [Specify Address], and then enter the IPv4 address or host name of the printer.

You cannot add an IPv4 address partially similar to the one already used. For example, if "192.168.0.2" is in use, "192.168.0.2xx" cannot be used. Similarly, if "192.168.0.20" is in use, "192.168.0.2" cannot be used.

- 17. Click [OK].
- Check that the selected port is highlighted in [Print to the following port:], and then click [OK].
- 19. Restart the computer to complete installation.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows 95/98/Me - IPP)

Comportant 🗋

- IPv6 cannot be used under Windows 95/98/Me.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- Select an interface language, and then click [OK].
 The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next>].
- 6. Click [Local printer], and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

- Select the name of the printer whose driver you want to install, and then click [Next >].
- 8. In the [Available ports:] box, click [LPT1: Printer Port], and then click [Next >].
- Change the printer name if you want, and then click [Next >].
 Select the [Yes] check box to configure the printer as default.

- 10. Specify whether or not to print a test page, and then click [Finish].
- On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- 12. Click the icon of the printer you want to use. On the [File] menu, click [Properties].
- 13. On the [Details] tab, click [Add Port...].
- 14. Click [SmartDeviceMonitor] in the Other list, and then click [OK].
- 15. Click [IPP].
- 16. In the [Printer URL] box, enter "http://(printer's address)/printer" as the printer's address. If the server authentification is issued, to enable SSL (a protocol for encrypted communication), enter "https://(printer's address)/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IPv4 address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http://(printer's address)/ipp" as the printer's address.

 Enter a name for identifying the printer in [IPP Port Name]. Use a name different from the one of any existing port.

If a name is not specified here, the address entered in the [Printer URL] box becomes the IPP port name.

18. Click [Detailed Settings] to make necessary settings.

For information about the settings, see SmartDeviceMonitor for Client Help.

- 19. Click [OK].
- Check that the selected port is highlighted in [Print to the following port:], and then click [OK].
- Restart the computer to complete installation.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows 2000 - TCP/IP)

🔁 Important 🔵

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

- 3. Select an interface language, and then click [OK]. The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next>].
- 6. Click [Local printer], and then click [Next >].

If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.

- 7. Click [Create a new port:].
- 8. Click [SmartDeviceMonitor], and then click [Next >].
- 9. Click [TCP/IP], and then click [Search].

A list of printers using TCP/IP appears.

10. Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a printer not listed here, click [Specify Address], and then enter the IPv4 address or host name of the printer.

- Check that the name of the printer whose driver you want to install is selected, and then click [Next >].
- 12. Change the printer name if you want, and then click [Next >].

Select the [Yes] check box to configure the printer as default.

- 13. Specify whether or not to share the printer, and then click [Next >].
- 14. Specify whether or not to print a test page, and then click [Next >].
- 15. Click [Finish].

The printer driver installation starts.

Vote

 Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.

- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows 2000 - IPP)

Comportant 🔁

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- IPv6 cannot be used under Windows 2000.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

4. Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5. Click [Next >].
- 6. Click [Local printer], and then click [Next >].

If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.

- 7. Click [Create a new port:].
- 8. Click [SmartDeviceMonitor], and then click [Next >].
- 9. Click [IPP].
- 10. In the [Printer URL] box, enter "http://(printer's address)/printer" as the printer's address.

If the server authentification is issued, to enable SSL (a protocol for encrypted communication), enter "https://(printer's address)/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IPv4 address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http://(printer's address)/ipp" as the printer's address.

 Enter a name for identifying the printer in [IPP Port Name]. Use a name different from the name of any existing port.

If a name is not specified here, the address entered in the [Printer URL] box becomes the IPP port name.

12. Click [Detailed Settings] to make necessary settings, and then click [OK].

For information about the settings, see SmartDeviceMonitor for Client Help.

- 13. Click [OK].
- Check that the name of the printer whose driver you want to install is selected, and then click [Next >].
- 15. Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.
- 16. Specify whether or not to share the printer, and then click [Next >].
- 17. Specify whether or not to print a test page, and then click [Next >].
- 18. Click [Finish].

The printer driver installation starts.

Vote

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2 - TCP/IP)

🚼 Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next >].

6. Click [Local printer attached to this computer], and then click [Next >].

If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.

- 7. Click [Create a new port:].
- 8. Click [SmartDeviceMonitor], and then click [Next >].
- 9. Click [TCP/IP], and then click [Search].

A list of printers using [TCP/IP] appears.

10. Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a printer not listed here, click [Specify Address], and then enter the IPv4 address or host name of the printer.

- Check that the name of the printer whose driver you want to install is selected, and then click [Next >].
- 12. Change the printer name if you want, and then click [Next >].

Select the [Yes] check box to configure the printer as default.

- 13. Specify whether or not to share the printer, and then click [Next >].
- 14. Specify whether or not to print a test page, and then click [Next >].
- 15. Click [Finish].

The printer driver installation starts.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2 - IPP)

🚼 Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

4. Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- Click [Next >].
- 6. Click [Local printer attached to this computer], and then click [Next >].

If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.

- 7. Click [Create a new port:].
- 8. Click [SmartDeviceMonitor], and then click [Next >].
- 9. Click [IPP].
- 10. In the [Printer URL] box, enter "http://(printer's address)/printer" as the printer's address.

If the server authentification is issued, to enable SSL (a protocol for encrypted communication), enter "https://(printer's address)/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IPv4 address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http://(printer's address)/ipp" as the printer's address.

 Enter a name for identifying the printer in [IPP Port Name]. Use a name different from the one of any existing port.

If a name is not specified here, the address entered in the [Printer URL] box becomes the IPP port name.

12. [Detailed Settings] to make necessary settings, and then click [OK].

For information about the settings, see SmartDeviceMonitor for Client Help.

- 13. Click [OK].
- Check that the name of the printer driver you want to install is selected, and then click [Next >].
- Change the name of the printer if you want, and then click [Next >].

Select the [Yes] check box to configure the printer as default.

- 16. Specify whether or not to share the printer, and then click [Next >].
- 17. Specify whether or not to print a test page, and then click [Next >].
- 18. Click [Finish].

The printer driver installation starts.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Changing the Port Settings for SmartDeviceMonitor for Client

Follow the procedure below to change the SmartDeviceMonitor for Client settings, such as TCP/IP timeout, recovery/parallel printing, and printer groups.

For Windows 95/98/Me:

- 1. On the [Start] menu, point to [Settings], and then click [Printers].
- In the [Printers] window, click the icon of the printer you want to use. On the [File] menu, click [Properties].
- 3. Click the [Details] tab, and then click [Port Settings...].

The [Port Settings] dialog box appears.

For Windows 2000 and Windows NT 4.0:

- 1. On the [Start] menu, point to [Settings], and then click [Printers].
- In the [Printers] window, click the icon of the printer you want to use. On the [File] menu, click [Properties].
- 3. On the [Ports] tab, click [Configure Port...].

The [Port Configuration] dialog box appears.

For Windows XP and Windows Server 2003/2003 R2:

1. On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

- 2. Click the icon of the printer you want to use. On the [File] menu, click [Properties]. The printer properties appear.
- 3. Click the [Ports] tab, and then click [Configure Port...].

The [Port Configuration] dialog box appears.

Vote

• For TCP/IP, timeout setting can be configured.

- User, proxy, and timeout settings can be configured for IPP.
- If no settings on the [Recovery/Parallel Printing] tab are available, follow the procedure below.
 - 1. Click [Cancel] to close the [Port Configuration:] dialog box.
 - 2. Start SmartDeviceMonitor for Client, and then right-click the SmartDeviceMonitor for Client icon on the task tray.
 - 3. Point to [Properties], and then click [Extended Features Settings].
 - 4. Select the [Set Recovery/Parallel Printing for each port] check box.
 - 5. Click [OK] to close the [Extended Features Settings] dialog box.
 - 6. For information about these settings, see SmartDeviceMonitor for Client Help.

Using the Standard TCP/IP Port

Installing the PCL or RPCS Printer Driver

🔂 Important

- To install printer driver under Windows 2000/XP Professional, and Windows Server 2003/2003 R2, you must have an account that has Manage Printers permission. Log on as an Administrators or Power Users group member.
- In an IPv6 environment, you cannot use the Standard TCP/IP Port. Use the SmartDeviceMonitor port.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

- 3. Select an interface language, and then click [OK]. The default interface language is English.
- 4. Click [PCL/RPCS Printer Drivers].
- 5. The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- 6. Select a printer driver you want to use in the [Select Program] dialog box.

You can select several printer drivers.

- 7. Click [Next >].
- 8. Select the printer model you want to use.

The printer name can be changed in the [Change settings for 'Printer Name'] box.

9. Double-click the printer name to display the printer settings.

The details shown in [Comment:], [Driver:], and [Port:] vary depending on the operating system, printer model, and port.

- 10. Click [Port:], and then click [Add].
- 11. Click [Standard TCP/IP Port], and then click [OK].

Configure the Standard TCP/IP port settings, and then see Windows Help if [Standard TCP/IP Port] does not appear.

- 12. Click [Next >] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.
- 13. Enter the printer name or IPv4 address in the [Printer Name or IP Address] box.

The [Port Name] text box automatically obtains a port name. Change this name if necessary. When screen for Device selection appears, select "RICOH NetworkPrinter Driver C Model".

- 14. Click [Next>].
- 15. Click [Finish] in the [Add Standard TCP/IP Printer Port Wizard] dialog box. The installation start dialog box reappears.
- 16. Check that the port of the selected printer is displayed in [Port:].
- 17. Configure the default printer as necessary.
- 18. Click [Continue].

The printer driver installation starts.

 After the installation is completed, select one of the options to restart the computer either now or later, and then click [Finish].

Restart the computer to complete installation.

\rm Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- To stop installation of the selected software, click [Cancel] before installation is complete.
- A message appears if there is a newer version of the printer driver already installed. If there is, you cannot install the printer driver using Auto Run. If you still want to install the printer driver, use [Add Printer].

Reference

• p.60 "Having Problems Installing the Printer Driver from the CD-ROM"

Installing the PostScript 3 Printer Driver (Windows 2000)

🚼 Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- In an IPv6 environment, you cannot use the Standard TCP/IP Port. Use the SmartDeviceMonitor port.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

- Select an interface language, and then click [OK]. The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next >].

6. Click [Local printer], and then click [Next >].

If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.

- 7. Click [Create a new port:].
- 8. Click [Standard TCP/IP Port], and then click [Next >].
- 9. Click [Next >] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.
- Enter the printer name or IPv4 address in the [Printer Name or IP Address] box, and then click [Next >[.

When screen for Device selection appears, select "RICOH NetworkPrinter Driver C Model".

- 11. Click [Finish] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.
- Check that the name of the printer whose driver you want to install is selected, and then click [Next >].
- Change the printer name if you want, and then click [Next >].
 Select the [Yes] check box to configure the printer as default.
- 14. Specify whether or not to share the printer, and then Click [Next >].
- 15. Specify whether or not to print a test page, and then click [Next>].
- 16. Click [Finish].

The printer driver installation starts.

Vote

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation . For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)

🚼 Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- In an IPv6 environment, you cannot use the Standard TCP/IP Port. Use the SmartDeviceMonitor port.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive.

The installer starts.

- 3. Select an interface language, and then click [OK]. The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next >].
- 6. Click [Local printer attached to this computer], and then click [Next >]. If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.
- 7. Click [Create a new port:].
- 8. Click [Standard TCP/IP Port] in [Create a new Port], and then click [Next >].
- 9. Click [Next >] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.
- 10. Enter the printer name or IPv4 address in the [Printer Name or IP Address] box. The [Port Name] text box automatically obtains a port name. Change this name if necessary. When screen for Device selection appears, select "RICOH NetworkPrinter Driver C Model".
- 11. Click [Next>].
- 12. Click [Finish] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.
- Check that the name of the printer whose driver you want to install is selected, and then click [Next >].
- 14. Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.
- 15. Specify whether or not to share the printer, and then Click [Next >].
- 16. Specify whether or not to print a test page, and then click [Next >].
- 17. Click [Finish].

The printer driver installation starts.

```
🛡 Note
```

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Using the LPR Port

Installing the PCL or RPCS Printer Driver

🚼 Important

- To install this printer driver under Windows 2000/XP Professional, Windows Server 2003/2003 R2, and Windows NT 4.0, you must have an account that has Manage Printers permission. Log on as an Administrators or Power Users group member.
- In an IPv6 environment, you cannot use the LPR Port. Use the SmartDeviceMonitor port.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

- Select an interface language, and then click [OK].
 The default interface language is English.
- 4. Click [PCL/RPCS Printer Drivers].
- The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- 6. Select a printer driver you want to use in the [Select Program] dialog box.

You can select several printer drivers.

7. Select the printer model you want to use.

The printer name can be changed in the [Change settings for 'Printer Name'] box.

8. Double-click the printer name to display the printer settings.

The details shown in [Comment:], [Driver:], and [Port:] vary depending on the operating system, printer model, and port.

- 9. Click [Port:], and then click [Add].
- Click [LPR Port], and then click [OK].
 If [LPR Port] does not appear, see Windows Help and install it.
- 11. Enter the printer's IPv4 address in the [Name or address of server providing lpd] box.
- Enter "lp" in the [Name of printer or print queue on that server] box, and then click [OK]. The port is added.
- 13. Check that the port of the selected printer is displayed in [Port:].
- 14. Configure the default printer as necessary.

15. Click [Finish].

The printer driver installation starts.

16. After the installation is completed, select one of the options to restart the computer either now or later, and then click [Finish].

Restart the computer to complete installation.

Vote

1

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- To stop installation of the selected software, click [Cancel] before installation is complete.
- A message appears if there is a newer version of the printer driver already installed. If there is, you cannot install the printer driver using Auto Run. If you still want to install the printer driver, use [Add Printer].

Reference

• p.60 "Having Problems Installing the Printer Driver from the CD-ROM"

Installing the PostScript 3 Printer Driver (Windows 2000)

C Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- In an IPv6 environment, you cannot use the LPR Port. Use the SmartDeviceMonitor port.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

4. Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5. Click [Next >].
- 6. Click [Local printer], and then click [Next >].

If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.

- 7. Click [Create a new port:].
- 8. Click [LPR Port], and then click [Next >].
- 9. Enter the printer's IPv4 address in the [Port Name] box, and then click [OK].

- Check that the name of the printer whose driver you want to install is selected, and then click [Next >].
- Change the printer name if you want, and then click [Next >].
 Select the [Yes] check box to configure the printer as default.
- 12. Specify whether or not to share the printer, and then click [Next >].
- 13. Specify whether or not to print a test page, and then click [Next >].
- 14. Click [Finish].

The printer driver installation starts.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)

🔁 Important 🔵

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- In an IPv6 environment, you cannot use the LPR Port. Use the SmartDeviceMonitor port.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

4. Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5. Click [Next >].
- 6. Click [Local Printer attached to this computer], and then click [Next >]. If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.
- 7. Click [Create a new port:].

- 8. Click [LPR Port] in [Create a new Port], and then click [Next >].
- 9. Enter the printer's IP address in the [Name or address of server providing lpd] box.
- 10. Enter "lp" in the [Name of printer or print queue on that server] box, and then click [OK].
- Check that the name of the printer whose driver you want to install is selected, and then click [Next >].
- Change the printer name if you want, and then click [Next >].
 Select the [Yes] check box to configure the printer as default.
- 13. Click [Next>].
- 14. Specify whether or not to print a test page, and then click [Next >].
- 15. Click [Finish].

The printer driver installation starts.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Using as the Windows Network Printer

Installing the PCL or RPCS Printer Driver

To use the print server, install the printer driver by selecting "Network printer server", and then select the Windows 2000/XP, or Windows Server 2003/2003 R2 shared printer.

This section assumes that the client has already been configured to communicate with a Windows 2000/ XP, or Windows Server 2003/2003 R2 print server. Do not begin the following procedure before the client is set up and configured correctly.

Coloritant 🔁

- To install printer driver under Windows 2000/XP Professional, and Windows Server 2003/2003 R2, you must have an account that has Manage Printers permission. For this, log on as an Administrators or Power Users group member.
- If you print with a print server connected to the printer using the SmartDeviceMonitor port, Recovery Printing and Parallel Printing cannot be used from the client.
- SmartDeviceMonitor's notification functions are not available if you are using a Windows XP or Windows Server 2000 print server.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [PCL/RPCS Printer Drivers].
- The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- Select a printer driver you want to use in the [Select Program] dialog box.
 You can select several printer drivers.
- Click [Next >].
- 8. Select the printer models you want to use.

The printer name can be changed in the [Change settings for 'Printer Name'] box.

9. Double-click the printer name to display the printer settings.

The details shown in [Comment:], [Driver:], and [Port:] vary depending on the operating system, printer model, and port.

10. Click [Port:], and then click [Add].

- 11. Click [Network Printer], and then click [OK].
- Double-click the computer name you want to use as a print server in the [Browse for Printer] window.
- 13. Select the printer you want to use, and then click [OK].
- 14. Check that the port of the selected printer is displayed in [Port:].
- 15. Configure the User Code as necessary.

For an RPCS printer driver, a User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

- 16. Select the [Default Printer] check box to configure the printer as default.
- 17. Click [Continue].

The printer driver installation starts.

18. After the installation is completed, select one of the options to restart the computer either now or later, and then click [Finish].

Restart the computer to complete installation.

Vote

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- To stop installation of the selected software, click [Cancel] before installation is complete.
- A message appears if there is a newer version of the printer driver already installed. If there is, you
 cannot install the printer driver using Auto Run. If you still want to install the printer driver, use [Add
 Printer].

Reference

• p.60

Installing the PostScript 3 Printer Driver (Windows 95/98/Me)

Coloritant 🔂

- If you print from a print server connected to the printer using the SmartDeviceMonitor port, the client cannot use Recovery Printing and Parallel Printing.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

4. Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5. Click [Next>].
- 6. Click [Network Printer], and then click [Next >].
- 7. Click [Browse].
- 8. Double-click the computer name you want to use as a print server in the [Browse for Printer] window.
- 9. Select the printer you want to use, and then click [OK].
- 10. Check the location of the selected printer is shown, and then click [Next >].
- Change the printer name if you want, and then click [Next >].
 Select the [Yes] check box to configure the printer as default.
- 12. Specify whether or not to print a test page, and then click [Finish].
- 13. Restart the computer.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows 2000)

🔁 Important

- Installing a printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- If you print from a print server connected to the printer using the SmartDeviceMonitor port, the client cannot use Recovery Printing and Parallel Printing.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- 3. Select an interface language, and then click [OK].

The default interface language is English.

4. Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5. Click [Next >].
- 6. Click [Network printer], and then click [Next >].
- 7. Select the location method from the [Locate Your Printer] screen, and then click [Next >].
- 8. Double-click the computer name you want to use as a print server in the [Shared printers:] box.
- 9. Select the printer you want to use, and then click [Next >].
- 10. The printer driver installation starts.
- 11. Click [Next>].

Select the [Yes] check box to configure the printer as default.

12. Click [Finish].

Restart the computer to complete installation.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)

Coloritant 🔂

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- If you print from a print server connected to the printer using the SmartDeviceMonitor port, the client cannot use Recovery Printing and Parallel Printing.
- If you print with a Windows XP or Windows Server 2003/2003 R2 print server, SmartDeviceMonitor notification functions may not be possible for the client.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next >].
- Click [A network printer, or a printer attached to another computer], and then click [Next >].
- 7. Select [Browse for a printer], and then click [Next >].
- 8. Double-click the computer name you want to use as a print server in the [Shared printers] window.
- 9. Select the printer you want to use, and then click [Next >].
- 10. The printer driver installation starts.
- 11. Click [Next >].

Select the [Yes] check box to configure the printer as default.

12. Click [Finish].

Restart the computer to complete installation.



- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A User Code can be set after the printer driver installation. For information about User Code, see the printer driver Help.

1

Using as the NetWare Print Server/Remote Printer

This explains how to set up the Windows computer used as the NetWare client.

🔁 Important

- To install this printer driver under Windows 2000/XP Professional, Windows Server 2003/2003 R2, and Windows NT 4.0, you must have an account that has Manage Printers permission. Log on as an Administrators or Power Users group member.
- In an IPv6 environment, Netware servers cannot be used.

The following explanation assumes NetWare Client is installed on the client computer and the NetWare server environment is correctly set up. Install all necessary client applications before following this procedure.

Set up the printer driver while logging on to the NetWare file server.

The following values are used in the example:

- Operating system: Windows 98
- NetWare version: 4.1
- File server name: CAREE
- Queue name: R-QUEUE
- 1. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

2. Select an interface language, and then click [OK].

The default interface language is English.

- 3. Click [PCL/RPCS Printer Drivers].
- 4. The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement.], and then click [Next >].
- Select the printer driver you want to use in the [Select Program] dialog box. You can select several printer drivers.
- 6. Click [Next >].
- 7. Select the printer models you want to use.

The printer name can be changed in the [Change settings for 'Printer Name'] box.

8. Double-click the printer name to display the printer settings.

The details shown in [Comment:], [Driver:], and [Port:] vary depending on the operating system, printer model, and port.

9. Click [Port:], and then click [Add].

- 10. Click [Network Printer], and then click [OK].
- Double-click the name of the NetWare file server on the network tree. The created queue is displayed.
- 12. Select the print queue, and then click [OK].
- 13. Check that the port of the selected printer is displayed in [Port:].
- 14. Click [Continue].

The printer driver installation starts.

- 15. Click [Finish] in the [Select Program] dialog box.
- 16. After the installation is completed, select one of the options to restart the computer either now or later, and then click [Finish].

Restart the computer to complete installation.

 After restarting the computer, launch the [Printers] window, and then open the printer properties.

Under Windows XP or Windows Server 2003/2003 R2, open the printer properties from the [Printers and Faxes] window.

- 18. Click [Finish] in the [Introduction complete] dialog box.
- 19. In the [Printers] window, open the printer properties.

Under Windows XP or Windows Server 2003/2003 R2, open the printer properties from the [Printers and Faxes] window.

20. On the [Printer Settings] tab, clear the [Form Feed] and [Enable Banner] check boxes. Under Windows 2000/XP, Windows Server 2003/2003 R2, or Windows NT 4.0, click the [NetWare setting] tab.

Do not select these check boxes since they are automatically selected by the printer driver. If you select the check boxes, the printer may not print correctly.

21. Click [OK] to close the printer properties dialog box.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- To stop installation of the selected software, click [Cancel] before installation is complete.
- The protocol is set to inactive as default. Enable it using Web Image Monitor or Telnet

When using the PostScript 3 Printer Driver

Follow the procedure below to set up the PostScript 3 printer driver.

49

1

🔁 Important

- In an IPv6 environment, Netware servers cannot be used.
- 1. In the [Printers] or [Printers and Faxes] window, open the printer properties.
- 2. Click the [PostScript] tab.

If you are using Windows 2000/XP or Windows NT4.0, click the [Device Settings] tab, and then clear the check boxes.

- 3. Click [Advanced].
- Clear the [Send CTRL+D before job] and [Send CTRL+D after job] check boxes, and then click [OK].
- 5. Click [OK] to close the printer properties dialog box.

Form Feed

Do not use NetWare to configure form feed. Form feed is controlled by the printer driver on Windows. If NetWare form feed is configured, the printer may not print properly.

Follow the procedure below to disable form feed according to the operating system used:

- Under Windows 95/98/Me, clear the [Form feed] check box on the [Printer Settings] tab in the printer properties dialog box.
- Under Windows 2000/XP, Windows Server 2003/2003 R2, or Windows NT 4.0, clear the [Form feed] check box on the [NetWare Settings] tab in the printer properties dialog box.

Banner Page

Do not use NetWare to configure a banner page.

Follow the procedure below to disable banner pages according to the operating system used:

- Under Windows 95/98/Me, clear the [Enable banner] check box on the [Printer Settings] tab in the printer properties dialog box.
- Under Windows 2000/XP, Windows Server 2003/2003 R2, or Windows NT 4.0, clear the [Enable banner] check box on the [NetWare Settings] tab in the printer properties dialog box.

Printing after Resetting the Printer

Printer to print server connection requires 30 - 40 seconds to resume after the printer is reset. During this period, jobs may be accepted (depending on NetWare specifications) but not printed.

To print after resetting the printer as the remote printer, check on the print server that the remote printer is disconnected, or wait for two minutes before trying to print.

Installing the Printer Driver Using USB

This section explains how to install printer drivers using USB.

Before installing, check that only the operating system is running on the computer and no print jobs are in progress.

The printer drivers can be installed from the CD-ROM provided with this printer.

Windows Me - USB

🔁 Important

- Installation via USB is not possible under Windows 95/98. Upgrade to Windows Me or later.
- Download USB Printing Support for Windows Me from the supplier's Web site.

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB" port is added to the [Printers] window.

1. Download USB Printing Support from the supplier's Web site.

Use a search to find the model name, and then download USB Printing Support from the supplier's Web site.

Save it where you can locate it easily.

- 2. Check that the power of the printer is off.
- 3. Connect the printer and computer using the USB cable.

Connect the USB cable firmly.

4. Turn on the power of the printer.

The Plug and Play is enabled, and [Found New Hardware Wizard] appears.

If USB Printing Support is already installed on the computer proceed to Step 10.

- In the [Found New Hardware Wizard] dialog box, click [Install from a list or specific location (Advanced)], and then click [Next >].
- 6. Select the [Specify a location:] check box, and then click [Browse...].

The [Browse for Folder] dialog box appears.

- 7. Specify the location where USB Printing Support is located, and then click [Next >].
- 8. Check the location, and then click [Next >].

USB Printing Support is installed.

9. Click [Finish].

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB001" port is added to the Printers window.

- 10. Insert the printer driver.
- In the [New Hardware Found Wizard] dialog box, click [Install from a list or specific location (Advanced)], and then click [Next >].
- Select the Specify a location: check box, and then click [Browse...]. The [Browse for Folder] dialog box appears.
- 13. Insert the CD-ROM into the CD-ROM drive.

When Auto Run starts, click [Exit].

14. Specify the location where the printer driver is located, and then click [Next >].

If the CD-ROM drive is D, the source files of the printer driver are stored in the following location:

• RPCS

D:\DRIVERS\RPCS\WIN9X_ME\(Language)\DISK1

• PCL 5e

D:\DRIVERS\PCL5E\WIN9X_ME\(Language)\DISK1

• PCL 6

D:\DRIVERS\PCL6\WIN9X_ME\(Language)\DISK1

PostScript 3

D:\DRIVERS\PS\WIN9X_ME\(Language)\DISK1

15. Check the location, and then click [Next >].

Add Printer Wizard starts.

16. Click [Finish].

Installation is complete. If installation is successful, the icon of the printer connected to the "USB001" port is added to the [Printers] window.

Note

- The number after "USB" varies depending on the number of printers connected.
- It is not necessary to reinstall USB Printing Support when connecting a different printer via USB interface when USB Printing Support is installed.
- After installing USB Printing Support, if the printer driver is not installed, follow the plug-and-play instructions of the printer.
- Install the printer driver from the CD-ROM provided with the printer.

Windows 2000 - USB

Coloritant 🗋

• Installing a printer driver requires Administrators permission. Log on using an account that has Administrators permission.

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB" port is added to the [Printers] window.

If the printer driver is not installed, follow the plug-and-play instructions of the printer to install it from the CD-ROM provided.

- 1. Check that the power of the printer is off.
- Connect the printer and computer using the USB cable. Connect the USB cable firmly.
- 3. Turn on the power of the printer.

Found New Hardware Wizard starts, and USB Printing Support is installed automatically.

- 4. In the [Found New Hardware Wizard] display, click [Search for a suitable driver for my device [recommended]], and then click [Next >].
- 5. Select the [Specify location] check box, and then click [Next >].
- 6. Insert the CD-ROM into the CD-ROM drive.

When Auto Run starts, click [Exit].

7. Specify the location where the source files of the printer driver is stored.

If the CD-ROM drive is D, the source files of the printer driver are stored in the following location:

RPCS

D:\DRIVES\RPCS\WIN2K_XP\(Language)\DISK1

PCL 5e

D:\DRIVES\PCL5E\WIN2K_XP\(Language)\DISK1

• PCL 6

D:\DRIVES\PCL6\WIN2K_XP\(Language)\DISK1

PostScript 3

D:\DRIVES\PS3\WIN2K_XP\(Language)\DISK1

- 8. Check the printer driver location, and then click [OK].
- 9. Click [Next>].
- 10. Click [Finish].

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB001" port is added to the [Printers] window.

Note

- To disable Auto Run, press the left Shift key when inserting the CD-ROM into the drive and keep it
 pressed until the computer finishes reading from the CD-ROM.
- The number after "USB" varies depending on the number of printers connected.

Windows XP, Windows Server 2003/2003 R2 - USB

Coloritant 🖸

• Installing a printer driver requires Administrators permission. Log on using an account that has Administrators permission.

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB" port is added to the [Printers and Faxes] window.

The printer drivers can be installed from the CD-ROM provided with this printer.

If the printer driver is not installed, follow the plug-and-play instructions of the printer to install it from the CD-ROM provided.

- 1. Check that the power of the printer is off.
- 2. Connect the printer and computer using the USB cable.

Connect the USB cable firmly.

3. Turn on the power of the printer.

Found New Hardware Wizard starts, and USB Printing Support is installed automatically.

- 4. In the Found New Hardware Wizard display, click [Search for a suitable driver for my device [recommended]], and then click [Next >].
- 5. Insert the CD-ROM into the CD-ROM drive.

If Auto Run starts, click [Cancel], and then [Exit].

6. Select the [Include this location in the search] check box under [Search for the best driver in these location], and then click [Browse] to select the printer driver location.

If the CD-ROM drive is D, the source files of the printer driver are stored in the following location:

RPCS

D:\DRIVES\RPCS\WIN2K_XP\(Language)\DISK1

- PCL 5e
 D:\DRIVES\PCL5E\WIN2K_XP\(Language)\DISK1
- PCL 6
 D:\DRIVES\PCL6\WIN2K_XP\(Language)\DISK1
- PostScript 3

D:\DRIVES\PS3\WIN2K_XP\(Language)\DISK1

- 7. Check the printer driver location, and then click [Next >].
- 8. Click [Continue].
- 9. Click [Finish].

If installation is successful, the icon of the printer connected to the "USB001" port is added to the [Printers and Faxes] window.

Note

- To disable Auto Run, press the left Shift key when inserting the CD-ROM into the drive and keep it pressed until the computer finishes reading from the CD-ROM.
- The number after "USB" varies depending on the number of printers connected.

Problem	Solutions	
The printer is not recognized automatically.	Turn off the power of the printer, reconnect the USB cable, and then turn it on again.	
Windows has already configured the USB settings.	Open Windows' Device Manager, and then, under [Universal Serial Bus controllers], remove any conflicting devices. Conflicting devices have a [!] or [?] icon by them. Take care not to accidentally remove required devices. For details, see Windows Help.	
	When using Windows 2000/XP or Windows Server 2003/2003 R2, an erroneous device is displayed under [USB Controller] in the [Device Manager] dialog box.	
Windows ME and the printer cannot be connected.	Download USB Printing Support from the supplier's website. Search the model name you use on the supplier's website, and download USB Printing Support.	

Troubleshooting USB

Printing with Parallel Connection

To use a printer connected using a parallel interface, click [LPT1] when installing the printer driver. The optional IEEE 1284 interface board must be installed on the printer.

Installing the PCL or RPCS Printer Driver

🚼 Important

- To install this printer driver under Windows 2000/XP Professional, Windows Server 2003/2003 R2, and Windows NT 4.0, you must have an account that has Manage Printers permission. Log on as an Administrators or Power Users group member.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- 3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [PCL/RPCS Printer Drivers].
- 5. The software license agreement appears in the [License Agreement] dialog box. After reading the agreement, click [I accept the agreement], and then click [Next >].
- 6. Select a printer driver you want to use in the [Select Program] dialog box. You can select several printer drivers.
- 7. Click [Next>].
- 8. Select the printer models you want to use.

The printer name can be changed in the [Change settings for 'Printer Name'] box.

9. Double-click the printer name to display the printer settings.

The details shown in [Comment:], [Driver:], and [Port:] vary depending on the operating system, printer model, and port.

- 10. Check that [LPT1:] is shown in [Port:].
- 11. Select the [Default Printer] check box to configure the printer as default.
- 12. Click [Finish].

The printer driver installation starts.

 After the installation is completed, select one of the options to restart the computer either now or later, and then click [Finish].

Vote

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- To stop installation of the selected software, click [Cancel] before installation is complete.
- A message appears if there is a newer version of the printer driver already installed. If there is, you cannot install the printer driver using Auto Run. If you still want to install the printer driver, use [Add Printer].

E Reference

• p.60 "Having Problems Installing the Printer Driver from the CD-ROM"

Installing the PostScript 3 Printer Driver (Windows 95/98/Me)

- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- Select an interface language, and then click [OK].
 The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next >].
- 6. Click [Local Printer], and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

- 7. Select the name of the printer whose driver you want to install, and then click [Next >].
- 8. In the [Available ports:] box, click [LPT: Printer Port], and then click [Next >].
- Change the printer name if you want, and then click [Next>].
 Select the [Yes] check box to configure the printer as default.
- 10. Specify whether or not to print a test page, and then click [Finish].
- 11. Restart the computer to complete installation.
- Vote
 - Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
 - The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
 - A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows 2000)

🔁 Important 🗋

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- 3. Select an interface language, and then click [OK]. The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next>].
- Click [Local printer], and then click [Next >].
 If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.
- 7. Select [LPT1:] at the [Printer Port] dialog box, and then click [Next >].
- 8. Select the name of the printer whose driver you want to install, and then click [Next >].
- Change the printer name if you want, and then click [Next>].
 Select the [Yes] check box to configure the printer as default.
- 10. Select whether or not to share the printer, and then click [Next >].
- 11. Specify whether or not to print a test page, and then click [Next >].
- 12. Click [Finish].

The printer driver installation starts.

13. Restart the computer to complete installation.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003/2003 R2)

🚼 Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- 1. Quit all applications currently running.
- Insert the CD-ROM into the CD-ROM drive. The installer starts.
- Select an interface language, and then click [OK].
 The default interface language is English.
- 4. Click [PostScript 3 Printer Driver]. Add Printer Wizard starts.
- 5. Click [Next>].
- 6. Click [Local printer attached to this computer], and then click [Next >].

If the [Automatically detect and install Plug and Play Printer] check box is selected, clear it.

7. Select the port you want to use, and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

- 8. Select the name of the printer whose driver you want to install, and then click [Next >].
- 9. Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.
- 10. Select whether or not to share the printer, and then click [Next >].
- 11. Specify whether or not to print a test page, and then click [Next >].
- 12. Click [Finish].

The printer driver installation starts.

13. Restart the computer to complete installation.

Note

- Auto Run may not work with certain operating system settings. If this happens, launch "Setup.exe" on the CD-ROM root directory.
- The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.
- A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Having Problems Installing the Printer Driver from the CD-ROM

If Quick Install fails, refer to "Using the SmartDeviceMonitor for Client" and proceed with the installation. If the installation procedures explained in "Installing PCL/RPCS Printer Drivers" or "Installing PostScript3 Printer Driver" fails, follow the procedure below.

For Windows 95/98/Me, Windows 2000 and Windows NT 4.0:

- 1. On the [Start] menu, point to [Settings], and then click [Printers].
- 2. Double-click the Add Printer icon.
- 3. Follow the instructions in Add Printer Wizard.

If the printer driver is on a CD-ROM, the location of the RPCS printer driver is either \DRIVERS\RPCS \WIN9X_ME, or \DRIVERS\RPCS\WIN2K_XP. If the installer starts, click [Cancel] to quit.

4. Change the port settings.

Refer to the port description for the procedure.

For Windows XP Professional and Windows Server 2003/2003 R2:

- 1. On the [Start] menu, click [Printers and Faxes].
- 2. Click [Add a printer].
- 3. Follow the instructions in Add Printer Wizard.

If the printer driver is on a CD-ROM, the location of the RPCS printer driver is \DRIVERS\RPCS \WIN2K_XP. If the installer starts, click [Cancel] to quit.

4. Change the port settings.

Refer to the port description for the procedure.

For Windows XP Home Editions:

- 1. On the [Start] menu, click [Control Panel].
- 2. Click [Printers and Other Hardware].
- 3. Click [Printers and Faxes].
- 4. Click [Install Printer].
- 5. Follow the instructions in Add Printer Wizard.

If the printer driver is on a CD-ROM, the location of the RPCS printer driver is \DRIVERS\RPCS \WIN2K_XP. If the installer starts, click [Cancel] to quit.

6. Change the port settings.

Refer to the port description for the procedure.

• Note

• Available ports may change depending on the combination of Windows operating system version and the interface. For details about how to find an available port, see "Confirming the Connection Method".

Reference

- p.17 "Confirming the Connection Method"
- p.21 "Using the SmartDeviceMonitor Port"
- p.35 "Using the Standard TCP/IP Port"
- p.39 "Using the LPR Port"

Making Option Settings for the Printer

Make option settings for the printer using the printer driver when bidirectional communication is disabled.

Conditions for Bidirectional Communication

Bidirectional communication allows information about paper size and feed direction settings to be automatically sent to the printer. You can check printer status from your computer.

- Bidirectional communication is supported by Windows 95/98/Me/2000/XP, Windows Server 2003/2003 R2, and Windows NT 4.0.
- If you use the RPCS printer driver and bidirectional communication is enabled under Windows 2000, the [Change Accessories] tab is unavailable.

Note

- The RPCS printer driver supports bidirectional communications and updates the printer status automatically.
- The PCL printer driver supports bidirectional communications. You can update printer status manually.
- The PostScript 3 printer driver does not support bidirectional communications.

To support bidirectional communication, the following conditions must be met:

When connected with parallel cables

- The computer must support bidirectional communication.
- The printer must support bidirectional communication.
- The interface cable must support bidirectional communication.
- The printer must be connected to the computer using the standard parallel cables and parallel connectors.
- Under Windows 2000, [Enable bidirectional support] must be selected, and [Enable printer pooling] must not be selected on the [Port] tab with the RPCS printer driver.

When connected with the network

- DeskTopBinder Lite must be installed, or the Standard TCP/IP port must be used.
- Under Windows 2000/XP, Windows Server 2003/2003 R2, [Enable bidirectional support] must be selected, and [Enable printer pooling] must not be selected on the [Ports] tab with the RPCS printer driver.

If the Standard TCP/IP port is not being used, one of the following conditions must be met in addition to the two above:

- The SmartDeviceMonitor for Client port and the TCP/IP protocol must be used.
- The standard TCP/IP port must be used without changing the default port name (for Windows 2000 / XP and Windows Server 2003/2003 R2).

- Microsoft TCP/IP print IP address must be specified for use (for Windows NT 4.0).
- When using IPP protocol with the PCL printer driver, the IPP port name must include the IP address.

When connected with USB

The printer must be connected to the computer's USB port using the USB interface cable.

The computer must support bidirectional communication.

Note

• Install SmartDeviceMonitor for Client from the CD-ROM provided.

If Bidirectional Communication is Disabled

Set up option settings when bidirectional communications are disabled.

🚼 Important

- Under Windows 2000/XP and Windows Server 2003/2003 R2, Manage Printers permission is required to change the printer properties in the [Printers] folder. Log on as an Administrators or Power Users group member.
- Under Windows NT 4.0, Full Control permission is required to change the printer properties in the [Printers] folder. Log on as an Administrators or Power Users group member.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].
- 4. Click the [Change Accessories] tab.

If options in the [Change Accessories] tab are disabled, bidirectional connection is enabled. In this case, no change is necessary for option settings.

If you are using the RPCS printer driver, click the [Change Accessories] tab.

If you are using the PS printer driver, click the [Device Settings] tab.

- 5. Select options installed from the [Option] area, and then make the necessary settings.
- Select the total amount of the memory in [Total Memory:], when the optional SDRAM module is added.
- 7. Under [Paper source tray settings:], click and highlight the tray to be used, and then select the appropriate size, position, and type for the tray. Select the [Tray locking] check box to exclude the tray from the targets of automatic tray selection.
- 8. Click [OK] to close the printer properties dialog box.

Memory Capacity and Paper Size

Additional memory apart from standard memory may be required depending on the paper size and data type.

Comportant Comportant

- Available paper sizes change depending on the selection you made for [Memory Usage] in the System menu.
- Only single-sided printing is possible on paper fed from the bypass tray. Duplex printing is not possible on paper that is fed from the bypass tray.

Standard	Extended	Total
128 MB	64 MB	192 MB
128 MB	128 MB	256 MB
128 MB	256 MB	384 MB

The table below shows the total SDRAM module capacities.

Font Priority

• Only single-sided printing (600 × 600 dpi)

128/192/256/384 MB:

- A4, B5 JIS, A5, Letter, Legal, and maximum custom sized paper can be printed on.
- Only single-sided printing (1200 × 600 dpi)

128 MB:

- A4, B5 JIS, A5, and Letter sized paper can be printed on.
- Complex images might fail to print out properly on Legal and maximum custom sized paper.

192/256/384 MB:

- A4, B5 JIS, A5, Letter, Legal, and maximum custom sized paper can be printed on.
- Duplex printing (600 × 600 dpi)

128 MB:

- A4, B5 JIS, A5, and Letter sized paper can be printed on.
- Complex images might fail to print out properly on Legal sized paper.

192/256/384 MB:

- A4, B5 JIS, A5, Letter, and Legal sized paper can be printed on.
- Duplex printing (1200 × 600 dpi)

128 MB:

- A5 sized paper can be printed on.
- Complex images might fail to print out properly on A4, B5 JIS, Letter, and Legal sized paper.

192/256/384 MB:

• A4, B5 JIS, A5, Letter, and Legal sized paper can be printed on.

Frame Priority

- Only single-sided printing (600 × 600 dpi)
 - 128/192/256/384 MB:
 - A4, B5 JIS, A5, Letter, Legal and maximum custom sized paper can be printed on.
- Only single-sided printing (1200 × 600 dpi)

128 MB:

- B5 JIS and A5 sized paper can be printed on.
- Complex images might fail to print out properly on A4, Letter, Legal, and maximum custom sized paper.

192/256 MB:

- A4, B5 JIS, A5, Letter, and Legal sized paper can be printed on.
- Complex images might fail to print out properly on maximum custom sized paper.

384 MB:

- A4, B5 JIS, A5, Letter, Legal, and maximum custom sized paper can be printed on.
- Duplex printing (600 × 600 dpi)

128 MB:

- B5 JIS and A5 sized paper can be printed on.
- Complex images might fail to print out properly on A4, Letter, and Legal sized paper.

192/256/384 MB:

• A4, B5 JIS, A5, Letter, and Legal sized paper can be printed on.

• Duplex printing (1200 × 600 dpi)

128 MB:

 Complex images might fail to print out properly on A4, B5 JIS, A5, Letter, and Legal sized paper.

192 MB:

- B5 JIS and A5 sized paper can be printed on.
- Complex images might fail to print out properly on A4, Letter, and Legal sized paper.

256 MB:

• B5 JIS and A5 sized paper can be printed on.

• Complex images might fail to print out properly on A4, Letter, and Legal sized paper.

384 MB:

- A4, B5 JIS, A5, and Letter sized paper can be printed on.
- Complex images might fail to print out properly on Legal sized paper.

• Note

• When printing from bypass tray, duplex printing will not be supported regardless of the memory capacity, and only one-side will be printed.

2. Setting Up the Printer Driver

PCL - Accessing the Printer Properties

Windows 95/98/Me - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings

To make the printer default settings, open the [Printer Properties] dialog box from the [Printers] window.

Comportant 🗋

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].
- 4. Make the necessary settings, and then click [OK].

🕗 Note

- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printer Properties] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 95/98/Me.

1. On the [File] menu, click [Print].

The [Print] dialog box appears.

2. Select the printer you want to use in the [Name] list, and then click [Properties].

The [Printer Properties] dialog box appears.

3. Make the necessary settings, and then click [OK].

4. Click [OK] to start printing.

Note

- The procedure to open the [Printer Properties] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows 2000 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🔁 Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Vote

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Printing Preferences

Coloritant 🗋

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Printing Preferences...]. The [Printing Preferences] dialog box appears.

4. Make the necessary settings, and then click [OK].

Vote

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printing Preferences] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 2000.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Select Printer] list.
- 3. Make the necessary settings, and then click [Print] to start printing.

Note

- The procedure to open the [Printing Preferences] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows XP, Windows Server 2003/2003 R2 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🚼 Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Printing Preferences

🚼 Important

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Printing Preferences...]. The [Printing Preferences] dialog box appears.
- 4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printing Preferences] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows XP

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Select Printer] list, and then click [Preferences].
- 3. Make the necessary settings, and then click [Print] to start printing.

Vote

- The procedure to open the [Printing Preferences] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows NT 4.0 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

C Important

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

• Note

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Default

Mission Important

2

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- 2. Click the icon of the printer you want to use.
- On the [File] menu, click [Document Defaults...].
 The [Default] dialog box appears.
- 4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printer Properties] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows NT 4.0.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Name] list, and then click [Properties]. The [Printer Properties] dialog box appears.
- 3. Make the necessary settings, and then click [OK].
- 4. Click [OK] to start printing.

Note

- The procedure to open the [Printer Properties] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

RPCS - Accessing the Printer Properties

There are two dialog box types of the [Printer Properties] dialog box. "Multi-tab" is used as an example in this manual. For details about changing the dialog box types, see the printer driver Help.

Multi-tab

This dialog box type is designed for users who often change print settings to perform various printing operations.

Custom Setting

This dialog box type is designed for users who rarely change print settings. This type of dialog box may vary depending on the installed options.

Windows 95/98/Me - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings

To make the printer default settings, open the [Printer Properties] dialog box from the [Printers] window.

🚼 Important

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

When you open the [Printer Properties] dialog box initially after installing the RPCS printer driver, a confirmation message appears. After clicking [OK], the [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Note

- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printer Properties] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 95/98/Me.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

2. Select the printer you want to use in the [Name:] list, and then click [Properties...].

The [Printer Properties] dialog box appears.

- 3. Make the necessary settings, and then click [OK].
- 4. Click [OK] to start printing.

Note

- The procedure to open the [Printer Properties] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows 2000 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🔁 Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

2. Click the icon of the printer you want to use.

3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

When you open the [Printer Properties] dialog box initially after installing the RPCS printer driver, a confirmation message appears. After clicking [OK], the [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

🖖 Note

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Printing Preferences

Content Important

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Printing Preferences...].

The [Printing Preferences] dialog box appears.

4. Make the necessary settings, and then click [OK].

Vote

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printing Preferences] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 2000.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Select Printer] list.
- 3. Make the necessary settings, and then click [Print] to start printing.

Note

- The procedure to open the [Printing Preferences] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows XP, Windows Server 2003/2003 R2 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🔁 Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

When you open the [Printer Properties] dialog box initially after installing the RPCS printer driver, a confirmation message appears. After clicking [OK], the [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Vote

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Printing Preferences

🔁 Important

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- On the [Start] menu, click [Printers and Faxes]. The [Printers and Faxes] window appears.
- 2. Click the icon of the printer you want to use.
- **3.** On the [File] menu, click [Printing Preferences...]. The [Printing Preferences] dialog box appears.
- 4. Make the necessary settings, and then click [OK].

🕗 Note 👘

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printing Preferences] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows XP.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Select Printer] list.
- 3. Make the necessary settings, and then click [Print] to start printing.

Note

- The procedure to open the [Printing Preferences] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows NT 4.0 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🚼 Important

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The printer properties dialog box appears.

When you open the printer properties dialog box initially after installing the RPCS printer driver, a confirmation message appears. After clicking [OK], the [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Vote

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Default

C Important

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- On the [File] menu, click [Document Defaults...].
 The [Default] dialog box appears.
- 4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printer Properties] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows NT 4.0.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

Select the printer you want to use in the [Name] list, and then click [Properties].

The [Printer Properties] dialog box appears.

- 3. Make the necessary settings, and then click [OK].
- 4. Click [OK] to start printing.

Note

- The procedure to open the [Printer Properties] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

PostScript 3 - Setting Up for Printing

Windows 95/98/Me - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings

To make the printer default settings, open the [Printer Properties] dialog box from the [Printers] window.

🔁 Important

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Note

- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printer Properties] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 95/98/Me.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- Select the printer you want to use in the [Name...] list, and then click [Properties...]. The [Printer Properties] dialog box appears.
- 3. Make the necessary settings, and then click [OK].
- 4. Click [OK] to start printing.

Note

- The procedure to open the [Printer Properties] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings
 made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows 2000 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🚼 Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Vote

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Printing Preferences

🔁 Important

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Printing Preferences...]. The [Printing Preferences] dialog box appears.

4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printing Preferences] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 2000.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Select Printer] list.
- 3. Make the necessary settings, and then click [Print] to start printing.

Note

- The procedure to open the [Printing Preferences] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows XP, Windows Server 2003/2003 R2 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🚼 Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Printing Preferences

🚼 Important

- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Printing Preferences...]. The [Printing Preferences] dialog box appears.
- 4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printing Preferences] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows XP.

1. On the [File] menu, click [Print...].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Select Printer] list.
- 3. Make the necessary settings, and then click [Print] to start printing.

Note

- The procedure to open the [Printing Preferences] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Windows NT 4.0 - Accessing the Printer Properties

This describes how to launch printer driver's properties.

Making Printer Default Settings - The Printer Properties

🚼 Important

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- 1. On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2. Click the icon of the printer you want to use.
- 3. On the [File] menu, click [Properties].

The [Printer Properties] dialog box appears.

4. Make the necessary settings, and then click [OK].

• Note

- Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].
- For details about settings, see the printer driver Help.

Making Printer Default Settings - Default

Mission Important

2

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- You cannot change the printer default settings for each user. Settings made in the [Printer Properties] dialog box are applied to all users.
- On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- 2. Click the icon of the printer you want to use.
- On the [File] menu, click [Document Defaults...].
 The [Default] dialog box appears.
- 4. Make the necessary settings, and then click [OK].

Note

- Settings you make here are used as the default settings for all applications.
- For details about settings, see the printer driver Help.

Making Printer Settings from an Application

You can make printer settings for a specific application. To make printer settings for a specific application, open the [Printer Properties] dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows NT 4.0.

1. On the [File] menu, click [Print].

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Name:] list, and then click [Properties]. The [Printer Properties] dialog box appears.
- 3. Make the necessary settings, and then click [OK].
- 4. Click [OK] to start printing.

Note

- The procedure to open the [Printer Properties] dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- Any settings you make in the following procedure are valid for the current application only.
- General users can change the properties displayed in the [Print] dialog box of an application. Settings made here are used as defaults when printing from this application.
- For details about settings, see the printer driver Help.

Mac OS - Setting Up for Printing

Making Paper Settings from an Application

- 1. Open the file you want to print.
- 2. On the [File] menu, click [Page Setup].
- 3. Check that the printer you want to use is displayed in [Printer:], and then select the paper size you want to use in [Paper:].

Under Mac OS X, select the paper size in [Paper Size].

If the printer you want to use is not displayed in [Printer:], select the printer you want to use.

4. Configure the settings, and then click [OK].

🕓 Note

• The [Page Setup] dialog box varies depending on the application you use. For details, see the manuals provided with the Mac OS.

Setting up for Printing from an Application

- 1. Open the file you want to print.
- 2. On the [File] menu, click [Print].
- 3. Check that the printer is selected in the [Printer] list, and then make the printer settings.
- 4. Configure the settings, and then click [OK].

2. Setting Up the Printer Driver

3. Other Print Operations

Printing a PDF File Directly

You can send PDF files directly to this printer for printing, without having to open a PDF application.

Comportant 🔿

- The function can be used with genuine Adobe PDF files only.
- This function supports version 1.3, 1.4, and 1.5 PDF files.
- Transparency (function of PDF version 1.4) may not be printed.
- PDF files created using Crypt Filter and/or the 16bit color image function of PDF version 1.5 cannot be printed.
- PDF version 1.6 (Acrobat 7.0) files created without any functions that are exclusive to PDF version 1.6 can be printed.
- Some types of High Compression PDF files may not be printed.

\rm Note

• Paper size errors may occur when printing on custom size paper.

Printing Method

The following procedures explain the two methods of direct PDF printing - using DeskTopBinder Lite or by entering commands.

Using DeskTopBinder Lite

Installing DeskTopBinder Lite

- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [DeskTopBinder SmartDeviceMonitor for Client] , and then click [Next >].
- 5. Follow the instructions on the display to install DeskTopBinder Lite.

If you are required to restart the computer after installing DeskTopBinder Lite, restart the computer and continue the configuration.

Note

 Auto Run may not work under certain operating system settings. In this case, launch "Setup.exe" located on the CD-ROM root directory.

DeskTopBinder Lite Enhancements

- On the [Start] menu, point to [Programs], [DeskTopBinder], and then click [Extended Features Wizard].
- 2. When [Extended Features Wizard] appears, select [Start], and then click [Next>] repeatedly until the [Printing Function2] screen appears.
- 3. On the [Printing Function2] screen, click [Add...] to display [PDF Direct Print Properties].
- 4. Select the driver for this printer, click [OK], and then click [Next >] repeatedly until [Finish] is displayed.
- 5. Click [Finish].

Function Palette

- Right-click the icon that is added to the task bar, and then click [Properties...] to display the [Properties] screen.
- Click the [Contents] tab, select the [PDF Direct Print] check box at the center, and then click [OK].

The [Properties] screen closes and the [PDF Direct Print] icon is added to the palette.

Note

 The Function palette contains buttons for functions that are already configured through DeskTopBinder Lite enhancement. Using these buttons, you can print Windows files, preview printouts, convert images, and register scanners for documents without having to open DeskTopBinder Lite. You can also use these functions simply by dragging a target file to the button corresponding to the required function and dropping it there.

PDF Direct Printing

- Drag the PDF file you want to print to the [PDF Direct Print] icon in the palette and drop it there.
- 2. [Output File List PDF Direct Print] is displayed.

Highlight the PDF you want to print, and then click [OK]. The PDF file is printed.

Printing PDF Password-Protected Documents

 On the [Start] menu, point to [Programs], [DeskTopBinder], and then click [Extended Features Wizard].

- 2. When [Extended Features Wizard] appears, select [Start], and then click [Next>] repeatedly until the [Printing Function2] screen appears.
- 3. On the [Printing Function2] screen, click [Properties] to display [PDF Direct Print Properties].
- Select the [Use PDF Password] check box at the bottom right of the screen, and then click [OK].

Click [Next>] repeatedly until [Finish] appears.

Click [Finish] to close the [Extended Features Wizard] screen.

- Move the PDF file you want to print to the [PDF Direct Print] icon on the palette using a dragand-drop operation.
- 6. [Output File List PDF Direct Print] is displayed.

Select the PDF file you want to output to make it reverse video, and then click [OK].

7. The [PDF Direct Print Properties] screen opens.


Enter the password for the PDF file you want to print in the [PDF Password:] field at the bottom right of the screen, and then click [OK].

The password-protected PDF file is printed.

Note

- Before printing a password-protected PDF file, perform one of the following:
 - Enter the PDF password in the [PDF Direct Print Properties] screen
 - Specify a PDF password by selecting [PDF: Change PW] in the [PDF Menu] on the control panel
 of this printer.
- If a [PDF Group PW] for the [PDF Menu] is assigned to either DeskTopBinder Lite or the control panel of this printer, a same group password needs to be assigned to the other.

PDF Direct Print Properties



1. Setting name:

Displays the plug-in configuration name (up to 63 single byte characters)

2. Change Icon...

Change the icon displayed on the tool bar.

3. Printer:

Displays a list of RPCS drivers that support PDF direct printing.

4. Duplex

Print on both sides of sheets.

5. Layout

Print multiple pages on a single sheet.

6. Punch (not selectable on this printer)

Punches holes in printed output.

7. Staple (not selectable on this printer)

Staples printed output together.

8. Display this dialog box before printing

Appears in PDF direct printing mode if this check box is selected.

9. Orientation:

Specify the original's orientation.

10. Number of copies

Specify the number of copies to print.

11. Collate

Use to sort prints.

12. Range:

Specify the print area on each page.

13. Resolution:

Specify a print resolution.

14. PDF Password:

If the PDF file is password-protected, enter the password in this field. Otherwise, the file cannot be printed.

15. Group Password:

If a group password is assigned to DeskTopBinder Lite and this printer, enter the group password in this field. Otherwise, printing cannot start.

Using Commands

Under Windows and UNIX, you can print PDF files directly, using commands such as "ftp" "sftp" and "lpr".

• p.269 "Printing Files Directly from Windows"

Unauthorized Copy Control

You can embed patterns and text under printed text to prevent unauthorized copying of the document. Unauthorized Copy Control consists of two functions: [Data security of copying] and [Mask type:].

Comportant 🗋

- This function is designed to discourage copying of confidential documents; it does not prevent unauthorized use of information.
- This function can be used with the RPCS printer driver.

Opening the Unauthorized Copy Control Window

- 1. In the RPCS printer driver, open the [Printing Preferences] window.
- 2. Click [Add/Change Custom Settings...].
- 3. Select the [Unauthorized copy...] check box.
- 4. Click [Control Settings...].
- 5. A confirmation message appears. Click [OK].

The Unauthorized Copy Control window appears.


Vote

• For details, see the printer driver Help.


Using [Data security for copying]

You can embed a pattern by setting it in the printer driver.

Setting [Data security for copying] in the printer driver



- Select the [Data security for copying] checkbox. You can also enter the text in the [Text:] box.
- You cannot select the [Mask type:] checkbox at the same time.
- To print a document protected by gray overprint, the printer must be set up correctly. Consult an administrator.



Printing a document using [Data security for copying]

- 1. The pattern and text you have set is printed.
- 2. The document is copied in copiers/multifunction machines which the supplier's optional Copy Data Security unit is installed.
- 3. The document is blanked by gray overprint.


Vote

- When printing a document that is set with [Data security for copying], the printer does not require the optional Copy Data Security unit to be installed. The Copy Data Security unit is required when copying or storing a document protected by gray overprint.
- Only the RPCS printer driver is supported.
- You cannot partially embed a pattern and text in a document.
- Use $182 \times 257 \text{ mm} (7^{1}/_{4} \times 10^{1}/_{2} \text{ in.})$ or larger paper.
- Use ordinary or recycled paper of at least 70% whiteness.
- Duplex printing may interfere with this function as a result of text and patterns being visible through the paper.
- The optional Copy Data Security Unit is for the supplier's copiers/multifunction machines. It cannot be installed on this printer.
- For details about setting [Data security for copying], see the printer driver Help.

Using [Mask type:]


You can embed patterns and text in a document by setting in the printer driver to prevent unauthorized copying.

Setting [Mask type:] in the printer driver



- Select a pattern from [Mask type:], and then enter text in the [Text:] box.
- You can set only [Text:], but [Mask type:] and [Text:] must be set together.

Printing a document using [Mask type:]



- 1. The pattern and text you have set is printed palely.
- 2. The document is copied in copiers/multifunction machines.
- 3. The pattern and text you have set appear clearly.

Vote

- Only the RPCS printer driver is supported.
- You cannot partially embed patterns and text strings in a document.
- To make the embedded pattern clear, set the character size at least 50 pt (preferably 70 to 80 pt) and character angle to between 30 and 40 degrees.
- Printing with background patterns and text may be slower than normal printing.
- For details about setting [Mask type:], see the printer driver Help.

Important Notice

- The supplier does not provide warranty regarding the appearance of print patterns and other copy protection features. The appearance of the print patterns and the performance of Unauthorized Copy Control may vary depending on the quality of paper used and the printer model and settings.
- The supplier takes no responsibility for any damages sustained in connection with use of or inability to make use of Unauthorized Copy Control print patterns.

Sample Print

Use this function to print only the first set of a multiple-set print job. After you have checked the result, remaining sets can be printed or canceled using the printer's control panel. This can reduce misprints due to mistakes in content or settings.

🚼 Important

- To use this function, the optional hard disk must be installed on the printer.
- A Sample Print file cannot be stored if:
 - the total number of Sample Print, Locked Print, Hold Print, and Stored Print files in the printer is over 100. (The maximum number varies depending on the volume of data in files.)
 - the file contains over 1,000 pages.
 - sent or stored files in the printer contain over 1,000 pages in total.

Vote

- If a Sample Print file has not been stored properly, check the error log on the control panel.
- Even after you turn off the printer, stored documents in the printer remain. However, the [Auto Del. Temp] or [Auto Del. Stored] settings are applied first.
- If the application has a collate option, make sure it is not selected before sending a print job. By default, Sample Print jobs are automatically collated by the printer driver. If a collate option is selected from the application's [Print] dialog box, more prints than intended may be produced.
- If the first set of the Sample Print files is not as you expected and you do not want to print remaining sets, delete the Sample Print file using the display panel. If you print the remaining sets of the Sample Print file, the job in the printer is deleted automatically.
- Sample Print files printed or deleted using Web Image Monitor, after you select [Sample Print] using the control panel will appear on the display panel. However, an error message will appear if you try to print or delete those Sample Print files.
- If stored files have similar and long file names, recognizing the file you want to print on the display panel may be difficult. Print the file you want to print either by checking the user ID or the time the file is sent, or by changing the file name to something that can be recognized easily.

Reference

- p.119 "Checking the Error Log"
- p.149 "System Menu"

Printing the First Set

The following procedure describes how to print a Sample Print file with the PCL 6/5e and the RPCS printer driver. For information about how to print a Sample Print file with the PostScript 3 printer driver, see Postscript 3 Supplement.

🔂 Important

- Applications with their own drivers, such as PageMaker, do not support this function.
- 1. From an application, select a command to print.

The [Print] dialog box appears.

Select the printer you want to use in the [Name] list, and then click [Properties].

The printer properties dialog box appears.

3. In the [Job Type:] box, click [Sample Print].

When printing with the PostScript 3 printer driver, click [Sample Print] in the [Job Type:] box on the [Job Log] tab.

4. Click [Details...], and then enter a User ID in the [User ID:] box.

This is used to identify the user. The user ID can be entered using up to eight alphanumeric (a-z, A-Z, 0-9) characters.

5. Execute a command to print.

Make sure to set more than two copies.

The Sample Print job is sent to the printer, and the first set is printed.

Printing the Remaining Sets

Printing a selected Sample Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Sample Print], and then press the [# Enter] key.
- 3. Press the [♥] or [▲] key to display [Print One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to print, and then press the [# Enter] key.
- Enter the number of sets you want to print using the [▲] or [▼] keys.

You can enter up to 999 sets.

If the number of sets to be printed is not specified, one less set than the smallest number specified on the machine is printed for every selected document. If the smallest number of sets specified on the machine is "1", one set each is printed for every document.

To cancel printing, press the [Escape] key.

6. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

7. Press the [Online] key.

The initial screen appears.

Printing all Sample Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Sample Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Print All File], and then press the [# Enter] key.

The user ID when the job was stored appear.

- Press the [♥] or [▲] key to display the user ID you want to print, and then press the [# Enter] key.
- 5. The number of documents selected for printing is displayed. Check the number, and if it is correct, press the [# Enter] key.
- 6. Enter the number of sets you want to print using the [▲] or [♥] keys.

You can enter up to 999 sets.

If the number of sets to be printed is not specified, one less set than the smallest number specified on the machine is printed for every selected document. If the smallest number of sets specified on the machine is "1", one set each is printed for every document.

To cancel printing, press the [Escape] key.

7. Press the [# Enter] key.

The "To print, press ESC 1 - 4 times" message appears. Then the file selection screen reappears.

8. Press the [Online] key.

The initial screen appears.

Note

- When printing is completed, the stored file will be deleted.
- To stop printing after printing has started, press the [Job Reset] key. The file will be deleted.

Deleting Sample Print Files

If you are not satisfied with the sample printout, you can delete the Sample Print file, revise it and print it again until the settings are suitable.

Deleting a selected Sample Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Sample Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

To cancel deleting a Sample Print file, press the [Escape] key.

- 5. Check the file you want to delete is displayed, and then press the [# Enter] key. The "Deleted" message appears. Then the file selection screen reappears.
- 6. Press the [Online] key.

The initial screen appears.

Deleting all Sample Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Sample Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID when the job was stored appear.
- Press the [▼] or [▲] key to display the user ID you want to delete, and then press the [# Enter] key.

To cancel deleting a Sample Print file, press the [Escape] key.

 The number of documents selected for deletion is displayed. Check the number, and if it is correct, press the [# Enter] key.

The "Deleted" message appears. Then the file selection screen reappears.

6. Press the [Online] key.

The initial screen appears.

Locked Print

Use this function to maintain privacy when printing confidential documents on the printer over a shared network. Usually, it is possible to print data using the display panel once it is stored in this printer. When using Locked Print, it is not possible to print unless a password is entered on the printer's display panel. Your confidential documents will be safe from being viewed by other people.

🚼 Important

3

- To use this function, the optional hard disk must be installed on the printer.
- A Locked Print file cannot be stored if:
 - the total number of Sample Print, Locked Print, Hold Print, and Stored Print files in the printer is over 100. (The maximum number varies depending on the volume of data in files.)
 - the file contains over 1,000 pages.
 - sent or stored files in the printer contain over 1,000 pages in total.

Note

- If a Locked Print file has not been stored properly, check the error log on the control panel.
- Even after you turn off the printer, stored documents remain. However, the [Auto Del. Temp] or [Auto Del. Stored] settings are applied first.
- If the application has a collate option, make sure it is not selected before sending a print job. Locked
 Print jobs are automatically collated by the printer driver as default. If a collate option is selected in
 the application print dialog box, more sets than intended may be printed.
- After the Locked Print file is printed, the job is automatically deleted.
- Locked Print files printed or deleted using Web Image Monitor, after you select [Locked Print] using the control panel will appear on the display panel. However, an error message will appear if you try to print or delete those Locked Print files.

Reference

- p.119 "Checking the Error Log"
- p.149 "System Menu"

Sending a Locked Print File

The following procedure describes how to print a Locked Print file with the PCL 6/5e and the RPCS printer driver. For information about how to print a Locked Print file with the PostScript 3 printer driver, see Postscript 3 Supplement.

Coloritant 🗋

• Applications with their own drivers, such as PageMaker, do not support this function.

3

1. From an application, select a command to print.

The [Print] dialog box appears.

- Select the printer you want to use in the [Name] list, and then click [Properties]. The [Printer Properties] dialog box appears.
- 3. In the [Job Type:] box, click [Locked Print].

When printing with the PostScript 3 printer driver, click [Locked Print] in the [Job Type:] box on the [Job Log] tab.

4. Click [Details...], and then enter a User ID in the [User ID:] box.

This is used to identify the user. The user ID can be entered using up to eight alphanumeric (a-z, A-Z, 0-9) characters.

- 5. In the [Password:] box, enter a four to eight digit password (0-9).
- 6. Execute a command to print.

The job is saved on the hard disk.

Printing a Locked Print File

Printing a selected Locked Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Locked Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Print One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to print, and then press the [# Enter] key.

The password screen appears.

Enter the password using the [▼] or [▲] key, and then press the [# Enter] key.

If you forget your password, ask your administrator for help.

Check that the file you want to print is displayed

To cancel printing, press the [Escape] key.

6. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

7. Press the [Online] key.

The initial screen appears.

Printing all Locked Print file

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Locked Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Print All File], and then press the [# Enter] key. The user ID when the job was stored appear.
- Press the [▼] or [▲] key to display the user ID you want to print, and then press the [# Enter] key.

The password screen appears.

5. Enter the password using the [♥] or [▲] key, and then press the [# Enter] key.

If you forget your password, ask your administrator for help.

6. The number of documents selected for printing is displayed. Check the number, and if it is correct, press the [# Enter] key.

The printer prints files that correspond to the entered password. The number of files to be printed is displayed on the confirmation screen.

The printer prints documents that correspond to the entered password. To print documents that do not correspond to the entered password, repeat the procedure and specify the appropriate password.

7. Check the file you want to print is displayed, and then press the [# Enter] key.

The "To print, press ESC 1 - 4 times" message appears. Then the file selection screen reappears.

8. Press the [Online] key.

The initial screen appears.

Vote

- When printing is completed, the stored file will be deleted.
- To stop printing after printing has started, press the [Job Reset] key. The file will be deleted.
- You can change a password after sending files to the printer using Web Image Monitor. For details about changing the password, consult your administrator.

Deleting Locked Print Files

Deleting a selected Locked Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

2. Press the [▼] or [▲] key to display [Locked Print], and then press the [♯ Enter] key.

3

- Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

The password screen appears.

- Enter the password using the [▼] or [▲] key, and then press the [# Enter] key.
 If you forget your password, ask your administrator for help.
- 6. Check the file you want to delete is displayed, and then press the [# Enter] key. The "Deleted" message appears. Then the file selection screen reappears.
- 7. Press the [Online] key.

The initial screen appears.

Deleting all Locked Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Locked Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID when the job was stored appear.
- Press the [▼] or [▲] key to display the user ID you want to delete, and then press the [# Enter] key.

The password screen appears.

To cancel deleting a Locked Print file, press the [Escape] key.

Enter the password using the [▼] or [▲] key, and then press the [# Enter] key.

If you forget your password, ask your administrator for help.

The printer deletes files that correspond to the entered password. The number of files to be deleted is displayed on the confirmation screen.

The printer deletes documents that correspond to the entered password. To delete documents that do not correspond to the entered password, repeat the procedure and specify the appropriate password.

 The number of documents selected for deletion is displayed. Check the number, and if it is correct, press the [# Enter] key.

The "Deleted" message appears. Then the file selection screen reappears.

7. Press the [Online] key.

The initial screen appears.

Hold Print

Use this function to temporarily hold a file in the printer, and print it from the computer or the printer's control panel later.

Comportant 🗋

- To use this function, the optional hard disk must be installed on the printer.
- A Hold Print file cannot be stored if:
 - the total number of Sample Print, Locked Print, Hold Print, and Stored Print files in the printer is over 100. (The maximum number varies depending on the volume of data in files.)
 - the file contains over 1,000 pages.
 - sent or stored files in the printer contain over 1,000 pages in total.

Vote

- If a Hold Print file has not been stored properly, check the error log on the control panel.
- Even after you turn off the printer, stored documents in the printer remain. However, the [Auto Del. Temp] or [Auto Del. Stored] settings are applied first.
- If the application has a collate option, make sure it is not selected before sending a print job. By default, Hold Print jobs are automatically collated by the printer driver. If a collate option is selected from the application's Print dialog box, more prints than intended may be produced.
- Hold Print files printed or deleted using Web Image Monitor, after you select [Hold Print] using the control panel will appear on the display panel. However, an error message will appear if you try to print or delete those Hold Print files.
- If stored files have similar and long file names, recognizing the file you want to print on the display panel may be difficult. Print the file you want to print either by checking the user ID or the time the file is sent, or by changing the file name to something that can be recognized easily. If you enter the document name on the printer driver's [Details...], that name appears on the display panel.
- The document name can be set for Hold Print Files, but they are not mandatory.

Reference

- p.119 "Checking the Error Log"
- p.149 "System Menu"

Hold Print Job to the Printer

The following procedure describes how to print a Hold Print file with the PCL 6/5e and the RPCS printer driver. For information about how to print a Hold Print file with the PostScript 3 printer driver, see Postscript 3 Supplement.

3

🔁 Important

- Applications with their own drivers, such as PageMaker, do not support this function.
- From an application, select a command to print. The [Print] dialog box appears.
- Select the printer you want to use in the [Name] list, and then click [Properties]. The [Printer Properties] dialog box appears.
- 3. In the [Job Type:] box, click [Hold Print].

When printing with the PostScript 3 printer driver, click [Hold Print] in the [Job Type:] box on the [Job Log] tab.

4. Click [Details...], and then enter a User ID in the [User ID:] box.

This is used to identify the user. The user ID can be entered using up to eight alphanumeric (a-z, A-Z, 0-9) characters.

You can also set a file name.

5. Execute a command to print.

Make sure to set more than two copies.

The Hold Print job is sent to the printer.

Printing a Hold Print File

Printing a selected Hold Print file only

🔁 Important

- Applications with their own drivers, such as PageMaker, do not support this function.
- 1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] to display key [Hold Print], and then press the [# Enter] key.
- Press the [▼] or [▲] to display key [Print One File], and then press the [# Enter] key.

The file name and the time when the job was stored appear.

 Press the [▼] or [▲] key to display the file you want to print, and then press the [# Enter] key.

To cancel printing, press the [Escape] key.

5. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

6. Press the [Online] key. The initial screen appears.

Printing all Hold Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Hold Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Print All File], and then press the [# Enter] key. The user ID when the job was stored appear.
- Press the [▼] or [▲] key to display the user ID you want to print, and then press the [# Enter] key.
- 5. The number of documents selected for printing is displayed. Check the number, and if it is correct, press the [# Enter] key.
- 6. Check the file you want to print is displayed, and then press the [# Enter] key.

The "To print, press ESC 1 - 4 times" message appears. Then the file selection screen reappears.

7. Press the [Online] key.

The initial screen appears.

🕓 Note

- When printing is completed, the stored file is deleted.
- To stop printing after printing has started, press the [Job Reset] key. The file is deleted.
- For details about setting printer drivers, see the printer driver Help. You can also print or delete a Hold Print file from Web Image Monitor. For details, see Web Image Monitor Help.

Deleting Hold Print Files

Deleting a selected Hold Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Hold Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.

 Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

To cancel deleting a Hold Print file, press the [Escape] key.

- 5. Check the file you want to delete is displayed, and then press the [# Enter] key. The "Deleted" message appears. Then the file selection screen reappears.
- 6. Press the [Online] key.

The initial screen appears.

Deleting all Hold Print files

- 1. Press the [Menu] key. The [Menu] screen appears.
- 2. Press the [▼] or [▲] key to display [Hold Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID when the job was stored appear.
- Press the [▼] or [▲] key to display the user ID you want to delete, and then press the [# Enter] key.

To cancel deleting a Hold Print file, press the [Escape] key.

5. The number of documents selected for deletion is displayed. Check the number, and if it is correct, press the [# Enter] key.

The "Deleted" message appears. Then the file selection screen reappears.

6. Press the [Online] key.

The initial screen appears.

Stored Print

Use this function to store a file in the printer, and then print it from the computer or the printer's control panel later. Jobs are not deleted after they are printed, so the same job need not be resent in order to print multiple copies.

🔁 Important

- To use this function, the optional hard disk must be installed on the printer.
- A Stored Print file cannot be stored if:
 - the total number of Sample Print, Locked Print, Hold Print, and Stored Print files in the printer is over 100. (The maximum number varies depending on the volume of data in files.)
 - the file contains over 1,000 pages.
 - sent or stored files in the printer contain over 1,000 pages in total.

Note

- If a Stored Print file has not been stored properly, check the error log on the control panel.
- Even after you turn off the printer, stored documents remain. However, the [Auto Del. Temp] or [Auto Del. Stored] settings are applied first.
- If the application has a collate option, make sure it is not selected before sending a print job. By default, Stored Print jobs are automatically collated by the printer driver. If a collate option is selected from the application's Print dialog box, more prints than intended may be produced.
- Stored Print files deleted using Web Image Monitor, after you select [Stored Print] using the control panel will appear on the display panel. However, an error message will appear if you try to delete those Stored Print files.
- If stored files have similar and long file names, recognizing the file you want to print on the display panel may be difficult. Print the file you want to print either by checking the user ID or the time the file is sent, or by changing the file name to something that can be recognized easily.
- If you enter the document name on the printer driver's [Details...], that name appears on the display panel.
- A password and document name can be set for Stored Print Files, but they are not mandatory.

Reference

- p.119 "Checking the Error Log"
- p.149 "System Menu"

Stored Print Job to the Printer

The following procedure describes how to print a Stored Print file with the PCL 6/5e, RPCS and Postscript 3 printer driver. For information about how to print a Stored Print file with the PostScript 3 printer driver, see Supplement included.

Coloritant 🔂

- Applications with their own drivers, such as PageMaker, do not support this function.
- 1. From an application, select a command to print.

The [Print] dialog box appears.

- 2. Select the printer you want to use in the [Name] list, and then click [Properties].
- 3. Start printing from the application's [Print] dialog box.

You can select two ways for Stored Print:

• [Stored Print]

Stores the file in the printer and print it later using the control panel.

• [Store and Normal Print] (or [Stored and Print])

Prints the file at once and also stores the file in the printer.

For details about configuring the printer drivers, see the relevant Help files.

4. Click [Details...], and then enter a User ID in the [User ID:] box.

You can also set a password. The same password must be entered when printing or deleting. You can set a file name.

5. Execute a command to print.

The Stored Print job is sent to the printer and stored.

Printing a Stored Print File

Printing a selected Stored Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Stored Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Print One File], and then press the [# Enter] key. The file name and the time when the job was stored appear. To cancel printing, press the [Escape] key.

Press the [▼] or [▲] key to display the file you want to print, and then press the [# Enter] key.

If you set a password in the printer driver, a password confirmation screen appears. Enter the password.

5. Enter the number of sets you want to print using the [▲] or [▼] keys.

You can enter up to 999 sets.

If the number of sets to be printed is not specified, one less set than the smallest number specified on the machine is printed for every selected document. If the smallest number of sets specified on the machine is "1", one set each is printed for every document.

To cancel printing, press the [Escape] key.

6. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

7. Press the [Online] key.

The initial screen appears.

Printing all Stored Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Stored Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Print All File], and then press the [# Enter] key. The user ID when the job was stored appear.
- Press the [▼] or [▲] key to display the user ID you want to print, and then press the [# Enter] key.
- 5. The number of documents selected for printing is displayed. Check the number, and if it is correct, press the [# Enter] key.
- 6. Enter the number of sets you want to print using the [▲] or [▼] keys.

You can enter up to 999 sets.

If the number of sets to be printed is not specified, one less set than the smallest number specified on the machine is printed for every selected document. If the smallest number of sets specified on the machine is "1", one set each is printed for every document.

To cancel printing, press the [Escape] key.

7. Press the [# Enter] key.

The "To print, press ESC 1 - 4 times" message appears. Then the file selection screen reappears.

8. Press the [Online] key.

The initial screen appears.

3

Note

- The machine prints files that correspond to the entered password and files that do not require a password.
- To stop printing after printing has started, press the [Job Reset] key. A Stored Print file is not deleted even if the [Job Reset] key is pressed.
- The Stored Print file that sent to the printer is not deleted unless you delete a file or select [Auto Del. Stored].
- You can change a password after sending files to the printer using Web Image Monitor. For details about changing the password, consult your administrator.
- For details about setting printer drivers, see the printer driver Help. You can also print or delete a Stored Print file from Web Image Monitor. For details, see Web Image Monitor Help.

Reference

• p.149 "System Menu"

Deleting Stored Print Files

Deleting a selected Stored Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Stored Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

To cancel deleting a Stored Print file, press the [Escape] key.

If you set the password in the printer driver, enter the password to delete.

If you forget your password, ask your administrator for help.

- 5. Check the file you want to delete is displayed, and then press the [# Enter] key. The "Deleted" message appears. Then the file selection screen reappears.
- 6. Press the [Online] key.

The initial screen appears.

Deleting all Stored Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [♥] or [▲] key to display [Stored Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID when the job was stored appear.
- Press the [♥] or [▲] key to display the user ID you want to delete, and then press the [# Enter] key.

To cancel deleting a Stored Print file, press the [Escape] key.

If you set the password in the printer driver, enter the password to delete.

If you forget your password, ask your administrator for help.

5. The number of documents selected for deletion is displayed. Check the number, and if it is correct, press the [# Enter] key.

The "Deleted" message appears. Then the file selection screen reappears.

6. Press the [Online] key.

The initial screen appears.

Note

• If a password is assigned to the file, the password screen appears. Enter the password. The machine deletes files that correspond to the entered password and files that do not require a password. To delete files that do not correspond to the entered password, repeat the procedures and specify the appropriate password.

3

Form Feed

This section gives instructions for operating the printer when there is no tray for the selected paper size or type, or when paper loaded in the printer has run out.

🔁 Important

- The tray cannot be changed if the following functions are set:
 - Duplex Print from a tray that does not support duplex printing
 - Cover Sheet
 - Slip Sheet

Note

- If form feed is selected for a tray with the following settings, you can change the tray by canceling the settings:
 - Duplex Print

Reference

• p.149 "System Menu"

Printing from a Selected Tray

If the printer does not have a tray for the selected paper size or paper type, or if the selected paper loaded in the printer has run out, a caution message appears. If this message appears, do the following procedure.

- 1. Press the [Form Feed] key, and then select the paper tray on the screen.
- 2. Press the [# Enter] key.

The job is printed from the selected tray.

Note

• If a tray with a smaller paper size is selected, the print job may be cut short, or other problems may occur.

Canceling a Print Job

You can cancel printing from either the printer or a client computer. Since canceling procedures vary depending on the print job status, check the job status and cancel printing according to the following procedure.

Windows - Canceling a Print Job

Comportant 🔁

 When the printer is connected to multiple computers, be careful not to accidentally cancel other users' print jobs.

If the print job you want to cancel is being printed

1. Check if the print job you want to cancel is currently being printed.

While the print job may not be being printed, the printer is receiving data if the Data In indicator is lit or blinking.

2. Press the [Job Reset] key.

The "Job Reset?" screen appears.

3. Select the current job or all jobs (including the current job) using the [▲] or [▼] key.

It is also possible to annul the cancellation. Printing resumes if you select [Resume Print], and then press the [# Enter] key.

4. Press the [# Enter] key.

A confirmation message appears.

Printing resumes if you press the [Escape] key after the message appears.

5. Press the [# Enter] key.

The job is canceled. When the cancellation procedure is complete, a message appears.

Vote

- A print job that contains a large volume of data may take considerable time to cancel.
- If printing resumes after being canceled, the period of time set for [I/O Timeout] is too short. Set a longer period of time for [I/O Timeout] on the [Host Interface] menu.

If the print job you want to cancel is not being printed

1. Double-click the printer icon on the Windows task tray.

A window appears showing all print jobs that are currently queuing to be printed. Check the current status of the job you want to cancel.

3

You can also open the print job queue window by double-clicking the printer icon in the [Printer] window.

- 2. Select the name of the job you want to cancel.
- 3. On the [Document] menu, click [Cancel Printing].

Note

- When this printer is used as a network printer, other users' print jobs cannot be canceled from a client computer.
- Clicking [Purge Print Documents] on the [Printer] menu deletes all currently queued print jobs. However, when this printer is used as a network printer, print jobs from other users' computer cannot be canceled from a client computer.
- When the print job you selected starts printing, it takes some time before the print job disappears from the printer window.

Mac OS - Canceling a Print Job

🚼 Important

 When the printer is connected to multiple computers, be careful not to accidentally cancel other users' print jobs.

If the print job you want to cancel is being printed

1. Check if the print job you want to cancel is currently being printed.

While the print job may not be being printed, the printer is receiving data if the Data In indicator is lit or blinking.

2. Press the [Job Reset] key.

The "Job Reset?" screen appears.

Select the current job or all jobs (including the current job) using the [▲] or [▼] key.

It is also possible to annul the cancellation. Printing resumes if you select [Resume Print], and then press the [# Enter] key.

4. Press the [# Enter] key.

A confirmation message appears.

Printing resumes if you press the [Escape] key after the message appears.

5. Press the [# Enter] key.

The job is canceled. When the cancellation procedure is complete, a message appears.

Vote

• A print job that contains a large volume of data may take considerable time to cancel.

 To secure enough time for sending a command to cancel printing, set a long period of time in [I/O Timeout] on the [Host Interface] menu.

If the print job you want to cancel is not being printed

1. Double-click the printer icon on the desktop.

A window appears showing all print jobs that are currently queuing to be printed. Check the current status of the job you want to cancel.

Under Mac OS X, start Print Center.

- 2. Select the name of the job you want to cancel.
- 3. Click the pause icon, and then click the trash icon.
- Note
 - When this printer is used as a network printer, other users' print jobs cannot be canceled from a client computer.

Checking the Error Log

If files could not be stored due to printing errors, identify the cause of the errors by checking the error log on the control panel.

C Important

- The most recent 30 errors are stored in the error log. If a new error is added when there are 30 errors already stored, the oldest error is deleted. However, if the oldest error belongs to one of the following print jobs, it is not deleted. The error is stored separately until the number of those errors reaches 30. You can check any of these print jobs for error log information.
 - Sample Print
 - Locked Print
 - Hold Print
 - Stored Print
- If the main power switch is turned off, the log is deleted.
- 1. Press the [Menu] key.

The [Menu] screen appears.

- Press the [▲] or [▼] key to display the print type you want to check, and then press the [# Enter] key.
- 3. Press the [▲] or [▼] key to display [Error File(s)], and then press the [# Enter] key.
- 4. Press the [▲] or [▼] key to check the log.

Note

- Press the [Online] key until the initial screen appears after checking the log.
- To print files that appear in the error log, resend them after stored files have been printed or deleted.


Collate

The Collate function allows you to print while sorting printouts into page-ordered sets, such as when printing multiple copies of meeting materials.

Comportant 🗋

- To use these functions, an optional memory unit of at least 192 MB or the optional hard disk drive must be installed on the printer.
- Up to 100 pages can be sorted using RAM. If the optional hard disk drive is installed, up to 1,000 pages can be sorted.

Output can be assembled as sets in sequential order.



Note

- If Auto Continue occurs on the first set, Collate will be canceled.
- If forced printing occurs on the first set, Collate will be canceled.
- When setting Collate in the printer driver settings, make sure that a collate option is not selected in the application's print settings. If a collate option is selected, printing will not be as intended.
- For details about printing method, see the printer driver Help.

Spool Printing

With Spool Printing, the print data is saved in the hard disk before printing. To use this function, set it from the menu. See Remote Maintenance by telnet.

🔂 Important

- Use the "spoolsw clear job" telnet command to clear a spooled print job. Do not turn off the printer or computer while a print job is being spooled and the Data In is flashing. Print jobs that are interrupted in this way remain on the printer's hard disk and will finish printing out when the printer is turned back on.
- The Spool Printing function is available when the optional hard disk is installed.
- The Spool Printing function is available for data received using diprint, lpr, ipp and ftp (TCP/IP (IPv6)).
- When using diprint, the Spool Printing function cannot be used with bidirectional communication.
- The domain reserved for spool printing is about 1 GB.
- Up to 150 jobs can be spool printed at a time.
- When Spool Printing is on, the size of a single print job cannot exceed 500 MB.
- When receiving jobs from multiple computers, the printer can spool a maximum of ten lpr jobs, and only one diprint, ipp, ftp, sftp, or smb job. If the printer's spooling capacity is exceeded, newer jobs cannot be printed. You must wait before sending further jobs.

Vote

- Printing the first page with Spool Printing will be slow.
- The computer requires less print processing time when large amounts of data are spooled.
- Stored spool jobs can be viewed or deleted using Web Image Monitor.
- The list of spool jobs cannot be viewed from the printer's control panel.

Reference

• p.197 "Remote Maintenance by telnet"

Setting Spool Printing

Spool printing settings can be made using telnet or Web Image Monitor.

Using Web Image Monitor

In [System] on the [Configuration] menu, click [Active] in [Spool Printing].

• Using telnet

Enter "spoolsw spool on".

Reference

- p.197 "Remote Maintenance by telnet"
- p.171 "Using Web Image Monitor"
- Web Image Monitor Help

Viewing or Deleting spooled jobs using Web Image Monitor

Follow the procedure below to check or delete spooled jobs using Web Image Monitor.

- 1. Open a Web browser.
- 2. Enter "http://(printer's address)/" in the address bar to access the printer whose settings you want to change.

Top Page of Web Image Monitor appears.

3. Click [Login].

The window for entering the login user name and password appears.

4. Enter the login user name and password, and then click [Login].

Contact your administrator for information about the settings.

5. In the menu area, click [Job].

A submenu will appear.

6. On the [Printer] menu, click [Spool Printing].

A list of spooled jobs appears.

- 7. To delete a job, select the check box of the job you want to delete, and then click [Delete]. The selected job is deleted.
- 8. Click [Logout].
- 9. Quit Web Image Monitor.

Reference

- p.171 "Using Web Image Monitor"
- Web Image Monitor Help

Using this function, you can insert cover fed from a different tray to that of the main paper, and print on them.

Coloritant 🔂


- To use this function, Collate must be set.
- The cover sheets should be the same size and orientation as the body of the paper.

Cover sheet

Prints the first page of the document on the sheet for the cover page.

• Print on one side


Prints on one side of the cover sheet only, even when duplex printing is selected.




• Print on both sides

Prints on both sides of the cover sheet when duplex printing is selected.

• Cover sheet printed on both sides




• Cover sheet printed on one side




- Blank
 - When printing one side

3



• When printing both sides



Vote

- If Auto Tray Select is set for the body paper feed tray, body paper will be delivered from a tray that contains paper set in portrait orientation. Therefore, if the cover paper is set to landscape orientation, the orientation of the cover and body paper will be different.
- For printing methods, see the printer driver Help.

Slip Sheets


This section explains the Slip Sheet Function that inserts a slip sheet between each page. When this function is enabled, paper is fed alternately from two trays.

Coloritant 🔁


- This function is available only if two or more paper trays are installed on the machine.
- When duplex or cover printing is set, you cannot insert slip sheets.

Inserting a slip sheet between each page

• Print




• Blank




Inserting a slip sheet between OHP transparencies

• Print



• Blank



- Collate cannot be set when using slip sheets.
- The slip sheet should be the same size and orientation as the main paper.
- If "Auto Tray Select" has been set as the paper feed tray for the body paper, the paper will be delivered from a tray containing paper in P orientation. Therefore, when the cover paper has been set to P orientation, the orientation of the output cover paper and body paper will be different.
- The same paper feed tray cannot be set for the main paper and slip sheets.

4. Using Paper Types that have Unique Names

From Registration of User Paper Types to Use

This section explains the procedures for selecting the paper type according to usage, registering the paper type under a unique name, and printing a file using the registered paper type.

🔁 Important

- This function can be used
 - when the machine is operating in a network,
 - in conjunction with the RPCS printer driver, and
 - under Windows 2000 or higher (under earlier systems, registered paper types appear as [Plain] in the printer driver).
- This function cannot be used
 - with the printer driver's [Save/Restore Settings] function (registered paper types appear as [Plain] in the printer driver) and
 - if the machine and computer are not using bi-directional communication.
- Also, be aware that
 - the printer driver might not display the paper type name correctly if it is registered using an unsupported language,
 - the control panel might not display the paper type name correctly if it is registered using nonalphanumeric characters (i.e., other than a-z, A-Z, or 0-9), and
 - the machine's logs do not record names of user paper types.

The example below explains setting a custom size paper under the name "Invoice A" and feeding it from a bypass tray.

- 1. Using Web Image Monitor, register the name under [User Paper Type].
 - Enter "Invoice A" for [Paper Name] and select [Plain Paper] for [Paper Type].
 - When printing a file, the paper type is automatically set by selecting [User Paper Types] on the printer driver setting screen.
 - For details about this procedure, see p.129 "Registering Names to Paper Types".
- 2. In Web Image Monitor, set [User Paper Type] for the bypass tray.
 - Set [Paper Type] for the tray to "Invoice A".
 - For details about this procedure, see p.130 "Setting User Paper Types to Trays".
- 3. Load the paper you want to use on the bypass tray.

4

- Set an unprinted paper on the bypass tray.
- For details about this procedure, see "Loading Paper", Hardware Guide.
- 4. Using RPCS Printer Driver, print a document on the registered custom size paper.
 - Select [Invoice A] for [Paper type:], then proceed with the printing. When [Paper type:] is set to [Invoice A], Plain paper that is suitable for "Invoice A" is selected automatically. Registering a descriptive name makes selecting a paper type from the [Paper type:] list easier.
 - For details about this procedure, see p.131 "Printing Using Registered Paper Types".

• You can register up to eight user paper types.

Registering Names to Paper Types

Log on to Web Image Monitor in the administrator mode.

🚼 Important 🔵

- The control panel might not display the paper type name correctly if it is registered using nonalphanumeric characters (i.e., other than a-z, A-Z, or 0-9).
- 1. Start your Web browser.
- 2. Enter "http://(printer's address)/" in the address bar of the Web browser.

The Top of Web Image Monitor appears.

If the printer's host name has been registered on the DNS or WINS server, you can enter it in the address bar.

If SSL (encrypted HTTP) is running in a server authentication environment, enter "https://(printer's address)".

3. On the Top Page, click [Login].

A dialog box for entering the user name and password appears.

4. Enter your login user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

- 5. In the menu area, click [Configuration].
- 6. On the [Device Settings], click [User Paper Type], and then change the settings as necessary. The screen for selecting [User Paper Type] appears.
- 7. Make changes to the following settings:

Paper Name: Enter a descriptive name for easier recognition.

Paper Type: Select a suitable paper type from the list.

The example below is for printing invoices.

- Enter "Invoice A" for [Paper Name].
- Select [Plain Paper] for [Paper Type]. If the setting is incorrect, the paper might become jammed or print quality could be affected.
- For details about combinations of paper sizes types, paper type, see "Types of Paper and Other Media", Hardware Guide.
- 8. Click [OK].



• You can register up to eight user paper types.

4

Setting User Paper Types to Trays

Before printing, set the paper registered on the user paper type to the paper tray, and then set the paper type already registered. Paper types can be set either from Web Image Monitor or from the printer's control panel.

- 1. Log on to Web Image Monitor in administrator mode.
- 2. In the menu area, click [Configuration].
- 3. On the [Device Settings], click [Paper].
- 4. Set the paper tray you want to use as a user paper type, and then select the registered paper type.

The example below is for printing invoices.

The registered paper type "Invoice A" is displayed as [+ Invoice A (Custom x)] on this screen. Select [+ Invoice A (Custom x)] for [User Paper Type]. Make the appropriate changes to other settings as required.

- 5. Click [OK].
- 6. Click [Logout].
- 7. Quit Web Image Monitor.
- Note
 - For details about loading paper, see "Loading Paper", Hardware Guide.
 - For details about setting the paper type from control panel, see "Specifying a Paper Type for Tray 1 and the Optional Paper Feed Unit" and "Specifying a Paper Type for the Bypass Tray", Hardware Guide.

Printing Using Registered Paper Types

Select a registered paper type to print onto.

🚼 Important

- This function can be used when the machine is operating in a network, in conjunction with the RPCS printer driver, and under Windows 2000 or higher (under earlier systems, registered paper types appear as [Plain] in the printer driver).
- This function cannot be used with the printer driver's [Save/Restore Settings] function (registered paper types appear as [Plain] in the printer driver) and if the machine and computer are not using bidirectional communication.
- Also, be aware that the printer driver might not display the paper type name correctly if it is registered using an unsupported language, the control panel might not display the paper type name correctly if it is registered using non-alphanumeric characters (i.e., other than a-z, A-Z, or 0-9), and the machine's logs do not record names of user paper types
- 1. Select your application's print command.
- 2. On the tab in the properties dialog box that appears, select a registered paper type under [Paper type:].

If you select Custom Setting, click the [Print Settings] tab.

3. Execute the print command.

The preregistered settings are applied and print is performed.

Note

• For details about printer driver settings, see the printer driver Help.

4. Using Paper Types that have Unique Names

5. Making Printer Settings Using the Control Panel

Menu Chart

This section explains how to change the default settings of the printer and provides information about the parameters included in each menu.

Sample Print

Menu
Print One File
Print All Files
Delete One File
Del. All Files
Error File(s)

Note

• This menu appears only if the optional hard disk is installed.

Locked Print

Same as the [Sample Print] menu.

Hold Print


Same as the [Sample Print] menu.

Stored Print

Same as the [Sample Print] menu.

Paper Input

٨	/lenu
Bypass Size	
Tray Paper Size	
Paper Type	
Duplex Setting	



• [Duplex Setting] appears when the optional duplex unit is installed.

List/Test	Print
-----------	-------

Menu
Multiple Lists
Config. Page
Error Log
Network Summary
Menu List
PCL Config.Page
PS Config. Page
PDF Config.Page
Hex Dump

Maintenance

Menu
Image Density
Registration
Curl Prevention
Del. All Temp
Del. All Stored
HD Format
Date/Time

Menu
WL.LAN Signal
WL.LAN Defaults
Panel Key Sound
Warm-Up Beeper

- [Del. All Temp] [Del. All Stored] [HDD Format] appear when the optional hard disk is installed.
- [WL.LAN Signal] and [WL.LAN Defaults] appear when the optional IEEE 802.11b interface unit is installed.

System

Menu
Prt. Err Report
Auto Continue
Memory Overflow
Copies
Printer Lang.
Sub Paper Size
Page Size
Edge-Edge Print
Def.Print Lang.
Duplex
Blank Pages
Rotate 180 Deg.
Energy Saver
Auto Reset Time
Auto Del. Temp

Menu
Auto Del.Stored
Memory Usage
Unit of Measure
Edge Smoothing
Toner Saving
Spool Printing
Letterhead Mode
Bypass Priority
Auto Tray SW
RAM Disk
Auto Email Ntfy

- [Auto Del. Temp] [Auto Del. Stored] [Spool Printing] appear when the optional hard disk is installed.
- [RAM Disk] will not appear when the optional hard disk is installed.

Host Interface

Menu	
I/O Buffer	
I/O Timeout	
Network Setup	
IEEE 802.11b	
Fixed USB Port	

Vote

- [Network Setup] appears when the optional Ethernet interface unit or IEEE 802.11b interface unit is installed.
- [IEEE 802.11b] appears when the optional IEEE 802.11b interface unit is installed.

PCL Menu

Menu
Orientation
Form Lines
Font Source
Font Number
Point Size
Font Pitch
Symbol Set
Courier Font
Ext. A4 Width
Append CR to LF
Resolution

PS Menu

Menu
Data Format
Resolution

PDF Menu

Menu
PDF: Change PW
PDF Group PW
Resolution

Language

Menu
English
German
French
Italian
Dutch
Swedish
Norwegian
Danish
Spanish
Finnish
Portuguese
Czech
Polish
Hungarian

Paper Input Menu

This section explains about paper settings on the Paper Input menu such as paper sizes and types on each tray.

Changing the Paper Input Menu

Auto Tray Select

Follow the procedure below to set Aut.Tray Select.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▲] or [▼] key to display [Paper Input], and then press the [# Enter] key.
- 3. Press the [▲] or [▼] key to display [Aut.Tray Select], and then press the [# Enter] key.
- Press the [▲] or [▼] key to display the tray you want to select, and then press the [# Enter] key.
- 5. Press the [▲] or [▼] key to display [On], and then press the [# Enter] key.

Wait two seconds. The [Aut.Tray Select] screen appears.

6. Press the [Online] key.

The initial screen appears.

Tray Priority

Follow the procedure below to change the tray priority.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▲] or [▼] key to display [Paper Input], and then press the [# Enter] key.
- 3. Press the [▲] or [▼] key to display [Tray Priority], and then press the [# Enter] key.
- Press the [▲] or [▼] key to select a tray you want to use, and then press the [# Enter] key. Wait two seconds. The [Paper Input] screen appears.
- 5. Press the [Online] key.

The initial screen appears.

5

Paper Input Menu Parameters

This section explains about parameters that can be set on the Paper Input menu.

Bypass Size

You can specify the paper size for Bypass Tray.

220-240V

A4 (210×297), A5 (148×210): Vert., A5 (148×210): Horiz., A6 (105×148), B5 JIS (182×257), C5 Env (162×229), C6 Env (114×162), DL Env (110×220), $8^{1}/{_{2}"\times14"}$, $8^{1}/{_{2}"\times13"}$, $8^{1}/{_{2}"\times11"}$, $8^{1}/{_{4}"\times13"}$, $8^{*}\times13"$, $7^{1}/{_{4}"\times10^{1}}/{_{2}"}$, $5^{1}/{_{2}"\times8^{1}}/{_{2}"}$: Vert., $5^{1}/{_{2}"\times8^{1}}/{_{2}"}$: Horiz., $4^{1}/{_{8}"\times9^{1}}/{_{2}"}$, $3^{7}/{_{8}"\times7^{1}}/{_{2}"}$, 16K (195×267), Custom Size

120V

8¹/₂"×14", 8¹/₂"×13", 8¹/₂"×11", 8¹/₄"×13", 8"×13", 7¹/₄"×10¹/₂", 5¹/₂"×8¹/₂": Vert., 5¹/₂"×8¹/₂": Horiz., 4¹/₈"×9¹/₂", 3⁷/₈"×7¹/₂", A4 (210×297), A5 (148×210): Vert., A5 (148×210): Horiz., A6 (105×148), B5 JIS (182×257), C5 Env (162×229), C6 Env (114×162), DL Env (110×220), 16K (195×267), Custom Size

Vote

- 220-240V Default: A4 (210×297)
- 120V Default: 8¹/₂" ×11"
- JIS stands for "Japanese Industrial Standard".

Tray Paper Size

Tray 1

You can specify the paper size for Tray 1.

220-240V

A5 (148×210): Horiz., 8¹/₂"×13", 8¹/₄"×13", 8"×13", 5¹/₂"×8¹/₂": Horiz., 16K (195×267), Custom Size

120V

8¹/₂"×13", 8¹/₄"×13", 8"×13", 5¹/₂"×8¹/₂": Horiz., A5 (148×210): Horiz., 16K (195×267), Custom Size

Vote

- 220-240V Default: A5 (148×210): Horiz.
- 120V Default: 8"×13"

Tray 2, Tray 3

You can specify the paper size for Tray 2 and Tray 3.

 220-240V

C5 Env (162×229), C6 Env (114×162), DL Env (110×220), $8^{1}/{_{2}^{"}}\times13^{"}$, $8^{1}/{_{4}^{"}}\times13^{"}$, $8^{"}\times13^{"}$, $7^{1}/{_{4}^{"}}\times10^{1}/{_{2}^{"}}$, $4^{1}/{_{8}^{"}}\times9^{1}/{_{2}^{"}}$, $3^{7}/{_{8}^{"}}\times7^{1}/{_{2}^{"}}$, 16K (195×267), Custom Size

8¹/₂"×13", 8¹/₄"×13", 8"×13", 7¹/₄"×10¹/₂", 4¹/₈"×9¹/₂", 3⁷/₈"×7¹/₂", C5 Env (162×229), C6 Env (114×162), DL Env (110×220), 16K (195×267), Custom Size

Note

- 220-240V Default: Custom Size
- 120V Default: 8"×13"

Paper Type

Tray 1

Plain Paper, Recycled Paper, Special Paper, Color Paper, Letterhead, Preprinted, Thick Paper, Custom Type 1-8

Note

- Default : Plain Paper
- For details about the type of paper loaded in each tray, see Hardware Guide.
- Be sure to set a paper type using the control panel. If you do not set it, the printing result might not be proper.

Tray 2, Tray 3

Plain Paper, Recycled Paper, Special Paper, Color Paper, Letterhead, Envelope, Preprinted, Thick Paper, Custom Type 1-8

Note

- Default : Plain Paper
- For details about the type of paper loaded in each tray, see Hardware Guide.
- Be sure to set a paper type using the control panel. If you do not set it, the printing result might not be proper.

Bypass Tray

Plain Paper, Recycled Paper, Special Paper, Color Paper, Letterhead, Transparency, Envelope, Preprinted, Thick Paper, Custom Type 1-8

Note

- Default : Plain Paper
- For details about the type of paper loaded in each tray, see Hardware Guide.
- Be sure to set a paper type using the control panel. If you do not set it, the printing result might not be proper.

Duplex Setting

Whether duplex printing is done in each tray is set.

- Duplex
- Do not duplex

• Default : Duplex

Aut.Tray Select

You can select whether to assign each tray to automatically print the paper size and type set by printer driver.

Note

- Default : On
- When using custom size paper, if [On] is selected in [Aut.Tray Select], the size selected on the control panel has priority, if [Off] is selected, the size selected from the printer driver has priority.
- Only installed trays appear on the display panel.
- You can select multiple trays.
- If you need to have a tray locked, you must select the tray using both printer driver and control panel.

Tray Priority

You can set a tray to be checked first when [Aut.Tray Select] is selected from the printer driver. The tray selected here is used when no tray is selected for a print job.

Note

- Default : Tray 1
- Only installed trays appear on the display panel.
- It is recommended that you load paper of the size and orientation you use most frequently in the tray selected in [Tray Priority].

List/Test Print Menu

You can print lists of configurations on printer or the paper printings. Also, you can check the types and characters of all the printable fonts.

Printing a Configuration Page

Follow the procedure below to print the configuration page.

🔁 Important

- The configuration page is printed on A4 or Letter (8¹/₂"×11") size paper, so load them in the same paper tray.
- 1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [List/Test Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Config. Page], and then press the [# Enter] key.

The configuration page is printed. The [List/Test Print] menu screen returns on completion of printing.

4. Press the [Online] key.

The initial screen appears.

Interpreting the Configuration Page

System Reference

Printer ID

The serial number assigned to the board by its manufacturer is displayed.

Pages Printed

The total number of pages printed by the printer to date is displayed.

Firmware Version

• Firmware

The version number of the printer controller firmware is displayed.

• Engine

The version number of the printer engine firmware is displayed.

NCS

The version number of the network interface board is displayed.

Device Connection

The items are displayed when the device options are installed.

HDD:Font / Macro Download

You can print the hard disk status when the optional hard disk when the optional hard disk is installed.

Printer Language

The version number of the printer language is displayed.

Connection Equipment

The options installed are displayed.

Paper Input

Settings made on the [Paper Input] menu are displayed.

🖪 Reference 🔵

• p.139 "Paper Input Menu"

Maintenance

Settings made on the [Maintenance] menu are displayed.

🖪 Reference 🔵

• p.146 "Maintenance Menu"

System

Settings made on the [System] menu are displayed.

🖪 Reference 🔵

• p.149 "System Menu"

PCL Menu

Settings made on the [PCL Menu] are displayed.

Reference

• p.163 "PCL Menu"

PS Menu

Settings made on the [PS Menu] are displayed.

Reference

• p.166 "PS Menu"

PDF Menu

Settings made on the [PDF Menu] are displayed.

Reference

• p.168 "PDF Menu"

Host Interface

Settings made on the [Host Interface] menu are displayed.

When DHCP is active on the network, the IPv4 address, subnet mask and gateway address appear in parentheses on the configuration page.

Reference

• p.157 "Host Interface Menu"

Interface Information

Interface information is displayed.

User Paper Type

Registered user paper types are displayed.

🖪 Reference 🔵

• p.127 "From Registration of User Paper Types to Use"

List/Test Print Menu Parameters

This section explains about parameters that can be set on the List/Test Print menu.

Multiple Lists

You can print the configuration page, error log and network summary.

Config. Page

You can print the current configuration of the printer.

Error Log

You can print an error report.

Network Summary

You can print the network device status.

Menu List

You can print a menu list showing all available menus.

PCL Config.Page

You can print the current configuration and installed PCL font list.

PS Config. Page

You can print the current configuration and installed PostScript font list.

PDF Config.Page

You can print the current configuration and installed PDF font list.

Hex Dump

You can print the data sent by the computer using Hex Dump.

Maintenance Menu

You can set printing conditions such as density and calibration, and printer management such as formatting the optional hard disk unit.

Changing the Maintenance Menu

This section explains changing the Maintenance menu using examples.

HD Format

Follow the procedure below to set HD Format.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Maintenance], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [HD Format], and then press the [# Enter] key.
- **4.** Read the HD format confirmation message, and then press the [# Enter] key. The hard disk unit is formatted, and the message appears.
- 5. Press the [# Enter] key.

The [HD Format] screen appears.

6. Press the [Online] key.

The initial screen appears.

🖪 Reference

• "Attaching Hard Disk Drive Type 2650", Hardware Guide.

Maintenance Menu Parameters

This section explains about parameters that can be set on the Maintenance menu.

Image Density

You can select the print image density.

-3 to 3

Reference

• "Adjusting the Image Density", Hardware Guide.

Registration

You can adjust the starting position of the printing page.

• Prt. Test Sheet

You can print the registration test sheet.

Tray 1, Tray 2, Tray 3, Bypass Tray, Duplex Unit

Note

- Only the installed trays appear on the display panel.
- Adjustment

You can select the start position for printing on a page.

Horiz.:Tray 1, Horiz.:Tray 2, Horiz.:Tray 3, Horiz.:Bypass, Horiz.:Dup.Back, Vert.:Std. Tray, Vert.:Opt. Tray, Vert.:Bypass, Vert.:Dup.Back

Note

• Only the installed trays appear on the display panel.

Curl Prevention

You can control the fuser temperature to prevent paper from curling.

- On
- Off

Vote

- Default: Off
- Use this mode only when paper misfeed occurs frequently during duplex printing.

Del. All Temp

This appears on the menu only when the hard disk is installed.

Use this function to delete all temporarily saved documents (Sample Print, Locked Print and Hold Print data) at once.

Del. All Stored

This appears on the menu only when the hard disk is installed.

Use this function to delete all saved documents (Stored Print data) at once.

HD Format

Appears when the hard disk is installed.

Date/Time

Use this to set the date and time.

WL.LAN Signal

You can check the signal strength when using LAN.

The menu appears when the 802.11b interface unit is installed.

WL.LAN Defaults

Reset the wireless LAN to default.

The menu appears when the 802.11b interface unit is installed.

Panel Key Sound

You can select whether or not to sound the beeper when the control panel is pressed.

- On
- Off

Note

• Default: On

Reference

• "Panel Tone", Hardware Guide.

Warm-Up Beeper

You can select whether or not to sound the beeper when the warming up is completed.

- On
- Off



• Default: On

System Menu

The System Menu allows you to set the printer's basic functions. Although you can operate the printer using the default settings, you can also change its settings to better suit your printing needs. Changes made to settings remain effective after power off.

Changing the System Menu

Follow the procedure below to change the settings for Energy Saver Timer.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press [▲] or [♥] key to display [System], and then press the [# Enter] key.
- 3. Press [▲] or [▼] key to display [Energy Saver], and then press the [# Enter] key.
- 4. Press the [▲] or [▼] key to display [E. Saver Timer], and then press the [# Enter] key.
- 5. Press the [▲] or [♥] key to select the lead time needed to switch to the Energy Saver mode.
- 6. Press the [# Enter] key.

Wait two seconds. The [Energy Saver] screen appears.

7. Press the [Online] key.

The initial screen appears.

System Menu parameters

This section explains about parameters that can be set on the System menu.

Prt. Err Report

You can select [On] or [Off] to have an error report printed when a printer error or memory error occurs.

- Off
- On

🕗 Note 💦 🔪

• Default: Off

Auto Continue

You can make the Auto Continue setting. When set to on, printing continues after a system error occurs.

- Off
- Immediate

- 1 minute
- 5 minutes
- 10 minutes
- 15 minutes

- Default: Off
- If you set [Auto Continue] to On, a job might be cancelled if an error occurs while it is printing out. When a job is cancelled due to error, the printer automatically begins the next job in the queue.

Memory Overflow

You can specify whether or not to print a memory overflow error report.

- Do not print
- Error Info.

Vote

• Default: Do not print

Copies

You can specify the number of pages to print.

This setting is disabled if the number of pages to print is specified by command or the printer driver.

• 1-999

Printer Lang.

You can specify the printer language.

- Auto Detect
- PCL
- PS
- PDF

Note

• Default: Auto Detect

Sub Paper Size

You can select [Off] or [Auto] to enable the Sub Paper Size function. When you select [Auto], the printer uses an alternative paper size if the currently specified paper is not loaded. When you select [Off], the printer uses any size paper in the current specified paper tray.

- Auto
- Off

• Default: Off

Page Size

You can specify the default paper size.

220-240V

A4 (210×297), A5 (148×210), A6 (105×148), B5 JIS (182×257), C5 Env (162×229), C6 Env (114×162), DL Env (110×220), 8¹/₂"×14", 8¹/₂"×13", 8¹/₂"×11", 8¹/₄"×13", 8"×13", 7¹/₄"×10¹/₂", 5¹/₂"×8¹/₂", 4¹/₈"×9¹/₂", 3⁷/₈"×7¹/₂", 16K (195×267), Custom Size

8¹/₂"×14", 8¹/₂"×13", 8¹/₂"×11", 8¹/₄"×13", 8"×13", 7¹/₄"×10¹/₂", 5¹/₂"×8¹/₂", 4¹/ 8×9¹/₂, 3⁷/₈"×7¹/₂", A4 (210×297), A5 (148×210), A6 (105×148), B6 JIS (182×257), C5 Env (162×229), C6 Env (114×162), DL Env (110×220), 16K (195×267), Custom Size

Note

- 220-240V Default: A4 (210×297)
- **120V** Default: 8¹/₂" ×11"
- The initial paper size is applied when the paper size is not specified in the print data.

Edge-Edge Print

You can print on the complete area of a sheet leaving no border on any edge.

- Off
- On

Note

• Default: Off

Def.Print Lang.

You can specify the initial printer language if the printer cannot detect the printer language.

- PCL
- PS
- PDF

Note

• Default: PCL

Duplex

You can specify whether or not to print on both sides of a sheet.

- Off
- Short Edge Bind
- Long Edge Bind

- Default: Off
- This menu appears only when the optional duplex unit is installed.

Blank Pages

You can specify whether or not to print blank pages.

- Print
- Do not print

Note

• Default: Print

Rotate 180 Deg.

You can select whether or not to rotate the image by 180 degrees when printing.

- On
- Off

Note

• Default: Off

Energy Saver

You can specify the number of minutes Energy Saver mode is applied.

E.Saver On/Off

You can specify whether or not to switch Energy Saver.

- On
- Off

Vote

- Default: On
- When the printer switches to Energy Saver mode, the Power indicator is unlit, but the Online indicator remains lit.

E.Saver Timer

You can select the lead time needed to switch to the Energy Saver mode. The Energy Saver mode reduces electric power consumption.

- 1 minute
- 5 minutes
- 15 minutes
- 30 minutes
- 45 minutes

• 60 minutes



• Default: 5 minute

Auto Reset Time

Auto Reset

Specify whether to revert to the initial configuration at certain interval. This also specifies the interval to reset the configuration.

- On
- Off



• Default: On

Reset Time(sec)

• 10 to 999 sec by 1 sec.



• Default: 60 seconds

Auto Del. Temp

This appears on the menu only when the hard disk is installed.

Specify whether to automatically delete temporarily saved documents (Sample Print, Locked Print and Hold Print data), such as sample print documents or confidential documents. Also specify the time period to elapse before deletion.

Auto Delete

- On
- Off

Vote

• Default: Off

Hours to Delete

• 1 to 200 hours by 1 hour.

Note

• Default: 8 hours

Auto Del.Stored

This appears on the menu only when the hard disk is installed.

Specify whether to automatically delete saved documents (Stored Print data).

Also specify the elapse time in days before deletion.

Auto Delete

- On
- Off

Note

• Default: On

Days to Delete

1 to 180 days by 1 day.

Note

• Default: 3 days

Memory Usage

You can select memory to be used from "Font Priority" or "Frame Priority".

- Font Priority
- Frame Priority

Note

• Default: Frame Priority

Unit of Measure

You can specify the unit of measurement in "mm" or "inch" for the custom paper size.

- mm
- inch

Note

• Default value is destination dependant.

Edge Smoothing

- On
- Off

Note

• Default: On

Toner Saving

• Off

• On

Note

• Default: Off

Spool Printing

You can select whether all of the print data is spooled to the hard disk drive before printing.

- On
- Off

Note

- Default: Off
- Spooling stores a sent print job temporarily in the printer, and then prints it.
- This menu appears only when the optional hard disk is installed.

Letterhead Mode

You can select the letterhead printing mode.

- Off
- Auto Detect
- On(Always)

Note

• Default: Off

Bypass Priority

When the different paper size or type is specified from the driver, you can specify which setting is given priority to, machine setting or command.

- Machine
- Driver/Command

Note

- Default: Driver/Command
- Appear only at network standard model.

Auto Tray SW

Specify the printer to change printing to the suitable tray, when printer driver specifies different paper size or type from the current tray.

• Off

• On

Vote

• Default: Off

RAM Disk

If the optional hard disk is not installed for PDF Direct Print, select a value of 2 MB or higher.

This menu appears only when the optional hard disk is not installed.

- 0 MB
- 2 MB
- 4 MB
- 8 MB
- 16 MB

• Note

- Default: 4 MB
- When the amount of SDRAM is small and RAM Disk is set to 16 MB, printing may not be possible depending on the print job and duplex printing may be canceled. If this happens, increase the amount of SDRAM, or set RAM Disk to 8 MB or less.
- For details about the optional SDRAM module, see Hardware Guide.

Reference

 "Attaching Memory Unit Type C 64MB/128MB/256MB (SDRAM Module)", Hardware Guide.

Auto Email Ntfy

You can specify whether or not to send an error message to a preset e-mail address when an error occurs in the printer.

- On
- Off

Note

- Default: On
- After changing the setting, turn off the power of the printer briefly, and then turn it on again.

Reference

• Web Image Monitor Help

Host Interface Menu

You can set configurations about network connections and communication when using parallel connection between the printer and the computer. The changed configuration holds even if the printer is turned off.

Changing the Host Interface Menu

Follow the procedure below to change the [I/O Timeout].

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Host Interface], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [I/O Timeout], and then press the [# Enter] key.
- Press the [▼] or [▲] key to select the lead time needed to end a printing operation, and then press the [# Enter] key.

Wait two seconds. The [I/O Timeout] menu appears.

5. Press the [Online] key.

The initial screen appears.

Host Interface Menu Parameters

This section explains parameters that can be set on the Host Interface menu.

I/O Buffer

You can select the size of I/O Buffer. Normally it is not necessary to change this setting.

- 128 KB
- 256 KB

Note

• Default: 128 KB

I/O Timeout

You can set how many seconds the printer should wait before ending a print job. If printing operation is frequently interrupted by data from other ports, you can increase the timeout period.

- 10 seconds
- 15 seconds
- 20 seconds
- 25 seconds

• 60 seconds

Vote

• Default: 15 seconds

Network Setup

You can make network-related settings.

This menu appears only when the optional 802.11b interface unit is installed.

Note

• For details about, see Hardware Guide.

IPv4 Settings

You can select whether to set the IPv4 address automatically or manually.

DHCP

On/Off (Default: On)

• IPv4 Address

You can specify the IPv4 address.

When DHCP is set to on, the IPv4 address cannot be changed. To change it, set DHCP to off. Contact your administrator for information about the network configuration.

Note

- Default: 0.0.0.0
- Subnet Mask

You can specify the subnet mask.

When DHCP is set to on, the subnet mask cannot be changed. To change it, set DHCP to off. Contact your administrator for information about the network configuration.



- Default: 0.0.0.0
- Gateway Address

You can specify the gateway address.

When DHCP is set to on, the gateway address cannot be changed. To change it, set DHCP to off. Contact your administrator for information about the network configuration.

Vote

• Default: 0.0.0.0

IPv6 Setting

• Stateless Sett.

You can enable or disable IPv6.

• Active

Not Active

Vote

• Default: Active

Frame Type (NW)

You can select the frame type for NetWare.

- Auto Select
- Ethernet II
- Ethernet 802.2
- Ethernet 802.3
- Ethernet SNAP

Note

• Default: Auto Select

Active Protocol

You can select the effective protocol.

• IPv4

Active, Not Active

Note

- Default: Active
- IPv6

Active, Not Active

Note

- Default: Not Active
- NetWare

Active, Not Active

Note

- Default: Active
- SMB

Active, Not Active

Note

- Default: Active
- AppleTalk

Active, Not Active

Note

• Default: Active

Ethernet Speed

You can select the network speed to operate the printer.

- Auto Select
- 10Mbps Half D.
- 10Mbps Full D.
- 100Mbps Half D.
- 100Mbps Full D.

Note

• Default: Auto Select

LAN Type

You can select Ethernet or IEEE 802.11b for LAN Type.

This menu appears only when the optional 802.11b interface unit is installed.

- Ethernet
- IEEE 802.11b

Note

• Default: Ethernet

IEEE 802.11b

You can make settings for wireless LAN. This menu appears only when the optional 802.11b interface unit is installed.

Comm. Mode

You can select the transmission mode for IEEE 802.11b.

- 802.11 Ad hoc
- Infrastructure
- Ad hoc

```
Note
```

- Default: 802.11 Ad hoc
- Comm. Mode can also be set using a Web Image Monitor. For details, see Web Image Monitor Help.

Channel

You can select channels:

220-240V 1-13 120V 1-11 ♦ Note • 220-240V 120V Default: 11

Trans. Speed

You can select the transmission speed for IEEE 802.11b.

- Auto
- 11 Mbps
- 5.5 Mbps
- 2 Mbps
- 1 Mbps

Note

• Default: Auto

SSID

You can set an SSID in the infrastructure mode and the 802.11 Ad hoc mode.

- View
- Enter ID

Note

- Default: blank (ASSID)
- Select [?] to enter [/] for the SSID. Also, [¥] appears when printing the configuration page, read it as [/].
- Characters used are ASCII 0x20-0x7e (32 bytes).
- An SSID is set automatically to the nearest access point if no SSID has been set.
- If no SSID has been set for the 802.11 ad hoc mode, an SSID is set automatically and the same SSID is used for the 802.11 ad hoc mode and the infrastructure mode.
- If blank is specified in SSID for 802.11b adhoc mode or adhoc mode, "ASSID" appears.
- An SSID can also be set using Web Image Monitor. For details, see Web Image Monitor Help.

Security Method

You can enable or disable encryption. You can also specify the security type when the encryption is enabled.

- None
- WEP

- Change (HEX): Enter the WEP key using a hexadecimal number sequence. When using 64 bit WEP, enter 10 ASCII characters. When using 128 bit WEP, enter 26 ASCII characters.
- Change (ASCII): Enter the WEP key using an ASCII character sequence. When using 64 bit WEP, enter 5 ASCII characters. When using 128 bit WEP, enter 13 ASCII characters.
- WPA

Encrypt. Meth.

- TKIP
- COMP(AES)

Authent. Meth.

- WPA-PSK: From 8 to 63 ASCII characters can be entered.
- WPA: When selecting this method, obtain a certificate using Web Image Monitor.
- WPA2-PSK: Same as WPA-PSK, 8 to 63 ASCII characters can be entered.
- WPA2: A supplemental specification of WPA. Fully compatible with IEEE802.11i.

PSK Entry: 8 to 63 characters can be entered.

Note

- Default: None
- The WEP key can also be set using Web Image Monitor. For details, see Web Image Monitor Help.

Fixed USB Port

- On
- Off

Note

- Default: Off
- The service engineer sets this function. Do not change this setting.

PCL Menu

You can set conditions when using PCL for printing.

Changing the PCL Menu

Follow the procedure below to change the setting for Orientation.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [PCL Menu], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Orientation], and then press the [# Enter] key.
- 4. Press the [▼] or [▲] key to select the orientation, and then press the [# Enter] key. Wait two seconds. The [Orientation] screen appears.
- 5. Press the [Online] key.

The initial screen appears.

PCL Menu Parameters

This section explains about parameters that can be set on the PCL menu.

Orientation

You can select the page orientation.

- Portrait
- Landscape

Vote

• Default: Portrait

Form Lines

You can specify the number of lines per page between 5 and 128.

Note

- 220-240V Default : 64
- 120V Default : 60

Font Source

You can set the location of the default font.

• Resident

- RAM
- HDD
- SD
- SD Font Download

- Default: Resident
- When you select [RAM], you can select only fonts downloaded to the printer RAM.
- When you select [HDD], you can select only fonts downloaded to the optional hard disk.
- When you select [SD], you can select only fonts for downloaded to the SD card.

Font Number

Specify the ID of the default font you want to use.

- 0 to 63 (Internal)
- 1 to X (Download; "X" is the number of downloaded fonts)

Point Size

You can specify the point size you want to use for the default font between 4 and 999.75 in 0.25 increments.

Note

- Default: 12.00 points
- This setting is effective only for a variable-space font.

Font Pitch

You can specify the number of characters per inch you want to use for the default font between 0.44 and 99.99 in 0.01 increments.

Note

- Default: 10.00 pitch
- This setting is effective only for fixed-space fonts.

Symbol Set

You can specify the character set for the default font. Available sets are as follows:

Roman-8, ISO L1, ISO L2, ISO L5, PC-8, PC-8 D/N, PC-850, PC-852, PC8-TK, Win L1, Win L2, Win L5, Desktop, PS Text, VN Intl, VN US, MS Publ, Math-8, PS Math, VN Math, Pifont, Legal, ISO 4, ISO 6, ISO 11, ISO 15, ISO 17, ISO 21, ISO 60, ISO 69, Win 3.0

Note

• Default: PC-8

Courier Font

You can select a courier-type font.

- Regular
- Dark

• Default: Regular

Ext. A4 Width

You can extend the width of the printable area of A4 sheets reducing side margin width.

- Off
- On

Note

• Default: Off

Append CR to LF

You can specify whether or not to append a CR code to each LF code to print text data clearly.

- Off
- On

• Note

• Default: Off

Resolution

You can specify the print resolution in dots per inch.

- 300 dpi
- 600 dpi

Note

• Default: 600 dpi

PS Menu

You can set conditions when using Postscript for printing.

Changing the PS Menu

Follow the procedure below to change the setting for date format.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [PS Menu], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Data Format], and then press the [# Enter] key.
- Press the [▼] or [▲] key to select [TBCP], and then press the [# Enter] key.

Wait two seconds. The [Data Format] screen appears.

5. Press the [Online] key.

The initial screen appears.

PS Menu Parameters

This section explains about parameters that can be set on the Postscript menu.

Data Format

You can select the data format.

- Binary Data
- TBCP

This setting is effective when using a parallel, USB, or EtherTalk connection.

When you use a parallel or USB connection, the print job is canceled if binary data is sent from the printer driver.

When you use an Ethernet connection, the print job is canceled if:

- The printer driver data format is TBCP and the data format selected using the control panel is Binary Data.
- The printer driver data format is binary and the data format selected using the control panel is TBCP.

\rm Note

Default: TBCP

Resolution

You can select the resolution.

- 300dpi
- 600dpi Fast
- 600dpi Std.

Note

• Default: 600dpi Fast

PDF Menu

You can set conditions when using PDF printing.

Changing the PDF Menu

Follow the procedure below to change the resolution setting.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▲] or [▼] key to display [PDF Menu], and then press the [# Enter] key.
- 3. Press the [▲] or [▼] key to display [Resolution], and then press the [# Enter] key.
- Press the [▲] or [▼] key to select the resolution, and then press the [# Enter] key.
 Wait two seconds. The [Resolution] screen appears.
- 5. Press the [Online] key.

The initial screen appears.

PDF Menu Parameters

This section explains about parameters that can be set on the PDF menu.

PDF: Change PW

You can specify the password for the PDF file executing PDF Direct Print.

🔂 Important

• If you do not set a PDF password, this menu does not appear.

Note

• The password can be set using Web Image Monitor, but must be sent through the network. For increased security, use this menu on the control panel to set the password directly.

PDF Group PW

You can set a group password specified using DeskTopBinder Lite.

Coloritant 🔂

• If you do not set a PDF group password, this menu does not appear.

Vote

- When you use a group password, the optional data protection unit must be installed.
- The password can be set using Web Image Monitor, but must be sent through the network. For increased security, use this menu on the control panel to set the password directly.

• Default: no password set

Resolution

You can select the resolution for the PDF file executing PDF Direct Print.

- 300dpi
- 600dpi Fast
- 600dpi Std.

Note

• Default: 600dpi Fast

Language Menu

You can set language displayed on the menu.

Changing the Language Menu

Follow the procedure below to change the language.

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▲] or [▼] key to display [Language], and then press the [# Enter] key.
- 3. Press the [▲] or [▼] key to select the language, and then press the [# Enter] key. Wait two seconds. The [Language] menu screen appears.
- 4. Press the [Online] key. The initial screen appears.

Language Menu Parameters

You can select the language you use. Available languages are as follows:

English, German, French, Italian, Dutch, Swedish, Norwegian, Danish, Spanish, Finnish, Portuguese, Czech, Polish, Hungarian.

Vote

• Default: English

6. Monitoring and Configuring the Printer

Using Web Image Monitor

Using Web Image Monitor, you can check the printer status and change settings.

Available operations

The following operations can be remotely performed using Web Image Monitor from a client computer.

- Displaying printer status or settings
- Checking the print job status or history
- Interrupting currently printing jobs
- Resetting the printer
- Managing the Address Book
- Making printer settings
- Making e-mail notification settings
- Making network protocol settings
- Making security settings

Configuring the printer

To perform the operations from Web Image Monitor, TCP/IP is required. After the printer is configured to use TCP/IP, operations from Web Image Monitor become available.

Recommended Web browser

• Windows:

Internet Explorer 5.5 SP2 or higher

Firefox 1.0 or higher

• Mac OS:

Firefox 1.0 or higher

Safari 1.0, 1.2, 2.0 (412.2) or higher

Web Image Monitor supports screen reader software

We recommend JAWS 7.0 or a later version.

Note

• Safari cannot be used on Mac OS X 10.4.1.

- Display and operation problems can occur if you do not enable JavaScript and cookies, or if you are using a non-recommended Web Browser.
- If you are using a proxy server, change the Web browser settings. Contact your administrator for information about the settings.
- If you click your browser's back button but the previous page does not appear, click the browser's refresh button and try again.
- Printer information is not automatically updated. To perform an update, click [Refresh] in the display area.
- We recommend using Web Image Monitor in the same network.
- You cannot access to the printer from outside the firewall.
- When using the printer under DHCP, the IPv4 address may be automatically changed by the DHCP server settings. Enable DDNS setting on the printer, and then connect using the printer's host name. Alternatively, set a static IPv4 address to the DHCP server.
- If the HTTP port is disabled, connection to the printer using the printer's URL cannot be established. SSL setting must be enabled on this printer. For details, consult your administrator.
- When using the SSL encryption protocol, enter "https://(printer's address)/". Internet Explorer must be installed on your computer. Use the most recent available version. We recommend Internet Explorer 6.0 or later.
- When you are using Firefox, fonts and colors may be different, or tables may be out of shape.
- To use JAWS 7.0 under Web Image Monitor, you must be running Windows OS and Microsoft Internet Explorer 5.5 SP2, or a later version.

Displaying Top Page

This section explains the Top Page and how to display Web Image Monitor.


- 1. Start your Web browser.
- 2. Enter "http://(printer's address)/" in the address bar of a Web browser.

Top Page of Web Image Monitor appears.

If the printer's host name has been registered on the DNS or WINS server, you can enter it.

When setting SSL, a protocol for encrypted communication, under environment which server authentification is issued, enter "https://(printer's address)/".

Every Web Image Monitor page is divided into the following areas:



1. Menu area

If you select menu, it's content will be shown on the work area, or the sub area.

2. Tab area

Details about each menu appears.

3. Header area

The dialog box for switching to the user mode and administrator mode appears, and each mode's menu will be displayed.

The link to help and dialog box for keyword search appears.

4. Help

Use Help to view or download Help file contents.

5. Display area

Displays the contents of the item selected in the menu area.

Machine information in the display area is not automatically updated. Click [Refresh] at the upper right in the display area to update the machine information. Click the Web browser's [Refresh] button to refresh the entire browser screen.

Note

• For details the printer's host name has been registered on the DNS or WINS server, see "Cautions to Take When Using in a Network".

Reference

• p.321 "Cautions to Take When Using in a network"

About Menu and Mode

There are two modes available with Web Image Monitor: guest mode and administrator mode.

Displayed items may differ depending on the printers.

About Guest Mode

In the guest mode, printer status, settings, and print job status can be viewed, but the printer settings cannot be changed.

	Web Image Monitor	• 9 7 j
Home Printer: Print Jobs Job Configuration	Home State Stress Mo Counter State Const Mon Counter Counter Counter Counter Counter Instate Instate Instate	
	Status	
	Printer 🐌 Ready 🔊 Printer:	2
		N
	Taner	
	Black 6 79 103	
	Input Tray	
Done 2	Input iray	C Sterr

1. Home

The [Status], [Device Info], and [Counter] tab are displayed. Details of the tab menu are displayed on the work area.

2. Printer: Print Jobs

Allows you to display list of Sample Print, Locked Print, Hold Print, and Stored Print jobs. Appear only when the optional hard disk is installed.

3. Job

Display all print files.

4. Configuration

Display current printer and network settings.

Administrator Mode

In the administrator mode, you can configure various printer settings.

Ple Edit Vev Povorke	i Tools Help	12 C
	의 @Search @Favorites @Hatory 관· @ 11	
Address 1 http://192.168.0.	54/web/entry/en/websys/web/arty/trainFrame.cgi	۰ ب ² ه
		🕫 🧣 ? i 🖬 Logout
	Web Image Monitor	1 Administrator
Address Book	Home States Device trifs Exactly Country Exactly Provided Technology Heart Clavics PRPAD/DDD Technology Device Technology	
	Status	<u>ـ</u>
	Printer 🖲 Ready 🔊 Printer:	
		E
	Toner	A
	Black Md 0 100 100	
	Input Troy	<u>م</u>
Done Done		tornatra 💿

1. Home

The [Status], [Device Info], and [Counter] tab are displayed. Details of the tab menu are displayed on the work area.

2. Printer: Print Jobs

Allows you to display list of Sample Print, Locked Print, Hold Print, and Stored Print jobs. Appear only when the optional hard disk is installed.

3. Job

Display all print files.

4. Address Book

User information can be registered, displayed, changed, and deleted.

5. Configuration

Make system settings for the printer, interface settings, and security.

6. Reset Device

Click to reset the printer. If a print job is being processed, the printer will be reset after the print job is completed. This button is located on Top Page.

7. Reset Print Job

Click to reset current print jobs and print jobs in queue. This button is located on Top Page.

Access in the Administrator Mode

Follow the procedure below to access Web Image Monitor in the administrator mode.

1. On Top Page, click [Login].

The dialog box for entering the user name and password appears.

2. Enter your login user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

Displaying Web Image Monitor Help

When using Help for the first time, clicking either [Help] in the header area or the icon marked "?" in the display area makes the following screen appear, in which you can view Help in two different ways, as shown below:

Viewing Help on our Web site

Downloading Help to your computer

Downloading and Checking Help

You can download Help to your computer. To view Help without connecting to the Internet, enter the path to your local Help files in your browser's URL bar.

Note

- By clicking [Help] in the header area, the contents of Help appear.
- You can view Help for a setting by clicking "?", the Help icon, in the display area.

Downloading Help

- 1. In the [OS] list, select the operating system.
- 2. In the [Language] list, select the language.
- 3. Click [Download].
- 4. Download Help by following the instructions on the screen.
- 5. Store the downloaded compressed file in a location, and then decompress the file.

To view the downloaded Web Image Monitor Help, set the path to the location of the decompressed file.

Linking the URL of the Help File to the Help Button

You can link the URL of the help file on a computer or Web server to the Help button.

- 1. Log on to Web Image Monitor in the administrator mode.
- 2. In the menu area, click [Configuration].
- 3. Click [Webpage].
- 4. In the [URL] box, enter the URL of the help file.

For example, if you saved the file to a Web server, and the URL of the index file is "http://a.b.c.d/ HELP/EN/index.html", enter "http://a.b.c.d/HELP/".

5. Click [OK].

Using SmartDeviceMonitor for Admin

Using SmartDeviceMonitor for Admin, you can monitor the network printers. Also, you can change the configuration of the network interface board using TCP/IP or IPX/SPX.

🔂 Important 🔵

• IPv6 cannot be used on this function.

Protocol stack provided with Operating System

• Windows 95/98/Me

TCP/IP

IPX/SPX

NetWare

NetWare Client32 for Windows 95

IntraNetWare Client for Windows 95

Novell Client for Windows 95/98/Me

• Windows 2000

TCP/IP

IPX/SPX

NetWare

Novell Client for Windows NT/2000/XP

• Windows Server 2003/2003 R2

TCP/IP

IPX/SPX

Windows XP

TCP/IP

IPX/SPX

Novell Client for Windows NT/2000/XP

• Windows NT 4.0

TCP/IP

IPX/SPX

Client Service for NetWare

NetWare Client32 for Windows NT

IntraNetWare Client for Windows NT

Novell Client for Windows NT/2000/XP

Available operations

The following functions are available:

- Printer Information function
 - Display the network settings and detailed information of the printer.
 - Display the number of pages printed under each user code.
 - Display the status of print jobs sent from computers.
 - Change the printer network settings.
- Device Settings function
 - Lock some of the setting items on the control panel so that they cannot be changed using the control panel.
 - Select type of paper loaded in the paper trays.
- Energy Saver function
 - Enable or disable the Energy Saver mode.
- System Status function
- Display the information such as when paper is depleted during printing on a computer.
- Groups function
 - Monitor multiple printers at the same time. When there are multiple printers to manage, you can create groups and classify the printers to facilitate management.
 - You can customize printer status according to groups, and send status notification e-mail to a computer.

Installing SmartDeviceMonitor for Admin

Follow the procedure below to install SmartDeviceMonitor for Admin.

- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3. Select an interface language, and then click [OK].

The default interface language is English.

- 4. Click [SmartDeviceMonitor for Admin] installation, and then click [Next>].
- The software license agreement appears in the [License Agreement] dialog box.
 After reading through its contents, click [Yes] if you agree, and then click [Next >].
- 6. Follow the instructions on the screen.

A message appears when the installation is complete.

7. Click [OK].

Note

- Auto Run may not work under certain operating system settings. In this case, launch "Setup.exe" located on the CD-ROM root directory.
- If you are required to restart the computer after installing SmartDeviceMonitor for Admin, restart the computer and continue the configuration.
- SmartDeviceMonitor for Admin supports following languages: Czech, Danish, German, English, Spanish, French, Italian, Hungarian, Dutch, Norwegian, Polish, Portuguese, Finnish, Swedish, Chinese Simple and Chinese Traditional.

Changing the Network Interface Board Configuration

Follow the procedure below to change the network interface board configuration using SmartDeviceMonitor for Admin.

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

A list of printers using the selected protocol appears. Select the protocol of the printer whose configuration you want to change.

If you are using IPv4 SNMPv3, enter the user authentication.

- 3. In the list, select a printer whose configuration you want to change.
- 4. On the [Tools] menu, click [NIB Setup Tool].

A Web browser opens and the dialog box for entering the user name and password for the Web Image Monitor administrator appears.

NIB Setup Tool starts when the network interface board is default. Follow the instruction on the screen.

5. Enter the login user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

- 6. Configure settings using Web Image Monitor.
- 7. Click [Logout].
- 8. Quit Web Image Monitor.
- 9. Quit SmartDeviceMonitor for Admin.

Reference

• p.171 "Using Web Image Monitor"

Locking the Menus on the Printer's Control Panel

Follow the procedure below to lock the menus on the printer's control panel.

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

A list of printers using the selected protocol appears.

Select the protocol of the printer whose configuration you want to change.

If you are using IPv4 SNMPv3, enter the user authentication.

- 3. Select a printer.
- 4. On the [Tools] menu, point to [Device Settings], and then click [System].

A Web browser opens and the dialog box for entering the password for the Web Image Monitor administrator appears.

5. Enter the user name and password, and then click [Login].

For details about the user name and password, consult your administrator.

The [System] page of Web Image Monitor appears.

- 6. Select [Level 1] or [Level 2] on [Protect Printer Display Panel] in "General Settings".
- 7. Click [OK].
- 8. Click [Logout].
- 9. Quit Web Image Monitor.
- 10. Quit SmartDeviceMonitor for Admin.

Vote

• For details about setting items, see Help in the [Device Settings] on [Configuration] page.

Changing the Paper Type

Follow the procedure below to change the paper type.

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

A list of printers using the selected protocol appears.

Select the protocol of the printer whose configuration you want to change.

If you are using IPv4 SNMPv3, enter the user authentication.

3. In the list, select a printer whose configuration you want to change.

4. On the [Tools] menu, point to [Device Settings], and then click [Paper].

A Web browser opens and the dialog box for entering the password for the Web Image Monitor administrator appears.

5. Enter the user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

The [Paper] page of Web Image Monitor appears.

- 6. Select a paper type in the [Paper Type] list for each tray.
- 7. Click [OK].
- 8. Click [Logout].
- 9. Quit Web Image Monitor.
- 10. Quit SmartDeviceMonitor for Admin.

Note

• For details about setting items, see Help in the [Device Settings] on [Configuration] page.

Managing User Information

Follow the procedure below to manage the user's information using SmartDeviceMonitor for Admin.

Prints jobs can be managed and functions restricted by user codes.

Starting User Management Tool

Follow the procedure below to start User Management Tool.

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

A list of printers using the selected protocol appears.

Select the protocol of the printer whose configuration you want to change.

If you are using IPv4 SNMPv3, enter the user authentication.

- 3. In the list, select a printer you want to manage.
- 4. On the [Tools] menu, click [User Management Tool].

The dialog box for entering the user name and password appears.

5. Enter the user name and password, and then click [OK].

For details about the user name and password, consult your administrator.

User Management Tool starts.

Note

• For details about User Management Tool, see SmartDeviceMonitor for Admin Help.

Displaying the Number of Sheets Printed

Follow the procedure below to display the number of sheets printed under each user code.

- 1. Start SmartDeviceMonitor for Admin.
- 2. Click the [User Counter Information] tab of User Management Tool. The number of pages printed under each user code appears.
- 3. Click [Exit] on the [File] menu to quit User Management Tool.

Exporting the information about the number of pages printed

Follow the procedure below to export the information of the number of pages printed under each user code as a ".csv" file.

- 1. Start SmartDeviceMonitor for Admin.
- 2. Click the [User Counter Information] tab of User Management Tool.
- 3. On the [File] menu, click [Export User Statistics List].
- 4. Specify the save location and file name, and then click [Save].
- 5. Click [Exit] on the [File] menu to quit User Management Tool.

Resetting the number of pages printed to 0

Follow the procedure below to reset the number of pages printed under each user code to 0.

- 1. Start SmartDeviceMonitor for Admin.
- 2. Click the [User Counter Information] tab of User Management Tool.
- 3. Click the user whose information you want to reset.
- 4. On the [Edit] menu, click [Reset User Counters].
- Select the check box of the items you want to reset, and then click [OK].
 A confirmation message appears.
- 6. Click [OK].
- 7. On the [Edit] menu, click [Apply Settings].

Changes are applied to information on the [User Counter Information] tab.

8. Click [Exit] on the [File] menu to quit User Management Tool.

Restricting Functions

Follow the procedure below to restrict use of individual functions.

- 1. Start SmartDeviceMonitor for Admin.
- 2. Click the [User Counter Information] tab of User Management Tool.
- 3. On the [Edit] menu of User Management Tool, click [Restrict Access To Device].
- 4. Select the check box of the functions you want to restrict.
- 5. Click [OK].

A confirmation message appears.

6. Click [Yes].

The settings are applied.

Setting Applicable Functions to New Users

Follow the procedure below to add new users and set functions applicable to them.

- 1. Start SmartDeviceMonitor for Admin.
- 2. Click the [Access Control List] tab of User Management Tool.
- 3. On the [Edit] menu, click [Add New User].
- 4. Enter the user code and user name.
- 5. Select the check box of the functions applicable to the new user.

If the check boxes are unavailable, there is no restriction to use that function. For details, see SmartDeviceMonitor for Admin Help.

6. Click [OK].

The new user is added.

7. On the [Edit] menu, click [Apply Settings].

The settings are applied.

8. Click [Exit] on the [File] menu to quit User Management Tool.

Vote

• For details about setting restrictions, see SmartDeviceMonitor for Admin Help.

Configuring the Energy Saver Mode

Follow the procedure below to configure Energy Saver mode.

1. Start SmartDeviceMonitor for Admin.

 On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

A list of printers using the selected protocol appears.

Select the protocol of the printer whose configuration you want to change.

If you are using IPv4 SNMPv3, enter the user authentication.

3. Select the printer whose settings you want to make.

To make settings for all printers in the selected group, select no printer.

- 4. On the [Group] menu, point to [Energy Save Mode], point to [Set Individually] to make the settings for only the selected printer or point to [Set By Group] to make the settings for all printers in the selected group, and then click [On] or [Off].
- 5. Quit SmartDeviceMonitor for Admin.

🕓 Note 🛛

6

• For details about the setting value for Energy Saver mode, see SmartDeviceMonitor for Admin Help.

Setting a Password

Follow the procedure below to set a password.

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

A list of printers using the selected protocol appears.

Select the protocol of the printer whose configuration you want to change.

If you are using IPv4 SNMPv3, enter the user authentication.

- 3. In the list, select a printer whose configuration you want to change.
- 4. On the [Tools] menu, click [NIB Setup Tool].

A Web browser opens and the dialog box for entering the password for the Web Image Monitor administrator appears.

NIB Setup Tool starts when the network interface board is default. Follow the instruction on the screen.

5. Enter the login user name and password, and then click [Login].

For details about the user name and password, consult your administrator.

Top Page of Web Image Monitor appears.

- 6. Click [Configuration].
- On the [Device Settings], click [Program/Change Administrator], and then change the settings.
- 8. Click [OK].

- 9. Quit Web Image Monitor.
- 10. Quit SmartDeviceMonitor for Admin.

Checking the Printer Status

Follow the procedure below to check printer status.

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

The status of printers is indicated by icons in the list.

If you are using IPv4 SNMPv3, enter the user authentication.

 To obtain status details, click the printer in the list, and then click [Open] on the [Device] menu.

The printer status appears in the dialog box.

- 4. Click [System] or [Printer].
- 5. Quit SmartDeviceMonitor for Admin.

Vote

• For details about status icons and items in the dialog box, see SmartDeviceMonitor for Admin Help.

Changing Names and Comments

Follow the procedure below to change the names and comments of the printer.

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3]. A list of printers using the selected protocol appears.

Select the protocol of the printer whose configuration you want to change.

The status of printers is indicated by icons in the list.

If you are using IPv4 SNMPv3, enter the user authentication.

- 3. Select a printer in the list.
- 4. On the [Tools] menu, click [NIB Setup Tool].

A Web browser opens and the dialog box for entering the password for the Web Image Monitor administrator appears.

NIB Setup Tool starts when the network interface board is default. Follow the instruction on the screen.

185

5. Enter the user name and password, and then click [Login].

Top Page of Web Image Monitor appears.

For details about the login user name and password, consult your administrator.

- 6. Click [Configuration].
- 7. Click [System] on the [Device Settings] area, and then change the settings.

8. Click [OK].

- In the [Device Name] box, enter a device name on the printer using up to 31 characters.
- In the [Comment] box, enter a comment on the printer using up to 31 characters.
- 9. Quit Web Image Monitor.
- 10. Quit SmartDeviceMonitor for Admin.

Viewing and Deleting Spool Print Jobs

- 1. Start SmartDeviceMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPv4], [IPX/SPX] or [IPv4 SNMPv3].

A list of printer using the selected protocol appears.

Select the protocol of the printer whose configuration you want to change.

If you are using IPv4 SNMPv3, enter the user authentication.

3. Select a printer in the list, and then click [Spool Printing Job List(Printer)] on the [Tools] menu. A Web browser opens and the dialog box for entering the login user name and password for the

Web Image Monitor administrator appears.

4. Enter the login user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

[Spool Printing Job List] appears in the Web Image Monitor.

To delete the Spool Printing Job, select the document you want to delete and then click [Delete].

Note

- To display [Spool Printing Job List], spool must be set to [Active] on Web Image Monitor in advance.
- For details, see Help in the [Spool Printing Job List] area.

Using SmartDeviceMonitor for Client

To view the status of printers using SmartDeviceMonitor for Client, configure SmartDeviceMonitor for Client beforehand.

Monitoring Printers

Follow the procedure below to monitor the printer using SmartDeviceMonitor for Client.

 Right-click the SmartDeviceMonitor for Client icon, point to [Properties], and then click [Option...].

The [SmartDeviceMonitor for Client - Options] dialog box appears.

2. Select the printer you want to monitor, and then select the [To be Monitored] check box in the Monitoring Information Settings area.

To display the printer status in the task tray using the SmartDeviceMonitor for Client icon, select the [Displayed on Task Bar] check box.

3. Click [OK].

The dialog box closes and the configured printer is monitored.

Note

• For details about status icons, see SmartDeviceMonitor for Client Help.

Checking the Printer Status

Follow the procedure below to check printer status using SmartDeviceMonitor for Client.

- 1. Start SmartDeviceMonitor for Client.
- 2. For status details, right-click the SmartDeviceMonitor for Client icon, and then click the printer.

The printer status appears in the dialog box.

Vote

• For details about items in the dialog box, see SmartDeviceMonitor for Client Help.

When Using IPP with SmartDeviceMonitor for Client

When using IPP with SmartDeviceMonitor for Client, note the following:

- The network printer can only receive one print job from SmartDeviceMonitor for Client at a time. While the network printer is printing, another user cannot access it until the job is finished. In this case, SmartDeviceMonitor for Client tries to access the network printer until the retry interval expires.
- If SmartDeviceMonitor for Client cannot access the network printer and times out, it will stop sending
 the print job. In this case, you should cancel the paused status from the print queue window.
 SmartDeviceMonitor for Client will resume access to the network printer. You can delete the print job
 from the print queue window, but canceling a print job printed by the network printer might cause the
 next job sent from another user to be incorrectly printed.
- If a print job sent from SmartDeviceMonitor for Client is interrupted and the network printer cancels the job because something went wrong, send the print job again.
- Print jobs sent from another computer do not appear in the print queue window, regardless of protocol.
- If various users send print jobs using SmartDeviceMonitor for Client to network printers, the printing order might not be the same as that in which the jobs were sent.
- An IP address cannot be used for the IPP port name because the IP address is used for the SmartDeviceMonitor for Client port name.
- When setting SSL, a protocol for encrypted communication, under environment which server authentification is issued, enter "https://(printer's address)/". Internet Explorer must be installed on your computer. Use the highest version. Internet Explorer 6.0 or higher is recommended.
- If the [Security Alert] dialog box appears when accessing the printer using IPP to create or configure an IPP port, or when printing, install the certificate. To select the certificate store location when using Certificate Import Wizard, click [Place all certificates in the following store], and then click [Local Computer] under [Trusted Root Certification Authorities].

Printer Status Notification by E-Mail

Whenever a paper tray becomes empty or paper jams, a notification e-mail is sent to the registered addresses.

You can make the timing and content settings for notification e-mail.

- Call Service
- Out of Toner
- Toner Almost Empty
- Replacement Required: Maintenance Kit
- Paper Misfeed
- Cover Open
- Out of Paper
- Almost Out of Paper
- Paper Tray Error
- Output Tray Full
- Unit Connection Error
- Duplex Unit Error
- Waste Toner Bottle is Full
- Waste Toner Bottle is Almost Full
- Replace Cleaning Web Soon
- File Storage Memory Full Soon
- Log Error
- Open a Web browser, and then enter "http://(printer's address)/" in the address bar. Top Page of Web Image Monitor appears.

When setting SSL, a protocol for encrypted communication, under environment which server authentification is issued, enter "https://(printer's address)/".

2. Click [Login] on Top Page of Web Image Monitor.

The window for entering the login user name and password appears.

3. Enter the user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

- 4. In the menu area, click [Configuration].
- 5. Click [E-mail] in "Device Settings".

- 6. Make the following settings:
 - Items in the Reception column: Make the necessary settings for sending and receiving e-mail.
 - Items in the SMTP column: Configure the SMTP server. Check your mailing environment, and then specify the necessary items. You can also perform mail authentication for the SMTP server.
 - Items in the POP before SMTP column: Configure the POP server. Check your mailing environment, and then specify the necessary items. You can also perform mail authentication for the POP server.
 - Items in the POP3/IMAP4 column: Configure the POP3 or IMAP4 server. Check your mailing environment, and then specify the necessary items.
 - Items in the E-mail Communication Port column: Configure the port to be used for access to the mail server.
 - Items in the E-Mail Notification Account column: Specify these items if you want to use on-demand e-mail notification.

7. Click [OK].

Auto E-mail Notification

 In the menu area, click [Configuration], and then click [Auto E-mail Notification] in "Device Settings".

The dialog box for making notification settings appears.

- 2. Make the following settings:
 - Items in the Notification Message column: You can set this according to your needs, for example, the printer's location, service representative contact information.
 - Items in the Groups to Notify column: E-mail notification addresses can be grouped as required.
 - Items in the Select Groups/Items to Notify column: Select groups for each notification type, such as printer status and error.

To make detailed settings for these items, [Edit] next to [Detailed Settings of Each Item].

- 3. Click [OK].
- 4. Click [Logout].
- 5. Quit Web Image Monitor.

On-demand E-mail Notification

 In the menu area, click [Configuration], and then click [On-demand E-mail Notification] in "Device Settings".

The dialog box for making notification settings appears.

2. Make the following settings:

- Notification Subject: Enter a text string to be added to the subject line of return e-mails.
- Items in the Notification Message column: You can set this according to your needs, for example, the printer's location, service representative contact information.
- Items in the Access Restriction to Information column: Select whether to restrict accesses based on a specific category of information.
- Items in the Receivable E-mail Address/Domain Name Settings column: Enter an e-mail address
 or domain name to use for requesting information by e-mail and to receive its return e-mail.
- 3. Click [OK].
- 4. Click [Logout].
- 5. Quit Web Image Monitor.

Mail authentication

You can configure mail authentication to prevent illegal use of the mail server.

SMTP Authentication

6

Specify SMTP authentication.

When mail is sent to the SMTP server, authentication is performed using the SMTP AUTH protocol by prompting the mail originator to enter the user name and password. This prevents illegal use of the SMTP server.

- 1. In the menu area, click [Configuration], and then click [E-mail] in "Device Settings".
- 2. Make the following settings:
 - SMTP Authentication: Enable or disable SMTP authentication.
 - SMTP Auth. E-mail Address: Enter the e-mail address.
 - SMTP Auth. User Name: Enter the SMTP account name.
 - SMTP Auth. Password: To set or change the password for SMTP AUTH.
 - SMTP Auth. Encryption: Select whether to encrypt the password or not.

[Auto Select]: If the authentication method is PLAIN, LOGIN, CRAM-MD5, or DIGEST-MD5.

[Active]: If the authentication method is CRAM-MD5 or DIGEST-MD5.

[Inactive]: If the authentication method is PLAIN or LOGIN.

- 3. Click [OK].
- 4. Click [Logout].
- 5. Quit Web Image Monitor.

POP before SMTP Authentication

Select whether to log on to the POP3 server before sending e-mail.

- 1. In the menu area, click [Configuration], and then click [E-mail] in "Device Settings".
- 2. Make the following settings:
 - POP before SMTP: Enable or disable POP before SMTP.
 - POP E-mail Address: Enter the e-mail address.
 - POP User Name: Enter the POP account name.
 - POP Password: To set or change the POP password.
 - Timeout setting after POP Auth.: Enter the time available before connecting to the SMTP server after logging on to the POP server.
- 3. Click [OK].
- 4. Click [Logout].
- 5. Quit Web Image Monitor.

Sending On-demand E-mail

To use on-demand e-mail notification, perform the following configuration tasks in Web Image Monitor.

- 1. In the menu area, click [Configuration], and then click [E-mail] in "Device Settings".
- 2. Make the following settings:
 - E-mail Notification E-mail Address: Enter the address using alphanumeric characters.
 - Receive E-mail Notification: Specify whether to use on-demand e-mail notification.
 - E-mail Notification User Name: Enter the administrator's user name as the mail originator name.
 - E-mail Notification Password: Enter the password of the mail notification user.
- 3. Click [OK].
- 4. Click [Logout].
- 5. Quit Web Image Monitor.

Format of on-demand e-mail messages

To use mail notification, you need to send an on-demand e-mail message to this printer.

Using your mail software, enter the following:

ltem	Description
Subject (Referred to as Subject)	Enter a request regarding the device. For details, see the table below.

ltem	Description
From (Referred to as From)	Specify a valid mail address. The device information will be sent to the address specified here.

Note

- A mail message must be within 10 KB in size.
- E-mail may be incomplete if sent immediately after power on.

Subject field

Format: devicestatus?parametername=parameter[&=parameter][& =parameter]...

Note

- The Subject field is case-insensitive.
- Parameter names can be written in any order.

Subject field coding examples

Coding example	Action
devicestatus?request=sysconfig& format=text& lang=en	The device's system configuration information will be sent in an English text format.
devicestatus?request=sysconfig	The device's system configuration information will be sent in a preset format and language.

Parameters

Parameter	Meaning	Default
request	Information to be obtained	Mandatory
format	Mail format	Mail will be sent in the format preset for each mail address.
lang	Language for mail body	Mail will be sent in the language preset for each mail address.

Parameters specifying the information to be obtained

Information to be obtained	Parameter
System configuration information	sysconfig
Network configuration information	netconfig
Printer configuration information	prtconfig
Supplies information	supply
Device status information	status

Parameters specifying the mail format

Mail format	Parameter
Text	text
HTML	html
XML	xml

Note

• HTML and XML can be selected for subject field, but output is text only.

Parameters specifying the language for mail body

Language for mail body	Parameter
English	en
French	fr
German	de
Italian	it
Spanish	es
Dutch	nl
Danish	da
Finnish	fi
Norwegian	no

Language for mail body	Parameter
Portuguese	pt
Swedish	sv
Czech	CS
Polish	pl
Hungarian	hu

Remote Maintenance by telnet

C Important

- Remote Maintenance should be password-protected so that access is allowed to administrators only.
- The password is the same as the one of Web Image Monitor administrator. When the password is changed using "mshell", other passwords change also.
- Some commands cannot be used depending on your printer.

Using telnet

Follow the procedure below to use telnet.

🔂 Important 🔵

- Only one user at a time can log on to perform remote maintenance.
- 1. Use the IP address or the host name of the printer to start telnet.
 - % telnet "IP_address"
- 2. Enter your user name and password.

Contact your administrator for information about the settings.

- 3. Enter a command.
- 4. Quit telnet.

```
msh> logout
```

The configuration message about saving the changes appears.

5. Enter "yes" to save the changes, and then press the [OK] key.

If you do not want to save the changes, enter "no", and then press the [OK] key. To make further changes, enter "return" at the command line, and then press the [OK] key.

🕗 Note

- If the message "Can not write NVRAM information" appears, the changes are not saved. Repeat the procedure above.
- When the changes are saved, the network interface board is reset automatically with that changes.
- When the network interface board resets, the print job in print process will be printed. However, print jobs in queue will be canceled.

access

Use the "access" command to view and configure access control. You can also specify two or more access ranges.

View settings

msh> access

IPv4 Configuration

msh> access [×] range "start-address end-address"

• [x] represents a target number between 1 and 5. (Up to five access ranges can be registered and selected.)

Example: to specify accessible IPv4 addresses between 192.168.0.10 and 192.168.0.20:

```
msh> access 1 range6 192.168.0.10 192.168.0.20
```

IPv6 Configuration

msh> access [×] range6 "start-address end-address"

• [x] represents a target number between 1 and 5. (Up to five access ranges can be registered and selected.)

Example: to specify accessible IPv6 addresses between 2001:DB8::100 and 2001:DB8::200.

msh> access 1 range6 2001:DB8::100 2001:DB8::200

IPv6 access mask Configuration

msh> access [×] mask6 "base-address prefixlen"

• [x] represents a target number between 1 and 5. (Up to five access ranges can be registered and selected.)

Example: to specify accessible IPv6 addresses to 2001:DB8::/32

msh> access 1 mask6 2001:DB8:: 32

Access control initialization

msh> access flush

• Use the "flush" command to restore the default settings so that all access ranges become "0.0.0.0" for IPv4, and ":: " for IPv6.

Note

- The access range restricts computers from use of the machine by IP address. If you do not need to restrict printing, make the setting "0.0.0.0" for IPv4, and "::" for IPv6.
- Valid ranges must be from lower (start address) to higher (end address).
- If you are running IPv4 or IPv6, up to five access ranges can be registered and selected.
- IPv6 can register and select the range and the mask for each access ranges.
- IPv6 mask ranges between 1 128 can be selected.

- Up to five access ranges can be specified. The entry is invalid if the target number is omitted.
- You cannot send print jobs, or access Web Image Monitor and diprint from a restricted IP address.

autonet

Use the "autonet" command to view and configure AutoNet parameters.

View settings

The following command displays the current AutoNet settings:

msh> autonet

Configuration

You can configure AutoNet settings.

msh> autonet {on|off}

• {on} means "active" and {off} means "inactive".

Current interface priority configuration display

msh> autonet priority

Interface priority configuration

msh> autonet priority "interface_name"

- You can give interface's AutoNet parameter priority.
- Priority settings are available when multiple interfaces are installed.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface name	Interface configured
ether	Ethernet interface
wlan	IEEE 802.11b interface

Note

- If an interface is not selected, the current interface connection settings remain in effect.
- For details about AutoNet, refer to autonet parameters.

bonjour(rendezvous)

Use the "bonjour(rendezvous)" command to display bonjour(rendezvous)-related settings.

View settings

Bonjour settings are displayed.

msh≻ bonjour

Bonjour service name setting

You can specify the bonjour service name.

```
msh> bonjour cname "computer name"
```

• The computer name can be entered using up to 63 alphanumeric characters.

Bonjour Installation location information setting

You can enter information about the location where the printer is installed.

```
msh> bonjour location "location"
```

• Information about location can be entered using up to 32 alphanumeric characters.

Setting order of priority for each protocol

• diprint

```
msh> bonjour diprint {0-99}
```

• lpr

```
msh> bonjour lpr {0-99}
```

ipp

6

```
msh> bonjour ipp {0-99}
```

You can specify the order of priority for "diprint", "lpr", and "ipp". Smaller numbers indicate higher priority.

IP TTL setting

msh> bonjour ipttl {1-255}

You can specify the IP TTL (the number of routers a packet can pass through).

Note

• The default is 255.

Resetting the computer name and location information

You can reset the computer name and location information.

```
msh> bonjour clear {cname | location}
```

cname

Reset the computer name. The default computer name will be displayed when the computer is restarted.

location

Reset the location information. The previous location information will be deleted.

Interface configuration

```
msh> bonjour linklocal "interface_name"
```

- If many types of interface are installed, configure the interface that communicates with linklocal address.
- If the connected computer's IP address is a link local address specified by the DHCP's Autonet, and multiple interfaces are connected to the printer, you can select an interface to communicate through.
- If you do not specify an interface, the Ethernet interface is automatically selected.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface	Interface configured
ether	Ethernet interface
wlan	IEEE 802.11b interface

Selecting the IPP port number

```
msh> bonjour ippport {ipp | ssl}
```

- Appears when SSL is enabled.
- If the "ipp" is selected, the port number is set to "631". If the "ssl" is selected, the port number is set to "443".

devicename

Use the "devicename" command to display and change the printer name.

View settings

```
msh> devicename
```

Printer name configuration

msh> devicename name "string"

- Enter a printer name using up to 31 alphanumeric characters.
- Set single names for each printer.

Printer name initialization

msh> devicename clearname

• Reset the printer name to its default.

dhcp

Use the "dhcp" command to configure DHCP settings.

View settings

The following command displays the current DHCP settings.

msh> dhcp

Configuration

You can configure DHCP.

msh> dhcp "interface_name" {on|off}

- Click {on} to enable DHCP. Click {off} to disable DHCP.
- If the DNS server address and domain name are obtained from DHCP, be sure to click {on}.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface name	Interface configured
ether	Ethernet interface
wlan	IEEE 802.11b interface

Current interface priority configuration display

```
msh> dhcp priority
```

Interface priority configuration

msh> dhcp priority "interface_name"

- You can select which interface has DHCP parameter priority.
- Priority settings are available when multiple interfaces are installed.

DNS server address selection

```
msh> dhcp dnsaddr {dhcp | static}
```

- Specify whether to obtain the DNS server address from the DHCP server or use the address set by a user.
- To obtain the DNS server address from the DHCP server, specify "dhcp". To use the address set by a user, specify "static".

Domain name selection

msh> dhcp domainname {dhcp | static}

- Specify whether to obtain the domain name from the DNS server or use the domain name set by a user.
- To obtain the domain name from the DHCP server, specify "dhcp". To use the domain name set by a user, specify "static".

diprint

The direct printing port enables direct printing from a network-connected computer. Use the "diprint" command to change direct printing port settings.

View settings

The following command displays the current direct printing port settings:

```
msh> diprint
```

Example output:

port 9100

timeout=300(sec)

bidirect on

- con multi
- apl async
 - The "port" specifies the port number of the direct printing port.
 - The "bidirect" setting indicates whether the direct printing port is bidirectional or not.

Setting timeout

```
msh> diprint timeout {30 - 65535}
```

- You can specify the timeout interval to use when the printer is expecting data from the network.
- The default is 300 seconds.

Specifying the number of concurrent connections

```
msh> diprint conn {multi | single}
```

- The above command specifies the number of concurrent diprint connections. Specify "multi" for multiple connections or "single" for a single connection.
- The default is "multi".

dns

Use the "dns" command to configure or display DNS (Domain Name System) settings.

View settings

The following command displays current DNS settings:

msh> dns

IPv4 DNS server configuration

The following command enables or disables the IPv4 DNS server address:

```
msh> dns "number" server "server address"
```

The following command displays a configuration using the IP address 192.168.15.16 on a DNS 1 server:

msh> dns 1 server 192.168.15.16

- You can register IPv4 DNS Server address.
- You can register up to three IPv4 DNS server numbers.
- You cannot use "255.255.255.255" as the DNS server address.

IPv6 DNS server configuration

The following command enables or disables the IPv6 DNS server address:

msh> dns "number" server6 "server address"

- You can register IPv6 DNS Server address.
- You can register up to three IPv6 DNS server numbers.

Dynamic DNS function setting

msh> dns "interface_name" ddns {on|off}

- You can set the dynamic DNS function "active" or "inactive".
- {on} means "active" and {off} means "inactive".
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface name	Interface configured
ether	Ethernet interface
wlan	IEEE 802.11b interface

Specifying the record overlap operation

msh> dns overlap {update|add}

- You can specify operations performed when records overlap.
- update

To delete old records and register new records.

add

To add new records and store the old records.

• When CNAME overlaps, it is always changed, irrespective of settings.

CNAME registration

msh> dns cname {on|off}

- You can specify whether to register CNAME.
- {on} means "active" and {off} means "inactive".
- The CNAME registered is the default name beginning with rnp. CNAME cannot be changed.

A records registration

msh> dns arecord {dhcp|own}

• {dhcp}

You can specify the method of registering an A record when the dynamic DNS function is enabled and DHCP is used.

• {own}

To register an A record using the printer as the DNS client.

The DNS server address and the domain name already designated are used for the registration.

Record updating interval settings

msh> dns interval "time"

- You can specify the interval after which records are updated when using the dynamic DNS function.
- The updating interval is specified hourly. It can be entered between 1 and 255 hours.
- The default is 24 hours.

domainname

Use the "domainname" command to display or configure the domain name settings. You can configure the Ethernet interface or IEEE 802.11b interface.

View settings

The following command displays the current domain name:

msh> domainname

Interface domain configuration

msh> domainname "interface_name"

Setting the Domain Name

msh> domainname "interface_name" name "domain name"

- A domain name can be entered using up to 63 alphanumeric characters.
- The Ethernet interface and IEEE 802.11b interface will have the same domain name.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface	Interface set
ether	Ethernet interface
wlan	IEEE 802.11b interface

Deleting the Domain Name

```
msh> domainname "interface_name" clear "name"
```

help

Use the "help" command to display the available command list and the procedures for using those commands.

Command list display

msh> help

Display of procedure for using commands

```
msh> help "command_name"
```

hostname

Use the "hostname" command to change the printer name.

View settings

msh> hostname

IPv4 Configuration

msh> hostname "interface_name" "printer_name"

- Enter the printer name using up to 63 alphanumeric characters.
- You cannot use a printer name starting with "RNP" or "rnp"
- The Ethernet interface and IEEE 802.11b interface will have the same printer name.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface name	Interface configured
ether	Ethernet interface
wlan	IEEE 802.11b interface

Initializing the printer name for each interface

```
msh>hostname "interface_name" clear "name"
```

ifconfig

Use the "ifconfig" command to view and configure TCP/IP (IP address, subnet mask, broadcast address, default gateway address) for the printer.

View settings

msh> ifconfig

IPv4 Configuration

msh> ifconfig "interface_name" "parameter" "address"

- If you did not enter an interface name, it is automatically set to the Ethernet interface.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface name	Interface configured
ether	Ethernet Interface
wlan	IEEE 802.11b Interface

The following explains how to configure an IPv4 address 192.168.15.16 on Ethernet interface.

msh> ifconfig ether 192.168.15.16

IPv6 Configuration

```
msh> ifconfig ether inet6 "interface_name" "prefixlen"
```

The following explains how to configure a IPv6 address to 2001:DB8::100 with prefix length 64 on the Ethernet interface.

msh> ifconfig ether inet6 2001:DB8::100 64

Netmask configuration

msh> ifconfig "interface_name" netmask "address"

The following explains how to configure a subnet mask 255.255.255.0 on Ethernet interface.

msh> ifconfig ether netmask 255.255.255.0

Broadcast address configuration

```
msh> ifconfig "interface_name" broadcast "address"
```

Changing the Interface

```
msh> ifconfig "interface" up
```

• You can specify either the Ethernet interface or IEEE 802.11b interface when using the optional IEEE 802.11b interface unit is installed.

Note

- To get the above addresses, contact your administrator.
- Use the default configuration if you cannot obtain setting addresses.
- The IP address, subnet mask and broadcast address are the same as that for the ethernet interface and IEEE 802.11b interface.
- TCP/IP configuration is the same for both Ethernet and IEEE 802.11b interface. If interfaces are changed, the new interface inherits the configuration.

• Use "Ox" as the initial two letters of a hexadecimal address.

info

Use the "info" command to display printer information such as paper tray, output tray, and printer language.

Printer information display

msh> info

Reference

• p.231 "Getting Printer Information over the Network"

ipp

Use the "ipp" command to view and configure IPP settings.

Viewing settings

The following command displays the current IPP settings:

msh> ipp

IPP timeout configuration

Specify how many seconds the computer waits before canceling an interrupted print job. The time can be entered between 30 to 65535 seconds.

msh> ipp timeout {30 - 65535}

IPP user authorization configuration

Use IPP user authorization to restrict users to print with IPP. The default is "off".

msh> ipp auth {basic|digest|off}

- User authorization settings are "basic" and "digest".
- Use "off" to remove a user's authorization.
- If user authorization is specified, register a user name. You can register up to 10 users.

IPP user configuration

Configure IPP users according to the following messages:

msh> ipp user

The following message appears:

msh> Input user number (1 to 10):

Enter the number, user name, and password.

msh> IPP user name:user1

msh> IPP password:******

After configuring the settings, the following message appears:

User configuration changed.

ipv6

Use the "ipv6" command to display and configure IPv6 settings.

View Setting

msh> ipv6

IPv6 stateless address

msh> ipv6 stateless {on|off}

If "on" is selected, IPv6 requests information required for maintaining stateful connection to the
router for as long as the printer power is turned on. This setting allows information from the router
to be obtained constantly, and periodically refreshes the effective period of the stateless address.

lpr

Use the "lpr" command to view and configure LPR settings.

View Setting

msh> lpr

Checking host name when deleting the job

msh> lpr chkhost {on|off}

• If "on" is selected, you can delete print jobs only from the IP address of the host that sent the print job. If LPR is disabled, you can also delete print jobs sent from the IP addresses other than that of the host.

netware

Use the "netware" command to configure the NetWare settings such as the print server name or file server name.

Netware Printer Server Names

- msh> netware pname "character string"
 - Enter the NetWare print server name using up to 47 characters.

Netware File Server Names

msh> netware fname

• Enter the NetWare file server name using up to 47 characters.

Encap type

msh> netware encap {802.3|802.2|snap|ethernet2|auto}

Remote Printer Number

msh> netware rnum {0-254}

Timeout

msh> netware timeout {3-255}

Printer server mode

msh> netware mode pserver

msh> netware mode ps

Remote printer mode

msh> netware mode rprinter

msh> netware mode rp

NDS context name

msh> netware context "character string"

SAP interval

msh> netware "sap_interval"

Setting login mode for file server

msh> netware login server

Setting login mode for NDS tree

msh> netware login tree

Setting login mode for NDS tree name

msh> netware tree "NDS name"

File transfer protocol

msh> netware trans {ipv4pri|ipxpri|ipv4|ipx}

• If you do not specify the protocol, the current setting is displayed.

Protocol	Set Protocol
ipv4pri	IPv4+IPX(IPv4)
ipxpri	IPv4+IPX(IPX)
ipv4	IPv4
ірх	IPX

passwd

Use the "passwd" command to change the remote maintenance password.

Changing the Password

msh> passwd

- Enter the current password.
- Enter the new password.
- Renter the new password to confirm it.

Changing the Password of the administrators using the Supervisor

msh> passwd {Administrator ID}

- You can delete the administrator password or set up a new one.
- Enter the new password.
- Renter the new password to confirm it.

Note

- Be sure not to forget or lose the password.
- The password can be entered using up to 32 alphanumeric characters. Passwords are case-sensitive. For example, "R" is not the same as "r".

pathmtu

Use the "pathmtu" command to display and configure the PathMTU Discovery service function.

View Setting

msh> pathmtu

Enabling / disabling the PathMTU Discovery service

msh> pathmtu {on | off}

- The default is "on".
- If the MTU size of the sent data is larger than the router's MTU, the router will declare it
 impassable, and communication fails. If this happens, selecting the "pathmtu" to "off" optimizes
 the MTU size and prevents data output failure.
- Depending on the environment, information might not be obtained from the router, and communication will fail. If this happens, select the "pathmtu" to "off".

prnlog

Use the "prnlog" command to obtain printer log information.

Print logs display

msh> prnlog

• Displays 16 previous print jobs.

msh> prnlog "ID Number"

 Specify the ID number of the displayed print log information to display additional details about a print job.

Reference

• p.231 "Getting Printer Information over the Network"

route

Use the "route" command to view and control the routing table.

All route information display

msh> route get "destination"

- Specify the IPv4 address to destination.
- "0.0.0.0" cannot be specified as destination address.
- If you do not specify a destination address, all the information about the router is displayed.

Enabling/disabling Specified IPv4 Destination

msh> route active {host|net} "destination" {on | off}

• You can turn the specified destination on or off. Host becomes the default setting.

Adding IPv4 Routing Table

msh> route add {host|net} "destination" "gateway"

- Adds a host or network route to "destination", and a gateway address to "gateway" in the table.
- Specify the IPv4 address to destination and gateway.
- Host becomes the default setting.

Setting Default IPv4 Gateway

msh> route add default "gateway"

Deleting specified IPv4 destination from Routing Table

msh> route delete {host|net} "destination"

- Host becomes the default setting.
- IPv4 address of destination can be specified.

Setting IPv6 Default Gateway

msh> route add6 default "gateway"

Adding a specified IPv6 destination to Routing Table

- msh> route add6 "destination" "prefixlen" "gateway"
 - Specify the IPv6 address to destination and gateway.

Deleting a specified IPv6 destination from Routing Table

- msh> route delete6 "destination" "prefixlen"
 - Specify the IPv6 address to destination and gateway.

Display information about a specified IPv6 route information

- msh> route get6 "destination"
 - Specify the IPv6 address to destination and gateway.

Enabling/disabling a specified IPv6 destination

msh> route active6 "destination" "prefixlen" {on | off}

Route initialization

msh> route flush

Note

- The maximum number of IPv4 routing tables is 16.
- The maximum number of IPv6 routing tables is 2.
- Set a gateway address when communicating with devices on an external network.
- The same gateway address is shared by all interfaces.
- "Prefixlen" is a number between 1 and 128.

set

Use the "set" command to set the protocol information display "active" or "inactive".

View settings

The following command displays protocol information (active/inactive).

```
msh> set ipv4
```

```
msh> set ipv6
```

```
msh> set appletalk
```

```
msh> set netware
```

- msh≻ set smb
- msh> set protocol
 - When protocol is specified, information about TCP/IP, AppleTalk, Netware, SCSI print, and SMB appears.

```
msh> set parallel
```

msh> set usb msh> set lpr msh> set lpr6 msh> set ftp msh> set ftp6 msh> set rsh msh> set rsh6 msh> set diprint msh> set diprint6 msh> set web msh> set snmp msh> set ssl msh> set ssl6 msh> set nrs msh> set rfu msh> set rfu6 msh> set ipp msh> set ipp6 msh> set http msh> set http6 msh> set bonjour msh> set nbt msh> set ssdp msh> set ssh msh> set sftp

msh> set sftp6

Configuration

• Enter "up" enable protocol, and enter "down" to disable protocol.

You can set the protocol to "active" or "inactive".

```
msh> set ipv4 {up | down}
```

- If you disable IPv4, you cannot use remote access after logging off. If you did this by mistake, you can use the control panel to enable remote access via IPv4.
- Disabling IPv4 also disables lpr, ftp, rsh, diprint, web, snmp, ssl, ipp, http, bonjour, and sftp.

msh> set ipv6 {up | down}

- If you disable IPv6, you cannot use remote access after logging off. If you did this by mistake, you can use the control panel to enable remote access via IPv6.
- Disabling IPv6 also disables lpr6, ftp6, rsh6, diprint6, ssl6, ipp6, http6, and sftp6.

```
msh> set appletalk {up | down}
msh> set netware {up | down}
msh> set smb {up | down}
msh> set smb {up | down}
msh> set lpr {up | down}
msh> set lpr6 {up | down}
msh> set ftp6 {up | down}
msh> set ftp6 {up | down}
msh> set rsh {up | down}
msh> set rsh6 {up | down}
msh> set diprint {up | down}
msh> set diprint6 {up | down}
msh> set set diprint6 {up | down}
msh> set set snmp {up | down}
msh> set ssl {up | down}
msh> set ssl {up | down}
```

• If Secured Sockets Layer (SSL, an encryption protocol) function is not available for the printer, you cannot use the function by enabling it.

```
msh> set nrs {up | down}
msh> set rfu {up | down}
msh> set rfu6 {up | down}
msh> set rfu6 {up | down}
msh> set ipp6 {up | down}
msh> set ipp6 {up | down}
msh> set http {up | down}
msh> set http6 {up | down}
msh> set ssh {up | down}
msh> set ssh {up | down}
msh> set ssh {up | down}
msh> set stp {up | down}
msh> set sftp {up | down}
msh> set sftp {up | down}
```

show

Use the "show" command to display network interface board configuration settings.

View settings

msh> show

• If "-p" is added, you can view settings one by one.

Reference

• p.237 "Understanding the Displayed Information"

slp

6

Use "slp" command to view and configure SLP settings.

msh> slp ttl "ttl_val"

- You can search the NetWare server using SLP in the PureIP environment of NetWare 5/5.1 and Netware 6/6.5. Using the "slp" command, you can configure the value of TTL which can be used by SLP multicast packet.
- The default value of TTL is 1. A search is executed only within a local segment. If the router does not support multicast, the settings are not available even if the TTL value is increased.
- The acceptable TTL value is between 1 and 255.

smb

Use the "smb" command to configure or delete the computer or workgroup name for SMB.

Computer Name settings

```
msh> smb comp "computer name"
```

 Set computer name using up to 15 characters. Names beginning with "RNP" or "rnp" cannot be entered.

Working Group Name settings

msh> smb group "work group name"

• Set workgroup name using up to 15 characters

Comment settings

```
msh> smb comment "comment"
```

• Set comment using up to 31 characters

Notify print job completion

```
msh> smb notif {on | off}
```

• To notify print job completion, specify "on". Otherwise, specify "off"

Deleting Computer Nam

msh> smb clear comp

Deleting Group Name

msh> smb clear group

Deleting Comment

msh> smb clear comment

View Protocol

msh> smb protocol

snmp

Use the "snmp" command to display and edit SNMP configuration settings such as the community name.

View settings

msh> snmp

• Default access settings 1 is as follows:

Community name:public

IPv4 address:0.0.0.0

IPv6 address:::

IPX address:0000000:00000000000

Access type:read-only

Effective Protocol: IPv4/IPv6/IPX

- Default access settings 2 is as follows:
 - Community name:admin

IPv4 address:0.0.0.0

IPv6 address:::

IPX address:0000000:00000000000

Access type:read-write

Effective Protocol: IPv4/IPv6/IPX

- If "-p" is added, you can view settings one by one.
- To display the current community, specify its registration number.

Display

msh> snmp ?

Community name configuration

msh> snmp "number" name "community_name"

- You can configure ten SNMP access settings numbered 1-10.
- The printer cannot be accessed from SmartDeviceMonitor for Admin or SmartDeviceMonitor for Client if "public" is not registered in numbers 1-10. When changing the community name, use SmartDeviceMonitor for Admin and SNMP Setup Tool to correspond with printer settings.
- The community name can be entered using up to 15 characters.

Deleting community name

msh> snmp "number" clear name

Access type configuration

```
msh> snmp "number" type "access_type"
```

Access type	Type of access permission
no	not accessible
read	read only
write	read and write
trap	user is notified of trapmessages

Protocol configuration

msh> snmp {ipv4|ipv6|ipx} {on|off}

- Use the following command to set protocols "active" or "inactive": If you set a protocol "inactive", all access settings for that protocol are disabled.
- Specify "ipv4" for IPv4, "ipv6" for IPv6, or "ipx" for IPX/SPX.
- {on} means "active" and {off} means "inactive".
- All protocols cannot be turned off concurrently.

Configuration of protocol for each registration number

msh> snmp "number" active {ipv4|ipv6|ipx} {on|off}

• To change the protocol of access settings, use the following command. However, if you have disabled a protocol with the above command, activating it here has no effect.

Access configuration

```
msh> snmp "number" {ipv4|ipv6|ipx} "address"
```

• You can configure a host address according to the protocol used.

- The network interface board accepts requests only from hosts that have IPv4, IPv6, and IPX addresses with access types of "read-only" or "read-write". Enter "0" to have network interface board accept requests from any host without requiring a specific type of access.
- Enter a host address to deliver "trap" access type information to.
- To specify IPv4 or IPv6, enter "ipv4" or "ipv6" followed by a space, and then the IPv4 or IPv6 address.
- To specify IPX/SPX, enter "ipx" followed by a space, the IPX address followed by a decimal, and then the MAC address of the network interface board.

sysLocation configuration

msh> snmp location

Deleting sysLocation

msh> snmp clear location

sysContact setting

msh> snmp contact

Deleting sysContact

msh> snmp clear contact

SNMP v1v2 function configuration

msh> snmp v1v2 {on|off}

• Specify "on" to enable, and "off" to disable.

SNMP v3 function configuration

msh> snmp v3 {on|off}

• Specify "on" to enable, and "off" to disable.

SNMP TRAP configuration

msh> snmp trap {v1|v2|v3} {on|off}

• Specify "on" to enable, and "off" to disable.

Remote Configuration Authorization configuration

msh> snmp remote {on|off}

• Specify "on" to enable, and "off" to disable the SNMP v1v2 setting.

SNMP v3 TRAP configuration display

msh> snmp v3trap

- msh> snmp v3trap {1-5}
 - If a number from 1-5 is entered, settings are displayed for that number only.

Configuring a sending address for SNMP v3 TRAP

msh> snmp v3trap {1-5} {ipv4|ipv6|ipx} "address"

Configuring a sending protocol for SNMP v3 TRAP

msh> snmp v3trap {1-5} active {ipv4|ipv6|ipx} {on|off}

Configuring a user account for SNMP v3 TRAP

msh> snmp v3trap {1-5} account "account_name"

• Enter an account name using up to 32 alphanumeric characters.

Deleting an SNMP v3 TRAP user account

msh> snmp v3trap {1-5} clear account

Configuring an SNMP v3 encryption algorithm

msh> snmp v3auth {md5|sha1}

Configuring SNMP v3 encryption

msh> snmp v3priv {auto|on}

- Set "auto" for automatic encryption configuration
- Set "on" for mandatory encryption configuration.

sntp

The printer clock can be synchronized with a NTP server clock using Simple Network Time Protocol (SNTP). Use the "sntp" command to change SNTP settings.

View settings

msh> sntp

NTP server address configuration

You can specify the IP address of the NTP server.

msh> sntp server "IP_address"

Interval configuration

```
msh> sntp interval "polling_time"
```

- You can specify the interval at which the printer synchronizes with the operator-specified NTP server. The default is 60 minutes.
- The interval can be entered from 0, or between 16 and 10,080 minutes.
- If you set 0, the printer synchronizes with the NTP server only when you turn the printer on. After that, the printer does not synchronize with the NTP server.

Time-zone configuration

```
msh> sntp timezone "+/-hour_time"
```

 You can specify the time difference between the printer clock and NTP server clock. The values are between -12:00 and +13:00.

spoolsw

Use the "spoolsw" command to view and configure Job Spool settings.

You can only specify diprint, lpr, ipp, ftp, smb and sftp protocol.

• The "spoolsw" command for configuring Job Spool settings is available only when the optional hard disk is installed.

View settings

The Job Spool setting appears.

msh> spoolsw

Job Spool setting

msh> spoolsw spool {on | off}

```
Note
```

• Specify "on" to enable Job Spool, or "off" to disable it.

Resetting Job spool setting

```
msh> spoolsw clear job {on | off}
```

 When the printer power is cut during job spooling, this determines whether to reprint the spooled job.

Protocol configuration

```
msh> spoolsw diprint {on | off}
msh> spoolsw lpr {on | off}
msh> spoolsw ipp {on | off}
msh> spoolsw smb {on | off}
msh> spoolsw ftp {on | off}
msh> spoolsw ftp {on | off}
```

• You can specify the settings for diprint, lpr, ipp, smb and sftp.

ssdp

Use the "ssdp" command to view and configure SSDP settings.

View settings

msh> ssdp

Setting effective time

msh> ssdp profile {1801-86400}

• The default is 10800 seconds.

Advertise packet TTL settings

msh> ssdp ttl {1-255}

• The default is 4.

ssh

Use the "ssh" command to view and configure SSH settings.

View settings

msh≻ ssh

Data compression communication settings

msh> ssh compression {on|off}

• The default is "on".

SSH/SFTP communication port setting

msh> ssh port {22, 1024-65535}

• The default is 22.

SSH/SFTP communication timeout setting

msh> ssh timeout {0-65535}

• The default is 300.

SSH/SFTP communication login timeout setting

msh> ssh logintimeout {0-65535}

• The default is 300.

Setting an open key for SSH/SFTP

msh> ssh genkey {512|768|1024} "character string"

- Create an open key for SSH/SFTP communication.
- Usable characters are ASCII 0x20-0x7e (32 bytes) other than "0".
- The default key length is 1024, and the character string is blank.

Deleting open key for ssh/sftp communication

msh≻ ssh delkey

🕗 Note

- If you do not specify a character string, current setting is displayed.
- SSH does not function if the capacity of the SDRAM module is 128 MB. If necessary, replace the SDRAM module with a higher capacity module.

status

Use the "status" command to display the printer status.

Messages

msh> status

Reference

• p.231 "Getting Printer Information over the Network"

syslog

Use the "syslog" command to display the information stored in the printer's system log.

View message

msh> syslog

Reference

• p.248 "Message List"

upnp

Use the "upnp" command to display and configure the universal plug and play.

Public URL display

msh> upnp url

Public URL configuration

Msh< upnp url "string"

• Enter the URL string in the character string.

web

Use the "web" command to display and configure parameters on Web Image Monitor.

View Settings

msh> web

URL Configuration

You can set URLs linked by clicking URL on Web Image Monitor.

msh> web url http://"The URL or IP address you want to register"/

 Specify "1" or "2" for x as the number corresponding to the URL. Up to two URLs can be registered and specified.

Deleting URLs registered as link destinations

msh> web x clear url

• Specify "1" or "2" for x as the corresponding number to the URL.

Link name configuration

You can enter the name for URL that appears on Web Image Monitor.

msh> web name "Name you want to display"

• Specify "1" or "2" for x as the corresponding number to the link name.

Resetting URL names registered as link destinations

msh> web x clear name

• Specify "1" or "2" for x as the number corresponding to the link name.

Help URL Configuration

You can set URLs linked by clicking [Help] or [?] on Web Image Monitor.

msh> web help http://"Help URL or IP address"/help/

Deleting Help URL

msh> web clear help

wiconfig

Use the "wiconfig" command to make settings for IEEE 802.11b.

View settings

msh> wiconfig

View IEEE 802.11b settings

msh> wiconfig cardinfo

• If IEEE 802.11b is not working correctly, its information is not displayed.

Configuration

msh> wiconfig "parameter"

Parameter	Value configured
mode {ap adhoc 802.11adhoc}	You can set the infrastructure mode (ap), the 802.11 ad hoc mode (802.11 adhoc), or the ad hoc mode (adhoc). The default is ad hoc mode.

Parameter	Value configured
ssid "ID value"	You can make settings for the SSID in the infrastructure mode.
	Usable characters are ASCII 0x20-0x7e (32 bytes).
	An SSID value is set automatically to the nearest access point if no setting is made.
	If no setting is made for the ad hoc mode, the same value as for the infrastructure mode or an ASSID value is automatically set. The default is blank.
channel frequency "channel no."	You can enable or disable the WEP function. To enable the WEP function, specify [on]; to disable it, specify [off].
	To start the WEP function, enter the correct WEP key. The default is "11".
key "key value" val {1 2 3 4}	You can specify the WEP key when entering in hexadecimal.
	With a 64-bit WEP, you can use 10 digit hexadecimals. With a 128-bit WEP, you can use 26 digit hexadecimals.
	Up to four WEP keys can be registered. Specify the number to be registered with "val".
	When a WEP is specified by key, the WEP specified by key phrase is overwritten.
	To use this function, set the same key number and WEP key for all ports that transmit data to each other. Put "Ox" on the front of WEP key.
	You can omit the numbers with "val". The key number is set to 1 when making these omissions. The default is blank.
keyphrase "phrase" val {1 2 3 4}	You can specify the WEP key when entering in ASCII.
	With a 64-bit WEP, you can use 10 digit hexadecimals. With a 128-bit WEP, you can use 26 digit hexadecimals.

Parameter	Value configured
	Up to four WEP keys can be registered. Specify the number to be registered with "val".
	When a WEP is specified by key phrase, the WEP specified by key is overwritten.
	To use this function, set the same key number and WEP key for all ports that transmit data to each other.
	You can omit the numbers with "val". The key number is set to 1 when making these omissions.
encval {1 2 3 4}	You can specify which of the four WEP keys is used for packet encoding. "1" is set if a number is not specified.
wepauth {open shared}	You can set an authorization mode when using WEP. The specified value and authorized mode are as follows:
	open: open system authorized (default) shared: shared key authorized rate
rate {auto 11m 5.5m 2m 1m}	You can set the IEEE 802.11b transmitting speed.
	The speed you specify here is the speed at which data is sent. You can receive data at any speed.
	auto: automatically set (default)
	11m: 11 Mbps fixed
	5.5m: 5.5 Mbps fixed
	2m:2 Mbps fixed
	1m: 1 Mbps fixed
security {none wep wpa}	You can specify the security mode.
	none: No encryption(default)S
	wep: WEP encryption
	wpa: WPA encryption
wpaenc {tkip ccmp}	You can specify WPA encryption key when using WPA encryption.
	tkip: TKIP (default)

Parameter	Value configured
	ccmp: CCMP (AES)
wpaauth {wpapsk wpa}	You can specify the WPA authentication mode when using WPA encryption. wpapsk: WPA-PSK authentication(default) wpa: WPA(802.1X) authentication
psk "character string"	You can specify the Pre-Shared key. Usable characters: ASCII 0x20-0x7e (8 to 63 bytes). The default is blank.
eap {tls ttls leap peap} {chap mschap mschapv2 pap md5 tls}	You can specify the EAP authentication type. tls: EAP-TLS (default) ttls: EAP-TTLS leap: LEAP peap: PEAP chap, mschap, mschapv2, pap, md5, or tls are settings for the phase 2 method, and must be set when using EAP-TTLS or PEAP. Do not make these settings when using other EAP authentication types. If you select EAP-TTLS, you can select chap, mschap, mschapv2, pap, or md5. If you select PEAP, you can select mschapv2 or tls.
username "character string"	You can specify the login user name for the Radius server. Usable characters: ASCII 0x20-0x7e(31 bytes) other than "@". The default is blank.
username2 "character string"	You can specify the phase 2 username for EAP- TTLS/PEAP phase 2 authentication. Usable characters: ASCII 0x20-0x7e (31 bytes) other than "@". The default is blank.
domain "character string"	You can specify the login domain name for the Radius server.

Parameter	Value configured
	Usable characters: ASCII0x20-0x7e (31 bytes) other than "@". The default is blank.
password "character string"	You can specify the login password for the Radius server. Usable characters: ASCII 0x20-0x7e(128 bytes). The default is blank.
srvcert {on off}	You can set the server certificate. The default is "off".
imca {on off}	You can enable or disable the certificate when the intermediate certificate authority is present. The default is "off".
srvid "character string"	You can set the server ID and subdomain of the certificate server.

Note

• You can use this command only when the IEEE 802.11b interface unit is installed.

wins

Use the "wins" command to configure WINS server settings.

Viewing settings

msh≻ wins

• If the IPv4 address obtained from DHCP differs from the WINS IPv4 address, the DHCP address is the valid address.

Configuration

```
msh> wins "interface_name" {on | off}
```

- {on} means "active" and {off} means "inactive".
- Be sure to specify the interface.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface name	Interface configured
ether	Ethernet interface
wlan	IEEE 802.11b interface

Address configuration

Use the following command to configure a WINS server IP address:

msh> wins "interface_name" {primary|secondary} "IP address"

- Use the "primary" command to configure a primary WINS server IPv4 address.
- Use the "secondary" command to configure a secondary WINS server IPv4 address.
- Do not use "255.255.255.255" as the IPv4 address.

NBT (NetBIOS over TCP/IP) Scope ID Selection

You can specify the NBT scope ID.

```
msh> wins "interface_name" scope "scope ID"
```

- The scope ID can be entered using up to 31 alphanumeric characters.
- Be sure to specify the interface.
- wlan can be specified only when the IEEE 802.11b interface unit is installed.

Interface name	Interface configured	
ether	Ethernet interface	
wlan	IEEE 802.11b interface	

SNMP

The SNMP agent operating on UDP and IPX is incorporated into the built-in Ethernet board and optional IEEE 802.11b interface unit of this printer.

Using the SNMP manager, you can get information about the printer.

Comportant 🔂

• If you changed the printer's community name, change the configuration of the connected computer accordingly, using SNMP Setup Tool. For details, see SNMP Setup Tool Help.

The default community names are [public] and [admin]. You can get MIB information using these community names.

Start SNMP Setup Tool

• Windows 95/98/Me, Windows 2000, Windows NT 4.0:

Click the [Start] button.

Point to SmartDeviceMonitor for Admin on the [Programs] menu.

Click [SNMP Setup Tool].

• Windows XP:

Click the [Start] button.

Point to SmartDeviceMonitor for Admin on the [All Programs] menu.

Click [SNMP Setup Tool].

Supported MIBs(SNMPv1/v2)

- MIB-II
- PrinterMIB
- HostResourceMIB
- RicohPrivateMIB

Supported MIBs(SNMPv3)

- MIB-II
- PrinterMIB
- HostResourceMIB
- RicohPrivateMIB
- SNMP-FRAMEWORK-MIB
- SNMP-TARGET-MIB
- SNMP-NOTIFICATION-MIB
- SNMP-USER-BASED-SM-MIB
- SNMP-VIEW-BASED-ACM-MIB

Getting Printer Information over the Network

This section explains details of each item displayed in the printer status and information.

Current Printer Status

The printer status can be checked using the following commands:

- UNIX: Use the "lpq" command and "rsh", "rcp", "ftp" and "sftp" parameters.
- mshell: Use the "status" command.

Messages	Description
Access Restricted	The job was canceled because user have no authority.
Adjusting	The printer is initializing or calibrating.
Call Service Center	There is a malfunction in the printer.
Canceled	The job is reset.
Canceling Job	The job is being reset.
Configuring	Setting is being changed.
Cooling Down Fusing Unit	Fusing unit is cooling down.
Cover Open: Duplex Unit	The cover of the duplex unit is open.
Cover Open: Front Cover	The front cover is open.
Empty: Black Toner	The black toner cartridge is almost empty.
Energy Saver Mode	The printer is in Energy Saver Mode.
Error	An error has occurred.
Error: DIMM Value	A memory error occurred.
Error: Ethernet Board	An Ethernet board error has occurred.
Error: HDD Board	A hard disk drive board error has occurred.
Error: Optional Font	An error has occurred in the font file of the printer.
Error: Parallel I/F Board	An error has occurred in the parallel interface.

Messages	Description
Error: PDL	An error has occurred in the page description language.
Error: Rem. Certificate Renewal	An error has occurred in the remote certificate renewal.
Error: USB Board	An error has occurred in the USB board.
Error: USB Interface	An error has occurred in the USB interface.
Error: Wireless Board	An error has occurred in the wireless board.
Error: Wireless Card	Wireless card is not inserted during start up, or the IEEE 802.11b interface unit or the wireless card is taken out after start up.
Full: Waste Toner	Waste toner is full.
Hex Dump Mode	It is a hex dump mode.
Independent-supplier Toner	Toner that is not recommended is set.
In Use: Input Tray	Other functions is using the input tray.
Jobs Suspended	All jobs are suspended.
Loading Toner	Toner is being supplied.
Low: Black Toner	The black toner cartridge is not set correctly, or toner is almost running out.
Low: Toner	The black toner cartridge is not set correctly, or toner is almost running out.
Malfunction: Duplex Unit	There is a problem with duplex unit.
Malfunction:Lower Paper Tray(s)	There is a problem with the Lower Paper Tray.
Malfunction: Output Tray	There is a problem with output tray.
Memory Low: Data Storage	Memory shortage has occurred while the document was being accumulated.
Miscellaneous Error	Other error has occurred.
Mismatch: Paper Size	Indicated paper tray does not contain paper of selected size.

Messages	Description
Mismatch: Paper Size and Type	Indicated paper tray does not contain paper of selected size and type.
Mismatch: Paper Type	Indicated paper tray does not contain paper of selected type.
Near Replacing: Fusing Unit	Prepare the new fusing unit.
Nearly Full: Waste Toner	Waste toner bottle is nearly full.
No Paper: Selected Tray	There is no paper in specified tray.
No Paper: Tray 1	There is no paper in tray 1.
No Paper: Tray 2	There is no paper in tray 2.
No Paper: Tray 3	There is no paper in tray 3.
Not Detected: Black Toner	Black toner is not correctly set.
Not Detected: Duplex Feed Unit	The duplex feed unit is not correctly set.
Not Detected: Duplex Unit	The duplex unit is not correctly set.
Not Detected: Fusing Unit	The fusing unit is not correctly set.
Not Detected: Input Tray	The paper feed tray is not correctly set.
Not Detected: Tray 1	Tray 1 is not correctly set.
Not Detected: Tray 2	Tray 2 is not correctly set.
Not Detected: Tray 3	Tray 3 is not correctly set.
Not Detected: WasteToner Bottle	Waste toner bottle is not correctly set.
Not Reached, Data Deleted	Unreached job is deleted.
Not Reached, Data Stored	Unreached job is preserved.
Offline	Printer is offline.
Operating Thermo-range Error	Exceeded appropriate thermo range.
Panel Off Mode	The printer is in Panel-Off mode.
Paper in Duplex Unit	The paper remains in the duplex unit.

Messages	Description
Paper Misfeed: Input Tray	The paper has jammed in the input tray.
Paper Misfeed: Internal/Output	The paper has jammed inside the printer.
Print Complete	The print was completed.
Printing	Printing is in progress.
Processing	Data is being processed.
Proxy Address/Port Incorrect	Proxy address or Port No. is incorrect.
Proxy User/Password Incorrect	Proxy user name or Password is incorrect.
RC Gate Connection Error	Failed connection with RC Gate.
Ready	The printer is ready to print.
Renewing Remote Certificate	Remote Certificate is Renewing.
Replace Charger Kit	It is time to replace the charger kit.
Replace Cleaning Web	It is time to replace the Cleaning Web.
Replace Fusing Unit	It is time to replace the fusing unit.
Replace Int. Transfer Unit	It is time to replace the transfer unit.
Replace Transfer Cleaning Unit	It is time to replace the transfer cleaning unit.
SD Card Authentication failed	SD card authentication failed.
Skipped due to Error	Skipped the error.
Storage Complete	The storage is complete.
Storage Failed	The storage has failed.
Supplies Order Call failed	The supply order call has failed.
Transmission Aborted	The transmission was interrupted.
Transmission Complete	The transmission completion was completed.
Transmission Failed	The transmission has failed.

Messages	Description
Tray Error: Chaptering	The paper feed tray specification error has occurred because chaptering as well as the normal paper use the same tray for printing.
Tray Error: Duplex Printing	Selected paper tray cannot be used for duplex printing.
Waiting for Job Suspension	All jobs are being suspended.
Warming Up	The printer is warming up.

Note

- For details about UNIX commands, see UNIX Supplement.
- Check the error contents that may be printed in the configuration page. For details about printing a configuration page, see "List/Test Print Menu".

Reference

• p.143 "List/Test Print Menu"

Printer Configuration

You can check the printer configuration using telnet.

This section explains the checking procedure for input/output tray and printer language.

- UNIX: Use the "info" command and "rsh", "rcp", "ftp" and "sftp" parameters.
- mshell: Use the "info" command.

Input Tray

ltem	Description
No.	ID number of the paper tray
Name	Name of the paper tray
PaperSize	Size of paper loaded in the paper tray
status	Current status of the paper tray Normal:Normal NoInputTray: No tray PaperEnd:No paper

Output Tray

ltem	Description	
No.	ID number of the output tray	
Name	Name of the output tray	
status	Current status of the output tray	
	Normal:Normal	
	PaperExist:Paper exist	
	OverFlow:Paper is full	
	• Error:Other errors	

Printer Language

ltem	Description
No.	ID number of the printer language used by the printer
Name	Name of the printer language used in the printer
Version	Version of the printer language

Vote

- For details about UNIX commands and parameters, see UNIX Supplement.
- For details about mshell "info" commands, see "Remote Maintenance by telnet".

Reference

• p.197 "Remote Maintenance by telnet"

Understanding the Displayed Information

This section explains how to read status information returned by the network interface board.

Print Job Information

Use the following command to display print job information:

- UNIX: Use the "info" command and "rsh", "rcp", and "ftp" parameters.
- mshell: Use the "info" command.

ltem	Description
Rank	Print job status.
	• active
	Printing or preparing for printing.
	Waiting
	Waiting to be transferred to the printer.
Owner	Print request user name.
Job	Print request number.
Files	The name of the document.
Total Size	The size of the data (spooled).
	The default is 0 bytes.

Note

- For details about UNIX commands and parameters, see UNIX Supplement.
- For details about mshell "info" commands, see "Remote Maintenance by telnet".

Reference

• p.197 "Remote Maintenance by telnet"

Print Log Information

This is a record of the most recent 16 jobs printed.

Use the following command to display print log information:

• UNIX: Use the "prnlog" command and "rsh", "rcp", and "ftp" parameters.

• telnet : Use the "prnlog" command. See Remote Maintenance by telnet.

ltem	Description	
ID	Print request ID.	
User	Print request user name.	
Page	Number of pages printed	
Result	Print Request Result Communication Result	
	• OK	
	Print was completed normally. However, the print result may not be as required due to printer problems.	
	• NG	
	Printing was not completed normally.	
	• Canceled	
	An "rcp", "rsh", or "lpr" command print request was canceled, possibly due to the printing application. Not applicable to the "ftp" or "rprinter" command.	
Time	Time the print requested was received.	
	Time of print request reception	
User ID	Printer driver-configured User ID.	
	Appears when the print request ID is specified.	
JobName	Name of the document for printing Appears when the print request ID is specified.	

Note

- For details about UNIX commands and parameters, see UNIX Supplement.
- For details about mshell "prnlog" commands, see "Remote Maintenance by telnet".

Reference

• p.197 "Remote Maintenance by telnet"

Configuring the Network Interface Board

Use the following command to display network interface board settings:

• telnet : Use the "show" command.

ltem			Description
Common			
	Mode		
	Protocol Up/ Down		Protocol Settings
		AppleTalk	
		IPv4	
		IPv6	
		NetWare	
		SMB	
		SCSI print	
	Device Up/Down		Device Settings
		Parallel	
		USB	
	Ethernet interface		
	Syslog priority		
	NVRAM version		
	Device name		
	Comment		
	Location		
	Contact		
	Soft switch		
AppleTalk			AppleTalk Settings

ltem			Description	
	Mode			
	Net			
	Object			
	Туре			
	Zone			
TCP/IP				
	Mode (IPv4)			
	Mode (IPv6)			
		ftp		
		lpr		
		rsh		
		telnet		
		diprint		
		web		
		http		
		ftpc		
		snmp		
		ірр		
		autonet		
		Bonjour		
		ssl		
		nrs		
		rfu		
		nbt		
		ssdp		

ltem			Description
	ssh		
	sftp		
IPv4			TCP/IP Settings
	DHCP		
	Address		
	Netmask		
	Broadcast		
	Gateway		
IPv6			
	Stateless		
	Manual		
	Gateway		
EncapType			
Host name			
DNS Domain			
Access Control			Access Control Settings
	IPv4		
		Access Entry [X]	X can be set between 1 and 5.
	IPv6		
		Access Entry [X]	X can be set between 1 and 5.
Time server			Time Settings
Time Zone			

ltem			Description	
	Time server polling time			
	SYSLOG server			Websys Settings
	Home page URL1			
	Home page link name l			URL of home page
	Home page URL2			
	Home page link name2			
	Help page URL			
NetWare				
	EncapType			
	RPRINTER number			
	Print server name			
	File server name			
	Context name			
	Switch			
		Mode		
		NDS/Bindery		
		Packet negotiation		
		Login Mode		
	Print job timeout			
	Protocol			
	SAP interval time			
	NDS Tree Name			
	Transfer Protocol			

ltem			Description	
SMB				SMB Settings
	Switch			
		Mode		
		Direct print		
		Notification		
	Workgroup name			
	Computer name			
	Comment			
	Share name[1]			
	Protocol			
SCSI print				
	Bidi			
IEEE 802.11b				IEEE 802.11b Settings
	Host name			
	Communication Mode			
	SSID			
	Channel range			
	Channel			
	TX Rate			
	Security			
	WEP Authentication			
	WEP Encryption key number			

ltem			Description
	WEP Encryption keys[X]		X can be set between 1 and 5.
	WPA Encryption		
	WPA Authentication		
	Pre-Shared Key		
	User name		
	Domain name		
	ЕАР Туре		
	Password		
	Phase 2 user name		
	Phase 2 Method TTLS		
	Phase 2 Method PEAP		
	Server cert		
	Intermediate CA		
	Server ID		
DNS			DNS Settings
	IPv4		
		Server [X]	X can be set between 1 and 3.
		Select IPv4 DNS Server	
	IPv6		
		Server [X]	X can be set between 1 and 3.

	lt	em	Description
Domain name			
	ether		
	wlan		
DDNS			
	ether		
	wlan		
WINS			WINS Settings
	ether		
		Primary WINS	
		Secondary WINS	
	wlan		
		Primary WINS	
		Secondary WINS	
SSDP			SSDP Settings
	Ad_Mode		
	UUID		
	Profile		
	TTL		
UPnP			UPnP Settings
	URL		
Bonjour			Bonjour (Rendezvous) Settings
	Computer Name (cname)		

	ltem	Description
	Local Hostname (ether)	
	Local Hostname (wlan)	
	Location	
	Priority (diprint)	
	Priority (lpr)	
	Priority (ipp)	
	IP TTL	
	LinkLocal Route for Multi I/F	
	IPP Port	
SNMP		SNMP Settings
	SMNPv1v2	
	SMNPv3	
	protocol	
	v1Trap	
	v2Trap	
	v3Trap	
	SNMPv1v2 Remote Setting	
	SNMPv3 Privacy	
ssh		ssh Settings
	Compression	
	Port	
	Timeout	

ltem			Description	
	LoginTimeOut			
AuthFree				Authfree Settings
	IPv4			
		AuthFree Entry [X]		X can be set between 1 and 5.
	IPv6			
		AuthFree Entry [X]		X can be set between 1 and 5.
	Parallel			
	USB			
LPR				
	lprm check host			
	lpr prnerrchk			
Certificate				
	Verification			
Shell mode				Remote maintenance tool mode

Message List

This is a list of messages that appear in the printer's system log. The system log can be viewed using the "syslog" command.

System Log Information

Use the following command to display the system log information:

- UNIX: Use the "syslog" command and "rsh", "rcp", "ftp", and "sftp" parameters.
- telnet : Use the "syslog" command.

Message	Problem and solutions
Access to NetWare server <file name="" server=""> denied. Either there is no account for this print server on the NetWare server or the password was incorrect.</file>	(In the print server mode) Login to the file server failed. Make sure that the print server is registered on the file server. If a password is specified for the print server, delete it.
account is unavailable: Same account name be used.	User account is disabled. This could be because it use the same account name as the administrator account.
account is unavailable: The authentication password is not set up.	User account is disabled. This could be because the authentication password is not set, and only the encryption account is set.
account is unavailable: encryption is impossible.	Encryption is not possible and account is disabled. This could be because: • Security option is not installed. • Encryption password has not been specified.
add_sess_IPv4: bad trap <ipv4 address="">, community:<community name=""></community></ipv4>	The IPv4 address (0.0.0.0.) is unavailable when the community access type is TRAP. Specify the host IPv4 address for the TRAP destination.
add_sess_IPv6: bad trap <ipv6 address="">, community:<community name=""></community></ipv6>	The IPv6 address [::] is unavailable when the community access type is TRAP. Specify the host IPv6 address for the TRAP destination.
add_sess_IPv4: community <community name=""> already defined.</community>	The same community name already exists. Use another community name.

Message	Problem and solutions
add_sess_IPv6: community <community name=""> already defined.</community>	The same community name already exists. Use another community name.
add_sess_IPX: bad trap <ipx address="">community <community name=""></community></ipx>	The IPX address (00:00:00:00:00:00) is unavailable when the community access type is TRAP. Specify the host IPX address for the TRAP destination.
add_sess_IPX: community <communityname> already defined.</communityname>	The same community name already exists. Use another community name.
Attach FileServer= <file servername=""></file>	Connection to the file server as the nearest server has been established.
Attach to print queue <print name="" queue=""></print>	(In the print server mode) Attached to the print queue.
Authentication mode mismatch< SSID >	Authentication mode is different to the AP. The required SSID is the SSID of the access point connected to when in infrastructure mode.
centrod is disabled.	Communication via parallel connections unavailable because centrod is disabled in the security mode. Enable centrod in the security mode.
Cannot create service connection	(In the remote printer mode) Connection to the file server has not been established. The number of file server users may have exceeded the maximum capacity of the file server.
Cannot find rprinter (<print name="" server="">/<printer number>)</printer </print>	The printer with the number displayed on the print server does not exist. Make sure that the printer number is registered on the print server.
Change IP address from DHCP Server.	The IP address changes when DHCP lease is renewed. To always assign the same IP address, set a static IP address to the DHCP server.
child process exec error! (process name)	The network service failed to start. Turn the printer off and then on. If this does not work, contact your service or sales representative.

Message	Problem and solutions
Client password rejected	The client's password was rejected. Check the client password.
Client tls certificate rejected	The client's TLS certificate was rejected. Check the certificate.
Connected DHCP Server(<dhcp serveraddress="">).</dhcp>	The IP address was successfully received from the DHCP server.
Could not attach to FileServer <error number=""></error>	(In the remote printer mode) Connection to the file server has not been established. The file server has refused the connection. Check the file server configuration.
Could not attach to PServer <print server=""></print>	(In the remote printermode) Connection to the print server has not been established. The print server has refused the connection. Check the print server configuration.
Current Interface Speed: xxxMbps	Speed of the network (10Mbps, 100 Mbps, or 1Gbps).
Current IP address <currentip address=""></currentip>	Current IPv4 address.
Current IPX address <ipx address=""></ipx>	Current IPX address
DHCP lease time expired.	DHCP lease time has expired. The printer tries to discover the DHCP server again. The IP address until now becomes invalid.
DHCP server not found.	The DHCP server was not found. Make sure that the DHCP is on the network.
dhcpcd start.	The DHCPCD service (dhcp client service) has started.
Duplicate IP= <ip address="">(from<mac address="">).</mac></ip>	The same IP address (IPv4, or IPv6 address) was used. Each IP address (IPv4, or IPv6 address) must be unique. Check the address of the device indicated in [MAC address].
Established SPX Connection with PServer, (RPSocket= <socketnumber>, connID=<connection ID>)</connection </socketnumber>	(In the remote printer mode) Connection to the print server has been established.

Message	Problem and solutions
exiting	The lpd service has ended and the system is exiting the process.
Exit pserver	(In the print server mode) The print server function is disabled because the necessary print server settings have not been made.
Frametype = <frame typename=""/>	The frame type name is configured to be used on NetWare.
httpd start.	The httpd service has started.
IEEE 802.11b <communication mode=""> mode</communication>	Displays IEEE 802.11b communication mode.
inetd start.	The inetd service has started.
Interface (interface name): Duplicate IP Address (IP address).	The same IP (IPv4 or IPv6) address was used. Each IP address must be unique. Check the address of the device indicated in [IP address].
< Interface > started with IP: < IP address >	IP address (IPv4, or IPv4 address) has been set for the interface and is operating.
< Interface >: Subnet overlap.	The same IP address (IPv4, or IPv6 address) and the subnet mask is used with other device.
IPP cancel-job: permission denied.	The printer could not authenticate the name of the user attempting to cancel a job.
IPP job canceled. jobid=%d.	The spooled job was canceled due to error or user request.
LeaseTime= <lease time="">(sec), RenewTime=<renewtime>(sec).</renewtime></lease>	The resource lease time received from the DHCP server is displayed in [lease time] in seconds. The renewal time is displayed in [renew time] in seconds.
Login to fileserver <file name="" server=""> (<ipx ipv4="" ="" <br="">IPv6>,<nds bindery="" ="">)</nds></ipx></file>	(In the print server mode) Login to the file server is in the NDS or BINDERY mode.
Memory allocate error.	Data cannot be obtained.
	Disconnect the USB cable, and then connect it.

Message	Problem and solutions
Name registration success. WINS Server= <wins server address> NetBIOS Name=<netbios name></netbios </wins 	Name registration of <netbios name=""> to <wins server address> was successful.</wins </netbios>
Name registration success in Broadcast name= <netbios name=""></netbios>	Name registration by Broadcast name of <netbios name=""> was successful.</netbios>
Name registration failed. name= <netbios name=""></netbios>	Name registration of <netbiosname> failed. Change to different NetBIOS name.</netbiosname>
nbtd start.	The nbtd service has started.
nprinter start (Netware)	(In the remote printer mode) The NetWare service has started.
nwstart start. (NetWare)	The service for NetWare protocol stack setting has started.
Open log file <file name=""></file>	(In the print server mode) The specified log file has been opened.
phy release file open failed.	Replacing the network interface board is required. Contact your sales or service representative.
Print queue <print name="" queue=""> cannot be serviced by printer 0, <print name="" server=""></print></print>	(In the print server mode) The print queue cannot be established. Make sure that print queue exists on the specified file server.
Print server <print servername="">has no printer.</print>	(In the print server mode) The printer is not assigned to the print server. Using NWadmin, assign the printer, and then restart it.
print session full	No more print jobs can be accepted.
Printer <printer name=""> has no queue</printer>	(In the print server mode) The print queue is not assigned to the printer. Using NWadmin, assign the print queue to the printer, and then restart it.
pserver start. (NetWare)	(In the print server mode) The NetWare service has started.
Required file server (<file servername="">) not found</file>	The required file server is not found.
received EAP Failure	EAP reception failed.
restarted.	The lpd service has started.

Message	Problem and solutions
sap enable, saptype= <sap type="">, sapname=<sap name></sap </sap>	The SAP function has started. The SAP packet is issued to advertise the service on the SAP table on the NetWare server.
server identity invalid	The server ID is disabled. Check the server authentication.
session IPv4 <community name=""> not defined.</community>	The requested community name is not defined.
session IPv6 <community name=""> not defined.</community>	The requested community name is not defined.
session <community name=""> already defined.</community>	The requested community name is not defined.
session_ipx <community name=""> not defined.</community>	The requested community name is not defined.
Set context to <nds contextname=""></nds>	An NDS context name has been set.
smbd start. (NETBIOS)	The smbd service has started.
SMTPC: failed to get smtp server ip-address.	The SMTP server IP address could not be obtained. This could be because:
	• The specified DNS server could not be found.
	 No connection to the network has been established.
	• The specified DNS server could not be found.
	• An incorrect DNS server is specified.
	• The specified SMTP server IP address could not be found in the DNS server.
SMTPC: failed to connect smtp server. timeout.	Connection to the SMTP server failed due to timeout. This could be because the specified SMTP server name is incorrect, or no connection to the network has been established, or the network configuration is incorrect, so there is no response from the SMTP server. Check the SMTP server name, or the network connection and configuration.
SMTPC: refused connect by smtp server.	Connection to the SMTP server is denied. This could be because server other than the SMTP server has been specified, or the specified SMTP server port

Message	Problem and solutions
	number is incorrect. Check the SMTP server name, port number, or the SMTP server port number.
SMTPC: no smtp server. connection close.	Connection to the SMTP server failed due to no response from SMTP. This could be because a server other than the SMTP server has been specified, or the specified SMTP server port number is incorrect. Check the SMTP server name, port number, or the SMTP server port number.
SMTPC: failed to connect smtp server.	Connection to the SMTP server failed. This could be because no connection to the network has been established, or the network configuration is incorrect, so there is no response from the SMTP server, or the specified SMTP server name is incorrect, or the specified SMTP server IP address could not be found in the DNS server, or a server other than the SMTP server has been specified, or the specified SMTP server port number is incorrect. Check the DNS Server's IP address and SMTP server's IP address, or the SMTP server name and SMTP port number, or the SMTP server's SMTP port number, or the network connection and configuration.
SMTPC: username or password wasn't correct. [response code] (information)	Connection to the SMTP server failed, because the specified SMTP user name is incorrect, or the specified SMTP password is incorrect. Check the SMTP user name and password.
Snmp over IPv4 is ready	Communication over IPv4 with snmp is available.
Snmp over IPv6 is ready.	Communication over IPv6 with snmp is available.
Snmp over IPX is ready.	Communication over IPX with snmp is available.
snmpd start.	The snmpd service has started.
started.	The direct print service has started.
Started.	The bonjour (rendezvous) function is enabled.
Terminated.	The bonjour (rendezvous) function is disabled.

Message	Problem and solutions
The print server received error <error number=""> during attempt to log in to the network. Access to the network was denied. Verify that the print server name and password are correct.</error>	Login to the file server failed. The print server is not registered or a password is specified. Register the print server without specifying a password.
trap account is unavailable.	v3Trap cannot be sent. This could be because the Trap destination account is different from the account specified by the printer.
usbd is disable.	Plug and Play function and printing is disabled because usbd is disabled in the security mode. Enable usbd in the security mode.
WINS name registration: No response to server <wins address="" server=""></wins>	There was no response from the WINS server. Check the correct WINS server address is entered. Alternatively, check the WINS server is functioning properly.
WINS wrong scopeID= <scope id=""></scope>	An invalid scope ID was used. Use a valid scope ID.
wpa authentication Failed	WPA authentication failed. Check the WPA configuration.
wpa authentication started	WPA authentication has started.
wpa IEEE802.1X started	WPA authentication has started.
wpa connecting to authenticator	WPA is connecting to authenticator.
wpa link up	WPA key exchange has finished, and communication has been terminated.
wpa probe response doesn't have IE.	WPA probe response does not have IE.
wpa success authenticated	WPA authentication was successful.
wpa success key received	WPA key reception was successful.
wpa waiting for key	Waiting for WPA key.
wpasupd start	wpasupd has started.
wpasupd stop	wpasupd has ended.

Vote

- For details about UNIX commands and parameters, see UNIX Supplement.
- For details about "syslog" command, see Remote "Remote Maintenance by telnet".

Reference

• p.197 "Remote Maintenance by telnet"

Preparing Printer Server

This section explains how to configure the printer as a Windows network printer. The printer is configured to enabling network clients to use it. When the network printer is connected via SmartDeviceMonitor for Client, you can set the printing notification function to notify clients of the results of their print jobs.

Comportant 🗋

- Under Windows 2000, Windows XP Professional, or Windows Server 2003/2003 R2, to change
 printer properties in the [Printer] folder, you need Printer Management access authentication; under
 Windows NT 4.0, Full Control access authentication. Log on to the file server as an Administrator or
 member of the PowerUsers group.
- 1. Open the [Printers] window from the [Start] menu.

The [Printers] window appears.

Under Windows XP or Windows Server 2003/2003 R2, [Printers and Faxes] window appears.

- 2. Click the icon of the printer you want to use. On the [File] menu, click [Properties]. The printer properties appear.
- 3. On the [Sharing] tab, click [Shared as:].
- To share the printer with users using a different version of Windows, click [Additional Drivers...].

If you have installed an alternative driver by selecting [Shared as:] during the printer driver installation, this step can be ignored.

5. Click [OK], and then close the printer properties.

Printing notification via SmartDeviceMonitor for Client

Follow the procedure below to configure the printer to use the printing notification function of SmartDeviceMonitor for Client.

Setting the print server

Coloritant 🔁

Under Windows 2000, Windows XP Professional, or Windows Server 2003/2003 R2, to change
printer properties in the [Printer] folder, you need Printer Management access authentication; under
Windows NT 4.0, Full Control access authentication. Log on to the file server as an Administrator or
member of the PowerUsers group.

 On the [Start] menu, point to [Programs], [DeskTopBinder], [SmartDeviceMonitor for Client], and then click [Print Server Setting].

The print server setting dialog box appears.

 Select the [Notify client PCs of printout/data-transmission] check box, and then click [OK]. After print server setting is made, a dialog box appears. Confirm the dialog box content, and click [OK].

Click [Cancel] to interrupt the procedure.

A dialog box appears for client setting.

3. A dialog box for specifying clients appears. Click [OK].

The print server setting is complete. Clients must be specified in order to receive notification.

Note

- Current printing jobs restart from the beginning after the spooler pauses briefly.
- When the expansion function is not used, the function is automatically set as available.
- If you log on using an account that does not have Administrator privileges, the client may not be notified.

Setting a Client

7

1. On the [Start] menu, point to [Program], [DeskTopBinder], [SmartDeviceMonitor for Client], and then click [Extended Features Settings].

A dialog box for setting the expansion function appears.

- 2. Select the [Use Extended Features] check box.
- Select the [Notify of printout/data-transmission when using print server] check box in "Notification".
- 4. Click [OK].

The dialog box for setting the expansion function closes.

The client setting is completed.

Vote

 Set the printing notification function on the printer driver as well as on SmartDeviceMonitor for Client.

Using NetWare

This section describes the setting procedure for network printers in the NetWare environment. In the NetWare environment, you can connect the printer as a "print server" or "remote printer".

Comportant 🗋

• IPv6 cannot be used on this function.

Setting procedure

- When using the printer as a print server
 - 1. Installing SmartDeviceMonitor for Admin
 - 2. Setting the network interface board.
 - 3. Turning the printer off and then back on.
- When using the printer as a remote printer
 - 1. Installing SmartDeviceMonitor for Admin.
 - 2. Setting the network interface board.
 - 3. Setting NetWare.
 - 4. Starting the print server.

Note

- This procedure assumes an environment is already prepared for normal NetWare running the printing service setting.
- The procedure is explained with the following example settings:
 - File server's name ...CAREE
 - Print server's name ... PSERV
 - Printer's name ...R-PRN
 - Queue name ...R-QUEUE

Using SmartDeviceMonitor for Admin

To use the printer in a NetWare environment, use SmartDeviceMonitor for Admin to set the NetWare printing environment.

Note

- The NetWare Client provided by Novell is required to set the printing environment using SmartDeviceMonitor for Admin under the following environments:
 - NDS mode in Windows 95/98/Me
 - NDS or Bindery mode in Windows 2000/XP, Windows NT 4.0

🖪 Reference 🔵

• p.177 "Using SmartDeviceMonitor for Admin"

Printers listed by SmartDeviceMonitor for Admin

SmartDeviceMonitor for Admin lists printers connected to the network. If you cannot identify the printer you want to configure, print configuration page, and then check the printer name.

Setting Up as a Print Server (NetWare 3.x)

Follow the procedure below to connect the printer as a print server using NetWare 3.x.

- 1. Start Web Image Monitor.
- 2. Click [Login].

A dialog box for entering the login user name and password appears.

3. Enter the login user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

- 4. In the left area, click [Configuration], and then click [NetWare] in "Network".
 - Print Server Name: Enter the NetWare print server name. To use the interface board as a print server, enter the name of a print server that is not active on the file server. Use up to 47 characters.
 - Logon Mode: Specify whether to designate a file server or NDS tree when logging on to NetWare.
 - File Server Name: When a file server name is entered here, only the specified file server is searched for. This item is mandatory. Use up to 47 characters.
 - NDS Tree: To enable NDS mode, enter the name of the NDS tree you want to log on to. Use up to 32 alphanumeric characters.
 - NDS Context Name: To enable NDS mode, enter the print server context. Use up to 127 characters.
 - Operation Mode: Specify whether to use the interface board as a print server or a remote printer.
 - Remote Printer No.: This item is effective when the interface board is specified as a remote printer.
 Enter the same number as the number of the printer to be created on the print server (0 to 254 characters).
 - Job Timeout: When the interface board is used as a NetWare remote printer, the printer cannot detect when a print job ends. Therefore, the printer terminates printing when a certain period of time has elapsed since it last received print data (i.e., when it has not received print data for a certain period of time). Specify here this period of time (3 to 255 seconds). The initial value is 15 (seconds).
 - Frame Type: Select the frame type from the drop-down menu.
 - Print Server Protocol: Select the protocol for NetWare from the drop-down menu.
- 5. Confirm the settings, and then click [OK].

Configuration is now complete. Wait several before restarting Web Image Monitor.

6. Click [Logout].

Vote

- To check that the configuration is made correctly, enter the following from the command prompt.
 F:> USERLIST
- If the printer works as configured, the name of the print server appears as a connected user.
- If you cannot identify the printer you want to configure, check the printer name with the configuration
 page printed from the printer. For details about printing a configuration page, see "List/Test Print
 Menu".
- If no printer names appear in the list, match the frame types of IPX/SPXs for the computer and printer. Use the [Network] dialog box of Windows to change the frame type of the computer.

Reference

• p.143 "List/Test Print Menu"

Setting Up as a Print Server (NetWare 4.x, 5/5.1, 6/6.5)

Follow the procedure below to connect the printer as a print server using NetWare 4.x, NetWare 5/5.1, or NetWare 6.0.

Coloritant 🖸

- When using the printer as a print server in NetWare 4.x, NetWare 5/5.1, or NetWare 6.0, set it to the NDS mode.
- When using NetWare 5/5.1 or NetWare 6.0, set the printer as a print server.
- 1. Start Web Image Monitor.
- 2. Click [Login].

A dialog box for entering the login user name and password appears.

3. Enter the login user name and password, and then click [Login].

For details about the login user name and password, consult your administrator.

- 4. In the left area, click [Configuration], and then click [NetWare] in "Network".
 - Print Server Name: Enter the NetWare print server name. To use the interface board as a print server, enter the name of a print server that is not active on the file server. Use up to 47 characters.
 - Logon Mode: Specify whether to designate a file server or NDS tree when logging on to NetWare.
 - File Server Name: When a file server name is entered here, only the specified file server is searched for. This item is mandatory. Use up to 47 characters.
 - NDS Tree: To enable NDS mode, enter the name of the NDS tree you want to log on to. Use up to 32 alphanumeric characters.

- NDS Context Name: To enable NDS mode, enter the print server context. Use up to 127 characters.
- Operation Mode: Specify whether to use the interface board as a print server or a remote printer.
- Remote Printer No.: This item is effective when the interface board is specified as a remote printer. Enter the same number as the number of the printer to be created on the print server (0 to 254 characters).
- Job Timeout: When the interface board is used as a NetWare remote printer, the printer cannot detect when a print job ends. Therefore, the printer terminates printing when a certain period of time has elapsed since it last received print data (i.e., when it has not received print data for a certain period of time). Specify here this period of time (3 to 255 seconds). The initial value is 15 (seconds).
- Frame Type: Select the frame type from the drop-down menu.
- Print Server Protocol: Select the protocol for NetWare from the drop-down menu.
- 5. Confirm the settings, and then click [OK].

Configuration is now complete. Wait several minutes before restarting Web Image Monitor.

6. Click [Logout].

Note

- To check that the configuration is made correctly, enter the following from the command prompt.
 F:> NLIST USER/A/B
- If the printer works as configured, the name of the print server appears as a connected user.
- If you cannot identify the printer you want to configure, check the printer name with the configuration
 page printed from the printer. For details about printing a configuration page, see "List/Test Print
 Menu".
- If no printer names appear in the list, match the frame types of IPX/SPXs for the computer and printer. Use the [Network] dialog box of Windows to change the frame type of the computer.

🖪 Reference 🔵

• p.143 "List/Test Print Menu"

Using Pure IP in the NetWare 5/5.1 or 6/6.5 Environment

Follow the procedure below to connect the printer as a print server in a pure IP environment of NetWare 5/5.1.

🚼 Important 🔵

- When creating a queued print server in a pure IP environment of NetWare 5/5.1 or NetWare 6.0, create a print queue on the file server using NetWare Administrator.
- This printer is not available as a remote printer for use in a pure IP environment.

• To use the printer in a pure IP environment, set it to TCP/IP.

Setting up using NWadmin

1. From Windows, start NWadmin.

For details about NWadmin, see the NetWare manuals.

- Select the object in which the print queue is located in the directory tree, and then click [Create] on the [Object] menu.
- 3. In the [Class of new object] box, click [Print Queue], and then click [OK].
- 4. In the [Print Queue Name] box, enter the name of the print queue.
- 5. In the [Print Queue Volume] box, click [Browse].
- 6. In the [Available objects] box, click the volume in which the print queue is created, and then click [OK].
- 7. Check the settings, and then click [Create].
- 8. Select the object in which the printer is located, and then click [Create] on the [Object] menu.
- In the [Class of new object] box, click [Printer], and then click [OK]. For NetWare 5, click [Printer (Non NDPS)].
- 10. In the [Printer name] box, enter the printer name
- 11. Select the [Define additional properties] check box, and then click [Create].
- 12. Click [Assignments], and then click [Add] in the [Assignments] area.
- 13. In the [Available objects] box, click the queue you, and then click [OK].
- 14. Click [Configuration], click [Parallel] in the [Printer type] list, and then click [Communication].
- 15. Click [Manual load] in the [Communication type] area, and then click [OK].
- 16. Check the settings, and then click [OK].
- 17. Select a context specified using NIB Setup Tool, and then click [Create] on the [Object] menu.
- In the [Class of new object] box, click [Print Server], and then click [OK]. For NetWare 5, click [Print Sever (Non NDPS)].
- **19.** In the [Print Server Name] box, enter the print server name. Use the same print server name specified using NIB Setup Tool.
- 20. Select the [Define additional properties] check box, and then click [Create].
- 21. Click [Assignments], and then click [Add] in the [Assignments] area.
- 22. In the [Available objects] box, click the queue you created, and then click [OK].
- 23. Check the settings, and then click [OK].
- 24. Start the print server by entering the following from the console of the NetWare server. If the print server is in operation, quit and restart it.

To exit

CAREE: unload pserver

To start

CAREE: load pserver "print_server_name"

Setting up using Web Image Monitor

- 1. Start Web Image Monitor.
- 2. Click [Login].

A dialog box for entering the login user name and login password appears.

- Enter the login user name and password, and then click [Login].
 For details about the login name and password, consult your administrator.
- 4. In the left area, click [Configuration], and then click [NetWare] in "Network".
- 5. Confirm the settings, and then click [OK].

Configuration is now complete. Wait several minutes before restarting Web Image Monitor.

6. Click [Logout].

Setting Up as a Remote Printer (NetWare 3.x)

Follow the procedure below to use the printer as a remote printer under NetWare 3.x.

Setting up using PCONSOLE

- 1. Enter "PCONSOLE" from the command prompt.
 - F:> PCONSOLE
- 2. Create a print queue.

When using the existing print queue, go to the procedure for creating a printer.

- From the [Available Options] menu, select [Print Queue Information], and then press the [Enter] key.
- 4. Press [Insert] key, and then enter a print queue name.
- 5. Press [Esc] key to return to the [Available Options] menu.
- 6. Set up the network connection to a printer.
- On the [Available Options] menu, click [Print Server Information], and then press the [Enter] key.
- 8. To create a new print server, press the [Insert] key, and then enter a print server name. For a currently defined print server, select a print server in the [Print Server] list.
- 9. From the [Print Server Information] menu, select [Print Server Configuration].

- 10. From the [Print Server Configuration] menu, select [Printer Configuration].
- 11. Select the printer indicated as [Not Installed].
- 12. To change the printer name, enter a new name. A name "Printer x" is assigned to the printer. The "x" stands for the number of the selected printer.
- As type, select [Remote Parallel, LPT1].
 The IRQ, Buffer size, Starting form, and Queue service mode are automatically configured.
- 14. Press the [Esc] key, and then click [Yes] on the confirmation message.
- 15. Press the [Esc] key to return to [Print Server Configuration Menu].
- 16. Assign print queues to the created printer.
- 17. From [Print Server Configuration Menu], select [Queues Serviced By Printer].
- 18. Select the printer created.
- Press the [Insert] key to select a queue serviced by the printer.
 You can select several queues.
- **20.** Follow the instructions on the screen to make other necessary settings. Following these steps, check that the queues are assigned.
- 21. Press the [Esc] key until "Exit?" appears, and then select [Yes] to exit PCONSOLE.
- 22. Start the print server by entering the following from the console of the NetWare server. If the print server is in operation, quit and restart it.

To quit

CAREE: unload pserver

To start

CAREE: load pserver "print_server_name"

Note

• If the printer works as configured, the message "Waiting for job" appears.

Setting up using Web Image Monitor

- 1. Start Web Image Monitor.
- 2. Click [Login].

A dialog box for entering the login user name and login password appears.

- Enter the login user name and password, and then click [Login].
 For details about the login name and password, consult your administrator.
- In the left area, click [Configuration], and then click [NetWare] in "Network".
- 5. Confirm the settings, and then click [OK].

Configuration is now complete. Wait several minutes before restarting Web Image Monitor.

6. Click [Logout].

Setting Up as a Remote Printer (NetWare 4.x, 5/5.1, 6/6.5)

Follow the procedure below to use the printer as a remote printer under NetWare 4.x, 5/5.1 and 6.

Coloritant 🖸

- To use the printer as a remote printer under NetWare $4 \times \frac{5}{5.1}$, set it to NDS mode.
- Do not use the printer as a remote printer when Pure IP is used.

Setting up using NWadmin

1. From Windows, start NWadmin.

For details about NWadmin, see the NetWare manuals.

- 2. Set up the network connection to a print queue. Select the object in which the print queue is located in the directory tree, and then click [Create] on the [Object] menu.
- 3. In the [Class of new object] box, click [Print Queue], and then click [OK].
- 4. In the [Print Queue Name] box, enter the name of the print queue.
- 5. In the [Print Queue Volume] box, click [Browse].
- 6. In the [Available objects] box, click the volume in which the print queue is created, and then click [OK].
- 7. Check the settings, and then click [Create].
- 8. Set up the network connection to a printer. Select the object in which the printer is located, and then click [Create] on the [Object] menu.
- 9. In the [Class of new object] box, click [Printer], and then click [OK]. For NetWare 5, click [Printer (Non NDPS)].
- 10. In the [Printer name] box, enter the printer name
- 11. Select the [Define additional properties] check box, and then click [Create].
- 12. Assign print queues to the created printer. Click [Assignments], and then click [Add] in the [Assignments] area.
- 13. In the [Available objects] box, click the queue you created, and then click [OK].
- 14. Click [Configuration], click [Parallel] in the [Printer type] list, and then click [Communication].
- 15. Click [Manual load] in the [Communication type] area, and then click [OK]. Check the settings, and then click [OK].
- Set up the network connection to a print server. Select a context specified using NIB Setup Tool, and then click [Create] on the [Object] menu.

- 17. In the [Class of new object] box, click [Print Server], and then click [OK]. For NetWare 5, click [Print Sever (Non NDPS)].
- In the [Print Server Name] box, enter the print server name.
 Use the same print server name specified using NIB Setup Tool.
- 19. Select the [Define additional properties] check box, and then click [Create].
- 20. Assign the printer to the created print server. Click [Assignments], and then click [Add] in the [Assignments] area.
- 21. In the [Available objects] box, click the queue you created, and then click [OK].
- 22. In the [Printers] area, click the printer you assigned, and then click [Printer Number].
- 23. Enter the printer number, and then click [OK]. Check the settings, and then click [OK].
- 24. Start the print server by entering the following from the console of the NetWare server. If the print server is in operation, quit and restart it.

To exit

CAREE: unload pserver

To start

CAREE: load pserver "print_server_name"

- 25. Enter the printer server name as the context name, and then press the [OK] key.
- 26. Select the printer name on the context menu, and then press the [OK] key.

Setting up using Web Image Monitor

- 1. Start Web Image Monitor.
- 2. Click [Login].

A dialog box for entering the login user name and login password appears.

- Enter the login user name and password, and then click [Login].
 For details about the login name and password, consult your administrator.
- 4. Click [Configuration] in the left area, and then click [NetWare] in "Network".
- 5. Confirm the settings, and then click [OK].

Configuration is now complete. Wait several minutes before restarting Web Image Monitor.

6. Click [Logout].

7. Using a Printer Server

8. Special Operations under Windows

Printing Files Directly from Windows

You can print files directly using Windows commands. For example, you can print PostScript files for PostScript 3.

Windows 95/98/Me

You can print files directly using "ftp" command.

Windows 2000/XP, Windows Server 2003/2003 R2, Windows NT 4.0

You can print files directly using "lpr", "rcp" or "ftp" command.

Note

• To use "sftp" commands, use an sftp client software that is compatible with ssh v2.

Setup

Follow the procedure below to make network environment settings.

1. Enable TCP/IP with the control panel, and then set up the printer's network environment about TCP/IP including IP addresses.

TCP/IP of the printer is set as default.

2. Install a TCP/IP in Windows to set up the network environment.

Consult the administrator for the local setting information.

 To print under Windows 2000/XP, Windows Server 2003/2003 R2, or Windows NT 4.0, install "Printing service for UNIX" as the network application. To print under Windows NT 4.0, install "Microsoft TCP/IP printing" as the network application.

Vote

- For details about setting up IPv4 address, see Hardware Guide.
- For details about setting the IPv4 address of the printer using DHCP, see "Cautions to Take When Using in a Network".
- This completes the setup for specifying a printer using an IPv4 address when printing. When using a
 host name to specify a printer, proceed to "Using a Host Name Instead of an IPv4 Address" and
 continue the setup.

Reference

• p.321 "Cautions to Take When Using in a network"

Using a Host Name Instead of an IPv4 Address

When a host name is defined, you can specify a printer by host name instead of IPv4 address. The host names vary depending on the network environment.

When using DNS

Use the host name set to the data file on the DNS server.

When setting the IPv4 address of a printer using DHCP

Use the printer name on the configuration page as the host name.

Note

• For details about printing a configuration page, see p.143 "List/Test Print Menu".

In other cases

Add the IPv4 address and host name of the network printer to the hosts file on the computer used for printing. Methods of addition vary depending on operating systems.

Windows 95/98/Me

- 1. Copy \WINDOWS\HOSTS.SAM to the same directory and name it "HOSTS" with no extension.
- 2. Open the "\WINDOWS\HOSTS" file created using memo pad files, for instance.
- 3. Add an IP address and host name to the hosts file using the following format:

192.168.15.16 host # NP

"192.168.15.16" is the IPv4 address, "host" is the printer's host name, and "#NP" is replaced by comments. Insert a space or tab between "192.168.15.16" and "host", between "host" and "#NP" respectively, using one line for this format.

4. Save the file.

Windows 2000/XP, Windows Server 2003/2003 R2, Windows NT 4.0

1. Open the hosts file using memo pad files, for instance.

The hosts file is in the following folder:

\WINNT\SYSTEM32\DRIVERS\ETC\HOSTS

"\WINNT" is the directory of the installation destination for Windows 2000/XP, Windows Server 2003/2003 R2, and Windows NT 4.0.

2. Add an IPv4 address and host name to the hosts file using the following format:

192.168.15.16 host # NP

"192.168.15.16" is the IPv4 address, "host" is the printer's host name, and "#NP" is replaced by comments. Insert a space or tab between "192.168.15.16" and "host", between "host" and "#NP" respectively, using one line for this format.

3. Save the file.

Note

• When using a host name under Windows Server 2003/2003 R2 with IPv6 protocol, perform host name resolution using an external DNS server. The host file cannot be used.

Printing Commands

The following explains printing operations using the "lpr", "rcp" and "ftp" commands.

Enter commands using the command prompt window. The location of the command prompts varies depending on operating systems:

• Windows 95/98

[Start] - [Programs] - [MS-DOS Prompt]

Windows Me

[Start] - [Programs] - [Accessories] - [MS-DOS Prompt]

• Windows 2000

[Start] - [Programs] - [Accessories] - [Command Prompt]

• Windows XP, Windows Server 2003/2003 R2

[Start] - [All Programs] - [Accessories] - [Command Prompt]

• Windows NT 4.0

[Start] - [Programs] - [Command Prompt]

```
Note
```

- Match the data format of the file to be printed with the emulation mode of the printer.
- If the message "print requests full" appears, no print jobs can be accepted. Try again when sessions end. For each command, the amount of possible sessions is indicated as follows:
 - lpr: 10
 - rcp, rsh: 5
 - ftp: 3
- Enter the file name in a format including the path from the directory executing commands.

lpr

When specifying a printer by IP address

```
c:> lpr -Sprinter's IP address [-Poption] [-ol] \pass name\file name
```

When using a host name instead of an IP address

c:> lpr -Sprinter's host name [-Poption] [-ol] \pass name\file name

When printing a binary file, add the "-ol" option (lowercase O, and lowercase L).

When using a printer with the host name "host" to print a PostScript file named "file 1" located in the "C: \PRINT" directory, the command line is as follows:

c:> lpr -Shost -Pfiletype=RPS -ol C:\PRINT\file1

rcp

First, register the printer's host name in the hosts file.

c:> rcp [-b] \pass name\file name [pass name\file name...] printer's host name: [option]

Note

- In file names, "*" and "?" can be used as wild cards.
- When printing a binary file, add the "-b" option.

When using a printer with the host name "host" to print a PostScript file named "file 1" or "file 2" located in the "C:\PRINT" directory, the command line is as follows:

c:> rcp -b C:\PRINT\file1 C:\PRINT\file2 host:filetype=RPS

ftp

Use the "put" or "mput" command according to the number of files to be printed.

When one file is printed

ftp> put \pass name\file name [option]

When multiple files are printed

ftp> mput \pass name\file name [\pass name\file name...] [option]

1. Formulate the printer's IP address or the host name of the hosts file printer as an argument and use the "ftp" command.

% ftp printer's IP address

2. Enter the user name and password, and then press the [OK] key.

For details about the user name and password, consult your administrator. User: Password:

3. When printing a binary file, set the file mode to binary.

ftp> bin

When printing a binary file in ASCII mode, print may not come out correctly.

4. Specify files to be printed.

The following shows the examples of printing a PostScript file named "file 1" in the "C:\PRINT" directory and printing file 1 and file 2.

ftp> put C:\PRINT\file1 filetype=RPS

ftp> mput C:\PRINT\file1 C:\PRINT\file2

5. Quit ftp.

ftp> bye

Note

- "=", ",", "_", and ";"cannot be used for filenames. File names will be read as option strings.
- For "mput" command, option can not be defined.
- For "mput" command, "*" and "?" can be used as wild cards in file names.
- When printing a binary file in ASCII mode, print may not come out correctly.

9. Mac OS Configuration

Mac OS

This section explains how to configure a Mac OS to use EtherTalk and USB.

The following explains how to configure Mac OS 9.1. If you are not using Mac OS 9.1, see the manual of the Mac OS you are using for details.

Comportant 🔁

- For Mac OS 8.6 and higher. (Mac OS X Classic environment is supported.)
- USB can be used only with Mac OS 9.2.2.

Note

• The PostScript 3 printer driver is stored in the following folder on the CD-ROM. Mac OS 8 and 9:PS Driver:(language):Disk1

Installing the PostScript 3 Printer Driver and PPD File

It is necessary to install a printer driver and PostScript Printer Description (PPD) files to print from a Mac OS.

Follow the procedure below to install a printer driver and a PPD file into a Mac OS using Mac OS 8.6 and higher.

PostScript 3 Printer Driver

- 1. Insert the CD-ROM into the CD-ROM drive.
- 2. Double-click the CD-ROM drive icon.
- 3. Double-click the [Mac OS 8 and 9] folder.
- 4. Double-click the [PS Driver] folder.
- 5. Double-click the folder of the language you use.
- 6. Open [Disk1], and then double-click the installer icon.
- 7. Follow the instructions on the screen.

PPD Files

- 1. Double-click the CD-ROM drive icon.
- 2. Double-click the [Mac OS 8 and 9] folder.
- 3. Double-click the [Printer Descriptions] folder.
- 4. Double-click the folder of the language you use.

- 5. Open the [Disk1] folder.
- 6. Drag the PPD file and the plugin file into [Printer Descriptions] in [Extensions] under [System Folder].
- 7. Restart the Mac OS.

Setting Up PPD Files

Comportant 🗋

- Make sure that the printers are connected to an AppleTalk network before performing the following procedure.
- 1. On the [Apple] menu, click [Chooser].
- 2. Click the Adobe PS icon.
- 3. In the [Select a PostScript Printer:] list, click the name of the printer you want to use.
- 4. Click [Create].
- 5. Click the printer you want to use, and then click [Select PPD].
- 6. A PPD file is set up and the Adobe PS icon appears at the left of the printer name in the list.

Using USB Interface

To use a printer connected by USB, create a desktop printer icon.

🚼 Important

- Make sure that printers are connected to the USB before performing the following procedure.
- USB can be used only with Mac OS 9.2.2.
- 1. Double-click [Desktop Printer Utility] in the [AdobePS Components] folder.
- 2. Click [AdobePS] in [With], click [Printer (USB)] in [Create Desktop], and then click [OK].
- 3. Click [Change] in [USB Printer Selection].
- 4. Select the model you are using in [Select a USB Printer:], and then click [OK].
- 5. Click [Create].
- 6. Enter the printer name, and then click [Save].
- 7. Quit Desktop Printer Utility.

Setting Up Options

1. On the [Apple] menu, click [Chooser].

- 2. Click the [Adobe PS] icon.
- 3. In the [Select the PostScript Printer:] list, click the name of the printer you want to use, and then click [Setup...].
- 4. Click [Configure].

A list of options appears.

- 5. Select the option you want to set up, and then select an appropriate setting for it.
- 6. Click [OK].

The list of options closes.

7. Click [OK].

The [Chooser] dialog box appears.

8. Close the [Chooser] dialog box.

Note

• If the option you want to select is not displayed, PPD files may not be set up correctly. To complete the setup, check the name of the PPD file displayed in the dialog box.

Installing Adobe Type Manager

🔁 Important

- Quit all applications currently running before installation. Install ATM after you restart the computer.
- 1. Insert the CD-ROM into the CD-ROM drive.
- 2. Double-click the CD-ROM drive con.
- 3. Double-click the [Mac OS 8 and 9] folder.
- 4. Double-click the [ATM] folder.
- 5. Double-click the [ATM 4.6.2 installer] icon.
- 6. Follow the instructions on the screen.
- When the procedure is complete, restart the computer. ATM will be completely installed only after restarting.
- 8. On the [Apple] menu, open [Control Panel], and then click [~ATM].

The ATM control panel opens.

Note

• For details about installation, see the operating instructions in the ATM folder.

Installing Screen Fonts

Follow the procedure below to install screen fonts.

The screen fonts described below can be found in the [Fonts] folder on the CD-ROM.

- 1. Insert the CD-ROM into the CD-ROM drive. The CD-ROM drive icon appears.
- 2. Double-click the CD-ROM drive icon. The contents of the CD-ROM appear.
- 3. Double-click the [Mac OS 8 and 9] folder.
- 4. Double-click the [Fonts] folder.
- 5. Double-click the [ScreenFonts] folder.
- 6. Double-click the [TrueType] or [Type1] folder. Select the font type you want to use.
- 7. Copy the fonts you want to install in [Fonts] folder under [System Folder].
- 8. A confirmation message appears.
- 9. Click [OK].

The fonts are installed.

10. Restart the Mac OS.

Changing to EtherTalk

Follow the procedure below to configure to a Mac OS to use EtherTalk.

- 1. Open [Control Panel], and then double-click the [AppleTalk] icon.
- 2. On the [Connect via:] pop-up menu, click [Ethernet].
- 3. If you change zones, select a name on the [OK] pop-up menu.
- 4. Close the AppleTalk control panel.
- 5. Restart the computer.

Vote

- The procedures used to configure Mac OS may vary depending on the Mac OS version. The following describes how to configure Mac OS 9.1. If you are using a different version of Mac OS, use the following procedures as a reference and see the manuals for your Mac OS version.
- Confirm the Connection to the Printer with TCP/IP.

Reference

• For information about installing applications required for EtherTalk, see the Mac OS manuals.

Mac OS X

This section explains how to configure a Mac OS X to use EtherTalk and USB.

Follow the procedure below to configure Mac OS X 10.1. If you are not using Mac OS X 10.1, see the manual of the Mac OS X you are using for details.

🔂 Important

- For Mac OS X 10.1 or higher.
- USB2.0 can be used only with Mac OS X 10.3.3 or higher.

Note

• The PPD files are stored in the following folder on the CD-ROM.

Mac OS X:PPD Installer

Installing the PPD Files

Follow the procedure below to install a PPD file to print from Mac OS X.

Comportant 🗋

- You need an administrator name and a password (phrase). For details, consult your administrator.
- 1. Insert the CD-ROM into the CD-ROM drive.
- 2. Double-click the CD-ROM drive icon.
- 3. Double-click the [Mac OS X] folder.
- 4. Double-click the [MacOSX PPD Installer] folder.
- 5. Double-click the installer icon.
- 6. Follow the instructions on the screen.

Setting Up PPD Files

- 1. Start Printer Setup Utility.
- 2. Click [Add].

Mac OS X 10.4 or later

Click [More Printers...]. Then select the zone from the second pop-up menu.

Other Mac OS X

Click [AppleTalk] on the first pop-up menu.

If the zone is set, select the zone from the second pop-up menu.

- 3. Select the printer, and then select its manufacturer from the [Printer Model:] pop-up menu. Under Mac OS X 10.4 or later, select the printer you are using from the [Print Using] popup menu. A list of printer types appears.
- 4. Select the PPD file for the model you are using, and then click [Add].
- 5. Quit Printer Setup Utility.

Setting Up Options

- 1. Start System Preferences.
- 2. Click [Print & Fax].
- In the [Printer] list, click the name of the printer you want to use, and then click [Printer Setup...].
- 4. Select the option you want to set up, and then select an appropriate setting for it.
- 5. Click [Apply Changes].

Vote

• If the option you want to select is not displayed, PPD files may not be set up correctly. To complete the setup, check the name of the PPD file displayed in the dialog box.

Using USB Interface

Follow the procedure below to setup USB connection.

C Important

- USB2.0 can be used only with Mac OS X 10.3.3 or higher.
- 1. Start Printer Setup Utility.
- 2. Click [Add].

Mac OS X 10.4 or later

Click a printer that has "USB" indicated in the "Connection" column.

Other Mac OS X

Click [USB] on the pop-up menu.

The connected printer appears.

3. Select the printer, and then select its manufacturer from the [Printer Model:] pop-up menu.

Under Mac OS X 10.4 or later, you are using from the [Print Using] pop-up menu.

A list of printer types appears.

4. Select the connected printer from the list of printer models, and then click [Add].

5. Quit Printer Setup Utility.

Vote

 When printing with a USB connection to a Macintosh computer, printer language does not change automatically. Use the control panel on this printer to change printer language to [Auto Detect] or [PS] before printing.

Using Bonjour (Rendezvous)

Follow the procedure below to print using Bonjour (Rendezvous) under Mac OS X 10.2.3 or higher. Ethernet, wireless LAN connections can also be used.

- 1. Start Printer Setup Utility.
- 2. Click [Add].

Mac OS X 10.4 or later

Click a printer that has "Bonjour" indicated in the "Connection" column.

Other Mac OS X

Click [Rendezvous] on the pop-up menu.

3. Select the name of the connected printer from the list of printer models, and then click [Add].

Under Mac OS X 10.4 or later, Installable Options window appears. Select the option you want to set up, and then select an appropriate setting for it, and then [Continue].

4. Quit Printer Setup Utility.

When printing with a Rendezvous connection to a Macintosh computer, printer language does not change automatically. Use the control panel on this printer to change printer language to [Auto Detect] or [PS] before printing.

Changing to EtherTalk

Follow the procedure below to configure a Mac OS X to use EtherTalk.

Coloritant 🔁

- You need an administrator name and a password (phrase). For details, consult your administrator
- 1. Open [System Preference], and then click the [Network] icon.
- 2. Click [Built-in Ethernet] in the [Show:] list box.
- 3. Click the [AppleTalk] tab.
- 4. Select the [Make AppleTalk Active] check box.
- 5. To change AppleTalk zones, select a name from the [AppleTalk Zone:] pop-up menu.

- 6. When the settings are made, click [Apply Now].
- 7. Quit [System Preference].

Reference

• For information about installing applications required for EtherTalk, see the Mac OS manuals.

Configuring the Printer

Use the control panel to enable AppleTalk. (The default is active.)

Using PostScript 3

Job Type

Use this to select the type of print job.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Job Type:] on [Job Log] in the print dialog box.
Mac OS X	[Job Type:] on [Job Log] in the print dialog box.

You can select the following items:

Normal Print

Select this for normal printing. The print job starts immediately after the print command is given.

Sample Print

Use this function to print only one set of a multiple print jobs.

The other sets are saved in the printer. The saved job can be printed from the printer's control panel. You can also delete the saved job.

Vote

- The "User ID:" can contain up to eight alphanumeric (a- z, A- Z, O- 9) characters.
- Entering the "User ID:" helps you distinguish your print job from others.

Locked Print

Use this function to save documents in the printer memory with a password, and then edit and print them as you want.

Note

- The "User ID:" can contain to eight alphanumeric (a-z, A-Z, 0-9) characters. The "Password" must be 4-8 digits.
- Entering the "User ID:" helps you distinguish your print job from others.

Hold Print

Use this function to temporarily hold a file in the printer, and print it from the computer or the printer's control panel later.

Note

- The "User ID:" can contain up to eight alphanumeric (a- z, A- Z, O- 9) characters.
- The "File Name:" can contain to 16 alphanumeric (a-z, A-Z, 0-9) characters.
- Entering the "User ID:" helps you distinguish your print job from others.

Stored Print

Use this function to store a file in the printer, and then print it from the computer or the printer's control panel later.

Note

- The "User ID:" can contain up to eight alphanumeric (a-z, A-Z, 0-9) characters. The "Password" must be 4-8 digits.
- The "File Name:" can contain to 16 alphanumeric (a-z, A-Z, 0-9) characters.
- You can assign a password to a saved document, but password assignment is not mandatory.
- Entering the "User ID:" helps you distinguish your print job from others.

Store and Print

Use this function to prints the file at once and also stores the file in the printer.

Note

- The "User ID:" can contain up to eight alphanumeric (a- z, A- Z, 0-9) characters. The "Password" must be 4-8 digits.
- The "File Name:" can contain to 16 alphanumeric (a-z, A-Z, 0-9) characters.
- You can assign a password to a saved document, but password assignment is not mandatory.
- Entering the "User ID:" helps you distinguish your print job from others.

Using Sample Print

Comportant 🗋

- You need Mac OS X v10.2 or higher to use this function.
- To use this function, the optional hard disk must be installed on the printer.
- The number of pages the printer can save varies depending on the contents of the print images. At most, the printer can save 100 jobs or 1,000 pages for Sample Print, Locked Print, Hold Print and Stored Print.
- Sample Print files will not appear on the display panel if they have already been executed or deleted using Web Image Monitor before you select [Sample Print] from the control panel.
- Sample Print files printed or deleted using Web Image Monitor after you select [Sample Print] using the control panel will appear on the display panel. However, an error message will appear if you try to print or delete those Sample Print files.
- If the application has a collate option, make sure that it is not selected before sending a print job. By default, sample print jobs are automatically collated by the printer driver. If the collate option is selected in the application print dialog box, more prints than intended may be printed.
- Print jobs are not saved on the hard disk in the following cases. You can check the error log for jobs not saved.

- When there are 100 Sample Print, Locked Print, Hold Print and Stored Print jobs saved on the hard disk.
- When the total number of pages saved on the hard disk exceeds 1,000 pages.
- 1. In the application, on the [File] menu, click [Print].

The [Print] dialog box appears.

2. Set the number of copies to two or more.

The sample print job is sent to the printer, and one set is printed.

- 3. In the pop-up menu, click [Job Log].
- 4. On the [Job Type:] pop-up menu, select [Sample Print].
- In the [User ID:] box, enter a user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters.

The user ID associates the user with his/her jobs.

6. Check the printed output to make sure the settings are correct.

If the settings are correct, perform the following steps to print the remaining sets.

If you want to delete a saved job, see "Deleting a Sample Print File".

7. Press the [Menu] key.

The [Menu] screen appears.

- 8. Press the [▼] or [▲] key to display [Sample Print], and then press the [# Enter] key.
- **9.** Press the [▼] or [▲] key to display [Print One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to print, and then press the [# Enter] key.

Enter the new number of sets using the [▲] or [▼] keys. You can enter up to 999 sets.

To cancel printing, press the [Escape] key.

11. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

12. Press the [Online] key.

The initial screen appears.

🕗 Note

• When printing is completed, the stored file will be deleted.

Deleting a selected Sample Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Sample Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

To cancel deleting a Sample Print file, press the [Escape] key.

- Press Check the file you want to delete is displayed, and then press the [# Enter] key. The selected file is deleted.
- 6. Press the [Online] key.

The initial screen appears.

Deleting all Sample Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Sample Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID and the time when the job was stored appear.
- Press the [▼] or [▲] key to confirm deleting all files, and then press the [# Enter] key. To cancel deleting a Sample Print file, press the [Escape] key.
- 5. Press the [# Enter] key.
- 6. Press the [Online] key.

The initial screen appears.

Using Locked Print

🔁 Important

- You need Mac OS X v10.2 or higher to use this function.
- To use this function, the optional hard disk must be installed on the printer.
- The number of pages the printer can save varies depending on the contents of the print images. At most, the printer can save 100 jobs or 1,000 pages for Sample Print, Locked Print and Hold Print.
- Locked Print files will not appear on the display panel if they have already been printed or deleted using Web Image Monitor before you select [Locked Print] using the control panel.
- Locked Print files printed or deleted using Web Image Monitor after you have selected [Locked Print]
 using the control panel will still appear on the display panel. However, an error message will appear
 if you try to print or delete those Locked Print files.

- If the application has a collate option, make sure that it is not selected before sending a print job. By default, locked print jobs are automatically collated by the printer driver. If the collate option is selected in the application print dialog box, more prints than intended may be printed.
- Print jobs are not saved on the hard disk in the following cases. You can check the error log for jobs not saved.
 - When there are 100 Sample Print, Locked Print, Hold Print and Stored Print jobs saved on the hard disk.
 - When the total number of pages saved on the hard disk exceeds 1,000 pages.
- 1. In the application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2. In the pop-up menu, click [Job Log].
- 3. On the [Job Type:] pop-up menu, click [Locked Print].
- 4. In the [User ID:] box, enter a user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters, and then enter a 4-8 digit password in the [Password:] box.

The user ID associates the user with his/her jobs.

5. After making the necessary settings, click [Print].

The document file is saved in the printer.

To print the document, perform the following steps.

To delete the document, see "Delete a Locked Print File".

6. Press the [Menu] key.

The [Menu] screen appears.

- 7. Press the [▼] or [▲] key to display [Locked Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Print One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Select the file you want to print using the [▲] or [▼] key, and then press the [# Enter] key. The password screen appears.
- 10. Enter the password using the [▼] or [▲] key, and then press the [# Enter] key. If you forget your password, ask your administrator for help. Check that the file you want to print is displayed
- Enter the number of sets you want to print, press the [♥] or [▲] key. To cancel printing, press the [Escape] key.
- 12. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

9

13. Press the [Online] key.

The initial screen appears.

Note

- When printing is completed, the stored file will be deleted.
- To stop printing after printing has started, press the [Job Reset] key. The file will be deleted.

Deleting a selected Locked Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Locked Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

The password screen appears.

- 5. Enter the password using the [♥] or [▲] key, and then press the [# Enter] key. If you forget your password, ask your administrator for help.
- 6. Press Check the file you want to delete is displayed, and then press the [# Enter] key. The selected file is deleted.
- 7. Press the [Online] key.

The initial screen appears.

Deleting all Locked Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Locked Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID and the time when the job was stored appear.
- Press the [▼] or [▲] key to confirm deleting all files, and then press the [# Enter] key. The password screen appears.

To cancel deleting a Locked Print file, press the [Escape] key.

5. Enter the password using the [▲] or [▼] key, and then press the [# Enter] key. If you forget your password, ask your administrator for help. The printer deletes files that correspond to the entered password. The number of files to be deleted is displayed on the confirmation screen.

- Press Check the file you want to delete is displayed, and then press the [# Enter] key. The selected file is deleted.
- 7. Press the [Online] key.

The initial screen appears.

Using Hold Print

Coloritant 🔂

- You need Mac OS X v10.2 or higher to use this function.
- To use this function, the optional hard disk must be installed on the printer.
- The number of pages the printer can save varies depending on the contents of the print images. At most, the printer can save 100 jobs or 1,000 pages for Sample Print, Locked Print and Hold Print.
- Hold Print files will not appear on the display panel if they have already been printed or deleted using Web Image Monitor before you select [Hold Print] using the control panel.
- Hold Print files printed or deleted using Web Image Monitor after you have selected [Hold Print] using the control panel will still appear on the display panel. However, an error message will appear if you try to print or delete those Hold Print files.
- If the application has a collate option, make sure that it is not selected before sending a print job. By default, Hold print jobs are automatically collated by the printer driver. If the collate option is selected in the application print dialog box, more prints than intended may be printed.
- Print jobs are not saved on the hard disk in the following cases. You can check the error log for jobs not saved.
 - When there are 100 Sample Print, Locked Print, Hold Print and Stored Print jobs saved on the hard disk.
 - When the total number of pages saved on the hard disk exceeds 1,000 pages.
- 1. In the application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2. In the pop-up menu, click [Job Log].
- 3. On the [Job Type:] pop-up menu, click [Hold Print].
- 4. In the [User ID:] box, enter a user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters. File Name can also be set.

The user ID associates the user with his/her jobs.

5. After making the necessary settings, click [Print].

The document file is saved in the printer.

To print the document, perform the following steps.

To delete the document, see "Deleting a Hold Print File".

6. Press the [Menu] key.

The [Menu] screen appears.

- 7. Press the [▼] or [▲] to display key [Hold Print], and then press the [# Enter] key.
- Press the [▼] or [▲] to display key [Print One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Select the file you want to print using the [▼] or [▲] key, and then press the [# Enter] key. To cancel printing, press the [Escape] key.
- 10. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

11. Press the [Online] key.

The initial screen appears.

Note

- When printing is completed, the stored file is deleted.
- To stop printing after printing has started, press the [Job Reset] key. The file is deleted.

Reference

• For details about setting printer drivers, see the printer driver Help. You can also print or delete a Hold Print file from Web Image Monitor. For details, see Web Image Monitor Help.

Deleting a selected Hold Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Hold Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

To cancel deleting a Hold Print file, press the [Escape] key.

- 5. Check that the file you want to delete is displayed, and then press the [# Enter] key.
- 6. Press the [Online] key.

The initial screen appears.

Deleting all Hold Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Hold Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID and the time when the job was stored appear.
- Press the [▼] or [▲] key to confirm deleting all files, and then press the [# Enter] key. To cancel deleting a Hold Print file, press the [Escape] key.
- 5. Press the [# Enter] key.
- 6. Press the [Online] key.

The initial screen appears.

Using Stored Print

🔂 Important

- You need Mac OS X v10.2 or higher to use this function.
- To use this function, the optional hard disk must be installed on the printer.
- Stored Print files will not appear on the display panel if they have already been printed or deleted using Web Image Monitor before you select [Stored Print] using the control panel.
- Stored Print files printed or deleted using Web Image Monitor after you have selected [Stored Print] using the control panel will still appear on the display panel. However, an error message will appear if you try to print or delete those Stored Print files.
- If the application has a collate option, make sure that it is not selected before sending a print job. By default, Stored print jobs are automatically collated by the printer driver. If the collate option is selected in the application print dialog box, more prints than intended may be printed.
- Print jobs are not saved on the hard disk in the following cases. You can check the error log for jobs not saved.
 - When there are 100 Sample Print, Locked Print, Hold Print and Stored Print jobs saved on the hard disk.
 - When the total number of pages saved on the hard disk exceeds 1,000 pages.
- 1. In the application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2. In the pop-up menu, click [Job Log].
- 3. On the [Job Type:] pop-up menu, click [Stored Print] or [Stored and Print].
 - [Stored Print]

Stores the file in the printer and print it later using the control panel.

• [Stored and Print]

Prints the file at once and also stores the file in the printer.

4. In the [User ID:] box, enter a user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters, and then enter a 4-8 digit password in the [Password:] box. File Name can also be set.

The user ID associates the user with his/her jobs.

You can assign a password to a saved document, but password assignment is not mandatory.

The password must be entered when printing or deleting.

5. After making the necessary settings, click [Print].

The document file is saved in the printer.

To print the document, perform the following steps.

To delete the document, see "Deleting Stored Print File".

6. Press the [Menu] key.

The [Menu] screen appears.

- 7. Press the [♥] or [▲] key to display [Stored Print], and then press the [# Enter] key.
- Press the [▼] or [▲] key to display [Print One File], and then press the [# Enter] key. The file name and the time when the job was stored appear. To cancel printing, press the [Escape] key.
- Press the [♥] or [▲] key to display the file you want to print, and then press the [# Enter] key.

If you set a password in the printer driver, a password confirmation screen appears. Enter the password.

10. Press the [# Enter] key.

The "To print, press [ESC] 1-4 times" message appears. Then the file selection screen reappears.

11. Press the [Online] key.

The initial screen appears.

Note

- To stop printing after printing has started, press the [Job Reset] key. A Stored Print file is not deleted even if the [Job Reset] key is pressed.
- The Stored Print file that sent to the printer is not deleted unless you delete a file or select [Auto Del. Stored].
- For details about setting printer drivers, see the printer driver Help. You can also print or delete a Stored Print file from Web Image Monitor. For details, see Web Image Monitor Help.
- For details about the [Auto Del. Stored], see "System Menu".

Reference

• p.149 "System Menu"

Deleting a selected Stored Print file only

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Stored Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Delete One File], and then press the [# Enter] key. The file name and the time when the job was stored appear.
- Press the [▼] or [▲] key to display the file you want to delete, and then press the [# Enter] key.

To cancel deleting a Stored Print file, press the [Escape] key.

If you set the password in the printer driver, enter the password to delete.

If you forget your password, ask your administrator for help.

- 5. Press the [# Enter] key.
- 6. Press the [Online] key.

The initial screen appears.

Deleting all Stored Print files

1. Press the [Menu] key.

The [Menu] screen appears.

- 2. Press the [▼] or [▲] key to display [Stored Print], and then press the [# Enter] key.
- 3. Press the [▼] or [▲] key to display [Del. All Files], and then press the [# Enter] key. The user ID and the time when the job was stored appear.
- 4. Press the [▼] or [▲] key to confirm deleting all files, and then press the [# Enter] key. To cancel deleting a Stored Print file, press the [Escape] key. If you set the password in the printer driver, enter the password to delete.

If you forget your password, ask your administrator for help.

5. Press the [# Enter] key.

Press the [Online] key.

The initial screen appears.

9

User Code

Use this to set a user code for print logging.

Enter a user code using up to eight digits. A user code identifies a group of users and allows you to check the number of sheets printed under each code with SmartDeviceMonitor for Admin.

The following table shows the tabs or menus where you can select this function.

Mac OS	Select the [Enable User Code] check box, and then enter a user code in the [User Code] box on [Job Log] in the print dialog box.
Mac OS X	Select the [Enable User Code] check box, and then enter a user code in the [User Code] box on [Job Log] in the print dialog box.

Paper Size

Use this to select the size of paper you want to use.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Paper:] on the [Page Attributes] tab in the Page Setup dialog box.
Mac OS X	[Paper Size:] in the Page Setup dialog box.

Fit to Paper

9

When the size of the document and paper size differ, set whether or not to print according to paper size.

Mac OS [Fit to Paper] on [Printer Specific Options] in the print dialog	oox.
---	------

Prompt User

Print is performed with the size of document to be printed unchanged.

Nearest Size and Scale

If the paper size is smaller than the selected paper size, the driver reduces the print size.

If the paper size is larger than the size of document to be printed, print is not to fit the paper size.

Nearest Size and Crop

When the paper size is smaller than the size of document to be printed, print is adjusted to meet the paper size.

Paper Source (Paper Feed)

Use this to select the paper sources.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Paper Source:] on [General] in the print dialog box.
Mac OS X	[Paper Feed] in the print dialog box.

Resolution

Use this to set the resolution types.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Resolution] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Resolution] on the [Features x] tab on [Printer Features] in the print dialog box.

Orientation Override

Use this to set the paper orientation.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Orientation Override] on [Printer Specific Options] in the print dialog box.	
Mac OS X	[Orientation Override] on the [Feature Sets: X] tab on [Printer Features] in the print dialog box.	

You can select the following items:

- Off
- Landscape
- Portrait

Duplex Printing

Use this function to select duplex printing.

🚼 Important

• To use this function, the optional duplex unit must be installed on the printer.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Print on Both Sides] on [Layout:] in the print dialog box.
Mac OS X	• 10.3 or higher
	The [Two Sided Printing] check box on [Layout:] in the print dialog box.
	Other Mac OS X
	The [Print on both Sides] check box on [Duplex:] in the print dialog box.

None

Disables duplex printing.

Flip on Long Edge

Prints so you can open it to the long edge when bound along the long edge.

Flip on Short Edge

Prints so you can open it to the short edge when bound along the short edge.

Toner Saving

Use this function to reduce the amount of toner used when printing.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Print Mode] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Print Mode] on the [Feature Set: x] tab on [Printer Features] in the print dialog box.

Reference

• For details about this function, see printer driver Help.

Collate

Use this function to enable collation. With this feature, the printer can efficiently print collated sets of multiplepage documents.

🚼 Important

- To use this function, a memory unit of at least 192 MB or hard disk drive must be installed on the printer.
- If you are using Mac OS or Mac OS X, make sure that the following check boxes have not been selected.
 - Mac OS

The [Collate:] check box in the print dialog box.

• Mac OS X

The [Collate:] check box on [Copies & Pages] in the printer dialog box.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Collate:] on [Printer Specific Options] in the print dialog box.	
Mac OS X	[Collate:] on the [Feature Sets: x] tab on [Printer Feature] in the printer dialog box.	

Paper Type

Use this to select the paper type.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Paper Type:] on [Printer Specific Options] in the print dialog box.	
Mac OS X	[Paper Type] on the [Feature Set: x] tab on [Printer Features] in the print dialog box.	

Image Smoothing

Use this to select the image smoothing type.

The following table shows the tabs or menus where you can select this function.

Mac OS	[Image Smoothing] on [Printer Specific Options] in the print dialog box.
	[Image Smoothing] on the [Feature Set: x] tab on [Printer Features] in the print dialog box.

Off

Disables image smoothing.

9

On

Performs image smoothing unconditionally.

Auto

Performs image smoothing automatically for images that have a resolution less than 25% of supported printer resolution.

Less than 90 ppi - Less than 300 ppi

Performs image smoothing only when the image has an image resolution (pixels per inch) less than the respective value you have selected in the list.

Note

- When Auto is selected, data processing may take a long time.
- When [Image Smoothing:] is used for a mask image, this function may have an undesired effect on the print result.

Dithering

Use this function to set the Image Rendering mode.

The following table shows the tabs or menus where you can select this function.

Mac OS	Dithering: on Printer Specific Options in the print dialog box.	
Mac OS X	Dithering: on the Feature Set: x tab on Printer Features in the print dialog box.	

You can select the following items:

Auto

Use this setting to configure the best dithering method automatically depending on the appearance of the document to be printed.

Photographic

Performs dithering using an appropriate pattern for photographs.

Text

Performs dithering using an appropriate pattern for text.

User Setting

Use this setting to print images set in half tone in your application.

Printer Utility for Mac

By using Printer Utility for Mac, you can download fonts, change the name of the printer and so on.

🔁 Important

• If a Macintosh and printer are connected by USB, you cannot use Printer Utility for Mac.

Note

- Printer Utility for Mac is included on the CD-ROM labeled "Printer Drivers and Utilities".
- Printer Utility for Mac requires Mac OS 7.6.1-9.x, or Mac OS X 10.1.x or 10.2.1. Mac OS X 10.0.x and 10.2 are not supported.

Installing Printer Utility for Mac

Follow these steps to install Printer Utility for Mac on the printer.

1. Insert the CD-ROM into the CD-ROM drive.

The CD-ROM icon appears.

- 2. Double-click the CD-ROM icon. The contents of the CD-ROM appear.
- 3. Double-click the [Mac OS 8 and 9] icon to open it.

Under Mac OS X, double-click the [Mac OS X] folder.

- 4. Double-click the [PS Utility] folder on the CD-ROM, and then drag the [Printer Utility for Mac] file, and then drop it into the Macintosh hard disk.
- 5. Drag the CD-ROM icon and drop it into [Trash] to eject the CD-ROM.

Printer Utility for Mac is installed.

Note

- Printer Utility for Mac is included on the CD-ROM labeled "Printer Drivers and Utilities".
- Printer Utility for Mac requires Mac OS 8.1 or higher. (Mac OS X Classic environment is supported.)
- Printer Utility for Mac cannot use Mac OS X (native mode).

Starting Printer Utility for Mac

Mac OS

😭 Important

- Before starting Printer Utility for Mac, make sure the printer is selected in [Chooser] on the Apple menu.
- 1. Double-click the Printer Utility for Mac icon.

The [Printer Utility for Mac] dialog box appears.

2. Click [OK].

Printer Utility for Mac will take a few seconds to start.

Mac OS X

1. Double-click the Printer Utility for Mac icon.

The [Printer Utility for Mac] dialog box appears.

- 2. Click [OK].
- 3. In the [Available Printers:] box, select the printer you want to use.

If you change zones, select a name from [Available Network Zones:].

Click [Choose Printer...] on the Printer Utility for Mac menu if you want to change the printer.

4. Select the printer you want to use.

Printer Utility for Mac will take a few seconds to start.

5. Click [Choose].

Printer Utility for Mac Functions

Downloading PS Fonts

You can download the PS fonts to the printer memory or hard disk drive.

🔁 Important

- The following procedure to download the fonts assume that you are a system administrator. If you are not, be sure to consult your system administrator.
- During the download, do not turn off the power switch, operate the panel or open or close the cover.
- If the printer restarts, all the printer settings return to the defaults.

- Confirm that a Macintosh and the printer are connected with Appletalk.
- 1. Select [Download PS Fonts...] on the [File] menu.
- 2. Click [Add to list].

The dialog box to select fonts appears.

3. Select the desired font files, and then click [Open].

The list of selectable font names appears.

4. After adding all the fonts you want to download, click [OK].

The dialog box of selected fonts to download appears.

5. Click [Download].

The fonts begin to download, and the download status is shown.

- 6. When the completion message appears, click [OK].
- 7. Click [Cancel].

Note

- Some fonts cannot be downloaded.
- Before downloading, read the documentation about the fonts you want to use.

Displaying Printer Fonts

You can display the available fonts currently downloaded to the printer. Fonts in the printer memory and hard disk drive can be displayed.

1. Select [Display Printer's Fonts...] on the [File] menu.

A dialog box appears.

- 2. Select [Printer's memory] or [Printer's disk].
- 3. Click [OK].

Note

• The fonts displayed in italics are the default fonts.

Deleting Fonts

You can delete fonts from the printer's memory or hard disk drive.

🔁 Important

- You cannot delete the fonts displayed in italic.
- 1. Select [Display Printer's fonts] on the [File] menu.

A dialog box appears.

- 2. Select [Printer's memory] or [Printer's disk].
- 3. Select the fonts you want to delete.
- 4. Click [Delete].

A confirmation message appears.

- Confirm the fonts you want to delete and the printer name from which you want to delete the fonts.
- 6. Click [Continue], and then click [OK].
- 7. Click [OK].

Initializing the Printer Disk

When initializing the printer hard disk, all the fonts downloaded to the printer hard disk drive are deleted. Before initializing, be sure to check the fonts on the hard disk drive.

🔁 Important

- When initializing the printer hard disk drive from the control panel, all of the data on the printer hard disk drive is deleted. Before initializing, be sure to check the data on the hard disk drive.
- Do not turn off the power switch until initializing is completed, otherwise the hard disk drive might be damaged.
- 1. Select [Initialize Printer's Disk...] on the [File] menu.

The confirmation message appears. To cancel initialization, click [Cancel].

2. Click [Execute].

Initializing starts.

3. When the completion message appears, click [OK].

Page Setup

You can set the paper size on which to print "Print Fonts Catalogue" and "Prints Fonts Sample".

- 1. Select [Page Setup...] on the [File] menu.
- 2. Select the paper size.
- 3. Click [OK].

Printing Font Catalog

You can print the names of fonts available on the printer.

1. Select [Print Fonts Catalog...] on the [File] menu.

2. Click [Print].

Vote

• The paper selected under [Page Setup] is used.

Printing Font Sample

You can print samples of fonts downloaded to the hard disk drive or memory.

- 1. Select [Print Fonts Sample...] on the [File] menu.
- 2. Click [Print].

Note

• Print by using the paper selected on [Page Setup].

Renaming the Printer

You can change the printer name displayed under Appletalk. If you connect several printers on the network, assign different names so you can identify them. If several printers have the same name, a digit appears next to the printer name in [Chooser].

🚼 Important

- You can enter up to 31 digits and letters.
- Do not use symbols, for example "*", ":", "=", "@", "~".

Mac OS

- 1. On the [File] menu, click [Rename Printer...].
- 2. In the [New Name:] filed enter a new name.
- 3. Click [Rename].

The printer name is changed.

- 4. Click [OK].
- 5. On the Apple menu, click [Chooser].
- 6. Click the [AdobePS] icon.
- 7. Select the printer whose name you changed, and then close the [Chooser] dialog box. If there are several AppleTalk zones, select the zone the printer belongs to.

Mac OS X

- 1. On the [File] menu, click [Rename Printer...].
- 2. In the [New Name:] filed enter a new name.

9

3. Click [Rename].

The printer name is changed.

- 4. Click [OK].
- 5. On the [Printer Utility for Mac] menu, click [Choose Printer...].
- 6. In the [Available Network Zones:] list, select the zone for the Macintosh in use.
- In the [Available Printers:] list, select the printer whose name you changed, and then click [Choose].

Restarting the Printer

You can restart the printer.

- 1. Select [Restart Printer] on the [File] menu.
- 2. Confirm the message that appears on the screen, and then click [Restart].

The printer restarts.

The fonts downloaded in the printer memory will be deleted.

If the printer restarts, all the printer settings return to the defaults.

Downloading PostScript Files

You can download a Postscript file to the printer.

- 1. Select [Download PostScript File...] on the [Utility] menu.
- 2. Select the file name to download, click the file name, and then click [Open].
- 3. Type the log file name, and then click [Save].

The selected file is downloaded.

Errors are recorded in the log file.

Selecting the Zone

You can change the zone to which the printer belongs under Appletalk.

🔂 Important 🔵

• Confirm that a Macintosh and printer are connected with Appletalk.

Mac OS

1. On the [Utility] menu, click [Select Zone...].

The zone to which the printer belongs and the available zone list appear.

- Select the zone in which you want to locate the printer, and then click [Change].
 A confirmation message appears.
- 3. Click [Continue].

A confirmation message appears.

- 4. Click [OK].
- 5. On the Apple menu, click [Chooser].
- 6. Click the [AdobePS] icon.
- 7. In the [AppleTalk zone:] list, select the zone you changed.
- 8. In the [Select a PostScript Printer:] list, select the printer you want to use.
- 9. Close the [Chooser] dialog box.

Mac OS X

1. On the [Utility] menu, click [Select Zone...].

The zone to which the printer belongs and the available zone list appear.

- Select the zone which you want to locate the printer in, and then click [Change]. A confirmation message appears.
- 3. Click [Continue].

A confirmation message appears.

- 4. Click [OK].
- 5. On the [Printer Utility for Mac] menu, click [Choose Printer...].
- 6. In the [Available Network Zones:] list, select the zone you changed.
- 7. In the [Available Printers:] list, select the model of printer in use, and then click [Choose].

Displaying the Printer Status

You can display and confirm the current status of the printer.

1. Select [Display Printer Status...] on the [Utility] menu.

The current status of the printer appears.

2. Confirm the current status of the printer.

You can confirm the memory capacity, the VM (Virtual Memory) space, the hard disk drive status and available space on the hard disk drive. You can also confirm the zone to which the printer belongs.

3. Click [OK].

9

Launching the Dialogue Console

You can create and edit a PostScript file for printing, and then download it to the printer.

Comportant)

- "Launch Dialogue Console" is recommended for users with an understanding of PostScript.
- Do not download any file other than PostScript files to the printer.
- "Launch Dialogue Console" must be used at your own responsibility.
- Select [Launch Dialogue Console...] on the [Utility] menu.
 Open the editing screen. The Dialogue Console menu bar appears.
- 2. Type the PostScript command in the editor screen.

To edit a PostScript file, select [Open] on the [File] menu to open it.

You can search or replace a character string by using the [Search] menu.

3. After editing the PostScript file, select [Download Top Window] on [Console] menu to start printing.

The PostScript file is sent to the printer.

The [Reply from Printer] box opens, depending on the PostScript file you sent.

4. Select [Return To Main Menu] on the [Console] menu to close the PostScript file.

10. Appendix

Software and Utilities Included on the CD-ROM

The following softwares and utilities are included in the CD-ROMs that come with the printer.

Font Manager 2000

For installing new screen fonts, or organizing and managing fonts already in the system. For details about Font Manager 2000, see the manual on the CD-ROM labeled "Printer Drivers and Utilities".

SmartDeviceMonitor for Admin

For the system administrator to manage network printers.

Reference

• SmartDeviceMonitor for Admin Help

DeskTopBinder - SmartDeviceMonitor for Client

For users to manage their network print status.

Reference

• DeskTopBinder - SmartDeviceMonitor for Client Help

Viewing the contents of the CD-ROM

1. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

2. Click [Browse This CD-ROM].

Explorer starts and displays the contents of the CD-ROM.

Printer Drivers for This Printer

Printing requires installing a printer driver appropriate to your operating system. The following drivers are included on the CD-ROM provided with this printer.

PCL 5e/6 printer driver

This printer driver allows the computer to communicate with the printer via a printer language.

The following operating system is supported.

• Windows 95/98/Me, Windows 2000/XP, and Windows Server 2003/2003 R2

Note

• For Windows NT 4.0, Service Pack 6 or higher is required.



RPCS printer driver

This printer driver allows the computer to communicate with the printer using a printer language. In addition to the conventional user interface, another preset user interface is provided.

The following operating system is supported.

• Windows 95/98/Me, Windows 2000/XP, and Windows Server 2003/2003 R2

PostScript Printer Drivers and PPD files

PostScript printer drivers and the PPD files are included on the CD-ROM provided with this printer. PostScript printer drivers allow the computer to communicate with the printer using a printer language. PPD files allow the printer driver to enable specific printer functions.

The following operating system is supported.

 Windows 95/98/Me, Windows 2000/XP, Windows Server 2003/2003 R2, Mac OS, and Mac OS X.

Vote

- The PostScript printer drivers and PPD files are included on the CD-ROM labeled "Printer Drivers and Utilities".
- For Mac OS, version 8.6 or higher is required. (Mac OS X Classic environment is supported.)

PPD files

PPD files are included on the CD-ROM provided with this printer. PPD files allow the printer driver to enable specific printer functions.

SmartDeviceMonitor for Admin

SmartDeviceMonitor for Admin is an application that uses TCP/IP and IPX/SPX to monitor network printers. It can monitor multiple network printers using IP address. We recommend that administrators use this application.

File path

SmartDeviceMonitor for Admin is stored in the following folder on the CD-ROM.

NETWORK\DEVMON\ADMIN\DISK1

Operating system	Protocol stack
Windows 95/98/Me	TCP/IP provided with Windows 95/98/Me IPX/SPX provided with Windows 95/98/Me
	NetWare Client provided with Windows 95/98 Novell Client provided with Windows 95/98
Windows 2000	TCP/IP provided with Windows 2000

Operating system	Protocol stack
	IPX/SPX provided with Windows 2000
	NetWare Client provided with Windows 2000
	Novell Client provided with Windows 2000 or Window NT
Windows XP	TCP/IP provided with Windows XP
	IPX/SPX provided with Windows XP
	NetWare Client provided with Windows XP
	Novell Client provided with Windows XP
Windows Server 2003/2003 R2	TCP/IP provided with Windows Server 2003/2003 R2
	IPX/SPX provided with Windows Server 2003/2003 R2
	NetWare Client provided with Windows Server 2003/2003 R2
	Novell Client provided with Windows Server 2003/2003 R2
Windows NT 4.0	TCP/IP provided with Windows NT
	IPX/SPX provided with Windows NT
	Client Service for NetWare provided with Windows NT
	Novell Client provided with Windows 2000 or Windows NT

Available functions

SmartDeviceMonitor for Admin has the following functions to check:

- printer supplies such as paper or toner;
- results of print jobs executed from the computer.

Reference

• For information about using SmartDeviceMonitor for Admin, see SmartDeviceMonitor for Admin Help.

DeskTopBinder - SmartDeviceMonitor for Client

SmartDeviceMonitor for Client has the following functions. We recommend that users install this application.

- Printing in a peer-to-peer network, using TCP/IP, and IPP from Windows 95/98/Me/2000/XP, Windows Server 2003/2003 R2, and Windows NT 4.0.
- Constantly monitoring the status of devices on the network using TCP/IP and IPX/SPX.

File path

SmartDeviceMonitor for Client is stored in the following folder on the CD-ROM.

NETWORK\DEVMON\CLIENT\DISK1

Operating system	Protocol stack
Windows 95/98/Me	TCP/IP provided with Windows 95/98/Me
	IPX/SPX provided with Windows 95/98/Me
	NetWare Client provided with Windows 95/98/Me
	Novell Client provided with Windows 95/98/Me
Windows 2000	TCP/IP provided with Windows 2000
	IPX/SPX provided with Windows 2000
	NetWare Client provided with Windows 2000
	Novell Client provided with Windows 2000 or NT
Windows XP	TCP/IP provided with Windows XP
	IPX/SPX provided with Windows XP
	NetWare Client provided with Windows XP
	Novell Client provided with Windows XP
Windows Server 2003/2003 R2	TCP/IP provided with Windows Server 2003/2003 R2
	IPX/SPX provided with Windows Server 2003/2003 R2
	NetWare Client provided with Windows Server 2003/2003 R2
	Novell Client provided with Windows Server 2003/2003 R2
Windows NT 4.0	TCP/IP provided with Windows NT
	IPX/SPX provided with Windows NT
	Client Service for NetWare provided with Windows NT
	Novell Client provided with Windows 2000 or Windows NT

Available functions

SmartDeviceMonitor for Client has the following functions.

- Peer-to-peer print function
 - Prints directly on the network printer without sending any data to a print server.
 - Prints on a substitute printer when there are too many jobs waiting on the specified printer, or when an error disables printing (Recovery Printing).
 - Allocates multiple print jobs to multiple printers (Parallel Printing).

- Executes prior group registration of printers specified for Recovery Printing or Parallel Printing.
- Notification function
 - Displays an error message when there is an error on the specified printer while transferring or printing data.
 - Notifies a print completion. You can also be notified of the print condition, such as displaying the notice only when Recovery Printing is executed.
- Monitoring function
 - Checks printer supplies such as paper or toner.
 - Simultaneously monitors multiple printers in use.
 - Checks the printer's network settings and detailed information of printers.
 - Enables you to check the print job log using the user ID
- Notifies the user when a print job is completed by displaying the [Printout/Data-transmission] dialog box. You can also be notified of specific print conditions, such as when Recovery printing is performed.
- Display the log of printed files, and the current status of the files being printed.

Coloritant 🔁

- To perform Recovery or Parallel printing, the same options that are installed on the original printer must be installed on the other printers also. Printers that lack a required option cannot be used for Recovery or Parallel printing.
- To perform Recovery or Parallel printing, the same paper loaded in the original printer must be loaded in the other printers also. Load all printers with the same paper as that loaded in the tray selected for printing.
- Results of Recovery or Parallel Printing might differ, depending on the model of the other printer and the options installed on it.
- If you select Sample Print or Locked Print, you cannot select Recovery Printing or Parallel Printing.

Reference

• For details about using SmartDeviceMonitor for Client, see SmartDeviceMonitor for Client Help.

Protection Using Encryption


When you access the printer using a Web Image Monitor or IPP, you can establish encrypted communication using SSL.

When you access the printer using an application such as SmartDeviceMonitor for Admin, you can establish encrypted communication using SNMPv3 or SSL. To protect data from interception, analysis, and tampering, you can install a server certificate in the printer, negotiate a secure connection, and encrypt transmitted data.

🔁 Important

- You must install one of the following memory options to perform encryption:
 - the hard disk
 - the SDRAM module
 - the data storage card

SSL (SSL (Secure Sockets Layer)Secure Sockets Layer)



1. To access the printer from a user's computer, request for the SSL server certificate and public key.

- 2. The server certificate and public key are sent from the printer to the user's computer.
- 3. Create shared key from the user's computer, and then encrypt it using public key.
- 4. The encrypted shared key is sent to the printer.
- 5. The encrypted shared key is decrypted in the machine using private key.
- 6. Transmit the encrypted data using the shared key, and then decrypt the data at the machine to attain secure transmission.

SSL (Secure Sockets Layer) Encryption

This can be specified by the administrator.

To protect the communication path and establish encrypted communication, create and install the server certificate. There are two ways of installing a server certificate: create and install a self-certificate using the printer, or request a certificate from a certificate authority and install it.

Configuration flow (self-signed certificate)

- Creating and installing the server certificate Install the server certificate using Web Image Monitor.
- 2. Enabling SSL

Enable the SSL/TLS setting using Web Image Monitor.

Configuration flow (certificate issued by a certificate authority)

1. Creating the server certificate

Create the server certificate using Web Image Monitor.

The application procedure after creating the certificate depends on the certificate authority. Follow the procedure specified by the certificate authority.

2. Installing the server certificate

Install the server certificate using Web Image Monitor.

3. Enabling SSL

Enable the SSL/TLS setting using Web Image Monitor.

Creating and Installing the Server Certificate (Self-Signed Certificate)

Create and install the server certificate using Web Image Monitor.

Vote

 To confirm whether SSL configuration is enabled, enter https://(printer's-address) in your Web Image Monitor's address bar to access this printer. If the "The page cannot be displayed" message appears, check the configuration as the SSL configuration is invalid.

Creating and Installing the Self-Signed Certificate

Create and install the server certificate using Web Image Monitor. This section explains the use of a selfcertificate as the server certificate.

- 1. Log on to Web Image Monitor in the administrator mode.
- In the left area, click [Configuration], and then click [Device Certificate] in "Security". The [Device Certificate] page appears.
- 3. Click [Create].
- 4. Make the necessary settings.
- 5. Click [OK].

The setting is changed.

6. Click [OK].

A security warning dialog box appears.

7. Check the details, and then click [OK].

[Installed] appears under [Certificate Status] to show that a server certificate for the printer has been installed.

8. Quite Web Image Monitor.

Note

• Click [Delete] to delete the server certificate from the printer.

Reference

• For details about the displayed items and selectable items, see Web Image Monitor Help.

Creating the Server Certificate (Certificate Issued by a Certificate Authority)

Create the server certificate using Web Image Monitor. This section explains the use of a certificate issued by a certificate authority as the server certificate.

- 1. Log on to Web Image Monitor in the administrator mode.
- In the left area, click [Configuration], and then click [Device Certificate] in "Security". The [Device Certificate] page appears.
- 3. Click [Request].
- 4. Make the necessary settings.
- 5. Click [OK].

[Requesting] appears for [Certificate Status] in the [Device Certificate] area.

6. Quite Web Image Monitor.

7. Apply to the certificate authority for the server certificate.

The application procedure depends on the certificate authority. For details, contact the certificate authority.

Vote

- If you apply for two certificates simultaneously, the certificate authority may not appear in the certificates. When you install these certificates, be sure to take notes of the certificate contents and the order in which the certificates were installed.
- Using Web Image Monitor, you can create the contents of the server certificate but you cannot send the application.
- Click [Cancel Request] to cancel the request for the server certificate.

Reference

• For details about the displayed items and selectable items, see Web Image Monitor Help.

Installing the Server Certificate (Certificate Issued by a Certificate Authority)

Install the server certificate using Web Image Monitor.

This section explains the use of a certificate issued by a certificate authority as the server certificate. Enter the server certificate contents issued by the certificate authority.

- 1. Log on to Web Image Monitor in the administrator mode.
- 2. In the left area, click [Configuration], and then click [Device Certificate] in "Security".

The [Device Certificate] page appears.

- 3. Click [Install].
- 4. Enter the contents of the server certificate.

In the Device Certificate Request box, enter the contents of the server certificate received from the certificate authority.

5. Click [OK].

[Installed] appears under [Certificate Status] to show that a server certificate for the printer has been installed.

6. Quite Web Image Monitor.

🕒 Reference

• For details about the displayed items and selectable items, see Web Image Monitor Help.

Enabling SSL

After installing the server certificate in the printer, enable the SSL setting.

This procedure is used for a self-signed certificate or a certificate issued by a certificate authority.

- 1. Log on to Web Image Monitor in the administrator mode.
- In the left area, click [Configuration], and then click [SSL/TLS] in "Security". The [SSL/TLS] page appears.
- 3. Click [Active] for [SSL/TLS].
- 4. Click [OK].

The SSL setting is enabled.

5. Quite Web Image Monitor.

Vote

 If you set [Permit SSL/TLS Communication] to [Ciphertext Priority], enter "https://(printer's address)/" to access the printer.

User Settings for SSL (Secure Sockets Layer)

If you have installed a server certificate and enabled SSL (Secure Sockets Layer), you need to install the certificate on the user's computer.

The administrator must explain the procedure for installing the certificate to users. If a warning dialog box appears while accessing the printer using the Web Image Monitor or IPP, start the Certificate Import Wizard and install a certificate.

1. When the [Security Alert] dialog box appears, click [View Certificate].

The [Certificate] dialog box appears.

To be able to respond to inquiries from users about such problems as expiry of the certificate, check the contents of the certificate.

2. On the [General] tab, click [Install Certificate...].

Certificate Import Wizard starts.

3. Install the certificate by following the Certificate Import Wizard instructions.

Note

- For details about how to install the certificate, see the Web Image Monitor Help.
- If a certificate issued by a certificate authority is installed in the printer, confirm the certificate store location with the certificate authority.

🖪 Reference 🔵

 For details about where to store the certificate when accessing the printer using IPP, see the SmartDeviceMonitor for Client Help.

Setting the SSL / TLS Encryption Mode

By specifying the SSL/TLS encrypted communication mode, you can change the security level.

Encrypted Communication Mode

Using the encrypted communication mode, you can specify encrypted communication.

Ciphertext Only	Allows encrypted communication only. If encryption is not possible, the printer does not communicate.
Ciphertext Priority	Performs encrypted communication if encryption is possible. If encryption is not possible, the printer communicates without it.
Ciphertext/Clear Text	Communicates with or without encryption, according to the setting.

Setting the SSL / TLS Encryption Mode

This can be specified by the administrator.

After installing the server certificate, specify the SSL/TLS encrypted communication mode. By making this setting, you can change the security level. Specify the SSL/TLS encrypted communication mode using Web Image Monitor.

- 1. Log on to Web Image Monitor in the administrator mode.
- 2. Click [Configuration].
- 3. Click [SSL/TLS] in "Security".
- 4. Select the encryption communication mode in the [Permit SSL/TLS Communication] list, and then click [OK].

Select [Ciphertext Only], [Ciphertext Priority], or [Ciphertext/Clear Text] as the encrypted communication mode.

5. Quit Web Image Monitor.

SNMPv3 Encryption

This can be specified by the administrator.

When using SmartDeviceMonitor for Admin or another application to make various settings, you can encrypt the data transmitted. By making this setting, you can protect data from being tampered with. Specify the SNMPv3 encrypted communication mode using Web Image Monitor.

- 1. Log on to Web Image Monitor in the administrator mode.
- 2. Click [Configuration].
- 3. Click [Network Security] in "Security".
- Click [Encryption Only] in the [Permit SNMPv3 Communication] area in the [SNMPv3] area, and then click [OK].
- 5. Quit Web Image Monitor.

Note

- To use SmartDeviceMonitor for Admin for encrypting the data for specifying settings, you need to specify the administrator's [Encryption Password] setting and [Encryption Key] in [SNMP Authentication Information] in SmartDeviceMonitor for Admin, in addition to specifying [Permit SNMPv3 Communication] on the printer.
- If administrator's [Encryption Password] setting is not specified, the data for transmission may not be encrypted or sent.

Reference

 For details about specifying [Encryption Key] in SmartDeviceMonitor for Admin, see the SmartDeviceMonitor for Admin Help.

10

Cautions to Take When Using in a network

Connecting a Dial-up Router to a Network

When the NetWare file server and printer are on opposite sides of a router, packets are sent back and forth, causing communication charges to be incurred. Because packet transmission is a specification of NetWare, you need to change the configuration of the router. If the network you are using does not allow you to configure the router, configure the printer instead.

Configuring the router

Filter packets so that they do not pass over the dial-up router.

Note

- The MAC address of the printer doing the filtering is printed on the printer configuration page. For details about printing a configuration page, see p.143 "List/Test Print Menu".
- For details about configuring the printer if the router cannot be configured, see the instructions below.

Configuring the printer with NetWare

- 1. Following the setup method described earlier in this manual, configure the file server.
- 2. Set the frame type for NetWare environment.

Reference

• For details about selecting a frame type, see p.157 "Host Interface Menu".

Configuring the printer without NetWare

When not printing, the network interface board sends packets over the network. Set NetWare to "inactive".

🖪 Reference 🔵

• For details about selecting protocols, see p.157 "Host Interface Menu".

Using DHCP

You can use the printer in a DHCP environment. You can also register the printer NetBIOS name on a WINS server when it is running. Note the following points when an Ethernet interface is simultaneously installed.

When static IPv4 addresses are set for each interface

- IPv4 address: When set at the same value, the Ethernet interface is preferred.
- Subnet mask: When a value overlaps, the Ethernet interface is preferred.
- Gateway address: The value set is used. For the gateway address, set the gateway address located in the subnetwork set by the interface. If the value is outside the subnet range set by the interface, it operates as "0.0.0.0".

When obtaining addresses from the DHCP server

- IP Address, Subnet Mask: you can configure addresses assigned by a DHCP server. If IPv4 addresses overlap or the same subnet IP addresses are selected, the effective value is assigned only to the prioritized interface. Ethernet has default interface priority.
- AutoNet: A temporary IPv4 address starting with 169.254 and not used on the network, is assigned to the prioritized interface.
- Gateway Address, DNS Server Address, and Domain Name: You can configure the addresses assigned by DHCP to the prioritized interface.

If the gateway address is beyond the range of the subnet selected for the interface, the printer operates using "0.0.0.0".

Ethernet has default interface priority.

When there are static IPv4 addresses and addresses assigned by DHCP

- IPv4 Address and subnet mask: if a static IPv4 address is the same as an address assigned by DHCP, or the static subnet mask address and the subnet mask address assigned by DHCP overlap, the printer uses the static IPv4 address interface. The interface with the DHCP setting is set by default.
- Gateway Address: operates using the address entered manually.

If a static address is not selected, or is set to 0.0.0.0, the interface using the address assigned by DHCP is used.

Note

- NetBIOS name on a WINS server must be configured for the WINS server.
- Supported DHCP servers are: Windows 2000 Server, Windows Server 2003/2003 R2, Windows NT 4.0, NetWare server, and the standard DHCP server of UNIX.
- If you do not use the WINS server, reserve the printer's IP address in the DHCP server so the same IPv4 address is assigned every time.
- To use the WINS server, change the WINS server setting to "active" using the control panel.
- Using the WINS server, you can configure the host name via the remote network printer port.
- DHCP relay-agent is not supported. If you use DHCP relay-agent on a network via ISDN, it will result in increased line charges. This is because your computer connects to the ISDN line whenever a packet is transferred from the printer.

• If there is more than one DHCP server, use the same setting for all servers. The printer operates using data from the DHCP server that responds first.

Using AutoNet

If the printer IPv4 address is not assigned by a DHCP server automatically, a temporary IPv4 address starting with 169.254, which is not used on the network, can be automatically selected by the printer.

You must change this setting to "on" to use AutoNet.

Note

- The IP address assigned by the DHCP server is given priority over that selected by AutoNet.
- You can confirm the current IPv4 address on the configuration page. For more information about the configuration page, see "List/Test Print Menu".
- When AutoNet is running, the NetBIOS name is not registered on the WINS server.
- The printer cannot communicate with devices that do not have the AutoNet function. However, this printer can communicate with Macintosh computers running Mac OS X 10.2.3. or higher.

Reference

- p.143 "List/Test Print Menu"
- p.197 "Remote Maintenance by telnet"

Configuring the WINS Server

The printer can be configured to register its NetBIOS name with a WINS server when the power is turned on. This enables the NetBIOS name of the printer to be specified from SmartDeviceMonitor for Admin even in a DHCP environment. This section explains configuring the WINS server.

Note

- The WINS server is supported with Windows NT 4.0 Server Service Pack 4 or higher, and Windows 2000 Servers WINS Manager.
- For details about the WINS server settings, see Windows Help.
- If there is no reply from the WINS server, the NetBIOS name is registered by broadcast.
- The NetBIOS name can be entered using up to 13 alphanumeric characters.

Using Web Image Monitor

1. Start a Web browser.

 Enter "http://(printer's address)/" in the address bar to access the printer whose settings you want to change.

Top Page of Web Image Monitor appears.

3. Click [Login].

The dialog box for entering the user name and password appears.

4. Enter the user name and password, and then click [Login].

Contact your administrator for information about the settings.

- 5. In the left area, click [Configuration], and then click [IPv4] in "Network".
- Check that [Active] is selected for [WINS] in the [Ethernet+IEEE 802.11b] column, and then enter the WINS server IPv4 address in [Primary WINS Server] and [Secondary WINS Server].
- 7. Click [OK].
- 8. Quit Web Image Monitor.

Using telnet

See p.197 "Remote Maintenance by telnet".

Using the Dynamic DNS Function

Dynamic DNS is a function which dynamically updates (registers and deletes) records (A record and PTR record) managed by the DNS server. When a DNS server is part of the network environment to which this printer, a DNS client, is connected, records can be dynamically updated using this function.

10

Updating

Updating procedure varies depending on whether the printer IP address is static or acquired by DHCP. When the dynamic DNS function is not used, records managed by the DNS server must be updated manually, if the printer's IP address is changed.

To update the record using the printer, the DNS server has to have one of the following:

- No security settings made.
- If security settings are made, an IP-specified client (this printer) permits updating.

For a static IP setting

If the IP address or host name is changed, the A and PTR records are updated.

If the A record is registered, CNAME is also registered. CNAMEs that can be registered are as follows:

• Ethernet and IEEE 802.11b

RNPXXXXXX (XXXXXX represents the last 3 hexadecimal bytes of the MAC address)

For DHCP settings

As a substitute for the printer, the DHCP server updates the record, and one of the following occurs:

- When the printer acquires the IP address from the DHCP server, the DHCP server updates the A and PTR records.
- When the printer acquires the IP address from the DHCP server, the printer updates the A record, and the DHCP server updates the PTR record.

If the A record is registered, CNAME is also registered. CNAMEs that can be registered are as follows:

• Ethernet and IEEE 802.11b

RNPXXXXXX (XXXXXX represents the last 3 hexadecimal bytes of the MAC address)

Vote

• Dynamic update using message authentication (TSIG, SIG (0)) is not supported.

DNS servers targeted for operation

For static IP setting

- Microsoft DNS servers with standard Windows 2000 Server/Windows Server 2003/2003 R2 features
- BIND 8.2.3 or higher

For DHCP setup, when the printer updates the A record

- Microsoft DNS servers with standard Windows 2000 Server/Windows Server 2003/2003 R2 features
- BIND 8.2.3 or higher

For DHCP setup, when the DHCP server updates records

- Microsoft DNS servers with standard Windows 2000 Server/Windows Server 2003/2003 R2 features
- BIND 8.2.3 or higher
- DNS servers with standard NetWare 5 (or a higher version) features

For IPv6 setting

- Microsoft DNS servers with standard Windows Server 2003/2003 R2 features
- BIND 9.2.3 or higher

DHCP servers targeted for operation

As a substitute for the printer, DHCP servers capable of updating the A record and PTR record are as follows:

- Microsoft DHCP servers with standard Windows 2000 Server (Service Pack 3 or higher versions)/ Windows Server 2003/2003 R2 features
- ISC DHCP 3.0 or higher
- DHCP server with standard NetWare 5 features

Setting the dynamic DNS function

Make settings with telnet using the "dns" command. For details, see p.197 "Remote Maintenance by telnet".

Installing Font Manager 2000

Comportant 🔁

- Under Windows 2000/XP, Windows Server 2003/2003 R2, or Windows NT 4.0, installing applications by Auto Run requires administrator permission. To install a printer driver by Auto Run, log on using an account that has administrator permission.
- 1. Quit all applications currently running.
- 2. Insert the CD-ROM into the CD-ROM drive.

The installer starts.

- 3. Click [Font Manager 2000].
- 4. Follow the instructions on the screen.

Using Adobe PageMaker Version 6.0, 6.5, or 7.0

Under Windows 95/98/Me/2000/XP, Windows Server 2003/2003 R2, or Windows NT 4.0 with Adobe PageMaker, you need to copy PPD files to the PageMaker folder.

PPD files have the .ppd extension in the folder "DRIVERS\PS\WIN9X_ME \(Language)\DISK1\" on the CD-ROM.

The "WIN9X_ME" folder inside the "PS" folder is for Windows 95/98/Me. Use the folder at this level that is appropriate for the operating system you are currently using.

The third folder "(Language)" may be substituted by an appropriate language name.

Copy the .ppd file to the PageMaker folder.

• For PageMaker 6.0 default installation

The directory is "C:\PM6\RSRC\PPD4".

• For PageMaker 6.5 default installation

The directory is "C:\PM65\RSRC\USENGLISH\PPD4".

The "USENGLISH" may vary depending on your language selection.

• For PageMaker 7.0 default installation

The directory is "C:\PM7\RSRC\USENGLISH\PPD4".

The "USENGLISH" may vary depending on your language selection.

Note

- If the driver is not set correctly after copying the ".ppd" file, printing may not be performed properly.
- When using PageMaker, the optional features that can be selected by the printer driver will not be active. The following procedure describes how to activate the optional printer features.
 - 1. On the [File] menu, click [Print].

The [Print Document] dialog box appears.

2. Make the necessary settings in the [Features] box.

When Using Windows Terminal Service/ MetaFrame

The following explains how to use Windows Terminal Service and Maintenance.

Operating Environment

The following operating systems and MetaFrame versions are supported.

Windows NT Server 4.0 Terminal Server Edition with SP6 or higher

- MetaFrame 1.8 SP3/FR1+SP3/SP4
- MetaFrame XP 1.0 SP1/SP2/FR1

Windows 2000 Server/Advanced Server

- MetaFrame 1.8 SP3/FR1+SP3/SP4
- MetaFrame XP 1.0 SP1/SP2/SP3/SP4/FR1/FR2/FR3
- MetaFrame Presentation Server 3.0
- Citrix Presentation Server 4.0

Windows Server 2003/2003 R2

- MetaFrame XP 1.0 FR3
- MetaFrame Presentation Server 3.0
- Citrix Presentation Server 4.0

Supported Printer Drivers

When Windows Terminal Service is operating

- PCL printer drivers
- PostScript 3
- RPCS drivers

Note

• Some RPCS printer driver functions do not work if Windows Terminal Service is installed.

Limitations

The following limitations apply to the Windows Terminal Service environment.

These limitations are built in Windows Terminal Service or MetaFrame.

Windows Terminal Service

In an environment where Windows Terminal Service is installed, some printer driver functions are unavailable, even if no Windows Terminal Service functions are used. Use the install mode to install SmartDeviceMonitor for Client in an environment where Terminal Service is running on a Windows NT Server 4.0 Terminal Server Edition or Windows 2000 Server family computer. The following are the two methods of installation using the install mode:

- 1. Use [Add/Remove Programs] in [Control Panel] to install SmartDeviceMonitor for Client.
- 2. Enter the following command in the MS-DOS command prompt:

CHANGE USER / INSTALL

To quit the install mode, enter the following command in the MS-DOS command prompt: CHANGE_USER_/EXECUTE

Reference

• For more information, see Windows Help.

MetaFrame's [Auto-creating client printers]

Using [Auto-creating client printers], you can select a logical printer created by copying the client's local printer data to the MetaFrame server. We strongly recommend testing this function in your network environment before using it for your work.

- The settings for optional equipment will not be stored in the server after the equipment is disconnected. The settings for optional equipment will be restored to its defaults each time the client computer logs on to the server.
- When printing a large number of bitmap images or using the server in a WAN environment over dial-up lines such as ISDN, printing may not be possible or errors may occur, depending on data transfer rates.
- When using MetaFrame XP 1.0 or higher versions, we recommend making settings in [Client Printer bandwidth] under [Citrix Management Console] according to the environment.
- If a print error occurs on the server and the print job or a printer created in [Auto-creating client printers] cannot be deleted, we recommend the following:
 - MetaFrame 1.8 SP3, MetaFrame XP 1.0 SP1/FR1

Make settings in [Delete unfinished print jobs] in the registry. For details, see the Readme file provided with MetaFrame.

MetaFrame XP 1.0 FR2

Make settings in [Delete pending print jobs at logout] under [Printer Properties Management] of Citrix Management Console.

MetaFrame's [Printer driver replication]

Using [Printer driver replication], you can distribute printer drivers across all servers in a server farm. We strongly recommend testing this function in your network environment before using it for your work. • If the printer drivers are not properly copied, install them directly onto each server.

10

Copyright Information about Installed Applications

expat

Use of the software installed on this product, including the controller (hereinafter "software") and the expat Version 1.95.2 application software (hereinafter "expat 1.95.2"), is subject to the following conditions:

The product manufacturer provides warranty and support to the software of the product including expat 1.95.2 and the product manufacturer allows the initial developer of expat 1.95.2 to be free from these obligations.

Copyright © 1998, 1999, 2000 Thai Open Source Software Center Ltd

and Clark Cooper

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Note

• Information on expat 1.95.2 is available at:

http://expat.sourceforge.net/

JPEG LIBRARY

The software installed on this product is based in part on the work of the Independent JPEG Group.

NetBSD

Copyright Notice of NetBSD

For all users to use this product:

This product contains NetBSD operating system:

For the most part, the software constituting the NetBSD operating system is not in the public domain; its authors retain their copyright.

The following text shows the copyright notice used for many of the NetBSD source code. For exact copyright notice applicable for each of the files/binaries, the source code tree must be consulted.

A full source code can be found at http://www.netbsd.org/.

Copyright © 1999, 2000 The NetBSD Foundation, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. All advertising materials mentioning features or use of this software must display the following acknowledgment:

This product includes software developed by the NetBSD Foundation, Inc. and its contributors.

4. Neither the name of The NetBSD Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE NETBSD FOUNDATION, INC. AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Authors Name List

All product names mentioned herein are trademarks of their respective owners.

The following notices are required to satisfy the license terms of the software that we have mentioned in this document:

- This product includes software developed by the University of California, Berkeley and its contributors.
- This product includes software developed by Jonathan R. Stone for the NetBSD Project.
- This product includes software developed by the NetBSD Foundation, Inc. and its contributors.

- This product includes software developed by Manuel Bouyer.
- This product includes software developed by Charles Hannum.
- This product includes software developed by Charles M. Hannum.
- This product includes software developed by Christopher G. Demetriou.
- This product includes software developed by TooLs GmbH.
- This product includes software developed by Terrence R. Lambert.
- This product includes software developed by Adam Glass and Charles Hannum.
- This product includes software developed by Theo de Raadt.
- This product includes software developed by Jonathan Stone and Jason R. Thorpe for the NetBSD Project.
- This product includes software developed by the University of California, Lawrence Berkeley Laboratory and its contributors.
- This product includes software developed by Christos Zoulas.
- This product includes software developed by Christopher G. Demetriou for the NetBSD Project.
- This product includes software developed by Paul Kranenburg.
- This product includes software developed by Adam Glass.
- This product includes software developed by Jonathan Stone.
- This product includes software developed by Jonathan Stone for the NetBSD Project.
- This product includes software developed by Winning Strategies, Inc.
- This product includes software developed by Frank van der Linden for the NetBSD Project.
- This product includes software developed for the NetBSD Project by Frank van der Linden
- This product includes software developed for the NetBSD Project by Jason R. Thorpe.
- The software was developed by the University of California, Berkeley.
- This product includes software developed by Chris Provenzano, the University of California, Berkeley, and contributors.

Samba(Ver 2.2.2-1.1)

Copyright © Andrew Tridgell 1994-1998

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details. You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 675 Mass Ave, Cambridge, MA 02139, USA.

RSA BSAFE ®



- This product includes RSA BSAFE [®] cryptographic or security protocol software from RSA Security Inc.
- RSA is a registered trademark and BSAFE is a registered trademark of RSA Security Inc.in the United States and/or other countries.
- RSA Security Inc. All rights reserved.

10. Appendix

INDEX

Α

Access Control
Administrator Mode173, 173
Adobe Type Manager27
Auto E-mail Notification19
Auto Tray Select13
autonet19
AutoNet

B

Banner Page	50
Bidirectional Communication is Disabled	63
Bonjour199	, 282

С

Canceling a Print Job116, 117
CD-ROM
Changing Names and Comments185
Changing the Paper Type180
Changing the Port Settings for SmartDeviceMonitor for Client
Collate120, 298
Conditions for Bidirectional Communication62
Configuration Page143
Configuring the WINS Server323
Confirming the Connection Method17
Copyright Information332
Cover123
Current Printer Status231

D

Data Format	166
Data Security for Copying	94
Deleting Fonts	
DeskTopBinder	15, 21, 89, 311
devicename	
DHCP	201, 321
Dial-up Router	
diprint	
Display	13
Displaying the Printer Status	
dns	
DNS	
domainname	

Downloading PostScript Files	.306
Downloading PS Fonts	.302
Duplex Printing	.297
Dynamic DNS	.324

E

E-Mail Notification	190
Encrypted Communication Mode	
Energy Saver Mode	183
Energy Saver Timer	149
Enter key	13
Error Log	119
Escape key	13
EtherTalk	278, 282
expat	

F

Fit to Paper	296
Font Manager 2000	327
Font Priority	64
Form Feed	50, 115
Form Feed key	13
Frame Priority	64

G

Guest Mode1	7	7	3	3
-------------	---	---	---	---

н

Having Problems Installing the Printer Driver f the CD-ROM	rom 60
HD Format	146
help	206
Hold Print106, 107, 108, 285, 3	291
Host Interface Menu	157
hostname	206

L

IEEE 1284	56
IEEE 802.11b	224
ifconfig	206
Image Smoothing	
Important Notice	97
info	
Initializing Printer Disk	
Installing DeskTopBinder Lite	

Installing DeskT Client			
Installing Printer	Utility for Ma	c	301
Installing Smart	DeviceMonitor	r for Admin.	178
Installing the PC 39,	L or RPCS Prin 43,		21, 35, 56
Installing the Pos 39, 43,			
Installing the PPI) Files		275, 280
IPP	23,	26, 29, 31,	188, 208
ipv6			209

J

Job Reset key	13
Job Spool	221
Job Type	
JPEG	

L

L	
Language Menu1	70
Launching the Dialogue Console3	80
List/Test Print Menu1	43
Local Connection	19
Locked Print102, 103, 104, 285, 2	88
Locking the Menus1	80
lpr2	09
LPR Port17,	39

Μ

Mac OS	87, 275, 302
Mac OS X	
Mail authentication	192
Maintenance Menu	146
Manuals for This Printer	10
Mask Type	95
Memory Capacity and Paper Size	64
Memory Usage	64
Menu Chart	133
Menu key	13
Message List	248
MetaFrame	329
MIB	230
Monitoring Printers	

Ν

NetBSD	
NetWare	48, 49, 209, 259, 321
NetWare 3.x	
NetWare 4.x	
NetWare 5/5.1	
NetWare 6/6.5	
Network Connection	17
Network Interface Board	Configuration239

0

On-demand E-mail	193
On-demand E-mail Notification	191
Online key	13
Option Settings	62
Orientation Override	297

Page Setup304
PageMaker
Paper Feed
Paper Input Menu
Paper Size
Paper Source
Paper Type
Parallel Connection19, 56, 57, 58, 59
passwd211
Password211
pathmtu211
PathMTU Discovery Service
PCL Menu
PCL Printer Driver15, 22, 23, 35, 39, 43, 51, 56, 67, 309
PDF Direct Print
PDF Menu168
PostScript 3 Printer Driver25, 26, 28, 29, 30, 31, 36, 37, 40, 41, 44, 45, 46, 49, 51, 57, 58, 59, 81, 275, 285
PPD File275, 280
Print Job237
Print Log237
Printer Configuration235
Printer Driver
Printer Fonts

Q

Quick Install15
Quick Install15

R

Renaming the Printer.	
Rendezvous	
Resolution	
route	
RPCS Printer Driver 56,	23, 35, 39, 43, 51, 309

S

Samba
Sample Print98, 99, 101, 285, 286
Screen Fonts278
Selecting the Zone
set213
Setting a Password184
Setting Applicable Functions to New Users 183
Setting the SSL / TLS Encryption Mode
Setting Up as a Remote Printer260, 261, 262, 264, 266
Setting Up for Printing81, 87
Setting Up Options276, 281
Setting Up PPD Files276, 280
show216
Slip Sheets125
slp216

SmartDe 181,	viceMonit 183,				
SmartDe 311	viceMonif	tor for Cl	ient	.21, 188,	257,
SmartDe	viceMonit	or Port		1	7, 21
smb					216
snmp					217
SNMP					230
	B Encryptic				
•					
	and Utilit				
Spool Pr	int Job				187
Spool Pr	inting				121
spoolsw.				•••••	221
ssdp				••••••	221
ssh					222
SSL Encr	yption				, 315
Standard	HTCP/IP	Port		1	7, 35
Stored P	rint	1	10, 111,	113, 285,	, 293
Symbols	••••••				11
syslog					223
System L	og				, 248
System N	Aenu				149
т					

TCP/IP	22, 25, 28, 30
TCP/IP address	206
telnet	197
Terminal Service	
Toner Saving	
Тор Раде	172
Tray Priority	139
Troubleshooting USB	

U

Unauthorized Copy Control	>5
Understanding the Displayed Information23	
UNIX	2
upnp22	23
USB Connection19, 51, 53, 5	54
User Code29	6
User Information	31
User Paper Type127, 129, 130, 13	81

User Settings for SSL	318
Using as the NetWare Print Server/Rem	ote Printer
	48
Using as the Windows Network Printer	43
Using Commands	92
Using Keys	13
Using the Dynamic DNS Function	324
Using the LPR Port	39
Using the SmartDeviceMonitor Port	21
Using the Standard TCP/IP Port	35
Using USB Interface	276, 281

W

web22	23
Web Image Monitor121, 127, 171, 32	23
Web Image Monitor Help17	'5
Windows 200028, 29, 36, 40, 45, 53, 58, 6 75, 8	8, 32
Windows 95/98/Me25, 26, 44, 51, 57, 6, 74, 8	7, 31
Windows NT 4.071, 78, 8	35
Windows Server 2003/2003 R230, 31, 3 41, 46, 54, 59, 69, 77, 8	
Windows XP 30, 31, 37, 41, 46, 54, 59, 69, 7, 83	7,
wins	28
WINS Server	23





GB (GB) G176-8606