

RICOH



PJ WX4130

Setup Guide

English

-
- 1 Preparations for Using the Projector
 - 2 Projecting an Image
 - 3 Appendix

TABLE OF CONTENTS

Manuals Provided with the Projector.....	2
Manuals for the Projector.....	2
Viewing the PDF Manual on the CD-ROM.....	3
How to Read This Manual.....	4
Symbols.....	4
Notes.....	4
1. Preparations for Using the Projector	
Checking the Accessories.....	5
Connecting Equipment to the Projector.....	7
Connecting a Computer.....	7
Connecting AV Equipment.....	7
Connecting the Power Cord.....	9
2. Projecting an Image	
Basic Operations.....	11
Turning On the Projector.....	11
Selecting an Input Signal.....	12
Turning Off the Projector.....	13
3. Appendix	
Trademarks.....	15
INDEX	17

Manuals Provided with the Projector

Manuals for the Projector

Read this manual carefully before you use the projector.

Refer to the manuals that are relevant to what you want to do with the projector.

★ Important

- The manuals are provided in various formats.
- Adobe® Acrobat® Reader®/Adobe Reader must be installed in order to view the manuals as PDF files.

Safety Information

Provides information about safe usage of the projector.

To avoid injury and prevent damage to the projector, be sure to read Safety Information.

Setup Guide

Provides basic information about how to install the projector. Since the contents of this manual are a summary of Operating Instructions, see Operating Instructions for detailed information.

Operating Instructions

Provides information about how to install the projector, how to project images using the projector, and how to configure the projector. It also provides information about troubleshooting and maintenance.

Viewing the PDF Manual on the CD-ROM

This section describes how to view the PDF manual on the supplied manual CD-ROM.

File path

The manual is included in the following folder on the CD-ROM:

Manual\ (language)

1. Insert the CD-ROM in the CD-ROM drive of your computer.
2. Double-click the "Manual" folder.
3. Double-click the folder corresponding to your language.
4. Double-click the PDF file.

The PDF manual is displayed on the screen.



Note

- To view the PDF manuals, you need to have Adobe Acrobat Reader/Adobe Reader installed on your computer.

How to Read This Manual

Symbols

This manual uses the following symbols:

Important

Indicates points to pay attention to when using the projector.

Note

Indicates supplementary explanations of the projector's functions, and instructions on resolving user errors.

[]

Indicates the names of buttons on the control panel and remote control. It also indicates items displayed on the menu screens.

Notes

Contents of this manual are subject to change without prior notice.

Two kinds of size notation are employed in this manual.

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Depending on which country you are in, certain units may be optional. For details, please contact your local dealer.








1. Preparations for Using the Projector

Checking the Accessories

1

The projector is provided with the following accessories. Make sure that everything is included in the package.

If anything is missing or damaged, contact your sales representative or service representative.

Remote control AAA battery LR03 (2 ea)	
RGB cable (3 m)	
Power cord	
Carrying bag	
Safety Information Setup Guide	
CD-ROM	
Warranty card	

Note

- The bundled accessories may vary depending on the location that this product was purchased.

- Use only the RGB cable provided with the projector.
- Use only the power cord set provided with the projector.

Connecting Equipment to the Projector

⚠ CAUTION

- Do not place the power cord and connection cable in a way that might cause someone to trip and fall. The product might fall over and cause an injury.


Various equipments can be connected to the projector.

Turn off the power to any equipment before connecting it to the projector. Be sure to read the manual for the applicable equipment before connecting it to the projector.

Connecting a Computer

Connect an RGB cable to the Computer In port of the projector and to the RGB output of a computer. To input audio signals, connect an audio cable to the Audio In port of the projector and to the audio output of a computer.

If an HDMI interface is available on a computer you want to use, connect an HDMI cable to the HDMI ports of the projector and the computer.



1. To the audio output
2. To the HDMI port
3. To the RGB output

Connecting AV Equipment


Use a cable that supports the signal being input when connecting AV equipment.

To connect a DVD recorder, connect a conversion adapter BNC-pin to the Computer In port of the projector and to the Y/Pb/Pr output of the recorder.

To connect a video recorder or a DVD player, connect a video cable to the Video In port of the projector and to the video output of the recorder or the player.

To input audio signals, connect an audio cable to the Audio In port of the projector and to the audio output of the recorder or the player.

If an HDMI interface is available on a device you want to use, connect an HDMI cable to the HDMI ports of the projector and the device.



1. Video player, DVD player
2. DVD recorder
3. To the audio output
4. To the video output
5. To the HDMI port
6. To the Y/Pb/Pr output
7. To the audio output

Connecting the Power Cord

WARNING

- Do not use any power sources other than those that match the specifications shown. Doing so could result in fire or electric shock.

WARNING

- Do not use any frequencies other than those that match the specifications shown. Doing so could result in fire or electric shock.

WARNING

- The supplied power cord is for use with this machine only. Do not use it with other appliances. Doing so could result in fire or electric shock.

WARNING

- It is dangerous to handle the power cord plug with wet hands. Doing so could result in electric shock.

CAUTION

- Do not place the power cord and connection cable in a way that might cause someone to trip and fall. The product might fall over and cause an injury.


CAUTION

- Push the power plug all the way into the power outlet. Do not use a power outlet with a loose connection. Doing so may result in heat buildup. Plug the power cord in the correct direction into the base. If they are not plugged in correctly, it could result in smoke, fire, or electric shock.

CAUTION

- When disconnecting the power cord from the wall outlet, always pull the plug, not the cord. Pulling the cord can damage the power cord. Use of damaged power cords could result in fire or electric shock.

1. Insert the connector of the power cord set into the AC In socket on the right side of the projector.



CLB029

2. Insert the power plug into a power outlet.

2. Projecting an Image

Basic Operations

WARNING

- Do not look into the projection window or vent when the product is on. The bright light may damage your eyes. Be especially careful in an environment with children.

CAUTION

- Do not place low heat resistant material near the exhaust vents. Hot air may come from the exhaust vents, resulting in damage to the product or an accident.

CAUTION

- Do not block the projection light when it is on. If you do so, the part that is blocking the projection light may get quite hot and deform, deteriorate or cause a burn or fire. The reflected light may make the projection window hot and cause a product failure. To temporarily suspend projection, select the mute function. To suspend longer, turn off the product.


Important

- Unplug the power cord if the projector will not be used for an extended period of time.
- If the lamp is used for an extended period of time, it may not light up or the image may become dark. If this happens, replace the lamp. In some rare cases, the lamp's brightness may vary slightly due to the characteristics of a lamp.

Turning On the Projector

Make sure that the power plug is inserted into a power outlet. For details, see p.9 "Connecting the Power Cord".

1. Press the [Power] button.



The projector beeps and the indicator flashes blue.

The start-up screen is displayed.

When the start menu is displayed


When the projector is turned on for the first time after it is purchased, specify the display language and lamp power level.

1. Select the display language, and then press the [Enter] button.
2. Select the lamp power level, and then press the [Enter] button.

Selecting an Input Signal

Select a signal that is compatible with the equipment that is connected to the projector.



1. Turn on the equipment that is connected to the projector.
To project the image of a video player, press the play button on the video player.
2. Press the [Input] button.



The input signal is detected automatically and the image is projected. The input signal changes each time the [Input] button is pressed.

When projecting the screen of a notebook computer

When connecting a notebook computer to the projector, switch the computer's image output.

In Windows operating systems, the image output can be switched with a function key. While pressing and holding the [Fn] key, press the  key, the  key, or the LCD/VGA function key.


2

Examples of various computers

Computer brand	Key combination
MSI	[Fn] + [F2]
Everex, Mitsubishi, NEC, Panasonic, Sotec	[Fn] + [F3]
Gateway, HP	[Fn] + [F4]
acer, Sharp, Sotec, Toshiba	[Fn] + [F5]
Hitachi, IBM, lenovo, Sony	[Fn] + [F7]
Asus, Dell, Epson, Hitachi	[Fn] + [F8]
Fujitsu	[Fn] + [F10]

Turning Off the Projector

1. Press the [Power] button.



CLB030

The confirm screen appears.

2. Press the [Power] button.

The projector beeps and the projector turns off.

3. Appendix

Trademarks

Adobe, Acrobat, and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

HDMI and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing, LLC.

Windows® is either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.

VGA is a trademark or a registered trademark of IBM Corporation in the United States, other countries or both.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

INDEX

A

Accessories.....5

B

Basic operations.....11

C

Connecting a computer.....7

Connecting AV equipment.....7

Connecting equipment.....7

Connecting the power cord.....9

H

How to read this manual.....4

I

Input button.....12

Input signal.....12

L

Language.....12

M

Manuals.....2, 3

N

Notebook computer.....13

Notes.....4

O

Operating Instructions.....2

P

PDF manual.....3

Power button.....11, 13

Power cord.....9

Projecting an image.....11

Projecting the computer's screen.....13

S

Safety Information.....2

Selecting an input signal.....12

Setup Guide.....2

Start menu.....12

Symbols.....4

T

Trademarks.....15

Turning off the projector.....13

Turning on the projector.....11

MEMO

MEMO

MEMO