

Remote Communication Gate S

User's Guide



2 Login and Logout

3 Displaying Device Information

4 Downloading and Installing Packages

5) Appendix

Read this manual carefully before you use this product and keep it handy for future reference.

How to Read This Manual

Symbols

The following set of symbols is used in this manual.

Comportant 1

Indicates a situation that may result in property damage or malfunction if instructions are not followed. Be sure to read the instructions.

Preparation

Indicates information or preparations required prior to operating.

Limitation

Indicates a function's limitations.

Vote

Indicates supplementary relevant information.

Reference

Indicates where you can find further relevant information.

[]

Indicates the names of keys that appear on the computer screen.

Terminology

The following is an explanation of the terminology used in this manual:

Term	Explanation
Device	A "device" is a printer or multifunction machine connected to the network or a printer connected to a computer via USB. Though the term generally includes routers, hubs, and other network devices, "device" in this manual is limited to printers and multifunction machines.
Domain name	Name of the domain with which computers with Remote Communication Gate S installed are affiliated. Entry is required if the Domain name entry field appears on the login screen. Ask the administrator for detailed information.

Term	Explanation
Download	In general, download is a process of receiving and saving a copy of programs or files in a computer via a network. In Remote Communication Gate S, it refers to the process of a user computer receiving and saving packages stored on the Remote Communication Gate S server.
Filter	On the device list screens, you can use filters to display only the printers or logs that meet specified conditions. Thus, you can sort the devices to be displayed by using the filtering functions. The filters created by the administrator and users and the filters created by a user can be edited by that user.
Group	The administrator creates groups in order to classify devices. Groups are displayed on the [Directory] tab and clicking them displays the device used in the group.
Login	Connection to Remote Communication Gate S on the network, noticing a state in which operations are enabled.
Logout	Disconnection from Remote Communication Gate S.
Menu bar	Grouping of operations that can be executed on displayed screens. Items are selected on the drop-down menu.
Package (Installation Package)	A package is an ".exe" file that contains all of the necessary files and settings to install a device driver. Packages are used to distribute device drivers by the administrator via Remote Communication Gate S. You can download it from the Remote Communication Gate S and all content registered in a package is installed by running the ".exe" file.

Screens

The explanations in this manual use screen images from Windows Vista and Internet Explorer 7.0. If you use another version of Windows, screen images may differ. However, you can perform the same steps.

Guides for This Solution

The following guides are available for Remote Communication Gate S:

Remote Communication Gate S User's Guide (this manual, HTML/PDF)

This guide is intended for the end user. It explains how to display devices, search for devices, and install packages by logging in Remote Communication Gate S.

Remote Communication Gate S Installation Guide (HTML/PDF)

This guide is intended for the administrator and explains the installation, uninstallation, and initial setup procedures for Remote Communication Gate S.

Remote Communication Gate S Administrator Operations Guide (HTML/PDF)

This guide is intended for the administrator. It explains how to utilize Remote Communication Gate S to configure and manage settings and operations: for example, registration and monitoring of devices, the creation of installation packages, or retrieval of device logs.

Note

- Acrobat Reader or Adobe Reader is required to view the PDF documentation.
- You can view the HTML documentation using a Web browser. We recommend Microsoft Internet Explorer 4.01 SP2 or a later version.
- A simplified version of the HTML documentation is available for earlier or non-recommended browsers.
- If JavaScript is disabled or unavailable in your browser, you will not be able to search or use certain buttons in the HTML documentation.
- If you are using an earlier or non-recommended browser and the simplified version of the documentation does not appear automatically, replace \int\index_book.htm with \unv \index_book.htm in your browser's address bar.

Important

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW:
 - THE SUPPLIER SHALL NOT BE LIABLE FOR THE RESULT OF OPERATION OF THIS SOFTWARE OR THE USE OF THIS DOCUMENT.
 - THE SUPPLIER SHALL NOT BE LIABLE TO YOU FOR DAMAGES OR LOSS OF ANY DOCUMENT OR DATA PRODUCED BY USING THIS SOFTWARE.
 - THE SUPPLIER SHALL NOT BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL OR INDIRECT DAMAGES (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION OR LOSS OF BUSINESS INFORMATION, AND THE LIKE) CAUSED BY FAILURE OF THIS SOFTWARE OR LOSS OF DOCUMENTS OR DATA, NOR FOR ANY OTHER DAMAGES ARISING OUT OF THE USE OF THIS SOFTWARE, IF THE SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.
- Some illustrations or explanations in this guide may differ from your product due to improvement or change in the product.
- The contents of this document are subject to change without notice.
- No part of this document may be duplicated, replicated, reproduced in any form, modified or quoted without prior consent of the supplier.
- It is possible that any document or data stored in the computer will be damaged or lost by user error during operation or software error. Be sure to back up all important data beforehand. Important documents and data should always be copied or backed up. Documents and data can be lost because of malfunction or human error. Furthermore, the customer is responsible for protection measures against computer viruses, worms, and other harmful software.
- Do not remove or insert any disk while operating this software.

Trademarks

Adobe[®], Adobe Acrobat[®], Acrobat Reader[®] and Flash[®] are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Microsoft[®], Windows[®], Windows Server[®], Windows Vista[®], and Internet Explorer[®] are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Pentium[®] is a registered trademark of Intel Corporation.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/)

The proper names of the Windows operating systems are as follows:

- The product names of Windows 2000 are as follows: Microsoft[®] Windows[®] 2000 Professional Microsoft[®] Windows[®] 2000 Server Microsoft[®] Windows[®] 2000 Advanced Server
- The product names of Windows XP are as follows: Microsoft[®] Windows[®] XP Home Edition Microsoft[®] Windows[®] XP Professional
- The product names of Windows Vista are as follows: Microsoft[®] Windows Vista[®] Ultimate Microsoft[®] Windows Vista[®] Enterprise Microsoft[®] Windows Vista[®] Business Microsoft[®] Windows Vista[®] Home Premium Microsoft[®] Windows Vista[®] Home Basic
- The product names of Windows 7 are as follows: Microsoft[®] Windows[®] 7 Home Premium Microsoft[®] Windows[®] 7 Professional Microsoft[®] Windows[®] 7 Ultimate
- The product names of Windows Server 2003 are as follows: Microsoft[®] Windows Server[®] 2003 Standard Edition Microsoft[®] Windows Server[®] 2003 Enterprise Edition
- The product names of Windows Server 2003 R2 are as follows: Microsoft[®] Windows Server[®] 2003 R2 Standard Edition

Microsoft[®] Windows Server[®] 2003 R2 Enterprise Edition

- The product names of Windows Server 2008 are as follows: Microsoft[®] Windows Server[®] 2008 Standard Microsoft[®] Windows Server[®] 2008 Enterprise
- The product names of Windows Server 2008 R2 are as follows: Microsoft[®] Windows Server[®] 2008 R2 Standard Microsoft[®] Windows Server[®] 2008 R2 Enterprise

TABLE OF CONTENTS

How to Read This Manual	1
Symbols	1
Terminology	1
Screens	2
Guides for This Solution	3
Important	4
Trademarks	5
1. Pre-operation Confirmation	
What You Can Do with Remote Communication Gate S	9
System Requirements	10
Activating Browser JavaScript	
2. Login and Logout	
Login	13
Logout	15
3. Displaying Device Information	
Layout of the Device List Screen	17
Device List Menu Functions	
Features of Status Icon on the Device List	20
Layout of Site Map	23
Changing the Login Password	24
Displaying the Device List	25
Displaying the Device List by Specifying Search Conditions	25
Displaying the Device List by Using Filters	
Sorting the Display Order of the Device List	
Displaying Maps	35
Displaying the Map from the Device List	35
Displaying the Simplified Map from the Printer Properties	
Displaying Device Information	41
Displaying Device Information from Menu Bar	41
Displaying Device Information from the Properties Icon	41
Content of the Device Information Screen	42
4. Downloading and Installing Packages	
What Are Packages?	

Downloading Packages	50
Downloading Packages from the Package List	50
Downloading Packages from the Map	52
Downloading Packages with a URL Sent by E-mail	52
Opening Packages and Installing Drivers	54
5. Appendix	
About Help	55
If Your Computer is Running Windows XP Service Pack 2 or later/Vista/7	56
Troubleshooting	57
INDEX.	59

1. Pre-operation Confirmation

This chapter explains Remote Communication Gate S and system requirements for user's computers to operate Remote Communication Gate S.

What You Can Do with Remote Communication Gate S

Remote Communication Gate S is a Web-based application that provides device management solutions.

Logging in from a computer to the Remote Communication Gate S server using a Web browser allows you to perform the following:

- Display the device list using search conditions
- Display the device map with device status and its location
- Display the detailed information for devices
- Download and Install drivers using a package created by the administrator

Reference

- For details about displaying the device list and searching for devices, see p.25 "Displaying the Device List".
- For details about displaying the Map, see p.35 "Displaying Maps".
- For details about displaying detailed device information, see p.41 "Displaying Device Information".
- For details about downloading and installing drivers using packages, see p.50 "Downloading Packages" and p.54 "Opening Packages and Installing Drivers".

System Requirements

To operate Remote Communication Gate S, the system must meet the following requirements.

ltem	Requirements
Hardware	CPU: Pentium compatible 500 MHz or higher
	Memory: 128 MB or higher
	 Minimum available hard disk space: same as recommended minimum for operating system
Operating System	 Windows 2000 Professional/Server/Advanced Server (i386): Service Pack 4 or later
	• Windows XP Home Edition/Professional: Service Pack 2 or later
	 Windows Vista Ultimate/Enterprise/Business/Home Premium/ Home Basic
	 Windows 7 Home Premium/Professional/Ultimate
	 Windows Server 2003 Standard Edition/Enterprise Edition: Service Pack 2 or later
	 Windows Server 2003 R2 Standard Edition/Enterprise Edition: Service Pack 2 or later
	 Windows Server 2008 Standard/Enterprise
	 Windows Server 2008 R2 Standard/Enterprise
Supported Language	English, German, French, Italian, Spanish, Dutch
	♦ Note
	 Remote Communication Gate S supports only these six languages. If the display language is not one of these languages, Remote Communication Gate S is displayed in English. The priority of the display language can be changed in the Language preference settings in Internet Explorer.

1

ltem	Requirements
Web Browser	Internet Explorer 6.0 Service Pack 1 or later
	Internet Explorer 7.0
	Internet Explorer 8.0
	☆Important
	 JavaScript must be activated.
	 Adobe Flash Player 9.0 or later must be installed.
	Reference
	 For details about the method for activating JavaScript, see p.11 "Activating Browser JavaScript".
Network	TCP/IP must be installed and properly configured.
Screen Resolution	1024 x 768 or higher

Activating Browser JavaScript

To access and view Remote Communication Gate S, it is necessary to activate JavaScript on the Web browser.

- 1. Select [Internet Options...] on the Internet Explorer [Tools] menu.
- 2. Click the [Security] tab.
- 3. Click [Custom Level...].
- 4. Under [Scripting] select [Enable] in [Active scripting].
- 5. Click [OK] to close the [Security Settings] dialog box.
- 6. Click [OK] to close the [Internet Options] dialog box.

1. Pre-operation Confirmation

2. Login and Logout

This chapter explains the procedures for logging in and out of the Remote Communication Gate S server.

Login

To log in to the Remote Communication Gate S server, the following information is required and must be obtained from the administrator in advance:

- URL of the Remote Communication Gate S server
- User name
- Password
- Domain name (If required)

🔁 Important

- If you are using Windows Server 2003 or 2008, settings must be made in advance. Contact the administrator.
- When using Remote Communication Gate S, do not use your browser's [Back] button or other browser functions. Use only the navigation controls on the content pages.
- If you want to switch users, click the [Logout] button, and then log in again as a different user.
 Do not use your browser's [Back] button to redisplay the login screen.
- 1. Start Internet Explorer.
- 2. Enter the following URL in the address bar, and then press the [Enter] key on the keyboard.

Condition	URL
Without SSL encryption	http://{host name}:{port number}/mgmt
	or
	http://{IP address}:{port number}/mgmt
With SSL encryption	http s ://{host name}:{port number}/mgmt
	or
	https://{IP address}:{port number}/mgmt

- {host name}: name of the Remote Communication Gate S server
- {IP address}: IP address of the Remote Communication Gate S server
- {port number}: port number specified when Remote Communication Gate S was installed

2

3. If the [Trial Version] screen appears, click [OK].

Remote Communication Gate S	
i Trial Version	?
Trial nerind: 40 de/s) remaining	
OK Cancel	

• Note

- The [Trial Version] screen will only appear if Remote Communication Gate S has not been activated. For details, contact the administrator.
- 4. Enter your user name in the [User name:] box on the login screen.

	Version/SOI 02.00-04 Copyright(C) 2005-2008 Risch Co, Ltd. All rights reserved
	~
Remote Communication Gate S for @Remote Enterprise Pro	
🔗 Residme 🛛 💐 Help	
User name: Password:	@Remote
This SOFTWARE PRCOUCT is understart properties have not international coupled features, as well as other interfaced property laws and treatment. Are unacharated coupled of all or pert of this program or unauthorized coupleg and distribution of this program is an intergenent of the coupled laws and treatment.	

5. Enter your password in the [Password:] box.

Reference

- For details about changing your password, see p.24 "Changing the Login Password".
- 6. Enter domain name if the [Domain name:] box is displayed.
- 7. Click [Login].

```
Note
```

• The login screen reappears if no operation is performed for more than 30 minutes after logging in to the Remote Communication Gate S server. Log in again if necessary.

2

Logout

Use the following procedure for logging out from Remote Communication Gate S.

1. Click [Logout] on the screen.

Directory 🕒									👤 User1
View by Filter		Main Group 🔍							
No Deserves Devices		All Printers							
No Response Devices	Ed	it Printer Filter	View Sort	by					6
Filter Settings	-				-				(P
		U 1-10/10item(s)	৬৬ জ	electer	d: 0			1	/ 1 page(s)
View by Group		levice Display Name		-	 IP Address 	System	Printer	Registered Group	
Main Group		imagio MP C5000(1)	130.196.155)		133.338.196.155	U	20	Ungrouped	
		Imagio MP C4500(1)	1 139.196.181)		139-199-196-181		2	Ungrouped	
		Aficio MP 171(100 13	0.196.220)		130.196.220			Ungrouped	
		Aficio MP 2000(1311)	18.196.226)		110.100.196.226			Ungrouped	
		magio MP C6000(1)	1 196.236)		139 199.196.236			Ungrouped	
		Ando SP 8200DN(11	196.237)		196.237			Ungrouped	
		Alicie MD C2050/101	1 196 249)		100.000 106 240			Ungrouped	
		105i0 SP C721(alla	195,249)		130, 196, 196, 249		52	Ungrouped	
		imanin Neo C385(13	110,196,250)		133 338 196 250			Ungrouped	

Note

• Do not use the [Close] button to shut down the system.

2. Login and Logout

3. Displaying Device Information

This chapter explains the device list screen which is displayed on the top page when you log in Remote Communication Gate S.

Layout of the Device List Screen

The screen layout of the device list is as follows:



1. Search button

Searches for a specific device using search conditions. When searching for a device, click this button, and then enter the conditions for your search.

Reference

- For details about searching for devices using Search button, see p.25 "Displaying the Device List by Specifying Search Conditions".
- 2. Group display

Displays the group name of the displayed device list.

3. [Directory] tab

Displays registered filters and groups.

4. Filter

Refines the device list using search conditions. When a filter is selected, the corresponding devices are displayed in the device list display area.

Filters can be added by the administrator, and you can also create your own filters. Filters that you create are available only to you.

Reference

- For details about searching for devices using filters, see p.28 "Displaying the Device List by Using Filters".
- 5. Group list

Displays the group list if the device is managed as a group.

6. Menu bar

Displays the menu that is available on the device list screen.

7. [Quick Links] area

Displays screen links that are used frequently or related to the present screen. For details about the selected links, contact the administrator.

8. Site Map button

Displays all operation links that are available in Remote Communication Gate S.

Reference

- For details about Site Map, see p.23 "Layout of Site Map".
- 9. Help button

Displays the Help screen.

🖪 Reference 🔵

- For details about Help, see p.55 "About Help".
- 10. [Logout] button

Logs out from the Remote Communication Gate S server.

🖪 Reference 🔵

- For details about logout, see p.15 "Logout".
- 11. Login user name

Displays the login user name.

12. Refresh button

Refreshes the device list screen and displays the latest device information.

13. Device list display area

Displays the list of devices.

Device List Menu Functions

Various functions available in the [Directory] tab are also accessible from the menu bar. The device list menu provides the following functions:

[Edit] menu

ltem	Allows you to
Select All	Select all found devices in the list.
Clear All	Deselect all devices selected in the list.

[Printer] menu

ltem	Allows you to
Refresh Selected Device	Connect to the selected devices and collect details about their current device status. The device list screen is not updated when you select this item.
	To display the device list screen with the most recent device status information, select [Refresh Selected Device] on the menu, and then click the Refresh button in the right-upper area on the screen.
Printer Properties	Display details of a selected device.
	E Reference
	 For details about the [Printer Properties] menu, see p.41 "Displaying Device Information".

[Filter] menu

ltem	Allows you to	
Printers with Errors	Display a list of devices with errors on the [Printers with Errors] screen	
	Reference	
	 For details about searching devices with errors, see p.28 "Displaying a list of devices with errors". 	
No Response Devices	Display a list of devices that have not responded to polling for a specified number of days.	
No Filters	Display a list of all found devices.	
Filter Settings	Register and edit filters that you created.	

[View] menu

ltem	Allows you to
Display Directory	Display the [Directory] tab.

ltem	Allows you to	
Hide Directory	Hide the [Directory] tab.	
List	Display a list of devices.	
Мар	 Display a floor map of grouped devices with device icons. Reference For details about the Map function, see p.35 "Displaying Maps". 	
Search Devices	Display the [Search] screen. Reference For details about searching for devices, see p.25 "Displaying the Device List by Specifying Search Conditions".	

[Sort by] menu

ltem	Allows you to	
Selected Printers	Sort the list of found devices alphabetically according to selected printers.	
Device Display Name	Sort the list of found devices alphabetically according to model names.	
IP Address	Sort the list of found devices according to their IP addresses.	
System	Sort the list of found devices according to common system icons.	
Printer	Sort the list of found devices according to printer status icons.	
MAC Address	Sort the list of found devices according to their MAC addresses.	
Registered Group	Sort the list of found devices according to the groups that the devices are registered to.	

Features of Status Icon on the Device List

Status icons appear on the device list screen and inform the visual notice with icons.

Directory O				👤 User1
View by Filter O Printers with Errors O No Response Devices No Filters Filter Settings	Main Group All Printers Edt Printer Filter View So	rt by		٢
View by Grown	N N I-10/10/tem(s) N N	Selected: 0	Surtem Printer Registered Course	/ 1 page(s)
B Chain Group	mage the C282(12):181-184-132 mage the C282(12):191-194-194 mage the C282(12):191-194-194 mage the C282(12):191-194-194 mage the C282(12):191-194-194 mage the C282(12):191-194-194-194 mage the C282(12):191-194-194 mage the C282(12):191-194-194	Image: 100 and	M More and a provide provide a provide a provide a provide a provide a provi	
Quick Links				
	Nanammont		Site Man	

1. System status icon

Reference

- There are several types of system status icon. For the details about each icon, see p.21 "System status icons".
- 2. Printer status icon

Reference

• There are several types of printer status icon. For details about the each icon, see p.22 "Printer status icons".

The following table explains the various icons displayed in the device list:

System status icons

Status icon	Explanation
?	There was no response from the printer.
2	A service call is required.
U	The printer has run out of paper, toner, or other supplies.
*	An access violation has occurred. An excessive number of attempts have been made to access this device.

Printer status icons

Status icon	Explanation
?	There was no response from the printer.
	The printer has run out of toner/ink.
8 1-	A paper jam has occurred.
Ē	The printer has run out of paper.
	A cover is open.
<u>ē</u>	The printer has run out of staples.
	The punch waste receptacle is full.
a	The waste toner receptacle is full.
<u>*</u>	A paper jam has occurred inside the Auto Document Feeder (ADF).
5	A communication error has occurred.
	The paper output tray is full.
	An output tray is full.
?	An unavailable function was attempted.
	An unknown error has occurred.
<mark>+</mark> ₩	The printer is currently offline.
U	The printer is warming up.
i	The printer's toner/ink is about to run out.
Ë	The printer's paper is about to run out.
Ð	Warning concerning a failed operation or unsupported function.

Status icon	Explanation	
	The printer is in Power Save Mode.	
8	The printer is busy processing and not ready to perform a new operation.	
B	The printer is busy printing a job.	
	The printer is ready to perform a new print job.	

Layout of Site Map

The screen layout of the Site Map is as follows:

	Remote Communication Gate S	
	Site Map Select screen links to be displayed on the Quick Links.	
1 —		
•	Manage ment	
~	All Printers	
2 —	Printers with Errors	
	User Account Settings	- 4
	Device Management Settings	
	Filter Settings	
		— F
3 —	Baok	_ 0
		VNADOFO

1. All Printers

Displays a list of devices connected to Remote Communication Gate S.

Reference

- For details about device list, see p.17 "Layout of the Device List Screen".
- 2. Printers with Errors

Displays a list of devices with system errors.

Reference

- For details about Printer with Errors, see p.28 "Displaying a list of devices with errors".
- 3. [Back] button

Returns to the previous page.

4. User Account Settings

Displays [User Information] screen, and you can change the password for login.

Reference

• For details about User Account Settings, see p.24 "Changing the Login Password".

5. Filter Settings

Displays the [Filter Settings] screen, and you can edit or delete registered filters.

Reference

• For details about Filter Settings, see p.31 "Editing filters", and p.33 "Deleting filters".

Changing the Login Password

The following procedure allows you to change your login password. Change your password for security reason.

- 1. On the device list screen, click the Site Map button in the upper-right area.
- 2. Click [User Account Settings].



- 3. Enter the new password.
- 4. Click [OK].

Displaying the Device List

Displaying the device list allows you to check the status and details of the devices connected to the Remote Communication Gate S server.

Network-connected devices are displayed in lists, which are sorted according by one of the two methods below:

- Specified search conditions
- Use of filters

Displaying the Device List by Specifying Search Conditions

Use the following procedure to display a list of devices according to advanced search conditions.

1. On the device list screen, click the Search button.

Remote Communication Gate S				
Directory O				👤 User1
 View by Filter Printers with Errors No Response Devices No Filters Filter Settings>> 	Main Group S All Printers Edit Printer Filter View Sort Edit 9:10/10/term(s) P	by		1 / 1 page(5)
 View by Group 	P Device Display Name	• IP Address	System Printer	Registered Group
E Wain Group	imagio MP C5000(133-135-195-155)	III 100.100.196.155	1	Ungrouped
	imagio MP C4500(111 119.196.181)	1100.100.196.181		Ungrouped
	Aficio MP 171(111-118-196.220)	10.100.196.220		Ungrouped
	Aficio MP 2000(110.100.196.226)	110.138.196.226		Ungrouped
	imagio MP C6000(111)-1196.236)	110.109.196.236		Ungrouped
	Aficio SP 8200DN(100.196.237)	iiii.iiii.196.237		Ungrouped
	Aficio SP C420DN(131.138.196.239)	110.139.196.239		Ungrouped
	Aficio MP C2050(1319-1196.248)	IN. 199.199.196.248	l	Ungrouped
	IPSIO SP C721(111.1196.249)	100.104.196.249		Ungrouped
	Imagio Neo C385(110.138.196.250)	III.134.196.250	U	Ungrouped
Quick Links				
	Management		Site Map	
	All Printers		Site Map	

2. Select items as search conditions from the [Search item:] list.



Search condition	Explanation
Device Display Name	Displays devices according to their names on the MFP screen.
Printer model	Displays devices according to their printer models.
IP address	Displays devices according to their IP addresses.
System error	Displays devices according to common system errors such as no response and failure due to excessive access attempts.
Printer status	Displays devices according to their print status.
MAC address	Displays devices according to the physical (MAC) address that all network-capable devices feature.
Device name	Displays devices according to their device names.
Host name	Displays devices according to their host names.
Comment	Displays devices according to a comment filter.
PPM	Displays devices according to their print capacity (measured in pages per minute).
B&W/Color	Displays devices according to their Black and White/ Color printing capability.
Scanner status	Displays devices according to their scanner status.
Fax status	Displays devices according to their fax status.
Copier status	Displays devices according to their copier status.

Search condition	Explanation
NIB model	Displays fail-over devices according to their NIB models.
NIB version	Displays fail-over systems according to their NIB versions.
NetWare print server	Displays devices according to their NetWare print server.
Serial Number	Displays devices according to their serial numbers.
Asset number	Displays devices in numerical order according to their number of asset utilities.
User Properties 1	Displays devices according to their user properties
User Properties 2	(specified by the administrator).
User Properties 3	
User Properties 4	
User Properties 5	

3. Select an option configuration item from the [Option:] list.

Remote Communication	Gate S			E ? Dopout
Directory C				👤 User1
Main Group Search(All Printers Search item: Option:	s) Parameter:			
P address range range Search Results:	• from	to	Search Clear Conditions	
Edit • Printer • Filter •	View • Sort by •			ø

Condition	Option
When specifying a character string for the parameter:	• include
	Exact match
When specifying a numeric value for the parameter:	• same
	• above
	• below
When specifying a numeric value (a range can be specified) for	• range
the parameter:	• same
	• above
	• below
When selecting the parameter from choices:	• same

4. Enter the set value in the [Parameter:] box. For example, if [IP address] is specified in [Search item:], enter the IP address.

- If you click [Clear Conditions], the search conditions return to their defaults.
- 5. Click [Search...].

emote Communication Gate	S					? +1 Logout
lirectory C						L User1
🕥 Main Group						
Search(All Printers)						
Search item: Option: Parame	ater:					
Radrass - sma -		Search	Slear Conditio	20		
Search Results:						
Edit • Printer • Filter • View •	So	rt by 🕶 📄				(4
(4 4 1-5/Sitem(s) (+) (+) Sele	ected:	0				1 /1page(s)
A Device Display Name		IP Address	System	Printer	Registered Group	
Aficio SP 8200DN(1331.139.196.237)		100.109.196.237	?	?	group2	
imagio MP C4500(133.338.196.181)		133.139.196.181		<u>181</u>	group1	
imagio MP C6000(1319-1199-196-236)		100.109.196.236			group2	
IPSiO CX9000(#10.139.196.250)		sld. sl#.196.250		C	group1	
IPSIO GX 3000(133.131.196.252)		110.139.196.252			Ungrouped	

The [Search Results] screen appears as a list.

Displaying the Device List by Using Filters

Use the following procedure to display the device list as corresponding to the filter conditions that are specified by the administrator and users.

The filters that created by the administrator are displayed in the upper area of [Filter] menu. You cannot edit filters that were created by the administrator.

Filters that you create for personal use from search conditions appear under the filters created by the administrator. You can edit and delete the filters that you create.

Displaying a list of devices with errors

Use the following procedure to display a list of devices with errors.

1. On the device list screen, click [View by Filter] on the [Directory] tab.

Remote Comn	nuni	cation Gate S					۲	? Depout
Directory O								👤 User1
View by Filter Printers with Errors No Response Devices No Filters Either Settions		Main Group (S) All Printers Edit Printer Filter View Sor	t by	D				ø
		(4) 1-10/10item(s) (b) (b) S	electe	d: 0		New 19	1	/ 1 page(s)
View by Group		Device Display Name	-	• IP Address	System	Printer	Registered Group	
el CMain Group		imagio MP C5000(111-118-196-155)		100.109.196.155		101 102	Ungrouped	
		(196.181)		199 199.196.161			Ungrouped	
		Ancio MP 171(1111111111111111111111111111111111		110 100 106 226			Ungrouped	
		magio MP (5000(1111-1111-196-226)		100.100.106.776		E C	Ungrouped	
		Africo SP 8200DN(110 110-120-237)		100.100.196.237			Ungrouped	
		Aficio SP C420DN(LEB.196.239)		138,139,196,239			Ungrouped	
		Aficio MP C2050(1319-119-196-248)		100 109.196.248		ē	Ungrouped	
		PSIO SP C721(100 + 196.249)	m	100.109.196.249		E.	Ungrouped	
		imagio Neo C385(110.138.196.250)		110.139.196.250			Ungrouped	
Quick Links								
		Management All Printers			Site M	Map IP		

2. Click [Printers with Errors].

Remote Comm	unication Gate S			? * Locout
Directory O				👤 User1
View by Filter Printers with Errors No Response Devices No Filters Filter Settings>>	Main Group S All Printers Edit Printer Filter View Sort # 4 1-10/101kem(s) > (k) s	by elected; 0		1 / 1 page(s)
 View by Group 	Device Display Name	 IP Address 	System Printer	Registered Group
B ∉ Mein Group	Image MP C2000 [19 [18 19.18] Image MP C2000 [18 119.18] Imag	100 100 <td></td> <td>Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped</td>		Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped

- ↓ Note
 - The filter can also be selected from [Filter] on the menu.

Displaying a list of devices not responding

Use the following procedure to display a list of devices that have not responded to polling for a specified number of days.

1. On the device list screen, click [View by Filter] on the [Directory] tab.

3

2. Click [No Response Devices].

The result appears as a list that you can sort by item.

Displaying a list of devices using other filters

Use the following procedure to display a list of devices according to search conditions that specified by the administrator and users.

- 1. On the device list screen, click [View by Filter] on the [Directory] tab.
- 2. Click the filter you want to use.

The search result appears as a list.

Vote

• The filter can also be selected from [Filter] on the menu.

Registering search conditions as a filter

Use the following procedure to register search conditions as a filter for your personal use.

- 1. On the device list screen, click the search button.
- 2. Select items as search conditions from the [Search item:] list.
- 3. Select an option configuration item from the [Option:] list.
- 4. Enter a value in the [Parameter:] box. For example, you selected [IP address] in [Search item:], enter the IP address you want to search for.
- 5. Click [Search...], and then click [Save as Filter].



6. On the [Filter Settings: Save as Filter] screen, enter [Filter name:] and [Comment:].



- 7. In [Display location:], select where to have the filter displayed.
- 8. Click [OK].
- 9. On the [Saved as Filter] screen, click [OK].

Remote Communication Gate S	?
(i) Saved as Filter	
The following filter has been added.	
Filter name: FilterforUser1	
ок	
Limitation	

• You can register up to 20 filters.

Vote

• The registered filters are displayed on the [Filter] menu, under the filters created by the administrator.

Filter Settings menu functions

The menu on the [Filter Settings] screen provides the following functions:

[Edit] menu

ltem	Allows you to
Edit	Edit the filter conditions.
Delete	Delete the registered filters.

Editing filters

Use the following procedure to edit a filter that you created.

- 1. On the device list screen, click the Site Map button in the upper-right area.
- 2. Click [Filter Settings].
- 3. Select the filter you want to edit.
- 4. Click [Edit] on the [Filter] menu.



5. Change the [Filter name:] and [Comment:] as necessary.

Remote Communication Gate	5		?
Nemote communication date			👤 User1
Filter Settings: Edit Filter Edit added filter settings.			
Filter name: FilterforUser1			
Comment: Temporary filter			
Display location: Menu Menu Menu and Directory Tab			
Search item: Option: Parameter: B8W/Color same Color			
OK Cancel			

- 6. In [Display location:], select where to have the filter displayed.
- 7. Click [OK].
- 8. On the [Filter Settings] screen, click [Back].
- 9. On the Site Map, click [Back].

The device list screen appears.

🕓 Note

• You can also access the filter editing function by clicking [Filter Settings] on the Site Map.

3

Deleting filters

Use the following procedure to delete filters that you created.

- 1. On the device list screen, click the Site Map button in the upper-right area.
- 2. Click [Filter Settings].
- 3. Click [Delete] on the [Filter] menu.



4. When a message confirming the deletion appears, click [OK].

Remote Communication Gate S	?
	LUser1
Filter Settings Exit filter settings and diaplay order. The maximum number of filters that users can add is 20. • Added filter latt: Private filter • District/CVart Temporary filter Meru • District/CVart Temporary filter Meru • Down • OK	<u>∎</u> Uær1

Sorting the Display Order of the Device List

Use the following procedure to sort the display order of the device list.

1. Click [Sort by] on the menu on the device list screen.

lineatures 🕥									Libort
Sheetory U									1 Oser
View by Filter	🚚 Main Group 🔍								
Printers with Errors	All Printorn								
No Response Devices		0.11							_
No Filters	Edit Printer Filter View	Sort b	yy						0
Filter Settings>>	(i) (i) 1-10/10item(s) (i) (ii)	Sele	octed	Printers				1	/ 1 page(s)
View by Group	Device Display Name	Devi	ice C	isplay Name		System	Printer	Registered Group	
Athin Group	impair MD (5000/s10 s10 196	✓ P A	ddre	18			52	Hearouned	
e totali i ci coop	195 imagin MR C4500(133 138 195	Syst	tem		81		5.7	Ungrouped	
	Africo MP 171(100 100, 196, 220	Prin	ter		20			Ungrouped	
	Aficio MP 2000(131, 135, 196, 22	Regi	ister	ed Group	26		ă	Ungrouped	
	100 imagin MP C6000(121125.196	236)		133,338,196,	236			Ungrouped	
	Aficio SP 8200DN(1101101.196.	237)		110.100.196.	237			Ungrouped	
	Aficio SP C420DN(100 100, 196.	239)		133.438.196.	239			Ungrouped	
	Aficio MP C2050(133,138,196.2	48)		133.338.196.	248			Ungrouped	
	PSIO SP C721(100 100.196.24	9)		139-199-196.	249		19	Ungrouped	
	196, 196, 196, 196, 196, 196, 196, 196,	250)	m	131.110.196.	250		E	Ungrouped	

2. Click the item to be designated as the sort key.

Devices will be sorted on the basis of the selected item.

Note

• To sort the list in ascending order, click the row name of the item in the displayed list. Clicking again sorts the list in descending order.

Displaying Maps

The Map function displays a floor map of grouped devices using device icons that provide visual details about a device and its location. Each group has one map registered by the administrator. If no map is registered for a group, the Map for that group appears blank.

The Map function allows you to perform the following:

- Display devices' visual location and their status
- Display the device information
- Download packages

There are two ways to display the Map as below.

- Display the Map from the device list
- Display the simplified Map from the printer properties

Displaying the Map from the Device List

Use the following procedure to display grouped devices in the Map.

1. On the device list screen, click [View by Group] on the [Directory] tab.

Remote Comr	nunic	ation Gate S					? +1 Logour
Directory O							👤 Usert
View by Filter Printers with Errors No Response Devices No Filters Filter Settings>>		Main Group All Printers dit Printer Filter View Sou (1-10/10/item(s) (H) ::	t by Selecte	nd: 0			i / 1 page(s)
 View by Group 		Device Display Name		• IP Address	System	Printer	Registered Group
C 🖉 Main Group		Imagio MC C3000(148.14):154.153 Imagio MC C3001(18.14):154.151 India MC C301(18.11):154.151 India MC C301(18.11):154.151 India MC C3000(18.11):154.151 Imagio MC C3000(18.11):154.251 India MC C300(18.11):155.251 India MC C300(18.11):155.251 Imagio MC C300(18.11):155.251		131.31.96.258 131.31.96.201 131.31.96.202 131.31.96.226 131.31.96.226 131.31.96.226 131.31.96.226 131.31.96.226 131.31.96.249 131.31.96.249 131.31.96.249 131.31.96.249			Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped

2. Click a group in the group tree.

A list of grouped devices appears.

3. Click the [Map] on the [View] menu.



4. Click a device icon on the Map to display the properties screen.

Remote Communic	ation Gate S	? *1 Lopout
Directory O		👤 Userl
View by Group C (Main Group E mon1 C (E Ungrouped	Air Gravy) and () Printers: Map 	
	Map Operator:	
	HING IN COLOR	

Layout of the Map

The screen layout of the Map is as follows:



1. View List button

Displays in list form the devices that appear on the Map.

2. [Directory] tab

Displays registered filters and groups.

3. Menu bar: [View]

Displays the menu that is available on the Map.

4. Map display area

Displays the Map with device icons.

5. Refresh button

Refreshes the Map screen and displays the latest device status.

6. [Map Opacity:] slider

Adjusts the transparency of the background of the Map.

7. [Map size:] buttons

Increases or decreases the size of the Map.

8. Device icon (Red)

Indicates printers with common system errors.

9. Device icon (Gray)

Indicates local (non-networked) printers.

10. Device icon (Blue)

Indicates networked printers that are registered to the Remote Communication Gate S. If you move your mouse pointer over a device's icon, the model ID and IP address/host name of that device will appear.

Map menu functions

The menu on the [Printers: Map] screen provides you the following function:

[View] menu

ltem	Allows you to
Display Directory	Display the [Directory] tab.
Hide Directory	Hide the [Directory] tab.
List	Display a list of devices that appear on the Map.
Мар	Display a floor map of grouped devices with device icons.

Resizing the Map display

Use the following procedure to resize the Map.

1. On the Map, click the [Map size:] buttons.



• Magnification range: ±200%

Adjusting the transparency of the background

Use the following procedure to adjust the transparency of the background of the Map.

1. On the Map, slide the [Map Opacity:] slider.

Displaying the Simplified Map from the Printer Properties

Use the following procedure to display the Map from the [Printer Properties: User Properties] screen.

The displayed Map is a simplified figure and shown items are different from that of displayed from the device list. The icon of the device that you selected will be blinking.

- 1. On the device list screen, select a check box of the device list.
- 2. Click [Printer Properties...] on the [Printer] menu.
- 3. Click the [User Properties] tab.

4. Click the [View Map] button on the [Printer Properties: User Properties] screen.



Layout of the simplified Map

The screen layout of the simplified Map is as follows:



1. [Web Image Monitor] button

Displays the device status using Web Image Monitor.

2. Device name/Group name

Displays the device name and group that the device belongs to.

3. Map display area

Displays the simplified Map with device icons.

4. Help button

Displays the Help screen about the Map.

5. Refresh button

Refreshes the Map screen and displays the latest device status.

6. [Map Opacity:] slider

Adjusts the transparency of the background of the Map.

7. [Map size]:buttons

Increases or decreases the size of the Map.

8. Device icon (Blinking)

Indicates the selected device.

9. Device icon (Red)

Indicates printers in common system errors.

10. Device icon (Gray)

Indicates local (non-networked) printers.

11. Device icon (Blue)

Indicates networked printers that are registered to the Remote Communication Gate S server. If you move your mouse pointer over a device's icon, the model ID and IP address/host name of that device will appear.

Displaying Device Information

Displaying Device Information from Menu Bar

Use the following procedure to display the properties screen, which features device information.

1. On the device list screen, select a check box of the device list.

Remote Comm	nunication Gate S			LUser1
View by Filter Printers with Errors No Response Devices No Filters Filter Settings>>	Main Group Image: Constraint of the second sec	W lected: 1		2 / 1 page(s)
 View by Group 	Device Display Name	 IP Address 	System Printer	Registered Group
B 🛃 Main Group	magio MP CO00(131.84.196.155) magio MP CO00(131.84.196.155) magio MP CO00(131.84.196.151) Ance MP 200(131.84.196.126) Ance MP 200(131.84.196.226) Ance MP 200(131.84.196.236) Ance MP 200(131.84.196.236) Ance MP 200(131.84.196.236) Mole SP 2000(131.84.196.236) Mole SP 2000(131.84.196.236) Mole MP 2000(131.84.196.236)	 Alkala 195 153 Alkala 195 154 Alkala 195 154 Alkala 195 266 		group1 Ungrouped group3 Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped Ungrouped

2. Click [Printer Properties...] on the [Printer] menu.

Remote Comm	unication Gate S					• ?	Dopout
Directory O							👤 User1
View by Filter Printers with Errors No Response Devices No Filters Filter Settings>>	Main Group All Printers Edit Printer Filter View S Refresh Selected Device Printer Properties	Sort by Selecter	D d: 1			1 /1	gage(s)
 View by Group 	Device Display name		• IP Address	System	Printer	Registered Group	
🗄 🦿 Main Group	imagio MP C5000(1331.139.196.15	5) 🔳	131.418.196.155	<u> </u>	لمّ	group1	
	imagio MP C4500(123 138.196.18	1)	133.338.196.181		لمًا	Ungrouped	
	Aficio MP 171(100 L00.220)		139 199.196.220			group1	
	Aficio MP 2000(131-118.196.226)		13h 196.226		U	Ungrouped	
	imagio MP C6000(100.139.196.23)	6)	111.110.196.236			Ungrouped	
	Aticio SP 8200DN(118,196.237	0 🗉	110 100.196.237		U	Ungrouped	
	Aficio SP C420DN(133.139.196.235	9) 🔲	133-138.196.239			Ungrouped	
	Andio MP C2050(133.139.196.248)		1.10.119.196.248		e	ungrouped	
	10510 SP C/21(116,116,196,249)		139.399.196.249			ungrouped	
	Unite c385(111111111111111111111111111111111111	0) 🗉	146.250		LG1	Ungrouped	

Displaying Device Information from the Properties Icon

Use the following procedure as an alternate way to display device information.

3

1. On the device list screen, click the properties icon.



Content of the Device Information Screen

The properties screen displays detailed information about a selected device features the following tabs:

- Printer Status
- Counter
- User Properties
- Download



The following items appear at the top of the properties screen.

ltem	Explanation
Device Display Name	Displays the name of a device as displayed in Remote Communication Gate S. Device details are displayed by clicking the [Web Image Monitor] link.
Printer model:	Displays the model name of the device.
Device Address	Displays the IP address or host name of the device.

ltem	Explanation
Latest Device Information Update Time:	Displays the time and date when detailed device information was most recently updated.

Printer Status tab

This screen displays the status of the selected device.

1. Click the [Printer Status] tab.



Note

• Displays may differ depending on device models.

ltem	Explanation
System Printer	Displays the selected device's status with status icons.
Copier Scanner	• For details about status icons, see p.20 "Features of Status Icon on the Device List".
<paper tray=""></paper>	Displays the status of the input tray.
<toner ink=""></toner>	Displays the remaining toner.

ltem	Explanation
<output tray=""></output>	Displays the output tray attached to the device.
<document server=""></document>	Displays the capacity and free space of the document server.

Counter tab

This screen displays device counter data collected from devices connected to Remote Communication Gate S. The device counter data can help you know how the device is being used.

1. Click the [Counter] tab.



• Displays may differ depending on device models. The counter data will be retrieved from devices that maintain usage counters.

ltem	Explanation
<print total=""></print>	Displays copy, printer and fax counter totals. • Total counter

ltem	Explanation
<copier></copier>	Displays copy function counter. • Copier B&W Counter • Copier Full Color Counter • Copier Single Color Counter • Copier Two-color Counter
<printer></printer>	Displays printer function counter. Printer B&W Counter Printer Full Color Counter Printer Single Color Counter Printer Two-color Counter Total Level Color Counter
<fax></fax>	Displays fax function counter. • Fax B&W Counter • Fax Single Color Counter
<a3 dlt=""></a3>	Displays large size print function counter. • A3/DLT
<a2></a2>	Displays A2 size print function counter. • A2
<duplex></duplex>	Displays two-sided print function counter. • 2 Sided
<coverage></coverage>	 Display toner coverage function counter. Coverage: Color (%) Coverage: B&W (%) Coverage: Color Print Page Coverage: B&W Print Page
<send total="" tx=""></send>	Displays send/TX total counter and fax transmission counter totals. • Send/TX Total B&W Counter • Send/TX Total Color Counter

ltem	Explanation
<fax transmission=""></fax>	Displays fax transmission function total.
	Fax Transmission Counter
<scanner send=""></scanner>	Displays scanner send function counter.
	Scanner Send B&W Counter
	Scanner Send Color Counter
<internal counter=""></internal>	Displays the internal counter totals.
	Color Copies
	B&W Copies
	Color Prints
	B&W Prints
	Economy Color Counter
	• B&W Total
	• Color Total

User Properties tab

This displays groups with which devices are associated.

1. Click the [User Properties] tab.



ltem	Explanation
<registered group=""></registered>	Displays the groups with which devices are associated.
<user properties=""></user>	Displays comments regarding on user properties.
View Map button 💷	If a map has been created for the group, this button displays the map in simplified view.

Reference

• For details about the using View Map button, see p.38 "Displaying the Simplified Map from the Printer Properties".

Download tab

This displays a list of packages created by the administrator for the devices.

1. Click the [Download] tab.



Reference

• For details about the packages, see p.50 "Downloading Packages".

3. Displaying Device Information

4. Downloading and Installing Packages

This chapter explains downloading and installing packages distributed by the administrator.

What Are Packages?

Remote Communication Gate S discovers devices on networks and distributes to all users a configuration setting program wizard called "Packages". The packages wizard starts automatically and users can install the necessary drivers for devices from Remote Communication Gate S server without any additional setup.

The following explains how to acquire a package and then install drivers using the package.

Downloading Packages

The packages are stored in the Remote Communication Gate S server.

The packages are retrieved using any of the following three procedures:

- Log in to the Remote Communication Gate S server and download from the package list.
- Log in to the Remote Communication Gate S server and download from the Map.
- Access the URL sent by the administrator in an e-mail message and download from the package list.

Downloading Packages from the Package List

Use the following procedure to download packages from the package list.

- 1. On the device list screen, select a check box of devices.
- 2. Click [Printer Properties...] on the [Printer] menu.



Reference

• For details about displaying the device information screen, see p.41 "Displaying Device Information".

3. Click the [Download] tab on the properties screen.



- 4. For detailed information about the package, click the properties icon.
- 5. Click [Download] next to the package you want to download.
- 6. Click [Save].



7. Specify where you want to save the package, and then click [Save].

The download begins.

8. Click [Close] to close [Download Completed] dialog box.

Reference

• For details about opening the package, see p.54 "Opening Packages and Installing Drivers".

4

Downloading Packages from the Map

Use the following procedure to download packages from the Map.

1. Display the Map.

Reference

- For details about how to display the Map, see p.35 "Displaying Maps".
- 2. Click a device icon of device whose package you want to download.
- 3. On the properties screen, click the [Download] tab.
- 4. For detailed information about the package, click the properties icon.
- 5. Click [Download] next to the package you want to download.
- 6. Click [Save].
- Specify where you want to save the package, and then click [Save]. The download begins.
- 8. Click [Close] to close [Download Completed] dialog box.

Downloading Packages with a URL Sent by E-mail

Use the following procedure to download packages with a URL sent by e-mail.

1. Click the URL written in the text of the e-mail sent by the administrator.

A download confirmation screen appears.

Reference

- For details about entering a URL manually, see p.53 "If Internet Explorer does not start automatically".
- 2. Click [Login].

000	Version/S01.02.00-04 yeight(C) 2005-2009 Ricch Co., Ltd. All rights reserved
Remote Communication Gate S for @Remote Enterprise Pro	
🔗 Readme 📕 Help	
User neme: Password Cooh	@Remote
The SOFTWRE PROLUCT is protected to coupleb laws and interactional coupleb treatises, as well as other interaction approach, here and here interaction were approach. The source of the source and approach treatises of the source and treatises.	

- 3. Click [Save].
- Specify where you want to save the package, and then click [Save]. The download begins.
- 5. Click [Close] to close [Download Completed] dialog box.

If Internet Explorer does not start automatically

Use the following procedure to start Internet Explorer when the URL notified by e-mail does not start automatically.

- 1. Start Internet Explorer manually.
- 2. Copy and paste the URL from the e-mail into the Internet Explorer address bar.
- 3. Press the [Enter] key.

Internet Explorer starts and the login screen appears.

Opening Packages and Installing Drivers

Use the following procedure to open packages and install them to your computers.

🔂 Important 🔵

- Before opening a package, log on to Windows as an Administrators group member and close any applications that are running.
- 1. Open the folder where the package is saved.
- 2. Double-click the downloaded package (.exe file).
- 3. When the [Security Warning] screen appears, click [Yes].
- 4. On the [User Account Control] screen, click [Allow].
- 5. Read the terms of the license agreement. If you agree with them, click [I accept the agreement], and then click [Next].

Add Printer and Utility Wizard	
License Agreement Do you accept the terms of the License Agreement	r •
Available Softwares	
RICOH Aficio SP 8200DN RPCS	۸ ٣
Please read the following License Agreement. agreement. SOFTWARE LICENSE AGREEMENT YOU, THE END USER SHALL USE THIS SOF THE TERMS OF THIS AGREEMENT. BY LOADING THE SOFTWARE INTO ANY COMPL	TWARE("THE SOFTWARE") ACCORDING TO
• I accept the agreement	⊂ I <u>d</u> on't accept the agreement.
	Next > Cancel

Installation of the drivers starts.

6. If [Confirm restart.] appears, click [Yes. Restart right now.], and then click [Finish].

Windows restarts.

Note

• During installation, the [Software Installation] dialog box may appear. In this case, click [Continue Anyway] to continue the installation.

5. Appendix

About Help

To understand operating procedures, see Help.

There is a Help button located on the login screen, the device list screen, and other screens. Clicking the Help button displays Help.

Login screen



Device list screen

View by Filter Printers with Errors		Main Group 🔍								<u>∎</u> Use
No Response Devices		All Printers			-					
No Filters	Edi	c Printer Filter	View	Sort by						(
Filter Settings>>		1-10/10item(s)	• H	Selecter	d Printers					1 / 1 page(s)
View by Group		evice Display Name		- Device c			System	Printer	Registered Grou	up qu
Main Group	L 11	imagio MP C5000(ii	11139.196	 I Moure Sustant 		55	1	53	Ungrouped	
	L (#	imagio MP C4500(1)	139.196	Printer		81	1	2	Ungrouped	
	L 🗇	Aficio MP 171(100 1	TP.196.220	Revistor	ed Group	20			Ungrouped	
	🗆 🗐	Aficio MP 2000(133	196.22	110610101	eu circop	26			Ungrouped	
	🗆 🎬	imagio MP C6000(1)	31 139.196.2	236) 🗐	133.338.196	236			Ungrouped	
		Aficio SP 8200DN(11	0 109.196.2	37) 🔳	139-139-196	.237			Ungrouped	
		Aficio SP C420DN(#1	1.196.2	39) 🗐	sill.sl#.196	239		<u> </u>	Ungrouped	
	L 19	Aficio MP C2050(130	1130.196.24	8)	133.338.196	248		U	Ungrouped	
		 IPSiO SP C721(310) 	139.196.249)	139-199-196	.249			Ungrouped	
	L 🗇	imagio Neo C385(11	13.138.196.2	50) 🔲	133.138.196	250			Ungrouped	

Other screen



If Your Computer is Running Windows XP Service Pack 2 or later/Vista/7

Comportant 🗋

5

- Under Windows XP Service Pack 2 or later/Vista/7, Help may not be displayed correctly because active content may be restricted from being shown depending on the Internet Explorer settings. Use the following procedure to deactivate active content controls.
- 1. Click [To help protect your security, Internet Explorer has restricted this file from showing active content that could access your computer. Click here for options...].

A menu is displayed.

- 2. On the menu bar, select [Allow blocked content...].
- 3. Click [Yes] on the [Security Warning] dialog box.

Troubleshooting

This describes the solutions for problems that maybe arise during operating Remote Communication Gate S. See the table below and perform the suggested solution in order to address the problem.

Problem	Cause and solutions
In the login screen, you cannot login to the Remote Communication Gate S.	The password might not be correct. Ask the administrator to confirm the password.
The Remote Communication Gate S login screen does not appear.	The Remote Communication Gate S server's URL specified in the browser is incorrect. Ask the administrator how to access to the Remote Communication Gate S Server.
The login screen reappears after a certain amount of time has passed.	The Login screen reappears if no operation is performed for more than 30 minutes after logging in to the Remote Communication Gate S server. Log in again if necessary.
The device list or other lists do not appear when connecting via SSL.	 You might have enabled the saving of encrypted pages. To turn off this function: 1. On the Internet Explorer menu bar, click [Tools] > [Internet Options], and then select the [Advanced] tab. 2. Clear the [Do not save encrypted pages to disk] check box. 3. Click [OK].

5. Appendix

INDEX

Α

Activating browser JavaScript	.11	1
All Printers	.23	3

В

Button

Help	
Logout	15, 18
Map Opacity	
Map size	
Refresh	18, 37, 40
Save as Filter	
Search	
Site Map	
View List	
View Map	

С

Counter tab	44

D

De	evice icon	
	Blinking	40
	Blue	37, 40
	Gray	37, 40
	Red	37, 40
De	vice information	41
	Content	42
	Display from menu bar	41
	Display from properties icon	41
De	evice list	17, 25
	All Printers	23
	Device list display area	18
	Download packages	50
	Edit menu	19
	Filter menu	19
	Group display	17
	Group list	18
	Login user name	18
	No response devices	29
	Printer menu	19
	Printers with errors	28
	Quick Links area	18
	Search conditions	25
	Sort by menu	20
	Sort the list	33
	Status icon	20

Use other filters	
View menu	19
Device list display area	18
Directory tab	17, 37
Domain name	13
Download packages	50
Download tab	47

E

Edit menu	
Device list	19
Filter Settings	31

F

Filter	17
Delete filters	33
Edit filters	
Filter Settings	
Printers with Errors	23
Save as filter	
Filter menu	19
Filter Settings	24

G

Group display	17
Group list	18

Н

Help	55
Help button	18, 40
How to read this manual	1

l Icon

Device icon (Blinking)	40
Device icon (Blue)	37, 40
Device icon (Gray)	37, 40
Device icon (Red)	37, 40
Printer status	22
System status	21

J

JavaScript	11
L	
Language	10
Layout	

Device list	17
Мар	36
Simplified Map	39
Site Map	23
Login	13
Login URL	
With SSL encryption	13
Without SSL encryption	13
Login user name	18
Logout	15
Logout button	15, 18

Μ

Ρ

Packages	49
Download from e-mail notification	52
Download from the Map	52
Download from the package list	47, 50
Install drivers	54
Open packages	54
Password	24
Printer menu	19
Printer properties	41
Counter tab	44
Download tab	47
Printer Status tab	43
User Properties tab	46
Printer status icon	22

Printer status tab	43
Printers with Errors	23
Q	

Quick Links area		1	8	3
------------------	--	---	---	---

R

Ref	resh button	
	Device list	
	Мар	37
	Simplified Map	40

S

Save as Filter button	30
Screens	2
Search	
Device	25
Option list	27
Save as filter	
Search button	17, 25
Search item list	26
Simplified Map	
Display from printer properties	
Map Opacity slider	40
Map size buttons	40
Refresh button	40
Site Map	23
All Printers	23
Filter Settings	24
Printers with Errors	23
Site Map button	18
User Account Settings	23
Sort by menu	20
Status icon	20
Symbols	1
System requirements	10
System status icon	21
·	

Т

Terminology	1
Trial Version	14
Troubleshooting	57
U	

User Account Settings	.23,	24
User Properties tab		.46

V

View List button	37
View Map button	47
View menu	
Device list	19
Man	38
mup	50

MEMO

MEMO

MEMO

Remote Communication Gate S User's Guide

•••••

•

