

本製品をお買い上げのお客様へ

このたびは本製品をお買い上げいただきまして、まことにありがとうございます。
使用説明書に不足な内容がありましたので、次のとおりに補足します。
使用説明書とあわせてご覧ください。

状態	対処方法
ペン先でポイントした位置とスクリーン上で表示される位置にずれがある。	・ パソコンのグラフィックドライバーで、ディスプレイの表示設定を変更し、投影した画面をパソコン側でスケーリングしないように設定してください。 (例：ディスプレイ > 一般設定 > スケーリング 「ディスプレイスケーリングを保持する」に変更) ・ パソコンの出力先の設定を、プロジェクターの画面だけ表示するよう変更してください。 設定について詳しくは、パソコンの説明書を確認してください。

Notes for Users

This supplement provides notes for the manual provided with this application.
Read this supplement in conjunction with the Operating Instructions.

Problem	Solutions
The location the pen nib points at does not correspond with what is displayed on the screen.	▪ Change the display settings using the computer's graphic driver, so that the screen projected is not scaled by the computer. (Example : Display > General Settings > Scaling > Maintain Display Scaling) ▪ Change the computer output settings so that only the projector screen is displayed. For details about settings, see the computer manual.

© 2013 Ricoh Co., Ltd.

Printed in China

JA (JP) EN (GB) EN (US) EN (AU)

Y028-7537



Y0287537