



J0316634B

このたびは、本製品をお買い求めいただきましてありがとうございます。本製品は、SG 3120B SF に使用する充電式のリチウムイオンバッテリーです。ご使用前に、この説明書をよくお読みの上、正しくお使いください。本書をすぐにご利用できるように保管してください。

安全上のご注意

⚠ 危険 ⚠

- 電池の使い方を誤ると、電池の液もれや破裂により、火災やけがの原因になることがあります。
- 車内や炎天下など、高温になる場所に放置しないでください。発熱、破裂、発火の原因となる恐れがあります。
- 電池は加熱したり、火や水の中に投げ込まないでください。
- 電磁調理器の上に置いたり、電子レンジに入れたりしないでください。
- 指定された機器以外には使用しないでください。
- 指定された充電方法以外で充電しないでください。
- 電池を分解、改造、直接ハンダ付けしたりしないでください。
- 落下などの衝撃を与えたバッテリーパックは使用しないでください。
- 釘を刺したり、ハンマーで叩いたり、踏みつけたりしないでください。
- 接続端子部を針金などで接続しないでください。
- 金属製のネックレスやヘアピン等と一緒に持ち運んだり、保管しないでください。電池がショート状態となり、発熱、破裂、発火の原因となります。
- 充電中、放電中、保管中に異臭、異常な発熱、変形などが生じた場合は、すぐに使用を中止し、機器から取り外してください。
- 電池は乳幼児や幼児の手の届くところに置かないでください。

⚠ 危険 ⚠

- 電池から液がもれたときの対処
 - もれた液が肌に付着したときは、すぐに水で洗い流し、医師に相談してください。
 - もれた液が手につかないように注意してティッシュペーパーなどで拭き取ってください。
 - 液を拭き取ったティッシュペーパーなどは、水を含ませてから燃えるゴミとして廃棄してください。

⚠ 注意 ⚠

- 電池は、間違ったタイプと交換した場合、爆発の危険があります。使用済みの電池は、取り扱い指示に従って処分してください。

充電

- バッテリーを充電するときは、必ず本体に AC アダプターを接続してください。
- バッテリーは、電源が切れているとき、または省エネモードのときに充電されます。バッテリー稼働中は充電されません。
- バッテリーは、温度が 0℃～60℃のときに充電されます。この温度範囲外では安全のため充電が停止します。
- バッテリーを完全に充電するのに約 3 時間かかります。省エネモードへの移行時間が長いときや、頻繁に使用しているときは 3 時間以上かかります。

使用上のご注意

- はじめて使用するときは、必ず本体 (SG 3120B SF) の AC アダプターを接続してください。AC アダプターの接続方法は、本体に同梱のマニュアルを参照してください。
- バッテリーを取り付けたり取り外したりするときは、必ず電源を切ってください。稼働中にバッテリーを取り外すと、本体が故障することがあります。
- 工場での出荷検査により、バッテリー端子に傷がついていることがありますが、製品の性能に影響はありません。
- 動作環境に記載されている温度を超える場所では、充電、使用、保管しないでください。
- バッテリーを長持ちさせるためには、周囲温度 10℃～32℃の環境で充電、使用、保管してください。特に、40℃以上の環境での充電、使用、保管は、バッテリーの劣化につながりますので注意してください。
- 長期間使用しないときは、機器から取り外し、出来るだけ涼しく乾燥した場所にて保管してください。

仕様

- 使用電池：リチウムイオン電池
- 最大電圧：16.4V
- 公称電圧：14.4V
- 容量：4700mAh/68Wh
- 外形寸法 / 質量
185(W) × 73(H) × 25.5(D)mm
約 500g

バッテリー (二次電池) の回収

弊社は使用済み製品 (バッテリー含む) の回収を行いリサイクルを推進しています。

回収方法について詳しくはご購入先にお問い合わせください。

- 不要になったバッテリーは、ショートによる発煙、発火の恐れがありますので端子部分をテープ等で絶縁するか、個別にポリ袋に入れてください。



使用後はリサイクルへ

お問い合わせ先

消耗品に関するお問い合わせ

弊社製品に関する消耗品は、お買上げの販売店にご注文ください。
NetRICOH のホームページからもご購入できます。
<http://www.netricoh.com/>

株式会社リコー

東京都大田区中馬込 1-3-6
〒143-8555
<http://www.ricoh.co.jp/>

Note for the Battery and/or Accumulator Symbol (For EU countries only)



In accordance with the Battery Directive 2006/66/EC Article 20 Information for end-users Annex II, the above symbol is printed on batteries and accumulators. This symbol means that in the European Union, used batteries and accumulators should be disposed of separately from your household waste. In the EU, there are separate collection systems for not only used electrical and electronic products but also batteries and accumulators. Please dispose of them correctly at your local community waste collection/recycling centre.

Rechargeable Battery P5

This product is a rechargeable Li-ion battery for SG 3120B SFNw. Before using this product, read this leaflet carefully in order to use this product safely. Keep this leaflet in a handy place for quick reference.

Safety Precautions to Be Followed

⚠ WARNING

- For safe operation, follow the warnings below regarding the battery. If you use a battery incorrectly, it may result in fire or injury due to battery leaking or exploding.
- Do not leave the battery in a place where the temperature is likely to be high, such as in a vehicle or strong sunlight. Doing so may cause abnormal heating, rupture, or fire.
- Do not place the batteries in fire or water.
- Do not place the battery in an induction heating cooker or a microwave oven.
- Do not use the battery with devices other than the specified machine.
- Do not recharge the battery using a method other than the specified recharging method.
- Do not disassemble, modify or solder the battery.
- Do not use the battery if it has received an impact—for example, by being dropped.
- Do not nail, hammer, or crush the battery.
- Do not connect the connecting terminals on a battery with a wire.
- Do not carry or store the battery with a metal object, such as a necklace or hairpin. Doing so may cause the battery to short-circuit, resulting in abnormal heating, rupture, or fire.
- If abnormal heating or deformation of the battery occurs during recharging, discharging, or storage, immediately stop using the battery and remove it from the machine.
- Keep the batteries out of the reach of children.
- What to do if a battery has leaked.
 - If leakage from a battery adheres to your skin, rinse it with water immediately, and then contact a doctor.
 - Wipe off the leakage with tissue paper while being careful not to touch it.
 - Soak the tissue paper that you used in water, and then throw it away as burnable trash.

Notes on Charging the Battery

- To charge the battery, connect the AC adapter to the machine.
- The battery is charged when the machine is off or in Energy Saver mode. It is not charged while it is powering the machine.
- The battery can be charged within a temperature range of 0 to 60°C. At a temperature above or below this range, charging stops.
- It normally takes about three hours to fully charge the battery. If the machine takes a long time to switch to Energy Saver mode or if the machine is used often, the time to fully charge increases.

Notes for Using Batteries

- When you use the machine for the first time, be sure to connect the AC adapter. For details about connecting the AC adapter, see the manual supplied with the machine.
- Be sure to turn the power off when you attach or detach the battery. If you do not turn the power off, machine malfunctions may result.
- When inspected at the factory prior to shipment, the battery terminal may be scratched. Scratches on the battery terminal it does not affect the performance of the product.
- Do not recharge, use, or store the battery in a place where the temperature exceeds that of the specified operating environment.
- To maximize the battery life, recharge, use, and store it in an environment with an ambient temperature of 10 to 32°C. Be careful about recharging, using, or storing the battery in an environment with an ambient temperature of 40°C or above. Doing so will cause the battery to deteriorate.
- If the machine is to be left unused for a long time, remove the battery and store it in a cool, dry place.

Specifications

- Cell chemistry: Li-ion
- Maximum voltage: 16.4 V
- Nominal voltage: 14.4 V
- Capacity: 4700 mAh/68 Wh

- Dimensions/Weight:
185 (W) × 73 (H) × 25.5 (D) mm/approx. 500g
7.28 (W) × 2.87 (H) × 1.00 (D) inches/approx.
1.1lbs

Notes for Disposal

- Dispose of replaced parts in accordance with local regulations.

For users in the state of California

Perchlorate Material - special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate

“CAUTION”

- Mishandling the battery may cause fire or chemical burns.
Do not disassemble the battery.
Handle a damaged or leaking lithium-ion battery with extreme care.
If the battery is damaged, electrolyte may leak from the cells and may cause injury.
- Do not incinerate or disassemble the battery. It may explode or release toxic materials.
Do not short-circuit the battery. It may cause burns.
- Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.
- Do not open, crush, use above the specified temperature (140°F/60°C) or incinerate the battery. It may cause fire or burns.
Follow the manufacturer's instructions.
- Replace this battery only with a RICOH Rechargeable Battery P5 module.
Battery pack is suitable for use only with RICOH Printer Model SG 3120B SFNw.

“Operating environment”

Ambient temperature range		
Charge	45 °C	
Discharge	60 °C (60 W)	
Ambient temperature range for battery storage	Less than 1 month	-20 – 50 °C
	Less than 3 months	-20 – 40 °C
	Less than 1 year	-20 – 20 °C

Charging parameters	
Maximum charging voltage	16.52 Vdc
Maximum charging current	3360 mA

CE Marking Traceability Information (For EU Countries Only)

Manufacturer:

Ricoh Co., Ltd.
3-6 Nakamagome 1-chome, Ohta-ku, Tokyo. 143-8555, Japan

Authorized representative:

Ricoh Europe PLC
20 Triton Street, London. NW1 3BF, United Kingdom

« ATTENTION »

- Une mauvaise manipulation de la batterie peut provoquer un incendie ou des brûlures chimiques.
Ne pas démonter la batterie.
Manipuler une batterie lithium-ion présentant des dommages ou une fuite avec extrême précaution.
Si la batterie est endommagée, de l'électrolyte peut fuir hors des cellules et provoquer des blessures.
- Ne pas incinérer ou démonter la batterie. Elle pourrait exploser ou libérer des substances toxiques.
Ne pas court-circuiter la batterie. Cela pourrait provoquer des brûlures.
- Risque d'explosion si la batterie est remplacée par un type incorrect.
Suivre les instructions pour jeter les batteries usagées.
- Ne pas ouvrir, écraser, utiliser à une température supérieure à celle spécifiée (60°C/140°F) ou incinérer la batterie. Cela peut provoquer un incendie ou des brûlures.
Suivre les instructions du fabricant.
- Remplacer la batterie uniquement par un module RICOH Rechargeable Battery P5.
Le bloc de batterie ne peut s'utiliser qu'avec le modèle d'imprimante RICOH SG 3120B SFNw.

« Environnement d'exploitation »

Plage de température ambiante		
En charge		45 °C
Déchargement		60 °C (60 W)
Température ambiante	Moins de 1 mois	-20 – 50 °C
	Moins de 3 mois	-20 – 40 °C
	Moins de 1 an	-20 – 20 °C

Paramètres de charge	
Voltage maximum de charge	16.52 V c.c.
Courant maximal de charge	3360 mA

© 2013, 2017

Printed in China

JA JP EN GB EN US EN AU
J031-6634B