

Adonis C2
(B003/B004/B006/B007)
PARTS CATALOG

First edition, February 2001

Ricoh Company, LTD.

Adonis C2 (B003/B004/B006/B007)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

CONTENTS

Adonis C2	(B003/B004)
	(B006/B007)
DF70	(B351)
SR760	(B352)
PT1045	(B376)
Punch Kit Type 1045	(B377)
Bridge Unit Type 1045	(B397)
Fax/G3/ISDN Unit Type 1045	(B360/B366/B367)
Printer Unit Type 1045	(B362)

Adonis C2
(B003/B004/B006/B007)

Adonis C2 (B003/B004/B006/B007)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

CONTENTS

LOCATION OF UNIT.....	2	18.TRANSFER UNIT 2 (B003/B004/B006/B007)	42
1.EXTERIOR 1 (B003/B004/B006/B007)	8	19.DEVELOPMENT UNIT (B003/B004/B006/B007)	44
2.EXTERIOR 2 (B003/B004/B006/B007)	10	20.FUSING UNIT (B003/B004/B006/B007)	46
3.EXTERIOR 3 (B003/B004/B006/B007)	12	21.PAPER SEPARATION UNIT (B003/B004/B006/B007) ..	48
4.PLATEN COVER (B003/B004/B006/B007)	14	22.DUPLEX UNIT 1 (B003/B004/B006/B007)	50
5.OPERATION PANEL ASS'Y (B003/B004/B006/B007) ...	16	23.DUPLEX UNIT 2 (B003/B004/B006/B007)	52
6.OPTICS UNIT 1 (B003/B004/B006/B007)	18	24.DUPLEX UNIT 3 (B003/B004/B006/B007)	54
7.OPTICS UNIT 2 (B003/B004/B006/B007)	20	25.DRIVE SECTION 1 (B003/B004/B006/B007)	56
8.LASER UNIT (B003/B004/B006/B007)	22	26.DRIVE SECTION 2 (B003/B004/B006/B007)	58
9.BY-PASS FEED UNIT 1 (B003/B004/B006/B007)	24	27.ELECTRICAL SECTION 1 (B003/B004/B006/B007)	60
10.BY-PASS FEED UNIT 2 (B003/B004/B006/B007)	26	28.ELECTRICAL SECTION 2 (B003/B004/B006/B007)	62
11.PAPER TRAY UNIT (B003/B004/B006/B007)	28	29.FRAME SECTION 1 (B003/B004/B006/B007)	64
12.PAPER FEED SECTION (B003/B004/B006/B007)	30	30.FRAME SECTION 2 (B003/B004/B006/B007)	66
13.PAPER REGISTRATION (B003/B004/B006/B007)	32	31.EXPANTION BOX (B003/B004/B006/B007)	68
14.TONER HOPPER UNIT (B003/B004/B006/B007)	34	32.IOB BOARD (B003/B004/B006/B007)	70
15.PCU UNIT 1 (B003/B004/B006/B007)	36	33.BICU BOARD (B003/B004/B006/B007)	74
16.PCU UNIT 2 (B003/B004/B006/B007)	38	34.CONTROLLER BOARD (B003/B004/B006/B007)	78
17.TRANSFER UNIT 1 (B003/B004/B006/B007)	40	35.DECAL AND DOCUMENT (B003/B004/B006/B007)	82


February ,5 ' 2001

CONTENTS (Continued)

36.SPECIAL TOOLS (B003/B004/B006/B007)	84
PARTS INDEX.....	87


LOCATIONS OF UNITS

1. EXTERIOR 1 (B003/B004/B006/B007)




See Page 9

2. EXTERIOR 2 (B003/B004/B006/B007)




See Page 11

3. EXTERIOR 3 (B003/B004/B006/B007)




See Page 13

4. PLATEN COVER
(B003/B004/B006/B007)




See Page 15

5. OPERATION PANEL ASS'Y



See Page 17


6. OPTICS UNIT 1 (B003/B004/B006/B007)



See Page 19


LOCATIONS OF UNITS

7. OPTICS UNIT 2 (B003/B004/B006/B007)




See Page 21

8. LASER UNIT (B003/B004/B006/B007)




See Page 23

9. BY-PASS FEED UNIT 1
(B003/B004/B006/B007)




See Page 25

10. BY-PASS FEED UNIT 2
(B003/B004/B006/B007)




See Page 27

11. PAPER TRAY UNIT
(B003/B004/B006/B007)



See Page 29


12. PAPER FEED SECTION
(B003/B004/B006/B007)



See Page 31


LOCATIONS OF UNITS

13. PAPER REGISTRATION
(B003/B004/B006/B007)




See Page 33

14. TONER HOPPER UNIT
(B003/B004/B006/B007)




See Page 35

15. PCU UNIT 1 (B003/B004/B006/B007)




See Page 37

16. PCU UNIT 2 (B003/B004/B006/B007)




See Page 39

17. TRANSFER UNIT 1
(B003/B004/B006/B007)



See Page 41


18. TRANSFER UNIT 2
(B003/B004/B006/B007)



See Page 43


LOCATIONS OF UNITS

19. DEVELOPMENT UNIT
(B003/B004/B006/B007)




See Page 45

20. FUSING UNIT (B003/B004/B006/B007)




See Page 47

21. PAPER SEPARATION UNIT




See Page 49

22. DUPLEX UNIT 1 (B003/B004/B006/B007)




See Page 51

23. DUPLEX UNIT 2 (B003/B004/B006/B007)



See Page 53


24. DUPLEX UNIT 3 (B003/B004/B006/B007)



See Page 55


LOCATIONS OF UNITS

25. DRIVE SECTION 1
(B003/B004/B006/B007)




See Page 57

26. DRIVE SECTION 2
(B003/B004/B006/B007)




See Page 59

27. ELECTRICAL SECTION 1
(B003/B004/B006/B007)




See Page 61

28. ELECTRICAL SECTION 2
(B003/B004/B006/B007)




See Page 63

29. FRAME SECTION 1
(B003/B004/B006/B007)




See Page 65

30. FRAME SECTION 2
(B003/B004/B006/B007)




See Page 67

LOCATIONS OF UNITS

31. EXPANTION BOX (B003/B004/B006/B007)  See Page 69		

1.EXTERIOR 1 (B003/B004/B006/B007)




1.EXTERIOR 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B351 6511	Left Scale - (EU)(Asia)(CHN)(TWN)	1
1	B351 6521	Left Scale (NA)	1
2	AA14 3520	Shoulder Screw - M3	7
3	A232 1357	Left Cover - Scanner	1
4	AC01 2067	Exposure Glass	1
5	A232 1677	Rear Scale	1
6	B004 1350	Upper Rear Cover - Scanner	1
7	B004 1356	Right Cover - Scanner	1
8	B004 1303	Cover - Guide Plate - Rear	1
9	B004 1301	Cover - Guide Plate - Scanner Unit	1
10	B004 7232	Operation Panel Ass'y (NA)(B003/B004)	1
10	B004 7632	Operation Panel Ass'y (EU)(B003/B004)	1
10	B004 7932	Operation Panel Ass'y (TWN)(B003/B004)	1
10	B004 7942	Operation Panel Ass'y (CHN)(B003/B004)	1
10	B004 7952	Operation Panel Ass'y (Asia)(B003/B004)	1
10	B007 7232	Operation Panel Ass'y (NA)(B006/B007)	1
11	B004 1358	Lower Cover	1
12	B004 5538	Harness - OPU	1
13	AA14 3523	Shoulder Screw - M3	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008H	Tapping Screw - M3x8	
102	0451 3012H	Tapping Screw - 3x12	
103	0451 3010H	Tapping Screw - 3x10	
104	0804 6075	Hexagonal Bolt - M3x8	

2.EXTERIOR 2 (B003/B004/B006/B007)




2.EXTERIOR 2 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 7226	Left Front Cover - NA	1
1	B004 7626	Left Front Cover - EU	1
2	AA06 3563	Spring	2
3	A232 1282	Cap - Switch	1
4	B004 1283	Left Rear Cover	1
5	B004 1285	Left Cover-paper Feed Sub-unit	1
6	A230 1268	Upper Cover - Paper Feed	1
7	G020 1332	Hinge - Front Cover	2
8	B004 1261	Front Cover Ass'y	1
9	B003 7210	Emblem (RIC)(B003)	1
9	B003 7211	Emblem (RIC-GSA)(B003)	1
9	B003 7212	Emblem (SVN)(B003)	1
9	B003 7213	Emblem (SVN-GSA)(B003)	1
9	B003 7214	Emblem (GES)(B003)	1
9	B003 7217	Emblem (INF)(B003)	1
9	B003 7218	Emblem (LAN)(B003)	1
9	B004 7210	Emblem (RIC)(B004)	1
9	B004 7211	Emblem (RIC-GSA)(B004)	1
9	B004 7212	Emblem (SVN)(B004)	1
9	B004 7213	Emblem (SVN-GSA)(B004)	1
9	B004 7214	Emblem (GES)(B004)	1
9	B004 7217	Emblem (INF)(B004)	1
9	B004 7218	Emblem (LAN)(B004)	1
9	B006 7210	Emblem (RIC)(B006)	1
9	B006 7212	Emblem (SVN)(B006)	1
9	B006 7218	Emblem (LAN)(B006)	1
9	B007 7210	Emblem (RIC)(B007)	1
9	B007 7212	Emblem (SVN)(B007)	1
9	B007 7218	Emblem (LAN)(B007)	1
10	B004 1385	Jam Removal Sheet	1
11	A232 2876	Lower Cover - Vertical Transport	1
12	5206 2686	Snap Ring	1
13	A232 2863	Stopper Band	1
14	AA06 3564	Tension Spring	2
15	AA08 0254	Bushing - M4	4

Index No.	Part No.	Description	Q'ty Per Assembly
16	AF02 0409	Driven Roller	2
17	A232 2860	Entrance Seal	1
18	A232 2859	Lower Support Plate	1
19	AA00 1392	Decal - A1	1
20	AG07 0014	Magnet Catch	1
21	A232 2857	Cover - Vertical Transport	1
22	A176 1317	Cap - 34x55	1
23	A232 2723	Support Plate - Knob	1
24	A232 2860	Entrance Seal	1
25	A232 2858	Upper Support Plate	1
26	A232 1272	Right Rear Cover	1
27	AB03 0584	Timing Pulley - 15T	1
28	AA00 0204	Decal - Right Lower Cover	1
29	A232 2724	Knob Cover	1
30	A232 2720	Gear Bracket	1
31	AA04 3416	Timing Belt - 40S3M192	1
32	A232 2722	Knob	1
33	AB03 0564	Pulley - M17	1
34	A232 5838	Spring Plate - BICU	1
35	A232 1286	Stopper - Plate	1
36	A232 2862	Driven Roller	2
37	A232 6780	Decal - ON (CHN)	1
38	A232 6781	Decal - Stand-by (CHN)	1
101	0451 3008H	Tapping Screw - M3x8	
102	0451 3006B	Tapping Screw - M3x6	
103	0720 0060E	Retaining Ring - M6	
104	0720 0030E	Retaining Ring - M3	
105	0450 3008B	Tapping Screw - M3x8	
106	0450 3012B	Tapping Screw -3x12	

3.EXTERIOR 3 (B003/B004/B006/B007)




3.EXTERIOR 3 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 4497	End Fence - Copy Tray	1
2	B004 4436	Copy Tray Guide	1
3	B004 4435	Sub Copy Tray	1
4	B004 1250	Upper Cover	1
5	B004 1324	Cover - Scanner Connector	1
6	A176 1317	Cap - 34x55	2
7	A232 1252	Duct - Upper Cover	1
8	AA15 3390	Sponge - 202x3.5x4	1
9	AG07 1010	Magnet Catch	2
10	A232 1381	Decal - Total Counter	1
11	AX31 0039	Total Counter - 7fig 24v	1
12	A284 1376	Inner Cover-left	1
13	A284 1372	Inner Cover-upper	1
13	B004 1093	Rear Stay	1
14	B004 5836	Front Grounding Plate	1
15	A232 1094	Nut	2
16	B004 1101	Front Bracket - Scanner Unit	1
17	B004 1104	Rear Bracket - Scanner Unit	1
18	B004 1296	Rear Cover - Paper Feed Sub-unit	1
19	B004 1291	Rear Cover	1
20	A232 1173	Sheet - Duct	1
21	B004 1043	Spacer - Scanner Unit	1
22	A232 1284	Spring Holder	2
23	A232 1251	Duct Cover - Lower Exhaust Ass'y	1
24	AA14 3501	Stepped Screw - M8	2
25	B004 1049	Scanner Arm Unit	1
26	B004 1048	Supporting Plate - Scanner Unit	1
27	B004 1038	Guide Plate - Scanner Unit	1
28	A232 4499	Copy Tray Mylar	4
29	A232 1257	Cap - Upper Cover	1
30	AA15 0685	Seal - 215x10	1
31	B004 1297	Rear Cover - Paper Feed Sub-unit	1
32	AA15 3070	Dehumidifier Sheet	1
33	G034 1253	Cover - Small - Upper Right	1
34	B004 7222	Css Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	A232 5837	Rear Grounding Plate	1
101	0451 3008H	Tapping Screw - M3x8	
102	0354 0080B	Screw - M4X8	
103	0450 3006B	Tapping Screw - M3x6	
104	0451 3006B	Tapping Screw - M3x6	

4.PLATEN COVER (B003/B004/B006/B007)




4.PLATEN COVER (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5448 2804	Platen Cover Sheet	1
2	AA16 2067	Platen Cover Pad	1
3	A134 1394	Front Platen Cover	1
4	A053 1957	Flex Hinge - Platen Cover	2
5	A134 1395	Rear Platen Cover	1
6	A134 1396	Original Holder	1
7	A153 1383	Platen Cover Feeler	1
8	A153 1370	Platen Cover Hinge	1
9	AC00 1060	Platen Cover Ass'y	1
10	A153 1380	Platen Cover Bracket	1
11	AA14 8447	Guide Pin - Platen Cover	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0142B	Binding Self Tapping Screw - M	

5. OPERATION PANEL ASS'Y (B003/B004/B006/B007)




5.OPERATION PANEL ASS'Y (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B004 7232	Operation Panel Ass'y (NA)(B003/B004)	1
*	B004 7632	Operation Panel Ass'y (EU)(B003/B004)	1
*	B004 7932	Operation Panel Ass'y (TWN)(B003/B004)	1
*	B004 7942	Operation Panel Ass'y (CHN)(B003/B004)	1
*	B004 7952	Operation Panel Ass'y (Asia)(B003/B004)	1
*	B007 7232	Operation Panel Ass'y (NA)(B006/B007)	1
1	B004 7238	Sheet-operation	1
2	B004 1502	Keytop - 10key (EU)	1
2	B004 7236	Keytop - 10key (NA)	1
3	B004 1505	Keytop - Start	1
4	B004 1503	Keytop - Clear/Stop	1
5	B004 1518	Operation Panel Board - Right	1
6	B004 1512	Keytop - Interrupt	1
7	B004 1509	Keytop - Block Diagram	1
8	B004 1506	Keytop - Power Source	1
9	B004 1504	Keytop - Try Print	1
10	B004 1535	Cover - Basic	1
11	B004 1534	Cover - Application	3
12	B004 1532	Keytop - Copy 2 (CHN)(B004)	1
12	B004 7242	Keytop - Copy 2 (NA)	1
12	B004 7642	Keytop - Copy 2 (EU)	1
13	B004 1531	Keytop - Copy 1 (CHN)(B004)	1
13	B004 7241	Keytop - Copy 1 (NA)	1
13	B004 7641	Keytop - Copy 1 (EU)	1
14	B004 1507	Keytop - Reset Switch	1
14	B004 7237	Keytop - Clear Modes	1
15	B004 1508	Keytop - Preheat	1
16	B004 1510	Keytop - Confirm	1
17	A229 5216	Touch Panel	1
18	B004 1511	Keytop - Counter	1
19	B004 1513	Dial - Contrast	1
20	B004 5203	Operation Panel Board (NA)(B003/B004)	1
20	B004 5204	Operation Panel Board (EU)(B003/B004)	1
20	B004 5205	Operation Panel Board (Asia/TWN)(B003/B004)	1
20	B004 5206	Operation Panel Board (CHN)(B003/B004)	1

Index No.	Part No.	Description	Q'ty Per Assembly
21	B004 1521	LCDC Cover	1
22	B004 1520	LCDC Bracket	1
23	B004 1519	Operation Panel Board - Left	1
24	B004 1501	Operation Panel Case (CHN)	1
24	B004 7234	Operation Panel Case (NA)	1
24	B004 7634	Operation Panel Case (EU)	1
25	A232 7234	Sheet - Switch (LT)	1
25	A232 7634	Sheet - Switch (A4)	1
26	B004 5215	LCD - HVGA U95 BL	1
27	B004 1515	Sheet - Preventfence Sheet - Right	1
28	B004 1517	Erath Sheet - Touch Panel	1

6.OPTICS UNIT 1 (B003/B004/B006/B007)




6.OPTICS UNIT 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 1678	Left Scale Bracket	1
2	AW01 0056	Original Sensor - H=2-66	2
3	B004 1681	Inner Cover	1
4	B351 6522	ADF Exposure Glass	1
5	AA15 0711	Shield -base	1
6	B004 1831	Lensholder Assy	1
7	A284 1738	Hinge Bracket	1
8	AW02 0100	Photointerrupter - P1CH2MM	1
9	B004 1849	ARDF Connector Bracket	1
10	B004 5541	Harness- ADF	1
11	AA06 0702	Tension Spring	1
12	A232 1682	Right Stay - Scanner Unit	1
13	AZ50 0055	Xenon Lamp Stabilizer	1
14	B004 5543	Harness - SIB	1
15	A232 1683	Spacer - Inner Cover	1
16	A232 1681	Cushion - Lens Block	1
17	B004 5538	Harness - OPU	1
18	B004 5397	Motor Drive Board	1
19	B004 1841	Scanner Interface Cable	1
20	A284 1751	Scanner Motor Stopper	1
21	B004 5542	Harness - SBU-50wick 80mm	1
22	AW01 0059	Original Sennsor - H=1-66	1
23	B004 5387	Scanner Interface Board	1
24	B004 1324	Cover - Scanner Connector	1
25	B004 1846	Motor Drive Board Bracket - L	1
26	B004 1732	Fan Bracket	1
27	AX64 0128	Fan Motor - 24V	1
28	B004 1847	Motor Drive Board Bracket - R	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0314 0120B	Philips Pan Head Screw - M4x12	
103	0353 0060B	Philips Pan Head Screw - M3x6	
104	1105 0162	Locking Support	
105	0451 3008B	Tapping Screw - M3x8	
106	0314 0180B	Philips Pan Head Screw - M4x18	

7.OPTICS UNIT 2 (B003/B004/B006/B007)




7.OPTICS UNIT 2 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 1809	Carriage Pulley - 22MM	2
2	B004 1713	Pulley 2 - 22MM	2
3	G404 2810	Spring Plate - Mirror - Second	4
4	B004 1820	2nd Mirror Ass'y	2
5	A232 1808	Harness Guide	1
6	A232 1798	2nd Scanner Ass'y	1
7	AA15 0702	Front Shield Plate	1
8	AX50 0073	Xenon Lamp - 8.5MM	1
9	A232 1791	Front Wire Holder	1
10	A232 1782	1st Scanner Ass'y	1
11	A232 1792	Rear Wire Holder	1
12	A232 1788	Reflector	1
13	AC03 0110	Scanner Mirror	1
14	A232 1789	1st Mirror Holder	2
15	B004 1843	Exposure Lamp Harness	1
16	A232 1728	Rail Supporter	2
17	A284 1736	Rear Side Plate	1
18	AA16 1133	Cushion - 4x15x1	2
19	AW02 0056	Photointerrupter - EE-SX4235A-P1	1
20	A232 1839	Bracket - Sensor	1
21	B004 1737	Base - Scanner - Rear	1
22	B004 1726	Rail - Flexible Board	1
23	B004 1728	Bracket - Heater	2
24	A232 1722	Rear Tension Plate - Scanner Wire	1
25	AA05 0106	Carriage Drive Wire	2
26	AA06 0703	Tension Spring	2
27	A232 1731	Scanner Rail	2
28	A232 1771	Busing - M8	1
29	A232 3566	Ball Bearing - 8x16x5	1
30	AB03 2062	Rear Scanner Pulley	1
31	AB03 0572	Timing Pulley - Z61	1
32	AA04 3439	Timing Belt - S2M-224	1
33	B004 1714	Idler Bracket	2
34	A232 1732	Rail Bracket	2
35	A232 1713	Lens Block Supporter	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	AH01 0009	Rubber Pad - H5	4
37	AB03 2061	Front Scanner Pulley	1
38	A232 1712	Front Tension Plate - Scanner Wire	1
39	A284 1735	Front Side Plate	1
40	A232 1707	Second Slide Rail	2
41	A284 1674	Exposure Glass Holder	4
42	AX40 0140	Heater - 120V 15W	1
42	AX40 0142	Heater - 240V 15W	1
43	B004 1741	Power Supply Cord	1
			
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0060E	Retaining Ring - M6	
103	0951 3006B	Philips Screw With Flat Washer - M3x6	
104	1005 0728	Rivet - NRP335	
105	0450 3008B	Tapping Screw - M3x8	
106	1105 0292	Wire Saddle	
107	1105 0291	Harness Clamp - LWS-3S	
108	0575 0050E	Hexagon Headless Set Screw - M5x5	
109	1105 0460	Clamp	
110	1105 0162	Locking Support	
111	0802 5276	Tapping Screw With Washer - M3x6	
112	0314 0060B	Philips Pan Head Screw - M4x6	
113	1105 0292	Wire Saddle	

8.LASER UNIT (B003/B004/B006/B007)




8.LASER UNIT (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B003 1873	Optical Housing Unit(NA/TWN)(B003/B006)	1
*	B003 1877	Optical Housing Unit(EU/Aasia/CHN)(B003)	1
*	B004 1873	Optical Housing Unit(NA/TWN)(B004/B007)	1
*	B004 1877	Optical Housing Unit(EU/Aasia/CHN)(B004)	1
1	A284 1904	Cover - Optical Housing	1
2	G020 1918	Decal - Laser Diode (230V)	1
2	G020 1920	Decal - Laser Diode (115V)	1
3	G020 1917	Decal - LD	1
4	A232 1904	Cap - Laser Unit Cover	1
5	A232 1971	Support Cover - Imaging Unit	1
6	A232 1900	Housing - Laser Unit	1
7	AA15 2403	Sponge - Laser Unit Cover	1
8	AC01 5025	Shield Glass	1
9	AX06 0141	Polygon Mirror Motor (B003/B006)	1
9	AX06 0180	Polygon Mirror Motor (B004/B007)	1
10	A232 1918	Heat Sink - Polygon Motor	1
11	A232 1920	Decal - Heat Sink	1
12	G020 1966	Cylindrical Lens	1
13	A232 1927	Cylindrical Lens Holder	1
14	A232 1926	Mirror Holder	2
15	A232 1925	Middle Mirror Holder	1
16	AC03 0115	Mirror	1
17	A232 1923	Front Holder - BTL	1
18	A232 1924	Rear Holder - BTL	1
19	G020 1969	BTL Lens	1
20	A232 1921	Front Holder - F Theta Mirror	1
21	A232 1922	Rear Holder - F Theta Mirror	1
22	G020 1968	F Theta Mirror	1
23	A232 1928	Holder - Sync. Detector Mirror	1
24	GC03 0020	Sync. Detector Mirror	1
25	A293 5310	Sync Detector Board	1
26	B002 1891	LD Unit (B003/B006)	1
26	B004 1891	LD Unit (B004/B007)	1
27	A232 5444	Harness - Laser Unit (B004/B007)	1
27	A232 5445	Harness - Laser Unit (B003/B006)	1

Index No.	Part No.	Description	Q'ty Per Assembly
28	AC01 5024	Shield Glass - Polygon Motor	1
101	0951 3008B	Philips Screw With Flat Washer - M3x8	
102	0450 3010B	Tapping Screw - M3x10	
103	0450 3008B	Tapping Screw - M3x8	

9.BY-PASS FEED UNIT 1 (B003/B004/B006/B007)




9.BY-PASS FEED UNIT 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 6106	Middle Lower Cover	1
2	A232 6095	Frame By-pass Unit Holder	1
3	A232 6109	Front Cover - By-pass Unit	1
4	A232 6108	Rear Cover - By-pass Unit	1
5	A232 6107	Middle Upper Cover	1
6	A232 6090	Bracket Positioning Pin	1
7	A232 6091	Positioning Pin	1
8	AA08 2070	Bushing - 8x16x7	1
9	AA06 6574	Torsion Spring	1
10	A232 6067	By - Pass Feed Table	1
11	A232 6068	Cover By-pass Table	1
12	A232 6082	Front Rack	1
13	G011 3305	Gear - 16T	1
14	A232 6083	Rear Rack	1
15	A232 6080	Paper Size Detector	1
16	A232 6073	Decal - By-pass Feed	1
17	A232 6085	Guide By - Pass Table	1
18	A232 6092	Roller - Holder	1
19	A232 6070	Rear Side Fence	1
20	A232 6072	Sub - Rear Fence	1
21	A232 6069	Front Side Fence	1
22	A232 6071	Sub - Front Fence	1
23	AF04 0559	Driven Roller - M9	1
24	A232 6009	By-pass Feed Table Ass'y	1
25	A232 6010	Support Stay	1




Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008H	Tapping Screw - M3x8	
102	1105 0349	Edge Saddle	
103	0720 0060E	Retaining Ring - M6	
104	0451 3008B	Tapping Screw - M3x8	
105	0451 4010B	Tapping Screw - 4x10	

10.BY-PASS FEED UNIT 2 (B003/B004/B006/B007)





11.PAPER TRAY UNIT (B003/B004/B006/B007)




11.PAPER TRAY UNIT (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 2905	Universal Paper Tray (NA)	1
1	B004 2910	Universal Paper Tray (EU)	1
2	B004 2932	Rear Stopper Lever	1
3	AF01 6166	Front Side Fence	1
4	B004 2940	Bottom Plate	1
5	AF01 3006	Bottom Plate Pad	1
6	AF01 7026	End Fence	1
7	AA00 3007	Decal- Paper Set Direction	1
8	B004 2988	Handle - Paper Tray	1
9	B004 2951	Stopper-right	1
10	A232 2975	Bottom Lift Plate	1
11	A232 2987	Roller - Paper Tray	2
12	B004 2915	Bottom Lift Shaft	1
13	B004 2943	Grounding Plate - Paper Tray	1
14	AF01 6167	Rear Side Fence	1
15	A232 2989	Screw Holder	1
16	B004 2947	Spring Plate-paper Size Sensor	1
17	B004 2952	Shoe- Left	1
18	B004 2933	Rear Stopper	1
19	B004 2934	Spring Plate - Lock Lever	1
20	B004 2954	Paper Size Dial (LT)	1
20	B004 2955	Paper Size Dial (A4)	1
21	B004 2948	Paper Size Sensor	1
22	B004 2924	Paper Guide Plate - Front	1
23	B004 2935	Paper Guide Plate - Rear	1
24	B004 2936	Gear - 16Z	1
25	B004 2920	Front Side Fence	1
26	B004 2922	Release Lever - Side Fence	1
27	B004 2923	Spring Plate - Release Lever	1
28	B004 2930	Rear Side Fence	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	1
102	0353 0060B	Philips Pan Head Screw - M3x6	1
103	0450 4008B	Tapping Screw - 4x8	1
104	0452 3008B	Tapping Screw - M3x8	1

12.PAPER FEED SECTION (B003/B004/B006/B007)




12.PAPER FEED SECTION (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF03 0034	Pick-up Roller	1
2	A232 2763	Pick-up Arm	1
3	AB01 1188	Gear - 21Z	1
4	AA06 0691	Tension Spring	1
5	5447 2681	Snap Ring	1
6	AF03 1035	Feed Roller	1
7	AB01 1189	Gear - 18Z	1
8	AA08 2070	Bushing - 8x16x7	1
9	A232 2760	Housing - Paper Feed Unit	1
10	A232 2765	Front Grounding Plate	1
11	B004 2783	Torque Limiter	1
12	B004 2777	Shaft - Paper Separation	1
13	A232 2762	Paper End Feeler	1
14	B004 2782	Rear Feed Mylar	1
15	A232 2776	Release Lever	1
16	5206 2686	Snap Ring	3
17	AB01 0107	Gear - 23Z	2
18	A232 2770	Stay - Paper Separation	1
19	AB01 0106	Gear - 24Z	1
20	AA14 0656	Shaft - Gear	1
21	A232 2774	Pressure Lever	1
22	A232 2775	Link Lever	1
23	AA06 0864	Tension Spring	1
24	A232 2786	Guide Plate	1
25	A232 2787	Vertical Transport Guide	1
26	AA08 2072	Bushing - M6	3
27	A232 2764	Rear Grounding Plate	1
28	AA14 0655	Shaft - Paper Feed	1
29	AA08 3014	One-way Clutch	1
30	A232 5428	Harness - Paper Feed Unit	1
31	AW02 0056	Photointerrupter - EE-SX4235A-P1	2
32	AF02 0404	Transport Roller	1
33	A232 2780	Stay - Paper Feed	1
34	A232 2781	Sensor Bracket	1
35	AW02 0096	Photointerrupter	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AF03 2035	Separation Roller	1
37	AA06 0693	Tension Spring	1
38	B004 2750	Paper Feed Unit	1
39	AB01 4090	Gear - 18Z	1
40	A232 2766	Feed Mylar	1
41	A232 2785	Vertical Guide	1
101	0451 3008B	Tapping Screw - M3x8	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	
104	0805 3480	Bushing - 6mm	
105	0805 0089	Retaining Ring - M4	
106	1105 0283	Clamp	

13.PAPER REGISTRATION (B003/B004/B006/B007)




13.PAPER REGISTRATION (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 2365	Guide Rail - PCU	1
2	B004 2310	Spur	8
3	A232 2366	Holder - ID Sensor	1
4	A232 1284	Spring Holder	1
5	A232 2367	ID Sensor	1
6	A232 1072	Lower Stay - PCU	1
7	AF02 0410	Registration Roller	1
8	AF02 1059	Driven Registration Roller	1
9	A232 2574	Upper Entrance Guide	1
10	AA06 2305	Tension Spring	1
11	AA14 9291	Pin - Link	1
12	A232 2596	Link Lever	1
13	5206 2686	Snap Ring	1
14	A232 2594	Bracket - Registration Sensor	1
15	A232 2583	Lower Entrance Guide	1
16	A232 5420	Harness - Registration Sensor	1
17	AW01 0048	Photosensor - GP2A28N1	1
18	AD02 1127	Receptacle	1
19	AA06 3304	Terminal Spring	2
20	AA08 2080	Bushing - M8	2
21	AX20 0138	Electrical Clutch - MICE-13	1
22	AA08 0230	Rear Busing - M6	1
23	AA06 2304	Pressure Spring	2
24	B004 1165	Bracket - Timing Pulley	1
25	A232 2578	Stopper - Guide Plate	2
26	AA08 0229	Front Busing - M6	1
27	AB01 4051	Gear - 16Z	1
28	AG05 0085	Registration Roller Knob	1
29	AA06 6577	Torsion Spring	1
30	A232 3985	Link - Cover	1
31	B004 2575	Knob - Entrance Guide	1
32	AA00 1393	Decal - A2	1
33	AB01 3485	Gear - 20Z	1
34	AA04 3554	Timing Belt - B60S3M129	1
35	AB03 0669	Timing Pulley - Resistration	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	B004 1167	Flange - 24MM	2
101	0451 3006B	Tapping Screw - M3x6	
102	0353 0060B	Philips Pan Head Screw - M3x6	
103	0720 0060E	Retaining Ring - M6	
104	0720 0040E	Retaining Ring - M4	
105	1105 0283	Clamp	
106	0450 3008B	Tapping Screw - M3x8	
107	1102 6246	Relay Connector - 3P	
108	0313 0060B	Philips Pan Head Screw - M3x6	
109	0720 0020E	Retaining Ring - M2	

14.TONER HOPPER UNIT (B003/B004/B006/B007)




14.TONER HOPPER UNIT (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 3206	Toner Supply Unit	1
2	A232 3266	Seal - Slide Rail	2
3	B004 3262	Slide Rail-toner Supply	1
4	AA14 5810	Slide Shaft	1
5	A232 3261	Handle - Toner Supply	1
6	A232 3230	Case - Toner Supply Ass'y	1
7	A232 3263	Spring Plate - Toner Bottle	1
8	AA06 3623	Pressure Spring	1
9	A232 3251	Chuck Shaft	1
10	A232 3252	Slider Ass'y	1
11	A134 3180	Bottle Chuck	1
12	A232 3240	Cover- Toner Bottle Ass'y	1
13	AA15 3083	Seal - Toner Supply Unit Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3010B	Tapping Bind Screw - M3x10	
102	0450 3008B	Tapping Screw - M3x8	

15.PCU UNIT 1 (B003/B004/B006/B007)




15.PCU UNIT 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B004 7361	PCU	1
1	A232 2293	Handle - PCU	1
2	A232 2281	Cover - Cleaning Unit	1
3	A232 2420	Right Seal - Cleaning Cover	1
4	A232 2419	Left Seal - Cleaning Cover	1
5	AD04 3050	Toner Collection Coil	1
6	A232 2292	Bushing - Toner Collection Coil	1
7	AB01 1377	Gear - 14Z	1
8	A232 2289	Front Bushing - Collection Mylar	1
9	A232 2288	Shaft - Toner Collection Mylar	1
10	AD04 4000	Toner Collection Mylar	1
11	A232 2290	Bushing - Collection Mylar	1
12	AB01 1378	Gear - 19Z	1
13	G065 2290	Idler Bracket	1
14	AB01 1380	Cam - Cleaning Blade	1
15	AB01 1379	Gear - 19Z	1
16	A232 2322	Shield - Shutter - Toner Supply	1
17	A232 2403	Receptacle - Charge Roller	1
18	A232 2329	Stopper - PCU	1
19	A232 2408	Spring Plate	1
20	A232 2328	Cap - Toner Supply	1
21	A232 2323	Front Cover - PCU	1
22	A232 2417	Seal - 1x7x12.5	1
23	A232 2413	Seal - Front Lower	1
24	A232 2414	Seal - 2x20x45	1
25	A232 2416	Seal - 1x3x80	1
26	A232 2412	Seal - 2x7x14.5	1
27	AA06 2303	Tension Spring	1
28	A232 2321	Shutter - Toner Supply	1
29	B004 2211	Shield - Shutter - Middle	1
30	A232 7365	Upper Frame - PCU	1
31	A232 1284	Spring Holder	1
32	B004 2210	Shield - PCU - Upper Left	1
33	B004 2212	Front Seal - Cleaning Cover	1
34	A232 2277	Seal - Drum Front	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	A232 2278	Seal - Drum Rear	1
36	A232 2399	Seal - Blade 13x9.5x3	2
37	A232 2348	Seal - Blade 12x7x3	2
38	A232 2350	Seal - Entrance	2
39	A232 3267	Seal - Toner Supply-entrance-front	1
40	A232 2279	Seal - Toner Supply-entrance	1
101	0450 3008B	Tapping Screw - M3x8	
102	0720 0040E	Retaining Ring - M4	

16.PCU UNIT 2 (B003/B004/B006/B007)




16.PCU UNIT 2 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 2316	Stud - Cleaning Bracket	1
2	A232 2406	Lower Frame - OPC	1
3	AD02 5021	Pick-off Pawl	2
4	A232 2340	Holder - Pick-off Pawl	2
5	AA06 2310	Pressure Spring	2
6	A232 2339	Spur	2
7	A232 2280	Tape - Entrance Seal	1
8	AD04 7023	Cleaning Entrance Seal	1
9	A232 2356	Stepped Screw - M6	2
10	A232 2298	Bracket - Charge Cleaning	1
11	AA06 2301	Tension Spring	1
12	A232 2300	Roller - Cleaning	1
13	G065 2280	Cleaning Pad	1
14	5447 2681	Snap Ring	2
15	A232 2303	Front Arm - Charge Unit	1
16	AA06 3561	Pressure Spring	2
17	A232 2315	Front Bushing - Cleaning Bracket	1
18	AA06 2299	Pressure Spring	1
19	AA06 2300	Tension Spring	1
20	A232 2310	Bracket - Cleaning Blade	1
21	A232 2318	Collar - Cleaning	1
22	A232 2353	Cleaning Blade Ass'y	1
23	A232 2305	Rear Arm - Charge Unit	1
24	A232 2308	Rear Terminal - Charge Roller	1
25	A232 2421	Bushing - 6x10x3	2
26	AD02 7006	Charge Roller	1
27	A232 2354	Front Terminal - Charge Roller	1
28	A232 3553	Ball Bearing - 8x16x5	1
29	A230 9510	OPC Drum	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0451 3008B	Tapping Screw - M3x8	
103	0450 3006B	Tapping Screw - M3x6	
104	0450 4010B	Tapping Screw - 4x10	
105	0720 0040E	Retaining Ring - M4	
106	0720 0015E	Retaining Ring - 1.5	
107	0451 3006B	Tapping Screw - M3x6	

17. TRANSFER UNIT 1 (B003/B004/B006/B007)




17. TRANSFER UNIT 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B004 7270	Transfer Unit	1
1	B004 3900	Case - Transfer Unit	1
2	A232 3925	Front Bushing - Cleaning Holder	1
3	A232 3935	Shaft - Transfer Unit Stopper	1
4	A232 3916	Pressure Lever - Transfer Belt	2
5	A232 3911	Rear Lever - Transfer Belt	1
6	A232 3912	Front Lever - Transfer Belt	1
7	A232 3921	Spring Anchor	2
8	AA06 3305	Torsion Spring	2
9	AA15 0401	Seal - 70x20	2
10	AA06 0711	Pressure Spring	2
11	AW31 0006	Toner Overflow Sensor	1
12	AB01 4189	Gear - 27Z	1
13	A232 3924	Rear Bushing - Cleaning Holder	1
14	A232 3917	Release Lever - Transfer Belt	1
15	A232 3908	Seal - Rear Case	1
16	B004 3911	Mylar - Remove Paper Dust	1
17	A232 3903	Tape - Entrance Mylar	1
18	A232 3905	Seal - Shield Plate	1
19	A232 3907	Seal - Transfer Exit	1
20	A232 3923	Bracket - Cleaning Blade	1
21	A232 3830	Cleaning Blade - Transfer Belt	1
22	A232 3909	Seal - Front Case	1
23	A232 3880	Transfer Belt	1
24	A232 3894	Drive Roller - Transfer Belt	1
25	A232 3893	Arm - Transfer Belt	2
26	AA08 0246	Bushing - Bias Roller	1
27	AA06 0712	Torsion Spring	2
28	A232 3889	Bias Roller	1
29	A232 3885	Driven Roller - Transfer Unit	1
30	A232 3883	Spring Plate - Transfer Unit	1
31	A232 3887	Rear Terminal - Transfer Belt	1
32	AA08 2054	Bushing - M4	1
33	A232 3891	Bias Terminal	1
34	AB01 1190	Gear - 25Z	1


Index No.	Part No.	Description	Q'ty Per Assembly
35	A232 3882	Frange - Transfer Unit	1
36	A232 3906	Seal - Rear Transfer Exit	1
37	B004 3915	Entrance Mylar - Transfer Unit	1
38	A232 3926	Transfer Belt Roller	2
39	A232 3927	Shield - Transfer Belt - Exit	2
40	B004 3914	Mylar - Belt Drive Roller	1
101	0451 3006B	Tapping Screw - M3x6	
102	0951 3006B	Philips Screw With Flat Washer - M3x6	
103	0450 3008B	Tapping Screw - M3x8	

18.TRANSFER UNIT 2 (B003/B004/B006/B007)





19.DEVELOPMENT UNIT (B003/B004/B006/B007)




19.DEVELOPMENT UNIT (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 7460	Development Unit	1
2	A232 3155	Front Cover - Development Unit	1
3	AB01 4061	Gear - 13Z	1
4	AB01 4060	Gear - 21Z	1
5	AB01 4062	Gear - 17Z/25Z	1
6	AA15 3052	Entrance Seal - Toner Supply	1
7	AA14 3219	Stepped Screw	2
8	A232 3132	Rear Shield - Development Sleeve	1
9	B004 3100	Development Roller Ass'y	1
10	A232 3131	Front Shield - Development Sleeve	1
11	AB01 1384	Gear - 29Z	1
12	AB01 1386	Development Sleeve Gear	1
13	5206 2686	Snap Ring	2
14	A232 3150	Entrance Seal Ass'y	1
15	AA01 2102	Development Filter	1
16	B004 3078	Joint - Paddle	1
17	A232 3067	Tape - TD Sensor	1
18	B004 3065	TD Sensor	1
19	A232 3068	Front Bias Terminal - Development	1
20	A232 3069	Rear Bias Terminal - Development	1
21	A232 3096	Flange - Side Plate	1
22	A232 3081	Flange - Paddle	1
23	B004 3056	Lower Development Case	1
24	AD03 8078	Paddle	1
25	B004 3062	Ground Plate- Doctor Blade	1
26	AA15 3062	Sponge - M46	1
27	AA15 3054	Sponge - 17x7x5	2
28	AA15 3053	Sponge - 317x5x5	1
29	AA15 3077	Shield Case - Development	2
30	AA08 0234	Bushing - 12x18x6	1
31	A232 3066	Decal - Development Unit	1
32	AA15 2283	Ring - M12	2
33	A232 3077	Spacer - M5	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3010B	Tapping Screw - M3x10	
102	0720 0030E	Retaining Ring - M3	
103	0725 0110E	C Ring - M11	
104	0720 0040E	Retaining Ring - M4	
105	0450 3008B	Tapping Screw - M3x8	
106	0450 3010B	Tapping Screw - M3x10	

20.FUSING UNIT (B003/B004/B006/B007)




20.FUSING UNIT (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 7320	Fusing Unit (115V)	1
1	B004 7720	Fusing Unit (230V)	1
2	AA14 3520	Shoulder Screw - M3	2
3	B004 4131	Fusing Cover	1
4	B004 4135	Guide Plate-fusing Exit	1
5	B004 4111	Front Heater Socket	1
6	AE04 4030	Hot Roller Stripper	7
7	AA06 0879	Tension Spring	7
8	B004 4105	Housing - Thermostat	2
9	B004 4115	Rear Heater Socket	1
10	B004 4081	Upper Frame - Fusing Unit	1
11	AW10 0053	Thermistor - Rear	1
12	B004 4106	Thermostat	1
13	B004 4055	Stay - Thermostat	1
14	AX43 0063	Heater - 120V 550W 335mm	1
14	AX43 0064	Heater - 230V 550W 335mm	1
15	A232 4064	C Ring - Hot Roller	2
16	AE03 0047	Ball Bearing - 30x42x7	2
17	AE01 1064	Hot Roller - 39.8mm T0.4	1
18	AB01 3882	Gear - 40Z	1
19	AG05 0090	Knob - Hot Roller	1
20	B004 4133	Cap- Fusing Cover	1
21	AE03 0048	Ball Bearing - 8x22x7	2
22	AE02 0108	Pressure Roller	1
23	A232 4059	Positioning Plate - Pressure Lever	1
24	A232 4057	Front Collar - Pressure Lever	1
25	B004 4056	Pressure Lever	2
26	AA06 0840	Pressure Spring - 29N	2
27	A232 4053	Fusing Lower Shield	1
28	A232 4051	Frame - Fusing Unit	1
29	AB01 4046	Gear - 25Z	1
30	A232 4058	Rear Collar - Pressure Lever	1
31	B004 4095	Terminal Plate - Fusing Unit	1
32	B004 4092	Bracket- Fusing Connector	1
33	B004 4117	Harness- Fusing Unit (120V)	1


Index No.	Part No.	Description	Q'ty Per Assembly
33	B004 4127	Harness- Fusing Unit (230V)	1
34	AA14 0140	Screw - M3X4.5	2
35	AE04 2039	Fusing Cleaning Roller	1
36	AA08 2073	Roller Busing	2
37	AA06 3570	Tension Spring	2
38	A232 4123	Upper Fusing Entrance Guide	1
39	B004 4126	Lower Entrance Guide Plate	1
40	B004 4087	Plate- Thermistor	2
41	AW10 0052	Thermistor - Center	1
42	AX44 0128	Heater - 120V 650W 215mm	1
42	AX44 0129	Heater - 230V 650W 215mm	1
101	0451 3006B	Tapping Screw - M3x6	
102	0451 3008B	Tapping Screw - M3x8	
103	0954 3012B	Screw - M3X12	
104	0801 0149	Philips Pan Head Screw - M4x6	
105	0720 0030E	Retaining Ring - M3	
106	0804 6075	Hexagonal Bolt - M3x8	
107	0957 3012B	Double Sems Screw - M3 X 12	
108	0451 3006B	Tapping Screw - M3x6	

21.PAPER SEPARATION UNIT (B003/B004/B006/B007)





22.DUPLEX UNIT 1 (B003/B004/B006/B007)




22.DUPLEX UNIT 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 4720	Inner Cover - Duplex Unit	1
2	B004 4852	Decal - Duplex Jam	1
3	AF02 0511	Reverse Roller - Driven	1
4	B004 4645	Guide Plate - Middle	1
5	5447 2681	Snap Ring	1
6	A232 4730	Rear Inner Cover	1
7	A232 4810	Harness Cover - Duplex Unit	1
8	A232 4793	Bracket - Link Lever	1
9	A232 4653	Pressure Plate - Guide Plate	2
10	AA08 0034	Bushing - 4x5x7	4
11	B004 4711	Right Cover - Duplex Unit	1
12	B004 4851	Decal - Jam Removal	1
13	A232 4647	Driven Guide Plate	1
14	AF02 5036	Duplex Junction Gate	1
15	AA06 0709	Tension Spring	1
16	AA06 3303	Pressure Spring	4
17	AF02 0512	Driven Roller - Duplex	2
18	B004 4701	Duplex Unit Cover	1
19	A680 1181	Magnetic Catch	2
20	B004 4710	Right Cover - Duplex Unit	1
21	B004 4853	Upper Decal - Duplex Unit	1
22	AA06 0839	Pressure Spring - Driven	2
23	AA08 0227	Bushing - M4	2
24	B004 5843	Shoulder Screw	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008H	Tapping Screw - M3x8	
102	0451 3006B	Tapping Screw - M3x6	
103	0450 3008H	Tapping Screw M3x8	

23.DUPLEX UNIT 2 (B003/B004/B006/B007)




23.DUPLEX UNIT 2 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2074	Bushing - M8	4
2	A232 4684	Handle - Unit Release	1
3	AW01 0048	Photosensor - GP2A28N1	1
4	AA06 6152	Tension Spring	1
5	A232 4685	Hook - Unit Release	1
6	B004 4763	Bracket - Entrance Sensor	1
7	AA16 2046	Cushion - 347x10x5	1
8	B004 4634	Guide Plate - Reverse	1
9	AF02 0511	Reverse Roller - Driven	1
10	AA08 0227	Bushing - M4	2
11	AA06 0839	Pressure Spring - Driven	2
12	AF02 0509	Reverse Roller - Duplex	2
13	B004 4642	Side Plate-rear	1
14	B004 4800	Main Board Bracket	1
15	B004 5140	Main Board - Duplex	1
16	B004 5460	Main Harness - Duplex Unit	1
17	B004 5461	Sensor Harness - Duplex Unit	1
18	AB03 0670	Gear - 24Z	1
19	AB01 4162	Gear - 46Z	1
20	AA04 3443	Timing Belt - S2M 140	1
21	B004 4666	Bracket - Inverter Motor	1
22	B004 4664	DC Motor - 28W	1
23	AB01 4161	Reverse Roller Gear	2
24	B004 4690	Link Solenoid Ass'y	1
25	B004 4638	Frontside Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	1105 0460	Clamp	
104	0451 3006B	Tapping Screw - M3x6	
105	0720 0030E	Retaining Ring - M3	
106	1204 2466	Micro Switch - V-16506-1c25	
107	0353 0120B	Bind Screw - M3x12	
108	1105 0328	Harness Clamp - ES-0505	

24.DUPLEX UNIT 3 (B003/B004/B006/B007)




24.DUPLEX UNIT 3 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA04 3444	Timing Belt - S2M 350	1
2	AB03 0474	Pulley - 24T	2
3	AA08 2075	Bushing - M6	2
4	AF02 0510	Exit Transport Roller	1
5	B004 4622	Guide Plate - Right Lower	1
6	AF02 0513	Transport Roller	1
7	B004 4630	Lower Stay - Duplex	1
8	A232 4757	Bracket - Feed Sensor	1
9	AW02 0102	Photointerrupter	1
10	AA04 3443	Timing Belt - S2M 140	1
11	AB03 0671	Gear Pulley - Rransport	1
12	B004 4678	Bracket - Feed Motor	1
13	AB01 1088	Gear - 30Z	1
14	B004 4664	DC Motor - 28W	1
15	AW02 0056	Photointerrupter - EE-SX4235A-P1	1
16	B004 4791	Sensor Bracket	1
17	AA06 6335	Torsion Spring	1
18	B004 4697	Micro Switch Bracket	1
19	AA14 3461	Stepped Screw - M2.5	1
20	A232 4790	Link - Duplex Unit	1
21	B004 4792	Middle Stay	1
22	B004 5462	Sensor Harness	1


Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 3480	Bushing - 6mm	
102	0451 3006B	Tapping Screw - M3x6	
103	1105 0291	Harness Clamp - LWS-3S	
104	1105 0328	Harness Clamp - ES-0505	
105	0802 5276	Tapping Screw With Washer - M3x6	
106	0720 0040E	Retaining Ring - M4	
107	1105 0283	Clamp	
108	1204 2466	Micro Switch - V-16506-1c25	
109	0313 0060B	Philips Pan Head Screw - M3x6	

25.DRIVE SECTION 1 (B003/B004/B006/B007)



57

26.DRIVE SECTION 2 (B003/B004/B006/B007)




26.DRIVE SECTION 2 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX20 0231	Magnetic Clutch - 0.5N M-28Z	2
2	AB01 4219	Gear - 24Z	2
3	AB03 0625	Timing Pulley - 20Z	2
4	AA04 3445	Timing Belt - S3M-360	1
5	AB01 4160	Idler Gear-registration	1
6	A232 2692	Cover - Paper Drive	1
7	B004 5453	Drawer Harness - Development	1
8	B004 5455	Harness - Paper Size Sensor	1
9	AB01 4038	Gear - 22Z	2
10	B004 1938	Holder - Optical Housing Unit	1
11	AA04 3446	Timing Belt - S3M-312	1
12	A232 2705	Tightener - Paper Feed	1
13	AA06 0694	Tension Spring	1
14	AB03 0562	Timing Pulley - 31Z/20T	1
15	B004 1177	Spacer - By-pass Feed	1
16	AB03 0590	Pulley - M17	2
17	AB03 0561	Timing Pulley - 31Z/20T	2
18	AX04 0078	DC Motor - 3W	1
19	AX20 0138	Electrical Clutch - MICE-13	1
20	B004 5130	pFB Board	1
21	AB01 4039	Gear - 31Z	1
22	A232 5405	Main Harness - Paper Feed	1
23	AB01 4040	Gear - 29Z	1
24	B004 1179	Lower Holder Plate	1
25	B004 1162	Upper Holder Plate	1
26	A232 2882	Bracket - Micro Switch	1
27	B004 1172	Support Bracket	1
28	AB03 0567	Timing Pulley - 18T	1
29	A232 3552	Ball Bearing - 8x22x7	2
30	AA14 9515	Gear Shaft	1
31	B004 1163	Pulley Bracket	1
32	AB03 0566	Timing Pulley - 20T	1
33	B004 1169	Tightener	1
34	AA06 0695	Tension Spring	1
35	B004 5457	Safety Switch Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AX06 0207	Feed/dev. Motor - DC 30W (B004/B007)	1
36	AX06 0208	Feed/dev. Motor - DC 24W (B003/B006)	1
37	B004 1321	Shield Plate - BICU	1
38	B004 1320	Base Cover	1
39	B004 1939	Holder - Optical Housing Unit	1
40	B004 1936	Plate - Optical Housing Unit	2
41	AB01 4159	Gear - 49Z	1
42	B004 1322	Shield Plate - DC Motor	1
43	AB01 4164	Gear - 28T	1
44	AA14 3301	Stepped Screw - M3x4	2
45	G020 2620	Push Switch - Paper Size	1
101	0805 3480	Bushing - 6mm	
102	0720 0060E	Retaining Ring - M6	
103	1204 2466	Micro Switch - V-16506-1c25	
104	0451 3014B	Tapping Screw - M3-14	
105	1105 0267	Harness Clamp - YMC-10-0	
106	0451 3006B	Tapping Screw - M3x6	
107	1102 7672	Connector - 54111-1615	
108	0451 3008H	Tapping Screw - M3x8	

27.ELECTRICAL SECTION 1 (B003/B004/B006/B007)




27.ELECTRICAL SECTION 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX64 0113	Fan Motor - 80mm	2
2	A232 1172	Duct - Cooling Fan	1
3	A232 1170	Left Duct	1
3	G034 1170	Duct - Main Frame - Left (GSA)	1
4	A232 1171	Right Duct	1
5	AZ32 0086	High Voltage Supply - Cbt	1
6	B004 5812	Bracket - High Voltage Supply	1
7	B004 1082	Support Plate - Scanner Arm	1
8	B004 1936	Plate - Optical Housing Unit	1
9	B004 5897	Bracket - Connector	1
10	B004 5811	Bracket - High Voltage Supply	1
11	B004 5520	Harness - DC Power Supply	1
12	B004 5611	Harness - Heater	1
13	A232 5526	Power Supply Cord - 115V	1
13	A232 5527	Power Supply Cord - 230V	1
13	A232 5528	Power Supply Cord - 230V (CHN)	1
14	AZ24 0060	Power Supply Unit - 115V 302W (NA/TWN)	1
14	AZ24 0061	Power Supply Unit - 230V 302W (EU/Asia)	1
14	AZ24 0062	Power Supply Unit - 230V 302W (CHN)	1
15	B004 5457	Safety Switch Harness	1
16	B004 5898	Bracket - Power Supply Cord	1
17	A232 5410	Connector - Finisher	1
18	A232 7757	Bracket - Circuit Breaker	1
19	A232 7756	Harness - Circuit Breaker	1
20	N607 4540	Choke Coil - RITL-9901 (120V)	1
20	N607 4542	Choke Coil - RITL-0006 (230V)	1
21	N607 6527	Fan Motor - DC 0.96W	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0291	Harness Clamp - LWS-3S	
102	0451 3006B	Tapping Screw - M3x6	
103	1105 0310	Harness Clamp - LWS-1S	
105	0451 3008H	Tapping Screw - M3x8	
106	1107 0472	Circuit Breaker - W28xQ1A 8A 25V	
107	0801 0149	Philips Pan Head Screw - M4x6	
108	1105 0437	Locking Support - FGS-4S	
109	0450 4035B	Philips Tapping Screw - M4x35	
110	1107 0907	Fuse - 6.3A 125V (120V)	
110	1107 0920	Fuse - 6.3A 250V (230V)	
111	1107 0908	Fuse - 10A 125V (120V)	
111	1107 0979	Fuse - LM20 TOMEI	
112	1107 0629	Fuse (Ceramic Case) - 15A - 125V	
113	1107 0910	Fuse - 2A 125V (120V)	
113	1107 0922	Fuse - 2A 250V (230V)	

28.ELECTRICAL SECTION 2 (B003/B004/B006/B007)




28.ELECTRICAL SECTION 2 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 5403	Harness - IOB / pFB	1
2	B004 5451	DC Harness - Front Lower	1
3	B004 5452	DC Harness - Front Upper	1
4	B004 5125	IOB Board	1
5	B004 5831	Bracket - IOB	1
6	B004 5055	BICU Board	1
7	B004 5520	Harness - DC Power Supply	1
8	B004 5291	Harness - Laser Diord Control	1
9	B004 5450	DC Main Harness - Upper	1
10	B004 5825	Connector Bracket	1
11	B004 5608	Main Harness - Fusing Unit (230V)	1
11	B004 5609	Main Harness - Fusing Unit (120V)	1
12	A232 5861	Lever - Interlock Switch	1
13	A232 5860	Bracket - Interlock Switch	1
14	AA14 3512	Stepped Screw - M2.5	4
15	B004 5866	Bracket - Power Switch	1
16	A232 5862	Cover - Switch Lever	1
17	B004 5021	Safety & Power Switch Ass'y	1
18	A232 5865	Lever - Push Switch	1
19	B004 5606	Harness - AC Switch	1
20	AA14 3301	Stepped Screw - M3x4	2
21	AA06 0713	Tension Spring	1
22	B004 5024	Safety Switch Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1204 2466	Micro Switch - V-16506-1C25	
102	1204 2477	Locker Switch - AC250V 10A	
103	1204 2521	Micro Switch	
104	0451 3006B	Tapping Screw - M3x6	
105	0950 4006M	Philips Screw With Flat Washer - M4x6	
107	1102 6261	Relay Connector - 4P	
108	1102 6249	Relay Connector - 6P	
109	1102 6246	Relay Connector - 3P	
110	1102 6260	Relay Connector - 3P	
111	1102 6263	Connector - 6P	
112	1102 6245	Relay Connector - 2P	
113	1102 6943	Relay Connector -10p	
114	1102 6266	Relay Connector - 9P	
115	1102 6256	Relay Connector - 13P	

29.FRAME SECTION 1 (B003/B004/B006/B007)




29.FRAME SECTION 1 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 1082	Left Stay - Paper Exit	1
2	A232 1083	Bracket - Bridge Unit	1
3	A232 1081	Center Frame	1
4	AA15 0684	Shield Plate	1
5	A232 1089	Upper Plate - Laser Unit	1
6	B004 3210	Guide - Toner Supply Unit	1
7	B004 3215	Toner Bottle Holder	1
8	A232 2362	Stay - PCU	1
9	A267 3455	Magnetic - Discharge Lamp	1
10	AX50 0046	Quenching Lamp	1
11	A232 1075	Guide Rail - Fusing Unit	1
12	A232 4201	Stopper - Fusing Unit	1
13	B004 4122	Decal - Warning (High Temperature)	1
14	A232 1071	Guide Rail - Development Unit	1
15	5206 2686	Snap Ring	1
16	G034 1971	Sheet - Shading Plate	1
17	B004 1969	Shield Plate - LDDR	1
18	A284 1021	Shield - Stay - PCU - Lower	1
19	AA15 3442	Shield - Stay - PCU	1
20	A232 4780	Pin - Stopper	1
21	B004 1081	Bracket - Fusing Connector	1
22	A232 1072	Lower Stay - PCU	1
23	A232 1937	Positing Pin - Laser Unit Ass'y	1
24	B004 1968	Shield Plate Ass'y - LDDR	1
25	A232 3264	Stopper - Slide Rail	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 3008B	Tapping Screw - M3x8	
103	1105 0349	Edge Saddle	
104	1105 0267	Harness Clamp - YMC-10-0	
105	1105 0290	Harness Clamp - Horizontal	
106	1105 0291	Harness Clamp - LWS-3S	

30.FRAME SECTION 2 (B003/B004/B006/B007)




30.FRAME SECTION 2 (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 1266	Left Hinge - Front Cover	1
2	A232 1177	Development Bracket	1
3	B004 1176	Lower Development Bracket	1
4	A230 2699	Stopper - Front Grip	1
5	A230 2696	Front Grip	1
6	B004 2995	Cap - Positioning	2
7	A232 2995	Front Positioning Guide	2
8	A232 2990	Guide Rail - Paper Tray	2
9	AH01 0009	Rubber Pad - H5	4
10	A232 1267	Right Hinge - Front Cover	1
11	B004 1089	Stay - Rear	1
12	A232 2996	Rear Positioning Guide	1
13	A230 2525	Stopper - Heater	1
14	AX40 0137	Heater - 120V 9W	1
14	AX40 0138	Heater - 230V 9W	1
15	A230 2520	Heat Sink - Heater	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	1105 0488	Harness Clamp	
103	0451 4006B	Tapping Screw - 4x6	
104	1105 0487	Harness Clamp	
105	1105 0349	Edge Saddle	
106	1105 0267	Harness Clamp - YMC-10-0	

31.EXPANTION BOX (B003/B004/B006/B007)



31.EXPANTION BOX (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 5192	Mother Board	1
2	B004 5871	Expansion Box	1
3	B004 5876	Stay - Rack	1
4	B004 5885	Rack Panel	1
5	A284 5842	Gasket - Rack	1
6	B004 5850	Bracket - Control Board (B003/B004)	1
6	B007 5850	Bracket - Control Board (B006/B007)	1
7	B004 5854	Connector Cover	1
8	A285 5893	Card Cover	1
9	B004 5890	Bracket - HDD - Ass'y	1
10	AA16 1125	Rubber Cushion	4
11	B004 5893	HDD - 20G Byte	1
12	B004 5475	Harness - HDD	1
13	B004 5476	DC Power Harness	1
14	AA14 3499	Stepped Screw	4
15	B004 5845	Control Board A'ssy	1
16	B004 5100	Control Board	1
17	B004 9099	NVRAM - Minus Counter	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	

32.IOB BOARD (B003/B004/B006/B007)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C101	193	C111	187	C121	189	C131	193	C141	189	C151	190	C161	192
C102	193	C112	186	C122	186	C132	186	C142	193	C152	190	C162	190
C103	186	C113	193	C123	187	C133	193	C143	193	C153	190	C163	193
C104	186	C114	193	C124	186	C134	190	C144	193	C154	190	C164	190
C105	186	C115	184	C125	187	C135	186	C145	193	C155	190	C165	190
C106	186	C116	193	C126	193	C136	193	C146	190	C156	190	C166	193
C107	186	C117	193	C127	193	C137	192	C147	193	C157	192	C167	189
C108	193	C118	193	C128	193	C138	185	C148	190	C158	190	C168	192
C109	193	C119	186	C129	193	C139	186	C149	190	C159	192	C169	193
C110	186	C120	189	C130	186	C140	186	C150	190	C160	192	C170	193

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C171	189	C181	190	C191	190	C201	192	C211	192	C221	190	C231	193
C172	192	C182	192	C192	193	C202	192	C212	193	C222	190	C232	193
C173	190	C183	190	C193	190	C203	190	C213	189	C223	190	C233	193
C174	190	C184	192	C194	193	C204	190	C214	189	C224	190	C234	191
C175	190	C185	192	C195	190	C205	190	C215	192	C225	190	C235	189
C176	189	C186	193	C196	190	C206	190	C216	193	C226	192	C236	193
C177	189	C187	193	C197	190	C207	193	C217	193	C227	190	C237	189
C178	193	C188	193	C198	190	C208	191	C218	193	C228	193	C238	193
C179	193	C189	189	C199	193	C209	193	C219	189	C229	190	C239	192
C180	190	C190	192	C200	192	C210	193	C220	190	C230	190	C240	189

32.IOB BOARD (B003/B004/B006/B007)

CAPACITOR

SYMBOL NO.	INDEX NO.
C241	189
C242	191
C243	193
C244	193
C245	193
C246	192
C247	190
C248	190
C249	192
C250	190

SYMBOL NO.	INDEX NO.
C251	190
C252	193
C253	189
C254	189
C255	193
C256	192
C257	193
C258	193
C259	192
C260	193

SYMBOL NO.	INDEX NO.
C261	192
C262	193
C263	192
C264	190
C265	188
C266	192
C267	190
C268	190
C269	190
C270	190

SYMBOL NO.	INDEX NO.
C271	193
C272	190
C273	190
C274	193
C275	190
C276	190

CONNECTOR

SYMBOL NO.	INDEX NO.
CN101	122
CN102	123
CN103	120
CN104	109
CN105	105
CN106	117
CN107	106
CN108	108
CN109	119
CN110	113

SYMBOL NO.	INDEX NO.
CN111	106
CN112	116
CN113	106
CN114	111
CN115	108
CN116	115
CN117	124
CN118	112
CN119	107
CN120	102

SYMBOL NO.	INDEX NO.
CN121	112
CN122	104
CN123	103
CN124	121
CN125	102
CN126	107
CN127	102
CN128	114
CN129	118
CN130	107

CONNECTOR

SYMBOL NO.	INDEX NO.
CN131	111
CN132	109
CN133	110
CN134	103

DIODE

SYMBOL NO.	INDEX NO.
D101	134
D102	134
D103	134
D104	136
D105	136
D106	134
D107	136
D108	134
D109	134
D110	136

SYMBOL NO.	INDEX NO.
D111	136
D112	136
D113	136

DIP SWITCH

SYMBOL NO.	INDEX NO.
DPS101	128

FB

SYMBOL NO.	INDEX NO.
FB101	157
FB102	157
FB103	157
FB104	157
FB105	157
FB106	157
FB107	157
FB108	157
FB109	157
FB110	157

SYMBOL NO.	INDEX NO.
FB111	157
FB112	157
FB113	157
FB114	157

FUSE

SYMBOL NO.	INDEX NO.
FU101 (Holder)	127
	125

IC

SYMBOL NO.	INDEX NO.
IC101	141
IC102	143
IC103	152
IC104	142
IC105	146
IC106	146
IC107	150
IC108	138
IC109	138
IC110	150

SYMBOL NO.	INDEX NO.
IC111	150
IC112	2
(IC112)	126
IC113	145
IC114	145
IC115	145
IC116	145
IC117	147
IC118	151
IC119	139
IC120	148

32.IOB BOARD (B003/B004/B006/B007)

IC

SYMBOL NO.	INDEX NO.
IC121	1
IC122	152
IC123	152
IC124	152
IC125	152
IC126	149
IC127	141
IC128	152
IC129	152
IC130	140

PC

SYMBOL NO.	INDEX NO.
IC131	143
IC132	143
IC133	144

OSC

SYMBOL NO.	INDEX NO.
OSC101	153

PC

SYMBOL NO.	INDEX NO.
PC101	137
PC102	137
PC103	137
PC104	137

Q

SYMBOL NO.	INDEX NO.
Q101	130
Q102	130
Q103	130
Q104	131
Q105	132
Q106	132
Q107	131
Q108	131
Q109	132
Q110	129

RESISTOR

SYMBOL NO.	INDEX NO.
R101	176
R102	176
R103	181
R104	181
R105	181
R106	181
R107	181
R108	181
R109	181
R110	181

SYMBOL NO.	INDEX NO.
R111	181
R112	181
R113	181
R114	181
R115	181
R116	181
R117	181
R118	181
R119	181
R120	181

SYMBOL NO.	INDEX NO.
R121	181
R122	181
R123	181
R124	181
R125	181
R126	181
R127	181
R128	181
R129	181
R130	181

RESISTOR

SYMBOL NO.	INDEX NO.
R131	181
R132	176
R133	176
R134	176
R135	176
R136	176
R137	183
R138	183
R139	171
R140	176

SYMBOL NO.	INDEX NO.
R141	176
R142	183
R143	183
R144	183
R145	183
R146	176
R147	161
R148	176
R149	170
R150	161

SYMBOL NO.	INDEX NO.
R151	169
R152	164
R153	164
R154	164
R155	170
R156	170
R157	170
R158	164
R159	164
R160	170

SYMBOL NO.	INDEX NO.
R161	170
R162	170
R163	170
R164	164
R165	170
R166	170
R167	164
R168	164
R169	158
R170	158

SYMBOL NO.	INDEX NO.
R171	170
R172	170
R173	170
R174	170
R175	170
R176	170
R177	170
R178	180
R179	177
R180	160

SYMBOL NO.	INDEX NO.
R181	162
R182	158
R183	162
R184	160
R185	159
R186	159
R187	162
R188	160
R189	161
R190	164

SYMBOL NO.	INDEX NO.
R191	164
R192	164
R193	164
R194	164
R195	164
R196	164
R197	164
R198	176
R199	158
R200	176

32.IOB BOARD (B003/B004/B006/B007)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R201	176	R211	174	R221	165	R231	170	R241	177	R251	167	R261	163
R202	159	R212	159	R222	165	R232	170	R242	170	R252	165	R262	169
R203	165	R213	176	R223	176	R233	170	R243	170	R253	180	R263	176
R204	165	R214	176	R224	176	R234	170	R244	165	R254	177	R264	176
R205	174	R215	165	R225	180	R235	164	R245	165	R255	164	R265	170
R206	168	R216	175	R226	177	R236	176	R246	165	R256	170	R266	170
R207	182	R217	165	R227	170	R237	176	R247	167	R257	176	R267	170
R208	182	R218	176	R228	170	R238	176	R248	165	R258	178	R268	170
R209	179	R219	173	R229	170	R239	176	R249	165	R259	166	R269	164
R210	182	R220	165	R230	170	R240	180	R250	176	R260	176	R270	170

RESISTOR

SYMBOL NO.	INDEX NO.
R271	172
R272	172
R273	165
R274	165
R275	164
R276	164
R277	170
R278	170
R279	170

RAY

SYMBOL NO.	INDEX NO.
RAY101	156
RAY102	156
RAY103	154
RAY104	156
RAY105	154
RAY106	154
RAY107	154
RAY108	154
RAY109	154
RAY110	154

SYMBOL NO.	INDEX NO.
RAY111	156
RAY112	154
RAY113	154
RAY114	154
RAY115	154
RAY116	155
RAY117	155
RAY118	154
RAY119	155
RAY120	156

SYMBOL NO.	INDEX NO.
RAY121	156
RAY122	156
RAY123	156
RAY124	154
RAY125	154
RAY126	156
RAY127	156

TP

SYMBOL NO.	INDEX NO.
TP101	101
TP102	101
TP103	101
TP104	101

ZD

SYMBOL NO.	INDEX NO.
ZD101	133
ZD102	133
ZD103	135

32.IOB BOARD (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B004 5125	IOB Board	1
1	A232 5355	IC - GATEX	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 3822	Connector - 20P	
102	1102 5306	Connector - 7P	
103	1102 6299	Connector - 6P	
104	1102 6301	Connector - 8P	
105	1102 6306	Connector - 13P	
106	1102 6311	Connector - 4P	
107	1102 6319	Connector - 12P	
108	1102 6334	Connector - 3P	
109	1102 6339	Connector - 8P	
110	1102 6341	Connector - 10P	
111	1102 6342	Connector - 11P	
112	1102 6354	Connector	
113	1102 6396	Connector - 1P	
114	1102 6401	Connector - 26P	
115	1102 6402	Connector - 2P	
116	1102 6896	Connector - 50P	
117	1102 7700	Connector - 50P	
118	1204 2480	Dip Switch - Dss808	
119	1400 0398	Transistor - 2SC2412K	
120	1400 0556	Transistor - DTB143EK	
121	1402 1142	Diode Array - DAN217	
122	1402 1322	Diode Array - DAN202U	
123	1402 1336	Diode - 1SS355	
124	1402 1378	Diode - PTZ12A	
125	1402 1380	Diode - PTZ 6.2A	
126	1402 1572	Diode - HZU3ALL	
127	1404 0360	Thermistor - 103HT	
128	1407 1535	IC - TD62308AP	
129	1407 1596	TTLIC - SN74LS14NS	
130	1407 1880	TTLIC - SN74LS04NS	
131	1407 2187	TTLIC - SN74LS07NS	
132	1407 2219	IC - TD62003AP	
133	1407 3290	IC - TC74HC02AF	
134	1407 4687	IC - TA8083F	
135	1407 5085	IC - TC4066BF(N)	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1408 1065	Comparator BA10339F	
137	1408 1095	IC - BA10324AF	
138	1503 0865	Oscillator - 9.8304MHZ	
139	1601 5414	Resistor - 330 Ω $\pm$ 5% 1W	
140	1601 7752	Resistor Array - 10K Ω $\pm$ 5%	
141	1601 7791	Resistor Array - 1K Ω $\pm$ 5%	
142	1630 1221	Resistor - 220 Ω $\pm$ 5% 1/4W	
143	1630 2221	Resistor - 220 Ω	
144	1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	
145	1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	
146	1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	
147	1630 4104	Resistor - 100 Ω $\pm$ 5% 1/16W	
148	1630 4105	Resistor - 1.0M Ω $\pm$ 5% 1/16W	
149	1630 4161	Resistor - 160 Ω $\pm$ 5% 1/16W	
150	1630 4204	Resistor - 200K Ω $\pm$ 5% 1/16W	
151	1630 4222	Resistor - 2.2K Ω $\pm$ 5%	
152	1630 4223	Resistor - 22K Ω $\pm$ 5% 1/16W	
153	1630 4472	Resistor - 4.7K Ω $\pm$ 5% 1/16W	
154	1630 4562	Resistor - 5.6k Ω - $\pm$ 5% - 1/16W	
155	1630 4681	Resistor - 680 Ω $\pm$ 5% 1/16W	
156	1630 4821	Resistor - 820 Ω $\pm$ 5% 1/16W	
157	1631 1000	Resistor - 100 Ω $\pm$ 1% 1/4W	
158	1634 1002	Resistor - 10 Ω $\pm$ 5% 1/16W	
159	1634 1003	Resistor - 100K Ω $\pm$ 1% 1/16W	
160	1634 1403	Resistor - 140k Ω $\pm$ 1% 1/16W	
161	1634 2002	Resistor - 20K Ω $\pm$ 1% 1/16W	
162	1634 2401	Resistor - 2.4K Ω $\pm$ 1% 1/16W	
163	1634 2402	Resistor - 24K Ω $\pm$ 1% 1/16W	
164	1634 4641	Resistor - 4.64k Ω $\pm$ 1% 1/16W	
165	1634 5621	Resistor - 5.62k Ω $\pm$ 1% 1/16W	
166	1640 2470	Capacitor - 47 μ F $\pm$ 20% 25V	
167	1640 5101	Capacitor - 100 μ F $\pm$ 20% 50V	
168	1642 5330	Capacitor - 33 μ F $\pm$ 20% 50V	
169	1660 2101	Capacitor - 100pF - $\pm$ 10% - 50V	

Index No.	Part No.	Description	Q'ty Per Assembly
170	1660 2270	Capacitor - 27pF $\pm$ 20% 35V	
171	1660 2471	Capacitor - 470pF - $\pm$ 5% - 50V	
172	1660 4102	Capacitor - 1000pF $\pm$ 10% 50V	
173	1660 4472	Capacitor - 4700pF $\pm$ 10% 50V	
174	1660 6103	Capacitor - 10000pF - +80%-20%50V	
175	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	

33.BICU BOARD (B003/B004/B006/B007)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C101	193	C111	187	C121	189	C131	193	C141	189	C151	190	C161	192
C102	193	C112	186	C122	186	C132	186	C142	193	C152	190	C162	190
C103	186	C113	193	C123	187	C133	193	C143	193	C153	190	C163	193
C104	186	C114	193	C124	186	C134	190	C144	193	C154	190	C164	190
C105	186	C115	184	C125	187	C135	186	C145	193	C155	190	C165	190
C106	186	C116	193	C126	193	C136	193	C146	190	C156	190	C166	193
C107	186	C117	193	C127	193	C137	192	C147	193	C157	192	C167	189
C108	193	C118	193	C128	193	C138	185	C148	190	C158	190	C168	192
C109	193	C119	186	C129	193	C139	186	C149	190	C159	192	C169	193
C110	186	C120	189	C130	186	C140	186	C150	190	C160	192	C170	193

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C171	189	C181	190	C191	190	C201	192	C211	192	C221	190	C231	193
C172	192	C182	192	C192	193	C202	192	C212	193	C222	190	C232	193
C173	190	C183	190	C193	190	C203	190	C213	189	C223	190	C233	193
C174	190	C184	192	C194	193	C204	190	C214	189	C224	190	C234	191
C175	190	C185	192	C195	190	C205	190	C215	192	C225	190	C235	189
C176	189	C186	193	C196	190	C206	190	C216	193	C226	192	C236	193
C177	189	C187	193	C197	190	C207	193	C217	193	C227	190	C237	189
C178	193	C188	193	C198	190	C208	191	C218	193	C228	193	C238	193
C179	193	C189	189	C199	193	C209	193	C219	189	C229	190	C239	192
C180	190	C190	192	C200	192	C210	193	C220	190	C230	190	C240	189

33.BICU BOARD (B003/B004/B006/B007)

CAPACITOR

SYMBOL NO.	INDEX NO.
C241	189
C242	191
C243	193
C244	193
C245	193
C246	192
C247	190
C248	190
C249	192
C250	190

SYMBOL NO.	INDEX NO.
C251	190
C252	193
C253	189
C254	189
C255	193
C256	192
C257	193
C258	193
C259	192
C260	193

SYMBOL NO.	INDEX NO.
C261	192
C262	193
C263	192
C264	190
C265	188
C266	192
C267	190
C268	190
C269	190
C270	190

SYMBOL NO.	INDEX NO.
C271	193
C272	190
C273	190
C274	193
C275	190
C276	190

CONNECTOR

SYMBOL NO.	INDEX NO.
CN101	122
CN102	123
CN103	120
CN104	109
CN105	105
CN106	117
CN107	106
CN108	108
CN109	119
CN110	113

SYMBOL NO.	INDEX NO.
CN111	106
CN112	116
CN113	106
CN114	111
CN115	108
CN116	115
CN117	124
CN118	112
CN119	107
CN120	102

SYMBOL NO.	INDEX NO.
CN121	112
CN122	104
CN123	103
CN124	121
CN125	102
CN126	107
CN127	102
CN128	114
CN129	118
CN130	107

CONNECTOR

SYMBOL NO.	INDEX NO.
CN131	111
CN132	109
CN133	110
CN134	103

DIODE

SYMBOL NO.	INDEX NO.
D101	134
D102	134
D103	134
D104	136
D105	136
D106	134
D107	136
D108	134
D109	134
D110	136

SYMBOL NO.	INDEX NO.
D111	136
D112	136
D113	136

DIP SWITCH

SYMBOL NO.	INDEX NO.
DPS101	128

FB

SYMBOL NO.	INDEX NO.
FB101	157
FB102	157
FB103	157
FB104	157
FB105	157
FB106	157
FB107	157
FB108	157
FB109	157
FB110	157

SYMBOL NO.	INDEX NO.
FB111	157
FB112	157
FB113	157
FB114	157

FUSE

SYMBOL NO.	INDEX NO.
FU101	127
(Holder)	125

IC

SYMBOL NO.	INDEX NO.
IC101	141
IC102	143
IC103	152
IC104	142
IC105	146
IC106	146
IC107	150
IC108	138
IC109	138
IC110	150

SYMBOL NO.	INDEX NO.
IC111	150
IC112	2
(IC112)	126
IC113	145
IC114	145
IC115	145
IC116	145
IC117	147
IC118	151
IC119	139
IC120	148

33.BICU BOARD (B003/B004/B006/B007)

IC

SYMBOL NO.	INDEX NO.
IC121	1
IC122	152
IC123	152
IC124	152
IC125	152
IC126	149
IC127	141
IC128	152
IC129	152
IC130	140

PC

SYMBOL NO.	INDEX NO.
IC131	143
IC132	143
IC133	144

OSC

SYMBOL NO.	INDEX NO.
OSC101	153

PC

SYMBOL NO.	INDEX NO.
PC101	137
PC102	137
PC103	137
PC104	137

Q

SYMBOL NO.	INDEX NO.
Q101	130
Q102	130
Q103	130
Q104	131
Q105	132
Q106	132
Q107	131
Q108	131
Q109	132
Q110	129

RESISTOR

SYMBOL NO.	INDEX NO.
R101	176
R102	176
R103	181
R104	181
R105	181
R106	181
R107	181
R108	181
R109	181
R110	181

SYMBOL NO.	INDEX NO.
R111	181
R112	181
R113	181
R114	181
R115	181
R116	181
R117	181
R118	181
R119	181
R120	181

SYMBOL NO.	INDEX NO.
R121	181
R122	181
R123	181
R124	181
R125	181
R126	181
R127	181
R128	181
R129	181
R130	181

RESISTOR

SYMBOL NO.	INDEX NO.
R131	181
R132	176
R133	176
R134	176
R135	176
R136	176
R137	183
R138	183
R139	171
R140	176

SYMBOL NO.	INDEX NO.
R141	176
R142	183
R143	183
R144	183
R145	183
R146	176
R147	161
R148	176
R149	170
R150	161

SYMBOL NO.	INDEX NO.
R151	169
R152	164
R153	164
R154	164
R155	170
R156	170
R157	170
R158	164
R159	164
R160	170

SYMBOL NO.	INDEX NO.
R161	170
R162	170
R163	170
R164	164
R165	170
R166	170
R167	164
R168	164
R169	158
R170	158

SYMBOL NO.	INDEX NO.
R171	170
R172	170
R173	170
R174	170
R175	170
R176	170
R177	170
R178	180
R179	177
R180	160

SYMBOL NO.	INDEX NO.
R181	162
R182	158
R183	162
R184	160
R185	159
R186	159
R187	162
R188	160
R189	161
R190	164

SYMBOL NO.	INDEX NO.
R191	164
R192	164
R193	164
R194	164
R195	164
R196	164
R197	164
R198	176
R199	158
R200	176

33.BICU BOARD (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B004 5055	BICU Board	1
1	B004 5120	IC - HG71C114FL	1
2	B004 5250	IC - CDIC RI5C481	1
3	B004 5260	IC - VIPU_S KS5M9U1198CFP	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 5305	Connector - 6P	
102	1102 6297	Connector - 4P	
103	1102 6595	Connector - 11P	
104	1102 7196	Connector - 50P	
105	1102 7389	Connector - FH12-50S-0.5SV	
106	1102 7456	Connector 176125-5	
107	1102 7729	Connector - DX10G1M-50SE	
108	1102 8243	Connector - FH12-33S-0.5SV	
109	1102 8272	Connector - TX25-100P-12ST-H1	
110	1400 0392	Transistor - DTC114EK	
111	1400 0398	Transistor - 2SC2412K	
112	1402 1336	Diode - 1SS355	
113	1402 1345	Diode - UDZ3.6B	
114	1402 1380	Diode - PTZ 6.2A	
115	1403 0907	Diode - SML-310LT	
116	1403 0978	LED - SML-310DT	
117	1407 2187	TTLIC - SN74LS07NS	
118	1407 2218	TTLIC - SN74LS06NS	
119	1407 3008	TTL - SN74ALS244CNS	
120	1407 4771	IC - MC68334GFC16	
121	1407 4827	IC - MBM29F400BC-70pFTN-SFK	
122	1407 4876	CMOS IC - 74VHC244 TSSOP	
123	1407 4879	CMOS IC - 74VHC74 TSSOP	
124	1407 5090	IC - DS90CF364MTD	
125	1408 0892	IC - RH5VI30A	
126	1408 1041	IC - MB3793-42	
127	1408 1295	IC - UPC2933T	
128	1408 1470	Series Regulator - TA18M025F(LBS1.S)	
129	1503 0460	Oscillator - 32.768KHZ	
130	1503 0936	Crystal Oscillator - 19.6608Mhz	
131	1503 0937	Crystal Oscillator - 40.97Mhz	
132	1601 7751	Resistor - 4.7K Ω $\pm$ 5%	
133	1601 7752	Resistor Array - 10K Ω $\pm$ 5%	
134	1601 7759	Resistor Array - 100k Ω $\pm$ 5% 0.063W	
135	1601 7791	Resistor Array - 1K Ω $\pm$ 5%	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1601 7796	Resistor Array - 2.2KO	
137	1601 7814	Resistor - 3.3k Ω $\pm$ 5%	
138	1601 7867	Resistor - 33 Ω $\pm$ 5% 1/16W	
139	1601 7869	Resistor - 1.2k Ω $\pm$ 5% 1/16W	
140	1601 7899	Resistor Array - 56 Ω $\pm$ 5% 1/16W	
141	1605 0781	Capacitor - 5pF 50V	
142	1605 0989	Capacitor - 0.22 μ F+80 -20% 16V	
143	1605 1084	Capacitor - 0.68 μ F $\pm$ 10% 10V	
144	1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	
145	1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	
146	1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	
147	1630 4104	Resistor - 100 Ω $\pm$ 5% 1/16W	
148	1630 4105	Resistor - 1.0M Ω $\pm$ 5% 1/16W	
149	1630 4106	Resistor - 10m Ω $\pm$ 5% 1/16W	
150	1630 4222	Resistor - 2.2K Ω $\pm$ 5%	
151	1630 4223	Resistor - 22K Ω $\pm$ 5% 1/16W	
152	1630 4330	Resistor - 33 Ω $\pm$ 5% 1/8W	
153	1630 4334	Resistor - 330K Ω $\pm$ 5% 1/16W	
154	1630 4391	Resistor - 390 Ω $\pm$ 5.00% 1/16W	
155	1630 4470	Resistor - 470 Ω $\pm$ 5% 1/16W	
156	1630 4472	Resistor - 4.7K Ω $\pm$ 5% 1/16W	
157	1630 4473	Resistor - 47k Ω - $\pm$ 5% - 1/16W	
158	1630 4510	Resistor - 51 Ω $\pm$ 5% 1/16W	
159	1630 4560	Resistor - 56 Ω $\pm$ 5% 1/16W	
160	1630 4562	Resistor - 5.6k Ω - $\pm$ 5% - 1/16W	
161	1630 4751	Resistor - 50 Ω $\pm$ 5.00% 1/16W	
162	1634 0000	Resistor - 0 Ω 1/16W	
163	1644 1470	Capacitor - 47 μ F $\pm$ 20% 16V	
164	1660 2101	Capacitor - 100pF - $\pm$ 10% - 50V	
165	1660 2150	Capacitor - 15pF $\pm$ 5% 50V	
166	1660 2220	Capacitor - 22pF $\pm$ 20% 35V	
167	1660 2330	Capacitor - 33pF - $\pm$ 5% - 50V	
168	1660 2471	Capacitor - 470pF - $\pm$ 5% - 50V	
169	1660 4102	Capacitor - 1000pF $\pm$ 10% 50V	

Index No.	Part No.	Description	Q'ty Per Assembly
170	1660 4103	Capacitor - 10000pF - $\pm$ 10% - 50V	
171	1660 6103	Capacitor - 10000pF - +80%-20%50V	
172	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	
173	1902 0042	RAM - 1M X8 70ns TSOP G2	

34.CONTROLLER BOARD (B003/B004/B006/B007)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C1	147	C18	183	C33	182	C45	179	C55	181	C67	181	C77	141
C3	175	C19	183	C36	179	C46	147	C56	179	C68	184	C80	172
C8	171	C25	145	C37	184	C47	180	C57	184	C69	184	C81	172
C9	183	C26	181	C38	184	C48	179	C58	179	C70	181	C82	172
C12	175	C27	183	C39	180	C49	184	C59	181	C71	184	C83	172
C13	143	C28	147	C40	183	C50	183	C60	184	C72	184	C84	172
C14	183	C29	142	C41	180	C51	180	C61	184	C73	141	C87	181
C15	183	C30	142	C42	183	C52	183	C62	179	C74	184	C88	184
C16	143	C31	184	C43	145	C53	184	C63	181	C75	184	C89	184
C17	183	C32	142	C44	144	C54	179	C66	181	C76	181	C90	177

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C91	177	C103	173	C113	184	C123	181	C138	184	C150	183	C160	174
C92	177	C104	184	C114	184	C124	181	C139	181	C151	183	C161	176
C93	177	C105	184	C115	181	C125	181	C140	181	C152	146	C162	176
C94	181	C106	184	C116	181	C127	178	C141	184	C153	146	C163	181
C95	184	C107	181	C117	184	C128	181	C142	181	C154	146	C164	181
C96	181	C108	181	C118	181	C130	179	C143	181	C155	146	C165	181
C97	184	C109	184	C119	181	C132	184	C144	181	C156	183	C166	181
C98	181	C110	181	C120	171	C133	184	C145	181	C157	183	C167	181
C99	184	C111	184	C121	183	C134	184	C146	181	C158	174	C168	181
C100	181	C112	181	C122	184	C136	184	C147	181	C159	174	C169	181

34.CONTROLLER BOARD (B003/B004/B006/B007)

CAPACITOR

SYMBOL NO.	INDEX NO.
C170	181
C171	181
C172	181
C173	181
C174	181
C175	181

CONNECTOR

SYMBOL NO.	INDEX NO.
CN1	105
CN2	112
CN3	107
---	---
CN5	108
---	---
CN7	109
CN8	109
CN9	111
CN10	102

DIODE

SYMBOL NO.	INDEX NO.
CN11	106
CN12	110
CN13	103
CN14	104
D1	120
D2	120
D3	119
D4	119

DA

SYMBOL NO.	INDEX NO.
DA1	118
DA2	118

IC

SYMBOL NO.	INDEX NO.
IC1	133
IC2	125
IC3	128
---	---
IC5	1
IC6	186
IC7	186
IC8	131
IC9	130
IC10	113

SYMBOL NO.	INDEX NO.
IC11	129
(Socket)	113
IC12	127
IC13	127
IC14	126
IC15	132
IC16	123
---	---
IC18	127
---	---
IC20	124

FILTER

SYMBOL NO.	INDEX NO.
FIL5	148
FIL16	148

IC

SYMBOL NO.	INDEX NO.
IC21	126
IC22	127
IC23	130
IC24	134
IC25	122
IC26	185
IC27	185

JP

SYMBOL NO.	INDEX NO.
JP1	166
JP2	166
JP3	166
JP6	166
JP8	166
JP10	166
JP12	166
JP15	166
JP18	166
JP19	166

SYMBOL NO.	INDEX NO.
JP20	166
JP21	166
JP23	166
JP24	166
JP25	166
JP26	166
JP27	166
JP28	166
JP29	166
JP30	166

SYMBOL NO.	INDEX NO.
JP31	166
---	---
JP33	166
JP34	166
JP35	166
JP36	166
JP37	166
JP38	166
JP39	166
JP40	166

SYMBOL NO.	INDEX NO.
JP41	166
JP42	166
JP43	166
JP44	166
JP45	166
JP46	166
JP47	166
JP48	166
JP49	166
JP50	166

SYMBOL NO.	INDEX NO.
JP51	166
JP52	166
JP53	166
JP54	166
JP55	166
JP56	166
JP57	166

L

SYMBOL NO.	INDEX NO.
L1	149
L2	150

LED

SYMBOL NO.	INDEX NO.
LED1	121
LED2	121

34.CONTROLLER BOARD (B003/B004/B006/B007)

OSC

SYMBOL NO.	INDEX NO.
OSC1	135

RESISTOR

SYMBOL NO.	INDEX NO.
R5	152
R6	152
R7	152
R14	152
R15	152
R16	154
R17	152
R18	152
R19	157
R21	157

SYMBOL NO.	INDEX NO.
R22	152
R23	154
R25	161
R26	152
R34	160
R35	160
R36	157
R37	161
R38	164
R39	164

SYMBOL NO.	INDEX NO.
R40	154
R41	154
R42	161
R43	157
R44	152
R45	152
R46	156
R47	156
R48	157
R49	157

SYMBOL NO.	INDEX NO.
R50	157
R51	157
R77	153
R78	153
R84	152
R85	152
R86	163
R87	163
R88	163
R89	153

SYMBOL NO.	INDEX NO.
R90	163
R91	163
R92	163
R93	163
R94	163
R95	163
R96	163
R97	163
R98	163
R100	155

SYMBOL NO.	INDEX NO.
R108	165
R110	162
R111	165
R112	152
R113	162
R114	165
R131	157
R132	152
R133	152
R134	152

Q

SYMBOL NO.	INDEX NO.
Q1	117
Q2	116
Q3	116

RESISTOR

SYMBOL NO.	INDEX NO.
R135	152
R136	168
R137	167
R139	151
R141	157
R142	157
R143	157
R145	157
R146	157
R147	157

SYMBOL NO.	INDEX NO.
R148	163
R150	157
R151	157
R152	157
R154	157
R155	157
R156	157
R157	157
R158	157
R159	157

SYMBOL NO.	INDEX NO.
R160	152
R161	157
R162	157
R163	157
R164	152
R165	152
R166	157
R167	158
R168	157
R169	157

SYMBOL NO.	INDEX NO.
R170	157
R171	157
R172	157
R173	157
R174	152
R175	152
R176	152
R177	152
R178	152
R179	159

SYMBOL NO.	INDEX NO.
R180	152
R181	152
R182	157
R183	152
R184	152
R185	159
R186	157
R188	157
R189	152
R190	152

SYMBOL NO.	INDEX NO.
R191	152
R193	152
R194	158
R195	152
R196	152
R197	152
R198	152
R199	152
R200	152
R201	152

SYMBOL NO.	INDEX NO.
R202	152
R203	152
R204	152
R205	152
R206	163
R208	152
R209	157
R210	157
R211	157
R212	157

34.CONTROLLER BOARD (B003/B004/B006/B007)

RESISTOR

SYMBOL NO.	INDEX NO.
R213	157
R214	157
R215	152
R216	152
R219	152
R220	152
R221	157
R222	152
R223	152
R224	151

SYMBOL NO.	INDEX NO.
R226	152
R229	152
R230	151
R232	152
R233	152
R234	152
R235	157
R236	157
R237	169
R238	170

SYMBOL NO.	INDEX NO.
R239	152
R240	157
R241	157
R242	152
R243	166
R244	166
R245	166
R246	166
R247	166
R248	166

SYMBOL NO.	INDEX NO.
RN1	138
RN10	139
RN11	139
RN12	139
RN13	140
RN14	140
RN15	140
RN16	139
RN17	138
RN18	138

RESISTOR

SYMBOL NO.	INDEX NO.
RN19	140
RN20	140
RN21	140
RN22	140
RN23	140
RN24	138
RN25	138
RN26	138
RN27	138
RN28	138

SYMBOL NO.	INDEX NO.
RN29	138
RN30	138
RN40	136
RN41	136
RN42	136
RN43	136
RN72	137
RN73	137
RN77	139
RN78	139

SYMBOL NO.	INDEX NO.
RN79	139
RN80	139
RN81	139
RN82	139
RN83	139
RN84	139
RN90	139
RN91	139

SWITCH

SYMBOL NO.	INDEX NO.
SW1	114
SW2	115

TEST PIN

SYMBOL NO.	INDEX NO.
TP1	101
TP2	101
TP3	101
TP4	101
TP5	101
TP6	101
TP7	101
TP8	101
TP9	101
TP10	101

SYMBOL NO.	INDEX NO.
TP11	101
TP12	101
TP13	101
TP14	101
TP15	101
TP16	101

34.CONTROLLER BOARD (B003/B004/B006/B007)








Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 5100	Control Board	1
	B004 5266	ASIC - SIMAC4	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1100 1474	Test Pin	
102	1102 2391	Connector - HIF3FB-40PA-2.54DSA	
103	1102 3566	Connector - S8B-XH-A(8pin)	
104	1102 6297	Connector - 4P	
105	1102 6789	Connector - 100P	
106	1102 6815	Connector - 53258-0410	
107	1102 8153	Connector - FCN-568P068-G/05A-V4	
108	1102 8189	Dimm Connector - 54534-1440	
109	1102 8355	Connector - Dimm - DMM2-SD72A-1131	
110	1102 8358	Connector - WR-100P-VF60-1	
111	1102 8523	Connector - 57RE-40360-830B(D7A)	
112	1102 8567	Connector - 52775-0800	
113	1104 0588	Dip Socket - 28p	
114	1204 1385	Push Switch	
115	1204 1542	Dip Switch	
116	1400 0591	Transistor - DTC113ZK	
117	1401 1055	Fet - SI9934DY	
118	1402 0595	Diode Array - DAN202K	
119	1402 1265	Diode - RB411D	
120	1402 1444	Diode - RB051L-40	
121	1403 0907	Diode - SML-310LT	
122	1407 2187	TTLIC - SN74LS07NS	
123	1407 4913	IC - 74VHC244	
124	1407 5040	IC - SN74LVC161284DL	
125	1407 5273	CPU - RM5231-200Q-REV1.2C	
126	1407 5274	CMOS Logic - 74LVCH162244A TSSOP	
127	1407 5275	CMOS Logic - 74LVCHR16245A TSSOP	
128	1407 5278	Clock Generator - ICS9148BF-17	
129	1407 5324	RAM - M48T35AV-10PC1	
130	1407 5327	CMOS Logic - 74LVC139A TSSOP	
131	1407 5328	CMOS Logic - 74ALVCH162827 TSSOP	
132	1407 5337	CMOS Logic - 74LVCH16373A TSSOP	
133	1408 1514	IC - M62293FP	
134	1408 1538	IC - M62032AFP	
135	1503 0842	Oscillator - 14.31818mhz	











Index No.	Part No.	Description	Q'ty Per Assembly
136	1601 7867	Resistor - 33 Ω $\pm$ 5% 1/16W	
137	1601 7887	Resistor Array - 10k Ω $\pm$ 5% 1/32W	
138	1601 7896	Resistor Array - 56 Ω $\pm$ 5% 1/32W	
139	1601 7898	Resistor Array	
140	1601 7909	Resistor Array - 10 Ω $\pm$ 5% 1/32W 1005	
141	1604 4683	Capacitor - 100UF $\pm$ 20% 10V	
142	1604 4822	Capacitor - 220 μ F $\pm$ 20% 10V	
143	1605 0878	Capacitor - 13PFpF $\pm$ 5% 50V	
144	1605 0927	Capacitor - 1000pF $\pm$ 5% 25V	
145	1605 1085	Ceramic Capacitor - 0.082Uf $\pm$ 10% 16V	
146	1605 1124	Capacitor - 4.7 μ F+80 -20% 10V	
147	1605 1162	Capacitor - 10 μ F+80 -20% 10V	
148	1607 1206	Filter - Acc2012I-250	
149	1607 1223	Inductor - 47uh $\pm$ 20% 2.7A	
150	1607 1227	Inductor - SLF12575-150M4R7	
151	1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	
152	1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	
153	1630 4122	Resistor - 1.2K Ω 5% 1/16W	
154	1630 4220	Resistor - 22 Ω $\pm$ 5% 1/16W	
155	1630 4222	Resistor - 2.2K Ω $\pm$ 5%	
156	1630 4229	Resistor - 2.2 Ω $\pm$ 5% - 1/16W	
157	1630 4330	Resistor - 33 Ω $\pm$ 5% 1/8W	
158	1630 4331	Resistor - 330 Ω $\pm$ 5% 1/16W	
159	1630 4472	Resistor - 4.7K Ω $\pm$ 5% 1/16W	
160	1630 4519	Resistor - 5.1 Ω $\pm$ 5% 1/16W	
161	1630 4560	Resistor - 56 Ω $\pm$ 5% 1/16W	
162	1630 4562	Resistor - 5.6k Ω - $\pm$ 5% - 1/16W	
163	1630 4680	Resistor - 68 Ω $\pm$ 5% 1/16W	
164	1630 4750	Resistor - 75 Ω $\pm$ 5% 1/16W	
165	1630 4820	Resistor - 82 Ω $\pm$ 5% 1/16W	
166	1634 0000	Resistor - 0 Ω 1/16W	
167	1634 1003	Resistor - 100K Ω $\pm$ 1% 1/16W	
168	1634 1153	Resistor - 115k Ω $\pm$ 1% 1/16W	
169	1634 1783	Resistor - 178k Ω $\pm$ 1% 1/16W	
170	1634 7502	Resistor - 75.0K Ω $\pm$ 1% 1/16W	

Index No.	Part No.	Description	Q'ty Per Assembly
171	1644 0220	Capacitor - 22 μ F $\pm$ 20% 10V	
172	1644 1100	Capacitor - 10 μ F $\pm$ 20% 16V	
173	1644 1470	Capacitor - 47 μ F $\pm$ 20% 16V	
174	1660 0100	Capacitor - 10PF $\pm$ 0.5pF 50V	
175	1660 2101	Capacitor - 100pF - $\pm$ 10% - 50V	
176	1660 2150	Capacitor - 15pF $\pm$ 5% 50V	
177	1660 2221	Capacitor - 220pF +80-20% 50V	
178	1660 2330	Capacitor - 33pF - $\pm$ 5% - 50V	
179	1660 2471	Capacitor - 470pF - $\pm$ 5% - 50V	
180	1660 2680	Capacitor - 68pF $\pm$ 5% 50V	
181	1660 4102	Capacitor - 1000pF $\pm$ 10% 50V	
182	1660 4472	Capacitor - 4700pF $\pm$ 10% 50V	
183	1660 6103	Capacitor - 10000pF - +80%-20%50V	
184	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	
185	1906 0017	Flash Memory - LH28F320BJ-PBTL70	
186	1907 0017	SDRAM - 128M 2MX16X4 100Mhz G2	

35.DECAL AND DOCUMENT (B003/B004/B006/B007)

1 	4 	7 
2 	5 	8 
3 	6 	

35.DECAL AND DOCUMENT (B003/B004/B006/B007)











9  注意 CAUTION ATTENTION ここを持たないでください。 ACHTUNG ATTENZIONE ATENCIÓN >PS<				19  >PS<	
10 機械本体に装着している感光体は、パフォーマンス契約上のリコーの所有物です。 パフォーマンス契約終了後は、当社にて引き上げをいたします。 社名 _____ 担当者 _____ >PS<	11  >PS<	12 	13 	20,21 	
14  >PS<				22 	
15  >PET<					
16  >PS<	17  >PS<	18  >PS<		23 	24 

35.DECAL AND DOCUMENT (B003/B004/B006/B007)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A232 1381	Decal - Total Counter	1
2	A232 1385	Decal - Indication	1
3	G020 1918	Decal - Laser Diode (230V)	1
3	G020 1920	Decal - Laser Diode (115V)	1
4	A232 3066	Decal - Development Unit	1
5	A232 3991	Decal - Shield Cover	1
6	A232 6073	Decal - By-pass Feed	1
7	A284 1384	Decal - Operation	1
8	A284 1390	Decal - Value Station	1
9	AA00 0204	Decal - Right Lower Cover	1
10	AA00 0211	Decal - Drum	1
11	AA00 1389	Large Decal - Energy Star	1
12	AA00 1392	Decal - A1	1
13	AA00 1393	Decal - A2	1
14	AA00 3007	Decal - Paper Set Direction	1
15	B004 4122	Decal - Warning (High Temperature)	1
16	B004 4851	Decal - Jam Removal	1
17	B004 4852	Decal - Duplex Jam	1
18	B004 4853	Upper Decal - Duplex Unit	1
19	G020 1917	Decal - LD	1
20	A284 8503	Operating Manual - Copy	1
21	A877 8520	Operating Manual - System	1
22	B004 6506	Operating Instructions - System (RIC-CHN)	1
22	B004 6507	Operating Instructions - System (RIC-NA) (English)	1
22	B004 6508	Operating Instructions - System (RIC-Asia) (English)	1
22	B004 6509	Operating Instructions - System (RIC-TWN)	1
22	B004 6560	Operating Instructions - System (INF) (English)	1
22	B004 6597	Operating Instructions - System (SVN) (English)	1
22	B004 6606	Operating Instructions - Copy (RIC-CHN)	1
22	B004 6607	Operating Instructions - Copy (RIC-NA) (English)	1

Index No.	Part No.	Description	Q'ty Per Assembly
22	B004 6608	Operating Instructions - Copy (RIC-Asia) (English)	1
22	B004 6609	Operating Instructions - Copy (RIC-TWN)	1
22	B004 6660	Operating Instructions - Copy (INF)(English)	1
22	B004 6697	Operating Instructions - Copy (SVN) (English)	1
22	B004 7205	Operating Instructions - Copy (LAN-NA) (English)	1
22	B004 7207	Installation Procedure (LAN)	1
23	A232 6781	Decal - Stand-by (CHN)	1
24	A232 6780	Decal - ON (CHN)	1

36.SPECIAL TOOLS (B003/B004/B006/B007)

1 	2 	3 	4 	5 
6 	7 	8 	9 	10 

36.SPECIAL TOOLS (B003/B004/B006/B007)



Index No.	Part No.	Description	Q'ty Per Assembly
1	A230 9004	Positioning Pin Laser Unit	1
2	A230 9003	Adjusting Cam - Laser Unit	1
3	A230 9352	Flash Memory Card - 4mb	1
4	A230 9351	Case - Flash Memory Card	1
5	A006 9104	Adjusting Scanner Pin (4pcs/set)	1
6	A292 9500	Test Chart - S5s (10 Pcs/set)	1
7	A029 9387	Digital Multimeter - Fluke87	1
8	A028 9300	Grease Barrierta Jfe 55/2	1
9	5203 9502	Grease 501	1
10	G021 9350	Loopback Connector - Parallel	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
BY-PASS FEED UNIT 2 (B003/B004/B006/B007)	AF03 2036	Separation Roller	Separation Roller	1	27- 2
	AF03 1036	Feed Roller	Feed Roller	1	27- 12
	AF03 0036	Pick Up Roller	Pick Up Roller	1	27- 22
PAPER FEED SECTION (B003/B004/B006/B007)	AF03 0034	Pick-up Roller	Pick-up Roller	1	31- 1
	AF03 1035	Feed Roller	Feed Roller	1	31- 6
	AF03 2035	Separation Roller	Separation Roller	1	31- 36
PCU UNIT 2 (B003/B004/B006/B007)	AD02 5021	Pick-off Pawl	Pick-off Pawl	2	39- 3
	G065 2280	Cleaning Pad	Cleaning Pad	1	39- 13
	A232 2353	Cleaning Blade Ass'y	Cleaning Blade Ass'y	1	39- 22
	AD02 7006	Charge Roller	Charge Roller	1	39- 26
	A232 3830	Cleaning Blade - Transfer Belt	Cleaning Blade - Transfer Belt	1	41- 21
TRANSFER UNIT (B003/B004/B006/B007)	A232 3880	Transfer Belt	Transfer Belt	1	41- 23
DEVELOPMENT UNIT (B003/B004/B006/B007)	AA01 2102	Development Filter	Development Filter	1	45- 15
FUSING UNIT (B003/B004/B006/B007)	AE04 4030	Hot Roller Stripper	Hot Roller Stripper	7	47- 6
	AE01 1064	Hot Roller - 39.8mm T0.4	Hot Roller - 39.8mm T0.4	1	47- 17
	AE02 0108	Pressure Roller	Pressure Roller	1	47- 22
	AW10 0052	Thermistor - Center	Thermistor - Center	1	47- 41
	AW10 0053	Thermistor - Rear	Thermistor - Rear	1	47- 11

Parts Index

Part No.	Description	Page and Index No.
B003 1873	Optical Housing Unit(NA/TWN)(B003/B006)	23- *
B003 1877	Optical Housing Unit(EU/Asia/CHN)(B003)	23- *
B003 7210	Emblem (RIC)(B003)	11- 9
B003 7211	Emblem (RIC-GSA)(B003)	11- 9
B003 7212	Emblem (SVN)(B003)	11- 9
B003 7213	Emblem (SVN-GSA)(B003)	11- 9
B003 7214	Emblem (GES)(B003)	11- 9
B003 7217	Emblem (INF)(B003)	11- 9
B003 7218	Emblem (LAN)(B003)	11- 9
B004 1038	Guide Plate - Scanner Unit	13- 27
B004 1043	Spacer - Scanner Unit	13- 21
B004 1048	Supporting Plate - Scanner Unit	13- 26
B004 1049	Scanner Arm Unit	13- 25
B004 1081	Bracket - Fusing Connector	65- 21
B004 1082	Support Plate - Scanner Arm	61- 7
B004 1089	Stay - Rear	67- 11
B004 1093	Rear Stay	13- 13
B004 1096	Development Drive Bracket	57- 32
B004 1101	Front Bracket - Scanner Unit	13- 16
B004 1104	Rear Bracket - Scanner Unit	13- 17
B004 1138	Development Drive Unit	57- 33
B004 1147	Tightener Development Drive	57- 38
B004 1150	Spring - Tightener	57- 39
B004 1153	Timing Pulley - Paddle	57- 37
B004 1156	Bracket - OPC Drum	57- 34
B004 1162	Upper Holder Plate	59- 25
B004 1163	Pulley Bracket	59- 31
B004 1165	Bracket - Timing Pulley	33- 24
B004 1167	Flange - 24MM	33- 36
B004 1169	Tightener	59- 33
B004 1172	Support Bracket	59- 27
B004 1176	Lower Development Bracket	67- 3
B004 1177	Spacer - By-pass Feed	59- 15
B004 1179	Lower Holder Plate	59- 24
B004 1250	Upper Cover	13- 4

Part No.	Description	Page and Index No.
B004 1261	Front Cover Ass'y	11- 8
B004 1283	Left Rear Cover	11- 4
B004 1285	Left Cover-paper Feed Sub-unit	11- 5
B004 1291	Rear Cover	13- 19
B004 1296	Rear Cover - Paper Feed Sub-unit	13- 18
B004 1297	Rear Cover - Paper Feed Sub-unit	13- 31
B004 1301	Cover - Guide Plate - Scanner Unit	9- 9
B004 1303	Cover - Guide Plate - Rear	9- 8
B004 1320	Base Cover	59- 38
B004 1321	Shield Plate - BICU	59- 37
B004 1322	Shield Plate - DC Motor	59- 42
B004 1324	Cover - Scanner Connector	19- 24
B004 1324	Cover - Scanner Connector	13- 5
B004 1350	Upper Rear Cover - Scanner	9- 6
B004 1356	Right Cover - Scanner	9- 7
B004 1358	Lower Cover	9- 11
B004 1385	Jam Removal Sheet	11- 10
B004 1501	Operation Panel Case (CHN)	17- 24
B004 1502	Keytop - 10key (EU)	17- 2
B004 1503	Keytop - Clear/Stop	17- 4
B004 1504	Keytop - Try Print	17- 9
B004 1505	Keytop - Start	17- 3
B004 1506	Keytop - Power Source	17- 8
B004 1507	Keytop - Reset Switch	17- 14
B004 1508	Keytop - Preheat	17- 15
B004 1509	Keytop - Block Diagram	17- 7
B004 1510	Keytop - Confirm	17- 16
B004 1511	Keytop - Counter	17- 18
B004 1512	Keytop - Interrupt	17- 6
B004 1513	Dial - Contrast	17- 19
B004 1515	Sheet - Preventence Sheet - Right	17- 27
B004 1517	Erath Sheet - Touch Panel	17- 28
B004 1518	Operation Panel Board - Right	17- 5
B004 1519	Operation Panel Board - Left	17- 23
B004 1520	LCDC Bracket	17- 22

Part No.	Description	Page and Index No.
B004 1521	LCDC Cover	17- 21
B004 1531	Keytop - Copy 1 (CHN)(B004)	17- 13
B004 1532	Keytop - Copy 2 (CHN)(B004)	17- 12
B004 1534	Cover - Application	17- 11
B004 1535	Cover - Basic	17- 10
B004 1678	Left Scale Bracket	19- 1
B004 1681	Inner Cover	19- 3
B004 1713	Pulley 2 - 22MM	21- 2
B004 1714	Idler Bracket	21- 33
B004 1726	Rail - Flexible Board	21- 22
B004 1728	Bracket - Heater	21- 23
B004 1732	Fan Bracket	19- 26
B004 1737	Base - Scanner - Rear	21- 21
B004 1741	Power Supply Cord	21- 43
B004 1809	Carrtage Pulley - 22MM	21- 1
B004 1820	2nd Mirror Aass'y	21- 4
B004 1831	Lensholder Assy	19- 6
B004 1841	Scanner Interface Cable	19- 19
B004 1843	Exposure Lamp Harness	21- 15
B004 1846	Motor Drive Board Bracket - L	19- 25
B004 1847	Motor Drive Board Bracket - R	19- 28
B004 1849	ARDF Connector Bracket	19- 9
B004 1873	Optical Housing Unit(NA/TWN)(B004/B007)	23- *
B004 1877	Optical Housing Unit(EU/Aasia/CHN)(B004)	23- *
B004 1891	LD Unit (B004/B007)	23- 26
B004 1936	Plate - Optical Housing Unit	59- 40
B004 1936	Plate - Optical Housing Unit	61- 8
B004 1938	Holder - Optical Housing Unit	59- 10
B004 1939	Holder - Optical Housing Unit	59- 39
B004 1968	Shield Plate Ass'y - LDDR	65- 24
B004 1969	Shield Plate - LDDR	65- 17
B004 2210	Shield - PCU - Upper Left	37- 32
B004 2211	Shield - Shutter - Middle	37- 29
B004 2212	Front Seal - Cleaning Cover	37- 33
B004 2310	Spur	33- 2

Part No.	Description	Page and Index No.
B004 2575	Knob - Entrance Guide	33- 31
B004 2750	Paper Feed Unit	31- 38
B004 2777	Shaft - Paper Separation	31- 12
B004 2782	Rear Feed Mylar	31- 14
B004 2783	Torque Limiter	31- 11
B004 2905	Universal Paper Tray (NA)	29- 1
B004 2910	Universal Paper Tray (EU)	29- 1
B004 2915	Bottom Lift Shaft	29- 12
B004 2920	Front Side Fence	29- 25
B004 2922	Release Lever - Side Fence	29- 26
B004 2923	Spring Plate - Release Lever	29- 27
B004 2924	Paper Guide Plate - Front	29- 22
B004 2930	Rear Side Fence	29- 28
B004 2932	Rear Stopper Lever	29- 2
B004 2933	Rear Stopper	29- 18
B004 2934	Spring Plate - Lock Lever	29- 19
B004 2935	Paper Guide Plate - Rear	29- 23
B004 2936	Gear - 16Z	29- 24
B004 2940	Bottom Plate	29- 4
B004 2943	Grounding Plate - Paper Tray	29- 13
B004 2947	Spring Plate-paper Size Sensor	29- 16
B004 2948	Paper Size Sensor	29- 21
B004 2951	Stopper-right	29- 9
B004 2952	Shoe- Left	29- 17
B004 2954	Paper Size Dial (LT)	29- 20
B004 2955	Paper Size Dial (A4)	29- 20
B004 2988	Handle - Paper Tray	29- 8
B004 2995	Cap - Positioning	67- 6
B004 3056	Lower Development Case	45- 23
B004 3062	Ground Plate- Doctor Blade	45- 25
B004 3065	TD Sensor	45- 18
B004 3078	Joint - Paddle	45- 16
B004 3100	Development Roller Ass'y	45- 9
B004 3206	Toner Supply Unit	35- 1
B004 3210	Guide - Toner Supply Unit	65- 6

Part No.	Description	Page and Index No.
B004 3215	Toner Bottle Holder	65- 7
B004 3262	Slide Rail-toner Supply	35- 3
B004 3900	Case - Transfer Unit	41- 1
B004 3911	Mylar - Remove Paper Dust	41- 16
B004 3914	Mylar - Belt Drive Roller	41- 40
B004 3915	Entrance Mylar - Transfer Unit	41- 37
B004 4055	Stay - Thermostat	47- 13
B004 4056	Pressure Lever	47- 25
B004 4081	Upper Frame - Fusing Unit	47- 10
B004 4087	Plate- Thermistor	47- 40
B004 4092	Bracket- Fusing Connector	47- 32
B004 4095	Terminal Plate - Fusing Unit	47- 31
B004 4105	Housing - Thermostat	47- 8
B004 4106	Thermostat	47- 12
B004 4111	Front Heater Socket	47- 5
B004 4115	Rear Heater Socket	47- 9
B004 4117	Harness- Fusing Unit (120V)	47- 33
B004 4122	Decal - Warning (High Temperature)	65- 13
B004 4122	Decal - Warning (High Temperature)	83- 15
B004 4126	Lower Entrance Guide Plate	47- 39
B004 4127	Harness- Fusing Unit (230V)	47- 33
B004 4131	Fusing Cover	47- 3
B004 4133	Cap- Fusing Cover	47- 20
B004 4135	Guide Plate-fusing Exit	47- 4
B004 4322	Guide Plate- Fusing Exit	43- 18
B004 4323	Bracket- Exitsensor	43- 17
B004 4327	Bushing - 4mm	43- 20
B004 4329	Grounding Plate - Exit Sensor	43- 35
B004 4330	Screw - 4.5mm	43- 37
B004 4435	Sub Copy Tray	13- 3
B004 4436	Copy Tray Guide	13- 2
B004 4437	Supporting Plate - Left Lower	49- 8
B004 4438	Bushing	49- 14
B004 4439	Protect Bracket - Middle	49- 45
B004 4453	Lower Guide Plate	49- 2

Part No.	Description	Page and Index No.
B004 4455	Frame - Left Lower	49- 10
B004 4458	Pressure Arm - Exit	49- 5
B004 4460	Shaft-pressure Roller	49- 3
B004 4463	Pressure Arm - Entrance	49- 9
B004 4466	Bracket - Contact Point	49- 7
B004 4469	Spring Plate - Exit Roller	49- 12
B004 4471	Frontplate	49- 35
B004 4472	Rear Plate	49- 23
B004 4477	Upperguide Plate	49- 32
B004 4478	Entrance Junction Gate	49- 13
B004 4479	Lever - Entrance Junction Gate	49- 24
B004 4481	Exit Junction Gate	49- 31
B004 4486	DC Solenoid	49- 28
B004 4490	Right Supporting Plate	49- 29
B004 4493	Joint	49- 15
B004 4494	Paper Feed Sensor Bracket	49- 16
B004 4497	Ground Plate - Discharge Brush	49- 34
B004 4622	Guide Plate - Right Lower	55- 5
B004 4630	Lower Stay - Duplex	55- 7
B004 4634	Guide Plate - Reverse	53- 8
B004 4638	Frontside Plate	53- 25
B004 4642	Side Plate-rear	53- 13
B004 4645	Guide Plate - Middle	51- 4
B004 4664	DC Motor - 28W	53- 22
B004 4664	DC Motor - 28W	55- 14
B004 4666	Bracket - Inverter Motor	53- 21
B004 4678	Bracket - Feed Motor	55- 12
B004 4690	Link Solenoid Ass'y	53- 24
B004 4697	Micro Switch Bracket	55- 18
B004 4701	Duplex Unit Cover	51- 18
B004 4710	Right Cover - Duplex Unit	51- 20
B004 4711	Right Cover - Duplex Unit	51- 11
B004 4763	Bracket - Entrance Sensor	53- 6
B004 4791	Sensor Bracket	55- 16
B004 4792	Middle Stay	55- 21

Part No.	Description	Page and Index No.
B004 4800	Main Board Bracket	53- 14
B004 4851	Decal - Jam Removal	83- 16
B004 4851	Decal - Jam Removal	51- 12
B004 4852	Decal - Duplex Jam	51- 2
B004 4852	Decal - Duplex Jam	83- 17
B004 4853	Upper Decal - Duplex Unit	51- 21
B004 4853	Upper Decal - Duplex Unit	83- 18
B004 5021	Safety & Power Switch Ass'y	63- 17
B004 5024	Safety Switch Ass'y	63- 22
B004 5055	BICU Board	77- *
B004 5055	BICU Board	63- 6
B004 5100	Control Board	81- *
B004 5100	Control Board	69- 16
B004 5120	IC - HG71C114FL	77- 1
B004 5125	IOB Board	73- *
B004 5125	IOB Board	63- 4
B004 5130	PFB Board	59- 20
B004 5140	Main Board - Duplex	53- 15
B004 5192	Mother Board	69- 1
B004 5203	Operation Panel Board (NA)(B003/B004)	17- 20
B004 5204	Operation Panel Board (EU)(B003/B004)	17- 20
B004 5205	Operation Panel Board (Asia/TWN)(B003/B004)	17- 20
B004 5206	Operation Panel Board (CHN)(B003/B004)	17- 20
B004 5215	LCD - HVGA U95 BL	17- 26
B004 5250	IC - CDIC RI5C481	77- 2
B004 5260	IC - VIPU_S KS5M9U1198CFP	77- 3
B004 5266	ASIC - SIMAC4	81- 1
B004 5291	Harness - Laser Diord Control	63- 8
B004 5387	Scanner Interface Board	19- 23
B004 5397	Motor Drive Board	19- 18
B004 5450	DC Main Harness - Upper	63- 9
B004 5451	DC Harness - Front Lower	63- 2
B004 5452	DC Harness - Front Upper	63- 3
B004 5453	Drawer Harness - Development	59- 7
B004 5454	Right Rear Harness	43- 28

Part No.	Description	Page and Index No.
B004 5455	Harness - Paper Size Sensor	59- 8
B004 5457	Safety Switch Harness	61- 15
B004 5457	Safety Switch Harness	59- 35
B004 5459	Exit Harness	49- 18
B004 5460	Main Harness - Duplex Unit	53- 16
B004 5461	Sensor Harness - Duplex Unit	53- 17
B004 5462	Sensor Harness	55- 22
B004 5466	Harness - Toner Overflow Sensor	43- 34
B004 5475	Harness - HDD	69- 12
B004 5476	DC Power Harness	69- 13
B004 5520	Harness - DC Power Supply	63- 7
B004 5520	Harness - DC Power Supply	61- 11
B004 5538	Harness - OPU	9- 12
B004 5538	Harness - OPU	19- 17
B004 5541	Harness- ADF	19- 10
B004 5542	Harness - SBU-50wick 80mm	19- 21
B004 5543	Harness - SIB	19- 14
B004 5606	Harness - AC Switch	63- 19
B004 5608	Main Harness - Fusing Unit (230V)	63- 11
B004 5609	Main Harness - Fusing Unit (120V)	63- 11
B004 5611	Harness - Heater	61- 12
B004 5811	Bracket - High Voltage Supply	61- 10
B004 5812	Bracket - High Voltage Supply	61- 6
B004 5825	Connector Bracket	63- 10
B004 5831	Bracket - IOB	63- 5
B004 5836	Front Grounding Plate	13- 14
B004 5843	Shoulder Screw	51- 24
B004 5845	Control Board A'ssy	69- 15
B004 5850	Bracket - Control Board (B003/B004)	69- 6
B004 5854	Connector Cover	69- 7
B004 5866	Bracket - Power Switch	63- 15
B004 5871	Expansion Box	69- 2
B004 5876	Stay - Rack	69- 3
B004 5885	Rack Panel	69- 4
B004 5890	Bracket - HDD - Ass'y	69- 9

Part No.	Description	Page and Index No.
B004 5893	HDD - 20G Byte	69- 11
B004 5897	Bracket - Connector	61- 9
B004 5898	Bracket - Power Supply Cord	61- 16
B004 6506	Operating Instructions - System (RIC-CHN)	83- 22
B004 6507	Operating Instructions - System (RIC-NA) (English)	83- 22
B004 6508	Operating Instructions - System (RIC-Asia) (English)	83- 22
B004 6509	Operating Instructions - System (RIC-TWN)	83- 22
B004 6560	Operating Instructions - System (INF)(English)	83- 22
B004 6597	Operating Instructions - System (SVN)(English)	83- 22
B004 6606	Operating Instructions - Copy (RIC-CHN)	83- 22
B004 6607	Operating Instructions - Copy (RIC-NA)(English)	83- 22
B004 6608	Operating Instructions - Copy (RIC-Asia)(English)	83- 22
B004 6609	Operating Instructions - Copy (RIC-TWN)	83- 22
B004 6660	Operating Instructions - Copy (INF)(English)	83- 22
B004 6697	Operating Instructions - Copy (SVN)(English)	83- 22
B004 7205	Operating Instructions - Copy (LAN-NA)(English)	83- 22
B004 7207	Installation Procedure (LAN)	83- 22
B004 7210	Emblem (RIC)(B004)	11- 9
B004 7211	Emblem (RIC-GSA)(B004)	11- 9
B004 7212	Emblem (SVN)(B004)	11- 9
B004 7213	Emblem (SVN-GSA)(B004)	11- 9
B004 7214	Emblem (GES)(B004)	11- 9
B004 7217	Emblem (INF)(B004)	11- 9
B004 7218	Emblem (LAN)(B004)	11- 9
B004 7222	Css Cover	13- 34
B004 7226	Left Front Cover - NA	11- 1
B004 7232	Operation Panel Ass'y (NA)(B003/B004)	9- 10
B004 7232	Operation Panel Ass'y (NA)(B003/B004)	17- *
B004 7234	Operation Panel Case (NA)	17- 24
B004 7236	Keytop - 10key (NA)	17- 2
B004 7237	Keytop - Clear Modes	17- 14
B004 7238	Sheet-operation	17- 1
B004 7241	Keytop - Copy 1 (NA)	17- 13

Part No.	Description	Page and Index No.
B004 7242	Keytop - Copy 2 (NA)	17- 12
B004 7270	Transfer Unit	41- *
B004 7320	Fusing Unit (115V)	47- 1
B004 7361	PCU	37- *
B004 7460	Development Unit	45- 1
B004 7626	Left Front Cover - EU	11- 1
B004 7632	Operation Panel Ass'y (EU)(B003/B004)	17- *
B004 7632	Operation Panel Ass'y (EU)(B003/B004)	9- 10
B004 7634	Operation Panel Case (EU)	17- 24
B004 7641	Keytop - Copy 1 (EU)	17- 13
B004 7642	Keytop - Copy 2 (EU)	17- 12
B004 7720	Fusing Unit (230V)	47- 1
B004 7932	Operation Panel Ass'y (TWN)(B003/B004)	17- *
B004 7932	Operation Panel Ass'y (TWN)(B003/B004)	9- 10
B004 7942	Operation Panel Ass'y (CHN)(B003/B004)	17- *
B004 7942	Operation Panel Ass'y (CHN)(B003/B004)	9- 10
B004 7952	Operation Panel Ass'y (Asia)(B003/B004)	9- 10
B004 7952	Operation Panel Ass'y (Asia)(B003/B004)	17- *
B004 9099	NVRAM - Minus Counter	69- 17
B006 7210	Emblem (RIC)(B006)	11- 9
B006 7212	Emblem (SVN)(B006)	11- 9
B006 7218	Emblem (LAN)(B006)	11- 9
B007 5850	Bracket - Control Board (B006/B007)	69- 6
B007 7210	Emblem (RIC)(B007)	11- 9
B007 7212	Emblem (SVN)(B007)	11- 9
B007 7218	Emblem (LAN)(B007)	11- 9
B007 7232	Operation Panel Ass'y (NA)(B006/B007)	9- 10
B007 7232	Operation Panel Ass'y (NA)(B006/B007)	17- *

Part No.	Description	Page and Index No.
AA00 0204	Decal - Right Lower Cover	83- 9
AA00 0204	Decal - Right Lower Cover	11- 28
AA00 0211	Decal - Drum	83- 10
AA00 1389	Large Decal - Energy Star	83- 11
AA00 1392	Decal - A1	11- 19
AA00 1392	Decal - A1	83- 12
AA00 1393	Decal - A2	83- 13
AA00 1393	Decal - A2	33- 32
AA00 3007	Decal - Paper Set Direction	83- 14
AA00 3007	Decal- Paper Set Direction	29- 7
AA01 2102	Development Filter	45- 15
AA04 3416	Timing Belt - 40S3M192	11- 31
AA04 3439	Timing Belt - S2M-224	21- 32
AA04 3442	Timing Belt - S3M-264	57- 3
AA04 3443	Timing Belt - S2M 140	53- 20
AA04 3443	Timing Belt - S2M 140	55- 10
AA04 3444	Timing Belt - S2M 350	55- 1
AA04 3445	Timing Belt - S3M-360	59- 4
AA04 3446	Timing Belt - S3M-312	59- 11
AA04 3551	Timing Belt - B50S3M213UG	57- 36
AA04 3553	Timing Belt - B60S2M316	57- 22
AA04 3554	Timing Belt - B60S3M129	33- 34
AA04 3555	Timing Belt - S2M234	49- 19
AA04 3569	Timing Belt - B50S3M228	57- 36
AA05 0106	Carriage Drive Wire	21- 25
AA05 1027	Wire - Fusing Drive	43- 25
AA06 0689	Tension Spring	43- 26
AA06 0690	Spring	57- 15
AA06 0691	Tension Spring	31- 4
AA06 0693	Tension Spring	31- 37
AA06 0694	Tension Spring	59- 13
AA06 0695	Tension Spring	59- 34
AA06 0696	Tension Spring	57- 8
AA06 0702	Tension Spring	19- 11
AA06 0703	Tension Spring	21- 26

Part No.	Description	Page and Index No.
AA06 0709	Tension Spring	51- 15
AA06 0711	Pressure Spring	41- 10
AA06 0712	Torsion Spring	41- 27
AA06 0713	Tension Spring	63- 21
AA06 0716	Tension Spring	49- 44
AA06 0839	Pressure Spring - Driven	51- 22
AA06 0839	Pressure Spring - Driven	53- 11
AA06 0840	Pressure Spring - 29N	47- 26
AA06 0855	Return Spring	49- 25
AA06 0864	Tension Spring	31- 23
AA06 0879	Tension Spring	47- 7
AA06 2299	Pressure Spring	39- 18
AA06 2300	Tension Spring	39- 19
AA06 2301	Tension Spring	39- 11
AA06 2303	Tension Spring	37- 27
AA06 2304	Pressure Spring	33- 23
AA06 2305	Tension Spring	33- 10
AA06 2310	Pressure Spring	39- 5
AA06 2312	Pressurespring	49- 37
AA06 2313	Gate Pawl Spring 1.5N	49- 26
AA06 3303	Pressure Spring	51- 16
AA06 3304	Terminal Spring	33- 19
AA06 3305	Torsion Spring	41- 8
AA06 3371	Spring	57- 29
AA06 3499	Pressure Spring	27- 5
AA06 3561	Pressure Spring	39- 16
AA06 3563	Spring	11- 2
AA06 3564	Tension Spring	11- 14
AA06 3567	Tension Spring	27- 29
AA06 3568	Pressure Spring	27- 26
AA06 3569	Spring	27- 36
AA06 3570	Tension Spring	47- 37
AA06 3623	Pressure Spring	35- 8
AA06 3854	Pressure Spring	49- 6
AA06 3855	Spring - 3.5N	43- 19

Part No.	Description	Page and Index No.
AA06 6152	Tension Spring	53- 4
AA06 6335	Torsion Spring	55- 17
AA06 6574	Torsion Spring	25- 9
AA06 6575	Torsion Spring	43- 8
AA06 6576	Torsion Spring	43- 12
AA06 6577	Torsion Spring	33- 29
AA08 0034	Bushing - 4x5x7	51- 10
AA08 0227	Bushing - M4	51- 23
AA08 0227	Bushing - M4	53- 10
AA08 0229	Front Busing - M6	33- 26
AA08 0230	Rear Busing - M6	33- 22
AA08 0234	Bushing - 12x18x6	45- 30
AA08 0246	Bushing - Bias Roller	41- 26
AA08 0254	Bushing - M4	11- 15
AA08 2054	Bushing - M4	41- 32
AA08 2058	Bushing - 6x10x9mm	49- 39
AA08 2070	Bushing - 8x16x7	25- 8
AA08 2070	Bushing - 8x16x7	31- 8
AA08 2072	Bushing - M6	31- 26
AA08 2073	Roller Busing	47- 36
AA08 2074	Bushing - M8	53- 1
AA08 2075	Bushing - M6	55- 3
AA08 2079	Bushing - 6x8x5.8	43- 3
AA08 2080	Bushing - M8	33- 20
AA08 3010	Clutch Roller - 6x14x10	27- 30
AA08 3014	One-way Clutch	31- 29
AA12 0089	Antistatic Brush	49- 43
AA14 0140	Screw - M3X4.5	47- 34
AA14 0655	Shaft - Paper Feed	31- 28
AA14 0656	Shaft - Gear	31- 20
AA14 0660	Feed Shaft	27- 21
AA14 0666	Shaft - Hook	43- 9
AA14 3219	Stepped Screw	45- 7
AA14 3301	Stepped Screw - M3x4	63- 20
AA14 3301	Stepped Screw - M3x4	59- 44

Part No.	Description	Page and Index No.
AA14 3461	Stepped Screw - M2.5	55- 19
AA14 3499	Stepped Screw	69- 14
AA14 3501	Stepped Screw - M8	13- 24
AA14 3512	Stepped Screw - M2.5	63- 14
AA14 3520	Shoulder Screw - M3	47- 2
AA14 3520	Shoulder Screw - M3	9- 2
AA14 3523	Shoulder Screw - M3	9- 13
AA14 5810	Slide Shaft	35- 4
AA14 8447	Guide Pin - Platen Cover	15- 11
AA14 9291	Pin - Link	33- 11
AA14 9515	Gear Shaft	59- 30
AA15 0401	Seal - 70x20	41- 9
AA15 0684	Shield Plate	65- 4
AA15 0685	Seal - 215x10	13- 30
AA15 0702	Front Shield Plate	21- 7
AA15 0711	Shield -base	19- 5
AA15 2283	Ring - M12	45- 32
AA15 2403	Sponge - Laser Unit Cover	23- 7
AA15 3052	Entrance Seal - Toner Supply	45- 6
AA15 3053	Sponge - 317x5x5	45- 28
AA15 3054	Sponge - 17x7x5	45- 27
AA15 3062	Sponge - M46	45- 26
AA15 3070	Dehumidifier Sheet	13- 32
AA15 3077	Shield Case - Development	45- 29
AA15 3083	Seal - Toner Supply Unit Cover	35- 13
AA15 3390	Sponge - 202x3.5x4	13- 8
AA15 3391	Frame Seal - Rear Right	43- 33
AA15 3392	Sponge - 24x6x5	43- 11
AA15 3393	Frame Seal - Rear Vertical	43- 29
AA15 3442	Shield - Stay - PCU	65- 19
AA16 1125	Rubber Cushion	69- 10
AA16 1133	Cushion - 4x15x1	21- 18
AA16 1628	Link Cushion - 10x5x2	49- 40
AA16 2046	Cushion - 347x10x5	53- 7
AA16 2067	Platen Cover Pad	15- 2

Part No.	Description	Page and Index No.
AB01 0106	Gear - 24Z	31- 19
AB01 0107	Gear - 23Z	31- 17
AB01 1088	Gear - 30Z	55- 13
AB01 1188	Gear - 21Z	31- 3
AB01 1189	Gear - 18Z	31- 7
AB01 1190	Gear - 25Z	41- 34
AB01 1377	Gear - 14Z	37- 7
AB01 1378	Gear - 19Z	37- 12
AB01 1379	Gear - 19Z	37- 15
AB01 1380	Cam - Cleaning Blade	37- 14
AB01 1384	Gear - 29Z	45- 11
AB01 1386	Development Sleeve Gear	45- 12
AB01 1387	Gear - 23Z	27- 23
AB01 1388	Gear - Z16	27- 8
AB01 1389	Gear - 20Z	27- 7
AB01 1390	Gear - 27Z	27- 34
AB01 3485	Gear - 20Z	33- 33
AB01 3882	Gear - 40Z	47- 18
AB01 4038	Gear - 22Z	59- 9
AB01 4039	Gear - 31Z	59- 21
AB01 4040	Gear - 29Z	59- 23
AB01 4041	Gear - 37Z	57- 17
AB01 4042	Gear - 37Z	57- 18
AB01 4043	Gear - 39Z	57- 13
AB01 4045	Gear - 33Z	57- 12
AB01 4046	Gear - 25Z	47- 29
AB01 4048	Gear - 30Z	57- 2
AB01 4049	Gear - 24Z	49- 22
AB01 4051	Gear - 16Z	33- 27
AB01 4060	Gear - 21Z	45- 4
AB01 4061	Gear - 13Z	45- 3
AB01 4062	Gear - 17Z/25Z	45- 5
AB01 4090	Gear - 18Z	31- 39
AB01 4159	Gear - 49Z	59- 41
AB01 4160	Idler Gear-registration	59- 5

Part No.	Description	Page and Index No.
AB01 4161	Reverse Roller Gear	53- 23
AB01 4162	Gear - 46Z	53- 19
AB01 4164	Gear - 28T	59- 43
AB01 4189	Gear - 27Z	41- 12
AB01 4219	Gear - 24Z	59- 2
AB01 7454	Gear - 24Z/30Z	27- 32
AB01 7458	Gear Pulley - 18Z/22T	49- 20
AB01 7460	Gear - Pulley - 30Z/24T	57- 4
AB01 7461	Gear Pulley - 30Z/20T	57- 5
AB03 0474	Pulley - 24T	55- 2
AB03 0561	Timing Pulley - 31Z/20T	59- 17
AB03 0562	Timing Pulley - 31Z/20T	59- 14
AB03 0564	Pulley - M17	11- 33
AB03 0566	Timing Pulley - 20T	59- 32
AB03 0567	Timing Pulley - 18T	59- 28
AB03 0568	Pulley - 23T	49- 27
AB03 0572	Timing Pulley - Z61	21- 31
AB03 0574	Timing Pulley - 79T	57- 21
AB03 0584	Timing Pulley - 15T	11- 27
AB03 0590	Pulley - M17	59- 16
AB03 0625	Timing Pulley - 20Z	59- 3
AB03 0669	Timing Pulley - Resistration	33- 35
AB03 0670	Gear - 24Z	53- 18
AB03 0671	Gear Pulley - Rransport	55- 11
AB03 0672	Idlerpulley	49- 21
AB03 2061	Front Scanner Pulley	21- 37
AB03 2062	Rear Scanner Pulley	21- 30
AC00 1060	Platen Cover Ass'y	15- 9
AC01 2067	Exposure Glass	9- 4
AC01 5024	Shield Glass - Polygon Motor	23- 28
AC01 5025	Shield Glass	23- 8
AC03 0110	Scanner Mirror	21- 13
AC03 0115	Mirror	23- 16
AD01 5020	Drum Shaft	57- 31
AD02 1127	Receptacle	33- 18

Part No.	Description	Page and Index No.
AD02 5021	Pick-off Pawl	39- 3
AD02 7006	Charge Roller	39- 26
AD03 8078	Paddle	45- 24
AD04 3050	Toner Collection Coil	37- 5
AD04 4000	Toner Collection Mylar	37- 10
AD04 7023	Cleaning Entrance Seal	39- 8
AE01 1064	Hot Roller - 39.8mm T0.4	47- 17
AE02 0108	Pressure Roller	47- 22
AE03 0047	Ball Bearing - 30x42x7	47- 16
AE03 0048	Ball Bearing - 8x22x7	47- 21
AE04 2039	Fusing Cleaning Roller	47- 35
AE04 4030	Hot Roller Stripper	47- 6
AF01 3006	Bottom Plate Pad	29- 5
AF01 3016	Bottom Plate Pad	27- 6
AF01 6166	Front Side Fence	29- 3
AF01 6167	Rear Side Fence	29- 14
AF01 7026	End Fence	29- 6
AF02 0404	Transport Roller	31- 32
AF02 0409	Driven Roller	11- 16
AF02 0410	Registration Roller	33- 7
AF02 0509	Reverse Roller - Duplex	53- 12
AF02 0510	Exit Transport Roller	55- 4
AF02 0511	Reverse Roller - Driven	51- 3
AF02 0511	Reverse Roller - Driven	53- 9
AF02 0512	Driven Roller - Duplex	51- 17
AF02 0513	Transport Roller	55- 6
AF02 0514	Exit Roller	49- 33
AF02 0515	Transport Roller	49- 30
AF02 0516	Driven Roller	43- 21
AF02 1059	Driven Registration Roller	33- 8
AF02 5036	Duplex Junction Gate	51- 14
AF03 0034	Pick-up Roller	31- 1
AF03 0036	Pick Up Roller	27- 22
AF03 1035	Feed Roller	31- 6
AF03 1036	Feed Roller	27- 12

Part No.	Description	Page and Index No.
AF03 2035	Separation Roller	31- 36
AF03 2036	Separation Roller	27- 2
AF04 0031	Driven Roller	27- 18
AF04 0559	Driven Roller - M9	25- 23
AF04 0571	Guide Roller	49- 1
AF04 0571	Guide Roller	43- 16
AF04 0572	Pressure Roller - Entrance	49- 38
AF04 0573	Pressure Roller	49- 4
AF04 0574	Guideroller	49- 42
AF04 0575	Driven Roller	49- 11
AG05 0085	Registration Roller Knob	33- 28
AG05 0090	Knob - Hot Roller	47- 19
AG05 1137	Handle Lever	43- 32
AG07 0014	Magnet Catch	11- 20
AG07 1010	Magnet Catch	13- 9
AH01 0009	Rubber Pad - H5	21- 36
AH01 0009	Rubber Pad - H5	67- 9
AW01 0048	Photosensor - GP2A28N1	33- 17
AW01 0048	Photosensor - GP2A28N1	53- 3
AW01 0049	Photo Reflection Sensor	49- 17
AW01 0056	Original Sensor - H=2-66	19- 2
AW01 0059	Original Sennsor - H=1-66	19- 22
AW01 0090	Exit Sensor- Fusing	43- 36
AW02 0056	Photointerrupter - EE-SX4235A-P1	55- 15
AW02 0056	Photointerrupter - EE-SX4235A-P1	21- 19
AW02 0056	Photointerrupter - EE-SX4235A-P1	31- 31
AW02 0056	Photointerrupter - EE-SX4235A-P1	27- 19
AW02 0096	Photointerrupter	31- 35
AW02 0097	Photointerrupter	57- 10
AW02 0100	Photointerrupter - P1CH2MM	19- 8
AW02 0102	Photointerrupter	55- 9
AW10 0052	Thermistor - Center	47- 41
AW10 0053	Thermistor - Rear	47- 11
AW31 0006	Toner Overflow Sensor	41- 11
AX04 0078	DC Motor - 3W	59- 18

Part No.	Description	Page and Index No.
AX05 0168	DC Motor - Toner Bottle	57- 23
AX06 0141	Polygon Mirror Motor (B003/B006)	23- 9
AX06 0180	Polygon Mirror Motor (B004/B007)	23- 9
AX06 0205	Main Motor - DC 21W (B004/B007)	57- 35
AX06 0206	Main Motor - DC 17W (B003/B006)	57- 35
AX06 0207	Feed/dev. Motor - DC 30W (B004/B007)	59- 36
AX06 0208	Feed/dev. Motor - DC 24W (B003/B006)	59- 36
AX20 0138	Electrical Clutch - MICE-13	33- 21
AX20 0138	Electrical Clutch - MICE-13	59- 19
AX20 0140	Electrical Clutch	27- 31
AX20 0231	Magnetic Clutch - 0.5N M-28Z	59- 1
AX31 0039	Total Counter - 7fig 24v	13- 11
AX40 0137	Heater - 120V 9W	67- 14
AX40 0138	Heater - 230V 9W	67- 14
AX40 0140	Heater - 120V 15W	21- 42
AX40 0142	Heater - 240V 15W	21- 42
AX43 0063	Heater - 120V 550W 335mm	47- 14
AX43 0064	Heater - 230V 550W 335mm	47- 14
AX44 0128	Heater - 120V 650W 215mm	47- 42
AX44 0129	Heater - 230V 650W 215mm	47- 42
AX50 0046	Quenching Lamp	65- 10
AX50 0073	Xenon Lamp - 8.5MM	21- 8
AX64 0113	Fan Motor - 80mm	61- 1
AX64 0128	Fan Motor - 24V	19- 27
AZ24 0060	Power Supply Unit - 115V 302W (NA/TWN)	61- 14
AZ24 0061	Power Supply Unit - 230V 302W (EU/Asia)	61- 14
AZ24 0062	Power Supply Unit - 230V 302W (CHN)	61- 14
AZ32 0086	High Voltage Supply - Cbt	61- 5
AZ50 0055	Xenon Lamp Stabilizer	19- 13
B002 1891	LD Unit (B003/B006)	23- 26
B351 6511	Left Scale - (EU)(Asia)(CHN)(TWN)	9- 1
B351 6521	Left Scale (NA)	9- 1
B351 6522	ADF Exposure Glass	19- 4
G011 3305	Gear - 16T	25- 13
G020 1184	Flange - Fly Wheel	57- 20

Part No.	Description	Page and Index No.
G020 1189	Fly Wheel	57- 19
G020 1332	Hinge - Front Cover	11- 7
G020 1917	Decal - LD	83- 19
G020 1917	Decal - LD	23- 3
G020 1918	Decal - Laser Diode (230V)	23- 2
G020 1918	Decal - Laser Diode (230V)	83- 3
G020 1920	Decal - Laser Diode (115V)	83- 3
G020 1920	Decal - Laser Diode (115V)	23- 2
G020 1966	Cylindrical Lens	23- 12
G020 1968	F Theta Mirror	23- 22
G020 1969	BTL Lens	23- 19
G020 2620	Push Switch - Paper Size	59- 45
G021 9350	Loopback Connector - Parallel	85- 10
G034 1170	Duct - Main Frame - Left (GSA)	61- 3
G034 1253	Cover - Small - Upper Right	13- 33
G034 1373	Inner Cover - Right	43- 10
G034 1971	Sheet - Shading Plate	65- 16
G065 2280	Cleaning Pad	39- 13
G065 2290	Idler Bracket	37- 13
G404 2810	Spring Plate - Mirror - Second	21- 3
GA08 0002	Bushing - 6mm	27- 35
GC03 0020	Sync. Detector Mirror	23- 24
N607 4540	Choke Coil - RITL-9901 (120V)	61- 20
N607 4542	Choke Coil - RITL-0006 (230V)	61- 20
N607 6527	Fan Motor - DC 0.96W	61- 21

Part No.	Description	Page and Index No.
A006 9104	Adjusting Scanner Pin (4pcs/set)	85- 5
A028 9300	Grease Barrierta Jfe 55/2	85- 8
A029 9387	Digital Multimeter - Fluke87	85- 7
A053 1957	Flex Hinge - Platen Cover	15- 4
A134 1394	Front Platen Cover	15- 3
A134 1395	Rear Platen Cover	15- 5
A134 1396	Original Holder	15- 6
A134 2661	Feeler Roller	27- 17
A134 3180	Bottle Chuck	35- 11
A153 1370	Platen Cover Hinge	15- 8
A153 1380	Platen Cover Bracket	15- 10
A153 1383	Platen Cover Feeler	15- 7
A176 1317	Cap - 34x55	11- 22
A176 1317	Cap - 34x55	13- 6
A229 5216	Touch Panel	17- 17
A230 1268	Upper Cover - Paper Feed	11- 6
A230 2520	Heat Sink - Heater	67- 15
A230 2525	Stopper - Heater	67- 13
A230 2696	Front Grip	67- 5
A230 2699	Stopper - Front Grip	67- 4
A230 9003	Adjusting Cam - Laser Unit	85- 2
A230 9004	Positioning Pin Laser Unit	85- 1
A230 9351	Case - Flash Memory Card	85- 4
A230 9352	Flash Memory Card - 4mb	85- 3
A230 9510	OPC Drum	39- 29
A232 1071	Guide Rail - Development Unit	65- 14
A232 1072	Lower Stay - PCU	65- 22
A232 1072	Lower Stay - PCU	33- 6
A232 1075	Guide Rail - Fusing Unit	65- 11
A232 1081	Center Frame	65- 3
A232 1082	Left Stay - Paper Exit	65- 1
A232 1083	Bracket - Bridge Unit	65- 2
A232 1089	Upper Plate - Laser Unit	65- 5
A232 1094	Nut	13- 15
A232 1115	Fusing Relay Gear	57- 16

Part No.	Description	Page and Index No.
A232 1124	Bracket - Gear	57- 14
A232 1136	Bracket - Belt Stopper	57- 6
A232 1138	Belt Holder	57- 1
A232 1160	Bracket - Switch Lever	43- 24
A232 1161	Lever - Interlock Switch	43- 27
A232 1170	Left Duct	61- 3
A232 1171	Right Duct	61- 4
A232 1172	Duct - Cooling Fan	61- 2
A232 1173	Sheet - Duct	13- 20
A232 1177	Development Bracket	67- 2
A232 1251	Duct Cover - Lower Exhaust Ass'y	13- 23
A232 1252	Duct - Upper Cover	13- 7
A232 1257	Cap - Upper Cover	13- 29
A232 1266	Left Hinge - Front Cover	67- 1
A232 1267	Right Hinge - Front Cover	67- 10
A232 1272	Right Rear Cover	11- 26
A232 1282	Cap - Switch	11- 3
A232 1284	Spring Holder	13- 22
A232 1284	Spring Holder	37- 31
A232 1284	Spring Holder	33- 4
A232 1286	Stopper - Plate	11- 35
A232 1357	Left Cover - Scanner	9- 3
A232 1381	Decal - Total Counter	13- 10
A232 1381	Decal - Total Counter	83- 1
A232 1385	Decal - Indication	83- 2
A232 1677	Rear Scale	9- 5
A232 1681	Cushion - Lens Block	19- 16
A232 1682	Right Stay - Scanner Unit	19- 12
A232 1683	Spacer - Inner Cover	19- 15
A232 1707	Second Slide Rail	21- 40
A232 1712	Front Tension Plate - Scanner Wire	21- 38
A232 1713	Lens Block Supporter	21- 35
A232 1722	Rear Tension Plate - Scanner Wire	21- 24
A232 1728	Rail Supporter	21- 16
A232 1731	Scanner Rail	21- 27

Part No.	Description	Page and Index No.
A232 1732	Rail Bracket	21- 34
A232 1771	Busing - M8	21- 28
A232 1782	1st Scanner Ass'y	21- 10
A232 1788	Reflector	21- 12
A232 1789	1st Mirror Holder	21- 14
A232 1791	Front Wire Holder	21- 9
A232 1792	Rear Wire Holder	21- 11
A232 1798	2nd Scanner Ass'y	21- 6
A232 1808	Harness Guide	21- 5
A232 1839	Bracket - Sensor	21- 20
A232 1900	Housing - Laser Unit	23- 6
A232 1904	Cap - Laser Unit Cover	23- 4
A232 1918	Heat Sink - Polygon Motor	23- 10
A232 1920	Decal - Heat Sink	23- 11
A232 1921	Front Holder - F Theta Mirror	23- 20
A232 1922	Rear Holder - F Theta Mirror	23- 21
A232 1923	Front Holder - BTL	23- 17
A232 1924	Rear Holder - BTL	23- 18
A232 1925	Middle Mirror Holder	23- 15
A232 1926	Mirror Holder	23- 14
A232 1927	Cylindrical Lens Holder	23- 13
A232 1928	Holder - Sync. Detector Mirror	23- 23
A232 1937	Positing Pin - Laser Unit Ass'y	65- 23
A232 1971	Support Cover - Imaging Unit	23- 5
A232 2277	Seal - Drum Front	37- 34
A232 2278	Seal - Drum Rear	37- 35
A232 2279	Seal - Toner Supply-entrance	37- 40
A232 2280	Tape - Entrance Seal	39- 7
A232 2281	Cover - Cleaning Unit	37- 2
A232 2288	Shaft - Toner Collection Mylar	37- 9
A232 2289	Front Bushing - Collection Mylar	37- 8
A232 2290	Bushing - Collection Mylar	37- 11
A232 2292	Bushing - Toner Collection Coil	37- 6
A232 2293	Handle - PCU	37- 1
A232 2298	Bracket - Charge Cleaning	39- 10

Part No.	Description	Page and Index No.
A232 2300	Roller - Cleaning	39- 12
A232 2303	Front Arm - Charge Unit	39- 15
A232 2305	Rear Arm - Charge Unit	39- 23
A232 2308	Rear Terminal - Charge Roller	39- 24
A232 2310	Bracket - Cleaning Blade	39- 20
A232 2315	Front Bushing - Cleaning Bracket	39- 17
A232 2316	Stud - Cleaning Bracket	39- 1
A232 2318	Collar - Cleaning	39- 21
A232 2321	Shutter - Toner Supply	37- 28
A232 2322	Shield - Shutter - Toner Supply	37- 16
A232 2323	Front Cover - PCU	37- 21
A232 2328	Cap - Toner Supply	37- 20
A232 2329	Stopper - PCU	37- 18
A232 2339	Spur	39- 6
A232 2340	Holder - Pick-off Pawl	39- 4
A232 2348	Seal - Blade 12x7x3	37- 37
A232 2350	Seal - Entrance	37- 38
A232 2353	Cleaning Blade Ass'y	39- 22
A232 2354	Front Terminal - Charge Roller	39- 27
A232 2356	Stepped Screw - M6	39- 9
A232 2362	Stay - PCU	65- 8
A232 2365	Guide Rail - PCU	33- 1
A232 2366	Holder - ID Sensor	33- 3
A232 2367	ID Sensor	33- 5
A232 2372	Lock Lever - Transfer Unit	57- 7
A232 2379	Transfer Unit Clutch	57- 9
A232 2380	Terminal Plate - Charge Roller	57- 30
A232 2381	Harness - Charge Roller	57- 27
A232 2382	Terminal Plate - Development Bias	57- 28
A232 2383	Harness - Development Bias	57- 26
A232 2399	Seal - Blade 13x9.5x3	37- 36
A232 2403	Receptacle - Charge Roller	37- 17
A232 2406	Lower Frame - OPC	39- 2
A232 2408	Spring Plate	37- 19
A232 2412	Seal - 2x7x14.5	37- 26

Part No.	Description	Page and Index No.
A232 2413	Seal - Front Lower	37- 23
A232 2414	Seal - 2x20x45	37- 24
A232 2416	Seal - 1x3x80	37- 25
A232 2417	Seal - 1x7x12.5	37- 22
A232 2419	Left Seal - Cleaning Cover	37- 4
A232 2420	Right Seal - Cleaning Cover	37- 3
A232 2421	Bushing - 6x10x3	39- 25
A232 2574	Upper Entrance Guide	33- 9
A232 2578	Stopper - Guide Plate	33- 25
A232 2583	Lower Entrance Guide	33- 15
A232 2594	Bracket - Registration Sensor	33- 14
A232 2596	Link Lever	33- 12
A232 2692	Cover - Paper Drive	59- 6
A232 2705	Tightener - Paper Feed	59- 12
A232 2720	Gear Bracket	11- 30
A232 2722	Knob	11- 32
A232 2723	Support Plate - Knob	11- 23
A232 2724	Knob Cover	11- 29
A232 2760	Housing - Paper Feed Unit	31- 9
A232 2762	Paper End Feeler	31- 13
A232 2763	Pick-up Arm	31- 2
A232 2764	Rear Grounding Plate	31- 27
A232 2765	Front Grounding Plate	31- 10
A232 2766	Feed Mylar	31- 40
A232 2770	Stay - Paper Separation	31- 18
A232 2774	Pressure Lever	31- 21
A232 2775	Link Lever	31- 22
A232 2776	Release Lever	31- 15
A232 2780	Stay - Paper Feed	31- 33
A232 2781	Sensor Bracket	31- 34
A232 2785	Vertical Guide	31- 41
A232 2786	Guide Plate	31- 24
A232 2787	Vertical Transport Guide	31- 25
A232 2857	Cover - Vertical Transport	11- 21
A232 2858	Upper Support Plate	11- 25

Part No.	Description	Page and Index No.
A232 2859	Lower Support Plate	11- 18
A232 2860	Entrance Seal	11- 24
A232 2860	Entrance Seal	11- 17
A232 2862	Driven Roller	11- 36
A232 2863	Stopper Band	11- 13
A232 2876	Lower Cover - Vertical Transport	11- 11
A232 2882	Bracket - Micro Switch	59- 26
A232 2975	Bottom Lift Plate	29- 10
A232 2987	Roller - Paper Tray	29- 11
A232 2989	Screw Holder	29- 15
A232 2990	Guide Rail - Paper Tray	67- 8
A232 2995	Front Positioning Guide	67- 7
A232 2996	Rear Positioning Guide	67- 12
A232 3066	Decal - Development Unit	45- 31
A232 3066	Decal - Development Unit	83- 4
A232 3067	Tape - TD Sensor	45- 17
A232 3068	Front Bias Terminal - Development	45- 19
A232 3069	Rear Bias Terminal - Development	45- 20
A232 3077	Spacer - M5	45- 33
A232 3081	Flange - Paddle	45- 22
A232 3096	Flange - Side Plate	45- 21
A232 3131	Front Shield - Development Sleeve	45- 10
A232 3132	Rear Shield - Development Sleeve	45- 8
A232 3150	Entrance Seal Ass'y	45- 14
A232 3155	Front Cover - Development Unit	45- 2
A232 3230	Case - Toner Supply Ass'y	35- 6
A232 3240	Cover- Toner Bottle Ass'y	35- 12
A232 3251	Chuck Shaft	35- 9
A232 3252	Slider Ass'y	35- 10
A232 3261	Handle - Toner Supply	35- 5
A232 3263	Spring Plate - Toner Bottle	35- 7
A232 3264	Stopper - Slide Rail	65- 25
A232 3266	Seal - Slide Rail	35- 2
A232 3267	Seal - Toner Supply-entrance-front	37- 39
A232 3552	Ball Bearing - 8x22x7	57- 24

Part No.	Description	Page and Index No.
A232 3552	Ball Bearing - 8x22x7	59- 29
A232 3553	Ball Bearing - 8x16x5	39- 28
A232 3566	Ball Bearing - 8x16x5	21- 29
A232 3830	Cleaning Blade - Transfer Belt	41- 21
A232 3880	Transfer Belt	41- 23
A232 3882	Frange - Transfer Unit	41- 35
A232 3883	Spring Plate - Transfer Unit	41- 30
A232 3885	Driven Roller - Transfer Unit	41- 29
A232 3887	Rear Terminal - Transfer Belt	41- 31
A232 3889	Bias Roller	41- 28
A232 3891	Bias Terminal	41- 33
A232 3893	Arm - Transfer Belt	41- 25
A232 3894	Drive Roller - Transfer Belt	41- 24
A232 3903	Tape - Entrance Mylar	41- 17
A232 3905	Seal - Shield Plate	41- 18
A232 3906	Seal - Rear Transfer Exit	41- 36
A232 3907	Seal - Transfer Exit	41- 19
A232 3908	Seal - Rear Case	41- 15
A232 3909	Seal - Front Case	41- 22
A232 3911	Rear Lever - Transfer Belt	41- 5
A232 3912	Front Lever - Transfer Belt	41- 6
A232 3916	Pressure Lever - Transfer Belt	41- 4
A232 3917	Release Lever - Transfer Belt	41- 14
A232 3921	Spring Anchor	41- 7
A232 3923	Bracket - Cleaning Blade	41- 20
A232 3924	Rear Bushing - Cleaning Holder	41- 13
A232 3925	Front Bushing - Cleaning Holder	41- 2
A232 3926	Transfer Belt Roller	41- 38
A232 3927	Shield - Transfer Belt - Exit	41- 39
A232 3935	Shaft - Transfer Unit Stopper	41- 3
A232 3940	Right Cover	43- 4
A232 3941	Fulcrum Pin - Right Cover	43- 1
A232 3942	Stopper - Right Cover	43- 2
A232 3945	Front Hook - Right Cover	43- 7
A232 3948	Rear Hook - Right Cover	43- 13

Part No.	Description	Page and Index No.
A232 3950	Hook Lever	43- 30
A232 3962	Spring Plate - Band Stopper	43- 23
A232 3963	Band Stopper	43- 22
A232 3977	Shield Cover	43- 6
A232 3985	Link - Cover	33- 30
A232 3991	Decal - Shield Cover	43- 5
A232 3991	Decal - Shield Cover	83- 5
A232 3998	Upper Entrance Guide	43- 15
A232 3999	Lower Entrance Guide	43- 14
A232 4051	Frame - Fusing Unit	47- 28
A232 4053	Fusing Lower Shield	47- 27
A232 4057	Front Collar - Pressure Lever	47- 24
A232 4058	Rear Collar - Pressure Lever	47- 30
A232 4059	Positioning Plate - Pressure Lever	47- 23
A232 4064	C Ring - Hot Roller	47- 15
A232 4123	Upper Fusing Entrance Guide	47- 38
A232 4201	Stopper - Fusing Unit	65- 12
A232 4484	Solenoid - Exit Gate	49- 36
A232 4497	End Fence - Copy Tray	13- 1
A232 4499	Copy Tray Mylar	13- 28
A232 4647	Driven Guide Plate	51- 13
A232 4653	Pressure Plate - Guide Plate	51- 9
A232 4684	Handle - Unit Release	53- 2
A232 4685	Hook - Unit Release	53- 5
A232 4720	Inner Cover - Duplex Unit	51- 1
A232 4730	Rear Inner Cover	51- 6
A232 4757	Bracket - Feed Sensor	55- 8
A232 4780	Pin - Stopper	65- 20
A232 4790	Link - Duplex Unit	55- 20
A232 4793	Bracket - Link Lever	51- 8
A232 4810	Harness Cover - Duplex Unit	51- 7
A232 5355	IC - GATEX	73- 1
A232 5403	Harness - IOB / PFB	63- 1
A232 5405	Main Harness - Paper Feed	59- 22
A232 5410	Connector - Finisher	61- 17

Part No.	Description	Page and Index No.
A232 5420	Harness - Registration Sensor	33- 16
A232 5427	Harness By-pass Feed	27- 28
A232 5428	Harness - Paper Feed Unit	31- 30
A232 5437	Relay Harness - Ccharge Contact Sensor	57- 11
A232 5444	Harness - Laser Unit (B004/B007)	23- 27
A232 5445	Harness - Laser Unit (B003/B006)	23- 27
A232 5526	Power Supply Cord - 115V	61- 13
A232 5527	Power Supply Cord - 230V	61- 13
A232 5528	Power Supply Cord - 230V (CHN)	61- 13
A232 5837	Rear Grounding Plate	13- 35
A232 5838	Spring Plate - BICU	11- 34
A232 5860	Bracket - Interlock Switch	63- 13
A232 5861	Lever - Interlock Switch	63- 12
A232 5862	Cover - Switch Lever	63- 16
A232 5865	Lever - Push Switch	63- 18
A232 6009	By-pass Feed Table Ass'y	25- 24
A232 6010	Support Stay	25- 25
A232 6022	Housing - By-pass Feed	27- 13
A232 6023	Grounding Plate - Reverse	27- 15
A232 6028	Guide Plate Paper Separator	27- 10
A232 6033	Shaft Driven Roller	27- 4
A232 6035	Shaft - Drive Roller	27- 9
A232 6038	Gear Cover	27- 11
A232 6043	Arm Paper Pick Up	27- 20
A232 6044	Support Plate	27- 24
A232 6046	Grounding Plate - Feed	27- 25
A232 6049	Solenoid Bracket	27- 37
A232 6051	Pickup Solenoid	27- 27
A232 6055	Paper End Feeler	27- 16
A232 6057	Bracket-by-pass Feed Drive	27- 40
A232 6059	Arm Tightener	27- 33
A232 6061	Tightener Bracket	27- 38
A232 6065	Rail - By-pass Feed	27- 39
A232 6067	By - Pass Feed Table	25- 10
A232 6068	Cover By-pass Table	25- 11

Part No.	Description	Page and Index No.
A232 6069	Front Side Fence	25- 21
A232 6070	Rear Side Fence	25- 19
A232 6071	Sub - Front Fence	25- 22
A232 6072	Sub - Rear Fence	25- 20
A232 6073	Decal - By-pass Feed	25- 16
A232 6073	Decal - By-pass Feed	83- 6
A232 6080	Paper Size Detector	25- 15
A232 6082	Front Rack	25- 12
A232 6083	Rear Rack	25- 14
A232 6085	Guide By - Pass Table	25- 17
A232 6090	Bracket Positioning Pin	25- 6
A232 6091	Positioning Pin	25- 7
A232 6092	Roller - Holder	25- 18
A232 6095	Frame By-pass Unit Holder	25- 2
A232 6106	Middle Lower Cover	25- 1
A232 6107	Middle Upper Cover	25- 5
A232 6108	Rear Cover - By-pass Unit	25- 4
A232 6109	Front Cover - By-pass Unit	25- 3
A232 6780	Decal - ON (CHN)	83- 24
A232 6780	Decal - ON (CHN)	11- 37
A232 6781	Decal - Stand-by (CHN)	83- 23
A232 6781	Decal - Stand-by (CHN)	11- 38
A232 7210	Drum Holder	57- 25
A232 7234	Sheet - Switch (LT)	17- 25
A232 7365	Upper Frame - PCU	37- 30
A232 7634	Sheet - Switch (A4)	17- 25
A232 7756	Harness - Circuit Breaker	61- 19
A232 7757	Bracket - Circuit Breaker	61- 18
A267 3455	Magnetic - Discharge Lamp	65- 9
A284 1021	Shield - Stay - PCU - Lower	65- 18
A284 1372	Inner Cover-upper	13- 13
A284 1376	Inner Cover-left	13- 12
A284 1384	Decal - Operation	83- 7
A284 1390	Decal - Value Station	83- 8
A284 1674	Exposure Glass Holder	21- 41

Part No.	Description	Page and Index No.
A284 1735	Front Side Plate	21- 39
A284 1736	Rear Side Plate	21- 17
A284 1738	Hinge Bracket	19- 7
A284 1751	Scanner Motor Stopper	19- 20
A284 1904	Cover - Optical Housing	23- 1
A284 2783	Torque Limiter	27- 3
A284 5842	Gasket - Rack	69- 5
A284 8503	Operating Manual - Copy	83- 20
A285 5893	Card Cover	69- 8
A292 9500	Test Chart - S5s (10 Pcs/set)	85- 6
A293 5310	Sync Detector Board	23- 25
A680 1181	Magnetic Catch	51- 19
A877 8520	Operating Manual - System	83- 21

Part No.	Description	Page and Index No.
5203 9502	Grease 501	85- 9
5206 2686	Snap Ring	31- 16
5206 2686	Snap Ring	11- 12
5206 2686	Snap Ring	65- 15
5206 2686	Snap Ring	45- 13
5206 2686	Snap Ring	33- 13
5216 4198	Stepped Screw - Guide Plate	27- 14
5447 2681	Snap Ring	31- 5
5447 2681	Snap Ring	39- 14
5447 2681	Snap Ring	43- 31
5447 2681	Snap Ring	49- 41
5447 2681	Snap Ring	51- 5
5447 2681	Snap Ring	27- 1
5448 2804	Platen Cover Sheet	15- 1

Part No.	Description	Page and Index No.
0313 0060B	Philips Pan Head Screw - M3x6	33-108
0313 0060B	Philips Pan Head Screw - M3x6	55-109
0314 0060B	Philips Pan Head Screw - M4x6	21-112
0314 0120B	Philips Pan Head Screw - M4x12	19-102
0314 0180B	Philips Pan Head Screw - M4x18	19-106
0353 0040B	Screw - M3X4	49-101
0353 0040B	Screw - M3X4	27-105
0353 0060B	Philips Pan Head Screw - M3x6	19-103
0353 0060B	Philips Pan Head Screw - M3x6	29-102
0353 0060B	Philips Pan Head Screw - M3x6	33-102
0353 0120B	Bind Screw - M3x12	53-107
0354 0080B	Screw - M4X8	13-102
0414 0142B	Binding Self Tapping Screw - M	15-101
0450 3006B	Tapping Screw - M3x6	13-103
0450 3006B	Tapping Screw - M3x6	39-103
0450 3006B	Tapping Screw - M3x6	49-105
0450 3008B	Tapping Screw - M3x8	45-105
0450 3008B	Tapping Screw - M3x8	21-105
0450 3008B	Tapping Screw - M3x8	27-106
0450 3008B	Tapping Screw - M3x8	23-103
0450 3008B	Tapping Screw - M3x8	43-102
0450 3008B	Tapping Screw - M3x8	41-103
0450 3008B	Tapping Screw - M3x8	39-101
0450 3008B	Tapping Screw - M3x8	37-101
0450 3008B	Tapping Screw - M3x8	11-105
0450 3008B	Tapping Screw - M3x8	35-102
0450 3008B	Tapping Screw - M3x8	33-106
0450 3008H	Tapping Screw M3x8	51-103
0450 3010B	Tapping Screw - M3x10	45-106
0450 3010B	Tapping Screw - M3x10	45-101
0450 3010B	Tapping Screw - M3x10	23-102
0450 3012B	Tapping Screw -3x12	11-106
0450 4008B	Tapping Screw - 4x8	29-103
0450 4010B	Tapping Screw - 4x10	39-104
0450 4035B	Philips Tapping Screw - M4x35	61-109

Part No.	Description	Page and Index No.
0451 3006B	Tapping Screw - M3x6	67-101
0451 3006B	Tapping Screw - M3x6	69-101
0451 3006B	Tapping Screw - M3x6	61-102
0451 3006B	Tapping Screw - M3x6	39-107
0451 3006B	Tapping Screw - M3x6	33-101
0451 3006B	Tapping Screw - M3x6	41-101
0451 3006B	Tapping Screw - M3x6	47-108
0451 3006B	Tapping Screw - M3x6	53-104
0451 3006B	Tapping Screw - M3x6	59-106
0451 3006B	Tapping Screw - M3x6	63-104
0451 3006B	Tapping Screw - M3x6	11-102
0451 3006B	Tapping Screw - M3x6	57-101
0451 3006B	Tapping Screw - M3x6	55-102
0451 3006B	Tapping Screw - M3x6	13-104
0451 3006B	Tapping Screw - M3x6	19-101
0451 3006B	Tapping Screw - M3x6	43-101
0451 3006B	Tapping Screw - M3x6	21-101
0451 3006B	Tapping Screw - M3x6	51-102
0451 3006B	Tapping Screw - M3x6	49-106
0451 3006B	Tapping Screw - M3x6	65-101
0451 3006B	Tapping Screw - M3x6	47-101
0451 3008B	Tapping Screw - M3x8	47-102
0451 3008B	Tapping Screw - M3x8	57-102
0451 3008B	Tapping Screw - M3x8	65-102
0451 3008B	Tapping Screw - M3x8	39-102
0451 3008B	Tapping Screw - M3x8	27-101
0451 3008B	Tapping Screw - M3x8	31-101
0451 3008B	Tapping Screw - M3x8	25-104
0451 3008B	Tapping Screw - M3x8	19-105
0451 3008H	Tapping Screw - M3x8	43-103
0451 3008H	Tapping Screw - M3x8	61-105
0451 3008H	Tapping Screw - M3x8	11-101
0451 3008H	Tapping Screw - M3x8	59-108
0451 3008H	Tapping Screw - M3x8	9-101
0451 3008H	Tapping Screw - M3x8	25-101

Part No.	Description	Page and Index No.
0451 3008H	Tapping Screw - M3x8	13-101
0451 3008H	Tapping Screw - M3x8	51-101
0451 3010H	Tapping Screw - 3x10	9-103
0451 3012H	Tapping Screw - 3x12	9-102
0451 3014B	Tapping Screw - M3-14	59-104
0451 3014B	Tapping Screw - M3-14	57-107
0451 4006B	Tapping Screw - 4x6	67-103
0451 4010B	Tapping Screw - 4x10	25-105
0452 3008B	Tapping Screw - M3x8	29-104
0452 3010B	Tapping Bind Screw - M3x10	35-101
0534 0050E	Headless Screw - M4 X 5	57-106
0575 0050E	Hexagon Headless Set Screw - M5x5	21-108
0720 0015E	Retaining Ring - 1.5	39-106
0720 0020E	Retaining Ring - M2	33-109
0720 0030E	Retaining Ring - M3	45-102
0720 0030E	Retaining Ring - M3	11-104
0720 0030E	Retaining Ring - M3	47-105
0720 0030E	Retaining Ring - M3	53-105
0720 0030E	Retaining Ring - M3	49-102
0720 0030E	Retaining Ring - M3	43-105
0720 0040E	Retaining Ring - M4	45-104
0720 0040E	Retaining Ring - M4	33-104
0720 0040E	Retaining Ring - M4	39-105
0720 0040E	Retaining Ring - M4	27-103
0720 0040E	Retaining Ring - M4	31-102
0720 0040E	Retaining Ring - M4	37-102
0720 0040E	Retaining Ring - M4	55-106
0720 0040E	Retaining Ring - M4	49-103
0720 0060E	Retaining Ring - M6	25-103
0720 0060E	Retaining Ring - M6	53-101
0720 0060E	Retaining Ring - M6	33-103
0720 0060E	Retaining Ring - M6	21-102
0720 0060E	Retaining Ring - M6	43-104
0720 0060E	Retaining Ring - M6	29-101
0720 0060E	Retaining Ring - M6	11-103

Part No.	Description	Page and Index No.
0720 0060E	Retaining Ring - M6	31-103
0720 0060E	Retaining Ring - M6	57-110
0720 0060E	Retaining Ring - M6	59-102
0720 0080E	Retaining Ring - M8	57-109
0725 0110E	C Ring - M11	45-103
0801 0149	Philips Pan Head Screw - M4x6	47-104
0801 0149	Philips Pan Head Screw - M4x6	61-107
0802 5276	Tapping Screw With Washer - M3x6	53-102
0802 5276	Tapping Screw With Washer - M3x6	57-108
0802 5276	Tapping Screw With Washer - M3x6	55-105
0802 5276	Tapping Screw With Washer - M3x6	21-111
0804 6075	Hexagonal Bolt - M3x8	47-106
0804 6075	Hexagonal Bolt - M3x8	9-104
0805 0089	Retaining Ring - M4	31-105
0805 3480	Bushing - 6mm	59-101
0805 3480	Bushing - 6mm	55-101
0805 3480	Bushing - 6mm	31-104
0805 3480	Bushing - 6mm	27-102
0950 4006M	Philips Screw With Flat Washer - M4x6	63-105
0951 3006B	Philips Screw With Flat Washer - M3x6	41-102
0951 3006B	Philips Screw With Flat Washer - M3x6	21-103
0951 3008B	Philips Screw With Flat Washer-m3x8	23-101
0954 3012B	Screw - M3X12	47-103
0957 3012B	Double Sems Screw - M3 X 12	47-107
1005 0728	Rivet - NRP335	21-104
1100 1474	Test Pin	81-101
1102 2391	Connector - HIF3FB-40PA-2.54DSA	81-102
1102 3566	Connector - S8B-XH-A(8pin)	81-103
1102 3822	Connector - 20P	73-101
1102 5305	Connector - 6P	77-101
1102 5306	Connector - 7P	73-102
1102 6245	Relay Connector - 2P	63-112
1102 6246	Relay Connector - 3P	63-109
1102 6246	Relay Connector - 3P	33-107
1102 6249	Relay Connector - 6P	63-108

Part No.	Description	Page and Index No.
1102 6256	Relay Connector - 13P	63-115
1102 6260	Relay Connector - 3P	63-110
1102 6261	Relay Connector - 4P	63-107
1102 6263	Connector - 6P	63-111
1102 6266	Relay Connector - 9P	63-114
1102 6297	Connector - 4P	81-104
1102 6297	Connector - 4P	77-102
1102 6299	Connector - 6P	73-103
1102 6301	Connector - 8P	73-104
1102 6306	Connector - 13P	73-105
1102 6311	Connector - 4P	73-106
1102 6319	Connector - 12P	73-107
1102 6334	Connector - 3P	73-108
1102 6339	Connector - 8P	73-109
1102 6341	Connector - 10P	73-110
1102 6342	Connector - 11P	73-111
1102 6354	Connector	73-112
1102 6396	Connector - 1P	73-113
1102 6401	Connector - 26P	73-114
1102 6402	Connector - 2P	73-115
1102 6595	Connector - 11P	77-103
1102 6789	Connector - 100P	81-105
1102 6815	Connector - 53258-0410	81-106
1102 6896	Connector - 50P	73-116
1102 6943	Relay Connector -10p	63-113
1102 7196	Connector - 50P	77-104
1102 7389	Connector - FH12-50S-0.5SV	77-105
1102 7456	Connector 176125-5	77-106
1102 7672	Connector - 54111-1615	59-107
1102 7700	Connector - 50P	73-117
1102 7729	Connector - DX10G1M-50SE	77-107
1102 8153	Connector - FCN-568P068-G/05A-V4	81-107
1102 8189	Dimm Connector - 54534-1440	81-108
1102 8243	Connector - FH12-33S-0.5SV	77-108
1102 8272	Connector - TX25-100P-12ST-H1	77-109

Part No.	Description	Page and Index No.
1102 8355	Connector - Dimm - DMM2-SD72A-1131	81-109
1102 8358	Connector - WR-100P-VF60-1	81-110
1102 8523	Connector - 57RE-40360-830B(D7A)	81-111
1102 8567	Connector - 52775-0800	81-112
1104 0588	Dip Socket - 28p	81-113
1105 0162	Locking Support	19-104
1105 0162	Locking Support	21-110
1105 0165	Flat Cable Clamp	43-106
1105 0267	Harness Clamp - YMC-10-0	67-106
1105 0267	Harness Clamp - YMC-10-0	27-104
1105 0267	Harness Clamp - YMC-10-0	65-104
1105 0267	Harness Clamp - YMC-10-0	59-105
1105 0283	Clamp	33-105
1105 0283	Clamp	31-106
1105 0283	Clamp	55-107
1105 0290	Harness Clamp - Horizontal	65-105
1105 0291	Harness Clamp - LWS-3S	21-107
1105 0291	Harness Clamp - LWS-3S	55-103
1105 0291	Harness Clamp - LWS-3S	65-106
1105 0291	Harness Clamp - LWS-3S	61-101
1105 0292	Wire Saddle	21-106
1105 0292	Wire Saddle	21-113
1105 0310	Harness Clamp - LWS-1S	61-103
1105 0328	Harness Clamp - ES-0505	55-104
1105 0328	Harness Clamp - ES-0505	53-108
1105 0328	Harness Clamp - ES-0505	57-103
1105 0329	Clamp - ES-0510	57-104
1105 0349	Edge Saddle	65-103
1105 0349	Edge Saddle	25-102
1105 0349	Edge Saddle	67-105
1105 0349	Edge Saddle	57-105
1105 0437	Locking Support - FGS-4S	61-108
1105 0460	Clamp	53-103
1105 0460	Clamp	21-109
1105 0487	Harness Clamp	67-104

Part No.	Description	Page and Index No.
1105 0488	Harness Clamp	67-102
1105 0511	Harness Clamp - LWS-0306ZC	49-104
1107 0472	Circuit Breaker - W28xQ1A 8A 25V	61-106
1107 0629	Fuse (Ceramic Case) - 15A - 125V	61-112
1107 0907	Fuse - 6.3A 125V (120V)	61-110
1107 0908	Fuse - 10A 125V (120V)	61-111
1107 0910	Fuse - 2A 125V (120V)	61-113
1107 0920	Fuse - 6.3A 250V (230V)	61-110
1107 0922	Fuse - 2A 250V (230V)	61-113
1107 0979	Fuse - LM20 TOMEI	61-111
1204 1385	Push Switch	81-114
1204 1542	Dip Switch	81-115
1204 2466	Micro Switch - V-16506-1c25	53-106
1204 2466	Micro Switch - V-16506-1c25	59-103
1204 2466	Micro Switch - V-16506-1C25	63-101
1204 2466	Micro Switch - V-16506-1c25	55-108
1204 2477	Locker Switch - AC250V 10A	63-102
1204 2480	Dip Switch - Dss808	73-118
1204 2521	Micro Switch	63-103
1400 0392	Transistor - DTC114EK	77-110
1400 0398	Transistor - 2SC2412K	77-111
1400 0398	Transistor - 2SC2412K	73-119
1400 0556	Transistor - DTB143EK	73-120
1400 0591	Transistor - DTC113ZK	81-116
1401 1055	Fet - SI9934DY	81-117
1402 0595	Diode Array - DAN202K	81-118
1402 1142	Diode Array - DAN217	73-121
1402 1265	Diode - RB411D	81-119
1402 1322	Diode Array - DAN202U	73-122
1402 1336	Diode - 1SS355	77-112
1402 1336	Diode - 1SS355	73-123
1402 1345	Diode - UDZ3.6B	77-113
1402 1378	Diode - PTZ12A	73-124
1402 1380	Diode - PTZ 6.2A	77-114
1402 1380	Diode - PTZ 6.2A	73-125

Part No.	Description	Page and Index No.
1402 1444	Diode - RB051L-40	81-120
1402 1572	Diode - HZU3ALL	73-126
1403 0907	Diode - SML-310LT	77-115
1403 0907	Diode - SML-310LT	81-121
1403 0978	LED - SML-310DT	77-116
1404 0360	Thermistor - 103HT	73-127
1407 1535	IC - TD62308AP	73-128
1407 1596	TTLIC - SN74LS14NS	73-129
1407 1880	TTLIC - SN74LS04NS	73-130
1407 2187	TTLIC - SN74LS07NS	81-122
1407 2187	TTLIC - SN74LS07NS	77-117
1407 2187	TTLIC - SN74LS07NS	73-131
1407 2218	TTLIC - SN74LS06NS	77-118
1407 2219	IC - TD62003AP	73-132
1407 3008	TTL - SN74ALS244CNS	77-119
1407 3290	IC - TC74HC02AF	73-133
1407 4687	IC - TA8083F	73-134
1407 4771	IC - MC68334GFC16	77-120
1407 4827	IC - MBM29F400BC-70PFTN-SFK	77-121
1407 4876	CMOS IC - 74VHC244 TSSOP	77-122
1407 4879	CMOS IC - 74VHC74 TSSOP	77-123
1407 4913	IC - 74VHC244	81-123
1407 5040	IC - SN74LVC161284DL	81-124
1407 5085	IC - TC4066BF(N)	73-135
1407 5090	IC - DS90CF364MTD	77-124
1407 5273	CPU - RM5231-200Q-REV1.2C	81-125
1407 5274	CMOS Logic - 74LVCH162244A TSSOP	81-126
1407 5275	CMOS Logic - 74LVCHR16245A TSSOP	81-127
1407 5278	Clock Generator - ICS9148BF-17	81-128
1407 5324	RAM - M48T35AV-10PC1	81-129
1407 5327	CMOS Logic - 74LVC139A TSSOP	81-130
1407 5328	CMOS Logic - 74ALVCH162827 TSSOP	81-131
1407 5337	CMOS Logic - 74LVCH16373A TSSOP	81-132
1408 0892	IC - RH5VI30A	77-125
1408 1041	IC - MB3793-42	77-126

Part No.	Description	Page and Index No.
1408 1065	Comparator BA10339F	73-136
1408 1095	IC - BA10324AF	73-137
1408 1295	IC - UPC2933T	77-127
1408 1470	Series Regulator - TA18M025F(LBS1.S)	77-128
1408 1514	IC - M62293FP	81-133
1408 1538	IC - M62032AFP	81-134
1503 0460	Oscillator - 32.768KHZ	77-129
1503 0842	Oscillator - 14.31818mhz	81-135
1503 0865	Oscillator - 9.8304MHZ	73-138
1503 0936	Crystal Oscillator - 19.6608Mhz	77-130
1503 0937	Crystal Oscillator - 40.97Mhz	77-131
1601 5414	Resistor - 330 Ω $\pm$ 5% 1W	73-139
1601 7751	Resistor - 4.7K Ω $\pm$ 5%	77-132
1601 7752	Resistor Array - 10K Ω $\pm$ 5%	73-140
1601 7752	Resistor Array - 10K Ω $\pm$ 5%	77-133
1601 7759	Resistor Array - 100k Ω $\pm$ 5% 0.063W	77-134
1601 7791	Resistor Array - 1K Ω $\pm$ 5%	73-141
1601 7791	Resistor Array - 1K Ω $\pm$ 5%	77-135
1601 7796	Resistor Array - 2.2KO	77-136
1601 7814	Resistor - 3.3k Ω $\pm$ 5%	77-137
1601 7867	Resistor - 33 Ω $\pm$ 5% 1/16W	81-136
1601 7867	Resistor - 33 Ω $\pm$ 5% 1/16W	77-138
1601 7869	Resistor - 1.2k Ω $\pm$ 5% 1/16W	77-139
1601 7887	Resistor Array - 10k Ω $\pm$ 5% 1/32W	81-137
1601 7896	Resistor Array - 56 Ω $\pm$ 5% 1/32W	81-138
1601 7898	Resistor Array	81-139
1601 7899	Resistor Array - 56 Ω $\pm$ 5% 1/16W	77-140
1601 7909	Resistor Array - 10 Ω $\pm$ 5% 1/32W 1005	81-140
1604 4683	Capacitor - 100 μ F $\pm$ 20% 10V	81-141
1604 4822	Capacitor - 220 μ F $\pm$ 20% 10V	81-142
1605 0781	Capacitor - 5pF 50V	77-141
1605 0878	Capacitor - 13PFpF $\pm$ 5% 50V	81-143
1605 0927	Capacitor - 1000pF $\pm$ 5% 25V	81-144
1605 0989	Capacitor - 0.22 μ F +80 -20% 16V	77-142
1605 1084	Capacitor - 0.68 μ F $\pm$ 10% 10V	77-143

Part No.	Description	Page and Index No.
1605 1085	Ceramic Capacitor - 0.082Uf $\pm$ 10% 16V	81-145
1605 1124	Capacitor - 4.7 μ F +80 -20% 10V	81-146
1605 1162	Capacitor - 10 μ F +80 -20% 10V	81-147
1607 1206	Filter - Acc2012I-250	81-148
1607 1223	Inductor - 47uh $\pm$ 20% 2.7A	81-149
1607 1227	Inductor - SLF12575-150M4R7	81-150
1630 1221	Resistor - 220 Ω $\pm$ 5% 1/4W	73-142
1630 2221	Resistor - 220 Ω	73-143
1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	77-144
1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	73-144
1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	73-145
1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	77-145
1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	81-151
1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	73-146
1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	77-146
1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	81-152
1630 4104	Resistor - 100 Ω $\pm$ 5% 1/16W	73-147
1630 4104	Resistor - 100 Ω $\pm$ 5% 1/16W	77-147
1630 4105	Resistor - 1.0M Ω $\pm$ 5% 1/16W	73-148
1630 4105	Resistor - 1.0M Ω $\pm$ 5% 1/16W	77-148
1630 4106	Resistor - 10m Ω $\pm$ 5% 1/16W	77-149
1630 4122	Resistor - 1.2K Ω 5% 1/16W	81-153
1630 4161	Resistor - 160 Ω $\pm$ 5% 1/16W	73-149
1630 4204	Resistor - 200K Ω $\pm$ 5% 1/16W	73-150
1630 4220	Resistor - 22 Ω $\pm$ 5% 1/16W	81-154
1630 4222	Resistor - 2.2K Ω $\pm$ 5%	73-151
1630 4222	Resistor - 2.2K Ω $\pm$ 5%	77-150
1630 4222	Resistor - 2.2K Ω $\pm$ 5%	81-155
1630 4223	Resistor - 22K Ω $\pm$ 5% 1/16W	73-152
1630 4223	Resistor - 22K Ω $\pm$ 5% 1/16W	77-151
1630 4229	Resistor - 2.2 Ω $\pm$ 5% - 1/16W	81-156
1630 4330	Resistor - 33 Ω $\pm$ 5% 1/8W	81-157
1630 4330	Resistor - 33 Ω $\pm$ 5% 1/8W	77-152
1630 4331	Resistor - 330 Ω $\pm$ 5% 1/16W	81-158
1630 4334	Resistor - 330K Ω $\pm$ 5% 1/16W	77-153

Part No.	Description	Page and Index No.
1630 4391	Resistor - 390Ω ±5.00% 1/16W	77-154
1630 4470	Resistor - 470 Ω ±5% 1/16W	77-155
1630 4472	Resistor - 4.7KΩ ±5% 1/16W	81-159
1630 4472	Resistor - 4.7KΩ ±5% 1/16W	77-156
1630 4472	Resistor - 4.7KΩ ±5% 1/16W	73-153
1630 4473	Resistor - 47k Ω - ±5% - 1/16W	77-157
1630 4510	Resistor - 51 Ω ±5% 1/16W	77-158
1630 4519	Resistor - 5.1Ω ±5% 1/16W	81-160
1630 4560	Resistor - 56Ω ±5% 1/16W	81-161
1630 4560	Resistor - 56Ω ±5% 1/16W	77-159
1630 4562	Resistor - 5.6k Ω - ±5% - 1/16W	77-160
1630 4562	Resistor - 5.6k Ω - ±5% - 1/16W	81-162
1630 4562	Resistor - 5.6k Ω - ±5% - 1/16W	73-154
1630 4680	Resistor - 68 Ω ±5% 1/16W	81-163
1630 4681	Resistor - 680 Ω ±5% 1/16W	73-155
1630 4750	Resistor - 75 Ω ±5% 1/16W	81-164
1630 4751	Resistor - 50Ω±5.00% 1/16W	77-161
1630 4820	Resistor - 82 Ω ±5% 1/16W	81-165
1630 4821	Resistor - 820 Ω ±5% 1/16W	73-156
1631 1000	Resistor - 100 Ω ±1% 1/4W	73-157
1634 0000	Resistor - 0 Ω 1/16W	77-162
1634 0000	Resistor - 0 Ω 1/16W	81-166
1634 1002	Resistor - 10 Ω ±5% 1/16W	73-158
1634 1003	Resistor - 100KΩ ±1% 1/16W	73-159
1634 1003	Resistor - 100KΩ ±1% 1/16W	81-167
1634 1153	Resistor - 115k Ω ±1% 1/16W	81-168
1634 1403	Resistor - 140kΩ ±1% 1/16W	73-160
1634 1783	Resistor - 178k Ω ±1% 1/16W	81-169
1634 2002	Resistor - 20K Ω ±1% 1/16W	73-161
1634 2401	Resistor - 2.4KΩ ±1% 1/16W	73-162
1634 2402	Resistor - 24K Ω ±1% 1/16W	73-163
1634 4641	Resistor - 4.64kΩ ±1% 1/16W	73-164
1634 5621	Resistor - 5.62kΩ ±1% 1/16W	73-165
1634 7502	Resistor - 75.0K Ω ±1% 1/16W	81-170
1640 2470	Capacitor - 47μF ±20% 25V	73-166

Part No.	Description	Page and Index No.
1640 5101	Capacitor - 100μF ±20% 50V	73-167
1642 5330	Capacitor - 33μF ±20% 50V	73-168
1644 0220	Capacitor - 22μF ±20% 10V	81-171
1644 1100	Capacitor - 10μF ±20% 16V	81-172
1644 1470	Capacitor - 47μF ±20% 16V	81-173
1644 1470	Capacitor - 47μF ±20% 16V	77-163
1660 0100	Capacitor - 10PF ±0.5pF 50V	81-174
1660 2101	Capacitor - 100pF - ±10% - 50V	81-175
1660 2101	Capacitor - 100pF - ±10% - 50V	77-164
1660 2101	Capacitor - 100pF - ±10% - 50V	73-169
1660 2150	Capacitor - 15pF ±5% 50V	81-176
1660 2150	Capacitor - 15pF ±5% 50V	77-165
1660 2220	Capacitor - 22pF ±20% 35V	77-166
1660 2221	Capacitor - 220pF +80-20% 50V	81-177
1660 2270	Capacitor - 27pF ±20% 35V	73-170
1660 2330	Capacitor - 33pF - ±5% - 50V	81-178
1660 2330	Capacitor - 33pF - ±5% - 50V	77-167
1660 2471	Capacitor - 470pF - ±5% - 50V	77-168
1660 2471	Capacitor - 470pF - ±5% - 50V	81-179
1660 2471	Capacitor - 470pF - ±5% - 50V	73-171
1660 2680	Capacitor - 68pF ±5% 50V	81-180
1660 4102	Capacitor - 1000pF ±10% 50V	77-169
1660 4102	Capacitor - 1000pF ±10% 50V	81-181
1660 4102	Capacitor - 1000pF ±10% 50V	73-172
1660 4103	Capacitor - 10000pF - ±10% - 50V	77-170
1660 4472	Capacitor - 4700pF ±10% 50V	73-173
1660 4472	Capacitor - 4700pF ±10% 50V	81-182
1660 6103	Capacitor - 10000pF - +80%-20%50V	77-171
1660 6103	Capacitor - 10000pF - +80%-20%50V	73-174
1660 6103	Capacitor - 10000pF - +80%-20%50V	81-183
1660 8104	Capacitor - 0.1μF +80-20% 25V	77-172
1660 8104	Capacitor - 0.1μF +80-20% 25V	73-175
1660 8104	Capacitor - 0.1μF +80-20% 25V	81-184
1902 0042	RAM - 1M X8 70ns TSOP G2	77-173
1906 0017	Flash Memory - LH28F320BJ-PBTL70	81-185

