
Quick Reference Printer Guide

⇒Please use this guide from behind your PC





How to use Web Image Monitor...

- Start a Web browser.
- 2 Enter the IPv4 address of your machine as a URL.
- **B** Choose from one of the following functions:
 - Home
 - Document Server • Printer: Print Jobs
 - Job
- Configuration

Why use it?

To have access to the machine anywhere via the web. To manage certain functions from your pc, which is easier to use

How to monitor your machine in the network...

- Use SmartDeviceMonitor, which is automatically installed with your printer drivers.
- **1** Right-click the green PC icon at the bottom of your screen.
- **2** Select [Properties], [Option...], [Network Devices] and press [Browse...].
- B Select your machine and press [OK].
- Select a machine in [Printers Folder] and select [To be monitored]. Select [Displayed on Task Bar].
- If you select this machine from the SmartDeviceMonitor icon, you can see the [Status], [Configuration] and [Job History]. Next time you print, you get a message on your pc in case of any failure.