

AD 50 (A217)

PARTS CATALOG

First Edition July 1997

RICOH COMPANY,LTD

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

AD50
DF64

(A217)
(A663)

AD 50 (A217)

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.


INDEX to PARTS CATALOG

LOCATION OF UNIT	3	19.DEVELOPMENT UNIT 1 (A217)	46
1.EXTERIOR (A217)	10	20.DEVELOPMENT UNIT 2 (A217)	48
2.PLATENCOVER (A217)	12	21.DRUM UNIT (A217).....	50
3.OPERATION PANEL (A217).....	14	22.CLEANING UNIT (A217).....	52
4.PAPER TRAY (A217).....	16	23.TRANSFER BELT UNIT (A217).....	54
5.TRAY PAPER FEED (A217)	18	24.FUSING UNIT 1 (A217).....	56
6.BY-PASS FEED UNIT 1 (A217)	20	25.FUSING UNIT 2 (A217).....	58
7.BY-PASS FEED UNIT 2 (A217)	22	26.PAPER EXIT SECTION (A217)	60
8.BY-PASS FEED UNIT 3 (A217)	24	27.DUPLEX UNIT 1 (A217)	62
9.LCT UNIT 1 (A217).....	26	28.DUPLEX UNIT 2 (A217)	64
10.LCT UNIT 2 (A217).....	28	29.DUPLEX UNIT 3 (A217)	66
11.VERTICAL TRANSPORT SECTION (A217)	30	30.DRIVE SECTION 1 (A217).....	68
12.PAPER REGISTRATION (A217)	32	31.DRIVE SECTION 2 (A217).....	70
13.OPTICS SECTION 1 (A217)	34	32.DRIVE SECTION 3 (A217).....	72
14.OPTICS SECTION 2 (A217)	36	33.ELECTRICAL SECTION 1 (A217)	74
15.OPTICS SECTION 3 (A217)	38	34.ELECTRICAL SECTION 2 (A217)	76
16.LASER SECTION (A217).....	40	35.ELECTRICAL SECTION 3 (A217)	78
17.CHARGE CORONA SECTION (A217)	42	36.ELECTRICAL SECTION 4 (A217)	80
18.TONNER BOTTLE SECTION (A217)	44	37.FRAME SECTION 1 (A217)	82

38.FRAME SECTION 2 (A217)	84
39.500 COPY TRAY (A615)	86
40.SCU BOARD (A217)	88
41.BCU BOARD (A217)	92
42.IPU BOARD (A217)	96
43.DECAL AND DOCUMENT (A217)	106
44.SPECIAL TOOLS (A217)	108
PARTS INDEX	111


LOCATION OF UNIT

1.EXTERIOR (A217)




See Page 11

2.PLATENCOVER (A217)




See Page 13

3.OPERATION PANEL (A217)




See Page 15

4.PAPER TRAY (A217)




See Page 17

5.TRAY PAPER FEED (A217)



See Page 19


6.BY-PASS FEED UNIT 1 (A217)



See Page 21


LOCATION OF UNIT

7.BY-PASS FEED UNIT 2 (A217)




See Page 23

8.BY-PASS FEED UNIT 3 (A217)




See Page 25

9.LCT UNIT 1 (A217)




See Page 27

10.LCT UNIT 2 (A217)




See Page 29

11.VERTICAL TRANSPORT SECTION (A217)



See Page 31


12.PAPER REGISTRATION (A217)



See Page 33


LOCATION OF UNIT

13.OPTICS SECTION 1 (A217)




See Page 35

14.OPTICS SECTION 2 (A217)




See Page 37

15.OPTICS SECTION 3 (A217)




See Page 39

16.LASER SECTION (A217)




See Page 41

17.CHARGE CORONA SECTION (A217)



See Page 43


18.TONNER BOTTLE SECTION (A133)



See Page 45


LOCATION OF UNIT

19.DEVELOPMENT UNIT 1 (A217)




See Page 47

20.DEVELOPMENT UNIT 2 (A217)




See Page 49

21.DRUM UNIT (A217)




See Page 51

22.CLEANING UNIT (A217)




See Page 53

23.TRANSFER BELT UNIT (A217)









See Page 55

24.FUSING UNIT 1 (A217)









See Page 57




LOCATION OF UNIT

25.FUSING UNIT 2 (A217)  See Page 59	26.PAPER EXIT SECTION (A217)  See Page 61	27.DUPLEX UNIT 1 (A217)  See Page 63
28.DUPLEX UNIT 2 (A217)  See Page 65	29.DUPLEX UNIT 3 (A217)  See Page 67	30.DRIVE SECTION 1 (A217)  See Page 69


LOCATION OF UNIT

31.DRIVE SECTION 2 (A217)  See Page 71	32.DRIVE SECTION 3 (A217)  See Page 73	33.ELECTRICAL SECTION 1 (A217)  See Page 75
34.ELECTRICAL SECTION 2 (A217)  See Page 77	35.ELECTRICAL SECTION 3 (A217)  See Page 79	36.ELECTRICAL SECTION 4 (A217)  See Page 81

LOCATION OF UNIT

37.FRAME SECTION 1 (A217)  See Page 83	38.FRAME SECTION 2 (A217)  See Page 85	39.500 COPY TRAY (A615)  See Page 87

1.EXTERIOR (A217)




1.EXTERIOR (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A153 6409	Decal - Keytop Cover (NRG)	1
2	C225 2867	Decal - Cover - Panel - Nashua	1
3	A133 7102	Left Cover	1
4	AA01 2079	Dust Filter	1
5	A134 1302	Upper Cover	1
6	AA14 8447	Guide Pin - Platen Cover	2
7	A133 7157	Rear Scale (LT)	1
7	A134 1922	Rear Scale (A4)	1
8	AA14 3219	Stepped Screw	3
9	A134 1923	Left Scale (A4)	1
9	A133 7155	Left Scale (LT)	1
10	AA14 3454	Stepped Screw - M3	2
11	A134 1924	Exposure Glass	1
12	A134 1282	Rear Cover	1
13	A134 1362	Right Upper Cover	1
14	A133 7094	Right Cover	1
15	A155 6241	LCT Harness Cover	1
16	AA15 2358	Sponge - 57x24x20	1
17	A133 7073	Front Upper Cover	1
18	A134 1352	Right Inner Cover	1
19	A134 1354	Middle Inner Cover	1
20	A217 7021	Front Cover (RIC-US)	1
20	A133 7106	Front Cover (NRG)	1
20	A217 7701	Front Cover (SVN)	1
21	A134 1317	Hinge - Front Cover	3
22	A134 1357	Left Inner Cover	1
23	AG07 0004	Magnetic Catch	1
24	A133 7112	Emblem (SVN)	1
24	A134 1383	Emblem (RIC)	1
25	AW01 0065	Auto Response Sensor	1
26	A217 7002	Operation Panel Ass'y (RIC/NRG LT)	1
26	A217 7301	Operation Panel Ass'y (A4)	1
26	A217 7711	Operation Panel Ass'y (SVN)	1
27	A134 1377	Cap - Front Upper Cover	1
28	A133 6124	Misfed Removal Sheet	1

Index No.	Part No.	Description	Q'ty Per Assembly
29	A130 1359	Small Inner Cover	1
30	AA00 1383	Decal - Energy Star	1
31	AA14 3718	Stepped Screw - M4	4
32	A134 1369	Seal - Front Upper Cover	1
33	A217 7901	Front Cover (INF)	1
33	A217 7023	Front Cover (RIC-EU/ASIA)	1
34	A217 7905	Support Cover (INF)	1
35	A134 1384	Cap - Front Cover	1
101	0802 5085	Tapping Screw - M4x8	
102	0324 0080B	Philips Sunken Head Screw - M4x8	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0801 0150	Philips Tapping Screw W/W - M4x8	
105	0802 5094	Tapping Truss Head Screw - M4x8	
106	0802 5232	Tapping Screw - M3x8	

2.PLATENCOVER (A217)




2.PLATENCOVER (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A406 9505	Platen Cover Sheet - 10 Sheet/1 Set	1
2	AA16 2053	Platen Cover Pad	1
3	A134 1394	Front Platen Cover	1
4	A053 1957	Flex Hinge - Platen Cover	2
5	A134 1395	Rear Platen Cover	1
6	A134 1396	Original Holder	1
7	A100 1324	Positioning Sensor Shutter	1
8	A100 1310	Platen Cover Hinge Ass'y	1
9	A100 1325	Hinge Spacer	1
10	A153 1380	Platen Cover Bracket	1
11	AA14 8447	Guide Pin - Platen Cover	2
12	A134 1392	Platen Cover Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0142W	Tapping Screw - M4x14	

3.OPERATION PANEL (A217)




3.OPERATION PANEL (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 1553	Cover - Option	1
2	A134 1543	Cap - Option	4
3	A133 6107	Key Top - User Tools (SVN)	1
3	A134 1538	Key Top - User Tools	1
4	A133 6106	Key Top - Guidance (SVN)	1
4	A134 1533	Key Top - Guidance	1
5	A133 7124	Operation Panel Case (LT)	1
5	A133 7125	Operation Panel Case (A4)	1
6	A133 6105	Key Top - Program (SVN)	1
6	A134 1523	Key Top - Program	1
7	A133 6104	Key Top - Job Recall (SVN)	1
7	A134 1518	Key Top - Job Recall	1
8	A134 1558	Cap - Apprication	1
9	A133 6103	Key Top - Clear Mode (SVN)	1
9	A134 1515	Key Top - Clear Mode	1
10	A133 6102	Key Top - Interrupt (SVN)	1
10	A134 1511	Key Top - Interrupt	1
11	A133 6100	Key Top - 10 Key (SVN)	1
11	A134 1506	Key Top - 10 Key	1
12	A133 6101	Key Top - Start/Stop (SVN)	1
12	A134 1507	Key Top - Start/Stop	1
13	A134 5156	PCB - 10 Key	1
14	A133 6120	Grounding Wire - 270 mm	1
15	A217 5149	Touch Panel	1
16	A134 5153	Grounding Wire - Op. Panel	1
17	A217 7731	IC - UVEPROM 4MX16 150 ns	1
18	A217 7704	Operation Panel Board	1
19	A134 5157	PCB - Option	1
20	A134 1548	Dial	1
21	A134 5152	Inverter Board	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1607 0747	FPC Core - FPC-25-12	
102	0802 5232	Tapping Screw - M3X8	
103	0353 0060F	Tapping Screw - M3X6	

4.PAPER TRAY (A217)



4.PAPER TRAY (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 2956	Paper Feed Front Cover	1
2	A134 2997	Decal - Paper Setting	1
3	AF01 6084	Front Side Fence	1
4	A134 2976	Stopper Lever	1
5	A134 2978	Spring Plate	1
6	A153 2991	Front Side Fence Guide	1
7	AF01 7012	End Fence	1
8	A204 2953	Paper Tray	1
9	AF01 3014	Bottom Plate Pad	1
10	A048 2838	Nylon Rivet	2
11	AF01 6085	Rear Side Fence	1
12	A153 2992	Rear Side Fence Guide	1
13	AF01 5027	Paper Size Slider	1
14	AB01 3868	Gear - 16Z	1
15	A134 2968	Grounding Plate	1
16	A204 2972	Bottom Lift Lever	1
17	A204 2971	Bottom Lift Shaft	1
18	A134 2986	Bottom Plate	1
19	A133 7292	Decal - Paper Size - LT	1
19	A133 7293	Decal - Paper Size - A4	1
20	A134 2960	Paper Talon	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0965 4008B	Tapping Screw - M4 X 8	
102	0434 0082B	Tapping Screw - M4x8	
103	0720 0060E	Retaining Ring - M6	
104	0344 0060F	Philips Truss Head Screw - M4x6	


This is a detailed exploded view diagram of a mechanical assembly, likely a printer or scanner mechanism. The diagram shows various components and their assembly sequence, indicated by numbers 1 through 108. The parts include structural frames, gears, rollers, springs, and fasteners. The assembly is shown in a disassembled state to illustrate the relationship between different components.

5. TRAY PAPER FEED (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 2839	Reverse Gide Plate	1
2	5447 2681	Snap Ring	3
3	AF03 0025	Pick-up Feed Roller	1
4	5447 2706	Gear - 15T	1
5	A134 2860	Pick-up Arm	1
6	AA14 0542	Feed Roller Shaft	1
7	A134 2878	Paper End Sensor Bracket	1
8	AW02 0075	Photointerrupter	2
9	A134 2873	Positioning Sensor Bracket	1
10	AA06 0577	Release Spring	1
11	A134 2866	Pick-up Solenoid	1
12	AA08 3009	Clutch Roller - 8x18x11	2
13	AA08 2046	Bushing - 6x12x6	3
14	AB03 0466	Timing Pulley - 20Z	1
15	A134 2826	Rear Side Plate	1
16	A134 2855	Lower Feed Stay	1
17	A134 2862	Paper End Sensor Feeler	1
18	AA06 0523	Pick-up Pressure Sping	1
19	A134 2863	Paper End Sensor Lever	1
20	AA08 2047	Bushing - 8x16x7	2
21	A134 2830	Drive Shaft	1
22	AB01 3420	Gear - 18Z	2
23	A134 2832	Driven Shaft Ass'y	1
24	A134 2885	Torque Limitter	1
25	AF03 2027	Seperation Roller	1
26	A134 2790	Reverse Stay	1
27	A134 2795	Pressure Lever	1
28	AA06 0636	Pressure Spring	1
29	AF02 0322	Lower Drive Roller - Transport	1
30	AA06 0575	Release Spring	1
31	A134 2810	Release Solenoid	1
32	AF02 0329	Relay Roller	1
33	AA08 0156	Bushing - M4	2
34	AA06 3487	Spring - 10mm	2
35	A134 2834	Vertical Transport Guide	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A134 5315	Relay Harness - Lower Paper Feed	1
37	A134 2846	Lower Guide Plate	1
38	A134 2821	Front Side Plate	1
39	AF03 1026	Paper Feed Roller	1
40	A134 2868	Solenoid Bracket	1
			
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0720 0040E	Retaining Ring - M4	
103	0720 0030E	Retaining Ring - M3	
104	0805 0088	Retaining Ring - M6	
105	0720 0060E	Retaining Ring - M6	
106	0742 3808	Ball Bearing - 8x16x5	
107	0960 3004B	Screw - M3x4	
108	1105 0199	Clamp	

6.BY-PASS FEED UNIT 1 (A217)




6.BY-PASS FEED UNIT 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A133 7309	By-pass Feed Table Ass'y	1
2	5447 2927	Friction Pad - B	1
3	A134 2741	By-pass Feed Entrance Guide	1
4	A134 2721	Front Paper Guide	1
5	A134 2711	Front Side Fence	1
6	A134 2726	Rear Paper Guide	1
7	A134 2716	Rear Side Fence	1
8	A134 2701	By-pass Feed Guide	1
9	A133 7347	By-pass Feed Table	1
10	A134 2705	Magnet Catch Plate	1
11	A134 5282	Paper Size Sensor Board	1
12	A134 2706	Rear Fence Rack	1
13	G011 3305	Gear - 16T	1
14	A134 2707	Front Fence Rack	1
15	A134 2746	By-pass Feed Cover	1
16	5215 2621	Snap Ring - M6	1
17	AA15 1998	Cushion - 10x30x5	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0965 3006B	Tapping Screw With Flat Washer M3x6	
102	0434 0060B	Philips Tapping Screw - M4x6	

7.BY-PASS FEED UNIT 2 (A217)




7.BY-PASS FEED UNIT 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF02 0365	Transport Roller	1
2	A133 7329	Guide Plate - Paper Feed	1
3	A134 2671	Left Guide Plate - By-pass Feed	1
4	AA08 0034	Bushing - 4x5x7	2
5	A133 7318	Guide Plate - Separator	1
6	AF02 0364	Driven Roller	1
7	A133 7312	Rear Plate - By-pass Feed	1
8	A133 7343	Rear Side Fence - By-pass	1
9	AB01 3420	Gear - 18Z	2
10	5447 2681	Snap Ring	1
11	A133 7320	Drive Shaft - Feed Roller	1
12	A133 7321	Shaft - Separation	1
13	AA06 3246	Pressure Spring	1
14	A133 7314	Stay - By-pass Feed	1
15	A134 2885	Separation Torque Limiter	1
16	AF03 2031	Separation Roller	1
17	A133 7341	Front Side Fence - By-pass	1
18	A133 7310	Front Plate - By-pass Feed	1
19	AA06 3487	Spring - 10mm	2
20	AA08 2047	Bushing - 8x16x7	2
21	AA08 2046	Bushing - 6x12x6	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0720 0030E	Retaining Ring - M3	
104	0720 0040E	Retaining Ring - M4	
105	0414 0080B	Binding Self-tapping Screw - M4x8	
106	0802 5236	Tapping Screw - M4x8	

8.BY-PASS FEED UNIT 3 (A217)




8.BY-PASS FEED UNIT 3 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A133 7336	By-pass Feed Solenoid	1
2	A133 7333	Paper Feed Solenoid - LCT	1
3	A133 7332	Pressure Lever - Pick-up	1
4	A133 7344	Bracket - Relay Sensor	1
5	A133 7345	Sensor Bracket	1
6	A133 7339	Stopper	1
7	A133 7738	Harness - By-pass Feed	1
8	A133 7325	Paper Feed Stay	1
9	A133 7331	Harness Bracket	1
10	A133 7328	Paper End Actuator	1
11	A133 7323	Arm - Pick-up	1
12	A133 7337	Solenoid Bracket	1
13	AA06 0638	Pressure Spring	1
14	AA06 0639	Pressure Spring	1
15	5447 2706	Gear - 15T	1
16	AF03 0031	Pick-up Roller	1
17	AF03 1031	Feed Roller	1
18	AA08 2047	Bushing - 8x16x7	2
19	5921 3104	Spring - Toner End Lever	1
20	AA14 0597	Shaft - Paper Feed	1
21	A096 6353	Feed Roller Lever	1
22	A469 2123	Rubber Cushion - 1x10x10mm	1
23	5447 2681	Snap Ring	2
24	AW02 0075	Photointerrupter	2
25	AW02 0085	Photointerrupter	1
26	A134 2661	Feeler Roller	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0313 0040B	Philips Pan Head Screw - M3x4	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0720 0060E	Retaining Ring - M6	
104	1105 0229	Clamp	
105	1105 0199	Clamp	

9.LCT UNIT 1 (A217)




9.LCT UNIT 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A133 7377	End Fence	1
2	A155 6113	Decal - Paper Set	1
3	A155 6207	Cover Bracket	1
4	A155 6301	Fix Hinge Ass'y	1
5	A155 6302	Hinge Angle	1
6	A155 6101	LCT Upper Cover	1
7	A335 3251	Top Cover Hinge	1
8	A155 6201	LCT Hinge Bracket	1
9	A133 7376	Upper Stay	1
10	A155 6312	Rear Paper Holder	1
11	A155 6313	Support Guide	2
12	A155 6307	Rear Side Fence	1
13	A421 2543	Friction Pad	1
14	A155 6142	LCT Paper Tray	1
15	A155 6221	LCT Rear Cover	1
16	A155 6231	LCT Right Cover	1
17	A133 7371	LCT Front Cover	1
18	A155 6181	Knob	1
19	A155 6171	Grip Bracket	1
20	AA06 3239	Spring - Handle	1
21	A155 6170	Hinge Bracket	1
22	A155 6306	Front Side Fence	1
23	A155 6311	Front Paper Holder	1
24	A155 6321	Front Spring Plate	1
25	A155 6322	Rear Sprig Plate	1
26	A133 7361	Bracket - Positioning Plate	1
27	A133 7364	Rail - LCT	1
28	A133 7358	Pressure Spring Plate	1
29	A133 7355	LCT Motor Cover	1
30	A155 6169	Hinge Holder	1
31	A155 6114	Daution Decal - LCT	1
32	A133 7360	Positioning Plate - LCT	1
33	AA14 3461	Stepped Screw - M2.5	1
34	A133 7369	Micro Switch	1
35	A155 6270	Cushion 20x30	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	1105 0197	Wire Saddle	
103	0802 5094	Tapping Truss Head Screw - M4x8	

10.LCT UNIT 2 (A217)




10.LCT UNIT 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A155 6143	Left Bracket	1
2	A155 6148	Paper End Sensor Feeler	1
3	A155 6147	Paper End Sensor Bracket	1
4	A155 5348	Paper End Sensor Harness	1
5	A155 6203	Paper Tray Stay	1
6	A155 6153	Upper Hinge	1
7	AW02 0075	Photointerrupter	2
8	AX05 0090	Motor - DC 24V 36W	1
9	AB03 0281	Timing Pulley - 28Z	4
10	A335 4351	Guide Roller	4
11	A155 6136	Lift Sensor Bracket	1
12	AA04 3456	Timing Belt - S3M167	2
13	5925 2258	Stopper Chain	1
14	AB01 1133	Gear - 49Z	1
15	AA14 0576	LCT Drive Shaft	1
16	AG07 0004	Magnetic Catch	1
17	A155 6141	Tray Bottom Plate	1
18	A155 5165	LCT Main Board	1
19	A155 6145	Tray Cover	1
20	A155 6118	Spring Plate	1
21	A155 6116	Safety Switch Bracket	1
22	A300 3155	Stepped Screw - M25x32	1
23	A155 6117	Safety Switch Lever	1
24	A133 7743	LCT Harness	1
25	A335 4352	Timing Belt Clamp	2
26	5053 0223	Bushing - 8mm	2
27	A155 5170	Push Switch	1
28	A155 6125	Rear Side Bracket	1
29	A155 6110	Front Side Plate - LCT	1
30	A155 6215	Harness Guide	1
31	A335 1341	Chain Hook	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0802 5236	Tapping Screw - M4x8	
103	0443 0060B	Hexagon Tapping Screw - M3x6	
104	0720 0060E	Retaining Ring - M6	
105	1204 2355	Micro Switch - AM51632A531	
106	0623 0160E	Spring Pin - 3x16mm	
107	1105 0196	Harness Clamp	
108	1105 0199	Clamp	
109	1105 0197	Wire Saddle	
110	1105 0192	Locking Support	
111	1106 0193	Bushing - 7.9mm	

11.VERTICAL TRANSPORT SECTION (A217)




11.VERTICAL TRANSPORT SECTION (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 2588	Paper Guide	1
2	A134 2585	Vertical Transfer Guide Plate	1
3	AG07 0004	Magnetic Catch	2
4	A133 7386	Pressure Guide - Vertical Transport	1
5	A133 7385	Bracket - Vertical Transport	1
6	A133 7375	Joint - Vertical Transport	1
7	A133 7066	Bracket - Right Inner Cover	1
8	A133 7037	Front LCT Frame	1
9	5446 1239	Plate Nut - Key Counter	1
10	A133 7007	By-pass Feed Bracket	1
11	A133 7040	Rail - LCT	1
12	A133 7046	Rear LCT Frame	1
13	A133 7060	Upper LCT Frame	1
14	A133 7064	Magnet Clutch Bracket	1
15	A133 7388	Fulcrum Bracket - Vertical Trans.	1
16	AW50 0012	Push Switch	1
17	A133 7383	Hinge - Vertical Transport	1
19	A133 7739	Vertical harness	1
20	AW02 0069	Photointerruptor	2
21	AA08 0034	Bushing - 4x5x7	4
22	AF02 0330	Vertical Driven Roller	2
23	AA06 3487	Spring - 10mm	4
24	5447 2681	Snap Ring	1
25	A133 7387	Stopper - Vertical Transport	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	1105 0329	Clamp - ES-0510	
103	0802 5237	Binding Self-tapping Screw - M4x10	
104	0720 0030E	Retaining Ring - M3	
105	0802 5094	Tapping Truss Head Screw - M4x8	
106	1105 0310	Wire Clamp	
107	0323 0080B	Philips Sunk Screw - M3x8	
108	0414 0080B	Binding Self-tapping Screw - M4x8	

12.PAPER REGISTRATION (A217)




12.PAPER REGISTRATION (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB01 3486	Gear - 14Z	1
2	AA08 0171	Bushing	1
3	AA06 3242	Registration Pressure Spring - Rear	2
4	5474 2152	Bushing - 8x12x12mm	2
5	AB01 3485	Gear - 20Z	1
6	AG05 0074	Registration Knob	1
7	AG05 0075	Middle Knob	1
8	A133 7023	Fusing Entrance Stay	1
9	AF02 1052	Upper Registration Roller	1
10	AF02 0316	Lower Registration Roller	1
11	A134 2557	Regist Sensor Bracket	1
12	AW02 0068	Photointerruptor	1
13	A134 5472	Relay Harness - Regist.Sensor	1
14	A134 2558	Upper Guide Plate - Registration	1
15	A134 2552	Lower Registration Guide	1
16	AA08 2047	Bushing - 8x16x7	1
17	A134 2900	Duplex Stay	1
18	AA08 3009	Clutch Roller - 8x18x11	1
19	AB03 0466	Timing Pulley - 20Z	1
20	AF02 0321	Paper Feed Drive Roller	1
21	A134 2903	Upper Guide Plate - Duplex Feed	1
22	A204 2904	Lower Guide Plate - Duplex Feed	1
23	A134 2895	Vertical Relay Guide	1
24	A133 7379	Bracket - Vertical Transfer	1
25	A133 7027	Registration Rolller Cleaner	1
26	AA08 0172	Bushing	1
27	A133 7226	Lower Development Stay	1
28	A133 7031	Idler Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0951 3006B	Philips Screw With Flat Washer-M3x6	
103	0720 0040E	Retaining Ring - M4	
104	0414 0080B	Binding Self-tapping Screw - M4x8	
105	0313 0040B	Philips Pan Head Screw - M3x4	
106	1105 0199	Clamp	
107	0434 0060B	Philips Tapping Screw - M4x6	
108	0802 5237	Binding Self-tapping Screw - M4x10	

13.OPTICS SECTION 1 (A217)




13.OPTICS SECTION 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB03 2717	Pulley - 26Z	4
2	AA13 2174	Spacer - M8	2
3	A134 1791	Spring Plate - 2nd Mirror	4
4	A069 1883	Shoe - Scanner	8
5	A134 5360	Harness - Scanner Lamp	1
6	A134 1782	2nd Scanner Ass'y	1
7	A217 1784	2nd Mirror Ass'y	2
8	A134 1776	Spring Plate - 1st Mirror	2
9	AC03 0073	1st Mirror	1
10	AX52 0033	Scanner Lamp - 75V 200W	1
11	A217 7051	1st Scanner Ass'y	1
12	A134 1726	Wire Stopper Plate	2
13	A096 1873	Scanner Shoe Pin	8
14	AW11 0017	Thermostat - 140C - AC120V 15A	1
15	A134 1926	Exposure Glass Stopper	4
16	A134 5370	Relay Harness - Scanner Lamp	1
17	AA15 0636	Seal - 90x29.5x0.2	1
18	A134 1929	Bracket - Left Scale	1
19	A134 1933	Right Stopper - Exposure Glass	1
20	A134 1932	Stay - Scanner Upper Right	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0313 0140B	Philips Pan Head Screw - M3x14	
102	0443 0060B	Hexagon Tapping Screw - M3x6	
103	0353 0040B	Screw - M3X4	
104	0720 0060E	Retaining Ring - M6	
105	0802 5246	Screw - M3x5	

14.OPTICS SECTION 2 (A217)




14.OPTICS SECTION 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A217 5230	EX-IPU Board	1
2	A134 5478	Scanner Harness - Front	1
3	A217 5392	Harness - Polygon Mirr	1
4	A134 5476	Scanner Harness - Rear Left	1
5	A133 7774	Harness LD Unit	1
6	AA15 0234	Mylar Seal - Base	1
7	A134 1955	Inner Cover - Scanner	1
8	A134 1962	Bracket Home Sensor	1
9	AX64 0060	Fan Motor - DC 0.96W	1
10	A134 1971	Bracket - Fan Motor	1
11	AW01 0072	Original Sensor	2
13	A217 1815	Lens Block Ass'y	1
14	AX40 0057	Heater - 115V 9W	1
14	AX40 0058	Heater - 230V 9W	1
15	AW01 0040	Original Sensor	1
16	AW02 0072	Photointerruptor	1
17	A133 7152	Right Bracket - IPU	1
18	A133 7151	Left Bracket - IPU	1
19	A133 7920	Harness HDD (230V)	1
20	A134 1299	Bracket - Front Upper Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0120B	Philips Pan Head Screw - M4x12	
102	0414 0060B	Tapping Screw - M4x6	
103	0314 0250B	Philips Pan Head Screw - M4x25	
105	0434 0060B	Philips Tapping Screw - M4x6	
106	0951 4006B	Philips Screw With Washer - M4x6	
107	1105 0310	Wire Clamp	
108	1105 0291	Wire Saddle	
109	1105 0329	Clamp - ES-0510	
110	0353 0080B	Screw - M3x8	
111	0354 0080B	Screw - M4x8	
112	0802 5246	Screw - M3x5	
113	1607 0663	Ferrite Core - TFC-20-10-10 (230V)	

15.OPTICS SECTION 3 (A217)




15.OPTICS SECTION 3 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX65 0015	Fan Motor - DC 5.8W	1
2	A134 1959	Bracket - Exhaust Fan	1
3	A134 1662	Polygon Motor Cover	1
4	A133 7159	LD Unit Cover	1
5	A134 1697	Lens Block Supporter	2
6	A134 1677	Front Tension Bracket	1
7	AB03 2717	Pulley - 26Z	2
8	A134 1964	Bracket - Flexible Harness	1
9	AA06 0221	Gripper Solenoid Spring	1
10	A134 1720	Bracket - Scanner Motor	1
11	A134 1724	Cushion - Stepper Motor	1
12	AB03 0459	Timing Pulley -22Z	1
13	A069 5352	Ground Wire - Scanner	1
14	AX06 0107	Motor - DC 24W	1
15	A134 1728	Fly Wheel	1
16	AA04 3372	Timing Belt - S2M400	1
17	AB03 0460	Timing Pulley - 44Z	1
18	A134 1722	Bracket - Drive Shaft	1
19	A134 1680	Guide - Flexible Harness	1
20	AB03 2718	Drive Pulley	2
21	AA14 0547	Drive Shaft	1
22	AA05 0085	Scanner Wire	2
23	A134 1678	Rear Tension Bracket	1
24	A134 1698	Idle Pulley	2
25	A134 1675	Front Scanner Frame	1
26	A134 1679	Rear Scanner Frame	1
27	A134 1668	Fan Guide	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0575 0050E	Hexagon Headless Set Screw - M5x5	
102	0314 0100B	Philips Pan Head Screw - M4x10	
103	0805 3368	Ball Bearing - 8 X 16 X 5mm	
104	0951 4005B	Philips Screw With Flat Wash.- M4x5	
105	0720 0060E	Retaining Ring - M6	
106	0951 4006B	Philips Screw With Washer - M4x6	
107	0314 0080B	Philips Pan Head Screw - M4x8	
108	0434 0060B	Philips Tapping Screw - M4x6	
109	0353 0080B	Screw - M3X8	
110	1105 0310	Wire Clamp	
111	1105 0329	Clamp - ES-0510	

16.LASER SECTION (A217)




16.LASER SECTION (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX06 0133	Polygon Mirror Motor	1
2	A134 5491	Relay Harness - Polygon Motor	1
3	A217 2085	LD Unit	1
4	A134 5190	LSD Board	2
5	AC01 5020	Toner Shield Glass	1
6	A217 5392	Harness - Polygon Mirr	1
7	A134 2088	Right Btl Bracket	1
8	A134 2079	BTL Lens	1
9	A134 2089	Left Btl Bracket	1
10	AC03 0080	1st Mirror	1
11	A134 2069	Bracket - 1st Mirror	2
12	AA15 1900	Seal - Toner Shield Glass	1
13	A134 2083	Guide Plate - Toner Shield Glass	1
14	AC02 0090	Cylindrical Lens	1
15	A100 2056	Plate - Cylindrical Lens	1
16	A134 2129	Bracket - Mirror	1
17	AA15 2302	Seal	2
18	A133 7166	Guide Harness LD	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 4010B	Philips Screw With Washer - M4x10	
102	0802 5238	Tapping Screw - M4x12	
103	0802 5232	Tapping Screw - M3x8	

17.CHARGE CORONA SECTION (A217)




17.CHARGE CORONA SECTION (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AD02 2283	Front End Block	1
2	AD02 3106	Charge Corona Casing	1
3	AD02 2285	Rear End Block	1
4	AA06 3248	Charge Terminal Spring	1
5	AA06 3249	Grid Terminal Spring	1
6	AD02 2307	Cover - Rear End Block	1
7	A096 2051	Rear Grid Anchor	1
8	AD02 0053	Charge Corona Wire	1
9	A096 2057	Charge Corona Grid	1
10	AA06 2284	Pressure Spring	1
11	AA14 3424	Knob Screw - M4x8	1
12	AD02 2306	Cover - Front End Block	1
13	A134 2363	Terminal Plate	1
14	A096 2052	Front Grid Anchor	1
15	A134 2380	Toner Collection Bottle Cap	1
16	A134 2387	Cap - Spring	1
17	AA06 3270	Pressure Spring	1
18	A134 2382	Upper Sponge - Collection Bottle	1
19	A134 2383	Lower Sponge - Collection Bottle	1
20	AD00 4075	Charge Corona Unit	1
21	A133 7236	Toner Collection Bottle	1
22	AA00 0180	Decal - Toner Collection (LT)	1
22	AA00 0181	Caution Decal - Toner Collect. Tank (A4)	1
23	A134 2384	Toner Overflow Sensor Ass'y	1
24	A130 9011	Charge Corona Unit	1
25	A096 2053	Cleaner Motor Cover	1
26	AA16 1105	Cleaner Cushion	1
27	AX04 0061	Cleaner Motor - DC 0.5W	1
28	AB01 0087	Gear - 20Z	1
29	AA08 0148	Rear Bushing	1
30	A096 2062	Wire Cleaner Slider	1
31	A096 2061	Screw Shaft	1
32	A096 2065	Slider Ring	1
33	A096 2063	Corona Wire Cleaner	1
34	AA08 0147	Front Bushing	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	A096 2054	Grounding Plate	1
36	A096 2055	Motor Grounding Plate	1
37	AA16 1119	Cushion - Wire	2
101	0971 4006A	Philips Polycarbonate Screw - M4x6	
102	0965 3008B	Tapping Screw With Washer - M3x8	
103	0720 0025E	Retaining Ring - M2.5	

18.TONNER BOTTLE SECTION (A133)




18.TONNER BOTTLE SECTION (A133)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 3185	Gear - Toner Bottle (RIC - 230V)	1
1	A133 3185	Gear - Toner Bottle (RIC - 115V)	1
1	A133 3195	Gear - Toner Bottle (SVN/INF/NRG)	1
2	AA15 1894	Seal - 67x53x2	1
3	A134 3180	Bottle Chuck	1
4	A204 3177	Toner Slider	1
5	AA14 3712	Chuck Shaft	1
6	A134 3181	Chuck Roller	1
7	A134 3179	Chuck Shaft	1
8	AA06 3366	Chuck Spring	1
9	A204 3190	Toner Bottle Stopper	1
10	AA14 3410	Stepped Screw - M4	1
11	AA06 3367	Pressure Spring	1
12	A134 3197	Bottle Holder	1
13	A134 3172	Toner Bottle Holder	1
14	A134 3161	Bottle Drive Bracket	1
15	AA15 1891	Shutter Seal	1
16	A134 3171	Shutter - Toner Bottle	1
17	A134 3164	Bracket - Toner Holder	1
18	AG07 0004	Magnetic Catch	1
19	A134 3157	Bottle Holder Bracket	1
20	A134 3162	Bottle Drive Motor DC 5.85w	1
21	AB01 7347	Idle Gear	1
22	AA14 8413	Idle Gear Shaft	1
23	A134 3212	Toner Receive Plate	1
24	AA00 1369	Decal - Adding Toner	1
25	AA06 6284	Torsion Spring	1
26	A134 3192	Seal - Toner Bottle	1
27	AA15 0234	Mylar Seal - Base	1
28	A134 3215	Rubber Cap	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0725 0100E	Retaining Ring C - M10	
103	0443 0060B	Hexagon Tapping Screw - M3x6	
104	0802 5231	Tapping Screw - M3x6	
105	0720 0040E	Retaining Ring - M4	
106	0802 5233	Tapping Screw - M3x10	
107	0323 0060B	Philips Sunk Screw - M3x6	
108	0800 0072	Philips Pan Head Screw - M2.6x4	
109	0805 0088	Retaining Ring - M6	

19.DEVELOPMENT UNIT 1 (A217)




19.DEVELOPMENT UNIT 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 3120	Toner Supply Unit	1
2	AB01 3886	Gear - 18Z	1
3	AA15 1889	Entrance Seal - Toner Supply Unit	1
4	AW31 0004	Toner Detect Sensor	1
5	A134 3090	Development Filter	1
6	A134 3060	Entrance Seal - Development	1
7	AZ30 0039	Power Pack - Development	1
8	A134 3088	Cover - Power Pack	1
9	A134 3095	Front Cover - Development	1
10	AW23 0008	ID Sensor	1
11	A134 5306	Harness - Development Unit	1
12	AB01 3887	Gear - 16Z	1
13	A134 3145	Disk - Torque Limiter	1
14	AA06 3382	Pressure Spring	1
15	5446 3108	Spacer - 1.5x4.2x11mm	1
16	A217 3050	Development Unit	1
17	A134 3056	Rear Seal - Development Roller	1
18	A134 3055	Front Seal - Development Roller	1
19	AA15 1882	Seal - 32x4x1	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 4008B	Philips Screw With Washer - M4x8	
102	0802 5232	Tapping Screw - M3x8	
103	0720 0040E	Retaining Ring - M4	
104	0353 0060B	Philips Pan Head Screw - M3x6	

20.DEVELOPMENT UNIT 2 (A217)




20.DEVELOPMENT UNIT 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB01 3878	Gear - 29Z	1
2	AB01 1150	Gear - 20Z	1
3	AD03 7043	Development Auger	1
4	AB01 1162	Gear - 16Z	1
5	AB01 3877	Gear - 28Z	1
6	AB01 1161	Gear - 20Z	1
7	A134 3086	Fixing Plate - Development	1
8	AB01 3880	Gear - 20Z	1
9	AB01 3879	Gear - 20Z	1
10	AA08 0176	Bushing	1
11	AA08 4047	Bushing Case	1
12	AA08 0178	Bushing - M5	1
13	AA13 2094	Spacer - Mounting Arm	2
14	AB01 1163	Gear - 33Z	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0802 5238	Tapping Screw - M4x12	
102	0443 0060B	Hexagon Tapping Screw - M3x6	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0443 0080B	Tapping Screw - M3x8	
105	0802 5232	Tapping Screw - M3x8	
106	0802 5237	Binding Self-tapping Screw - M4x10	
107	0720 0040E	Retaining Ring - M4	

21.DRUM UNIT (A217)




21.DRUM UNIT (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 2268	Front Drun Stand	1
2	A134 2252	Front Drum Plate	1
3	A096 2330	Drum Shaft Knob	1
4	A134 2300	Bushing - Drum	1
5	A096 3575	Blade Release Lever	1
6	AA06 3269	Pressure Spring	1
7	5853 1190	Spring - Click Plate	1
8	A134 2275	Cleaning Blade	1
9	A134 2259	Right Drum Stay	1
10	A133 9510	OPC Drum	1
11	A134 2271	Bracket - Cleaning Blade	1
12	A134 2391	Front Drum Seal	1
13	A134 2392	Rear Drum Seal	1
14	A134 2255	Rear Drum Plate	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0443 0050B	Philips Pan Head Screw - M3x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0443 0080B	Tapping Screw - M3x8	

22.CLEANING UNIT (A217)




22.CLEANING UNIT (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 2284	Cleaning Case Cover	1
2	A134 5310	Harness - ID Sensor	1
3	A134 5251	ID Sensor	1
4	AB01 3873	Gear - 26Z	1
5	A134 2278	Joint Gear - Cleaning	1
6	AA08 2045	Cleaning Brush Bushing	1
7	A134 2269	Positioning Plate - Pick-off Pawl	1
8	AA06 3373	Spring - 60mm	1
9	5324 1658	Bushing- 4x8x4.5mm	1
10	AD02 5020	Pick-off Pawl	2
11	A352 2138	Slide Collar - 0.6x4.5x6	2
12	AA06 6250	Pressure Spring	1
13	A096 3646	Pick-off Pawl Shaft	1
14	AA06 6251	Pressure Spring	1
15	AA08 0155	Rear Pawl Bushing	1
16	AD04 3033	Toner Collection Coil	1
17	AD04 2029	Cleaning Roller	1
18	A134 2277	Drive Shaft - Cleaning Roller	1
19	AB01 7323	Cam Gear - 35z	1
20	A134 2292	Casing Cleaning	1
21	A134 2263	Entrance Seal - Tape	1
22	AD04 7017	Entrance Seal - Cleaning	1

Index No.	Part No.	Description	Q'ty Per Assembly
102	0720 0030E	Retaining Ring - M3	
103	0802 5237	Binding Self-tapping Screw - M4x10	
104	0802 5232	Tapping Screw - M3x8	
105	0443 0050B	Philips Pan Head Screw - M3x6	

23.TRANSFER BELT UNIT (A217)




23.TRANSFER BELT UNIT (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 3850	Transfer Belt	1
2	A134 3872	Drive Roller - Transfer	1
3	A134 3854	Frame - Transfer Unit	1
4	A134 3880	Bias Roller - Transfer	1
5	AA08 2054	Bushing - M4	2
6	AA08 2051	Bushing - M8	2
7	A134 3856	Side Plate Drive Roller	2
8	AB01 3892	Gear - 18Z	1
9	A134 3891	Bushing - Drive Roller	1
10	AB01 3891	Gear - 30Z	1
11	A134 3860	Terminal Plate - Bias Roller	1
12	A134 3865	Bushing - Driver Roller	1
13	A217 3874	Driven Roller Transfer	1
14	A134 3998	Supporter - Transfer Unit	1
15	A134 3935	Lever - Transfer Belt Cleaning	1
16	AA06 6240	Pressure Spring	1
17	AA15 1922	Seal - 12x75x4	2
18	AZ30 0040	Power Pack - Transfer Unit	1
19	A134 3908	Seal - Power Pack - Transfer	1
20	A134 3915	Rear Release Lever	1
21	AB01 3569	Gear - 20Z	1
22	5205 2612	Gear - 19T	1
23	5875 2088	Shoulder Screw - M4	4
24	A134 3914	Front Release Lever	2
25	5219 1958	Spring - Lens Guide	2
26	A134 3912	Release Stay	1
27	A134 3934	Stay - Transfer Belt Cleaning	1
28	A134 3937	Bushing - Belt Cleaning	1
29	A134 3945	Cleaning Blade - Transfer Belt	1
30	AA14 3713	Shaft - Release Stay	1
31	A134 3903	Casing - Transfer Belt	1
32	AA13 2025	Spacer - 1x8x12	1
33	A079 3054	Seal - 3x5x8mm	1
34	A134 3960	Toner Collection Coil - Transfer	1
35	A134 3920	Mylar Transfer Entrance	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A134 3921	Tape 3 X 319	1
37	A134 3910	Mylar - Transfer Exit	1
38	A217 3800	Transfer Unit	1
101	0414 0080B	Binding Self-tapping Screw - M4x8	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0720 0060E	Retaining Ring - M6	
104	0720 0040E	Retaining Ring - M4	
105	0805 3490	Bushing - 5x10x4mm	
106	0725 0120E	Retaining Ring C - M12	
107	0313 0080B	Philips Pan Head Screw - M3x8	
108	0443 0060B	Hexagon Tapping Screw - M3x6	
109	1105 0229	Clamp	

24.FUSING UNIT 1 (A217)




24.FUSING UNIT 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 4130	Fusing Front Cover	1
2	AA14 3715	Stepped Screw - M5	2
3	A134 4063	Bias Plate - Thermofuse	1
4	A134 5265	Thermofuse	1
5	A134 5266	Thermistor	1
6	A134 4061	Rear Terminal Plate	1
7	A217 4051	Fusing Cover	1
8	A217 4084	Fusing Connector Bracket	1
9	A217 5407	Fusing Harness - 115V	1
9	A217 5408	Fusing Harness - 230V	1
10	AB01 3883	Idle Gear - 25Z	1
11	A217 4121	Heater Holder	2
12	AB01 3985	Gear - 40Z	1
13	AE03 2018	Bushing - 25x30x9	2
14	AE03 0003	Bushing - 30x42x27	2
15	AE01 1036	Hot Roller	1
16	AX44 0105	Fusing Lamp - 120V 790W (115V)	1
16	AX44 0106	Fusing Lamp - 230V 790W (230V)	1
17	A153 4114	Stripper Stopper	7
18	AE04 4013	Hot Roller Stripper	7
19	AA06 0103	Solenoid Spring	7
20	A204 4115	Shielding Plate	1
21	A217 4123	Discharge Brush	1
22	A204 4312	Stripper Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0954 4008B	Philips Screw - M4x8	
102	0950 4006M	Philips Screw With Flat Washer	
103	0313 0080B	Philips Pan Head Screw - M3x8	
104	1101 0475	Terminal	
105	0314 0100B	Philips Pan Head Screw - M4x10	
106	0725 0250E	Retaining Ring C - M25	
107	0314 0060B	Philips Pan Head Screw - M4x6	
108	0720 0060E	Retaining Ring - M6	

25.FUSING UNIT 2 (A217)




25.FUSING UNIT 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 4006	Fusing Exit Unit	1
2	AB01 3885	Idle Gear - 20Z	1
3	AB01 3884	Exit Gear - 17Z	1
4	AF02 0326	Exit Roller Ass'y	1
5	AF04 0548	Exit Driven Roller	2
6	AG07 0009	Magnetic Catch	1
7	A134 4280	Fusing Exit Guide - Lower	1
8	A153 4250	Fusing Exit Frame	1
9	AA06 2296	Tension Spring - 88N	2
10	AE02 0072	Pressure Roller	1
11	AE03 0027	Bearing - 12x24x64mm	2
12	AG05 0076	Fusing Knob	1
13	A134 4161	Pressure Lever	2
14	A204 4101	Front Side Plate	1
15	A204 4181	Front Release Lever	1
16	A204 4110	Rear Side Plate	1
17	A204 4185	Rear Release Lever	1
18	A204 4116	Entrance Guide Stay	1
19	A077 4162	Shoulder Screw - M3	1
20	A134 4153	Slide Rail - Fusing	1
21	A204 4151	Fusing Unit Base	1
22	AE03 1028	Bushing - 8x10x5	2
23	AE04 2030	Cleaning Roller	1
24	A204 4270	Cleaning Roller Bracket	1
25	A153 4207	Front Guide Plate	1
26	A217 4197	Lower Fusing Guide	1
27	A204 4207	Bracket - Exit Unit	1
28	A204 4072	Front Holder	1
29	A204 4073	Rear Holder	1
30	A153 4208	Rear Guide Plate	1
31	A134 4272	Roller Holder	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0802 5236	Tapping Screw - M4x8	
102	0434 0082B	Tapping Screw - M4x8	
103	0725 0120	Retaining Ring C - M12	
104	0720 0040E	Retaining Ring - M4	
105	0950 4008B	Philips Screw With Spring Waser - M4x8	
106	0805 3480	Bushing - 6mm	
107	0314 0060E	Philips Pan Head Screw - M4x6	
108	0951 4008B	Philips Screw With Waser - M4x8	

26.PAPER EXIT SECTION (A217)




26.PAPER EXIT SECTION (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 4464	Left Reverse Guide	1
2	AF04 0031	Upper Exit Roller	6
3	A134 4450	Upper Exit Guide	1
4	AA08 2058	Bushing - 6x10x9mm	2
5	A134 4456	Bracket - Exit Sensor	1
6	AW02 0071	Photointerruptor - Actuator	1
7	A134 5479	Harness - Exit Sensor	1
8	AF02 0327	Exit Roller	1
9	AF02 5023	Exit Pick-off Pawl	1
10	A133 7521	Exit Cover	1
11	A134 1092	Lamp Stabilizer Stay	1
12	AF02 0328	Relay Drive Roller	2
13	AB03 0475	Pulley - 18Z S2M	2
14	A134 4465	Turn Guide - Right Lower	1
15	A134 4460	Turn Gate - Right Upper Ass'y	1
16	AG07 0004	Magnetic Catch	2
17	A134 4458	Exit Unit Knob	1
18	AB01 3889	Gear - 24Z	1
19	A134 4455	Upper Guide Bracket	1
20	A134 4468	Lower Guide Plate	1
21	A134 4467	Left Bracket - Turn Gate	1
22	A134 4471	Stripper Solenoid	1
23	A470 1703	Shift Clutch	1
24	A470 1704	Spring - Lower Exit Roller	1
25	A134 4453	Roller Holder	6
26	5215 4497	Exit Antistatic Brush	1
27	A134 4466	Seal - Turn Guide	1
28	A134 4475	Guide Plate - Pulley	1
29	A134 1193	Sheet - Lamp Stabilizer Stay	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0802 5237	Binding Self-tapping Screw - M4x10	
102	0720 0040E	Retaining Ring - M4	
103	0313 0040B	Philips Pan Head Screw - M3x4	
104	0701 0060B	Flat Washer - M6	
105	0802 5085	Tapping Screw - M4x8	
106	0802 5236	Tapping Screw - M4x8	
107	0434 0060B	Philips Tapping Screw - M4x6	
108	0805 3480	Bushing - 6mm	
109	1105 0291	Wire Saddle	
110	1105 0328	Harness Clamp - ES-0505	

27.DUPLEX UNIT 1 (A217)




27.DUPLEX UNIT 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 2956	Paper Feed Front Cover	1
2	A134 4720	End Fence Upper Cover	1
3	A134 4701	Front Upper Cover	1
4	A134 4721	Connector Cover	1
5	A134 4728	Inverter Feeler	1
6	A134 4732	Upper Guide Plate	1
7	AF02 2077	Driven Roller	5
8	5206 2686	Snap Ring	2
9	A134 4726	Guide Plate Knob	1
10	A134 4739	Lower Guide Plate Knob	1
11	AF04 0031	Upper Exit Roller	1
12	A134 4619	Guide Plate Link	1
13	5447 2768	Stepped Screw - M3	1
14	A134 4730	Entrance Feeler	1
15	A134 4740	Lower Guide Plate	1
16	AA12 0067	Antistatic Brush	1
17	A154 4616	Paper Holder (RIC)	2
18	AF01 0018	Duplex Tray	1
19	AA16 2069	Guide Plate Pad	1
20	AA16 2068	Guide Plate Pad	1
21	A134 4884	Decal - Duplex Misfeed Removal	1


Index No.	Part No.	Description	Q'ty Per Assembly
101	0344 0080F	Philips Truss Head Screw - M4x8	
102	0802 5236	Tapping Screw - M4x8	
103	0802 5231	Tapping Screw - M3x6	
104	0443 0060B	Hexagon Tapping Screw - M3x6	

28.DUPLEX UNIT 2 (A217)





29.DUPLEX UNIT 3 (A217)




29.DUPLEX UNIT 3 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A154 4620	Bottom Plate	1
2	AF01 3003	Bottom Plate Pad - Duplex	1
3	AF01 6160	Rear Side Fence	1
4	AF01 6161	Front Side Fence	1
5	A204 4651	Bottom Pressure Plate	1
6	AA14 0291	Bottom Plate Shaft	1
7	A491 4690	Bottom Plate Hook	1
8	G011 3305	Gear - 16T	1
9	A134 4689	Rear Side Fence Rack	1
10	A134 4688	Front Side Fence Rack	1
11	AB03 0473	End Fence Pulley - 22Z	2
12	AB01 3881	Gear - 31Z	1
13	AB01 7400	Gear- 18Z/68Z	1
14	AB01 7339	End Fence Gear - 22Z/58Z	1
15	A134 4714	Tightener	1
16	AA06 3370	Spring	1
17	AA04 3374	Timing Belt - S2M800	1
18	AW02 0075	Photointerrupter	3
19	A134 4620	Grounding Plate	1
20	A134 5291	Jogger Drive Motor DC 6.48W	1
21	A134 5292	Jogger Drive Motor DC 10.56W	1
22	A134 5323	Motor Harness	1
23	A134 5254	Duplex Control Board	1
24	A134 4710	End Fence Actuator	1
25	A134 5322	End Fence Harness	1
26	A134 4525	End Fence Ass'y	1
27	AA06 6094	End Fence Spring	1
28	AA14 8252	End Fence Shaft	1
29	AF01 7014	End Fence	1
30	A134 5320	Duplex Main Harness	1
31	AF01 0018	Duplex Tray	1
32	A134 5321	Sensor Relay Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 3006B	Philips Screw With Flat Washer-M3x6	
102	0802 5232	Tapping Screw - M3x8	
103	0720 0040E	Retaining Ring - M4	
104	0802 5236	Tapping Screw - M4x8	
105	0720 0025E	Retaining Ring - M2.5	
106	0443 0122B	Hexagonal Tapping Screw - M3x12	

30.DRIVE SECTION 1 (A217)




30.DRIVE SECTION 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 5828	Long Bracket - Main Harness	1
2	AX07 0015	Motor - DC 63w	1
3	A134 5819	Left Upper Bracket - DC Supply	1
4	AA04 3368	Timing Belt - S3M609	1
5	AA04 3367	Timing Belt - S3M432	1
6	A134 2574	Flange - Gear	1
7	AB01 7342	Timing Pulley - 36/25Z	1
8	5013 0815	Pressuer Spring	1
9	AA04 3411	Timing Belt - S2M 300	1
10	A134 4481	Tightener Bracket	1
11	5414 4630	Bottle Spring	1
12	AA13 2013	Spacer - 8.2	1
13	A134 1154	Release Lever - Fusing Drive	1
14	A134 1150	Tension Bracket - Fusing Drive	1
15	AB01 7345	Timing Pulley - 35Z	1
16	AA04 3369	Timing Belt - S3M267	1
17	A134 1121	Joint Gear	1
18	AA05 1022	Drive Wire	1
19	AA06 0604	Spring - 230gf	1
20	A134 2370	Cam - Toner Collection Bottle	1
21	AB01 7344	Timing Rulley - 25/20Z	1
22	5215 3872	Gear - 45T	1
23	AB03 0463	Fusing Cam Pulley	1
24	AB01 3872	Fusing Cam Gear - 28Z	1
25	AB01 7346	Exit Gear	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	1105 0292	Wire Saddle	
104	1105 0316	Clamp	
105	1105 0413	Harness Clamp	
106	0951 4008B	Philips Screw With Washer - M4x8	
107	0720 0060E	Retaining Ring - M6	
108	0707 8100B	Bushing - M8x10	

31.DRIVE SECTION 2 (A217)




31.DRIVE SECTION 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX06 0135	DC Motor - 22W	1
2	A134 1114	Drum Holder	1
3	A134 1135	Fly Wheel	2
4	AA13 4092	Flange - Fly Wheel	1
5	AB03 0169	Timing Pulley - 120Z	1
6	AA04 3366	Timing Belt - S2M380	1
7	AB01 3893	Gear - 29Z	1
8	AX21 0046	Electrical Spring Clutch	1
9	AW02 0075	Photointerrupter	1
10	A134 5820	Bracket - Harness Clamp	1
11	A134 1109	Tightner Bracket - Paper Feed	1
12	A134 2278	Joint Gear - Cleaning	1
13	AA14 8418	Relay Shaft	1
14	AA06 3380	Spring - 16mm	1
15	A134 1126	Bracket - Cleaning Drive	1
16	AB01 4006	Gear - 40Z	1
17	AB01 7430	Timing Pulley - 30/35/25Z	1
18	A134 2358	Drum Shaft	1
19	AX20 0135	Magnetic Clutch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0314 0120B	Philips Pan Head Screw - M4x12	
103	0434 0060B	Philips Tapping Screw - M4x6	
105	0802 5236	Tapping Screw - M4x8	
106	0414 0080B	Binding Self-tapping Screw - M4x8	
107	1105 0328	Harness Clamp - ES-0505	
109	0720 0040E	Retaining Ring - M4	
110	0805 3480	Bushing - 6mm	
111	0951 4008B	Philips Screw With Washer - M4x8	
112	1105 0199	Clamp	
113	0725 0120W	Retaining Ring - M12	
114	0534 0040E	Hexagon Headless Set Screw - M4x4	

32.DRIVE SECTION 3 (A217)




32.DRIVE SECTION 3 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX20 0125	Magnetic Clutch - 0.35n.m - Z35	1
2	A133 7299	Stopper - Clutch	1
3	AB01 1170	Gear - 36Z	1
4	AB01 7432	Gear - 25Z	1
5	AB01 7335	Timing Pulley - 22Z/37Z	1
6	A134 2574	Flange - Gear	1
7	AB01 7333	Timing Pulley - 35/25Z	1
8	AA04 3364	Timing Belt - S3M300	1
9	AB03 0465	Timing Pulley - 25Z	1
10	A134 2572	Middle Tightener	1
11	AA06 0663	Spring - Tightener	1
12	AB03 0455	Tightener Pulley - 8x20x13	2
13	AB01 1153	Idle Gear - 25Z	1
14	AB01 1169	Gear - 28Z	1
15	A134 1109	Tightner Bracket - Paper Feed	1
16	AX20 0099	Magnetic Clutch - 7kgf.cm 26z	1
17	A134 2570	Stopper Bracket - Registration	1
18	A134 2579	Stopper Bracket	1
19	5053 0223	Bushing - 8mm	1
20	A134 2577	Upper Support Bracket - Paper Feed	1
21	A134 2575	Tightener Arm	1
22	AA06 0664	Spring - Tightener	1
23	AB01 7336	Timing Pulley - 30Z/35Z	2
24	AX20 0098	Magnetic Clutch - 7kg Cm 35z	1
25	AB03 0464	Timing Pulley - 30Z	1
26	AA04 3368	Timing Belt - S3M609	1
27	AX20 0100	Magnetic Clutch - 3.5kgf Cm 35z	1
28	AB01 3875	Reverse Gear - 27Z	1
29	AX20 0126	Magnetic Clutch - 0.25n.m - Z42	1
30	AA13 2133	Spacer - M8	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	1105 0199	Clamp	
104	0720 0030E	Retaining Ring - M3	
105	0951 4006B	Philips Screw With Washer - M4x6	
106	0720 0040E	Retaining Ring - M4	
107	0720 0060E	Retaining Ring - M6	

33.ELECTRICAL SECTION 1 (A217)




33.ELECTRICAL SECTION 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A133 7742	Harness - DC Main - Front	1
2	AW03 0052	Optics Fiber - 1300mm	1
4	A133 7725	SCU Board (230V)	1
4	A217 7715	SCU Board (115V)	1
5	A134 5834	Bracket - SCU	1
6	AZ32 0073	Power Pack - Charge	1
7	A134 5829	Bracket - Charge Power Pack	1
8	A134 5813	Bracket - AC Drive Board	1
9	A217 5500	AC Drive Board (115V)	1
9	A133 7710	AC Drive Board (230V)	1
10	A217 5405	AC Main Harness - 115V	1
10	A217 5406	AC Main Harness - 230V	1
11	A217 5301	Harness - DC Main	1
12	A133 7742	Harness - DC Main - Front	1
12	A217 5302	Harness - DC Main - Rear	1
13	A217 7726	BCU Board	1
14	A134 5831	Bracket - BCU	1
15	AZ24 0028	DC Supply Board (115V)	1
15	AZ24 0031	DC Supply Board (230V)	1
16	A134 1966	Drive Board - Scanne Motor	1
17	AZ23 0075	Lamp Stabilizer (115V)	1
17	AZ23 0073	Lamp Stabilizer (230V)	1
18	AW03 0051	Optics Fiber - 520mm	1
19	A217 7717	IC - UVEPROM 4M X16 150NS (LT)	1
20	A217 7720	IC - UVEPROM 4M X16 150NS (LT)	1
21	A217 7723	IC - UVNPROM 4MX16 150NS	1
22	A133 7786	Grounding Plate Bracket - SCU (230V)	1
23	A134 5372	Harness - Scanner Lamp	1
24	AZ02 0009	Choke Coil - 10mH 2A	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0443 0060B	Hexagon Tapping Screw - M3x6	
102	1105 0329	Clamp - ES-0510	
103	1105 0291	Wire Saddle	
104	1105 0199	Clamp	
105	0951 4006B	Philips Screw With Washer - M4x6	
106	1107 0554	Fuse (glass Case) - 17A - 125V	
107	1105 0292	Wire Saddle	
108	1107 0393	Fuse (glass Case) - 8A - 125V	
109	1107 0392	Fuse (glass Case) - 6.3A - 125V	
110	0434 0060B	Philips Tapping Screw - M4x6	
111	1407 4696	IC - M48T58Y-70PC1	
112	1105 0310	Clamp - LWS-1S	
113	0353 0080B	Screw - M3x8	

34.ELECTRICAL SECTION 2 (A217)




34.ELECTRICAL SECTION 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 1174	Exhaust Fan Motor - DC, 2.88W	1
2	AW50 0010	Push Switch	2
3	A134 2941	Bracket - Paper Sizesensor	2
4	A134 5816	Right Upper Bracket - DC Supply	1
5	AA01 0098	Ozone Filter - 64x45x30	1
6	A130 1175	Main Corona Duct	1
7	A134 1099	Right Bracket - ADF	1
8	A134 5827	Short Bracket - Main Harness	1
9	AW03 0051	Optics Fiber - 520mm	1
10	A134 1065	Fusing Connector Bracket	1
11	A217 5405	AC Main Harness - 115V	1
11	A217 5406	Harness - AC Main (230V)	1
12	A134 1096	Left Bracket - ADF	1
13	AW02 0022	Photointerruptor	1
14	A134 1098	Positioning Sensor Bracket	1
15	AA14 3301	Stepped Screw - M3x4	2
16	AW03 0053	Optics Fiber - 860mm	1
17	A134 5811	Bracket - Power Cord	1
18	A217 5301	Harness - DC Main	1
19	AZ00 0013	Power Supply Cord - (115V)	1
19	A153 5671	Power Supply Cord (230V)	1
20	AA01 2077	Dust Filter - Exhaust Fan	1
21	A134 1190	Exhaust Fan Duct	1
22	AX64 0054	Fan Motor - DC 2.4W	1
23	A134 2933	Tray Lift Motor - DC24V 0.5W	1
24	A134 1292	Bracket - Upper Cover	1
25	A154 4618	Bracket Socket	1
26	A134 5319	Harness - Duplex Unit	1
27	AA06 3532	Spring	2
28	AA14 3452	Stepped Screw	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 4052	Optional Connector	
102	0443 0060B	Hexagon Tapping Screw - M3x6	
103	0414 0352B	Tapping Screw -M4x35	
104	0434 0060B	Philips Tapping Screw - M4x6	
105	1105 0316	Clamp	
106	0414 0060B	Tapping Screw - M4x6	
107	1105 0229	Clamp	
108	0434 0120B	Tapping Screw - M4x12	
109	0414 0080B	Binding Self-tapping Screw - M4x8	
110	0323 0060B	Philips Sunk Screw - M3x6	
111	0314 0350B	Philips Pan Head Screw - M4x35	
112	0950 4006M	Philips Screw With Flat Washer-M4x6	
113	1105 0292	Wire Saddle	
114	0801 0149	Philips Pan Head Screw - M4x6	
115	1105 0413	Harness Clamp	

35.ELECTRICAL SECTION 3 (A217)




35.ELECTRICAL SECTION 3 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A133 7775	Bracket - Interlock Switch	1
2	A134 5823	Arm - Interlock Switch	1
3	5442 4467	Spring - Stripper Pawl Plate	1
4	AA05 1022	Drive Wire	1
5	AX31 0022	Total Counter	1
6	A134 5826	Bracket - Total Counter	1
7	A134 2344	Harness Bracket	1
8	5408 5160	Short Connector	1
9	AG07 0004	Magnetic Catch	1
10	A134 1318	Side Bracket - Front Cover	1
11	A134 3203	Shutter Bracket - Toner Holder	1
12	A134 3201	Cam - Toner Bottle	1
13	A133 7017	Right Grip Plate	1
14	5875 2088	Shoulder Screw - M4	2
15	A134 5824	Bracket - Power Pack	1
16	A134 1319	Middle Bracket - Front Cover	1
17	A133 7098	Total Caunter Cover	1
18	A134 5241	Power Pack	1
19	A134 1071	Left Grip Plate	1
20	A134 1072	Right Bracket - Grip Plate	1
21	A134 1073	Left Bracket - Grip Plate	1
22	A133 7097	Right Hinge Bracket	1
23	A133 7784	Power Pack Bracket	1
24	A133 7785	Spring Plate - Power Pack	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1204 2355	Micro Switch - AM51632A531	
102	0313 0350B	Philips Pan Head Screw - M3x35	
103	1102 4559	Connector - 3p	
104	1102 6245	Connector - 2p	
105	1102 4473	Ct Connector - 2p	
106	0434 0060B	Philips Tapping Screw - M4x6	
107	0353 0300B	Bind Screw - M3x30	
108	1105 0199	Clamp	
109	1105 0310	Wire Clamp	
110	1105 0291	Wire Saddle	
111	1105 0292	Wire Saddle	
112	1105 0329	Clamp - ES-0510	
113	1204 2421	Main Switch	
114	1105 0367	Spacer	

36.ELECTRICAL SECTION 4 (A217)




36.ELECTRICAL SECTION 4 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A133 7798	Bracket - HDD	1
2	A133 7885	HDD-1.7GB-SCSI	1
3	A133 7920	HDD Harness	1
4	A134 5833	Lower Bracket - SCU	1
5	A134 5832	Upper Bracket - SCU	1
6	A134 1345	Rear Cover Bracket	1
7	A134 5818	Left Lower Bracket - DC Supply	1
8	A134 5817	Right Lower Bracket - DC Supply	1
9	A134 1071	Left Grip Plate	1
10	A134 1073	Left Bracket - Grip Plate	1
11	A134 1072	Right Bracket - Grip Plate	1
12	A133 7099	Braclet - Rear Cover	1
13	A133 7781	Bracket - Circuit Breaker (230V)	1
14	A133 7760	Relay Harness - Circuit Breaker (230V)	1
15	A133 7705	Relay Board	1
16	A133 7017	Right Grip Plate	1
17	A133 7788	Spring Plate - HDD	1
18	AA14 3499	Stepped Screw - HDD	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0329	Clamp - ES-0510	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0742 3808M	Bushing - 8x16x5	
104	0720 0060E	Retaining Ring - M6	
105	0720 0040E	Retaining Ring - M4	
106	0443 0060B	Hexagon Tapping Screw - M3x6	
107	0805 3386	Bushing - 8mm	
108	0443 0140B	Tapping Screw - M3x14	
109	0805 3492	Bushing - 8x16x5	
110	1105 0087	Clamp	
111	1105 0316	Clamp	
112	1105 0292	Wire Saddle	
113	1105 0291	Wire Saddle	
114	0960 3004B	Screw - M3x4	
115	1105 0310	Wire Clamp	
116	0801 0153	Bind Screw - M6	
117	1105 0193	Nylon Stud	
118	1107 0472	Circuit Breaker - 250V/8A	

37.FRAME SECTION 1 (A217)




37.FRAME SECTION 1 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 2921	Left Slide Rail	2
2	A134 2926	Paper Feed Lock Bracket	2
3	A096 6266	Tray Lock Arm	2
4	AA06 0534	Tray Lock Spring - 19mm	2
5	A134 3975	Paper Guide Stay	1
6	AA08 2064	Bushing - 10mm	1
7	A134 2947	Heater Cover	1
8	AX40 0066	Heater - 120V 9W	2
8	AX40 0067	Heater - 230V 9W	2
9	A134 4352	Fusing Lock Lever	1
10	5442 4467	Spring - Stripper Pawl Plate	1
11	5203 1686	Screw - Slid Rail	1
12	A134 4351	Stay - Fusing Rail	1
13	A134 2375	Left Stay - Collection Bottle	1
14	A134 4355	Fusing Unit Stopper	1
15	A134 1081	Transfer Unit Stay	1
16	A134 2374	Right Stay - Collection Bottle	1
17	A134 3980	Stay - Transfer Unit Handle	1
18	A134 1063	Transfer Unit Bracket	1
19	5215 2621	Snap Ring - M6	1
20	AH01 0007	Rubber Foot	4
21	A134 1084	Drum Heater Cover	1
22	A060 3826	Toner Collection Bottle Roller	2
23	A134 1083	Paper Feed Stay	1
24	A134 4901	Duplex Right Rail	1
25	A134 2930	Right Slide Rail	1
26	AG05 1113	Handle - Transfer Unit	1
27	AA14 3724	Stepped Screw	4
28	A060 3827	Roller Holder	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0720 0040E	Retaining Ring - M4	
103	0414 0080B	Binding Self-tapping Screw - M4x8	
104	0960 4010B	Philips Flange Screw - M4 X 10	

38.FRAME SECTION 2 (A217)




38.FRAME SECTION 2 (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A134 1076	Left Stay - Exposure Unit	1
2	A134 1164	Cooling Fan Bracket	1
3	AX64 0053	Fan Motor - DC 1.44W	1
4	AX50 0051	Quenching Lamp	1
5	A134 2332	Absorb Duct	1
6	AA01 2078	Dust Filter - Vacuum Fan	1
7	A134 2334	Middle Exhaust Duct	1
8	A134 1080	Right Stay - Exposure Unit	1
9	A134 3229	Stopper - Development Unit	1
10	A134 5825	Rear Bracket - Power Pack	1
11	A134 3227	Positioning Holder - Development	1
13	AD02 1121	Receptacle - Charger	1
14	A134 1192	Seal - Fan Motor	1
15	A134 1161	Cooling Fan Duct	1
16	A134 2346	Drum Guide Stay - Left	1
17	A134 1195	Seal - Fan Harness	1
18	A134 2342	Cusion - Drum	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0060B	Tapping Screw - M4x6	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0951 4006B	Philips Screw With Washer - M4x6	
104	0353 0300B	Bind Screw - M3x30	
105	1607 0903	Ferrite Core : HF70RH16x28x10 (230V)	

39.500 COPY TRAY (A615)



39.500 COPY TRAY (A615)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF04 3069	Copy Tray	1
2	AF04 3076	Copy Tray Slide	1
3	AF04 3077	Copy Tray Guide	1
4	AA06 0666	Tension Spring : 12N	1
5	AA07 0034	Slide Rail	1
6	AA14 3737	Stripped Screw	1
7	AB01 5013	Rack	1
8	A615 4453	Side Plate : Rising Tray : Front	1
9	A615 4455	Bracket : Paper Ext Sup	1
10	A615 4463	Rear Side Plate - Copy Tray Holder	1
11	A615 4472	Upper Stay	1
12	A615 4473	Lower Stay	1
13	A615 4474	Copy Tray Holder	1
14	A615 4480	Cover - Copy Tray	1
15	A615 4457	Oil Dumper - 0.05 NFM	1
16	A615 4465	Rear Side Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006B	Tapping Screw - 4x6	
102	0720 0040E	Retaining Ring - M4	
103	0313 0050B	Philips Pan Head Screw - M3x5	
104	0802 5236	Tapping Screw - M4x8	

40.SCU BOARD (A217)

CAPACITOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
C401	159	C411	132	C421	132	C431	132	C441	132	C451	134	C461	134
C402	159	C412	132	C422	132	C432	132	C442	132	C452	134	C462	----
C403	132	C413	132	C423	132	C433	132	C443	130	C453	134	C463	134
C404	132	C414	132	C424	132	C434	132	C444	132	C454	134	C464	134
C405	132	C415	133	C425	132	C435	132	C445	132	C455	134	C465	133
C406	132	C416	132	C426	133	C436	132	C446	----	C456	134	C466	133
C407	133	C417	132	C427	135	C437	132	C447	----	C457	134	C467	133
C408	133	C418	132	C428	129	C438	132	C448	134	C458	134	C468	133
C409	133	C419	131	C429	132	C439	132	C449	134	C459	134	C469	----
C410	132	C420	131	C430	134	C440	132	C450	134	C460	134	C470	----

CNNECTOR

CYMBOL NO.	INDEX NO.
CN401	108
CN402	103
CN403	101
CN404	109
CN405	113
CN406	106
CN407	112
CN408	104
CN409	111
CN410	110

CYMBOL NO.	INDEX NO.
CN411	----
CN412	----
CN413	107
CN414	102
CN415	105

DPS

CYMBOL NO.	INDEX NO.
DPS401	116

FIB

CYMBOL NO.	INDEX NO.
FIB401	136
FIB402	136
FIB403	----
FIB404	136
FIB405	137
FIB406	137
FIB407	136

FL

CYMBOL NO.	INDEX NO.
FL401	128
FL402	138
FL403	138
FL404	138
FL405	138
FL406	138
FL407	138
FL408	138
FL409	138
FL410	138

CYMBOL NO.	INDEX NO.
FL411	138
FL412	138

IC

CYMBOL NO.	INDEX NO.
IC401	125
IC402	124
IC403	120
IC404	----
IC405	119
IC406	123
(IC406)	115
IC407	1
IC408	122
IC409	122
IC410	121

IC

CYMBOL NO.	INDEX NO.
(IC411)	114
(IC412)	114
(IC413)	114

RED

CYMBOL NO.	INDEX NO.
LED401	118

OSC

CYMBOL NO.	INDEX NO.
OSC401	127
OSC402	126

RESISTOR

CYMBOL NO.	INDEX NO.
R401	152
R402	148
R403	156
R404	151
R405	144
R406	154
R407	143
R408	154
R409	143
R410	143

CYMBOL NO.	INDEX NO.
R411	143
R412	143
R413	143
R414	143
R415	143
R416	140
R417	140
R228	140
R419	140
R420	140

CYMBOL NO.	INDEX NO.
R421	140
R422	140
R423	140
R424	144
R425	144
R426	147
R427	142
R428	142
R429	153
R430	144

CYMBOL NO.	INDEX NO.
R431	144
R432	153
R433	143
R434	157
R435	158
R436	152
R437	152
R438	152
R439	152
R440	152

RESISTOR

CYMBOL NO.	INDEX NO.
R441	152
R442	152
R443	152
R444	152
R445	152
R446	152
R447	152
R448	152
R449	152
R450	152

CYMBOL NO.	INDEX NO.
R451	152
R452	143
R453	144
R454	145
R455	156
R456	151
R457	144
R458	144
R459	144
R460	144

CYMBOL NO.	INDEX NO.
R461	144
R462	150
R463	146
R464	143
R465	144
R466	144
R467	144
R468	144
R469	144
R470	144

CYMBOL NO.	INDEX NO.
R471	144
R472	144
R473	144
R474	144
R475	149
R476	144
R477	148
R478	139
R479	149
R480	152

CYMBOL NO.	INDEX NO.
R481	152
R482	152
R483	144
R484	149
R485	149
R486	144
R487	144
R488	149
R489	149
R490	155

CYMBOL NO.	INDEX NO.
R491	149
R492	149
R493	149
R494	149
R495	149
R496	149
R497	149
R498	149
R499	149
R500	149

CYMBOL NO.	INDEX NO.
R501	149
R502	149
R503	149
R504	149
R505	149
R506	149
R507	149
R508	149
R509	149
R510	149

40.SCU BOARD (A217)

RESISTOR

CYMBOL NO.	INDEX NO.
R511	149
R512	149
R513	149
R514	149
R515	149
R516	149
R517	149
R518	141
R519	149
R520	149

CYMBOL NO.	INDEX NO.
R521	152
R522	152

TP

CYMBOL NO.	INDEX NO.
TP401	----
TP402	100

ZD

CYMBOL NO.	INDEX NO.
ZD401	117

40.SCU BOARD (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A217 7715	SCU Board (115V)	1
*	A133 7725	SCU Board (230V)	1
1	A134 5119	IC - TC160G22AF-1024	1
2	A217 7717	IC - UVNPROM 4MX16 150NS (115V)	1
3	A217 7720	IC - UVNPROM 4MX16 150NS (115V)	1
4	A217 7723	IC - UVNPROM 4MX16 150NS (115V)	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	1101 0328	Connector Pin Contact	
101	1102 4201	Connector - 2P	
102	1102 4202	Connector - 3P	
103	1102 4203	CT Header - 4P	
104	1102 4204	CT Header - 5P	
105	1102 4621	CT Header - 4P	
106	1102 4631	CT Connector - 2P	
107	1102 5276	Connector - 4P	
108	1102 5311	Connector - 6P	
109	1102 5409	Connector - 20P	
110	1102 5718	Optical Fiber Connector	
111	1102 6295	Connector - 2P	
112	1102 6559	Connector - 60P	
113	1103 1317	Connector	
114	1104 0376	IC Socket - 40P - DICF-40CS-E	
115	1104 0377	IC Socket - 28P - DICF-28CS-E	
116	1204 1570	Dip Switch	
117	1402 0688	Diode	
118	1403 0308	LED - RED - TLR102A	
119	1407 2344	IC - TD62382F	
120	1407 4145	IC - HD74LS07pF	
121	1407 4209	CPU MC68340FE16E	
122	1407 4336	PSRAM	
123	1407 4696	IC - M48T58Y-70PC1	
124	1408 0611	IC - 3771	
125	1408 0874	Transistor Array - M54587FP	
126	1503 0095	Oscillator - P3 32.768KHZ	
127	1503 0518	Oscillator - CSA4.91MGG	
128	1602 0918	Filter - 270pF - Emi	
129	1605 0223	Capacitor - 20pF 50V	
130	1605 0322	Capacitor - 47pF 50V	
131	1605 0343	Capacitor - 30pF ±5% 50V	
132	1605 0636	Capacitor - 0.1MF	
133	1606 1139	Capacitor - 0.01μF±20%	
134	1606 1208	Capacitor - 100pF ±5% 50V	

Index No.	Part No.	Description	Q'ty Per Assembly
135	1606 1450	Capacitor - 10pF 50V	
136	1607 0477	Coil - BLM21A121SPB	
137	1607 0551	Inductor - BLM32A07PB	
138	1607 0705	Noize Filter - ACF51832-470	
139	1630 1121	Resistor - 120Ω±5% 1/8W	
140	1630 1161	Resistor - 160Ω ±5% 1/8W	
141	1630 2100	Resistor - 10Ω 1/8W ±5%	
142	1630 2101	Resistor - 100Ω 1/8W	
143	1630 2102	Resistor - 1K Ω 1/8W ±5%	
144	1630 2103	Resistor - 10K Ω 1/8W	
145	1630 2106	Resistor - 10MΩ -1/8W	
146	1630 2206	Resistor - 20M Ω 1/8W ±5%	
147	1630 2221	Resistor - 220 Ω	
148	1630 2222	Resistor - 2.2K Ω 1/8W	
149	1630 2330	Resistor - 33Ω 1/8W ±5%	
150	1630 2334	Resistor - 330KΩ	
151	1630 2471	Resistor - 470Ω 1/8W ±5%	
152	1630 2472	Resistor - 4.7K Ω 1/8W ±5%	
153	1630 2473	Resistor - 47KΩ 1/8W ±5%	
154	1630 2511	Resistor - 510Ω 1/8W ±5%	
155	1630 2680	Resistor - 68Ω 1/8W ±5%	
156	1630 2681	Resistor - 680Ω 1/8W ±5%	
157	1632 1002	Resistor - 10.0KΩ1/8W±1%	
158	1632 3481	Resistor - 3.48KΩ ±1% 1/8W	
159	1640 5101	Capacitor - 100μF±20% 50V	

Index No.	Part No.	Description	Q'ty Per Assembly

41.BCU BOARD (A217)

CAPACITOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
C201	188	C211	152	C221	152	C231	156	C241	157	C251	152	C261	152
C202	188	C212	155	C222	152	C232	152	C242	157	C252	152	C262	152
C203	189	C213	155	C223	152	C233	152	C243	152	C253	152	C263	155
C204	152	C214	152	C224	152	C234	152	C244	152	C254	152	C264	157
C205	157	C215	152	C225	152	C235	152	C245	152	C255	152	C225	152
C206	157	C216	152	C226	152	C236	152	C246	152	C256	152	C266	153
C207	157	C217	----	C227	150	C237	152	C247	152	C257	152	C267	153
C208	154	C218	151	C228	156	C238	152	C248	152	C258	152	C268	154
C209	152	C219	152	C229	157	C239	152	C249	152	C259	152	C269	154
C210	157	C220	152	C230	150	C240	157	C250	152	C260	152	C270	154

CAPACITOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
C271	152	C281	157	C291	157	C301	155	C311	155	CN201	116	CN211	114
C272	154	C282	152	C292	155	C302	155	C312	155	CN202	192	CN212	113
C273	152	C283	152	C293	155	C303	155	C313	----	CN203	104	CN213	113
C274	152	C284	152	C294	155	C304	155	C314	152	CN204	----	CN214	114
C275	152	C285	157	C295	155	C305	155			CN205	110	CN215	104
C276	152	C286	157	C296	155	C306	155			CN206	103	CN216	106
C277	157	C287	157	C297	155	C307	148			CN207	102	CN217	105
C278	157	C288	157	C298	155	C308	148			CN208	107	CN218	111
C279	157	C289	157	C299	155	C309	155			CN209	107	CN219	115
C280	152	C290	154	C300	155	C310	155			CN210	112	CN220	115

CNNECTOR

41.BCU BOARD (A217)

CNNECTOR

CYMBOL NO.	INDEX NO.
CN221	115
CN222	108
CN223	101
CN299	109

DA

CYMBOL NO.	INDEX NO.
DA201	123
DA202	123
DA203	124
DA204	123
DA205	124

DPS

CYMBOL NO.	INDEX NO.
DPS201	119

FL

CYMBOL NO.	INDEX NO.
FL201	193

IC

CYMBOL NO.	INDEX NO.
IC201	140
IC202	2
(SolCket)	118
IC203	128
IC204	128
IC205	128
IC206	136
IC207	135
IC208	190
IC209	126
IC210	129

CYMBOL NO.	INDEX NO.
IC211	130
IC212	1
IC213	3
(SolCket)	117
IC214	130
IC215	137
IC216	130
IC217	135
IC218	132
IC219	128
IC220	127

CYMBOL NO.	INDEX NO.
IC221	131
IC222	138
IC223	---
IC224	138
IC225	139
IC226	133
IC227	126
IC228	190

L

CYMBOL NO.	INDEX NO.
L201	158
L202	158
L203	158
L204	158
L205	158

LED

CYMBOL NO.	INDEX NO.
LED201	125
LED202	125

OSC

CYMBOL NO.	INDEX NO.
OSC201	194
OSC202	142
OSC203	143

Q

CYMBOL NO.	INDEX NO.
Q201	120

RESISTOR

CYMBOL NO.	INDEX NO.
R201	177
R202	164
R203	171
R204	165
R205	161
R206	161
R207	161
R208	162
R209	165
R210	165

CYMBOL NO.	INDEX NO.
R211	165
R212	171
R213	165
R214	165
R215	165
R216	195
R217	195
R228	165
R219	165
R220	165

CYMBOL NO.	INDEX NO.
R221	164
R222	181
R223	165
R224	165
R225	165
R226	165
R227	165
R228	165
R229	165
R230	165

RESISTOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
R231	174	R241	177	R251	165	R261	165	R271	174	R281	165	R291	165
R232	165	R242	165	R252	165	R262	165	R272	165	R282	165	R292	165
R233	169	R243	165	R253	165	R263	165	R273	165	R283	164	R293	165
R234	175	R244	165	R254	165	R264	165	R274	165	R284	164	R294	165
R235	165	R245	165	R255	165	R265	165	R275	164	R285	164	R295	164
R236	165	R246	165	R256	165	R266	165	R276	165	R286	165	R296	165
R237	165	R247	165	R257	165	R267	165	R277	165	R287	165	R297	165
R238	165	R248	165	R258	165	R268	165	R278	180	R288	179	R298	165
R239	165	R249	165	R259	165	R269	165	R279	163	R289	164	R299	178
R240	166	R250	164	R260	165	R270	195	R280	165	R290	165	R300	165

RESISTOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
R301	165	R311	164	R321	165	R331	174	R341	164	R351	195	R361	165
R302	187	R312	165	R322	164	R332	185	R342	179	R352	195	R362	165
R303	184	R313	165	R323	165	R333	165	R343	164	R353	195	R363	165
R304	174	R314	170	R324	165	R334	164	R344	183	R354	179	R364	165
R305	178	R315	170	R325	167	R335	164	R345	165	R355	195	R365	165
R306	168	R316	164	R326	176	R336	164	R346	179	R356	195	R366	165
R307	168	R317	179	R327	165	R337	164	R347	164	R357	195	R367	165
R308	178	R318	165	R328	191	R338	178	R348	160	R358	178	R368	165
R309	172	R319	164	R329	185	R339	165	R349	171	R359	165	R369	165
R310	172	R320	165	R330	174	R340	179	R350	195	R360	165	R370	165

41.BCU BOARD (A217)

RESISTOR

CYMBOL NO.	INDEX NO.
R371	195
R372	195
R373	195
R374	195
R375	195
R376	195
R377	195
R378	165
R379	165
R380	195

CYMBOL NO.	INDEX NO.
R381	195
R382	195
R383	195
R384	195
R385	195
R386	195
R387	195
R388	195
R389	195
R390	165

CYMBOL NO.	INDEX NO.
R391	165
R392	165
R393	195
R394	195

TP

CYMBOL NO.	INDEX NO.
TP208	100

ZD

CYMBOL NO.	INDEX NO.
ZD201	121
ZD202	122
ZD203	122
ZD204	122

41.BCU BOARD (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A217 7726	BCU Board	1
1	A134 5109	IC - JSL38G519AN05	1
2	A217 5108	IC - UVNPROM 4MX16 150NS	1
3	A217 7727	IC - HD6433278A44P10	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	1101 0328	Connector Pin Contact	
101	1102 4202	Connector - 3P	
102	1102 4203	CT Header - 4P	
103	1102 4205	CT Header - 6P	
104	1102 4207	Connector - 8P	
105	1102 4208	Connector - 9P	
106	1102 4211	CT Header - 12P	
107	1102 4497	Connector - 13P	
108	1102 4621	CT Header - 4P	
109	1102 4626	Connector - 9P	
110	1102 4644	Connector - 9P	
111	1102 5007	CT Header - 14P	
112	1102 5409	CT Header - 20P	
113	1102 5410	Connector - 22P	
114	1102 5413	Connector - 28P	
115	1102 5718	Optical Fiber Connector	
116	1102 6600	Connector - 8PP	
117	1104 0370	IC Socket - 64P	
118	1104 0376	IC Socket - 40P - DICF-40CS-E	
119	1204 1537	Dip Switch	
120	1400 0558	Transistor - 2SD780	
121	1402 0688	Diode	
122	1402 1037	Diode - U1ZB12	
123	1402 1122	Diode - MA159A	
124	1402 1191	Diode - 400V 1A	
125	1403 0308	LED - Red - TLR102A	
126	1407 1596	TTLIC - SN74LS14NS	
127	1407 1598	TTLIC - SN74LS125ANS	
128	1407 2187	TTLIC - SN74LS07NS	
129	1407 2218	TTLIC - SN74LS06NS	
130	1407 2231	IC - TD62308AF	
131	1407 2261	IC - NJM2902M	
132	1407 3285	IC - TC74HC08AF	
133	1407 3380	HS - C2MOS - TC74HCT04AF	
134	1407 4315	IC - TE7751	

Index No.	Part No.	Description	Q'ty Per Assembly
135	1407 4791	CPU MC68340FT16E	
136	1408 0598	IC - MB3773pF	
137	1408 0770	IC - L293D	
138	1408 0874	Transistor Array - M54587FP	
139	1408 0877	Comparator - LM339NS	
140	1408 1278	IC:L6220	
141	1503 0460	Ocsillator - 32.768kHz	
142	1503 0504	Ocsillator - TQC-246C-6R-3.6864M	
143	1503 0569	Ocsillator - 19.66MHz	
144	1601 7738	Resistor - 10 Ω X 8 5%	
145	1601 7739	Resistor - 4.7K Ω X 2 5%	
146	1601 7740	Resistor - 4.7K Ω -5% 1/32W	
147	1601 7741	Resistor - 4.7K Ω -5% 1/32W	
148	1604 4521	Capacitor - 0.47 μ F $\pm$ 20% 50V	
149	1605 0219	Capacitor - 1000pF 50V +80% -20%	
150	1605 0223	Capacitor - 20pF 50V	
151	1605 0322	Capacitor - 47pF 50V	
152	1605 0636	Capacitor - 0.1MF	
153	1606 1133	Capacitor - 22pF - 50V	
154	1606 1135	Capacitor - 470pF 50V	
155	1606 1208	Capacitor - 100pF $\pm$ 5% 50V	
156	1606 1450	Capacitor - 10pF 50V	
157	1606 1452	Capacitor - 0.01 μ F50V	
158	1607 0551	Inductor - BLM32A07PB	
159	1607 0796	Noize Filter - ACF51832-470	
160	1630 1101	Resistor - 100 Ω 1/4W $\pm$ 5%	
161	1630 1121	Resistor - 120 Ω $\pm$ 5% 1/8W	
162	1630 1161	Resistor - 160 Ω $\pm$ 5% 1/8W	
163	1630 1222	Resistor - 2.2K Ω $\pm$ 5% 1/8W	
164	1630 2102	Resistor - 1K Ω 1/8W $\pm$ 5%	
165	1630 2103	Resistor - 10K Ω 1/8W	
166	1630 2106	Resistor - 10M Ω -1/8W	
167	1630 2152	Resistor - 1.5K Ω 1/8W $\pm$ 5%	
168	1630 2204	Resistor - 200K Ω $\pm$ 5% 1/8W	

Index No.	Part No.	Description	Q'ty Per Assembly
169	1630 2206	Resistor - 20M Ω 1/8W $\pm$ 5%	
170	1630 2221	Resistor - 220 Ω	
171	1630 2222	Resistor - 2.2K Ω 1/8W	
172	1630 2243	Resistor - 24K Ω 1/8W $\pm$ 5%	
173	1630 2330	Resistor - 33 Ω 1/8W $\pm$ 5%	
174	1630 2332	Resistor - 3.3K Ω 1/8W $\pm$ 5%	
175	1630 2334	Resistor - 330K Ω	
176	1630 2362	Resistor - 3.6K Ω 1/8W $\pm$ 5%	
177	1630 2471	Resistor - 470 Ω 1/8W $\pm$ 5%	
178	1630 2472	Resistor - 4.7K Ω 1/8W $\pm$ 5%	
179	1630 2511	Resistor - 510 Ω 1/8W $\pm$ 5%	
180	1630 2561	Resistor - 560 Ω $\pm$ 5% 1/8W	
181	1630 2680	Resistor - 68 Ω 1/8W $\pm$ 5%	
182	1630 2750	Resistor - 758 Ω 1/8W $\pm$ 5%	
183	1630 2821	Resistor - 820 Ω 1/8W $\pm$ 5%	
184	1632 4641	Resistor - 4.64K Ω $\pm$ 1% 1/8W	
185	1632 5231	Resistor - 5.23K Ω $\pm$ 1%	
186	1632 5360	Resistor - 536 Ω $\pm$ 1% 1/8W	
187	1632 5621	Resistor - 5.62K Ω $\pm$ 1% 1/8W	
188	1640 5101	Capacitor - 100 μ F $\pm$ 20% 50V	
189	1640 5338	Capacitor - 0.33mF $\pm$ 20%	
190	1902 0012	C SRAM 256K X8 100NS G3	

42.IPU BOARD (A217)

AR

CYMBOL NO.	INDEX NO.
AR 1	156
AR 2	156
AR 3	156
AR 4	156
AR 5	156
AR 6	156
AR 7	157
AR 8	157
AR 9	158
AR10	158

CYMBOL NO.	INDEX NO.
AR11	158
AR12	158
AR13	158
AR14	----
AR15	----
AR16	158
AR17	158
AR18	----
AR19	----
AR20	156

CYMBOL NO.	INDEX NO.
AR21	156
AR22	160
AR23	160
AR24	160
AR25	160
AR26	159
AR27	159
AR28	159
AR29	159
AR30	159

CYMBOL NO.	INDEX NO.
AR31	158
AR32	158

CAPACITOR

CYMBOL NO.	INDEX NO.
C 1	224
C 2	236
C 3	235
C 4	237
C 5	226
C 6	----
C 7	----
C 8	----
C 9	235
C10	220

CYMBOL NO.	INDEX NO.
C11	237
C12	----
C13	----
C14	237
C15	164
C16	237
C17	237
C18	237
C19	237
C20	237

CYMBOL NO.	INDEX NO.
C21	237
C22	237
C23	237
C24	237
C25	237
C26	237
C27	237
C28	237
C29	237
C30	237

CAPACITOR

CYMBOL NO.	INDEX NO.
C31	237
C32	232
C33	231
C34	232
C35	231
C36	227
C37	232
C38	231
C39	232
C40	231

CYMBOL NO.	INDEX NO.
C41	227
C42	237
C43	235
C44	237
C45	235
C46	237
C47	235
C48	235
C49	235
C50	161

CYMBOL NO.	INDEX NO.
C51	236
C52	220
C53	220
C54	220
C55	220
C56	227
C57	231
C58	228
C59	227
C60	227

CYMBOL NO.	INDEX NO.
C61	231
C62	227
C63	231
C64	228
C65	227
C66	227
C67	237
C68	237
C69	237
C70	235

CYMBOL NO.	INDEX NO.
C71	235
C72	237
C73	226
C74	235
C75	231
C76	223
C77	237
C78	237
C79	237
C80	237

CYMBOL NO.	INDEX NO.
C81	237
C82	229
C83	162
C84	229
C85	230
C86	237
C87	237
C88	225
C89	226
C90	221

CYMBOL NO.	INDEX NO.
C91	162
C92	221
C93	230
C94	235
C95	235
C96	235
C97	235
C98	235
C99	235
C100	235

42.IPU BOARD (A217)

CAPACITOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
C101	235	C111	237	C121	---	C131	235	C141	237	C151	165	C161	237
C102	237	C112	237	C122	165	C132	235	C142	237	C152	237	C162	235
C103	237	C113	237	C123	235	C133	235	C143	235	C153	237	C163	235
C104	237	C114	237	C124	235	C134	237	C144	235	C154	235	C164	237
C105	237	C115	237	C125	237	C135	237	C145	164	C155	237	C165	237
C106	237	C116	237	C126	237	C136	235	C146	237	C156	237	C166	237
C107	237	C117	237	C127	237	C137	235	C147	----	C157	237	C167	237
C108	237	C118	237	C128	234	C138	164	C148	237	C158	235	C168	164
C109	235	C119	237	C129	237	C139	237	C149	235	C159	235	C169	235
C110	235	C120	237	C130	237	C140	235	C150	237	C160	237	C170	237

CAPACITOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
C171	237	C181	165	C191	166	C201	237	C211	236	C221	----	C231	237
C172	237	C182	165	C192	166	C202	237	C212	236	C222	----	C232	163
C173	235	C183	165	C193	166	C203	237	C213	236	C223	----	C233	163
C174	237	C184	165	C194	237	C204	237	C214	236	C224	----	C234	237
C175	235	C185	165	C195	235	C205	237	C215	----	C225	237	C235	235
C176	237	C186	165	C196	237	C206	237	C216	----	C226	237	C236	237
C177	237	C187	235	C197	235	C207	235	C217	----	C227	237	C237	235
C178	237	C188	237	C198	233	C208	235	C218	----	C228	237	C238	237
C179	236	C189	166	C199	233	C209	235	C219	----	C229	235	C239	163
C180	237	C190	166	C200	237	C210	236	C220	----	C230	163	C240	163

CAPACITOR

CYMBOL NO.	INDEX NO.
C241	163
C242	237
C243	235
C244	237
C245	237
C246	237
C247	235
C248	235
C249	----
C250	----

CNNECTOR

CYMBOL NO.	INDEX NO.
CN501	106
CN502	105
CN503	100
CN504	107
CN505	103
CN506	111
CN507	109
CN508	110
CN509	----
CN510	----

CYMBOL NO.	INDEX NO.
CN511	----
CN512	----
CN513	----
CN514	112
CN515	102
CN516	103
CN517	108
CN518	101
CN519	104
CN520	----

CYMBOL NO.	INDEX NO.
CN524	111
CN707	113

D

CYMBOL NO.	INDEX NO.
D 1	123

DA

CYMBOL NO.	INDEX NO.
DA1	122
DA2	122
DA3	122

FIL

CYMBOL NO.	INDEX NO.
FIL 1	----
FIL 2	172
FIL 3	172
FIL 4	169
FIL 5	169
FIL 6	169
FIL 7	169
FIL 8	169
FIL 9	169
FIL10	169

CYMBOL NO.	INDEX NO.
FIL11	169
FIL12	169
FIL13	169
FIL14	170

IC

CYMBOL NO.	INDEX NO.
IC 1	240
IC 2	240
IC 3	240
IC 4	240
IC 5	240
IC 6	240
IC 7	11
IC 8	5
IC 9	144
IC10	136

CYMBOL NO.	INDEX NO.
IC11	142
IC12	142
IC13	142
IC14	142
IC15	142
IC16	142
IC17	142
IC18	142
IC19	142
IC20	142

CYMBOL NO.	INDEX NO.
IC21	142
IC22	142
IC23	142
IC24	142
IC25	143
IC26	143
IC27	143
IC28	143
IC29	145
(Socket)	115
IC30	150

CYMBOL NO.	INDEX NO.
IC31	140
IC32	8
(Socket)	116
IC33	9
IC34	146
IC35	146
IC36	142
IC37	142
IC38	142
IC39	142
IC40	2
(Socket)	114

CYMBOL NO.	INDEX NO.
IC41	----
IC42	----
IC43	3
IC44	130
IC45	134
IC46	135
IC47	----
IC48	----
IC49	----
IC50	1

CYMBOL NO.	INDEX NO.
IC51	1
IC52	137
IC53	131
IC54	6
IC55	142
IC56	142
IC57	133
IC58	149
IC59	138
IC60	138

CYMBOL NO.	INDEX NO.
IC61	141
IC62	128
IC63	4
IC64	139
IC65	139
IC66	130
IC67	127
IC68	130
IC69	130
IC70	148

42.IPU BOARD (A217)

IC

CYMBOL NO.	INDEX NO.
IC71	147
IC72	129

JP

CYMBOL NO.	INDEX NO.
JP 1	219
JP 2	219
JP 3	219
JP 4	219
JP 5	219
JP 6	202
JP 7	219
JP 8	219
JP 9	219
JP10	219

L

CYMBOL NO.	INDEX NO.
JP11	219
JP12	219
JP13	219

L

CYMBOL NO.	INDEX NO.
L 1	167
L 2	167
L 3	167
L 4	167
L 5	----
L 6	----
L 7	167
L 8	----
L 9	----
L10	167

LED

CYMBOL NO.	INDEX NO.
L11	167
L12	171
L13	171
L14	168
L15	168
L16	----
L17	----
L18	168
L19	----
L20	----

LED

CYMBOL NO.	INDEX NO.
LED1	126
LED2	125
LED3	125

Q

CYMBOL NO.	INDEX NO.
Q 1	117
Q 2	117
Q 3	117
Q 4	118
Q 5	119
Q 6	118
Q 7	118
Q 8	118
Q 9	120
Q10	118

Q

CYMBOL NO.	INDEX NO.
Q11	120
Q12	120
Q13	121
Q14	120
Q15	121
Q16	120

QA

CYMBOL NO.	INDEX NO.
QA 1	132

REG

CYMBOL NO.	INDEX NO.
REG 1	151

RESISTOR

CYMBOL NO.	INDEX NO.
R 1	176
----	----
----	----
R24	175
R25	175
R26	174
R27	192
R28	192
R29	192
R30	187

CYMBOL NO.	INDEX NO.
R31	187
R32	194
R33	187
R34	187
R35	187
R36	187
R37	187
R38	187
R39	187
R40	187

CYMBOL NO.	INDEX NO.
R41	187
R42	187
R43	187
R44	177
R45	194
R46	194
R47	176
R48	175
R49	176
R50	194

CYMBOL NO.	INDEX NO.
R51	182
R52	182
R53	194
R54	194
R55	194
R56	182
R57	182
R58	182
R59	182
R60	174

CYMBOL NO.	INDEX NO.
R61	174
R62	176
R63	176
R64	194
R65	176
R66	175
R67	194
R68	182
R69	182
R70	194

42.IPU BOARD (A217)

RESISTOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
R71	177	R81	217	R91	187	R101	199	R111	194	R121	182	R131	178
R72	176	R82	209	R92	187	R102	199	R112	182	R122	194	R132	176
R73	185	R83	175	R93	187	R103	199	R113	174	R123	182	R133	194
R74	182	R84	175	R94	187	R104	199	R114	179	R124	176	R134	176
R75	182	R85	175	R95	187	R105	199	R115	193	R125	175	R135	210
R76	182	R86	198	R96	187	R106	199	R116	183	R126	208	R136	190
R77	194	R87	198	R97	199	R107	199	R117	188	R127	207	R137	175
R78	194	R88	198	R98	199	R108	199	R118	194	R128	215	R138	194
R79	194	R89	175	R99	176	R109	187	R119	182	R129	211	R139	204
R80	174	R90	187	R100	176	R110	173	R120	181	R130	176	R140	179

RESISTOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
R141	203	R151	----	R161	176	R171	176	R181	175	R191	209	R201	187
R142	205	R152	193	R162	187	R172	174	R182	181	R192	209	R202	187
R143	215	R153	216	R163	187	R173	209	R183	175	R193	174	R203	187
R144	211	R154	211	R164	187	R174	209	R184	180	R194	213	R204	187
R145	176	R155	206	R165	187	R175	184	R185	194	R195	189	R205	187
R146	178	R156	218	R166	187	R176	174	R186	214	R196	174	R206	187
R147	176	R157	175	R167	176	R177	213	R187	212	R197	213	R207	176
R148	----	R158	175	R168	187	R178	189	R188	197	R198	175	R208	174
R149	----	R159	197	R169	195	R179	174	R189	184	R199	187	R209	180
R150	175	R160	176	R170	175	R180	213	R190	174	R200	187	R210	180

42.IPU BOARD (A217)

RESISTOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
R211	196	R221	174	R231	187	R241	177	R251	176	R261	177	R271	201
R212	197	R222	186	R232	193	R242	177	R252	176	R262	177	R272	201
R213	174	R223	194	R233	187	R243	193	R253	177	R263	187	R273	201
R214	186	R224	194	R234	193	R244	177	R254	177	R264	187	R274	----
R215	181	R225	187	R235	187	R245	177	R255	177	R265	201	R275	----
R216	197	R226	187	R236	187	R246	177	R256	177	R266	201	R276	----
R217	174	R227	187	R237	193	R247	177	R257	177	R267	201	R277	----
R218	180	R228	187	R238	176	R248	176	R258	177	R268	201	R278	----
R219	----	R229	187	R239	177	R249	176	R259	177	R269	201	R279	----
R220	196	R230	187	R240	193	R250	176	R260	177	R270	201	R280	----

RESISTOR

CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.	CYMBOL NO.	INDEX NO.
R281	----	R291	201	R301	----	R311	175	R321	200	R331	187	R341	----
R282	176	R292	201	R302	----	R312	201	R322	200	R332	187	R342	----
R283	176	R293	201	R303	----	R313	201	R323	200	R333	----	R343	173
R284	177	R294	201	R304	194	R314	187	R324	181	R334	----	R344	200
R285	177	R295	201	R305	175	R315	187	R325	201	R335	----	R345	200
R286	177	R296	----	R306	181	R316	187	R326	173	R336	----	R346	200
R287	193	R297	----	R307	200	R317	187	R327	201	R337	----	R347	191
R288	193	R298	----	R308	200	R318	181	R328	187	R338	----	R348	191
R289	193	R299	----	R309	200	R319	175	R329	181	R339	----	R349	191
R290	201	R300	----	R310	200	R320	200	R330	187	R340	----	R350	191

42.IPU BOARD (A217)

RESISTOR

CYMBOL NO.	INDEX NO.
R351	191
R352	200
R353	187
R354	----
R355	----
R356	----
R357	----
R358	----
R359	----
R360	----

CYMBOL NO.	INDEX NO.
R500	187

XTL

CYMBOL NO.	INDEX NO.
XTL1	152
XTL2	153
XTL3	155
XTL4	154

ZD

CYMBOL NO.	INDEX NO.
ZD 1	124
ZD 2	124

42.IPU BOARD (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A217 5230	EX-IPU Board	1
1	A100 5406	IC - Analog Processing	1
2	A133 7693	IC - UVEPROM 2MX8 150NS	1
3	A133 7900	IC - GASHITE	1
4	A134 5215	IC - RF5GV94	1
5	A217 5250	IC - GAABS-A	1
6	A217 5251	IC - GARD1S	1
8	A217 5259	IC - UVEPROM 4MX16 100NS	1
9	A217 5265	IC - GA3FHFHFAST	1
10	A669 5355	IC - GAFBTC	1

Index No.	Part No.	Description	Q'ty Per Assembly
100	1102 4201	Connector - 2P	
101	1102 4204	CT Header - 5P	
102	1102 4205	CT Header - 6P	
103	1102 4207	Connector - 8P	
104	1102 4212	CT Header - 15P	
105	1102 4468	Ct Header - 10P	
106	1102 4506	Connector - 20P	
107	1102 4619	Connector - 2P	
108	1102 4620	Ct Header - 3P	
109	1102 4630	Ct Header - 15P	
110	1102 5007	CT Header - 14P	
111	1102 5301	Connector - 2P	
112	1102 5331	Connector - 8P	
113	1102 5375	Connector - 50P	
114	1104 0473	32P - IC Socket	
115	1104 0511	IC SOCKET - 8P - DICF-8CS-E	
116	1104 0612	Connector - 40P	
117	1400 0392	Transistor - DTC114EK	
118	1400 0398	Transistor - 2SC2412K	
119	1400 0663	Transistor - 2SA1037AK	
120	1400 0717	Transistor - 2SA1226E4	
121	1400 0738	Transistor - 2SC2223F14	
122	1402 1142	Diode Array - DAN217	
123	1402 1269	Diode - 1SS353	
124	1402 1323	Zener Diode - UDZ5.6B	
125	1403 0828	Diode - SEC1901C	
126	1403 0829	Diode - SEC1201C	
127	1407 1600	TTLIC - SN74LS244NS	
128	1407 1746	TTL SN74LS240NS	
129	1407 2147	TTLIC - 74F374SJ	
130	1407 2187	TTLIC - SN74LS07NS	
131	1407 2218	TTLIC - SN74LS06NS	
132	1407 2231	IC - TD62308AF	
133	1407 2463	TTL IC SN74ALS08NS	
134	1407 2781	TTL - SN74AS04NS	

42.IPU BOARD (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
135	1407 3381	Cmos - IC - TC74HC4066AF	
136	1407 3481	IC - SN74AS32NS	
137	1407 4023	IC - M62353GP	
138	1407 4109	IC - CXD1175AM	
139	1407 4323	TTL TD74ABT244AF	
140	1407 4330	CPU UPD70433GD-5BB	
141	1407 4536	PLL ICS1574	
142	1407 4671	FIFO M66256FP	
143	1407 4688	IC - UPD485506G5-25-7JF	
144	1407 4689	LSI - SCSI CONT. - SYM53CF92-64PQFP	
145	1407 4691	IC - NM93C66N	
146	1407 4734	IC - M66257FP	
147	1407 4793	CMOS 74LCX240SJ	
148	1407 4794	CMOS 74LCX244SJ	
149	1408 0595	IC - NJM2904M	
150	1408 0611	IC - 3771	
151	1408 1233	IC - LT1117CST-3.3	
152	1503 0533	Oscillator - CK4400AC 40.0MHZ	
153	1503 0708	Oscillator - AT-51 25MHZ	
154	1503 0755	Oscillator - 1332-M1 28.0MHZ	
155	1503 0756	Oscillator - SMD-49 42.8MHZ	
156	1601 1413	Resistor - RCB8C330J	
157	1601 7664	Resistor - 220 ohm /330 Ω	
158	1601 7752	Resistor ARRAY - 10K Ω $\pm 5\%$	
159	1601 7793	Resistor - 10K Ω	
160	1601 7813	Resistor - 15 Ω $\pm 5\%$ 1/16W	
161	1604 1731	Capacitor - 56 μ F $\pm 20\%$ 25V	
162	1604 2601	Condensor - 47mF $\pm 20\%$ 25V	
163	1605 0511	Capacitor - 30pF $\pm 5\%$ 50V	
164	1605 0685	Capacitor - 0.47mF	
165	1605 0846	Capacitor - C8pF ± 0.5 P	
166	1605 0877	Capacitor - 6PF ± 0.5 pF 50V	
167	1607 0280	Inductor - BLM41	
168	1607 0494	IC - LALO4NA220K	
169	1607 0705	Noize Filter - ACF51832-470	












Index No.	Part No.	Description	Q'ty Per Assembly
170	1607 0706	Noize Filter - ACF51832-220	
171	1607 0723	Noize Filter - N2012Z121	
172	1607 0925	Noize Filter - HF70ACC321611	
173	1630 3100	Resistor - 10 Ω $\pm 5\%$ 1/10W	
174	1630 3101	Resistor - 100 Ω - 1/10W	
175	1630 3102	Resistor - 1K Ω 1/10W $\pm 5\%$	
176	1630 3103	Resistor - 10K Ω 1/10W $\pm 5\%$	
177	1630 3150	Resistor - 15 Ω $\pm 5\%$ 1/10W	
178	1630 3162	Resistor - 1.6K Ω 1/10W $\pm 5\%$	
179	1630 3181	Resistor - 180 Ω $\pm 5\%$ 1/10W	
180	1630 3202	Resistor - 2K Ω -1/10W	
181	1630 3222	Resistor - 2.2K Ω 1/10W $\pm 5\%$	
182	1630 3223	Resistor - 22k Ω - 1/10W	
183	1630 3241	Resistor - 240 Ω 1/10W $\pm 5\%$	
184	1630 3242	Resistor - 2.4K Ω $\pm 5\%$ 1/10W	
185	1630 3273	Resistor - 27k Ω - 1/10W	
186	1630 3302	Resistor - 3K Ω - 1/10W	
187	1630 3330	Resistor - 33 Ω $\pm 5\%$ 1/10W	
188	1630 3331	Resistor - 330 Ω $\pm 5\%$ 1/10W	
189	1630 3332	Resistor - 3.3K Ω 1/10W $\pm 5\%$	
190	1630 3364	Resistor - 360K Ω $\pm 5\%$ 1/10W	
191	1630 3390	Resistor - 39 Ω $\pm 5\%$ 1/10W	
192	1630 3470	Resistor - 47 Ω 1/10W $\pm 5\%$	
193	1630 3471	Resistor - 470 Ω - 1/10W	
194	1630 3472	Resistor - 4.7K Ω 1/10W $\pm 5\%$	
195	1630 3511	Resistor - 510 Ω $\pm 5\%$ 1/10W	
196	1630 3512	Resistor - 5.10K Ω - 1/10W	
197	1630 3562	Resistor - 5.6K Ω $\pm 5\%$ 1/10W	
198	1630 3681	Resistor - 680 Ω $\pm 5\%$ 1/10W	
199	1630 4330	Resistor - 33 Ω $\pm 5\%$ 1/8W	
200	1630 4472	Resistor - 4.7K Ω $\pm 5\%$ 1/16W	
201	1630 4473	Resistor - 47K Ω - $\pm 5\%$ - 1/16W	
202	1633 0000	Resistor - 0 Ω 1/10W:JAMPER CHIP	

42.IPU BOARD (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
203	1633 1202	Resistor - 12K Ω $\pm 1\%$ 1/10W	
204	1633 1601	Resistor - 1.6K Ω $\pm 1\%$ 1/8W	
205	1633 1602	Resistor - 16K Ω $\pm 1\%$ 1/4W	
206	1633 1802	Resistor - 18K Ω $\pm 1\%$ 1/4W	
207	1633 1871	Resistor - 1.87K Ω $\pm 1\%$ 1/10W	
208	1633 2371	Resistor - 2.37K Ω $\pm 1\%$ 1/10W	
209	1633 2701	Resistor - 2.7K Ω $\pm 1\%$ 1/10W	
210	1633 2702	Resistor - 27K Ω $\pm 1\%$ 1/10W	
211	1633 3602	Resistor - 36K Ω $\pm 1\%$ 1/10W	
212	1633 4700	Resistor - 470 Ω - $\pm 1\%$ - 1/10W	
213	1633 6340	Resistor - 634 Ω $\pm 1\%$ 1/10W	
214	1633 6800	Resistor - 680 Ω $\pm 1\%$ 1/10W	
215	1633 7501	Resistor - 7.5K Ω $\pm 5\%$ 1/10W	
216	1633 7502	Resistor - 57K 0HM $\pm 1\%$ 1/10W	
217	1633 8201	Resistob - 8.2k Ω $\pm 1\%$ 1/10w	
218	1633 9101	Resistor - 9.1K Ω 1/10W	
219	1634 0000	Resistor - 0 Ω - 1/16W	
220	1640 2470	Capacitor - 47 μ F $\pm 20\%$ 25V	
221	1640 5109	Capacitor - 1 μ F- $\pm 20\%$ - 50V	
222	1640 5470	Capacitor - 47 μ F $\pm 20\%$ 50V	
223	1640 5479	Capacitor - 4.7 μ F $\pm 20\%$ 50V	
224	1642 0470	Capacitor - 47 μ F $\pm 20\%$ 10V	
225	1643 0220	Capacitor - 22uF $\pm 20\%$ 10V	
226	1643 1470	Capacitor - 47 μ F $\pm 20\%$ 16V	
227	1644 0100	Capacitor - 10uF $\pm 20\%$ 10V	
228	1644 0330	Capacitor - 33uF $\pm 20\%$ 10V	
229	1644 0470	Capacitor - 47uF $\pm 20\%$ 10V	
230	1644 2330	Capacitor - 33uF $\pm 20\%$ 25V	
231	1644 2479	Capacitor - 4.7 μ F $\pm 20\%$ 25V	
232	1644 5339	Capacitor - 3.3uF $\pm 20\%$ 50V	
233	1660 3150	Capacitor - 15pF 50V	
234	1660 3471	Capacitor - 470pF 50V	
235	1660 7103	Capacitor - 10000pF 50V	

Index No.	Part No.	Description	Q'ty Per Assembly
236	1660 7104	Capacitor - 100000pF 50V	
237	1660 9104	C - 0.1uF 25V	
238	1902 0012	IC - SRAM - 64K X8 100NS G1	
239	1902 0021	IC - SRAM - 1M - X8 - 100NS/G4	
240	1903 0007	DRAM 16M 2MX8 60NS G1	

43.DECAL AND DOCUMENT (A217)









1 	6  7 					
2 	8 					
3 	4 	5 	9 Operation 	10 	11 	12 

43.DECAL AND DOCUMENT (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA00 0181	Caution Decal - Toner Collect. Tank	1
2	A133 7292	Decal - Paper Size	1
2	A133 7293	Decal - Paper Size	1
3	A134 2997	Decal - Paper Setting	1
4	A134 4884	Decal - Duplex Misfeed Removal	1
5	A155 6113	Decal - Paper Set	1
6	AA00 2206	Decal - Paper Size	1
7	A155 6114	Caution Decal - LCT	1
8	AA00 2209	Decal - Paper Size	1
9	A217 8690	Operating Instructions - English A4 (NRG)	1
9	A217 8650	Operating Instructions - English LT (SVN)	1
9	A217 8607	Operating Instructions - English LT	1
9	A217 8697	Operating Instructions - English LT (NRG)	1
9	A217 8608	Operating Instructions - English AA	1
10	A153 6406	Model Name Plate - GER	1
11	AA00 1383	Decal - Energy Star	1
12	A153 6409	Decal - Keytop Cover	1
12	C225 2866	Decal - Key Top Cover	1
12	C225 2867	Decal - Cover - Panel - Nashua	1
13	A217 7860	Decal - Brand Name - GES	1
13	A217 7862	Decal - Brand Name - Nasua	1
13	A217 7864	Decal - Brand Name - Rex	1

Index No.	Part No.	Description	Q'ty Per Assembly

44.SPECIAL TOOLS (A217)

1	2	3	4	5
				
6	7	8	9	
				

44.SPECIAL TOOLS (A217)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A006 9104	Scanner Positioning Pin (4 pcs/set)	1
2	5420 9516	Test Chart - OS-A3 (10 pcs/set)	1
3	5447 9078	Heat Resistant Grease - MT-78	1
4	5203 9501	Silicone Grease G-501	1
5	5420 9507	Digital Multimeter	1
6	A130 9011	Charge Corona Unit With Cleaner	1
7	A130 9005	Exposure Glasse With Electoric Conductor Coat	1
8	A130 9006	Grounding Plate - Exposure Glass	1
9	AC06 0002	White Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No
EXTERIOR (A217)	AA01 2079	Dust Filter	Dust Filter	1	11- 4
PAPER TRAY (A217)	AF01 3014	Bottom Plate Pad	Bottom Plate Pad	1	17- 9
TRAY PAPER FEED (A217)	AF03 0025	Pick-up,Feed Separation Rollers	Pick-up Feed Roller	1	19- 3
	AF03 2027	Separation Roller	Separation Roller	1	19- 25
	AF03 1026	Paper Feed Roller	Paper Feed Roller	1	19- 39
BY-PASS FEED UNIT 2 (A217)	AF03 2031	Separation Roller	Separation Roller	1	23- 16
BY-PASS FEED UNIT 3 (A217)	AF03 0031	Pick-up,Feed Separation Rollers	Pick-up Roller	1	25- 16
	AF03 1031	Feed Roller	Feed Roller	1	25- 17
CHARGE CORONA SECTION (A217)	AD02 0053	Corona Wires	Charge Corona Wire	1	43- 8
	A096 2057	Charge Grid	Charge Corona Grid	1	43- 9
DEVELOPMENT UNIT 1 (A217)	A134 3090	Development Filter	Development Filter	1	47- 5
DEVELOPMENT UNIT 2 (A217)	AB01 1150	Development Drive Gears	Gear - 20Z	1	49- 2
	AB01 1162	Development Drive Gears	Gear - 16Z	1	49- 4
	AB01 1161	Development Drive Gears	Gear - 20Z	1	49- 6
	AB01 1163	Development Drive Gears	Gear - 33Z	1	49- 14
CLEANING UNIT (A217)	AD02 5020	Pick-off Pawls	Pick-off Pawl	2	53- 10
	AD04 2029	Brush Roller	Cleaning Roller	1	53- 17
TRANSFER BELT UNIT (A217)	A134 3850	Transfer Belt	Transfer Belt	1	55- 1
	AE01 1036	Hot Roller	Hot Roller	1	57- 15
FUSING UNIT 1 (A217)	AE04 4013	Hot Roller Stripper	Hot Roller Stripper	7	57- 18
FUSING UNIT 2 (A217)	AE02 0072	Pressure Roller	Pressure Roller	1	59- 10
DUPLEX UNIT 2 (A217)	AF03 1024	Feed Roller	Feed Roller	1	65- 20
	AF03 2026	Separation Roller	Separation Roller	1	65- 31
DUPLEX UNIT 3 (A217)	AF01 3003	Bottom Plate Pad	Bottom Plate Pad - Duplex	1	67- 2

Part No.	Description	Page and Index No.
A217 1784	2nd Mirror Ass'y	35- 7
A217 1815	Lens Block Ass'y	37- 13
A217 2085	LD Unit	41- 3
A217 3050	Development Unit	47- 16
A217 3800	Transfer Unit	55- 38
A217 3874	Driven Roller Transfer	55- 13
A217 4051	Fusing Cover	57- 7
A217 4084	Fusing Connector Bracket	57- 8
A217 4121	Heater Holder	57- 11
A217 4123	Discharge Brush	57- 21
A217 4197	Lower Fusing Guide	59- 26
A217 5108	IC - UVNPROM 4MX16 150NS	95- 2
A217 5149	Touch Panel	15- 15
A217 5230	EX-IPU Board	103- *
A217 5230	EX-IPU Board	37- 1
A217 5250	IC - GAABS-A	103- 5
A217 5251	IC - GARD1S	103- 6
A217 5259	IC - UVEPROM 4MX16 100NS	103- 8
A217 5265	IC - GA3FHFAST	103- 9
A217 5301	Harness - DC Main	75- 11
A217 5301	Harness - DC Main	77- 18
A217 5302	Harness - DC Main - Rear	75- 12
A217 5392	Harness - Polygon Mirr	41- 6
A217 5392	Harness - Polygon Mirr	37- 3
A217 5405	AC Main Harness - 115V	77- 11
A217 5405	AC Main Harness - 115V	75- 10
A217 5406	Harness - AC Main (230V)	77- 11
A217 5406	AC Main Harness - 230V	75- 10
A217 5407	Fusing Harness - 115V	57- 9
A217 5408	Fusing Harness - 230V	57- 9
A217 5500	AC Drive Board (115V)	75- 9
A217 7002	Operation Panel Ass'y (RIC/NRG LT)	11- 26
A217 7021	Front Cover (RIC-US)	11- 20
A217 7023	Front Cover (RIC-EU/ASIA)	11- 33

Part No.	Description	Page and Index No
A217 7051	1st Scanner Ass'y	35- 11
A217 7301	Operation Panel Ass'y (A4)	11- 26
A217 7701	Front Cover (SVN)	11- 20
A217 7704	Operation Panel Board	15- 18
A217 7711	Operation Panel Ass'y (SVN)	11- 26
A217 7715	SCU Board (115V)	91- *
A217 7715	SCU Board (115V)	75- 4
A217 7717	IC - UVNPROM 4MX16 150NS (115V)	91- 2
A217 7717	IC - UVEPROM 4M X16 150NS (LT)	75- 19
A217 7720	IC - UVNPROM 4MX16 150NS (115V)	91- 3
A217 7720	IC - UVEPROM 4M X16 150NS (LT)	75- 20
A217 7723	IC - UVNPROM 4MX16 150NS (115V)	91- 4
A217 7723	IC - UVNPROM 4MX16 150NS	75- 21
A217 7726	BCU Board	95- *
A217 7726	BCU Board	75- 13
A217 7727	IC - HD6433278A44P10	95- 3
A217 7731	IC - UVEPROM 4MX16 150 ns	15- 17
A217 7860	Decal - Brand Name - GES	107- 13
A217 7862	Decal - Brand Name - Nasua	107- 13
A217 7864	Decal - Brand Name - Rex	107- 13
A217 7901	Front Cover (INF)	11- 33
A217 7905	Support Cover (INF)	11- 34
A217 8607	Operating Instructions - English LT	107- 9
A217 8608	Operating Instructions - English AA	107- 9
A217 8650	Operating Instructions - English LT (SVN)	107- 9
A217 8690	Operating Instructions - English A4 (NRG)	107- 9
A217 8697	Operating Instructions - English LT (NRG)	107- 9

Part No.	Description	Page and Index No.
AA00 0180	Decal - Toner Collection (LT)	43- 22
AA00 0181	Caution Decal - Toner Collect. Tank (A4)	43- 22
AA00 0181	Caution Decal - Toner Collect. Tank	107- 1
AA00 1369	Decal - Adding Toner	45- 24
AA00 1383	Decal - Energy Star	107- 11
AA00 1383	Decal - Energy Star	11- 30
AA00 2206	Decal - Paper Size	107- 6
AA00 2209	Decal - Paper Size	107- 8
AA01 0098	Ozone Filter - 64x45x30	77- 5
AA01 2077	Dust Filter - Exhaust Fan	77- 20
AA01 2078	Dust Filter - Vacuum Fan	85- 6
AA01 2079	Dust Filter	11- 4
AA04 3364	Timing Belt - S3M300	73- 8
AA04 3366	Timing Belt - S2M380	71- 6
AA04 3367	Timing Belt - S3M432	69- 5
AA04 3368	Timing Belt - S3M609	69- 4
AA04 3368	Timing Belt - S3M609	73- 26
AA04 3369	Timing Belt - S3M267	69- 16
AA04 3372	Timing Belt - S2M400	39- 16
AA04 3373	Timing Belt - S2M308	65- 4
AA04 3374	Timing Belt - S2M800	67- 17
AA04 3411	Timing Belt - S2M 300	69- 9
AA04 3456	Timing Belt - S3M167	29- 12
AA05 0085	Scanner Wire	39- 22
AA05 1022	Drive Wire	79- 4
AA05 1022	Drive Wire	69- 18
AA06 0103	Solenoid Spring	57- 19
AA06 0221	Gripper Solenoid Spring	39- 9
AA06 0523	Pick-up Pressure Sping	19- 18
AA06 0534	Tray Lock Spring - 19mm	83- 4
AA06 0575	Release Spring	19- 30
AA06 0577	Release Spring	19- 10
AA06 0593	Spring	65- 38
AA06 0604	Spring - 230gf	69- 19

Part No.	Description	Page and Index No
AA06 0636	Pressure Spring	19- 28
AA06 0638	Pressure Spring	25- 13
AA06 0639	Pressure Spring	25- 14
AA06 0663	Spring - Tightener	73- 11
AA06 0664	Spring - Tightener	73- 22
AA06 0666	Tension Spring : 12N	87- 4
AA06 2284	Pressure Spring	43- 10
AA06 2296	Tension Spring - 88N	59- 9
AA06 3239	Spring - Handle	27- 20
AA06 3242	Registration Pressure Spring - Rear	33- 3
AA06 3246	Pressure Spring	23- 13
AA06 3248	Charge Terminal Spring	43- 4
AA06 3249	Grid Terminal Spring	43- 5
AA06 3269	Pressure Spring	51- 6
AA06 3270	Pressure Spring	43- 17
AA06 3366	Chuck Spring	45- 8
AA06 3367	Pressure Spring	45- 11
AA06 3370	Spring	67- 16
AA06 3373	Spring - 60mm	53- 8
AA06 3380	Spring - 16mm	71- 14
AA06 3382	Pressure Spring	47- 14
AA06 3385	Pressure Spring	65- 27
AA06 3487	Spring - 10mm	19- 34
AA06 3487	Spring - 10mm	23- 19
AA06 3487	Spring - 10mm	31- 23
AA06 3532	Spring	77- 27
AA06 6094	End Fence Spring	67- 27
AA06 6240	Pressure Spring	55- 16
AA06 6250	Pressure Spring	53- 12
AA06 6251	Pressure Spring	53- 14
AA06 6284	Torsion Spring	45- 25
AA07 0034	Slide Rail	87- 5
AA08 0034	Bushing - 4x5x7	31- 21
AA08 0034	Bushing - 4x5x7	23- 4

Part No.	Description	Page and Index No.
AA08 0128	Bushing - 6x9x8	65- 28
AA08 0147	Front Bushing	43- 34
AA08 0148	Rear Bushing	43- 29
AA08 0155	Rear Pawl Bushing	53- 15
AA08 0156	Bushing - M4	19- 33
AA08 0171	Bushing	33- 2
AA08 0172	Bushing	33- 26
AA08 0176	Bushing	49- 10
AA08 0178	Bushing - M5	49- 12
AA08 2045	Cleaning Brush Bushing	53- 6
AA08 2046	Bushing - 6x12x6	19- 13
AA08 2046	Bushing - 6x12x6	23- 21
AA08 2047	Bushing - 8x16x7	23- 20
AA08 2047	Bushing - 8x16x7	25- 18
AA08 2047	Bushing - 8x16x7	33- 16
AA08 2047	Bushing - 8x16x7	19- 20
AA08 2051	Bushing - M8	55- 6
AA08 2054	Bushing - M4	55- 5
AA08 2058	Bushing - 6x10x9mm	61- 4
AA08 2064	Bushing - 10mm	83- 6
AA08 3009	Clutch Roller - 8x18x11	19- 12
AA08 3009	Clutch Roller - 8x18x11	33- 18
AA08 4047	Bushing Case	49- 11
AA11 1208	Paper End Sensor Feeler	65- 9
AA12 0067	Antistatic Brush	63- 16
AA13 2013	Spacer - 8.2	69- 12
AA13 2025	Spacer - 1x8x12	55- 32
AA13 2094	Spacer - Mounting Arm	49- 13
AA13 2133	Spacer - M8	73- 30
AA13 2174	Spacer - M8	35- 2
AA13 2184	Motor Cushion	65- 48
AA13 4092	Flange - Fly Wheel	71- 4
AA14 0291	Bottom Plate Shaft	67- 6
AA14 0542	Feed Roller Shaft	19- 6

Part No.	Description	Page and Index No.
AA14 0547	Drive Shaft	39- 21
AA14 0576	LCT Drive Shaft	29- 15
AA14 0597	Shaft - Paper Feed	25- 20
AA14 3219	Stepped Screw	11- 8
AA14 3301	Stepped Screw - M3x4	77- 15
AA14 3307	Stepped Screw - M3x4	65- 23
AA14 3410	Stepped Screw - M4	45- 10
AA14 3424	Knob Screw - M4x8	43- 11
AA14 3452	Stepped Screw	77- 28
AA14 3454	Stepped Screw - M3	11- 10
AA14 3461	Stepped Screw - M2.5	27- 33
AA14 3499	Stepped Screw - HDD	81- 18
AA14 3712	Chuck Shaft	45- 5
AA14 3713	Shaft - Release Stay	55- 30
AA14 3715	Stepped Screw - M5	57- 2
AA14 3718	Stepped Screw - M4	11- 31
AA14 3724	Stepped Screw	83- 27
AA14 3737	Srepped Screw	87- 6
AA14 8252	End Fence Shaft	67- 28
AA14 8413	Idle Gear Shaft	45- 22
AA14 8418	Relay Shaft	71- 13
AA14 8447	Guide Pin - Platen Cover	11- 6
AA14 8447	Guide Pin - Platen Cover	13- 11
AA15 0234	Mylar Seal - Base	45- 27
AA15 0234	Mylar Seal - Base	37- 6
AA15 0636	Seal - 90x29.5x0.2	35- 17
AA15 1882	Seal - 32x4x1	47- 19
AA15 1889	Entrance Seal - Toner Supply Unit	47- 3
AA15 1891	Shutter Seal	45- 15
AA15 1894	Seal - 67x53x2	45- 2
AA15 1900	Seal - Toner Shield Glass	41- 12
AA15 1922	Seal - 12x75x4	55- 17
AA15 1998	Cushion - 10x30x5	21- 17
AA15 2302	Seal	41- 17

Part No.	Description	Page and Index No.
AA15 2358	Sponge - 57x24x20	11- 16
AA16 1067	Cushion - Motor	65- 45
AA16 1105	Cleaner Cushion	43- 26
AA16 1119	Cushion - Wire	43- 37
AA16 2053	Platen Cover Pad	13- 2
AA16 2068	Guide Plate Pad	63- 20
AA16 2069	Guide Plate Pad	63- 19
AB01 0087	Gear - 20Z	43- 28
AB01 1133	Gear - 49Z	29- 14
AB01 1150	Gear - 20Z	49- 2
AB01 1153	Idle Gear - 25Z	73- 13
AB01 1161	Gear - 20Z	49- 6
AB01 1162	Gear - 16Z	49- 4
AB01 1163	Gear - 33Z	49- 14
AB01 1165	Gear - 32Z	65- 34
AB01 1166	Gear - 33Z	65- 13
AB01 1167	Gear - 25Z	65- 32
AB01 1169	Gear - 28Z	73- 14
AB01 1170	Gear - 36Z	73- 3
AB01 3420	Gear - 18Z	19- 22
AB01 3420	Gear - 18Z	23- 9
AB01 3485	Gear - 20Z	33- 5
AB01 3486	Gear - 14Z	33- 1
AB01 3569	Gear - 20Z	55- 21
AB01 3868	Gear - 16Z	17- 14
AB01 3872	Fusing Cam Gear - 28Z	69- 24
AB01 3873	Gear - 26Z	53- 4
AB01 3875	Reverse Gear - 27Z	73- 28
AB01 3877	Gear - 28Z	49- 5
AB01 3878	Gear - 29Z	49- 1
AB01 3879	Gear - 20Z	49- 9
AB01 3880	Gear - 20Z	49- 8
AB01 3881	Gear - 31Z	67- 12
AB01 3883	Idle Gear - 25Z	57- 10

Part No.	Description	Page and Index No
AB01 3884	Exit Gear - 17Z	59- 3
AB01 3885	Idle Gear - 20Z	59- 2
AB01 3886	Gear - 18Z	47- 2
AB01 3887	Gear - 16Z	47- 12
AB01 3889	Gear - 24Z	61- 18
AB01 3891	Gear - 30Z	55- 10
AB01 3892	Gear - 18Z	55- 8
AB01 3893	Gear - 29Z	71- 7
AB01 3985	Gear - 40Z	57- 12
AB01 4006	Gear - 40Z	71- 16
AB01 5013	Rack	87- 7
AB01 7323	Cam Gear - 35z	53- 19
AB01 7332	Gear - 24Z/41Z	65- 33
AB01 7333	Timing Pulley - 35/25Z	73- 7
AB01 7335	Timing Pulley - 22Z/37Z	73- 5
AB01 7336	Timing Pulley - 30Z/35Z	73- 23
AB01 7337	Gear - 15Z/55Z	65- 39
AB01 7339	End Fence Gear - 22Z/58Z	67- 14
AB01 7342	Timing Pulley - 36/25Z	69- 7
AB01 7344	Timing Rulley - 25/20Z	69- 21
AB01 7345	Timing Pulley - 35Z	69- 15
AB01 7346	Exit Gear	69- 25
AB01 7347	Idle Gear	45- 21
AB01 7400	Gear- 18Z/68Z	67- 13
AB01 7430	Timing Pulley - 30/35/25Z	71- 17
AB01 7432	Gear - 25Z	73- 4
AB03 0169	Timing Pulley - 120Z	71- 5
AB03 0281	Timing Pulley - 28Z	29- 9
AB03 0455	Tightener Pulley - 8x20x13	73- 12
AB03 0459	Timing Pulley -22Z	39- 12
AB03 0460	Timing Pulley - 44Z	39- 17
AB03 0463	Fusing Cam Pulley	69- 23
AB03 0464	Timing Pulley - 30Z	73- 25
AB03 0465	Timing Pulley - 25Z	73- 9

Part No.	Description	Page and Index No.
AB03 0466	Timing Pulley - 20Z	33- 19
AB03 0466	Timing Pulley - 20Z	19- 14
AB03 0473	End Fence Pulley - 22Z	67- 11
AB03 0474	Pulley - 24Z	65- 5
AB03 0475	Pulley - 18Z S2M	61- 13
AB03 2717	Pulley - 26Z	35- 1
AB03 2717	Pulley - 26Z	39- 7
AB03 2718	Drive Pulley	39- 20
AB04 0015	Spring Clutch - Tray Bottom Plate	65- 35
AC01 5020	Toner Shield Glass	41- 5
AC02 0090	Cylindrical Lens	41- 14
AC03 0073	1st Mirror	35- 9
AC03 0080	1st Mirror	41- 10
AC06 0002	White Plate	109- 9
AD00 4075	Charge Corona Unit	43- 20
AD02 0053	Charge Corona Wire	43- 8
AD02 1121	Receptacle - Charger	85- 13
AD02 2283	Front End Block	43- 1
AD02 2285	Rear End Block	43- 3
AD02 2306	Cover - Front End Block	43- 12
AD02 2307	Cover - Rear End Block	43- 6
AD02 3106	Charge Corona Casing	43- 2
AD02 5020	Pick-off Pawl	53- 10
AD03 7043	Development Auger	49- 3
AD04 2029	Cleaning Roller	53- 17
AD04 3033	Toner Collection Coil	53- 16
AD04 7017	Entrance Seal - Cleaning	53- 22
AE01 1036	Hot Roller	57- 15
AE02 0072	Pressure Roller	59- 10
AE03 0003	Bushing - 30x42x27	57- 14
AE03 0027	Bearing - 12x24x64mm	59- 11
AE03 1028	Bushing - 8x10x5	59- 22
AE03 2018	Bushing - 25x30x9	57- 13
AE04 2030	Cleaning Roller	59- 23

Part No.	Description	Page and Index No
AE04 4013	Hot Roller Stripper	57- 18
AF01 0018	Duplex Tray	67- 31
AF01 0018	Duplex Tray	63- 18
AF01 3003	Bottom Plate Pad - Duplex	67- 2
AF01 3014	Bottom Plate Pad	17- 9
AF01 5027	Paper Size Slider	17- 13
AF01 6084	Front Side Fence	17- 3
AF01 6085	Rear Side Fence	17- 11
AF01 6160	Rear Side Fence	67- 3
AF01 6161	Front Side Fence	67- 4
AF01 7012	End Fence	17- 7
AF01 7014	End Fence	67- 29
AF02 0316	Lower Registration Roller	33- 10
AF02 0317	Stack Roller	65- 17
AF02 0319	Transport Roller	65- 1
AF02 0320	Right Transport Roller	65- 2
AF02 0321	Paper Feed Drive Roller	33- 20
AF02 0322	Lower Drive Roller - Transport	19- 29
AF02 0326	Exit Roller Ass'y	59- 4
AF02 0327	Exit Roller	61- 8
AF02 0328	Relay Drive Roller	61- 12
AF02 0329	Relay Roller	19- 32
AF02 0330	Vertical Driven Roller	31- 22
AF02 0364	Driven Roller	23- 6
AF02 0365	Transport Roller	23- 1
AF02 1052	Upper Registration Roller	33- 9
AF02 2077	Driven Roller	65- 19
AF02 2077	Driven Roller	63- 7
AF02 5023	Exit Pick-off Pawl	61- 9
AF03 0025	Pick-up Feed Roller	19- 3
AF03 0031	Pick-up Roller	25- 16
AF03 1024	Feed Roller	65- 20
AF03 1026	Paper Feed Roller	19- 39
AF03 1031	Feed Roller	25- 17

Part No.	Description	Page and Index No.
AF03 2026	Separation Roller	65- 31
AF03 2027	Separation Roller	19- 25
AF03 2031	Separation Roller	23- 16
AF04 0031	Upper Exit Roller	63- 11
AF04 0031	Upper Exit Roller	61- 2
AF04 0548	Exit Driven Roller	59- 5
AF04 3069	Copy Tray	87- 1
AF04 3076	Copy Tray Slide	87- 2
AF04 3077	Copy Tray Guide	87- 3
AG05 0074	Registration Knob	33- 6
AG05 0075	Middle Knob	33- 7
AG05 0076	Fusing Knob	59- 12
AG05 1113	Handle - Transfer Unit	83- 26
AG07 0004	Magnetic Catch	31- 3
AG07 0004	Magnetic Catch	61- 16
AG07 0004	Magnetic Catch	29- 16
AG07 0004	Magnetic Catch	79- 9
AG07 0004	Magnetic Catch	45- 18
AG07 0004	Magnetic Catch	11- 23
AG07 0009	Magnetic Catch	59- 6
AH01 0007	Rubber Foot	83- 20
AW01 0040	Original Sensor	37- 15
AW01 0065	Auto Response Sensor	11- 25
AW01 0072	Original Sensor	37- 11
AW02 0022	Photointerruptor	77- 13
AW02 0068	Photointerruptor	33- 12
AW02 0069	Photointerruptor	31- 20
AW02 0071	Photointerruptor - Actuator	61- 6
AW02 0072	Photointerruptor	37- 16
AW02 0075	Photointerruptor	65- 7
AW02 0075	Photointerruptor	29- 7
AW02 0075	Photointerruptor	67- 18
AW02 0075	Photointerruptor	71- 9
AW02 0075	Photointerruptor	25- 24

Part No.	Description	Page and Index No
AW02 0075	Photointerruptor	19- 8
AW02 0085	Photointerruptor	25- 25
AW03 0051	Optics Fiber - 520mm	77- 9
AW03 0051	Optics Fiber - 520mm	75- 18
AW03 0052	Optics Fiber - 1300mm	75- 2
AW03 0053	Optics Fiber - 860mm	77- 16
AW11 0017	Thermostat - 140C - AC120V 15A	35- 14
AW23 0008	ID Sensor	47- 10
AW31 0004	Toner Detect Sensor	47- 4
AW50 0010	Push Switch	77- 2
AW50 0012	Push Switch	31- 16
AX04 0061	Cleaner Motor - DC 0.5W	43- 27
AX05 0090	Motor - DC 24V 36W	29- 8
AX06 0107	Motor - DC 24W	39- 14
AX06 0133	Polygon Mirror Motor	41- 1
AX06 0135	DC Motor - 22W	71- 1
AX07 0015	Motor - DC 63w	69- 2
AX20 0098	Magnetic Clutch - 7kg Cm 35z	73- 24
AX20 0099	Magnetic Clutch - 7kgf.cm 26z	73- 16
AX20 0100	Magnetic Clutch - 3.5kgf Cm 35z	73- 27
AX20 0125	Magnetic Clutch - 0.35n.m - Z35	73- 1
AX20 0126	Magnetic Clutch - 0.25n.m - Z42	73- 29
AX20 0135	Magnetic Clutch	71- 19
AX21 0046	Electrical Spring Clutch	71- 8
AX31 0022	Total Counter	79- 5
AX40 0057	Heater - 115V 9W	37- 14
AX40 0058	Heater - 230V 9W	37- 14
AX40 0066	Heater - 120V 9W	83- 8
AX40 0067	Heater - 230V 9W	83- 8
AX44 0105	Fusing Lamp - 120V 790W (115V)	57- 16
AX44 0106	Fusing Lamp - 230V 790W (230V)	57- 16
AX50 0051	Quenching Lamp	85- 4
AX52 0033	Scanner Lamp - 75V 200W	35- 10
AX64 0053	Fan Motor - DC 1.44W	85- 3

Part No.	Description	Page and Index No.
AX64 0054	Fan Motor - DC 2.4W	77- 22
AX64 0060	Fan Motor - DC 0.96W	37- 9
AX65 0015	Fan Motor - DC 5.8W	39- 1
AZ00 0013	Power Supply Cord - (115V)	77- 19
AZ02 0009	Choke Coil - 10mH 2A	75- 24
AZ23 0073	Lamp Stabilizer (230V)	75- 17
AZ23 0075	Lamp Stabilizer (115V)	75- 17
AZ24 0028	DC Supply Board (115V)	75- 15
AZ24 0031	DC Supply Board (230V)	75- 15
AZ30 0039	Power Pack - Development	47- 7
AZ30 0040	Power Pack - Transfer Unit	55- 18
AZ32 0073	Power Pack - Charge	75- 6
C225 2866	Decal - Key Top Cover	107- 12
C225 2867	Decal - Cover - Panel - Nashua	107- 12
C225 2867	Decal - Cover - Panel - Nashua	11- 2
G011 3305	Gear - 16T	67- 8
G011 3305	Gear - 16T	21- 13

Part No.	Description	Page and Index No.
A006 9104	Scanner Positioning Pin (4 pcs/set)	109- 1
A048 2838	Nylon Rivet	17- 10
A053 1957	Flex Hinge - Platen Cover	13- 4
A060 3826	Toner Collection Bottle Roller	83- 22
A060 3827	Roller Holder	83- 28
A069 1883	Shoe - Scanner	35- 4
A069 5352	Ground Wire - Scanner	39- 13
A077 4162	Shoulder Screw - M3	59- 19
A079 3054	Seal - 3x5x8mm	55- 33
A079 3626	Stepped Screw - Swing Cleaning	65- 47
A096 1873	Scanner Shoe Pin	35- 13
A096 2051	Rear Grid Anchor	43- 7
A096 2052	Front Grid Anchor	43- 14
A096 2053	Cleaner Motor Cover	43- 25
A096 2054	Grounding Plate	43- 35
A096 2055	Motor Grounding Plate	43- 36
A096 2057	Charge Corona Grid	43- 9
A096 2061	Screw Shaft	43- 31
A096 2062	Wire Cleaner Slider	43- 30
A096 2063	Corona Wire Cleaner	43- 33
A096 2065	Slider Ring	43- 32
A096 2330	Drum Shaft Knob	51- 3
A096 3575	Blade Release Lever	51- 5
A096 3646	Pick-off Pawl Shaft	53- 13
A096 6266	Tray Lock Arm	83- 3
A096 6353	Feed Roller Lever	25- 21
A100 1310	Platen Cover Hinge Ass'y	13- 8
A100 1324	Positioning Sensor Shutter	13- 7
A100 1325	Hinge Spacer	13- 9
A100 2056	Plate - Cylindrical Lens	41- 15
A100 5406	IC - Analog Processing	103- 1
A130 1175	Main Corona Duct	77- 6
A130 1359	Small Inner Cover	11- 29
A130 9005	Exposure Glasse	109- 7

Part No.	Description	Page and Index No.
A130 9006	Grounding Plate - Exposure Glass	109- 8
A130 9011	Charge Corona Unit	43- 24
A130 9011	Charge Corona Unit With Cleaner	109- 6
A133 3185	Gear - Toner Bottle (RIC - 115V)	45- 1
A133 3195	Gear - Toner Bottle (SVN/INF/NRG)	45- 1
A133 6100	Key Top - 10 Key (SVN)	15- 11
A133 6101	Key Top - Start/Stop (SVN)	15- 12
A133 6102	Key Top - Interrupt (SVN)	15- 10
A133 6103	Key Top - Clear Mode (SVN)	15- 9
A133 6104	Key Top - Job Recall (SVN)	15- 7
A133 6105	Key Top - Program (SVN)	15- 6
A133 6106	Key Top - Guidance (SVN)	15- 4
A133 6107	Key Top - User Tools (SVN)	15- 3
A133 6120	Grounding Wire - 270 mm	15- 14
A133 6124	Misfed Removal Sheet	11- 28
A133 7007	By-pass Feed Bracket	31- 10
A133 7017	Right Grip Plate	79- 13
A133 7017	Right Grip Plate	81- 16
A133 7023	Fusing Entrance Stay	33- 8
A133 7027	Registration Roller Cleaner	33- 25
A133 7031	Idler Bracket	33- 28
A133 7037	Front LCT Frame	31- 8
A133 7040	Rail - LCT	31- 11
A133 7046	Rear LCT Frame	31- 12
A133 7060	Upper LCT Frame	31- 13
A133 7064	Magnet Clutch Bracket	31- 14
A133 7066	Bracket - Right Inner Cover	31- 7
A133 7073	Front Upper Cover	11- 17
A133 7094	Right Cover	11- 14
A133 7097	Right Hinge Bracket	79- 22
A133 7098	Total Caunter Cover	79- 17
A133 7099	Braclet - Rear Cover	81- 12
A133 7102	Left Cover	11- 3
A133 7106	Front Cover (NRG)	11- 20

Part No.	Description	Page and Index No
A133 7112	Emblem (SVN)	11- 24
A133 7124	Operation Panel Case (LT)	15- 5
A133 7125	Operation Panel Case (A4)	15- 5
A133 7151	Left Bracket - IPU	37- 18
A133 7152	Right Bracket - IPU	37- 17
A133 7155	Left Scale (LT)	11- 9
A133 7157	Rear Scale (LT)	11- 7
A133 7159	LD Unit Cover	39- 4
A133 7166	Guide Harness LD	41- 18
A133 7226	Lower Development Stay	33- 27
A133 7236	Toner Collection Bottle	43- 21
A133 7292	Decal - Paper Size	107- 2
A133 7292	Decal - Paper Size - LT	17- 19
A133 7293	Decal - Paper Size - A4	17- 19
A133 7293	Decal - Paper Size	107- 2
A133 7299	Stopper - Clutch	73- 2
A133 7309	By-pass Feed Table Ass'y	21- 1
A133 7310	Front Plate - By-pass Feed	23- 18
A133 7312	Rear Plate - By-pass Feed	23- 7
A133 7314	Stay - By-pass Feed	23- 14
A133 7318	Guide Plate - Separator	23- 5
A133 7320	Drive Shaft - Feed Roller	23- 11
A133 7321	Shaft - Separation	23- 12
A133 7323	Arm - Pick-up	25- 11
A133 7325	Paper Feed Stay	25- 8
A133 7328	Paper End Actuator	25- 10
A133 7329	Guide Plate - Paper Feed	23- 2
A133 7331	Harness Bracket	25- 9
A133 7332	Pressure Lever - Pick-up	25- 3
A133 7333	Paper Feed Solenoid - LCT	25- 2
A133 7336	By-pass Feed Solenoid	25- 1
A133 7337	Solenoid Bracket	25- 12
A133 7339	Stopper	25- 6
A133 7341	Front Side Fence - By-pass	23- 17

Part No.	Description	Page and Index No.
A133 7343	Rear Side Fence - By-pass	23- 8
A133 7344	Bracket - Relay Sensor	25- 4
A133 7345	Sensor Bracket	25- 5
A133 7347	By-pass Feed Table	21- 9
A133 7355	LCT Motor Cover	27- 29
A133 7358	Pressure Spring Plate	27- 28
A133 7360	Positioning Plate - LCT	27- 32
A133 7361	Bracket - Positioning Plate	27- 26
A133 7364	Rail - LCT	27- 27
A133 7369	Micro Switch	27- 34
A133 7371	LCT Front Cover	27- 17
A133 7375	Joint - Vertical Transport	31- 6
A133 7376	Upper Stay	27- 9
A133 7377	End Fence	27- 1
A133 7379	Bracket - Vertical Transfer	33- 24
A133 7383	Hinge - Vertical Transport	31- 17
A133 7385	Bracket - Vertical Transport	31- 5
A133 7386	Pressure Guide - Vertical Transport	31- 4
A133 7387	Stopper - Vertical Transport	31- 25
A133 7388	Fulcrum Bracket - Vertical Trans.	31- 15
A133 7521	Exit Cover	61- 10
A133 7693	IC - UVEPROM 2MX8 150NS	103- 2
A133 7705	Relay Board	81- 15
A133 7710	AC Drive Board (230V)	75- 9
A133 7725	SCU Board (230V)	75- 4
A133 7725	SCU Board (230V)	91- *
A133 7738	Harness - By-pass Feed	25- 7
A133 7739	Vertical harness	31- 19
A133 7742	Harness - DC Main - Front	75- 1
A133 7742	Harness - DC Main - Front	75- 12
A133 7743	LCT Harness	29- 24
A133 7760	Relay Harness - Circuit Breaker (230V)	81- 14
A133 7774	Harness LD Unit	37- 5
A133 7775	Bracket - Interlock Switch	79- 1

Part No.	Description	Page and Index No
A133 7781	Bracket - Circuit Breaker (230V)	81- 13
A133 7784	Power Pack Bracket	79- 23
A133 7785	Spring Plate - Power Pack	79- 24
A133 7786	Grounding Plate Bracket - SCU (230V)	75- 22
A133 7788	Spring Plate - HDD	81- 17
A133 7798	Bracket - HDD	81- 1
A133 7885	HDD-1.7GB-SCSI	81- 2
A133 7900	IC - GASHITE	103- 3
A133 7920	HDD Harness	81- 3
A133 7920	Harness HDD (230V)	37- 19
A133 9510	OPC Drum	51- 10
A134 1063	Transfer Unit Bracket	83- 18
A134 1065	Fusing Connector Bracket	77- 10
A134 1071	Left Grip Plate	81- 9
A134 1071	Left Grip Plate	79- 19
A134 1072	Right Bracket - Grip Plate	79- 20
A134 1072	Right Bracket - Grip Plate	81- 11
A134 1073	Left Bracket - Grip Plate	79- 21
A134 1073	Left Bracket - Grip Plate	81- 10
A134 1076	Left Stay - Exposure Unit	85- 1
A134 1080	Right Stay - Exposure Unit	85- 8
A134 1081	Transfer Unit Stay	83- 15
A134 1083	Paper Feed Stay	83- 23
A134 1084	Drum Heater Cover	83- 21
A134 1092	Lamp Stabilizer Stay	61- 11
A134 1096	Left Bracket - ADF	77- 12
A134 1098	Positioning Sensor Bracket	77- 14
A134 1099	Right Bracket - ADF	77- 7
A134 1109	Tightner Bracket - Paper Feed	73- 15
A134 1109	Tightner Bracket - Paper Feed	71- 11
A134 1114	Drum Holder	71- 2
A134 1121	Joint Gear	69- 17
A134 1126	Bracket - Cleaning Drive	71- 15
A134 1135	Fly Wheel	71- 3

Part No.	Description	Page and Index No.
A134 1150	Tension Bracket - Fusing Drive	69- 14
A134 1154	Release Lever - Fusing Drive	69- 13
A134 1161	Cooling Fan Duct	85- 15
A134 1164	Cooling Fan Bracket	85- 2
A134 1174	Exhaust Fan Motor - DC, 2.88W	77- 1
A134 1190	Exhaust Fan Duct	77- 21
A134 1192	Seal - Fan Motor	85- 14
A134 1193	Sheet - Lamp Stabilizer Stay	61- 29
A134 1195	Seal - Fan Harness	85- 17
A134 1282	Rear Cover	11- 12
A134 1292	Bracket - Upper Cover	77- 24
A134 1299	Bracket - Front Upper Cover	37- 20
A134 1302	Upper Cover	11- 5
A134 1317	Hinge - Front Cover	11- 21
A134 1318	Side Bracket - Front Cover	79- 10
A134 1319	Middle Bracket - Front Cover	79- 16
A134 1345	Rear Cover Bracket	81- 6
A134 1352	Right Inner Cover	11- 18
A134 1354	Middle Inner Cover	11- 19
A134 1357	Left Inner Cover	11- 22
A134 1362	Right Upper Cover	11- 13
A134 1369	Seal - Front Upper Cover	11- 32
A134 1377	Cap - Front Upper Cover	11- 27
A134 1383	Emblem (RIC)	11- 24
A134 1384	Cap - Front Cover	11- 35
A134 1392	Platen Cover Ass'y	13- 12
A134 1394	Front Platen Cover	13- 3
A134 1395	Rear Platen Cover	13- 5
A134 1396	Original Holder	13- 6
A134 1506	Key Top - 10 Key	15- 11
A134 1507	Key Top - Start/Stop	15- 12
A134 1511	Key Top - Interrupt	15- 10
A134 1515	Key Top - Clear Mode	15- 9
A134 1518	Key Top - Job Recall	15- 7

Part No.	Description	Page and Index No
A134 1523	Key Top - Program	15- 6
A134 1533	Key Top - Guidance	15- 4
A134 1538	Key Top - User Tools	15- 3
A134 1543	Cap - Option	15- 2
A134 1548	Dial	15- 20
A134 1553	Cover - Option	15- 1
A134 1558	Cap - Application	15- 8
A134 1662	Polygon Motor Cover	39- 3
A134 1668	Fan Guide	39- 27
A134 1675	Front Scanner Frame	39- 25
A134 1677	Front Tension Bracket	39- 6
A134 1678	Rear Tension Bracket	39- 23
A134 1679	Rear Scanner Frame	39- 26
A134 1680	Guide - Flexible Harness	39- 19
A134 1697	Lens Block Supporter	39- 5
A134 1698	Idle Pulley	39- 24
A134 1720	Bracket - Scanner Motor	39- 10
A134 1722	Bracket - Drive Shaft	39- 18
A134 1724	Cushion - Stepper Motor	39- 11
A134 1726	Wire Stopper Plate	35- 12
A134 1728	Fly Wheel	39- 15
A134 1776	Spring Plate - 1st Mirror	35- 8
A134 1782	2nd Scanner Ass'y	35- 6
A134 1791	Spring Plate - 2nd Mirror	35- 3
A134 1922	Rear Scale (A4)	11- 7
A134 1923	Left Scale (A4)	11- 9
A134 1924	Exposure Glass	11- 11
A134 1926	Exposure Glass Stopper	35- 15
A134 1929	Bracket - Left Scale	35- 18
A134 1932	Stay - Scanner Upper Right	35- 20
A134 1933	Right Stopper - Exposure Glass	35- 19
A134 1955	Inner Cover - Scanner	37- 7
A134 1959	Bracket - Exhaust Fan	39- 2
A134 1962	Bracket Home Sensor	37- 8

Part No.	Description	Page and Index No.
A134 1964	Bracket - Flexible Harness	39- 8
A134 1966	Drive Board - Scanne Motor	75- 16
A134 1971	Bracket - Fan Motor	37- 10
A134 2069	Bracket - 1st Mirror	41- 11
A134 2079	BTL Lens	41- 8
A134 2083	Guide Plate - Toner Shield Glass	41- 13
A134 2088	Right Btl Bracket	41- 7
A134 2089	Left Btl Bracket	41- 9
A134 2129	Bracket - Mirror	41- 16
A134 2252	Front Drum Plate	51- 2
A134 2255	Rear Drum Plate	51- 14
A134 2259	Right Drum Stay	51- 9
A134 2263	Entrance Seal - Tape	53- 21
A134 2268	Front Drum Stand	51- 1
A134 2269	Positioning Plate - Pick-off Pawl	53- 7
A134 2271	Bracket - Cleaning Blade	51- 11
A134 2275	Cleaning Blade	51- 8
A134 2277	Drive Shaft - Cleaning Roller	53- 18
A134 2278	Joint Gear - Cleaning	53- 5
A134 2278	Joint Gear - Cleaning	71- 12
A134 2284	Cleaning Case Cover	53- 1
A134 2292	Casing Cleaning	53- 20
A134 2300	Bushing - Drum	51- 4
A134 2332	Absorb Duct	85- 5
A134 2334	Middle Exhaust Duct	85- 7
A134 2342	Cusion - Drum	85- 18
A134 2344	Harness Bracket	79- 7
A134 2346	Drum Guide Stay - Left	85- 16
A134 2358	Drum Shaft	71- 18
A134 2363	Terminal Plate	43- 13
A134 2370	Cam - Toner Collection Bottle	69- 20
A134 2374	Right Stay - Collection Bottle	83- 16
A134 2375	Left Stay - Collection Bottle	83- 13
A134 2380	Toner Collection Bottle Cap	43- 15

Part No.	Description	Page and Index No
A134 2382	Upper Sponge - Collection Bottle	43- 18
A134 2383	Lower Sponge - Collection Bottle	43- 19
A134 2384	Toner Overflow Sensor Ass'y	43- 23
A134 2387	Cap - Spring	43- 16
A134 2391	Front Drum Seal	51- 12
A134 2392	Rear Drum Seal	51- 13
A134 2552	Lower Registration Guide	33- 15
A134 2557	Regist Sensor Bracket	33- 11
A134 2558	Upper Guide Plate - Registration	33- 14
A134 2570	Stopper Bracket - Registration	73- 17
A134 2572	Middle Tightener	73- 10
A134 2574	Flange - Gear	69- 6
A134 2574	Flange - Gear	73- 6
A134 2575	Tightener Arm	73- 21
A134 2577	Upper Support Bracket - Paper Feed	73- 20
A134 2579	Stopper Bracket	73- 18
A134 2585	Vertical Transfer Guide Plate	31- 2
A134 2588	Paper Guide	31- 1
A134 2661	Feeler Roller	25- 26
A134 2671	Left Guide Plate - By-pass Feed	23- 3
A134 2701	By-pass Feed Guide	21- 8
A134 2705	Magnet Catch Plate	21- 10
A134 2706	Rear Fence Rack	21- 12
A134 2707	Front Fence Rack	21- 14
A134 2711	Front Side Fence	21- 5
A134 2716	Rear Side Fence	21- 7
A134 2721	Front Paper Guide	21- 4
A134 2726	Rear Paper Guide	21- 6
A134 2741	By-pass Feed Entrance Guide	21- 3
A134 2746	By-pass Feed Cover	21- 15
A134 2790	Reverse Stay	19- 26
A134 2795	Pressure Lever	19- 27
A134 2810	Release Solenoid	19- 31
A134 2821	Front Side Plate	19- 38

Part No.	Description	Page and Index No.
A134 2826	Rear Side Plate	19- 15
A134 2830	Drive Shaft	19- 21
A134 2832	Driven Shaft Ass'y	19- 23
A134 2834	Vertical Transport Guide	19- 35
A134 2839	Reverse Gide Plate	19- 1
A134 2846	Lower Guide Plate	19- 37
A134 2855	Lower Feed Stay	19- 16
A134 2860	Pick-up Arm	19- 5
A134 2862	Paper End Sensor Feeler	19- 17
A134 2863	Paper End Sensor Lever	19- 19
A134 2866	Pick-up Solenoid	19- 11
A134 2868	Solenoid Bracket	19- 40
A134 2873	Positioning Sensor Bracket	19- 9
A134 2878	Paper End Sensor Bracket	19- 7
A134 2885	Separation Torque Limitter	23- 15
A134 2885	Torque Limitter	19- 24
A134 2895	Vertical Relay Guide	33- 23
A134 2900	Duplex Stay	33- 17
A134 2903	Upper Guide Plate - Duplex Feed	33- 21
A134 2921	Left Slide Rail	83- 1
A134 2926	Paper Feed Lock Bracket	83- 2
A134 2930	Right Slide Rail	83- 25
A134 2933	Tray Lift Motor - DC24V 0.5W	77- 23
A134 2941	Bracket - Paper Sizesensor	77- 3
A134 2947	Heater Cover	83- 7
A134 2956	Paper Feed Front Cover	17- 1
A134 2956	Paper Feed Front Cover	63- 1
A134 2960	Paper Talon	17- 20
A134 2968	Grounding Plate	17- 15
A134 2976	Stopper Lever	17- 4
A134 2978	Spring Plate	17- 5
A134 2986	Bottom Plate	17- 18
A134 2997	Decal - Paper Setting	17- 2
A134 2997	Decal - Paper Setting	107- 3

Part No.	Description	Page and Index No
A134 3055	Front Seal - Development Roller	47- 18
A134 3056	Rear Seal - Development Roller	47- 17
A134 3060	Entrance Seal - Development	47- 6
A134 3086	Fixing Plate - Development	49- 7
A134 3088	Cover - Power Pack	47- 8
A134 3090	Development Filter	47- 5
A134 3095	Front Cover - Development	47- 9
A134 3120	Toner Supply Unit	47- 1
A134 3145	Disk - Torque Limiter	47- 13
A134 3157	Bottle Holder Bracket	45- 19
A134 3161	Bottle Drive Bracket	45- 14
A134 3162	Bottle Drive Motor DC 5.85w	45- 20
A134 3164	Bracket - Toner Holder	45- 17
A134 3171	Shutter - Toner Bottle	45- 16
A134 3172	Toner Bottle Holder	45- 13
A134 3179	Chuck Shaft	45- 7
A134 3180	Bottle Chuck	45- 3
A134 3181	Chuck Roller	45- 6
A134 3185	Gear - Toner Bottle (RIC - 230V)	45- 1
A134 3192	Seal - Toner Bottle	45- 26
A134 3197	Bottle Holder	45- 12
A134 3201	Cam - Toner Bottle	79- 12
A134 3203	Shutter Bracket - Toner Holder	79- 11
A134 3212	Toner Receive Plate	45- 23
A134 3215	Rubber Cap	45- 28
A134 3227	Positioning Holder - Development	85- 11
A134 3229	Stopper - Development Unit	85- 9
A134 3850	Transfer Belt	55- 1
A134 3854	Frame - Transfer Unit	55- 3
A134 3856	Side Plate Drive Roller	55- 7
A134 3860	Terminal Plate - Bias Roller	55- 11
A134 3865	Bushing - Driver Roller	55- 12
A134 3872	Drive Roller - Transfer	55- 2
A134 3880	Bias Roller - Transfer	55- 4

Part No.	Description	Page and Index No.
A134 3891	Bushing - Drive Roller	55- 9
A134 3903	Casing - Transfer Belt	55- 31
A134 3908	Seal - Power Pack - Transfer	55- 19
A134 3910	Mylar - Transfer Exit	55- 37
A134 3912	Release Stay	55- 26
A134 3914	Front Release Lever	55- 24
A134 3915	Rear Release Lever	55- 20
A134 3920	Mylar Transfer Entrance	55- 35
A134 3921	Tape 3 X 319	55- 36
A134 3934	Stay - Transfer Belt Cleaning	55- 27
A134 3935	Lever - Transfer Belt Cleaning	55- 15
A134 3937	Bushing - Belt Cleaning	55- 28
A134 3945	Cleaning Blade - Transfer Belt	55- 29
A134 3960	Toner Collection Coil - Transfer	55- 34
A134 3975	Paper Guide Stay	83- 5
A134 3980	Stay - Transfer Unit Handle	83- 17
A134 3998	Supporter - Transfer Unit	55- 14
A134 4006	Fusing Exit Unit	59- 1
A134 4061	Rear Terminal Plate	57- 6
A134 4063	Bias Plate - Thermofuse	57- 3
A134 4130	Fusing Front Cover	57- 1
A134 4153	Slide Rail - Fusing	59- 20
A134 4161	Pressure Lever	59- 13
A134 4272	Roller Holder	59- 31
A134 4280	Fusing Exit Guide - Lower	59- 7
A134 4351	Stay - Fusing Rail	83- 12
A134 4352	Fusing Lock Lever	83- 9
A134 4355	Fusing Unit Stopper	83- 14
A134 4450	Upper Exit Guide	61- 3
A134 4453	Roller Holder	61- 25
A134 4455	Upper Guide Bracket	61- 19
A134 4456	Bracket - Exit Sensor	61- 5
A134 4458	Exit Unit Knob	61- 17
A134 4460	Turn Gate - Right Upper Ass'y	61- 15

Part No.	Description	Page and Index No.
A134 4464	Left Reverse Guide	61- 1
A134 4465	Turn Guide - Right Lower	61- 14
A134 4466	Seal - Turn Guide	61- 27
A134 4467	Left Bracket - Turn Gate	61- 21
A134 4468	Lower Guide Plate	61- 20
A134 4471	Stripper Solenoid	61- 22
A134 4475	Guide Plate - Pulley	61- 28
A134 4481	Tightener Bracket	69- 10
A134 4508	Inverter Guide Plate	65- 24
A134 4512	Feed Roller Shaft	65- 22
A134 4525	End Fence Ass'y	67- 26
A134 4619	Guide Plate Link	63- 12
A134 4620	Grounding Plate	67- 19
A134 4646	Separation Roller Shaft	65- 30
A134 4649	Paper Guide Holder	65- 18
A134 4662	Duplex Guide Plate	65- 25
A134 4671	Bracket - Separation Roller	65- 29
A134 4676	Paper End Feeler	65- 3
A134 4688	Front Side Fence Rack	67- 10
A134 4689	Rear Side Fence Rack	67- 9
A134 4690	Clutch Stopper	65- 43
A134 4701	Front Upper Cover	63- 3
A134 4710	End Fence Actuator	67- 24
A134 4712	Right Cover Bracket	65- 46
A134 4714	Tightener	67- 15
A134 4720	End Fence Upper Cover	63- 2
A134 4721	Connector Cover	63- 4
A134 4726	Guide Plate Knob	63- 9
A134 4728	Inverter Feeler	63- 5
A134 4730	Entrance Feeler	63- 14
A134 4732	Upper Guide Plate	63- 6
A134 4739	Lower Guide Plate Knob	63- 10
A134 4740	Lower Guide Plate	63- 15
A134 4751	Front Side Plate	65- 44

Part No.	Description	Page and Index No.
A134 4765	Grounding Plate	65- 6
A134 4781	Rear Side Plate	65- 12
A134 4790	Paper End Sensor	65- 11
A134 4799	Motor Bracket	65- 42
A134 4800	Motor Bracket	65- 41
A134 4804	Guide Plate Stopper	65- 10
A134 4808	Rear Guide Holder	65- 21
A134 4809	Front Guide Holder	65- 16
A134 4884	Decal - Duplex Misfeed Removal	107- 4
A134 4884	Decal - Duplex Misfeed Removal	63- 21
A134 4901	Duplex Right Rail	83- 24
A134 5109	IC - JSL38G519AN05	95- 1
A134 5119	IC - TC160G22AF-1024	91- 1
A134 5152	Inverter Board	15- 21
A134 5153	Grounding Wire - Op. Panel	15- 16
A134 5156	PCB - 10 Key	15- 13
A134 5157	PCB - Option	15- 19
A134 5190	LSD Board	41- 4
A134 5215	IC - RF5GV94	103- 4
A134 5241	Power Pack	79- 18
A134 5251	ID Sensor	53- 3
A134 5254	Duplex Control Board	67- 23
A134 5265	Thermofuse	57- 4
A134 5266	Thermistor	57- 5
A134 5282	Paper Size Sensor Board	21- 11
A134 5290	Transport Drive Motor	65- 40
A134 5291	Jogger Drive Motor DC 6.48W	67- 20
A134 5292	Jogger Drive Motor DC 10.56W	67- 21
A134 5306	Harness - Development Unit	47- 11
A134 5310	Harness - ID Sensor	53- 2
A134 5315	Relay Harness - Lower Paper Feed	19- 36
A134 5319	Harness - Duplex Unit	77- 26
A134 5320	Duplex Main Harness	67- 30
A134 5321	Sensor Relay Harness	67- 32

Part No.	Description	Page and Index No
A134 5322	End Fence Harness	67- 25
A134 5323	Motor Harness	67- 22
A134 5360	Harness - Scanner Lamp	35- 5
A134 5370	Relay Harness - Scanner Lamp	35- 16
A134 5372	Harness - Scanner Lamp	75- 23
A134 5472	Relay Harness - Regist.Sensor	33- 13
A134 5476	Scanner Harness - Rear Left	37- 4
A134 5478	Scanner Harness - Front	37- 2
A134 5479	Harness - Exit Sensor	61- 7
A134 5491	Relay Harness - Polygon Motor	41- 2
A134 5811	Bracket - Power Cord	77- 17
A134 5813	Bracket - AC Drive Board	75- 8
A134 5816	Right Upper Bracket - DC Supply	77- 4
A134 5817	Right Lower Bracket - DC Supply	81- 8
A134 5818	Left Lower Bracket - DC Supply	81- 7
A134 5819	Left Upper Bracket - DC Supply	69- 3
A134 5820	Bracket - Harness Clamp	71- 10
A134 5823	Arm - Interlock Switch	79- 2
A134 5824	Bracket - Power Pack	79- 15
A134 5825	Rear Bracket - Power Pack	85- 10
A134 5826	Bracket - Total Counter	79- 6
A134 5827	Short Bracket - Main Harness	77- 8
A134 5828	Long Bracket - Main Harness	69- 1
A134 5829	Bracket - Charge Power Pack	75- 7
A134 5831	Bracket - BCU	75- 14
A134 5832	Upper Bracket - SCU	81- 5
A134 5833	Lower Bracket - SCU	81- 4
A134 5834	Bracket - SCU	75- 5
A153 1380	Platen Cover Bracket	13- 10
A153 2991	Front Side Fence Guide	17- 6
A153 2992	Rear Side Fence Guide	17- 12
A153 4114	Stripper Stopper	57- 17
A153 4207	Front Guide Plate	59- 25
A153 4208	Rear Guide Plate	59- 30

Part No.	Description	Page and Index No.
A153 4250	Fusing Exit Frame	59- 8
A153 5671	Power Supply Cord (230V)	77- 19
A153 6406	Model Name Plate - GER	107- 10
A153 6409	Decal - Keytop Cover	107- 12
A153 6409	Decal - Keytop Cover (NRG)	11- 1
A154 4616	Paper Holder (RIC)	63- 17
A154 4618	Bracket Socket	77- 25
A154 4620	Bottom Plate	67- 1
A154 4626	Vibrating Plate	65- 26
A155 5165	LCT Main Board	29- 18
A155 5170	Push Switch	29- 27
A155 5348	Paper End Sensor Harness	29- 4
A155 6101	LCT Upper Cover	27- 6
A155 6110	Front Side Plate - LCT	29- 29
A155 6113	Decal - Paper Set	27- 2
A155 6113	Decal - Paper Set	107- 5
A155 6114	Caution Decal - LCT	107- 7
A155 6114	Caution Decal - LCT	27- 31
A155 6116	Safety Switch Bracket	29- 21
A155 6117	Safety Switch Lever	29- 23
A155 6118	Spring Plate	29- 20
A155 6125	Rear Side Bracket	29- 28
A155 6136	Lift Sensor Bracket	29- 11
A155 6141	Tray Bottom Plate	29- 17
A155 6142	LCT Paper Tray	27- 14
A155 6143	Left Bracket	29- 1
A155 6145	Tray Cover	29- 19
A155 6147	Paper End Sensor Bracket	29- 3
A155 6148	Paper End Sensor Feeler	29- 2
A155 6153	Upper Hinge	29- 6
A155 6169	Hinge Holder	27- 30
A155 6170	Hinge Bracket	27- 21
A155 6171	Grip Bracket	27- 19
A155 6181	Knob	27- 18

Part No.	Description	Page and Index No
A155 6201	LCT Hinge Bracket	27- 8
A155 6203	Paper Tray Stay	29- 5
A155 6207	Cover Bracket	27- 3
A155 6215	Harness Guide	29- 30
A155 6221	LCT Rear Cover	27- 15
A155 6231	LCT Right Cover	27- 16
A155 6241	LCT Harness Cover	11- 15
A155 6270	Cushion 20x30	27- 35
A155 6301	Fix Hinge Ass'y	27- 4
A155 6302	Hinge Angle	27- 5
A155 6306	Front Side Fence	27- 22
A155 6307	Rear Side Fence	27- 12
A155 6311	Front Paper Holder	27- 23
A155 6312	Rear Paper Holder	27- 10
A155 6313	Support Guide	27- 11
A155 6321	Front Spring Plate	27- 24
A155 6322	Rear Sprig Plate	27- 25
A204 2904	Lower Guide Plate - Duplex Feed	33- 22
A204 2953	Paper Tray	17- 8
A204 2971	Bottom Lift Shaft	17- 17
A204 2972	Bottom Lift Lever	17- 16
A204 3177	Toner Slider	45- 4
A204 3190	Toner Bottle Stopper	45- 9
A204 4072	Front Holder	59- 28
A204 4073	Rear Holder	59- 29
A204 4101	Front Side Plate	59- 14
A204 4110	Rear Side Plate	59- 16
A204 4115	Shielding Plate	57- 20
A204 4116	Entrance Guide Stay	59- 18
A204 4151	Fusing Unit Base	59- 21
A204 4181	Front Release Lever	59- 15
A204 4185	Rear Release Lever	59- 17
A204 4207	Bracket - Exit Unit	59- 27
A204 4270	Cleaning Roller Bracket	59- 24

Part No.	Description	Page and Index No.
A204 4312	Stripper Bracket	57- 22
A204 4651	Bottom Pressure Plate	67- 5
A300 3155	Stepped Screw - M25x32	29- 22
A334 4706	Disk - Bottom Plate Clutch	65- 36
A335 1341	Chain Hook	29- 31
A335 3251	Top Cover Hinge	27- 7
A335 4351	Guide Roller	29- 10
A335 4352	Timing Belt Clamp	29- 25
A352 2138	Slide Collar - 0.6x4.5x6	53- 11
A406 9505	Platen Cover Sheet - 10 Sheet/1 Set	13- 1
A421 2543	Friction Pad	27- 13
A469 2123	Rubber Cushion - 1x10x10mm	25- 22
A470 1703	Shift Clutch	61- 23
A470 1704	Spring - Lower Exit Roller	61- 24
A491 4690	Bottom Plate Hook	67- 7
A615 4453	Side Plate : Rising Tray : Front	87- 8
A615 4455	Bracket : Paper Ext Sup	87- 9
A615 4457	Oil Dumper - 0.05 NFM	87- 15
A615 4463	Rear Side Plate - Copy Tray Holder	87- 10
A615 4465	Rear Side Plate	87- 16
A615 4472	Upper Stay	87- 11
A615 4473	Lower Stay	87- 12
A615 4474	Copy Tray Holder	87- 13
A615 4480	Cover - Copy Tray	87- 14
A669 5355	IC - GAFBTC	103- 10

Part No.	Description	Page and Index No
5013 0815	Pressuer Spring	69- 8
5053 0223	Bushing - 8mm	73- 19
5053 0223	Bushing - 8mm	29- 26
5203 1686	Screw - Slid Rail	83- 11
5203 9501	Silicone Grease G-501	109- 4
5205 2612	Gear - 19T	55- 22
5206 2686	Snap Ring	63- 8
5215 2621	Snap Ring - M6	83- 19
5215 2621	Snap Ring - M6	21- 16
5215 2621	Snap Ring - M6	65- 15
5215 3872	Gear - 45T	69- 22
5215 4497	Exit Antistatic Brush	61- 26
5219 1958	Spring - Lens Guide	55- 25
5304 1639	Bushing - 8mm	65- 14
5324 1658	Bushing- 4x8x4.5mm	53- 9
5408 5160	Short Connector	79- 8
5414 4630	Bottle Spring	69- 11
5420 9507	Digital Multimeter	109- 5
5420 9516	Test Chart - OS-A3 (10 pcs/set)	109- 2
5442 4467	Spring - Stripper Pawl Plate	83- 10
5442 4467	Spring - Stripper Pawl Plate	79- 3
5443 2668	Bushing - 4x6x7mm	65- 8
5446 1239	Plate Nut - Key Counter	31- 9
5446 3108	Spacer - 1.5x4.2x11mm	47- 15
5447 2681	Snap Ring	23- 10
5447 2681	Snap Ring	25- 23
5447 2681	Snap Ring	19- 2
5447 2681	Snap Ring	65- 37
5447 2681	Snap Ring	31- 24
5447 2706	Gear - 15T	25- 15
5447 2706	Gear - 15T	19- 4
5447 2768	Stepped Screw - M3	63- 13
5447 2927	Friction Pad - B	21- 2
5447 9078	Heat Resistant Grease - MT-78	109- 3

Part No.	Description	Page and Index No.
5474 2152	Bushing - 8x12x12mm	33- 4
5853 1190	Spring - Click Plate	51- 7
5875 2088	Shoulder Screw - M4	79- 14
5875 2088	Shoulder Screw - M4	55- 23
5921 3104	Spring - Toner End Lever	25- 19
5925 2258	Stopper Chain	29- 13

Part No.	Description	Page and Index No
0313 0040B	Philips Pan Head Screw - M3x4	33-105
0313 0040B	Philips Pan Head Screw - M3x4	25-101
0313 0040B	Philips Pan Head Screw - M3x4	61-103
0313 0050B	Philips Pan Head Screw - M3x5	87-103
0313 0050B	Philips Pan Head Screw - M3x5	65-110
0313 0080B	Philips Pan Head Screw - M3x8	57-103
0313 0080B	Philips Pan Head Screw - M3x8	55-107
0313 0140B	Philips Pan Head Screw - M3x14	35-101
0313 0350B	Philips Pan Head Screw - M3x35	79-102
0314 0060B	Philips Pan Head Screw - M4x6	51-102
0314 0060B	Philips Pan Head Screw - M4x6	73-101
0314 0060B	Philips Pan Head Screw - M4x6	57-107
0314 0060E	Philips Pan Head Screw - M4x6	59-107
0314 0080B	Philips Pan Head Screw - M4x8	39-107
0314 0100B	Philips Pan Head Screw - M4x10	57-105
0314 0100B	Philips Pan Head Screw - M4x10	39-102
0314 0120B	Philips Pan Head Screw - M4x12	37-101
0314 0120B	Philips Pan Head Screw - M4x12	71-102
0314 0250B	Philips Pan Head Screw - M4x25	37-103
0314 0350B	Philips Pan Head Screw - M4x35	77-111
0323 0060B	Philips Sunk Screw - M3x6	45-107
0323 0060B	Philips Sunk Screw - M3x6	77-110
0323 0080B	Philips Sunk Screw - M3x8	31-107
0324 0080B	Philips Sunken Head Screw - M4x8	11-102
0344 0060F	Philips Truss Head Screw - M4x6	17-104
0344 0080F	Philips Truss Head Screw - M4x8	63-101
0353 0040B	Screw - M3X4	35-103
0353 0060B	Philips Pan Head Screw - M3x6	47-104
0353 0060F	Tapping Screw - M3X6	15-103
0353 0080B	Screw - M3x8	75-113
0353 0080B	Screw - M3X8	39-109
0353 0080B	Screw - M3x8	37-110
0353 0300B	Bind Screw - M3x30	85-104
0353 0300B	Bind Screw - M3x30	79-107

Part No.	Description	Page and Index No.
0354 0080B	Screw - M4x8	37-111
0414 0060B	Tapping Screw - M4x6	37-102
0414 0060B	Tapping Screw - M4x6	77-106
0414 0060B	Tapping Screw - M4x6	85-101
0414 0080B	Binding Self-tapping Screw - M4x8	55-101
0414 0080B	Binding Self-tapping Screw - M4x8	33-104
0414 0080B	Binding Self-tapping Screw - M4x8	77-109
0414 0080B	Binding Self-tapping Screw - M4x8	71-106
0414 0080B	Binding Self-tapping Screw - M4x8	31-108
0414 0080B	Binding Self-tapping Screw - M4x8	83-103
0414 0080B	Binding Self-tapping Screw - M4x8	23-105
0414 0142W	Tapping Screw - M4x14	13-101
0414 0352B	Tapping Screw - M4x35	77-103
0434 0060B	Philips Tapping Screw - M4x6	21-102
0434 0060B	Philips Tapping Screw - M4x6	55-102
0434 0060B	Philips Tapping Screw - M4x6	23-102
0434 0060B	Philips Tapping Screw - M4x6	69-102
0434 0060B	Philips Tapping Screw - M4x6	81-102
0434 0060B	Philips Tapping Screw - M4x6	37-105
0434 0060B	Philips Tapping Screw - M4x6	25-102
0434 0060B	Philips Tapping Screw - M4x6	73-102
0434 0060B	Philips Tapping Screw - M4x6	49-103
0434 0060B	Philips Tapping Screw - M4x6	33-107
0434 0060B	Philips Tapping Screw - M4x6	39-108
0434 0060B	Philips Tapping Screw - M4x6	65-109
0434 0060B	Philips Tapping Screw - M4x6	19-101
0434 0060B	Philips Tapping Screw - M4x6	71-103
0434 0060B	Philips Tapping Screw - M4x6	85-102
0434 0060B	Philips Tapping Screw - M4x6	79-106
0434 0060B	Philips Tapping Screw - M4x6	77-104
0434 0060B	Philips Tapping Screw - M4x6	27-101
0434 0060B	Philips Tapping Screw - M4x6	11-103
0434 0060B	Philips Tapping Screw - M4x6	29-101
0434 0060B	Philips Tapping Screw - M4x6	45-101

Part No.	Description	Page and Index No.
0434 0060B	Philips Tapping Screw - M4x6	75-110
0434 0060B	Philips Tapping Screw - M4x6	61-107
0434 0060B	Philips Tapping Screw - M4x6	31-101
0434 0060B	Philips Tapping Screw - M4x6	83-101
0434 0082B	Tapping Screw - M4x8	17-102
0434 0082B	Tapping Screw - M4x8	59-102
0434 0120B	Tapping Screw - M4x12	77-108
0443 0050B	Philips Pan Head Screw - M3x6	53-105
0443 0050B	Philips Pan Head Screw - M3x6	51-101
0443 0060B	Hexagon Tapping Screw - M3x6	29-103
0443 0060B	Hexagon Tapping Screw - M3x6	75-101
0443 0060B	Hexagon Tapping Screw - M3x6	55-108
0443 0060B	Hexagon Tapping Screw - M3x6	81-106
0443 0060B	Hexagon Tapping Screw - M3x6	45-103
0443 0060B	Hexagon Tapping Screw - M3x6	77-102
0443 0060B	Hexagon Tapping Screw - M3x6	35-102
0443 0060B	Hexagon Tapping Screw - M3x6	63-104
0443 0060B	Hexagon Tapping Screw - M3x6	65-102
0443 0060B	Hexagon Tapping Screw - M3x6	49-102
0443 0060W	Hexagon Head Tapping Screw - M3x6	65-111
0443 0080B	Tapping Screw - M3x8	49-104
0443 0080B	Tapping Screw - M3x8	51-103
0443 0122B	Hexagonal Tapping Screw - M3x12	67-106
0443 0140B	Tapping Screw - M3x14	81-108
0451 4006B	Tapping Screw - 4x6	87-101
0534 0040E	Hexagon Headless Set Screw - M4x4	71-114
0575 0050E	Hexagon Headless Set Screw - M5x5	39-101
0623 0160E	Spring Pin - 3x16mm	29-106
0701 0060B	Flat Washer - M6	61-104
0707 8100B	Bushing - M8x10	69-108
0720 0025E	Retaining Ring - M2.5	67-105
0720 0025E	Retaining Ring - M2.5	43-103
0720 0030E	Retaining Ring - M3	31-104
0720 0030E	Retaining Ring - M3	23-103

Part No.	Description	Page and Index No.
0720 0030E	Retaining Ring - M3	65-105
0720 0030E	Retaining Ring - M3	73-104
0720 0030E	Retaining Ring - M3	19-103
0720 0030E	Retaining Ring - M3	53-102
0720 0040E	Retaining Ring - M4	49-107
0720 0040E	Retaining Ring - M4	69-101
0720 0040E	Retaining Ring - M4	55-104
0720 0040E	Retaining Ring - M4	73-106
0720 0040E	Retaining Ring - M4	67-103
0720 0040E	Retaining Ring - M4	83-102
0720 0040E	Retaining Ring - M4	19-102
0720 0040E	Retaining Ring - M4	81-105
0720 0040E	Retaining Ring - M4	87-102
0720 0040E	Retaining Ring - M4	47-103
0720 0040E	Retaining Ring - M4	33-103
0720 0040E	Retaining Ring - M4	23-104
0720 0040E	Retaining Ring - M4	65-104
0720 0040E	Retaining Ring - M4	45-105
0720 0040E	Retaining Ring - M4	71-109
0720 0040E	Retaining Ring - M4	61-102
0720 0040E	Retaining Ring - M4	59-104
0720 0060E	Retaining Ring - M6	39-105
0720 0060E	Retaining Ring - M6	69-107
0720 0060E	Retaining Ring - M6	23-101
0720 0060E	Retaining Ring - M6	73-107
0720 0060E	Retaining Ring - M6	25-103
0720 0060E	Retaining Ring - M6	71-101
0720 0060E	Retaining Ring - M6	55-103
0720 0060E	Retaining Ring - M6	57-108
0720 0060E	Retaining Ring - M6	81-104
0720 0060E	Retaining Ring - M6	35-104
0720 0060E	Retaining Ring - M6	19-105
0720 0060E	Retaining Ring - M6	17-103
0720 0060E	Retaining Ring - M6	65-106

Part No.	Description	Page and Index No.
0720 0060E	Retaining Ring - M6	33-101
0720 0060E	Retaining Ring - M6	29-104
0725 0100E	Retaining Ring C - M10	45-102
0725 0120	Retaining Ring C - M12	59-103
0725 0120E	Retaining Ring C - M12	55-106
0725 0120W	Retaining Ring - M12	71-113
0725 0250E	Retaining Ring C - M25	57-106
0742 3808	Ball Bearing - 8x16x5	19-106
0742 3808M	Bushing - 8x16x5	81-103
0800 0072	Philips Pan Head Screw - M2.6x4	45-108
0801 0149	Philips Pan Head Screw - M4x6	77-114
0801 0150	Philips Tapping Screw W/W - M4x8	11-104
0801 0153	Bind Screw - M6	81-116
0802 5085	Tapping Screw - M4x8	11-101
0802 5085	Tapping Screw - M4x8	61-105
0802 5094	Tapping Truss Head Screw - M4x8	27-103
0802 5094	Tapping Truss Head Screw - M4x8	11-105
0802 5094	Tapping Truss Head Screw - M4x8	31-105
0802 5231	Tapping Screw - M3x6	45-104
0802 5231	Tapping Screw - M3x6	63-103
0802 5232	Tapping Screw - M3x8	53-104
0802 5232	Tapping Screw - M3x8	67-102
0802 5232	Tapping Screw - M3x8	49-105
0802 5232	Tapping Screw - M3x8	47-102
0802 5232	Tapping Screw - M3X8	15-102
0802 5232	Tapping Screw - M3x8	11-106
0802 5232	Tapping Screw - M3x8	41-103
0802 5233	Tapping Screw - M3x10	45-106
0802 5236	Tapping Screw - M4x8	59-101
0802 5236	Tapping Screw - M4x8	87-104
0802 5236	Tapping Screw - M4x8	63-102
0802 5236	Tapping Screw - M4x8	61-106
0802 5236	Tapping Screw - M4x8	65-101
0802 5236	Tapping Screw - M4x8	23-106

Part No.	Description	Page and Index No.
0802 5236	Tapping Screw - M4x8	29-102
0802 5236	Tapping Screw - M4x8	67-104
0802 5236	Tapping Screw - M4x8	71-105
0802 5237	Binding Self-tapping Screw - M4x10	53-103
0802 5237	Binding Self-tapping Screw - M4x10	49-106
0802 5237	Binding Self-tapping Screw - M4x10	33-108
0802 5237	Binding Self-tapping Screw - M4x10	61-101
0802 5237	Binding Self-tapping Screw - M4x10	31-103
0802 5238	Tapping Screw - M4x12	49-101
0802 5238	Tapping Screw - M4x12	41-102
0802 5246	Screw - M3x5	35-105
0802 5246	Screw - M3x5	37-112
0805 0088	Retaining Ring - M6	19-104
0805 0088	Retaining Ring - M6	45-109
0805 3368	Ball Bearing - 8 X 16 X 5mm	39-103
0805 3385	Bushing - 6mm	65-107
0805 3386	Bushing - 8mm	81-107
0805 3480	Bushing - 6mm	59-106
0805 3480	Bushing - 6mm	71-110
0805 3480	Bushing - 6mm	61-108
0805 3490	Bushing - 5x10x4mm	55-105
0805 3492	Bushing - 8x16x5	81-109
0950 4006M	Philips Screw With Flat Washer-M4x6	77-112
0950 4006M	Philips Screw With Flat Washer	57-102
0950 4008B	Philips Screw With Spring Waser - M4x8	59-105
0951 3006B	Philips Screw With Flat Washer-M3x6	33-102
0951 3006B	Philips Screw With Flat Washer-M3x6	67-101
0951 4005B	Philips Screw With Flat Wash.- M4x5	39-104
0951 4006B	Philips Screw With Washer - M4x6	75-105
0951 4006B	Philips Screw With Washer - M4x6	73-105
0951 4006B	Philips Screw With Washer - M4x6	85-103
0951 4006B	Philips Screw With Washer - M4x6	39-106
0951 4006B	Philips Screw With Washer - M4x6	37-106
0951 4008B	Philips Screw With Washer - M4x8	69-106

Part No.	Description	Page and Index No
0951 4008B	Philips Screw With Washer - M4x8	71-111
0951 4008B	Philips Screw With Washer - M4x8	47-101
0951 4008B	Philips Screw With Washer - M4x8	65-103
0951 4008B	Philips Screw With Waser - M4x8	59-108
0951 4010B	Philips Screw With Washer - M4x10	41-101
0954 4008B	Philips Screw - M4x8	57-101
0960 3004B	Screw - M3x4	19-107
0960 3004B	Screw - M3x4	81-114
0960 4010B	Philips Flange Screw - M4 X 10	83-104
0965 3006B	Tapping Screw With Flat Washer M3x6	21-101
0965 3008B	Tapping Screw With Washer - M3x8	43-102
0965 4008B	Tapping Screw - M4 X 8	17-101
0971 4006A	Philips Polycarbonate Screw - M4x6	43-101
1101 0328	Connector Pin Contact	91-100
1101 0328	Connector Pin Contact	95-100
1101 0475	Terminal	57-104
1102 4052	Optional Connector	77-101
1102 4201	Connector - 2P	91-101
1102 4201	Connector - 2P	103-100
1102 4202	Connector - 3P	95-101
1102 4202	Connector - 3P	91-102
1102 4203	CT Header - 4P	95-102
1102 4203	CT Header - 4P	91-103
1102 4204	CT Header - 5P	103-101
1102 4204	CT Header - 5P	91-104
1102 4205	CT Header - 6P	95-103
1102 4205	CT Header - 6P	103-102
1102 4207	Connector - 8P	103-103
1102 4207	Connector - 8P	95-104
1102 4208	Connector - 9P	95-105
1102 4211	CT Header - 12P	95-106
1102 4212	CT Header - 15P	103-104
1102 4468	Ct Header - 10P	103-105
1102 4473	Ct Connector - 2p	79-105

Part No.	Description	Page and Index No.
1102 4497	Connector - 13P	95-107
1102 4506	Connector - 20P	103-106
1102 4559	Connector - 3p	79-103
1102 4619	Connector - 2P	103-107
1102 4620	Ct Header - 3P	103-108
1102 4621	CT Header - 4P	91-105
1102 4621	CT Header - 4P	95-108
1102 4626	Connector - 9P	95-109
1102 4630	Ct Header - 15P	103-109
1102 4631	CT Connector - 2P	91-106
1102 4644	Connector - 9P	95-110
1102 5007	CT Header - 14P	103-110
1102 5007	CT Header - 14P	95-111
1102 5276	Connector - 4P	91-107
1102 5301	Connector - 2P	103-111
1102 5311	Connector - 6P	91-108
1102 5331	Connector - 8P	103-112
1102 5375	Connector - 50P	103-113
1102 5409	CT Header - 20P	95-112
1102 5409	Connector - 20P	91-109
1102 5410	Connector - 22P	95-113
1102 5413	Connector - 28P	95-114
1102 5718	Optical Fiber Connector	91-110
1102 5718	Optical Fiber Connector	95-115
1102 6245	Connector - 2p	79-104
1102 6295	Connector - 2P	91-111
1102 6559	Connector - 60P	91-112
1102 6600	Connector - 8PP	95-116
1103 1317	Connector	91-113
1104 0370	IC Socket - 64P	95-117
1104 0376	IC Socket - 40P - DICF-40CS-E	91-114
1104 0376	IC Socket - 40P - DICF-40CS-E	95-118
1104 0377	IC Socket - 28P - DICF-28CS-E	91-115
1104 0473	32P - IC Socket	103-114

Part No.	Description	Page and Index No
1104 0511	IC SOCKET - 8P - DICF-8CS-E	103-115
1104 0612	Connector - 40P	103-116
1105 0087	Clamp	81-110
1105 0192	Locking Support	29-110
1105 0193	Nylon Stud	81-117
1105 0196	Harness Clamp	29-107
1105 0197	Wire Saddle	27-102
1105 0197	Wire Saddle	29-109
1105 0199	Clamp	79-108
1105 0199	Clamp	33-106
1105 0199	Clamp	29-108
1105 0199	Clamp	75-104
1105 0199	Clamp	65-108
1105 0199	Clamp	73-103
1105 0199	Clamp	71-112
1105 0199	Clamp	25-105
1105 0199	Clamp	19-108
1105 0229	Clamp	77-107
1105 0229	Clamp	55-109
1105 0229	Clamp	25-104
1105 0291	Wire Saddle	81-113
1105 0291	Wire Saddle	75-103
1105 0291	Wire Saddle	61-109
1105 0291	Wire Saddle	37-108
1105 0291	Wire Saddle	79-110
1105 0292	Wire Saddle	77-113
1105 0292	Wire Saddle	69-103
1105 0292	Wire Saddle	75-107
1105 0292	Wire Saddle	79-111
1105 0292	Wire Saddle	81-112
1105 0310	Wire Clamp	79-109
1105 0310	Wire Clamp	37-107
1105 0310	Clamp - LWS-1S	75-112
1105 0310	Wire Clamp	39-110

Part No.	Description	Page and Index No.
1105 0310	Wire Clamp	31-106
1105 0310	Wire Clamp	81-115
1105 0316	Clamp	77-105
1105 0316	Clamp	69-104
1105 0316	Clamp	81-111
1105 0328	Harness Clamp - ES-0505	61-110
1105 0328	Harness Clamp - ES-0505	71-107
1105 0329	Clamp - ES-0510	75-102
1105 0329	Clamp - ES-0510	31-102
1105 0329	Clamp - ES-0510	39-111
1105 0329	Clamp - ES-0510	37-109
1105 0329	Clamp - ES-0510	81-101
1105 0329	Clamp - ES-0510	79-112
1105 0367	Spacer	79-114
1105 0413	Harness Clamp	77-115
1105 0413	Harness Clamp	69-105
1106 0193	Bushing - 7.9mm	29-111
1107 0392	Fuse (glass Case) - 6.3A - 125V	75-109
1107 0393	Fuse (glass Case) - 8A - 125V	75-108
1107 0472	Circuit Breaker - 250V/8A	81-118
1107 0554	Fuse (glass Case) - 17A - 125V	75-106
1204 1537	Dip Switch	95-119
1204 1570	Dip Switch	91-116
1204 2355	Micro Switch - AM51632A531	29-105
1204 2355	Micro Switch - AM51632A531	79-101
1204 2421	Main Switch	79-113
1400 0392	Transistor - DTC114EK	103-117
1400 0398	Transistor - 2SC2412K	103-118
1400 0558	Transistor - 2SD780	95-120
1400 0663	Transistor - 2SA1037AK	103-119
1400 0717	Transistor - 2SA1226E4	103-120
1400 0738	Transistor - 2SC2223F14	103-121
1402 0688	Diode	95-121
1402 0688	Diode	91-117

Part No.	Description	Page and Index No
1402 1037	Diode - U1ZB12	95-122
1402 1122	Diode - MA159A	95-123
1402 1142	Diode Array - DAN217	103-122
1402 1191	Diode - 400V 1A	95-124
1402 1269	Diode - 1SS353	103-123
1402 1323	Zener Diode - UDZ5.6B	103-124
1403 0308	LED - RED - TLR102A	91-118
1403 0308	LED - Red - TLR102A	95-125
1403 0828	Diode - SEC1901C	103-125
1403 0829	Diode - SEC1201C	103-126
1407 1596	TTLIC - SN74LS14NS	95-126
1407 1598	TTLIC - SN74LS125ANS	95-127
1407 1600	TTLIC - SN74LS244NS	103-127
1407 1746	TTL SN74LS240NS	103-128
1407 2147	TTLIC - 74F374SJ	103-129
1407 2187	TTLIC - SN74LS07NS	95-128
1407 2187	TTLIC - SN74LS07NS	103-130
1407 2218	TTLIC - SN74LS06NS	95-129
1407 2218	TTLIC - SN74LS06NS	103-131
1407 2231	IC - TD62308AF	103-132
1407 2231	IC - TD62308AF	95-130
1407 2261	IC - NJM2902M	95-131
1407 2344	IC - TD62382F	91-119
1407 2463	TTL IC SN74ALS08NS	103-133
1407 2781	TTL - SN74AS04NS	103-134
1407 3285	IC - TC74HC08AF	95-132
1407 3380	HS - C2MOS - TC74HCT04AF	95-133
1407 3381	Cmos - IC - TC74HC4066AF	103-135
1407 3481	IC - SN74AS32NS	103-136
1407 4023	IC - M62353GP	103-137
1407 4109	IC - CXD1175AM	103-138
1407 4145	IC - HD74LS07PF	91-120
1407 4209	CPU MC68340FE16E	91-121
1407 4315	IC - TE7751	95-134

Part No.	Description	Page and Index No.
1407 4323	TTL TD74ABT244AF	103-139
1407 4330	CPU UPD70433GD-5BB	103-140
1407 4336	PSRAM	91-122
1407 4536	PLL ICS1574	103-141
1407 4671	FIFO M66256FP	103-142
1407 4688	IC - UPD485506G5-25-7JF	103-143
1407 4689	LSI - SCSI CONT. - SYM53CF92-64PQFP	103-144
1407 4691	IC - NM93C66N	103-145
1407 4696	IC - M48T58Y-70PC1	75-111
1407 4696	IC - M48T58Y-70PC1	91-123
1407 4734	IC - M66257FP	103-146
1407 4791	CPU MC68340FT16E	95-135
1407 4793	CMOS 74LCX240SJ	103-147
1407 4794	CMOS 74LCX244SJ	103-148
1408 0595	IC - NJM2904M	103-149
1408 0598	IC - MB3773PF	95-136
1408 0611	IC - 3771	91-124
1408 0611	IC - 3771	103-150
1408 0770	IC - L293D	95-137
1408 0874	Transistor Array - M54587FP	95-138
1408 0874	Transistor Array - M54587FP	91-125
1408 0877	Comparator - LM339NS	95-139
1408 1233	IC - LT1117CST-3.3	103-151
1408 1278	IC:L6220	95-140
1503 0095	Oscillator - P3 32.768KHZ	91-126
1503 0460	Ocsillator - 32.768kHz	95-141
1503 0504	Ocsillator - TQC-246C-6R-3.6864M	95-142
1503 0518	Oscillator - CSA4.91MGG	91-127
1503 0533	Oscillator - CK4400AC 40.0MHZ	103-152
1503 0569	Ocsillator - 19.66MHz	95-143
1503 0708	Oscillator - AT-51 25MHZ	103-153
1503 0755	Oscillator - 1332-M1 28.0MHZ	103-154
1503 0756	Oscillator - SMD-49 42.8MHZ	103-155
1601 1413	Resistor - RCB8C330J	103-156

Part No.	Description	Page and Index No
1601 7664	Resistor - 220 ohm /330 Ω	103-157
1601 7738	Resistor - 10 Ω X 8 5%	95-144
1601 7739	Resistor - 4.7K Ω X 2 5%	95-145
1601 7740	Resistor - 4.7K Ω -5% 1/32W	95-146
1601 7741	Resistor - 4.7K Ω -5% 1/32W	95-147
1601 7752	Resistor ARRAY - 10K Ω $\pm$ 5%	103-158
1601 7793	Resistor - 10K Ω	103-159
1601 7813	Resistor - 15 Ω $\pm$ 5% 1/16W	103-160
1602 0918	Filter - 270pF - Emi	91-128
1604 1731	Capacitor - 56 μ F $\pm$ 20% 25V	103-161
1604 2601	Condensor - 47mF $\pm$ 20% 25V	103-162
1604 4521	Capacitor - 0.47 μ F $\pm$ 20% 50V	95-148
1605 0219	Capacitor - 1000pF 50V +80% -20%	95-149
1605 0223	Capacitor - 20pF 50V	95-150
1605 0223	Capacitor - 20pF 50V	91-129
1605 0322	Capacitor - 47pF 50V	91-130
1605 0322	Capacitor - 47pF 50V	95-151
1605 0343	Capacitor - 30pF $\pm$ 5% 50V	91-131
1605 0511	Capacitor - 30pF $\pm$ 5% 50V	103-163
1605 0636	Capacitor - 0.1 μ F	91-132
1605 0636	Capacitor - 0.1 μ F	95-152
1605 0685	Capacitor - 0.47mF	103-164
1605 0846	Capacitor - C8pF $\pm$ 0.5P	103-165
1605 0877	Capacitor - 6PF $\pm$ 0.5pF 50V	103-166
1606 1133	Capacitor - 22pF - 50V	95-153
1606 1135	Capacitor - 470pF 50V	95-154
1606 1139	Capacitor - 0.01 μ F $\pm$ 20%	91-133
1606 1208	Capacitor - 100pF $\pm$ 5% 50V	95-155
1606 1208	Capacitor - 100pF $\pm$ 5% 50V	91-134
1606 1450	Capacitor - 10pF 50V	91-135
1606 1450	Capacitor - 10pF 50V	95-156
1606 1452	Capacitor - 0.01 μ F 50V	95-157
1607 0280	Inductor - BLM41	103-167

Part No.	Description	Page and Index No.
1607 0477	Coil - BLM21A121SPB	91-136
1607 0494	IC - LALO4NA220K	103-168
1607 0551	Inductor - BLM32A07PB	95-158
1607 0551	Inductor - BLM32A07PB	91-137
1607 0663	Ferrite Core - TFC-20-10-10 (230V)	37-113
1607 0705	Noize Filter - ACF51832-470	103-169
1607 0705	Noize Filter - ACF51832-470	91-138
1607 0706	Noize Filter - ACF51832-220	103-170
1607 0723	Noize Filter - N2012Z121	103-171
1607 0747	FPC Core - FPC-25-12	15-101
1607 0796	Noize Filter - ACF51832-470	95-159
1607 0903	Ferrite Core : HF70RH16x28x10 (230V)	85-105
1607 0925	Noize Filter - HF70ACC321611	103-172
1630 1101	Resistor - 100 Ω 1/4W $\pm 5\%$	95-160
1630 1121	Resistor - 120 $\Omega \pm 5\%$ 1/8W	95-161
1630 1121	Resistor - 120 $\Omega \pm 5\%$ 1/8W	91-139
1630 1161	Resistor - 160 $\Omega \pm 5\%$ 1/8W	95-162
1630 1161	Resistor - 160 $\Omega \pm 5\%$ 1/8W	91-140
1630 1222	Resistor - 2.2K $\Omega \pm 5\%$ 1/8W	95-163
1630 2100	Resistor - 10 Ω 1/8W $\pm 5\%$	91-141
1630 2101	Resistor - 100 Ω 1/8W	91-142
1630 2102	Resistor - 1K Ω 1/8W $\pm 5\%$	91-143
1630 2102	Resistor - 1K Ω 1/8W $\pm 5\%$	95-164
1630 2103	Resistor - 10K Ω 1/8W	95-165
1630 2103	Resistor - 10K Ω 1/8W	91-144
1630 2106	Resistor - 10M Ω -1/8W	95-166
1630 2106	Resistor - 10M Ω -1/8W	91-145
1630 2152	Resistor - 1.5K Ω 1/8W $\pm 5\%$	95-167
1630 2204	Resistor - 200K $\Omega \pm 5\%$ 1/8W	95-168
1630 2206	Resistor - 20M Ω 1/8W $\pm 5\%$	91-146
1630 2206	Resistor - 20M Ω 1/8W $\pm 5\%$	95-169
1630 2221	Resistor - 220 Ω	91-147
1630 2221	Resistor - 220 Ω	95-170

Part No.	Description	Page and Index No
1630 2222	Resistor - 2.2K Ω 1/8W	91-148
1630 2222	Resistor - 2.2K Ω 1/8W	95-171
1630 2243	Resistor - 24K Ω 1/8W $\pm 5\%$	95-172
1630 2330	Resistor - 33 Ω 1/8W $\pm 5\%$	91-149
1630 2330	Resistor - 33 Ω 1/8W $\pm 5\%$	95-173
1630 2332	Resistor - 3.3K Ω 1/8W $\pm 5\%$	95-174
1630 2334	Resistor - 330K Ω	91-150
1630 2334	Resistor - 330K Ω	95-175
1630 2362	Resistor - 3.6K Ω 1/8W $\pm 5\%$	95-176
1630 2471	Resistor - 470 Ω 1/8W $\pm 5\%$	91-151
1630 2471	Resistor - 470 Ω 1/8W $\pm 5\%$	95-177
1630 2472	Resistor - 4.7K Ω 1/8W $\pm 5\%$	91-152
1630 2472	Resistor - 4.7K Ω 1/8W $\pm 5\%$	95-178
1630 2473	Resistor - 47K Ω 1/8W $\pm 5\%$	91-153
1630 2511	Resistor - 510 Ω 1/8W $\pm 5\%$	95-179
1630 2511	Resistor - 510 Ω 1/8W $\pm 5\%$	91-154
1630 2561	Resistor - 560 $\Omega \pm 5\%$ 1/8W	95-180
1630 2680	Resistor - 68 Ω 1/8W $\pm 5\%$	91-155
1630 2680	Resistor - 68 Ω 1/8W $\pm 5\%$	95-181
1630 2681	Resistor - 680 Ω 1/8W $\pm 5\%$	91-156
1630 2750	Resistor - 758 Ω 1/8W $\pm 5\%$	95-182
1630 2821	Resistor - 820 Ω 1/8W $\pm 5\%$	95-183
1630 3100	Resistor - 10 $\Omega \pm 5\%$ 1/10W	103-173
1630 3101	Resistor - 100 Ω - 1/10W	103-174
1630 3102	Resistor - 1K Ω 1/10W $\pm 5\%$	103-175
1630 3103	Resistor - 10K Ω 1/10W $\pm 5\%$	103-176
1630 3150	Resistor - 15 $\Omega \pm 5\%$ 1/10W	103-177
1630 3162	Resistor - 1.6K Ω 1/10W $\pm 5\%$	103-178
1630 3181	Resistor - 180 $\Omega \pm 5\%$ 1/10W	103-179
1630 3202	Resistor - 2K Ω -1/10W	103-180
1630 3222	Resistor - 2.2K Ω 1/10W $\pm 5\%$	103-181
1630 3223	Resistor - 22k Ω - 1/10W	103-182

Part No.	Description	Page and Index No.
1630 3241	Resistor - 240Ω 1/10W ±5%	103-183
1630 3242	Resistor - 2.4K Ω ±5% 1/10W	103-184
1630 3273	Resistor - 27kΩ - 1/10W	103-185
1630 3302	Resistor - 3KΩ - 1/10W	103-186
1630 3330	Resistor - 33 Ω ±5% 1/10W	103-187
1630 3331	Resistor - 330 Ω ±5% 1/10W	103-188
1630 3332	Resistor - 3.3KΩ 1/10W ±5%	103-189
1630 3364	Resistor - 360K Ω ±5% 1/10W	103-190
1630 3390	Resistor - 39 Ω ±5% 1/10W	103-191
1630 3470	Resistor - 47Ω 1/10W ±5%	103-192
1630 3471	Resistor - 470Ω - 1/10W	103-193
1630 3472	Resistor - 4.7KΩ 1/10W ±5%	103-194
1630 3511	Resistor - 510 Ω ±5% 1/10W	103-195
1630 3512	Resistor - 5.10KΩ - 1/10W	103-196
1630 3562	Resistor - 5.6K Ω +5% 1/10W	103-197
1630 3681	Resistor - 680 Ω ±5% 1/10W	103-198
1630 4330	Resistor - 33Ω ±5% 1/8W	103-199
1630 4472	Resistor - 4.7KΩ ±5% 1/16W	103-200
1630 4473	Resistor - 47K Ω - ±5% - 1/16W	103-201
1632 1002	Resistor - 10.0KΩ1/8W±1%	91-157
1632 3481	Resistor - 3.48KΩ ±1% 1/8W	91-158
1632 4641	Resistor - 4.64KΩ ±1% 1/8W	95-184
1632 5231	Resistor - 5.23K Ω ±1%	95-185
1632 5360	Resistor - 536Ω ±1% 1/8W	95-186
1632 5621	Resistor - 5.62KΩ ±1% 1/8W	95-187
1633 0000	Resistor - 0Ω 1/10W:JAMPER CHIP	103-202
1633 1202	Resistor - 12K Ω ±1% 1/10W	103-203
1633 1601	Resistor - 1.6KΩ ±1% 1/8W	103-204
1633 1602	Resistor - 16K Ω ±1% 1/4W	103-205
1633 1802	Resistor - 18K Ω ±1% 1/4W	103-206
1633 1871	Resistor - 1.87K Ω ±1% 1/10W	103-207
1633 2371	Resistor - 2.37K Ω ±1% 1/10W	103-208
1633 2701	Resistor - 2.7K Ω ±1% 1/10W	103-209

Part No.	Description	Page and Index No
1633 2702	Resistor - 27KΩ ±1% 1/10W	103-210
1633 3602	Resistor - 36K Ω ±1% 1/10W	103-211
1633 4700	Resistor - 470 Ω - ±1% - 1/10W	103-212
1633 6340	Resistor - 634 Ω ±1% 1/10W	103-213
1633 6800	Resistor - 680 Ω ±1% 1/10W	103-214
1633 7501	Resistor - 7.5K Ω ±5% 1/10W	103-215
1633 7502	Resistor - 57K 0HM ±1% 1/10W	103-216
1633 8201	Resistor - 8.2k Ω ±1% 1/10W	103-217
1633 9101	Resistor - 9.1K Ω 1/10W	103-218
1634 0000	Resistor - 0Ω - 1/16W	103-219
1640 2470	Capacitor - 47μF ±20% 25V	103-220
1640 5101	Capacitor - 100μF ±20% 50V	91-159
1640 5101	Capacitor - 100μF ±20% 50V	95-188
1640 5109	Capacitor - 1μF - ±20% - 50V	103-221
1640 5338	Capacitor - 0.33mF ±20%	95-189
1640 5470	Capacitor - 47μF ±20% 50V	103-222
1640 5479	Capacitor - 4.7μF ±20% 50V	103-223
1642 0470	Capacitor - 47μF ±20% 10V	103-224
1643 0220	Capacitor - 22uF ±20% 10V	103-225
1643 1470	Capacitor - 47μF ±20% 16V	103-226
1644 0100	Capacitor - 10uF ±20% 10V	103-227
1644 0330	Capacitor - 33uF ±20% 10V	103-228
1644 0470	Capacitor - 47uF ±20% 10V	103-229
1644 2330	Capacitor - 33uF ±20% 25V	103-230
1644 2479	Capacitor - 4.7μF ±20% 25V	103-231
1644 5339	Capacitor - 3.3uF ±20% 50V	103-232
1660 3150	Capacitor - 15pF 50V	103-233
1660 3471	Capacitor - 470pF 50V	103-234
1660 7103	Capacitor - 10000pF 50V	103-235
1660 7104	Capacitor - 100000pF 50V	103-236
1660 9104	C - 0.1uF 25V	103-237
1902 0012	C SRAM 256K X8 100NS G3	95-190
1902 0012	IC - SRAM - 64K X8 100NS G1	103-238
1902 0021	IC - SRAM - 1M - X8 - 100NS/G4	103-239

