

**Model T-C1a/C1b/C1bN
(J012/J013/J014)
PARTS CATALOG**

First edition, July 2007

Ricoh Company, LTD.

Model T-C1a/C1b/C1bN (J012/J013/J014)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

Model T-C1a/C1b/C1bN	(J012/J013/J014)
Paper Feed Unit TK2000	(J509)
Multi Bypass Tray Type BY1000	(J507)
Network Interface Bord Type GX4	(J510)

Model T-C1a/C1b/C1bN
(J012/J013/J014)

Model T-C1a/C1b/C1bN (J012/J013/J014)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior 1 (J012/J013/J014)	2
2.Exterior 2 (J012/J013/J014)	4
3.ADF Exterior (J012/J013/J014)	6
4.OP/Optics (J012/J013/J014)	8
5.Paper Tray (J012/J013/J014)	10
6.Duplex Unit (J012/J013/J014)	12
7.Main Parts 1 (J012/J013/J014)	14
8.Main Parts 2 (J012/J013/J014)	16
9.Main Parts 3 (J012/J013/J014)	18
Parts Index	22

July ,30 ' 2007

1.Exterior 1 (J012/J013/J014)




1.Exterior 1 (J012/J013/J014)

Index No.	Part No.	Description	Q'ty Per Assembly
*	J012 9221	Plotter:Unit:NA	1
*	J012 9222	Plotter:Unit:EU	1
*	J013 9221	Plotter:Unit:NA	1
*	J013 9222	Plotter:Unit:EU	1
*	J014 9221	Plotter:Unit:NA	1
*	J014 9222	Plotter:Unit:EU	1
1	J012 1552	Left Cover - NA	1
1	J012 1502	Cover:Left:Tos-C1	1
2	J012 1522	Right Cover - NA	1
2	J013 1522	Right Cover - NA	1
2	J014 1522	Right Cover - NA	1
2	J012 1523	Right Cover - EU	1
2	J013 1523	Right Cover - EU	1
2	J014 1523	Right Cover - EU	1
3	J012 0161	Ink Cartridge Cover - NA	1
3	J012 0153	Cover:Ink Cartridge:Tos-C1:Ass'y	1
4	J012 5550	Push Switch:JPS1220-0101FC	1
5	J012 1509	Cover:Usb:Tos-C1	1
6	J012 1102	Right Fan Filter	1
7	J012 1562	Tank Cover - NA	1
7	J012 1542	Cover:Tank:Tos-C1	1
8	J012 6653	IC:Driver:Manual:Tos-C1a:English	1
8	J013 6654	CD-ROM:Driver:Manual:Tos-C1b:English	1
9	J012 0154	Cover:Original:Tos-C1:Ass'y	1
10	J012 0156	Originalpressure Plate	1
11	J012 5511	Power Supply Cord - NA	1
11	J001 5493	Power Supply Cord:EU	1
12	J014 0501	Network Interface Board	1
13	J012 1100	Fan Motor Bracket- Right Front	1
14	J007 5621	Fan:Mm60:15mm:37V	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3010N	Binding Self-Tapping Screw:3x10	
102	0450 4025N	Tapping Screw:4x25	

2.Exterior 2 (J012/J013/J014)




2.Exterior 2 (J012/J013/J014)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J012 0157	Front Cover - NA	1
1	J012 0150	Cover:Front:Tos-C1:Ass'y	1
2	J007 5440	Harness:Safety Switch:Front:Tos	1
3	J007 1544	Cover:Safety Switch:TP	1
4	J006 2304	Decal:Operate:Dial	1
5	J012 1555	Left Front Cover - NA	1
5	J012 1505	Cover:Left Front:Tos-C1	1
6	J012 1556	Right Front Cover - NA	1
6	J012 1506	Cover:Right Front:Tos-C1	1
7	J012 1071	Rear Fan Filter	1
8	J012 5489	Harness:GND	1
9	J012 1510	Cover:Power Supply Cord:Tos-C1	1
10	J012 1551	Rear Cover - NA	1
10	J012 1501	Cover:Rear:Tos-C1	1
11	J001 1008	Rubber Foot	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0452 3010N	Binding Self-Tapping Screw:3x10	
103	0452 3008N	Tapping Screw - M3x8	
104	0454 3006Q	Tapping Screw - M3x6	

3.ADF Exterior (J012/J013/J014)




3.ADF Exterior (J012/J013/J014)



Index No.	Part No.	Description	Q'ty Per Assembly
*	J013 0087	ADF Unit	1
1	J013 8701	Originalpickup Roller	1
2	J013 8700	Friction Pad- ARDF	1
3	J012 0156	Originalpressure Plate	1
4	J013 8705	Lefthinge- ARDF	1
5	J013 8704	Righthinge- ARDF	1
6	J013 8703	Original Tray	1
7	J012 2306	Decal - ARDFJam Removal	1
8	J012 2311	Decal - Original Set	1
9	J013 8721	ARDFCover	1
10	J013 8722	Extra Tray	1
11	J013 1508	Plate - Logo RIC	1

Index No.	Part No.	Description	Q'ty Per Assembly

4.OP/Optics (J012/J013/J014)




4.OP/Optics (J012/J013/J014)

Index No.	Part No.	Description	Q'ty Per Assembly
*	J012 0071	Scanner Unit - LT	1
*	J013 0071	Scanner Unit - LT	1
*	J014 0071	Scanner Unit - LT	1
*	J012 0072	Scanner Unit - A/B	1
*	J013 0072	Scanner Unit - A/B	1
*	J014 0072	Scanner Unit - A/B	1
1	J012 1508	Plate:Logo:RIC	1
2	J012 0511	Main Control Board - Exp	1
2	J013 0511	Main Control Board - Exp	1
3	J013 0527	NCU - 115V	1
3	J013 0547	NCU - 230V	1
4	J012 0507	ARDFInterfaceharness	1
5	J012 2314	Cautiondecal - Copying	1
5	J012 2308	Cautiondecal - Copying	1
5	J012 2315	Cautiondecal - Copying EU	1
5	J012 2309	Cautiondecal - Copying EU	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	

5. Paper Tray (J012/J013/J014)




5.Paper Tray (J012/J013/J014)



Index No.	Part No.	Description	Q'ty Per Assembly
*	J012 0031	Paper Feed:Cassette:Ass'y	1
1	J012 0494	Exit Tray Unit	1
2	J012 3003	End Fence:Tos-C1	1
3	J001 3057	Tension Spring:Base:P1	2
4	J012 3019	Arm:Cassette	2
5	J012 3020	Protection:Cassette	2
6	J007 3025	Base Plate:Exp:Ass'y	1
7	J012 3004	Side Fence:Left:A4:Tos-C1	1
8	J012 3005	Side Fence:Right:A4:Tos-C1	1
9	J001 3008	Gear:Side Fence	1

Index No.	Part No.	Description	Q'ty Per Assembly

6. Duplex Unit (J012/J013/J014)




6.Duplex Unit (J012/J013/J014)

Index No.	Part No.	Description	Q'ty Per Assembly
*	J012 0680	Duplex Unit	1
1	J003 6877	Lever:Open And Close	1
2	J003 6866	Roller:Opposed:Transport Roller	3
3	J003 6867	Spring:Pressure Roller	3
4	J003 6878	Spring:Lever:Open And Close	1
5	J007 6857	Guide Plate:Open And Close:A4	1
6	J003 6832	PCB:Duplex Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly

7.Main Parts 1 (J012/J013/J014)




7.Main Parts 1 (J012/J013/J014)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J007 3517	Spring:Guide Rod:1	2
2	J007 3518	Spring:Guide Rod:2	1
3	J007 3519	Ground Plate:Guide Rod:Left	2
4	J006 1148	Spring:Tightener:Drive	1
5	J007 1130	Pulley:Tightener:Drive	1
6	J007 1118	Bracket:Tightener:Ass'y	1
7	J007 3514	Cam:Guide Rod:Left	2
8	J007 1122	Timing Belt:227ST1.5-6.0	1
9	J015 5205	DC Motor 37V 25.9W	1
10	J007 5470	Harness:Main:Seconddary:Motor	1
11	J007 5655	PCB:Senc:Tos/Pie	1
12	J007 4062	Guide Plate:Dc Solenoid	1
13	J007 4060	Bracket:Actuator:Valve	1
14	AX11 0125	DC Solenoid:Valve	1
15	J007 3513	Cam:Guide Rod:Right	1
16	J007 4061	Lever:Actuator:Valve	1
17	J001 4604	Tension Spring:Lever	1
18	GW01 0008	Photo Refiection Sensor:SG113-RC80	1
19	J007 3524	Cam:Guide Rod:Right Front	1
20	J007 3534	Spring:Lever:3N	1
21	J007 3540	Plate Spring - Guide Rod	2
22	J007 3504	Lever:Guide Rod:Tos	1
23	J007 3410	Cover:Carriage:Tos	1
24	J007 3520	Sheet:Encoder:Tos	1
25	J007 3018	Friction Pad Unit	1
26	AW02 0150	Photointerruptor:Flat:7mm	1
27	GW02 0020	Photointerruptor:LG248NL1	1
28	J001 1168	Slider:Transport Roller	1
29	J007 1161	Timing Pulley - 140T	1


Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0951 3005N	Screw:Polished Round:M3x5	
103	0720 0025E	Retaining Ring - M2.5	
104	0452 3008N	Tapping Screw - M3x8	
105	0353 0040N	Screw - M3x4	
106	0623 0100E	Spring Pin - 3x10mm	

8.Main Parts 2 (J012/J013/J014)





9.Main Parts 3 (J012/J013/J014)



9.Main Parts 3 (J012/J013/J014)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J007 5439	Harness:Safety Switch:Rear	1
2	J007 5223	PCB:DIB:Tos/Pie	1
3	J008 1034	Bracket:Drawer:Machine Or Copier	1
4	J007 5426	Harness	1
5	J007 5471	Harness:Main:Motor	1
6	J007 3502	DC Motor:Carriage:25.9W	1
7	J007 5621	Fan:Mm60:15mm:37V	1
8	J012 5480	Harness - Inlet	1
9	J007 3525	Timing Belt:524ST55-6.0	1
10	J007 3533	Spring:Pressure Roller:30n	1
11	J006 3405	Holder:Pressure Roller:P-P2W	1
12	J006 3406	Spring Plate:Holder:Pressure Roller	1
13	J007 3535	Pressure Roller:Press Fit	1
14	J007 3528	Shaft:Pressure Roller	1
15	J012 1083	Cover:Power Supply Cord:NA	1
16	J001 1015	Gear:Idler:Dial	1
17	J001 1014	Gear:Drive:Dial	1
18	J006 2992	Spring:Roller:Leading Edge	4
19	J007 2700	Pressure Plate:Roller:Leading Edge:Ass'y	1
20	J007 2701	Pressure Plate:Roller: Leading Edge:Right:Ass'y	1
21	GW02 0020	Photointerruptor:LG248NL1	1
22	J007 3016	Spring Clutch:Feed	1
23	J007 1017	Bracket:Dial:Tos-P1:Ass'y	1
24	J007 5476	Harness:Pdet2:Connecting	1
25	J007 3539	Bracket:Holder:Pressure Roller	1
26	J007 5472	Harness:Trailing Edge:Connecting	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	1403 1384	Registration Sensor:No.2	
103	0451 4020N	Tapping Screw:4x20	
104	0805 0088	Retaining Ring - M6	
105	0454 3006Q	Tapping Screw - M3x6	
106	0950 4006N	Screw - M4x6	
107	0452 3008N	Tapping Screw - M3x8	
108	1105 0516	Clamp	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
J012 0031	Paper Feed:Cassette:Ass'y	11 - *
J012 0071	Scanner Unit - LT	9 - *
J012 0072	Scanner Unit - A/B	9 - *
J012 0150	Cover:Front:Tos-C1:Ass'y	5 - 1
J012 0153	Cover:Ink Cartridge:Tos-C1:Ass'y	3 - 3
J012 0154	Cover:Original:Tos-C1:Ass'y	3 - 9
J012 0156	Originalpressure Plate	7 - 3
J012 0156	Originalpressure Plate	3 - 10
J012 0157	Front Cover - NA	5 - 1
J012 0161	Ink Cartridge Cover - NA	3 - 3
J012 0494	Exit Tray Unit	11 - 1
J012 0507	ARDFInterfaceharness	9 - 4
J012 0511	Main Control Board - Exp	9 - 2
J012 0680	Duplex Unit	13 - *
J012 1071	Rear Fan Filter	5 - 7
J012 1083	Cover:Power Supply Cord:NA	19 - 15
J012 1100	Fan Motor Bracket- Right Front	3 - 13
J012 1102	Right Fan Filter	3 - 6
J012 1501	Cover:Rear:Tos-C1	5 - 10
J012 1502	Cover:Left:Tos-C1	3 - 1
J012 1505	Cover:Left Front:Tos-C1	5 - 5
J012 1506	Cover:Right Front:Tos-C1	5 - 6
J012 1508	Plate:Logo:RIC	9 - 1
J012 1509	Cover:Usb:Tos-C1	3 - 5
J012 1510	Cover:Power Supply Cord:Tos-C1	5 - 9
J012 1522	Right Cover - NA	3 - 2
J012 1523	Right Cover - EU	3 - 2
J012 1542	Cover:Tank:Tos-C1	3 - 7
J012 1551	Rear Cover - NA	5 - 10
J012 1552	Left Cover - NA	3 - 1
J012 1555	Left Front Cover - NA	5 - 5
J012 1556	Right Front Cover - NA	5 - 6
J012 1562	Tank Cover - NA	3 - 7
J012 2306	Decal - ARDFJam Removal	7 - 7
J012 2308	Cautiondecal - Copying	9 - 5

Part No.	Description	Page and Index No.
J012 2309	Cautiondecal - Copying EU	9 - 5
J012 2311	Decal - Original Set	7 - 8
J012 2314	Cautiondecal - Copying	9 - 5
J012 2315	Cautiondecal - Copying EU	9 - 5
J012 3003	End Fence:Tos-C1	11 - 2
J012 3004	Side Fence:Left:A4:Tos-C1	11 - 7
J012 3005	Side Fence:Right:A4:Tos-C1	11 - 8
J012 3019	Arm:Cassette	11 - 4
J012 3020	Protection:Cassette	11 - 5
J012 5110	Main Board	17 - 2
J012 5330	Power Supply Unit:Tos-C1:DOM/NA	17 - 17
J012 5331	Power Supply Unit:Tos-C1:EU	17 - 17
J012 5480	Harness - Inlet	19 - 8
J012 5489	Harness:GND	5 - 8
J012 5493	Harness:Ink Cartridge:C1	17 - 18
J012 5494	Harness:Remote Control:C1	17 - 16
J012 5499	Harness:Power Supply Unit	17 - 26
J012 5511	Power Supply Cord - NA	3 - 11
J012 5550	Push Switch:JPS1220-0101FC	3 - 4
J012 6653	IC:Driver:Manual:Tos-C1a:English	3 - 8
J012 9221	Plotter:Unit:NA	3 - *
J012 9222	Plotter:Unit:EU	3 - *

Part No.	Description	Page and Index No.
J001 1008	Rubber Foot	5 - 11
J001 1014	Gear:Drive:Dial	19 - 17
J001 1015	Gear:Idler:Dial	19 - 16
J001 1168	Slider:Transport Roller	15 - 28
J001 2804	Gear:Transport Roller:Pressure	17 - 3
J001 2807	Spring:Feeler:Registration Sensor	17 - 9
J001 2808	Roller:No.1	17 - 4
J001 2810	Bushing:Roller:No.1	17 - 6
J001 2811	Pawl:Guide:Reverse	17 - 10
J001 2813	Spring:Pawl:Guide	17 - 11
J001 2814	Spring:Roller:No.1	17 - 7
J001 2928	Timing Pulley:Exit Roller	17 - 33
J001 2989	Guide:Sheet:Reverse	17 - 5
J001 2991	Pickoff Pawl	17 - 15
J001 3008	Gear:Side Fence	11 - 9
J001 3057	Tension Spring:Base:P1	11 - 3
J001 4604	Tension Spring:Lever	15 - 17
J001 5493	Power Supply Cord:EU	3 - 11
J003 6832	PCB:Duplex Unit	13 - 6
J003 6866	Roller:Opposed:Transport Roller	13 - 2
J003 6867	Spring:Pressure Roller	13 - 3
J003 6877	Lever:Open And Close	13 - 1
J003 6878	Spring:Lever:Open And Close	13 - 4
J006 1148	Spring:Tightener:Drive	15 - 4
J006 2304	Decal:Operate:Dial	5 - 4
J006 2927	Timing Belt:B30S2M88	17 - 32
J006 2992	Spring:Roller:Leading Edge	19 - 18
J006 3405	Holder:Pressure Roller:P-P2W	19 - 11
J006 3406	Spring Plate:Holder:Pressure Roller	19 - 12
J007 0411	Maintenance Unit	17 - 31
J007 1017	Bracket:Dial:Tos-P1:Ass'y	19 - 23
J007 1055	Cover - Power Pack	17 - 19
J007 1062	Shielding Plate:Power Supply Unit	17 - 39
J007 1118	Bracket:Tightener:Ass'y	15 - 6
J007 1122	Timing Belt:227ST1.5-6.0	15 - 8

Part No.	Description	Page and Index No.
J007 1130	Pulley:Tightener:Drive	15 - 5
J007 1161	Timing Pulley - 140T	15 - 29
J007 1544	Cover:Safety Switch:TP	5 - 3
J007 2302	Decal:Reverse:Left	17 - 13
J007 2303	Decal:Reverse:Right	17 - 12
J007 2700	Pressure Plate:Roller:Leading Edge:Ass'y	19 - 19
J007 2701	Pressure Plate:Roller:Leading Edge:Right:Ass'y	19 - 20
J007 2806	Feeler:Registration Sensor	17 - 8
J007 2990	Guide:Reverse	17 - 14
J007 3016	Spring Clutch:Feed	19 - 22
J007 3018	Friction Pad Unit	15 - 25
J007 3025	Base Plate:Exp:Ass'y	11 - 6
J007 3410	Cover:Carriage:Tos	15 - 23
J007 3502	DC Motor:Carriage:25.9W	19 - 6
J007 3504	Lever:Guide Rod:Tos	15 - 22
J007 3510	Holder:Harness:Carriage	17 - 23
J007 3513	Cam:Guide Rod:Right	15 - 15
J007 3514	Cam:Guide Rod:Left	15 - 7
J007 3517	Spring:Guide Rod:1	15 - 1
J007 3518	Spring:Guide Rod:2	15 - 2
J007 3519	Ground Plate:Guide Rod:Left	15 - 3
J007 3520	Sheet:Encoder:Tos	15 - 24
J007 3524	Cam:Guide Rod:Right Front	15 - 19
J007 3525	Timing Belt:524ST55-6.0	19 - 9
J007 3528	Shaft:Pressure Roller	19 - 14
J007 3533	Spring:Pressure Roller:30n	19 - 10
J007 3534	Spring:Lever:3N	15 - 20
J007 3535	Pressure Roller:Press Fit	19 - 13
J007 3539	Bracket:Holder:Pressure Roller	19 - 25
J007 3540	Plate Spring - Guide Rod	15 - 21
J007 4060	Bracket:Actuator:Valve	15 - 13
J007 4061	Lever:Actuator:Valve	15 - 16
J007 4062	Guide Plate:Dc Solenoid	15 - 12
J007 4200	Holder - Left	17 - 1
J007 4696	Positioning Plate:Cartridge:Tos	17 - 21

Part No.	Description	Page and Index No.
J007 4900	Exit Roller:Ass'y	17 - 36
J007 4902	Cover - Exit Roller	17 - 25
J007 5223	PCB:DIB:Tos/Pie	19 - 2
J007 5291	PCB:CCB:Tos	17 - 37
J007 5360	Power Pack	17 - 20
J007 5426	Harness	19 - 4
J007 5432	Harness:Motor:Tos	17 - 24
J007 5434	Harness:HVP:Tos	17 - 30
J007 5435	Harness:Sensor:Rear:Tos	17 - 29
J007 5437	Harness:CCB:Tos	17 - 27
J007 5439	Harness:Safety Switch:Rear	19 - 1
J007 5440	Harness:Safety Switch:Front:Tos	5 - 2
J007 5446	Harness:Sensor:Front:Tos	17 - 28
J007 5465	Harness:Used Develper:Base	17 - 22
J007 5470	Harness:Main:Seconddary:Motor	15 - 10
J007 5471	Harness:Main:Motor	19 - 5
J007 5472	Harness:Trailing Edge:Connecting	19 - 26
J007 5476	Harness:Pdet2:Connecting	17 - 40
J007 5476	Harness:Pdet2:Connecting	19 - 24
J007 5591	Core:FFC:HRB	17 - 38
J007 5621	Fan:Mm60:15mm:37V	19 - 7
J007 5621	Fan:Mm60:15mm:37V	3 - 14
J007 5655	PCB:Senc:Tos/Pie	15 - 11
J007 6857	Guide Plate:Open And Close:A4	13 - 5
J008 1034	Bracket:Drawer:Machine Or Copier	19 - 3
J013 0071	Scanner Unit - LT	9 - *
J013 0072	Scanner Unit - A/B	9 - *
J013 0087	ADF Unit	7 - *
J013 0511	Main Control Board - Exp	9 - 2
J013 0527	NCU - 115V	9 - 3
J013 0547	NCU - 230V	9 - 3
J013 1508	Plate - Logo RIC	7 - 11
J013 1522	Right Cover - NA	3 - 2
J013 1523	Right Cover - EU	3 - 2
J013 6654	CD-ROM:Driver:Manual:Tos-C1b:English	3 - 8

Part No.	Description	Page and Index No.
J013 8700	Friction Pad- ARDF	7 - 2
J013 8701	Originalpickup Roller	7 - 1
J013 8703	Original Tray	7 - 6
J013 8704	Righthinge- ARDF	7 - 5
J013 8705	Lefthinge- ARDF	7 - 4
J013 8721	ARDFCover	7 - 9
J013 8722	Extra Tray	7 - 10
J013 9221	Plotter:Unit:NA	3 - *
J013 9222	Plotter:Unit:EU	3 - *
J014 0071	Scanner Unit - LT	9 - *
J014 0072	Scanner Unit - A/B	9 - *
J014 0501	Network Interface Board	3 - 12
J014 1522	Right Cover - NA	3 - 2
J014 1523	Right Cover - EU	3 - 2
J014 5110	Main Board	17 - 2
J014 9221	Plotter:Unit:NA	3 - *
J014 9222	Plotter:Unit:EU	3 - *
J015 5205	DC Motor 37V 25.9W	15 - 9

Part No.	Description	Page and Index No.
AA08 2101	Bushing - 6x10x6	17 - 34
AW02 0150	Photointerruptor:Flat:7mm	15 - 26
AX11 0125	DC Solenoid:Valve	15 - 14
GW01 0008	Photo Refiection Sensor:SG113-RC80	15 - 18
GW02 0020	Photointerruptor:LG248NL1	15 - 27
GW02 0020	Photointerruptor:LG248NL1	19 - 21

Part No.	Description	Page and Index No.
0353 0040N	Screw - M3x4	15 - 105
0450 4025N	Tapping Screw:4x25	3 - 102
0451 3006N	Tapping Screw - 3x6	15 - 101
0451 3006N	Tapping Screw - 3x6	5 - 101
0451 3006N	Tapping Screw - 3x6	17 - 101
0451 3006N	Tapping Screw - 3x6	19 - 101
0451 3006N	Tapping Screw - 3x6	9 - 101
0451 3008N	Tapping Screw - M3x8	17 - 104
0451 4020N	Tapping Screw:4x20	19 - 103
0452 3008N	Tapping Screw - M3x8	15 - 104
0452 3008N	Tapping Screw - M3x8	5 - 103
0452 3008N	Tapping Screw - M3x8	17 - 103
0452 3008N	Tapping Screw - M3x8	19 - 107
0452 3010N	Binding Self-Tapping Screw:3x10	3 - 101
0452 3010N	Binding Self-Tapping Screw:3x10	5 - 102
0454 3006Q	Tapping Screw - M3x6	5 - 104
0454 3006Q	Tapping Screw - M3x6	19 - 105
0623 0100E	Spring Pin - 3x10mm	15 - 106
0720 0025E	Retaining Ring - M2.5	15 - 103
0805 0088	Retaining Ring - M6	19 - 104
0950 4006N	Screw - M4x6	19 - 106
0951 3005N	Screw:Polished Round:M3x5	15 - 102
1105 0508	Harness Clamp - LWS-0711	17 - 102
1105 0516	Clamp	19 - 108
1403 1384	Registration Sensor:No.2	19 - 102

