

Iris (A258)

PARTS CATALOG

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

Iris	(A258)
DF64	(A663)
PS380/390	(A832/A833)
ST10	(A555)
ST32	(A834)
CS160	(A849)
SPU4	(A846)
Platen Cover Type 100	(A749)
Holder Type D	(A702)

Iris (A258)

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.


INDEX to PARTS CATALOG

LOCATION OF UNIT.....	2	18.TRANSFER BELT CLEANING 2 (A258)	44
1.EXTERIOR 1 (A258).....	10	19.TRANSFER BELT UNIT (A258)	46
2.EXTERIOR 2 (A258).....	12	20.DRAWER UNIT 1 (A258).....	48
3.OPERATION PANEL (A258)	14	21.DRAWER UNIT 2 (A258).....	50
4.BY-PASS FEED SECTION 1 (A258).....	16	22.DRUM UNIT (A258).....	52
5.BY-PASS FEED SECTION 2 (A258).....	18	23.DRUM CLEANING (A258).....	54
6.PAPER TRAY SECTION (A258)	20	24.PAPER TRANSFER UNIT (A258)	56
7.PAPER FEED SECTION 1 (A258)	22	25.FUSING UNIT 1 (A258)	58
8.PAPER FEED SECTION 2 (A258)	24	26.FUSING UNIT 2 (A258)	60
9.OPTICS SECTION 1 (A258).....	26	27.FUSING UNIT 3 (A258)	62
10.OPTICS SECTION 2 (A258).....	28	28.FUSING UNIT 4 (A258)	64
11.OPTICS SECTION 3 (A258).....	30	29.PAPER EXIT SECTION (A258).....	66
12.OPTICS SECTION 4 (A258).....	32	30.DRIVE SECTION 1 (A258)	68
13.LD UNIT (A258)	34	31.DRIVE SECTION 2 (A258)	70
14.PAPER REGISTRATION (A258).....	36	32.DRIVE SECTION 3 (A258)	72
15.DEVELOPMENT UNIT 1 (A258)	38	33.DRIVE SECTION 4 (A258)	74
16.DEVELOPMENT UNIT 2 (A258)	40	34.ELECTRICAL SECTION 1 (A258).....	76
17.TRANSFER BELT CLEANING 1 (A258)	42	35.ELECTRICAL SECTION 2 (A258).....	78

36.ELECTRICAL SECTION 3 (A258)	80
37.ELECTRICAL SECTION 4 (A258)	82
38.FRAME SECTION 1 (A258)	84
39.FRAME SECTION 2 (A258)	86
40.TRANSPORT UNIT (A258)	88
41.MAIN CONTROL BOARD (A258)	90
42.I/O CONTROL BOARD (A258).....	96
43.IPU BOARD (A258)	100
44.DECAL AND DOCUMENT (A258)	106
45.SPECIAL TOOLS (A258)	108
PARTS INDEX	111


LOCATION OF UNIT

1.EXTERIOR 1 (A258)




See Page 11

2.EXTERIOR 2 (A258)




See Page 13

3.OPERATION PANEL (A258)




See Page 15

4.BY-PASS FEED SECTION 1 (A258)




See Page 17

5.BY-PASS FEED SECTION 2 (A258)



See Page 19


6.PAPER TRAY SECTION (A258)



See Page 21


LOCATION OF UNIT

7.PAPER FEED SECTION 1 (A258)




See Page 23

8.PAPER FEED SECTION 2 (A258)




See Page 25

9.OPTICS SECTION 1 (A258)




See Page 27

10.OPTICS SECTION 2 (A258)




See Page 29

11.OPTICS SECTION 3 (A258)



See Page 31


12.OPTICS SECTION 4 (A258)



See Page 33


LOCATION OF UNIT

13.LD UNIT (A258)




See Page 35

14.PAPER REGISTRATION (A258)




See Page 37

15.DEVELOPMENT UNIT 1 (A258)




See Page 39

16.DEVELOPMENT UNIT 2 (A258)




See Page 41

17.TRANSFER BELT CLEANING 1 (A258)



See Page 43


18.TRANSFER BELT CLEANING 2 (A258)



See Page 45


LOCATION OF UNIT

19.TRANSFER BELT UNIT (A258)




See Page 47

20.DRAWER UNIT 1 (A258)




See Page 49

21.DRAWER UNIT 2 (A258)




See Page 51

22.DRUM UNIT (A258)




See Page 53

23.DRUM CLEANING (A258)



See Page 55


24.PAPER TRANSFER UNIT (A258)



See Page 57


LOCATION OF UNIT

25.FUSING UNIT 1 (A258)




See Page 59

26.FUSING UNIT 2 (A258)




See Page 61

27.FUSING UNIT 3 (A258)




See Page 63

28.FUSING UNIT 4 (A258)




See Page 65

29.PAPER EXIT SECTION (A258)



See Page 67


30.DRIVE SECTION 1 (A258)



See Page 69


LOCATION OF UNIT

31.DRIVE SECTION 2 (A258)




See Page 71

32.DRIVE SECTION 3 (A258)




See Page 73

33.DRIVE SECTION 4 (A258)




See Page 75

34.ELECTRICAL SECTION 1 (A258)




See Page 77

35.ELECTRICAL SECTION 2 (A258)



See Page 79


36.ELECTRICAL SECTION 3 (A258)



See Page 81


LOCATION OF UNIT

37.ELECTRICAL SECTION 4 (A258)




See Page 83

38.FRAME SECTION 1 (A258)




See Page 85

39.FRAME SECTION 2 (A258)




See Page 87

40.TRANSPORT UNIT (A258)



See Page 89

1.EXTERIOR 1 (A258)




1.EXTERIOR 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 1345	Drawer Inner Cover	1
2	A259 1348	Decal - Toner Supply	1
3	A259 1526	Decal - Paper Size Indication	1
4	A259 3442	Konb Screw	1
5	A259 1347	Duct Seal	1
6	A259 1350	Transfer Inner Cover	1
7	A259 1340	Transport Inner Cover	1
8	AG07 1010	Magnet Catch	1
9	A259 1330	Right Inner Cover	1
10	A166 1363	Hinge Pin	2
11	A259 1258	Door Stopper	1
12	A166 1351	Magnet Catch Plate	2
13	A259 1257	Door Duct	1
14	A153 1357	Operating Instruction Holder	1
15	A259 1520	Decal - Front Operation	1
16	A258 6800	Front Cover Ass'y (RIC)	1
16	A258 6803	Front Cover Ass'y (SVN/LAN)	1
16	A258 6804	Front Cover Ass'y (INF)	1
16	A258 6806	Front Cover Ass'y (NRG)	1
17	A259 1525	Decal - Emblem Color (RIC)	1
17	A217 7905	Support Cover (INF)	1
18	A258 6822	Model Name Plate - NSA CS506	1
18	A258 6823	Model Name Plate - REX CS806	1
18	A258 6821	Model Name Plate - GES CS206	1
18	A258 6824	Model Name Plate - SVN SDC306	1
18	A258 6825	Model Name Plate - LAN 5706	1
19	A259 1349	Decal - Toner Cartridge Position	1
20	A259 1267	Duct Seal	1
21	A259 1268	Pull Out Seal	1
22	A259 1346	Inner Cover Seal - Small	1
23	A166 1376	Color Decal (RIC)	1
24	A259 1531	Decal - Precaution	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4006H	Tapping Screw - M4x6	
103	0450 4008H	Tapping Screw - M4x8	

2.EXTERIOR 2 (A258)




2.EXTERIOR 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A258 1451	Operation Panel Ass'y - LT	1
1	A258 1452	Operation Panel Ass'y - A4	1
2	AA14 3219	Stepped Screw	2
3	A259 1510	Cover - SP	1
4	A259 1275	Left Cover	1
5	A259 1591	Copy Tray Ass'y	1
6	AF04 3077	Copy Tray Guide	1
7	A259 1320	Left Louver Cover	1
8	A259 1680	Scanner Filter	1
9	A259 1270	Left Upper Cover	1
10	A166 1837	Decal - Caution	1
11	A259 1838	Left Scale - LT	1
11	A259 1837	Left Scale - A4	1
12	AA14 3454	Stepped Screw - M3	2
13	A259 1283	Front Right Cover	1
14	A134 1922	Rear Scale	1
15	A259 1295	Rear Upper Cover	1
16	A259 1302	Rear Left Cover	1
17	A259 1303	Rear Connector Cover	1
18	A259 1310	Rear Right Cover	1
19	A259 1315	Rear Lower Cover	1
20	A259 1280	Right Upper Cover	1
21	A259 1290	Right Rear Cover	1
22	AG07 1010	Magnet Catch	1
23	A259 1285	Right Middle Cover	1
24	A259 1312	Duct Seal - Rear Right Cover	1
25	A259 1317	Duct Seal - Lower Cover	1
26	A259 1305	Duct Seal - Exhaust Length	2
27	A259 1306	Duct Seal - Exhaust Side	2
28	A259 1524	Decal - Main Switch 230V	1
29	AA00 0542	Decal - Laser Class 1	1
30	AA14 3219	Stepped Screw	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006H	Tapping Screw - M4x6	
102	0451 3006B	Tapping Screw - M3x6	
103	0450 4008H	Tapping Screw - M4x8	

3.OPERATION PANEL (A258)




3.OPERATION PANEL (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A258 1451	Operation Panel Ass'y - LT	1
*	A258 1452	Operation Panel Ass'y - A4	1
1	A258 1460	Operation Panel Case - LT	1
1	A258 1500	Operation Panel Case - A4	1
2	A232 1502	Key Top - 10 Key	1
3	A232 1503	Key Top - Start	1
4	A232 1504	Key Top - Clear	1
5	A232 1508	Key Top - Switch	1
6	A258 1467	Sheet - Behind (LT)	1
6	A258 1501	Sheet - Behind (A4)	1
7	A258 1468	Sheet - Main Switch (LT)	1
7	A258 1502	Sheet - Main Switch (A4)	1
8	A258 1469	LCD Sheet (LT)	1
8	A258 1503	LCD Sheet (A4)	1
9	A258 1471	Cover Behind	1
10	A258 1473	Key Top - Center	1
11	A258 1474	Key Top - Interrupt	1
12	A258 1475	Key Top - Counter	1
13	A258 1476	Key Top - Standby	1
14	A258 1477	Key Top - Program	1
15	A258 1478	Key Top - Clear Mode	1
16	A258 1480	Operation Panel Board (LT)	1
16	A258 1490	Operation Panel Board (A4)	1
17	A153 6409	Decal - Keytop Cover (GES)	1
17	C225 2866	Decal - Keytop Cover (REX)	1
17	C225 2867	Decal - Keytop Cover (NSA)	1
18	A259 1510	Cover - SP	1
19	A258 1481	Grounding Wire	1
20	A258 1482	Ferrite Core	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0802 5273	Tapping Screw - M3x10	
102	0451 3006B	Tapping Screw - M3x6	

4.BY-PASS FEED SECTION 1 (A258)




4.BY-PASS FEED SECTION 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 2810	By-pass Feed Table Ass'y	1
2	5215 2621	Snap Ring - M6	1
3	A259 2970	Front Side Fence	1
4	A259 2975	Rear Side Fence	1
5	G020 2707	Conductor Plate	1
6	A259 2980	Friction Pad	1
7	A259 2950	By-pass Feed Table	1
8	A259 2955	Paper Guide - By-pass Feed Table	1
9	A259 5410	Paper Size Detection Board	1
10	A134 2705	Magnet Catch Plate	1
11	G011 3305	Gear - 16T	1
12	A259 2960	By-pass Feed Table Cover	1
13	A260 5492	Sensor Harness - Vertical Guide	1
14	A259 2628	Band	1
15	A259 2554	Switch Bracket	1
16	A259 2550	Guide Plate - Vertical Transport	1
17	AF02 2107	Transport Driven Roller	1
18	AA08 0228	Bushing - M4	2
19	AA06 3322	Compression Spring	2
20	AG07 1010	Magnet Catch	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 4008B	Binding Self Tapping Screw - M4x8	
102	1204 2497	Micro Switch	
103	0451 3012B	Tapping Screw With Washer - M3x12	
104	0451 3006B	Tapping Screw - M3x6	
105	0453 4008B	Tapping Bind Screw - M4x8	

5.BY-PASS FEED SECTION 2 (A258)




5.BY-PASS FEED SECTION 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 2825	By-pass Feed Unit	1
2	5447 2681	Snap Ring	3
3	AF03 1025	Feed Roller	1
4	A259 2860	Guide Plate - Paper Feed	1
5	AA06 0766	Pick-up Spring	1
6	A259 2865	Pick-up Arm	1
7	AB01 1343	Idle Gear - 23Z	1
8	AF03 0362	Pick-up Roller	1
9	A134 2662	Grounding Plate	1
10	A259 2880	Middle Guide Plate	1
11	AW02 0075	Photointerrupter	1
12	A259 2885	Paper End Feeler	1
13	A259 2870	Grounding Plate	1
14	A259 2850	Solenoid Guide Plate	1
15	AA06 0767	By-pass Feed Spring	1
16	A259 2854	By-pass Feed Solenoid	1
17	A259 2895	By-pass Feed Harness	1
18	A166 2849	Drive Support Plate	1
19	AX20 0101	Magnetic Clutch - 2.5kgf 35Z	1
20	AA08 3010	Clutch Roller - 6x14x10	1
21	A259 2872	Grounding Plate	1
22	5053 0447	Bushing - 6mm	3
23	AB01 1346	Gear - 27Z	1
24	AW50 0012	Push Switch	1
25	A259 2626	Connecting Guide	1
26	A134 2663	Separation Guide	1
27	AB01 1345	Gear - 20Z	1
28	A166 2783	Separation Shaft	1
29	AB01 1344	Gear - 16Z	1
30	A134 2668	Separation Driven Shaft	1
31	AA08 0037	Bushing - 6mm	1
32	A134 2674	Torque Limiter - 400fg	1
33	AF03 2025	Separation Roller	1
34	AA06 3499	Pressure Spring	1
35	AA14 0602	Feed Shaft	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A259 2875	Reverse Roller Guide	1
37	A259 2877	Reverse Roller guide - Exit	1
101	0720 0040E	Retaining Ring - M4	
102	0450 4012B	Tapping Screw - M4x12	
103	0451 3006B	Tapping Screw - M3x6	
104	1105 0310	Harness Clamp - LWS-1S	
105	0451 4008B	Philips Tapping Screw - M4x8	
106	0622 0100E	Spring Pin - 2x10mm	

6.PAPER TRAY SECTION (A258)




6.PAPER TRAY SECTION (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 2520	Paper Tray Ass'y	1
2	A232 2986	Screw - M4X8	4
3	A232 2979	Front Side Fence	1
4	A232 2977	Bottom Plate	1
5	AF01 3014	Bottom Plate Pad	1
6	AF01 7020	End Fence	1
7	AA00 3002	Decal - Add Paper	1
8	A232 2988	Handle - Paper Tray	1
9	AA14 3762	Tapping Screw - M3x10	2
10	A232 2975	Bottom Lift Plate	1
11	A232 2987	Roller - Paper Tray	2
12	A232 2972	Bottom Lift Shaft	1
13	A232 2976	Grounding Plate - Paper Tray	1
14	A232 2983	Rear Side Fence	1
15	A235 2979	Feeler - Paper Height Sensor	1
16	A232 2999	Right Spacer	2
17	A232 2997	Right Stopper - Paper Tray	2
18	A259 3314	Screw Driver	1
19	A259 2632	Tray Left Cover	1
20	A259 2633	Tray Right Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0353 0060B	Philips Pan Head Screw - M3x6	

7.PAPER FEED SECTION 1 (A258)




7.PAPER FEED SECTION 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 2555	Front Bracket - Paper Feed	1
2	A232 2785	Vertical Guide	1
3	5887 4176	Screw	1
4	A259 2557	Lower Guide Plate - Paper Feed	1
5	A232 2995	Front Positioning Guide	1
6	A259 2604	Rail Plate	1
7	A259 2600	Right Rail Ass'y	1
8	A259 2570	Registration Guide	1
9	AB01 4037	Gear - 24Z	1
10	AX21 0062	Magnetic Clutch - 0.44n	1
11	AA04 3276	Timing Belt - S3M225	1
12	AB03 0565	Timing Pulley - 20T	1
13	A259 2630	Drive Bracket - Paper Feed	1
14	AB01 4038	Gear - 22Z	1
15	A259 2584	Transport Roller Guide	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	1105 0292	Wire Saddle	
103	0451 3006B	Tapping Screw - M3x6	
104	0805 3480	Bushing - 6mm	
105	1105 0199	Clamp	
106	1106 0458	Bushing - 9.9mm	

8.PAPER FEED SECTION 2 (A258)




8.PAPER FEED SECTION 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF03 0035	Pick-up Roller	1
2	A232 2763	Pick-up Arm	1
3	AB01 1188	Gear - 21Z	1
4	AA06 0691	Tension Spring	1
5	5447 2681	Snap Ring	2
6	AF03 1035	Feed Roller	1
7	AB01 1189	Gear - 18Z	1
8	AA08 2070	Bushing - 8x16x7	1
9	A232 2760	Housing - Paper Feed Unit	1
10	A232 2765	Front Grounding Plate	1
11	A232 2783	Torque Limitter	1
12	A232 2777	Shaft - Paper Separation	1
13	A232 2762	Paper End Feeler	1
14	A232 2782	Rear Feed Mylar	1
15	A232 2776	Release Lever	1
16	5206 2686	Snap Ring	2
17	AB01 0107	Gear - 23Z	1
18	A232 2770	Stay - Paper Separation	1
19	AB01 0106	Gear - 24Z	1
20	AA14 0656	Shaft - Gear	1
21	A232 2774	Pressure Lever	1
22	A232 2775	Link Lever	1
23	AA06 0692	Tension Spring	1
24	AF03 2035	Separation Roller	1
25	AA06 0693	Pressure Spring	3
26	AA08 2072	Bushing - M6	3
27	A232 2764	Rear Grounding Plate	1
28	AA14 0655	Shaft - Paper Feed	1
29	AA08 3014	One-way Clutch	1
30	A232 5428	Harness - Paper Feed Unit	1
31	AW02 0056	Photointerruptor - EE-SX4235A-P1	2
32	AF02 0404	Transport Roller	1
33	A232 2780	Stay - Paper Feed	1
34	A232 2781	Sensor Bracket	1
35	AW02 0096	Photointerruptor	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A232 2750	Paper Feed Unit Ass'y	1
37	A232 2766	Feed Mylar	1
101	0451 3008B	Tapping Screw - M3x8	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	
104	0805 3480	Bushing - 6mm	
105	0805 0089	Retaining Ring - M4	
106	1105 0283	Clamp	

9.OPTICS SECTION 1 (A258)




9.OPTICS SECTION 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 1836	Exposure Glass	1
2	A259 1832	Right Stay	1
3	A259 1985	Scanner Stand	1
4	A134 1926	Exposure Glass Stopper	4
5	A259 1981	Scanner Hinge Ass'y	2
6	A259 1702	Front Right Seal	2
7	A259 1701	Front Middle Seal	1
8	A259 1700	Front Left Seal	1
9	A259 1834	Left Scale Bracket	1
10	A166 5974	Scanner Release Rod	1
11	A259 1697	Wire Cover	1
12	5215 1924	Cushion	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	1105 0310	Harness Clamp - LWS-1S	

10.OPTICS SECTION 2 (A258)




10.OPTICS SECTION 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AW01 0055	Original Sensor H=71.4	1
2	A259 5239	SBU Harness	1
3	A259 1805	CCD Board	1
4	A259 1854	Inner Cover - CCD Drive Board	1
5	A259 1738	Scanner Left Stay	1
6	A259 5320	Scanner Drive Board	1
7	AW02 0022	Photointerruptor	1
8	A259 1718	Platen Cover Bracket	1
9	A259 5230	Scanner DC Harness	1
10	A259 5231	Scanner Rear Harness	1
11	A259 5237	Exposuer Lamp Relay Harness	1
12	AW03 0030	Fiber Cable - 400	1
13	A259 5235	Scanner Control Harness	1
14	A259 5273	IPU Harness - Data	1
15	A259 5137	Scanner IPU-B Board	1
16	A259 5234	Scanner Front Harness	1
17	A259 5236	Scanner AC Harness	1
18	AZ23 0079	Lamp Regulator (120V)	1
18	AZ23 0088	Lamp Regulator (230V)	1
19	A259 1739	Connector Bracket	1
20	A259 1733	Scanner Middle Duct	1
21	A259 1864	IPU Board Bracket	1
22	A259 1880	Original Sensor Bracket	1
23	A250 1761	Original Sensor - H=2-66	1
24	A259 1882	Bracket Cover - IPU	1
25	A259 5140	IDU Board	1
26	A259 1885	Grounding Plate	2
27	A259 5242	Original Sensor Harness	1
28	AW01 0053	Original Sensor - H=62	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 3010B	Tapping Screw - M3x10	
103	1105 0199	Clamp	
104	1105 0291	Harness Clamp - LWS-3S	
105	0314 0120B	Philips Pan Head Screw - M4x12	
106	1102 6418	Connector - PA1002	
107	1105 0229	Clamp	
108	0453 3006	Tapping Screw - M3x6	

11.OPTICS SECTION 3 (A258)




11.OPTICS SECTION 3 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 1790	2nd Carriage Ass'y	1
2	A134 1791	Spring Plate - 2nd Mirror	4
3	A259 1801	2nd Mirror Ass'y	1
4	A259 1800	Harness Guide	1
5	A259 1802	3rd Mirror Ass'y	1
6	A259 1791	2nd Carriage	1
7	A259 1771	1st Carriage Ass'y	1
8	AX52 0036	Exposuer Lamp - 65V 128W	1
9	A166 1736	Spring Plate	2
10	A259 1787	1st Mirror Ass'y	1
11	A259 1784	Spring Plate	2
12	A259 1786	Wire Clamp	2
13	A134 1771	Front Terminal	1
14	A134 5370	Relay Harness - Exposure Lamp	1
15	AW11 0020	Thermostat - 140°C DC75V 3A	1
16	A259 5238	Exposure Lamp Harness	1
17	A134 1773	Rear Terminal	1
18	A259 1726	Left Pulley Ass'y	2
19	A259 1765	Timing Belt - S2M 220	1
20	A259 1917	Motor Spring - 6N	1
21	A259 1910	Scanner Motor Bracket	1
22	A134 1724	Cushion - Stepper Motor	1
23	A259 1761	Scanner Motor - DC24V 11.02W	1
24	A259 5240	Grounding Wire	1
25	A259 1745	Fly Wheel	1
26	A259 1754	Carriage Drive Wire	2
27	A259 1753	Rear Wire Pulley	1
28	A232 3566	Ball Bearing - 8x16x5	2
29	A259 1751	Drive Shaft	1
30	A259 1752	Front Wire Pulley	1
31	A259 1730	Right Pulley Ass'y	2
32	A259 1913	Scanner Motor Tightner	1
33	A259 1916	Belt Pulley	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	1105 0283	Clamp	
103	0434 0060B	Pan Head Self-tapping Screw - M4x6	
104	0314 0100B	Philips Pan Head Screw - M4x10	
105	0575 0050E	Hexagon Headless Set Screw - M5x5	
106	0720 0060B	Retaining Ring - M6	
107	0720 0040E	Retaining Ring - M4	
108	0720 0060E	Retaining Ring - M6	
109	0951 3006B	Philips Screw With Flat Washer - M3X6	

12.OPTICS SECTION 4 (A258)




12.OPTICS SECTION 4 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 1866	IPU Board Stay - Front	1
2	A259 1871	Front Spring Plate	10
3	A259 1696	Stay Holder Bracket	1
4	AA06 0221	Gripper Solenoid Spring	2
5	A259 1755	Front Bracket - Tension Wire	1
6	A259 1870	IPU Board Stay - Left	1
7	A259 1676	Fan Guide Bracket	1
8	A259 1679	Lower Flow Seal	1
9	A259 1678	Left Flow Seal	1
10	AX65 0028	Fan Motor - DC5.8W	1
11	AW02 0022	Photointerruptor	1
12	AX40 0122	Anticondensation Heater - 120V 9W	1
12	AX40 0123	Anticondensation Heater - 230V 10W	1
13	A259 1677	Harness Guide	1
14	A259 1692	Front Rail - 2	1
15	A259 1688	Front Rail - 1	1
16	A259 1711	Rear Rail - 2	1
17	A259 1708	Rear Rail - 1	1
18	A259 1736	Scanner Rear Stay	1
19	A259 1851	Rear Scanner Duct	1
20	AX64 0101	Fan Motor - DC24V	1
21	A259 1737	Scanner Right Stay	1
22	A259 1756	Rear Bracket - Tension Wire	1
23	A259 1714	Rear Stay Bracket	1
24	A259 1869	IPU Board Stay - Rear	1
25	A259 1852	Duct Fan Seal	1
26	A259 1886	Grounding Plate	1
27	AA13 2184	Motor Cushion	4
28	AA16 1067	Cushion - Motor	4
29	A079 3626	Stepped Screw - Swing Cleaning	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	1105 0199	Clamp	
103	0314 0120B	Philips Pan Head Screw - M4x12	
104	0313 0050B	Philips Pan Head Screw - M3x5	
105	1105 0291	Harness Clamp - LWS-3S	
106	0450 4035B	Philips Tapping Screw - M4x35	

13.LD UNIT (A258)




13.LD UNIT (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 2050	Optical Housing Unit	1
2	G020 1918	Decal - Laser Diode (230V)	1
3	G020 1917	Decal - LD	1
4	A259 2128	Imaging Unit Cover	1
5	AA15 2411	Cover Seal	1
6	A259 5271	Sync Detector Harness	1
7	A259 5259	Sync Detector Board	2
8	AA15 2361	Sync Detector Seal	2
9	A259 2101	Mirror Plate	2
10	A166 2081	Mirror Ass'y	1
11	A166 2076	Front Lens Holder	1
12	A166 2078	Lens - BLT	1
13	A166 2077	Rear Lens Holder	1
14	A259 5280	Polygon Motor	1
15	A259 5282	Polygon Motor Drive Board	1
16	A259 5272	Polygon Scanner Harness	1
17	AA15 2410	Scanner Seal	2
18	A259 2081	Cylindrical Lens Holder	1
19	AC02 0074	Cylindrical Lens	1
20	A259 5270	LD Control Harness	1
21	A259 2115	Laser Diode Unit	1
22	A259 2066	Positioning Pin	1
23	AA15 2409	Glass Seal	1
24	AA15 2362	Laser Unit Seal	1
25	A259 2076	Shield Glass Guide	1
26	A166 2062	Shielding Glass	1
27	A259 5283	Polygon Motor Harness	1
28	A259 1058	Front Side Support Plate	1
29	A259 1059	Scanner Holder	2
30	A259 2321	Frame Stopper	1
31	A259 1045	Grounding Plate	2
32	A259 1046	Insulating Sheet	2
33	A259 2061	Insulating Sheet	1
34	A259 2131	Ferrite Core Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060B	Philips Pan Head Screw - M3x6	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	1105 0292	Wire Saddle	
104	1105 0310	Harness Clamp - LWS-1S	

14.PAPER REGISTRATION (A258)




14.PAPER REGISTRATION (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2021	Bushing - 8x12x10mm	4
2	A259 2621	Registration Roller Knob	1
3	AA06 3324	Compression Spring	2
4	AA08 0037	Bushing - 6 Mm	4
5	AB03 0600	Timing Pulley - 20Z S3M	1
6	G020 2783	Registration Roller Knob	1
7	A259 2560	Upper Registration Roller	1
8	A259 2562	Registration Driven Roller	1
9	AW01 0048	Photo Sensor - GP2A28N1	1
10	A259 2577	Registration Sensor Holder	1
11	A259 5570	Registration Sensor Harness	1
12	A259 2573	Guide Plate - Upper Registration	1
13	G012 1531	Magnet	2
14	AA06 3323	Middle Spring	2
15	AF02 0463	Transport Driven Roller	1
16	A259 2582	Registration Guide	1
17	A259 2581	Registration Guide - Leading	1
18	A259 6105	Support Stay	1
19	AF02 0421	Transport Drive Roller	1
20	A259 2578	Registration Guide - Release	1
21	5887 4176	Screw	2
22	AX40 0126	Heater - 100V 13W	1
22	AX40 0127	Heater - 120V 13W	1
22	AX40 0128	Heater - 230V 13W	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0451 3006B	Tapping Screw - M3x6	
103	0720 0040E	Retaining Ring - M4	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	1105 0199	Clamp	
106	0632 0120	Parallel Pin - M2x12	

15.DEVELOPMENT UNIT 1 (A258)



15.DEVELOPMENT UNIT 1 (A258)




Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 3229	Development Unit Holder	8
2	A259 3020	Development Unit	4
3	A259 3234	Gear - 12Z/30Z	4
4	A259 3232	Gear - 54Z	4
5	A259 3236	Toner Cartridge Spring	4
6	A259 3235	Toner Cartridge Stopper	1
7	A259 3433	Screw - M4x8	1
8	A259 3432	Development Knob	1
9	A259 3420	Front Holder Ass'y	1
10	A259 3426	Rear Holder Ass'y	1
11	A259 3434	Coupling Support Plate	1
12	G029 1980	Decal - LD	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0720 0030B	Retaining Ring - M3	
103	0451 3008B	Tapping Screw - M3x8	

16.DEVELOPMENT UNIT 2 (A258)




16.DEVELOPMENT UNIT 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 3020	Development Unit	1
2	A259 3161	Ball Bearing - 8x18.3	1
3	A259 3130	Left Screw	1
4	A259 3128	Right Screw	1
5	A259 3141	Development Cover Shutter	1
6	A259 3142	Shutter Plate	1
7	A259 3169	Toner Supply Seal	1
8	A259 3143	Development Cover	1
9	A259 3166	Side Fence Seal	2
10	A259 3165	Rear Seal	1
11	A259 3164	Doctor Blade Seal	1
12	A259 3147	Bearing Holder	2
13	A259 3158	Gear - 27Z	1
14	A259 3174	Rear Side Fence	1
15	A259 3156	Gear - 27Z	1
16	A259 3160	Gear - 16Z	1
17	A259 3154	Gear - 18Z	1
18	A259 3163	Spacer - 4.5x6mm	1
19	A259 3152	Gear - 18Z	1
20	A259 3172	Front Side Fence	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3008B	Tapping Screw - M3x8	
102	0720 0060B	Retaining Ring - M6	
103	0805 3507	Bushing - 6mm	

17.TRANSFER BELT CLEANING 1 (A258)




17.TRANSFER BELT CLEANING 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A259 6003	Transfer Belt Cleaning Unit	1
1	A259 6714	Lubricant Bar Cover	1
2	A259 6715	Cleaning Brush Roller	1
3	A259 6745	Lubricant Bar	1
4	A259 6759	Lubricant Pressure Spring	2
5	A259 6711	Lubricant Bar Holder	1
6	A259 6754	Bushing - 6 6mm	6
7	G011 1058	Snap Ring	9
8	AB01 4130	Gear - 17Z	2
9	AB01 4131	Idler Gear - 17Z	1
10	A259 6726	Position Shaft	1
11	AB01 4129	Gear - 20Z	1
12	A259 6302	Cleaning Belt Stopper	2
13	A259 6318	Toner Catch Pan	1
14	A259 6765	Timing Belt - S2M 180	1
15	AB03 0474	Pulley - 24T	1
16	A259 6748	Stopper Shaft	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	

18.TRANSFER BELT CLEANING 2 (A258)




18.TRANSFER BELT CLEANING 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 6741	Cleaning Blade	1
2	A259 6708	Cleaning Blade Holder	1
3	A259 6735	Blade Position Shaft	2
4	A259 6761	Cam Shaft Spring	1
5	A259 6727	Cam Shaft	1
6	A259 6728	Release Cam	3
7	A259 6416	Stopper Cam Shaft	2
8	A259 6415	Cam Bushing	2
9	A259 6750	Grounding Plate	1
10	AB03 0474	Pulley - 24T	1
11	A259 6755	Bushing - 6 12mm	1
12	A259 6758	Blade Spring - 2.6n	1
13	A259 6736	Entrance Seal Collar	2
14	A259 6719	Entrance Seal Holder	1
15	A259 6760	Entrance Seal Spring	1
16	A259 6766	Seal - 4x342x2	1
17	A259 6390	Casing Seal	2
18	A259 6418	Toner Spring	1
19	A259 6419	Toner Stopper	1
20	A259 6724	Entrance Seal Link	1
21	A259 6314	Duct Seal	1
22	A259 6343	Cleaning Unit Joint	1
23	A259 6730	Toner Collection Auger	1
24	A259 6720	Entrance Seal	1
25	A259 6721	Entrance Seal Tape	1
26	AA06 3593	Compression Spring	1
27	A259 6763	Blade Spring 700mn	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0450 3008B	Tapping Screw - M3x8	

19. TRANSFER BELT UNIT (A258)




19.TRANSFER BELT UNIT (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 6002	Transfer Belt Unit	1
2	A259 6050	Transfer Belt	1
3	A259 6130	Grounding Roller Bushing	1
4	A259 6075	Grounding Roller	1
5	A259 6070	Bias Roller	1
6	A259 6129	Ball Bearing	2
7	A259 6085	Release Cam Bracket	1
8	A259 6055	Belt Drive Roller	1
9	A259 6098	Front Collar	1
10	5206 2686	Snap Ring	1
11	AA14 3402	Screw - Scale	2
12	A259 6089	Release Lever	1
13	A259 6087	Release Cam	2
14	A259 6088	Release Cam Shaft	1
15	A259 6099	Rear Collar	1
16	A259 1103	Driven Joint	1
17	A259 6121	Compression Spring	2
18	A259 6128	Tension Roller Bushing	2
19	A259 6065	Belt Pressure Roller	1
20	A259 6060	Transfer Belt Roller	1
21	A259 6093	Upper Insulating Sheet	1
22	A259 6092	Support Plate	1
23	A259 6076	Compression Spring	2
24	A259 6141	Belt Holder	2
25	A259 6133	Antistatic Brush Holder	1
26	AA12 0079	Antistatic Brush	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0805 3511	Bushing 8mm	
104	0451 3010B	Tapping Screw - M3x10	
105	0451 3006B	Tapping Screw - M3x6	

20.DRAWER UNIT 1 (A258)






20.DRAWER UNIT 1 (A258)



Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 2462	Front Supporter - Drum Shaft	1
2	A259 6104	Drum Stay	1
3	AA06 3329	Compression Spring	1
4	A259 3302	Bias Receptacle	1
5	A259 2447	Charge Corona Cover	1
6	A259 5056	Power Pack Ass'y - B	1
7	A259 2241	Corona Wire Cleaner	1
8	A008 2087	Corona Cleaner Pad	2
9	A259 2443	Grid Pad	1
10	AD00 4097	Charge Corona Unit	1
11	A259 2457	Duct Cover Charge Corona	1
12	AD02 2361	Front End Block	1
13	A259 2452	Front Grid Stay	1
14	AD02 2363	Front End Block Cover	1
15	AD02 0082	Charge Corona Grid	1
16	AD02 2364	Rear End Block Cover	1
17	AA06 0048	Spring - Charge Wire	1
18	AD02 0081	Charge Corona Wire	1
19	AD02 4025	Corona Wire Terminal	1
20	AD02 2362	Rear End Block	1
21	A006 2122	Cleaner Stopper	1
22	AA01 2092	Dust Filter	1
23	AX64 0100	Fan Motor - DC 24V	1
24	A259 2482	Front Duct - Drawer Unit	1
25	A259 2484	Left Duct Seal - Charge Corona	1
26	A259 2483	Duct Seal - Charge Corona	1
27	A259 5476	Drawer Unit Front Harness	1
28	A259 3296	Bias Terminal - Development	1
29	A259 6101	Drum Stay	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006B	Tapping Screw - 4x6	
102	0971 3006A	Philips Polycarbonate Screw - M3x6	
103	0451 3008B	Tapping Screw - M3x8	
104	0452 3006B	Tapping Screw - M3x6	
105	0354 0080B	Screw - M4X8	
106	0450 4035B	Philips Tapping Screw - M4x35	
107	1105 0199	Clamp	

21.DRAWER UNIT 2 (A258)




21.DRAWER UNIT 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 3418	Lower Right Seal	1
2	A259 5562	Drawer Unit Middle Harness	1
3	A259 3315	Photo Reflection Sensor	1
4	A259 5563	Cartridge Sensor Harness	1
5	A259 3444	Turn Stopper	1
6	AW02 0075	Photointerrupter	1
7	A259 3311	Toner End Sensor Bracket	1
8	A259 3312	Toner End Sensor	1
9	A259 5565	Toner End Sensor Harness	1
10	A259 3428	Toner Catch Pan	1
11	A259 2475	ID Sensor Cover	1
12	A259 5566	ID Sensor Harness	1
13	AW01 0081	ID Sensor	1
14	A259 2473	Density Sensor Bracket	1
15	A259 3438	Drum Drive Holder	1
16	A259 3431	Seal - Toner Catch Pan	2
17	A259 2491	Magnet Seal - Side	2
18	A259 2490	Magnet Seal - Center	1
19	A259 3456	Magnet	1
20	A259 3417	Middle Stay Seal	1
21	A259 3355	Screw	1
22	A259 3363	Toner Supply Gear	1
23	A259 3350	Bushing	1
24	A259 2392	Pull Out Stay	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0451 3006B	Tapping Screw - M3x6	
103	0453 3006B	Tapping Screw - M3x6	
104	1105 0229	Clamp	
105	1105 0199	Clamp	
106	1105 0292	Wire Saddle	
107	0451 4006B	Tapping Screw - 4x6	
108	0313 0060B	Philips Pan Head Screw - M3x6	

22.DRUM UNIT (A258)




22.DRUM UNIT (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AW33 0006	Drum Potential Sensor	1
2	A166 2316	Rear Seal - Main Corona	1
3	A259 2304	Frame Cover	1
4	A259 2303	Upper Frame	1
5	A259 2314	Left Shield - Charge Corona	1
6	A259 5431	Quenching Lamp	1
7	AA14 3480	Screw - M3	1
8	A259 2307	Lower Frame	1
9	A259 2308	Potential Sensor Bracket	1
10	A259 9510	OPC Drum	1
11	A259 2309	Potential Sensor Seal	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0711 0030B	Hexagon Nut - M3	
102	0451 3008B	Tapping Screw - M3x8	

23.DRUM CLEANING (A258)




23.DRUM CLEANING (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 3501	Drum Cleaning Unit	1
2	AD04 1058	Cleaning Blade	1
3	A259 3576	Cleaning Blade Holder	1
4	A259 3589	Cleaning Seal	1
5	A259 3594	Cleaning Side Seal	2
6	A259 3598	Rear Seal	1
7	A259 3562	Lubricant Bar Case	1
8	A259 3599	Front Seal	1
9	A259 3564	Seal Plate	1
10	A259 3565	Lubricant Bar	1
11	AA06 0732	Blade Spring	1
12	A259 3552	Cleaning Casing	1
13	A259 3597	Front Seal - Cleaning Unit	1
14	AB01 4105	Gear - 18Z	1
15	G011 1058	Snap Ring	2
16	AB01 4106	Gear - 26Z	1
17	AD04 7016	Cleaning Entrance Seal	1
18	A166 3591	Entrance Seal	1
19	A259 3591	Toner Outlet Shield	1
20	A259 3582	Toner Outlet Cap	1
21	A259 3571	Toner Transport Screw	1
22	A259 3596	Rear Seal - Cleaning Unit	1
23	AD04 2036	Cleaning Brush Roller	1
24	A259 3557	Rear Holder - Brush Roller	1
25	A259 3586	Drive Joint	1
26	A259 3581	Toner Stopper	1
27	AA06 3325	Spring - Toner Stopper	1
28	A166 3594	Cleaning Case Seal	1
29	A259 3522	Discharge Corona Casing	1
30	AD02 4025	Corona Wire Terminal	1
31	5442 2108	Corona Wire Spring	1
32	A259 3526	Discharge Corona Cover	2
33	AD02 0083	Discharge Corona Wire	1
34	A259 3595	Entrance Seal	2
35	AA08 0248	Bushing - 6mm	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AA06 3603	Compression Spring	2
101	0353 0040B	Screw - M3X4	
102	0451 3006B	Tapping Screw - M3x6	

24.PAPER TRANSFER UNIT (A258)




24.PAPER TRANSFER UNIT (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 6230	Separation Corona	1
2	A259 6234	Guide Plate	1
3	A259 6233	Spring Pin	1
4	A259 6232	Separation Corona Spring	1
5	A259 6231	Separation Corona Wire	1
6	A259 6235	Separation Corona Casing	1
7	AA14 3480	Screw - M3	1
8	A259 6240	Positioning Plate	1
9	A259 6260	Paper Transfer Unit	1
10	A259 6224	Toner Catch Pan	1
11	A259 6220	Transfer Roller Shaft	1
12	A259 6219	Bushing - Transfer Roller	2
13	A259 6221	Roller	1
14	AA06 3353	Pressure Spring	2
15	A259 6246	Guide Plate - Transfer Roller	1
16	A259 6223	Screw - M3x5	1
17	A259 6209	Transfer Unit Stay	1
18	A259 6210	Transfer Roller Bracket	1
19	A259 6228	Blade Spring	1
20	A259 6214	Toner Catchpan Seal	2
21	AA08 0162	Bushing - 8mm	2
22	A259 6255	Lubricant Bar	1
23	A259 6200	Transfer Roller	1
24	A259 6225	Blade	1
25	A259 6216	Blade Holder	1
26	A259 6217	Transfer Roller Gear	1
27	5400 3404	Stepped Screw	1
28	A259 6215	Entrance Seal	1
29	5409 1855	Mounting Pin	1
30	A259 6218	Idler Gear - Transfer Roller	1
31	A259 6239	Screw - M3X4	1
32	A096 3863	Spacer - 4x6x1	1
33	A259 6247	Grounding Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0720 0040B	Retaining Ring - M4	
104	0720 0060B	Retaining Ring - M6	

25.FUSING UNIT 1 (A258)






25.FUSING UNIT 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 4003	Paper Exit Unit	1
2	AA06 6300	Feeler Spring	1
3	A259 4116	Paper Exit Sensor Feeler	1
4	A259 4062	Exit Guide	1
5	AB01 3976	Gear - 15Z	1
6	5840 1632	Stepped Screw	1
7	AG07 0009	Magnetic Catch	1
8	A259 4123	Exit Roller Holder	4
9	AF04 0564	Exit Driven Roller	4
10	AF02 0453	Lower Exit Roller	1
11	G011 1058	Snap Ring	1
12	AA03 6007	Oil Tank Cap	1
13	AA03 1011	Oil Tank	1
14	A259 4117	Front Left Cover	1
15	A259 4121	Fusing Cover Knob	1
16	AG05 0087	Fusing Knob	1
17	A259 4140	Fusing Cover Ass'y	1
18	A259 4130	Fusing Unit Stopper	1
19	5209 5320	Oil End Sensor	1
20	A259 5496	Oil End Sensor Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0720 0040B	Retaining Ring - M4	
103	0807 2089	Washer - 10mm	
104	0450 3006B	Tapping Screw - M3x6	
105	0805 3480	Bushing - 6mm	
106	0451 4008B	Philips Tapping Screw - M4x8	

26.FUSING UNIT 2 (A258)




26.FUSING UNIT 2 (A258)



Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 4106	Oil Supply Bracket	1
2	AA18 0057	Oil Supply Tube - 5.5mm	1
3	AA06 0778	Tension Spring	2
4	A259 4119	Blade Bracket	1
5	AE04 1002	Hot Roller Blade	1
6	AE04 0025	Oil Supply Roller	1
7	AE04 0026	Oil Supply Sub Roller	1
8	A259 4118	Spring Anchor	2
9	AA06 3586	Compression Spring	2
10	AE03 1031	Bushing - 4mm	4
11	A259 4080	Oil Supply Pad	1
12	A259 4083	Spring Plate	1
13	A259 4126	Oil Tube Holder	1
14	A259 4127	Lock Lever	1
15	AA06 6310	Lock Spring	1
16	A259 4128	Stepped Screw	1
17	A259 4129	Lock Lever Knob	1
18	A259 4059	Roller Holder - Oil Supply	1
19	A259 4111	Actuator Ass'y	1
20	AA06 6301	Actuator Spring	1
21	AA18 0035	Sleeve - Oil Pump	1
22	AA18 0053	Tank Tube	1
23	AB01 4117	Gear - 30Z	1
24	H006 3398	Arm Bushing - Master Drive	2
25	A166 4167	Valve - Oil Pump	2
26	5447 4241	Tube Clamp	2
27	5447 2769	Stepped Screw	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0451 3006B	Tapping Screw - M3x6	
103	0451 3008B	Tapping Screw - M3x8	
104	0720 0030E	Retaining Ring - M3	
105	0720 0040E	Retaining Ring - M4	
106	0734 0508D	Bushing - 5x8	

27.FUSING UNIT 3 (A258)




27.FUSING UNIT 3 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G012 4617	Stepped Screw - M3	3
2	A259 4088	Scraper Plate	1
3	A259 4087	Scraper Cushion	2
4	A259 4086	Cleaning Roller Scraper	1
5	A259 4085	Scraper Bracket	1
6	A259 4071	Front Heater Holder	1
7	AB01 4101	Gear - 20Z	1
8	A259 4075	Gear Bracket	1
9	A259 4074	Hot Roller Front Stopper	1
10	AB01 4116	Gear - 20Z	1
11	AE03 1021	Bushing - 6mm	2
12	AA06 3285	Spring	1
13	A259 4078	Front Positioning Plate	1
14	A259 5651	Thermofuse - 184°C	1
15	A259 4050	Upper Side Plate	1
16	AA06 3284	Spring	1
17	A259 4073	Hot Roller Rear Stopper	1
18	A259 4070	Rear Heater Holder	1
19	AB01 4148	Gear - 22Z	1
20	AB01 4102	Gear - 20Z	1
21	A259 4084	Fusing Cleaning Roller	1
22	A259 4079	Upper Left Stay	1
23	AE03 0015	Ball Bearing - 35x47x7	2
24	AB01 4100	Gear - 55Z	1
25	AE01 0025	Hot Roller	1
26	AE03 2017	Bushing - 30x40x14.5	2
27	AB01 4099	Gear - 58Z	1
28	AX43 0048	Fusing Lamp - 120V 800W	1
28	AX43 0049	Fusing Lamp - 230V 800W	1
29	AA14 0696	Stepped Screw - M4x8.8	2
30	A259 4138	Gear Holder	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0450 3006B	Tapping Screw - M3x6	
104	0720 0060E	Retaining Ring - M6	
105	0725 0300E	Retaining Ring C - M30	

28.FUSING UNIT 4 (A258)




28.FUSING UNIT 4 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AE03 0019	Ball Bearing - 7x20x32	2
2	AB01 4107	Gear - 53Z	1
3	AE02 0085	Pressure Roller	1
4	AX44 0114	Fusing Lamp - 120V 400W	1
4	AX44 0115	Fusing Lamp - 230V 400W	1
5	A259 4072	Thermistor Upper Bracket	1
6	A259 5446	Thermistor Ass'y - Fusing	1
7	A259 4096	Front Side Plate	1
8	AW02 0075	Photointerrupter	1
9	A259 4103	Paper Feed Sensor Bracket	1
10	A259 4131	Front Pressure Lever	1
11	A259 4100	Front Heater Holder - Pressure	2
12	A259 4105	Front Lever Holder	1
13	AA06 3562	Pressure Spring	2
14	A259 4124	Spring Spacer	4
15	AB01 3973	Gear - 15Z	1
16	A259 5447	Thermistor Ass'y - Pressure	1
17	A259 4125	Thermistor Lower Bracket	1
18	A259 5574	Exit Relay Harness	1
19	A259 5653	Thermofuse - 167°C	1
20	A259 4064	Base Plate - Fusing Unit	1
21	AE04 2029	Fusing Cleaning Roller (120V)	1
22	AE03 1028	Bushing - 4mm (120V)	2
23	A259 4137	Cleaning Roller Holder (120V)	2
24	A259 4063	Fusing Connector Bracket	1
25	A259 5561	Drawer Harness	1
26	A259 4115	Oil Application Shaft	1
27	A259 4135	Fusing Guide Plate	1
28	A259 4060	Fusing Entrance Upper Guide	1
29	AB01 3975	Gear - 20Z	1
30	A259 4101	Rear Pressure Lever	1
31	A259 4104	Rear Lever Holder	1
32	A259 4089	Rear Side Plate	1
33	A259 4139	Harness Guide Plate	1
34	A259 4141	Harness Guide Plate - Connector	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	A259 4144	Oil Pad - Pressure Roller (230V)	1
36	A259 4055	Blade Bracket (230V)	1
37	A259 4056	Blade Screw (230V)	1
38	AE04 1005	Blade (230V)	1
39	AA06 0777	Spring (230V)	2
101	0450 3006B	Tapping Screw - M3x6	
102	0450 3008B	Tapping Screw - M3x8	
103	0451 3006B	Tapping Screw - M3x6	
104	0720 0060B	Retaining Ring - M6	
105	0314 0300B	Philips Pan Head Screw - M4x30	
106	0585 0500B	Hexagon Bolt - M5x50	
107	0451 3008B	Tapping Screw - M3x8	
108	0720 0040E	Retaining Ring - M4	
109	0451 4006B	Tapping Screw - 4x6	

29.PAPER EXIT SECTION (A258)




29.PAPER EXIT SECTION (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA06 3505	Spring	1
2	AB01 3801	Gear - 30Z	1
3	A259 4477	Exit Drive Bracket	1
4	AB01 3967	Gear - 18Z	1
5	AA08 2058	Bushing - 6x10x9mm	2
6	A259 4467	Exit Cover Bracket	1
7	A166 4492	Exit Cover	1
8	A166 4496	Exit Cover Pawl	1
9	A259 2605	Left Rail Ass'y	1
10	A259 4496	Rear Plate - Copy Tray	1
11	AA12 0084	Discharge Brush	1
12	A259 4493	Front Plate - Copy Tray	1
13	A259 4481	Exit Cover Stay	1
14	AF04 0554	Paper Exit Roller	1
15	A259 4464	Exit Guide Plate	1
16	A166 4017	Driven Roller	2
17	A166 4466	Spring Plate	2
18	AF02 5026	Paper Exit Pawl	1
19	N607 4525	Coil - RITL-9704	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0807 4123	Spacer - 6x13x1	
103	0451 4008B	Philips Tapping Screw - M4x8	
104	0720 0040E	Retaining Ring - M4	
105	0451 3006B	Tapping Screw - M3x6	
106	0450 4008B	Tapping Screw - 4x8	

30.DRIVE SECTION 1 (A258)




30.DRIVE SECTION 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 2251	Drum Shaft Holder	1
2	A259 2271	Charge Corona Receptacle	1
3	AB03 0610	Pulley - 140Z	1
4	A259 1190	Fly Wheel	1
5	AX06 0162	DC Motor - DC 24V 20W	1
6	AA14 3756	Flat Screw	2
7	A259 3270	Toner Supply Motor	1
8	A259 3250	Stepper Motor - DC24V 144W	1
9	AX04 0113	DC Motor - 3W	1
10	A259 3446	Development Holder	1
11	A259 1191	Fly Wheel Balancer	4
12	A259 1185	Idler Shaft	1
13	AB01 4128	Gear - 24Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0450 3012B	Tapping Screw - 3x12	
103	0951 5014W	Philips Screw W/H Flat Washer - M5x14	
104	0450 4010B	Tapping Screw - 4x10	
105	0354 0120B	Screw - M4X12	
106	0720 0040B	Retaining Ring - M4	
107	0453 4006B	Tapping Screw - 4x6	

31.DRIVE SECTION 2 (A258)




31.DRIVE SECTION 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 1124	DC Motor Holder	1
2	A259 1142	Spring Clutch Holder	1
3	A259 1110	Rear Side Plate	1
4	A259 1127	Timing Belt - S2M 540	1
5	5053 0447	Bushing - 6mm	1
6	AB03 0605	Timing Pulley - Brush Roller	1
7	A259 1138	Drive Shaft	1
8	A259 1137	Pulley Holder	1
9	A259 1134	Spring Plate - 6mm	1
10	AA06 3040	Spring	1
11	A259 1132	Rear Joint - Toner Supply	1
12	A259 1133	Front Joint - Toner Supply	1
13	H053 2208	Bushing - M4	2
14	AX20 0159	Magnetic Clutch	2
15	AB03 0606	Timing Pulley - 33Z	2
16	A259 1135	Magnetic Clutch Holder - Drive	2
17	AA14 5815	Drive Roller Shaft	1
18	AB01 4098	Gear - 24Z	1
19	A259 1115	Tightener Ass'y	1
20	AW02 0075	Photointerrupter	1
21	AA06 0768	Tension Spring	1
22	AX21 0066	Magnetic Spring Clutch	1
23	AB03 0603	Idler Pulley - 35Z	2
24	AB03 0276	Tightener Pulley	1
25	AA13 2116	Collar - 8	1
26	AB01 7512	Gear - 23Z/108Z	1
27	A259 1112	Ball Bearing - 2	1
28	AB01 7477	Gear - 46Z/70Z	1
29	A259 1114	Boss	1
30	A259 1146	Cleaning Sensor Joint	1
31	AA06 0823	Tension Spring	1
32	AA06 3584	Compression Spring	1
33	AB01 7479	Gear - 54Z	1
34	A259 1120	Tightener Ass'y	1
35	AB03 0602	Idler Pulley - 70Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A259 1125	Timing Belt - DS2M 560	1
37	A259 1105	Front Side Plate	1
38	A259 1113	Drive Joint	1
39	A259 1109	Ball Bearing	1
40	G011 1058	Snap Ring	3
41	AB01 4095	Gear - 30Z	1
42	AA14 5813	Scraper Drive Shaft	1
43	AA08 0141	Bushing - 5x12x4mm	1
44	A259 1144	Cleaner Sensor Feeler	1
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	
104	0451 4008B	Philips Tapping Screw - M4x8	

32.DRIVE SECTION 3 (A258)




32.DRIVE SECTION 3 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 6505	Toner Collection Pipe	1
2	G011 1058	Snap Ring	7
3	A259 2362	Grounding Plate	1
4	A259 5571	Fusing Motor Harness	1
5	AX06 0164	DC Motor - DC 24V 24W	1
6	A259 1171	Timing Belt - S3M 540	1
7	A259 6250	Vacuum Duct	1
8	A109 3635	Gear - 18Z	2
9	A109 3631	Gear - 18Z/20Z	2
10	AA06 0771	Tension Spring	1
11	A259 1175	Tightner Arm	1
12	A259 1172	Fusing Drive Holder	1
13	AX20 0160	Magnetic Spring Clutch	1
14	AB03 0607	Gear - 34Z	1
15	AA13 2107	Spring Holder	1
16	AA06 3585	Compression Spring	1
17	AB01 4097	Gear - 23Z	1
18	AB01 7488	Gear - 48Z/30Z	1
19	AB03 0276	Tightener Pulley	1
20	AB01 7489	Gear - 83Z/30Z	1
21	A259 2351	Discharge Corona Receptacle	1
22	A259 6590	Bushing	2
23	A109 3651	Gear - 20Z	1
24	H072 2220	Spacer - M6x10	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	1105 0292	Wire Saddle	
103	0720 0060E	Retaining Ring - M6	
104	0805 3497	Bushing - 8x12x3.5mm	
105	0471 3906	Bushing 6mm	
106	0451 4008B	Philips Tapping Screw - M4x8	
107	0452 3008B	Tapping Screw - M3x8	
108	0720 0040B	Retaining Ring - M4	

33.DRIVE SECTION 4 (A258)




33.DRIVE SECTION 4 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A166 5421	Transfer Belt Sensor	1
2	A259 5567	Positioning Sensor Harness	1
3	A259 6119	Positioning Sensor Bracket	1
4	A259 6122	Receptacle	1
5	A259 6120	Receptacle Swivel Spring	1
6	AA14 3708	Stepped Screw - M4	1
7	A259 2620	Positioning Rear Guide	1
8	A259 6288	Receptacle Spring	1
9	A259 6280	Transfer Roller Receptacle	1
10	A259 6293	Screw - M3X4.5	1
11	AW02 0075	Photointerrupter	1
12	A259 6289	Sensor Bracket	1
13	A259 5495	T2 Sensor Harness	1
14	A259 1151	Paper Feed Drive Unit	1
15	AX21 0065	Magnetic Spring Clutch	1
16	5215 2621	Snap Ring - M6	3
17	AX21 0064	Magnetic Clutch - 0.5n	1
18	AX21 0063	Magnetic Clutch - 0.5n	1
19	AX06 0163	DC Motor - DC 24V 15W	1
20	A259 1153	Timing Belt - S3M 789	1
21	A259 1155	Paper Feed Drive Case	1
22	A259 1158	Pulley Flange	1
23	AA06 0770	Tension Spring	1
24	A259 1160	Belt Tightner	1
25	AB01 7487	Gear - 84Z/20Z	1
26	AB01 4096	Gear - 26Z	1
27	AB01 7485	Gear - 21Z/24Z	1
28	AB01 7481	Gear - 24Z/20Z	1
29	AB01 7482	Gear - 24Z/20Z	1
30	AB03 0608	Idler Pulley	3
31	AB01 7486	Gear - 56Z/16Z	1
32	AB01 7480	Gear - 16Z/30Z	1
33	AB01 7484	Gear - 31Z/18Z	1
34	AB01 7483	Gear - 18Z/26Z	1
35	A259 1164	Grounding Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AA14 8556	Stud Screw	1
101	0313 0100B	Philips Pan Head Screw - M3x10	
102	0451 3006B	Tapping Screw - M3x6	
103	0451 4008B	Philips Tapping Screw - M4x8	
104	0450 4010B	Tapping Screw - 4x10	

34.ELECTRICAL SECTION 1 (A258)




34.ELECTRICAL SECTION 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 5843	Development Control Board Bracket	1
2	A259 5300	Development Drive Board	1
3	A259 5839	I/O Control Board Bracket	1
4	A259 5051	I/O Control Board	1
5	A259 5471	Rear Upper Harness	1
6	A259 5473	Rear Lower Harness	1
7	A259 5474	Rear Middle Harness	1
8	AW23 0009	Toner End Sensor	1
9	A007 3751	Large Cap - Toner Collection Tank	1
10	A259 1528	Decal - Toner Recycling	1
11	A259 6655	Toner Collection Bottle	1
12	A259 6660	Small Bottle Cap	1
13	A259 5416	Interface Board - Css/bank	1
14	A259 5493	Exit Switch Harness	1
15	A259 5826	CSS Bracket	1
16	A259 5822	Power Supply Cord Bracket	1
17	A259 5514	DC Power Harness - S/S	1
18	A193 5711	Power Supply Cord (120V)	1
18	A193 5712	Power Supply Cord (230V)	1
19	A259 5510	Relay Harness - TMP/Humidity	1
20	A259 5852	Grounding Plate	1
21	A259 5825	I/O Board Bracket	1
22	A232 7756	Harness - Circuit Breaker	1
23	A258 5523	Grounding Wire	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	1105 0292	Wire Saddle	
103	0451 4008B	Philips Tapping Screw - M4x8	
104	0450 3008B	Tapping Screw - M3x8	
105	1107 0472	Circuit Breaker - W28XQ1A 8A 25V	
106	1102 4052	Optional Connector	
107	0801 0149	Philips Pan Head Screw - M4x6	
108	0451 4006B	Tapping Screw - 4x6	
109	1607 0721	Ferrite Core - TFC-23-11-14	

35.ELECTRICAL SECTION 2 (A258)




35.ELECTRICAL SECTION 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 5837	Power Supply Bracket 1	1
2	A259 3261	Connector Bracket	1
3	AA14 3480	Screw - M3	4
4	A259 5055	Power Pack Ass'y - T2/D	1
5	A259 1089	Rear Cover Support Plate	1
6	A259 5821	Fusing Unit Conector Bracket	1
7	A259 5513	DC Power Harness - Scanner	1
8	AZ23 0086	Power Supply Unit - 250W (120V)	1
8	A259 5329	Power Supply Unit - 250W (230V)	1
9	A259 5468	AC Harness - 120V	1
9	A259 5469	AC Harness - 230V	1
10	A259 5853	Grounding Plate	3
11	A259 4143	Connector Stopper (230V)	1
12	AX65 0027	Fan Motor - DC24V	1
13	A259 5861	Motor Bracket	1
14	A259 5869	Fan motor Seal	1
15	A258 5523	Grounding Wire	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0292	Wire Saddle	
102	0451 3006B	Tapping Screw - M3x6	
103	0451 4008B	Philips Tapping Screw - M4x8	
104	1105 0229	Clamp	
105	1107 0906	Fuse - 4A 125V (120V)	
106	1107 0910	Fuse - 2A 125V (120V)	
107	1107 0919	Fuse - 8A 125V (120V)	
108	1107 0887	Fuse - 250V 15A (120V)	
109	0451 4030B	Philips Tapping Screw - M4x30	
110	1105 0229	Clamp	
111	0954 3008B	Philips Screw - M3x8	

36.ELECTRICAL SECTION 3 (A258)




36.ELECTRICAL SECTION 3 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AZ32 0093	Power Pack - C/G	1
2	A259 5844	Power Pack Bracket	1
3	A259 2366	Discharge Corona Duct	1
4	A259 1084	Rear Duct	1
5	A259 5054	Power Pack Ass'y - T1/PCC	1
6	A259 1086	Rear Duct - Cleaning Belt	1
7	A259 5856	ADF Bracket	1
8	A259 5516	DC Power Harness - ADF	1
9	A259 1049	Joint Duct	1
10	A259 1083	Ozone Filter Case	1
11	A259 1085	Case Cover - Ozone Filter	1
12	A259 1082	Dust Filter	1
13	A259 1081	Ozone Filter	1
14	A259 1074	Fan Bracket	1
15	AX65 0026	Sirocco Fan - DC24V 3350RPM	1
16	AW14 0007	Thermo Sensor - CHS-GSST-RC	1
17	A259 1097	Exhaust Duct	1
18	A259 1048	Corner Fence	1
19	A079 3106	Seal - 3x8x14mm	1
20	A259 1062	Fan Bracket	1
21	AX65 0027	Fan Motor - DC24V	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	1105 0316	Clamp	
103	1105 0292	Wire Saddle	
104	0451 3006B	Tapping Screw - M3x6	
105	1105 0229	Clamp	
106	1102 4052	Optional Connector	
107	0451 4012B	Tapping Screw - 4x12	
108	0451 4030B	Philips Tapping Screw - M4x30	
109	1105 0160	Clamp	
110	0954 3008B	Philips Screw - M3x8	

37.ELECTRICAL SECTION 4 (A258)




37.ELECTRICAL SECTION 4 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX31 0035	Total Counter	1
2	AX31 0037	Total Counter	1
3	A259 1582	Operation Panel Bracket	1
4	A259 1581	Rubber Cushion	4
6	AG07 1010	Magnet Catch	1
7	A259 1335	Main Switch Inner Cover	1
8	A259 9520	NVRAM - Minus Counter	1
9	A259 1262	Right Hinge Bracket	1
10	A259 1259	Stopper Bracket	1
11	A259 5831	Total Counter Bracket	1
12	A258 5087	Main Control Board	1
13	A259 5829	Rocker Switch Bracket	1
14	A259 5830	Release Lever - Safety Switch	1
15	A259 5842	Spring Plate	1
16	A259 5253	LD Main Board	1
17	A259 5511	Grounding Wire	1
18	A259 5274	LD Harness - Data	1
19	A258 5538	Operation Panel Harness	1
20	AW03 0086	Optical Fiber - 1200mm	1
21	AW03 0085	Optical Fiber - 700mm	1
22	A259 5472	Right Side Harness	1
23	A259 5862	Grounding Plate	2
24	A259 1034	Key Counter Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0316	Clamp	
102	1105 0292	Wire Saddle	
103	1105 0310	Harness Clamp - LWS-1S	
104	0451 3006B	Tapping Screw - M3x6	
105	0451 4006Z	Tapping Screw 4x6	
106	0954 3008B	Philips Screw - M3x8	
107	1204 2497	Micro Switch	
108	1204 2468	Switch - AC250/16A	
109	0313 0350W	Philips Pan Head Screw - M3x35	
110	1607 0721	Ferrite Core - TFC-23-11-14	

38.FRAME SECTION 1 (A258)




38.FRAME SECTION 1 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 5854	Grounding Plate	1
2	A259 1073	Fusing Duct Cover	1
3	AX64 0090	Fan Motor - DC24V	1
4	A259 1091	Duct Seal	1
5	A259 1065	Fusing Fan Duct	1
6	A259 1092	Inner Duct Seal	1
7	A259 5841	Power Supply Bracket 2	1
8	A259 1077	Heat Duct Stay	1
9	A259 1068	Left Rail Stay	1
10	A259 3448	Pull Out Slide Rail	2
11	A259 1261	Left Hinge Bracket	1
12	A259 1075	Fusing Rail	1
13	A259 5850	Grounding Plate	1
14	A259 5845	Grounding Plate	1
15	A259 5855	Grounding Plate	1
16	A259 5851	Grounding Plate	1
17	A259 5840	I/O Control Board Bracket	1
18	A259 1078	Fusing Exhaust Duct	1
19	A259 1096	Scanner Fan Seal	1
20	A259 1093	Scanner Fan Bracket	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0453 4006B	Tapping Screw - 4x6	
103	0450 4030B	Tapping Screw - M4x30	

39.FRAME SECTION 2 (A258)




39.FRAME SECTION 2 (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 1054	Rear Grip	1
2	A259 1057	Rear Grip Bracket	1
3	A259 6271	Spring Clutch Feeler	1
4	A259 6272	Transfer Roller Cam Shaft	1
5	A259 6274	Positioning Plate	1
6	A259 6273	Cam	1
7	AX40 0114	Anticondensation Heater - 120V 18W	1
7	AX40 0124	Anticondensation Heater - 230V 18W	1
8	AW50 0012	Push Switch	1
9	A259 5573	Paper Volume Sensor Harness	1
10	AW02 0075	Photointerrupter	2
11	A259 6290	Rail Bracket	1
12	A259 6294	Separation Heater Cover	1
13	AA08 2057	Bushing - 8mm	1
14	AH01 0007	Rubber Foot	2
15	A134 1071	Left Grip Plate	1
16	A259 1087	Grip Bracket	1
17	A259 1055	Control Board Stay	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0960 4010B	Philips Flange Screw - M4x10	
104	0720 0060E	Retaining Ring - M6	
105	0314 0080B	Philips Pan Head Screw - M4x8	

40.TRANSPORT UNIT (A258)



40.TRANSPORT UNIT (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A259 1087	Grip Bracket	1
2	A134 1071	Left Grip Plate	2
3	A259 1056	Grip Bracket - Front Left	1
4	A259 3890	Positioning Plate	1
5	AH01 0007	Rubber Foot	2
6	AG05 1138	Transport Release Grip	1
7	AA08 2070	Bushing - 8x16x7	1
8	A259 3924	Vacuum Guide	2
9	A259 3923	Transport Grip Shaft	1
10	A259 3911	Separation Plate	1
11	A259 3920	Release Plate	1
12	A259 3850	Transport Unit	1
13	AF02 2070	Right Transport Roller	1
14	A259 3870	Transfer Belt Guide	1
15	A259 3880	Spring Plate	2
16	AB01 4103	Gear - 26Z	1
17	G020 4479	Bushing - 6mm	2
18	AA04 0028	Transport Belt	1
19	AF02 2109	Transport Belt Roller	1
20	AX64 0088	Fan Motor - DC24V 0.69W	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0960 4010B	Philips Flange Screw - M4x10	
102	0451 4006Z	Tapping Screw 4x6	
103	0720 0060E	Retaining Ring - M6	
104	0451 4025B	Tapping Screw - M4x25	
105	0451 4008B	Philips Tapping Screw - M4x8	
106	0720 0040B	Retaining Ring - M4	

41.MAIN CONTROL BOARD (A258)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C121	195	---	---	C151	195	C161	187	C171	195	C181	195
---	---	C142	188	C152	195	C162	195	C172	195	---	---
C123	186	C143	188	C153	195	C163	195	---	---	---	---
C124	195	C144	195	---	---	C164	186	---	---	C184	195
C125	195	C145	195	C155	195	C165	195	C175	195	---	---
---	---	C146	156	C156	195	C166	187	---	---	---	---
---	---	C147	192	C157	195	C167	186	---	---	C197	193
---	---	C148	195	C158	188	C168	195	C178	195	C198	195
C129	195	C149	195	C159	195	---	---	---	---	C199	195
C137	192	C150	195	C160	187	C170	195	C180	195	C200	195
										C201	195
										C202	195
										C203	195
										C204	195
										C205	195
										C206	195
										---	---
										---	---
										C209	195
										C210	192

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C211	195	---	---	---	---	C241	195	C251	195	C261	188
C212	195	---	---	C232	195	C242	195	C252	195	C262	188
C213	195	C223	190	C233	192	C243	195	C253	195	C263	195
C214	195	C224	195	C234	195	C244	190	C254	192	C264	195
C215	195	---	---	C235	195	C245	195	C255	195	C265	194
C216	195	C226	190	C236	195	C246	189	C256	194	C266	195
C217	195	C227	195	C237	194	C247	190	C257	195	C267	194
C218	195	---	---	C238	192	C248	189	C258	195	C268	195
C219	195	C229	191	C239	195	C249	195	C259	194	C269	195
---	---	C230	195	C240	195	C250	188	C230	194	C270	195
										C271	194
										C272	195
										C273	195
										C274	195
										C275	194
										C276	194
										C277	194
										C278	194
										C279	194
										C280	194

41.MAIN CONTROL BOARD (A258)

CAPACITOR

SYMBOL NO.	INDEX NO.
C281	194
C282	195
C283	195
C284	194
C285	194
C286	192
C287	194
C288	195
C289	195
C290	195

CONNECTOR

SYMBOL NO.	INDEX NO.
---	---
---	---
C293	194
C294	194
C295	195
C296	194
C900	194
C905	195

SYMBOL NO.	INDEX NO.
CN301	104
CN302	111
CN303	113
CN304	110
CN305	114
CN306	112
CN307	106
---	---
---	---
CN310	109

SYMBOL NO.	INDEX NO.
CN314	117
CN351	116
CN352	105
CN354	108
CN355	107
CN356	115

DIODE

SYMBOL NO.	INDEX NO.
D102	128
D900	131

DA

SYMBOL NO.	INDEX NO.
DA105	127
DA106	127
DA107	127
DA108	127
DA109	127
DA110	127
DA111	127

FIL

SYMBOL NO.	INDEX NO.
FIL124	161
FIL127	157
FIL128	157
FIL129	161
FIL130	159
FIL131	158
FIL133	158
FIL135	160
FIL136	160

IC

SYMBOL NO.	INDEX NO.
IC102	138
IC104	119
IC106	120
---	---
IC115	2
IC116	137
IC117	142
IC118	196
IC119	196
IC120	137

SYMBOL NO.	INDEX NO.
IC121	147
IC122	136
---	---
IC124	134
IC125	144
IC126	145
IC127	139
IC128	140
IC129	143
IC130	146

SYMBOL NO.	INDEX NO.
IC131	139
IC132	143
IC133	139
---	---
IC135	137
IC136	139
IC137	134
IC138	1
IC139	141
IC140	141

SYMBOL NO.	INDEX NO.
IC141	136
IC142	135
IC143	143
IC149	145
IC150	136
IC151	145
IC154	133

JP

SYMBOL NO.	INDEX NO.
JP900	181

LED

SYMBOL NO.	INDEX NO.
LED105	132

OSC

SYMBOL NO.	INDEX NO.
OSC104	148
OSC105	149

Q

SYMBOL NO.	INDEX NO.
Q102	126
Q103	126
Q104	125
Q105	126
Q106	124

41.MAIN CONTROL BOARD (A258)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R114	167	R141	163	R151	168	R161	174	---	---	R181	174	R191	172
---	---	R142	165	R152	167	R162	178	---	---	R182	177	R192	172
R256	174	R143	164	R153	174	R163	175	R173	174	R183	174	R193	172
R257	167	R144	163	R154	175	R164	174	R174	175	R184	175	R194	172
R131	174	R145	163	R155	168	R165	172	R175	174	R185	177	R195	172
R132	169												
		R146	165	R156	172	R166	172	R176	174	R186	175	R196	167
R133	178	R147	162	R157	175	R167	168	R177	175	R187	178	R197	175
R134	178	---	---	R158	174	R168	168	---	---	R188	175	R198	174
R139	167	---	---	R159	172	R169	177	R179	174	R189	177	R199	175
R140	163	R150	177	R160	175	---	---	R180	175	R190	178	R200	175

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R201	175	R211	172	R221	172	R231	167	R241	175	R251	167	R261	168
R202	171	R212	172	R222	172	R232	172	R242	167	R252	168	R262	168
R203	175	R213	167	R223	172	R233	172	R243	168	R253	168	R263	168
R204	175	R214	175	R224	167	R234	167	R244	168	R254	168	R264	168
R205	177	R215	172	R225	172	R235	168	R245	175	R255	168	R265	168
R206	175	R216	175	R226	167	R236	167	R246	168	R256	168	R266	168
R207	167	R217	172	R227	168	R237	167	R247	168	R257	168	R267	178
R208	167	R218	172	R228	172	R238	167	R248	167	R258	168	R268	168
R209	168	R219	172	R229	172	R239	178	R249	167	R259	168	R269	168
R210	172	R220	167	R230	167	R240	168	R250	167	R260	168	R270	168

41.MAIN CONTROL BOARD (A258)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R271	168	R281	168	R291	168	R387	168	R438	168	R451	168	R461	168
R272	168	R282	168	R292	168	R388	168	---	---	R452	167	R462	168
R273	168	R283	168	R293	168	R397	168	---	---	R453	178	---	---
R274	168	---	---	R305	172	R398	168	---	---	R454	178	---	---
R275	168	---	---	R307	177	R407	168	---	---	R455	178	R465	167
R276	168	---	---	R328	175	R416	168	---	---	---	---	---	---
R277	168	R287	178	R332	175	R417	168	R447	184	R457	180	R467	168
R278	168	R288	168	R341	168	R418	168	R448	182	R458	168	R468	172
R279	168	R289	168	R377	168	R427	168	R449	174	R459	167	R469	177
R280	168	R290	168	R379	179	R436	168	R450	178	R460	168	R470	172

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R471	172	R481	178	R491	172	R501	172	R511	168	R521	172	---	---
R472	168	R482	172	R492	178	R502	172	R512	168	R522	168	R532	168
R473	172	R483	172	R493	172	R503	172	R513	172	R523	172	R533	168
R474	172	R484	174	R494	168	R504	170	---	---	R524	172	R534	168
R475	172	R485	166	R495	172	R505	172	R515	168	R525	168	R535	174
R476	172	R486	172	R496	177	R506	174	---	---	R526	172	R536	168
R477	172	R487	172	R497	172	R507	172	R517	172	R527	172	---	---
R478	172	R488	174	R498	172	R508	176	R518	168	R528	172	R538	167
R479	172	R489	172	R499	174	R509	172	R519	172	R529	168	R539	172
R480	172	R490	168	R500	172	R510	172	R520	172	R530	168	R540	175

41.MAIN CONTROL BOARD (A258)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	R551	168	R561	172	R571	168	R581	168	R591	174	---	---
R542	168	---	---	R562	179	R572	179	R582	174	R592	178	---	---
R543	168	R553	168	R563	172	R573	168	R583	168	R593	174	R603	168
R544	178	R554	175	R564	172	R574	183	R584	175	R594	171	R604	168
R545	168	---	---	R565	168	R575	179	R585	178	R595	174	---	---
R546	175	R556	175	R566	172	R576	179	R586	175	R596	171	R606	168
---	---	R557	185	R567	168	R577	179	R587	174	R597	168	R607	168
R548	168	R558	172	R568	183	R578	179	R588	168	R598	168	R608	174
R549	175	R559	185	R569	172	R579	179	R589	168	R599	168	R609	168
R550	168	R560	172	R570	168	R580	179	R590	168	R600	168		

RESISTOR

SYMBOL NO.	INDEX NO.
R611	167
R900	173

RN

SYMBOL NO.	INDEX NO.
---	---
---	---
RN103	152
RN104	154
RN105	154
RN106	155
RN107	150
RN108	150
RN109	150
RN110	153

SYMBOL NO.	INDEX NO.
RN111	152
RN112	154
RN113	154
RN114	153
RN115	152
RN116	154
RN117	154
RN118	150
RN119	150
RN120	153

SYMBOL NO.	INDEX NO.
RN121	152
RN122	153
RN123	152
RN124	150
RN125	150
RN126	150
---	---
---	---
---	---
---	---

SYMBOL NO.	INDEX NO.
RN131	152
RN132	153
RN133	154
RN134	152
RN135	153
RN136	154
RN137	154
RN138	154
RN139	154
RN140	154

SYMBOL NO.	INDEX NO.
RN141	150
RN142	150
RN143	154
RN144	151

TB

SYMBOL NO.	INDEX NO.
TB104	103
TB106	102

TEST POINT

SYMBOL NO.	INDEX NO.
TP101	101
TP102	101
TP107	101
TP130	101
TP131	101
TP134	101
TP137	101
TP138	101
TP141	101
TP142	101

SYMBOL NO.	INDEX NO.
TP143	101
TP144	101
TP145	101
TP148	101
TP153	101
TP154	101
TP155	101
TP156	101
TP157	101
TP158	101

SYMBOL NO.	INDEX NO.
TP160	101
TP162	101
TP165	101
TP167	101
TP168	101
TP170	101
TP172	101
TP173	101
TP174	101
TP176	101

SYMBOL NO.	INDEX NO.
TP178	101
TP182	101
TP185	101
TP186	101
TP187	101
TP900	101

ZD

SYMBOL NO.	INDEX NO.
ZD102	129
ZD103	129
ZD104	129
ZD105	130
ZD106	130

41.MAIN CONTROL BOARD (A258)



Index No.	Part No.	Description	Q'ty Per Assembly
*	A258 5087	Main Control Board	1
1	A259 5112	IC - JSC05SV519AY17	1
2	A700 5106	IC - PI	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1101 0328	Connector Pin Contact	
102	1101 0376	Jumper Board Dic-152-2p	
103	1102 2452	Terminal Block - 3p	
104	1102 5302	Connector - 3P	
105	1102 5718	Optical Fiber Connector	
106	1102 7102	Connector - JC20EF-J68HR1-A1	
107	1102 7835	Connector - B3B	
108	1102 7837	Connector - B5B	
109	1102 7845	Connector - B13B	
110	1102 7846	Connector - B14B	
111	1102 7850	Connector - B18B	
112	1102 7851	Connector - B20B	
113	1102 7852	Connector - B22B	
114	1102 7853	Connector - B24B	
115	1102 7909	Connector - B3B	
116	1102 8005	Connector - 1-178670-1	
117	1102 8038	Connector - B5B	
118	1103 1878	Receptacle - 9067	
119	1104 0589	Dip Socket - 32p	
120	1104 0765	IC Socket	
121	1204 1228	Switch	
122	1204 2373	Key Bord Switch - SKQDPA	
123	1204 2415	Dip Switch - DSS802	
124	1400 0392	Transistor - DTC114EK	
125	1400 0398	Transistor - 2SC2412K	
126	1400 0459	Transistor - DTC143XKA	
127	1402 1142	Diode Array - DAN217	
128	1402 1343	Diode - RB106L-40	
129	1402 1345	Diode - UDZ3.6B	
130	1402 1380	Diode - PTZ 6.2A	
131	1402 1444	Diode - RB051L-40	
132	1403 0829	Diode - SEC1201C	
133	1407 1596	TTLIC - SN74LS14NS	
134	1407 1600	TTLIC - SN74LS244NS	
135	1407 2051	TTL - IC - SN74LS00NS	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1407 2187	TTLIC - SN74LS07NS	
137	1407 2378	TTL - SN74ALS245ANS	
138	1407 2588	TTLIC - SN74ALS04BNS	
139	1407 3008	TTL - SN74ALS244CNS	
140	1407 3017	TTL - SN74ALS11ANS	
141	1407 3952	IC - ANALOG SW- 4053	
142	1407 4114	IC - SN751177	
143	1407 4323	TTL - TD74ABT244F	
144	1407 4743	Flash Memory - LH28F016SUT-70	
145	1407 4746	TTLIC - TD74ABT245AF	
146	1407 4959	IC - MC68334GCFC20	
147	1408 0575	IC - M51957BFP	
148	1503 0563	Oscillator-9.83Mhz 040	
149	1503 0841	Oscillator - 38.4KHZ	
150	1601 7801	Resistor Array - 10K Ω $\pm$ 5% 1/16W	
151	1601 7805	Resistor Array - 33 Ω $\pm$ 5% 1/16W	
152	1601 7808	Resistor - 4.7k Ω $\pm$ 5% 1/16W	
153	1601 7809	Resistor Array - 2.2k Ω 1/16W	
154	1601 7822	Resistor Array - 22 Ω $\pm$ 5% 1/16W	
155	1601 7851	Resistor - 47K Ω $\pm$ 5% 1/16W	
156	1605 0943	Capacitor - 0.33 μ F+80 -20% 25V	
157	1607 0732	Noise Filter - AEF321825-470	
158	1607 0815	BLM41P600SPB	
159	1607 0973	Inductor - BLM11A121SPB	
160	1607 0978	Inductor - BLM21P300SPB	
161	1607 1061	Filter - BLM11P300SPB	
162	1630 1121	Resistor - 120 Ω $\pm$ 5% 1/8W	
163	1630 3154	Resistor - 150K Ω $\pm$ 5% 1/10W	
164	1630 3472	Resistor - 4.7K Ω 1/10W $\pm$ 5%	
165	1630 3752	Resistor - 7.5K Ω $\pm$ 5% 1/10W	
166	1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	
167	1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	
168	1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	
169	1630 4105	Resistor - 1.0M Ω $\pm$ 5% 1/16W	

Index No.	Part No.	Description	Q'ty Per Assembly
170	1630 4106	Resistor -10m Ω $\pm$ 5% 1/16W	
171	1630 4121	Resistor - 120 Ω $\pm$ 5% 1/16W	
172	1630 4220	Resistor - 22 Ω $\pm$ 5% 1/16W	
173	1630 4221	Resistor - 220 Ω $\pm$ 5% 1/16W	
174	1630 4222	Resistor - 2.2k Ω - $\pm$ 5%	
175	1630 4330	Resistor - 33 Ω $\pm$ 5% 1/8W	
176	1630 4334	Resistor - 330K Ω $\pm$ 5% 1/16W	
177	1630 4471	Resistor - 470 Ω $\pm$ 5% 1/16W	
178	1630 4472	Resistor - 4.7K Ω $\pm$ 5% 1/16W	
179	1630 4473	Resistor - 47k Ω - $\pm$ 5% - 1/16W	
180	1630 4751	Resistor - 50 Ω $\pm$ 5.00% 1/16W	
181	1634 0000	Resistor - 0 Ω - 1/16W	
182	1634 1002	Resistor - 10 Ω $\pm$ 5% 1/16W	
183	1634 1003	Resistor - 100K Ω $\pm$ 1% 1/16W	
184	1634 3921	Resistor - 3.92K Ω $\pm$ 1% 1/1	
185	1634 5231	Resistor - 5.23K Ω $\pm$ 1% 1/16W	
186	1640 2101	Capacitor - 100 μ F $\pm$ 20% 25V	
187	1640 2470	Capacitor - 47 μ F $\pm$ 20% 25V	
188	1660 2101	Capacitor - 100pF - $\pm$ 10% - 50V	
189	1660 2120	Capacitor - 12 pF $\pm$ 5% 50V	
190	1660 2220	Capacitor - 22pF $\pm$ 20% 35V	
191	1660 2470	Capacitor - 47pF $\pm$ 5% 50V	
192	1660 2471	Capacitor - 470pF - $\pm$ 5% - 50V	
193	1660 4102	Capacitor - 1000pF $\pm$ 10% 50V	
194	1660 6103	Capacitor - 10000pF - +80%-20%, 50V	
195	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	
196	1903 0024	IC - 16M 1MX16 60NS G6	

42.I/O CONTROL BOARD (A258)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	---	---	C221	171	C231	173	---	---	C251	174
---	---	---	---	C222	170	C232	173	C242	175	---	---
C203	171	---	---	C223	169	C233	175	C243	175	---	---
---	---	---	---	---	---	---	---	C244	173	C254	175
C205	173	C215	173	C225	170	C235	173	C245	173	C255	175
C206	173	C216	173	C226	170	C236	173	---	---	C256	175
C207	175	C217	173	---	---	C237	174	---	---	C257	175
C208	175	C218	173	C228	171	C238	175	---	---	---	---
---	---	C219	173	C229	173	C239	175	---	---	C259	175
---	---	C220	171	C230	173	---	---	C250	175	C260	175
										C261	175
										C262	175
										C263	174
										C264	173
										C265	173
										C266	175
										C267	175
										C268	175
										C269	175
										C270	173

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C271	172	C281	175	C291	173	C301	173
C272	172	C282	173	C292	173	C302	173
C273	175	C283	175	C293	173	C303	173
C274	175	C284	175	C294	173	C305	173
C275	175	C285	175	C295	173	C309	173
C276	175	C286	175	C296	173	C320	175
C277	175	C287	175	C297	173	C322	175
C278	175	C288	175	C298	173	C323	170
C279	175	C289	173	C299	173	C324	174
C280	175	C290	173	C300	173	C325	175

CONNECTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C339	175	CN201	120	CN211	108
C340	175	CN202	103	CN212	121
C341	175	CN203	115	CN213	119
C342	175	CN204	121	CN214	124
C343	175	CN205	123	CN215	122
C344	175	CN206	125	CN216	102
		CN207	118	CN217	116
		CN208	109	CN218	126
		CN209	111	CN219	107
		CN210	110	CN220	106

42.I/O CONTROL BOARD (A258)

CONNECTOR

SYMBOL NO.	INDEX NO.
CN221	128
---	---
CN223	127
CN224	124
---	---
CN226	113
CN227	123
CN228	105
CN229	104
---	---

SYMBOL NO.	INDEX NO.
CN231	118
CN232	116
CN233	125
CN234	117
CN235	114
CN236	112
CN237	116

DA

SYMBOL NO.	INDEX NO.
DA201	133

DIODE

SYMBOL NO.	INDEX NO.
D201	132
D202	132
D203	132
D204	132

FIL

SYMBOL NO.	INDEX NO.
FIL201	150
FIL202	150
FIL204	150
FIL205	150

IC

SYMBOL NO.	INDEX NO.
---	---
---	---
---	---
IC204	142
IC205	143
IC206	141
---	---
IC208	137
IC209	137
---	---

SYMBOL NO.	INDEX NO.
IC211	137
IC212	140
IC213	139
IC214	1
IC215	137
IC216	141
IC217	137
IC218	144
IC219	141
---	---

SYMBOL NO.	INDEX NO.
IC221	143
IC222	136
IC223	143

OSC

SYMBOL NO.	INDEX NO.
OSC201	145

Q

SYMBOL NO.	INDEX NO.
Q201	131
Q202	138
Q204	130
Q207	131
Q208	129
Q211	138

RESISTOR

SYMBOL NO.	INDEX NO.
--	---
R202	157
R203	156
R204	156
R205	156
R206	151
R207	151
R208	151
R209	151
R210	151

SYMBOL NO.	INDEX NO.
R211	151
R212	151
R213	151
R214	156
R215	156
R216	156
R217	156
R218	156
R219	155
R220	162

SYMBOL NO.	INDEX NO.
R221	162
R222	155
R223	155
R224	156
R225	162
R226	164
R227	164
R228	165
R229	165
R230	165

SYMBOL NO.	INDEX NO.
R231	165
R232	165
R233	165
R234	165
R235	165
R236	161
R237	158
R238	166
R239	156
R240	156

SYMBOL NO.	INDEX NO.
R241	156
R242	167
R243	163
R244	156
R245	156
R246	164
---	---
---	---
R249	164
R250	164

SYMBOL NO.	INDEX NO.
---	---
R252	164
---	---
R254	156
R255	159
---	---
R257	156
R258	156
R259	156
R260	168

42.I/O CONTROL BOARD (A258)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R261	154	R271	156	R281	156	R291	156	R301	153	R311	167	R321	167
R262	154	R272	157	R282	156	R292	155	R302	153	R312	167	R322	156
R263	168	R273	156	R283	160	R293	156	R303	153	R313	167	R323	156
R264	154	R274	156	R284	163	R294	156	R304	153	R314	167	R324	156
R265	154	R275	156	R285	156	R295	156	R305	153	---	---	---	---
R266	146	R276	168	R286	156	R296	167	R306	155	R316	167	R326	164
R267	157	R277	168	---	---	R297	163	R307	155	R317	163	R327	164
R268	152	R278	156	---	---	R298	153	R308	167	R318	156	R328	164
R269	156	---	---	---	---	R299	153	R309	167	R319	164	R329	156
R270	156	R280	156	---	---	R300	153	R310	167	R320	163	R330	156

RESISTOR

SYMBOL NO.	INDEX NO.
R331	156
R332	156
R333	154
R334	154
R335	168
R336	168
---	---
---	---
---	---
---	---

SYMBOL NO.	INDEX NO.
R341	156
R342	156
R343	156
R344	156
R345	163
R346	167
R347	146
R348	156
R349	156
---	---

RN

SYMBOL NO.	INDEX NO.
RN201	147
RN202	147
RN203	147
RN204	147
RN205	147
---	---
---	---
---	---
RN209	147
RN210	147

SYMBOL NO.	INDEX NO.
R211	147
R212	147
R213	147
R214	147
R215	147
R216	148
R217	149
R218	148
R219	149
R220	147

SYMBOL NO.	INDEX NO.
R221	147
R222	147
R223	147
R224	147

TEST POINT

SYMBOL NO.	INDEX NO.
TP213	101
TP232	101
TP233	101
TP239	101
TP240	101
TP241	101
TP242	101
TP243	101
TP244	101
TP247	101

ZD

SYMBOL NO.	INDEX NO.
ZD201	134
ZD202	135
ZD203	135

42.I/O CONTROL BOARD (A258)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A259 5051	I/O Control Board	1
1	A259 5110	IC - I/O-EXPANDER	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1101 0328	Connector Pin Contact	
102	1102 4201	Connector - 2P	
103	1102 4202	Connector - 3P	
104	1102 4205	CT Header- 6p	
105	1102 4207	Connector - 8P	
106	1102 4208	Connector - 9P	
107	1102 5276	Connector - 4P	
108	1102 5301	Connector - 2P	
109	1102 5302	Connector - 3P	
110	1102 5306	Connector - 7P	
111	1102 5525	Connector - 5566-12A	
112	1102 6299	Connector - 6P	
113	1102 6302	Connector - 9P	
114	1102 6313	Connector - 6P	
115	1102 6515	Connector - 34P	
116	1102 7834	Connector - B2B	
117	1102 7835	Connector - B3B	
118	1102 7836	Connector - B4B	
119	1102 7838	Connector - B6B	
120	1102 7840	Connector - B8B	
121	1102 7844	Connector - B12B	
122	1102 7846	Connector - B14B	
123	1102 7849	Connector - B16B	
124	1102 7850	Connector - B18B	
125	1102 7851	Connector - B20B	
126	1102 7852	Connector - B22B	
127	1102 7885	Connector - B2B	
128	1103 1422	Connector - 20P	
129	1400 0663	Transistor - 2SA1037AK	
130	1400 0700	Transistor - DTD133HK	
131	1401 0869	Transistor-array - TD62003F	
132	1402 1058	Diode Array - DA114	
133	1402 1322	Diode Array - DAN202U	
134	1402 1378	Diode - PTZ12A	
135	1402 1380	Diode - PTZ 6.2A	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1407 2055	IC - TD62304F	
137	1407 2187	TTLIC - SN74LS07NS	
138	1407 2231	IC - TD62308AF	
139	1407 2378	TTL - SN74ALS245ANS	
140	1407 3008	TTL - SN74ALS244CNS	
141	1407 3290	IC - TC74HC02AF	
142	1407 4687	IC - TA8083F	
143	1408 0810	IC - BA10358F	
144	1408 1065	Comparator Ba10339f	
145	1503 0837	Oscillator - 21.576MHZ	
146	1600 1625	Resistor - 100 Ω 1/2W $\pm$ 5%	
147	1601 7801	Resistor Array - 10K Ω $\pm$ 5% 1/16W	
148	1601 7808	Resistor - 4.7k Ω $\pm$ 5% 1/16W	
149	1601 7809	Resistor Array - 2.2k Ω 1/16W	
150	1607 0815	BLM41P600SPB	
151	1630 3221	Resistor - 220 Ω $\pm$ 5% 1/10W	
152	1630 3680	Resistor - 68 Ω $\pm$ 5% 1/10W	
153	1630 4100	Resistor - 10 Ω $\pm$ 5% 1/16W	
154	1630 4101	Resistor - 100 Ω $\pm$ 5% 1/16W	
155	1630 4102	Resistor - 1.0K Ω $\pm$ 5% 1/16W	
156	1630 4103	Resistor - 10K Ω $\pm$ 5% 1/16W	
157	1630 4104	Resistor - 100 Ω $\pm$ 5% 1/16W	
158	1630 4105	Resistor - 1.0M Ω $\pm$ 5% 1/16W	
159	1630 4112	Resistor - 1.1K Ω $\pm$ 5.00% 1/16W	
160	1630 4202	Resistor - 2k Ω - $\pm$ 5% -	
161	1630 4221	Resistor - 220 Ω $\pm$ 5% 1/16W	
162	1630 4222	Resistor - 2.2k Ω - $\pm$ 5%	
163	1630 4243	Resistor - 24K Ω $\pm$ 5% 1/16W	
164	1630 4330	Resistor - 33 Ω $\pm$ 5% 1/8W	
165	1630 4470	Resistor - 470 Ω $\pm$ 5% 1/16W	
166	1630 4471	Resistor - 470 Ω $\pm$ 5% 1/16W	
167	1630 4472	Resistor - 4.7K Ω $\pm$ 5% 1/16W	
168	1634 1003	Resistor - 100K Ω $\pm$ 1% 1/16W	

Index No.	Part No.	Description	Q'ty Per Assembly
169	1640 5101	Capacitor - 100 μ F $\pm$ 20% 50V	
170	1642 5330	Capacitor - 33 μ F $\pm$ 20% 50V	
171	1643 5100	Capacitor - 10 μ F $\pm$ 20% 50V	
172	1660 3180	Capacitor - 18pF $\pm$ 5% 50v	
173	1660 4103	Capacitor - 10000pF - $\pm$ 10% - 50V	
174	1660 7104	Capacitor - 100000pF 50V	
175	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	

43.IPU BOARD (A258)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	C11	207	C21	208	C31	205	C41	206	C51	213	C61	213
C2	216	C12	207	C22	213	---	---	C42	213	C52	213	C62	213
C3	216	C13	207	C23	213	---	---	C43	213	C53	211	C63	213
---	---	C14	207	C24	213	---	---	C44	213	C54	213	C64	213
C5	206	C15	207	C25	208	---	---	C45	213	C55	212	C65	213
C6	207	C16	207	C26	213	C36	203	C46	213	C56	212	C66	213
C7	207	C17	207	C27	213	C37	204	---	---	C57	212	---	---
C8	207	C18	213	C28	213	C38	202	C48	157	C58	212	C68	213
C9	207	C19	213	C29	208	C39	202	---	---	C59	212	C69	213
C10	207	C20	213	---	---	C40	202	C50	213	C60	213	C70	204

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C71	204	C81	213	C91	159	C101	159	C111	213	C121	213	C131	213
C72	204	C82	212	C92	159	C102	213	C112	213	C122	213	C132	213
C73	204	C83	212	C93	159	C103	213	C113	213	C123	213	C133	213
C74	204	C84	212	C94	159	C104	213	C114	213	C124	213	C134	213
C75	204	C85	213	C95	213	C105	159	C115	213	C125	213	C135	213
C76	213	C86	213	C96	213	C106	159	C116	213	C126	213	C136	213
C77	213	C87	213	C97	213	C107	159	C117	213	C127	213	C137	213
---	---	C88	---	C98	159	C108	159	C118	213	C128	213	C138	213
---	---	C89	213	C99	159	C109	213	C119	213	---	---	C139	213
C80	213	C90	213	C100	159	C110	213	C120	213	C130	213	C140	213

43.IPU BOARD (A258)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C141	213	C151	213	C161	213	C171	213	C181	213	C191	213	C201	213
C142	213	C152	213	C162	213	C172	213	C182	160	C192	213	---	---
C143	213	C153	213	C163	158	C173	213	C183	213	C193	160	C203	211
C144	213	C154	210	C164	213	C174	213	C184	160	C194	213	C204	213
C145	213	C155	210	C165	213	C175	213	C185	213	C195	213	C205	213
C146	213	---	---	C166	213	C176	213	C186	213	C196	213	C206	213
C147	213	C157	213	C167	213	C177	213	C187	160	C197	160	C207	213
C148	213	C158	213	C168	213	C178	213	C188	213	C198	213	C208	160
C149	213	C159	213	C169	213	C179	213	C189	213	C199	213	C209	213
C150	213	C160	213	C170	213	C180	213	C190	160	C200	213	C210	213

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C211	211	C221	213	C231	213	C241	160	---	---	C261	213	CN401	107
C212	213	C222	213	C232	160	C242	213	C252	213	C262	213	CN402	110
C213	160	C223	213	C233	213	C243	213	C253	202	C263	213	CN403	103
C214	213	C224	211	C234	213	C244	213	C254	213			CN404	111
C215	213	C225	160	C235	160	---	---	C255	213			CN405	104
C216	213	C226	213	C236	213	C246	213	C256	202			CN406	102
C217	213	C227	213	C237	160	C247	213	C257	213			CN407	109
C218	213	C228	160	C238	213	C248	160	---	---			CN408	108
C219	213	C229	213	C239	213	C249	213	---	---			CN409	106
C220	213	C230	213	C240	160	C250	213	C260	213			CN410	113

CONNECTOR

43.IPU BOARD (A258)

CONNECTOR

SYMBOL NO.	INDEX NO.
CN411	112
CN413	105

DA

SYMBOL NO.	INDEX NO.
DA1	118
DA2	118
DA3	118
DA4	118
DA5	118
DA6	118
DA7	119
DA8	119
DA9	119
DA10	119

SYMBOL NO.	INDEX NO.
DA11	119
DA12	119
DA13	119
DA14	119
DA15	119
DA16	119
DA17	118
DA18	118
DA19	118

FIL

SYMBOL NO.	INDEX NO.
FIL1	163
FIL2	163
FIL3	163
FIL4	163
FIL5	163
FIL6	163
FIL7	163
FIL8	163
FIL9	163
FIL10	163

SYMBOL NO.	INDEX NO.
FIL11	163
FIL12	163
FIL20	164
FIL21	163
FIL22	165
FIL23	165
FIL24	166
FIL25	166
FIL26	166
FIL28	162

SYMBOL NO.	INDEX NO.
FIL29	162
FIL30	164
FIL31	164
FIL32	164
FIL33	162
FIL34	162
FIL35	164
FIL36	164
FIL37	162
FIL38	162

FUSE

SYMBOL NO.	INDEX NO.
FU1	114
FU2	115

IC

SYMBOL NO.	INDEX NO.
IC1	129
IC2	127
IC3	132
IC4	132
IC5	132
IC6	215
IC7	139
IC8	139
IC9	139
IC10	4

SYMBOL NO.	INDEX NO.
IC11	2
IC12	3
IC13	5
IC14	138
IC15	138
IC16	1
IC17	125
IC18	6
IC19	135
IC20	135

SYMBOL NO.	INDEX NO.
IC21	144
IC22	144
IC23	144
IC24	134
IC25	134
IC26	143
IC27	143
IC28	143
IC29	141
IC30	141

SYMBOL NO.	INDEX NO.
IC31	136
IC32	124
IC33	124
IC34	133
IC35	133
IC36	133
IC37	141
IC38	214
IC39	137
IC40	124

SYMBOL NO.	INDEX NO.
IC41	125
IC42	123
IC43	123
IC44	122
IC45	140
IC46	131
IC47	130
IC48	130
IC49	130
IC50	217

SYMBOL NO.	INDEX NO.
IC51	217
IC52	217
IC53	217
IC54	128
IC55	218
IC56	128
IC57	7

L

SYMBOL NO.	INDEX NO.
L1	161
L2	161

43.IPU BOARD (A258)

LED

SYMBOL NO.	INDEX NO.
LED1	121
LED2	121
LED3	121
LED4	121
LED5	121
LED6	121

OSC

SYMBOL NO.	INDEX NO.
OSC1	148
OSC2	147

Q

SYMBOL NO.	INDEX NO.
Q1	126
Q2	117
Q3	117
Q4	117
Q5	117
Q6	117
Q7	117
Q8	117
Q9	117

REG

SYMBOL NO.	INDEX NO.
REG1	142
REG3	146
REG4	145

RESISTOR

SYMBOL NO.	INDEX NO.
R1	171
R2	149
R3	182
R4	182
R5	182
R6	168
R7	168
R8	168
R9	168
R10	168

SYMBOL NO.	INDEX NO.
R11	168
R12	175
R13	167
---	---
R15	183
R16	183
R17	183
R18	183
R19	183
R20	176

SYMBOL NO.	INDEX NO.
R21	176
R22	176
R23	176
R24	176
---	---
---	---
---	---
R29	188
R30	188

RESISTOR

SYMBOL NO.	INDEX NO.
R31	188
R32	188
R33	188
R34	188
R35	173
R36	173
R37	173
R38	173
R39	173
R40	173

SYMBOL NO.	INDEX NO.
R41	168
R42	198
R43	200
R44	175
R45	175
R46	183
R47	183
R48	182
R49	182
R50	182

SYMBOL NO.	INDEX NO.
R51	182
R52	182
R53	182
R54	182
R55	182
R56	182
R57	182
R58	182
R59	182
R60	182

SYMBOL NO.	INDEX NO.
R61	182
R62	182
R63	182
R64	182
R65	182
R66	182
R67	183
R68	176
R69	173
R70	173

SYMBOL NO.	INDEX NO.
R71	173
R72	173
R73	173
R74	173
R75	168
R76	168
R77	168
R78	168
R79	168
R80	168

SYMBOL NO.	INDEX NO.
R81	187
R82	187
R83	187
R84	187
R85	187
R86	187
R87	169
R88	169
R89	169
R90	169

SYMBOL NO.	INDEX NO.
R91	169
R92	169
R93	169
R94	169
R95	169
R96	173
R97	168
R98	199
R99	193
R100	195

43.IPU BOARD (A258)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R101	192	R111	183	R121	183	R131	174	R141	184	---	---
R102	180	R112	183	R122	177	R132	174	R142	178	R152	183
R103	169	R113	183	R123	177	R133	169	---	---	R153	173
R104	169	R114	183	R124	177	R134	183	R144	175	R154	189
R105	179	R115	183	R125	170	R135	183	R145	180	R155	189
R106	183	R116	169	R126	170	R136	183	---	---	R156	191
---	---	R117	172	R127	170	R137	194	R147	175	R157	191
R108	183	R118	181	R128	191	R138	196	R148	180	R158	191
R109	197	---	---	R129	191	R139	201	R149	169	R159	183
R110	191	R120	183	R130	191	R140	190	---	---	R160	186
										R161	186
										R162	186
										R163	186
										R164	183
										R165	150
										R166	150
										R167	174
										R168	183

RN

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
RN1	151	RN11	152
RN2	154	RN12	151
RN3	152	RN13	151
RN4	152	RN14	153
RN5	151	RN15	153
RN6	152	RN16	151
RN7	152	RN17	151
RN8	152	RN18	151
RN9	152	RN19	155
RN10	152	RN20	153

SYMBOL NO.	INDEX NO.
RN21	153
RN22	153
RN23	153

SWITCH

SYMBOL NO.	INDEX NO.
SW2	116

TEST POINT

SYMBOL NO.	INDEX NO.
TP16	101
TP22	101

ZD

SYMBOL NO.	INDEX NO.
ZD1	120

43.IPU BOARD (A258)








Index No.	Part No.	Description	Q'ty Per Assembly
*	A259 5137	SCANNER IPU-B	1
1	A259 5101	IC - UPD97211GJ-201-3EB	1
2	A259 5102	IC - TC220C180EF-001	1
3	A259 5103	IC - UPD82141GD-001-LML	1
4	A259 5104	IC - HG73C005FD	1
5	A259 5106	IC - MB87F1462	1
6	A259 5108	IC - JSC05RR519AU15	1
101	1101 0429	Test Pin	
102	1102 4211	CT Header - 12P	
103	1102 4212	CT Header - 15P	
104	1102 5003	Fiber Connector - DC1002 - 2p	
105	1102 6298	Connector - 5P	
106	1102 6579	Receptacle Connector	
107	1102 6600	Connector - 8P	
108	1102 7460	Connector - FH12-50S-0.5SH	
109	1102 7835	Connector - B3B	
110	1102 7845	Connector - B13B	
111	1102 7992	Connector - IL-404-30S-TW	
112	1102 7993	Card Connector - FCN-568P068-G/G-V4	
113	1102 7994	Connector - HIF6A-52PA-1.27DS	
114	1109 0007	IC - MINISMDC100-02	

Index No.	Part No.	Description	Q'ty Per Assembly
115	1109 0009	IC - MINISMDC075-02	
116	1204 2481	Dip Switch - 73D-0601	
117	1400 0398	Transistor - 2SC2412K	
118	1402 0595	Diode-array - DAN202K	
119	1402 1142	Diode Array - DAN217	
120	1402 1206	Zener Diode	
121	1403 0829	Diode - SEC1201C	
122	1407 2127	TTL - IC74F00SJ	
123	1407 2128	TTL - IC74F02SJ	
124	1407 2187	TTLIC - SN74LS07NS	
125	1407 2218	TTLIC - SN74LS06NS	
126	1407 2231	IC - TD62308AF	
127	1407 2463	TTL - IC - SN74ALS08NS	
128	1407 2464	TTL - IC - SN74ALS74ANS	
129	1407 2588	TTLIC - SN74ALS04BNS	
130	1407 2816	TTL - SN74ALS374ANS	
131	1407 3008	TTL - SN74ALS244CNS	
132	1407 3197	IC - SN74ALS240ANS	
133	1407 3381	Cmos - IC - TC74HC4066AF	
134	1407 4023	IC - M62353GP	
135	1407 4935	IC - 74LCX374 SOP	
136	1407 4959	IC - MC68334GCFC20	
137	1407 4963	IC - MBM29F800TA-70pFTN	
138	1407 5037	IC - MSM5412222-25JS	
139	1407 5038	IC - MSM518222-30JS-1	
140	1408 0575	IC - M51957BFP	
141	1408 0595	IC - NJM2904M	
142	1408 1308	Regulator - PQ3RF33	
143	1408 1380	IC - CXA2045Q	
144	1408 1381	IC - CXD2311AR	
145	1408 1383	Regulator - TA7812F	
146	1408 1384	Regulator - TA7805F	
147	1503 0460	Oscillator - 32.768KHZ	
148	1503 0836	Oscillator - 13.5MHZ	
149	1601 5300	Resistor - 10 Ω $\pm$ 5% 2W	

Index No.	Part No.	Description	Q'ty Per Assembly
150	1601 5414	Resistor - 330 Ω $\pm$ 5% 1W	
151	1601 7801	Resistor Array - 10K Ω $\pm$ 5% 1/16W	
152	1601 7805	Resistor Array - 33 Ω $\pm$ 5% 1/16W	
153	1601 7808	Resistor - 4.7k Ω $\pm$ 5% 1/16W	
154	1601 7822	Resistor Array - 22 Ω $\pm$ 5% 1/16W	
155	1601 7839	Resistor Array - 22K $\pm$ 5% 1/16W	
156	1602 0987	Capacitor & Coil - 270pF 100V	
157	1604 2601	Capacitor - 47 μ F $\pm$ 20% 25v	
158	1605 0738	Capacitor - 0.01 μ F25V	
159	1605 0753	Capacitor - 1 μ F+80-20% 25V	
160	1605 0992	Capacitor - 1 μ F $\pm$ 20% 16V	
161	1607 0284	Inductor - BLM31A02PB	
162	1607 0789	Inductor - BLM11A221SPB	
163	1607 0803	Filter - ACF451832-680	
164	1607 1014	EMI Filter - BLM11P600SPB	
165	1607 1055	Filter - MEA8020T10R0	
166	1607 1066	Filter - MEM2012T10R0	
167	1630 2121	Resistor - 120 Ω $\pm$ 5% 1/8W	
168	1630 3101	Resistor - 100 Ω - 1/10W	
169	1630 3103	Resistor - 10K Ω 1/10W $\pm$ 5%	
170	1630 3104	Resistor - 100K Ω 1/10W $\pm$ 5%	
171	1630 3105	Resistor - 1M Ω $\pm$ 5% 1/10W	
172	1630 3106	Resistor - 10M Ω $\pm$ 5% 1/10W	
173	1630 3152	Resistor - 1.5k Ω - 1/10W	
174	1630 3220	Resistor - 22 Ω $\pm$ 5% 1/10W	
175	1630 3222	Resistor - 2.2K Ω 1/10W $\pm$ 5%	
176	1630 3223	Resistor - 22k Ω - 1/10W	
177	1630 3301	Resistor - 300 Ω $\pm$ 5% 1/10W	
178	1630 3330	Resistor - 33 Ω $\pm$ 5% 1/10W	
179	1630 3331	Resistor - 330 Ω $\pm$ 5% 1/10W	
180	1630 3332	Resistor - 3.3K Ω 1/10W $\pm$ 5%	
181	1630 3334	Resistor - 330K Ω $\pm$ 5% 1/10W	
182	1630 3470	Resistor - 47 Ω 1/10W $\pm$ 5%	


Index No.	Part No.	Description	Q'ty Per Assembly
183	1630 3472	Resistor - 4.7K Ω 1/10W $\pm$ 5%	
184	1630 3511	Resistor - 510 Ω $\pm$ 5% 1/10W	
185	1630 3564	Resistor - 560K Ω $\pm$ 5% 1/10W	
186	1630 3680	Resistor - 68 Ω $\pm$ 5% 1/10W	
187	1630 3681	Resistor - 680 Ω $\pm$ 5% 1/10W	
188	1630 3751	Resistor - 750 Ω $\pm$ 5% 1/10W	
189	1630 4330	Resistor - 33 Ω $\pm$ 5% 1/8W	
190	1633 1001	Resistor - 1K Ω $\pm$ 1% 1/10W	
191	1633 1002	Resistor - 10K Ω $\pm$ 1% 1/10W	
192	1633 1201	Resistor - 1.2K Ω $\pm$ 1% 1/10W	
193	1633 1502	Resistor - 15k Ω $\pm$ 1% 1/10W	
194	1633 2001	Resistor - 2K Ω $\pm$ 1% 1/10W	
195	1633 2201	Resistor - 2.2 Ω $\pm$ 1% 1/10W	
196	1633 3901	Resistor - 3.9 Ω $\pm$ 1% 1/10W	
197	1633 3921	Resistor - 3.92k Ω - $\pm$ 1% - 1/10W	
198	1633 4700	Resistor - 470 Ω - $\pm$ 1% - 1/10W	
199	1633 4701	Resistor - 4.7K Ω $\pm$ 1% 1/10W	
200	1633 5600	Resistor - 560 Ω $\pm$ 1% 1/10W	
201	1633 8201	Resistor - 8.2k Ω $\pm$ 1% 1/10W	
202	1640 3101	Capacitor - 100 μ F $\pm$ 20% 35V	
203	1640 5101	Capacitor - 100 μ F $\pm$ 20% 50V	
204	1642 0221	Capacitor - 220 μ F $\pm$ 20% 10V	
205	1642 2470	Capacitor - 47 μ F $\pm$ 20% 25V	
206	1643 0470	Capacitor - 47 μ F $\pm$ 20% 10V	
207	1644 0100	Capacitor - 10 μ F $\pm$ 20% 10V	
208	1644 2330	Capacitor - 33 μ F $\pm$ 20% 25V	
209	1660 1100	Capacitor - 10pF 50V	
210	1660 3220	Capacitor - 122pF $\pm$ 5% 50V	
211	1660 3391	Capacitor - 390 pF $\pm$ 5% 50V	
212	1660 7103	Capacitor - 10000pF 50V	
213	1660 9104	C - 0.1 μ F25V	
214	1902 0039	IC - SRAM 1M X16 70NS G1	
215	1903 1009	IC - DRAM 16M 4MX4 60NS EDO G2	

44.DECAL AND DOCUMENT (A258)

1 	2 	3 	6 
4 			7 
5 			8 

44.DECAL AND DOCUMENT (A258)


9




10




11



12




13




44.DECAL AND DOCUMENT (A258)


14




15




16




17



18















19





45.SPECIAL TOOLS (A258)

1	2	3	4	5
				
6	7	8	9	10
				
11	12	13		
				

45.SPECIAL TOOLS (A258)



Index No.	Part No.	Description	Q'ty Per Assembly
1	5203 9501	Grease 501	1
2	A029 9387	Digital Multimeter - FLUKE87	1
3	5420 9550	Silicone Oil	1
4	5442 9101	Setting Powder	1
5	5442 9103	Launa Oil 40	1
6	5447 9078	Heat Resistant Grease - MT-78	1
7	A259 9010	Scanner Adjust Pin 100mm (4pcs/set)	1
8	A008 9502	Silicone Grease - G40M	1
9	A012 9111	Optics Cloth	1
10	A028 9300	Grease Barrierta JFE 55/2	1
11	A092 9503	C4 Color Test Chart (3 PCS/SET)	1
12	C401 9503	20X Magnification Scope	1
13	H515 9350	Mirror Cleaner Set	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No
EXTERIOR 2 (A258)	A259 1680	Dust Filter	Scanner Filter	1	13- 8
OPTICS SECTION 3 (A258)	AX52 0036	Halogen Lamp	Exposuer Lamp - 65v 128w	1	31- 8
TRANSFER BELT CLEANING 1 (A258)	A259 6715	Lubricant Brush	Cleaning Brush Roller	1	43- 2
	A259 6745	Lubricant Bar	Lubricant Bar	1	43- 3
TRANSFER BELT CLEANING 2 (A258)	A259 6741	Belt Cleaning Blade	Cleaning Blade	1	45- 1
TRANSFER BELT UNIT (A258)	A259 6050	Transfer Belt	Transfer Belt	1	47- 2
DRAWER UNIT 1 (A258)	AD02 0082	Charge Corona Grid	Charge Corona Grid	1	49- 15
	AD02 0081	Charge Corona Wire	Charge Corona Wire	1	49- 18
	AA01 2092	Dust Filter	Dust Filter	1	49- 22
DRUM CLEANING (A258)	AD04 1058	Drum Cleaning Blade	Cleaning Blade	1	55- 2
	A259 3565	Lubricant Bar	Lubricant Bar	1	55- 10
	AD04 2036	Drum Cleaning Brush	Cleaning Brush Roller	1	55- 23
	AD02 0083	PPC Charge Wire	Discharge Corona Wire	1	55- 33
PAPER TRANSFER UNIT (A258)	A259 6231	Paper Discharge Corona Wire	Separation Corona Wire	1	57- 5
	A259 6255	Lubricant Bar	Lubricant Bar	1	57- 22
	A259 6225	Paper Transfer Roller Blade	Blade	1	57- 24
FUSING UNIT 2 (A258)	AE04 1002	Hot Roller Blade	Hot Roller Blade	1	61- 5
	A259 4080	Oil Supply Pad	Oil Supply Pad	1	61- 11
FUSING UNIT 3 (A258)	AE01 0025	Hot Roller	Hot Roller	1	63- 25
FUSING UNIT 4 (A258)	AE02 0085	Pressuer Roller	Pressure Roller	1	65- 3
	A259 4144	Pressuer Roller Pad (EU/Asia only)	Oil Pad - Pressure Roller (230V)	1	65- 35
	AE04 1005	Pressuer Roller Blade(EU/Asia only)	Blade (230V)	1	65- 38
ELECTRICAL SECTION 3 (A258)	A259 1082	Exhaust Filter	Dust Filter	1	81- 12

Parts Index

Part No.	Description	Page and Index No.
A258 1451	Operation Panel Ass'y - LT	15- *
A258 1451	Operation Panel Ass'y - LT	13- 1
A258 1452	Operation Panel Ass'y - A4	13- 1
A258 1452	Operation Panel Ass'y - A4	15- *
A258 1460	Operation Panel Case - LT	15- 1
A258 1467	Sheet - Behind (LT)	15- 6
A258 1468	Sheet - Main Switch (LT)	15- 7
A258 1469	LCD Sheet (LT)	15- 8
A258 1471	Cover Behind	15- 9
A258 1473	Key Top - Center	15- 10
A258 1474	Key Top - Interrupt	15- 11
A258 1475	Key Top - Counter	15- 12
A258 1476	Key Top - Standby	15- 13
A258 1477	Key Top - Program	15- 14
A258 1478	Key Top - Clear Mode	15- 15
A258 1480	Operation Panel Board (LT)	15- 16
A258 1481	Grounding Wire	15- 19
A258 1482	Ferrite Core	15- 20
A258 1490	Operation Panel Board (A4)	15- 16
A258 1500	Operation Panel Case - A4	15- 1
A258 1501	Sheet - Behind (A4)	15- 6
A258 1502	Sheet - Main Switch (A4)	15- 7
A258 1503	LCD Sheet (A4)	15- 8
A258 1550	Decal - Keytop Option (LT)	107- 6
A258 1551	Decal - Keytop Option (A4)	107- 6
A258 5087	Main Control Board	95- *
A258 5087	Main Control Board	83- 12
A258 5523	Grounding Wire	77- 23
A258 5523	Grounding Wire	79- 15
A258 5538	Operation Panel Harness	83- 19
A258 6800	Front Cover Ass'y (RIC)	11- 16
A258 6803	Front Cover Ass'y (SVN/LAN)	11- 16
A258 6804	Front Cover Ass'y (INF)	11- 16
A258 6806	Front Cover Ass'y (NRG)	11- 16
A258 6821	Model Name Plate - GES CS206	11- 18

Part No.	Description	Page and Index No.
A258 6822	Model Name Plate - NSA CS506	11- 18
A258 6823	Model Name Plate - REX CS806	11- 18
A258 6824	Model Name Plate - SVN SDC306	11- 18
A258 6825	Model Name Plate - LAN 5706	11- 18
A258 8607	Operating Instructions - RIC English (LT)	107- 1
A258 8608	Operating Instructions - RIC English (Asia)	107- 1
A258 8609	Operating Instructions - RIC Taiwan	107- 1
A258 8650	Quick Guide - English (A4)	107- 2
A258 8657	Quick Guide - English (LT)	107- 2
A258 8658	Quick Guide - English (Asia)	107- 2
A258 8659	Quick Guide - English (Taiwan)	107- 2
A258 8690	Operating Instructions - NRG English (A4)	107- 1
A258 8697	Operating Instructions - SVN English (LT)	107- 1

Part No.	Description	Page and Index No.
AA00 0542	Decal - Laser Class 1	13- 29
AA00 3002	Decal - Add Paper	21- 7
AA00 3002	Decal - Add Paper	107- 15
AA01 2092	Dust Filter	49- 22
AA03 1011	Oil Tank	59- 13
AA03 6007	Oil Tank Cap	59- 12
AA04 0028	Transport Belt	89- 18
AA04 3276	Timing Belt - S3M225	23- 11
AA06 0048	Spring - Charge Wire	49- 17
AA06 0221	Gripper Solenoid Spring	33- 4
AA06 0691	Tension Spring	25- 4
AA06 0692	Tension Spring	25- 23
AA06 0693	Pressure Spring	25- 25
AA06 0732	Blade Spring	55- 11
AA06 0766	Pick-up Spring	19- 5
AA06 0767	By-pass Feed Spring	19- 15
AA06 0768	Tension Spring	71- 21
AA06 0770	Tension Spring	75- 23
AA06 0771	Tension Spring	73- 10
AA06 0777	Spring (230V)	65- 39
AA06 0778	Tension Spring	61- 3
AA06 0823	Tension Spring	71- 31
AA06 3040	Spring	71- 10
AA06 3284	Spring	63- 16
AA06 3285	Spring	63- 12
AA06 3322	Compression Spring	17- 19
AA06 3323	Middle Spring	37- 14
AA06 3324	Compression Spring	37- 3
AA06 3325	Spring - Toner Stopper	55- 27
AA06 3329	Compression Spring	49- 3
AA06 3353	Pressure Spring	57- 14
AA06 3499	Pressure Spring	19- 34
AA06 3505	Spring	67- 1
AA06 3562	Pressure Spring	65- 13
AA06 3584	Compression Spring	71- 32

Part No.	Description	Page and Index No.
AA06 3585	Compression Spring	73- 16
AA06 3586	Compression Spring	61- 9
AA06 3593	Compression Spring	45- 26
AA06 3603	Compression Spring	55- 36
AA06 6300	Feeler Spring	59- 2
AA06 6301	Actuator Spring	61- 20
AA06 6310	Lock Spring	61- 15
AA08 0037	Bushing - 6mm	19- 31
AA08 0037	Bushing - 6 Mm	37- 4
AA08 0141	Bushing - 5x12x4mm	71- 43
AA08 0162	Bushing - 8mm	57- 21
AA08 0228	Bushing - M4	17- 18
AA08 0248	Bushing - 6mm	55- 35
AA08 2021	Bushing - 8x12x10mm	37- 1
AA08 2057	Bushing - 8mm	87- 13
AA08 2058	Bushing - 6x10x9mm	67- 5
AA08 2070	Bushing - 8x16x7	89- 7
AA08 2070	Bushing - 8x16x7	25- 8
AA08 2072	Bushing - M6	25- 26
AA08 3010	Clutch Roller - 6x14x10	19- 20
AA08 3014	One-way Clutch	25- 29
AA12 0079	Antistatic Brush	47- 26
AA12 0084	Discharge Brush	67- 11
AA13 2107	Spring Holder	73- 15
AA13 2116	Collar - 8	71- 25
AA13 2184	Motor Cushion	33- 27
AA14 0602	Feed Shaft	19- 35
AA14 0655	Shaft - Paper Feed	25- 28
AA14 0656	Shaft - Gear	25- 20
AA14 0696	Stepped Screw - M4x8.8	63- 29
AA14 3219	Stepped Screw	13- 30
AA14 3219	Stepped Screw	13- 2
AA14 3402	Screw - Scale	47- 11
AA14 3454	Stepped Screw - M3	13- 12
AA14 3480	Screw - M3	79- 3

Part No.	Description	Page and Index No.
AA14 3480	Screw - M3	57- 7
AA14 3480	Screw - M3	53- 7
AA14 3708	Stepped Screw - M4	75- 6
AA14 3756	Flat Screw	69- 6
AA14 3762	Tapping Screw - M3x10	21- 9
AA14 5813	Scraper Drive Shaft	71- 42
AA14 5815	Drive Roller Shaft	71- 17
AA14 8556	Stud Screw	75- 36
AA15 2361	Sync Detector Seal	35- 8
AA15 2362	Laser Unit Seal	35- 24
AA15 2409	Glass Seal	35- 23
AA15 2410	Scanner Seal	35- 17
AA15 2411	Cover Seal	35- 5
AA16 1067	Cushion - Motor	33- 28
AA18 0035	Sleeve - Oil Pump	61- 21
AA18 0053	Tank Tube	61- 22
AA18 0057	Oil Supply Tube - 5.5mm	61- 2
AB01 0106	Gear - 24Z	25- 19
AB01 0107	Gear - 23Z	25- 17
AB01 1188	Gear - 21Z	25- 3
AB01 1189	Gear - 18Z	25- 7
AB01 1343	Idle Gear - 23Z	19- 7
AB01 1344	Gear - 16Z	19- 29
AB01 1345	Gear - 20Z	19- 27
AB01 1346	Gear - 27Z	19- 23
AB01 3801	Gear - 30Z	67- 2
AB01 3967	Gear - 18Z	67- 4
AB01 3973	Gear - 15Z	65- 15
AB01 3975	Gear - 20Z	65- 29
AB01 3976	Gear - 15Z	59- 5
AB01 4037	Gear - 24Z	23- 9
AB01 4038	Gear - 22Z	23- 14
AB01 4095	Gear - 30Z	71- 41
AB01 4096	Gear - 26Z	75- 26
AB01 4097	Gear - 23Z	73- 17

Part No.	Description	Page and Index No.
AB01 4098	Gear - 24Z	71- 18
AB01 4099	Gear - 58Z	63- 27
AB01 4100	Gear - 55Z	63- 24
AB01 4101	Gear - 20Z	63- 7
AB01 4102	Gear - 20Z	63- 20
AB01 4103	Gear - 26Z	89- 16
AB01 4105	Gear - 18Z	55- 14
AB01 4106	Gear - 26Z	55- 16
AB01 4107	Gear - 53Z	65- 2
AB01 4116	Gear - 20Z	63- 10
AB01 4117	Gear - 30Z	61- 23
AB01 4128	Gear - 24Z	69- 13
AB01 4129	Gear - 20Z	43- 11
AB01 4130	Gear - 17Z	43- 8
AB01 4131	Idler Gear - 17Z	43- 9
AB01 4148	Gear - 22Z	63- 19
AB01 7477	Gear - 46Z/70Z	71- 28
AB01 7479	Gear - 54Z	71- 33
AB01 7480	Gear - 16Z/30Z	75- 32
AB01 7481	Gear - 24Z/20Z	75- 28
AB01 7482	Gear - 24Z/20Z	75- 29
AB01 7483	Gear - 18Z/26Z	75- 34
AB01 7484	Gear - 31Z/18Z	75- 33
AB01 7485	Gear - 21Z/24Z	75- 27
AB01 7486	Gear - 56Z/16Z	75- 31
AB01 7487	Gear - 84Z/20Z	75- 25
AB01 7488	Gear - 48Z/30Z	73- 18
AB01 7489	Gear - 83Z/30Z	73- 20
AB01 7512	Gear - 23Z/108Z	71- 26
AB03 0276	Tightener Pulley	73- 19
AB03 0276	Tightener Pulley	71- 24
AB03 0474	Pulley - 24T	45- 10
AB03 0474	Pulley - 24T	43- 15
AB03 0565	Timing Pulley - 20T	23- 12
AB03 0600	Timing Pulley - 20Z S3M	37- 5

Part No.	Description	Page and Index No.
AB03 0602	Idler Pulley - 70Z	71- 35
AB03 0603	Idler Pulley - 35Z	71- 23
AB03 0605	Timing Pulley - Brush Roller	71- 6
AB03 0606	Timing Pulley - 33Z	71- 15
AB03 0607	Gear - 34Z	73- 14
AB03 0608	Idler Pulley	75- 30
AB03 0610	Pulley - 140Z	69- 3
AC02 0074	Cylindrical Lens	35- 19
AD00 4097	Charge Corona Unit	49- 10
AD02 0081	Charge Corona Wire	49- 18
AD02 0082	Charge Corona Grid	49- 15
AD02 0083	Discharge Corona Wire	55- 33
AD02 2361	Front End Block	49- 12
AD02 2362	Rear End Block	49- 20
AD02 2363	Front End Block Cover	49- 14
AD02 2364	Rear End Block Cover	49- 16
AD02 4025	Corona Wire Terminal	55- 30
AD02 4025	Corona Wire Terminal	49- 19
AD04 1058	Cleaning Blade	55- 2
AD04 2036	Cleaning Brush Roller	55- 23
AD04 7016	Cleaning Entrance Seal	55- 17
AE01 0025	Hot Roller	63- 25
AE02 0085	Pressure Roller	65- 3
AE03 0015	Ball Bearing - 35x47x7	63- 23
AE03 0019	Ball Bearing - 7x20x32	65- 1
AE03 1021	Bushing - 6mm	63- 11
AE03 1028	Bushing - 4mm (120V)	65- 22
AE03 1031	Bushing - 4mm	61- 10
AE03 2017	Bushing - 30x40x14.5	63- 26
AE04 0025	Oil Supply Roller	61- 6
AE04 0026	Oil Supply Sub Roller	61- 7
AE04 1002	Hot Roller Blade	61- 5
AE04 1005	Blade (230V)	65- 38
AE04 2029	Fusing Cleaning Roller (120V)	65- 21
AF01 3014	Bottom Plate Pad	21- 5

Part No.	Description	Page and Index No.
AF01 7020	End Fence	21- 6
AF02 0404	Transport Roller	25- 32
AF02 0421	Transport Drive Roller	37- 19
AF02 0453	Lower Exit Roller	59- 10
AF02 0463	Transport Driven Roller	37- 15
AF02 2070	Right Transport Roller	89- 13
AF02 2107	Transport Driven Roller	17- 17
AF02 2109	Transport Belt Roller	89- 19
AF02 5026	Paper Exit Pawl	67- 18
AF03 0035	Pick-up Roller	25- 1
AF03 0362	Pick-up Roller	19- 8
AF03 1025	Feed Roller	19- 3
AF03 1035	Feed Roller	25- 6
AF03 2025	Separation Roller	19- 33
AF03 2035	Separation Roller	25- 24
AF04 0554	Paper Exit Roller	67- 14
AF04 0564	Exit Driven Roller	59- 9
AF04 3077	Copy Tray Guide	13- 6
AG05 0087	Fusing Knob	59- 16
AG05 1138	Transport Release Grip	89- 6
AG07 0009	Magnetic Catch	59- 7
AG07 1010	Magnet Catch	83- 6
AG07 1010	Magnet Catch	11- 8
AG07 1010	Magnet Catch	13- 22
AG07 1010	Magnet Catch	17- 20
AH01 0007	Rubber Foot	89- 5
AH01 0007	Rubber Foot	87- 14
AW01 0048	Photo Sensor - GP2A28N1	37- 9
AW01 0053	Original Sensor - H=62	29- 28
AW01 0055	Original Sensor H=71.4	29- 1
AW01 0081	ID Sensor	51- 13
AW02 0022	Photointerruptor	33- 11
AW02 0022	Photointerruptor	29- 7
AW02 0056	Photointerruptor - EE-SX4235A-P1	25- 31
AW02 0075	Photointerruptor	51- 6

Part No.	Description	Page and Index No.
AW02 0075	Photointerrupter	75- 11
AW02 0075	Photointerrupter	71- 20
AW02 0075	Photointerrupter	87- 10
AW02 0075	Photointerrupter	19- 11
AW02 0075	Photointerrupter	65- 8
AW02 0096	Photointerruptor	25- 35
AW03 0030	Fiber Cable - 400	29- 12
AW03 0085	Optical Fiber - 700mm	83- 21
AW03 0086	Optical Fiber - 1200mm	83- 20
AW11 0020	Thermostat - 140°C DC75V 3A	31- 15
AW14 0007	Thermo Sensor - CHS-GSST-RC	81- 16
AW23 0009	Toner End Sensor	77- 8
AW33 0006	Drum Potential Sensor	53- 1
AW50 0012	Push Switch	19- 24
AW50 0012	Push Switch	87- 8
AX04 0113	DC Motor - 3W	69- 9
AX06 0162	DC Motor - DC 24V 20W	69- 5
AX06 0163	DC Motor - DC 24V 15W	75- 19
AX06 0164	DC Motor - DC 24V 24W	73- 5
AX20 0101	Magnetic Clutch - 2.5kgf 35Z	19- 19
AX20 0159	Magnetic Clutch	71- 14
AX20 0160	Magnetic Spring Clutch	73- 13
AX21 0062	Magnetic Clutch - 0.44n	23- 10
AX21 0063	Magnetic Clutch - 0.5n	75- 18
AX21 0064	Magnetic Clutch - 0.5n	75- 17
AX21 0065	Magnetic Spring Clutch	75- 15
AX21 0066	Magnetic Spring Clutch	71- 22
AX31 0035	Total Counter	83- 1
AX31 0037	Total Counter	83- 2
AX40 0114	Anticondensation Heater - 120V 18W	87- 7
AX40 0122	Anticondensation Heater - 120V 9W	33- 12
AX40 0123	Anticondensation Heater - 230V 10W	33- 12
AX40 0124	Anticondensation Heater - 230V 18W	87- 7
AX40 0126	Heater - 100V 13W	37- 22
AX40 0127	Heater - 120V 13W	37- 22

Part No.	Description	Page and Index No.
AX40 0128	Heater - 230V 13W	37- 22
AX43 0048	Fusing Lamp - 120V 800W	63- 28
AX43 0049	Fusing Lamp - 230V 800W	63- 28
AX44 0114	Fusing Lamp - 120V 400W	65- 4
AX44 0115	Fusing Lamp - 230V 400W	65- 4
AX52 0036	Exposuer Lamp - 65V 128W	31- 8
AX64 0088	Fan Motor - DC24V 0.69W	89- 20
AX64 0090	Fan Motor - DC24V	85- 3
AX64 0100	Fan Motor - DC 24V	49- 23
AX64 0101	Fan Motor - DC24V	33- 20
AX65 0026	Sirocco Fan - DC24V 3350RPM	81- 15
AX65 0027	Fan Motor - DC24V	79- 12
AX65 0027	Fan Motor - DC24V	81- 21
AX65 0028	Fan Motor - DC5.8W	33- 10
AZ23 0079	Lamp Regulator (120V)	29- 18
AZ23 0086	Power Supply Unit - 250W (120V)	79- 8
AZ23 0088	Lamp Regulator (230V)	29- 18
AZ32 0093	Power Pack - C/G	81- 1
C225 2866	Decal - Keytop Cover (REX)	107- 3
C225 2866	Decal - Keytop Cover (REX)	15- 17
C225 2867	Decal - Keytop Cover (SVN)	107- 3
C225 2867	Decal - Keytop Cover (NSA)	15- 17
C401 9503	20X Magnification Scope	109- 12
G011 1058	Snap Ring	59- 11
G011 1058	Snap Ring	55- 15
G011 1058	Snap Ring	43- 7
G011 1058	Snap Ring	71- 40
G011 1058	Snap Ring	73- 2
G011 3305	Gear - 16T	17- 11
G012 1531	Magnet	37- 13
G012 4617	Stepped Screw - M3	63- 1
G020 1917	Decal - LD	35- 3
G020 1917	Decal - LD	107- 16
G020 1918	Decal - Laser Diode (230V)	35- 2
G020 1918	Decal - Laser Diode (230V)	107- 17

Part No.	Description	Page and Index No.
G020 2707	Conductor Plate	17- 5
G020 2783	Registration Roller Knob	37- 6
G020 4479	Bushing - 6mm	89- 17
G029 1980	Decal - LD	39- 12
G029 1980	Decal - LD	107- 18
H006 3398	Arm Bushing - Master Drive	61- 24
H053 2208	Bushing - M4	71- 13
H072 2220	Spacer - M6x10	73- 24
H515 9350	Mirror Cleaner Set	109- 13
N607 4525	Coil - RITL-9704	67- 19

Part No.	Description	Page and Index No.
A006 2122	Cleaner Stopper	49- 21
A007 3751	Large Cap - Toner Collection Tank	77- 9
A008 2087	Corona Cleaner Pad	49- 8
A008 9502	Silicone Grease - G40M	109- 8
A012 9111	Optics Cloth	109- 9
A028 9300	Grease Barrierta JFE 55/2	109- 10
A029 9387	Digital Multimeter - FLUKE87	109- 2
A079 3106	Seal - 3x8x14mm	81- 19
A079 3626	Stepped Screw - Swing Cleaning	33- 29
A092 9503	C4 Color Test Chart (3 PCS/SET)	109- 11
A096 3863	Spacer - 4x6x1	57- 32
A109 3631	Gear - 18Z/20Z	73- 9
A109 3635	Gear - 18Z	73- 8
A109 3651	Gear - 20Z	73- 23
A134 1071	Left Grip Plate	89- 2
A134 1071	Left Grip Plate	87- 15
A134 1724	Cushion - Stepper Motor	31- 22
A134 1771	Front Terminal	31- 13
A134 1773	Rear Terminal	31- 17
A134 1791	Spring Plate - 2nd Mirror	31- 2
A134 1922	Rear Scale	13- 14
A134 1926	Exposure Glass Stopper	27- 4
A134 2662	Grounding Plate	19- 9
A134 2663	Separation Guide	19- 26
A134 2668	Separation Driven Shaft	19- 30
A134 2674	Torque Limiter - 400fg	19- 32
A134 2705	Magnet Catch Plate	17- 10
A134 5370	Relay Harness - Exposure Lamp	31- 14
A153 1357	Operating Instruction Holder	11- 14
A153 6409	Decal - Keytop Cover (GES)	15- 17
A153 6409	Decal - Keytop Cover (GES)	107- 3
A166 1351	Magnet Catch Plate	11- 12
A166 1363	Hinge Pin	11- 10
A166 1376	Color Decal (RIC)	107- 5
A166 1376	Color Decal (RIC)	11- 23

Part No.	Description	Page and Index No.
A166 1736	Spring Plate	31- 9
A166 1837	Decal - Caution	107- 4
A166 1837	Decal - Caution	13- 10
A166 2062	Shielding Glass	35- 26
A166 2076	Front Lens Holder	35- 11
A166 2077	Rear Lens Holder	35- 13
A166 2078	Lens - BLT	35- 12
A166 2081	Mirror Ass'y	35- 10
A166 2316	Rear Seal - Main Corona	53- 2
A166 2783	Separation Shaft	19- 28
A166 2849	Drive Support Plate	19- 18
A166 3591	Entrance Seal	55- 18
A166 3594	Cleaning Case Seal	55- 28
A166 4017	Driven Roller	67- 16
A166 4167	Valve - Oil Pump	61- 25
A166 4466	Spring Plate	67- 17
A166 4492	Exit Cover	67- 7
A166 4496	Exit Cover Pawl	67- 8
A166 5421	Transfer Belt Sensor	75- 1
A166 5974	Scanner Release Rod	27- 10
A193 5711	Power Supply Cord (120V)	77- 18
A193 5712	Power Supply Cord (230V)	77- 18
A217 7905	Support Cover (INF)	11- 17
A232 1502	Key Top - 10 Key	15- 2
A232 1503	Key Top - Start	15- 3
A232 1504	Key Top - Clear	15- 4
A232 1508	Key Top - Switch	15- 5
A232 2750	Paper Feed Unit Ass'y	25- 36
A232 2760	Housing - Paper Feed Unit	25- 9
A232 2762	Paper End Feeler	25- 13
A232 2763	Pick-up Arm	25- 2
A232 2764	Rear Grounding Plate	25- 27
A232 2765	Front Grounding Plate	25- 10
A232 2766	Feed Mylar	25- 37
A232 2770	Stay - Paper Separation	25- 18

Part No.	Description	Page and Index No.
A232 2774	Pressure Lever	25- 21
A232 2775	Link Lever	25- 22
A232 2776	Release Lever	25- 15
A232 2777	Shaft - Paper Separation	25- 12
A232 2780	Stay - Paper Feed	25- 33
A232 2781	Sensor Bracket	25- 34
A232 2782	Rear Feed Mylar	25- 14
A232 2783	Torque Limiter	25- 11
A232 2785	Vertical Guide	23- 2
A232 2972	Bottom Lift Shaft	21- 12
A232 2975	Bottom Lift Plate	21- 10
A232 2976	Grounding Plate - Paper Tray	21- 13
A232 2977	Bottom Plate	21- 4
A232 2979	Front Side Fence	21- 3
A232 2983	Rear Side Fence	21- 14
A232 2986	Screw - M4X8	21- 2
A232 2987	Roller - Paper Tray	21- 11
A232 2988	Handle - Paper Tray	21- 8
A232 2995	Front Positioning Guide	23- 5
A232 2997	Right Stopper - Paper Tray	21- 17
A232 2999	Right Spacer	21- 16
A232 3566	Ball Bearing - 8x16x5	31- 28
A232 5428	Harness - Paper Feed Unit	25- 30
A232 7756	Harness - Circuit Breaker	77- 22
A235 2979	Feeler - Paper Height Sensor	21- 15
A250 1761	Original Sensor - H=2-66	29- 23
A259 1034	Key Counter Bracket	83- 24
A259 1045	Grounding Plate	35- 31
A259 1046	Insulating Sheet	35- 32
A259 1048	Corner Fence	81- 18
A259 1049	Joint Duct	81- 9
A259 1054	Rear Grip	87- 1
A259 1055	Control Board Stay	87- 17
A259 1056	Grip Bracket - Front Left	89- 3
A259 1057	Rear Grip Bracket	87- 2

Part No.	Description	Page and Index No.
A259 1058	Front Side Support Plate	35- 28
A259 1059	Scanner Holder	35- 29
A259 1062	Fan Bracket	81- 20
A259 1065	Fusing Fan Duct	85- 5
A259 1068	Left Rail Stay	85- 9
A259 1073	Fusing Duct Cover	85- 2
A259 1074	Fan Bracket	81- 14
A259 1075	Fusing Rail	85- 12
A259 1077	Heat Duct Stay	85- 8
A259 1078	Fusing Exhaust Duct	85- 18
A259 1081	Ozone Filter	81- 13
A259 1082	Dust Filter	81- 12
A259 1083	Ozone Filter Case	81- 10
A259 1084	Rear Duct	81- 4
A259 1085	Case Cover - Ozone Filter	81- 11
A259 1086	Rear Duct - Cleaning Belt	81- 6
A259 1087	Grip Bracket	87- 16
A259 1087	Grip Bracket	89- 1
A259 1089	Rear Cover Support Plate	79- 5
A259 1091	Duct Seal	85- 4
A259 1092	Inner Duct Seal	85- 6
A259 1093	Scanner Fan Bracket	85- 20
A259 1096	Scanner Fan Seal	85- 19
A259 1097	Exhaust Duct	81- 17
A259 1103	Driven Joint	47- 16
A259 1105	Front Side Plate	71- 37
A259 1109	Ball Bearing	71- 39
A259 1110	Rear Side Plate	71- 3
A259 1112	Ball Bearing - 2	71- 27
A259 1113	Drive Joint	71- 38
A259 1114	Boss	71- 29
A259 1115	Tightener Ass'y	71- 19
A259 1120	Tightener Ass'y	71- 34
A259 1124	DC Motor Holder	71- 1
A259 1125	Timing Belt - DS2M 560	71- 36

Part No.	Description	Page and Index No
A259 1127	Timing Belt - S2M 540	71- 4
A259 1132	Rear Joint - Toner Supply	71- 11
A259 1133	Front Joint - Toner Supply	71- 12
A259 1134	Spring Plate - 6mm	71- 9
A259 1135	Magnetic Clutch Holder - Drive	71- 16
A259 1137	Pulley Holder	71- 8
A259 1138	Drive Shaft	71- 7
A259 1142	Spring Clutch Holder	71- 2
A259 1144	Cleaner Sensor Feeler	71- 44
A259 1146	Cleaning Sensor Joint	71- 30
A259 1151	Paper Feed Drive Unit	75- 14
A259 1153	Timing Belt - S3M 789	75- 20
A259 1155	Paper Feed Drive Case	75- 21
A259 1158	Pulley Flange	75- 22
A259 1160	Belt Tightner	75- 24
A259 1164	Grounding Plate	75- 35
A259 1171	Timing Belt - S3M 540	73- 6
A259 1172	Fusing Drive Holder	73- 12
A259 1175	Tightner Arm	73- 11
A259 1185	Idler Shaft	69- 12
A259 1190	Fly Wheel	69- 4
A259 1191	Fly Wheel Balancer	69- 11
A259 1257	Door Duct	11- 13
A259 1258	Door Stopper	11- 11
A259 1259	Stopper Bracket	83- 10
A259 1261	Left Hinge Bracket	85- 11
A259 1262	Right Hinge Bracket	83- 9
A259 1267	Duct Seal	11- 20
A259 1268	Pull Out Seal	11- 21
A259 1270	Left Upper Cover	13- 9
A259 1275	Left Cover	13- 4
A259 1280	Right Upper Cover	13- 20
A259 1283	Front Right Cover	13- 13
A259 1285	Right Middle Cover	13- 23
A259 1290	Right Rear Cover	13- 21

Part No.	Description	Page and Index No.
A259 1295	Rear Upper Cover	13- 15
A259 1302	Rear Left Cover	13- 16
A259 1303	Rear Connector Cover	13- 17
A259 1305	Duct Seal - Exhaust Length	13- 26
A259 1306	Duct Seal - Exhaust Side	13- 27
A259 1310	Rear Right Cover	13- 18
A259 1312	Duct Seal - Rear Right Cover	13- 24
A259 1315	Rear Lower Cover	13- 19
A259 1317	Duct Seal - Lower Cover	13- 25
A259 1320	Left Louver Cover	13- 7
A259 1330	Right Inner Cover	11- 9
A259 1335	Main Switch Inner Cover	83- 7
A259 1340	Transport Inner Cover	11- 7
A259 1345	Drawer Inner Cover	11- 1
A259 1346	Inner Cover Seal - Small	11- 22
A259 1347	Duct Seal	11- 5
A259 1348	Decal - Toner Supply	11- 2
A259 1348	Decal - Toner Supply	107- 7
A259 1349	Decal - Toner Cartridge Position	107- 8
A259 1349	Decal - Toner Cartridge Position	11- 19
A259 1350	Transfer Inner Cover	11- 6
A259 1510	Cover - SP	13- 3
A259 1510	Cover - SP	15- 18
A259 1520	Decal - Front Operation	107- 9
A259 1520	Decal - Front Operation	11- 15
A259 1522	Decal - Inner Cover	107- 10
A259 1524	Decal - Main Switch 230V	13- 28
A259 1524	Decal - Main Switch 230V	107- 11
A259 1525	Decal - Emblem Color (RIC)	11- 17
A259 1525	Decal - Emblem Color	107- 12
A259 1526	Decal - Paper Size Indication	107- 13
A259 1526	Decal - Paper Size Indication	11- 3
A259 1528	Decal - Toner Recycling	77- 10
A259 1528	Decal - Toner Recycling	107- 14
A259 1531	Decal - Precaution	11- 24

Part No.	Description	Page and Index No.
A259 1531	Decal - Precaution	107- 19
A259 1581	Rubber Cushion	83- 4
A259 1582	Operation Panel Bracket	83- 3
A259 1591	Copy Tray Ass'y	13- 5
A259 1676	Fan Guide Bracket	33- 7
A259 1677	Harness Guide	33- 13
A259 1678	Left Flow Seal	33- 9
A259 1679	Lower Flow Seal	33- 8
A259 1680	Scanner Filter	13- 8
A259 1688	Front Rail - 1	33- 15
A259 1692	Front Rail - 2	33- 14
A259 1696	Stay Holder Bracket	33- 3
A259 1697	Wire Cover	27- 11
A259 1700	Front Left Seal	27- 8
A259 1701	Front Middle Seal	27- 7
A259 1702	Front Right Seal	27- 6
A259 1708	Rear Rail - 1	33- 17
A259 1711	Rear Rail - 2	33- 16
A259 1714	Rear Stay Bracket	33- 23
A259 1718	Platen Cover Bracket	29- 8
A259 1726	Left Pulley Ass'y	31- 18
A259 1730	Right Pulley Ass'y	31- 31
A259 1733	Scanner Middle Duct	29- 20
A259 1736	Scanner Rear Stay	33- 18
A259 1737	Scanner Right Stay	33- 21
A259 1738	Scanner Left Stay	29- 5
A259 1739	Connector Bracket	29- 19
A259 1745	Fly Wheel	31- 25
A259 1751	Drive Shaft	31- 29
A259 1752	Front Wire Pulley	31- 30
A259 1753	Rear Wire Pulley	31- 27
A259 1754	Carriage Drive Wire	31- 26
A259 1755	Front Bracket - Tension Wire	33- 5
A259 1756	Rear Bracket - Tension Wire	33- 22
A259 1761	Scanner Motor - DC24V 11.02W	31- 23

Part No.	Description	Page and Index No.
A259 1765	Timing Belt - S2M 220	31- 19
A259 1771	1st Carriage Ass'y	31- 7
A259 1784	Spring Plate	31- 11
A259 1786	Wire Clamp	31- 12
A259 1787	1st Mirror Ass'y	31- 10
A259 1790	2nd Carriage Ass'y	31- 1
A259 1791	2nd Carriage	31- 6
A259 1800	Harness Guide	31- 4
A259 1801	2nd Mirror Ass'y	31- 3
A259 1802	3rd Mirror Ass'y	31- 5
A259 1805	CCD Board	29- 3
A259 1832	Right Stay	27- 2
A259 1834	Left Scale Bracket	27- 9
A259 1836	Exposure Glass	27- 1
A259 1837	Left Scale - A4	13- 11
A259 1838	Left Scale - LT	13- 11
A259 1851	Rear Scanner Duct	33- 19
A259 1852	Duct Fan Seal	33- 25
A259 1854	Inner Cover - CCD Drive Board	29- 4
A259 1864	IPU Board Bracket	29- 21
A259 1866	IPU Board Stay - Front	33- 1
A259 1869	IPU Board Stay - Rear	33- 24
A259 1870	IPU Board Stay - Left	33- 6
A259 1871	Front Spring Plate	33- 2
A259 1880	Original Sensor Bracket	29- 22
A259 1882	Bracket Cover - IPU	29- 24
A259 1885	Grounding Plate	29- 26
A259 1886	Grounding Plate	33- 26
A259 1910	Scanner Motor Bracket	31- 21
A259 1913	Scanner Motor Tightner	31- 32
A259 1916	Belt Pulley	31- 33
A259 1917	Motor Spring - 6N	31- 20
A259 1981	Scanner Hinge Ass'y	27- 5
A259 1985	Scanner Stand	27- 3
A259 2050	Optical Housing Unit	35- 1

Part No.	Description	Page and Index No.
A259 2061	Insulating Sheet	35- 33
A259 2066	Positioning Pin	35- 22
A259 2076	Shield Glass Guide	35- 25
A259 2081	Cylindrical Lens Holder	35- 18
A259 2101	Mirror Plate	35- 9
A259 2115	Laser Diode Unit	35- 21
A259 2128	Imaging Unit Cover	35- 4
A259 2131	Ferrite Core Ass'y	35- 34
A259 2241	Corona Wire Cleaner	49- 7
A259 2251	Drum Shaft Holder	69- 1
A259 2271	Charge Corona Receptacle	69- 2
A259 2303	Upper Frame	53- 4
A259 2304	Frame Cover	53- 3
A259 2307	Lower Frame	53- 8
A259 2308	Potential Sensor Bracket	53- 9
A259 2309	Potential Sensor Seal	53- 11
A259 2314	Left Shield - Charge Corona	53- 5
A259 2321	Frame Stopper	35- 30
A259 2351	Discharge Corona Receptacle	73- 21
A259 2362	Grounding Plate	73- 3
A259 2366	Discharge Corona Duct	81- 3
A259 2392	Pull Out Stay	51- 24
A259 2443	Grid Pad	49- 9
A259 2447	Charge Corona Cover	49- 5
A259 2452	Front Grid Stay	49- 13
A259 2457	Duct Cover Charge Corona	49- 11
A259 2462	Front Supporter - Drum Shaft	49- 1
A259 2473	Density Sensor Bracket	51- 14
A259 2475	ID Sensor Cover	51- 11
A259 2482	Front Duct - Drawer Unit	49- 24
A259 2483	Duct Seal - Charge Corona	49- 26
A259 2484	Left Duct Seal - Charge Corona	49- 25
A259 2490	Magnet Seal - Center	51- 18
A259 2491	Magnet Seal - Side	51- 17
A259 2520	Paper Tray Ass'y	21- 1

Part No.	Description	Page and Index No.
A259 2550	Guide Plate - Vertical Transport	17- 16
A259 2554	Switch Bracket	17- 15
A259 2555	Front Bracket - Paper Feed	23- 1
A259 2557	Lower Guide Plate - Paper Feed	23- 4
A259 2560	Upper Registration Roller	37- 7
A259 2562	Registration Driven Roller	37- 8
A259 2570	Registration Guide	23- 8
A259 2573	Guide Plate - Upper Registration	37- 12
A259 2577	Registration Sensor Holder	37- 10
A259 2578	Registration Guide - Release	37- 20
A259 2581	Registration Guide - Leading	37- 17
A259 2582	Registration Guide	37- 16
A259 2584	Transport Roller Guide	23- 15
A259 2600	Right Rail Ass'y	23- 7
A259 2604	Rail Plate	23- 6
A259 2605	Left Rail Ass'y	67- 9
A259 2620	Positioning Rear Guide	75- 7
A259 2621	Registration Roller Knob	37- 2
A259 2626	Connecting Guide	19- 25
A259 2628	Band	17- 14
A259 2630	Drive Bracket - Paper Feed	23- 13
A259 2632	Tray Left Cover	21- 19
A259 2633	Tray Right Cover	21- 20
A259 2810	By-pass Feed Table Ass'y	17- 1
A259 2825	By-pass Feed Unit	19- 1
A259 2850	Solenoid Guide Plate	19- 14
A259 2854	By-pass Feed Solenoid	19- 16
A259 2860	Guide Plate - Paper Feed	19- 4
A259 2865	Pick-up Arm	19- 6
A259 2870	Grounding Plate	19- 13
A259 2872	Grounding Plate	19- 21
A259 2875	Reverse Roller Guide	19- 36
A259 2877	Reverse Roller guide - Exit	19- 37
A259 2880	Middle Guide Plate	19- 10
A259 2885	Paper End Feeler	19- 12

Part No.	Description	Page and Index No.
A259 2895	By-pass Feed Harness	19- 17
A259 2950	By-pass Feed Table	17- 7
A259 2955	Paper Guide - By-pass Feed Table	17- 8
A259 2960	By-pass Feed Table Cover	17- 12
A259 2970	Front Side Fence	17- 3
A259 2975	Rear Side Fence	17- 4
A259 2980	Friction Pad	17- 6
A259 3020	Development Unit	39- 2
A259 3020	Development Unit	41- 1
A259 3128	Right Screw	41- 4
A259 3130	Left Screw	41- 3
A259 3141	Development Cover Shutter	41- 5
A259 3142	Shutter Plate	41- 6
A259 3143	Development Cover	41- 8
A259 3147	Bearing Holder	41- 12
A259 3152	Gear - 18Z	41- 19
A259 3154	Gear - 18Z	41- 17
A259 3156	Gear - 27Z	41- 15
A259 3158	Gear - 27Z	41- 13
A259 3160	Gear - 16Z	41- 16
A259 3161	Ball Bearing - 8x18.3	41- 2
A259 3163	Spacer - 4.5x6mm	41- 18
A259 3164	Doctor Blade Seal	41- 11
A259 3165	Rear Seal	41- 10
A259 3166	Side Fence Seal	41- 9
A259 3169	Toner Supply Seal	41- 7
A259 3172	Front Side Fence	41- 20
A259 3174	Rear Side Fence	41- 14
A259 3229	Development Unit Holder	39- 1
A259 3232	Gear - 54Z	39- 4
A259 3234	Gear - 12Z/30Z	39- 3
A259 3235	Toner Cartridge Stopper	39- 6
A259 3236	Toner Cartridge Spring	39- 5
A259 3250	Stepper Motor - DC24V 144W	69- 8
A259 3261	Connector Bracket	79- 2

Part No.	Description	Page and Index No.
A259 3270	Toner Supply Motor	69- 7
A259 3296	Bias Terminal - Development	49- 28
A259 3302	Bias Receptacle	49- 4
A259 3311	Toner End Sensor Bracket	51- 7
A259 3312	Toner End Sensor	51- 8
A259 3314	Screw Driver	21- 18
A259 3315	Photo Reflection Sensor	51- 3
A259 3350	Bushing	51- 23
A259 3355	Screw	51- 21
A259 3363	Toner Supply Gear	51- 22
A259 3417	Middle Stay Seal	51- 20
A259 3418	Lower Right Seal	51- 1
A259 3420	Front Holder Ass'y	39- 9
A259 3426	Rear Holder Ass'y	39- 10
A259 3428	Toner Catch Pan	51- 10
A259 3431	Seal - Toner Catch Pan	51- 16
A259 3432	Development Knob	39- 8
A259 3433	Screw - M4x8	39- 7
A259 3434	Coupling Support Plate	39- 11
A259 3438	Drum Drive Holder	51- 15
A259 3442	Konb Screw	11- 4
A259 3444	Turn Stopper	51- 5
A259 3446	Development Holder	69- 10
A259 3448	Pull Out Slide Rail	85- 10
A259 3456	Magnet	51- 19
A259 3501	Drum Cleaning Unit	55- 1
A259 3522	Discharge Corona Casing	55- 29
A259 3526	Discharge Corona Cover	55- 32
A259 3552	Cleaning Casing	55- 12
A259 3557	Rear Holder - Brush Roller	55- 24
A259 3562	Lubricant Bar Case	55- 7
A259 3564	Seal Plate	55- 9
A259 3565	Lubricant Bar	55- 10
A259 3571	Toner Transport Screw	55- 21
A259 3576	Cleaning Blade Holder	55- 3

Part No.	Description	Page and Index No.
A259 3581	Toner Stopper	55- 26
A259 3582	Toner Outlet Cap	55- 20
A259 3586	Drive Joint	55- 25
A259 3589	Cleaning Seal	55- 4
A259 3591	Toner Outlet Shield	55- 19
A259 3594	Cleaning Side Seal	55- 5
A259 3595	Entrance Seal	55- 34
A259 3596	Rear Seal - Cleaning Unit	55- 22
A259 3597	Front Seal - Cleaning Unit	55- 13
A259 3598	Rear Seal	55- 6
A259 3599	Front Seal	55- 8
A259 3850	Transport Unit	89- 12
A259 3870	Transfer Belt Guide	89- 14
A259 3880	Spring Plate	89- 15
A259 3890	Positioning Plate	89- 4
A259 3911	Separation Plate	89- 10
A259 3920	Release Plate	89- 11
A259 3923	Transport Grip Shaft	89- 9
A259 3924	Vacuum Guide	89- 8
A259 4003	Paper Exit Unit	59- 1
A259 4050	Upper Side Plate	63- 15
A259 4055	Blade Bracket (230V)	65- 36
A259 4056	Blade Screw (230V)	65- 37
A259 4059	Roller Holder - Oil Supply	61- 18
A259 4060	Fusing Entrance Upper Guide	65- 28
A259 4062	Exit Guide	59- 4
A259 4063	Fusing Connector Bracket	65- 24
A259 4064	Base Plate - Fusing Unit	65- 20
A259 4070	Rear Heater Holder	63- 18
A259 4071	Front Heater Holder	63- 6
A259 4072	Thermistor Upper Bracket	65- 5
A259 4073	Hot Roller Rear Stopper	63- 17
A259 4074	Hot Roller Front Stopper	63- 9
A259 4075	Gear Bracket	63- 8
A259 4078	Front Positioning Plate	63- 13

Part No.	Description	Page and Index No.
A259 4079	Upper Left Stay	63- 22
A259 4080	Oil Supply Pad	61- 11
A259 4083	Spring Plate	61- 12
A259 4084	Fusing Cleaning Roller	63- 21
A259 4085	Scraper Bracket	63- 5
A259 4086	Cleaning Roller Scraper	63- 4
A259 4087	Scraper Cushion	63- 3
A259 4088	Scraper Plate	63- 2
A259 4089	Rear Side Plate	65- 32
A259 4096	Front Side Plate	65- 7
A259 4100	Front Heater Holder - Pressure	65- 11
A259 4101	Rear Pressure Lever	65- 30
A259 4103	Paper Feed Sensor Bracket	65- 9
A259 4104	Rear Lever Holder	65- 31
A259 4105	Front Lever Holder	65- 12
A259 4106	Oil Supply Bracket	61- 1
A259 4111	Actuator Ass'y	61- 19
A259 4115	Oil Application Shaft	65- 26
A259 4116	Paper Exit Sensor Feeler	59- 3
A259 4117	Front Left Cover	59- 14
A259 4118	Spring Anchor	61- 8
A259 4119	Blade Bracket	61- 4
A259 4121	Fusing Cover Knob	59- 15
A259 4123	Exit Roller Holder	59- 8
A259 4124	Spring Spacer	65- 14
A259 4125	Thermistor Lower Bracket	65- 17
A259 4126	Oil Tube Holder	61- 13
A259 4127	Lock Lever	61- 14
A259 4128	Stepped Screw	61- 16
A259 4129	Lock Lever Knob	61- 17
A259 4130	Fusing Unit Stopper	59- 18
A259 4131	Front Pressure Lever	65- 10
A259 4135	Fusing Guide Plate	65- 27
A259 4137	Cleaning Roller Holder (120V)	65- 23
A259 4138	Gear Holder	63- 30

Part No.	Description	Page and Index No.
A259 4139	Harness Guide Plate	65- 33
A259 4140	Fusing Cover Ass'y	59- 17
A259 4141	Harness Guide Plate - Connector	65- 34
A259 4143	Connector Stopper (230V)	79- 11
A259 4144	Oil Pad - Pressure Roller (230V)	65- 35
A259 4464	Exit Guide Plate	67- 15
A259 4467	Exit Cover Bracket	67- 6
A259 4477	Exit Drive Bracket	67- 3
A259 4481	Exit Cover Stay	67- 13
A259 4493	Front Plate - Copy Tray	67- 12
A259 4496	Rear Plate - Copy Tray	67- 10
A259 5051	I/O Control Board	99- *
A259 5051	I/O Control Board	77- 4
A259 5054	Power Pack Ass'y - T1/PCC	81- 5
A259 5055	Power Pack Ass'y - T2/D	79- 4
A259 5056	Power Pack Ass'y - B	49- 6
A259 5101	IC - UPD97211GJ-201-3EB	105- 1
A259 5102	IC - TC220C180EF-001	105- 2
A259 5103	IC - UPD82141GD-001-LML	105- 3
A259 5104	IC - HG73C005FD	105- 4
A259 5106	IC - MB87F1462	105- 5
A259 5108	IC - JSC05RR519AU15	105- 6
A259 5110	IC - I/O-EXPANDER	99- 1
A259 5112	IC - JSC05SV519AY17	95- 1
A259 5137	Scanner IPU-B Board	29- 15
A259 5137	SCANNER IPU-B	105- *
A259 5140	IDU Board	29- 25
A259 5230	Scanner DC Harness	29- 9
A259 5231	Scanner Rear Harness	29- 10
A259 5234	Scanner Front Harness	29- 16
A259 5235	Scanner Control Harness	29- 13
A259 5236	Scanner AC Harness	29- 17
A259 5237	Exposuer Lamp Relay Harness	29- 11
A259 5238	Exposure Lamp Harness	31- 16
A259 5239	SBU Harness	29- 2

Part No.	Description	Page and Index No.
A259 5240	Grounding Wire	31- 24
A259 5242	Original Sensor Harness	29- 27
A259 5253	LD Main Board	83- 16
A259 5259	Sync Detector Board	35- 7
A259 5270	LD Control Harness	35- 20
A259 5271	Sync Detector Harness	35- 6
A259 5272	Polygon Scanner Harness	35- 16
A259 5273	IPU Harness - Data	29- 14
A259 5274	LD Harness - Data	83- 18
A259 5280	Polygon Motor	35- 14
A259 5282	Polygon Motor Drive Board	35- 15
A259 5283	Polygon Motor Harness	35- 27
A259 5300	Development Drive Board	77- 2
A259 5320	Scanner Drive Board	29- 6
A259 5329	Power Supply Unit - 250W (230V)	79- 8
A259 5410	Paper Size Detection Board	17- 9
A259 5416	Interface Board - Css/bank	77- 13
A259 5431	Quenching Lamp	53- 6
A259 5446	Thermistor Ass'y - Fusing	65- 6
A259 5447	Thermistor Ass'y - Pressure	65- 16
A259 5468	AC Harness - 120V	79- 9
A259 5469	AC Harness - 230V	79- 9
A259 5471	Rear Upper Harness	77- 5
A259 5472	Right Side Harness	83- 22
A259 5473	Rear Lower Harness	77- 6
A259 5474	Rear Middle Harness	77- 7
A259 5476	Drawer Unit Front Harness	49- 27
A259 5493	Exit Switch Harness	77- 14
A259 5495	T2 Sensor Harness	75- 13
A259 5496	Oil End Sensor Harness	59- 20
A259 5510	Relay Harness - TMP/Humidity	77- 19
A259 5511	Grounding Wire	83- 17
A259 5513	DC Power Harness - Scanner	79- 7
A259 5514	DC Power Harness - S/S	77- 17
A259 5516	DC Power Harness - ADF	81- 8

Part No.	Description	Page and Index No.
A259 5561	Drawer Harness	65- 25
A259 5562	Drawer Unit Middle Harness	51- 2
A259 5563	Cartridge Sensor Harness	51- 4
A259 5565	Toner End Sensor Harness	51- 9
A259 5566	ID Sensor Harness	51- 12
A259 5567	Positioning Sensor Harness	75- 2
A259 5570	Registration Sensor Harness	37- 11
A259 5571	Fusing Motor Harness	73- 4
A259 5573	Paper Volume Sensor Harness	87- 9
A259 5574	Exit Relay Harness	65- 18
A259 5651	Thermofuse - 184°C	63- 14
A259 5653	Thermofuse - 167°C	65- 19
A259 5821	Fusing Unit Conector Bracket	79- 6
A259 5822	Power Supply Cord Bracket	77- 16
A259 5825	I/O Board Bracket	77- 21
A259 5826	CSS Bracket	77- 15
A259 5829	Rocker Switch Bracket	83- 13
A259 5830	Release Lever - Safety Switch	83- 14
A259 5831	Total Counter Bracket	83- 11
A259 5837	Power Supply Bracket 1	79- 1
A259 5839	I/O Control Board Bracket	77- 3
A259 5840	I/O Control Board Bracket	85- 17
A259 5841	Power Supply Bracket 2	85- 7
A259 5842	Spring Plate	83- 15
A259 5843	Development Control Board Bracket	77- 1
A259 5844	Power Pack Bracket	81- 2
A259 5845	Grounding Plate	85- 14
A259 5850	Grounding Plate	85- 13
A259 5851	Grounding Plate	85- 16
A259 5852	Grounding Plate	77- 20
A259 5853	Grounding Plate	79- 10
A259 5854	Grounding Plate	85- 1
A259 5855	Grounding Plate	85- 15
A259 5856	ADF Bracket	81- 7
A259 5861	Motor Bracket	79- 13

Part No.	Description	Page and Index No.
A259 5862	Grounding Plate	83- 23
A259 5869	Fan motor Seal	79- 14
A259 6002	Transfer Belt Unit	47- 1
A259 6003	Transfer Belt Cleaning Unit	43- *
A259 6050	Transfer Belt	47- 2
A259 6055	Belt Drive Roller	47- 8
A259 6060	Transfer Belt Roller	47- 20
A259 6065	Belt Pressure Roller	47- 19
A259 6070	Bias Roller	47- 5
A259 6075	Grounding Roller	47- 4
A259 6076	Compression Spring	47- 23
A259 6085	Release Cam Bracket	47- 7
A259 6087	Release Cam	47- 13
A259 6088	Release Cam Shaft	47- 14
A259 6089	Release Lever	47- 12
A259 6092	Support Plate	47- 22
A259 6093	Upper Insulating Sheet	47- 21
A259 6098	Front Collar	47- 9
A259 6099	Rear Collar	47- 15
A259 6101	Drum Stay	49- 29
A259 6104	Drum Stay	49- 2
A259 6105	Support Stay	37- 18
A259 6119	Positioning Sensor Bracket	75- 3
A259 6120	Receptacle Swivel Spring	75- 5
A259 6121	Compression Spring	47- 17
A259 6122	Receptacle	75- 4
A259 6128	Tension Roller Bushing	47- 18
A259 6129	Ball Bearing	47- 6
A259 6130	Grounding Roller Bushing	47- 3
A259 6133	Antistatic Brush Holder	47- 25
A259 6141	Belt Holder	47- 24
A259 6200	Transfer Roller	57- 23
A259 6209	Transfer Unit Stay	57- 17
A259 6210	Transfer Roller Bracket	57- 18
A259 6214	Toner Catchpan Seal	57- 20

Part No.	Description	Page and Index No.
A259 6215	Entrance Seal	57- 28
A259 6216	Blade Holder	57- 25
A259 6217	Transfer Roller Gear	57- 26
A259 6218	Idler Gear - Transfer Roller	57- 30
A259 6219	Bushing - Transfer Roller	57- 12
A259 6220	Transfer Roller Shaft	57- 11
A259 6221	Roller	57- 13
A259 6223	Screw - M3x5	57- 16
A259 6224	Toner Catch Pan	57- 10
A259 6225	Blade	57- 24
A259 6228	Blade Spring	57- 19
A259 6230	Separation Corona	57- 1
A259 6231	Separation Corona Wire	57- 5
A259 6232	Separation Corona Spring	57- 4
A259 6233	Spring Pin	57- 3
A259 6234	Guide Plate	57- 2
A259 6235	Separation Corona Casing	57- 6
A259 6239	Screw - M3X4	57- 31
A259 6240	Positioning Plate	57- 8
A259 6246	Guide Plate - Transfer Roller	57- 15
A259 6247	Grounding Plate	57- 33
A259 6250	Vacuum Duct	73- 7
A259 6255	Lubricant Bar	57- 22
A259 6260	Paper Transfer Unit	57- 9
A259 6271	Spring Clutch Feeler	87- 3
A259 6272	Transfer Roller Cam Shaft	87- 4
A259 6273	Cam	87- 6
A259 6274	Positioning Plate	87- 5
A259 6280	Transfer Roller Receptacle	75- 9
A259 6288	Receptacle Spring	75- 8
A259 6289	Sensor Bracket	75- 12
A259 6290	Rail Bracket	87- 11
A259 6293	Screw - M3X4.5	75- 10
A259 6294	Separation Heater Cover	87- 12
A259 6302	Cleaning Belt Stopper	43- 12

Part No.	Description	Page and Index No.
A259 6314	Duct Seal	45- 21
A259 6318	Toner Catch Pan	43- 13
A259 6343	Cleaning Unit Joint	45- 22
A259 6390	Casing Seal	45- 17
A259 6415	Cam Bushing	45- 8
A259 6416	Stopper Cam Shaft	45- 7
A259 6418	Toner Spring	45- 18
A259 6419	Toner Stopper	45- 19
A259 6505	Toner Collection Pipe	73- 1
A259 6590	Bushing	73- 22
A259 6655	Toner Collection Bottle	77- 11
A259 6660	Small Bottle Cap	77- 12
A259 6708	Cleaning Blade Holder	45- 2
A259 6711	Lubricant Bar Holder	43- 5
A259 6714	Lubricant Bar Cover	43- 1
A259 6715	Cleaning Brush Roller	43- 2
A259 6719	Entrance Seal Holder	45- 14
A259 6720	Entrance Seal	45- 24
A259 6721	Entrance Seal Tape	45- 25
A259 6724	Entrance Seal Link	45- 20
A259 6726	Position Shaft	43- 10
A259 6727	Cam Shaft	45- 5
A259 6728	Release Cam	45- 6
A259 6730	Toner Collection Auger	45- 23
A259 6735	Blade Position Shaft	45- 3
A259 6736	Entrance Seal Collar	45- 13
A259 6741	Cleaning Blade	45- 1
A259 6745	Lubricant Bar	43- 3
A259 6748	Stopper Shaft	43- 16
A259 6750	Grounding Plate	45- 9
A259 6754	Bushing - 6 6mm	43- 6
A259 6755	Bushing - 6 12mm	45- 11
A259 6758	Blade Spring - 2.6n	45- 12
A259 6759	Lubricant Pressure Spring	43- 4
A259 6760	Entrance Seal Spring	45- 15

Part No.	Description	Page and Index No
A259 6761	Cam Shaft Spring	45- 4
A259 6763	Blade Spring 700mn	45- 27
A259 6765	Timing Belt - S2M 180	43- 14
A259 6766	Seal - 4x342x2	45- 16
A259 6840	Color Decal (SVN)	107- 5
A259 9010	Scanner Adjust Pin 100mm (4pcs/set)	109- 7
A259 9510	OPC Drum	53- 10
A259 9520	NVRAM - Minus Counter	83- 8
A260 5492	Sensor Harness - Vertical Guide	17- 13
A700 5106	IC - PI	95- 2

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	19- 22
5053 0447	Bushing - 6mm	71- 5
5203 9501	Grease 501	109- 1
5206 2686	Snap Ring	25- 16
5206 2686	Snap Ring	47- 10
5209 5320	Oil End Sensor	59- 19
5215 1924	Cushion	27- 12
5215 2621	Snap Ring - M6	75- 16
5215 2621	Snap Ring - M6	17- 2
5400 3404	Stepped Screw	57- 27
5409 1855	Mounting Pin	57- 29
5420 9550	Silicone Oil	109- 3
5442 2108	Corona Wire Spring	55- 31
5442 9101	Setting Powder	109- 4
5442 9103	Launa Oil 40	109- 5
5447 2681	Snap Ring	25- 5
5447 2681	Snap Ring	19- 2
5447 2769	Stepped Screw	61- 27
5447 4241	Tube Clamp	61- 26
5447 9078	Heat Resistant Grease - MT-78	109- 6
5840 1632	Stepped Screw	59- 6
5887 4176	Screw	37- 21
5887 4176	Screw	23- 3

Part No.	Description	Page and Index No.
0313 0050B	Philips Pan Head Screw - M3x5	33-104
0313 0060B	Philips Pan Head Screw - M3x6	51-108
0313 0060B	Philips Pan Head Screw - M3x6	37-104
0313 0100B	Philips Pan Head Screw - M3x10	75-101
0313 0350W	Philips Pan Head Screw - M3x35	83-109
0314 0080B	Philips Pan Head Screw - M4x8	87-105
0314 0100B	Philips Pan Head Screw - M4x10	31-104
0314 0120B	Philips Pan Head Screw - M4x12	29-105
0314 0120B	Philips Pan Head Screw - M4x12	33-103
0314 0300B	Philips Pan Head Screw - M4x30	65-105
0353 0040B	Screw - M3X4	55-101
0353 0060B	Philips Pan Head Screw - M3x6	35-101
0353 0060B	Philips Pan Head Screw - M3x6	21-102
0354 0080B	Screw - M4X8	49-105
0354 0120B	Screw - M4X12	69-105
0434 0060B	Pan Head Self-tapping Screw - M4x6	31-103
0450 3006B	Tapping Screw - M3x6	59-104
0450 3006B	Tapping Screw - M3x6	63-103
0450 3006B	Tapping Screw - M3x6	65-101
0450 3008B	Tapping Screw - M3x8	45-102
0450 3008B	Tapping Screw - M3x8	59-101
0450 3008B	Tapping Screw - M3x8	77-104
0450 3008B	Tapping Screw - M3x8	65-102
0450 3012B	Tapping Screw - 3x12	69-102
0450 4008B	Tapping Screw - 4x8	67-106
0450 4008H	Tapping Screw - M4x8	11-103
0450 4008H	Tapping Screw - M4x8	13-103
0450 4010B	Tapping Screw - 4x10	69-104
0450 4010B	Tapping Screw - 4x10	75-104
0450 4012B	Tapping Screw - M4x12	19-102
0450 4030B	Tapping Screw - M4x30	85-103
0450 4035B	Philips Tapping Screw - M4x35	33-106
0450 4035B	Philips Tapping Screw - M4x35	49-106
0451 3006B	Tapping Screw - M3x6	77-101
0451 3006B	Tapping Screw - M3x6	45-101

Part No.	Description	Page and Index No.
0451 3006B	Tapping Screw - M3x6	15-102
0451 3006B	Tapping Screw - M3x6	85-101
0451 3006B	Tapping Screw - M3x6	43-101
0451 3006B	Tapping Screw - M3x6	81-104
0451 3006B	Tapping Screw - M3x6	37-102
0451 3006B	Tapping Screw - M3x6	27-101
0451 3006B	Tapping Screw - M3x6	87-101
0451 3006B	Tapping Screw - M3x6	33-101
0451 3006B	Tapping Screw - M3x6	47-105
0451 3006B	Tapping Screw - M3x6	79-102
0451 3006B	Tapping Screw - M3x6	11-101
0451 3006B	Tapping Screw - M3x6	51-102
0451 3006B	Tapping Screw - M3x6	65-103
0451 3006B	Tapping Screw - M3x6	55-102
0451 3006B	Tapping Screw - M3x6	23-103
0451 3006B	Tapping Screw - M3x6	63-101
0451 3006B	Tapping Screw - M3x6	61-102
0451 3006B	Tapping Screw - M3x6	67-105
0451 3006B	Tapping Screw - M3x6	71-101
0451 3006B	Tapping Screw - M3x6	29-101
0451 3006B	Tapping Screw - M3x6	57-101
0451 3006B	Tapping Screw - M3x6	75-102
0451 3006B	Tapping Screw - M3x6	19-103
0451 3006B	Tapping Screw - M3x6	73-101
0451 3006B	Tapping Screw - M3x6	13-102
0451 3006B	Tapping Screw - M3x6	31-101
0451 3006B	Tapping Screw - M3x6	83-104
0451 3006B	Tapping Screw - M3x6	17-104
0451 3008B	Tapping Screw - M3x8	53-102
0451 3008B	Tapping Screw - M3x8	61-103
0451 3008B	Tapping Screw - M3x8	39-103
0451 3008B	Tapping Screw - M3x8	65-107
0451 3008B	Tapping Screw - M3x8	49-103
0451 3008B	Tapping Screw - M3x8	25-101
0451 3010B	Tapping Screw - M3x10	29-102

Part No.	Description	Page and Index No.
0451 3010B	Tapping Screw - M3x10	47-104
0451 3012B	Tapping Screw With Washer - M3x12	17-103
0451 4006B	Tapping Screw - 4x6	51-107
0451 4006B	Tapping Screw - 4x6	77-108
0451 4006B	Tapping Screw - 4x6	65-109
0451 4006B	Tapping Screw - 4x6	49-101
0451 4006H	Tapping Screw - M4x6	11-102
0451 4006H	Tapping Screw - M4x6	13-101
0451 4006Z	Tapping Screw 4x6	83-105
0451 4006Z	Tapping Screw 4x6	89-102
0451 4008B	Philips Tapping Screw - M4x8	69-101
0451 4008B	Philips Tapping Screw - M4x8	23-101
0451 4008B	Philips Tapping Screw - M4x8	57-102
0451 4008B	Philips Tapping Screw - M4x8	67-103
0451 4008B	Philips Tapping Screw - M4x8	27-102
0451 4008B	Philips Tapping Screw - M4x8	59-106
0451 4008B	Philips Tapping Screw - M4x8	19-105
0451 4008B	Philips Tapping Screw - M4x8	71-104
0451 4008B	Philips Tapping Screw - M4x8	61-101
0451 4008B	Philips Tapping Screw - M4x8	87-102
0451 4008B	Philips Tapping Screw - M4x8	89-105
0451 4008B	Philips Tapping Screw - M4x8	79-103
0451 4008B	Philips Tapping Screw - M4x8	75-103
0451 4008B	Philips Tapping Screw - M4x8	81-101
0451 4008B	Philips Tapping Screw - M4x8	35-102
0451 4008B	Philips Tapping Screw - M4x8	77-103
0451 4008B	Philips Tapping Screw - M4x8	47-102
0451 4008B	Philips Tapping Screw - M4x8	39-101
0451 4008B	Philips Tapping Screw - M4x8	73-106
0451 4008B	Philips Tapping Screw - M4x8	51-101
0451 4012B	Tapping Screw - 4x12	81-107
0451 4025B	Tapping Screw - M4x25	89-104
0451 4030B	Philips Tapping Screw - M4x30	81-108
0451 4030B	Philips Tapping Screw - M4x30	79-109
0452 3006B	Tapping Screw - M3x6	49-104

Part No.	Description	Page and Index No.
0452 3008B	Tapping Screw - M3x8	73-107
0452 3008B	Tapping Screw - M3x8	41-101
0452 4008B	Binding Self Tapping Screw - M4x8	17-101
0453 3006	Tapping Screw - M3x6	29-108
0453 3006B	Tapping Screw - M3x6	51-103
0453 4006B	Tapping Screw - 4x6	69-107
0453 4006B	Tapping Screw - 4x6	85-102
0453 4008B	Tapping Bind Screw - M4x8	17-105
0471 3906	Bushing 6mm	73-105
0575 0050E	Hexagon Headless Set Screw - M5x5	31-105
0585 0500B	Hexagon Bolt - M5x50	65-106
0622 0100E	Spring Pin - 2x10mm	19-106
0632 0120	Parallel Pin - M2x12	37-106
0711 0030B	Hexagon Nut - M3	53-101
0720 0030B	Retaining Ring - M3	39-102
0720 0030E	Retaining Ring - M3	61-104
0720 0040B	Retaining Ring - M4	73-108
0720 0040B	Retaining Ring - M4	69-106
0720 0040B	Retaining Ring - M4	57-103
0720 0040B	Retaining Ring - M4	59-102
0720 0040B	Retaining Ring - M4	89-106
0720 0040B	Retaining Ring - M4	67-101
0720 0040E	Retaining Ring - M4	63-102
0720 0040E	Retaining Ring - M4	19-101
0720 0040E	Retaining Ring - M4	67-104
0720 0040E	Retaining Ring - M4	71-102
0720 0040E	Retaining Ring - M4	65-108
0720 0040E	Retaining Ring - M4	31-107
0720 0040E	Retaining Ring - M4	61-105
0720 0040E	Retaining Ring - M4	25-102
0720 0040E	Retaining Ring - M4	37-103
0720 0060B	Retaining Ring - M6	31-106
0720 0060B	Retaining Ring - M6	65-104
0720 0060B	Retaining Ring - M6	57-104
0720 0060B	Retaining Ring - M6	41-102

Part No.	Description	Page and Index No.
0720 0060E	Retaining Ring - M6	73-103
0720 0060E	Retaining Ring - M6	31-108
0720 0060E	Retaining Ring - M6	47-101
0720 0060E	Retaining Ring - M6	37-101
0720 0060E	Retaining Ring - M6	71-103
0720 0060E	Retaining Ring - M6	87-104
0720 0060E	Retaining Ring - M6	25-103
0720 0060E	Retaining Ring - M6	21-101
0720 0060E	Retaining Ring - M6	63-104
0720 0060E	Retaining Ring - M6	89-103
0725 0300E	Retaining Ring C - M30	63-105
0734 0508D	Bushing - 5x8	61-106
0801 0149	Philips Pan Head Screw - M4x6	77-107
0802 5273	Tapping Screw - M3x10	15-101
0805 0089	Retaining Ring - M4	25-105
0805 3480	Bushing - 6mm	23-104
0805 3480	Bushing - 6mm	25-104
0805 3480	Bushing - 6mm	59-105
0805 3497	Bushing - 8x12x3.5mm	73-104
0805 3507	Bushing - 6mm	41-103
0805 3511	Bushing 8mm	47-103
0807 2089	Washer - 10mm	59-103
0807 4123	Spacer - 6x13x1	67-102
0951 3006B	Philips Screw With Flat Washer - M3X6	31-109
0951 5014W	Philips Screw W/H Flat Washer - M5x14	69-103
0954 3008B	Philips Screw - M3x8	83-106
0954 3008B	Philips Screw - M3x8	81-110
0954 3008B	Philips Screw - M3x8	79-111
0960 4010B	Philips Flange Screw - M4x10	87-103
0960 4010B	Philips Flange Screw - M4x10	89-101
0971 3006A	Philips Polycarbonate Screw - M3x6	49-102
1101 0328	Connector Pin Contact	95-101
1101 0328	Connector Pin Contact	99-101
1101 0376	Jumper Board Dic-152-2p	95-102
1101 0429	Test Pin	105-101

Part No.	Description	Page and Index No.
1102 2452	Terminal Block - 3p	95-103
1102 4052	Optional Connector	77-106
1102 4052	Optional Connector	81-106
1102 4201	Connector - 2P	99-102
1102 4202	Connector - 3P	99-103
1102 4205	CT Header- 6p	99-104
1102 4207	Connector - 8P	99-105
1102 4208	Connector - 9P	99-106
1102 4211	CT Header - 12P	105-102
1102 4212	CT Header - 15P	105-103
1102 5003	Fiber Connector - DC1002 - 2p	105-104
1102 5276	Connector - 4P	99-107
1102 5301	Connector - 2P	99-108
1102 5302	Connector - 3P	95-104
1102 5302	Connector - 3P	99-109
1102 5306	Connector - 7P	99-110
1102 5525	Connector - 5566-12A	99-111
1102 5718	Optical Fiber Connector	95-105
1102 6298	Connector - 5P	105-105
1102 6299	Connector - 6P	99-112
1102 6302	Connector - 9P	99-113
1102 6313	Connector - 6P	99-114
1102 6418	Connector - PA1002	29-106
1102 6515	Connector - 34P	99-115
1102 6579	Receptacle Connector	105-106
1102 6600	Connector - 8P	105-107
1102 7102	Connector - JC20EF-J68HR1-A1	95-106
1102 7460	Connector - FH12-50S-0.5SH	105-108
1102 7834	Connector - B2B	99-116
1102 7835	Connector - B3B	95-107
1102 7835	Connector - B3B	105-109
1102 7835	Connector - B3B	99-117
1102 7836	Connector - B4B	99-118
1102 7837	Connector - B5B	95-108
1102 7838	Connector - B6B	99-119

Part No.	Description	Page and Index No
1102 7840	Connector - B8B	99-120
1102 7844	Connector - B12B	99-121
1102 7845	Connector - B13B	95-109
1102 7845	Connector - B13B	105-110
1102 7846	Connector - B14B	95-110
1102 7846	Connector - B14B	99-122
1102 7849	Connector - B16B	99-123
1102 7850	Connector - B18B	99-124
1102 7850	Connector - B18B	95-111
1102 7851	Connector - B20B	95-112
1102 7851	Connector - B20B	99-125
1102 7852	Connector - B22B	99-126
1102 7852	Connector - B22B	95-113
1102 7853	Connector - B24B	95-114
1102 7885	Connector - B2B	99-127
1102 7909	Connector - B3B	95-115
1102 7992	Connector - IL-404-30S-TW	105-111
1102 7993	Card Connector - FCN-568P068-G/G-V4	105-112
1102 7994	Connector - HIF6A-52PA-1.27DS	105-113
1102 8005	Connector - 1-178670-1	95-116
1102 8038	Connector - B5B	95-117
1103 1422	Connector - 20P	99-128
1103 1878	Receptacle - 9067	95-118
1104 0589	Dip Socket - 32p	95-119
1104 0765	IC Socket	95-120
1105 0160	Clamp	81-109
1105 0199	Clamp	23-105
1105 0199	Clamp	29-103
1105 0199	Clamp	33-102
1105 0199	Clamp	37-105
1105 0199	Clamp	49-107
1105 0199	Clamp	51-105
1105 0229	Clamp	79-104
1105 0229	Clamp	51-104
1105 0229	Clamp	79-110

Part No.	Description	Page and Index No.
1105 0229	Clamp	29-107
1105 0229	Clamp	81-105
1105 0283	Clamp	31-102
1105 0283	Clamp	25-106
1105 0291	Harness Clamp - LWS-3S	33-105
1105 0291	Harness Clamp - LWS-3S	29-104
1105 0292	Wire Saddle	23-102
1105 0292	Wire Saddle	83-102
1105 0292	Wire Saddle	73-102
1105 0292	Wire Saddle	35-103
1105 0292	Wire Saddle	77-102
1105 0292	Wire Saddle	51-106
1105 0292	Wire Saddle	81-103
1105 0292	Wire Saddle	79-101
1105 0310	Harness Clamp - LWS-1S	27-103
1105 0310	Harness Clamp - LWS-1S	83-103
1105 0310	Harness Clamp - LWS-1S	35-104
1105 0310	Harness Clamp - LWS-1S	19-104
1105 0316	Clamp	83-101
1105 0316	Clamp	81-102
1106 0458	Bushing - 9.9mm	23-106
1107 0472	Circuit Breaker - W28XQ1A 8A 25V	77-105
1107 0887	Fuse - 250V 15A (120V)	79-108
1107 0906	Fuse - 4A 125V (120V)	79-105
1107 0910	Fuse - 2A 125V (120V)	79-106
1107 0919	Fuse - 8A 125V (120V)	79-107
1109 0007	IC - MINISMDC100-02	105-114
1109 0009	IC - MINISMDC075-02	105-115
1204 1228	Switch	95-121
1204 2373	Key Bord Switch - SKQDPA	95-122
1204 2415	Dip Switch - DSS802	95-123
1204 2468	Switch - AC250/16A	83-108
1204 2481	Dip Switch - 73D-0601	105-116
1204 2497	Micro Switch	17-102
1204 2497	Micro Switch	83-107

Part No.	Description	Page and Index No
1400 0392	Transistor - DTC114EK	95-124
1400 0398	Transistor - 2SC2412K	105-117
1400 0398	Transistor - 2SC2412K	95-125
1400 0459	Transistor - DTC143XKA	95-126
1400 0663	Transistor - 2SA1037AK	99-129
1400 0700	Transistor - DTD133HK	99-130
1401 0869	Transistor-array - TD62003F	99-131
1402 0595	Diode-array - DAN202K	105-118
1402 1058	Diode Array - DA114	99-132
1402 1142	Diode Array - DAN217	105-119
1402 1142	Diode Array - DAN217	95-127
1402 1206	Zener Diode	105-120
1402 1322	Diode Array - DAN202U	99-133
1402 1343	Diode - RB106L-40	95-128
1402 1345	Diode - UDZ3.6B	95-129
1402 1378	Diode - PTZ12A	99-134
1402 1380	Diode - PTZ 6.2A	95-130
1402 1380	Diode - PTZ 6.2A	99-135
1402 1444	Diode - RB051L-40	95-131
1403 0829	Diode - SEC1201C	105-121
1403 0829	Diode - SEC1201C	95-132
1407 1596	TTLIC - SN74LS14NS	95-133
1407 1600	TTLIC - SN74LS244NS	95-134
1407 2051	TTL - IC - SN74LS00NS	95-135
1407 2055	IC - TD62304F	99-136
1407 2127	TTL - IC74F00SJ	105-122
1407 2128	TTL - IC74F02SJ	105-123
1407 2187	TTLIC - SN74LS07NS	99-137
1407 2187	TTLIC - SN74LS07NS	105-124
1407 2187	TTLIC - SN74LS07NS	95-136
1407 2218	TTLIC - SN74LS06NS	105-125
1407 2231	IC - TD62308AF	99-138
1407 2231	IC - TD62308AF	105-126
1407 2378	TTL - SN74ALS245ANS	95-137
1407 2378	TTL - SN74ALS245ANS	99-139

Part No.	Description	Page and Index No.
1407 2463	TTL - IC - SN74ALS08NS	105-127
1407 2464	TTL - IC - SN74ALS74ANS	105-128
1407 2588	TTLIC - SN74ALS04BNS	95-138
1407 2588	TTLIC - SN74ALS04BNS	105-129
1407 2816	TTL - SN74ALS374ANS	105-130
1407 3008	TTL - SN74ALS244CNS	105-131
1407 3008	TTL - SN74ALS244CNS	95-139
1407 3008	TTL - SN74ALS244CNS	99-140
1407 3017	TTL - SN74ALS11ANS	95-140
1407 3197	IC - SN74ALS240ANS	105-132
1407 3290	IC - TC74HC02AF	99-141
1407 3381	Cmos - IC - TC74HC4066AF	105-133
1407 3952	IC - ANALOG SW- 4053	95-141
1407 4023	IC - M62353GP	105-134
1407 4114	IC - SN751177	95-142
1407 4323	TTL - TD74ABT244F	95-143
1407 4687	IC - TA8083F	99-142
1407 4743	Flash Memory - LH28F016SUT-70	95-144
1407 4746	TTLIC - TD74ABT245AF	95-145
1407 4935	IC - 74LCX374 SOP	105-135
1407 4959	IC - MC68334GCFC20	105-136
1407 4959	IC - MC68334GCFC20	95-146
1407 4963	IC - MBM29F800TA-70PFTN	105-137
1407 5037	IC - MSM5412222-25JS	105-138
1407 5038	IC - MSM518222-30JS-1	105-139
1408 0575	IC - M51957BFP	95-147
1408 0575	IC - M51957BFP	105-140
1408 0595	IC - NJM2904M	105-141
1408 0810	IC - BA10358F	99-143
1408 1065	Comparator Ba10339f	99-144
1408 1308	Regulator - PQ3RF33	105-142
1408 1380	IC - CXA2045Q	105-143
1408 1381	IC - CXD2311AR	105-144
1408 1383	Regulator - TA7812F	105-145
1408 1384	Regulator - TA7805F	105-146

Part No.	Description	Page and Index No
1503 0460	Oscillator - 32.768KHZ	105-147
1503 0563	Oscillator-9.83Mhz 040	95-148
1503 0836	Oscillator - 13.5MHZ	105-148
1503 0837	Oscillator - 21.576MHZ	99-145
1503 0841	Oscillator - 38.4KHZ	95-149
1600 1625	Resistor - 100 Ω 1/2W $\pm$ 5%	99-146
1601 5300	Resistor - 10 Ω $\pm$ 5% 2W	105-149
1601 5414	Resistor - 330 Ω $\pm$ 5% 1W	105-150
1601 7801	Resistor Array - 10K Ω $\pm$ 5% 1/16W	99-147
1601 7801	Resistor Array - 10K Ω $\pm$ 5% 1/16W	95-150
1601 7801	Resistor Array - 10K Ω $\pm$ 5% 1/16W	105-151
1601 7805	Resistor Array - 33 Ω $\pm$ 5% 1/16W	95-151
1601 7805	Resistor Array - 33 Ω $\pm$ 5% 1/16W	105-152
1601 7808	Resistor - 4.7k Ω $\pm$ 5% 1/16W	95-152
1601 7808	Resistor - 4.7k Ω $\pm$ 5% 1/16W	99-148
1601 7808	Resistor - 4.7k Ω $\pm$ 5% 1/16w	105-153
1601 7809	Resistor Array - 2.2k Ω 1/16W	99-149
1601 7809	Resistor Array - 2.2k Ω 1/16W	95-153
1601 7822	Resistor Array - 22 Ω $\pm$ 5% 1/16W	95-154
1601 7822	Resistor Array - 22 Ω $\pm$ 5% 1/16W	105-154
1601 7839	Resistor Array - 22K $\pm$ 5% 1/16W	105-155
1601 7851	Resistor - 47K Ω $\pm$ 5% 1/16W	95-155
1602 0987	Capacitor & Coil - 270pF 100V	105-156
1604 2601	Capacitor - 47 μ F $\pm$ 20% 25v	105-157
1605 0738	Capacitor - 0.01 μ F 25V	105-158
1605 0753	Capacitor - 1 μ F +80-20% 25V	105-159
1605 0943	Capacitor - 0.33 μ F +80 -20% 25V	95-156
1605 0992	Capacitor - 1 μ F $\pm$ 20% 16V	105-160
1607 0284	Inductor - BLM31A02PB	105-161
1607 0721	Ferrite Core - TFC-23-11-14	77-109
1607 0721	Ferrite Core - TFC-23-11-14	83-110
1607 0732	Noise Filter - AEF321825-470	95-157
1607 0789	Inductor - BLM11A221SPB	105-162

Part No.	Description	Page and Index No.
1607 0803	Filter - ACF451832-680	105-163
1607 0815	BLM41P600SPB	95-158
1607 0815	BLM41P600SPB	99-150
1607 0973	Inductor - BLM11A121SPB	95-159
1607 0978	Inductor - BLM21P300SPB	95-160
1607 1014	EMI Filter - BLM11P600SPB	105-164
1607 1055	Filter - MEA8020T10R0	105-165
1607 1061	Filter - BLM11P300SPB	95-161
1607 1066	Filter - MEM2012T10R0	105-166
1630 1121	Resistor - 120 Ω ±5% 1/8W	95-162
1630 2121	Resistor - 120 Ω ±5% 1/8W	105-167
1630 3101	Resistor - 100 Ω - 1/10W	105-168
1630 3103	Resistor - 10K Ω 1/10W ±5%	105-169
1630 3104	Resistor - 100K Ω 1/10W ±5%	105-170
1630 3105	Resistor - 1M Ω ±5% 1/10W	105-171
1630 3106	Resistor - 10M Ω ±5% 1/10W	105-172
1630 3152	Resistor - 1.5k Ω - 1/10W	105-173
1630 3154	Resistor - 150K Ω ±5% 1/10W	95-163
1630 3220	Resistor - 22 Ω ±5% 1/10W	105-174
1630 3221	Resistor - 220 Ω ±5% 1/10W	99-151
1630 3222	Resistor - 2.2K Ω 1/10W ±5%	105-175
1630 3223	Resistor - 22k Ω - 1/10W	105-176
1630 3301	Resistor - 300 Ω ±5% 1/10W	105-177
1630 3330	Resistor - 33 Ω ±5% 1/10W	105-178
1630 3331	Resistor - 330 Ω ±5% 1/10W	105-179
1630 3332	Resistor - 3.3K Ω 1/10W ±5%	105-180
1630 3334	Resistor - 330K Ω ±5% 1/10W	105-181
1630 3470	Resistor - 47 Ω 1/10W ±5%	105-182
1630 3472	Resistor - 4.7K Ω 1/10W ±5%	95-164
1630 3472	Resistor - 4.7K Ω 1/10W ±5%	105-183
1630 3511	Resistor - 510 Ω ±5% 1/10W	105-184
1630 3564	Resistor - 560K Ω ±5% 1/10W	105-185
1630 3680	Resistor - 68 Ω ±5% 1/10W	105-186

Part No.	Description	Page and Index No
1630 3680	Resistor - 68 Ω ±5% 1/10W	99-152
1630 3681	Resistor - 680 Ω ±5% 1/10W	105-187
1630 3751	Resistor - 750 Ω ±5% 1/10W	105-188
1630 3752	Resistor - 7.5K Ω ±5% 1/10W	95-165
1630 4100	Resistor - 10 Ω ±5% 1/16W	95-166
1630 4100	Resistor - 10 Ω ±5% 1/16W	99-153
1630 4101	Resistor - 100 Ω ±5% 1/16W	99-154
1630 4102	Resistor - 1.0K Ω ±5% 1/16W	95-167
1630 4102	Resistor - 1.0K Ω ±5% 1/16W	99-155
1630 4103	Resistor - 10K Ω ±5% 1/16W	95-168
1630 4103	Resistor - 10K Ω ±5% 1/16W	99-156
1630 4104	Resistor - 100 Ω ±5% 1/16W	99-157
1630 4105	Resistor - 1.0M Ω ±5% 1/16W	99-158
1630 4105	Resistor - 1.0M Ω ±5% 1/16W	95-169
1630 4106	Resistor -10m Ω ±5% 1/16W	95-170
1630 4112	Resistor - 1.1K Ω ±5.00% 1/16W	99-159
1630 4121	Resistor - 120 Ω ±5% 1/16W	95-171
1630 4202	Resistor - 2k Ω - ±5% -	99-160
1630 4220	Resistor - 22 Ω ±5% 1/16W	95-172
1630 4221	Resistor - 220 Ω ±5% 1/16W	99-161
1630 4221	Resistor - 220 Ω ±5% 1/16W	95-173
1630 4222	Resistor - 2.2k Ω - ±5%	99-162
1630 4222	Resistor - 2.2k Ω - ±5%	95-174
1630 4243	Resistor - 24K Ω ±5% 1/16W	99-163
1630 4330	Resistor - 33 Ω ±5% 1/8W	105-189
1630 4330	Resistor - 33 Ω ±5% 1/8W	99-164
1630 4330	Resistor - 33 Ω ±5% 1/8W	95-175
1630 4334	Resistor - 330K Ω ±5% 1/16W	95-176
1630 4470	Resistor - 470 Ω ±5% 1/16W	99-165
1630 4471	Resistor - 470 Ω ±5% 1/16W	99-166
1630 4471	Resistor - 470 Ω ±5% 1/16W	95-177
1630 4472	Resistor - 4.7K Ω ±5% 1/16W	99-167
1630 4472	Resistor - 4.7K Ω ±5% 1/16W	95-178

Part No.	Description	Page and Index No.
1630 4473	Resistor - 47k Ω - $\pm 5\%$ - 1/16W	95-179
1630 4751	Resistor - 50 Ω $\pm 5.00\%$ 1/16W	95-180
1633 1001	Resistor - 1K Ω $\pm 1\%$ 1/10W	105-190
1633 1002	Resistor - 10K Ω $\pm 1\%$ 1/10W	105-191
1633 1201	Resistor - 1.2K Ω $\pm 1\%$ 1/10W	105-192
1633 1502	Rasistor - 15k Ω $\pm 1\%$ 1/10W	105-193
1633 2001	Resistor - 2K Ω $\pm 1\%$ 1/10W	105-194
1633 2201	Resistor - 2.2 Ω $\pm 1\%$ 1/10W	105-195
1633 3901	Resistor - 3.9 Ω $\pm 1\%$ 1/10W	105-196
1633 3921	Resistor - 3.92k Ω - $\pm 1\%$ - 1/10W	105-197
1633 4700	Resistor - 470 Ω - $\pm 1\%$ - 1/10W	105-198
1633 4701	Resistor - 4.7K Ω $\pm 1\%$ 1/10W	105-199
1633 5600	Resistor - 560 Ω $\pm 1\%$ 1/10W	105-200
1633 8201	Resistor - 8.2k Ω $\pm 1\%$ 1/10W	105-201
1634 0000	Resistor - 0 Ω - 1/16W	95-181
1634 1002	Resistor - 10 Ω $\pm 5\%$ 1/16W	95-182
1634 1003	Resistor - 100K Ω $\pm 1\%$ 1/16W	95-183
1634 1003	Resistor - 100K Ω $\pm 1\%$ 1/16W	99-168
1634 3921	Resistor - 3.92K Ω $\pm 1\%$ 1/1	95-184
1634 5231	Resistor - 5.23K Ω $\pm 1\%$ 1/16W	95-185
1640 2101	Capacitor - 100 μ F $\pm 20\%$ 25V	95-186
1640 2470	Capacitor - 47 μ F $\pm 20\%$ 25V	95-187
1640 3101	Capacitor - 100 μ F $\pm 20\%$ 35V	105-202
1640 5101	Capacitor - 100 μ F $\pm 20\%$ 50V	105-203
1640 5101	Capacitor - 100 μ F $\pm 20\%$ 50V	99-169
1642 0221	Capacitor - 220 μ F $\pm 20\%$ 10V	105-204
1642 2470	Capacitor - 47 μ F $\pm 20\%$ 25V	105-205
1642 5330	Capacitor - 33 μ F $\pm 20\%$ 50V	99-170
1643 0470	Capacitor - 47 μ F $\pm 20\%$ 10V	105-206
1643 5100	Capacitor - 10 μ F $\pm 20\%$ 50V	99-171
1644 0100	Capacitor - 10 μ F $\pm 20\%$ 10V	105-207
1644 2330	Capacitor - 33 μ F $\pm 20\%$ 25V	105-208
1660 1100	Capacitor - 10pF 50V	105-209

Part No.	Description	Page and Index No
1660 2101	Capacitor - 100pF - $\pm 10\%$ - 50V	95-188
1660 2120	Capacitor - 12 pF $\pm 5\%$ 50V	95-189
1660 2220	Capacitor - 22pF $\pm 20\%$ 35V	95-190
1660 2470	Capacitor - 47pF $\pm 5\%$ 50V	95-191
1660 2471	Capacitor - 470pF - $\pm 5\%$ - 50V	95-192
1660 3180	Capacitor - 18pF $\pm 5\%$ 50v	99-172
1660 3220	Capacitor - 122pF $\pm 5\%$ 50V	105-210
1660 3391	Capacitor - 390 pF $\pm 5\%$ 50V	105-211
1660 4102	Capacitor - 1000pF $\pm 10\%$ 50V	95-193
1660 4103	Capacitor - 10000pF - $\pm 10\%$ - 50V	99-173
1660 6103	Capacitor - 10000pF - +80%-20%, 50V	95-194
1660 7103	Capacitor - 10000pF 50V	105-212
1660 7104	Capacitor - 100000pF 50V	99-174
1660 8104	Capacitor - 0.1 μ F +80-20% 25V	99-175
1660 8104	Capacitor - 0.1 μ F +80-20% 25V	95-195
1660 9104	C - 0.1 μ F 25V	105-213
1902 0039	IC - SRAM 1M X16 70NS G1	105-214
1903 0024	IC - 16M 1MX16 60NS G6	95-196
1903 1009	IC - DRAM 16M 4MX4 60NS EDO G2	105-215