
## **Quick Reference Printer Guide**

# ⇒Please use this guide from behind your PC<</p>



### How to use Web Image Monitor...

- **1** Start a Web browser.
- 2 Enter the IPv4 address of your machine as a URL.
- **E** Choose from one of the following functions:
- Home
- Document Server
- Printer: Print Jobs Job
- Configuration

#### Why use it?

- To have access to the machine anywhere via the web.
- To manage certain functions from your pc, which is easier to use.

#### How to monitor your machine in the network...

- Use SmartDeviceMonitor, which is automatically installed with your printer drivers.
- **1** Right-click the green PC icon at the bottom of your screen.
- **2** Select [Properties], [Option...], [Network Devices] and press [Browse...].
- **B** Select your machine and press [OK].
- Select a machine in [Printers Folder] and select [To be monitored]. Select [Displayed on Task Bar].
- If you select this machine from the SmartDeviceMonitor icon, you can see the [Status], [Configuration] and [Job History]. Next time you print, you get a message on your pc in case of any failure.