## Notes for Users

The following are revisions to the operating instructions. Refer to the following information in place of the information presented in the original operating instructions.

## The DDST driver and TWAIN driver support Windows XP/Vista/7 and Windows Server 2003/2008.

When installing either driver in Windows Vista/7 or Windows Server 2008, follow the instructions from the launcher. For how to use the driver, see the Help.

