

Model Founder FA318/FA320L (B282-69/B283-69) PARTS CATALOG

First edition, August 2011

Ricoh Company, LTD.

Model Founder FA318/FA320L (B282-69/B283-69)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

CONTENTS

Model Founder FA318/FA320L	(B282-69/B283-69)
ADF DF2000	(B813)
ARDF DF2010	(B814)
Platen Cover Type 1080	(B406)
PS460/Grip	(B385/B274)
PS450/Grip	(B384/B274)

Model Founder FA318/FA320L
(B282-69/B283-69)

Model Founder FA318/FA320L (B282-69/B283-69)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

CONTENTS


CONTENTS (Continued)

Location of Unit	2	17.Duplex Unit 1 (B282).....	40
1.Exterior 1 (B282/B283)	8	18.Duplex Unit 2 (B282).....	42
2.Operation Panel (B282/B283)	10	19.Duplex Unit 3 (B282).....	44
3.Optics Section 1 (B282/B283)	12	20.Drive Section (B282/B283)	46
4.Optics Section 2 (B282/B283)	14	21.Electrical Section 1 (B282/B283)	48
5.Optics Section 3 (B282/B283)	16	22.Electrical Section 2 (B282/B283)	50
6.Laser Unit (B282/B283)	18	23.Frame Section 1 (B282/B283)	52
7.By-pass Feed Section (B282/B283)	20	24.Frame Section 2 (B282/B283)	54
8.Paper Cassette (B282/B283).....	22	25.GDI Unit (B282/B283).....	56
9.Paper Registration (B282/B283).....	24	26.Decals and Documents (B282/B283)	70
10.1st Paper Feed Section (B282/B283).....	26	27.Special Tools (B282/B283)	72
11.Vertical Transport (B283)	28	Parts Index.....	76
12.PCU 1 (B282/B283)	30		
13.PCU 2 (B282/B283)	32		
14.Toner Supply Unit (B282/B283).....	34		
15.Fusing Unit (B282/B283)	36		
16.Paper Exit Section (B282/B283).....	38		

August 23, 2011


LOCATIONS OF UNITS

1. Exterior 1 (B282/B283)




See Page 9

2. Operation Panel (B282/B283)




See Page 11

3. Optics Section 1 (B282/B283)




See Page 13

4. Optics Section 2 (B282/B283)




See Page 15

5. Optics Section 3 (B282/B283)



See Page 17


6. Laser Unit (B282/B283)



See Page 19


LOCATIONS OF UNITS

7. By-pass Feed Section (B282/B283)




See Page 21

8. Paper Cassette (B282/B283)




See Page 23

9. Paper Registration (B282/B283)




See Page 25

10. 1st Paper Feed Section (B282/B283)




See Page 27

11. Vertical Transport (B283)



See Page 29


12. PCU 1 (B282/B283)



See Page 31


LOCATIONS OF UNITS

13. PCU 2 (B282/B283)




See Page 33

14. Toner Supply Unit (B282/B283)




See Page 35

15. Fusing Unit (B282/B283)




See Page 37

16. Paper Exit Section (B282/B283)




See Page 39

17. Duplex Unit 1 (B282)



See Page 41


18. Duplex Unit 2 (B282)



See Page 43


LOCATIONS OF UNITS

19. Duplex Unit 3 (B282)




See Page 45

20. Drive Section (B282/B283)




See Page 47

21. Electrical Section 1 (B282/B283)




See Page 49

22. Electrical Section 2 (B282/B283)




See Page 51

23. Frame Section 1 (B282/B283)




See Page 53

24. Frame Section 2 (B282/B283)




See Page 55

LOCATIONS OF UNITS

25. GDI Unit (B282/B283)  See Page 57		

1.Exterior 1 (B282/B283)




1.Exterior 1 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B121 1316	Left Cove NA	1
2	B276 1332	Cover:Scanner:Left:NA	1
3	D100 1355	Cover:Exit:C3-DOM	1
4	B039 1333	Rear Scanner Cover	1
5	B277 1370	Cover:Exit:Rear:C:NA (B282)	1
5	B276 1368	Cover:Exit:Rear:B:NA (B283)	1
6	B277 1339	Cover:Rear:C:NA (B282)	1
6	B121 1337	Rear Cover NA (B283)	1
7	B121 1313	IC Card Cap	1
8	B121 1348	Paper Bank Cap	1
9	B276 1335	Cover:Scanner:Right:NA	1
10	B277 1347	Cover:Right Rear:C:NA (B282)	1
10	B039 1347	Right Rear Cover (B283)	1
11	B277 1310	Cover:Right Upper Front:C:NA (B282)	1
11	B039 1339	Cover - Front Right Upper (B283)	1
12	B282 1352	Cover:Front:CHN	1
13	B259 1367	Cover Magnet	2
14	B039 1361	Magnet Catch	2
15	B276 1338	Front Door - CNH	1
16	B282 0482	Model Name Plate:B282-69:FOU	1
16	B283 0482	Model Name Plate:B283-69:FOU	1
17	B277 1372	Cover:Sorter:NA (B282)	1
18	B039 1365	Sheet - Operation Instructions	1
19	B039 1367	Rivet - M6	2
20	B039 1364	Rivet - M7	1
21	B122 1323	Left Upper Cover (B282)	1
21	B121 1322	Left Upper Cover B (B283)	1
22	B132 1531	Panel:Logo	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	

2.Operation Panel (B282/B283)




2.Operation Panel (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B243 1468	Cover - CPS EU	1
2	B243 1451	Case:Operation Sub-unit	1
3	B282 1485	PCB:Duplex:GW-C3D	1
4	B282 1417	Operation Sub-unit:Base: Duplex:GW-C3D:Ass'y	1
4	B283 1427	Operation Sub-unit:Base:GW-C3:Ass'y	1
5	B276 1452	Cover:Operation Sub-Unit:Lower	1
6	B243 1425	Cover - Operation Panel	1
7	B039 1469	Ground Plate	2
8	B229 1453	Keytop - Start	1
9	B229 1454	Keytop - Clear/Stop	1
10	B229 1475	Keytop - 10key	1
11	B229 1525	Keytop-INITIAL	1
12	B229 1537	Keytop - Clear Modes	1
13	B243 1458	Keytop - Power Source	1
14	B243 1459	Keytop - Cursor	1
15	B259 1499	Tapping Screw - M3x8	18
16	B282 1454	Sheet:Operation Sub-unit:Duplex (B282)	1
16	B283 1454	Sheet:Operation Sub-unit:One Side (B283)	1
17	B229 1522	Sheet-Power Source-EU	1
18	B243 1469	Keytop:CPS:EU	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0353 0050N	Screw-M3x5	

3.Optics Section 1 (B282/B283)




3.Optics Section 1 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B390 1759	Shaft:Scale	5
2	B268 1749	Scale - Left	1
3	B039 1710	Left Scanner Bracket	1
4	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
5	A193 1705	Sheet:Photointerruptor	1
6	GW02 0020	Photointerruptor:LG248NL1	1
7	A250 1822	Heater - 9W	1
8	B276 1808	Inner Cover:Lens	1
9	B259 1813	Holder:Lens:Ass'y	1
10	A250 1752	Exposure Glass	1
11	B268 1751	Scale - Inner Back	1
12	B039 1666	Bracket - Operation Panel	1
13	B243 1804	Harness - FFC	1
14	B039 1712	Right Scanner Bracket	1
15	5442 1924	Exposure Glass Cushion	2
16	B039 1658	Rear Scale Bracket	1
17	B121 1069	Support Bracket	1
18	B039 1068	ADF Bracket	1
19	B238 1845	Seal:Exposure Glass	2
20	A193 1752	White Sheet	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0454 3006Q	Tapping Screw - M3x6	

4.Optics Section 2 (B282/B283)




4.Optics Section 2 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B039 1796	Mirror:No.2:Ass'y	2
2	B039 1781	2nd Mirror Holder	4
3	B039 1785	Scanner Drive Pulley	4
4	B121 1782	Flexible Board Guide	1
5	B259 1768	Carriage No.2 Ass'y	1
6	B039 1784	Scanner Drive Belt	2
7	B259 1778	Idler Belt Pulley Bracket - Rear	1
8	B039 1790	Tension Spring	2
9	B259 1776	Idler Belt Pulley Bracket - Front	1
10	B121 1757	Xenon Lamp MM8 26000/70	1
11	B039 1758	Timing Belt Holder - Front	1
12	B121 1754	Carriage:No.1:Ass'y	1
13	B039 1759	Timing Belt Holder - Rear	1
14	B121 1766	No.1 Mirror Clamp	2
15	B121 1763	Mirror:No.1	1
16	B259 1763	Xenon Lamp Stabilizer	1
17	B259 5223	Harness - Stabilizer	1
18	G570 2730	Slider - Scanner	8

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	

5.Optics Section 3 (B282/B283)




5.Optics Section 3 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B039 1663	Rear Scanner Frame	1
2	B039 1662	Front Scanner Frame	1
3	B039 1703	Pulley - 37Z	2
4	B039 1705	Bracket:Idler	2
5	B039 1704	Spring - Timing Pulley	2
6	B121 1667	Lens Stay Bracket	2
7	B039 1649	Timing Belt:S1.411M:1058	2
8	B121 1697	Timing Belt:L147	1
9	B039 1695	Flange - Pulley	1
10	B039 1694	Pulley - 37/41Z	1
11	B259 1691	Scanner Drive Shaft	1
12	B039 1692	Pulley - 37Z	1
13	B039 1668	Bracket - Stabilizer Harness	1
14	B121 1664	Bracket - Timing Belt	2
15	B039 1699	Stepper Motor:MM42:2.9W	1
16	B259 1702	Pulley Shaft	2
17	B039 1683	Tension Spring - Stepper Motor	1
18	B121 1680	Gear - 53Z/60Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0454 3006Q	Tapping Screw - M3x6	
103	1105 0511	Harness Clamp - LWS-0306ZC	
104	1105 0487	Harness Clamp	
105	0805 3530	Bearing 8x22x7	
106	0720 0060E	Retaining Ring - M6	
107	0360 3006P	Screw - M3x6	
108	0453 3006N	Tapping Screw - M3x6	
109	0313 0060N	Screw - M3x6	

6.Laser Unit (B282/B283)




6.Laser Unit (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B276 1251	Cover:Shield Glass	1
2	B039 1905	Adjusting Plate	1
3	B259 2381	Discharge Lamp - QL	1
4	B121 5204	Harness - Discharge Lamp	1
5	B039 1088	Sheet - Duct	1
6	B283 1961	Shield Glass:Ass'y	1
7	B283 1981	Decal:LD	1
8	AC03 0139	Sync Detector Mirror	1
9	AC02 4009	Cylindrical Lens	1
10	B039 1942	Cylindrical Lens Holder	1
11	B039 1954	Holder - Sync Detector Mirror	1
12	B283 1971	Optical Housing Cover	1
13	B121 5439	Harness - Polygon Mirror Motor	1
14	B121 5250	Harness - LDD	1
15	B276 1917	Laser Diode Unit:Ass'y	1
16	AX06 0323	Polygon Motor - 23622RPM	1
17	AC03 0138	2nd Mirror	1
18	B039 1953	2nd Mirror Holder	2
19	AC02 0095	Sync Detector Lenz	1
20	B121 1975	Rubber Bushing	2
21	B283 1876	Imaging Unit:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3010N	Binding Self-Tapping Screw:3x10	
102	0450 3012N	Tapping Screw:3x12	
103	0450 3020N	Tapping Screw:M3x20	
104	0452 3014N	Binding Self-Tapping Screw:M3x14	

7.By-pass Feed Section (B282/B283)




7.By-pass Feed Section (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B039 2631	Front Side Fence	1
2	B039 2628	Bottom Plate Pad	1
3	B039 2632	Rear Side Fence	1
4	B039 2630	Tray Bottom Plate	1
5	B039 2638	Rack - Rear Side Fence	1
6	B039 2637	Rack - Front Side Fence	1
7	G012 3050	Side Fence Gear	1
8	AA06 3643	Spring - By-pass Feed Table	2
9	B039 2645	Rotary Switch	1
10	B039 2629	Stay - Tray Bottom Plate	1
11	B039 2620	Paper Guide - Extension	1
12	B039 2621	Paper Guide	1
13	B121 2617	Magnet Catch - By-pass Feed	1
14	B039 2619	By-pass Feed Table	1
15	G020 2784	Lever - By-pass Feed Table	1
16	B039 2643	Link - By-pass Feed Table	2
17	B039 2633	Decal - By-pass Feed	1
18	5447 2681	Snap Ring	3
19	B259 2642	Pin - MM6	2
20	B259 2786	Lever Shaft	1
21	B259 2602	Manual Feed Table Ass'y	1
22	B238 2753	Decal - Side Fence	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	

8. Paper Cassette (B282/B283)




8.Paper Cassette (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B245 2840	Paper Tray:PD-C2:Ass'y	1
1	B276 2644	End Fence	1
2	B039 2704	Front Stopper Lever	1
3	B039 2701	Tray Bottom Plate	1
4	B039 2707	Spring Plate - Side Fence	1
5	B039 2734	Side Fence - Front	1
6	5215 2621	Snap Ring - M6	1
7	B039 2712	Ground Plate - Tray Bottom Plate	1
8	B039 2731	Side Fence - Rear	1
9	B039 2821	Rear Stopper Lever	1
10	B259 2737	Paper Feed Roller Shaft Ass'y	1
11	B039 2740	Paper Feed Roller	1
12	A267 2869	Gear - 16Z	1
13	B276 2719	Spring:Base:5.8N	1
14	B039 2742	Ground Plate - Paper Feed Roller	1
15	B039 2823	Joint - Paper Feed Roller	1
16	B039 2727	Bushing - 8x12x10	2
17	B039 2732	Spring - Paper Feed Roller	1
18	B039 2711	Friction Pad	1
19	B039 2713	Spring - Friction Pad	1
20	B039 2827	Paper Size Sensor Board	1
21	A250 2808	Stopper Base	1
22	G020 2599	Spring - Release Lever	1
23	B039 2739	Shaft - Joint	1
24	B243 2701	Paper Tray	1
25	B039 2721	Decal - Cassette Operation	1
26	B243 2702	Cover - Paper Tray	1
27	5215 2713	Bottom Plate Pad	1
28	B039 2778	Paper Size Detector - A4	1
29	B039 2706	Front Side Fence	1
30	B039 2705	Rear Side Fence	1
31	B276 2646	Rubber Bushing	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 0088	Retaining Ring - M6	
102	0450 3008N	Tapping Screw - M3x8	

9. Paper Resistration (B282/B283)



9. Paper Resistration (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B039 2575	Bracket - Registration Roller	1
2	AA06 2254	Registration Roller Spring	2
3	5447 2681	Snap Ring	2
4	AB01 2312	Gear - 16Z	1
5	AA08 0342	Fornt Bushing-registration Roller	1
6	AA08 0267	Bushing - 8x12x18	1
7	AB01 2311	Gear - 18Z	1
8	AA10 0015	Snap Ring - M6	2
9	B121 3804	Transfer Unit	1
10	AA06 6342	Registration Sensor Spring	1
11	B039 2570	Registration Feeler	1
12	B039 2567	Guide - Right Registration Roller	1
13	GW02 0020	Photointerruptor:LG248NL1	1
14	B121 5202	Harness - Registration Sensor	1
15	B039 2560	Registration Cleaning Mylar	1
16	B039 2572	Guide - Left Registration Roller	1
17	B039 2558	Driven Roller	1
18	B259 2571	Registration Roller Driven - DIA16	1
19	B259 2562	Registration Roller Drive	1
20	B039 1130	Development Sensor Bracket	1
21	B121 5248	Harness - Development Sensor	1
22	AA08 0343	Rear Bushing-registration Roller	1
23	AA08 2110	Bushing - 8x12x22	1
24	AA06 3607	Pressure Spring	4
25	B039 3820	Transfer Roller	1
26	B259 3890	Density Sensor	1
27	B039 3891	ID Sensor Cover	1
28	B259 1131	Screw:PCU	2
29	B121 5206	Harness - Density Sensor	1
30	B039 3866	Pressure Cover	2
31	B039 3867	Roller - Transfer Unit	2
32	B039 3863	Quenching Terminal Plate	1
33	B043 2554	Registration Guide Spacer	1
34	B121 3860	Harness Cover	1
35	B039 3864	Quenching Terminal Plate-front	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	B039 3865	Transfer Terminal Plate	1
37	B120 3862	Front Discharge Brush	1
101	0450 3008N	Tapping Screw - M3x8	
102	0450 3012N	Tapping Screw:3x12	
103	1105 0522	Edge Saddle - LES0510	

This diagram illustrates the exploded view of a mechanical assembly, showing various components and their assembly sequence. The parts are numbered as follows:

- 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37


The assembly includes a main frame (1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37) and a motor (26). The motor is connected to a gear train (24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37) which drives the main frame. The diagram shows the assembly sequence from the motor and gear train to the main frame and its various components.

10.1st Paper Feed Section (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B039 2754	Bracket - Paper Size Sensor	1
2	G800 3035	Push SW - Paper Size	1
3	B039 2736	Bracket - Paper End Sensor	1
4	B039 2730	Paper End Sensor	1
5	B121 5215	Harness - Paper End Sensor No.1	1
6	5447 2681	Snap Ring	2
7	B039 2585	Exit Guide Plate	1
8	B039 1142	Housing - Paper Feed	1
9	B039 2766	Guide Plate - Transport Roller	1
10	B039 2797	Guide Plate - Transport Roller	1
11	B039 2558	Driven Roller	2
12	B039 2795	Guide Plate - Transport	1
13	B039 2825	Ground Plate - Vertical Transport	1
14	B276 1151	Magnetic Clutch:0.5N m:Z31	1
15	AA08 2101	Bushing - 6x10x6	5
16	B276 2576	Transport Roller	1
17	B039 2583	Vertical Transport Feeler	1
18	B259 1194	Manual Feed Drivebracket	1
19	B039 1191	Gear - 19Z	1
20	B259 1190	Shaft - Drive Manual Feed	1
21	B276 1183	Shaft:Paper Feed:Drive:Ass'y	1
22	B121 1188	Bushing	1
23	B259 1178	Paper Feed Drive Bracket	1
24	B039 1187	Gear - 30Z	1
25	B039 1186	Gear - 46Z	1
26	B276 1150	Magnetic Clutch:Paper Feed:Drive:Ass'y	1
27	B039 2813	Lower Bracket - Relay Sensor	1
28	B039 2812	Upper Bracket - Relay Sensor	1
29	GW02 0020	Photointerruptor:LG248NL1	1
30	B282 5201	Harness:Registration Sensor:5V (B282)	1
31	B039 1193	Bushing - By-pass Feed	1
32	B039 1199	Spring - By-pass Feed	1
33	B276 1192	Gear:Idler:Connecting	1
34	B039 2830	Right Rail	1
35	B276 1152	Magnetic Clutch:Manual Feed:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	B039 2587	Mylar - Exit Guide Plate	1
37	B039 2834	Decal - Exit Paper Feed	1
101	0451 3006N	Tapping Screw - 3x6	
102	0454 3006Q	Tapping Screw - M3x6	
103	0720 0040E	Retaining Ring - M4	
104	0805 0097	Ring Separator	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	0450 3008N	Tapping Screw - M3x8	
107	1105 0487	Harness Clamp	
108	0457 3006N	Tapping Screw:WP:3x6	

11.Vertical Transport (B283)




11.Vertical Transport (B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF02 2138	Vertical Transport Roller	1
2	AA08 0268	Bushing - Vertical Transport	2
3	AA06 3399	Spring - Vertical Transport	2
5	B039 2653	Vertical Transport Guide	1
6	B039 2592	Lower Guide Plate - By-pass Feed	1
7	AA06 3398	Spring - Friction Pad	1
8	G030 2670	Friction Pad (B283)	1
8	B039 2596	Friction Pad (B282)	1
9	A232 3962	Spring Plate - Band Stopper	1
10	B039 2660	Band - Right Door	1
11	B039 2594	Upper Guide Plate - By-pass Feed	1
12	B259 2594	Shaft - Feed	1
13	AB01 2313	Gear - 25Z	1
14	B121 4470	Right Lower Exit Guide Plate	1
15	B259 2609	Paper End Sensor:Manual Feed:Ass'y	1
16	B039 2658	Sponge - By-pass Feed	2
17	AF03 1060	By-pass Feed Roller	1
18	AA08 2101	Bushing - 6x10x6	2
19	B039 2610	Bracket - Paper End Sensor	1
20	AA06 6343	Spring - Paper End Sensor	1
21	B039 2611	Feeler - Paper End Sensor	1
22	GW02 0020	Photointerruptor:LG248NL1	1
23	B121 5259	Harness - Paper End Sensor	1
24	B039 4480	Stepped Screw - M5	2
25	A250 1388	Spring	1
26	B039 2651	Right Door Lever	1
27	B039 2670	Right Door	1
28	B039 2558	Driven Roller	2
29	B039 4488	Jam Removal Decal	1
30	B259 2648	Door:Right:C2B:Ass'y	1
31	AG07 0514	Magnet Catch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	0451 3006N	Tapping Screw - 3x6	
103	0720 0040E	Retaining Ring - M4	

12.PCU 1 (B282/B283)




12.PCU 1 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B282 2211	PCU:Gratwall-C4:EXP:Ass'y	1
1	B259 2371	Rear Drum Stay	1
2	A267 3440	Development Joint	1
3	B039 2361	Front Side Plate - Drum	1
4	B039 2367	Drum Shutter Spring	1
5	B039 2362	Drum Shutter Gear	1
6	B282 3051	Development Roller:Ass'y	1
7	B039 3159	Case:Development Roller:Ass'y	1
8	B259 3170	Development Case Ass'y	1
9	B039 3062	Idler Gear - 16Z	2
10	B259 3390	Density Sensor:K-C2.5:Ass'y	1
11	B039 3245	Gear - 15Z	2
12	B039 3060	Development Roller Gear	1
13	B121 9640	Developer Type 28 Black	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0360 3006N	Screw - M3x6	
102	0452 3008N	Tapping Screw - M3x8	

13.PCU 2 (B282/B283)




13.PCU 2 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B121 2311	PCU Toner Supply Shutter	1
2	B039 2312	Shutter Spring	1
3	B039 2343	Drum Shutter	1
4	B039 2293	Pin - Front Pressure Arm	1
5	B039 2272	Recycled Toner Coil	1
6	B039 2321	Front PCU Cover	1
7	B039 2274	Recycled Toner Plate	1
8	B121 2313	Toner Supply Seal	1
9	B039 2276	Rear Bushing - Toner Coil	1
10	B039 2350	Clip - OPC Drum	1
11	AA14 3444	Stepped Screw	1
12	AB01 1403	Gear - 13Z	1
13	AB01 1402	Gear - 14Z	1
14	B039 2335	Pickoff Pawl	2
15	AD04 2059	Cleaning Blade Ass'y	1
16	B039 2288	Cam - Cleaning Blade	1
17	B039 9510	OPC Drum	1
18	B039 2295	Rear Pressure Arm - Charge Roller	1
19	B039 2287	Charge Roller Spring	2
20	B039 2292	Front Pressure Arm - Charge Roller	1
21	AD02 7018	Roller:Charge:A3	1
22	AD04 2058	Charge Cleaner Brush Roller	1
23	B259 2325	OPC Drum Shutter Plate	1
24	B039 2329	Spacer - M3	2
25	B039 2265	Shield:Frame:Lower	1
26	B282 2252	Frame:PCU:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060N	Bind Screw - M3x6	
102	0452 3012N	Binding Self-Tapping Screw:M3x12	
103	0736 0610	Bushing 6x10	

14.Toner Supply Unit (B282/B283)




14.Toner Supply Unit (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B259 3031	Toner Supply Unit	1
2	B039 3360	Cam - Handle	1
3	A184 3420	Bottle Chuck	1
4	A184 3421	Chuck Shaft	1
5	B259 3422	Shaft:Slide	1
6	B039 1141	Shaft - Paper Feed Frame	1
7	A267 3556	Chuck Spring - Tonner Bottle	1
8	G020 3334	Slider Ass'y	1
9	B243 5233	Harness - High Voltage Line C/T	1
10	B039 3870	Terminal - Transfer	1
11	B039 2578	Grounding Plate	1
12	B039 3381	Cover:Toner Bottle:Ass'y	1
13	B121 5219	Harness - Ground Wire	1
14	B039 2382	Quenching Lamp Terminal	1
15	B039 3392	Guide Plate - Tonner Supply Unit	1
16	B039 3395	Ground Plate - Toner Supply Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	0452 3008N	Tapping Screw - M3x8	
103	0450 3010N	Tapping Screw - M3x10	
104	1105 0511	Harness Clamp - LWS-0306ZC	

15.Fusing Unit (B282/B283)




15.Fusing Unit (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B283 4006	Fusing Unit:Panda-C4:Ass'y	1
1	B039 4102	Fusing Exit Guide	1
2	AA14 3870	Stepped Screw	2
3	AW10 0073	Thermistor	1
4	B039 4118	Front Ground Plate	1
5	B039 4120	Thermostat	1
6	B283 4103	Frame:Fusing	1
7	A232 2374	Spur	4
8	AA06 6637	Stripper Pawl Spring	5
9	AE04 4062	Stripper Pawls	5
10	B245 4115	Electrode Plate:Front	1
11	B121 4120	Thermostat Ass'y	1
12	B121 4113	Short Electrode Plate	1
13	B245 4112	Electrode Plate:Middle	1
14	B245 4114	Electrode Plate:Rear	1
15	B039 4140	Rear Holder	1
16	B039 4112	Fusing Lamp - 230V 700W	1
17	G029 4140	External Circlip	2
18	B039 4171	Gear - 41Z	1
19	G052 4618	Bearing 30x42x7	2
20	B245 4052	Hot Roller	1
21	B039 4138	Front Holder	1
22	AE02 0100	Pressure Roller	1
23	B039 4107	Fusing Exit Door	1
24	AA06 6635	Spring - Fusing Exit Guide	1
25	B039 4135	Pressure Roller Lever	2
26	AA06 6640	Pressure Spring	2
27	G029 4174	Pressure Roller Bushing	2
28	B245 4054	Frame:Pressure:Printing	1
29	B039 4170	Stripper Pawls Roller	5
30	B259 4115	Fusing Entrance Guide Plate	1
31	B039 4117	Discharge Brush	1
32	B039 4114	Rear Ground Plate	1
33	B039 4168	Stripper Pawlsstopper	5

Index No.	Part No.	Description	Q'ty Per Assembly
101	0804 6123	Hexagonal Bolt:W/Washer:M3x8	
102	0954 3010N	Screw:Polished Round/Spring:M3x10	
103	0452 3008N	Tapping Screw - M3x8	
104	0313 0060N	Screw - M3x6	
105	0954 4008N	Screw - M4x8	

16.Paper Exit Section (B282/B283)




16.Paper Exit Section (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B121 1084	Heater Wire Cover	1
2	B123 1302	Fusing Cover:Paper Exit Sub-unit: Duplex (B282)	1
2	B039 1239	Fusing Cover:Paper Exit Sub-unit: One Side:Sub-Ass'y (B283)	1
3	B259 4471	Exit Roller 2	1
4	B039 4473	Ring:Exit Roller	4
5	B120 2063	Bushing - 4mm	2
6	B039 1082	Door Switch Bracket	1
7	B282 5205	Harness:Door Switch:Front	1
8	B039 1096	Door Switch Lever - 7	1
9	B039 1123	Door Switch Lever - 8	1
10	B039 1095	Door Switch Lever - 6	1
11	B039 1094	Door Switch Lever - 5	1
12	B039 1098	Door Switch Spring	1
13	B039 1093	Door Switch Lever - 4	1
14	B039 1092	Door Switch Lever - 3	1
15	B039 1099	Door Switch Lever - 2	1
16	B039 1090	Door Switch Lever - 1	1
17	B039 4119	Fusing Grounding Harness	1
18	B039 4116	Ground Plate - Fusing Unit	1
19	B121 4503	Exit Photointerruptor Bracket	1
20	B121 4451	Exit Middle Guide Plate	1
21	B121 5238	Harness - Paper Feed Sensor	1
22	G361 5570	Photointerruptor - Duplex	1
23	B043 4979	Exit Roller	4
24	B261 4983	Gate Pawl	1
25	AA06 6641	Gate Pawl Spring	1
26	B039 1163	Pulley - 23Z	1
27	B121 1132	Fusing Drive Release Bracket	1
28	B122 4460	Lower Exit Guide Plate	1
29	B121 4473	Exit Roller Ring MM14	2
30	B268 1085	Switch:LF-105-11	2
31	G052 4873	Outer Exit Cover Roller	4
32	B121 4465	Short Front Outer Holder	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	B121 4469	Long Rear Middle Holder	1
34	B121 4477	Short Rear Outer Holder	1
35	B121 4467	Long Front Middle Holder	1
36	B121 4461	Exit Lower Guide Plate	1
37	G029 4176	Turn Roller - Exit Sub-unit	2
38	B039 4459	Exit Roller Holder - Inner	2
39	G800 4854	Exit Roller	2
40	B123 4508	Middle:Reverse Holder	2
41	B122 4492	Large Exit Discharge Brush	2
42	B122 4493	Small Exit Discharge Brush	2
43	B121 1126	Harness Guide	1
101	0450 4010N	Tapping Screw:M4x10	
102	0450 3008N	Tapping Screw - M3x8	
103	0451 3006N	Tapping Screw - 3x6	
104	0450 3012N	Tapping Screw:3x12	
105	0720 0030E	Retaining Ring - M3	

17.Duplex Unit 1 (B282)




17.Duplex Unit 1 (B282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF02 2138	Vertical Transport Roller	1
2	AA08 0268	Bushing - Vertical Transport	2
3	AA06 3399	Spring - Vertical Transport	2
4	B039 2558	Driven Roller	2
5	B282 4662	Guide Plate-Vertical Transport	1
6	B043 4676	Bracket - Duplex Entrance Sensor	1
7	G060 2641	Transport Driven Roller - Middle	3
8	AA08 0313	Driven Roller Bushing	6
9	B043 4647	Lower Spring Plate - Driven Roller	1
10	B123 4675	Exit Duplex Sensor Bracket	1
11	B039 4480	Stepped Screw - M5	2
12	B123 4640	Driven Duplex Guide Plate Ass'y	1
13	B043 4642	Stopper - Guide Plate	1
14	B123 4670	Right Lower Exit Guide Plate Ass'y	1
15	B043 4692	Grip Decal	1
16	B123 5245	Harness:Duplex:Ground Wire	2
17	B123 4691	Decal	1
18	B043 4645	Spring - 2N	2
19	B043 4646	Upper Spring Plate - Driven Roller	1
20	B043 4651	Door Lever	1
21	A250 1388	Spring	1
22	B043 4671	Bracket - Upper Guide Plate	2
23	B123 4679	Exit Sensor Cover	1
24	B043 4674	Cover - Duplex Entrance Sensor	1
25	B123 4977	Right Upper Exit Guide Plate Ass'y	1
26	B123 4617	Entrance Duplex Guide Plate	1
27	AW02 0181	Paper Feed Sensor	2
28	B282 2655	Guide:Vertical Transport	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	0451 3006N	Tapping Screw - 3x6	
103	1105 0511	Harness Clamp - LWS-0306ZC	

18.Duplex Unit 2 (B282)




18.Duplex Unit 2 (B282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B043 4609	Duplex Lower Stay	1
2	B282 4710	Stepper Motor:Ass'y	1
3	B043 4667	By-pass Feed Guide - Lower	1
4	B043 4685	Spring - 2.8N	1
5	B261 4650	Separation Pad	1
6	B261 4624	Transport Roller:Drive:Duplex:Exit	1
7	B261 4623	Transport Roller - Connecting	1
8	B261 4625	Transport Roller:Drive:Duplex:Entrance	1
9	B043 4684	By-pass Feed Guide - Upper	1
10	B039 2610	Bracket - Paper End Sensor	1
11	B123 5252	Harness - Duplex Paper End Sensor	1
12	GW02 0020	Photointerruptor:LG248NL1	1
13	B039 2611	Feeler - Paper End Sensor	1
14	AA06 6343	Spring - Paper End Sensor	1
15	AF03 1060	By-pass Feed Roller	1
16	B261 4686	Manual Feed Drive Shaft	1
17	AA08 2101	Bushing - 6x10x6	8
18	B043 4624	Pulley - 30Z	1
19	B123 4505	Timing Belt - 40S2M290	2
20	AB03 0569	Pulley - 30T	2
21	B043 4698	Cap - 30x36	1
22	B123 4661	Rear Duplex Inner Cover	1
23	B043 4714	Gear - 25Z	1
24	B043 4633	Gear - 22Z	1
25	B043 4713	Gear - 25Z	1
26	B043 4631	Gear - 38Z	1
27	B123 4697	Tension Spring 27N	1
28	B123 4627	Adhesion Duplex Cover	1
29	B123 5241	Harness - Duplex Unit	1
30	B043 4632	Coupled Gear 25/59Z	1
31	B261 4705	Stepper Motor Bracket	1
32	B123 4693	Duplex Unit Stopper Ass'y	1
33	B259 2609	Paper End Sensor:Manual Feed:Ass'y	1
34	B043 4694	Chain Bracket	1
35	AG07 0514	Magnet Catch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0450 3008N	Tapping Screw - M3x8	
103	0720 0040E	Retaining Ring - M4	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0009	Nylon Clamp - 5N	
106	0433 0060N	Pan Self-Tapping Screw:3x6	

19.Duplex Unit 3 (B282)




19.Duplex Unit 3 (B282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B043 4993	Reverser Shelf	1
2	B261 4989	Reverse Roller	1
3	B121 4490	Antistatic Brush	1
4	B043 4975	Gear - 18Z	1
5	B269 4981	Guide Plate:Reverse:Left Upper	1
6	B123 4973	Reverse Paper Feed Sensor Bracket	1
7	B123 5245	Harness:Duplex:Ground Wire	1
8	B043 4998	Rail - Reverser Shelf	1
9	GW01 0007	Photo Reflection Sensor:Exit	1
10	B043 4991	Coupled Gear - 15/51Z	1
11	B261 4994	Stepper Motor Bracket	1
12	B282 4710	Stepper Motor:Ass'y	1
13	B277 4984	DC Solenoid:Ass'y	1
14	B123 4502	Middle Reverse Guide Plate	1
15	B123 5253	Harness - Duplex Sensor	1
16	B123 4506	Reverse Roller Ground Plate	1
17	G104 5141	Knob Screw:M3	2
18	B122 1083	Bracket	1
19	B282 3383	Bushing:DIA5xDIA10x6	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0450 3008N	Tapping Screw - M3x8	
103	0313 0060N	Screw - M3x6	
104	0720 0040E	Retaining Ring - M4	

20. Drive Section (B282/B283)




20. Drive Section (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B276 1055	Brushless Motor:24V	1
2	B121 1162	Small Spring	1
3	B039 1164	Timing Belt:S2M:3X226	1
4	B245 1149	Magnetic Clutch:0.5N M:Z39	1
5	B039 1170	Gear - 63Z	1
6	B276 3310	DC Motor:Toner Bottle:Kir-C3:Ass'y	1
7	B039 1144	Bushing - 8x16x9	1
8	B282 1135	Electrode Plate:Development:Ass'y	1
9	B282 1128	Ground	1
10	B121 1161	Large Spring	1
11	B259 1157	Fusing Swivel Bracket	1
12	B039 1156	Coupled Gear - 20/49Z (12)	1
13	B039 1148	Drum Shaft (02)	1
14	B039 1145	Coupled Gear - 34/63Z (01)	1
15	B039 1146	Coupled Gear - 32/71Z (04)	1
16	B039 1155	Gear/pulley - 61/34Z (11)	1
17	B259 1174	Development Drive Shaft (03)	1
18	B039 1154	Coupled Gear - 37/97Z (05)	1
19	B039 1173	Gear - 78Z (06)	1
20	B039 1168	Gear - 32Z (10)	1
21	B039 1167	Gear - 22Z (09)	1
22	B039 1165	Coupled Gear - 49/59/38Z (08)	1
23	B039 1166	Gear - 37Z (07)	1
24	5304 1639	Bushing - 8mm	1
25	B121 1140	Main Drive Housing	1
26	AA10 0015	Snap Ring - M6	1
27	B121 1145	Harness Hook	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 4010N	Tapping Screw:M4x10	
102	0454 3008Q	Tapping Screw:3x8	
103	0720 0060E	Retaining Ring - M6	
104	0450 3008N	Tapping Screw - M3x8	
105	1105 0488	Harness Clamp	
106	0451 3006N	Tapping Screw - 3x6	

21.Electrical Section 1 (B282/B283)




21.Electrical Section 1 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B122 5208	Ground Wire	1
1	B121 5208	Harness - Ground Wire Scanner (B283)	1
2	B121 5822	Guide Mylar (B282)	1
3	AX64 0169	Fan DC24V 1.92W	1
4	B121 5240	Harness - Document Feeder	1
5	B039 5831	ADF Plug Bracket	1
6	B123 1102	Rear Fan Bracket	1
7	B245 5223	Harness:Scanner	1
8	B121 5215	Harness - Paper End Sensor No.1	1
9	B282 5103	PCB:BICU:GWC4:CHN:Ass'y	1
10	B121 5810	BICU Bracket	1
11	B121 5220	Harness - HPS	1
12	B245 5217	AC Harness - Fusing (B282)	1
13	AZ23 0229	Power Supply Unit:CHN	1
14	B243 5018	Choke Coil - B2435018	1
15	B259 5034	Harness:Dehumidifier:EXP:Ass'y (B283)	1
15	B282 5034	Harness:Dehumidifier:C:EXP:Ass'y (B282)	1
15	B243 5228	Harness - AC Dehumidifier EXP (B283)	1
15	B282 5228	Harness:AC:Dehumidifier:EXP (B282)	1
16	B243 5226	Harness - AC Switch 187	1
17	B243 5230	Harness - Power Supply Unit	1
18	AZ00 0084	Power Supply Cord:Stopper:CHN	1
18	B039 4744	Other Section:Service Parts:Power Supply Cord	1
18	B039 5744	Power Supply Cord - 230V	1
18	B039 5746	Power Supply Cord:Stopper:CHN:Ass'y	1
19	B121 5825	Power Supply Cord Bracket	1
20	B245 5200	Scanner Motor Harness	1
21	B243 5203	Harness - Main Motor	1
22	B122 5821	Box Holder	1
23	B121 5212	Harness - Manual Feed	1
24	B243 5261	Harness - Key Counter	1
25	B259 5223	Harness - Stabilizer	1
26	B243 1804	Harness - FFC	1
27	B243 5231	Harness - High Voltage	1

Index No.	Part No.	Description	Q'ty Per Assembly
28	B121 5204	Harness - Discharge Lamp	1
29	B121 5206	Harness - Density Sensor	1
30	B282 5205	Harness:Door Switch:Front (B282)	1
31	B282 5246	Harness:Duplex (B282)	1
32	B282 5201	Harness:Registration Sensor:5V (B282)	1
33	B121 5250	Harness - LDD	1
34	AA14 3592	Screw- M4x6	1
35	B039 5729	Inductor:Nfu-19	1
101	0451 3008N	Tapping Screw - M3x8	
102	0451 3006N	Tapping Screw - 3x6	
103	0451 3030N	Tapping Screw:3x30	
104	1204 2608	Rocker Switch:SDDJE33900	
105	1105 0487	Harness Clamp	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	1107 1317	Fuse:FIH 250V 2.5A(EM)	
107	1107 1083	Fuse:SST 4	
108	1107 1084	Fuse:CES14-8A-N1	
109	1407 5299	RAM:FM1608-120-P	
110	1105 0518	Edge Saddle - LES-1010	
111	1105 0488	Harness Clamp	
112	0802 5299	Tapping Screw - M3x8	

22.Electrical Section 2 (B282/B283)




22.Electrical Section 2 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B282 5242	Harness:Duplex:Machine or Copier (B282)	1
2	B244 5155	PCB DCB (B282)	1
3	B039 1073	Right Door Stopper	2
4	B121 1110	Upper Main Duct	1
5	B122 1075	Front Reverse Sub-Unit Holder	1
6	B121 1112	Frame Duct	1
7	B121 1108	Lower Main Duct Ass'y	1
8	B259 1119	Tapping Screw:M3x33	2
9	GX64 5734	Fan Motor:Mm80 DC24V 3.12W	1
10	B121 1107	Exhaust Duct	1
11	B121 1109	Left Duct Ass'y	1
12	B282 5851	Bracket:DCU (B282)	1
13	B282 5246	Harness:Duplex (B282)	1
14	B039 5887	Heater Switch Cover	1
15	B282 5841	Bracket:Power Pack:BCT	1
15	B121 5841	BCT Power Pack Bracket	1
16	AZ32 0152	Power Pack BCT	1
17	G020 5871	Spacer - KGLS-12RF	2
18	B243 5232	Harness - High Voltage Line B	1
19	B243 5233	Harness - High Voltage Line C/T	1
20	B243 5231	Harness - High Voltage	1
21	B282 5244	Harness:Duplex:Duplex Unit (B282)	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0450 3008N	Tapping Screw - M3x8	
103	1105 0487	Harness Clamp	
104	1105 0499	Support Spacer - M3x29	
105	0450 3010N	Tapping Screw - M3x10	

23.Frame Section 1 (B282/B283)




23.Frame Section 1 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B276 1073	Cover:Grip	4
2	B259 6058	Heater:Paper Feed:No.1:EU:Ass'y	1
3	B276 1072	Grip	4
4	B121 1070	Grip Bracket 2	4
5	AH01 0010	Rubber Foot:H5	4
6	B259 1053	Door Shaft - Right Front	1
7	B121 5802	Guide Plate Bracket	1
8	B243 5018	Choke Coil - B2435018	1
9	B121 5801	Power Supply Unit Bracket	1
10	B039 4185	Fusing Lamp Bracket	1
11	B180 2801	Holder:Paper Tray	1
12	B259 1058	Door Shaft - Right Rear	1
13	G020 5626	Push Switch	1
14	B282 1128	Ground Plate:OPC Drum2:Ass'y	1
15	B039 2783	Tray Heater	1
16	B243 5260	Harness - AC Dehumidifier	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0451 3008N	Tapping Screw - M3x8	
103	0454 3006Q	Tapping Screw - M3x6	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0487	Harness Clamp	
106	1105 0197	Wire Saddle	
107	0450 3008N	Tapping Screw - M3x8	
108	0950 3006N	Screw:Spring Washer:M3x6	
109	1105 0488	Harness Clamp	

24.Frame Section 2 (B282/B283)




24.Frame Section 2 (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B039 2754	Bracket - Paper Size Sensor	1
2	G800 3035	Push Sw - Paper Size	1
3	B180 2801	Holder:Paper Tray	1
4	AH01 0010	Rubber Foot:H5	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	1105 0511	Harness Clamp - LWS-0306ZC	
103	0950 3006N	Screw:Spring Washer:M3x6	

25.GDI Unit (B282/B283)







25.GDI Unit (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B843 5880	Cover - Controller Box	1
2	B865 5040	PCB:3.5L:GDI:Ass'y	1
3	B243 5870	PCB Bracket	1
4	B622 5872	Rail Holder	1
5	D109 1313	Cover:CTL:D109	1
6	B268 5874	Cover:Expand:Gdi	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0353 0060N	Bind Screw - M3x6	

26.Decals and Documents (B282/B283)

1	2	3	6
			
5	4		
			
	7		
			


26.Decals and Documents (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B039 2633	Decal - By-pass Feed	1
2	B039 2721	Decal - Cassette Operation	1
3	B039 2834	Decal - Exit Paper Feed	1
4	B039 4488	Jam Removal Decal (B283)	1
5	B043 4692	Grip Decal	1
6	B123 4691	Decal	1
7	B283 1981	Decal:LD	1


Index No.	Part No.	Description	Q'ty Per Assembly

27.Special Tools (B282/B283)


1




2




3



4



5



6



27.Special Tools (B282/B283)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5203 9502	Grease 501	1
2	A006 9104	Adjusting Scanner Pin (4pcs/set)	1
3	VSSM 9000	Digital Multimeter-Fluke187	1
4	N803 6701	Flash Memory Card-4MB	1
5	A257 9300	Grease - Barrierta S552R	1
6	A292 9500	Test Chart - S5S (10 pcs/set)	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B282 0471	Model Name Plate:B28268:GES	9 - 16
B282 1128	Ground	47 - 9
B282 1128	Ground Plate:OPC Drum2:Ass'y	53 - 14
B282 1135	Electrode Plate:Development:Ass'y	47 - 8
B282 1352	Cover:Front:CHN	9 - 12
B282 1417	Operation Sub-unit:Base: Duplex:GW-C3D:Ass'y	11 - 4
B282 1454	Sheet:Operation Sub-unit:Duplex (B282)	11 - 16
B282 1485	PCB:Duplex:GW-C3D	11 - 3
B282 2210	PCU - Ass'y	31 - *
B282 2252	Frame:PCU:Ass'y	33 - 26
B282 2655	Guide:Vertical Transport	41 - 28
B282 3051	Development Roller:Ass'y	31 - 6
B282 3383	Bushing:DIA5xDIA10x6	45 - 19
B282 4662	Guide Plate-Vertical Transport	41 - 5
B282 4710	Stepper Motor:Ass'y	45 - 12
B282 4710	Stepper Motor:Ass'y	43 - 2
B282 5034	Harness:Dehumidifier:C:EXP:Ass'y(B282-67)	49 - 15
B282 5103	PCB:BICU:GWC4:CHN:Ass'y	49 - 9
B282 5201	Harness:Registration Sensor:5V (B282)	27 - 30
B282 5201	Harness:Registration Sensor:5V (B282)	49 - 32
B282 5205	Harness:Door Switch:Front (B282)	49 - 30
B282 5205	Harness:Door Switch:Front	39 - 7
B282 5228	Harness:AC:Dehumidifier:EXP (B282)	49 - 15
B282 5242	Harness:Duplex:Machine or Copier (B282)	51 - 1
B282 5244	Harness:Duplex:Duplex Unit (B282)	51 - 21
B282 5246	Harness:Duplex (B282)	49 - 31
B282 5246	Harness:Duplex (B282)	51 - 13
B282 5841	Bracket:Power Pack:BCT	51 - 15
B282 5851	Bracket:DCU (B282)	51 - 12
B283 0474	Model Name Plate:B283-67:RIC	9 - 16
B283 0479	Model Name Plate:B283-68:GES	9 - 16
B283 1427	Operation Sub-unit:Base:GW-C3:Ass'y	11 - 4
B283 1454	Sheet:Operation Sub-unit:One Side (B283)	11 - 16
B283 1876	Imaging Unit:Ass'y	19 - 21

Part No.	Description	Page and Index No.
B283 1961	Shield Glass:Ass'y	19 - 6
B283 1971	Optical Housing Cover	19 - 12
B283 1981	Decal:LD	71 - 7
B283 1981	Decal:LD	19 - 7
B283 4006	Fusing Unit:Panda-C4:Ass'y	37 - *
B283 4103	Frame:Fusing	37 - 6

Part No.	Description	Page and Index No.
A006 9104	Adjusting Scanner Pin (4pcs/set)	73 - 2
A184 3420	Bottle Chuck	35 - 3
A184 3421	Chuck Shaft	35 - 4
A193 1705	Sheet:Photointerruptor	13 - 5
A232 2374	Spur	37 - 7
A232 3962	Spring Plate - Band Stopper	29 - 9
A250 1388	Spring	29 - 25
A250 1388	Spring	41 - 21
A250 1752	Exposure Glass	13 - 10
A250 1822	Heater - 9W	13 - 7
A250 2808	Stopper Base	23 - 21
A257 9300	Grease - Barrierta S552R	73 - 5
A267 2869	Gear - 16Z	23 - 12
A267 3440	Development Joint	31 - 2
A267 3556	Chuck Spring - Tonner Bottle	35 - 7
A292 9500	Test Chart - S5S (10 pcs/set)	73 - 6
B039 1068	ADF Bracket	13 - 18
B039 1073	Right Door Stopper	51 - 3
B039 1082	Door Switch Bracket	39 - 6
B039 1088	Sheet - Duct	19 - 5
B039 1090	Door Switch Lever - 1	39 - 16
B039 1092	Door Switch Lever - 3	39 - 14
B039 1093	Door Switch Lever - 4	39 - 13
B039 1094	Door Switch Lever - 5	39 - 11
B039 1095	Door Switch Lever - 6	39 - 10
B039 1096	Door Switch Lever - 7	39 - 8
B039 1098	Door Switch Spring	39 - 12
B039 1099	Door Switch Lever - 2	39 - 15
B039 1123	Door Switch Lever - 8	39 - 9
B039 1130	Development Sensor Bracket	25 - 20
B039 1141	Shaft - Paper Feed Frame	35 - 6
B039 1142	Housing - Paper Feed	27 - 8
B039 1144	Bushing - 8x16x9	47 - 7
B039 1145	Coupled Gear - 34/63Z (01)	47 - 14
B039 1146	Coupled Gear - 32/71Z (04)	47 - 15

Part No.	Description	Page and Index No.
B039 1148	Drum Shaft (02)	47 - 13
B039 1154	Coupled Gear - 37/97Z (05)	47 - 18
B039 1155	Gear/pulley - 61/34Z (11)	47 - 16
B039 1156	Coupled Gear - 20/49Z (12)	47 - 12
B039 1163	Pulley - 23Z	39 - 26
B039 1164	Timing Belt:S2M:3X226	47 - 3
B039 1165	Coupled Gear - 49/59/38Z (08)	47 - 22
B039 1166	Gear - 37Z (07)	47 - 23
B039 1167	Gear - 22Z (09)	47 - 21
B039 1168	Gear - 32Z (10)	47 - 20
B039 1170	Gear - 63Z	47 - 5
B039 1173	Gear - 78Z (06)	47 - 19
B039 1186	Gear - 46Z	27 - 25
B039 1187	Gear - 30Z	27 - 24
B039 1191	Gear - 19Z	27 - 19
B039 1193	Bushing - By-pass Feed	27 - 31
B039 1199	Spring - By-pass Feed	27 - 32
B039 1239	Fusing Cover:Paper Exit Sub-unit: One Side:Sub-Ass'y (B283)	39 - 2
B039 1333	Rear Scanner Cover	9 - 4
B039 1339	Cover - Front Right Upper (B283)	9 - 11
B039 1347	Right Rear Cover (B283)	9 - 10
B039 1361	Magnet Catch	9 - 14
B039 1364	Rivet - M7	9 - 20
B039 1365	Sheet - Operation Instructions	9 - 18
B039 1367	Rivet - M6	9 - 19
B039 1469	Ground Plate	11 - 7
B039 1649	Timing Belt:S1.411M:1058	17 - 7
B039 1658	Rear Scale Bracket	13 - 16
B039 1662	Front Scanner Frame	17 - 2
B039 1663	Rear Scanner Frame	17 - 1
B039 1666	Bracket - Operation Panel	13 - 12
B039 1668	Bracket - Stabilizer Harness	17 - 13
B039 1683	Tension Spring - Stepper Motor	17 - 17
B039 1692	Pulley - 37Z	17 - 12

Part No.	Description	Page and Index No.
B039 1694	Pulley - 37/41Z	17 - 10
B039 1695	Flange - Pulley	17 - 9
B039 1699	Stepper Motor:MM42:2.9W	17 - 15
B039 1703	Pulley - 37Z	17 - 3
B039 1704	Spring - Timing Pulley	17 - 5
B039 1705	Bracket:Idler	17 - 4
B039 1710	Left Scanner Bracket	13 - 3
B039 1712	Right Scanner Bracket	13 - 14
B039 1758	Timing Belt Holder - Front	15 - 11
B039 1759	Timing Belt Holder - Rear	15 - 13
B039 1781	2nd Mirror Holder	15 - 2
B039 1784	Scanner Drive Belt	15 - 6
B039 1785	Scanner Drive Pulley	15 - 3
B039 1790	Tension Spring	15 - 8
B039 1796	Mirror:No.2:Ass'y	15 - 1
B039 1905	Adjusting Plate	19 - 2
B039 1942	Cylindrical Lens Holder	19 - 10
B039 1953	2nd Mirror Holder	19 - 18
B039 1954	Holder - Sync Detector Mirror	19 - 11
B039 2265	Shield:Frame:Lower	33 - 25
B039 2272	Recycled Toner Coil	33 - 5
B039 2274	Recycled Toner Plate	33 - 7
B039 2276	Rear Bushing - Toner Coil	33 - 9
B039 2287	Charge Roller Spring	33 - 19
B039 2288	Cam - Cleaning Blade	33 - 16
B039 2292	Front Pressure Arm - Charge Roller	33 - 20
B039 2293	Pin - Front Pressure Arm	33 - 4
B039 2295	Rear Pressure Arm - Charge Roller	33 - 18
B039 2312	Shutter Spring	33 - 2
B039 2321	Front PCU Cover	33 - 6
B039 2329	Spacer - M3	33 - 24
B039 2335	Pickoff Pawl	33 - 14
B039 2343	Drum Shutter	33 - 3
B039 2350	Clip - OPC Drum	33 - 10
B039 2361	Front Side Plate - Drum	31 - 3

Part No.	Description	Page and Index No.
B039 2362	Drum Shutter Gear	31 - 5
B039 2367	Drum Shutter Spring	31 - 4
B039 2382	Quenching Lamp Terminal	35 - 14
B039 2558	Driven Roller	41 - 4
B039 2558	Driven Roller	29 - 28
B039 2558	Driven Roller	25 - 17
B039 2558	Driven Roller	27 - 11
B039 2560	Registration Cleaning Mylar	25 - 15
B039 2567	Guide - Right Registration Roller	25 - 12
B039 2570	Registration Feeler	25 - 11
B039 2572	Guide - Left Registration Roller	25 - 16
B039 2575	Bracket - Registration Roller	25 - 1
B039 2578	Grounding Plate	35 - 11
B039 2583	Vertical Transport Feeler	27 - 17
B039 2585	Exit Guide Plate	27 - 7
B039 2587	Mylar - Exit Guide Plate	27 - 36
B039 2592	Lower Guide Plate - By-pass Feed	29 - 6
B039 2594	Upper Guide Plate - By-pass Feed	29 - 11
B039 2596	Friction Pad	29 - 8
B039 2610	Bracket - Paper End Sensor	29 - 19
B039 2610	Bracket - Paper End Sensor	43 - 10
B039 2611	Feeler - Paper End Sensor	43 - 13
B039 2611	Feeler - Paper End Sensor	29 - 21
B039 2619	By-pass Feed Table	21 - 14
B039 2620	Paper Guide - Extension	21 - 11
B039 2621	Paper Guide	21 - 12
B039 2628	Bottom Plate Pad	21 - 2
B039 2629	Stay - Tray Bottom Plate	21 - 10
B039 2630	Tray Bottom Plate	21 - 4
B039 2631	Front Side Fence	21 - 1
B039 2632	Rear Side Fence	21 - 3
B039 2633	Decal - By-pass Feed	71 - 1
B039 2633	Decal - By-pass Feed	21 - 17
B039 2637	Rack - Front Side Fence	21 - 6
B039 2638	Rack - Rear Side Fence	21 - 5

Part No.	Description	Page and Index No.
B039 2643	Link - By-pass Feed Table	21 - 16
B039 2645	Rotary Switch	21 - 9
B039 2651	Right Door Lever	29 - 26
B039 2653	Vertical Transport Guide	29 - 5
B039 2658	Sponge - By-pass Feed	29 - 16
B039 2660	Band - Right Door	29 - 10
B039 2670	Right Door	29 - 27
B039 2701	Tray Bottom Plate	23 - 3
B039 2704	Front Stopper Lever	23 - 2
B039 2705	Rear Side Fence	23 - 30
B039 2706	Front Side Fence	23 - 29
B039 2707	Spring Plate - Side Fence	23 - 4
B039 2711	Friction Pad	23 - 18
B039 2712	Ground Plate - Tray Bottom Plate	23 - 7
B039 2713	Spring - Friction Pad	23 - 19
B039 2721	Decal - Cassette Operation	71 - 2
B039 2721	Decal - Cassette Operation	23 - 25
B039 2727	Bushing - 8x12x10	23 - 16
B039 2730	Paper End Sensor	27 - 4
B039 2731	Side Fence - Rear	23 - 8
B039 2732	Spring - Paper Feed Roller	23 - 17
B039 2734	Side Fence - Front	23 - 5
B039 2736	Bracket - Paper End Sensor	27 - 3
B039 2739	Shaft - Joint	23 - 23
B039 2740	Paper Feed Roller	23 - 11
B039 2742	Ground Plate - Paper Feed Roller	23 - 14
B039 2754	Bracket - Paper Size Sensor	27 - 1
B039 2754	Bracket - Paper Size Sensor	55 - 1
B039 2766	Guide Plate - Transport Roller	27 - 9
B039 2778	Paper Size Detector - A4	23 - 28
B039 2783	Tray Heater	53 - 15
B039 2795	Guide Plate - Transport	27 - 12
B039 2797	Guide Plate - Transport Roller	27 - 10
B039 2812	Upper Bracket - Relay Sensor	27 - 28
B039 2813	Lower Bracket - Relay Sensor	27 - 27

Part No.	Description	Page and Index No.
B039 2821	Rear Stopper Lever	23 - 9
B039 2823	Joint - Paper Feed Roller	23 - 15
B039 2825	Ground Plate - Vertical Transport	27 - 13
B039 2827	Paper Size Sensor Board	23 - 20
B039 2830	Right Rail	27 - 34
B039 2834	Decal - Exit Paper Feed	71 - 3
B039 2834	Decal - Exit Paper Feed	27 - 37
B039 3060	Development Roller Gear	31 - 12
B039 3062	Idler Gear - 16Z	31 - 9
B039 3159	Case:Development Roller:Ass'y	31 - 7
B039 3245	Gear - 15Z	31 - 11
B039 3360	Cam - Handle	35 - 2
B039 3381	Cover:Toner Bottle:Ass'y	35 - 12
B039 3392	Guide Plate - Toner Supply Unit	35 - 15
B039 3395	Ground Plate - Toner Supply Unit	35 - 16
B039 3820	Transfer Roller	25 - 25
B039 3863	Quenching Terminal Plate	25 - 32
B039 3864	Quenching Terminal Plate-front	25 - 35
B039 3865	Transfer Terminal Plate	25 - 36
B039 3866	Pressure Cover	25 - 30
B039 3867	Roller - Transfer Unit	25 - 31
B039 3870	Terminal - Transfer	35 - 10
B039 3891	ID Sensor Cover	25 - 27
B039 4102	Fusing Exit Guide	37 - 1
B039 4107	Fusing Exit Door	37 - 23
B039 4112	Fusing Lamp - 230V 700W	37 - 16
B039 4114	Rear Ground Plate	37 - 32
B039 4116	Ground Plate - Fusing Unit	39 - 18
B039 4117	Discharge Brush	37 - 31
B039 4118	Front Ground Plate	37 - 4
B039 4119	Fusing Grounding Harness	39 - 17
B039 4120	Thermostat	37 - 5
B039 4135	Pressure Roller Lever	37 - 25
B039 4138	Front Holder	37 - 21
B039 4140	Rear Holder	37 - 15

Part No.	Description	Page and Index No.
B039 4168	Stripper Pawlsstopper	37 - 33
B039 4170	Stripper Pawls Roller	37 - 29
B039 4171	Gear - 41Z	37 - 18
B039 4185	Fusing Lamp Bracket	53 - 10
B039 4459	Exit Roller Holder - Inner	39 - 38
B039 4473	Ring:Exit Roller	39 - 4
B039 4480	Stepped Screw - M5	41 - 11
B039 4480	Stepped Screw - M5	29 - 24
B039 4488	Jam Removal Decal	29 - 29
B039 4488	Jam Removal Decal (B283)	71 - 4
B039 5744	Power Supply Cord - 230V	49 - 18
B039 5746	Power Supply Cord:Stopper:CHN:Ass'y	49 - 18
B039 5831	ADF Plug Bracket	49 - 5
B039 5887	Heater Switch Cover	51 - 14
B039 9510	OPC Drum	33 - 17
B043 2554	Registration Guide Spacer	25 - 33
B043 4609	Duplex Lower Stay	43 - 1
B043 4624	Pulley - 30Z	43 - 18
B043 4631	Gear - 38Z	43 - 26
B043 4632	Coupled Gear 25/59Z	43 - 30
B043 4633	Gear - 22Z	43 - 24
B043 4642	Stopper - Guide Plate	41 - 13
B043 4645	Spring - 2N	41 - 18
B043 4646	Upper Spring Plate - Driven Roller	41 - 19
B043 4647	Lower Spring Plate - Driven Roller	41 - 9
B043 4651	Door Lever	41 - 20
B043 4667	By-pass Feed Guide - Lower	43 - 3
B043 4671	Bracket - Upper Guide Plate	41 - 22
B043 4674	Cover - Duplex Entrance Sensor	41 - 24
B043 4676	Bracket - Duplex Entrance Sensor	41 - 6
B043 4684	By-pass Feed Guide - Upper	43 - 9
B043 4685	Spring - 2.8N	43 - 4
B043 4692	Grip Decal	41 - 15
B043 4692	Grip Decal	71 - 5
B043 4694	Chain Bracket	43 - 34

Part No.	Description	Page and Index No.
B043 4698	Cap - 30x36	43 - 21
B043 4713	Gear - 25Z	43 - 25
B043 4714	Gear - 25Z	43 - 23
B043 4975	Gear - 18Z	45 - 4
B043 4979	Exit Roller	39 - 23
B043 4991	Coupled Gear - 15/51Z	45 - 10
B043 4993	Reverser Shelf	45 - 1
B043 4998	Rail - Reverser Shelf	45 - 8
B120 2063	Bushing - 4mm	39 - 5
B120 3862	Front Discharge Brush	25 - 37
B121 1069	Support Bracket	13 - 17
B121 1070	Grip Bracket 2	53 - 4
B121 1084	Heater Wire Cover	39 - 1
B121 1107	Exhaust Duct	51 - 10
B121 1108	Lower Main Duct Ass'y	51 - 7
B121 1109	Left Duct Ass'y	51 - 11
B121 1110	Upper Main Duct	51 - 4
B121 1112	Frame Duct	51 - 6
B121 1126	Harness Guide	39 - 43
B121 1132	Fusing Drive Release Bracket	39 - 27
B121 1140	Main Drive Housing	47 - 25
B121 1145	Harness Hook	47 - 27
B121 1161	Large Spring	47 - 10
B121 1162	Small Spring	47 - 2
B121 1188	Bushing	27 - 22
B121 1313	IC Card Cap	9 - 7
B121 1316	Left Cove NA	9 - 1
B121 1322	Left Upper Cover B (B283)	9 - 21
B121 1337	Rear Cover NA (B283)	9 - 6
B121 1348	Paper Bank Cap	9 - 8
B121 1664	Bracket - Timing Belt	17 - 14
B121 1667	Lens Stay Bracket	17 - 6
B121 1680	Gear - 53Z/60Z	17 - 18
B121 1697	Timing Belt:L147	17 - 8
B121 1754	Carriage:No.1:Ass'y	15 - 12

Part No.	Description	Page and Index No.
B121 1757	Xenon Lamp MM8 26000/70	15 - 10
B121 1763	Mirror:No.1	15 - 15
B121 1766	No.1 Mirror Clamp	15 - 14
B121 1782	Flexible Board Guide	15 - 4
B121 1975	Rubber Bushing	19 - 20
B121 2311	PCU Toner Supply Shutter	33 - 1
B121 2313	Toner Supply Seal	33 - 8
B121 2617	Magnet Catch - By-pass Feed	21 - 13
B121 3804	Transfer Unit	25 - 9
B121 3860	Harness Cover	25 - 34
B121 4113	Short Electrode Plate	37 - 12
B121 4120	Thermostat Ass'y	37 - 11
B121 4451	Exit Middle Guide Plate	39 - 20
B121 4461	Exit Lower Guide Plate	39 - 36
B121 4465	Short Front Outer Holder	39 - 32
B121 4467	Long Front Middle Holder	39 - 35
B121 4469	Long Rear Middle Holder	39 - 33
B121 4470	Right Lower Exit Guide Plate	29 - 14
B121 4473	Exit Roller Ring MM14	39 - 29
B121 4477	Short Rear Outer Holder	39 - 34
B121 4490	Antistatic Brush	45 - 3
B121 4503	Exit Photointerruptor Bracket	39 - 19
B121 5202	Harness - Registration Sensor	25 - 14
B121 5204	Harness - Discharge Lamp	19 - 4
B121 5204	Harness - Discharge Lamp	49 - 28
B121 5206	Harness - Density Sensor	25 - 29
B121 5206	Harness - Density Sensor	49 - 29
B121 5208	Harness - Ground Wire Scanner (B283)	49 - 1
B121 5212	Harness - Manual Feed	49 - 23
B121 5215	Harness - Paper End Sensor No.1	27 - 5
B121 5215	Harness - Paper End Sensor No.1	49 - 8
B121 5219	Harness - Ground Wire	35 - 13
B121 5220	Harness - HPS	49 - 11
B121 5238	Harness - Paper Feed Sensor	39 - 21
B121 5240	Harness - Document Feeder	49 - 4

Part No.	Description	Page and Index No.
B121 5248	Harness - Development Sensor	25 - 21
B121 5250	Harness - LDD	49 - 33
B121 5250	Harness - LDD	19 - 14
B121 5259	Harness - Paper End Sensor	29 - 23
B121 5439	Harness - Polygon Mirror Motor	19 - 13
B121 5801	Power Supply Unit Bracket	53 - 9
B121 5802	Guide Plate Bracket	53 - 7
B121 5810	BICU Bracket	49 - 10
B121 5822	Guide Mylar (B282)	49 - 2
B121 5825	Power Supply Cord Bracket	49 - 19
B121 5841	BCT Power Pack Bracket	51 - 15
B121 9640	Developer Type 28 Black	31 - 13
B122 1075	Front Reverse Sub-Unit Holder	51 - 5
B122 1083	Bracket	45 - 18
B122 1323	Left Upper Cover (B282)	9 - 21
B122 4460	Lower Exit Guide Plate	39 - 28
B122 4492	Large Exit Discharge Brush	39 - 41
B122 4493	Small Exit Discharge Brush	39 - 42
B122 5208	Ground Wire	49 - 1
B122 5821	Box Holder	49 - 22
B123 1102	Rear Fan Bracket	49 - 6
B123 1302	Fusing Cover:Paper Exit Sub-unit: Duplex (B282)	39 - 2
B123 4502	Middle Reverse Guide Plate	45 - 14
B123 4505	Timing Belt - 40S2M290	43 - 19
B123 4506	Reverse Roller Ground Plate	45 - 16
B123 4508	Middle:Reverse Holder	39 - 40
B123 4617	Entrance Duplex Guide Plate	41 - 26
B123 4627	Adhesion Duplex Cover	43 - 28
B123 4640	Driven Duplex Guide Plate Ass'y	41 - 12
B123 4661	Rear Duplex Inner Cover	43 - 22
B123 4670	Right Lower Exit Guide Plate Ass'y	41 - 14
B123 4675	Exit Duplex Sensor Bracket	41 - 10
B123 4679	Exit Sensor Cover	41 - 23
B123 4691	Decal	71 - 6

Part No.	Description	Page and Index No.
B123 4691	Decal	41 - 17
B123 4693	Duplex Unit Stopper Ass'y	43 - 32
B123 4697	Tension Spring 27N	43 - 27
B123 4973	Reverse Paper Feed Sensor Bracket	45 - 6
B123 4977	Right Upper Exit Guide Plate Ass'y	41 - 25
B123 5241	Harness - Duplex Unit	43 - 29
B123 5245	Harness:Duplex:Ground Wire	45 - 7
B123 5245	Harness:Duplex:Ground Wire	41 - 16
B123 5252	Harness - Duplex Paper End Sensor	43 - 11
B123 5253	Harness - Duplex Sensor	45 - 15
B132 1531	Panel:Logo	9 - 22
B180 2801	Holder:Paper Tray	55 - 3
B180 2801	Holder:Paper Tray	53 - 11
B229 1453	Keytop - Start	11 - 8
B229 1454	Keytop - Clear/Stop	11 - 9
B229 1475	Keytop - 10key	11 - 10
B229 1522	Sheet-Power Source-EU	11 - 17
B229 1525	Keytop-INITIAL	11 - 11
B229 1537	Keytop - Clear Modes	11 - 12
B238 1845	Seal:Exposure Glass	13 - 19
B238 2753	Decal - Side Fence	21 - 22
B243 1425	Cover - Operation Panel	11 - 6
B243 1451	Case:Operation Sub-unit	11 - 2
B243 1458	Keytop - Power Source	11 - 13
B243 1459	Keytop - Cursor	11 - 14
B243 1468	Cover - CPS EU	11 - 1
B243 1469	Keytop:CPS:EU	11 - 18
B243 1804	Harness - FFC	49 - 26
B243 1804	Harness - FFC	13 - 13
B243 2701	Paper Tray	23 - 24
B243 2702	Cover - Paper Tray	23 - 26
B243 5018	Choke Coil - B2435018	53 - 8
B243 5018	Choke Coil - B2435018	49 - 14
B243 5203	Harness - Main Motor	49 - 21
B243 5226	Harness - AC Switch 187	49 - 16

Part No.	Description	Page and Index No.
B243 5228	Harness - AC Dehumidifier EXP (B283)	49 - 15
B243 5230	Harness - Power Supply Unit	49 - 17
B243 5231	Harness - High Voltage	49 - 27
B243 5231	Harness - High Voltage	51 - 20
B243 5232	Harness - High Voltage Line B	51 - 18
B243 5233	Harness - High Voltage Line C/T	51 - 19
B243 5233	Harness - High Voltage Line C/T	35 - 9
B243 5260	Harness - AC Dehumidifier	53 - 16
B243 5261	Harness - Key Counter	49 - 24
B243 5870	PCB Bracket	57 - 3
B244 5155	PCB DCB (B282)	51 - 2
B245 1149	Magnetic Clutch:0.5N M:Z39 (RIC)	47 - 4
B245 2840	Paper Tray:PD-C2:Ass'y	23 - *
B245 4052	Hot Roller	37 - 20
B245 4054	Frame:Pressure:Printing	37 - 28
B245 4112	Electrode Plate:Middle	37 - 13
B245 4114	Electrode Plate:Rear	37 - 14
B245 4115	Electrode Plate:Front	37 - 10
B245 5200	Scanner Motor Harness	49 - 20
B245 5217	AC Harness - Fusing (B282)	49 - 12
B245 5223	Harness:Scanner	49 - 7
B259 1053	Door Shaft - Right Front	53 - 6
B259 1058	Door Shaft - Right Rear	53 - 12
B259 1119	Tapping Screw:M3x33	51 - 8
B259 1131	Screw:PCU	25 - 28
B259 1157	Fusing Swivel Bracket	47 - 11
B259 1174	Development Drive Shaft (03)	47 - 17
B259 1178	Paper Feed Drive Bracket	27 - 23
B259 1190	Shaft - Drive Manual Feed	27 - 20
B259 1194	Manual Feed Drivebracket	27 - 18
B259 1367	Cover Magnet	9 - 13
B259 1499	Tapping Screw - M3x8	11 - 15
B259 1691	Scanner Drive Shaft	17 - 11
B259 1702	Pulley Shaft	17 - 16
B259 1763	Xenon Lamp Stabilizer	15 - 16

Part No.	Description	Page and Index No.
B259 1768	Carriage No.2 Ass'y	15 - 5
B259 1776	Idler Belt Pulley Bracket - Front	15 - 9
B259 1778	Idler Belt Pulley Bracket - Rear	15 - 7
B259 1813	Holder:Lens:Ass'y	13 - 9
B259 2325	OPC Drum Shutter Plate	33 - 23
B259 2371	Rear Drum Stay	31 - 1
B259 2381	Discharge Lamp - QL	19 - 3
B259 2562	Registration Roller Drive	25 - 19
B259 2571	Registration Roller Driven - DIA16	25 - 18
B259 2594	Shaft - Feed	29 - 12
B259 2602	Manual Feed Table Ass'y	21 - 21
B259 2609	Paper End Sensor:Manual Feed:Ass'y	29 - 15
B259 2609	Paper End Sensor:Manual Feed:Ass'y	43 - 33
B259 2642	Pin - MM6	21 - 19
B259 2648	Door:Right:C2B:Ass'y	29 - 30
B259 2737	Paper Feed Roller Shaft Ass'y	23 - 10
B259 2786	Lever Shaft	21 - 20
B259 3031	Toner Supply Unit	35 - 1
B259 3170	Development Case Ass'y	31 - 8
B259 3390	Density Sensor:K-C2.5:Ass'y	31 - 10
B259 3422	Shaft:Slide	35 - 5
B259 3890	Density Sensor	25 - 26
B259 4115	Fusing Entrance Guide Plate	37 - 30
B259 4471	Exit Roller 2	39 - 3
B259 5034	Harness:Dehumidifier:EXP:Ass'y (B283-67)	49 - 15
B259 5223	Harness - Stabilizer	49 - 25
B259 5223	Harness - Stabilizer	15 - 17
B259 6058	Heater:Paper Feed:No.1:EU:Ass'y	53 - 2
B261 4623	Transport Roller - Connecting	43 - 7
B261 4624	Transport Roller:Drive:Duplex:Exit	43 - 6
B261 4625	Transport Roller:Drive:Duplex:Entrance	43 - 8
B261 4650	Separation Pad	43 - 5
B261 4686	Manual Feed Drive Shaft	43 - 16
B261 4705	Stepper Motor Bracket	43 - 31
B261 4983	Gate Pawl	39 - 24

Part No.	Description	Page and Index No.
B261 4989	Reverse Roller	45 - 2
B261 4994	Stepper Motor Bracket	45 - 11
B268 1085	Switch:LF-105-11	39 - 30
B268 1749	Scale - Left	13 - 2
B268 1751	Scale - Inner Back	13 - 11
B268 5874	Cover:Expand:Gdi	57 - 6
B269 4981	Guide Plate:Reverse:Left Upper	45 - 5
B272 2510	Grip:Option:Paper Tray	23 - 32
B276 1055	Brushless Motor:24V	47 - 1
B276 1072	Grip	53 - 3
B276 1073	Cover:Grip	53 - 1
B276 1149	Magnetic Clutch:0.5N m:Z39 (GES)	47 - 4
B276 1150	Magnetic Clutch:Paper Feed:Drive:Ass'y	27 - 26
B276 1151	Magnetic Clutch:0.5N m:Z31	27 - 14
B276 1152	Magnetic Clutch:Manual Feed:Ass'y	27 - 35
B276 1183	Shaft:Paper Feed:Drive:Ass'y	27 - 21
B276 1192	Gear:Idler:Connecting	27 - 33
B276 1251	Cover:Shield Glass	19 - 1
B276 1332	Cover:Scanner:Left:NA	9 - 2
B276 1335	Cover:Scanner:Right:NA	9 - 9
B276 1338	Front Door - CNH	9 - 15
B276 1368	Cover:Exit:Rear:B:NA (B283)	9 - 5
B276 1452	Cover:Operation Sub-Unit:Lower	11 - 5
B276 1808	Inner Cover:Lens	13 - 8
B276 1917	Laser Diode Unit:Ass'y	19 - 15
B276 2576	Transport Roller	27 - 16
B276 2644	End Fence	23 - 1
B276 2646	Rubber Bushing	23 - 31
B276 2719	Spring:Base:5.8N	23 - 13
B276 3310	DC Motor:Toner Bottle:Kir-C3:Ass'y	47 - 6
B277 1310	Cover:Right Upper Front:C:NA (B282)	9 - 11
B277 1339	Cover:Rear:C:NA (B282)	9 - 6
B277 1347	Cover:Right Rear:C:NA (B282)	9 - 10
B277 1370	Cover:Exit:Rear:C:NA (B282)	9 - 5
B277 1372	Cover:Sorter:NA (B282)	9 - 17

Part No.	Description	Page and Index No.
B277 4984	DC Solenoid:Ass'y	45 - 13
B390 1759	Shaft:Scale	13 - 1
B622 5872	Rail Holder	57 - 4
B843 5880	Cover - Controller Box	57 - 1
B865 5040	PCB:3.5L:GDI:Ass'y	57 - 2
D100 1355	Cover:Exit:C3-DOM	9 - 3
D109 1313	Cover:CTL:D109	57 - 5
G012 3050	Side Fence Gear	21 - 7
G020 2599	Spring - Release Lever	23 - 22
G020 2784	Lever - By-pass Feed Table	21 - 15
G020 3334	Slider Ass'y	35 - 8
G020 5626	Push Switch	53 - 13
G020 5871	Spacer - KGLS-12RF	51 - 17
G029 4140	External Circlip	37 - 17
G029 4174	Pressure Roller Bushing	37 - 27
G029 4176	Turn Roller - Exit Sub-unit	39 - 37
G052 4618	Bearing 30x42x7	37 - 19
G052 4873	Outer Exit Cover Roller	39 - 31
G060 2641	Transport Driven Roller - Middle	41 - 7
G104 5141	Knob Screw:M3	45 - 17
G361 5570	Photointerruptor - Duplex	39 - 22
G570 2730	Slider - Scanner	15 - 18
G800 3035	Push SW - Paper Size	27 - 2
G800 3035	Push Sw - Paper Size	55 - 2
G800 4854	Exit Roller	39 - 39

Part No.	Description	Page and Index No.
N803 6701	Flash Memory Card-4MB	73 - 4

Part No.	Description	Page and Index No.
AA06 2254	Registration Roller Spring	25 - 2
AA06 3398	Spring - Friction Pad	29 - 7
AA06 3399	Spring - Vertical Transport	41 - 3
AA06 3399	Spring - Vertical Transport	29 - 3
AA06 3607	Pressure Spring	25 - 24
AA06 3643	Spring - By-pass Feed Table	21 - 8
AA06 6342	Registration Sensor Spring	25 - 10
AA06 6343	Spring - Paper End Sensor	29 - 20
AA06 6343	Spring - Paper End Sensor	43 - 14
AA06 6635	Spring - Fusing Exit Guide	37 - 24
AA06 6637	Stripper Pawl Spring	37 - 8
AA06 6640	Pressure Spring	37 - 26
AA06 6641	Gate Pawl Spring	39 - 25
AA08 0267	Bushing - 8x12x18	25 - 6
AA08 0268	Bushing - Vertical Transport	29 - 2
AA08 0268	Bushing - Vertical Transport	41 - 2
AA08 0313	Driven Roller Bushing	41 - 8
AA08 0342	Fornt Bushing-registration Roller	25 - 5
AA08 0343	Rear Bushing-registration Roller	25 - 22
AA08 2101	Bushing - 6x10x6	29 - 18
AA08 2101	Bushing - 6x10x6	43 - 17
AA08 2101	Bushing - 6x10x6	27 - 15
AA08 2110	Bushing - 8x12x22	25 - 23
AA10 0015	Snap Ring - M6	47 - 26
AA10 0015	Snap Ring - M6	25 - 8
AA14 3444	Stepped Screw	33 - 11
AA14 3592	Screw- M4x6	49 - 34
AA14 3870	Stepped Screw	37 - 2
AB01 1402	Gear - 14Z	33 - 13
AB01 1403	Gear - 13Z	33 - 12
AB01 2311	Gear - 18Z	25 - 7
AB01 2312	Gear - 16Z	25 - 4
AB01 2313	Gear - 25Z	29 - 13
AB03 0569	Pulley - 30T	43 - 20
AC02 0095	Sync Detector Lenz	19 - 19

Part No.	Description	Page and Index No.
AC02 4009	Cylindrical Lens	19 - 9
AC03 0138	2nd Mirror	19 - 17
AC03 0139	Sync Detector Mirror	19 - 8
AD02 7018	Roller:Charge:A3	33 - 21
AD04 2058	Charge Cleaner Brush Roller	33 - 22
AD04 2059	Cleaning Blade Ass'y	33 - 15
AE02 0100	Pressure Roller	37 - 22
AE04 4062	Stripper Pawls	37 - 9
AF02 2138	Vertical Transport Roller	29 - 1
AF02 2138	Vertical Transport Roller	41 - 1
AF03 1060	By-pass Feed Roller	29 - 17
AF03 1060	By-pass Feed Roller	43 - 15
AG07 0514	Magnet Catch	29 - 31
AG07 0514	Magnet Catch	43 - 35
AH01 0010	Rubber Foot:H5	53 - 5
AH01 0010	Rubber Foot:H5	55 - 4
AW02 0156	Photointerruptor:EE-SX4235A-P2	13 - 4
AW02 0181	Paper Feed Sensor	41 - 27
AW10 0073	Thermistor	37 - 3
AX06 0323	Polygon Motor - 23622RPM	19 - 16
AX64 0169	Fan DC24V 1.92W	49 - 3
AZ23 0229	Power Supply Unit:CHN	49 - 13
AZ32 0152	Power Pack BCT	51 - 16
GW01 0007	Photo Reflection Sensor:Exit	45 - 9
GW02 0020	Photointerruptor:LG248NL1	43 - 12
GW02 0020	Photointerruptor:LG248NL1	29 - 22
GW02 0020	Photointerruptor:LG248NL1	27 - 29
GW02 0020	Photointerruptor:LG248NL1	25 - 13
GW02 0020	Photointerruptor:LG248NL1	13 - 6
GX64 5734	Fan Motor:Mm80 DC24V 3.12W	51 - 9

Part No.	Description	Page and Index No.
VSSM 9000	Digital Multimeter-Fluke187	73 - 3

Part No.	Description	Page and Index No.
0313 0060N	Screw - M3x6	45 - 103
0313 0060N	Screw - M3x6	17 - 109
0313 0060N	Screw - M3x6	37 - 104
0353 0050N	Screw-M3x5	11 - 102
0353 0060N	Bind Screw - M3x6	57 - 102
0353 0060N	Bind Screw - M3x6	33 - 101
0360 3006N	Screw - M3x6	31 - 101
0360 3006P	Screw - M3x6	17 - 107
0433 0060N	Pan Self-Tapping Screw:3x6	43 - 106
0450 3008N	Tapping Screw - M3x8	39 - 102
0450 3008N	Tapping Screw - M3x8	27 - 106
0450 3008N	Tapping Screw - M3x8	29 - 101
0450 3008N	Tapping Screw - M3x8	41 - 101
0450 3008N	Tapping Screw - M3x8	43 - 102
0450 3008N	Tapping Screw - M3x8	25 - 101
0450 3008N	Tapping Screw - M3x8	23 - 102
0450 3008N	Tapping Screw - M3x8	35 - 101
0450 3008N	Tapping Screw - M3x8	45 - 102
0450 3008N	Tapping Screw - M3x8	47 - 104
0450 3008N	Tapping Screw - M3x8	53 - 107
0450 3008N	Tapping Screw - M3x8	51 - 102
0450 3010N	Tapping Screw - M3x10	35 - 103
0450 3010N	Tapping Screw - M3x10	51 - 105
0450 3012N	Tapping Screw:3x12	19 - 102
0450 3012N	Tapping Screw:3x12	25 - 102
0450 3012N	Tapping Screw:3x12	39 - 104
0450 3020N	Tapping Screw:M3x20	19 - 103
0450 4010N	Tapping Screw:M4x10	39 - 101
0450 4010N	Tapping Screw:M4x10	47 - 101
0451 3006N	Tapping Screw - 3x6	57 - 101
0451 3006N	Tapping Screw - 3x6	55 - 101
0451 3006N	Tapping Screw - 3x6	53 - 101
0451 3006N	Tapping Screw - 3x6	49 - 102
0451 3006N	Tapping Screw - 3x6	51 - 101
0451 3006N	Tapping Screw - 3x6	41 - 102

Part No.	Description	Page and Index No.
0451 3006N	Tapping Screw - 3x6	43 - 101
0451 3006N	Tapping Screw - 3x6	47 - 106
0451 3006N	Tapping Screw - 3x6	45 - 101
0451 3006N	Tapping Screw - 3x6	39 - 103
0451 3006N	Tapping Screw - 3x6	27 - 101
0451 3006N	Tapping Screw - 3x6	13 - 101
0451 3006N	Tapping Screw - 3x6	15 - 101
0451 3006N	Tapping Screw - 3x6	17 - 101
0451 3006N	Tapping Screw - 3x6	29 - 102
0451 3008N	Tapping Screw - M3x8	11 - 101
0451 3008N	Tapping Screw - M3x8	53 - 102
0451 3008N	Tapping Screw - M3x8	49 - 101
0451 3008N	Tapping Screw - M3x8	9 - 101
0451 3008N	Tapping Screw - M3x8	21 - 101
0451 3030N	Tapping Screw:3x30	49 - 103
0452 3008N	Tapping Screw - M3x8	31 - 102
0452 3008N	Tapping Screw - M3x8	35 - 102
0452 3008N	Tapping Screw - M3x8	37 - 103
0452 3010N	Binding Self-Tapping Screw:3x10	19 - 101
0452 3012N	Binding Self-Tapping Screw:M3x12	33 - 102
0452 3014N	Binding Self-Tapping Screw:M3x14	19 - 104
0453 3006N	Tapping Screw - M3x6	17 - 108
0454 3006Q	Tapping Screw - M3x6	27 - 102
0454 3006Q	Tapping Screw - M3x6	53 - 103
0454 3006Q	Tapping Screw - M3x6	13 - 102
0454 3006Q	Tapping Screw - M3x6	17 - 102
0454 3008Q	Tapping Screw:3x8	47 - 102
0457 3006N	Tapping Screw:WP:3x6	27 - 108
0720 0030E	Retaining Ring - M3	39 - 105
0720 0040E	Retaining Ring - M4	27 - 103
0720 0040E	Retaining Ring - M4	43 - 103
0720 0040E	Retaining Ring - M4	29 - 103
0720 0040E	Retaining Ring - M4	45 - 104
0720 0060E	Retaining Ring - M6	47 - 103
0720 0060E	Retaining Ring - M6	17 - 106

Part No.	Description	Page and Index No.
0736 0610	Bushing 6x10	33 - 103
0802 5299	Tapping Screw - M3x8	49 - 112
0804 6123	Hexagonal Bolt:W/Washer:M3x8	37 - 101
0805 0088	Retaining Ring - M6	23 - 101
0805 0097	Ring Separator	27 - 104
0805 3530	Bearing 8x22x7	17 - 105
0950 3006N	Screw:Spring Washer:M3x6	53 - 108
0950 3006N	Screw:Spring Washer:M3x6	55 - 103
0954 3010N	Screw:Polished Round/Spring:M3x10	37 - 102
0954 4008N	Screw - M4x8	37 - 105
1105 0009	Nylon Clamp - 5N	43 - 105
1105 0197	Wire Saddle	53 - 106
1105 0487	Harness Clamp	51 - 103
1105 0487	Harness Clamp	53 - 105
1105 0487	Harness Clamp	49 - 105
1105 0487	Harness Clamp	17 - 104
1105 0487	Harness Clamp	27 - 107
1105 0488	Harness Clamp	53 - 109
1105 0488	Harness Clamp	47 - 105
1105 0488	Harness Clamp	49 - 111
1105 0499	Support Spacer - M3x29	51 - 104
1105 0511	Harness Clamp - LWS-0306ZC	43 - 104
1105 0511	Harness Clamp - LWS-0306ZC	35 - 104
1105 0511	Harness Clamp - LWS-0306ZC	41 - 103
1105 0511	Harness Clamp - LWS-0306ZC	53 - 104
1105 0511	Harness Clamp - LWS-0306ZC	17 - 103
1105 0511	Harness Clamp - LWS-0306ZC	49 - 106
1105 0511	Harness Clamp - LWS-0306ZC	55 - 102
1105 0511	Harness Clamp - LWS-0306ZC	27 - 105
1105 0518	Edge Saddle - LES-1010	49 - 110
1105 0522	Edge Saddle - LES0510	25 - 103
1107 1063	Fuse:ET-2.5A	49 - 107
1107 1083	Fuse:SST 4	49 - 107
1107 1084	Fuse:CES14-8A-N1	49 - 108
1204 2608	Rocker Switch:SDDJE33900	49 - 104

Part No.	Description	Page and Index No.
1407 5299	RAM:FM1608-120-P	49 - 109

Part No.	Description	Page and Index No.
5203 9502	Grease 501	73 - 1
5215 2621	Snap Ring - M6	23 - 6
5215 2713	Bottom Plate Pad	23 - 27
5304 1639	Bushing - 8mm	47 - 24
5442 1924	Exposure Glass Cushion	13 - 15
5447 2681	Snap Ring	21 - 18
5447 2681	Snap Ring	25 - 3
5447 2681	Snap Ring	27 - 6

Parts Index

Part No.	Description	Page and Index No.
B282 0482	Model Name Plate:B282-69:FOU	9 - 16
B282 1128	Ground Plate:OPC Drum2:Ass'y	53 - 14
B282 1128	Ground	47 - 9
B282 1135	Electrode Plate:Development:Ass'y	47 - 8
B282 1352	Cover:Front:CHN	9 - 12
B282 1417	Operation Sub-unit:Base: Duplex:GW-C3D:Ass'y	11 - 4
B282 1454	Sheet:Operation Sub-unit:Duplex (B282)	11 - 16
B282 1485	PCB:Duplex:GW-C3D	11 - 3
B282 2211	PCU:Gratwall-C4:EXP:Ass'y	31 - *
B282 2252	Frame:PCU:Ass'y	33 - 26
B282 2655	Guide:Vertical Transport	41 - 28
B282 3051	Development Roller:Ass'y	31 - 6
B282 3383	Bushing:DIA5xDIA10x6	45 - 19
B282 4662	Guide Plate-Vertical Transport	41 - 5
B282 4710	Stepper Motor:Ass'y	43 - 2
B282 4710	Stepper Motor:Ass'y	45 - 12
B282 5034	Harness:Dehumidifier:C:EXP:Ass'y (B282)	49 - 15
B282 5103	PCB:BICU:GWC4:CHN:Ass'y	49 - 9
B282 5201	Harness:Registration Sensor:5V (B282)	49 - 32
B282 5201	Harness:Registration Sensor:5V (B282)	27 - 30
B282 5205	Harness:Door Switch:Front	39 - 7
B282 5205	Harness:Door Switch:Front (B282)	49 - 30
B282 5228	Harness:AC:Dehumidifier:EXP (B282)	49 - 15
B282 5242	Harness:Duplex:Machine or Copier (B282)	51 - 1
B282 5244	Harness:Duplex:Duplex Unit (B282)	51 - 21
B282 5246	Harness:Duplex (B282)	49 - 31
B282 5246	Harness:Duplex (B282)	51 - 13
B282 5841	Bracket:Power Pack:BCT	51 - 15
B282 5851	Bracket:DCU (B282)	51 - 12
B283 0482	Model Name Plate:B283-69:FOU	9 - 16
B283 1427	Operation Sub-unit:Base:GW-C3:Ass'y	11 - 4
B283 1454	Sheet:Operation Sub-unit:One Side (B283)	11 - 16
B283 1876	Imaging Unit:Ass'y	19 - 21

Part No.	Description	Page and Index No.
B283 1961	Shield Glass:Ass'y	19 - 6
B283 1971	Optical Housing Cover	19 - 12
B283 1981	Decal:LD	71 - 7
B283 1981	Decal:LD	19 - 7
B283 4006	Fusing Unit:Panda-C4:Ass'y	37 - *
B283 4103	Frame:Fusing	37 - 6

Part No.	Description	Page and Index No.
A006 9104	Adjusting Scanner Pin (4pcs/set)	73 - 2
A184 3420	Bottle Chuck	35 - 3
A184 3421	Chuck Shaft	35 - 4
A193 1705	Sheet:Photointerruptor	13 - 5
A193 1752	White Sheet	13 - 20
A232 2374	Spur	37 - 7
A232 3962	Spring Plate - Band Stopper	29 - 9
A250 1388	Spring	41 - 21
A250 1388	Spring	29 - 25
A250 1752	Exposure Glass	13 - 10
A250 1822	Heater - 9W	13 - 7
A250 2808	Stopper Base	23 - 21
A257 9300	Grease - Barrierta S552R	73 - 5
A267 2869	Gear - 16Z	23 - 12
A267 3440	Development Joint	31 - 2
A267 3556	Chuck Spring - Tonner Bottle	35 - 7
A292 9500	Test Chart - S5S (10 pcs/set)	73 - 6
B039 1068	ADF Bracket	13 - 18
B039 1073	Right Door Stopper	51 - 3
B039 1082	Door Switch Bracket	39 - 6
B039 1088	Sheet - Duct	19 - 5
B039 1090	Door Switch Lever - 1	39 - 16
B039 1092	Door Switch Lever - 3	39 - 14
B039 1093	Door Switch Lever - 4	39 - 13
B039 1094	Door Switch Lever - 5	39 - 11
B039 1095	Door Switch Lever - 6	39 - 10
B039 1096	Door Switch Lever - 7	39 - 8
B039 1098	Door Switch Spring	39 - 12
B039 1099	Door Switch Lever - 2	39 - 15
B039 1123	Door Switch Lever - 8	39 - 9
B039 1130	Development Sensor Bracket	25 - 20
B039 1141	Shaft - Paper Feed Frame	35 - 6
B039 1142	Housing - Paper Feed	27 - 8
B039 1144	Bushing - 8x16x9	47 - 7
B039 1145	Coupled Gear - 34/63Z (01)	47 - 14

Part No.	Description	Page and Index No.
B039 1146	Coupled Gear - 32/71Z (04)	47 - 15
B039 1148	Drum Shaft (02)	47 - 13
B039 1154	Coupled Gear - 37/97Z (05)	47 - 18
B039 1155	Gear/pulley - 61/34Z (11)	47 - 16
B039 1156	Coupled Gear - 20/49Z (12)	47 - 12
B039 1163	Pulley - 23Z	39 - 26
B039 1164	Timing Belt:S2M:3X226	47 - 3
B039 1165	Coupled Gear - 49/59/38Z (08)	47 - 22
B039 1166	Gear - 37Z (07)	47 - 23
B039 1167	Gear - 22Z (09)	47 - 21
B039 1168	Gear - 32Z (10)	47 - 20
B039 1170	Gear - 63Z	47 - 5
B039 1173	Gear - 78Z (06)	47 - 19
B039 1186	Gear - 46Z	27 - 25
B039 1187	Gear - 30Z	27 - 24
B039 1191	Gear - 19Z	27 - 19
B039 1193	Bushing - By-pass Feed	27 - 31
B039 1199	Spring - By-pass Feed	27 - 32
B039 1239	Fusing Cover:Paper Exit Sub-unit: One Side:Sub-Ass'y (B283)	39 - 2
B039 1333	Rear Scanner Cover	9 - 4
B039 1339	Cover - Front Right Upper (B283)	9 - 11
B039 1347	Right Rear Cover (B283)	9 - 10
B039 1361	Magnet Catch	9 - 14
B039 1364	Rivet - M7	9 - 20
B039 1365	Sheet - Operation Instructions	9 - 18
B039 1367	Rivet - M6	9 - 19
B039 1469	Ground Plate	11 - 7
B039 1649	Timing Belt:S1.411M:1058	17 - 7
B039 1658	Rear Scale Bracket	13 - 16
B039 1662	Front Scanner Frame	17 - 2
B039 1663	Rear Scanner Frame	17 - 1
B039 1666	Bracket - Operation Panel	13 - 12
B039 1668	Bracket - Stabilizer Harness	17 - 13
B039 1683	Tension Spring - Stepper Motor	17 - 17

Part No.	Description	Page and Index No.
B039 1692	Pulley - 37Z	17 - 12
B039 1694	Pulley - 37/41Z	17 - 10
B039 1695	Flange - Pulley	17 - 9
B039 1699	Stepper Motor:MM42:2.9W	17 - 15
B039 1703	Pulley - 37Z	17 - 3
B039 1704	Spring - Timing Pulley	17 - 5
B039 1705	Bracket:Idler	17 - 4
B039 1710	Left Scanner Bracket	13 - 3
B039 1712	Right Scanner Bracket	13 - 14
B039 1758	Timing Belt Holder - Front	15 - 11
B039 1759	Timing Belt Holder - Rear	15 - 13
B039 1781	2nd Mirror Holder	15 - 2
B039 1784	Scanner Drive Belt	15 - 6
B039 1785	Scanner Drive Pulley	15 - 3
B039 1790	Tension Spring	15 - 8
B039 1796	Mirror:No.2:Ass'y	15 - 1
B039 1905	Adjusting Plate	19 - 2
B039 1942	Cylindrical Lens Holder	19 - 10
B039 1953	2nd Mirror Holder	19 - 18
B039 1954	Holder - Sync Detector Mirror	19 - 11
B039 2265	Shield:Frame:Lower	33 - 25
B039 2272	Recycled Toner Coil	33 - 5
B039 2274	Recycled Toner Plate	33 - 7
B039 2276	Rear Bushing - Toner Coil	33 - 9
B039 2287	Charge Roller Spring	33 - 19
B039 2288	Cam - Cleaning Blade	33 - 16
B039 2292	Front Pressure Arm - Charge Roller	33 - 20
B039 2293	Pin - Front Pressure Arm	33 - 4
B039 2295	Rear Pressure Arm - Charge Roller	33 - 18
B039 2312	Shutter Spring	33 - 2
B039 2321	Front PCU Cover	33 - 6
B039 2329	Spacer - M3	33 - 24
B039 2335	Pickoff Pawl	33 - 14
B039 2343	Drum Shutter	33 - 3
B039 2350	Clip - OPC Drum	33 - 10

Part No.	Description	Page and Index No.
B039 2361	Front Side Plate - Drum	31 - 3
B039 2362	Drum Shutter Gear	31 - 5
B039 2367	Drum Shutter Spring	31 - 4
B039 2382	Quenching Lamp Terminal	35 - 14
B039 2558	Driven Roller	41 - 4
B039 2558	Driven Roller	29 - 28
B039 2558	Driven Roller	27 - 11
B039 2558	Driven Roller	25 - 17
B039 2560	Registration Cleaning Mylar	25 - 15
B039 2567	Guide - Right Registration Roller	25 - 12
B039 2570	Registration Feeler	25 - 11
B039 2572	Guide - Left Registration Roller	25 - 16
B039 2575	Bracket - Registration Roller	25 - 1
B039 2578	Grounding Plate	35 - 11
B039 2583	Vertical Transport Feeler	27 - 17
B039 2585	Exit Guide Plate	27 - 7
B039 2587	Mylar - Exit Guide Plate	27 - 36
B039 2592	Lower Guide Plate - By-pass Feed	29 - 6
B039 2594	Upper Guide Plate - By-pass Feed	29 - 11
B039 2596	Friction Pad (B282)	29 - 8
B039 2610	Bracket - Paper End Sensor	29 - 19
B039 2610	Bracket - Paper End Sensor	43 - 10
B039 2611	Feeler - Paper End Sensor	43 - 13
B039 2611	Feeler - Paper End Sensor	29 - 21
B039 2619	By-pass Feed Table	21 - 14
B039 2620	Paper Guide - Extension	21 - 11
B039 2621	Paper Guide	21 - 12
B039 2628	Bottom Plate Pad	21 - 2
B039 2629	Stay - Tray Bottom Plate	21 - 10
B039 2630	Tray Bottom Plate	21 - 4
B039 2631	Front Side Fence	21 - 1
B039 2632	Rear Side Fence	21 - 3
B039 2633	Decal - By-pass Feed	21 - 17
B039 2633	Decal - By-pass Feed	71 - 1
B039 2637	Rack - Front Side Fence	21 - 6

Part No.	Description	Page and Index No.
B039 2638	Rack - Rear Side Fence	21 - 5
B039 2643	Link - By-pass Feed Table	21 - 16
B039 2645	Rotary Switch	21 - 9
B039 2651	Right Door Lever	29 - 26
B039 2653	Vertical Transport Guide	29 - 5
B039 2658	Sponge - By-pass Feed	29 - 16
B039 2660	Band - Right Door	29 - 10
B039 2670	Right Door	29 - 27
B039 2701	Tray Bottom Plate	23 - 3
B039 2704	Front Stopper Lever	23 - 2
B039 2705	Rear Side Fence	23 - 30
B039 2706	Front Side Fence	23 - 29
B039 2707	Spring Plate - Side Fence	23 - 4
B039 2711	Friction Pad	23 - 18
B039 2712	Ground Plate - Tray Bottom Plate	23 - 7
B039 2713	Spring - Friction Pad	23 - 19
B039 2721	Decal - Cassette Operation	71 - 2
B039 2721	Decal - Cassette Operation	23 - 25
B039 2727	Bushing - 8x12x10	23 - 16
B039 2730	Paper End Sensor	27 - 4
B039 2731	Side Fence - Rear	23 - 8
B039 2732	Spring - Paper Feed Roller	23 - 17
B039 2734	Side Fence - Front	23 - 5
B039 2736	Bracket - Paper End Sensor	27 - 3
B039 2739	Shaft - Joint	23 - 23
B039 2740	Paper Feed Roller	23 - 11
B039 2742	Ground Plate - Paper Feed Roller	23 - 14
B039 2754	Bracket - Paper Size Sensor	55 - 1
B039 2754	Bracket - Paper Size Sensor	27 - 1
B039 2766	Guide Plate - Transport Roller	27 - 9
B039 2778	Paper Size Detector - A4	23 - 28
B039 2783	Tray Heater	53 - 15
B039 2795	Guide Plate - Transport	27 - 12
B039 2797	Guide Plate - Transport Roller	27 - 10
B039 2812	Upper Bracket - Relay Sensor	27 - 28

Part No.	Description	Page and Index No.
B039 2813	Lower Bracket - Relay Sensor	27 - 27
B039 2821	Rear Stopper Lever	23 - 9
B039 2823	Joint - Paper Feed Roller	23 - 15
B039 2825	Ground Plate - Vertical Transport	27 - 13
B039 2827	Paper Size Sensor Board	23 - 20
B039 2830	Right Rail	27 - 34
B039 2834	Decal - Exit Paper Feed	71 - 3
B039 2834	Decal - Exit Paper Feed	27 - 37
B039 3060	Development Roller Gear	31 - 12
B039 3062	Idler Gear - 16Z	31 - 9
B039 3159	Case:Development Roller:Ass'y	31 - 7
B039 3245	Gear - 15Z	31 - 11
B039 3360	Cam - Handle	35 - 2
B039 3381	Cover:Toner Bottle:Ass'y	35 - 12
B039 3392	Guide Plate - Toner Supply Unit	35 - 15
B039 3395	Ground Plate - Toner Supply Unit	35 - 16
B039 3820	Transfer Roller	25 - 25
B039 3863	Quenching Terminal Plate	25 - 32
B039 3864	Quenching Terminal Plate-front	25 - 35
B039 3865	Transfer Terminal Plate	25 - 36
B039 3866	Pressure Cover	25 - 30
B039 3867	Roller - Transfer Unit	25 - 31
B039 3870	Terminal - Transfer	35 - 10
B039 3891	ID Sensor Cover	25 - 27
B039 4102	Fusing Exit Guide	37 - 1
B039 4107	Fusing Exit Door	37 - 23
B039 4112	Fusing Lamp - 230V 700W	37 - 16
B039 4114	Rear Ground Plate	37 - 32
B039 4116	Ground Plate - Fusing Unit	39 - 18
B039 4117	Discharge Brush	37 - 31
B039 4118	Front Ground Plate	37 - 4
B039 4119	Fusing Grounding Harness	39 - 17
B039 4120	Thermostat	37 - 5
B039 4135	Pressure Roller Lever	37 - 25
B039 4138	Front Holder	37 - 21

Part No.	Description	Page and Index No.
B039 4140	Rear Holder	37 - 15
B039 4168	Stripper Pawlsstopper	37 - 33
B039 4170	Stripper Pawls Roller	37 - 29
B039 4171	Gear - 41Z	37 - 18
B039 4185	Fusing Lamp Bracket	53 - 10
B039 4459	Exit Roller Holder - Inner	39 - 38
B039 4473	Ring:Exit Roller	39 - 4
B039 4480	Stepped Screw - M5	41 - 11
B039 4480	Stepped Screw - M5	29 - 24
B039 4488	Jam Removal Decal	29 - 29
B039 4488	Jam Removal Decal (B283)	71 - 4
B039 4744	Other Section:Service Parts:Power Supply Cord	49 - 18
B039 5729	Inductor:Nfu-19	49 - 35
B039 5744	Power Supply Cord - 230V	49 - 18
B039 5746	Power Supply Cord:Stopper:CHN:Ass'y	49 - 18
B039 5831	ADF Plug Bracket	49 - 5
B039 5887	Heater Switch Cover	51 - 14
B039 9510	OPC Drum	33 - 17
B043 2554	Registration Guide Spacer	25 - 33
B043 4609	Duplex Lower Stay	43 - 1
B043 4624	Pulley - 30Z	43 - 18
B043 4631	Gear - 38Z	43 - 26
B043 4632	Coupled Gear 25/59Z	43 - 30
B043 4633	Gear - 22Z	43 - 24
B043 4642	Stopper - Guide Plate	41 - 13
B043 4645	Spring - 2N	41 - 18
B043 4646	Upper Spring Plate - Driven Roller	41 - 19
B043 4647	Lower Spring Plate - Driven Roller	41 - 9
B043 4651	Door Lever	41 - 20
B043 4667	By-pass Feed Guide - Lower	43 - 3
B043 4671	Bracket - Upper Guide Plate	41 - 22
B043 4674	Cover - Duplex Entrance Sensor	41 - 24
B043 4676	Bracket - Duplex Entrance Sensor	41 - 6
B043 4684	By-pass Feed Guide - Upper	43 - 9
B043 4685	Spring - 2.8N	43 - 4

Part No.	Description	Page and Index No.
B043 4692	Grip Decal	71 - 5
B043 4692	Grip Decal	41 - 15
B043 4694	Chain Bracket	43 - 34
B043 4698	Cap - 30x36	43 - 21
B043 4713	Gear - 25Z	43 - 25
B043 4714	Gear - 25Z	43 - 23
B043 4975	Gear - 18Z	45 - 4
B043 4979	Exit Roller	39 - 23
B043 4991	Coupled Gear - 15/51Z	45 - 10
B043 4993	Reverser Shelf	45 - 1
B043 4998	Rail - Reverser Shelf	45 - 8
B120 2063	Bushing - 4mm	39 - 5
B120 3862	Front Discharge Brush	25 - 37
B121 1069	Support Bracket	13 - 17
B121 1070	Grip Bracket 2	53 - 4
B121 1084	Heater Wire Cover	39 - 1
B121 1107	Exhaust Duct	51 - 10
B121 1108	Lower Main Duct Ass'y	51 - 7
B121 1109	Left Duct Ass'y	51 - 11
B121 1110	Upper Main Duct	51 - 4
B121 1112	Frame Duct	51 - 6
B121 1126	Harness Guide	39 - 43
B121 1132	Fusing Drive Release Bracket	39 - 27
B121 1140	Main Drive Housing	47 - 25
B121 1145	Harness Hook	47 - 27
B121 1161	Large Spring	47 - 10
B121 1162	Small Spring	47 - 2
B121 1188	Bushing	27 - 22
B121 1313	IC Card Cap	9 - 7
B121 1316	Left Cove NA	9 - 1
B121 1322	Left Upper Cover B (B283)	9 - 21
B121 1337	Rear Cover NA (B283)	9 - 6
B121 1348	Paper Bank Cap	9 - 8
B121 1664	Bracket - Timing Belt	17 - 14
B121 1667	Lens Stay Bracket	17 - 6

Part No.	Description	Page and Index No.
B121 1680	Gear - 53Z/60Z	17 - 18
B121 1697	Timing Belt:L147	17 - 8
B121 1754	Carriage:No.1:Ass'y	15 - 12
B121 1757	Xenon Lamp MM8 26000/70	15 - 10
B121 1763	Mirror:No.1	15 - 15
B121 1766	No.1 Mirror Clamp	15 - 14
B121 1782	Flexible Board Guide	15 - 4
B121 1975	Rubber Bushing	19 - 20
B121 2311	PCU Toner Supply Shutter	33 - 1
B121 2313	Toner Supply Seal	33 - 8
B121 2617	Magnet Catch - By-pass Feed	21 - 13
B121 3804	Transfer Unit	25 - 9
B121 3860	Harness Cover	25 - 34
B121 4113	Short Electrode Plate	37 - 12
B121 4120	Thermostat Ass'y	37 - 11
B121 4451	Exit Middle Guide Plate	39 - 20
B121 4461	Exit Lower Guide Plate	39 - 36
B121 4465	Short Front Outer Holder	39 - 32
B121 4467	Long Front Middle Holder	39 - 35
B121 4469	Long Rear Middle Holder	39 - 33
B121 4470	Right Lower Exit Guide Plate	29 - 14
B121 4473	Exit Roller Ring MM14	39 - 29
B121 4477	Short Rear Outer Holder	39 - 34
B121 4490	Antistatic Brush	45 - 3
B121 4503	Exit Photointerruptor Bracket	39 - 19
B121 5202	Harness - Registration Sensor	25 - 14
B121 5204	Harness - Discharge Lamp	19 - 4
B121 5204	Harness - Discharge Lamp	49 - 28
B121 5206	Harness - Density Sensor	49 - 29
B121 5206	Harness - Density Sensor	25 - 29
B121 5208	Harness - Ground Wire Scanner (B283)	49 - 1
B121 5212	Harness - Manual Feed	49 - 23
B121 5215	Harness - Paper End Sensor No.1	27 - 5
B121 5215	Harness - Paper End Sensor No.1	49 - 8
B121 5219	Harness - Ground Wire	35 - 13

Part No.	Description	Page and Index No.
B121 5220	Harness - HPS	49 - 11
B121 5238	Harness - Paper Feed Sensor	39 - 21
B121 5240	Harness - Document Feeder	49 - 4
B121 5248	Harness - Development Sensor	25 - 21
B121 5250	Harness - LDD	49 - 33
B121 5250	Harness - LDD	19 - 14
B121 5259	Harness - Paper End Sensor	29 - 23
B121 5439	Harness - Polygon Mirror Motor	19 - 13
B121 5801	Power Supply Unit Bracket	53 - 9
B121 5802	Guide Plate Bracket	53 - 7
B121 5810	BICU Bracket	49 - 10
B121 5822	Guide Mylar (B282)	49 - 2
B121 5825	Power Supply Cord Bracket	49 - 19
B121 5841	BCT Power Pack Bracket	51 - 15
B121 9640	Developer Type 28 Black	31 - 13
B122 1075	Front Reverse Sub-Unit Holder	51 - 5
B122 1083	Bracket	45 - 18
B122 1323	Left Upper Cover (B282)	9 - 21
B122 4460	Lower Exit Guide Plate	39 - 28
B122 4492	Large Exit Discharge Brush	39 - 41
B122 4493	Small Exit Discharge Brush	39 - 42
B122 5208	Ground Wire	49 - 1
B122 5821	Box Holder	49 - 22
B123 1102	Rear Fan Bracket	49 - 6
B123 1302	Fusing Cover:Paper Exit Sub-unit: Duplex (B282)	39 - 2
B123 4502	Middle Reverse Guide Plate	45 - 14
B123 4505	Timing Belt - 40S2M290	43 - 19
B123 4506	Reverse Roller Ground Plate	45 - 16
B123 4508	Middle:Reverse Holder	39 - 40
B123 4617	Entrance Duplex Guide Plate	41 - 26
B123 4627	Adhesion Duplex Cover	43 - 28
B123 4640	Driven Duplex Guide Plate Ass'y	41 - 12
B123 4661	Rear Duplex Inner Cover	43 - 22
B123 4670	Right Lower Exit Guide Plate Ass'y	41 - 14

Part No.	Description	Page and Index No.
B123 4675	Exit Duplex Sensor Bracket	41 - 10
B123 4679	Exit Sensor Cover	41 - 23
B123 4691	Decal	41 - 17
B123 4691	Decal	71 - 6
B123 4693	Duplex Unit Stopper Ass'y	43 - 32
B123 4697	Tension Spring 27N	43 - 27
B123 4973	Reverse Paper Feed Sensor Bracket	45 - 6
B123 4977	Right Upper Exit Guide Plate Ass'y	41 - 25
B123 5241	Harness - Duplex Unit	43 - 29
B123 5245	Harness:Duplex:Ground Wire	41 - 16
B123 5245	Harness:Duplex:Ground Wire	45 - 7
B123 5252	Harness - Duplex Paper End Sensor	43 - 11
B123 5253	Harness - Duplex Sensor	45 - 15
B132 1531	Panel:Logo	9 - 22
B180 2801	Holder:Paper Tray	53 - 11
B180 2801	Holder:Paper Tray	55 - 3
B229 1453	Keytop - Start	11 - 8
B229 1454	Keytop - Clear/Stop	11 - 9
B229 1475	Keytop - 10key	11 - 10
B229 1522	Sheet-Power Source-EU	11 - 17
B229 1525	Keytop-INITIAL	11 - 11
B229 1537	Keytop - Clear Modes	11 - 12
B238 1845	Seal:Exposure Glass	13 - 19
B238 2753	Decal - Side Fence	21 - 22
B243 1425	Cover - Operation Panel	11 - 6
B243 1451	Case:Operation Sub-unit	11 - 2
B243 1458	Keytop - Power Source	11 - 13
B243 1459	Keytop - Cursor	11 - 14
B243 1468	Cover - CPS EU	11 - 1
B243 1469	Keytop:CPS:EU	11 - 18
B243 1804	Harness - FFC	13 - 13
B243 1804	Harness - FFC	49 - 26
B243 2701	Paper Tray	23 - 24
B243 2702	Cover - Paper Tray	23 - 26
B243 5018	Choke Coil - B2435018	49 - 14

Part No.	Description	Page and Index No.
B243 5018	Choke Coil - B2435018	53 - 8
B243 5203	Harness - Main Motor	49 - 21
B243 5226	Harness - AC Switch 187	49 - 16
B243 5228	Harness - AC Dehumidifier EXP (B283)	49 - 15
B243 5230	Harness - Power Supply Unit	49 - 17
B243 5231	Harness - High Voltage	51 - 20
B243 5231	Harness - High Voltage	49 - 27
B243 5232	Harness - High Voltage Line B	51 - 18
B243 5233	Harness - High Voltage Line C/T	35 - 9
B243 5233	Harness - High Voltage Line C/T	51 - 19
B243 5260	Harness - AC Dehumidifier	53 - 16
B243 5261	Harness - Key Counter	49 - 24
B243 5870	PCB Bracket	57 - 3
B244 5155	PCB DCB (B282)	51 - 2
B245 1149	Magnetic Clutch:0.5N M:Z39	47 - 4
B245 2840	Paper Tray:PD-C2:Ass'y	23 - *
B245 4052	Hot Roller	37 - 20
B245 4054	Frame:Pressure:Printing	37 - 28
B245 4112	Electrode Plate:Middle	37 - 13
B245 4114	Electrode Plate:Rear	37 - 14
B245 4115	Electrode Plate:Front	37 - 10
B245 5200	Scanner Motor Harness	49 - 20
B245 5217	AC Harness - Fusing (B282)	49 - 12
B245 5223	Harness:Scanner	49 - 7
B259 1053	Door Shaft - Right Front	53 - 6
B259 1058	Door Shaft - Right Rear	53 - 12
B259 1119	Tapping Screw:M3x33	51 - 8
B259 1131	Screw:PCU	25 - 28
B259 1157	Fusing Swivel Bracket	47 - 11
B259 1174	Development Drive Shaft (03)	47 - 17
B259 1178	Paper Feed Drive Bracket	27 - 23
B259 1190	Shaft - Drive Manual Feed	27 - 20
B259 1194	Manual Feed Drivebracket	27 - 18
B259 1367	Cover Magnet	9 - 13
B259 1499	Tapping Screw - M3x8	11 - 15

Part No.	Description	Page and Index No.
B259 1691	Scanner Drive Shaft	17 - 11
B259 1702	Pulley Shaft	17 - 16
B259 1763	Xenon Lamp Stabilizer	15 - 16
B259 1768	Carriage No.2 Ass'y	15 - 5
B259 1776	Idler Belt Pulley Bracket - Front	15 - 9
B259 1778	Idler Belt Pulley Bracket - Rear	15 - 7
B259 1813	Holder:Lens:Ass'y	13 - 9
B259 2325	OPC Drum Shutter Plate	33 - 23
B259 2371	Rear Drum Stay	31 - 1
B259 2381	Discharge Lamp - QL	19 - 3
B259 2562	Registration Roller Drive	25 - 19
B259 2571	Registration Roller Driven - DIA16	25 - 18
B259 2594	Shaft - Feed	29 - 12
B259 2602	Manual Feed Table Ass'y	21 - 21
B259 2609	Paper End Sensor:Manual Feed:Ass'y	43 - 33
B259 2609	Paper End Sensor:Manual Feed:Ass'y	29 - 15
B259 2642	Pin - MM6	21 - 19
B259 2648	Door:Right:C2B:Ass'y	29 - 30
B259 2737	Paper Feed Roller Shaft Ass'y	23 - 10
B259 2786	Lever Shaft	21 - 20
B259 3031	Toner Supply Unit	35 - 1
B259 3170	Development Case Ass'y	31 - 8
B259 3390	Density Sensor:K-C2.5:Ass'y	31 - 10
B259 3422	Shaft:Slide	35 - 5
B259 3890	Density Sensor	25 - 26
B259 4115	Fusing Entrance Guide Plate	37 - 30
B259 4471	Exit Roller 2	39 - 3
B259 5034	Harness:Dehumidifier:EXP:Ass'y (B283)	49 - 15
B259 5223	Harness - Stabilizer	49 - 25
B259 5223	Harness - Stabilizer	15 - 17
B259 6058	Heater:Paper Feed:No.1:EU:Ass'y	53 - 2
B261 4623	Transport Roller - Connecting	43 - 7
B261 4624	Transport Roller:Drive:Duplex:Exit	43 - 6
B261 4625	Transport Roller:Drive:Duplex:Entrance	43 - 8
B261 4650	Separation Pad	43 - 5

Part No.	Description	Page and Index No.
B261 4686	Manual Feed Drive Shaft	43 - 16
B261 4705	Stepper Motor Bracket	43 - 31
B261 4983	Gate Pawl	39 - 24
B261 4989	Reverse Roller	45 - 2
B261 4994	Stepper Motor Bracket	45 - 11
B268 1085	Switch:LF-105-11	39 - 30
B268 1749	Scale - Left	13 - 2
B268 1751	Scale - Inner Back	13 - 11
B268 5874	Cover:Expand:Gdi	57 - 6
B269 4981	Guide Plate:Reverse:Left Upper	45 - 5
B276 1055	Brushless Motor:24V	47 - 1
B276 1072	Grip	53 - 3
B276 1073	Cover:Grip	53 - 1
B276 1150	Magnetic Clutch:Paper Feed:Drive:Ass'y	27 - 26
B276 1151	Magnetic Clutch:0.5N m:Z31	27 - 14
B276 1152	Magnetic Clutch:Manual Feed:Ass'y	27 - 35
B276 1183	Shaft:Paper Feed:Drive:Ass'y	27 - 21
B276 1192	Gear:Idler:Connecting	27 - 33
B276 1251	Cover:Shield Glass	19 - 1
B276 1332	Cover:Scanner:Left:NA	9 - 2
B276 1335	Cover:Scanner:Right:NA	9 - 9
B276 1338	Front Door - CNH	9 - 15
B276 1368	Cover:Exit:Rear:B:NA (B283)	9 - 5
B276 1452	Cover:Operation Sub-Unit:Lower	11 - 5
B276 1808	Inner Cover:Lens	13 - 8
B276 1917	Laser Diode Unit:Ass'y	19 - 15
B276 2576	Transport Roller	27 - 16
B276 2644	End Fence	23 - 1
B276 2646	Rubber Bushing	23 - 31
B276 2719	Spring:Base:5.8N	23 - 13
B276 3310	DC Motor:Toner Bottle:Kir-C3:Ass'y	47 - 6
B277 1310	Cover:Right Upper Front:C:NA (B282)	9 - 11
B277 1339	Cover:Rear:C:NA (B282)	9 - 6
B277 1347	Cover:Right Rear:C:NA (B282)	9 - 10
B277 1370	Cover:Exit:Rear:C:NA (B282)	9 - 5

Part No.	Description	Page and Index No.
B277 1372	Cover:Sorter:NA (B282)	9 - 17
B277 4984	DC Solenoid:Ass'y	45 - 13
B390 1759	Shaft:Scale	13 - 1
B622 5872	Rail Holder	57 - 4
B843 5880	Cover - Controller Box	57 - 1
B865 5040	PCB:3.5L:GDI:Ass'y	57 - 2
D100 1355	Cover:Exit:C3-DOM	9 - 3
D109 1313	Cover:CTL:D109	57 - 5
G012 3050	Side Fence Gear	21 - 7
G020 2599	Spring - Release Lever	23 - 22
G020 2784	Lever - By-pass Feed Table	21 - 15
G020 3334	Slider Ass'y	35 - 8
G020 5626	Push Switch	53 - 13
G020 5871	Spacer - KGLS-12RF	51 - 17
G029 4140	External Circlip	37 - 17
G029 4174	Pressure Roller Bushing	37 - 27
G029 4176	Turn Roller - Exit Sub-unit	39 - 37
G030 2670	Friction Pad (B283)	29 - 8
G052 4618	Bearing 30x42x7	37 - 19
G052 4873	Outer Exit Cover Roller	39 - 31
G060 2641	Transport Driven Roller - Middle	41 - 7
G104 5141	Knob Screw:M3	45 - 17
G361 5570	Photointerruptor - Duplex	39 - 22
G570 2730	Slider - Scanner	15 - 18
G800 3035	Push SW - Paper Size	27 - 2
G800 3035	Push Sw - Paper Size	55 - 2
G800 4854	Exit Roller	39 - 39

Part No.	Description	Page and Index No.
N803 6701	Flash Memory Card-4MB	73 - 4

Part No.	Description	Page and Index No.
AA06 2254	Registration Roller Spring	25 - 2
AA06 3398	Spring - Friction Pad	29 - 7
AA06 3399	Spring - Vertical Transport	41 - 3
AA06 3399	Spring - Vertical Transport	29 - 3
AA06 3607	Pressure Spring	25 - 24
AA06 3643	Spring - By-pass Feed Table	21 - 8
AA06 6342	Registration Sensor Spring	25 - 10
AA06 6343	Spring - Paper End Sensor	29 - 20
AA06 6343	Spring - Paper End Sensor	43 - 14
AA06 6635	Spring - Fusing Exit Guide	37 - 24
AA06 6637	Stripper Pawl Spring	37 - 8
AA06 6640	Pressure Spring	37 - 26
AA06 6641	Gate Pawl Spring	39 - 25
AA08 0267	Bushing - 8x12x18	25 - 6
AA08 0268	Bushing - Vertical Transport	29 - 2
AA08 0268	Bushing - Vertical Transport	41 - 2
AA08 0313	Driven Roller Bushing	41 - 8
AA08 0342	Fornt Bushing-registration Roller	25 - 5
AA08 0343	Rear Bushing-registration Roller	25 - 22
AA08 2101	Bushing - 6x10x6	29 - 18
AA08 2101	Bushing - 6x10x6	43 - 17
AA08 2101	Bushing - 6x10x6	27 - 15
AA08 2110	Bushing - 8x12x22	25 - 23
AA10 0015	Snap Ring - M6	47 - 26
AA10 0015	Snap Ring - M6	25 - 8
AA14 3444	Stepped Screw	33 - 11
AA14 3592	Screw- M4x6	49 - 34
AA14 3870	Stepped Screw	37 - 2
AB01 1402	Gear - 14Z	33 - 13
AB01 1403	Gear - 13Z	33 - 12
AB01 2311	Gear - 18Z	25 - 7
AB01 2312	Gear - 16Z	25 - 4
AB01 2313	Gear - 25Z	29 - 13
AB03 0569	Pulley - 30T	43 - 20
AC02 0095	Sync Detector Lenz	19 - 19

Part No.	Description	Page and Index No.
AC02 4009	Cylindrical Lens	19 - 9
AC03 0138	2nd Mirror	19 - 17
AC03 0139	Sync Detector Mirror	19 - 8
AD02 7018	Roller:Charge:A3	33 - 21
AD04 2058	Charge Cleaner Brush Roller	33 - 22
AD04 2059	Cleaning Blade Ass'y	33 - 15
AE02 0100	Pressure Roller	37 - 22
AE04 4062	Stripper Pawls	37 - 9
AF02 2138	Vertical Transport Roller	29 - 1
AF02 2138	Vertical Transport Roller	41 - 1
AF03 1060	By-pass Feed Roller	29 - 17
AF03 1060	By-pass Feed Roller	43 - 15
AG07 0514	Magnet Catch	29 - 31
AG07 0514	Magnet Catch	43 - 35
AH01 0010	Rubber Foot:H5	53 - 5
AH01 0010	Rubber Foot:H5	55 - 4
AW02 0156	Photointerruptor:EE-SX4235A-P2	13 - 4
AW02 0181	Paper Feed Sensor	41 - 27
AW10 0073	Thermistor	37 - 3
AX06 0323	Polygon Motor - 23622RPM	19 - 16
AX64 0169	Fan DC24V 1.92W	49 - 3
AZ00 0084	Power Supply Cord:Stopper:CHN	49 - 18
AZ23 0229	Power Supply Unit:CHN	49 - 13
AZ32 0152	Power Pack BCT	51 - 16
GW01 0007	Photo Reflection Sensor:Exit	45 - 9
GW02 0020	Photointerruptor:LG248NL1	43 - 12
GW02 0020	Photointerruptor:LG248NL1	29 - 22
GW02 0020	Photointerruptor:LG248NL1	27 - 29
GW02 0020	Photointerruptor:LG248NL1	25 - 13
GW02 0020	Photointerruptor:LG248NL1	13 - 6
GX64 5734	Fan Motor:Mm80 DC24V 3.12W	51 - 9

Part No.	Description	Page and Index No.
VSSM 9000	Digital Multimeter-Fluke187	73 - 3

Part No.	Description	Page and Index No.
0313 0060N	Screw - M3x6	45 - 103
0313 0060N	Screw - M3x6	17 - 109
0313 0060N	Screw - M3x6	37 - 104
0353 0050N	Screw-M3x5	11 - 102
0353 0060N	Bind Screw - M3x6	57 - 102
0353 0060N	Bind Screw - M3x6	33 - 101
0360 3006N	Screw - M3x6	31 - 101
0360 3006P	Screw - M3x6	17 - 107
0433 0060N	Pan Self-Tapping Screw:3x6	43 - 106
0450 3008N	Tapping Screw - M3x8	39 - 102
0450 3008N	Tapping Screw - M3x8	27 - 106
0450 3008N	Tapping Screw - M3x8	29 - 101
0450 3008N	Tapping Screw - M3x8	41 - 101
0450 3008N	Tapping Screw - M3x8	43 - 102
0450 3008N	Tapping Screw - M3x8	25 - 101
0450 3008N	Tapping Screw - M3x8	23 - 102
0450 3008N	Tapping Screw - M3x8	35 - 101
0450 3008N	Tapping Screw - M3x8	45 - 102
0450 3008N	Tapping Screw - M3x8	47 - 104
0450 3008N	Tapping Screw - M3x8	53 - 107
0450 3008N	Tapping Screw - M3x8	51 - 102
0450 3010N	Tapping Screw - M3x10	35 - 103
0450 3010N	Tapping Screw - M3x10	51 - 105
0450 3012N	Tapping Screw:3x12	19 - 102
0450 3012N	Tapping Screw:3x12	25 - 102
0450 3012N	Tapping Screw:3x12	39 - 104
0450 3020N	Tapping Screw:M3x20	19 - 103
0450 4010N	Tapping Screw:M4x10	39 - 101
0450 4010N	Tapping Screw:M4x10	47 - 101
0451 3006N	Tapping Screw - 3x6	57 - 101
0451 3006N	Tapping Screw - 3x6	55 - 101
0451 3006N	Tapping Screw - 3x6	53 - 101
0451 3006N	Tapping Screw - 3x6	49 - 102
0451 3006N	Tapping Screw - 3x6	51 - 101
0451 3006N	Tapping Screw - 3x6	41 - 102

Part No.	Description	Page and Index No.
0451 3006N	Tapping Screw - 3x6	43 - 101
0451 3006N	Tapping Screw - 3x6	47 - 106
0451 3006N	Tapping Screw - 3x6	45 - 101
0451 3006N	Tapping Screw - 3x6	39 - 103
0451 3006N	Tapping Screw - 3x6	27 - 101
0451 3006N	Tapping Screw - 3x6	13 - 101
0451 3006N	Tapping Screw - 3x6	15 - 101
0451 3006N	Tapping Screw - 3x6	17 - 101
0451 3006N	Tapping Screw - 3x6	29 - 102
0451 3008N	Tapping Screw - M3x8	11 - 101
0451 3008N	Tapping Screw - M3x8	53 - 102
0451 3008N	Tapping Screw - M3x8	49 - 101
0451 3008N	Tapping Screw - M3x8	9 - 101
0451 3008N	Tapping Screw - M3x8	21 - 101
0451 3030N	Tapping Screw:3x30	49 - 103
0452 3008N	Tapping Screw - M3x8	31 - 102
0452 3008N	Tapping Screw - M3x8	35 - 102
0452 3008N	Tapping Screw - M3x8	37 - 103
0452 3010N	Binding Self-Tapping Screw:3x10	19 - 101
0452 3012N	Binding Self-Tapping Screw:M3x12	33 - 102
0452 3014N	Binding Self-Tapping Screw:M3x14	19 - 104
0453 3006N	Tapping Screw - M3x6	17 - 108
0454 3006Q	Tapping Screw - M3x6	27 - 102
0454 3006Q	Tapping Screw - M3x6	53 - 103
0454 3006Q	Tapping Screw - M3x6	13 - 102
0454 3006Q	Tapping Screw - M3x6	17 - 102
0454 3008Q	Tapping Screw:3x8	47 - 102
0457 3006N	Tapping Screw:WP:3x6	27 - 108
0720 0030E	Retaining Ring - M3	39 - 105
0720 0040E	Retaining Ring - M4	27 - 103
0720 0040E	Retaining Ring - M4	43 - 103
0720 0040E	Retaining Ring - M4	29 - 103
0720 0040E	Retaining Ring - M4	45 - 104
0720 0060E	Retaining Ring - M6	47 - 103
0720 0060E	Retaining Ring - M6	17 - 106

Part No.	Description	Page and Index No.
0736 0610	Bushing 6x10	33 - 103
0802 5299	Tapping Screw - M3x8	49 - 112
0804 6123	Hexagonal Bolt:W/Washer:M3x8	37 - 101
0805 0088	Retaining Ring - M6	23 - 101
0805 0097	Ring Separator	27 - 104
0805 3530	Bearing 8x22x7	17 - 105
0950 3006N	Screw:Spring Washer:M3x6	53 - 108
0950 3006N	Screw:Spring Washer:M3x6	55 - 103
0954 3010N	Screw:Polished Round/Spring:M3x10	37 - 102
0954 4008N	Screw - M4x8	37 - 105
1105 0009	Nylon Clamp - 5N	43 - 105
1105 0197	Wire Saddle	53 - 106
1105 0487	Harness Clamp	51 - 103
1105 0487	Harness Clamp	53 - 105
1105 0487	Harness Clamp	49 - 105
1105 0487	Harness Clamp	17 - 104
1105 0487	Harness Clamp	27 - 107
1105 0488	Harness Clamp	53 - 109
1105 0488	Harness Clamp	47 - 105
1105 0488	Harness Clamp	49 - 111
1105 0499	Support Spacer - M3x29	51 - 104
1105 0511	Harness Clamp - LWS-0306ZC	43 - 104
1105 0511	Harness Clamp - LWS-0306ZC	35 - 104
1105 0511	Harness Clamp - LWS-0306ZC	41 - 103
1105 0511	Harness Clamp - LWS-0306ZC	53 - 104
1105 0511	Harness Clamp - LWS-0306ZC	17 - 103
1105 0511	Harness Clamp - LWS-0306ZC	49 - 106
1105 0511	Harness Clamp - LWS-0306ZC	55 - 102
1105 0511	Harness Clamp - LWS-0306ZC	27 - 105
1105 0518	Edge Saddle - LES-1010	49 - 110
1105 0522	Edge Saddle - LES0510	25 - 103
1107 1083	Fuse:SST 4	49 - 107
1107 1084	Fuse:CES14-8A-N1	49 - 108
1107 1317	Fuse:FIH 250V 2.5A(EM)	49 - 107
1204 2608	Rocker Switch:SDDJE33900	49 - 104

Part No.	Description	Page and Index No.
1407 5299	RAM:FM1608-120-P	49 - 109

Part No.	Description	Page and Index No.
5203 9502	Grease 501	73 - 1
5215 2621	Snap Ring - M6	23 - 6
5215 2713	Bottom Plate Pad	23 - 27
5304 1639	Bushing - 8mm	47 - 24
5442 1924	Exposure Glass Cushion	13 - 15
5447 2681	Snap Ring	21 - 18
5447 2681	Snap Ring	25 - 3
5447 2681	Snap Ring	27 - 6