


PostScript 3 Supplement





- 2 Mac OS Configuration
- 3 Using PostScript 3
- 4) Printer Utility for Mac

Read this manual carefully before you use this machine and keep it handy for future reference. For safe and correct use, be sure to read the Safety Information in "About This Machine" before using the machine.

Introduction

This manual contains detailed instructions and notes on the operation and use of this machine. For your safety and benefit, read this manual carefully before using the machine. Keep this manual in a handy place for quick reference.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Notes:

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Manuals for This Machine

Refer to the manuals that are relevant to what you want to do with the machine.

∰Important

- □ Media differ according to manual.
- **□** The printed and electronic versions of a manual have the same contents.
- Adobe Acrobat Reader/Adobe Reader must be installed in order to view the manuals as PDF files.
- Depending on which country you are in, there may also be html manuals. To view these manuals, a Web browser must be installed.

* About This Machine

Be sure to read the Safety Information in this manual before using the machine.

This manual provides an introduction to the functions of the machine. It also explains the control panel, preparation procedures for using the machine, how to enter text, and how to install the CD-ROMs provided.

General Settings Guide

Explains User Tools settings, and Address Book procedures such as registering fax numbers, e-mail addresses, and user codes. Also refer to this manual for explanations on how to connect the machine.

Trouble Shooting

Provides a guide to solving common problems, and explains how to replace paper, toner, and other consumables.

Security Reference

This manual is for administrators of the machine. It explains security functions that you can use to prevent unauthorized use of the machine, data tampering, or information leakage.

For enhanced security, we recommend the following settings.

- Install the Server Certificate.
- Enable SSL(Secure Sockets Layer) Encryption.
- Change the user name and password of the administrator using Web Image Monitor.

For details, see "Setting Up the Machine", Security Reference.

Be sure to read this manual when setting the enhanced security functions, or user and administrator authentication.

Copy Reference

Explains Copier functions and operations. Also refer to this manual for explanations on how to place originals.

Facsimile Reference

Explains Facsimile functions and operations.

Printer Reference

Explains Printer functions and operations.

Scanner Reference

Explains Scanner functions and operations.

Network Guide

Explains how to configure and operate the machine in a network environment, and use the software provided.

This manual covers all models, and includes descriptions of functions and settings that might not be available on this machine. Images, illustrations, and information about operating systems that are supported might also differ slightly from those of this machine.

Other manuals

- Manuals for This Machine
- Safety Information
- Quick Reference Copy Guide
- Quick Reference Fax Guide
- Quick Reference Printer Guide
- Quick Reference Scanner Guide
- PostScript 3 Supplement
- UNIX Supplement
- Manuals for DeskTopBinder Lite
 - DeskTopBinder Lite Setup Guide
 - DeskTopBinder Introduction Guide
 - Auto Document Link Guide

🖉 Note

- □ Manuals provided are specific to machine types.
- For "UNIX Supplement", please visit our Web site or consult an authorized dealer.

TABLE OF CONTENTS

Manuals for This Machine	i
How to Read This Manual1	I
Symbols1	l

1. Windows Configuration

Using the DeskTopBinder - SmartDeviceMonitor for Client Port	3
Installing DeskTopBinder - SmartDeviceMonitor for Client	3
Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me - TCP/IP)	4
Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me - IPP)	5
Installing the PostScript 3 Printer Driver (Windows 2000 - TCP/IP)	7
Installing the PostScript 3 Printer Driver (Windows 2000 - IPP)	8
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003 - TCP/IP)	.10
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003 - IPP)	.11
Installing the PostScript 3 Printer Driver (Windows NT 4.0 - TCP/IP)	
Installing the PostScript 3 Printer Driver (Windows NT 4.0 - IPP)	
Changing the Port Settings for DeskTopBinder - SmartDeviceMonitor for Client	. 15
Using the Standard TCP/IP Port	
Installing the PostScript 3 Printer Driver (Windows 2000)	.17
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)	. 18
Using the LPR Port	.20
Installing the PostScript 3 Printer Driver (Windows 2000)	
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)	.21
Installing the PostScript 3 Printer Driver (Windows NT 4.0)	.23
Using as the Windows Network Printer	.24
Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me)	.24
Installing the PostScript 3 Printer Driver (Windows 2000)	
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)	
Installing the PostScript 3 Printer Driver (Windows NT 4.0)	.27
Using as the NetWare Print Server / Remote Printer	.28
When using the PostScript 3 Printer Driver	.28
Installing the Printer Driver Using USB	.29
Windows 98 SE / Me - USB	.29
Windows 2000 - USB	
Windows XP, Windows Server 2003 - USB	
Troubleshooting for using USB	.33
Printing with Parallel Connection	.34
Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me)	.34
Installing the PostScript 3 printer driver (Windows 2000)	
Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)	
Installing the PostScript 3 Printer Driver (Windows NT 4.0)	.37
Printing with Bluetooth Connection	.38
Supported Profiles	
Printing with Bluetooth Connection	. 38
If a Message Appears during Installation	.41
Making Option Settings for the Printer	.42

Setting Up the Printer Driver	43
Windows 95 / 98 / Me - Accessing the Printer Properties	
Windows 2000 - Accessing the Printer Properties	
Windows XP, Windows Server 2003 - Accessing the Printer Properties	
Windows NT 4.0 - Accessing the Printer Properties	

2. Mac OS Configuration

Mac OS	51
Installing the PostScript 3 Printer Driver and PPD File	
Setting Up PPD Files	52
Setting Up Options	52
Installing Adobe Type Manager	53
Installing Screen fonts	
Using USB Interface	
Changing to EtherTalk	55
Mac OS X	56
Mac OS X Installing the PPD Files	
Installing the PPD Files	56
Installing the PPD Files Setting Up the PPD File	56 57
Installing the PPD Files Setting Up the PPD File Setting Up Options	56 57 57
Installing the PPD Files Setting Up the PPD File Setting Up Options Using USB Interface	56 57 57 58
Installing the PPD Files Setting Up the PPD File Setting Up Options	56 57 57 58 59

3. Using PostScript 3

Setting Up Options	63
Printing a Document	65
Job Type	
User Code	66
Paper Selection	66
Paper Size	67
Fit to Paper	67
Input Slot	68
Resolution	68
Orientation Override	69
Print Mode	69
Duplex Printing	70
Collate	72
Paper Type	72
Destination	73
Staple	73
Watermark	74
Watermark Text	74
Watermark Font	74
Watermark Size	
Watermark Angle	75
Watermark Style	
Dithering	
Image Smoothing	77

4. Printer Utility for Mac

Installing Printer Utility for Mac	79
Starting Printer Utility for Mac	80
Mac OS	
Mac OS X	80
Printer Utility for Mac Functions	
Downloading PS Fonts	
Displaying Printer's Fonts	
Deleting Fonts	83
Page Setup	
Printing Fonts Catalog	84
Printing Fonts Sample	
Renaming the Printer	84
Restarting the Printer	
Downloading PostScript Files	
Selecting the Zone	
Displaying the Printer Status	
Launching the Dialogue Console	
INDEX	88

How to Read This Manual

Symbols

This manual uses the following symbols:

A WARNING:

Indicates important safety notes.

Ignoring these notes could result in serious injury or death. Be sure to read these notes. They can be found in the "Safety Information" section of About This Machine.

A CAUTION:

Indicates important safety notes.

Ignoring these notes could result in moderate or minor injury, or damage to the machine or to property. Be sure to read these notes. They can be found in the "Safety Information" section of About This Machine.

Important

Indicates points to pay attention to when using the machine, and explanations of likely causes of paper misfeeds, damage to originals, or loss of data. Be sure to read these explanations.

🔗 Note

Indicates supplementary explanations of the machine's functions, and instructions on resolving user errors.

₽ Reference

This symbol is located at the end of sections. It indicates where you can find further relevant information.

[]

Indicates the names of keys that appear on the machine's display panel.

Indicates the names of keys on the machine's control panel.

1. Windows Configuration

Using the DeskTopBinder -SmartDeviceMonitor for Client Port

Installing DeskTopBinder - SmartDeviceMonitor for Client

∰Important

- To install DeskTopBinder SmartDeviceMonitor for Client under Windows 2000 / XP Professional, Windows Server 2003, and Windows NT 4.0, you must have an account that has Manage Printers permission. Log on as an Administrator.
- Install DeskTopBinder SmartDeviceMonitor for Client before installing the printer driver when using the DeskTopBinder - SmartDeviceMonitor for Client port.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

B Select an interface language, and then click [OK].

The default interface language is English.

Click [DeskTopBinder - SmartDeviceMonitor for Client].

Select an interface language, and then click [OK].

The default interface language is English.

- The message to quit all other applications appears. Quit all applications, and then click [Next >].
- The software license agreement appears in the [License Agreement] dialog box. After reading through its contents, click [Yes].
- **B** Follow the instructions on the display and click [Next >] to proceed next step.
- After the installation is completed, select one of the options to restart the computer either now or later, and click [Complete].

Restart the computer to complete installation.

🖉 Note

- □ To stop installation of the selected software, click **[Cancel]** before installation is complete.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me - TCP/IP)

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

E Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

5 Click [Next >].

Click [Local Printer], and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

Select the name of the machine whose driver you want to install, and then click [Next >].

In the [Available ports:] box, click [Printer Port], and then click [Next >].

Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.

 ${f U}$ Specify whether or not to print a test page, and then click [Finish].

U On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.

Click the icon of the printer you want to use. On the [File] menu, click [Properties].

U On the [Details] tab, click [Add Port...].

Click [SmartDeviceMonitor] in the [Other] list, and then click [OK].

E Click [TCP/IP], and then click [Search].

A list of printers using TCP/IP appears.

${f U}$ Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a machine not listed here, click **[Specify Address]**, enter the IP address or host name of the machine, and then click **[OK]**.

You cannot add an IP address partially similar to the one already used. For example, if "192.168.0.2" is in use, "192.168.0.2xx" cannot be used. Similarly, if "192.168.0.20" is in use, "192.168.0.2" cannot be used.

Check that the selected port is highlighted in [Print to the following port], and then click [OK].

E Restart the computer to complete installation.

🔗 Note

- A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me - IPP)

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

E Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

Click [Next >].

6 Click [Local Printer], and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

Select the name of the machine whose driver you want to install, and then click [Next >].

- In the [Available ports:] box, click [Printer Port], and then click [Next >].
- **9** Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.
- ${f U}$ Specify whether or not to print a test page, and then click [Finish].
- On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- Click the icon of the printer you want to use. On the [File] menu, click [Properties].
- U On the [Details] tab, click [Add Port...].
- Click [SmartDeviceMonitor] in the [Other] list, and then click [OK].
- Click [IPP].
- In the [Printer URL] box, enter "http://(printer's address)/printer" as the printer's address.

If the server authentification is issued, to enable SSL (a protocol for encrypted communication), enter "https://(printer's address)/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IP address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http://printer's address/ipp" as the printer's address.

Enter a name for identifying the printer in [IPP Port Name]. Use a name different from the one of any existing port.

If a name is not specified here, the address entered in the **[Printer URL]** box becomes the IPP port name.

Click [Detailed Settings] to configure proxy server, IPP user name, and other settings. Make these settings, and then click [OK].

You can enter "http://printer's address/ipp" as the printer's address.

Click [OK].

Check that the selected port is highlighted in [Print to the following port], and then click [OK].

A Restart the computer to complete installation.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows 2000 - TCP/IP)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

U Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

Click [Next >].

Click [Local printer], and then click [Next >].

Click [Create a new port:].

Select [SmartDeviceMonitor] in the [Type] list, and then click [Next >].

Click [TCP/IP], and then click [Search].

A list of printers using TCP/IP appears.

${f U}$ Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a machine not listed here, click **[Specify Address]**, and then enter the IP address or host name of the machine.

Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.

E Specify whether or not to share the printer, and then click [Next >].

Specify whether or not to print a test page, and then click [Next >].

Click [Finish].

The printer driver installation starts.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows 2000 - IPP)

∰Important

□ Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

E Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

5 Click [Next >].

Click [Local printer], and then click [Next >].

2 Click [Create a new port:].

Select [SmartDeviceMonitor] in the [Type] list, and then click [Next >].

9 Click [IPP].

In the [Printer URL] box, enter "http://(printer's address)/printer" as the printer's address.

If the server authentification is issued, to enable SSL (a protocol for encrypted communication), enter "https://(printer's address)/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IP address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http://printer's address/ipp" as the printer's address.

Enter a name for identifying the printer in [IPP Port Name]. Use a name different from the name of any existing port.

If a name is not specified here, the address entered in the **[Printer URL]** box becomes the IPP port name.

Click [Detailed Settings] to configure proxy server, the IPP user name and other settings. Specify the necessary settings, and then click [OK].

For information about the settings, see DeskTopBinder - SmartDeviceMonitor for Client Help.

Click [OK].

Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

E Change the printer name if you want, and then click [Next >].

U Specify whether or not to print a test page, and then click [Next >].

Click [Finish].

The printer driver installation starts.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003 - TCP/IP)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

Click [Next >].

Click [Local printer attached to this computer.], and then click [Next >].

Click [Create a new port:].

Select [SmartDeviceMonitor] in the [Type of port:] list, and then click [Next >].

Click [TCP/IP], and then click [Search].

A list of printers using TCP/IP appears.

${f W}$ Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a machine not listed here, click **[Specify Address]**, and then enter the IP address or host name of the machine.

Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.

E Specify whether or not to print a test page, and then click [Next>].

Click [Finish].

The printer driver installation starts.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003 - IPP)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

5 Click [Next >].

Click [Local printer attached to this computer.], and then click [Next >].

- Click [Create a new port:].
- Select [SmartDeviceMonitor] in the [Type of port:] list, and then click [Next >].
- **9** Click [IPP].
- U In the [Printer URL] box, enter "http://(printer's address)/printer" as the printer's address.

If the server authentification is issued, to enable SSL (a protocol for encrypted communication), enter "https://(printer's address)/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IP address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http://printer's address/ipp" as the printer's address.

Enter a name for identifying the printer in [IPP Port Name]. Use a name different from the one of any existing port.

If a name is not specified here, the address entered in the **[Printer URL]** box becomes the IPP port name.

Click [Detailed Settings] to make necessary, and then click [OK].

For information about the settings, see DeskTopBinder - SmartDeviceMonitor for Client Help.

Click [OK].

Check that the name of the printer driver you want to install is selected, and then click [Next >].

Change the name of the printer if you want, and then click [Next >]. Select the **[Yes]** check box to configure the printer as default.

Click [Finish].

The printer driver installation starts.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows NT 4.0 - TCP/IP)

∰Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- □ If your operating system is Windows NT4.0, download printer driver for Windows NT4.0 from the supplier's Web site.

U Double-click on "SETUP.EXE" in the downloaded folder.

Add Printer Wizard starts.

Select [My Computer], and then click [Next >].

- Click [Add Port...].
- Click [SmartDeviceMonitor], and then click [New Port...].

5 Click [TCP/IP], and then click [Search].

12 A list of printers using **[TCP/IP]** appears.

6 Select the printer you want to use, and then click [OK].

Only printers that respond to a broadcast from the computer appear. To use a machine not listed here, click **[Specify Address]**, and then enter the IP address or host name of the machine.

Click [Close] to close the [Printer Port] dialog box.

Click [Next >].

Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.

Specify whether or not to share the printer, and then click [Next >].

Specify whether or not to print a test page, and then click [Finish]. The printer driver installation starts.

E Restart the computer to complete installation if necessary.

🔗 Note

A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Installing the PostScript 3 Printer Driver (Windows NT 4.0 - IPP)

Important

- □ Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- □ If your operating system is Windows NT4.0, download printer driver for Windows NT4.0 from the supplier's Web site.

U Double-click on "SETUP.EXE" in the downloaded folder.

Add Printer Wizard starts.

- Select [My Computer], and then click [Next >].
- Click [Add Port...].
- Click [SmartDeviceMonitor], and then click [New Port...].
- **5** Click [IPP].

In the [Printer URL] box, enter "http://(printer's address)/printer" as the printer's address.

If the server authentification is issued, to enable SSL (a protocol for encrypted communication), enter "https://(printer's address)/printer" (Internet Explorer 5.01, or a higher version must be installed).

(example IP address: 192.168.15.16)

http://192.168.15.16/printer

https://192.168.15.16/printer

You can enter "http://printer's address/ipp" as the printer's address.

Lenter a name for identifying the printer in [IPP Port Name]. Use a name different from the one of any existing port.

If a name is not specified here, the address entered in the **[Printer URL]** box becomes the IPP port name.

Click [Detailed Settings] to make necessary settings, and then click [OK].

For information about the settings, see DeskTopBinder - SmartDeviceMonitor for Client Help.

Click [OK].

Click [Close] to close the [Printer Port] dialog box.

Click [Next >].

Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

E Change the printer name if you want, and then click [Next >].

Select the [Yes] check box to configure the printer as default.

Specify whether or not to share the printer, and then click [Next >].

U Specify whether or not to print a test page, and then click [Finish]. The printer driver installation starts.

U Restart the computer to complete installation if necessary.

🖉 Note

□ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Changing the Port Settings for DeskTopBinder -SmartDeviceMonitor for Client

Follow the procedure below to change the DeskTopBinder - SmartDeviceMonitor for Client settings, such as TCP/IP timeout, recovery/parallel printing, and printer groups.

Windows 95 / 98:

Open the [Printers] window from the [Start] menu.

In the [Printers] window, click the icon of the printer you want to use. On the [File] menu, click [Properties].

Click the [Details] tab, and then click [Port Settings].

The **[Port Settings]** dialog box appears.

Windows 2000 / Windows NT 4.0:

Open the [Printers] window from the [Start] menu.

2 In the [Printers] window, click the icon of the printer you want to use. On the [File] menu, click [Properties].

U On the [Ports] tab, click [Configure Port]

The [Port Configuration] dialog box appears.

Windows XP, Windows Server 2003:

Open the [Printers and Faxes] window from the [Start] menu. The [Printers and Faxes] window appears.

2 Click the icon of the machine you want to use. On the [File] menu, click [Properties]. The printer properties appear.

Click the [Ports] tab, and then click [Configure Port].

The [Port Configuration] dialog box appears.

- For TCP/IP, timeout setting can be configured.
- User, proxy, and timeout settings can be configured for IPP.

For information about these settings, see DeskTopBinder - SmartDevice-Monitor for Client Help.

How to enable Recovery/Parallel Printing

If no settings on the **[Recovery/Parallel Printing]** tab are available, follow the procedure below.

1 Start DeskTopBinder - SmartDeviceMonitor for Client, and then rightclick the DeskTopBinder - SmartDeviceMonitor for Client icon on the taskbar.

2 Point to [Property] and then, click [Extended Features Settings].

Select the [Set Recovery/Parallel Printing for each port] check box.

Click [OK] to close the [Extended Features Settings] dialog box.

Using the Standard TCP/IP Port

Installing the PostScript 3 Printer Driver (Windows 2000)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

E Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5 Click [Next >].
- Click [Local printer], and then click [Next >].
- Click [Create a new port:].

Select [Standard TCP/IP Port] in the [Type:] list, and then click [Next >].

Click [Next >] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.

Enter the printer name or IP address in the [Printer Name or IP Address] box. The [Port Name] text box automatically obtains a port name. Change this name if necessary.

- Click [Next >]
- Click [Finish] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.
- E Check that the name of the machine whose driver you want to install is selected, and then click [Next >].
- Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.

Click [Next >].

U Specify whether or not to print a test page, and then click [Next >].

Click [Finish].

The printer driver installation starts.

🖉 Note

- □ A user code can be set after the printer driver installation . For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

5 Click [Next >].

Click [Local printer attached to this printer], and then click [Next >].

Click [Create a new port:].

Select [Standard TCP/IP Port] in the [Type of port:] list, and then click [Next >].

Click [Next >] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.

Enter the printer name or IP address in the [Printer Name or IP Address] box. The [Port Name] text box automatically obtains a port name. Change this name if necessary.

Click [Next >]

Click [Finish] in the [Add Standard TCP/IP Printer Port Wizard] dialog box.

E Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.

E Specify whether or not to print a test page, and then click [Next>].

Click [Finish].

The printer driver installation starts.

🔗 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Using the LPR Port

Installing the PostScript 3 Printer Driver (Windows 2000)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

E Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- **5** Click [Next >].
- Click [Local printer], and then click [Next >].
- Click [Create a new port:].
- Select [LPR Port] in the [Type:], and then click [Next >].
- Enter the printer's IP address in the [Name or address of server providing lpd] box.
- Enter "1p" in the [Name of printer or print queue on that server] box, and then click [OK].
- Check that the name of the machine whose driver you want to install is selected, and then click [Next >].
- Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.
- Click [Next >].
- Specify whether or not to print a test page, and then click [Next >].
- Click [Finish].

The printer driver installation starts.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)

∰Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- □ In an IPv6 environment, you cannot use the LPR Port. Use the DeskTop Binder-SmartDeviceMonitor port.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

5 Select [My Computer], and then click [Next >].

Click [Local Printer attached to this computer.], and then click [Next >].

Click [Create a new port:].

Select [LPR Port] in the [Type of port:], and then click [Next >].

If LPR Port is not available, you need to install the optional networking component, Print Services for UNIX. See p.22 "Installing Print Services for UN-IX".

- Enter the printer's IP address in the [Name or address of server providing lpd] box.
- Enter "1p" in the [Name of printer or print queue on that server box], and then click [OK].

Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

Change the printer name if you want, and then click [Next >].

Select the **[Yes]** check box to configure the printer as default.

Specify whether or not to print a test page, and then click [Next >].

Click [Finish].

The printer driver installation starts.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing Print Services for UNIX

Click [Start], and then click [Control Panel].

2 In Control Panel, click [Add or Remove Programs].

Click [Add/Remove Windows Components].

In the Windows Components Wizard, click [Other Network File and Print Services], and then click [Details].

5 Select [Print Services for UNIX], and then click [OK].

6 Click [Next], and then click [Finish].

Installing the PostScript 3 Printer Driver (Windows NT 4.0)

∰Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- □ If your operating system is Windows NT4.0, download printer driver for Windows NT4.0 from the supplier's Web site.
- **1 Double-click on "SETUP.EXE" in the downloaded folder.** Add Printer Wizard starts.
- **2** Select [My Computer], and then click [Next >].
- Click [Add Port...].
- Select [LPR Port], and then click [New Port...].
- Enter the printer's IP address in the [Name or address of server providing lpd] box.
- Enter "lp" in the [Name of printer or print queue on that server:] box, and then click [OK].
- Click [Close] to close the [Printer Port] dialog box.
- Click [Next >].
- Check that the name of the machine whose driver you want to install is selected, and then click [Next >].

Change the printer name if you want, and then click [Next >]. Select the [Yes] check box to configure the printer as default.

Specify whether or not to share the printer, and then click [Next >].

Specify whether or not to print a test page, and then click [Finish]. The printer driver installation starts.

E Restart the computer to complete installation.

🖉 Note

□ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Using as the Windows Network Printer

Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me)

∰Important

If you print from a print server connected to the printer using the DeskTop Binder-SmartDeviceMonitor port, the client cannot use Recovery Printing and Parallel Printing.

U Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5 Click [Next >].
- Click [Network printer], and then click [Next >].
- Click [Browse].
- Click the computer name you want to use as a print server in the [Browse for Printer] window.

Select the printer you want to use, and then click [OK].

Check the location of the selected printer is shown, and then click [Next >].

Change the printer name if you want, and then click [Next >].

Select the **[Yes]** check box to configure the printer as default.

B Specify whether or not to print a test page, and then click [Finish].

B Restart the computer.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows 2000)

∰Important

- Installing a printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- If you print from a print server connected to the printer using the DeskTop Binder-SmartDeviceMonitor port, the client cannot use Recovery Printing and Parallel Printing.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- 5 Click [Next >].
- Click [Network printer], and then click [Next >].
- Select the location method from the [Locate Your Printer] screen, and then click [Next >].

Double-click the computer name you want to use as a print server in the [Shared printers] window.

Select the printer you want to use, and then click [Next >].

The printer driver installation starts.

Click [Next >].

Select the **[Yes]** check box to configure the printer as default.

Click [Finish].

Restart the computer to complete installation.

🖉 Note

- A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)

∰Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- If you print from a print server connected to the printer using the DeskTop Binder-SmartDeviceMonitor port, the client cannot use Recovery Printing and Parallel Printing.
- □ If you print with a Windows XP or Windows Server 2003 print server, Desk-Top Binder-SmartDeviceMonitor notification functions may not be possible for the client.
- **1** Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- **5** Click [Next >].
- Click [A network printer, or a printer attached to another computer] and then click [Next >].
- Select [Connect to this printer [or to browse for a printer, select this option and click Next]:], and then click [Next >].

Double-click the computer name you want to use as a print server in the [Shared printers] window.

Select the printer you want to use, and then click [Next >].

The printer driver installation starts.

Click [Next >].

Select the **[Yes]** check box to configure the printer as default.

Click [Finish].

Restart the computer to complete installation.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows NT 4.0)

∰Important

- Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.
- □ If you print from a print server connected to the printer using the DeskTop Binder-SmartDeviceMonitor port, the client cannot use Recovery Printing and Parallel Printing.
- □ To print from a Windows NT 4.0 print server, install the printer driver before you connect the print server to the printer.
- □ If your operating system is Windows NT4.0, download printer driver for Windows NT4.0 from the supplier's Web site.
- **U** Double-click on "SETUP.EXE" in the downloaded folder.

Add Printer Wizard starts.

- Click [Network printer server], and then click [Next >].
- Double-click the computer name you want to use as a print server in the [Shared printers] window.
- Select the printer you want to use, and then click [Next >].
- **5** Check the location of the selected printer is shown, and then click [Next >].
- Change the printer name if you want, and then click [Next >].
- Specify whether or not to print a test page, and then click [Finish].

Restart the computer to complete installation.

🖉 Note

□ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Using as the NetWare Print Server / Remote Printer

When using the PostScript 3 Printer Driver

∰Important

□ In an IPv6 environment, Netware servers cannot be used.

Follow the procedure below to set up the PostScript 3 printer driver.

For Windows 95 / 98 / Me

- **1** In the [Printers] window, open the printer properties.
- Click the [PostScript] tab.
- Click [Advanced].
- Clear the [Send CTRL+D before job] and [Send CTRL+D after job] check boxes, and then click [OK].
- **5** Click **[OK]** to close the printer properties dialog box.

For Windows 2000 / XP / Server 2003 / NT4.0

- **1** In the [Printers] windows, open the printer properties.
- **2** Click [Device Settings].
- Select [No] in the [Send CTRL-D After Each Job:] and [Send CTRL-D Each Job:] lists, and then click [OK].

Installing the Printer Driver Using USB

This section explains how to install printer drivers using USB.

∰Important

□ Make sure that machine is connected to the computer's USB ports using the USB interface cable.

Before installing, check that only the operating system is running on the computer and no print jobs are in progress.

The printer drivers can be installed from the CD-ROM provided with this machine.

Windows 98 SE / Me - USB

∰Important

Installation via USB is not possible under Windows 95 / 98. Upgrade to Windows 98 SE / Me.

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB" port is added to the **[Printers]** window.

1 Turn off the power of the machine.

2 Connect the machine to the computer using the USB cable.

Connect the USB cable firmly.

3 Turn on the power of the machine.

The plug and play function starts and the **[New Hardware Found]**, **[Device Driver Wizard]**, or **[Add New Hardware Wizard]** dialog box appears, depending on the operating system.

4 Click [Next >].

Click [Search for the best driver for your device. (Recommended).], and then click [Next >].

Select the [Specify a location:] check box, and then click [Browse...].

The [Browse for Folder] dialog box appears.

2 Insert the CD-ROM into the CD-ROM drive.

Specify the location where USB Printing Support is located, and then click [Next >].

If the CD-ROM drive is D, the source files of USB Printing Support are stored in the following location:

D:\DRIVERS\RPCS\WIN9X_ME

Check the location, and then click [Next >].

USB Printing Support is installed.

Click [Finish].

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB001" port is added to the **[Printers]** window.

Click [Next >].

Click [Search for the best driver for your device. {Recommended}.], and then click [Next >].

E Select the [Specify a location:], check box, and then click [Browse...].

The [Browse for Folder] dialog box appears.

Insert the CD-ROM into the CD-ROM drive.

E Specify the location where the source files of the printer driver is stored, and then click [Next >].

If the CD-ROM drive is D, the source files of the printer driver are stored in the following location:

 PostScript 3 D:\DRIVERS\PS\WIN9X_ME\(Language)\DISK1

Check the location, and then click [Next >].

Add Printer Wizard starts.

Click [Finish].

Installation is complete. If installation is successful, the icon of the printer connected to the "USB001" port is added to the **[Printers]** window.

🖉 Note

□ When Auto Run starts, click [Exit].

- □ To disable Auto Run, press the **[Shift]** key when inserting the CD-ROM into the drive and keep it pressed until the computer finishes reading from the CD-ROM.
- □ The number after "USB" varies depending on the number of printers connected.
- It is not necessary to reinstall USB Printing Support when connecting a different machine via USB interface when USB Printing Support is installed.
- After installing USB Printing Support, if the printer driver is not installed, follow the plug-and-play instructions of the printer.
- □ Install the printer driver from the CD-ROM provided with the printer.


Windows 2000 - USB

∰Important

Installing a printer driver requires Administrators permission. Log on using an account that has Administrators permission.

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB" port is added to the **[Printers]** window.

If the printer driver is not installed, follow the plug-and-play instructions of the printer to install it from the CD-ROM provided.



2 Connect the machine to the computer using the USB cable.

Connect the USB cable firmly.

B Turn on the power of the machine.

Found New Hardware Wizard starts, and USB Printing Support is installed automatically.

Click [Next >] in the [Found New Hardware Wizard] dialog box.

Select the [Search for a suitable driver for my device (recommended)] check box, and then click [Next >].

6 Select the [Specify location] check box, and then click [Next >].

2 Insert the CD-ROM into the CD-ROM drive.


Specify the location where the source files of the printer driver is stored.

If the CD-ROM drive is D, the source files of the printer driver are stored in the following location:

 PostScript 3 D:\DRIVERS\PS\WIN2K_XP\(Language)\DISK1

Check the printer driver location, and then click [OK].

Click [Next >].



If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB001" port is added to the **[Printers]** window.

🖉 Note

- When Auto Run starts, click [Exit].
- □ To disable Auto Run, press the left **[Shift]** key when inserting the CD-ROM into the drive and keep it pressed until the computer finishes reading from the CD-ROM.
- □ The number after "USB" varies depending on the number of printers connected.

Windows XP, Windows Server 2003 - USB

∰Important

Installing a printer driver requires Administrators permission. Log on using an account that has Administrators permission.

If the printer driver has already been installed, plug and play is enabled, and the icon of the printer connected to the "USB" port is added to the **[Printers]** window.

The printer drivers can be installed from the CD-ROM provided with this machine.

If the printer driver is not installed, follow the plug-and-play instructions of the printer to install it from the CD-ROM provided.

1 Turn off the power of the machine.

2 Connect the machine to the computer using the USB cable.

Connect the USB cable firmly.

3 Turn on the power of the machine.

Found New Hardware Wizard starts, and USB Printing Support is installed automatically.

In the Found New Hardware Wizard display, select [No, not this time], and then click [Next>].

Select [Install from a list or specific location [Advanced]], and then click [Next>].

6 To disable Auto Run, press the left [Shift] key when inserting the CD-ROM into the drive and keep it pressed until the computer finishes reading from the CD-ROM.

Select the [Include this location in the search] check box under [Search for the best driver in these location], and then click [Browse] to select the printer driver location.

If the CD-ROM drive is D, the source files of the printer driver are stored in the following location:

 PostScript 3 D:\DRIVERS\PS\WIN2K_XP\(Language)\DISK1

$_{32}$ **B** Check the printer driver location, and then click [Next >].

Click [Continue].

Click [Finish].

If installation is successful, the icon of the printer connected to the "USB001" port is added to the **[Printers]** window.

🖉 Note

- □ If Auto Run starts, click [Cancel], and then [Exit].
- □ The number after "USB" varies depending on the number of printers connected.

Troubleshooting for using USB

Problems	Solutions
The machine is not automatically rec- ognized.	Turn off the power of the machine, reconnect the USB cable, and then turn it on again.
Windows has already configured the USB settings.	Open Windows' Device Manager, and then, under [Universal Serial Bus controllers], remove any conflicting devices. Conflicting devices have a yellow [!] or [?] icon by them. Take care not to accidentally remove required devices. For details, see Windows Help.

Printing with Parallel Connection

To use a machine connected using a parallel interface, click **[LPT1]** when installing the printer driver.

Installing the PostScript 3 Printer Driver (Windows 95 / 98 / Me)

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

- **5** Click [Next >].
- Click [Local printer], and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

Select the name of the machine whose printer driver you want to install, and then click [Next >].

In the [Available ports:] box, click [Printer Port], and then click [Next >].

Change the printer name if you want, and then click [Next >].

Select the **[Yes]** check box to configure the printer as default.

 ${f U}$ Specify whether or not to print a test page, and then click [Finish].

W Restart the computer to complete installation.

🔗 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 printer driver (Windows 2000)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

U Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

E Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

Click [Next >].

Click [Local printer], and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

Select [LPT1] at the [Printer Port] dialog box, and then click [Next >].

B Select whether or not to share the printer, and then click [Next >].

Select the name of the machine whose driver you want to install, and then click [Next >].

U Select whether or not you want to print a test page, and then click [Finish]. The printer driver installation starts.

W Restart the computer to complete installation if necessary.

🖉 Note

A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.

Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows XP, Windows Server 2003)

∰Important

Installing this printer driver requires Administrators permission. Log on using an account that has Administrators permission.

1 Quit all applications currently running.

2 Insert the CD-ROM into the CD-ROM drive.

The installer starts.

3 Select an interface language, and then click [OK].

The default interface language is English.

The printer driver with the selected language will be installed. The English printer driver is installed when the following language is selected: Cestina, Magyar, Polski, Portugues, Suomi.

Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

5 Click [Next >].

Click [Local printer attached to this computer], and then click [Next >].

Select the port you want to use, and then click [Next >].

A dialog box for selecting the printer manufacturer and model name appears.

- Select the name of the machine whose driver you want to install, and then click [Next >].
- Click [Close] to close the [Printer Port] dialog box.

Click [Next >].

- Change the printer name if you want, and then click [Next >].
- B Specify whether or not to print a test page, and then click [Finish].

The printer driver installation starts.

E Restart the computer to complete installation.

🖉 Note

- □ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.
- □ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Installing the PostScript 3 Printer Driver (Windows NT 4.0)

∰Important

	Installing this printer driver requires Administrators permission. Log on us- ing an account that has Administrators permission.		
	If your operating system is Windows NT4.0, download printer driver for Windows NT4.0 from the supplier's Web site.		
1	1 Double-click on "SETUP.EXE" in the downloaded folder.		
	Add Printer Wizard starts.		
2	2 Select [My Computer], and then click [Next >].		
3	Select the port you want to use, and then click [Next >].		
	A dialog box for selecting the printer manufacturer and model name appears.		
4	Select the name of the machine whose driver you want to install, and then click [Next >].		
5	5 Change the printer name if you want, and then click [Next >].		
	Select the [Yes] check box to configure the printer as default.		
6	6 Specify whether or not to share the printer, and then click [Next >].		
7	\mathbf{Z} Specify whether or not to print a test page, and then click [Finish].		
	The printer driver installation starts.		
B Restart the computer to complete installation if necessary.			
	Solution Note		
	□ A user code can be set after the printer driver installation. For information about user code, see the printer driver Help.		

□ Auto Run may not work with certain operating system settings. In that case, launch "Setup.exe" on the CD-ROM root directory.

Printing with Bluetooth Connection

Supported Profiles

SPP, HCRP

- A maximum of two Bluetooth adaptor or Bluetooth-equipped computers can be connected at the same time using the Bluetooth interface: one by SPP, one by HCRP.
- When connecting more than one Bluetooth adaptor or Bluetooth-equipped computer at the same time, the first device that establishes connection is selected. When selecting the connection between the other devices, cancel the first established connection.
- Conditions for bidirectional communications
 - SPP connection does not support bidirectional communications.
 - HCRP connection supports bidirectional communications.

✤ BIP

- For BIP connection, a module including PostScript 3 must be installed in the machine.
- Only one Bluetooth adaptor or Bluetooth-equipped computer can be connected via BIP.
- Only JPEG images that can be printed using BIP.
- User codes are disabled for BIP. You cannot print if print functions are restricted.
- Some printers do not support BIP.

Printing with Bluetooth Connection

To install the printer driver, follow the procedure used to install parallel interface.

∰Important

□ To install the printer driver under Windows 2000 / XP Professional or Windows Server 2003, you must have an account that has Manage Printers permission. Log on as an Administrator or Power Users group member.

🖉 Note

- System requirements vary depending on the Bluetooth standard and specifications. For details, see the manuals provided with each product.
- For information about setting up Bluetooth under other operating systems or using it with different utilities, see the manuals provided with those operating systems or utilities.

- **1** Start 3Com Bluetooth Connection Manager.
- **2** Check that the printer you want to use appears in 3Com Bluetooth Connection Manager.
- On the [Tool] menu, click [COM port].

Check that the message "Bluetooth Serial Client (COMx) " appears under Client Ports. (X indicates the COM port number used by Bluetooth.)

5 Click [Close].

- **6** On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.
- **U** Click the icon of the printer you want to use.
- On the [File] menu, click [Properties].
- Click the [Ports] tab.
- Under [Port], select the [COMx:] check box. X indicates the COM port number used by Bluetooth.

Click [OK].

Close the [Printers] window.

If a dialog box appears while transmitting a print job, reestablish network connection as follows:

Select the printer you want to use in the [Printers and Fax] box.

2 Click [Connect].

🖉 Note

□ To always use the same printer, select the [Always use for this connection] check box.

For details, see the manuals provided with the Bluetooth adaptor or computer equipped with Bluetooth.

Configuring Security Mode Settings

1 Start 3Com Bluetooth Connection Manager.

On the [Tools] menu, click [Security Mode].

The [Security Mode] dialog box appears.

E Select the security mode in the [Security Mode:] list.

If you click **[High]**, or **[Custom]**, and specify **[Link]** in the **[Custom Settings]** dialog box, enter the Bluetooth password. For information about entering the password, see p.40 "Printing in the Security Mode"

For all other security modes and custom settings, no password is required.

For information about each mode, see the manuals provided with the utility.

Click [OK].

Close the [Security Mode] dialog box.

Reference

For details about the security mode, see 3Com Bluetooth Connection Manager Help. For details about the password entry which is required to transmit print jobs, see p.40 "Printing in the Security Mode".

Printing in the Security Mode

Send the print job to the printer in use.

Depending on the computer configuration, the **[Connect]** dialog box may appear. If it does, use it to establish the network connection.

2 The [Authentication] dialog box appears.

Enter the Bluetooth password, and then click [OK].

As the Bluetooth password, enter the last four digits of the machine's serial number. You can find the serial number on the label on the back of the machine. For example, if the serial number is 00A0-001234, the Bluetooth password is 1234.

The print job is sent.

🖉 Note

□ The Bluetooth password differs for each machine and cannot be changed.

If a Message Appears during Installation

Message number 58 or 34 indicates the printer driver cannot be installed using Auto Run. Install the printer driver using **[Add Printer]** or **[Install Printer]**.

For Windows 95 / 98 / Me, Windows 2000 and Windows NT 4.0:

1 On the [Start] menu, point to [Settings], and then click [Printers].

2 Double-click the Add Printer icon.

3 Follow the instructions in Add Printer Wizard.

- 🔗 Note
- If the printer driver is on a CD-ROM, the location of the PostScript 3 printer driver is either D:\DRIVERS\PS\WIN9X_ME\(Language)\DISK1 or D:\DRIVERS\PS\WIN2K_XP\(Language)\DISK1. If the installer starts, click [Cancel] to quit.

For Windows XP Professional and Windows Server 2003:

On the [Start] menu, click [Printers and Faxes].

2 Click [Add a printer].

3 Follow the instructions in Add Printer Wizard.

🖉 Note

□ If the printer driver is on a CD-ROM, the location of the PostScript 3 printer driver is D:\DRIVERS\PS\WIN2K_XP\(Language)\DISK1. If the installer starts, click **[Cancel]** to quit.

For Windows XP Home Editions:

On the [Start] menu, click [Control Panel].

Click [Printers and Other Hardware].

- **E** Click [Printers and Faxes].
- Click [Add a printer].

5 Follow the instructions in Add Printer Wizard.

🖉 Note

□ If the printer driver is on a CD-ROM, the location of the PostScript 3 printer driver is D:\DRIVERS\PS\WIN2K_XP\(Language)\DISK1. If the installer starts, click **[Cancel]** to quit.

Making Option Settings for the Printer

Make option settings for the machine using the printer driver when bidirectional communication is disabled.

Set up option settings when bidirectional communications are disabled.

∰Important

- Under Windows 2000 / XP and Windows Server 2003, Manage Printers permission is required to change the printer properties in the [Printers] folder. Log on as an Administrators or Power Users group member.
- □ Under Windows NT 4.0, Full Control permission is required to change the printer properties in the **[Printers]** folder. Log on as an Administrators or Power Users group member.

Open the [Printers] or [Printer and Faxes] window from the [Start] menu.

2 Click the icon of the printer you want to use.

On the [File] menu, click [Properties].

Click the [Accessories] tab.

Under Windows 2000 / XP, Windows Server 2003 and Windows NT 4.0, click the **[Device Settings]** tab.

Select options installed from the [Options] area, and then make the necessary settings.

Under Windows 2000 / XP, Windows Server 2003 and Windows NT 4.0, click the **[Installable Options]** area.

6 Click [Apply], and then click [OK] to close the printer properties dialog box.

For details about making option settings for the printer, see p.63 "Setting Up Options".

Setting Up the Printer Driver

Windows 95 / 98 / Me - Accessing the Printer Properties

There are two methods to open the printer properties dialog box.

Making printer default settings

To make the printer default settings, open the printer properties dialog box from the **[Printers]** window.

∰Important

You cannot change the printer default settings for each user. Settings made in the printer properties dialog box are applied to all users.

On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

2 Click the icon of the printer you want to use.

U On the [File] menu, click [Properties].

The printer properties dialog box appears.

Make the necessary settings, and then click [OK].

Click [OK].

🖉 Note

With some applications, the printer driver settings are not used, and the application's own default settings are applied.

For details, see the printer driver Help.

Making printer settings from an application

You can make printer settings for a specific application.

To make printer settings for a specific application, open the printer properties dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 95/98/Me.

On the [File] menu, click [Print].

The [Print] dialog box appears.

2 Select the printer you want to use in the [Name] list, and then click [Properties].

The printer properties dialog box appears.

E Make the necessary settings, and then click [OK].

4 Click [OK] to start printing.

🖉 Note

- The procedure to open the printer properties dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- □ With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- □ Any settings you make in the following procedure are valid for the current application only.
- □ General users can change the properties displayed in the **[Print]** dialog box of an application. Settings made here are used as defaults when printing from this application.

Reference

For details, see the printer driver Help.

Windows 2000 - Accessing the Printer Properties

Making printer default settings - the printer properties

∰Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- □ You cannot change the printer default settings for each user. Settings made in the printer properties dialog box are applied to all users.

On the [Start] menu, point to [Settings], and then click [Printers].

The **[Printers]** window appears.

2 Click the icon of the printer you want to use.

3 On the [File] menu, click [Properties].

The printer properties dialog box appears.

A Make the necessary settings, and then click [OK].

🖉 Note

- □ Settings you make here are used as the default settings for all applications.
- Do not make a setting for **[Form to Tray Assignment]**.

For details, see the printer driver Help.

Making printer default settings - Printing Preferences

∰Important

You cannot change the printer default settings for each user. Settings made in the printer properties dialog box are applied to all users.

On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears.

2 Click the icon of the printer you want to use.

On the [File] menu, click [Printing Preferences...].

The [Printing Preferences] dialog box appears.

Make the necessary settings, and then click [OK].

🖉 Note

□ Settings you make here are used as the default settings for all applications.

Reference

For details, see the printer driver Help.

Making printer settings from an application

You can make printer settings for a specific application.

To make printer settings for a specific application, open the **[Printing Preferences]** dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows 2000.

On the [File] menu, click [Print...].

The [Print] dialog box appears.

Select the printer you want to use in the [Select Printer] list.

3 Make the necessary settings, and then click [Print] to start printing.

🖉 Note

- □ The procedure to open the **[Printing Preferences]** dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- □ General users can change the properties displayed in the **[Print]** dialog box of an application. Settings made here are used as defaults when printing from this application.

Reference

For details, see the printer driver Help.

Windows XP, Windows Server 2003 - Accessing the Printer Properties

Making printer default settings - the printer properties

∰Important

- To change the printer default settings including option configuration settings, log on using an account that has Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default.
- You cannot change the printer default settings for each user. Settings made in the printer properties dialog box are applied to all users.

1 On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

2 Click the icon of the printer you want to use.

On the [File] menu, click [Properties].

The printer properties dialog box appears.

A Make the necessary settings, and then click [OK].

🖉 Note

- □ Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].

PReference

For details, see the printer driver Help.

Making printer default settings - Printing Preferences

Important

You cannot change the printer default settings for each user. Settings made in the printer properties dialog box are applied to all users.

On the [Start] menu, click [Printers and Faxes].

The [Printers and Faxes] window appears.

2 Click the icon of the printer you want to use.

1 On the [File] menu, click [Printing Preferences...].

The [Printing Preferences] dialog box appears.

Make the necessary settings, and then click [OK].

🖉 Note

□ Settings you make here are used as the default settings for all applications.

PReference

For details, see the printer driver Help.

Making printer settings from an application

You can make printer settings for a specific application.

To make printer settings for a specific application, open the **[Printing Preferences]** dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows XP.

On the [File] menu, click [Print...].

The [Print] dialog box appears.

Select the printer you want to use in the [Select Printer] list.

Click [Preferences].

A Make the necessary settings, and then click [Print] to start printing.

🖉 Note

- □ The procedure to open the **[Printing Preferences]** dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- Any settings you make in the following procedure are valid for the current application only.
- □ General users can change the properties displayed in the **[Print]** dialog box of an application. Settings made here are used as defaults when printing from this application.

℅ Reference

For details, see the printer driver Help.

Windows NT 4.0 - Accessing the Printer Properties

Making printer default settings - the printer properties

∰Important

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- □ You cannot change the printer default settings for each user. Settings made in the printer properties dialog box are applied to all users.

U On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

2 Click the icon of the printer you want to use.

On the [File] menu, click [Properties].

The printer properties dialog box appears.

A Make the necessary settings, and then click [OK].

🖉 Note

- □ Settings you make here are used as the default settings for all applications.
- Do not make a setting for [Form to Tray Assignment].

For details, see the printer driver Help.

Making printer default settings - Default

∰Important

- To change the printer default settings including option configuration settings, log on using an account that has Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default.
- You cannot change the printer default settings for each user. Settings made in the printer properties dialog box are applied to all users.

U On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

2 Click the icon of the printer you want to use.

On the [File] menu, click [Document Defaults...].

The [Default] dialog box appears.

Make the necessary settings, and then click [OK].

🖉 Note

□ Settings you make here are used as the default settings for all applications.

PReference

For details, see the printer driver Help.

Making printer settings from an application

You can make printer settings for a specific application.

To make printer settings for a specific application, open the printer properties dialog box from that application. The following explains how to make settings for the WordPad application provided with Windows NT 4.0.

On the [File] menu, click [Print].

The [Print] dialog box appears.

2 Select the printer you want to use in the [Name] list, and then click [Properties].

The printer properties dialog box appears.

U Make the necessary settings, and then click [OK].

4 Click [OK] to start printing.

🖉 Note

- The procedure to open the printer properties dialog box may vary depending on the application. For details, see the manuals provided with the application you use.
- □ With some applications, the printer driver settings are not used, and the application's own default settings are applied.
- Any settings you make in the following procedure are valid for the current application only.
- □ General users can change the properties displayed in the **[Print]** dialog box of an application. Settings made here are used as defaults when printing from this application.

Reference

For details, see the printer driver Help.

2. Mac OS Configuration

Mac OS

This section explains how to configure a Mac OS to use EtherTalk and USB.

The following explains how to configure Mac OS 9.1. If you are not using Mac OS 9.1, see the manual of the Mac OS you are using for details

∰Important

- □ For Mac OS 8.6 and higher. (Mac OS X Classic environment is supported.)
- □ USB printing requires Mac OS 9.2.2 or later.

🖉 Note

□ The PostScript 3 printer driver is stored in the following folder on the CD-ROM.

Mac OS 8 and 9: PS Driver:(language):Disk1

Installing the PostScript 3 Printer Driver and PPD File

It is necessary to install a printer driver and PostScript Printer Description (PPD) files to print from a Mac OS.

Follow the procedure below to install a printer driver and a PPD file into a Mac OS using Mac OS 8.6 and higher.

PostScript 3 Printer Driver

1 Insert the CD-ROM into the CD-ROM drive.

2 Double-click the CD-ROM drive icon.

Double-click the [Mac OS 8 and 9] folder.

Double-click the [PS Driver] folder.

5 Double-click the folder of the language you use.

6 Open [Disk1], and then double-click the installer icon.

7 Follow the instructions on the screen.

PPD Files

- **1** Double-click the CD-ROM drive icon.
- **2** Double-click the [Mac OS 8 and 9] folder.
- Double-click the [Printer Descriptions] folder.
- **Double-click the folder of the language you are using.**
- **5** Open the [Disk1] folder.
- Drag the PPD file and the plugin file into [Printer Descriptions] in [Extensions] under [System Folder].
- **2** Restart the Mac OS.

Setting Up PPD Files

Important

- Make sure that the printers are connected to an AppleTalk network before performing the following procedure.
- On the [Apple] menu, click [Chooser].

2 Click the Adobe PS icon.

In the [Select a PostScript Printer:] list, click the name of the printer you want to use.

4 Click [Create].

5 Click the printer you want to use, and then click [Setup].

A PPD file is set up and the Adobe PS icon appears at the left of the printer name in the list. Follow the procedure on p.52 "Setting Up Options" to make option settings; otherwise close the **[Chooser]** dialog box.

Setting Up Options

On the [Apple] menu, click [Chooser].

2 Click the Adobe PS icon.

In the [Select a PostScript Printer:] list, click the name of the printer you want to use, and then click [Setup].

4 Click [Configure].

A list of options appears.

5 Select the option you want to set up, and then select an appropriate setting for it.

Click [OK].

The list of options closes.

Click [OK].

The [Chooser] dialog box appears.

Close the [Chooser] dialog box.

🖉 Note

If the option you want to select is not displayed, PPD files may not be set up correctly. To complete the setup, check the name of the PPD file displayed in the dialog box.

Installing Adobe Type Manager

∰Important

- Quit all applications currently running before installation. Install ATM after you restart the computer.
- **1** Start a Mac OS.
- **2** Insert the CD-ROM into the CD-ROM drive.
- **3** Double-click the CD-ROM drive icon.
- Double-click the [Mac OS 8 and 9] folder.
- **5** Double-click the [ATM] folder.
- **Double-click the ATM 4.6.2 installer icon.**
- **2** Follow the instructions on the screen.
- **B** When the procedure is complete, restart the computer. ATM will be completely installed only after restarting.
- On the [Apple] menu, open [Control Panel], and then click [~ATM].
- The ATM control panel opens.

🔗 Note

For details about installation, see the operating instructions in the ATM folder.

Installing Screen fonts

Follow the procedure below to install screen fonts.

The screen fonts described below can be found in the **[Fonts]** folder on the CD-ROM.

1 Start a Mac OS.

- **2 Insert the CD-ROM into the CD-ROM drive.** The CD-ROM drive icon appears.
- **3** Double-click the CD-ROM drive icon.
 - The contents of the CD-ROM appear.
- Double-click the [Mac OS 8 and 9] folder.
- **5** Double-click the [Fonts] folder.
- Double-click the [Screen font] folder.
- **Double-click the [TrueType] or [Type1] folder.** Select the font type you want to use.
- Copy the fonts you want to install in [System Folder].
 - A confirmation message appears.
- Click [OK].
 - The fonts are installed.
- Restart the Mac OS.

Using USB Interface

∰Important

USB printing requires Mac OS 9.2.2 or later.

Follow the procedure below to setup USB connection.

Open the [AdobePS Component] folder on the hard disk.

- **2** Double-click [Desktop Printer Utility].
- Click [AdobePS] in [With:], click [Printer (USB)] in [Create Desktop], and then click [OK].
- Click [Change] in [PostScriptTM Printer Description (PPD) File].
- **5** Select the PPD files of the connected printer, and then click [Select].
- Click [Change] in [USB Printer Selection].

Select the model you are using in [Select a USB Printer:], and then click [OK].

8 Click [Create].

The following message appears.

9 Click [Save].

 ${f U}$ Specify the file location and the name, and then click [Save].

The printer icon appears on the desktop.

U Quit Desktop Printer Utility.

🖉 Note

- □ Mac OS supports only the standard USB ports for this printer.
- When printing with a USB connection to a Macintosh computer, printer language does not change automatically. Use the control panel on this printer to change printer language to [Auto Detect] or [PS] before printing.

Changing to EtherTalk

Follow the procedure below to configure to a Mac OS to use EtherTalk.

U Open [Control Panel], and then double-click the AppleTalk icon.

2 On the [Connect via:] pop-up menu, click [Ethernet].

If you change zones, select a name on the [Current zone:] pop-up menu.

Close the AppleTalk control panel.

5 Restart the computer.

🔗 Note

The procedures used to configure Mac OS may vary depending on the Mac OS version. The following describes how to configure Mac OS 9.1. If you are using a different version of Mac OS, use the following procedures as a reference and see the manuals for your Mac OS version.

□ Confirm the Connection to the Printer with TCP/IP

Reference

For information about installing applications required for EtherTalk, see the Mac OS manuals.

Mac OS X

This section explains how to configure a Mac OS X to use EtherTalk, USB and TCP/IP.

Follow the procedure below to configure Mac OS X 10.3.8. If you are not using Mac OS X 10.3.8, see the manual of the Mac OS X you are using for details.

∰Important

- **\square** For Mac OS X 10.1 or higher.
- □ USB printing requires Mac OS X 10.3.3 or later.

🖉 Note

□ The PPD files are stored in the following folder on the CD-ROM.

```
Mac OS X: PPD Installer
```

Installing the PPD Files

Follow the procedure below to install a PPD file to print from Mac OS X.

∰Important

- You need an administrator name and a password (phrase). For details, consult your network administrator.
- **1** Insert the CD-ROM into the CD-ROM drive.
- **2** Double-click the CD-ROM drive icon.
- Double-click the [Mac OS X] folder.
- Double-click the [MacOSX PPD Installer] folder.
- **5** Double-click the installer icon.
- **6** Follow the instructions on the screen.

Setting Up the PPD File

1 Start Printer Setup Utility.

Click [Add].

Mac OS X 10.4 or later

Click a printer that has "AppleTalk" indicated in the "Connection" column.

If the zone is set, click **[More Printers...]**, and then select the zone from the second pop-up menu.

Other Mac OS X

Click **[AppleTalk]** on the first pop-up menu. If the zone is set, select the zone from the second pop-up menu.

Select the printer, and then select its manufacturer from the [Printer Model:] pop-up menu.

Under Mac OS X 10.4 or later, you are using from the **[Print Using]** popup menu.

A list of printer types appears.

Select the PPD file for the model you are using, and then click [Add].

5 Quit Printer Setup Utility.

Setting Up Options

1 Start System Preferences.

2 Click [Print & Fax].

In the [Printer] list, click the name of the printer you want to use, and then click [Printer Setup...].

Select the option you want to set up, and then select an appropriate setting for it.

Click [Apply Changes].

🖉 Note

If the option you want to select is not displayed, PPD files may not be set up correctly. To complete the setup, check the name of the PPD file displayed in the dialog box.

Using USB Interface

∰Important

USB printing requires Mac OS X 10.3.3 or later.Follow the procedure below to set up USB connection.

U Start Printer Setup Utility.

2 Click [Add].

Mac OS X 10.4 or later

Click a printer that has "USB" indicated in the "Connection" column.

Other Mac OS X

Click **[USB]** on the pop-up menu. The connected printer appears.

Select the printer, and then select its manufacturer from the [Printer Model:] pop-up menu.

Under Mac OS X 10.4 or later, you are using from the **[Print Using]** pop-up menu.

A list of printer types appears.

Select the connected printer from the list of printer models, and then click [Add].

5 Quit Printer Setup Utility.

🖉 Note

- When printing with a USB connection to a Macintosh computer, printer language does not change automatically. Use the control panel on this printer to change printer language to [Auto Detect] or [PS] before printing.
- □ USB2.0 can be used only with Mac OS X 10.3.3 or higher.

Using Bonjour (Rendezvous)

Follow the procedure below to print using Bonjour (Rendezvous) under Mac OS X 10.2.3 or higher. Ethernet, wireless LAN and IEEE 1394 (IP over 1394) connections can also be used.

1 Start Printer Setup Utility.

2 Click [Add].

Mac OS X 10.4 or later

Click a printer that has "Bonjour" indicated in the "Connection" column. If the zone is set, click **[More Printers...]**, and then select the zone from the second pop-up menu.

Other Mac OS X

Click **[Rendezvous]** on the pop-up menu. If the zone is set, select the zone from the second pop-up menu.

Select the name of the connected printer from the list of printer models, and then click [Add].

Under Mac OS X 10.4 or later, Installable Options window appears. Select the option you want to set up, and then select an appropriate setting for it, and then **[Continue]**.

4 Quit Printer Setup Utility.

🖉 Note

When printing with a Rendezvous connection to a Macintosh computer, printer language does not change automatically. Use the control panel on this printer to change printer language to [Auto Detect] or [PS] before printing.

Changing to EtherTalk

Follow the procedure below to configure a Mac OS X to use EtherTalk.

∰Important

- You need an administrator name and a password (phrase). For details, consult your network administrator
- Open [System Preference], and then click the Network icon.
- **2** Click [Built-in Ethernet] in the [Show:] list box.
- Click the [AppleTalk] tab.
- Select the [Make AppleTalk Active] check box.
- To change AppleTalk zones, select a name from the [AppleTalk Zone:] pop-up menu.

b When the settings are made, click [Apply Now].

Reference

For information about installing applications required for EtherTalk, see the Mac OS manuals.

Configuring the Printer

Use the control panel to enable AppleTalk. (The default is active.)

2

3. Using PostScript 3

Setting Up Options

To use installed options correctly, first set up the printer driver. If the options are not recognized, you cannot use them, even though they are physically installed. The procedure to set up a printer driver varies depending on the operating system.

✤ Windows

∰Important

- If your system is Windows 2000, Windows XP Professional, or Windows Server 2003, changing printer driver settings requires Manage Printers permission. Members of Administrators and Power Users groups have Manage Printers permission by default. When you change printer driver settings, log on with an account that has Manage Printers permission.
- If your system is Windows NT 4.0, changing printer driver settings requires Full Control access permission. Members of Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default. When you change printer driver settings, log on with an account that has Full Control permission.
- If you are using Adobe Page Maker 6.0, 6.5, or 7.0 with Windows 95 / 98 / Me / 2000 / XP, Windows Server 2003, or Windows NT 4.0, you have to set up options in the Adobe PageMaker's print dialog box.

Windows 95 / 98 / Me	[Options] on the [Accessories] tab.
Windows 2000 / XP, Windows Server 2003	[Installable Options] on the [Device Settings] tab.
Windows NT 4.0	[Installable Options] on the [Device Settings] tab in the Properties dialog box.
Mac OS	For ethernet, [Chooser] on the Apple Menu. For USB, [Change Setup] from the [Printing] menu to open the Desktop printer.
Mac OS X	[Printer Setup] in [Print & Fax] to open the System Preferences.

You can set up any of the options using the following tabs:

🖉 Note

□ To set up options, access the printer driver from Windows. You cannot set up options if you access the printer driver from an application.

✤ Mac OS

∰Important

 \Box If you are using Mac OS X, this function cannot be used. You can set up all options using the **[Chooser]** dialog box.

Reference

See p.42 "Making Option Settings for the Printer", p.52 "Setting Up Options" or p.57 "Setting Up Options" for the installation method appropriate to your printing environment.

Printing a Document

This documentation describes the specific printer functions and menus that are added by installing the PPD file. For more information about the functions and menus of the Windows 95 / 98 / Me PostScript printer driver, see the printer driver's Help.

∰Important

□ On a Macintosh, Mac OS 8.6 or higher (Mac OS X Classic environment is supported.), or Mac OS X 10.1 or higher is required.

🖉 Note

- □ If you are using Mac OS X 10.2.x or higher, the Job Type function can be used.
- □ "Mac OS X" in the tables below refers to Mac OS X 10.2.3. Depending on the version, **[Features x]** is displayed as **[Set x]** (x is a number). Make adjustments according to the version you use.

Job Type

Use this to select the type of print job.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Job Type:] on the [Setup] tab.	
----------------------	---------------------------------	--

You can select the following items:

✤ [Normal Print]

Select this for normal printing. The print job starts immediately after the print command is given.

🖉 Note

Under Windows 95 / 98 / Me, if you want to use an User ID, click the [Details...] button.

User Code

Use this to set a user code for print logging.

Enter a user code using up to eight digits. A user code identifies a group of users and allows you to check the number of sheets printed under each code with SmartDeviceMonitor for Admin.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[User Code] on the [Statistics] tab.
Windows 2000 / XP, Windows Serv- er 2003	[User ID:] on the [Job Log] tab in the Printing Preferences dialog box.
Windows NT 4.0	[User ID:] on the [Job Log] tab in the Document Defaults dialog box.
Mac OS	Select the [Enable User Code] check box, and then enter a user code in the [User Code] box on [Job Log] in the print dialog box.
Mac OS X	Select the [Enable User Code] check box, and then enter a user code in the [User Code] box on [Job Log] in the print dialog box.

Reference

For details about using SmartDeviceMonitor for Admin, see Help.

Paper Selection

Use this to select the media type and input tray.

∰Important

□ This function is for Windows 95 / 98 / Me only.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me[Paper Selection] on the [Paper] tab.

Reference

For details about the Paper Selection. See the printer driver's Help.

Paper Size

Use this to select the size of paper you want to use.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Size:] on the [Paper] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Paper Size:] on [Paper/Output] on [Advanced] on the [Pa- per/Quality] tab in the Printing Preference dialog box.
Windows NT 4.0	[Paper Size:] on the [Page Setup] tab in the Document Defaults dialog box.
Mac OS	[Paper:] on the [Page Attributes] tab in the Page Setup dialog box.
Mac OS X	[Paper Size:] in the Page Setup dialog box.

Reference

For details about the paper sizes supported by this machine, see General Settings Guide.

Fit to Paper

When the size of the document and paper size differ, set whether or not to print according to paper size.

Windows 95 / 98 / Me	[Fit to Print Size:] on the [Paper] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Fit to Paper] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Fit to Paper] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Fit to Paper] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Fit to Paper] on the [Features x] tab on [Printer Features] in the print dialog box.

[Prompt User]

Print is performed with the size of document to be printed unchanged.

[Nearest Size and Scale]

The printer selects the paper size that is closest to the size specified by the file. If the paper size is smaller than the selected paper size, the driver reduces the print size.

If the paper size is larger than the size of document to be printed, print is not to fit the paper size.

[Nearest Size and Crop]

The printer selects the paper size that is closest to the size specified by the file, but the print image is not reduced or enlarged to fit the selected paper size.

Input Slot

Use this to select the paper sources.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Input Tray:] on the [Paper] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Paper Source] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Paper Source] on the [Page Setup] tab in the Document Defaults dialog box.
Mac OS	[Paper Source:] on [General] in the print dialog box.
Mac OS X	[Paper Feed] in the print dialog box.

₽ Reference

For details about the paper sources, see Printer Reference.

Resolution

Use this to set the resolution types.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Resolution] on the [Print Quality] tab.
----------------------	--

₽ Reference

For more information about the resolution types, see Printer Reference.

Orientation Override

Use this to set the paper orientation.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Orientation Override] on the [Setup] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Orientation Override] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Orientation Override] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Orientation Override] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Orientation Override] on the [Features x] tab on [Printer Fea- tures] in the print dialog box.

You can select the following items:

- [Off]
- [Landscape]
- [Portrait]
- 🖉 Note
- □ Under Windows 95/98/Me, select the [Orientation Override] check box, and then select [Landscape] or [Portrait] in the [Orientation:] list.

Print Mode

Use this function to reduce the amount of toner used when printing.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Toner Saving] on the [Print Quality] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Print Mode] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] tab in the Printing Pref- erences dialog box.
Windows NT 4.0	[Print Mode] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Print Mode] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Print Mode] on the [Features x] tab on [Printer Features] in the print dialog box.

For details about this function, see Printer Reference.

Duplex Printing

Use this function to select duplex printing.

Important

□ To use this function, the optional duplex unit must be installed on the machine.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Duplex:] on the [Setup] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Print on Both Sides] on the [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Print on Both Sides (Duplex Printing)] on the [Page Setup] tab in the Document Defaults dialog box.
Mac OS	[Print on Both Sides] on [Layout] in the print dialog box.
Mac OS X	 10.3 or higher The [Two Sided] check box on [Layout] in the print dialog box. Other Mac OS X The [Print on both Sides] check box on [Duplex] in the print dialog box.

The following items may vary depending on the operating system you are using.

Windows 95 / 98 / Me

* [Off]

Disables Duplex Printing.

✤ [Open to Left]

Prints output so that you can open it to the left.

✤ [Open to Top]

Prints output so that you can open it to the top.

Windows 2000 / XP, Windows Server 2003, Mac OS

✤ [None]

Disables Duplex Printing.

✤ [Flip on Short Edge]

Prints output so that you can open it to the short edge when bound along the short edge.

[Flip on Long Edge]

Prints output so that you can open it to the long edge when bound along the long edge.

🖉 Note

□ If you are using a Mac OS, click to select the button that means "Flip on Long Edge" or "Flip on Short Edge".

Windows NT 4.0

✤ [None]

Disables Duplex Printing.

✤ [Long Side]

Prints output so that you can open it to the long edge when bound along the long edge.

✤ [Short Side]

Prints output so that you can open it to the short edge when bound along the short edge.

Mac OS X

The following functions are selectable under Mac OS X 10.3 or higher (for Mac OS X 10.2 or earlier, see p.70 "Windows 2000 / XP, Windows Server 2003, Mac OS"):

* [Off]

Disables Duplex Printing.

[Long-edged binding]

Prints output so that you can open it to the long edge when bound along the long edge.

[Short-edged binding]

Prints output so that you can open it to the short edge when bound along the short edge.

Collate

Use this function to enable collation. With this feature, the machine can efficiently print collated sets of multiple-page documents.

∰Important

□ If you are using Windows 2000, Windows XP, Mac OS or Mac OS X, make sure that the following check boxes have not been selected.

- Windows 2000, Windows XP The [Collate] check box on [Copy Count:] on [Paper/Output] on [Advanced...] on the [Paper/ Quality] tab in the Printing Preferences dialog box.
- Mac OS The **[Collate]** check box in the print dialog box.
- Mac OS X The [Collated] check box on [Copies & Pages] in the printer dialog box.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Collate:]on the [Setup] tab.
Windows 2000, Windows XP	[Collate:] on [Printer Features] on [Document Options] on [Ad- vanced] on the [Paper/Quality] tab in the Printing Prefer- ences dialog box.
Windows NT 4.0	[Collate:] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Collate:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Collate:] on the [Features X] tab on [Printer Features] in the printer dialog box.

Paper Type

Use this to select the paper type.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Type:] on the [Paper] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Media:] on the [Paper/Quality] tab in the Printing Preference dialog box.
Windows NT 4.0	[Paper/Output] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Paper Type] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Paper Type] on the [Features x] tab on [Printer Features] in the print dialog box.

For details about the media type supported by this machine, see General Settings Guide.

Destination

Use this to select the destination tray.

The following table shows where you can select this function.

Windows 95 / 98 / Me	[Output Tray:] in the [Paper] tab.
Windows 2000 / XP, Windows Server 2003	[Destination] in [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Destination] in [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Destination] in [Printer Specific Options] in the print dialog box.
Mac OS X	[Destination] on the [Features x] tab in [Printer Features] in the print dialog box.

₽ Reference

For details about the destination tray supported by this machine, see General Settings Guide.

Staple

Use this function to staple sheets of printed paper together.

∰Important

When stapling, use the finisher option. See General Setting Guide or Printer Reference.

Windows 95 / 98 / Me	[Staple:] on the [Setup] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Staple:] in [Printer Features] on [Document Options] on [Ad- vanced] on the [Paper/ Quality] or [Layout] tab.
Windows NT 4.0	[Staple:] in [Printer Features] on [Document Options] on the [Advanced] tab.
Mac OS	[Staple:] in [Printer Specific Options] in the print dialog box.
Mac OS X	[Staple:] on the [Features x] tab in [Printer Features] in the print dialog box.

The following table shows where you can select this function.

🖉 Note

□ The stapling location might differ depending on the orientation of the machine set in the printer and the orientation of the data to be printed. For details, see Printer Reference.

Watermark

Set the Watermark function.

Windows 2000 / XP, Windows Serv- er 2003	[Watermark:] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Watermark:] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.

🖉 Note

When using this function under Windows 95 / 98 / Me, Mac OS, or Mac OS X, see the printer driver Help. The following explains the procedure for Windows 2000 / XP, Windows Server 2003, and Windows NT 4.0.

Watermark Text

Select the Watermark Text type.

Windows 2000 / XP, Windows Serv- er 2003	[Watermark Text] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Watermark Text] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.

🖉 Note

When using this function under Windows 95 / 98 / Me, Mac OS, or Mac OS X, see the printer driver Help. The following explains the procedure for Windows 2000 / XP, Windows Server 2003, and Windows NT 4.0.

Watermark Font

Select the Watermark Font type.

Windows 2000 / XP, Windows Serv- er 2003	[Watermark Font] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Watermark Font] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.

🖉 Note

When using this function under Windows 95 / 98 / Me, Mac OS, or Mac OS X, see the printer driver Help. The following explains the procedure for Windows 2000 / XP, Windows Server 2003, and Windows NT 4.0.

Watermark Size

Select the Watermark size.

Windows 2000 / XP, Windows Serv- er 2003	[Watermark Size] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Watermark Size] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.

🖉 Note

When using this function under Windows 95 / 98 / Me, Mac OS, or Mac OS X, see the printer driver Help. The following explains the procedure for Windows 2000 / XP, Windows Server 2003, and Windows NT 4.0.

Watermark Angle

Select the Watermark angle.

∰Important

□ This item is only for portrait, not for landscape.

Windows 2000 / XP, Windows Serv- er 2003	[Watermark Angle] on [Printer Features] on [Document Op- tions] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Watermark Angle] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.

🖉 Note

When using this function under Windows 95 / 98 / Me, Mac OS, or Mac OS X, see the printer driver Help. The following explains the procedure for Windows 2000 / XP, Windows Server 2003, and Windows NT 4.0.

Watermark Style

Select the Watermark style.

Windows 2000 / XP, Windows Serv- er 2003	[Watermark Style] on [Printer Features] on [Document Op- tions] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Watermark Style] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.

🖉 Note

When using this function under Windows 95 / 98 / Me, Mac OS, or Mac OS X, see the printer driver Help. The following explains the procedure for Windows 2000 / XP, Windows Server 2003, and Windows NT 4.0.

Dithering

Use this to set the Image Rendering mode.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Dithering:] on the [Print Quality] tab.
Windows 2000 / XP, Windows Server 2003	[Dithering:] on [Printer Features] on [Document Options] on [Advanced] on the [Paper/Quality] or [Layout] tab in the Printing Preferences dialog box.
Windows NT 4.0	[Dithering:] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Dithering:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Dithering:] on the [Features x] tab on [Printer Features] in the print dialog box.

You can select the following items:

✤ [Auto]

Use this setting to configure the best dithering method automatically depending on the appearance of the document to be printed.

✤ [Photographic]

Performs dithering using an appropriate pattern for photographs.

✤ [Text]

Performs dithering using an appropriate pattern for text.

✤ [User Setting]

Use this setting to print images set in half tone in your application.

Image Smoothing

Use this to select the image smoothing type.

The following table shows the tabs or menus where you can select this function.

Windows 95 / 98 / Me	[Image Smoothing:] on the [Print Quality] tab.
Windows 2000 / XP, Windows Serv- er 2003	[Image Smoothing:] on [Printer Features] on [Document Op- tions] on [Advanced] on the [Paper/Quality] or [Layout]tab in the Printing Preferences dialog box.
Windows NT 4.0	[Image Smoothing:] on [Printer Features] on [Document Options] on the [Advanced] tab in the Document Defaults dialog box.
Mac OS	[Image Smoothing:] on [Printer Specific Options] in the print dialog box.
Mac OS X	[Image Smoothing:] on the [Features x] tab on [Printer Fea- tures] in the print dialog box.

✤ [Off]

Disables image smoothing.

∻ [On]

Performs image smoothing unconditionally.

[Auto]

Performs image smoothing automatically for images that have a resolution less than 25% of supported printer resolution.

✤ [Less than 90 ppi] - [Less than 300 ppi]

Performs image smoothing only when the image has an image resolution (pixels per inch) less than the respective value you have selected in the list.

🖉 Note

- □ When **[Auto]** is selected, data processing may take a long time.
- □ When **[Image Smoothing:]** is used for a mask image, this function may have an undesired effect on the print result.

4. Printer Utility for Mac

By using Printer Utility for Mac, you can download fonts, change the name of the printer and so on.

Installing Printer Utility for Mac

Follow these steps to install Printer Utility for Mac on the machine.

Important

□ If a Macintosh and printer are connected by USB, you cannot use Printer Utility for Mac.

1 Start the Mac OS.

2 Insert the CD-ROM into the CD-ROM drive.

The CD-ROM icon appears.

3 Double-click the CD-ROM icon.

The contents of the CD-ROM appear.

Double-click the [Mac OS] folder.

Under Mac OS X, double-click the [Mac OS X] folder.

Double-click the [PS Utility] folder on the CD-ROM, and then drag the [Printer Utility for Mac] file, and then drop it into the Macintosh hard disk.

b Drag the CD-ROM icon and drop it into [**Trash**] to eject the CD-ROM.

Printer Utility for Mac is installed.

🔗 Note

- Printer Utility for Mac is included on the CD-ROM labeled "Printer Drivers and Utilities".
- Printer Utility for Mac requires Mac OS 8.1 or higher. (Mac OS X Classic environment is supported.)
- **D** Printer Utility for Mac cannot use Mac OS X (native mode).

Starting Printer Utility for Mac

The following instructions describe how to start Printer Utility for Mac.

Mac OS

∰Important

Before starting Printer Utility for Mac, make sure the printer is selected in [Chooser] on the Apple menu.

Double-click the Printer Utility for Mac icon. The [Printer Utility for Mac] dialog box appears.

2 Click **[OK]**.

Printer Utility for Mac will take a few seconds to start.

Mac OS X

1 Double-click the Printer Utility for Mac icon.

The [Printer Utility for Mac] dialog box appears.

Click [OK].

In the [Available Printers:] box, select the printer you want to use.

If you change zones, select a name from [Available Network Zones:].

Click **[Choose Printer...]** on the Printer Utility for Mac menu if you want to change the printer.

Select the printer you want to use.

Printer Utility for Mac will take a few seconds to start.

5 Click [Choose].

Printer Utility for Mac Functions

Printer Utility for Mac functions are described below.

File menu

- **[Download PS Fonts...]** Download fonts (PostScript Type 1) to the printer. See p.82 "Downloading PS Fonts".
- **[Display Printer's Fonts...]** Display and delete the fonts in printer memory. See p.83 "Displaying Printer's Fonts".
- [Initialize Printer's Disk...] This function cannot be used.
- **[Page Setup...]** Set up the paper size to print "Printer Font Catalog" and "Printer Font Sample". See p.83 "Page Setup".
- [Print Fonts Catalog...] Print the names of available fonts. See p.84 "Printing Fonts Catalog".
- [Print Fonts Sample...] Print a sample of fonts. See p.84 "Printing Fonts Sample".
- [Rename Printer...] Change the printer's name when viewed via Appletalk. See p.84 "Renaming the Printer".
- **[Restart Printer]** Restart the printer. See p.85 "Restarting the Printer".

✤ Utility menu

- [Download PostScript File...] Download a PostScript file. See p.85 "Downloading PostScript Files"Post-
 - Script.
- [Select Zone...] Change the zone to which the printer belongs to via Appletalk. See p.86 "Selecting the Zone".
- **[Display Printer Status...]** Display the status of the printer. See p.87 "Displaying the Printer Status".
- [Launch Dialogue Console...] Create and edit a PostScript file, and then download it to the printer. See p.87 "Launching the Dialogue Console".

Downloading PS Fonts

You can download the PS fonts to the printer's memory.

Important

- The following procedures to download the fonts assume that you are a system administrator. If you are not, be sure to consult your system administrator.
- □ If the printer restarts, all the printer settings return to their defaults.
- **□** Confirm that a Mac OS and the printer are connected with Appletalk.
- During the download, do not turn off the power switch, operate the panel or open or close the cover.

Select [Download PS Fonts...] on the [File] menu.

2 Click [Add to list].

The dialog box to select fonts appears.

Click to select the desired font files, and then click [Open].

The list of selectable font names appears.

After adding all the fonts you want to download, click [OK]. Under Mac OS X, click [choose].

The dialog box of selected fonts to download appears.

5 Click [Download].

The fonts begin to download, and the download status is shown.

6 When the completion message appears, click [OK].

2 Click [Cancel].

🖉 Note

- □ Some fonts cannot be downloaded.
- Before downloading, read the documentation about the fonts you want to use.

Displaying Printer's Fonts

You can display the available fonts currently downloaded to the printer. Fonts in the printer's memory can be displayed.

Select [Display Printer's Fonts...] on the [File] menu.

A dialog box appears.

2 Select [Printer's memory].

Click [OK].

🖉 Note

□ The fonts displayed in italics are the default fonts.

Deleting Fonts

You can delete fonts from the printer's memory.

∰Important

□ You cannot delete the fonts displayed in italic.

Select [Display Printer's fonts] on the [File] menu.

A dialog box appears.

- Select [Printer's memory].
- Select the fonts you want to delete.
- 4 Click [Delete].

A confirmation message appears.

- **5** Confirm the fonts you want to delete and the printer name from which you want to delete the fonts.
- **6** Click [Continue], and then click [OK].

7 Click [**0**K].

Page Setup

You can set the paper size on which to print "Print Fonts Catalogue" and "Prints Fonts Sample".

Select [Page Setup...] on the [File] menu.

2 Choose the paper size.

4

Printing Fonts Catalog

Print the names of fonts available on the printer.

Select [Print Fonts Catalogue] on the [File] menu.

2 Click [Print].

- 🖉 Note
- □ The paper selected under [Page Setup] is used.

Printing Fonts Sample

You can print samples of fonts downloaded to the memory.

Select [Print Fonts Sample...] on the [File] menu.

2 Click [Print].

🔗 Note

□ Print by using the paper selected on [Page Setup].

Renaming the Printer

You can change the printer name displayed under Appletalk. If you connect several printers on the network, assign different names so you can identify them. If several printers have the same name, a digit appears next to the printer name in **[Chooser]**.

∰Important

□ You can enter up to 31 digits and letters.

□ Do not use symbols, for example "*", ":", "=", "@", "~".

Mac OS

On the [File] menu, click [Rename Printer...].

2 In the [New Name:] filed enter a new name.

Click [Rename].

The printer name is changed.

- Click [OK].
- **5** On the Apple menu, click [Chooser].
- **6** Click the [AdobePS] icon.

Select the printer whose name you changed, and then close the [Chooser] dialog box.

If there are several Appletalk zones, select the zone the machine belongs to.

Mac OS X

On the [File] menu, click [Rename Printer...].

2 In the [New name:] filed enter a new name.

Click [Rename].

The printer name is changed.

Click [OK].

5 On the [Printer Utility for Mac] menu, click [Choose Printer...].

1 In the [Available Network Zones:] list, select the zone for the Macintosh in use.

In the [Available Printers:] list, select the printer whose name you changed, and then click [Choose].

Restarting the Printer

You can restart the printer.

Select [Restart Printer] on the [File] menu.

2 Confirm the message that appears on the screen, and then click [Restart]. The printer restarts.

The fonts that you downloaded in the printer's memory will be deleted.

If the printer restarts, all the printer settings return to their defaults.

Downloading PostScript Files

You can download a Postscript file to the printer.

Select [Download PostScript File...] on the [Utility] menu.

2 Select the file name to download and click the file name, and then click [Open].

U Type the log file name, and then click [Save...].

The selected file is downloaded.

Errors are recorded in the log file.

Selecting the Zone

You can change the zone to which the printer belongs under Appletalk.

∰Important

Confirm that a Macintosh and printer are connected with Appletalk.

Mac OS

On the [Utility] menu, click [Select Zone...].

The zone to which the printer belongs and the available zone list appear.

22 Select the zone in which you want to locate the printer, and then click [Change].

A confirmation message appears.

Click [Continue].

A confirmation message appears.

Click [OK].

5 On the Apple menu, click [Chooser].

6 Click the [AdobePS] icon.

1 In the [Appletalk zone:] list, select the zone you changed.

In the [Select a PostScript Printer:] list, select the printer you want to use.

Close the [Chooser] dialog box.

Mac OS X

On the [Utility] menu, click [Select Zone...].

The zone to which the printer belongs and the available zone list appear.

2 Select the zone which you want to locate the printer in, and then click [Change].

A confirmation message appears.

Click [Continue].

A confirmation message appears.

Click [OK].

On the [Printer Utility for Mac] menu, click [Choose Printer...].

1 In the [Available Network Zones:] list, select the zone you changed.

In the [Available Printers:] list, select the model of printer in use, and then click [Choose].

Displaying the Printer Status

You can display and confirm the current status of the printer.

Select [Display Printer Status...] on the [Utility] menu.

The current status of the printer appears.

2 Confirm the current status of the printer.

You can confirm the memory capacity. You can also confirm the zone to which the printer belongs to.

Click [OK].

Launching the Dialogue Console

You can create and edit a PostScript file for printing, and then download it to the printer.

∰Important

- "Launch Dialogue Console" is recommended for users with an understanding of PostScript.
- Do not download any file other than PostScript files to the printer.
- □ "Launch Dialogue Console" must be used at your own responsibility.

Select [Launch Dialogue Console...] on the [Utility] menu.

Open the editing screen. The Dialogue Console menu bar appears.

2 Type the PostScript command in the editor screen.

To edit a PostScript file, select [Open] on the [File] menu to open it.

You can search or replace a character string by using the [Search] menu.

After editing the PostScript file, select [Download Top Window] on [Console] menu to start printing.

The PostScript file is sent to the printer.

The **[Reply from Printer]** or the **[Printer Says...]** box opens, depending on the Post-Script file you sent.

Select [Return To Main Menu] on the [Console] menu to close the PostScript file.

INDEX

В

Bluetooth, 38

С

Changing to EtherTalk, 55, 60 Collate, 72

D

Deleting Fonts, 83 Destination, 73 Displaying Printer's Fonts, 83 Displaying the Printer Status, 87 Dithering, 76 document defaults, PostScript 3, 48 Downloading PostScript Files, 85 Downloading PS Fonts, 82 Duplex Printing, 70

F

Fit to Paper, 67

Η

How to Read This Manual, 1

I

Image Smoothing, 77 Input Slot, 68 Input Tray, 68 Installing Adobe Type Manager, 53 Installing Printer Utility for Mac, 79 Installing Print Services for UNIX, 22 Installing Screen fonts, 54 Installing the PostScript 3 Printer Driver and PPD File, 51 Installing the PPD Files, 56 Installing the Printer Driver Using USB, 29

J

Job Type, 65

L

Launching the Dialogue Console, 87

Μ

Mac OS, 51, 52, 53, 54 Mac OS X, 56, 57, 58, 59

0

Orientation Override, 69

Ρ

Page Setup, 83 Paper Selection, 66 Paper Size, 67 Paper Source, 68 Paper Type, 72 printer properties, PostScript 3, 43, 44, 46, 48 Printer Utility for Mac, 84, 86 Printer Utility for Mac Functions, 81 Printing a Document, 65 Printing Fonts Catalog, 84 Printing Fonts Sample, 84 Printing with Bluetooth Connection, 38 Printing with Parallel Connection, 34 Print Mode, 69

R

Renaming the Printer, 84 Resolution, 68 Restarting the Printer, 85

S

Selecting the Zone, 86 Setting Up Options, 52, 57, 63 Setting Up PPD Files, 52 Setting Up the PPD File, 57 Standard TCP/IP Port, 17 Staple, 73 U

User Code, 66 User ID, 66 Using Bonjour, 59 Using USB Interface, 58

W

Watermark, 74 Watermark Angle, 75 Watermark Font, 74 Watermark Size, 75 Watermark Style, 75 Watermark Text, 74 Windows 2000, 34, 44 Windows 95/98/Me, 43 Windows NT 4.0, 48 Windows Server 2003, 46 Windows XP, 46





EN USA AE AE



Trademarks

Microsoft[®], Windows[®] and Windows $NT^{\mathbb{R}}$ are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe[®] and PostScript[®] are registered trademarks of Adobe Systems Incorporated.

Apple, AppleTalk, EtherTalk, Macintosh, Mac OS and TrueType are trademarks of Apple Computer, Inc, registered in the U.S. and other countries.

Bonjour[™] is a trademark of Apple Computer, Inc.

The Bluetooth[®] word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Ricoh Company, Ltd. is under license.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

The proper names of the Windows operating systems are as follows:

- The product name of Windows[®] 95 is Microsoft[®] Windows 95.
- The product name of Windows[®] 98 is Microsoft[®] Windows 98.
- The product name of Windows[®] Me is Microsoft[®] Windows Millennium Edition (Windows Me).
- The product names of Windows 2000 are as follows: Microsoft[®] Windows[®] 2000 Professional Microsoft[®] Windows[®] 2000 Server Microsoft[®] Windows[®] 2000 Advanced Server
- The product names of Windows XP are as follows: Microsoft[®] Windows[®] XP Professional Microsoft[®] Windows[®] XP Home Edition Microsoft[®] Windows[®] XP Media Center Edition Microsoft[®] Windows[®] XP Tablet PC Edition
- The product names of Windows Server 2003 are as follows: Microsoft[®] Windows Server[®] 2003 Standard Edition Microsoft[®] Windows Server[®] 2003 Enterprise Edition Microsoft[®] Windows Server[®] 2003 Web Edition Microsoft[®] Windows Server[®] 2003 Datacenter Edition
- The product names of Windows NT 4.0 are as follows: Microsoft[®] Windows NT[®] Workstation 4.0 Microsoft[®] Windows NT[®] Server 4.0





