

# Notes for Users


This supplement provides notes and corrections for the manuals provided with this machine.

## ⚠ CAUTION




- Some of the internal components of this machine might be fragile. When you remove jammed paper, do not touch the sensors shown in this manual. Doing so may cause malfunctions.

### Main Unit




DGQ001




DGQ002

### LCIT PB3230




DGQ003

### Paper Feed Unit PB3220



DGQ004

### Paper Feed Unit PB3150



DGQ005

 : Sensors

## ◆ Fax

Facsimile Features > Send Settings > Backup File TX Setting

### Additional information

- When the specified destination is updated using the central address book management function, the spooled documents are sent to the destination after updating.

## ◆ Scan

1. Sending Scanned Documents to a Client Computer > Specifying the Destination or Recipient > Selecting the Destination from the Machine's Address Book > Searching the machine's address book for the destination and selecting it > Basic Procedure When Using Scan to Folder > Sending Files to a Shared Network Folder > Entering the Path to the Destination Manually > Simultaneous Storage and Sending by Scan to Folder

### Additional information

#### ↓ Note

- When the specified destination is updated using the central address book management function, the spooled documents are sent to the destination after updating.
- For details about central address book management, see "Administrator Tools", Connecting the Machine/ System Settings.

## ◆ Maintenance and Specifications

Specifications > Specifications for Scanner

### Correction

Topic	Error	Corrections
Scan speed (the machine equipped with the ARDF):Black and white	<u>70</u> pages/minute	80 pages/minute, 79 pages/minute
Scan speed (the machine equipped with the ARDF):Full Color	<u>70</u> pages/minute	80 pages/minute, 79 pages/minute

## ◆ Connecting the Machine/ System Settings

System Settings > Timer Settings

### Correction

Topic	Error	Corrections
Sleep Mode Timer	The time can be set from 1 to 240 minutes, using the number keys.	The time can be set from 1 to 60 minutes, using the number keys.

© 2014

Printed in Thailand

EN **US** EN **AU**

D202-7058A



D2027058A