

Controller Option (D556/...)

Controller Option (D556/...)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.


1.Controller Option 1 (D556/..)	2
2.Controller Option 2 (D556/..)	4
Parts Index	8

February 21, 2011

1.Controller Option 1 (D556/..)

IPDS Unit Type C2551 (D556-12/13/14)

USB2.0/SD Slot Type G (D566-16)




1.Controller Option 1 (D556/..)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D556 5012	SD-Card:IPDS:Di-C1.5:EXP:Ass'y	1
2	D422 1264	Lens:SD/USB	1
3	D422 1265	Shielding Plate:LED	1
4	D422 1267	Bracket:PCB:Ass'y	1
5	D422 1275	Case:SD/USB:EXP:Ass'y	1
6	D422 1277	Panel:USB:EXP	1
7	D422 1278	Cover:Guard:SD:EXP	1
8	D422 5112	Decal:Sd/Usb:EXP	1
9	D422 1280	Bracket:SD/USB:Main:EXP	1
10	D422 1281	Panel:SD:EXP	1
11	D422 1284	Bracket:Cover:Left	1
12	D422 5000	Cable:USB:700	1
13	D422 5020	Discharge Brush:12F:P025:Front	1
14	D422 5701	PCB:Fusion:Ass'y	1
15	D422 5052	Spring Plate:Base	1
16	D422 5030	Gasket:65TSV:Front	1
17	D422 5025	Shield Tape:CU10S:Front	1
18	D556 5016	SD-Card:PDF:Di-C1.5:EXP:Ass'y	1
19	D422 5108	Decal:SD-Card:Operate:EXP	1
19	D422 5110	Decal:SD-Card:Operate:Exp2	1


Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060N	Bind Screw - M3x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0454 3006Q	Tapping Screw - M3x6	
104	0456 3008N	Tapping Screw - M3x8	
105	0450 3010N	Tapping Screw - M3x10	

2.Controller Option 2 (D556/..)


IEEE 1284 Interface Board Type A (B679-17)




IEEE 802.11a/g Interface Unit Type J (D377-01/-02)




Gigabit Ethernet Type B (D377-21)




Browser Unit Type E (D430-05/-06/-07)




Camera Direct Print Card Type I (D546-21)




File Format Converter Type E (D377-04)



Bluetooth Interface Unit Type 3245 (B826-17)



IEEE 802.11g Interface Unit Type K (D377-19)



2.Controller Option 2 (D556/..)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B595 5670	PCB Assy - IEEE1284	1
2	G178 6033	PCB:Gigaethernet:PCIE	1
3	B129 5008	Cap - LAN Connector	1
4	GA00 3229	Decal:Pictbridge	1
5	D546 5021	SD-Card:P-Bridge:Apatc2.5:EXP:Ass'y	1
6	B582 5300	Card Cover	1
7	B826 5400	Card - Bluetooth CF	1
8	B826 5402	Card Adapter:Bluetooth	1
9	B582 5900	PCB:Wireless-Adapter	1
10	D377 5521	PCB:W-lan1s:Ext:NA:Ass'y	1
10	D377 5522	PCB:W-lan1s:Ext:EU:Ass'y	1
11	B234 1574	Keytop:Kino_menu:NA	1
11	B234 1580	Keytop:Kino_menu:EU	1
12	B223 1533	Keytop:Function:NA	1
12	B223 1539	Keytop:Function:EU	1
13	B234 1573	Keytop:To_kino:NA	1
13	B234 1579	Keytop:To_kino:EU	1
14	D430 5005	SD-Card:Browser:08S:NA:Ass'y	1
15	D377 5603	PCB:MLB32	1
16	D377 5542	PCB:W-lan1s:G-EXT:EU:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1607 2060	Ferrite Core:RFC-5 BK	
102	0451 3006N	Tapping Screw - 3x6	
103	1105 0688	Clamp:KS-15	
104	1607 1461	Ferrite Core	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D556 5012	SD-Card:IPDS:Di-C1.5:EXP:Ass'y	3 - 1
D556 5016	SD-Card:PDF:Di-C1.5:EXP:Ass'y	3 - 18

Part No.	Description	Page and Index No.
B129 5008	Cap - LAN Connector	5 - 3
B223 1533	Keytop:Function:NA	5 - 12
B223 1539	Keytop:Function:EU	5 - 12
B234 1573	Keytop:To_kino:NA	5 - 13
B234 1574	Keytop:Kino_menu:NA	5 - 11
B234 1579	Keytop:To_kino:EU	5 - 13
B234 1580	Keytop:Kino_menu:EU	5 - 11
B582 5300	Card Cover	5 - 6
B582 5900	PCB:Wireless-Adapter	5 - 9
B595 5670	PCB Assy - IEEE1284	5 - 1
B826 5400	Card - Bluetooth CF	5 - 7
B826 5402	Card Adapter:Bluetooth	5 - 8
D377 5521	PCB:W-lan1s:Ext:NA:Ass'y	5 - 10
D377 5522	PCB:W-lan1s:Ext:EU:Ass'y	5 - 10
D377 5542	PCB:W-lan1s:G-EXT:EU:Ass'y	5 - 16
D377 5603	PCB:MLB32	5 - 15
D422 1264	Lens:SD/USB	3 - 2
D422 1265	Shielding Plate:LED	3 - 3
D422 1267	Bracket:PCB:Ass'y	3 - 4
D422 1275	Case:SD/USB:EXP:Ass'y	3 - 5
D422 1277	Panel:USB:EXP	3 - 6
D422 1278	Cover:Guard:SD:EXP	3 - 7
D422 1280	Bracket:SD/USB:Main:EXP	3 - 9
D422 1281	Panel:SD:EXP	3 - 10
D422 1284	Bracket:Cover:Left	3 - 11
D422 5000	Cable:USB:700	3 - 12
D422 5020	Discharge Brush:12F:P025:Front	3 - 13
D422 5025	Shield Tape:CU10S:Front	3 - 17
D422 5030	Gasket:65TSV:Front	3 - 16
D422 5052	Spring Plate:Base	3 - 15
D422 5108	Decal:SD-Card:Operate:EXP	3 - 19
D422 5110	Decal:SD-Card:Operate:Exp2	3 - 19
D422 5112	Decal:Sd/Usb:EXP	3 - 8
D422 5701	PCB:Fusion:Ass'y	3 - 14
D430 5005	SD-Card:Browser:08S:NA:Ass'y	5 - 14

Part No.	Description	Page and Index No.
D546 5021	SD-Card:P-Bridge:Apatc2.5:EXP:Ass'y	5 - 5
G178 6033	PCB:Gigaethernet:PCIE	5 - 2

Part No.	Description	Page and Index No.
0353 0060N	Bind Screw - M3x6	3 - 101
0450 3010N	Tapping Screw - M3x10	3 - 105
0451 3006N	Tapping Screw - 3x6	3 - 102
0451 3006N	Tapping Screw - 3x6	5 - 102
0454 3006Q	Tapping Screw - M3x6	3 - 103
0456 3008N	Tapping Screw - M3x8	3 - 104
1105 0688	Clamp:KS-15	5 - 103
1607 1461	Ferrite Core	5 - 104
1607 2060	Ferrite Core:RFC-5 BK	5 - 101