

PS/Browser/Netware/  
FAX Connection  
(D645)

## **PS/Browser/Netware/FAX Connection (D645)**

### **PARTS CATALOG**

This catalog gives the numbers and names of parts on this machine.


### **CONTENTS**

|                                                 |          |
|-------------------------------------------------|----------|
| 1.PS/Browser/FAX Connection/Netware (D645)..... | 2        |
| <b>Parts Index .....</b>                        | <b>5</b> |


**January 10, 2012**

## 1.PS/Browser/FAX Connection/Netware (D64519)


SD card for NetWare printing Type H  
(D645-23)




Postscript3 Unit Type C5502  
(D645-11/12/13)




IPDS Unit Type 5502  
(D645-07/08/09)




Browser Unit Type F (D645-24/25)



Fax Connection Unit Type B  
(D645-19/20/21)



Camera Direct Print Card Type J  
(D645-15)



**1.PS/Browser/FAX Connection/Netware (D64519)**

| Index No. | Part No.  | Description                         | Q'ty Per Assembly |
|-----------|-----------|-------------------------------------|-------------------|
| 1         | D645 5023 | SD-Card:Netware:APATC3:EXP:Ass'y    | 1                 |
| 2         | D645 5011 | SD-Card:PS3:EXP:Ass'y               | 1                 |
| 3         | D645 5007 | SD-Card:IPDS:EXP:Ass'y              | 1                 |
| 4         | D645 5017 | SD-Card:MFPBrowser:APATC3:EXP:Ass'y | 1                 |
| 5         | D645 5019 | SD-Card:Connection:EXP:Ass'y        | 1                 |
| 6         | D645 5015 | SD-Card:P-Bridge:EXP:Ass'y          | 1                 |

| Index No. | Part No. | Description | Q'ty Per Assembly |
|-----------|----------|-------------|-------------------|
|           |          |             |                   |

# Parts Index

## Parts Index

| Part No.  | Description                         | Page and Index No. |
|-----------|-------------------------------------|--------------------|
| D645 5007 | SD-Card:IPDS:EXP:Ass'y              | 3 - 3              |
| D645 5011 | SD-Card:PS3:EXP:Ass'y               | 3 - 2              |
| D645 5015 | SD-Card:P-Bridge:EXP:Ass'y          | 3 - 6              |
| D645 5017 | SD-Card:μFPBrowser:APATC3:EXP:Ass'y | 3 - 4              |
| D645 5019 | SD-Card:Connection:EXP:Ass'y        | 3 - 5              |
| D645 5023 | SD-Card:Netware:APATC3:EXP:Ass'y    | 3 - 1              |

| Part No. | Description | Page and Index No. |
|----------|-------------|--------------------|
|          |             |                    |