## **Quick Reference Copy Guide**

# ⇒Please put this guide above your machine <>

12. [Start] key

13. [#] key (Enter key)


or sending.


Press to start copying, printing, scanning,

15. Number keys

17. Indicators

16. Function keys






 Auto Document Feeder (Face up)




- **B** Make desired settings.
- 4 Enter the number of copies.
- Press the [Start] key.





Place the originals, and then press the [Start]

key. (Paper size is selected automatically.)




5. [Interrupt] key

[Energy Saver] key

Operation switch

Main power indicator





1. [User Tools/Counter] key

Press to clear the current settings.

2. Display panel

3. [Clear Modes] key





### **Simplified Display**

When you press the [Simplified Display] key, the screen changes to the simplified display. Letters and keys are displayed at a larger size, making operations easier. Certain keys do not appear on the simplified display.

#### **Advanced features**

#### Reduce/Enlarge

(2. Basic Copying)

- · Zoom: You can specify the reproduction ratio in increments of 1%.
- Magnification: You can specify the horizontal and vertical reproduction ratios, individually.

#### **Series Copies**

· Separately copies the front and back of a 2-sided original onto two sheets.

#### Booklet/Magazine

 Copies two or more originals in page order.

#### Edit/Stamp

- Image Repeat/Double Copies: The original image is copied repeatedly.
- Centering: Moves image to center
- Erase: Erases the center and/or all four sides of the original image.
- Stamps: Copies with the date, page numbers, etc.

#### Cover/Slip Sheet

- Front Cover / Front/Back Cover: Create cover sheets.
- Designate: Copies certain pages of the original onto designation sheets.