

For Users of This Product

Thank you for purchasing this product.

This product is equipped with a Wireless LAN function. The wireless LAN function is disabled as a factory default.

This document describes precautions about using the product's wireless LAN function. Be sure to read this document before using the product, and keep it safe for future reference.

Be sure to read this document before using the wireless LAN function.

The product uses the 2.4 GHz frequency range for communication. Communications using radio waves may be interrupted by noise or interference. If you want to use this product for external communication, please be aware that communication failures may occur.

★ Important

- It is prohibited by law to disassemble or modify this product. The company takes no responsibility for illegal modifications that are made to the wireless LAN module of this product.
- The company takes no responsibility for financial losses, such as damages incurred due to communication failures, arising from failures, malfunctions, or defects of the wireless LAN function, or arising from the operating environment, communication failures, power outages, or other external factors.
- No measures to prevent or block data tampering are available for devices that use radio waves for communication. The company takes no responsibility for security problems arising due to wireless LAN specifications or other conditions.

↓ Note

- The frequency range used by this product may also be used by other products (industrial, scientific, or medical devices) manufactured by other companies. The outdoor use of wireless devices may be restricted. Pay attention to where you use this function.
- To export this product, conform with the Foreign Exchange and Foreign Trade Act, the Export Administration Regulations, and other related laws and regulations, and conduct the necessary proceedings specified by them.
- This function's SSID is not configured as a factory default. If you want to use SSID, you must configure the SSID setting yourself.
- Some applications of this product use the wireless LAN function. Depending on the environment where you use the wireless LAN function, communication may be interrupted due to radio wave interference.
- Usable frequencies vary depending on the access point you use.
- The wireless LAN function is disabled as a factory default. To use the applications of this product that use the wireless LAN function, you need to enable the wireless LAN function.

☐ To service representatives (in the case of installation by service representatives only):

Give this document to the user when the installation of this product is complete.

© 2013

Printed in Japan

EN (US) EN (GB) EN (AU) D150-1462



D1501462