


# Notes for Users

## Additional Information

**Read This First** > 2. Safety Information for This Machine > Safety Labels of This Machine > Positions of WARNING and CAUTION labels > Finisher SR3230 or Booklet Finisher SR3240



DLU004

1 and 2.

During operation, rollers for transporting the paper revolve. Take care not to touch rollers during operation. Otherwise, an injury might occur.

3.

Keep your hands clear of the booklet finisher tray when pulling out or pushing in the finisher's staple unit, or removing paper jam. You might trap your fingers if you do not. Take care not to touch the booklet finisher tray during operation. Otherwise, an injury might occur.

4 and 5.

Be careful of the protruding parts of the front cover when replacing the cartridge in the saddle stitch unit or clearing a paper jam from the saddle stitch unit.


6.

Keep your hands clear of the booklet finisher tray when pulling out or pushing in the finisher's staple unit, or removing paper jam. You might trap your fingers if you do not.

# Remarques à l'attention des utilisateurs

## Informations supplémentaires

**Read This First** > 1. Consignes de sécurité pour cet appareil > Étiquettes de sécurité de cet appareil > Emplacements des étiquettes AVERTISSEMENT et ATTENTION > Finisher SR3230 ou Booklet Finisher SR3240



DLU004

1 et 2.

Pendant l'utilisation, les rouleaux de transport du papier tournent. Veillez à ne pas toucher les rouleaux pendant le fonctionnement. Sinon, vous risqueriez de vous blesser.

3.

Ne posez pas les mains sur le réceptacle du finisseur livret lorsque vous insérez ou extrayez l'unité d'agrafage du finisseur ou lorsque vous retirez du papier coincé. Dans le cas contraire, vous pourriez vous coincer les doigts. Prenez garde à ne pas toucher le réceptacle du finisseur livret lors de cette opération. Sinon, vous risqueriez de vous blesser.

4 et 5.

Veillez faire attention aux parties saillantes du capot avant lorsque vous remplacez la cartouche dans l'unité de piqûre à cheval ou lorsque vous retirez du papier coincé dans l'unité de piqûre à cheval.

6.

Ne posez pas les mains sur le réceptacle du finisseur livret lorsque vous insérez ou extrayez l'unité d'agrafage du finisseur ou lorsque vous retirez du papier coincé. Dans le cas contraire, vous pourriez vous coincer les doigts.

© 2016

Printed in China

EN (US) EN (AU) FR (FR)

D241-7076



D2417076