Notes for Users

The following notes supplement the information provided in the manuals.

Back Up/Restore Address Book

You can back up the machine's address book to external storage or restore the backup copy from the external storage.
Backup requires a removable SD card to be installed in this machine.
For details about installing and removing the SD card, contact your sales or service representative.

- Back Up
  You can back up the machine's address book to external storage.
- Restore
  You can restore the backup copy of the address book from external storage.
- Format
  You can format the external storage.
- Obtain Media Info
  The free space and occupied space of the external storage are displayed.

< Note >

- Restore data overwrites Address Book data stored on the machine, and clears the counter of each registered user of the machine.
- You can also back up and restore the machine's Address Book using Web Image Monitor or SmartDeviceMonitor for Admin. For details, see the Help files of Web Image Monitor or SmartDeviceMonitor for Admin.

D0157108