PCL 6/5c Printer Driver Installation Guide

This manual assumes that you are familiar with general Windows procedures and practices. If you are not, see the documentation that comes with Windows for details.

Important □ Before starting this installation, close all documents and applications. In a network environment, confirm that users who are logged on are disconnected. Be sure to do this when it will create the least interference with other users. □ After installing a printer driver, you must restart the computer. ☑ Note □ Available operating systems are as follows: Windows 2000/XP/Vista, Windows Server 2003/2003 R2/2008. □ If the "plug and play" function is started, click[Cancel] in the [Found New Hardware Wizard] dialog box, and then insert the CD-ROM. The [Found New Hardware Wizard] dialog box appears depending on the system version of the Windows

2000/XP/Vista, Windows Server 2003/2003 R2/2008.

Installing the PCL 6/5c Printer Driver

Auto Run starts the installer automatically when you load the CD-ROM in the CD-ROM drive.

Two kinds of PCL printer drivers, PCL 6 and PCL 5c, are provided with this machine. We recommend PCL 6 as your first choice.

TCP/IP requires the following:

- This machine must be connected to the network through the network interface cable.
- This machine must be turned on.
- The TCP/IP protocol must be configured.
- An IP address must be allocated to this machine and to the computer.

∰Important

- ☐ If your system is Windows 2000/XP/Vista, or Windows Server 2003/2003 R2/2008, installing a printer driver by Auto Run requires Administrators permission. When you install a printer driver by Auto Run, log on using an account that has Administrators permission.
- ☐ When updating the printer driver by installing the latest version, you should uninstall that of former version if any.

If you want to cancel Auto Run, hold down the [Shift] key (when your system is Windows 2000, hold down the left [Shift] key) while inserting the CD-ROM. Keep the [Shift] key held down until the computer has finished accessing the CD-ROM.

- 1 Close all applications that are running.
- **2** Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

B Select a language to change the interface language, and then click [OK].

The following languages are available: Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Nederlands (Dutch) Default interface language is English.

- **4** Select the PCL printer driver.
- The software license agreement appears in the [License Agreement] dialog box. After reading through all of the contents, click [laccept the agreement.] to agree with the License Agreement, and then click [Next].
- Select the printer driver you want to install when the [Select Program] dialog box appears.
- **7** Follow the instructions on the screen.

B	Note
	Auto Run might not automatically work with certain OS settings. In this case, launch "Setup.exe" located on the CD-ROM root directory.
	During installation in Windows 2000, the [Digital Signature Not Found] dialog box may appear. In this case, click [Yes] to continue the installation.
	During installation in Windows XP, Windows Server 2003/2003 R2, the [Hardware Installation] dialog box may appear. In this case, click [Continue Anyway] to continue the installation.
	During installation in Windows Vista, the [Windows Security] dialog box may appear. In this case, click [Install this driver software anyway] to continue the installation.

Setting up options

#Important

- ☐ If the machine is equipped with certain options, you should set up the options with the printer driver.
- ☐ In Windows 2000/XP/Vista, Windows Server 2003/2003 R2/2008, changing the printer settings requires Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default. When you set up options, log on using an account that has Manage Printers permission.

When setting up options, you should access the printer properties dialog box from Windows. You cannot set up options by accessing the printer properties dialog box from an application.

Click [Start] on the taskbar, point to [Settings], and then click [Printers].

The **[Printers]** window appears.

In Windows XP Professional, Windows Server 2003/2003 R2, access the [Printers and Faxes] window from [Start] on the taskbar.

In Windows XP Home Edition, access the [Printers and Faxes] window. Click [Start] on the taskbar, click [Control Panel], [Printers and Other Hardware] and then [Printers and Faxes].

In Windows Vista, Windows Server 2008, access the [Printers] window. Click [Start] on the taskbar, click [Control Panel], and then [Printers].

- **2** Click to select the icon of the printer you want to use.
- On the [File] menu, click [Properties].

The printer properties dialog box appear.

- 4 Click the [Accessories] tab.
- **5** Select options you have installed from the [Options] group.
- 6 Click [OK].

Trademarks

Microsoft®, Windows®, Windows Server®, and Windows Vista® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. PCL[®] is a registered trademark of Hewlett-Packard Company.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

The proper names of the Windows operating systems are as follows:

• The product name of Windows 2000 are as follows:

Microsoft® Windows® 2000 Professional

Microsoft® Windows® 2000 Server

Microsoft® Windows® 2000 Advanced Server

The product name of Windows XP are as follows:

Microsoft® Windows® XP Professional

Microsoft® Windows® XP Home Edition

Microsoft® Windows® XP Media Center Edition

Microsoft® Windows® XP Tablet PC Edition

The product names of Windows Vista are as follows:

Microsoft® Windows Vista® Ultimate

Microsoft® Windows Vista® Enterprise

Microsoft[®] Windows Vista[®] Business Microsoft[®] Windows Vista[®] Home Premium

Microsoft® Windows Vista® Home Basic

The product name of Windows Server 2003 are as follows:

Microsoft® Windows Server® 2003 Standard Edition

Microsoft® Windows Server® 2003 Enterprise Edition

The product name of Windows Server 2003 R2 are as follows:

Microsoft® Windows Server® 2003 R2 Standard Edition

Microsoft® Windows Server® 2003 R2 Enterprise Edition

The product names of Windows Server 2008 are as follows:

Microsoft® Windows Server® 2008 Standard

Microsoft[®] Windows Server[®] 2008 Enterprise

Symbols

This manual uses the following symbols:

瓣Important

Indicates points to pay attention to when using the machine, and explanations of likely causes of paper misfeeds, damage to originals, or loss of data. Be sure to read these explanations.

Note

Indicates supplementary explanations of the machine's functions, and instructions on resolving user errors.

Indicates the names of keys that appear on the machine's display panel.

Indicates the names of keys on the machine's control panel.

EN (GB) EN (US) D502-6770