

Notes for Users

This machine is compliant with the revisions to the International Energy Star Program effective July 2009. The following information covers recent changes made to the Energy Star Program. Please read this information.

Topic: "Safety Information"> *ENERGY STAR Program*> *Specifications*

❖ Changes to Specifications

Energy Saver mode	Power Consumption	8.5 W
	Default Time	15 minutes

- The above listed changes to specifications are based on the main unit with the Paper Cassette Type 240 installed.
- Power consumption can vary depending on the environment in which the machine is being used.
- Temperature fluctuation can cause condensation to build up inside the machine, which can lead to deterioration of copy images. To prevent this, the machine has an anti-condensation function. This function can only be enabled by a service representative. If you want this function enabled, inform your sales or service representative at the time of delivery/installation. When this function is enabled, the anti-condensation heater remains active even when the main power switch is turned to "Off". By keeping the machine slightly warm, the heater prevents condensation forming inside the main unit.

Copyright © 2009

Printed in Japan

EN^{US} G180-7581



G1807581