

RICOH

RICOH NC8015

PARTS CATALOG

First Edition January 1992

RICOH COMPANY, LTD.

FT8015 (A092)

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of these parts on this machine.

INDEX to PARTS CATALOG

LOCATION OF UNIT	3
1. EXTERIOR 1 (A092)	10
2. EXTERIOR 2 (A092)	12
3. OPERATION PANEL (A092)	14
4. PLATEN COVER AND CASSETTE (A092)	16
5. OPTICS SECTION 1 (A092)	18
6. OPTICS SECTION 2 (A092)	20
7. OPTICS SECTION 3 (A092)	22
8. OPTICS SECTION 4 (A092)	24
9. LASER UNIT 1 (A092)	26
10. LASER UNIT 2 (A092)	28
11. PAPER FEED AND REGISTRATION 1 (A092)	30
12. PAPER FEED AND REGISTRATION 2 (A092)	32
13. PAPER FEED AND REGISTRATION 3 (A092)	35
14. PAPER FEED AND REGISTRATION 4 (A092)	37
15. MAIN CORONA SECTION (A092)	40
16. DEVELOPMENT UNIT 1 (A092)	42


17. DEVELOPMENT UNIT 2 (A092)	44
18. TONER TANK SECTION (A092)	46
19. TRANSFER UNIT 1 (A092)	48
20. TRANSFER UNIT 2 (A092)	50
21. TRANSFER UNIT 3 (A092)	52
22. TRANSFER UNIT 4 (A092)	54
23. TRANSFER BELT CLEANING (A092)	56
24. TRANSFER / DEVELOPMENT DRIVE SECTION (A092)	58
25. FUSING SECTION 1 (A092)	60
26. FUSING SECTION 2 (A092)	62
27. FUSING SECTION 3 (A092)	64
28. FUSING SECTION 4 (A092)	66
29. DRUM CLEANING UNIT (A092)	68
30. TONER COLLECTION SECTION (A092)	70
31. DRIVE SECTION 1 (A092)	72
32. DRIVE SECTION 2 (A092)	74
33. DRIVE SECTION 3 (A092)	76

34. FRAME SECTION 1 (A092)	79
35. FRAME SECTION 2 (A092)	81
36. OZONE FILTER (A092)	83
37. ELECTRICAL SECTION 1 (A092)	85
38. ELECTRICAL SECTION 2 (A092)	87
39. ELECTRICAL SECTION 3 (A092)	89
40. ELECTRICAL SECTION 4 (A092)	91
41. HARNESS (A092)	93
42. SCANNER CONTROL BOARD (A092)	95
43. LD CONTROL BOARD (A092)	100
44. MAIN MOTOR CONTROL BOARD (A092)	107
45. SEQUENCE CONTROL BOARD (A092)	101
46. PROCESS CONTROL BOARD (A092)	114
47. IPU MEMORY BOARD (A092)	119
48. IPU BOARD 1 (A092)	125
49. IPU BOARD 1.5 (A092)	128
50. IPU BOARD 2 (A092)	131

51. SYSTEM CONTROL BOARD (A092)	134
52. MEMORY BOARD (A092)	137
53. LASER UNIT CONTROL BOARD - BK,Y (A092)	139
54. LASER UNIT CONTROL BOARD - M,C (A092)	145
55. AC HARNESS (A092)	151
56. FRONT DC HARNESS (A092)	153
57. REAR DC HARNESS (A092)	155
58. DECAL AND DOCUMENT (A092)	157
59. SPECIAL TOOL (A092)	163


Parts Index	165
--------------------------	------------

1. EXTERIOR 1 (A092)




See Page 10

2. EXTERIOR 2 (A092)




See Page 12

3. OPERATION PANEL (A092)




See Page 14

4. PLATEN COVER AND CASSETTE (A092)




See Page 16

5. OPTICS SECTION 1 (A092)




See Page 18

6. OPTICS SECTION 2 (A092)




See Page 20

7. OPTICS SECTION 3 (A092)




See Page 22

8. OPTICS SECTION 4 (A092)




See Page 24

9. LASER UNIT 1 (A092)




See Page 26

10. LASER UNIT 2 (A092)




See Page 28

11. PAPER FEED AND REGISTRATION 1 (A092)



See Page 30


12. PAPER FEED AND REGISTRATION 2 (A092)



See Page 32


LOCATION OF UNIT

13. PAPER FEED AND REGISTRATION 3 (A092)




See Page 34

14. PAPER FEED AND REGISTRATION 4 (A092)




See Page 36

15. MAIN CORONA SECTION (A092)




See Page 38

16. DEVELOPMENT UNIT 1 (A092)




See Page 40

17. DEVELOPMENT UNIT 2 (A092)




See Page 42

18. TONER TANK SECTION (A092)




See Page 44

19. TRANSFER UNIT 1 (A092)




See Page 46

20. TRANSFER UNIT 2 (A092)




See Page 48

21. TRANSFER UNIT 3 (A092)




See Page 50

22. TRANSFER UNIT 4 (A092)




See Page 52

23. TRANSFER BELT CLEANING (A092)




See Page 54

24. TRANSFER / DEVELOPMENT DRIVE SECTION (A092)




See Page 56

25. FUSING SECTION 1 (A092)




See Page 58

26. FUSING SECTION 2 (A092)




See Page 60

27. FUSING SECTION 3 (A092)




See Page 62

28. FUSING SECTION 4 (A092)




See Page 64

29. DRUM CLEANING UNIT (A092)




See Page 66

30. TONER COLLECTION SECTION (A092)




See Page 68

31. DRIVE SECTION 1 (A092)




See Page 70

32. DRIVE SECTION 2 (A092)




See Page 72

33. DRIVE SECTION 3 (A092)




See Page 74

34. FRAME SECTION 1 (A092)




See Page 76

35. FRAME SECTION 2 (A092)




See Page 78

36. OZONE FILTER (A092)




See Page 80

37. ELECTRICAL SECTION 1 (A092)




See Page 82

38. ELECTRICAL SECTION 2 (A092)




See Page 84

39. ELECTRICAL SECTION 3 (A092)




See Page 86

40. ELECTRICAL SECTION 4 (A092)




See Page 88

41. HARNESS (A092)



See Page 90


1. EXTERIOR 1 (A092)



Index No.	Part No.	Description	Qty per Assembly
1	A030 5802	Receiving Tray	1
2	A092 1586	Bracket Stay	1
3	AG04 0031	Operating Instructions Holder	1
4	A049 1323	Left Upper Cover	1
5	A049 1330	Dust Filter	1
6	A049 1327	Filter Bracket	1
7	A049 1365	Left Cover	1
8	A049 1369	Main Switch Cover	1
9	A049 1318	Top Left Cover	1
10	AA14 3213	Lever Support Pin	2
11	A049 1291	Stopper Chain - Left Door	1
12	A049 1355	Right Upper Cover	1
13	A049 1357	Spring Plate	2
14	A049 1356	Right Upper Small Cover	1
15	A049 1332	Rear Upper Cover	1
16	A049 1338	Connector Guide	1
17	A049 1290	Rear Left Cover	1
18	A049 1280	Rear Right Cover	1
19	A092 1399	Decal - Misfeed Removal - English	1
20	A092 1359	Upper Right Cover	1
21	A049 1361	Right Cover Cap	2
22	A092 1363	Lower Right Cover	1
23	A049 1351	Front Right Cover Bracket	1
24	A049 1350	Front Right Cover	1
25	A092 6609	Door Support Plate	1
26	A049 1268	Right Door Stopper	1
27	A049 1274	Left Door Shaft	4
28	A049 5644	Grounding Wire	2
29	A049 1299	Safety Switch Actuator	1
30	A092 1262	Right Door	1
31	A049 1298	Safety Switch Actuator - Right Door	1
32	A049 1270	Right Door Grip	1
33	A049 1266	Right Door Bracket	1
34	A012 1871	Front Scale Stopper	4
35	A049 1259	Lever Stopper - Transfer	1

Index No.	Part No.	Description	Q'ty per Assembly
36	A049 1297	Safety Switch Actuator - Left Door	1
37	A092 1253	Left Door Ass'y	1
38	A049 1260	Left Door Grip	1
39	A049 1256	Grip Bracket - Left Door	1
40	A092 1394	Decal - Main Switch	1
			
101	0354 0060F	Philips Pan Head Screw - M4x6	
102	0354 0060B	Screw - M4x6	
103	0414 0062B	Binding Self Tapping Screw - M4x6	
104	0315 0080B	Philips Pan Head Screw - M5x8	
105	0720 0030B	Retaining Ring - M3	

2. EXTERIOR 2 (A092)




2. EXTERIOR 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 3357	Development Unit Stand	1
2	AA03 6010	Small Cap - Toner Tank	1
3	A049 6810	Toner Collection Bottle Cover	1
4	AA15 1363	Cushion - 49x79x12	1
5	A049 6605	Left Bracket - Collection Bottole	1
6	5919 2201	Shoulder Screw - M4	2
7	A049 3356	Magnet Angle Adjuster Knob	1
8	A049 3355	Magnet Angle Adjuster Bracket	1
9	A049 6606	Left Door Hinge	2
10	A092 6784	Toner Collection Tank	1
11	5215 5304	Toner Overflow Sensor	1
12	AA03 6009	Joint Cap	1
13	A007 3751	Cap Large - Toner Collection Tank	1
14	5446 3475	Developer - Receptacle	1
15	AG07 0004	Magnet Catch Ass'y	5
16	A092 5853	Safety Switch Lever	1
17	A049 5856	Safety Switch Actuator	1
18	A049 3282	Latch	1
19	A049 5854	Right Bracket - Collection Bottle	1
20	A092 5852	Safety Switch Bracket	1
21	A049 6544	Stopper Pin Guide Plate	1
22	A049 6545	Mylar - Stopper Guide Plate	1
23	A049 5855	Switch Cover	1
24	A049 6608	SP Panel Cover	1
25	A049 5858	Laser Unit Control Board Bracket	2
26	A049 3281	Latch Bracket	1
27	A092 5440	SP Panel Board Ass'y	1
28	A049 6604	Right Door Hinge	2
29	A466 5121	Push Switch	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0324 0060B	Philips Sunken Head Screw - M4x6	
102	0354 0060B	Screw - M4x6	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0354 0080F	Screw - M4x8	
105	0803 0018	Knob Screw	
106	0414 0082B	Binding Self Tapping Screw - M4x8	
107	0720 0030B	Retaining Ring - M3	
108	1204 1373	Push Switch	
109	1105 0291	Wire Saddle	
			

3. OPERATION PANEL (A092)




3. OPERATION PANEL (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 1520	Operation Panel Ass'y	1
1	A092 1455	Operation Panel Cover	1
2	A092 1460	Key Top Cover - Mode Selection	1
3	A092 1461	Key Top Cover - Color Adjustment	1
4	A092 1462	Decal - Mode Selection Cover	1
5	A092 1463	Decal - Color Adjustment Cover	1
6	A092 1464	Decal - Mode Selection	1
7	A092 1465	Decal - Color Adjustment	1
8	A092 1466	LED Cover	2
9	A092 1467	Key Top - Start	1
10	A092 1468	Key Top - R/#	1
11	A092 1469	Key Top - Clear Mode	1
12	A092 1470	Key Top - Program	1
13	A092 1471	Key Top - Original Recognition	1
14	A092 1472	Key Top - Full Cover	1
15	A092 1473	Key Top - C/S	1
16	A092 1474	Key Top - 0	1
17	A092 1475	Key Top - 1	1
18	A092 1476	Key Top - 2	1
19	A092 1477	Key Top - 3	1
20	A092 1478	Key Top - 4	1
21	A092 1479	Key Top - 5	1
22	A092 1480	Key Top - 6	1
23	A092 1481	Key Top - 7	1
24	A092 1482	Key Top - 8	1
25	A092 1483	Key Top - 9	1
26	A092 1484	Key Top - Point	1
27	A092 1485	Key Top - Darker	1
28	A092 1486	Key Top - Lighter	1
29	A092 1487	Key Top - Letter/Photo	1
30	A092 1488	Key Top - Paper Selection	1
31	A092 1489	Key Top - Cassette Select	1
32	A092 1495	Key Top - Paper	1
33	A092 1496	Key Top - Full Size	1
34	A092 1497	Key Top - Zoom Up	1

Index No.	Part No.	Description	Q'ty per Assembly
35	A092 1498	Key Top - Zoom Down	1
36	A092 1499	Key Top - Black	1
37	A092 1500	Key Top - White	1
38	A092 1501	Key Top - Yellow	1
39	A092 1502	Key Top - Orange	1
40	A092 1503	Key Top - Red	1
41	A092 1504	Key Top - Magenta	1
42	A092 1505	Key Top - Blue	1
43	A092 1506	Key Top - Cyan	1
44	A092 1507	Key Top - Green	1
45	A092 1508	Key Top - Light Green	1
46	A092 1509	Key Top - User Color	1
47	A092 1510	Right Key - Mode Select	1
48	A092 1511	Left Key - Mode Select	1
49	A092 1512	Color Adjusting Key	1
50	A092 1513	Shielding Sheet - Mode Key	1
51	A092 1514	Shielding Sheet - Color Key	1
52	A092 1515	Shielding Sheet - 10 Key	1
53	A092 1516	Shielding Sheet - Mode Select Key	1
54	A092 15458	Shielding Sheet - Control Board	1
55	A092 15459	Left Shielding Sheet	1
56	A092 15457	Right Operation Panel Board	1
57	A092 15452	Left Operation Panel Board	1
58	A092 15446	Operation Panel Control Board	1
59	A092 15460	ROM Board	1
60	A092 15513	IC - MBM27C1001-15	1
61	A092 15514	IC - MBM27C1001-15	1
62	A092 15517	IC - MBM27C1001-15	1
63	A092 15518	IC - MBM27C1001-15	1
64	A092 1522	Operation Panel Bracket	3
101	1105 0397	PCB Stud	
102	1105 0398	Spacer	
103	0414 0062B	Screw - M4x6	

4. PLATEN COVER AND CASSETTE (A092)




4. PLATEN COVER AND CASSETTE (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 1594	Grounding Plate	1
2	A092 1572	Hinge	1
3	A092 1590	Hinge Bracket	1
4	A092 1585	Platen Cover Ass'y	1
5	A053 1957	Flex Hinge - Platen Cover	2
6	A060 1865	Front Platen Cover	1
7	A060 1866	Rear Platen Cover	1
8	A092 1591	Platen Cover Pad	1
9	A092 1592	Platen Cover Sheet	1
10	5215 2838	Rubber Magnet	1
11	A049 2761	Dampproof Sheet - A3	1
11	A049 2763	Dampproof Sheet - A4	1
11	A049 2764	Dampproof Sheet - A4R	1
11	A092 2771	Dampproof Sheet - 11x17	1
11	A092 2772	Dampproof Sheet - 17 1/2x14	1
11	A092 2773	Dampproof Sheet - 11x17 1/2	1
12	5215 2839	Spring	1
13	5215 5843	Spring	2
14	5205 2953	Rear Fence	1
15	A007 2950	Cassette Body - Small	1
15	A007 2955	Cassette Body - Large	1
16	AA00 2007	Decal - A3	1
16	AA00 2008	Decal - A4R	1
16	AA00 2009	Decal - A4	1
16	AA00 2003	Decal - 8 1/2x14	1
16	AA00 2004	Decal - 11x17	1
16	AA00 2005	Decal - 8 1/2x11R	1
17	5205 2960	Actuator - A3	1
17	5205 2962	Actuator - A4R	1
17	5205 2964	Actuator - A4S	1
17	5205 2971	Actuator - 11x17	1
17	5205 2979	Actuator - 11x8 1/2	1
17	5205 2996	Actuator - 8 1/2x11	1
18	A053 2915	Bottom Plate - Large	1
18	A053 2917	Bottom Plate - Small	1

Index No.	Part No.	Description	Q'ty per Assembly
19	A053 2916	Friction Pad - B	1
20	5205 2869	Front Side Fence - Large	1
20	5205 6493	Front Side Fence - Small	1
21	5413 4835	Decal - Paper Level	2
22	5205 2947	Rear Side Fence - Large	1
22	5205 6492	Rear Side Fence - Small	1
23	AF01 2004	Cassette Cover - Large	1
23	AF01 2008	Cassette Cover - Small	1
24	5205 2959	Cassette Body Cushion	1
25	A092 1593	Support Sheet	1
101	0354 0080W	Screw - M4X8	
102	0414 0102W	Tapping Screw - M4x10	
103	0802 5131	Truss Head Screw - M4x8	
104	0965 4012W	Philips Pan Head Screw - M4x12	



5. OPTICS SECTION 1 (A092)



5. OPTICS SECTION 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 1780	Left Filter Stay	1
2	A049 1975	PCB Cover Grid	1
3	A049 1980	Leaf Spring Plate	1
4	A049 1982	PCB Support Bracket - Left	1
5	A049 1983	Grounding Plate	1
6	A049 5302	PCB Relay Harness	1
7	A049 5303	PCB Relay Harness	1
8	A049 1854	CCD Drive Board Set	1
9	A049 5280	Scanner Control Board	1
10	A049 1691	Left Inner Cover	1
11	A049 1964	Screw Cover	6
12	AC04 2025	Left Scale	1
13	A049 1956	Front Scale (A4)	1
13	A092 1956	Front Scale (LT)	1
14	A049 1706	Exposure Glass	1
15	A049 1965	Front Scale Holder	1
16	5875 2088	Shoulder Screw - M4	2
17	A049 1711	Exposure Glass Stopper	1
18	5419 5714	Stepped Screw - M4	2
19	A049 1709	Left Scale Bracket	1
20	5403 2075	Stepped Screw	6
21	A092 1958	Right Scale (A4)	1
21	A092 1959	Right Scale (LT)	1
22	A049 1793	Dust Filter	1
23	A049 5205	Scanner Mother Board	1
24	A049 1708	Right Scale Bracket	1
25	A049 1925	Scanner Mother Board Bracket	1
26	A049 5290	Scanner Motor Board	1
27	A049 1660	Scanner Motor Board Bracket	1
28	AZ50 0014	Stabilizer	1
29	A049 1928	Rear Scanner Fan Bracket	1
30	AX65 0005	Fan Motor - DC24V	1
31	A049 1787	Rear Filter Stay	1
32	A049 1695	Right Inner Cover	1
33	A049 1699	Middle Inner Cover	1

Index No.	Part No.	Description	Q'ty per Assembly
34	A049 1785	Dust Filter	1
101	0354 0060B	Screw - M4x6	
102	0951 3005B	Philips Screw With Flat Washer M3x5	
103	0354 0050W	Philips Pan Head Screw - M4x5	
104	0951 4006B	Philips Screw with Flat Washer - M4	
105	0951 3006B	Philips Screw with Flat Washer - M3	




6. OPTICS SECTION 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 5308	Scanner EOS Harness	4
2	A049 1942	PCB Bracket	2
3	A049 1876	Positioning Sensor Roller	4
4	A049 1854	CCD Drive Board Set	1
6	A049 1823	Bushing - 12x6x6	1
7	A049 1819	Scanner Unit Guide Roller	1
8	AA14 3247	Positioning Pin	1
9	A049 1815	Front Tension Arm	1
10	AA06 0242	Spring	1
11	A049 1842	Wire Clamp	2
12	A049 1895	Left Upper Cover - Scanner	1
13	A007 1920	Cushion - Exposure Glass	7
14	A049 1903	Lower Scanner Cover	1
15	A049 1659	Exposure Lamp Harness Bracket	1
16	A049 1930	Lower Coaxial Cable Bracket	1
17	AA15 0182	Seal - 26x130x0.2	2
18	5205 3863	Leaf Spring	1
19	A049 1811	Harness Guide Plate	1
20	A049 1931	Lower Shielding Plate Bracket	1
21	A049 1833	Rear Left Tension Arm	1
22	A049 1934	Upper Support Shielding Plate	1
23	A049 1898	Right Upper Cover - Scanner	1
24	A049 5300	Scanner Coaxial Harness	1
25	A049 1851	Upper Coaxial Cable Bracket	1
26	A049 1825	Harness Guide	1
27	AX40 0019	Heater - DC24V 20W $\pm$ 15%	2
28	AX50 0032	Fluorescent Lamp	2
29	A049 1830	Rear Right Tension Arm	1
30	AA06 0243	Spring	2
31	A049 1836	Tension Arm Bracket	1
32	A049 5330	Optical Harness	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0951 3006B	Philips Screw with Flat Washer - M3	
102	0353 0080B	Screw - M3x8	
103	0720 0030B	Retaining Ring - M3	
104	0533 0040B	Hexagonal Set Screw - M3x4	
105	0720 0050B	Retaining Ring - M5	
106	0353 0050B	Philips Truss Head Screw M3x5	
107	0354 0060B	Screw - M4x6	
108	0805 3403	Bearing - DR18 - H6	
109	0313 0040B	Philips Pan Head Screw - M3x4	
110	0353 0040B	Screw - M3x4	
111	0352 5050B	Screw - M2.5x5	
112	1105 0201	Harness Clamp	
113	1106 0241	Bushing - 6.7mm	
114	1105 0229	Clamp	

7. OPTICS SECTION 3 (A092)



7. OPTICS SECTION 3 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 1704	PCB Guide Bracket - Front	1
2	A049 1705	PCB Guide Bracket - Front Right	2
3	A049 1669	Rear Upper Side Plate	1
4	A049 1701	PCB Guide Rail Bracket - Rear Left	1
5	A049 1703	PCB Guide Rail Bracket - Rear Right	2
6	A049 1702	PCB Guide Rail Bracket - Rear	2
7	AX40 0009	Heater - 220V 18W	1
7	AX40 0008	Heater - 115V 18W	1
8	A049 1933	Upper Shielding Plate Bracket	1
9	A049 1940	Heater Bracket	1
10	A049 1983	Grounding Plate	1
11	A049 1949	PCB Support Bracket - Right	1
12	A049 1683	Rear Right Cover Bracket	1
13	A092 1769	Harness Guide Plate	1
14	A049 1664	Front Upper Side Plate	1
15	A049 1935	Leaf Spring	2
16	AA16 1055	Stopper - 12.7x12.7x5.8	1
17	A049 1984	Grounding Plate	2
18	A049 5324	Heater Relay Harness	1
19	A049 1796	Scanner Stopper Chain	1
20	A049 5305	Scanner Main Harness	1
21	A049 5310	Scanner Optical Fiber	1
22	A049 5313	Scanner Data Harness	1
23	A049 1939	Connector Bracket	1
24	A049 5306	Scanner Optical Fiber - SPU	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0951 3005B	Philips Screw With Flat Washer M3x5	
103	0951 4010B	Philips Screw With Flat Washer - M4	
104	0312 5100B	Philips Pan Head Screw - M2.5x10	
105	0710 0025B	Hexagon Nut - M2.5	
106	1005 0907	Rail - 50x6040	
107	1105 0196	Harness Clamp	
108	1105 0197	Wire Saddle	
109	1105 0201	Harness Clamp	
110	1105 0199	Clamp	
111	1106 0310	Bushing	
112	1102 4052	Optional Connector	
113	1105 0229	Clamp	
114	1106 0241	Bushing - 6.7mm	





3. OPTICS SECTION 4 (A092

Index No.	Part No.	Description	Q'ty per Assembly
1	AX65 0005	Fan Motor - DC24V	1
2	A049 1713	Scanner Fan Cover	1
3	A049 1751	Front Left Pulley	1
4	A049 1749	Front Left Pulley Bracket	1
5	A049 1666	Front Lower Side Plate	1
6	AC05 0003	Guide Rod	1
7	AA14 3246	Pressure Pin	2
8	AA06 3134	Spring	1
9	A049 1732	Scanner Guide Rod Bracket	1
10	A049 1738	Front Right Pulley Bracket	1
11	A049 1740	Front Right Pulley	2
12	AA14 3076	Stepped Screw - M4	12
13	AA06 3132	Spring	2
14	A049 1720	Stopper Bracket - Scanner Unit	1
15	AA14 3244	Guide Lock Pin	1
16	A049 1724	Scanner Lock Shaft	1
17	AA14 3245	Lock Pin	1
18	A049 1698	Leaf Spring	3
19	AA06 3133	Spring	1
20	A049 1745	Rear Right Pulley Bracket	1
21	A049 5318	Scanner Motor Relay Harness	1
22	A049 1757	Rear Left Pulley	1
23	A049 5320	Home Position Sensor Harness	1
24	5205 5250	LED Sensor Type S	2
25	A049 1911	Scanner Home Sensor Bracket	1
26	A049 1754	Rear Left Pulley Bracket	1
27	AX05 0031	Motor - 9W	1
28	AA05 0040	Scanner Drive Wire - Long	1
29	AB03 2036	Scanner Wire Pulley	1
30	AA05 0041	Scanner Drive Wire	1
31	A049 1914	Scanner Motor Bracket	1
32	A049 1765	Support Plate - Rear Right Pulley	1
33	AA16 1057	Cushion - 50x18x1.6	1
34	A049 1776	Scanner Wire Clamp	1
35	AA16 1056	Cushion - 27x50x0.8	1

Index No.	Part No.	Description	Q'ty per Assembly
36	A049 1773	Wire Clamp Bracket	1
37	A049 1766	Support Plate - Rear Left Pulley	1
38	A049 1674	Rear Lower Side Plate	1
101	0354 0060B	Screw - M4x6	
102	0354 0100B	Screw - M4x10	
103	0951 3006B	Philips Screw with Flat Washer - M3	
104	0574 0050E	Hexagon Headless Set Screw - M4x5	
105	0720 0040B	Retaining Ring - M4	
106	0720 0060B	Retaining Ring - M6	
107	0951 4010B	Philips Screw With Flat Washer - M4	
108	0354 0200B	Screw - M4x20	
109	1105 0229	Clamp	

9. LASER UNIT 1 (A092)




9. LASER UNIT 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 2051	Laser Unit (220/240V)	1
*	A092 2057	Laser Unit (115V)	1
1	A049 2098	1st Mirror Lower Bracket	2
2	AC03 0049	1st Lower Mirror	2
3	5506 6300	Shaft - Master Eject Command	8
4	AA06 3059	Spring	8
5	5442 2117	Shoulder Screw - Hinge	8
6	AA06 3043	Shaft Bracket Spring	2
7	A049 2102	1st Mirror Upper Bracket	2
8	AC03 0051	1st Upper Mirror	2
9	A049 2191	Laser Unit Grip Chain	2
10	A049 2139	Polygon Motor Cover	1
11	AC01 5008	Shielding Glass	2
12	AA15 1459	Seal - 4.5x51x2	2
13	AA15 2133	Seal - 9x341x2	2
14	A049 5750	Polygon Motor	1
15	AA15 2116	Seal - 8x35x3	1
16	A049 2141	Polygon Motor Harness Cover	1
17	AA15 2123	Seal	8
18	A049 2135	Connector Bracket	4
19	G000 1945	Cylinder	4
20	A049 2134	Connector Holder	4
21	A049 5674	Optical Fiber Cable - Cyan	1
22	A049 5673	Optical Fiber Cable - Yellow	1
23	A049 5668	Laser Unit Sequence Harness	1
24	5353 5625	Thermistor	1
25	AA15 2132	Seal - 11x483x1	2
26	A049 2195	Seal - Yellow	4
27	AA14 3258	Stepped Screw - M4x7	6
28	AA14 3257	Shielding Grass Stopper	4
29	A049 2145	Laser Unit Lower Cover	1
30	A049 3946	Seal - Cyan	5
31	A049 2194	Seal - Magenta	4
32	A049 3945	Seal - Black	4
33	A049 9001	Toner Shield Glass : -40;C	1

Index No.	Part No.	Description	Q'ty per Assembly
33	A049 9002	Toner Shield Glass : -30;C	1
33	A049 9003	Toner Shield Glass : -20;C	1
33	A049 9004	Toner Shield Glass : -10;C	1
33	A049 9005	Toner Shield Glass : +2;C	1
33	A049 9006	Toner Shield Glass : +10;C	1
33	A049 9007	Toner Shield Glass : +20;C	1
33	A049 9008	Toner Shield Glass : +30;C	1
33	A049 9009	Toner Shield Glass : +40;C	1
34	A049 2100	2nd Mirror Lower Bracket	2
35	AC03 0050	2nd Lower Mirror	2
36	5447 5638	Anticondensation Heater - 220/240V	2
36	5447 5438	Anticondensation Heater - 115V	2
37	A049 5667	Laser Unit Heater Harness	2
38	A049 2124	Heater Harness Cover	1
39	AC03 0052	2nd Upper Mirror	2
40	A049 2104	2nd Mirror Upper Bracket	2
41	A049 5671	Optical Fiber Cable - Black	1
42	A049 5672	Optical Fiber Cable - Magenta	1
43	5353 1267	Decal - Laser Caution	1
44	AA00 0035	Decal - LD	1
101	0708 0060B	Washer - M6	
102	0951 4008B	Philips Screw With Flat Washer - M4	
103	0951 4006B	Philips Screw with Flat Washer - M4	
104	0951 4012B	Philips Screw With Flat Washer	
105	0354 0060B	Screw - M4x6	
106	0951 3008B	Philips Screw With Flat Washer - M3	
107	0965 3006B	Tapping Screw With Flat Washer M3x6	
108	1105 0008	Nylon Clip - 2N	

10. LASER UNIT 2 (A092)




10. LASER UNIT 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 2184	LD Drive Board Cover	1
2	A049 5668	Laser Unit Sequence Harness	1
3	A049 5661	Laser Unit DC Harness	1
4	A049 5663	Polygon Motor Harness	1
5	A049 2196	Harness Holder	2
6	A049 5664	Laser Unit Main Harness	1
7	A049 5470	LD Control Board	1
8	A049 2092	LD Mirror Bracket	2
9	AC03 0048	LD Mirror	2
10	5400 3404	Stepped Screw	6
11	A049 2182	Grounding Plate	3
12	A049 2083	F Theta Lens Bracket - 1	4
13	A049 5756	Polygon Motor Control Board	1
14	A049 2188	Motor Bracket	1
15	A049 2171	Laser Unit Cover	1
16	AA15 2130	Seal - 6x231x1	2
17	GC02 5001	F Theta Lens L1	4
18	AA15 2129	Seal - 10x89x1	2
19	AA15 2128	Seal - 38x322x3	1
20	AA15 2131	Seal - 7x488x1	1
21	A049 2087	F Theta Lens Bracket - 2	4
22	A049 2093	F Theta Lens - 2	4
23	A049 5665	Laser Unit Control Harness	4
24	AA15 2094	Seal - 22x38x2	4
25	A049 2198	LD Unit	4
26	AA00 0035	Decal - LD	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0951 3006B	Philips Screw with Flat Washer - M3	
103	0951 4010B	Philips Screw With Flat Washer - M4	
104	0951 3025B	Philips Screw With Flatwasher - M3x	
105	1105 0292	Wire Saddle	
106	1105 0291	Wire Saddle	
107	1105 0310	Wire Clamp	
108	1105 0319	Harness Clamp	
109	1607 0430	Ferrite Core - TRCC-23-11-14	
110	1607 0323	Ferrite Core	
111	1607 0332	Ferrite Core - TRCC-25-15-12	

11. PAPER FEED AND REGISTRATION 1 (A092)




11. PAPER FEED AND REGISTRATION 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	5208 5331	Stepper Motor - DC 6V	1
2	AB01 1071	Gear - 16Z	1
3	A049 2624	Motor Support Bracket	1
4	A049 5435	Paper Feed Motor Board	1
5	AG05 1062	Upper Registration Guide Knob	1
6	A049 2628	Bracket - Paper Feed Motor Board	1
7	AA14 3238	Motor Drive Shaft	1
8	A049 2622	Gear Holder Plate	1
9	AB01 7143	Gear - 30/32Z	1
10	AB01 3400	Gear - 28Z	1
11	A049 2585	Magnet Clutch Stopper	1
12	A049 2621	Paper Feed Motor Bracket	1
13	AA16 1014	Cushion - Motor	3
14	AA13 2110	Collar	1
15	A049 2613	Entrance Guide - Transfer Unit	1
16	AA13 2111	Spacer - 8x12x0.5	1
17	AB02 3016	Sprocket - 18T/50Hz	1
18	5205 2697	Bushing - Upper Registration Roller	2
19	5442 2754	Spring - Registration Roller	2
20	5205 2866	Magnetic Clutch Collar	1
21	AX20 0017	Magnetic Clutch - Registration	1
22	AA13 2025	Spacer - 1x8x12	1
23	AB01 3399	Gear - 30Z	1
24	AB01 7144	Gear - 18/21Z	1
25	A049 2669	Rear Cover - Paper Feed Unit	1
26	A049 1300	Right Cover - Paper Feed Unit	1
27	A092 1391	Decal - Paper Feed Unit	1
28	A092 2665	Front Cover - Paper Feed	1
29	AA00 1159	Decal - A4	1
30	A092 1398	Decal - Misfeed Removal - Small	1
31	AA00 1147	Decal - A2	1
32	A049 2608	Spacer - 118x13.5x1	1
33	A049 2600	Upper Registration Guide	1
34	A007 2577	Registration Knob	1
35	AB01 3397	Gear - 20Z	1

Index No.	Part No.	Description	Q'ty per Assembly
36	AF02 1037	Lower Registration Roller	1
37	AF02 0143	Upper Registration Roller	1
38	AB01 3398	Gear - 18Z	1
39	A049 2610	Lower Registration Guide	1
40	A092 5643	Grounding Wire - Paper Feed	1
41	A049 2609	Edgeing - 341x5x3.7	1
42	A049 2607	Registration Sensor Bracket	1
43	5207 7702	Photo Coupler - ON2509	1
44	A049 5610	Registration Sensor Relay Harness	1
101	0951 4008B	Philips Screw With Flat Washer - M4	
102	0354 0060B	Screw - M4x6	
103	0720 0040E	Retaining Ring - M4	
104	0742 3808	Ball Bearing - 8x16	
105	0533 0040B	Hexagonal Set Screw - M3x4	
106	0951 4014B	Philips Screw With Flat Washer M4	
107	0707 4050B	Bushing - 4x5	
108	0574 0040E	Hexagon Headless Set Screw - M4x4	
109	0313 0060B	Philips Pan Head Screw - M3x6	
110	0574 0050E	Hexagon Headless Set Screw - M4x5	
111	0720 0050B	Retaining Ring - M5	
112	0434 0060B	Philips Tapping Screw - M4x6	
113	0314 0060B	Philips Pan Head Screw - M4x6	
114	0314 0100B	Philips Pan Head Screw - M4x10	
115	0632 0120	Parallel Pin - M2x12	
116	0720 0060B	Retaining Ring - M6	
117	0965 4008B	Tapping Screw - M4 x 8	
118	1105 0159	PCB Stud	

12. PAPER FEED AND REGISTRATION 2 (A092)



12. PAPER FEED AND REGISTRATION 2 (A092)


Index No.	Part No.	Description	Q'ty per Assembly
1	A007 2745	Upper Solenoid - Paper Feed	1
2	A007 2749	Pick-up Arm - Manual Feed	1
3	A007 2742	Shutter Plate	2
4	A092 2531	By-pass Feed Table Ass'y (A4)	1
4	A092 2700	By-pass Feed Table Ass'y (LT)	1
5	5205 5251	LED Sensor Type - T	4
6	A007 5251	Lift Motor Harness	1
7	A049 2710	Bracket - Paper Feed Control Board	1
8	A049 5612	Lift Sensor Relay Harness	1
9	A049 5430	Paper Feed Control Board	1
10	A007 2747	Lower Solenoid - Paper Feed	1
11	A007 2655	Separation Fixed Bracket	1
12	A049 2712	Support Bracket	1
13	AX20 0018	Paper Feed Clutch	1
14	AA13 2025	Spacer - 1x8x12	1
15	5205 2865	Bushing - Paper Feed Roller	1
16	A007 2698	Upper Magnetic Clutch Stopper	1
17	AA13 2024	Spacer - M6	2
18	AB01 3077	Gear - 20T	1
19	5053 0447	Bushing - 6mm	3
20	5205 2734	Magnet - By-pass Table	1
21	A049 2700	Paper Feed Stay	1
22	AA14 0045	Pick Up Shaft	1
23	AA14 0046	Paper Feed Shaft - Upper	1
24	A007 2686	Feed Guide - Paper Feed Roller	1
25	5447 2723	Pick-up Roller	1
26	5447 2681	Snap Ring	3
27	AB01 3079	Gear - 21T	1
28	5447 2726	Paper Feed Roller	1
29	AB01 3078	Gear - 18T	1
30	5053 0223	Bushing - 8mm	1
31	5447 2693	Separation Roller	1
32	5447 2678	Slip Clutch Cover	1
33	AA14 0135	Separation Shaft	1
34	AB01 1024	Gear - 25T	1

Index No.	Part No.	Description	Q'ty per Assembly
35	AA06 3162	Paper Feed Separation Spring	1
36	A007 2657	Separation Arm	1
37	AA14 0044	Pressure Arm Shaft	1
38	AB01 1023	Gear - 15T	1
39	AA06 0082	Pick-up Lever - Spring	1
40	A049 2566	Right Upper Stay	1
41	AA02 0004	Paper Tray Magnet	1
42	A007 2634	Upper Feed Guide	1
43	A007 2802	Decal - Side Fence - Manual Feed	1
44	AF01 6023	Side Fence - Manual Feed - Rear	1
45	AA00 2030	Decal - Manual Feed - A3/A4	1
46	5443 2706	Plate - 12x220x1T	1
47	AF01 6022	Front Side Fence	1
48	A049 2681	By-pass Feed Table	1
49	A049 2692	Spacer - 132x10	1
50	A012 2812	Rear Side Fence Gear	1
51	A012 2688	Front Side Fence Gear	1
52	A049 2691	Spacer - 14x6	1
53	A012 2692	Wave Washer	1
54	AB01 3125	Gear - 16T	1
55	A092 5434	By-pass Paper Size Sensor (A4)	1
55	A092 5432	By-pass Paper Size Sensor (LT)	1
56	AA06 0112	Pressure Spring - Pick-up	1
57	A049 2682	By-pass Feed Table Cover	1
58	5447 2927	Friction Pad - B	1
59	A049 2687	By-pass Feed Table Support	1
60	5447 2695	Input Hub	1
61	A007 2805	Manual Feed Sensor Bracket	1
62	A007 2649	Separation Guide	1
63	A007 2718	Paper End Feeler	1
64	5443 2668	Bushing	2
65	A007 2720	Paper End Actuator Bracket	1
66	5447 2676	Output Hub	1
67	A007 2684	Bracket - Paper Feed Roller	1
68	A007 2803	Manual Feed Table Holder	2

Index No.	Part No.	Description	Q'ty per Assembly
69	5447 2697	Cylindrical Spring	1
70	A007 2725	Paper End Shutter - Upper	1
71	A007 2733	Feed Control Board Bracket	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0313 0060B	Philips Pan Head Screw - M3x6	
103	0951 3006B	Philips Screw with Flat Washer - M3	
104	0314 0100B	Philips Pan Head Screw - M4x10	
105	0434 0060B	Philips Tapping Screw - M4x6	
106	0720 0050B	Retaining Ring - M5	
107	0720 0060E	Retaining Ring - M6	
108	0720 0040E	Retaining Ring - M4	
109	0434 0080W	Tapping Screw - M4x8	
110	0574 0050E	Hexagon Headless Set Screw - M4x5	
111	0720 0050E	Retaining Ring - M5	
112	0622 0100W	Parallel Pin - M2x10	
113	0314 0060B	Philips Pan Head Screw - M4x6	
114	0720 0030B	Retaining Ring - M3	
115	1105 0291	Wire Saddle	
116	0965 3008B	Tapping Screw With Washer - M3x8	
117	0353 0060B	Screw - M3x6	
118	0314 0100W	Philips Pan Head Screw - M4x10	
119	0805 3042	Ball Bearing - 6x10x3mm	
120	1105 0292	Wire Saddle	
121	1105 0005	Nylon Clip - 3N	

13. PAPER FEED AND REGISTRATION 3 (A092)




13. PAPER FEED AND REGISTRATION 3 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A007 2883	Roller Plate Release Roller	1
2	A007 2885	Cam - Bottom Plate Release	1
3	AA13 2024	Spacer - M6	1
4	A007 2857	Actuator - Bottom Plate Release	1
5	A007 2867	Link Plate - Release Arm Lever	1
6	A007 2861	Link Plate - Release Arm	1
7	A007 2864	Release Arm Lever	1
8	A007 2850	Release Arm - Bottom Plate	2
9	5053 0223	Bushing - 8mm	2
10	5205 2681	Coupled Gear - 17T/50T	2
11	5205 2680	Coupled Gear - 16T/53T	2
12	AA06 0132	Spring	2
13	A000 5507	Lift Motor - DC1.69W	2
14	A007 2765	Paper Lift Motor Ass'y - Upper	1
15	A007 2766	Paper Lift Motor Ass'y - Lower	1
16	A049 5616	Paper Feed Unit Harness	1
17	A007 2877	Cushion - Upper Pick-off Bracket	1
18	A049 2743	Rear Cassette Holder	1
19	A007 2880	Bottom Plate Release Stopper	1
20	A007 2759	Sector Gear	2
21	A007 2756	Bushing - Volume Sensor Shaft	4
22	A007 2757	Sector Gear Bushing	4
23	AA14 0053	Shaft - Bottom Plate Release	1
24	A049 2741	Front Cassette Holder	1
25	A007 2649	Separation Guide	1
26	A007 2754	Bottom Plate Lever	2
27	A007 2752	Volume Sensor Shaft	2
28	A007 2722	Upper Bracket - Paper End	1
29	5215 5230	Photointerruptor - L Type	3
30	AA06 0049	Release Lever Spring	1
31	A007 2848	Cushion - Release Lever	1
32	A007 2844	Release Lever - Bottom Plate	1
33	AG05 1064	Knob	1
34	A007 2853	Link Plate - Release Lever	1
35	A049 2751	Front Cover Support Plate	1

Index No.	Part No.	Description	Q'ty per Assembly
36	A049 5646	Grounding Wire - Lift Motor	2
37	A049 2720	Cassette Arm Shaft Stopper	2
38	A007 2724	Lower Bracket - Paper End	1
101	0720 0030E	Retaining Ring - M3	
102	0720 0040E	Retaining Ring - M4	
103	1105 0016	Nylon Clip - 4N	
104	0314 0080W	Philips Pan Head Screw - M4x8	
105	0434 0060B	Philips Tapping Screw - M4x6	
106	0314 0100B	Philips Pan Head Screw - M4x10	
107	0951 4006B	Philips Screw with Flat Washer - M4	
108	0324 0060W	Philips Sunken Head Screw - M4x6	
109	0720 0050B	Retaining Ring - M5	
110	0720 0040B	Retaining Ring - M4	
111	0354 0060B	Screw - M4x6	

14. PAPER FEED AND REGISTRATION 4 (A092)



14. PAPER FEED AND REGISTRATION 4 (A092)


Index No.	Part No.	Description	Q'ty per Assembly
1	A049 2631	Paper Feed Drive Chain - 100P	1
2	AX20 0042	Magnetic Clutch	1
3	AX20 0018	Paper Feed Clutch	1
4	AA13 2025	Spacer - 1x8x12	3
5	5205 2865	Bushing - Paper Feed Roller	1
6	5429 2830	Roller	1
7	AB02 3018	Sprocket - 15T	1
8	5205 1101	Sprocket - 12T	1
9	A049 2625	Tension Arm	1
10	AA06 0050	Tightener Spring	1
11	5887 4162	Screw - Driven Guide Plate	1
12	AB01 3077	Gear - 20T	1
13	AA13 2024	Spacer - M6	2
14	5053 0447	Bushing - 6mm	2
15	A049 2595	Magnet Clutch Stopper	1
16	A007 2877	Cushion - Upper Pick-off Bracket	1
17	A007 2718	Paper End Feeler	1
18	5443 2668	Bushing	2
19	A007 2726	Paper End Actuator Bracket	1
20	5205 2777	Cushion - Lower Pick Up Guide	2
21	A007 2630	Lower Guide - Paper Feed Solenoid	1
22	A007 2712	Lower Paper Feed Stay	1
23	A007 2894	Cushion - 8x15x30	1
24	A007 5253	Upper Paper Size Harness	1
25	5205 5253	Photointerruptor Pack	2
26	A007 2661	Paper Size Sensor Bracket	2
27	AA14 0046	Paper Feed Shaft - Upper	1
28	AA14 0045	Pick Up Shaft	1
29	A007 2686	Feed Guide - Paper Feed Roller	1
30	5447 2723	Pick-up Roller	1
31	5447 2681	Snap Ring	3
32	AB01 3079	Gear - 21T	1
33	A007 2709	Paper Feed Roller Bracket	1
34	5053 0223	Bushing - 8mm	1
35	AB01 3078	Gear - 18T	1

Index No.	Part No.	Description	Q'ty per Assembly
36	5447 2726	Paper Feed Roller	1
37	5447 2693	Separation Roller	1
38	5447 2678	Slip Clutch Cover	1
39	5447 2676	Output Hub	1
40	5447 2697	Cylindrical Spring	1
41	5447 2695	Input Hub	1
42	AA14 0135	Separation Shaft	1
43	A007 2653	Paper Feed Brace - Upper	1
44	AF02 0024	Lower Middle Roller	1
45	AA06 3162	Paper Feed Separation Spring	1
46	AB01 1024	Gear - 25T	1
47	A007 2657	Separation Arm	1
48	AA14 0044	Pressure Arm Shaft	1
49	AB01 1023	Gear - 15T	1
50	A007 2655	Separation Fixed Bracket	1
51	5205 2644	Paper End Actuator	1
52	A007 2675	Paper Feed Stay - Lower	1
53	AF02 0023	Upper Middle Roller	1
54	A049 2636	Connector Bracket	1
55	A049 5608	Paper Feed Relay Harness	1
56	A049 2592	Upper Paper Guide	1
57	A007 2848	Cushion - Release Lever	2
58	A053 2632	Knob - Transport Middle Guide	1
59	A049 2591	Lower Paper Guide	1
60	5205 2697	Bushing - Upper Registration Roller	2
61	AA06 3041	Relay Roller Spring	2

Index No.	Part No.	Description	Q'ty per Assembly
101	0574 0050E	Hexagon Headless Set Screw - M4x5	
102	0434 0080W	Tapping Screw - M4x8	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0720 0060E	Retaining Ring - M6	
105	0720 0040E	Retaining Ring - M4	
106	0742 3808	Ball Bearing - 8x16	
107	0720 0060B	Retaining Ring - M6	
108	0314 0100W	Philips Pan Head Screw - M4x10	
109	0720 0050E	Retaining Ring - M5	
110	0805 3042	Ball Bearing - 6x10x3mm	
111	0313 0080B	Philips Pan Head Screw - M3x8	
112	0433 0050B	Tapping Screw - M3x5	
113	0720 0050B	Retaining Ring - M5	
114	0951 4006B	Philips Screw with Flat Washer - M4	
115	0720 0030B	Retaining Ring - M3	
116	1105 0120	Wire Clip	

Index No.	Part No.	Description	Q'ty per Assembly

15. MAIN CORONA SECTION (A092)




15. MAIN CORONA SECTION (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 2279	Main Corona Unit	4
2	A006 2267	Front Cover - Main Corona	4
3	A006 2114	Grid Anchor	4
4	AA06 0141	Spring - Charge Corona Grid	8
5	AD02 2181	Front End Block - Charge Corona	4
6	A092 2309	Plastic Screw - Main Corona	4
7	A049 3945	Seal - Black	4
7	A049 2194	Seal - Yellow	4
7	A049 2195	Seal - Magenta	4
7	A049 3946	Seal - Blue	5
8	A049 2422	Drum Stay	4
9	A049 1084	Support Plate - Development Cover	1
10	A049 1085	Development Cover	1
11	A049 2283	Left Casing - Corona Unit	4
12	A006 2266	Rear Cover - Charge Corona	4
13	5442 2108	Spring - Corona Wire	5
14	AD02 2265	Rear End Block - Charge Corona	4
15	5442 2110	Plug - Corona Unit	5
16	A092 9500	Charge Corona Wire - 10pcs/set	1
17	A049 2284	Right Casing - Corona Unit	4
18	A049 2272	Charge Grid - 85T	4
19	A049 3832	Belt Discharge Corona Unit	1
20	A049 3953	Belt Discharge Corona Casing	1
21	A049 3919	Corona Wire Hook - BK,M	1
22	AD02 2262	Front End Block - Main Corona	1
23	AD02 2182	Rear End Block - Belt Discharge	1
24	AD02 0038	Belt Discharge Corona Wire	1
25	AD02 2263	Front Cover - Main Corona	6
26	AD02 2264	Rear Cover - Main Corona	1
27	A049 2264	Left Rail - Charge Corona	4
28	A049 2265	Right Rail - Charge Corona	4
29	A049 2267	Leaf Spring	4
30	A049 2266	Leaf Spring	8
31	A049 2260	Charge Corona Casing	4
32	A049 2268	Quenching Lamp Spacer	4

Index No.	Part No.	Description	Q'ty per Assembly
33	A049 5780	Quenching Lamp	4
34	A049 3956	Discharge Corona Rail - Paper	1
35	A049 2452	Drum Unit Cover Stad	2
36	AA14 3280	Positioning Pin - Belt Discharge	1
37	A049 2301	Cleaner - Main Corona Unit	4
101	0413 0082B	Tapping Screw - M3x8	
102	0413 0062B	Tapping Screw - M3x6	
103	0354 0060B	Screw - M4x6	
104	0414 0082B	Binding Self Tapping Screw - M4x8	
105	0314 0100B	Philips Pan Head Screw - M4x10	

16. DEVELOPMENT UNIT 1 (A092)




16. DEVELOPMENT UNIT 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 3055	Development Unit	4
1	A049 3195	Development Upper Cover	4
2	A049 3187	Front Grip Holder	4
3	AG05 1066	Development Unit Grip	4
4	A049 3188	Rear Grip Holder	4
5	A049 5767	Toner Supply Sensor	4
6	A049 3181	Toner Supply Sensor Bracket	4
7	A049 3175	Development Top Cover	4
8	AA11 5006	Harness Clamp	4
9	AB01 1080	Gear - 30Z	4
10	AA14 3261	Stud	4
11	A049 5604	Development Unit Harness	4
12	A049 5495	Toner Density Sensor	4
13	A049 2469	Insulating Plate	4
14	5507 4312	Stepped Screw - Etching	4
15	A049 3075	Bias Terminal Plate	4
16	AA11 5007	Harness Clamp	4
17	AD03 7020	Toner Supply Auger	4
18	A049 3076	Collection Coil Cap	4
19	A049 3294	Receptacle - Toner Supply	4

Index No.	Part No.	Description	Q'ty per Assembly
101	0414 0102B	Tapping Screw M4 x 10	
102	0313 0050B	Philips Pan Head Screw - M3x5	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0354 0060B	Screw - M4x6	
105	0720 0025B	Retaining Ring - M2.5	
106	0314 0100B	Philips Pan Head Screw - M4x10	
107	0413 0062B	Tapping Screw - M3x6	
108	0314 0120B	Philips Pan Head Screw - M4x12	
109	0354 0060F	Philips Pan Head Screw - M4x6	

17. DEVELOPMENT UNIT 2 (A092)




17. DEVELOPMENT UNIT 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	AA15 1447	Seal - 7.5x336x2	8
2	A049 3067	Doctor Plate	4
3	AD03 7012	Lower Development Auger	4
4	A049 3159	Auger Cover	4
5	AD03 7015	Upper Development Auger	4
6	AD03 1151	Development Roller	4
7	AB01 3183	Gear - 26Z	4
8	A049 3109	Toner Supply Blade	4
9	AD03 3012	Toner Supply Roller	4
10	AA15 2111	Seal - 5x9x3.8	8
11	A049 3099	Toner Supply Foam Roller	4
12	AA15 1445	Seal - 14x10	8
13	AA15 2110	Seal - 4x8x5.3	8
14	A049 3095	Toner Agitator	4
15	AA14 0277	Development Agitator Shaft	4
16	AA15 0185	Seal - 35x335x2	4
17	A049 3090	Development Unit Casing	4
18	A049 9010	Exit Guide Set	4
19	A049 3227	Side Seal - 23x83x0.1	8
20	AA14 3251	Stepped Screw - M3x10.5	16
21	AA15 1446	Seal - 4.5x12x2	16
22	AA08 0061	Bushing	4
23	AA08 0088	Bushing	4
24	A049 3121	Front Shaft Plate	4
25	AA15 1470	Seal - 13.5x16.5x20	8
26	A049 3235	Development Adjuster	4
27	A049 3167	Bearing Case	4
28	AA15 1569	Seal - 11x15x1	8
29	A049 3068	Front Plate - Development	4
30	AB01 3181	Gear - 15Z	8
31	AA08 0086	Bushing	16
32	AB01 3182	Gear - 22Z	4
33	A049 3079	Rear Plate - Development	4
34	A049 3092	Magnet	4
35	AB01 1079	Gear - 14Z	8

Index No.	Part No.	Description	Q'ty per Assembly
36	AB01 1077	Gear - 17Z	8
37	AB01 1078	Gear - 14Z	4
38	A049 3155	Joint - Toner Supply	4
39	A049 3122	Rear Shaft Plate	4
			
101	0720 0040B	Retaining Ring - M4	
102	0314 0120B	Philips Pan Head Screw - M4x12	
103	0313 0060B	Philips Pan Head Screw - M3x6	
104	0314 0060B	Philips Pan Head Screw - M4x6	
105	0720 0030B	Retaining Ring - M3	
106	0725 0120	Retaining Ring C - M12	

18. TONER TANK SECTION (A092)




18. TONER TANK SECTION (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A092 1393	Decal - Adding Toner	1
2	A049 3365	Tank Unit Left Plate	1
3	A049 5615	Toner Tank Unit Relay Harness	1
4	A049 5437	Toner Supply Motor Board	1
5	A049 3328	Top Cover - Cyan	1
6	5403 2817	Reverse Pin - Reverse Roller	4
7	A049 3332	Toner Cartridge Guide - Cyan	1
8	A049 3333	Toner Guide Seal	4
9	A049 3054	Toner Tank Ass'y	4
10	A049 3327	Top Cover - Yellow	1
11	A049 3331	Toner Cartridge Guide - Yellow	1
12	A049 3326	Top Cover - Magenta	1
13	A049 3330	Toner Cartridge Guide - Magenta	1
14	A049 3255	Hopper Cover	4
15	A049 5606	Toner Tank Unit Harness	1
16	A049 3284	Tank Unit Rear Plate	1
17	5205 2893	Cushion - Sector Gear	1
18	A049 3292	Tank Unit Stopper	1
19	A049 3325	Top Cover - Blue	1
20	A049 3329	Toner Cartridge Guide - Blue	1
21	AB01 1081	Gear - 50Z	4
22	A049 5765	Toner End Sensor	4
23	A049 3337	Toner Tank Entrance Shield	4
24	AA15 1535	Seal - 11x20x1	20
25	5447 3200	Bushing - 6mm	16
26	A420 2761	Gear - 38T	4
27	A049 3303	Toner Supply Motor Bracket	4
28	A028 5306	DC Motor - DC 24V	4
29	AA15 2114	Seal - 2.7x16x1	4
30	AD03 7026	Toner Supply Auger	4
31	AA03 6012	Large Cap - Toner Tank	4
32	AA06 3137	Spring	4
33	A049 3250	Toner Tank Cover	4
34	AA14 0268	Agitator Large Shaft	4
35	A049 3300	Large Agitator - Toner Tank	4

Index No.	Part No.	Description	Q'ty per Assembly
36	AD03 7016	Small Agitator Shaft	4
37	A049 3310	Small Agitator - Toner Tank	4
38	A049 3309	Agitator Support Plate	4
39	A049 3370	Tank Unit Right Plate	1
40	A049 3371	Magnet	4
41	A049 3363	Toner Catch Pan	4
42	A049 3360	Toner Catch Pan Bracket	4
43	AA08 0058	Bushing	4
44	AB01 3184	Gear - 16Z	4
45	5205 2612	Gear - 19Z	4
46	AB01 3355	Gear - 18Z	4
47	A049 3340	Tank Unit Front Cover	1
48	A092 1395	Decal - Toner Tank	1
101	0354 0060B	Screw - M4x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0951 3005B	Philips Screw With Flat Washer M3x5	
104	0313 0050B	Philips Pan Head Screw - M3x5	
105	0443 0102W	Tapping Screw - M3 x 10 mm	
106	0951 3006B	Philips Screw with Flat Washer - M3	
107	0313 0080B	Philips Pan Head Screw - M3x8	
108	0354 0060F	Philips Pan Head Screw - M4x6	
109	0323 0080B	Philips Sunk Screw - M3x8	
110	0313 0100B	Philips Pan Head Screw - M3x10	
111	0720 0040B	Retaining Ring - M4	
112	0720 0030B	Retaining Ring - M3	
113	0951 3010B	Philips Screw With Flat Washer - M3	
114	0720 0025W	Retaining Ring - M2.5	
115	0807 2036	Washer - M3	
116	1105 0010	Nylon Clip - 6N	
117	1105 0008	Nylon Clip - 2N	

19. TRANSFER UNIT 1 (A092)




19. TRANSFER UNIT 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 3830	Transfer Corona Unit - BK,M	2
2	A049 3831	Transfer Corona Unit - Y,C	2
3	AD02 2263	Front Cover - Main Corona	4
4	A012 9001	Main Charge Corona Wire - 10pcs/set	1
5	A049 3947	Corona Wire Guide - BK,M,D	2
6	A049 3948	Corona Wire Guide - Y,C	2
7	A049 3915	Corona Wire Holder	4
8	AA06 0251	Spring	4
9	AD02 2262	Front End Block - Main Corona	4
10	A049 3945	Seal - Black	1
11	A049 2194	Seal	1
12	A049 2195	Seal	1
13	A049 3946	Seal - Blue	1
14	A049 3919	Corona Wire Hook - BK,M	2
15	A049 3920	Corona Wire Hook - Y,C	2
16	A049 3909	Transfer Corona Casing	4
17	AA14 3265	Positioning Pin - Transfer Corona	4
18	AA06 3143	Spring	4
19	A092 3850	Transfer Belt	1
20	AF02 0148	Transfer Drive Roller	1
21	A092 3970	Transfer Unit Stay - BK,M,D	1
22	A049 3977	Charge Corona Unit Stay	1
23	A092 3984	Guide Mylar - Transfer Belt	1
24	A049 3876	Left Rail - Transfer Corona Unit	2
25	AA14 3005	Stepped Screw - M4x2.5	4
26	A049 3864	Power Pack Case Cover	1
27	A049 3865	Grounding Plate	1
28	AZ32 0040	Power Pack - Transfer Unit	1
29	A092 3973	Transfer Unit Stay - Y,C	1
30	5215 2621	Snap Ring - M6	2
31	5400 3404	Stepped Screw	8
32	AD02 1062	Transfer Corona Receptacle	2
33	A049 3897	Receptacle Bracket	1
34	AB01 3414	Gear - 36Z	1
35	A049 3863	Power Pack Case	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0805 3205	Ball Bearing - 10x19x7mm	
102	0354 0060B	Screw - M4x6	
103	0725 0100E	Retaining Ring C - M10	
104	0574 0050E	Hexagon Headless Set Screw - M4x5	

20. TRANSFER UNIT 2 (A092)




20. TRANSFER UNIT 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 3884	Leaf Spring	2
2	A049 3882	Transfer Belt Pad	1
3	A049 3889	Stay - Transfer Belt Pad	1
4	A049 3977	Charge Corona Unit Stay	1
5	A092 3871	Transfer Unit Guide	1
6	A049 3876	Left Rail - Transfer Corona Unit	1
7	AA14 3005	Stepped Screw - M4x2.5	4
8	A049 3864	Power Pack Case Cover	1
9	A049 3865	Grounding Plate	1
10	AZ32 0040	Power Pack - Transfer Unit	1
11	A049 3863	Power Pack Case	1
12	A049 3965	Spacer	1
13	A092 3983	Guide Mylar - Transfer Belt	1
14	A049 3875	Right Rail - Transfer Corona Unit	1
15	A049 3887	Transport Driven Roller Pad	1
16	A049 3962	Transfer Belt Guide	1
17	AA14 0318	Transfer Unit Shaft	1
18	AF02 1019	Driven Roller - Transfer	1
19	A092 3850	Transfer Belt	1
20	5403 2075	Stepped Screw	2
21	6754 3278	Stepped Screw	1
22	5400 3404	Stepped Screw	8
23	AG05 1073	Transfer Change Lever	1
24	A049 3961	Lever Holder	1
25	5937 2162	Magnetic Clutch Collar	1
26	AA06 3043	Shaft Bracket Spring	1
27	AA13 2024	Spacer - M6	1
28	5447 2630	Spring - Registration Roller	2
29	AA08 2028	Bushing	2
30	A049 3879	Receptacle Bracket	1
31	AD02 1062	Transfer Corona Receptacle	2
32	A092 3978	Stay Mylar	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0314 0050B	Philips Pan Head Screw - M4x5	
103	0574 0040E	Hexagon Headless Set Screw - M4x4	
104	0951 3008B	Philips Screw With Flat Washer - M3	
105	0574 0050E	Hexagon Headless Set Screw - M4x5	
106	0720 0040B	Retaining Ring - M4	

21. TRANSFER UNIT 3 (A092)





21. TRANSFER UNIT 3 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 6466	Left Stay Support Plate	1
2	5403 2075	Stepped Screw	2
3	A049 6476	Pressure Arm	1
4	AA13 2113	Roller	1
5	AA14 8226	Roller Shaft	1
6	AA14 8227	Pressure Arm Shaft	1
7	5446 2569	Spring - Detent	1
8	A049 6559	Transfer Belt Unit Guide	1
9	A049 6561	Pick-off Pawl Bracket	3
10	A049 6560	Pick-off Pawl	3
11	5216 3133	Drive Spring - Toner End	3
12	5413 1882	Stepped Screw	2
13	AA06 0158	Spring - Pick-up Roller Arm	1
14	A049 6553	Pick-off Pawl Link Plate	1
15	AA14 0337	Adjusting Cam Shaft	1
16	A049 6552	Middle Stay	1
17	A049 6467	Adjusting Shaft Bracket	1
18	5053 0447	Bushing - 6mm	2
19	5447 2681	Snap Ring	1
20	AA14 8225	Positioning Pin	1
21	A049 3935	Discharge Corona Unit Rail	1
22	AA00 1108	Electrical Power Decal	1
23	A092 1397	Decal - Misfeed Removal - Transfer	1
24	A049 6507	Transfer Belt Unit Cover	1
25	A092 1396	Decal - Back-up	1
26	A049 6551	Pick-off Pawl Solenoid	1
27	AZ31 0031	AC Power Pack - Discharge	1
28	AD02 1062	Transfer Corona Receptacle	1
29	AA14 3262	Positioning Pin	1
30	A049 3833	Discharge Corona Unit	1
31	A049 6501	Stay Cover - Belt Unit	1
32	AA06 3143	Spring	1
33	AA14 3265	Positioning Pin - Transfer Corona	1
34	A049 3915	Corona Wire Holder	1
35	A049 3947	Corona Wire Guide - BK,M,D	1

Index No.	Part No.	Description	Q'ty per Assembly
36	A092 9500	Charge Corona Wire - 10pcs/set	1
37	AA06 0251	Spring	1
38	AD02 2263	Front Cover - Main Corona	1
39	AD02 2262	Front End Block - Main Corona	1
40	A049 3939	Discharge Corona Unit Casing	1
41	A049 3919	Corona Wire Hook - BK,M	1
42	A049 6464	Left Stay - Belt Unit	1
43	A049 6554	Solenoid Bracket - Pick-off Pawl	1
44	A049 6556	Pick-off Pawl Lever	1
101	0354 0060B	Screw - M4x6	
102	0720 0050B	Retaining Ring - M5	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	0720 0030B	Retaining Ring - M3	
106	0354 0060F	Philips Pan Head Screw - M4x6	
107	1106 0310	Bushing	
108	1105 0199	Clamp	
109	1105 0291	Wire Saddle	
110	1105 0196	Harness Clamp	

22. TRANSFER UNIT 4 (A092)




22. TRANSFER UNIT 4 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A092 5609	Transport Belt Unit Harness	1
2	A049 6504	Belt Unit Connector Cover	1
3	A049 3891	Transport Unit Stopper	1
4	A049 3892	Positioning Plate - Transport Unit	1
5	AA08 0002	Bushing - 10x14x4.5	4
6	AA14 3262	Positioning Pin	1
7	A049 6487	Lift Shaft Lock	1
8	AA14 0283	Transfer Belt Lift Shaft	1
9	A049 6484	Lift Shaft Bracket	2
10	A049 6492	Transfer Belt Link	2
11	AA14 0280	Pressure Arm	1
12	AA08 2031	Bushing	2
13	AA13 2114	Roller	2
14	AA06 3166	Spring	2
15	A049 6489	Transfer Belt Lift Plate	1
16	A049 3718	Pressure Plate Link	1
17	AA14 0265	Transfer Belt Drive Shaft	1
18	AA14 0281	Pressure Arm Shaft	1
19	AA13 2113	Roller	1
20	AA14 8226	Roller Shaft	1
21	AA14 8227	Pressure Arm Shaft	1
22	A049 6476	Pressure Arm	1
23	5446 2569	Spring - Detent	1
24	5403 2075	Stepped Screw	2
25	5304 1639	Bushing - 8mm	2
26	A049 3719	Cleaning Unit Pressure Plate	1
27	AA14 5113	Link Shaft	1
28	AA14 5112	Pressure Shaft - Belt Cleaning Unit	1
29	A049 6474	Right Support Plate Stay	1
30	AG05 1069	Transfer Belt Unit Lever	1
31	A049 6460	Right Stay - Belt Unit	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0720 0080B	Retaining Ring - M8	
103	0725 0100E	Retaining Ring C - M10	
104	0720 0050B	Retaining Ring - M5	
105	0720 0040B	Retaining Ring - M4	
106	0720 0060B	Retaining Ring - M6	
107	0314 0060B	Philips Pan Head Screw - M4x6	
108	0354 0200W	Screw - M4x20	
109	1105 0291	Wire Saddle	

23. TRANSFER BELT CLEANING (A092)




23. TRANSFER BELT CLEANING (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	AA14 0265	Transfer Belt Drive Shaft	1
2	5447 2681	Snap Ring	2
3	AB01 3214	Gear - 20T	3
4	A049 3663	Front Holder - Cleaning Brush	1
5	AB01 3179	Gear - 14Z	1
6	AD04 2013	Cleaning Brush - Transfer Belt	1
7	A049 3661	Bushing - Cleaning Brush	2
8	A049 3622	Cleaning Blade - Transfer Belt	1
9	A049 3646	Front Seal	1
10	A049 3673	Cleaning Blade Holder	1
11	5446 3648	Stepped Screw - M4	1
12	A049 3656	Rear Seal	1
13	AD04 3021	Collection Auger - Belt Cleaning	1
14	A049 9012	Entrance Seal - Belt Cleaning	1
15	AA15 1425	Seal - 7x10x6	2
16	AA15 1426	Seal - 3x4x338	1
17	A049 3621	Casing - Transfer Belt	1
18	A049 3723	Cleaning Unit Cover	1
19	5053 0447	Bushing - 6mm	2
20	A049 3707	Front Bracket - Belt Cleaning	1
21	A049 3632	Front Bearing - Cleaning Brush	1
22	AA06 0214	Pressure Spring	2
23	A049 3662	Pressure Plate - Cleaning Blade	2
24	AA15 1400	Seal - 3x3x1	2
25	A049 3641	Front Side Plate	1
26	A049 3155	Joint - Toner Supply	1
27	A049 3666	Rear Holder - Cleaning Brush	1
28	AA06 3135	Spring	1
29	AA13 0037	Bushing	1
30	A049 3652	Rear Bearing - Cleaning Brush	1
31	A049 3710	Rear Bracket - Belt Cleaning	1
32	A049 3649	Rear Side Plate	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0354 0100B	Screw - M4x10	
103	0720 0040B	Retaining Ring - M4	
104	0353 0060B	Screw - M3x6	
105	0313 0060B	Philips Pan Head Screw - M3x6	
106	0354 0060F	Philips Pan Head Screw - M4x6	
107	0807 7088	Spacer - 17.2x23x0.1	

24. TRANSFER / DEVELOPMENT DRIVE SECTION (A092)




24. TRANSFER / DEVELOPMENT DRIVE SECTION (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	AB01 1075	Worm Wheel - 42Z	1
2	A049 1157	Oil Seal	1
3	5204 4505	Collar	1
4	A049 1159	Oil Pan Top Cover	1
5	AA14 0109	Transfer Drive Shaft	1
6	A049 1151	Drive Shaft Holder	1
7	5206 2687	Stud Screw - M3	2
8	AA06 3145	Spring	1
9	AB01 3177	Gear - 35Z	1
10	AB03 0180	Pulley - 56Z	1
11	AB01 1073	Worm Gear	1
12	A049 1156	Oil Pan Rear Cover	1
13	A049 1158	Oil Pan	1
14	AA04 3085	Timing Belt - 100S3M384	1
15	AB03 0192	Pulley - 35Z	1
16	AA14 5109	Fusing Unit Drive Shaft	1
17	AA06 0212	Tension Spring	1
18	A049 6686	Belt Tightener	1
19	AB03 0194	Pulley - 20Z	1
20	AB03 0188	Pulley - 25Z	1
21	AB01 3402	Gear - 21Z	1
22	A049 1195	Fusing Unit Drive Bracket	1
23	A049 6681	Fusing Unit Relay Shaft	1
24	AB03 0190	Pulley - 47Z	1
25	G003 4068	Spring	1
26	AB03 0184	Pulley - 42Z	1
27	A049 1178	Tightener Bracket Lever	1
28	AA04 3087	Timing Belt - 40S2M440	1
29	AB03 0182	Pulley - 28Z	1
30	A049 1176	Transfer Belt Motor Bracket	1
31	AX06 0026	Motor - DC24V	1
32	A049 1179	Tightner Bracket Shaft	1
33	5400 3404	Stepped Screw	1
34	5413 1882	Stepped Screw	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0315 0080B	Philips Pan Head Screw - M5x8	
102	0574 0040E	Hexagon Headless Set Screw - M4x4	
103	0593 0060B	Hexagonal Bolt - M3x6	
104	0951 4008B	Philips Screw With Flat Washer - M4	
105	0720 0060B	Retaining Ring - M6	
106	0720 0050E	Retaining Ring - M5	
107	0720 0060E	Retaining Ring - M6	
108	0720 0080B	Retaining Ring - M8	
109	0720 0040B	Retaining Ring - M4	
110	0741 3008	Ball Bearing - 8x22	
111	0742 3010	Ball Bearing - 10x26	
112	0354 0060B	Screw - M4x6	
113	0574 0050E	Hexagon Headless Set Screw - M4x5	

25. FUSING SECTION 1 (A092)




25. FUSING SECTION 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 4002	Fusing Unit	1
1	5840 1632	Stepped Screw	4
2	A092 1392	Decal - Paper Exit	1
3	AA00 1160	Decal - B4	1
4	AA00 0015	Decal - High Temperature	1
5	A092 4024	Upper Exit Cover	1
6	A049 4226	Lock Lever - Fusing Exit	1
7	5400 3404	Stepped Screw	4
8	A049 4225	Lock Lever Bracket	1
9	A049 4201	Fusing Exit Frame	1
10	A049 4227	Lock Lever Spring	1
11	AA06 0246	Spring	1
12	AA06 3099	Spring - Exit	2
13	5216 4145	Thermofuse Decal	1
14	5205 2697	Bushing - Upper Registration Roller	2
15	5209 4470	Upper Exit Roller	1
16	A049 4221	Front Lock Arm	1
17	AA14 0276	Paper Exit Upper Lock Shaft	1
18	A049 4223	Rear Lock Arm	1
19	AA06 0189	Spring - Stripper Pawl Plate	1
20	A049 4210	Guide Plate - Hot Roller Stripper	1
21	AA14 0275	Pick-off Pawl Shaft	1
22	5205 4305	Spring - Hot Roller Stripper	6
23	A030 9010	Hot Roller Stripper	1
24	A049 4230	Upper Guide Plate	1
25	AA00 1140	Decal - B2	1
26	A049 4261	Front Fusing Cover	1
27	AG05 0042	Fusing Unit Knob	1
28	AA14 0274	Upper Drive Shaft - Paper Exit	1
29	A049 4195	Fusing Entrance Cover	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0720 0050B	Retaining Ring - M5	
103	0720 0030B	Retaining Ring - M3	

26. FUSING SECTION 2 (A092)




26. FUSING SECTION 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	5415 4125	Nylon Clip	3
2	A092 5762	Thermofuse - 169;C	1
3	A049 4161	Upper Stay - Fusing Unit	1
4	A049 4165	Silicone Oil Nozzle	1
5	AA18 0008	Oil Tube - 320mm	1
6	A049 4159	Oil Supply Bracket	1
7	5447 4241	Tube Clamp	2
8	5415 4310	Valve - Oil Pump	2
9	AA18 0035	Sleeve - Oil Pump	1
10	A049 4127	Fusing Unit Guide Plate	1
11	A049 4155	Leaf Spring - Oil End Sensor	1
12	AA08 0016	Bushing - 5x7x16	1
13	A030 4133	Oil Pump Lever	1
14	AA06 6079	Spring - Oil Pump Lever	1
15	AA03 6009	Joint Cap	1
16	AA03 6005	Oil Bottle Cap	1
17	AA03 1005	Oil Tank	1
18	AA18 0031	Oil Supply Tube	1
19	AB01 7038	Gear - 32T	1
20	A049 4153	Support Plate - Front Fusing Cover	1
21	A049 4190	Support Plate - Oil Supply Pad	2
22	A049 4177	Pressure Plate - Oil Supply Pad	1
23	A049 4176	Oil Supply Pad Bracket	1
24	AE04 5011	Oil Supply Felt	1
25	AA06 0244	Spring	2
26	5215 4116	Oil Blade Holder	1
27	AE04 3003	Oil Blade	1
28	A007 4195	Oil Sump	1
29	5215 5250	Thermistor	1
30	5203 4146	Thermistor Spring	1
31	A049 4145	Thermistor Housing Frame	1
32	A092 5618	Fusing Unit Harness	1
33	A049 4128	Connector Bracket	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0313 0060B	Philips Pan Head Screw - M3x6	
103	0354 0120B	Screw - M4x12	
104	0951 3005	Philips Screw With Flat Washer - M3	
105	0951 4008F	Screw - M4x8	
106	0720 0040B	Retaining Ring - M4	

27. FUSING SECTION 3 (A092)




27. FUSING SECTION 3 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A092 4480	Fusing Exit Cover	1
2	5840 1632	Stepped Screw	2
3	AF02 0144	Lower Exit Roller	1
4	5205 5251	LED Sensor Type - T	1
5	5442 4495	Slip Clutch	1
6	AB01 3412	Gear - 19Z	1
7	AB01 3062	Gear - 19T	1
8	A006 4263	Paper Exit Shutter	1
9	AA11 1007	Sleeve - Oil Pump	1
10	A049 4450	Fusing Exit Frame	1
11	AA14 3219	Stepped Screw	1
12	5447 2681	Snap Ring	1
13	A049 4470	Lower Guide Plate Bracket	1
14	A092 4135	Roller Support Lever	2
15	A049 4130	Pressure Lever	2
16	A092 4139	Pressure Shaft	2
17	AA06 3141	Spring	2
18	A049 4125	Oil Pan	1
19	A049 4105	Oil Supply Support Bracket	1
20	A049 4471	Lower Exit Guide Plate	1
21	A092 4138	Pressure Shaft Knob	2

Index No.	Part No.	Description	Q'ty per Assembly
101	0720 0050B	Retaining Ring - M5	
102	0720 0040B	Retaining Ring - M4	
103	0710 0050	Hexagonal Nut - M5	
104	0720 0060B	Retaining Ring - M6	
105	0354 0060B	Screw - M4x6	
106	0805 3385	Bushing - 6mm	
107	0354 0080B	Screw - M4x8	

28. FUSING SECTION 4 (A092)




28. FUSING SECTION 4 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 4094	Left Rail Edging	1
2	A049 4090	Left Fusing Rail	1
3	5419 5714	Stepped Screw - M4	2
4	AX43 0012	Heater - 230V 550W	1
4	AX43 0011	Heater - 115V 550W	1
5	AE01 0003	Hot Roller	1
6	AA14 0168	Pressure Roller Shaft	1
7	AE03 0008	Ball Bearing - 12x28x8mm	2
8	AE02 0018	Pressure Roller	1
9	AA14 0272	Fusing Unit Drive Shaft	1
10	A049 4140	Lower Entrance Guide	1
11	5400 3404	Stepped Screw	2
12	A049 4080	Right Fusing Rail	1
13	A049 4106	Front Heater Holder	1
14	A030 4064	Spacer - Hot Roller	2
15	AE03 0007	Ball Bearing-25x47x12mm	2
16	AE03 2007	Bushing - 20x25x12mm	2
17	AB01 3363	Gear - 16Z	1
18	AE03 1006	Collar	1
19	5053 0223	Bushing - 8mm	1
20	A049 4115	Rear Holder Plate	1
21	AB01 3267	Gear - 17T	1
22	A049 4120	Rear Heater Holder	1
23	AB01 3407	Gear - 45Z	1
24	AB01 3409	Gear - 20Z	1
25	AB01 3408	Gear - 27Z	1
26	AA06 3140	Spring	1
27	A049 4100	Front Fusing Bracket	1
28	A049 4110	Rear Fusing Bracket	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0354 0080B	Screw - M4x8	
103	0314 0080B	Philips Pan Head Screw - M4x8	
104	0725 0120E	Retaining Ring C - M12	
105	0725 0200E	Retaining Ring C - M20	
106	0720 0060B	Retaining Ring - M6	
107	0720 0040B	Retaining Ring - M4	
108	0355 0160B	Screw - M5x16	
109	0805 3104	Ball Bearing - 8x22x7mm	

29. DRUM CLEANING UNIT (A092)




29. DRUM CLEANING UNIT (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 3501	Cleaning Unit - BK,M,Y	3
*	A092 3502	Cleaning Unit - C	1
1	AA15 2153	Seal - 28x212x0.2	3
2	A092 3592	Shielding Plate - BK,M,Y	3
3	A092 3595	Shielding Plate - C	1
4	A049 3580	Cleaning Unit Casing	4
5	AA15 2186	Seal - 27x330x0.2	4
6	AA15 1423	Seal - 6x6x1	8
7	AA15 1424	Seal - 6x5x336	4
8	A049 9011	Cleaning Entrance Seal	4
9	A049 3590	Cleaning Blade Lever	4
10	AA15 1418	Front Holder Seal	4
11	AA15 1420	Seal - 8.5x15x2	4
12	AA06 3131	Spring	8
13	A049 3587	Cleaning Blade Holder	4
14	AA15 1419	Rear Holder Seal	4
15	AA15 1421	Seal - 8.5x15x2	4
16	5446 3648	Stepped Screw - M4	4
17	AD04 1014	Cleaning Blade	4
18	AD04 2014	Cleaning Brush	4
19	AD04 3018	Toner Collection Auger - Cleaning	4
20	A049 3560	Front Plate - Cleaning	4
21	5447 3922	Gear - 16T	8
22	A049 3565	Front Drive Shaft - Cleaning Brush	4
23	AA15 2069	Seal - 12x22x5	4
24	A049 3569	Rear Plate - Cleaning	4
25	A049 3604	Grounding Plate	4
26	AA06 3130	Spring	4
27	A049 3576	Toner Receiving Pipe	4
28	A049 3578	Joint - Cleaning Brush	4
29	A049 3579	Rear Holder - Cleaning Brush	4
30	A049 3574	Rear Drive Shaft - Cleaning Brush	4

Index No.	Part No.	Description	Q'ty per Assembly
101	0433 0040B	Screw - M3x4	
102	0433 0080B	Philips Screw - M3x8	
103	0433 0060B	Philips Tapping Screw - M3x6	
104	0433 0100B	Philips Tapping Screw - M3X10	
105	0720 0040B	Retaining Ring - M4	

30. TONER COLLECTION SECTION (A092)




30. TONER COLLECTION SECTION (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 6855	Roller Bracket	1
2	AA14 5111	Roller Shaft	1
3	A049 6766	Roller	1
4	A049 6756	Sensor Bracket	1
5	AB01 3178	Gear - 34Z	1
6	5053 0447	Bushing - 6mm	4
7	A049 6777	Gear Bracket - Belt Cleaning	1
8	AA14 5110	Small Drive Shaft - Belt Cleaning	1
9	5219 3712	Compression Spring	1
10	A049 1118	Small Toner Supply Cam	1
11	A049 1119	Large Toner Supply Cam	1
12	AA04 1008	Belt	1
13	AB03 3011	Pulley	1
14	AB01 7178	Gear - 38Z	1
15	AB01 7084	Gear - 30/32Z	1
16	5360 2575	Gear - 28Z	1
17	A049 6767	Toner Collection Pipe Bracket	1
18	5446 1817	Lens Guide Roller	2
19	5446 4577	Spring - Turn Plate	1
20	A049 6860	Pipe Knock Lever	1
21	5203 1852	Bushing - 6x8x4mm	2
22	AA17 4005	Noizeproof Padding	1
23	5203 1159	Pressure Spring	1
24	A049 6769	Joint - Shield	1
25	A049 6739	Toner Collection Pipe	1
26	AA15 1090	Seal - 13x34x8	1
27	AD04 3020	Toner Collection Auger - Toner Bott	1
28	AB03 2022	Pulley	1
29	A049 6738	Bearing - Toner Transport Coil	2
30	AA03 6009	Joint Cap	1
31	A049 6735	Joint - Belt Cleaning	1
32	AA13 0035	Joint Pipe - Large	3
33	A049 6733	Joint - Cleaning	4
34	AA13 0036	Joint Pipe - Small	2
35	A049 6732	Joint - Collection Bottle	1

Index No.	Part No.	Description	Q'ty per Assembly
36	A049 6737	Toner Coil Sensor Actuator	1
37	AD04 3019	Toner Collection Auger	1
38	A049 6731	Toner Collection Joint Bracket	1
39	5216 5245	Photointerruptor - IL-G-3P-S3T2-E	1
40	A049 3725	Stud - Base	2
41	A049 3727	Knock Pin Base	1
42	A049 3737	Clamp Bracket	1
43	A049 3733	Knock Arm	3
44	A049 3732	Knock Arm Pin	3
45	A049 3730	Knock Pin Shaft	1
46	A458 2479	Lock Pin Spring	3
47	A049 3734	Cam Frower Arm	1
48	A049 3739	Gear - 46Z	1
49	A049 3741	Connector Cover	1
101	0354 0060B	Screw - M4x6	
102	0720 0040B	Retaining Ring - M4	
103	0720 0060B	Retaining Ring - M6	
104	0720 0030B	Retaining Ring - M3	
105	0313 0060B	Philips Pan Head Screw - M3x6	
106	1105 0316	Clamp	
107	0701 0040W	Flat Washer - M4	
108	0353 0060B	Screw - M3x6	

31. DRIVE SECTION 1 (A092)




31. DRIVE SECTION 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	AB03 0176	Idler - 28	2
2	A049 1187	Belt Tightener	1
3	AA04 3084	Timing Belt - 100S3M699	1
4	A049 1184	Motor Connector Bracket	1
5	A049 1191	Belt Tightener	1
6	A049 1189	Spring Anchor	1
7	AA06 0184	Tension Spring	1
8	AA06 0249	Spring	1
9	A049 1182	Main Motor Bracket	1
10	AX06 0025	DC Motor - 66W	1
11	5205 3863	Leaf Spring	2
12	A049 2341	ID Sensor Duct	4
13	A030 3389	Color Development Motor	1
14	AB01 0022	Gear - 96Z	1
15	5053 0447	Bushing - 6mm	1
16	A049 3350	Toner Collection Motor Bracket	1
17	AA14 0278	Toner Collection Drive Shaft	1
18	5304 1639	Bushing - 8mm	1
19	AA06 3136	Spring	1
20	AB01 3401	Gear - 22Z	1
21	A049 3232	Rear Holder - Development Unit	1
22	A049 4495	Slide Lock Arm Bracket	1
23	5413 2596	Stud - Paper Feed Unit	4
24	AB03 0186	Pulley - 30Z	1
25	A049 6631	Development Rear Cover	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0951 5012B	Philips Pan Head Screw - M5x12	
104	0965 4008B	Tapping Screw - M4 x 8	
105	0313 0060B	Philips Pan Head Screw - M3x6	
106	0720 0060B	Retaining Ring - M6	
107	0720 0040B	Retaining Ring - M4	
108	0574 0040E	Hexagon Headless Set Screw - M4x4	
109	0930 0406A	Parallel Key	
110	1106 0430	Bushing - 13mm	
111	1105 0291	Wire Saddle	
112	1105 0120	Wire Clip	

32. DRIVE SECTION 2 (A092)




32. DRIVE SECTION 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 1166	OPC Drum Motor Bracket	1
2	AX06 0026	Motor - DC24V	1
3	A049 1148	Seal - Oil Pan Rear Cover	4
4	AB03 0182	Pulley - 28Z	1
5	AA04 3086	Timing Belt - 40S2M440	1
6	G003 4068	Spring	1
7	AB03 0184	Pulley - 42Z	1
8	A049 1170	Tightener Bracket	1
9	AB03 0180	Pulley - 56Z	1
10	AA14 0108	Worm Shaft	1
11	A049 1146	Oil Pan Rear Cover	4
12	A049 1149	Oil Pan Top Cover	4
13	A049 1145	Oil Pan	4
14	A049 1141	Worm Gear Holder	5
15	AB01 1074	Worm Wheel	4
16	5206 2687	Stud Screw - M3	10
17	A049 6675	Rear Cover Shielding Plate	1
18	A049 6679	Shielding Plate Bracket	1
19	A049 1136	Worm Gear Support Bracket	1
20	5434 7916	High Voltage Decal	4
21	AA04 3083	Timing Belt - 150S3M1260	1
22	5053 0449	Collar - Shaft Fixing	1
23	AB01 1072	Worm Gear	4

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0574 0040E	Hexagon Headless Set Screw - M4x4	
103	0951 4008B	Philips Screw With Flat Washer - M4	
104	0314 0080B	Philips Pan Head Screw - M4x8	
105	0712 0080Z	Hexagonal Nut - M8	
106	0593 0120W	Hexagon Headless Set Screw - 3x12	
107	0720 0040B	Retaining Ring - M4	
108	0575 0050E	Hexagon Headless Set Screw - M5x5	
109	1106 0458	Bushing - 9.9mm	
110	1105 0278	Harness Clamp	

33. DRIVE SECTION 3 (A092)



33. DRIVE SECTION 3 (A092)


Index No.	Part No.	Description	Q'ty per Assembly
1	AA00 1108	Electrical Power Decal	4
2	A049 2451	Knob - Drum Unit Cover	2
3	5434 7916	High Voltage Decal	1
4	A049 2453	Drum Unit Cover	1
5	A049 2443	Drum Shaft Alignment Plate	4
6	A049 2445	Leaf Spring	4
7	A049 2444	Drum Shaft Holder	4
8	A092 2446	Drum Unit Cover Handle	2
9	A049 2442	Front Side Plate	1
10	5447 2630	Spring - Registration Roller	3
11	AA16 1065	Cushion - 9x16x1.5	4
12	A092 2424	Drum Shaft Knob	4
13	5447 4982	Decal - Open	4
14	A049 2422	Drum Stay	4
15	5211 2259	Spacer - M20 X 0.1	4
16	AA08 0080	Bushing	4
17	A049 2403	Front Drum Frange	4
18	A092 9502	OPC Drum	4
19	A049 2405	Drum Guide	4
20	AD01 5009	Drum Shaft	4
21	AD01 4019	Drum Flange	4
22	A049 3231	Front Holder - Development Unit	4
23	AB01 3401	Gear - 22Z	8
24	AA06 3136	Spring	4
25	A049 1119	Large Toner Supply Cam	4
26	A049 1118	Small Toner Supply Cam	4
27	5219 3712	Compression Spring	4
28	A049 1104	Drum Shaft Support Bracket	4
29	A049 3578	Joint - Cleaning Brush	4
30	AA06 0291	Spring	4
31	AA14 3204	Magnetic Clutch Bracket Stay	8
32	AB01 3175	Gear - 38Z	4
33	AA14 8197	Magnetic Clutch Shaft -Toner Supply	4
34	AA04 3082	Timing Belt - 60S2M250	4
35	AX20 0040	Magnetic Clutch	4

Index No.	Part No.	Description	Q'ty per Assembly
36	A049 1122	Toner Supply Clutch Bracket	4
37	A049 1113	Belt Tightener	4
38	AA14 3332	Worm Shaft Bracket	4
39	AA14 3243	Stud	4
40	AB01 7074	Gear - 18Z	4
41	AA14 8196	Toner Supply Shaft	4
42	AB01 3174	Gear - 24Z	8
43	AA14 8198	Cleaning Unit Drive Shaft	4
44	AB01 3176	Gear - 50Z	4
45	A049 1126	Retaining Ring C - M37.5	4
46	A049 1144	Drum Shaft Collar	4
47	AA15 1451	Seal - 5x56x2	4
48	AA14 3239	Stud	4
49	AB03 0176	Idler - 28	4
50	5219 3633	Collar	4
51	AA14 3240	Stud	4
52	AB01 7146	Gear - 28/26Z	4
53	AA04 3083	Timing Belt - 150S3M1260	1
54	AA14 0264	Development Drive Shaft	4
55	AA14 3241	Stud	4
56	AB03 0177	Pulley	4
57	AA06 0379	Spring	4

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060F	Philips Pan Head Screw - M4x6	
102	0583 0141B	Hexagonal Head Bolt - M3x14	
103	0710 0030B	Hexagon Nut - M3	
104	0740 3906	Bearing	
105	0354 0060B	Screw - M4x6	
106	0725 0190E	Retaining Ring C - M19	
107	0314 0080B	Philips Pan Head Screw - M4x8	
108	0313 0060B	Philips Pan Head Screw - M3x6	
109	0720 0040B	Retaining Ring - M4	
110	0725 0120E	Retaining Ring C - M12	
111	0720 0050B	Retaining Ring - M5	
112	0720 0060B	Retaining Ring - M6	
113	0951 5018B	Screw - M5x18	
114	0741 3906	Bushing - M6	
115	0574 0040E	Hexagon Headless Set Screw - M4x4	
116	0951 4008F	Screw - M4x8	
117	1105 0229	Clamp	

Index No.	Part No.	Description	Q'ty per Assembly

34. FRAME SECTION 1 (A092)




34. FRAME SECTION 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 6614	Operation Panel Support Plate	2
2	A049 6611	Upper Front Stay	1
3	AA00 0042	Counter Decal - Color	1
4	AA00 0043	Counter Decal	1
5	5446 5832	Connector Guide Pin	2
6	A049 1094	Front Right Support Plate	1
7	A049 3261	Slide Rail Bracket	2
8	AA07 0014	Slide Rail	2
9	A049 3204	Development Guide Rail	4
10	A049 3273	Dumper Holder	2
11	A049 3262	Left Slide Rail Spring	1
12	A049 3254	Slide Rail Left Stay	1
13	A049 3324	Connector Cover	1
14	A049 3274	Connector Bracket	1
15	A420 3232	Connector Spring	2
16	A049 5605	Relay Harness - Toner Supply	1
17	A049 1095	Front Support Plate	1
18	A049 3263	Right Slide Rail Spring	1
19	A049 2197	Grounding Plate	4
20	A049 3279	Dumper	2
21	A049 3253	Slide Rail Right Stay	1
22	A049 1088	Left Support Stay - Laser Unit	1
23	AG07 0004	Magnet Catch Ass'y	1
24	A049 1097	PCB Cover	1
25	5205 3863	Leaf Spring	1
26	A049 1688	Rear Scanner Unit Guide	1
27	A049 1722	Front Scanner Unit Guide	1
28	A049 6636	Rear Cover - Paper Feed Unit	1
29	A049 1086	Right Support Stay - Laser Unit	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0354 0060F	Philips Pan Head Screw - M4x6	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0414 0082B	Binding Self Tapping Screw - M4x8	
105	0951 3006B	Philips Screw with Flat Washer - M3	
106	0951 4008B	Philips Screw With Flat Washer - M4	
107	0803 0020	Stepped Screw	
108	1105 0316	Clamp	
109	1105 0009	Nylon Clip - 5N	

35. FRAME SECTION 2 (A092)




35. FRAME SECTION 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 6645	Left Stay - Transfer Slide Rail	1
2	AA07 0015	Slide Rail	2
3	A049 6516	Left Slide Rail Guide	1
4	5403 2320	Guide Pin - Drum Stay	2
5	AG05 1063	Paper Feed Unit Lever	1
6	AA08 0002	Bushing - 10x14x4.5	2
7	A049 6515	Slide Rail Guide Bracket	1
8	AA07 0013	Slide Rail	2
9	A049 2571	Front Slide Rail Guide	1
10	5205 3863	Leaf Spring	2
11	A049 2569	Front Support Bracket	1
12	A049 2576	Paper Feed Bottom Plate	1
13	A049 2658	Stopper Arm	1
14	A049 2653	Front Lock Arm	1
15	A007 2883	Roller Plate Release Roller	1
16	AA06 0241	Spring	1
17	A049 2662	Paper Feed Unit Guide Plate	1
18	A049 2652	Paper Feed Unit Lock Shaft	1
19	A049 2675	Rear Lock Arm	1
20	A049 2573	Rear Support Bracket	1
21	5446 5832	Connector Guide Pin	2
22	A049 2674	Paper Feed Lock Cover	1
23	A049 2575	Rear Slide Rail Guide	1
24	A049 1098	Upper Cover - Power Supply Unit	1
25	AA06 6099	Spring	1
26	A049 2660	Stopper Plate Bracket	1
26	A049 2656	Stopper Plate	1
27	5413 1882	Stepped Screw	2
28	A049 6513	Right Slide Rail Guide	1
29	5208 2675	Spring	2
30	5208 2454	Stepped Screw - M4	2
31	A049 5840	Paper Feed Unit Connector Bracket	1
32	A420 3232	Connector Spring	2

Index No.	Part No.	Description	Q'ty per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0354 0060B	Screw - M4x6	
103	0314 0100B	Philips Pan Head Screw - M4x10	
104	0314 0040W	Philips Pan Head Screw - M4x4	
105	0725 0100E	Retaining Ring C - M10	
106	0720 0050B	Retaining Ring - M5	
107	0720 0030E	Retaining Ring - M3	
108	1105 0291	Wire Saddle	
109	1105 0278	Harness Clamp	
110	1106 0430	Bushing - 13mm	
111	1105 0291	Wire Saddle	
112	1105 0016	Nylon Clip - 4N	

36. OZONE FILTER (A092)




36. OZONE FILTER (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 6915	Shutter	1
2	A049 6918	Ozone Unit Rail	2
3	A049 6917	Shutter Frame	1
4	A049 6905	Upper Cover - Ozone Filter Case	1
5	A049 6909	Shutter Solenoid	1
6	5171 1605	Pressure Spring	1
7	AA15 1460	Seal - 130x130x6	2
8	AA16 1058	Cushion - 4x15x3.2	2
9	A049 6908	Rear Side Plate	1
10	AA14 3037	Development Cover Screw	2
11	A049 5613	Exhaust Fan Harness	1
12	AX05 0008	Transport Fan Motor	2
13	A049 6924	Ozone Neutrizer Casing	1
14	AA01 0024	Ozone Filter	2
15	A049 6932	Filter Left Casing	1
16	AA01 2037	Filter	1
17	A049 6931	Filter Right Casing	1
18	A049 6907	Front Side Plate	1
19	A049 6920	Filter Bracket	1
20	A049 6901	Ozone Neutrizer Casing	1
21	A049 1677	Front Rail Bracket	1
22	A049 6651	Front Stay - Scanner Slide Rail	1
23	AA07 0015	Slide Rail	2
24	5215 4497	Exit Antistatic Brush	1
25	A092 4490	Paper Exit Frame	1
26	AA14 8219	Adjusting Pin	6
27	A049 6653	Rear Stay - Scanner Slide Rail	1
28	A049 1680	Rear Slide Rail Bracket	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0314 0450B	Philips Pan Head Screw - M4x45	
103	0314 0040W	Philips Pan Head Screw - M4x4	
104	0434 0060B	Philips Tapping Screw - M4x6	
105	1105 0008	Nylon Clip - 2N	

37. ELECTRICAL SECTION 1 (A092)




37. ELECTRICAL SECTION 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 5877	Front Support Plate - PCB Guide	1
2	A049 5876	PCB Guide Bracket	2
3	A049 6610	Key Counter Cover	1
4	A049 5880	PCB Support Plate Bracket	2
5	A049 5674	Optical Fiber Cable - Cyan	1
6	A049 5673	Optical Fiber Cable - Yellow	1
7	A049 5191	IPU Memory Harness	1
8	A049 5666	Laser Unit Data Harness	1
9	A049 5190	IPU Harness - 2	1
10	A049 5314	Scanner Regist Harness	1
11	A049 5630	Laser Unit Optical Fiber	1
12	A049 5311	Scanner Relay Optical Fiber	1
13	A049 5671	Optical Fiber Cable - Black	1
14	A049 5312	Scanner Harness - I/P	1
15	A049 5631	Operation Panel Optical Fiber	1
16	A049 5464	Laser Unit Control Board - BK,Y	1
17	A049 5465	Laser Unit Control Board - M,C	1
18	A049 5130	IPU Memory Board	1
19	A049 5140	IPU Board 1.5	1
20	A049 5100	IPU Board 1	1
21	A049 5404	System Control Board	1
22	A049 5406	Laser Unit Mother Board	1
23	A049 5870	Mother Board Bracket - Laser Unit	1
24	A049 6623	Right Cover - IPU Board	1
25	A049 6621	Upper Right Stay	1
26	A092 5882	PCB Cover	1
27	A049 5672	Optical Fiber Cable - Magenta	1
28	5415 2904	Stopper Pin	1
29	A049 6938	Inner Cover - Ozone Unit	1
30	A049 5160	IPU Board 2	1
31	A049 5879	Rear Support Plate - PCB Guide	1
32	A049 5192	IPU 1.5 Harness	1
33	A049 6661	Main Switch Cover	1
34	AX31 0006	Counter	1
35	AX31 0007	Counter	1

Index No.	Part No.	Description	Q'ty per Assembly
36	AX05 0008	Transport Fan Motor	1
101	0354 0060B	Screw - M4x6	
102	0354 0060F	Philips Pan Head Screw - M4x6	
103	0314 0450B	Philips Pan Head Screw - M4x45	
104	1005 0785	PCB Guide Rail	
105	1607 0332	Ferrite Core	
106	1105 0351	Clamp	
107	1204 1545	Main Switch	

38. ELECTRICAL SECTION 2 (A092)




38. ELECTRICAL SECTION 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	AA15 1465	Seal - 145x164x6	1
2	AA01 0025	Ozone Filter	1
3	A049 6936	Ozone Filter Stopper	1
4	A049 6923	Ozone Filter Casing	1
5	AX05 0008	Transport Fan Motor	1
6	A049 6617	Rear Exhaust Fan Bracket	1
7	A049 2311	Charge Fan Duct	4
8	A049 5642	High Voltage Cable - Charge Grid	4
9	A049 5641	High Voltage Cable - Main Charge	4
10	AZ32 0039	Power Pack - Development	4
11	A049 5611	Charging Fan Harness	1
12	AX04 0006	Blower Fan	1
13	AX04 0004	Cooling Fan Motor	4
14	A049 6626	Rear Stay	1
15	A049 5802	AC Power Supply Bracket	1
16	5205 3863	Leaf Spring	2
17	AZ31 0013	AC Power Pack - Discharge	1
18	A049 2325	Filter Holder	2
19	A049 2324	Filter - 585x76	1
20	A049 2322	Cooling Fan Bracket	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0314 0450B	Philips Pan Head Screw - M4x45	
103	0314 0300B	Philips Pan Head Screw - M4x30	
104	0314 0140B	Philips Pan Head Screw - M4x14	
105	0313 0350B	Philips Pan Head Screw - M3x35	
106	1105 0229	Clamp	
107	1105 0316	Clamp	
108	1105 0292	Wire Saddle	

39. ELECTRICAL SECTION 3 (A092)




39. ELECTRICAL SECTION 3 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A049 6526	Belt Unit Stopper Cam	2
2	A049 6523	Middle Left Stay	1
3	A049 3204	Development Guide Rail	1
4	A049 6820	Base Plate - Toner Collection	1
5	A049 6850	Left Stay	1
6	A049 6541	Middle Stay - Stopper Pin	1
7	AA14 3263	Stopper Pin	1
8	AA14 0282	Stopper Shaft	1
9	A049 1082	Main Motor Cover	1
10	A049 1080	Heater Support Stay	1
11	A049 1081	Heater Connector Bracket	1
12	AX40 0009	Heater - 220V 18W	2
12	AX40 0008	Heater - 115V 18W	2
13	A049 6525	Middle Right Stay	1
14	A049 5636	AC Harness - AC In	1
15	A049 5607	AC/DC Harness	1
16	A464 4174	Stand	4
17	5446 1086	Leveling Foot Guide	4
18	A092 5801	Power Supply Unit Panel	1
19	5442 1053	Rear Grip - Bottom Plate	4
20	5415 1053	Caster	4
21	5301 1662	Hexagon Bolt	12
22	AZ24 0014	DC Power Supply Unit - 230V 500W	1
22	AZ24 0013	DC Power Supply Unit - 115V	1
23	6754 3278	Stepped Screw	2
24	A092 5635	AC Harness - AC Out	1
25	A092 5722	Lightning Arrester Board (220/240V)	1
25	A049 5720	Lightning Arrester Board (115V)	1
26	A092 5800	Power Supply Unit Base	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0353 0060B	Screw - M3x6	
103	0951 4008B	Philips Screw With Flat Washer - M4	
104	0951 4014B	Philips Screw With Flat Washer M4	
105	0434 0060B	Philips Tapping Screw - M4x6	
106	0720 0050B	Retaining Ring - M5	
107	0314 0160B	Philips Pan Head Screw - M4x16	
108	1105 0291	Wire Saddle	
109	1107 0550	Circuit Breaker - 10A (220/240V)	
109	1107 0550	Circuit Breaker - 115V	
110	1208 0176	Solid State Relay - 240V	
110	1208 0466	Solid State Relay - 120V	
111	1105 0199	Clamp	
112	1602 0946	Noise Filter - 220/240V	
112	1602 0991	Noise Filter - 115V	
113	1208 1029	Power Relay	
114	1104 0224	Relay Bracket	
115	1105 0291	Wire Saddle	
116	1105 0316	Clamp	

40. ELECTRICAL SECTION 4 (A092)




40. ELECTRICAL SECTION 4 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	AD02 1060	Charge Corona Receptacle	4
2	A049 3232	Rear Holder - Development Unit	4
3	A049 5825	Right Support Plate	1
4	5442 2165	Receptacle Housing - Main Corona	1
5	A049 5640	High Voltage Harness - Discharge	1
6	A049 5603	Drum Unit Harness	1
7	A049 1077	Rear Slide Plate	1
8	AA00 1108	Electrical Power Decal	1
9	A049 5826	Left Support Plate	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	1105 0291	Wire Saddle	
103	1105 0316	Clamp	
104	1105 0120	Wire Clip	
105	1105 0292	Wire Saddle	
106	1105 0278	Harness Clamp	

41. HARNESS (A092)



41. HARNESS (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	A092 5414	Sequence Control Board	1
2	A049 5630	Laser Unit Optical Fiber	1
3	A049 5810	Sequence Control Board Bracket	1
4	A092 5695	Front DC Harness	1
5	A092 6664	Retaining Ring - M29	1
6	AA00 1190	Decal - Ground	2
7	A049 6666	Power Supply Cord Bracket (220/240V)	1
7	A092 6669	Power Supply Cord Bracket (115V)	1
8	AZ00 0018	Power Supply Cord - 250V 10A	1
9	A092 6670	Power Supply Cord Holder	1
10	A049 5620	Relay Harness	1
11	A049 5830	Harness Clamp	1
12	A092 5621	AC Harness	1
13	A049 5603	Drum Unit Harness	1
14	A092 5420	Process Control Board	1
15	5446 5832	Connector Guide Pin	6
16	5424 2625	Spring - Connector	2
17	A420 3232	Connector Spring	4
18	AX04 0006	Blower Fan	1
19	A049 6862	Cooling Fan Duct	1
20	AA01 2042	Cooling Fan Duct	1
21	A092 5426	Main Motor Control Board (220/240V)	1
21	A049 5426	Main Motor Control Board (115V)	1
22	A049 5820	Process Control Board Bracket	1
23	A092 5696	Rear DC Harness	1
24	A049 5645	Grounding Wire - Process Control	1
25	5413 2596	Stud - Paper Feed Unit	4
26	A092 6668	Noise Filter Bracket	1
27	A092 5636	Noise Filter Harness	1

Index No.	Part No.	Description	Q'ty per Assembly
101	0354 0060B	Screw - M4x6	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0315 0080M	Philips Pan Head Screw - M5x8	
104	0313 0140B	Philips Pan Head Screw - M3x14	
105	0314 0140B	Philips Pan Head Screw - M4x14	
106	0314 0120B	Philips Pan Head Screw - M4x12	
107	0313 0350B	Philips Pan Head Screw - M3x35	
108	1105 0010	Nylon Clip - 6N	
109	1607 0353	Ferrite Core	
110	1101 0359	Terminal - 3P	
111	1106 0458	Bushing - 9.9mm	
112	1105 0199	Clamp	
113	1107 0673	Fuse - 6.3A/250V	
113	1107 0392	Fuse - 6.3A (115V)	
114	1107 0739	Fuse - 2A (220/240V)	
114	1107 0388	Fuse - 2A (115V)	
115	1106 0350	Bushing - 29mm	
116	1105 0291	Wire Saddle	
117	1106 0430	Bushing - 13mm	
118	0950 4008B	Screw - M4x8	
119	1602 0946	Noise Filter	

42. SCANNER BOARD (A092)

BL

CAPACITOR

SYMBOL NO.	INDEX NO.
BL701	146
BL702	146

SYMBOL NO.	INDEX NO.
C701	145
C702	145
C703	145
C704	145
C705	145
C706	145
C707	145
C708	145
C709	145
C710	145

SYMBOL NO.	INDEX NO.
C711	145
C712	145
C713	145
C714	145
C715	145
C716	145
C717	145
C718	145
C719	145
C720	145

SYMBOL NO.	INDEX NO.
C721	145
C722	145
C723	145
C724	145
C725	144
C726	144
C727	145
C728	145
C729	145
C730	145

SYMBOL NO.	INDEX NO.
C731	143
C732	145
C733	145
C734	144
C735	144
C736	145
C737	145
C738	141
C739	145
C740	145

SYMBOL NO.	INDEX NO.
C741	145
C742	145
C743	145
C744	145
C745	145
C746	145
C747	145
C748	145
C749	145
C750	145

SYMBOL NO.	INDEX NO.
C751	145
C752	145
C753	145
C754	145
C755	142
C756	145
C757	145
C758	145
C759	145
C760	145

SYMBOL NO.	INDEX NO.
C761	145
C762	145
C763	145
C764	145
C765	145
C766	145
C767	145
C768	145
C769	145
C770	145

SYMBOL NO.	INDEX NO.
C771	145
C772	145
C773	145
C774	145
C775	145
C776	145
C777	145
C778	145
C779	145
C780	145

SYMBOL NO.	INDEX NO.
C781	145
C782	145
C783	145
C784	145
C785	145
C786	145
C787	145
C788	145
C789	145
C790	145

SYMBOL NO.	INDEX NO.
C791	145
C792	145
C793	145
C794	145
C795	145
C796	145
C797	145
C798	145
C799	145
C800	145

SYMBOL NO.	INDEX NO.
C801	145
C802	145
C803	145
C804	145
C805	145
C806	145
C807	145
C808	145
C809	145
C810	145

SYMBOL NO.	INDEX NO.
C811	145
C812	145
C813	145
C814	145
C815	145
C816	145
C817	145
C818	145
C819	145
C820	145

SYMBOL NO.	INDEX NO.
C821	145
C822	145
C823	145
C824	145
C825	145
C826	145
C827	145
C828	145
C829	145
C830	145

42. SCANNER CONTROL BOARD (A092)

SYMBOL NO.	INDEX NO.
C831	145
C832	145
C833	145
C834	145
C835	145
C836	145
C837	145
C838	145
C839	145
C840	145

SYMBOL NO.	INDEX NO.
C841	145

COIL

SYMBOL NO.	INDEX NO.
L701	161

CONNECTOR

SYMBOL NO.	INDEX NO.
CN270	106
CN271	107
CN272	108
CN273	105

DGS

SYMBOL NO.	INDEX NO.
DGS701	111
DGS702	111

DL

SYMBOL NO.	INDEX NO.
DL701	160

DPS

SYMBOL NO.	INDEX NO.
DPS701	110
DPS702	162

HB

SYMBOL NO.	INDEX NO.
HB701	139

IC

SYMBOL NO.	INDEX NO.
IC701	163
IC702	117
IC703	117
IC704	164
IC705	114
IC706	115
IC707	126
IC708	155
IC709	113
IC710	127

SYMBOL NO.	INDEX NO.
IC711	3
(Socket)	109
IC712	123
IC713	118
IC714	121
IC715	121
IC716	125
IC717	158
IC718	112
IC719	114

SYMBOL NO.	INDEX NO.
IC720	121
IC721	121
IC722	121
IC723	163
IC724	117
IC725	159
IC726	133
IC727	114
IC728	2
IC729	130

SYMBOL NO.	INDEX NO.
IC730	121
IC731	157
IC732	115
IC733	113
IC734	168
IC735	122
IC736	119
IC737	116
IC738	117
IC739	164

SYMBOL NO.	INDEX NO.
IC740	112
IC741	112
IC742	157
IC743	124
IC744	131
IC745	128
IC746	128
IC747	128
IC748	112
IC749	131

SYMBOL NO.	INDEX NO.
IC750	112
IC751	129
IC752	159
IC753	165
IC754	115
IC755	1
IC756	124
IC757	124
IC758	156
IC759	156

SYMBOL NO.	INDEX NO.
IC760	128
IC761	128
IC762	128
IC763	132
IC764	121
IC765	156
IC766	121
IC767	156
IC768	128
IC769	128

SYMBOL NO.	INDEX NO.
IC770	166
IC771	156
IC772	166
IC773	112
IC774	156
IC775	124
IC776	156
IC777	128
IC778	128
IC779	128

SYMBOL NO.	INDEX NO.
IC780	156
IC781	156
IC782	121
IC783	156
IC784	128
IC785	128
IC786	120
IC787	156
IC788	166
IC789	156

42. SCANNER CONTROL BOARD (A092)

SYMBOL NO.	INDEX NO.
C831	145
C832	145
C833	145
C834	145
C835	145
C836	145
C837	145
C838	145
C839	145
C840	145

SYMBOL NO.	INDEX NO.
C841	145

COIL

SYMBOL NO.	INDEX NO.
L701	161

CONNECTOR

SYMBOL NO.	INDEX NO.
CN270	106
CN271	107
CN272	108
CN273	105

DGS

SYMBOL NO.	INDEX NO.
DGS701	111
DGS702	111

DPS

SYMBOL NO.	INDEX NO.
DPS701	110
DPS702	162

IC

SYMBOL NO.	INDEX NO.
IC701	163
IC702	117
IC703	117
IC704	164
IC705	114
IC706	115
IC707	126
IC708	155
IC709	113
IC710	127

SYMBOL NO.	INDEX NO.
IC711 (Socket)	3 109
IC712	123
IC713	118
IC714	121
IC715	121
IC716	125
IC717	158
IC718	112
IC719	114

DL

SYMBOL NO.	INDEX NO.
DL701	160

HB

SYMBOL NO.	INDEX NO.
HB701	139

SYMBOL NO.	INDEX NO.
IC720	121
IC721	121
IC722	121
IC723	163
IC724	117
IC725	159
IC726	133
IC727	114
IC728	2
IC729	130

SYMBOL NO.	INDEX NO.
IC730	121
IC731	157
IC732	115
IC733	113
IC734	168
IC735	122
IC736	119
IC737	116
IC738	117
IC739	164

SYMBOL NO.	INDEX NO.
IC740	112
IC741	112
IC742	157
IC743	124
IC744	131
IC745	128
IC746	128
IC747	128
IC748	112
IC749	131

SYMBOL NO.	INDEX NO.
IC750	112
IC751	129
IC752	159
IC753	165
IC754	115
IC755	1
IC756	124
IC757	124
IC758	156
IC759	156

SYMBOL NO.	INDEX NO.
IC760	128
IC761	128
IC762	128
IC763	132
IC764	121
IC765	156
IC766	121
IC767	156
IC768	128
IC769	128

SYMBOL NO.	INDEX NO.
IC770	166
IC771	156
IC772	166
IC773	112
IC774	156
IC775	124
IC776	156
IC777	128
IC778	128
IC779	128

SYMBOL NO.	INDEX NO.
IC780	156
IC781	156
IC782	121
IC783	156
IC784	128
IC785	128
IC786	120
IC787	156
IC788	166
IC789	156

42. SCANNER CONTROL BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5280	Scanner Control Board	1
1	A049 5275	IC - MB7132L	2
2	A049 5279	IC - RF5GF26-017	1
3	A049 5287	IC - HN27C256G	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1101 0382	Connector - 1P	
104	1102 2442	DIC Switch	
105	1102 2845	Connector - 16P	
106	1102 4879	Connector - 90P	
107	1103 0755	Connector - 50P	
108	1103 1489	Connector - 3P	
109	1104 0271	IC Socket - 28P	
110	1204 1541	DIP Switch	
111	1204 2189	Digital Switch	
112	1407 0539	IC - SN74LS04N	
113	1407 0610	IC - SN74LS32N	
114	1407 0614	IC - SN74LS74AN	
115	1407 0621	IC - SN74LS08N	
116	1407 0711	IC - 74LS151	
117	1407 0714	IC - SN74LS163N	
118	1407 0794	IC - SN74LS245N	
119	1407 0814	IC - HD74LS139P	
120	1407 0842	TTL IC - SN74LS399N	
121	1407 0887	IC - SN74LS244N	
122	1407 1016	IC - D8255AC-2	
123	1407 1026	IC - SN74LS373N	
124	1407 1073	IC - SN74LS283N	
125	1407 1537	IC - TC74HC14P	
126	1407 2510	IC - D78C10G	
127	1407 2870	IC - MPD71054C	
128	1407 3268	IC - UPD42505C-50H	
129	1407 3456	IC - N74F374N	
130	1407 3460	IC - SN74ALS34N	
131	1407 3461	IC - SN74AS1805N	
132	1407 3475	IC - MSM514221-6RS	
133	1408 0494	IC - MB3371P	
134	1503 0181	Oscillator - 10MHz	
135	1503 0370	Oscillator - 16.0224MHz	

43. LD CONTROL BOARD (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C600	154	C610	154	C620	146	C630	154	C640	154	C650	154	C660	154
C601	148	C611	154	C621	154	C631	154	C641	154	C651	154	C661	154
C602	154	C612	154	C622	154	C632	154	C642	154	C652	154	C662	154
C603	154	C613	154	C623	145	C633	154	C643	154	C653	154	C663	154
C604	154	C614	154	C624	154	C634	144	C644	154	C654	154	C664	154
C605	154	C615	154	C625	146	C635	154	C645	154	C655	152	C665	154
C606	154	C616	154	C626	154	C636	145	C646	154	C656	154	C666	154
C607	154	C617	154	C627	154	C637	143	C647	154	C657	154	C667	154
C608	154	C618	154	C628	154	C638	147	C648	143	C658	154	C668	154
C609	154	C619	154	C629	154	C639	154	C649	149	C659	154	C669	154

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C670	154	C680	154	C690	154	C700	143	C710	154	C720	154	C730	154
C671	154	C681	154	C691	154	C701	154	C711	154	C721	154	C731	154
C672	154	C682	154	C692	154	C702	149	C712	154	C722	154	C732	154
C673	154	C683	154	C693	154	C703	154	C713	154	C723	154	C733	154
C674	154	C684	154	C694	154	C704	154	C714	154	C724	154	C734	154
C675	154	C685	154	C695	154	C705	154	C715	154	C725	154	C735	154
C676	154	C686	154	C696	154	C706	154	C716	154	C726	154	C736	154
C677	154	C687	154	C697	154	C707	152	C717	154	C727	154	C737	154
C678	154	C688	154	C698	154	C708	154	C718	154	C728	154	C738	154
C679	154	C689	154	C699	154	C709	154	C719	154	C729	154	C739	154

43. LD CONTROL BOARD (A092)

SYMBOL NO.	INDEX NO.
C740	154
C741	143
C742	154
C743	154
C744	154
C745	149
C746	154
C747	154
C748	152
C749	154

SYMBOL NO.	INDEX NO.
C750	154
C751	154
C752	154
C753	154
C754	154
C755	154
C756	154
C757	154
C758	154
C759	154

SYMBOL NO.	INDEX NO.
C760	154
C761	154
C762	154
C763	154
C764	154
C765	154
C766	154
C767	154
C768	154
C769	154

SYMBOL NO.	INDEX NO.
C770	154
C771	154
C772	154
C773	154
C774	154
C775	154
C776	154
C777	154
C778	154
C779	154

SYMBOL NO.	INDEX NO.
C780	154
C781	154
C782	154
C783	154
C784	154
C785	154
C786	154
C787	154
C788	154
C789	154

SYMBOL NO.	INDEX NO.
C790	154
C791	154
C792	154
C793	154
C794	154
C795	154
C796	154
C797	143
C798	149
C799	154

SYMBOL NO.	INDEX NO.
C800	154
C801	154
C802	154
C803	154
C804	152
C805	154
C806	154
C807	154
C808	154
C809	154

SYMBOL NO.	INDEX NO.
C810	155
C811	153
C812	145
C813	154
C814	154
C815	154
C816	154
C817	154
C818	154
C819	154

SYMBOL NO.	INDEX NO.
C820	154
C821	154
C822	154
C823	154
C824	154
C825	154
C826	154
C827	154
C828	154
C829	154

SYMBOL NO.	INDEX NO.
C830	154
C831	154
C832	154
C833	154
C834	154
C835	154
C836	154
C837	154
C838	154
C839	154

SYMBOL NO.	INDEX NO.
C840	154
C841	154
C842	155
C843	154
C844	154
C845	154
C846	154
C847	154
C848	145
C849	145

CAY

SYMBOL NO.	INDEX NO.
CAY600	150
CAY601	150

COIL

SYMBOL NO.	INDEX NO.
L600	107
L601	156
L602	107
L603	156

CONNECTOR

SYMBOL NO.	INDEX NO.
CN601	102
CN602	103
CN603	106
CN604	104
CN605	105
CN606	105
CN607	105
CN608	105

43. LD CONTROL BOARD (A092)

DIODE

SYMBOL NO.	INDEX NO.
D600	111
D601	111
D602	111
D603	111
D604	111

DL

SYMBOL NO.	INDEX NO.
DL600	157
DL601	158
DL602	158
DL603	158
DL604	158
DL605	158
DL606	158
DL607	158
DL608	157
DL609	157

SYMBOL NO.	INDEX NO.
DL610	158
DL611	158
DL612	158
DL613	158
DL614	158
DL615	158
DL616	158
DL617	157
DL618	157
DL619	158

SYMBOL NO.	INDEX NO.
DL620	158
DL621	158
DL622	158
DL623	158
DL624	158
DL625	158
DL626	157
DL627	157
DL628	158
DL629	158

SYMBOL NO.	INDEX NO.
DL630	158
DL631	158
DL632	158
DL633	158
DL634	158
DL635	157

DPS

SYMBOL NO.	INDEX NO.
DPS600	108
DPS601	108
DPS602	108
DPS603	108

F

SYMBOL NO.	INDEX NO.
F600	142

IC

SYMBOL NO.	INDEX NO.
IC600	178
IC601	122
IC602	128
IC603	124
IC604	124
IC605	178
IC606	124
IC607	120
IC608	117
IC609	117

SYMBOL NO.	INDEX NO.
IC610	130
IC611	131
IC612	125
IC613	125
IC614	123
IC615	127
IC616	133
IC617	115
IC618	114
IC619	113

SYMBOL NO.	INDEX NO.
IC620	118
IC621	121
IC622	132
IC623	128
IC624	124
IC625	124
IC626	126
IC627	115
IC628	116
IC629	113

SYMBOL NO.	INDEX NO.
IC630	124
IC631	119
IC632	176
IC633	114
IC634	177
IC635	177
IC636	177
IC637	136
IC638	130
IC639	131

SYMBOL NO.	INDEX NO.
IC640	125
IC641	125
IC642	123
IC643	127
IC644	117
IC645	117
IC646	118
IC647	121
IC648	132
IC649	128

SYMBOL NO.	INDEX NO.
IC650	124
IC651	124
IC652	115
IC653	116
IC654	113
IC655	119
IC656	176
IC657	114
IC658	177
IC659	177

SYMBOL NO.	INDEX NO.
IC660	177
IC661	136
IC662	124
IC663	130
IC664	131
IC665	125
IC666	125
IC667	123
IC668	127
IC669	117

SYMBOL NO.	INDEX NO.
IC670	115
IC671	116
IC672	113
IC673	118
IC674	121
IC675	132
IC676	128
IC677	124
IC678	124
IC679	123

43. LD CONTROL BOARD (A092)

SYMBOL NO.	INDEX NO.
IC680	126
IC681	119
IC682	176
IC683	114
IC684	177
IC685	177
IC686	177
IC687	136
IC688	124
IC689	127

SYMBOL NO.	INDEX NO.
IC690	120
IC691	117
IC692	118
IC693	121
IC694	132
IC695	130
IC696	131
IC697	125
IC698	125
IC699	134

SYMBOL NO.	INDEX NO.
IC700	115
IC701	116
IC702	113
IC703	119
IC704	176
IC705	114
IC706	177
IC707	177
IC708	177
IC709	136

SYMBOL NO.	INDEX NO.
IC710	178
IC711	178
IC712	122
IC713	122
IC714	178
IC715	134
IC716	129

LED

SYMBOL NO.	INDEX NO.
LED600	175
LED601	175
LED602	175
LED603	175

REG

SYMBOL NO.	INDEX NO.
REG600	135
REG601	135
REG602	135
REG603	135

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY600	141
RAY601	140
RAY602	139
RAY603	141
RAY604	141
RAY605	139
RAY606	140
RAY607	138
RAY608	139
RAY609	140

RESISTOR

SYMBOL NO.	INDEX NO.
RAY610	141
RAY611	141
RAY612	139
RAY613	140
RAY614	139
RAY615	140

SYMBOL NO.	INDEX NO.
R600	169
R601	167
R602	167
R603	170
R604	166
R605	164
R606	160
R607	166
R608	166
R609	160

SYMBOL NO.	INDEX NO.
R610	160
R611	174
R612	172
R613	160
R614	161
R615	162
R616	160
R617	160
R618	169
R619	169

SYMBOL NO.	INDEX NO.
R620	171
R621	171
R622	161
R623	160
R624	170
R625	166
R626	164
R627	160
R628	166
R629	166

SYMBOL NO.	INDEX NO.
R630	160
R631	160
R632	174
R633	172
R634	160
R635	161
R636	167
R637	167
R638	169
R639	171

SYMBOL NO.	INDEX NO.
R640	171
R641	161
R642	160
R643	167
R644	167
R645	170
R646	166
R647	164
R648	160
R649	166

SYMBOL NO.	INDEX NO.
R650	166
R651	160
R652	160
R653	174
R654	172
R655	160
R656	161
R657	171
R658	171
R659	161

43. LD CONTROL BOARD (A092)

SYMBOL NO.	INDEX NO.
R660	160
R661	169
R662	170
R663	166
R664	164
R665	160
R666	166
R667	166
R668	160
R669	160

SYMBOL NO.	INDEX NO.
R670	174
R671	172
R672	160
R673	161
R674	166
R675	166
R676	166
R677	171
R678	169
R679	163

SYMBOL NO.	INDEX NO.
R680	169
R681	159
R682	167
R683	167
R684	161
R685	160
R686	171
R687	171
R688	159
R689	173

SYMBOL NO.	INDEX NO.
R690	168
R691	166
R692	166
R693	166
R694	171
R695	165
R696	169
R697	169
R698	169
R699	169

TEST POINT

SYMBOL NO.	INDEX NO.
TP600	101
TP601	101
TP602	101
TP603	101
TP604	101
TP605	101
TP606	101
TP607	101
TP608	101
TP609	101

SYMBOL NO.	INDEX NO.
TP610	101
TP611	101
TP612	101
TP613	101
TP614	101
TP615	101

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q600	110
Q601	110
Q602	110
Q603	110
Q604	112
Q605	112

VARIABLE RESISTOR

SYMBOL NO.	INDEX NO.
VR600	137
VR601	137
VR602	137
VR603	137

43. LD CONTROL BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	* A049 5470	LD Control Board	1
	A049 5472	Shielding Plate	2

Index No.	Part No.	Description	Q'ty per Assembly
101	1101 0328	Connector Pin Contact	
102	1102 0999	Connector - 9P	
103	1102 4173	Connector - 20P	
104	1103 0650	Connector - 40P	
105	1103 0770	Connector - 9P	
106	1103 0773	Connector - 8P	
107	1201 0039	Coil	
108	1204 2193	Slide Switch	
109	1204 2196	Rotary Switch	
110	1400 0087	Transistor - 2SC1815	
111	1401 0611	Diode - 1S1588	
112	1401 0855	Transistor - 2SJ143	
113	1407 0539	IC - SN74LS04N	
114	1407 0542	IC - NS74LS00NS	
115	1407 0614	IC - SN74LS74AN	
116	1407 0617	IC - SN74LS02N	
117	1407 0621	IC - SN74LS08N	
118	1407 0623	IC - HD74LS175P	
119	1407 0710	IC - HD74LS107	
120	1407 0760	IC - SN74LS14N	
121	1407 0816	IC - SN74LS157N	
122	1407 0887	IC - SN74LS244N	
123	1407 1394	IC - SN74ALS32N	
124	1407 1431	TTLIC - 74F04PC	
125	1407 1432	TTLIC - 74F08PC	
126	1407 1450	TTLIC - 74F240PC	
127	1407 1584	IC - 74F151APC	
128	1407 1586	IC - 74F175APC	
129	1407 2028	IC - SN74LS06N	
130	1408 0199	IC - TL074CN	
131	1408 0290	IC - LM311N	
132	1408 0460	IC - HA17008RP	
133	1408 0493	IC - NE556N	
134	1408 0494	IC - MB3371P	
135	1408 0813	IC - TA78L005AP	

Index No.	Part No.	Description	Q'ty per Assembly
136	1408 0817	IC - HA17012P-B	
137	1601 2925	Resistor - 2K Ω 0.5W	
138	1601 7196	Resistor Array - 270 Ω	
139	1601 7373	Resistor Array - 3.3k Ω	
140	1601 7375	Resistor Array - 6.8k Ω	
141	1601 7449	Resistor - 100 Ω $\pm 5\%$	
142	1602 7029	Noise Filter - 22000pF 50V	
143	1604 1351	Capacitor - 22mF 10V	
144	1604 1354	Capacitor - 100uF 10V	
145	1604 1356	Capacitor - 330uF 10V	
146	1604 1369	Capacitor - 330uF $\pm 20\%$	
147	1604 1379	Capacitor - 2.2uF $\pm 20\%$ 50V	
148	1604 1388	Capacitor - 330uF 50V	
149	1605 0468	Capacitor - 0.33uF $\pm 20\%$ 50V	
150	1605 0647	Capacitor - 0.01uF	
151	1606 1311	Capacitor - 47pF 50V	
152	1606 1321	Capacitor - 330pF 50V	
153	1606 1332	Capacitor - 1000pF 50V	
154	1606 1336	Capacitor - 10000pF -20% +80% 50V	
155	1606 1511	Capacitor - 022mF 50V	
156	1607 0427	SN Coil - SF-T10-30	
157	1607 0489	IC - RWT020P-2	
158	1607 0490	IC - RWT025P-2	
159	1611 4101	Resistor - 100 Ω 1/4T $\pm 5\%$	
160	1611 4102	Resistor - 1K Ω 1/4T $\pm 5\%$	
161	1611 4103	Resistor - 10k Ω 1/4T $\pm 5\%$	
162	1611 4105	Resistor - 1M Ω 1/4T $\pm 5\%$	
163	1611 4154	Resistor - 150k Ω 1/4T $\pm 5\%$	
164	1611 4181	Resistor - 180 Ω 1/4T $\pm 5\%$	
165	1611 4184	Resistor - 180k Ω , 1/4T +5%	
166	1611 4203	Resistor - 20k Ω 1/4T	
167	1611 4272	Resistor - 2.7k Ω 1/4T $\pm 5\%$	
168	1611 4332	Resistor - 3.3K Ω 1/4T $\pm 5\%$	
169	1611 4472	Resistor - 4.7k Ω $\pm 5\%$ 1/4W	
170	1611 4511	Resistor - 510 Ω 1/4T +5%	

Index No.	Part No.	Description	Q'ty per Assembly
171	1611 4512	Resistor - 5.1k Ω 1/4T $\pm 5\%$	
172	1611 4561	Resistor - 560 Ω 1/4T $\pm 5\%$	
173	1611 4682	Resistor - 6.8k Ω 1/4T $\pm 5\%$	
174	1611 4751	Resistor - 750 Ω 1/4T $\pm 5\%$	
175	1403 0416	LED - Red	
176	1407 0759	IC - SN74LS10N	
177	1407 0945	IC - SN74LS191	
178	1407 1130	IC - SN74LS204N	

44. MAIN MOTOR CONTROL BOARD (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.
C501	136
C502	138
C504	140
C505	134
C506	134
C512	136
C514	137
C515	135
C516	140
C517	140

SYMBOL NO.	INDEX NO.
C519	141
C520	141
C521	140
C522	141
C523	141
C524	150
C525	141
C526	141
C527	141
C528	141

SYMBOL NO.	INDEX NO.
C529	141
C530	141
C531	141
C532	141
C534	141
C535	141
C536	141
C537	140
C539	141
C540	141

SYMBOL NO.	INDEX NO.
C541	141
C542	140
C543	139
C544	140
C545	139
C546	140
C547	141
C548	141
C549	141
C550	141

SYMBOL NO.	INDEX NO.
C551	141
C552	141
C553	141
C554	141

COIL

SYMBOL NO.	INDEX NO.
L501	111

DGS

SYMBOL NO.	INDEX NO.
DGS501	112
DGS502	112

CONNECTOR

SYMBOL NO.	INDEX NO.
CN501	108
CN502	105
CN503	104
CN504	103
CN505	101

DIODE

SYMBOL NO.	INDEX NO.
D501	119

DPS

SYMBOL NO.	INDEX NO.
DPS501	114
DPS502	113

FUSE

SYMBOL NO.	INDEX NO.
FU501	109
(FU501)	107
FU502	109
(FU502)	107
FU503	110
(FU503)	107

IC

SYMBOL NO.	INDEX NO.
IC501	132
IC502	123
IC503	130
IC505	126
IC506	154
IC507	154
IC509	122
IC510	128
IC511	128
IC512	121

SYMBOL NO.	INDEX NO.
IC513	129
IC514	128
IC515	130
IC516	124
IC517	122
IC518	124
IC519	129
IC520	1
IC521	120
IC522	131

SYMBOL NO.	INDEX NO.
IC524	125
IC525	127

OSC

SYMBOL NO.	INDEX NO.
OSC501	133

RESISTOR

SYMBOL NO.	INDEX NO.
R502	144
R503	144
R504	144
R505	151
R506	152
R507	148
R508	151
R509	152
R510	148
R511	151

SYMBOL NO.	INDEX NO.
R512	152
R513	148
R514	151
R515	152
R516	148
R517	151
R518	152
R519	148
R520	151
R521	152

TEST POINT

TRANSISTOR

SYMBOL NO.	INDEX NO.
R522	148
R523	153
R524	142
R525	148
R526	148
R527	148
R528	148
R529	148
R530	148
R531	148

SYMBOL NO.	INDEX NO.
R532	148
R533	145
R534	143
R535	148
R536	148
R537	148
R538	148
R539	148
R540	148
R541	148

SYMBOL NO.	INDEX NO.
R542	148
R543	148
R544	148
R545	148
R546	148
R547	148
R548	148
R549	148
R550	148
R551	149

SYMBOL NO.	INDEX NO.
R552	149
R553	149
R554	149
R555	147
R556	147
R557	147
R558	147
R559	147
R560	147
R561	148

SYMBOL NO.	INDEX NO.
R562	146
R563	144
R564	153
R565	153
R567	153
R568	153
R569	153
R570	153
R571	147

SYMBOL NO.	INDEX NO.
TP501	102
TP502	102
TP503	102
TP504	102
TP505	102
TP506	102
TP507	102
TP508	102

SYMBOL NO.	INDEX NO.
Q501	115
Q502	116
Q503	115
Q504	116
Q505	115
Q506	116
Q507	115
Q508	116
Q509	115
Q510	116

ZENER DIODE

SYMBOL NO.	INDEX NO.
Q511	115
Q512	116
Q513	117

SYMBOL NO.	INDEX NO.
ZD501	118
ZD502	118
ZD503	118
ZD504	118
ZD505	118
ZD506	118

44. MAIN MOTOR CONTROL BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 5426	Main Motor Control Board (220/240V)	1
*	A049 5426	Main Motor Control Board (115V)	1
1	A049 5512	IC - UPD78P312ACW	1
101	1100 1093	Connector - 6P	
102	1101 0328	Connector Pin Contact	
103	1102 0958	Connector - 2P	
104	1103 0428	Connector - 20P	
105	1103 0725	Connector - 3P	
107	1104 0351	Fuse Holder	
108	1103 0832	Connector - 7P	
109	1107 0739	Fuse - 2A (220/240V)	
109	1107 0388	Fuse - 2A (115V)	
110	1107 0673	Fuse - 6.3A/250V	
110	1107 0392	Fuse - 6.3A (115V)	
111	1201 0039	Coil	
112	1204 1228	Switch	
113	1204 1537	DIP Switch	
114	1204 1570	DIP Switch	
115	1400 0403	Transistor - 2SC1623I6	
116	1401 0445	Transistor - 2SA812M5	
117	1401 0859	Transistor - 2SK815	
118	1402 0894	Diode - RD12MB	
119	1402 0977	Diode - 31DF1	

Index No.	Part No.	Description	Q'ty per Assembly
120	1407 2058	IC - 82C54FP-6	
121	1407 2187	IC - SN74LS07NS	
122	1407 3203	IC - TC74HC10AF	
123	1407 3257	IC - TC74HC14A	
124	1407 3259	IC - TC74HC125AF	
125	1407 3284	IC - TC74HC74AF	
126	1407 3286	IC - TC74HC04AF	
127	1407 3290	IC - 74HC02A	
128	1407 3486	IC - TC74HC153AF	
129	1407 3509	IC - TC74HC11AF	
130	1407 3510	IC - SLA5017	
131	1408 0537	IC - TL7705CPS	
132	1408 0595	IC - NJM2904M	
133	1503 0182	Ceramic Oscillator - 12MHz	
134	1604 0987	Capacitor - 10mF 16V	
135	1604 1381	Capacitor - 4.7uF 50V	
136	1604 1386	Capacitor - 100mF $\pm 20\%$ 50V	
137	1604 1387	Capacitor - 220 uF 50V	
138	1604 1783	Capacitor - 220uF 25V	
139	1605 0534	Capacitor - 1000pF +80 -20%	
140	1606 1451	Capacitor - 0.1uF 50V	
141	1606 1452	Capacitor - 0.01uF 50V	
142	1610 0025	Resistor - 22 Ω 1/8W $\pm 5\%$	
143	1610 0035	Resistor - 100 Ω 1/8W $\pm 5\%$	
144	1610 0049	Resistor - 470 Ω 1/8W $\pm 5\%$	
145	1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	
146	1610 0065	Resistor - 3.3K Ω 1/8W $\pm 5\%$	
147	1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	
148	1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	
149	1610 0089	Resistor - 100k Ω 1/8W $\pm 5\%$	
150	1610 0286	Capacitor - 100pF 50V $\pm 10\%$	
151	1610 1032	Resistor - 1.0k Ω 1/4W	
152	1610 1033	Resistor - 1.5k Ω 1/4W	
153	1610 1133	Resistor - 150 Ω $\pm 5\%$ 1/4W	
154	1407 3287	IC - TC74HC393AF	

45. SEQUENCE CONTROL BOARD (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.
C100	143
C102	143
C103	142
C104	146
C105	146
C106	146
C107	146
C108	146
C109	146
C110	146

SYMBOL NO.	INDEX NO.
C111	146
C112	146
C113	146
C114	146
C115	146
C116	146
C117	146
C118	146
C119	146
C120	146

SYMBOL NO.	INDEX NO.
C121	146
C122	146
C123	146
C124	146
C125	144
C126	146
C127	146
C128	146
C130	146
C131	146

SYMBOL NO.	INDEX NO.
C132	146
C133	146
C134	146
C135	145
C136	146
C137	146
C138	146
C139	146
C140	146
C141	146

SYMBOL NO.	INDEX NO.
C142	146
C143	146
C144	146
C145	146
C146	146
C147	146
C148	146
C149	146
C150	146
C151	146

SYMBOL NO.	INDEX NO.
C152	146
C153	146
C154	146
C155	146
C156	145
C157	146
C158	146
C159	146
C160	146
C161	146

SYMBOL NO.	INDEX NO.
C162	145
C163	146
C164	146
C165	146
C166	146

COIL

SYMBOL NO.	INDEX NO.
L100	147

CONNECTOR

SYMBOL NO.	INDEX NO.
CN400	104
CN401	105
CN402	107
CN403	108
CN404	106
CN405	104
CN406	102
CN407	101
CN408	106

DIODE

SYMBOL NO.	INDEX NO.
D100	112

HB

SYMBOL NO.	INDEX NO.
HB100	141
HB103	141
HB104	141
HB105	141
HB106	141
HB107	141
HB108	141

IC

SYMBOL NO.	INDEX NO.
IC100	117
IC101	117
IC102	116
IC103	116
IC104	116
IC105	122
IC106	129
IC107	116
IC108	116
IC109	116

SYMBOL NO.	INDEX NO.
IC110	122
IC111	129
IC112	129
IC113	130
IC114	115
IC115	119
IC116	121
IC117	115
IC118	130
IC119	116

SYMBOL NO.	INDEX NO.
IC120	126
IC121	116
IC122	118
IC123	123
IC124	130
IC125	115
IC126	120
IC127	120
IC128	120
IC129	120

45. SEQUENCE CONTROL BOARD (A092)

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
IC130	115
IC131	116
IC132	125
IC133	128
IC134	1
(IC134)	109
IC135	124
IC136	129
IC137	115
IC138	120
IC139	127

SYMBOL NO.	INDEX NO.
IC140	131
IC141	132
IC142	129

OSC

SYMBOL NO.	INDEX NO.
OSC100	133

SYMBOL NO.	INDEX NO.
RAY100	140
RAY101	138
RAY102	137
RAY103	135
RAY104	134
RAY105	140
RAY106	140
RAY107	139
RAY108	139
RAY109	140

RESISTOR

SYMBOL NO.	INDEX NO.
RAY110	136
RAY111	136
RAY112	140

SYMBOL NO.	INDEX NO.
R100	162
R101	163
R102	160
R103	161
R104	161
R105	161
R106	161
R107	161
R108	161
R109	161

SYMBOL NO.	INDEX NO.
R110	161
R111	157
R112	152
R113	157
R114	157
R115	157
R116	152
R117	150
R118	151
R119	152

SYMBOL NO.	INDEX NO.
R120	152
R121	152
R122	150
R123	150
R124	150
R125	150
R126	151
R127	151
R128	151
R129	151

SYMBOL NO.	INDEX NO.
R130	157
R131	157
R132	153
R133	150
R134	148
R135	157
R136	157
R137	155
R138	157
R139	157

SYMBOL NO.	INDEX NO.
R140	157
R141	158
R142	158
R143	158
R144	158
R145	155
R146	155
R147	155
R148	155
R149	159

SYMBOL NO.	INDEX NO.
R150	159
R151	159
R152	159
R153	159
R154	159
R155	159
R156	159
R157	154
R158	149
R159	157

SYMBOL NO.	INDEX NO.
R160	157
R161	153
R162	150
R163	157
R164	157
R165	157
R166	157
R167	157
R168	157
R169	157

SYMBOL NO.	INDEX NO.
R170	151
R171	150
R172	157
R173	157
R174	157
R175	153
R176	150
R177	153
R178	150
R179	157

SYMBOL NO.	INDEX NO.
R180	157
R181	156

SW

SYMBOL NO.	INDEX NO.
SW100	110

TEST POINT

SYMBOL NO.	INDEX NO.
TP100	103
TP101	103
TP102	103
TP103	103
TP104	103
TP105	103
TP106	103
TP107	103
TP108	103
TP109	103

45. SEQUENCE CONTROL BOARD (A092)

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q100	111
Q101	111
Q102	111
Q103	111

ZENER DIODE

SYMBOL NO.	INDEX NO.
ZD100	113
ZD101	114
ZD102	113
ZD103	113
ZD104	113

SYMBOL NO.	INDEX NO.
TP110	103
TP111	103
TP112	103
TP113	103
TP114	103
TP115	103
TP116	103
TP117	103
TP118	103
TP119	103

45. SEQUENCE CONTROL BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
* 1	A092 5414 A092 5507	Sequence Control Board IC - MBM27C512-20CZ	1 1
101	1100 1090	Connector - 3P	
102	1100 1093	Connector - 6P	
103	1101 0328	Connector Pin Contact	
104	1102 4874	Connector - 60P	
105	1102 4962	Optical Connector - White	
106	1103 0428	Connector - 20P	
107	1103 0650	Connector - 40P	
108	1103 0653	Connector - 34P	
109	1104 0271	IC Socket - 28P	
110	1204 1015	DIP Switch	
111	1401 0234	Transistor - 2SD686	
112	1402 0247	Diode - W06B	
113	1402 0269	Zener Diode - RD39FC	
114	1402 0501	Zener Diode	
115	1407 1535	IC - TD62308AP	
116	1407 1600	IC - SN74LS244NS	
117	1407 1883	IC - TC4050BF	
118	1407 2052	IC - NS74LS74ANS	
119	1407 2078	IC - TD62785P	
120	1407 2187	IC - SN74LS07NS	
121	1407 2510	IC - D78C10G	
122	1407 2514	IC - TD62381P	
123	1407 2544	IC - MB89371PF	
124	1407 2671	IC - HM62256LP-15	
125	1407 2767	IC - MB89254-PF	
126	1407 3257	IC - TC74HC14A	
127	1407 3282	IC - TC74HC138AF	
128	1407 3283	IC - TC74HC373AF	

Index No.	Part No.	Description	Q'ty per Assembly
129	1407 3286	IC - TC74HC04AF	
130	1407 3359	IC - RF5C60	
131	1407 3509	IC - TC74HC11AF	
132	1408 0611	IC - MB3771PF	
133	1503 0079	Oscillator - 10000MHz	
134	1601 7345	Resistor - 330 Ω	
135	1601 7347	Resistor - 680 Ω	
136	1601 7354	Resistor Array - 10K Ω	
137	1601 7367	Resistor Array - 330 Ω	
138	1601 7369	Resistor Array - 680 Ω	
139	1601 7370	Resistor Array - 1k Ω	
140	1601 7376	Resistor Array - 10k Ω $\pm$ 5% 1/8W	
141	1602 0911	Surge Killer - 0.01mF	
142	1604 1376	Capacitor - 0.33uF 50V	
143	1604 1386	Capacitor - 100mF $\pm$ 20% 50V	
144	1605 0517	Capacitor - 330pF $\pm$ 80 -20% 50V	
145	1606 1451	Capacitor - 0.1uF 50V	
146	1606 1454	Capacitor - 0.01uF 25V	
147	1607 0428	SN Coil - SF-T10-30M	
148	1610 0035	Resistor - 100 Ω 1/8W $\pm$ 5%	
149	1610 0043	Resistor - 220 Ω 1/8W $\pm$ 5%	
150	1610 0047	Resistor - 330 Ω 1/8W $\pm$ 5%	
151	1610 0051	Resistor - 680 Ω 1/8W $\pm$ 5%	
152	1610 0053	Resistor - 1k Ω 1/8W $\pm$ 5%	
153	1610 0055	Resistor - 1.2k Ω 1/8W $\pm$ 5%	
154	1610 0061	Resistor - 2.2k Ω 1/8W $\pm$ 5%	
155	1610 0064	Resistor - 3k Ω 1/8W $\pm$ 5%	
156	1610 0067	Resistor - 4.7k Ω 1/8W $\pm$ 5%	
157	1610 0071	Resistor - 10k Ω $\pm$ 5% 1/8W	
158	1610 0079	Resistor - 22k Ω 1/8W $\pm$ 5%	
159	1610 0091	Resistor - 120k Ω	
160	1611 4183	Resistor - 18k Ω , 1/4T $\pm$ 5%	
161	1611 4221	Resistor - 220 Ω 1/4T $\pm$ 5%	
162	1611 4223	Resistor - 22k Ω 1/4T $\pm$ 5%	
163	1611 4332	Resistor - 3.3K Ω 1/4T $\pm$ 5%	

46. PROCESS CONTROL BOARD (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.
C203	150
C204	150
C205	150
C206	150
C207	150
C208	150
C209	154
C210	153
C211	152
C212	150

SYMBOL NO.	INDEX NO.
C213	153
C214	151
C215	153
C216	153
C217	153
C218	153
C219	153
C220	153
C221	153
C222	153

SYMBOL NO.	INDEX NO.
C223	153
C224	153
C225	153
C226	153
C227	153
C228	153
C229	153
C230	153
C231	153
C232	153

SYMBOL NO.	INDEX NO.
C233	153
C234	153
C235	153
C236	153
C237	153
C238	153
C239	153
C240	153
C241	153
C242	153

SYMBOL NO.	INDEX NO.
C243	153
C244	153
C245	153
C246	153
C247	153
C248	153
C249	153
C250	153
C251	153
C252	153

SYMBOL NO.	INDEX NO.
C253	153
C254	153
C255	153
C256	154
C257	153
C258	153
C259	153
C260	153
C261	153
C262	153

SYMBOL NO.	INDEX NO.
C263	154
C264	154
C265	154
C266	154
C267	153
C268	154
C269	154
C270	153
C271	153
C272	153

SYMBOL NO.	INDEX NO.
C273	153
C274	153
C275	153
C276	153
C277	153
C278	153
C279	153
C280	153
C281	153
C282	153

SYMBOL NO.	INDEX NO.
C283	153
C284	153
C285	153
C286	153
C287	153
C288	152
C289	152
C290	152
C291	152
C292	152

SYMBOL NO.	INDEX NO.
C293	152
C294	152
C295	152
C297	153
C298	167

COIL

SYMBOL NO.	INDEX NO.
L201	156
L202	155
L203	155
L204	168
L205	168

CONNECTOR

SYMBOL NO.	INDEX NO.
CN411	116
CN412	118
CN413	118
CN414	119
CN415	117
CN416	115
CN417	120

DIODE

SYMBOL NO.	INDEX NO.
D201	166
D202	166
D203	124
D204	124
D205	166
D206	124
D207	166
D208	166
D209	124
D210	124

SYMBOL NO.	INDEX NO.
D211	166
D212	166
D213	124
D214	124
D215	166
D216	166
D217	124
D218	124
D219	166
D220	166

46. PROCESS CONTROL BOARD (A092)

IC

SYMBOL NO.	INDEX NO.
D221	124
D222	124
D223	127

SYMBOL NO.	INDEX NO.
IC201	143
IC202	143
IC203	143
IC204	143
IC205	143
IC206	143
IC207	130
IC208	134
IC209	130
IC210	134

SYMBOL NO.	INDEX NO.
IC211	134
IC212	134
IC213	143
IC214	143
IC215	143
IC216	143
IC217	141
IC218	141
IC219	141
IC220	132

SYMBOL NO.	INDEX NO.
IC221	128
IC222	139
IC223	136
IC224	136
IC225	136
IC226	138
IC227	135
IC228	133
IC229	139
IC230	139

SYMBOL NO.	INDEX NO.
IC231	136
IC232	136
IC233	136
IC234	136
IC235	139
IC236	139
IC237	131
IC238	1
(IC238)	121
IC239	137

SYMBOL NO.	INDEX NO.
IC240	129
IC241	140
IC242	142
IC243	129
IC244	129
IC245	132
IC246	132
IC247	132
IC248	132

OSC

SYMBOL NO.	INDEX NO.
OSC201	144

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY201	147
RAY202	147
RAY203	147
RAY204	147
RAY205	147
RAY206	147
RAY207	146
RAY208	147
RAY209	146
RAY210	146

RESISTOR

SYMBOL NO.	INDEX NO.
RAY211	147
RAY212	147
RAY213	149
RAY214	149
RAY215	147
RAY216	147
RAY217	147
RAY218	148

SYMBOL NO.	INDEX NO.
R201	160
R202	160
R203	160
R204	160
R205	160
R206	160
R207	160
R208	160
R209	160
R210	160

SYMBOL NO.	INDEX NO.
R211	160
R212	160
R213	160
R214	160
R215	160
R216	160
R217	160
R218	160
R219	160
R220	160

SYMBOL NO.	INDEX NO.
R221	160
R222	160
R223	160
R224	160
R225	160
R226	160
R227	160
R228	160
R229	160
R230	160

SYMBOL NO.	INDEX NO.
R231	160
R232	160
R233	160
R234	160
R235	160
R236	145
R237	145
R238	145
R239	145
R240	145

SYMBOL NO.	INDEX NO.
R252	159
R253	158
R254	160
R258	159
R259	158
R260	159
R261	158
R262	159
R263	158
R265	162

46. PROCESS CONTROL BOARD (A092)

SYMBOL NO.	INDEX NO.
R266	162
R267	162
R268	162
R269	162
R270	162
R271	159
R272	159
R273	159
R274	159
R275	159

SYMBOL NO.	INDEX NO.
R276	162
R277	162
R278	162
R279	162
R280	162
R281	162
R282	162
R283	162
R284	162
R285	162

SYMBOL NO.	INDEX NO.
R286	157
R287	157
R288	157
R289	160
R290	161
R291	161
R292	160
R293	160
R294	160
R295	160

SYMBOL NO.	INDEX NO.
R296	160
R297	160
R298	160
R299	160
R300	160
R301	160
R302	161
R303	160
R304	160
R305	161

SYMBOL NO.	INDEX NO.
R306	161
R307	160
R308	161
R309	160
R310	161
R311	160
R312	161
R313	160
R314	161
R315	160

SYMBOL NO.	INDEX NO.
R316	161
R317	163
R318	163
R319	163
R320	163
R321	163
R322	163
R323	163
R324	163
R325	163

SYMBOL NO.	INDEX NO.
R326	163
R327	163
R328	163
R329	163
R330	163
R331	163
R332	163
R333	163
R334	163
R335	163

SYMBOL NO.	INDEX NO.
R336	163
R337	163
R338	163
R339	163
R340	163
R341	160
R342	162
R343	160
R344	161
R345	162

SYMBOL NO.	INDEX NO.
R346	165
R347	164

TEST POINT

SYMBOL NO.	INDEX NO.
TP201	114
TP202	114
TP203	114
TP204	114
TP205	114
TP206	114
TP207	114
TP208	114
TP209	114
TP210	114

SYMBOL NO.	INDEX NO.
TP211	114
TP212	114
TP213	114
TP214	114
TP215	114
TP216	114
TP217	114
TP218	114
TP219	114
TP220	114

SYMBOL NO.	INDEX NO.
TP221	114

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q201	122
Q202	122
Q203	122
Q204	122
Q205	122
Q206	123

ZENER DIODE

SYMBOL NO.	INDEX NO.
ZD201	126
ZD202	125
ZD203	125
ZD204	125

46. PROCESS CONTROL BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 5420	Process Control Board	1
1	A092 5509	IC - HN27C256G-26	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1102 2979	Connector - 14P	
102	1206 0032	Lithium Cell - BR2325-1HC	
103	1401 0296	Transistor - 2SA1162Y	
104	1401 0298	Transistor - 2SC2712YT	
105	1402 0476	Diode - 1SS184	
106	1402 0682	Zener Diode - RD3.6M	
107	1407 1741	IC - SN74LS32NS	
108	1407 3511	IC - MPD43256AGU-15L	
109	1606 1454	Capacitor - 0.01uF 25V	
110	1610 0067	Resistor - 4.7k Ω 1/8W $\pm$ 5%	
111	1610 0890	Resistor - 160 Ω $\pm$ 5% 1/8W	
112	1630 2103	Resistor - 10K Ω 1/8W	
113	1630 2152	Resistor - 1.5K Ω 1/8W $\pm$ 5%	
114	1101 0328	Connector Pin Contact	
115	1102 2986	Connector - 14P	
116	1103 0649	Connector - 50P	
117	1103 0651	Connector - 34P	
118	1103 0652	Plug-26P	
119	1103 0655	Connector - 16P	
120	1103 0778	Connector - 2P	
121	1104 0271	IC Socket - 28P	
122	1400 0510	Transistor - 2SC1623	
123	1401 0296	Transistor - 2SA1162Y	
124	1402 0476	Diode - 1SS184	
125	1402 0633	Diode - RD3.9MB2	
126	1402 0688	Diode	
127	1402 0696	Diode - MA704	
128	1407 1535	IC - TD62308AP	
129	1407 1600	IC - SN74LS244NS	
130	1407 1723	IC - TC4052BF	
131	1407 1730	IC - TC74HC154P	
132	1407 2187	IC - SN74LS07NS	
133	1407 2304	IC - SN74LS161ANS	
134	1407 2348	IC - TC4051BF	
135	1407 2510	IC - D78C10G	

47. IPU MEMORY BOARD (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.
C500	116
C501	117
C502	117
C503	117
C504	117
C505	117
C506	117
C507	117
C508	117
C509	117

SYMBOL NO.	INDEX NO.
C510	117
C511	117
C512	120
C513	120
C514	120
C515	120
C516	120
C517	120
C518	120
C519	120

SYMBOL NO.	INDEX NO.
C520	120
C521	120
C522	120
C523	120
C524	120
C525	120
C526	120
C527	120
C528	120
C529	120

SYMBOL NO.	INDEX NO.
C530	120
C531	120
C532	120
C533	120
C534	120
C535	120
C536	120
C537	120
C538	120
C539	120

SYMBOL NO.	INDEX NO.
C540	120
C541	120
C542	120
C543	120
C544	120
C545	120
C546	120
C547	120
C548	117
C549	117

SYMBOL NO.	INDEX NO.
C550	117
C551	117
C552	117
C553	120
C554	120
C555	120
C556	120
C557	117
C558	117
C559	117

SYMBOL NO.	INDEX NO.
C560	117
C561	117
C562	117
C563	120
C564	120
C565	117
C566	117
C567	117
C568	117
C569	117

SYMBOL NO.	INDEX NO.
C570	117
C571	117
C572	117
C573	117
C574	117
C575	117
C576	117
C577	117
C578	117
C579	117

SYMBOL NO.	INDEX NO.
C580	117
C581	117
C582	117
C583	117
C584	120
C585	120
C586	120
C587	120
C588	120
C589	120

SYMBOL NO.	INDEX NO.
C590	120
C591	120
C592	120
C593	117
C594	120
C595	120
C596	120
C597	120
C598	120
C599	120

SYMBOL NO.	INDEX NO.
C600	120
C601	120
C602	120
C603	120
C604	120
C605	120
C606	120
C607	120
C608	120
C609	120

SYMBOL NO.	INDEX NO.
C610	120
C611	120
C612	120
C613	120
C614	120
C615	120
C616	120
C617	120
C618	120
C619	120

SYMBOL NO.	INDEX NO.
C620	120
C621	120
C622	120
C623	120
C624	120
C625	120
C626	120
C627	120
C628	120
C629	120

SYMBOL NO.	INDEX NO.
C630	120
C631	120
C632	120
C633	120
C634	120
C635	120
C636	120
C637	120
C638	120
C639	120

47. IPU MEMORY BOARD (A092)

SYMBOL NO.	INDEX NO.
C640	120
C641	120
C642	120
C643	120
C644	120
C645	120
C646	120
C647	120
C648	120
C649	120

SYMBOL NO.	INDEX NO.
C650	120
C651	120
C652	120
C653	120
C654	120
C655	120
C656	120
C657	120
C658	120
C659	120

SYMBOL NO.	INDEX NO.
C660	120
C661	120
C662	120
C663	120
C664	120
C665	120
C666	120
C667	120
C668	120
C669	120

SYMBOL NO.	INDEX NO.
C670	120
C671	120
C672	120
C673	120
C674	120
C675	120
C676	120
C677	120
C678	120
C679	120

SYMBOL NO.	INDEX NO.
C680	120
C681	120
C682	120
C683	120
C684	120
C685	120
C686	120
C687	120
C688	120
C689	120

SYMBOL NO.	INDEX NO.
C690	120
C691	120
C692	120
C693	117
C694	117

COIL

SYMBOL NO.	INDEX NO.
L500	121
L501	121

CONNECTOR

SYMBOL NO.	INDEX NO.
CN141	103
CN142	103
CN143	103
CN144	105
CN145	104

IC

SYMBOL NO.	INDEX NO.
IC500	110
IC501	110
IC502	110
IC503	110
IC504	110
IC505	110
IC506	110
IC507	110
IC508	110
IC509	110

SYMBOL NO.	INDEX NO.
IC510	110
IC511	110
IC512	110
IC513	110
IC514	110
IC515	110
IC516	110
IC517	110
IC518	110
IC519	110

SYMBOL NO.	INDEX NO.
IC520	110
IC521	110
IC522	110
IC523	110
IC524	110
IC525	110
IC526	110
IC527	110
IC528	110
IC529	110

SYMBOL NO.	INDEX NO.
IC530	110
IC531	110
IC532	110
IC533	110
IC534	110
IC535	110
IC536	110
IC537	110
IC538	110
IC539	110

SYMBOL NO.	INDEX NO.
IC540	110
IC541	110
IC542	110
IC543	110
IC544	110
IC545	110
IC546	110
IC547	110
IC548	110
IC549	110

SYMBOL NO.	INDEX NO.
IC550	110
IC551	110
IC552	110
IC553	110
IC554	110
IC555	110
IC556	110
IC557	110
IC558	110
IC559	110

47. IPU MEMORY BOARD (A092)

SYMBOL NO.	INDEX NO.
IC560	110
IC561	110
IC562	110
IC563	110
IC564	110
IC565	110
IC566	110
IC567	110
IC568	110
IC569	110

SYMBOL NO.	INDEX NO.
IC570	110
IC571	110
IC572	110
IC573	110
IC574	110
IC575	110
IC576	110
IC577	110
IC578	110
IC579	110

SYMBOL NO.	INDEX NO.
IC580	110
IC581	110
IC582	110
IC583	110
IC584	110
IC585	110
IC586	110
IC587	110
IC588	110
IC589	110

SYMBOL NO.	INDEX NO.
IC590	110
IC591	110
IC592	110
IC593	110
IC594	110
IC595	110
IC596	110
IC597	110
IC598	110
IC599	110

SYMBOL NO.	INDEX NO.
IC600	110
IC601	110
IC602	110
IC603	110
IC604	110
IC605	110
IC606	110
IC607	110
IC608	111
IC609	111

SYMBOL NO.	INDEX NO.
IC610	111
IC611	111
IC612	111
IC613	111
IC614	111
IC615	111
IC616	106
IC617	106
IC618	106
IC619	2

SYMBOL NO.	INDEX NO.
IC620	111
IC621	111
IC622	111
IC623	111
IC624	3
IC625	111
IC626	111
IC627	111
IC628	111
IC629	111

SYMBOL NO.	INDEX NO.
IC630	111
IC631	111
IC632	1
IC633	106
IC634	106
IC635	109
IC636	108
IC637	106
IC638	106
IC639	110

SYMBOL NO.	INDEX NO.
IC640	110
IC641	110
IC642	110
IC643	110
IC644	110
IC645	110
IC646	110
IC647	110
IC648	110
IC649	110

SYMBOL NO.	INDEX NO.
IC650	110
IC651	110
IC652	110
IC653	110
IC654	110
IC655	110
IC656	110
IC657	110
IC658	110
IC659	110

SYMBOL NO.	INDEX NO.
IC660	110
IC661	110
IC662	110
IC663	110
IC664	110
IC665	110
IC666	110
IC667	110
IC668	110
IC669	110

SYMBOL NO.	INDEX NO.
IC670	110
IC671	110
IC672	110
IC673	110
IC674	110
IC675	106
IC676	106
IC677	111
IC678	111
IC679	111

SYMBOL NO.	INDEX NO.
IC680	111
IC681	111
IC682	111
IC683	111
IC684	111
IC685	107

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY500	112
RAY501	113
RAY502	114
RAY503	115
RAY504	114
RAY505	115
RAY506	114
RAY507	115

47. IPU MEMORY BOARD (A092)

RESISTOR

SYMBOL NO.	INDEX NO.
R500	118
R501	118
R502	118
R503	118
R504	118
R505	118
R506	118
R507	118
R508	118
R509	118

SYMBOL NO.	INDEX NO.
R510	118
R511	118
R512	118
R513	118
R514	118
R515	118
R516	118
R517	118
R518	118
R519	118

SYMBOL NO.	INDEX NO.
R520	118
R521	118
R522	118
R523	118
R524	118
R525	118
R526	118
R527	118
R528	118
R529	118

SYMBOL NO.	INDEX NO.
R530	118
R531	118
R532	118
R533	118
R534	118
R535	118
R536	118
R537	118
R538	118
R539	118

SYMBOL NO.	INDEX NO.
R540	118
R541	118
R542	118
R543	118
R544	118
R545	118
R546	118
R547	118
R548	118
R549	118

SYMBOL NO.	INDEX NO.
R550	118
R551	118
R552	118
R553	118
R554	118
R555	118
R556	118
R557	118
R558	118
R559	118

SYMBOL NO.	INDEX NO.
R560	118
R561	118
R562	118
R563	118
R564	118
R565	118
R566	118
R567	118
R568	118
R569	118

SYMBOL NO.	INDEX NO.
R570	118
R571	118
R572	118
R573	118
R574	118
R575	118
R576	118
R577	118
R578	118
R579	118

SYMBOL NO.	INDEX NO.
R580	118
R581	118
R582	118
R583	118
R584	118
R585	118
R586	118
R587	118
R588	118
R589	118

SYMBOL NO.	INDEX NO.
R590	118
R591	118
R592	118
R593	118
R595	119
R596	119
R597	119
R598	119
R599	119
R600	119

SYMBOL NO.	INDEX NO.
R601	119
R602	119
R603	119
R604	118
R605	118
R606	118
R607	118
R608	118
R609	118
R610	119

SYMBOL NO.	INDEX NO.
R611	119
R612	119
R613	119
R614	118
R615	118
R616	118
R617	118
R618	118
R619	118
R620	118

SYMBOL NO.	INDEX NO.
R621	118
R622	118
R623	118
R624	119
R625	119
R626	118
R627	118
R628	118
R629	118
R630	119

SYMBOL NO.	INDEX NO.
R631	118
R632	118
R633	118
R634	118
R635	118
R636	118
R637	118
R638	118
R639	118
R640	118

47. IPU MEMORY BOARD (A092)

SYMBOL NO.	INDEX NO.
R641	118
R642	118
R643	118
R644	118
R645	118
R646	118
R647	118
R648	118
R649	118
R650	118

SYMBOL NO.	INDEX NO.
R651	118
R652	118
R653	118
R654	118
R655	119
R656	118
R657	118
R658	118
R659	118
R660	118

SYMBOL NO.	INDEX NO.
R661	118
R662	118
R663	118
R664	118
R665	118
R666	118
R667	118
R668	118
R669	118
R670	118

SYMBOL NO.	INDEX NO.
R671	118
R672	118
R673	118
R674	118
R675	118
R676	118
R677	118
R678	118
R679	118
R680	118

SYMBOL NO.	INDEX NO.
R681	118
R682	118
R683	118
R684	118
R685	118
R686	118
R687	118
R688	118
R689	118
R690	118

SYMBOL NO.	INDEX NO.
R691	118
R692	118
R693	118
R694	118
R695	118
R696	118
R697	118
R698	118
R699	118
R700	118

SYMBOL NO.	INDEX NO.
R701	118
R702	118
R703	118
R704	118
R705	118
R706	118
R707	118
R708	118
R709	118
R710	118

TEST POINT

SYMBOL NO.	INDEX NO.
R711	118
R712	118
R713	118
R714	118
R715	118
R716	122
R717	122
R718	122
R719	122
R720	122

SYMBOL NO.	INDEX NO.
R721	122
R722	122
R723	122

SYMBOL NO.	INDEX NO.
TP500	102
TP501	102
TP502	102
TP503	102
TP504	102
TP505	102
TP506	102
TP507	102
TP508	102
TP509	102

SYMBOL NO.	INDEX NO.
TP510	102
TP511	102
TP512	102
TP513	102
TP514	102
TP515	102
TP516	102
TP517	102
TP518	102
TP519	102

SYMBOL NO.	INDEX NO.
TP520	102

47. IPU MEMORY BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5130	IPU Memory Board	1
1	A049 5132	IC - SLA7340F2H	1
2	A049 5133	IC - SLA7160F0J	1
3	A049 5134	IC - SLA7800F0R	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1102 2165	Connector - 1P	
104	1103 1317	Connector	
105	1103 1489	Connector - 3P	
106	1407 1600	IC - SN74LS244NS	
107	1407 1880	IC - SN74LS04NS	
108	1407 2077	IC - SN74LS138NS	
109	1407 2081	IC - SN74LS08NS	
110	1407 2558	IC - 1MX1BIT	
111	1407 3082	IC - SN74AS244NS	
112	1601 7346	Resistor Array - 470 Ω $\pm$ 5% 1/2W	
113	1601 7368	Resistor Array - 470 Ω $\pm$ 5% 1/8W	
114	1601 7373	Resistor Array - 3.3k Ω	
115	1601 7375	Resistor Array - 6.8k Ω	
116	1604 1357	Capacitor - 470mF, 10V	
117	1606 1451	Capacitor - 0.1uF 50V	
118	1610 0025	Resistor - 22 Ω 1/8W $\pm$ 5%	
119	1610 0067	Resistor - 4.7k Ω 1/8W $\pm$ 5%	
120	1605 0283	Capacitor - 1uF	
121	1607 0062	SN Coil - SN-5-400	
122	1610 0042	Resistor - 200 Ω 1/8W $\pm$ 5%	

48. IPU BOARD 1 (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C300	118	C310	119	C320	119	C330	119	C340	124	C350	124	C360	119
C301	119	C311	119	C321	119	C331	119	C341	124	C351	124	C361	119
C302	119	C312	119	C322	124	C332	124	C342	124	C352	124	C362	119
C303	119	C313	119	C323	124	C333	119	C343	124	C353	119	C363	119
C304	124	C314	124	C324	124	C334	119	C344	124	C354	124	C364	119
C305	124	C315	124	C325	124	C335	124	C345	124	C355	124	C365	119
C306	119	C316	124	C326	124	C336	119	C346	119	C356	124		
C307	119	C317	124	C327	119	C337	119	C347	124	C357	124		
C308	124	C318	124	C328	124	C338	124	C348	119	C358	124		
C309	124	C319	119	C329	119	C339	124	C349	124	C359	119		

COIL

SYMBOL NO.	INDEX NO.
L301	120

IC

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
IC300	9	IC310	106	IC320	106	IC330	2	IC340	5	IC350	123
IC301	4	IC311	7	IC321	2	IC331	1	IC341	108	IC351	1
IC302	111	IC312	4	IC322	123	IC332	106	IC342	106	IC352	110
IC303	3	IC313	111	IC323	123	IC333	108	IC343	123	IC353	106
IC304	111	IC314	3	IC324	1	IC334	1	IC344	123	IC354	113
IC305	106	IC315	111	IC325	106	IC335	2	IC345	110	IC355	107
IC306	8	IC316	10	IC326	1	IC336	6	IC346	106	IC356	112
IC307	4	IC317	4	IC327	123	IC337	6	IC347	1	IC357	109
IC308	111	IC318	111	IC328	123	IC338	6	IC348	2	IC358	125
IC309	3	IC319	3	IC329	106	IC339	1	IC349	123	IC359	125

CONNECTOR

SYMBOL NO.	INDEX NO.
CN121	103
CN122	103
CN123	103
CN124	105
CN125	104

48. IPU BOARD 1 (A092)

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY301	114
RAY302	115
RAY303	116
RAY304	117
RAY305	116
RAY306	117
RAY307	116
RAY308	117

RESISTOR

SYMBOL NO.	INDEX NO.
R300	122
R301	122
R303	122
R304	122
R305	122
R306	122
R307	122
R308	121
R309	122
R312	122

SYMBOL NO.	INDEX NO.
R313	122
R314	122
R315	122
R316	122
R318	122
R319	122
R320	122
R321	122
R322	122
R324	122

SYMBOL NO.	INDEX NO.
R325	122
R326	122
R327	122
R328	122
R329	122
R330	122
R331	122
R332	122
R333	122
R334	122

SYMBOL NO.	INDEX NO.
R335	122
R336	122
R337	122
R338	122
R339	122
R340	122
R341	122
R342	122
R343	122
R344	122

SYMBOL NO.	INDEX NO.
R345	122
R346	122
R348	122
R349	122
R350	122
R351	122
R352	122
R353	122
R354	122
R355	122

SYMBOL NO.	INDEX NO.
R356	122
R357	122
R358	122
R359	122
R362	122
R363	122
R367	122
R368	122
R370	122

TEST POINT

SYMBOL NO.	INDEX NO.
TP300	102
TP301	102
TP302	102
TP306	102
TP307	102
TP308	102

48. IPU BOARD 1 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5100	IPU Board 1	1
1	A049 5102	IC - TC23SC080AF-501	3
2	A049 5103	IC - MB604161	3
3	A049 5104	IC - MB652461U	1
4	A049 5106	IC - RF5GF21-017	1
5	A049 5107	Oscillator - CX0-104B-11.6668	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1102 2165	Connector - 1P	
104	1102 4873	Connector - 60P	
105	1103 0402	Pin Header - 26P	
106	1407 1600	IC - SN74LS244NS	
107	1407 1741	IC - SN74LS32NS	
108	1407 1746	IC - SN74LS240NS	
109	1407 1879	IC - SN74LS86ANS	
110	1407 1880	IC - SN74LS04NS	
111	1407 1994	IC - SN74LS30NS	
112	1407 2052	IC - NS74LS74ANS	
113	1407 2077	IC - SN74LS138NS	
114	1407 2081	IC - SN74LS08NS	
115	1407 2247	IC - SN74LS164NS	
116	1407 2249	IC - SN74LS174NS	
117	1407 2347	IC - SN74LS161NS	
118	1407 2890	IC - CXK5864BM-70L	
119	1407 3485	IC - M5M5256BFP-85L	
120	1601 7373	Resistor Array - 3.3k Ω	
121	1601 7375	Resistor Array - 6.8k Ω	
122	1604 1355	Capacitor - 220mF 10V	
123	1606 1451	Capacitor - 0.1uF 50V	
124	1607 0026	SN Coil - SN-12-500	
125	1610 0053	Resistor - 1K Ω 1/8W $\pm 5\%$	
126	1610 0067	Resistor - 4.7K Ω 1/8W $\pm 5\%$	
127	1407 3268	IC - UPD42505C-50H	
128	1605 0283	Capacitor - 1uF	

49. IPU BOARD 1.5 (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.
C401	118
C402	118
C403	119
C404	119
C405	119
C406	119
C407	119
C408	119
C409	119
C410	119

SYMBOL NO.	INDEX NO.
C411	119
C412	119
C413	119
C414	119
C415	119
C416	119
C417	119
C418	119
C419	119
C420	119

SYMBOL NO.	INDEX NO.
C421	119
C422	119
C423	119
C424	119
C425	119
C426	119
C427	119
C428	119
C429	119
C430	119

SYMBOL NO.	INDEX NO.
C431	119
C432	119
C433	119
C434	119
C435	119
C436	119
C437	119
C438	119
C439	119
C440	119

SYMBOL NO.	INDEX NO.
C441	119
C442	119
C443	119
C444	119
C445	119
C446	119
C447	119
C448	119
C449	119
C450	119

SYMBOL NO.	INDEX NO.
C451	119
C452	119
C453	119
C454	119
C455	119
C456	119
C457	119
C458	119
C459	119
C460	119

SYMBOL NO.	INDEX NO.
C461	119
C462	119
C463	119
C464	119
C465	119
C466	119
C467	119
C468	119
C469	119
C470	119

COIL

SYMBOL NO.	INDEX NO.
L401	122
L402	122

CONNECTOR

SYMBOL NO.	INDEX NO.
CN131	103
CN132	103
CN133	103
CN134	104
CN135	104

IC

SYMBOL NO.	INDEX NO.
IC401	114
IC402	114
IC403	114
IC404	3
IC405	114
IC406	114
IC407	4
IC408	2
IC409	2
IC410	2

SYMBOL NO.	INDEX NO.
IC411	114
IC412	114
IC413	114
IC414	115
IC415	115
IC416	115
IC417	115
IC418	115
IC419	115
IC420	114

SYMBOL NO.	INDEX NO.
IC421	114
IC422	114
IC423	114
IC424	114
IC425	114
IC426	114
IC427	114
IC428	114
IC429	114
IC430	114

SYMBOL NO.	INDEX NO.
IC431	114
IC432	114
IC433	105
IC434	1
IC435	1
IC436	1
IC437	121
IC438	111
IC439	112
IC440	121

SYMBOL NO.	INDEX NO.
IC441	111
IC442	111
IC443	113
IC444	111
IC445	108
IC446	111
IC447	112
IC448	121
IC449	109
IC450	113

49. IPU BOARD 1.5 (A092)

SYMBOL NO.	INDEX NO.
IC451	111
IC452	106
IC453	107
IC454	110
IC455	105
IC456	109
IC457	109
IC458	110
IC459	105
IC460	121

SYMBOL NO.	INDEX NO.
IC461	121
IC462	110
IC463	105
IC464	114

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY401	116
RAY402	117
RAY403	116
RAY404	117
RAY405	116
RAY406	117
RAY407	116
RAY408	117

RESISTOR

SYMBOL NO.	INDEX NO.
R401	120
R402	120
R403	120
R404	120
R405	120
R406	120
R407	120
R408	120
R409	120
R410	120

SYMBOL NO.	INDEX NO.
R411	120
R412	120
R413	120
R414	120
R415	120
R416	120
R417	120
R418	120
R419	120
R420	120

SYMBOL NO.	INDEX NO.
R421	120

TEST POINT

SYMBOL NO.	INDEX NO.
TP401	102
TP402	102
TP403	102

49. IPU BOARD 1.5 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5140	IPU Board 1.5	1
1	A049 5105	IC - RF5GF58-025	3
2	A049 5112	IC - MB87494	10
3	A049 5142	IC - RF5GF45-032	1
4	A049 5143	IC - RF5GV161-012	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1102 2165	Connector - 1P	
104	1103 0402	Pin Header - 26P	
105	1407 1600	IC - SN74LS244NS	
106	1407 1783	IC - SN74LS02NS	
107	1407 1879	IC - SN74LS86ANS	
108	1407 1880	IC - SN74LS04NS	
109	1407 2051	IC - SN74LS00NS	
110	1407 2077	IC - SN74LS138NS	
111	1407 2247	IC - SN74LS164NS	
112	1407 2252	IC - SN74LS257NS	
113	1407 2386	IC - SN74LS163NS	
114	1407 3268	IC - UPD42505C-50H	
115	1407 3475	IC - MSM514221-6RS	
116	1601 7373	Resistor Array - 3.3k Ω	
117	1601 7375	Resistor Array - 6.8k Ω	
118	1604 1355	Capacitor - 220mF 10V	
119	1606 1451	Capacitor - 0.1uF 50V	
120	1630 2472	Resistor - 4.7K Ω 1/8W $\pm$ 5%	
121	1407 1792	IC - SN74LS374NS	
122	1607 0062	SN Coil - SN-5-400	

50. IPU BOARD 2 (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.
C200	122
C201	123
C202	128
C203	128
C204	128
C205	128
C206	128
C207	128
C208	123
C209	128

SYMBOL NO.	INDEX NO.
C210	123
C211	123
C212	123
C213	123
C214	123
C215	123
C216	128
C217	128
C218	128
C220	128

SYMBOL NO.	INDEX NO.
C221	123
C222	123
C223	123
C224	128
C225	128
C226	128
C227	123
C228	123
C229	123
C230	123

SYMBOL NO.	INDEX NO.
C231	123
C232	123
C233	128
C234	123
C235	123
C236	123
C237	123
C238	123
C239	128
C240	128

SYMBOL NO.	INDEX NO.
C241	128
C242	128
C243	123
C244	123
C245	123
C246	128
C247	128
C248	128
C249	128
C250	128

SYMBOL NO.	INDEX NO.
C251	128
C252	128
C253	123
C255	123
C256	123
C257	128
C258	128
C259	128
C260	128
C262	128

SYMBOL NO.	INDEX NO.
C263	128
C264	123
C265	123
C266	123
C267	123
C268	123
C269	123
C270	123

GOIL

SYMBOL NO.	INDEX NO.
L200	124

IC

SYMBOL NO.	INDEX NO.
IC200	106
IC201	106
IC202	1
IC203	127
IC204	127
IC205	2
IC206	119
IC207	119
IC208	106
IC209	106

SYMBOL NO.	INDEX NO.
IC210	1
IC211	127
IC212	127
IC213	119
IC214	119
IC215	2
IC216	117
IC217	117
IC218	1
IC219	127

SYMBOL NO.	INDEX NO.
IC220	127
IC221	119
IC222	119
IC223	112
IC224	107
IC225	109
IC226	107
IC227	114
IC228	113
IC229	2

SYMBOL NO.	INDEX NO.
IC230	106
IC231	106
IC233	127
IC234	127
IC235	106
IC236	106
IC237	106
IC238	106
IC240	127
IC241	127

SYMBOL NO.	INDEX NO.
IC242	3
IC243	106
IC244	4
IC245	106
IC247	127
IC248	127
IC249	118
IC250	118
IC251	118
IC252	108

SYMBOL NO.	INDEX NO.
IC253	115
IC254	106
IC255	106
IC256	116
IC257	114
IC258	107
IC259	111
IC260	110

CONNECTOR

SYMBOL NO.	INDEX NO.
CN111	103
CN112	103
CN113	103
CN114	104
CN115	105

50. IPU BOARD 2 (A092)

OSC

SYMBOL NO.	INDEX NO.
OSC200	5

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY200	120
RAY201	121
RAY202	120
RAY203	121
RAY204	120
RAY205	121
RAY206	121
RAY207	120
RAY208	121
RAY209	120

SYMBOL NO.	INDEX NO.
RAY210	121
RAY211	120
RAY212	121
RAY213	120

RESISTOR

SYMBOL NO.	INDEX NO.
R200	126
R201	126
R202	126
R203	126
R204	126
R205	126
R206	126
R207	126
R208	126
R209	126

SYMBOL NO.	INDEX NO.
R210	126
R211	126
R212	126
R213	126
R214	126
R215	126
R216	126
R217	126
R218	126
R219	126

SYMBOL NO.	INDEX NO.
R220	126
R221	126
R222	126
R223	126
R224	126
R225	126
R226	126
R227	126
R232	126
R233	126

SYMBOL NO.	INDEX NO.
R254	126
R255	126
R256	126
R257	126
R258	126
R260	126
R261	126
R262	126
R263	126
R264	126

TEST POINT

SYMBOL NO.	INDEX NO.
R265	126
R266	126
R267	126
R268	126
R269	126
R270	126
R271	126
R272	126
R273	126
R274	126

SYMBOL NO.	INDEX NO.
R275	126
R276	126
R277	126
R278	126
R279	125

SYMBOL NO.	INDEX NO.
TP200	102
TP201	102
TP202	102
TP203	102
TP204	102
TP205	102
TP206	102
TP207	102
TP208	102
TP209	102

SYMBOL NO.	INDEX NO.
TP210	102
TP211	102
TP212	102

50. IPU BOARD 2 (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5160	IPU Board 2	1
1	A049 5112	IC - MB87494	10
2	A049 5113	IC - RF5C83	4
3	A049 5115	IC - TC17G042AF-0236	4
4	A049 5116	IC - RF5C61	4
5	A049 5121	IC - TC110G11AF-023	1
6	A049 5126	IC - UPD27C1000AD-12	3
7	A049 5152	IC - RF5C65-0011	1
8	A049 5153	IC - RF5C65-0012	1
9	A049 5154	IC - RF5C65-0013	1
10	A049 5162	IC - RF5C65-0015	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1102 2165	Connector - 1P	
104	1103 0402	Pin Header - 26P	
105	1103 1489	Connector - 3P	
106	1407 1600	IC - SN74LS244NS	
107	1407 1880	IC - SN74LS04NS	
108	1407 2077	IC - SN74LS138NS	
109	1407 2081	IC - SN74LS08NS	
110	1407 2890	IC - CXK5864BM-70L	
111	1407 3268	IC - UPD42505C-50H	
112	1407 3481	IC - SN74AS32NS	
113	1407 3482	IC - SN74LS377NS	
114	1601 7351	Resistor Array - 3.3k Ω	
115	1601 7353	Resistor Array - 6.8k Ω	
116	1601 7373	Resistor Array - 3.3k Ω	
117	1601 7375	Resistor Array - 6.8k Ω	
118	1604 1355	Capacitor - 220mF 10V	
119	1606 1451	Capacitor - 0.1uF 50V	
120	1607 0026	SN Coil - SN-12-500	
121	1630 2102	Resistor - 1K Ω 1/8W $\pm 5\%$	
122	1630 2472	Resistor - 4.7K Ω 1/8W $\pm 5\%$	
123	1407 1792	IC - SN74LS374NS	
124	1605 0283	Capacitor - 1uF	
125	1407 2252	IC - SN74LS257NS	

51. SYSTEM CONTROL BOARD (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.
C101	135
C102	135
C103	135
C104	135
C105	135
C106	135
C107	135
C108	135
C109	133
C110	134

SYMBOL NO.	INDEX NO.
C111	135
C112	135
C113	135
C114	135
C115	135
C116	135
C117	135
C118	135
C119	135
C120	135

SYMBOL NO.	INDEX NO.
C121	135
C122	135
C123	135
C124	135
C125	135
C126	135
C127	135
C128	135
C129	135
C130	135

SYMBOL NO.	INDEX NO.
C131	135
C132	135
C133	135
C134	135
C135	135
C136	135
C137	135
C138	135
C139	135

COIL

SYMBOL NO.	INDEX NO.
L101	109

CONNECTOR

SYMBOL NO.	INDEX NO.
CN101	103
CN103	103
CN104	105
CN105	104
CN106	106
CN108	139
CN109	107

DPS

SYMBOL NO.	INDEX NO.
DPS101	140

FLT

SYMBOL NO.	INDEX NO.
FLT101	130
FLT102	131
FLT103	131
FLT104	132

IC

SYMBOL NO.	INDEX NO.
IC101	117
IC102	117
IC103	113
IC104	121
IC105	111
IC106	121
IC107	124
IC108	115
IC109	116
IC110	116

SYMBOL NO.	INDEX NO.
IC111	113
IC112	112
IC113	113
IC114	141
IC115	118
IC116	118
IC117	118
IC118	119
IC119	119
IC120	120

SYMBOL NO.	INDEX NO.
IC121	123
IC122	114
IC123	113
IC124	1
(IC124)	108
IC125	5
(IC125)	108
IC126	3
(IC126)	108
IC127	113

SYMBOL NO.	INDEX NO.
IC128	113
IC129	4
(IC129)	108
IC130	2
(IC130)	108
IC131	115
IC132	115
IC133	115
IC134	115

OSC

SYMBOL NO.	INDEX NO.
OSC101	125

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY101	128
RAY102	128
RAY103	126
RAY104	127
RAY105	129
RAY106	128
RAY107	128
RAY108	128
RAY109	128
RAY110	128

SYMBOL NO.	INDEX NO.
RAY111	127
RAY112	129
RAY113	126
RAY114	126

51. SYSTEM CONTROL BOARD (A092)

RESISTOR

SYMBOL NO.	INDEX NO.
R101	137
R102	138
R103	137
R104	138
R105	137
R106	138
R107	136

TEST POINT

SYMBOL NO.	INDEX NO.
TP101	102
TP102	102
TP103	102
TP104	102
TP105	102
TP106	102
TP107	102
TP108	102
TP109	102
TP110	102

SYMBOL NO.	INDEX NO.
TP111	102
TP112	102
TP113	102
TP114	102

ZENER DIODE

SYMBOL NO.	INDEX NO.
ZD101	110

51. SYSTEM CONTROL BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 5404	System Control Board	1
1	A092 5504	IC - MBM27C512-20CZ	1
2	A092 5525	IC - MBM27C512-20CZ	1
3	A092 5526	IC - MBM27C512-20CZ	1
4	A092 5527	IC - MBM27C512-20CZ	1
5	A092 5528	IC - MBM27C512-20CZ	1
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1102 2165	Connector - 1P	
104	1102 4960	Optical Connector - Red	
105	1102 4962	Optical Connector - White	
106	1103 0779	Connector - 2P	

Index No.	Part No.	Description	Q'ty per Assembly
107	1103 1614	Socket	
108	1104 0271	IC Socket - 28P	
109	1201 0039	Coil	
110	1402 0501	Zener Diode	
111	1407 0610	IC - SN74LS32N	
112	1407 0621	IC - SN74LS08N	
113	1407 0887	IC - SN74LS244N	
114	1407 1016	IC - D8255AC-2	
115	1407 1026	IC - SN74LS373N	
116	1407 2318	IC - SN74AS138N	
117	1407 2671	IC - HM62256LP-15	
118	1407 2753	IC - D71051C	
119	1407 2868	IC - MPD71059C	
120	1407 2870	IC - MPD71054C	
121	1407 2871	IC - MPD70116C-8	
122	1407 3476	IC - UPB8284AD	
123	1407 3477	IC - 74AC04	
124	1408 0494	IC - MB3371P	
125	1503 0195	Oscillator - 24MHz	
126	1601 7348	Resistor Array - 470 Ω 1/8W $\pm$ 5%	
127	1601 7370	Resistor Array - 1k Ω	
128	1601 7376	Resistor Array - 10k Ω $\pm$ 5% 1/8W	
129	1601 7422	Resistor - 2K Ω $\pm$ 5%	
130	1602 0922	Capacitor - 100pF $\pm$ 20%	
131	1602 7011	Capacitor - 270pF $\pm$ 20% 50V	
132	1602 7029	Noise Filter - 22000pF 50V	
133	1604 1376	Capacitor - 0.33uF 50V	
134	1604 1986	Capacitor - 220mF 50V	
135	1606 1336	Capacitor - 10000pF -20% +80% 50V	
136	1611 4102	Resistor - 1K Ω 1/4T $\pm$ 5%	
137	1611 4221	Resistor - 220 Ω 1/4T $\pm$ 5%	
138	1611 4222	Resistor - 2.2K Ω 1/4T $\pm$ 5%	
139	1102 4961	Optical Connector - Blue	
140	1204 1422	DIP Switch	
141	1407 1970	IC - SN74LS07N	

52. MEMORY BOARD (A092)

BAT

SYMBOL NO.	INDEX NO.
BAT201	102

CONNECTOR

SYMBOL NO.	INDEX NO.
CN201	101

IC

SYMBOL NO.	INDEX NO.
IC201	108
IC202	108
IC203	107

RESISTOR

SYMBOL NO.	INDEX NO.
R201	113
R202	111
R203	110
R204	113
R205	112

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q201	104
Q202	103

CAPACITOR

SYMBOL NO.	INDEX NO.
C201	109
C202	109
C203	109

DIODE

SYMBOL NO.	INDEX NO.
D201	105
D202	105

ZENER DIODE

SYMBOL NO.	INDEX NO.
ZD201	106

52. MEMORY BOARD (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5410	Memory Board	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1103 1608	Socket	
102	1206 0032	Lithium Cell - BR2325-1HC	
103	1401 0296	Transistor - 2SA1162Y	
104	1401 0298	Transistor - 2SC2712YT	
105	1402 0476	Diode - 1SS184	
106	1402 0682	Zener Diode - RD3.6M	
107	1407 1741	IC - SN74LS32NS	
108	1407 3511	IC - MPD43256AGU-15L	
109	1606 1454	Capacitor - 0.01uF 25V	
110	1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	
111	1610 0890	Resistor - 160 Ω $\pm 5\%$ 1/8W	
112	1630 2103	Resistor - 10K Ω 1/8W	
113	1630 2152	Resistor - 1.5K Ω 1/8W $\pm 5\%$	

53. LASER UNIT CONTROL BOARD - BK,Y (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C600	148	C610	149	C620	148	C630	148	C640	147	C650	157	C660	157
C601	148	C611	148	C621	148	C631	150	C641	157	C651	157	C661	157
C602	148	C612	148	C622	158	C632	148	C642	156	C652	157	C662	157
C603	148	C613	148	C623	148	C633	148	C643	156	C653	157	C663	153
C604	149	C614	150	C624	148	C634	158	C644	157	C654	157	C664	157
C605	148	C615	148	C625	148	C635	148	C645	157	C655	157	C665	157
C606	148	C616	148	C626	148	C636	148	C646	157	C656	157	C666	157
C607	148	C617	148	C627	148	C637	148	C647	157	C657	156	C667	157
C608	149	C618	148	C628	148	C638	148	C648	157	C658	157	C668	157
C609	148	C619	148	C629	148	C639	148	C649	157	C659	157	C669	157

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C670	157	C680	157	C690	157	C700	157	C710	157	C720	157	C730	157
C671	157	C681	157	C691	152	C701	157	C711	157	C721	157	C731	157
C672	157	C682	178	C692	157	C702	157	C712	157	C722	157	C732	157
C673	157	C683	157	C693	157	C703	157	C713	157	C723	157	C733	157
C674	157	C684	157	C694	157	C704	157	C714	157	C724	157	C734	157
C675	157	C685	157	C695	157	C705	157	C715	157	C725	157	C735	157
C676	157	C686	157	C696	157	C706	157	C716	157	C726	157	C736	154
C677	157	C687	157	C697	157	C707	157	C717	153	C727	157	C737	154
C678	157	C688	157	C698	157	C708	157	C718	157	C728	157	C738	151
C679	157	C689	157	C699	157	C709	157	C719	157	C729	157	C739	155

53. LASER UNIT CONTROL BOARD - BK,Y (A092)

SYMBOL NO.	INDEX NO.
C740	157
C741	157
C742	157
C743	157
C744	157
C745	157
C746	157
C747	157
C748	157
C749	157

SYMBOL NO.	INDEX NO.
C750	157
C751	157
C752	157
C753	157
C754	157
C755	157
C756	152
C757	157
C758	157
C759	157

SYMBOL NO.	INDEX NO.
C760	157
C761	157
C762	157
C763	157
C764	157
C765	157
C766	157
C767	157
C768	157
C769	157

SYMBOL NO.	INDEX NO.
C770	157
C771	157
C772	157
C773	157
C774	158
C775	157
C776	157
C777	157
C778	157
C779	157

SYMBOL NO.	INDEX NO.
C780	157
C781	157
C782	157
C783	157
C784	157
C785	157
C786	157
C787	157
C788	157
C789	157

SYMBOL NO.	INDEX NO.
C790	157
C791	157
C792	157
C793	157
C794	157
C795	157
C796	157
C797	157
C798	157
C799	157

SYMBOL NO.	INDEX NO.
C800	157
C801	157
C802	157
C803	157
C804	157
C805	157
C806	157
C807	157
C808	157
C809	157

SYMBOL NO.	INDEX NO.
C810	157
C811	157
C812	157
C813	157

COIL

SYMBOL NO.	INDEX NO.
L600	159
L601	159
L602	159
L603	159
L604	162
L605	159
L606	161
L607	161
L608	159
L609	159

SYMBOL NO.	INDEX NO.
L610	159
L611	159
L612	159
L613	159
L614	159
L615	163
L616	160
L617	159
L618	159
L619	159

SYMBOL NO.	INDEX NO.
L620	159
L621	160
L622	160
L623	159
L624	160
L625	159
L626	160
L627	160
L628	163

CONNECTOR

SYMBOL NO.	INDEX NO.
CN151	103
CN153	104
CN154	106
CN155	107
CN156	105
CN157	5

DGS

SYMBOL NO.	INDEX NO.
DGS600	181
DGS601	181
DGS602	181
DGS603	109
DGS604	109
DGS605	109
DGS606	110
DGS607	110
DGS608	110
DGS609	111

SYMBOL NO.	INDEX NO.
DGS610	111
DGS611	111

53. LASER UNIT CONTROL BOARD - BK,Y (A092)

DIODE

SYMBOL NO.	INDEX NO.
D600	113

DL

SYMBOL NO.	INDEX NO.
DL600	124
DL601	124
DL602	183
DL603	183
DL604	183
DL605	125
DL606	125
DL607	183
DL608	183
DL609	183

SYMBOL NO.	INDEX NO.
DL610	124
DL611	124

IC

SYMBOL NO.	INDEX NO.
IC600	117
IC601	127
IC602	127
IC603	127
IC604	3
(IC604)	108
IC605	130
IC606	130
IC607	130
IC608	129
IC609	133

SYMBOL NO.	INDEX NO.
IC610	133
IC611	133
IC612	137
IC613	136
IC614	182
IC615	2
IC616	1
IC617	126
IC618	133
IC619	131

SYMBOL NO.	INDEX NO.
IC620	128
IC621	138
IC622	182
IC624	131
IC625	132
IC626	122
IC627	120
IC628	134
IC629	135
IC630	138

SYMBOL NO.	INDEX NO.
IC631	127
IC632	127
IC633	127
IC634	4
(IC634)	108
IC635	126
IC636	133
IC637	131
IC638	123
IC639	115

SYMBOL NO.	INDEX NO.
IC640	136
IC641	137
IC642	133
IC643	133
IC644	133
IC645	135
IC646	138
IC647	2
IC648	1
IC649	130

SYMBOL NO.	INDEX NO.
IC650	130
IC651	130
IC652	128
IC653	122
IC654	120
IC655	134
IC656	138
IC657	182
IC658	129
IC659	121

SYMBOL NO.	INDEX NO.
IC660	118
IC661	182
IC662	117
IC663	118
IC664	182
IC665	182
IC666	182
IC667	118
IC668	182
IC669	116

LED

SYMBOL NO.	INDEX NO.
LED600	114
LED601	114

OSC

SYMBOL NO.	INDEX NO.
OSC600	139
OSC601	140

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY600	145
RAY601	145
RAY602	145
RAY603	145
RAY604	145
RAY605	146
RAY606	146
RAY607	145
RAY608	146
RAY609	142

SYMBOL NO.	INDEX NO.
RAY610	141
RAY611	145
RAY612	145
RAY613	145
RAY614	146
RAY615	146
RAY616	146
RAY617	143
RAY618	144
RAY619	144

SYMBOL NO.	INDEX NO.
RAY620	143
RAY621	144
RAY622	143
RAY623	145
RAY624	145
RAY625	145
RAY626	144
RAY627	143

53. LASER UNIT CONTROL BOARD - BK,Y (A092)

RESISTOR

SYMBOL NO.	INDEX NO.
R600	167
R601	166
R602	166
R603	166
R604	166
R605	166
R606	166
R607	166
R608	173
R609	166

SYMBOL NO.	INDEX NO.
R610	174
R611	174
R612	174
R613	169
R614	166
R615	171
R616	174
R617	177
R618	172
R619	179

SYMBOL NO.	INDEX NO.
R620	171
R621	176
R622	176
R623	180
R624	170
R625	168
R626	165
R627	175
R628	164
R629	171

SYMBOL NO.	INDEX NO.
R630	174
R631	177
R632	172
R633	164
R634	175
R635	173
R636	176
R637	176
R638	179
R639	173

SYMBOL NO.	INDEX NO.
R640	180
R641	174
R642	174
R643	174
R644	170
R645	168
R646	165
R647	169
R648	166
R649	171

SYMBOL NO.	INDEX NO.
R650	166
R651	167

TEST POINT

SYMBOL NO.	INDEX NO.
TP600	102
TP601	102
TP602	102

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q600	112
Q601	112

53. LASER UNIT CONTROL BOARD - BK,Y (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5464	Laser Unit Control Board - BK,Y	1
1	A049 5540	IC - RF5GF21-017	4
2	A049 5541	IC - RF5GF21-019	4
3	A049 5530	IC - HN27C256G-26	1
4	A049 5531	IC - HN27C256G-26	1
5	G003 2630	Fiber Connector	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1102 2165	Connector - 1P	
104	1102 4869	Connector - 44P	
105	1102 4965	Optical Connector - White	
106	1103 1317	Connector	
107	1103 1256	Connector	
108	1104 0516	IC Socket - 28P	
109	1204 2189	Digital Switch	
110	1204 2191	Digital Switch	
111	1204 2192	Digital Switch	
112	1400 0087	Transistor - 2SC1815	
113	1401 0611	Diode - IS1588	
114	1403 0652	LED - Red	
115	1407 0539	IC - SN74LS04N	
116	1407 0610	IC - SN74LS32N	
117	1407 0711	IC - 74LS151	
118	1407 0887	IC - SN74LS244N	
119	1407 1073	IC - SN74LS283N	
120	1407 1402	IC: TTL, SN74LS628N	
121	1407 2028	IC - SN74LS06N	
122	1407 2960	IC - TC5081AP	
123	1407 3439	IC - TC5082P	
124	1407 3440	IC - DS1000M-75	
125	1407 3441	IC - DS1000M-20	
126	1407 3442	IC - N74F133N	
127	1407 3448	IC - CKX5864BSP-70L	
128	1407 3449	IC - TC9122P	
129	1407 3450	IC - SN74LS19N	
130	1407 3451	IC - N74F175N	
131	1407 3452	IC - N74F74N	
132	1407 3453	IC - N74F20N	
133	1407 3454	IC - N74F10N	
134	1408 0722	IC - SN76514N	
135	1408 0812	IC - AD847JN	

Index No.	Part No.	Description	Q'ty per Assembly
136	1408 0813	IC - TA78L005AP	
137	1408 0814	IC - TA79L005P	
138	1408 0815	IC - NJM360D	
139	1503 0368	Oscillator - 3579.545KHz	
140	1503 0369	Oscillator - 6MHz	
141	1601 7345	Resistor - 330 Ω	
142	1601 7347	Resistor - 680 Ω	
143	1601 7367	Resistor Array - 330 Ω	
144	1601 7369	Resistor Array - 680 Ω	
145	1601 7374	Resistor Array - 4.7K Ω	
146	1601 7376	Resistor Array - 10k Ω $\pm$ 5% 1/8W	
147	1604 1363	Capacitor - 10uF $\pm$ 20% 25V	
148	1604 1366	Capacitor - 47uF $\pm$ 20% 25V	
149	1604 1369	Capacitor - 330uF $\pm$ 20%	
150	1604 1783	Capacitor - 220uF 25V	
151	1605 0108	Capacitor - 33pF	
152	1605 0142	Capacitor - 220pF 50V	
153	1605 0358	Capacitor - 6pF	
154	1605 0359	Capacitor - 22pF 50V	
155	1605 0369	Capacitor - 47pF 50V	
156	1605 0517	Capacitor - 330pF +80 -20% 50V	
157	1606 1140	Capacitor - 0.1uF +80%-20%	
158	1606 1584	Capacitor - 0.47uF 50V	
159	1607 0069	Fuse - BL02RN2-R62-PB	
160	1607 0152	Inductor - 47uH	
161	1607 0426	SN Coil - SF-T3-20-01	
162	1607 0427	SN Coil - SF-T10-30	
163	1607 0429	Coil - 154AN-42038N	
164	1610 0026	Resistor - 24 Ω 1/8W	
165	1610 0031	Resistor - 47 Ω 1/8W	
166	1610 0035	Resistor - 100 Ω 1/8W $\pm$ 5%	
167	1610 0036	Resistor - 110 Ω 1/8W $\pm$ 5%	
168	1610 0048	Resistor - 390 Ω 1/8W $\pm$ 5%	
169	1610 0053	Resistor - 1k Ω 1/8W $\pm$ 5%	
170	1610 0058	Resistor - 1.6 k Ω 1/8W $\pm$ 5%	

Index No.	Part No.	Description	Q'ty per Assembly
171	1610 0061	Resistor - 2.2k Ω 1/8W $\pm$ 5%	
172	1610 0063	Resistor - 2.7k Ω 1/8W	
173	1610 0067	Resistor - 4.7k Ω 1/8W $\pm$ 5%	
174	1610 0071	Resistor - 10k Ω $\pm$ 5% 1/8W	
175	1610 0074	Resistor - 13k Ω 1/8W $\pm$ 5%	
176	1610 0076	Resistor - 16K Ω 1/8W	
177	1610 0100	Resistor - 300K Ω 1/8W	
178	1610 0286	Capacitor - 100pF 50V $\pm$ 10%	
179	1610 0649	Resistor - 620 Ω $\pm$ 5% 1/8W	
180	1610 0652	Resistor - 3.6K Ω $\pm$ 5% 1/8W	
181	1204 2190	DIP Switch	
182	1407 1130	IC - SN74LS240N	
183	1607 0339	IC - DS1000H-50	

54. LASER UNIT CONTROL BOARD - M,C (A092)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C600	149	C610	150	C620	149	C630	149	C640	148	C650	158	C660	158
C601	149	C611	149	C621	149	C631	151	C641	158	C651	158	C661	158
C602	149	C612	149	C622	159	C632	149	C642	157	C652	158	C662	158
C603	149	C613	149	C623	149	C633	149	C643	157	C653	158	C663	154
C604	150	C614	151	C624	149	C634	159	C644	158	C654	158	C664	158
C605	149	C615	149	C625	149	C635	149	C645	158	C655	158	C665	158
C606	149	C616	149	C626	149	C636	149	C646	158	C656	158	C666	158
C607	149	C617	149	C627	149	C637	149	C647	158	C657	157	C667	158
C608	150	C618	149	C628	149	C638	149	C648	158	C658	158	C668	158
C609	149	C619	149	C629	149	C639	149	C649	158	C659	158	C669	158

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C670	158	C680	158	C690	158	C700	158	C710	158	C720	158	C730	158
C671	158	C681	158	C691	153	C701	158	C711	158	C721	158	C731	158
C672	158	C682	179	C692	158	C702	158	C712	158	C722	158	C732	158
C673	158	C683	158	C693	158	C703	158	C713	158	C723	158	C733	158
C674	158	C684	158	C694	158	C704	158	C714	158	C724	158	C734	158
C675	158	C685	158	C695	158	C705	158	C715	158	C725	158	C735	158
C676	158	C686	158	C696	158	C706	158	C716	158	C726	158	C736	155
C677	158	C687	158	C697	158	C707	158	C717	154	C727	158	C737	155
C678	158	C688	158	C698	158	C708	158	C718	158	C728	158	C738	152
C679	158	C689	158	C699	158	C709	158	C719	158	C729	158	C739	156

54. LASER UNIT CONTROL BOARD - M,C (A092)

SYMBOL NO.	INDEX NO.
C740	158
C741	158
C742	158
C743	158
C744	158
C745	158
C746	158
C747	158
C748	158
C749	158

SYMBOL NO.	INDEX NO.
C750	158
C751	158
C752	158
C753	158
C754	158
C755	158
C756	153
C757	158
C758	158
C759	158

SYMBOL NO.	INDEX NO.
C760	158
C761	158
C762	158
C763	158
C764	158
C765	158
C766	158
C767	158
C768	158
C769	158

SYMBOL NO.	INDEX NO.
C770	158
C771	158
C772	158
C773	158
C774	179
C775	158
C776	158
C777	158
C778	158
C779	158

SYMBOL NO.	INDEX NO.
C780	158
C781	158
C782	158
C783	158
C784	158
C785	158
C786	158
C787	158
C788	158
C789	158

SYMBOL NO.	INDEX NO.
C790	158
C791	158
C792	158
C793	158
C794	158
C795	158
C796	158
C797	158
C798	158
C799	158

SYMBOL NO.	INDEX NO.
C800	158
C801	158
C802	158
C803	158
C804	158
C805	158
C806	158
C807	158
C808	158
C809	158

COIL

SYMBOL NO.	INDEX NO.
C810	158
C811	158
C812	158
C813	158

SYMBOL NO.	INDEX NO.
L600	160
L601	160
L602	160
L603	160
L604	163
L605	160
L606	162
L607	162
L608	160
L609	160

SYMBOL NO.	INDEX NO.
L610	160
L611	160
L612	160
L613	160
L614	160
L615	164
L616	161
L617	160
L618	160
L619	160

SYMBOL NO.	INDEX NO.
L620	160
L621	161
L622	161
L623	160
L624	161
L625	160
L626	161
L627	161
L628	164

CONNECTOR

SYMBOL NO.	INDEX NO.
CN151	103
CN153	104
CN154	106
CN155	108
CN156	105
CN157	5

DGS

SYMBOL NO.	INDEX NO.
DGS600	181
DGS601	181
DGS602	181
DGS603	109
DGS604	109
DGS605	109
DGS606	110
DGS607	110
DGS608	110
DGS609	111

SYMBOL NO.	INDEX NO.
DGS610	111
DGS611	111

54. LASER UNIT CONTROL BOARD - M,C (A092)

DIODE

SYMBOL NO.	INDEX NO.
D600	113

DL

SYMBOL NO.	INDEX NO.
DL600	124
DL601	124
DL602	183
DL603	183
DL604	183
DL605	125
DL606	125
DL607	183
DL608	183
DL609	183

SYMBOL NO.	INDEX NO.
DL610	124
DL611	124

IC

SYMBOL NO.	INDEX NO.
IC600	117
IC601	128
IC602	128
IC603	128
IC604	3
(IC604)	109
IC605	130
IC606	130
IC607	130
IC608	129
IC609	133

SYMBOL NO.	INDEX NO.
IC610	133
IC611	133
IC612	138
IC613	137
IC614	182
IC615	2
IC616	1
IC617	126
IC618	133
IC619	131

SYMBOL NO.	INDEX NO.
IC620	129
IC621	139
IC622	182
IC624	131
IC625	132
IC626	123
IC627	120
IC628	135
IC629	136
IC630	129

SYMBOL NO.	INDEX NO.
IC631	128
IC632	128
IC633	128
IC634	4
(IC634)	109
IC635	126
IC636	133
IC637	131
IC638	124
IC639	115

SYMBOL NO.	INDEX NO.
IC640	137
IC641	138
IC642	133
IC643	133
IC644	133
IC645	136
IC646	139
IC647	2
IC648	1
IC649	130

SYMBOL NO.	INDEX NO.
IC650	130
IC651	130
IC652	129
IC653	123
IC654	120
IC655	135
IC656	139
IC657	182
IC658	129
IC659	121

SYMBOL NO.	INDEX NO.
IC660	118
IC661	182
IC662	117
IC663	118
IC664	182
IC665	182
IC666	182
IC667	118
IC668	182
IC669	116

LED

SYMBOL NO.	INDEX NO.
LED600	115
LED601	115

OSC

SYMBOL NO.	INDEX NO.
OSC600	140
OSC601	141

RESISTOR ARRAY

SYMBOL NO.	INDEX NO.
RAY600	146
RAY601	146
RAY602	146
RAY603	146
RAY604	146
RAY605	147
RAY606	147
RAY607	146
RAY608	147
RAY609	143

SYMBOL NO.	INDEX NO.
RAY610	142
RAY611	146
RAY612	146
RAY613	146
RAY614	147
RAY615	147
RAY616	147
RAY617	144
RAY618	145
RAY619	145

SYMBOL NO.	INDEX NO.
RAY620	144
RAY621	145
RAY622	144
RAY623	146
RAY624	146
RAY625	146
RAY626	145
RAY627	144

54. LASER UNIT CONTROL BOARD - M,C (A092)

RESISTOR

SYMBOL NO.	INDEX NO.
R600	168
R601	167
R602	167
R603	167
R604	167
R605	167
R606	167
R607	167
R608	174
R609	167

SYMBOL NO.	INDEX NO.
R610	175
R611	175
R612	175
R613	170
R614	167
R615	172
R616	175
R617	178
R618	173
R619	180

SYMBOL NO.	INDEX NO.
R620	172
R621	177
R622	177
R623	181
R624	171
R625	169
R626	166
R627	176
R628	165
R629	172

SYMBOL NO.	INDEX NO.
R630	175
R631	178
R632	173
R633	165
R634	176
R635	174
R636	177
R637	177
R638	180
R639	174

SYMBOL NO.	INDEX NO.
R640	181
R641	175
R642	175
R643	175
R644	171
R645	169
R646	166
R647	170
R648	167
R649	172

SYMBOL NO.	INDEX NO.
R650	167
R651	168

TEST POINT

SYMBOL NO.	INDEX NO.
TP600	102
TP601	102
TP602	102

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q600	113
Q601	113

54. LASER UNIT CONTROL BOARD - M,C (A092)


Index No.	Part No.	Description	Q'ty per Assembly
*	A049 5465	Laser Unit Control Board - M,C	1
1	A049 5540	IC - RF5GF21-017	4
2	A049 5541	IC - RF5GF21-019	4
3	A049 5532	IC - HN27C256G-26	1
4	A049 5533	IC - HN27C256G-26	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1005 0528	Card Puller	
102	1101 0328	Connector Pin Contact	
103	1102 2165	Connector - 1P	
104	1102 4869	Connector - 44P	
105	1102 4963	Optical Connector - Red	
106	1102 4964	Optical Connector - Blue	
107	1103 1317	Connector	
108	1103 1256	Connector	
109	1104 0516	IC Socket - 28P	
110	1204 2189	Digital Switch	
111	1204 2191	Digital Switch	
112	1204 2192	Digital Switch	
113	1400 0087	Transistor - 2SC1815	
114	1401 0611	Diode - IS1588	
115	1403 0652	LED - Red	
116	1407 0539	IC - SN74LS04N	
117	1407 0610	IC - SN74LS32N	
118	1407 0711	IC - 74LS151	
119	1407 0887	IC - SN74LS244N	
120	1407 1073	IC - SN74LS283N	
121	1407 1402	IC: TTL, SN74LS628N	
122	1407 2028	IC - SN74LS06N	
123	1407 2960	IC - TC5081AP	
124	1407 3439	IC - TC5082P	
125	1407 3440	IC - DS1000M-75	
126	1407 3441	IC - DS1000M-20	
127	1407 3442	IC - N74F133N	
128	1407 3448	IC - CKX5864BSP-70L	
129	1407 3449	IC - TC9122P	
130	1407 3450	IC - SN74LS19N	
131	1407 3451	IC - N74F175N	
132	1407 3452	IC - N74F74N	
133	1407 3453	IC - N74F20N	
134	1407 3454	IC - N74F10N	
135	1408 0722	IC - SN76514N	

Index No.	Part No.	Description	Q'ty per Assembly
136	1408 0812	IC - AD847JN	
137	1408 0813	IC - TA78L005AP	
138	1408 0814	IC - TA79L005P	
139	1408 0815	IC - NJM360D	
140	1503 0368	Oscillator - 3579.545KHz	
141	1503 0369	Oscillator - 6MHz	
142	1601 7345	Resistor - 330 Ω	
143	1601 7347	Resistor - 680 Ω	
144	1601 7367	Resistor Array - 330 Ω	
145	1601 7369	Resistor Array - 680 Ω	
146	1601 7374	Resistor Array - 4.7K Ω	
147	1601 7376	Resistor Array - 10k Ω $\pm 5\%$ 1/8W	
148	1604 1363	Capacitor - 10uF $\pm 20\%$ 25V	
149	1604 1366	Capacitor - 47uF $\pm 20\%$ 25V	
150	1604 1369	Capacitor - 330uF $\pm 20\%$	
151	1604 1783	Capacitor - 220uF 25V	
152	1605 0108	Capacitor - 33pF	
153	1605 0142	Capacitor - 220pF 50V	
154	1605 0358	Capacitor - 6pF	
155	1605 0359	Capacitor - 22pF 50V	
156	1605 0369	Capacitor - 47pF 50V	
157	1605 0517	Capacitor - 330pF +80 -20% 50V	
158	1606 1140	Capacitor - 0.1uF +80%-20%	
159	1606 1584	Capacitor - 0.47uF 50V	
160	1607 0069	Fuse - BL02RN2-R62-PB	
161	1607 0152	Inductor - 47uH	
162	1607 0426	SN Coil - SF-T3-20-01	
163	1607 0427	SN Coil - SF-T10-30	
164	1607 0429	Coil - 154AN-42038N	
165	1610 0026	Resistor - 24 Ω 1/8W	
166	1610 0031	Resistor - 47 Ω 1/8W	
167	1610 0035	Resistor - 100 Ω 1/8W $\pm 5\%$	
168	1610 0036	Resistor - 110 Ω 1/8W $\pm 5\%$	
169	1610 0048	Resistor - 390 Ω 1/8W $\pm 5\%$	
170	1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	

Index No.	Part No.	Description	Q'ty per Assembly
171	1610 0058	Resistor - 1.6 k Ω 1/8W $\pm 5\%$	
172	1610 0061	Resistor - 2.2k Ω 1/8W $\pm 5\%$	
173	1610 0063	Resistor - 2.7k Ω 1/8W	
174	1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	
175	1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	
176	1610 0074	Resistor - 13k Ω 1/8W $\pm 5\%$	
177	1610 0076	Resistor - 16K Ω 1/8W	
178	1610 0100	Resistor - 300K Ω 1/8W	
179	1610 0286	Capacitor - 100pF 50V $\pm 10\%$	
180	1610 0649	Resistor - 620 Ω $\pm 5\%$ 1/8W	
181	1610 0652	Resistor - 3.6K Ω $\pm 5\%$ 1/8W	
182	1204 2190	DIP Switch	
183	1407 1130	IC - NS74LS240N	
184	1607 0339	IC - DS1000H-50	

55. AC HARNESS (A092)




55. AC HARNESS (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 5621	AC Harness	1

Index No.	Part No.	Description	Q'ty per Assembly
101	1100 0350	Closed Terminal	
102	1100 0853	Closed Terminal	
103	1100 0916	Connector - 2P	
104	1100 1041	Pin - Mate-N-Lock	
105	1100 1042	Socket - Mate-N-Lock	
106	1100 1171	Fastening Receptacle	
107	1100 1172	Fastening Receptacle	
108	1100 1239	Pin - Mate-N-Lock	
109	1100 1240	Socket - Mate-N-Lock	
110	1102 0782	Connector - 4P	
111	1102 0983	Connector - 2P	
112	1102 0989	Connector - 9P	
113	1102 1005	Connector - 1P	
114	1102 1006	Pin Housing - 1P	
115	1102 1402	Receptacle Housing - 1P	
116	1102 1403	Receptacle Housing	
117	1102 1404	Connector - 1P	
118	1102 1524	Connector - 2P	
119	1102 1532	Connector - 2P	

56. FRONT DC HARNESS (A092)



56. FRONT DC HARNESS (A092)



Index No.	Part No.	Description	Q'ty per Assembly
*	A092 5695	Front DC Harness	1
101	1100 0350	Closed Terminal	
102	1100 0504	Closed Terminal - 44mm	

Index No.	Part No.	Description	Q'ty per Assembly
103	1100 0844	Socket - Mate-N-Lock	
104	1100 0853	Closed Terminal	
105	1100 1159	Socket - Mate-N-Lock	
106	1100 1172	Fastening Receptacle	
107	1100 1182	Socket - Mate-N-Lock	
108	1100 1238	Pin - Mate-N-Lock	
109	1100 1239	Pin - Mate-N-Lock	
110	1100 1240	Socket - Mate-N-Lock	
111	1100 1241	Socket - Mate-N-Lock	
112	1100 1247	Terminal	
113	1100 1259	Socket - Mate-N-Lock	
114	1100 1270	Fastening Receptacle	
115	1100 1271	Fastening Receptacle	
116	1100 1327	Contact	
117	1100 1520	Connector - 1P	
118	1100 1535	Pin Connect	
119	1102 0185	Connector - 4P	
120	1102 1307	Connector - 4P	
121	1102 1401	Receptacle Housing - 1P	
122	1102 1402	Receptacle Housing - 1P	
123	1102 1403	Receptacle Housing	
124	1102 1404	Connector - 1P	
125	1102 1412	Connector - 2P	
126	1102 1509	Connector - 4P	
127	1102 1511	Connector - 9P	
128	1102 1519	Connector - 9P	
129	1102 1524	Connector - 2P	
130	1102 1532	Connector - 2P	
131	1102 1741	Connector - 9P	
132	1102 1785	Connector - 11P	
133	1102 1911	Connector - 3P	
134	1102 2061	Connector - 6P	
135	1102 4932	Connector - 34P	
136	1103 0661	Connector	
137	1103 1622	Receptacle Housing - 17P	


57. REAR DC HARNESS (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A092 5696	Rear DC Harness	1
101	1100 0350	Closed Terminal	
102	1100 0853	Closed Terminal	
103	1100 1043	Pin - Mate-N-Lock	
104	1100 1182	Socket - Mate-N-Lock	
105	1100 1238	Pin - Mate-N-Lock	
106	1100 1239	Pin - Mate-N-Lock	
107	1100 1241	Socket - Mate-N-Lock	
108	1100 1247	Terminal	
109	1100 1259	Socket - Mate-N-Lock	
110	1100 1270	Fastening Receptacle	
111	1100 1271	Fastening Receptacle	
112	1100 1329	Socket Contact	
113	1100 1339	Pin Contact	
114	1100 1340	Terminal	
115	1100 1344	Pin Contact	
116	1100 1498	Connector - 1P	
117	1100 1499	Connector - 1P	
118	1100 1520	Connector - 1P	
119	1100 1535	Pin Connect	
120	1100 1536	Connector - 1P	
121	1102 0984	Connector - 2P	

Index No.	Part No.	Description	Q'ty per Assembly
122	1102 0990	Connector - 9P	
123	1102 1089	Connector - 3P	
124	1102 1091	Connector - 6P	
125	1102 1094	Connector - 12P	
126	1607 0323	Ferrite Core - ESD-QR-25	
127	1102 1412	Connector - 2P	
128	1102 1471	Connector - 7P	
129	1102 1511	Connector - 9P	
130	1102 1512	Connector - 12P	
131	1102 1513	Connector - 15P	
132	1102 1515	Connector - 2P	
133	1102 1516	Connector - 3P	
134	1102 1519	Connector - 9P	
135	1102 1529	Connector - 12P	
136	1102 1878	Connector - 3P	
137	1102 1982	Socket Housing - 2P	
138	1102 1983	Connector - 3P	
139	1102 2549	Connector - 2P	
140	1102 3981	Connector - 60P	
141	1102 4150	Connector - 4P	
142	1102 4162	Optional Connector - 10P	
143	1102 4402	Connector - 12P	
144	1102 4404	Connector - 32P	
145	1102 4931	Connector - 13P	
146	1102 4933	Connector - 34P	
147	1102 4935	Connector - 30P	
148	1103 0657	Connector - 50P	
149	1103 0658	Connector - 40P	
150	1103 0659	Connector - 34P	
151	1103 0660	Connector - 16P	
152	1103 0661	Connector	
153	1103 0662	Connector - 20P	
154	1103 0663	Connector - 16P	
155	1104 0506	Connector - 2P	
156	1607 0216	Ferrite Core ESD-R-47	


1	温度ヒューズ THERMAL CUTOFF 169°C	3	WARNING HIGH VOLTAGE	5		10	I On Stand by 
2		4	 OPEN	8	While pressing lever , open cover  until it stops.		
6						11	Push
7	Hold the grip and pull out the paper feed unit. 		9		● When the Add Toner indicator  is on, add toner. ● Add only one bottle of toner at a time.		

12



13


Removing Misfed Paper




Be careful not to damage the transparent belt when removing misfed paper.

14


Removing Misfed Paper




Turn knob **A** counterclockwise.




Remove misfed paper from the left side of the paper feed unit.




If paper cannot be removed, lift lever **A** and open the cover of the unit.



Remove misfed paper.



If paper cannot be removed, lift and hold lever **A** and remove misfed paper.



Close the cover of the paper feed unit and carefully push it back to its original position. Close the front doors.

15

Adding Toner



Push the toner unit. The unit will unlock and come out.



Check the new toner's color. Tap the new toner bottle to loosen the toner.



Shake the new bottle right and left, then up and down at least ten times each.



Open the cover of the toner unit. Align the arrows of the unit and the bottle, then press the toner bottle down until it sets in position.



While holding the toner bottle upright, turn it clockwise until it stops (about 180°). The toner will fall into the unit. Caution: Do not tap the toner bottle.



Check that the bottle is empty. Then turn it counterclockwise and remove it.



Slowly push the unit back in until it locks. Close the front doors.

Removing Misfed Paper

If A is blinking



Push down lever 1.



Hold the grip and pull out the paper feed unit.



To remove misfed paper, follow the instructions on the paper feed unit.



Close the cover of the paper feed unit and carefully push it back to its original position. Close the front doors.

If B is blinking



If paper misfed as it was coming out, pull and turn knob 1 clockwise. This will make the sheet come out completely.



If paper cannot be removed, push lever 2 down to the right. Pull out the paper transport unit.



Gently remove misfed paper.



If paper is in the fusing unit, while pressing lever 3, open cover 4 until it stops.



Turn knob 1 clockwise and remove misfed paper.





Close cover 4.



Return the paper transport unit by pressing lever 2. Return lever 2 to its original position. Make sure it locks.

16



17  CAUTION Hot Surface Avoid Contact ACHTUNG Heiße Oberfläche ATTENTION Surface Chaude Evitez Le Contact HP P6050 SL	18 	24 	25 
20 WARNING - Do not incinerate waste toner. - Toner dust may cause flashback when exposed to vopen flame.	21 	26 	27 
22 	23 		

28 A4210×297	30 A3A4 A4FD ← A3A4	31 Laserstrahl Rated Output Power 5mW 760nm-810nm	32 DANGER INVISIBLE LASER RADIATION WHEN OPEN, AVOID DIRECT EXPOSURE TO BEAM VORSICHT LASERSTRAHLUNG, WENN ABGEKAPPT, GEÖFFNET, NICHT DEM STRAHLE AUSSETZEN
29 A4210×297		33 OPERATING INSTRUCTIONS	






58. DECAL AND DOCUMENT (A092)

Index No.	Part No.	Description	Q'ty per Assembly
*	A382 1300	Multi Decal - French	1
*	A382 1301	Multi Decal - German	1
*	A382 1302	Multi Decal - Spanish	1
*	A382 1303	Multi Decal - Italian	1
*	A382 1305	Multi Decal - Operation - French	1
*	A382 1306	Multi Decal - Operation - German	1
*	A382 1307	Multi Decal - Operation - Spanish	1
*	A382 1308	Multi Decal - Operation - Italian	1
*	A382 1310	Multi Decal - Operation - French	1
1	5216 4145	Thermofuse Decal	1
2	5413 4835	Decal - Paper Level	6
3	5434 7916	High Voltage Decal	8
4	5447 4982	Decal - Open	4
5	A007 2802	Decal - Side Fence - Manual Feed	1
6	A012 8301	Decal - Drum Knob	8
7	A092 1391	Decal - Paper Feed Unit	1
8	A092 1392	Decal - Paper Exit	1
9	A092 1393	Decal - Adding Toner	1
10	A092 1394	Decal - Main Switch	1
11	A092 1395	Decal - Toner Tank	1
12	A092 1396	Decal - Back-up	1
13	A092 1397	Decal - Misfeed Removal - Transfer	1
14	A092 1398	Decal - Misfeed Removal - Small	1
15	A092 1399	Decal - Misfeed Removal - English	1
16	A092 7000	Editing Sheet - A4	1
17	AA00 0015	Decal - High Temperature	1
18	AA00 0042	Counter Decal - Color	1
19	AA00 0043	Counter Decal	1
20	AA00 0059	Caution Decal - English	1
21	AA00 1108	Electrical Power Decal	3
22	AA00 1140	Decal - B2	1
23	AA00 1147	Decal - A2	1
24	AA00 1159	Decal - A4	1
25	AA00 1160	Decal - B4	1
26	AA00 1190	Decal - Ground	2

Index No.	Part No.	Description	Q'ty per Assembly
27	AA00 2007	Decal - A3	3
27	AA00 2003	Decal - 8 1/2x14	3
28	AA00 2008	Decal - A4R	3
28	AA00 2005	Decal - 11x17	3
29	AA00 2009	Decal - A4	3
29	AA00 2004	Decal - 8 1/2x11R	3
30	AA00 2035	Decal - Manual Feed - Na	1
30	AA00 2030	Decal - Manual Feed - EU	1
31	5353 1267	Decal - Laser Caution	1
32	AA00 0035	Decal- LD	1
33	A092 8630	Operating Instructions - English (EU)	1
33	A092 8631	Operating Instructions - German	1
33	A092 8632	Operating Instructions - French	1
33	A092 8633	Operating Instructions - Italian	1
33	A092 8634	Operating Instructions - Spanish (EU)	1



59. SPECIAL TOOL (A092)

1	2	3	4	5
				
6	7	8	9	10
				
11	12	13		
				

59. SPECIAL TOOL (A092)

Index No.	Part No.	Description	Q'ty per Assembly
1	5442 9102	Light Shelding Bag	1
2	5420 9504	Thermo Meter - HLC	1
3	5420 9505	Probe - HLC-30	1
4	5420 9507	Digital Multimeter - Beckman	1
5	5420 9508	Test Lead Kit	1
6	5420 9550	Silicone Oil	1
7	5442 9103	Launa Oil 40	1
8	5447 9078	Heat Resisting Grease MT-78	1
8	A028 9300	Grease - Nok Barrierta JFE 5 5/2	1
9	5205 9101	Gap Gauge	1
10	5206 9600	Sensor Checker	1
11	A092 9504	DG Gauge	2
12	A008 9502	Silicone Grease - G40m	1
13	A092 9503	Test Chart - C4	3

Index No.	Part No.	Description	Q'ty per Assembly

PARTS INDEX

Part No.	Description	Paper and Index No.
A092 1253	Left Door Ass'y	11- 37
A092 1262	Right Door	11- 30
A092 1359	Upper Right Cover	11- 20
A092 1363	Lower Right Cover	11- 22
A092 1391	Decal - Paper Feed Unit	31- 27
A092 1391	Decal - Paper Feed Unit	141- 7
A092 1392	Decal - Paper Exit	59- 2
A092 1392	Decal - Paper Exit	141- 8
A092 1393	Decal - Adding Toner	45- 1
A092 1393	Decal - Adding Toner	141- 9
A092 1394	Decal - Main Switch	11- 40
A092 1394	Decal - Main Switch	141- 10
A092 1395	Decal - Toner Tank	45- 48
A092 1395	Decal - Toner Tank	141- 11
A092 1396	Decal - Back-up	51- 25
A092 1396	Decal - Back-up	141- 12
A092 1397	Decal - Misfeed Removal - Transfer	51- 23
A092 1397	Decal - Misfeed Removal - Transfer	141- 13
A092 1398	Decal - Misfeed Removal - Small	31- 30
A092 1398	Decal - Misfeed Removal - Small	141- 14
A092 1399	Decal - Misfeed Removal - English	11- 19
A092 1399	Decal - Misfeed Removal - English	141- 15
A092 1455	Operation Panel Cover	15- 1
A092 1460	Key Top Cover - Mode Selection	15- 2
A092 1461	Key Top Cover - Color Adjustment	15- 3
A092 1462	Decal - Mode Selection Cover	15- 4
A092 1463	Decal - Color Adjustment Cover	15- 5
A092 1464	Decal - Mode Selection	15- 6
A092 1465	Decal - Color Adjustment	15- 7
A092 1466	LED Cover	15- 8
A092 1467	Key Top - Start	15- 9
A092 1468	Key Top - R/#	15- 10
A092 1469	Key Top - Clear Mode	15- 11
A092 1470	Key Top - Program	15- 12
A092 1471	Key Top - Original Recognition	15- 13

Part No.	Description	Paper and Index No.
A092 1472	Key Top - Full Cover	15- 14
A092 1473	Key Top - C/S	15- 15
A092 1474	Key Top - 0	15- 16
A092 1475	Key Top - 1	15- 17
A092 1476	Key Top - 2	15- 18
A092 1477	Key Top - 3	15- 19
A092 1478	Key Top - 4	15- 20
A092 1479	Key Top - 5	15- 21
A092 1480	Key Top - 6	15- 22
A092 1481	Key Top - 7	15- 23
A092 1482	Key Top - 8	15- 24
A092 1483	Key Top - 9	15- 25
A092 1484	Key Top - Point	15- 26
A092 1485	Key Top - Darker	15- 27
A092 1486	Key Top - Lighter	15- 28
A092 1487	Key Top - Letter/Photo	15- 29
A092 1488	Key Top - Paper Selection	15- 30
A092 1489	Key Top - Cassette Select	15- 31
A092 1495	Key Top - Paper	15- 32
A092 1496	Key Top - Full Size	15- 33
A092 1497	Key Top - Zoom Up	15- 34
A092 1498	Key Top - Zoom Down	15- 35
A092 1499	Key Top - Black	15- 36
A092 1500	Key Top - White	15- 37
A092 1501	Key Top - Yellow	15- 38
A092 1502	Key Top - Orange	15- 39
A092 1503	Key Top - Red	15- 40
A092 1504	Key Top - Magenta	15- 41
A092 1505	Key Top - Blue	15- 42
A092 1506	Key Top - Cyan	15- 43
A092 1507	Key Top - Green	15- 44
A092 1508	Key Top - Light Green	15- 45
A092 1509	Key Top - User Color	15- 46
A092 1510	Right Key - Mode Select	15- 47
A092 1511	Left Key - Mode Select	15- 48

Part No.	Description	Paper and Index No.
A092 1512	Color Adjusting Key	15- 49
A092 1513	Shielding Sheet - Mode Key	15- 50
A092 1514	Shielding Sheet - Color Key	15- 51
A092 1515	Shielding Sheet - 10 Key	15- 52
A092 1516	Shielding Sheet - Mode Select Key	15- 53
A092 1520	Operation Panel Ass'y	15- *
A092 1522	Operation Panel Bracket	15- 64
A092 1572	Hinge	17- 2
A092 1585	Platen Cover Ass'y	17- 4
A092 1586	Bracket Stay	11- 2
A092 1590	Hinge Bracket	17- 3
A092 1591	Platen Cover Pad	17- 8
A092 1592	Platen Cover Sheet	17- 9
A092 1593	Support Sheet	17- 25
A092 1769	Harness Guide Plate	23- 13
A092 1956	Front Scale (LT)	19- 13
A092 1958	Right Scale (A4)	19- 21
A092 1959	Right Scale (LT)	19- 21
A092 2051	Laser Unit (220/240V)	27- *
A092 2057	Laser Unit (115V)	27- *
A092 2309	Plastic Screw - Main Corona	39- 6
A092 2424	Drum Shaft Knob	75- 12
A092 2446	Drum Unit Cover Handle	75- 8
A092 2531	By-pass Feed Table Ass'y (A4)	33- 4
A092 2665	Front Cover - Paper Feed	31- 28
A092 2700	By-pass Feed Table Ass'y (LT)	33- 4
A092 2771	Dampproof Sheet - 11x17	17- 11
A092 2772	Dampproof Sheet - 17 1/2x14	17- 11
A092 2773	Dampproof Sheet - 11x17 1/2	17- 11
A092 3501	Cleaning Unit - BK,M,Y	67- *
A092 3502	Cleaning Unit - C	67- *
A092 3592	Shielding Plate - BK,M,Y	67- 2
A092 3595	Shielding Plate - C	67- 3
A092 3850	Transfer Belt	47- 19
A092 3850	Transfer Belt	49- 19

Part No.	Description	Paper and Index No.
A092 3871	Transfer Unit Guide	49- 5
A092 3970	Transfer Unit Stay - BK,M,D	47- 21
A092 3973	Transfer Unit Stay - Y,C	47- 29
A092 3978	Stay Mylar	49- 32
A092 3983	Guide Mylar - Transfer Belt	49- 13
A092 3984	Guide Mylar - Transfer Belt	47- 23
A092 4024	Upper Exit Cover	59- 5
A092 4135	Roller Support Lever	63- 14
A092 4138	Pressure Shaft Knob	63- 21
A092 4139	Pressure Shaft	63- 16
A092 4480	Fusing Exit Cover	63- 1
A092 4490	Paper Exit Frame	81- 25
A092 5404	System Control Board	121- *
A092 5414	Sequence Control Board	91- 1
A092 5414	Sequence Control Board	105- *
A092 5420	Process Control Board	91- 14
A092 5420	Process Control Board	109- *
A092 5426	Main Motor Control Board (220/240V)	91- 21
A092 5426	Main Motor Control Board (220/240V)	101- *
A092 5432	By-pass Paper Size Sensor (LT)	33- 55
A092 5434	By-pass Paper Size Sensor (A4)	33- 55
A092 5440	SP Panel Board Ass'y	13- 27
A092 5446	Operation Panel Control Board	15- 58
A092 5452	Left Operation Panel Board	15- 57
A092 5457	Right Operation Panel Board	15- 56
A092 5458	Shielding Sheet - Control Board	15- 54
A092 5459	Left Shielding Sheet	15- 55
A092 5460	ROM Board	15- 59
A092 5504	IC - MBM27C512-20CZ	121- 1
A092 5507	IC - MBM27C512-20CZ	105- 1
A092 5509	IC - HN27C256G-26	109- 1
A092 5513	IC - MBM27C1001- 15	15- 60
A092 5514	IC - MBM27C1001- 15	15- 61
A092 5517	IC - MBM27C1001- 15	15- 62
A092 5518	IC - MBM27C1001- 15	15- 63

Part No.	Description	Paper and Index No.
A092 5525	IC - MBM27C512-20CZ	121- 2
A092 5526	IC - MBM27C512-20CZ	121- 3
A092 5527	IC - MBM27C512-20CZ	121- 4
A092 5528	IC - MBM27C512-20CZ	121- 5
A092 5609	Transport Belt Unit Harness	53- 1
A092 5618	Fusing Unit Harness	61-32
A092 5621	AC Harness	91-12
A092 5621	AC Harness	133- *
A092 5635	AC Harness - AC Out	87-24
A092 5636	Noise Filter Harness	91-27
A092 5643	Grounding Wire - Paper Feed	31-40
A092 5695	Front DC Harness	91- 4
A092 5695	Front DC Harness	135- *
A092 5696	Rear DC Harness	91-23
A092 5696	Rear DC Harness	137- *
A092 5722	Lightning Arrester Board (220/240V)	87-25
A092 5762	Thermofuse - 169;C	61- 2
A092 5800	Power Supply Unit Base	87-26
A092 5801	Power Supply Unit Panel	87-18
A092 5852	Safety Switch Bracket	13-20
A092 5853	Safety Switch Lever	13-16
A092 5882	PCB Cover	83-26
A092 6609	Door Support Plate	11-25
A092 6664	Retaining Ring - M29	91- 5
A092 6668	Noise Filter Bracket	91-26
A092 6669	Power Supply Cord Bracket (115V)	91- 7
A092 6670	Power Supply Cord Holder	91- 9
A092 6784	Toner Collection Tank	13-10
A092 7000	Editing Sheet - A4	141-16
A092 8630	Operating Instructions - English (EU)	141-33
A092 8631	Operating Instructions - German	141-33
A092 8632	Operating Instructions - French	141-33
A092 8633	Operating Instructions - Italian	141-33
A092 8634	Operating Instructions - Spanish (EU)	141-33
A092 9500	Charge Corona Wire - 10pcs/set	39-16

Part No.	Description	Paper and Index No.
A092 9500	Charge Corona Wire - 10pcs/set	51-36
A092 9502	OPC Drum	75-18
A092 9503	Test Chart - C4	143-13
A092 9504	DG Gauge	143-11

Part No.	Description	Paper and Index No.
AA00 0015	Decal - High Temperature	59- 4
AA00 0015	Decal - High Temperature	141- 17
AA00 0035	Decal - LD	27- 44
AA00 0035	Decal - LD	29- 26
AA00 0035	Decal - LD	141- 32
AA00 0042	Counter Decal - Color	77- 3
AA00 0042	Counter Decal - Color	141- 18
AA00 0043	Counter Decal	77- 4
AA00 0043	Counter Decal	141- 19
AA00 0059	Caution Decal - English	141- 20
AA00 1108	Electrical Power Decal	51- 22
AA00 1108	Electrical Power Decal	75- 1
AA00 1108	Electrical Power Decal	89- 8
AA00 1108	Electrical Power Decal	141- 21
AA00 1140	Decal - B2	59- 25
AA00 1140	Decal - B2	141- 22
AA00 1147	Decal - A2	31- 31
AA00 1147	Decal - A2	141- 23
AA00 1159	Decal - A4	31- 29
AA00 1159	Decal - A4	141- 24
AA00 1160	Decal - B4	59- 3
AA00 1160	Decal - B4	141- 25
AA00 1190	Decal - Ground	91- 6
AA00 1190	Decal - Ground	141- 26
AA00 2003	Decal - 8 1/2x14	17- 16
AA00 2003	Decal - 8 1/2x14	141- 27
AA00 2004	Decal - 11x17	17- 16
AA00 2004	Decal - 8 1/2x11R	141- 29
AA00 2005	Decal - 8 1/2x11R	17- 16
AA00 2005	Decal - 11x17	141- 28
AA00 2007	Decal - A3	17- 16
AA00 2007	Decal - A3	141- 27
AA00 2008	Decal - A4R	17- 16
AA00 2008	Decal - A4R	141- 28
AA00 2009	Decal - A4	17- 16

Part No.	Description	Paper and Index No.
AA00 2009	Decal - A4	141- 29
AA00 2030	Decal - Manual Feed - A3/A4	33- 45
AA00 2030	Decal - Manual Feed - EU	141- 30
AA00 2035	Decal - Manual Feed - Na	141- 30
AA01 0024	Ozone Filter	81- 14
AA01 0025	Ozone Filter	85- 2
AA01 2037	Filter	81- 16
AA01 2042	Cooling Fan Duct	91- 20
AA02 0004	Paper Tray Magnet	33- 41
AA03 1005	Oil Tank	61- 17
AA03 6005	Oil Bottle Cap	61- 16
AA03 6009	Joint Cap	13- 12
AA03 6009	Joint Cap	61- 15
AA03 6009	Joint Cap	69- 30
AA03 6010	Small Cap - Toner Tank	13- 2
AA03 6012	Large Cap - Toner Tank	45- 31
AA04 1008	Belt	69- 12
AA04 3082	Timing Belt - 60S2M250	75- 34
AA04 3083	Timing Belt - 150S3M1260	73- 21
AA04 3083	Timing Belt - 150S3M1260	75- 53
AA04 3084	Timing Belt - 100S3M699	71- 3
AA04 3085	Timing Belt - 100S3M384	57- 14
AA04 3086	Timing Belt - 40S2M440	73- 5
AA04 3087	Timing Belt - 40S2M440	57- 28
AA05 0040	Scanner Drive Wire - Long	25- 28
AA05 0041	Scanner Drive Wire	25- 30
AA06 0049	Release Lever Spring	35- 30
AA06 0050	Tightener Spring	37- 10
AA06 0082	Pick-up Lever - Spring	33- 39
AA06 0112	Pressure Spring - Pick-up	33- 56
AA06 0132	Spring	35- 12
AA06 0141	Spring - Charge Corona Grid	39- 4
AA06 0158	Spring - Pick-up Roller Arm	51- 13
AA06 0184	Tension Spring	71- 7
AA06 0189	Spring - Stripper Pawl Plate	59- 19

Part No.	Description	Paper and Index No.
AA06 0212	Tension Spring	57- 17
AA06 0214	Pressure Spring	55-22
AA06 0241	Spring	79- 16
AA06 0242	Spring	21- 10
AA06 0243	Spring	21-30
AA06 0244	Spring	61-25
AA06 0246	Spring	59- 11
AA06 0249	Spring	71- 8
AA06 0251	Spring	47- 8
AA06 0251	Spring	51-37
AA06 0291	Spring	75-30
AA06 0379	Spring	75-57
AA06 3041	Relay Roller Spring	37-61
AA06 3043	Shaft Bracket Spring	27- 6
AA06 3043	Shaft Bracket Spring	49-26
AA06 3059	Spring	27- 4
AA06 3099	Spring - Exit	59- 12
AA06 3130	Spring	67-26
AA06 3131	Spring	67- 12
AA06 3132	Spring	25- 13
AA06 3133	Spring	25- 19
AA06 3134	Spring	25- 8
AA06 3135	Spring	55-28
AA06 3136	Spring	71- 19
AA06 3136	Spring	75-24
AA06 3137	Spring	45-32
AA06 3140	Spring	65-26
AA06 3141	Spring	63- 17
AA06 3143	Spring	47- 18
AA06 3143	Spring	51-32
AA06 3145	Spring	57- 8
AA06 3162	Paper Feed Separation Spring	33-35
AA06 3162	Paper Feed Separation Spring	37-45
AA06 3166	Spring	53- 14
AA06 6079	Spring - Oil Pump Lever	61- 14

Part No.	Description	Paper and Index No.
AA06 6099	Spring	79-25
AA07 0013	Slide Rail	79- 8
AA07 0014	Slide Rail	77- 8
AA07 0015	Slide Rail	79- 2
AA07 0015	Slide Rail	81-23
AA08 0002	Bushing - 10x14x4.5	53- 5
AA08 0002	Bushing - 10x14x4.5	79- 6
AA08 0016	Bushing - 5x7x16	61- 12
AA08 0058	Bushing	45-43
AA08 0061	Bushing	43-22
AA08 0080	Bushing	75-16
AA08 0086	Bushing	43-31
AA08 0088	Bushing	43-23
AA08 2028	Bushing	49-29
AA08 2031	Bushing	53-12
AA11 1007	Sleeve - Oil Pump	63- 9
AA11 5006	Harness Clamp	41- 8
AA11 5007	Harness Clamp	41-16
AA13 0035	Joint Pipe - Large	69-32
AA13 0036	Joint Pipe - Small	69-34
AA13 0037	Bushing	55-29
AA13 2024	Spacer - M6	33-17
AA13 2024	Spacer - M6	35- 3
AA13 2024	Spacer - M6	37- 13
AA13 2024	Spacer - M6	49-27
AA13 2025	Spacer - 1x8x12	31-22
AA13 2025	Spacer - 1x8x12	33-14
AA13 2025	Spacer - 1x8x12	37- 4
AA13 2110	Collar	31-14
AA13 2111	Spacer - 8x12x0.5	31-16
AA13 2113	Roller	51- 4
AA13 2113	Roller	53-19
AA13 2114	Roller	53-13
AA14 0044	Pressure Arm Shaft	33-37
AA14 0044	Pressure Arm Shaft	37-48

Part No.	Description	Paper and Index No.
AA14 0045	Pick Up Shaft	33- 22
AA14 0045	Pick Up Shaft	37- 28
AA14 0046	Paper Feed Shaft - Upper	33- 23
AA14 0046	Paper Feed Shaft - Upper	37- 27
AA14 0053	Shaft - Bottom Plate Release	35- 23
AA14 0108	Worm Shaft	73- 10
AA14 0109	Transfer Drive Shaft	57- 5
AA14 0135	Separation Shaft	33- 33
AA14 0135	Separation Shaft	37- 42
AA14 0168	Pressure Roller Shaft	65- 6
AA14 0264	Development Drive Shaft	75- 54
AA14 0265	Transfer Belt Drive Shaft	53- 17
AA14 0265	Transfer Belt Drive Shaft	55- 1
AA14 0268	Agitator Large Shaft	45- 34
AA14 0272	Fusing Unit Drive Shaft	65- 9
AA14 0274	Upper Drive Shaft - Paper Exit	59- 28
AA14 0275	Pick-off Pawl Shaft	59- 21
AA14 0276	Paper Exit Upper Lock Shaft	59- 17
AA14 0277	Development Agitator Shaft	43- 15
AA14 0278	Toner Collection Drive Shaft	71- 17
AA14 0280	Pressure Arm	53- 11
AA14 0281	Pressure Arm Shaft	53- 18
AA14 0282	Stopper Shaft	87- 8
AA14 0283	Transfer Belt Lift Shaft	53- 8
AA14 0318	Transfer Unit Shaft	49- 17
AA14 0337	Adjusting Cam Shaft	51- 15
AA14 3005	Stepped Screw - M4x2.5	47- 25
AA14 3005	Stepped Screw - M4x2.5	49- 7
AA14 3037	Development Cover Screw	81- 10
AA14 3076	Stepped Screw - M4	25- 12
AA14 3204	Magnetic Clutch Bracket Stay	75- 31
AA14 3213	Lever Support Pin	11- 10
AA14 3219	Stepped Screw	63- 11
AA14 3238	Motor Drive Shaft	31- 7
AA14 3239	Stud	75- 48

Part No.	Description	Paper and Index No.
AA14 3240	Stud	75- 51
AA14 3241	Stud	75- 55
AA14 3243	Stud	75- 39
AA14 3244	Guide Lock Pin	25- 15
AA14 3245	Lock Pin	25- 17
AA14 3246	Pressure Pin	25- 7
AA14 3247	Positioning Pin	21- 8
AA14 3251	Stepped Screw - M3x10.5	43- 20
AA14 3257	Shielding Grass Stopper	27- 28
AA14 3258	Stepped Screw - M4x7	27- 27
AA14 3261	Stud	41- 10
AA14 3262	Positioning Pin	51- 29
AA14 3262	Positioning Pin	53- 6
AA14 3263	Stopper Pin	87- 7
AA14 3265	Positioning Pin - Transfer Corona	47- 17
AA14 3265	Positioning Pin - Transfer Corona	51- 33
AA14 3280	Positioning Pin - Belt Discharge	39- 36
AA14 3332	Worm Shaft Bracket	75- 38
AA14 5109	Fusing Unit Drive Shaft	57- 16
AA14 5110	Small Drive Shaft - Belt Cleaning	69- 8
AA14 5111	Roller Shaft	69- 2
AA14 5112	Pressure Shaft - Belt Cleaning Unit	53- 28
AA14 5113	Link Shaft	53- 27
AA14 8196	Toner Supply Shaft	75- 41
AA14 8197	Magnetic Clutch Shaft -Toner Supply	75- 33
AA14 8198	Cleaning Unit Drive Shaft	75- 43
AA14 8219	Adjusting Pin	81- 26
AA14 8225	Positioning Pin	51- 20
AA14 8226	Roller Shaft	51- 5
AA14 8226	Roller Shaft	53- 20
AA14 8227	Pressure Arm Shaft	51- 6
AA14 8227	Pressure Arm Shaft	53- 21
AA15 0182	Seal - 26x130x0.2	21- 17
AA15 0185	Seal - 35x335x2	43- 16
AA15 1090	Seal - 13x34x8	69- 26

Part No.	Description	Paper and Index No.
AA15 1363	Cushion - 49x79x12	13- 4
AA15 1400	Seal - 3x3x1	55-24
AA15 1418	Front Holder Seal	67- 10
AA15 1419	Rear Holder Seal	67- 14
AA15 1420	Seal - 8.5x15x2	67- 11
AA15 1421	Seal - 8.5x15x2	67- 15
AA15 1423	Seal - 6x6x1	67- 6
AA15 1424	Seal - 6x5x336	67- 7
AA15 1425	Seal - 7x10x6	55- 15
AA15 1426	Seal - 3x4x338	55- 16
AA15 1445	Seal - 14x10	43- 12
AA15 1446	Seal - 4.5x12x2	43- 21
AA15 1447	Seal - 7.5x336x2	43- 1
AA15 1451	Seal - 5x56x2	75- 47
AA15 1459	Seal - 4.5x51x2	27- 12
AA15 1460	Seal - 130x130x6	81- 7
AA15 1465	Seal - 145x164x6	85- 1
AA15 1470	Seal - 13.5x16.5x20	43- 25
AA15 1535	Seal - 11x20x1	45- 24
AA15 1569	Seal - 11x15x1	43- 28
AA15 2069	Seal - 12x22x5	67- 23
AA15 2094	Seal - 22x38x2	29- 24
AA15 2110	Seal - 4x8x5.3	43- 13
AA15 2111	Seal - 5x9x3.8	43- 10
AA15 2114	Seal - 2.7x16x1	45- 29
AA15 2116	Seal - 8x35x3	27- 15
AA15 2123	Seal	27- 17
AA15 2128	Seal - 38x322x3	29- 19
AA15 2129	Seal - 10x89x1	29- 18
AA15 2130	Seal - 6x231x1	29- 16
AA15 2131	Seal - 7x488x1	29- 20
AA15 2132	Seal - 11x483x1	27- 25
AA15 2133	Seal - 9x341x2	27- 13
AA15 2153	Seal - 28x212x0.2	67- 1
AA15 2186	Seal - 27x330x0.2	67- 5

Part No.	Description	Paper and Index No.
AA16 1014	Cushion - Motor	31- 13
AA16 1055	Stopper - 12.7x12.7x5.8	23- 16
AA16 1056	Cushion - 27x50x0.8	25- 35
AA16 1057	Cushion - 50x18x1.6	25- 33
AA16 1058	Cushion - 4x15x3.2	81- 8
AA16 1065	Cushion - 9x16x1.5	75- 11
AA17 4005	Noizeproof Padding	69- 22
AA18 0008	Oil Tube - 320mm	61- 5
AA18 0031	Oil Supply Tube	61- 18
AA18 0035	Sleeve - Oil Pump	61- 9
AB01 0022	Gear - 96Z	71- 14
AB01 1023	Gear - 15T	33- 38
AB01 1023	Gear - 15T	37- 49
AB01 1024	Gear - 25T	33- 34
AB01 1024	Gear - 25T	37- 46
AB01 1071	Gear - 16Z	31- 2
AB01 1072	Worm Gear	73- 23
AB01 1073	Worm Gear	57- 11
AB01 1074	Worm Wheel	73- 15
AB01 1075	Worm Wheel - 42Z	57- 1
AB01 1077	Gear - 17Z	43- 36
AB01 1078	Gear - 14Z	43- 37
AB01 1079	Gear - 14Z	43- 35
AB01 1080	Gear - 30Z	41- 9
AB01 1081	Gear - 50Z	45- 21
AB01 3062	Gear - 19T	63- 7
AB01 3077	Gear - 20T	33- 18
AB01 3077	Gear - 20T	37- 12
AB01 3078	Gear - 18T	33- 29
AB01 3078	Gear - 18T	37- 35
AB01 3079	Gear - 21T	33- 27
AB01 3079	Gear - 21T	37- 32
AB01 3125	Gear - 16T	33- 54
AB01 3174	Gear - 24Z	75- 42
AB01 3175	Gear - 38Z	75- 32

Part No.	Description	Paper and Index No.
AB01 3176	Gear - 50Z	75- 44
AB01 3177	Gear - 35Z	57- 9
AB01 3178	Gear - 34Z	69- 5
AB01 3179	Gear - 14Z	55- 5
AB01 3181	Gear - 15Z	43- 30
AB01 3182	Gear - 22Z	43- 32
AB01 3183	Gear - 26Z	43- 7
AB01 3184	Gear - 16Z	45- 44
AB01 3214	Gear - 20T	55- 3
AB01 3267	Gear - 17T	65- 21
AB01 3355	Gear - 18Z	45- 46
AB01 3363	Gear - 16Z	65- 17
AB01 3397	Gear - 20Z	31- 35
AB01 3398	Gear - 18Z	31- 38
AB01 3399	Gear - 30Z	31- 23
AB01 3400	Gear - 28Z	31- 10
AB01 3401	Gear - 22Z	71- 20
AB01 3401	Gear - 22Z	75- 23
AB01 3402	Gear - 21Z	57- 21
AB01 3407	Gear - 45Z	65- 23
AB01 3408	Gear - 27Z	65- 25
AB01 3409	Gear - 20Z	65- 24
AB01 3412	Gear - 19Z	63- 6
AB01 3414	Gear - 36Z	47- 34
AB01 7038	Gear - 32T	61- 19
AB01 7074	Gear - 18Z	75- 40
AB01 7084	Gear - 30/32Z	69- 15
AB01 7143	Gear - 30/32Z	31- 9
AB01 7144	Gear - 18/21Z	31- 24
AB01 7146	Gear - 28/26Z	75- 52
AB01 7178	Gear - 38Z	69- 14
AB02 3016	Sprocket - 18T/50Hz	31- 17
AB02 3018	Sprocket - 15T	37- 7
AB03 0176	Idler - 28	71- 1
AB03 0176	Idler - 28	75- 49

Part No.	Description	Paper and Index No.
AB03 0177	Pulley	75- 56
AB03 0180	Pulley - 56Z	57- 10
AB03 0180	Pulley - 56Z	73- 9
AB03 0182	Pulley - 28Z	57- 29
AB03 0182	Pulley - 28Z	73- 4
AB03 0184	Pulley - 42Z	57- 26
AB03 0184	Pulley - 42Z	73- 7
AB03 0186	Pulley - 30Z	71- 24
AB03 0188	Pulley - 25Z	57- 20
AB03 0190	Pulley - 47Z	57- 24
AB03 0192	Pulley - 35Z	57- 15
AB03 0194	Pulley - 20Z	57- 19
AB03 2022	Pulley	69- 28
AB03 2036	Scanner Wire Pulley	25- 29
AB03 3011	Pulley	69- 13
AC01 5008	Shielding Glass	27- 11
AC03 0048	LD Mirror	29- 9
AC03 0049	1st Lower Mirror	27- 2
AC03 0050	2nd Lower Mirror	27- 35
AC03 0051	1st Upper Mirror	27- 8
AC03 0052	2nd Upper Mirror	27- 39
AC04 2025	Left Scale	19- 12
AC05 0003	Guide Rod	25- 6
AD01 4019	Drum Flange	75- 21
AD01 5009	Drum Shaft	75- 20
AD02 0038	Belt Discharge Corona Wire	39- 24
AD02 1060	Charge Corona Receptacle	89- 1
AD02 1062	Transfer Corona Receptacle	47- 32
AD02 1062	Transfer Corona Receptacle	49- 31
AD02 1062	Transfer Corona Receptacle	51- 28
AD02 2181	Front End Block - Charge Corona	39- 5
AD02 2182	Rear End Block - Belt Discharge	39- 23
AD02 2262	Front End Block - Main Corona	39- 22
AD02 2262	Front End Block - Main Corona	47- 9
AD02 2262	Front End Block - Main Corona	51- 39

Part No.	Description	Paper and Index No.
AD02 2263	Front Cover - Main Corona	39- 25
AD02 2263	Front Cover - Main Corona	47- 3
AD02 2263	Front Cover - Main Corona	51- 38
AD02 2264	Rear Cover - Main Corona	39- 26
AD02 2265	Rear End Block - Charge Corona	39- 14
AD03 1151	Development Roller	43- 6
AD03 3012	Toner Supply Roller	43- 9
AD03 7012	Lower Development Auger	43- 3
AD03 7015	Upper Development Auger	43- 5
AD03 7016	Small Agitator Shaft	45- 36
AD03 7020	Toner Supply Auger	41- 17
AD03 7026	Toner Supply Auger	45- 30
AD04 1014	Cleaning Blade	67- 17
AD04 2013	Cleaning Brush - Transfer Belt	55- 6
AD04 2014	Cleaning Brush	67- 18
AD04 3018	Toner Collection Auger - Cleaning	67- 19
AD04 3019	Toner Collection Auger	69- 37
AD04 3020	Toner Collection Auger - Toner Bott	69- 27
AD04 3021	Collection Auger - Belt Cleaning	55- 13
AE01 0003	Hot Roller	65- 5
AE02 0018	Pressure Roller	65- 8
AE03 0007	Ball Bearing-25x47x12mm	65- 15
AE03 0008	Ball Bearing - 12x28x8mm	65- 7
AE03 1006	Collar	65- 18
AE03 2007	Bushing - 20x25x12mm	65- 16
AE04 3003	Oil Blade	61- 27
AE04 5011	Oil Supply Felt	61- 24
AF01 2004	Cassette Cover - Large	17- 23
AF01 2008	Cassette Cover - Small	17- 23
AF01 6022	Front Side Fence	33- 47
AF01 6023	Side Fence - Manual Feed - Rear	33- 44
AF02 0023	Upper Middle Roller	37- 53
AF02 0024	Lower Middle Roller	37- 44
AF02 0143	Upper Registration Roller	31- 37
AF02 0144	Lower Exit Roller	63- 3

Part No.	Description	Paper and Index No.
AF02 0148	Transfer Drive Roller	47- 20
AF02 1019	Driven Roller - Transfer	49- 18
AF02 1037	Lower Registration Roller	31- 36
AG04 0031	Operating Instructions Holder	11- 3
AG05 0042	Fusing Unit Knob	59- 27
AG05 1062	Upper Registration Guide Knob	31- 5
AG05 1063	Paper Feed Unit Lever	79- 5
AG05 1064	Knob	35- 33
AG05 1066	Development Unit Grip	41- 3
AG05 1069	Transfer Belt Unit Lever	53- 30
AG05 1073	Transfer Change Lever	49- 23
AG07 0004	Magnet Catch Ass'y	13- 15
AG07 0004	Magnet Catch Ass'y	77- 23
AX04 0004	Cooling Fan Motor	85- 13
AX04 0006	Blower Fan	85- 12
AX04 0006	Blower Fan	91- 18
AX05 0008	Transport Fan Motor	81- 12
AX05 0008	Transport Fan Motor	83- 36
AX05 0008	Transport Fan Motor	85- 5
AX05 0031	Motor - 9W	25- 27
AX06 0025	DC Motor - 66W	71- 10
AX06 0026	Motor - DC24V	57- 31
AX06 0026	Motor - DC24V	73- 2
AX20 0017	Magnetic Clutch - Registration	31- 21
AX20 0018	Paper Feed Clutch	33- 13
AX20 0018	Paper Feed Clutch	37- 3
AX20 0040	Magnetic Clutch	75- 35
AX20 0042	Magnetic Clutch	37- 2
AX31 0006	Counter	83- 34
AX31 0007	Counter	83- 35
AX40 0008	Heater - 115V 18W	23- 7
AX40 0008	Heater - 115V 18W	87- 12
AX40 0009	Heater - 220V 18W	23- 7
AX40 0009	Heater - 220V 18W	87- 12
AX40 0019	Heater - DC24V 20W $\pm 15\%$	21- 27

Part No.	Description	Paper and Index No.
AX43 0011	Heater - 115V 550W	65- 4
AX43 0012	Heater - 230V 550W	65- 4
AX50 0032	Fluorescent Lamp	21- 28
AX65 0005	Fan Motor - DC24V	19-30
AX65 0005	Fan Motor - DC24V	25- 1
AZ00 0018	Power Supply Cord - 250V 10A	91- 8
AZ24 0013	DC Power Supply Unit - 115V	87-22
AZ24 0014	DC Power Supply Unit - 230V 500W	87-22
AZ31 0013	AC Power Pack - Discharge	85- 17
AZ31 0031	AC Power Pack - Discharge	51-27
AZ32 0039	Power Pack - Development	85- 10
AZ32 0040	Power Pack - Transfer Unit	47-28
AZ32 0040	Power Pack - Transfer Unit	49- 10
AZ50 0014	Stabilizer	19-28
A000 5507	Lift Motor - DC1.69W	35- 13
A006 2114	Grid Anchor	39- 3
A006 2266	Rear Cover - Charge Corona	39- 12
A006 2267	Front Cover - Main Corona	39- 2
A006 4263	Paper Exit Shutter	63- 8
A007 1920	Cushion - Exposure Glass	21- 13
A007 2577	Registration Knob	31- 34
A007 2630	Lower Guide - Paper Feed Solenoid	37- 21
A007 2634	Upper Feed Guide	33- 42
A007 2649	Separation Guide	33- 62
A007 2649	Separation Guide	35- 25
A007 2653	Paper Feed Brace - Upper	37- 43
A007 2655	Separation Fixed Bracket	33- 11
A007 2655	Separation Fixed Bracket	37- 50
A007 2657	Separation Arm	33- 36
A007 2657	Separation Arm	37- 47
A007 2661	Paper Size Sensor Bracket	37- 26
A007 2675	Paper Feed Stay - Lower	37- 52
A007 2684	Bracket - Paper Feed Roller	33- 67
A007 2686	Feed Guide - Paper Feed Roller	33- 24
A007 2686	Feed Guide - Paper Feed Roller	37- 29

Part No.	Description	Paper and Index No.
A007 2698	Upper Magnetic Clutch Stopper	33- 16
A007 2709	Paper Feed Roller Bracket	37- 33
A007 2712	Lower Paper Feed Stay	37- 22
A007 2718	Paper End Feeler	33- 63
A007 2718	Paper End Feeler	37- 17
A007 2720	Paper End Actuator Bracket	33- 65
A007 2722	Upper Bracket - Paper End	35- 28
A007 2724	Lower Bracket - Paper End	35- 38
A007 2725	Paper End Shutter - Upper	33- 70
A007 2726	Paper End Actuator Bracket	37- 19
A007 2733	Feed Control Board Bracket	33- 71
A007 2742	Shutter Plate	33- 3
A007 2745	Upper Solenoid - Paper Feed	33- 1
A007 2747	Lower Solenoid - Paper Feed	33- 10
A007 2749	Pick-up Arm - Manual Feed	33- 2
A007 2752	Volume Sensor Shaft	35- 27
A007 2754	Bottom Plate Lever	35- 26
A007 2756	Bushing - Volume Sensor Shaft	35- 21
A007 2757	Sector Gear Bushing	35- 22
A007 2759	Sector Gear	35- 20
A007 2765	Paper Lift Motor Ass'y - Upper	35- 14
A007 2766	Paper Lift Motor Ass'y - Lower	35- 15
A007 2802	Decal - Side Fence - Manual Feed	33- 43
A007 2802	Decal - Side Fence - Manual Feed	141- 5
A007 2803	Manual Feed Table Holder	33- 68
A007 2805	Manual Feed Sensor Bracket	33- 61
A007 2844	Release Lever - Bottom Plate	35- 32
A007 2848	Cushion - Release Lever	35- 31
A007 2848	Cushion - Release Lever	37- 57
A007 2850	Release Arm - Bottom Plate	35- 8
A007 2853	Link Plate - Release Lever	35- 34
A007 2857	Actuator - Bottom Plate Release	35- 4
A007 2861	Link Plate - Release Arm	35- 6
A007 2864	Release Arm Lever	35- 7
A007 2867	Link Plate - Release Arm Lever	35- 5

Part No.	Description	Paper and Index No.
A007 2877	Cushion - Upper Pick-off Bracket	35- 17
A007 2877	Cushion - Upper Pick-off Bracket	37- 16
A007 2880	Bottom Plate Release Stopper	35- 19
A007 2883	Roller Plate Release Roller	35- 1
A007 2883	Roller Plate Release Roller	79- 15
A007 2885	Cam - Bottom Plate Release	35- 2
A007 2894	Cushion - 8x15x30	37- 23
A007 2950	Cassette Body - Small	17- 15
A007 2955	Cassette Body - Large	17- 15
A007 3751	Cap Large - Toner Collection Tank	13- 13
A007 4195	Oil Sump	61- 28
A007 5251	Lift Motor Harness	33- 6
A007 5253	Upper Paper Size Harness	37- 24
A008 9502	Silicone Grease - G40m	143- 12
A012 1871	Front Scale Stopper	11- 34
A012 2688	Front Side Fence Gear	33- 51
A012 2692	Wave Washer	33- 53
A012 2812	Rear Side Fence Gear	33- 50
A012 8301	Decal - Drum Knob	141- 6
A012 9001	Main Charge Corona Wire - 10pcs/set	47- 4
A028 5306	DC Motor - DC 24V	45- 28
A028 9300	Grease - Nok Barrierta JFE 5 5/2	143- 8
A030 3389	Color Development Motor	71- 13
A030 4064	Spacer - Hot Roller	65- 14
A030 4133	Oil Pump Lever	61- 13
A030 5802	Receiving Tray	11- 1
A030 9010	Hot Roller Stripper	59- 23
A049 1077	Rear Slide Plate	89- 7
A049 1080	Heater Support Stay	87- 10
A049 1081	Heater Connector Bracket	87- 11
A049 1082	Main Motor Cover	87- 9
A049 1084	Support Plate - Development Cover	39- 9
A049 1085	Development Cover	39- 10
A049 1086	Right Support Stay - Laser Unit	77- 29
A049 1088	Left Support Stay - Laser Unit	77- 22

Part No.	Description	Paper and Index No.
A049 1094	Front Right Support Plate	77- 6
A049 1095	Front Support Plate	77- 17
A049 1097	PCB Cover	77- 24
A049 1098	Upper Cover - Power Supply Unit	79- 24
A049 1104	Drum Shaft Support Bracket	75- 28
A049 1113	Belt Tightener	75- 37
A049 1118	Small Toner Supply Cam	69- 10
A049 1118	Small Toner Supply Cam	75- 26
A049 1119	Large Toner Supply Cam	69- 11
A049 1119	Large Toner Supply Cam	75- 25
A049 1122	Toner Supply Clutch Bracket	75- 36
A049 1126	Retaining Ring C - M37.5	75- 45
A049 1136	Worm Gear Support Bracket	73- 19
A049 1141	Worm Gear Holder	73- 14
A049 1144	Drum Shaft Collar	75- 46
A049 1145	Oil Pan	73- 13
A049 1146	Oil Pan Rear Cover	73- 11
A049 1148	Seal - Oil Pan Rear Cover	73- 3
A049 1149	Oil Pan Top Cover	73- 12
A049 1151	Drive Shaft Holder	57- 6
A049 1156	Oil Pan Rear Cover	57- 12
A049 1157	Oil Seal	57- 2
A049 1158	Oil Pan	57- 13
A049 1159	Oil Pan Top Cover	57- 4
A049 1166	OPC Drum Motor Bracket	73- 1
A049 1170	Tightener Bracket	73- 8
A049 1176	Transfer Belt Motor Bracket	57- 30
A049 1178	Tightener Bracket Lever	57- 27
A049 1179	Tightner Bracket Shaft	57- 32
A049 1182	Main Motor Bracket	71- 9
A049 1184	Motor Connector Bracket	71- 4
A049 1187	Belt Tightener	71- 2
A049 1189	Spring Anchor	71- 6
A049 1191	Belt Tightener	71- 5
A049 1195	Fusing Unit Drive Bracket	57- 22

Part No.	Description	Paper and Index No.
A049 1256	Grip Bracket - Left Door	11- 39
A049 1259	Lever Stopper - Transfer	11- 35
A049 1260	Left Door Grip	11- 38
A049 1266	Right Door Bracket	11- 33
A049 1268	Right Door Stopper	11- 26
A049 1270	Right Door Grip	11- 32
A049 1274	Left Door Shaft	11- 27
A049 1280	Rear Right Cover	11- 18
A049 1290	Rear Left Cover	11- 17
A049 1291	Stopper Chain - Left Door	11- 11
A049 1297	Safety Switch Actuator - Left Door	11- 36
A049 1298	Safety Switch Actuator - Right Door	11- 31
A049 1299	Safety Switch Actuator	11- 29
A049 1300	Right Cover - Paper Feed Unit	31- 26
A049 1318	Top Left Cover	11- 9
A049 1323	Left Upper Cover	11- 4
A049 1327	Filter Bracket	11- 6
A049 1330	Dust Filter	11- 5
A049 1332	Rear Upper Cover	11- 15
A049 1338	Connector Guide	11- 16
A049 1350	Front Right Cover	11- 24
A049 1351	Front Right Cover Bracket	11- 23
A049 1355	Right Upper Cover	11- 12
A049 1356	Right Upper Small Cover	11- 14
A049 1357	Spring Plate	11- 13
A049 1361	Right Cover Cap	11- 21
A049 1365	Left Cover	11- 7
A049 1369	Main Switch Cover	11- 8
A049 1594	Grounding Plate	17- 1
A049 1659	Exposure Lamp Harness Bracket	21- 15
A049 1660	Scanner Motor Board Bracket	19- 27
A049 1664	Front Upper Side Plate	23- 14
A049 1666	Front Lower Side Plate	25- 5
A049 1669	Rear Upper Side Plate	23- 3
A049 1674	Rear Lower Side Plate	25- 38

Part No.	Description	Paper and Index No.
A049 1677	Front Rail Bracket	81- 21
A049 1680	Rear Slide Rail Bracket	81- 28
A049 1683	Rear Right Cover Bracket	23- 12
A049 1688	Rear Scanner Unit Guide	77- 26
A049 1691	Left Inner Cover	19- 10
A049 1695	Right Inner Cover	19- 32
A049 1698	Leaf Spring	25- 18
A049 1699	Middle Inner Cover	19- 33
A049 1701	PCB Guide Rail Bracket - Rear Left	23- 4
A049 1702	PCB Guide Rail Bracket - Rear	23- 6
A049 1703	PCB Guide Rail Bracket - Rear Right	23- 5
A049 1704	PCB Guide Bracket - Front	23- 1
A049 1705	PCB Guide Bracket - Front Right	23- 2
A049 1706	Exposure Glass	19- 14
A049 1708	Right Scale Bracket	19- 24
A049 1709	Left Scale Bracket	19- 19
A049 1711	Exposure Glass Stopper	19- 17
A049 1713	Scanner Fan Cover	25- 2
A049 1720	Stopper Bracket - Scanner Unit	25- 14
A049 1722	Front Scanner Unit Guide	77- 27
A049 1724	Scanner Lock Shaft	25- 16
A049 1732	Scanner Guide Rod Bracket	25- 9
A049 1738	Front Right Pulley Bracket	25- 10
A049 1740	Front Right Pulley	25- 11
A049 1745	Rear Right Pulley Bracket	25- 20
A049 1749	Front Left Pulley Bracket	25- 4
A049 1751	Front Left Pulley	25- 3
A049 1754	Rear Left Pulley Bracket	25- 26
A049 1757	Rear Left Pulley	25- 22
A049 1765	Support Plate - Rear Right Pulley	25- 32
A049 1766	Support Plate - Rear Left Pulley	25- 37
A049 1773	Wire Clamp Bracket	25- 36
A049 1776	Scanner Wire Clamp	25- 34
A049 1780	Left Filter Stay	19- 1
A049 1785	Dust Filter	19- 34

Part No.	Description	Paper and Index No.
A049 1787	Rear Filter Stay	19- 31
A049 1793	Dust Filter	19- 22
A049 1796	Scanner Stopper Chain	23- 19
A049 1811	Harness Guide Plate	21- 19
A049 1815	Front Tension Arm	21- 9
A049 1819	Scanner Unit Guide Roller	21- 7
A049 1823	Bushing - 12x6x6	21- 6
A049 1825	Harness Guide	21- 26
A049 1830	Rear Right Tension Arm	21- 29
A049 1833	Rear Left Tension Arm	21- 21
A049 1836	Tension Arm Bracket	21- 31
A049 1842	Wire Clamp	21- 11
A049 1851	Upper Coaxial Cable Bracket	21- 25
A049 1854	CCD Drive Board Set	19- 8
A049 1854	CCD Drive Board Set	21- 4
A049 1876	Positioning Sensor Roller	21- 3
A049 1895	Left Upper Cover - Scanner	21- 12
A049 1898	Right Upper Cover - Scanner	21- 23
A049 1903	Lower Scanner Cover	21- 14
A049 1911	Scanner Home Sensor Bracket	25- 25
A049 1914	Scanner Motor Bracket	25- 31
A049 1925	Scanner Mother Board Bracket	19- 25
A049 1928	Rear Scanner Fan Bracket	19- 29
A049 1930	Lower Coaxial Cable Bracket	21- 16
A049 1931	Lower Shielding Plate Bracket	21- 20
A049 1933	Upper Shielding Plate Bracket	23- 8
A049 1934	Upper Support Shielding Plate	21- 22
A049 1935	Leaf Spring	23- 15
A049 1939	Connector Bracket	23- 23
A049 1940	Heater Bracket	23- 9
A049 1942	PCB Bracket	21- 2
A049 1949	PCB Support Bracket - Right	23- 11
A049 1956	Front Scale (A4)	19- 13
A049 1964	Screw Cover	19- 11
A049 1965	Front Scale Holder	19- 15

Part No.	Description	Paper and Index No.
A049 1975	PCB Cover Grid	19- 2
A049 1980	Leaf Spring Plate	19- 3
A049 1982	PCB Support Bracket - Left	19- 4
A049 1983	Grounding Plate	19- 5
A049 1983	Grounding Plate	23- 10
A049 1984	Grounding Plate	23- 17
A049 2083	F Theta Lens Bracket - 1	29- 12
A049 2087	F Theta Lens Bracket - 2	29- 21
A049 2092	LD Mirror Bracket	29- 8
A049 2093	F Theta Lens - 2	29- 22
A049 2098	1st Mirror Lower Bracket	27- 1
A049 2100	2nd Mirror Lower Bracket	27- 34
A049 2102	1st Mirror Upper Bracket	27- 7
A049 2104	2nd Mirror Upper Bracket	27- 40
A049 2124	Heater Harness Cover	27- 38
A049 2134	Connector Holder	27- 20
A049 2135	Connector Bracket	27- 18
A049 2139	Polygon Motor Cover	27- 10
A049 2141	Polygon Motor Harness Cover	27- 16
A049 2145	Laser Unit Lower Cover	27- 29
A049 2171	Laser Unit Cover	29- 15
A049 2182	Grounding Plate	29- 11
A049 2184	LD Drive Board Cover	29- 1
A049 2188	Motor Bracket	29- 14
A049 2191	Laser Unit Grip Chain	27- 9
A049 2194	Seal - Magenta	27- 31
A049 2194	Seal - Yellow	39- 7
A049 2194	Seal	47- 11
A049 2195	Seal - Yellow	27- 26
A049 2195	Seal - Magenta	39- 7
A049 2195	Seal	47- 12
A049 2196	Harness Holder	29- 5
A049 2197	Grounding Plate	77- 19
A049 2198	LD Unit	29- 25
A049 2260	Charge Corona Casing	39- 31

Part No.	Description	Paper and Index No.
A049 2264	Left Rail - Charge Corona	39- 27
A049 2265	Right Rail - Charge Corona	39- 28
A049 2266	Leaf Spring	39- 30
A049 2267	Leaf Spring	39- 29
A049 2268	Quenching Lamp Spacer	39- 32
A049 2272	Charge Grid - 85T	39- 18
A049 2279	Main Corona Unit	39- 1
A049 2283	Left Casing - Corona Unit	39- 11
A049 2284	Right Casing - Corona Unit	39- 17
A049 2301	Cleaner - Main Corona Unit	39- 37
A049 2311	Charge Fan Duct	85- 7
A049 2322	Cooling Fan Bracket	85- 20
A049 2324	Filter - 585x76	85- 19
A049 2325	Filter Holder	85- 18
A049 2341	ID Sensor Duct	71- 12
A049 2403	Front Drum Frange	75- 17
A049 2405	Drum Guide	75- 19
A049 2422	Drum Stay	39- 8
A049 2422	Drum Stay	75- 14
A049 2442	Front Side Plate	75- 9
A049 2443	Drum Shaft Alignment Plate	75- 5
A049 2444	Drum Shaft Holder	75- 7
A049 2445	Leaf Spring	75- 6
A049 2451	Knob - Drum Unit Cover	75- 2
A049 2452	Drum Unit Cover Stad	39- 35
A049 2453	Drum Unit Cover	75- 4
A049 2469	Insulating Plate	41- 13
A049 2566	Right Upper Stay	33- 40
A049 2569	Front Support Bracket	79- 11
A049 2571	Front Slide Rail Guide	79- 9
A049 2573	Rear Support Bracket	79- 20
A049 2575	Rear Slide Rail Guide	79- 23
A049 2576	Paper Feed Bottom Plate	79- 12
A049 2585	Magnet Clutch Stopper	31- 11
A049 2591	Lower Paper Guide	37- 59

Part No.	Description	Paper and Index No.
A049 2592	Upper Paper Guide	37- 56
A049 2595	Magnet Clutch Stopper	37- 15
A049 2600	Upper Registration Guide	31- 33
A049 2607	Registration Sensor Bracket	31- 42
A049 2608	Spacer - 118x13.5x1	31- 32
A049 2609	Edgeing - 341x5x3.7	31- 41
A049 2610	Lower Registration Guide	31- 39
A049 2613	Entrance Guide - Transfer Unit	31- 15
A049 2621	Paper Feed Motor Bracket	31- 12
A049 2622	Gear Holder Plate	31- 8
A049 2624	Motor Support Bracket	31- 3
A049 2625	Tension Arm	37- 9
A049 2628	Bracket - Paper Feed Motor Board	31- 6
A049 2631	Paper Feed Drive Chain - 100P	37- 1
A049 2636	Connector Bracket	37- 54
A049 2652	Paper Feed Unit Lock Shaft	79- 18
A049 2653	Front Lock Arm	79- 14
A049 2656	Stopper Plate	79- 26
A049 2658	Stopper Arm	79- 13
A049 2660	Stopper Plate Bracket	79- 26
A049 2662	Paper Feed Unit Guide Plate	79- 17
A049 2669	Rear Cover - Paper Feed Unit	31- 25
A049 2674	Paper Feed Lock Cover	79- 22
A049 2675	Rear Lock Arm	79- 19
A049 2681	By-pass Feed Table	33- 48
A049 2682	By-pass Feed Table Cover	33- 57
A049 2687	By-pass Feed Table Support	33- 59
A049 2691	Spacer - 14x6	33- 52
A049 2692	Spacer - 132x10	33- 49
A049 2700	Paper Feed Stay	33- 21
A049 2710	Bracket - Paper Feed Control Board	33- 7
A049 2712	Support Bracket	33- 12
A049 2720	Cassette Arm Shaft Stopper	35- 37
A049 2741	Front Cassette Holder	35- 24
A049 2743	Rear Cassette Holder	35- 18

Part No.	Description	Paper and Index No.
A049 2751	Front Cover Support Plate	35- 35
A049 2761	Dampproof Sheet - A3	17- 11
A049 2763	Dampproof Sheet - A4	17- 11
A049 2764	Dampproof Sheet - A4R	17- 11
A049 3054	Toner Tank Ass'y	45- 9
A049 3055	Development Unit	41- *
A049 3067	Doctor Plate	43- 2
A049 3068	Front Plate - Development	43- 29
A049 3075	Bias Treminal Plate	41- 15
A049 3076	Collection Coil Cap	41- 18
A049 3079	Rear Plate - Development	43- 33
A049 3090	Development Unit Casing	43- 17
A049 3092	Magnet	43- 34
A049 3095	Toner Agitator	43- 14
A049 3099	Toner Supply Foam Roller	43- 11
A049 3109	Toner Supply Blade	43- 8
A049 3121	Front Shaft Plate	43- 24
A049 3122	Rear Shaft Plate	43- 39
A049 3155	Joint - Toner Supply	43- 38
A049 3155	Joint - Toner Supply	55- 26
A049 3159	Auger Cover	43- 4
A049 3167	Bearing Case	43- 27
A049 3175	Development Top Cover	41- 7
A049 3181	Toner Supply Sensor Bracket	41- 6
A049 3187	Front Grip Holder	41- 2
A049 3188	Rear Grip Holder	41- 4
A049 3195	Development Upper Cover	41- 1
A049 3204	Development Guide Rail	77- 9
A049 3204	Development Guide Rail	87- 3
A049 3227	Side Seal - 23x83x0.1	43- 19
A049 3231	Front Holder - Development Unit	75- 22
A049 3232	Rear Holder - Development Unit	71- 21
A049 3232	Rear Holder - Development Unit	89- 2
A049 3235	Development Adjuster	43- 26
A049 3250	Toner Tank Cover	45- 33

Part No.	Description	Paper and Index No.
A049 3253	Slide Rail Right Stay	77- 21
A049 3254	Slide Rail Left Stay	77- 12
A049 3255	Hopper Cover	45- 14
A049 3261	Slide Rail Bracket	77- 7
A049 3262	Left Slide Rail Spring	77- 11
A049 3263	Right Slide Rail Spring	77- 18
A049 3273	Dumper Holder	77- 10
A049 3274	Connector Bracket	77- 14
A049 3279	Dumper	77- 20
A049 3281	Latch Bracket	13- 26
A049 3282	Latch	13- 18
A049 3284	Tank Unit Rear Plate	45- 16
A049 3292	Tank Unit Stopper	45- 18
A049 3294	Receptacle - Toner Supply	41- 19
A049 3300	Large Agitator - Toner Tank	45- 35
A049 3303	Toner Supply Motor Bracket	45- 27
A049 3309	Agitator Support Plate	45- 38
A049 3310	Small Agitator - Toner Tank	45- 37
A049 3324	Connector Cover	77- 13
A049 3325	Top Cover - Blue	45- 19
A049 3326	Top Cover - Magenta	45- 12
A049 3327	Top Cover - Yellow	45- 10
A049 3328	Top Cover - Cyan	45- 5
A049 3329	Toner Cartridge Guide - Blue	45- 20
A049 3330	Toner Cartridge Guide - Magenta	45- 13
A049 3331	Toner Cartridge Guide - Yellow	45- 11
A049 3332	Toner Cartridge Guide - Cyan	45- 7
A049 3333	Toner Guide Seal	45- 8
A049 3337	Toner Tank Entrance Shield	45- 23
A049 3340	Tank Unit Front Cover	45- 47
A049 3350	Toner Collection Motor Bracket	71- 16
A049 3355	Magnet Angle Adjuster Bracket	13- 8
A049 3356	Magnet Angle Adjuster Knob	13- 7
A049 3357	Development Unit Stand	13- 1
A049 3360	Toner Catch Pan Bracket	45- 42

Part No.	Description	Paper and Index No.
A049 3363	Toner Catch Pan	45- 41
A049 3365	Tank Unit Left Plate	45- 2
A049 3370	Tank Unit Right Plate	45- 39
A049 3371	Magnet	45- 40
A049 3560	Front Plate - Cleaning	67- 20
A049 3565	Front Drive Shaft - Cleaning Brush	67- 22
A049 3569	Rear Plate - Cleaning	67- 24
A049 3574	Rear Drive Shaft - Cleaning Brush	67- 30
A049 3576	Toner Receiving Pipe	67- 27
A049 3578	Joint - Cleaning Brush	67- 28
A049 3578	Joint - Cleaning Brush	75- 29
A049 3579	Rear Holder - Cleaning Brush	67- 29
A049 3580	Cleaning Unit Casing	67- 4
A049 3587	Cleaning Blade Holder	67- 13
A049 3590	Cleaning Blade Lever	67- 9
A049 3604	Grounding Plate	67- 25
A049 3621	Casing - Transfer Belt	55- 17
A049 3622	Cleaning Blade - Transfer Belt	55- 8
A049 3632	Front Bearing - Cleaning Brush	55- 21
A049 3641	Front Side Plate	55- 25
A049 3646	Front Seal	55- 9
A049 3649	Rear Side Plate	55- 32
A049 3652	Rear Bearing - Cleaning Brush	55- 30
A049 3656	Rear Seal	55- 12
A049 3661	Bushing - Cleaning Brush	55- 7
A049 3662	Pressure Plate - Cleaning Blade	55- 23
A049 3663	Front Holder - Cleaning Brush	55- 4
A049 3666	Rear Holder - Cleaning Brush	55- 27
A049 3673	Cleaning Blade Holder	55- 10
A049 3707	Front Bracket - Belt Cleaning	55- 20
A049 3710	Rear Bracket - Belt Cleaning	55- 31
A049 3718	Pressure Plate Link	53- 16
A049 3719	Cleaning Unit Pressure Plate	53- 26
A049 3723	Cleaning Unit Cover	55- 18
A049 3725	Stud - Base	69- 40

Part No.	Description	Paper and Index No.
A049 3727	Knock Pin Base	69- 41
A049 3730	Knock Pin Shaft	69- 45
A049 3732	Knock Arm Pin	69- 44
A049 3733	Knock Arm	69- 43
A049 3734	Cam Frower Arm	69- 47
A049 3737	Clamp Bracket	69- 42
A049 3739	Gear - 46Z	69- 48
A049 3741	Connector Cover	69- 49
A049 3830	Transfer Corona Unit - BK,M	47- 1
A049 3831	Transfer Corona Unit - Y,C	47- 2
A049 3832	Belt Discharge Corona Unit	39- 19
A049 3833	Discharge Corona Unit	51- 30
A049 3863	Power Pack Case	47- 35
A049 3863	Power Pack Case	49- 11
A049 3864	Power Pack Case Cover	47- 26
A049 3864	Power Pack Case Cover	49- 8
A049 3865	Grounding Plate	47- 27
A049 3865	Grounding Plate	49- 9
A049 3875	Right Rail - Transfer Corona Unit	49- 14
A049 3876	Left Rail - Transfer Corona Unit	47- 24
A049 3876	Left Rail - Transfer Corona Unit	49- 6
A049 3879	Receptacle Bracket	49- 30
A049 3882	Transfer Belt Pad	49- 2
A049 3884	Leaf Spring	49- 1
A049 3887	Transport Driven Roller Pad	49- 15
A049 3889	Stay - Transfer Belt Pad	49- 3
A049 3891	Transport Unit Stopper	53- 3
A049 3892	Positioning Plate - Transport Unit	53- 4
A049 3897	Receptacle Bracket	47- 33
A049 3909	Transfer Corona Casing	47- 16
A049 3915	Corona Wire Holder	47- 7
A049 3915	Corona Wire Holder	51- 34
A049 3919	Corona Wire Hook - BK,M	39- 21
A049 3919	Corona Wire Hook - BK,M	47- 14
A049 3919	Corona Wire Hook - BK,M	51- 41

Part No.	Description	Paper and Index No.
A049 3920	Corona Wire Hook - Y,C	47- 15
A049 3935	Discharge Corona Unit Rail	51- 21
A049 3939	Discharge Corona Unit Casing	51- 40
A049 3945	Seal - Black	27- 32
A049 3945	Seal - Black	39- 7
A049 3945	Seal - Black	47- 10
A049 3946	Seal - Cyan	27- 30
A049 3946	Seal - Blue	39- 7
A049 3946	Seal - Blue	47- 13
A049 3947	Corona Wire Guide - BK,M,D	47- 5
A049 3947	Corona Wire Guide - BK,M,D	51- 35
A049 3948	Corona Wire Guide - Y,C	47- 6
A049 3953	Belt Discharge Corona Casing	39- 20
A049 3956	Discharge Corona Rail - Paper	39- 34
A049 3961	Lever Holder	49- 24
A049 3962	Trasnfer Belt Guide	49- 16
A049 3965	Spacer	49- 12
A049 3977	Charge Corona Unit Stay	47- 22
A049 3977	Charge Corona Unit Stay	49- 4
A049 4002	Fusing Unit	59- *
A049 4080	Right Fusing Rail	65- 12
A049 4090	Left Fusing Rail	65- 2
A049 4094	Left Rail Edgeing	65- 1
A049 4100	Front Fusing Bracket	65- 27
A049 4105	Oil Supply Support Bracket	63- 19
A049 4106	Front Heater Holder	65- 13
A049 4110	Rear Fusing Bracket	65- 28
A049 4115	Rear Holder Plate	65- 20
A049 4120	Rear Heater Holder	65- 22
A049 4125	Oil Pan	63- 18
A049 4127	Fusing Unit Guide Plate	61- 10
A049 4128	Connector Bracket	61- 33
A049 4130	Pressure Lever	63- 15
A049 4140	Lower Entrance Guide	65- 10
A049 4145	Thermistor Housing Frame	61- 31

Part No.	Description	Paper and Index No.
A049 4153	Support Plate - Front Fusing Cover	61- 20
A049 4155	Leaf Spring - Oil End Sensor	61- 11
A049 4159	Oil Supply Bracket	61- 6
A049 4161	Upper Stay - Fusing Unit	61- 3
A049 4165	Silicone Oil Nozzle	61- 4
A049 4176	Oil Supply Pad Bracket	61- 23
A049 4177	Pressure Plate - Oil Supply Pad	61- 22
A049 4190	Support Plate - Oil Supply Pad	61- 21
A049 4195	Fusing Entrance Cover	59- 29
A049 4201	Fusing Exit Frame	59- 9
A049 4210	Guide Plate - Hot Roller Stripper	59- 20
A049 4221	Front Lock Arm	59- 16
A049 4223	Rear Lock Arm	59- 18
A049 4225	Lock Lever Bracket	59- 8
A049 4226	Lock Lever - Fusing Exit	59- 6
A049 4227	Lock Lever Spring	59- 10
A049 4230	Upper Guide Plate	59- 24
A049 4261	Front Fusing Cover	59- 26
A049 4450	Fusing Exit Frame	63- 10
A049 4470	Lower Guide Plate Bracket	63- 13
A049 4471	Lower Exit Guide Plate	63- 20
A049 4495	Slide Lock Arm Bracket	71- 22
A049 5100	IPU Board 1	83- 20
A049 5100	IPU Board 1	115- *
A049 5102	IC - TC23SC080AF-501	115- 1
A049 5103	IC - MB604161	115- 2
A049 5104	IC - MB652461U	115- 3
A049 5105	IC - RF5GF58-025	117- 1
A049 5106	IC - RF5GF21-017	115- 4
A049 5107	Oscillator - CX0-104B-11.6668	115- 5
A049 5112	IC - MB87494	117- 2
A049 5112	IC - MB87494	119- 1
A049 5113	IC - RF5C83	119- 2
A049 5115	IC - TC17G042AF-0236	119- 3
A049 5116	IC - RF5C61	119- 4

Part No.	Description	Paper and Index No.
A049 5121	IC - TC110G11AF-023	119- 5
A049 5126	IC - UPD27C1000AD-12	119- 6
A049 5130	IPU Memory Board	83- 18
A049 5130	IPU Memory Board	113- *
A049 5132	IC - SLA7340F2H	113- 1
A049 5133	IC - SLA7160F0J	113- 2
A049 5134	IC - SLA7800F0R	113- 3
A049 5140	IPU Board 1.5	83- 19
A049 5140	IPU Board 1.5	117- *
A049 5142	IC - RF5GF45-032	117- 3
A049 5143	IC - RF5GV161-012	117- 4
A049 5152	IC - RF5C65-0011	119- 7
A049 5153	IC - RF5C65-0012	119- 8
A049 5154	IC - RF5C65-0013	119- 9
A049 5160	IPU Board 2	83-30
A049 5160	IPU Board 2	119- *
A049 5162	IC - RF5C65-0015	119-10
A049 5190	IPU Harness - 2	83- 9
A049 5191	IPU Memory Harness	83- 7
A049 5192	IPU 1.5 Harness	83-32
A049 5205	Scanner Mother Board	19-23
A049 5275	IC - MB7132L	95- 1
A049 5279	IC - RF5GF26-017	95- 2
A049 5280	Scanner Control Board	19- 9
A049 5280	Scanner Control Board	95- *
A049 5287	IC - HN27C256G	95- 3
A049 5290	Scanner Motor Board	19-26
A049 5300	Scanner Coaxial Harness	21-24
A049 5302	PCB Relay Harness	19- 6
A049 5303	PCB Relay Harness	19- 7
A049 5305	Scanner Main Harness	23-20
A049 5306	Scanner Optical Fiber - SPU	23-24
A049 5308	Scanner EOS Harness	21- 1
A049 5310	Scanner Optical Fiber	23-21
A049 5311	Scanner Relay Optical Fiber	83- 12

Part No.	Description	Paper and Index No.
A049 5312	Scanner Harness - I/P	83- 14
A049 5313	Scanner Data Harness	23-22
A049 5314	Scanner Regist Harness	83-10
A049 5318	Scanner Motor Relay Harness	25-21
A049 5320	Home Position Sensor Harness	25-23
A049 5324	Heater Relay Harness	23-18
A049 5330	Optical Harness	21-32
A049 5404	System Control Board	83-21
A049 5406	Laser Unit Mother Board	83-22
A049 5410	Memory Board	123- *
A049 5426	Main Motor Control Board (115V)	91-21
A049 5426	Main Motor Control Board (115V)	101- *
A049 5430	Paper Feed Control Board	33- 9
A049 5435	Paper Feed Motor Board	31- 4
A049 5437	Toner Supply Motor Board	45- 4
A049 5464	Laser Unit Control Board - BK,Y	83-16
A049 5464	Laser Unit Control Board - BK,Y	127- *
A049 5465	Laser Unit Control Board - M,C	83-17
A049 5465	Laser Unit Control Board - M,C	131- *
A049 5470	LD Control Board	29- 7
A049 5470	LD Control Board	99- *
A049 5472	Shielding Plate	99- 1
A049 5495	Toner Density Sensor	41-12
A049 5512	IC - UPD78P312ACW	101- 1
A049 5530	IC - HN27C256G-26	127- 3
A049 5531	IC - HN27C256G-26	127- 4
A049 5532	IC - HN27C256G-26	131- 3
A049 5533	IC - HN27C256G-26	131- 4
A049 5540	IC - RF5GF21-017	127- 1
A049 5540	IC - RF5GF21-017	131- 1
A049 5541	IC - RF5GF21-019	127- 2
A049 5541	IC - RF5GF21-019	131- 2
A049 5603	Drum Unit Harness	89- 6
A049 5603	Drum Unit Harness	91-13
A049 5604	Development Unit Harness	41- 11

Part No.	Description	Paper and Index No.
A049 5605	Relay Harness - Toner Supply	77- 16
A049 5606	Toner Tank Unit Harness	45- 15
A049 5607	AC/DC Harness	87- 15
A049 5608	Paper Feed Relay Harness	37- 55
A049 5610	Registration Sensor Relay Harness	31- 44
A049 5611	Charging Fan Harness	85- 11
A049 5612	Lift Sensor Relay Harness	33- 8
A049 5613	Exhaust Fan Harness	81- 11
A049 5615	Toner Tank Unit Relay Harness	45- 3
A049 5616	Paper Feed Unit Harness	35- 16
A049 5620	Relay Harness	91- 10
A049 5630	Laser Unit Optical Fiber	83- 11
A049 5630	Laser Unit Optical Fiber	91- 2
A049 5631	Operation Panel Optical Fiber	83- 15
A049 5636	AC Harness - AC In	87- 14
A049 5640	High Voltage Harness - Discharge	89- 5
A049 5641	High Voltage Cable - Main Charge	85- 9
A049 5642	High Voltage Cable - Charge Grid	85- 8
A049 5644	Grounding Wire	11- 28
A049 5645	Grounding Wire - Process Control	91- 24
A049 5646	Grounding Wire - Lift Motor	35- 36
A049 5661	Laser Unit DC Harness	29- 3
A049 5663	Polygon Motor Harness	29- 4
A049 5664	Laser Unit Main Harness	29- 6
A049 5665	Laser Unit Control Harness	29- 23
A049 5666	Laser Unit Data Harness	83- 8
A049 5667	Laser Unit Heater Harness	27- 37
A049 5668	Laser Unit Sequence Harness	27- 23
A049 5668	Laser Unit Sequence Harness	29- 2
A049 5671	Optical Fiber Cable - Black	27- 41
A049 5671	Optical Fiber Cable - Black	83- 13
A049 5672	Optical Fiber Cable - Magenta	27- 42
A049 5672	Optical Fiber Cable - Magenta	83- 27
A049 5673	Optical Fiber Cable - Yellow	27- 22
A049 5673	Optical Fiber Cable - Yellow	83- 6

Part No.	Description	Paper and Index No.
A049 5674	Optical Fiber Cable - Cyan	27- 21
A049 5674	Optical Fiber Cable - Cyan	83- 5
A049 5720	Lightning Arrester Board (115V)	87- 25
A049 5750	Polygon Motor	27- 14
A049 5756	Polygon Motor Control Board	29- 13
A049 5765	Toner End Sensor	45- 22
A049 5767	Toner Supply Sensor	41- 5
A049 5780	Quenching Lamp	39- 33
A049 5802	AC Power Supply Bracket	85- 15
A049 5810	Sequence Control Board Bracket	91- 3
A049 5820	Process Control Board Bracket	91- 22
A049 5825	Right Support Plate	89- 3
A049 5826	Left Support Plate	89- 9
A049 5830	Harness Clamp	91- 11
A049 5840	Paper Feed Unit Connector Bracket	79- 31
A049 5854	Right Bracket - Collection Bottle	13- 19
A049 5855	Switch Cover	13- 23
A049 5856	Safety Switch Actuator	13- 17
A049 5858	Laser Unit Control Board Bracket	13- 25
A049 5870	Mother Board Bracket - Laser Unit	83- 23
A049 5876	PCB Guide Bracket	83- 2
A049 5877	Front Support Plate - PCB Guide	83- 1
A049 5879	Rear Support Plate - PCB Guide	83- 31
A049 5880	PCB Support Plate Bracket	83- 4
A049 6460	Right Stay - Belt Unit	53- 31
A049 6464	Left Stay - Belt Unit	51- 42
A049 6466	Left Stay Support Plate	51- 1
A049 6467	Adjusting Shaft Bracket	51- 17
A049 6474	Right Support Plate Stay	53- 29
A049 6476	Pressure Arm	51- 3
A049 6476	Pressure Arm	53- 22
A049 6484	Lift Shaft Bracket	53- 9
A049 6487	Lift Shaft Lock	53- 7
A049 6489	Transfer Belt Lift Plate	53- 15
A049 6492	Transfer Belt Link	53- 10

Part No.	Description	Paper and Index No.
A049 6501	Stay Cover - Belt Unit	51- 31
A049 6504	Belt Unit Connector Cover	53- 2
A049 6507	Transfer Belt Unit Cover	51- 24
A049 6513	Right Slide Rail Guide	79- 28
A049 6515	Slide Rail Guide Bracket	79- 7
A049 6516	Left Slide Rail Guide	79- 3
A049 6523	Middle Left Stay	87- 2
A049 6525	Middle Right Stay	87- 13
A049 6526	Belt Unit Stopper Cam	87- 1
A049 6541	Middle Stay - Stopper Pin	87- 6
A049 6544	Stopper Pin Guide Plate	13- 21
A049 6545	Mylar - Stopper Guide Plate	13- 22
A049 6551	Pick-off Pawl Solenoid	51- 26
A049 6552	Middle Stay	51- 16
A049 6553	Pick-off Pawl Link Plate	51- 14
A049 6554	Solenoid Bracket - Pick-off Pawl	51- 43
A049 6556	Pick-off Pawl Lever	51- 44
A049 6559	Transfer Belt Unit Guide	51- 8
A049 6560	Pick-off Pawl	51- 10
A049 6561	Pick-off Pawl Bracket	51- 9
A049 6602	SP Panel Cover	13- 24
A049 6604	Right Door Hinge	13- 28
A049 6605	Left Bracket - Collection Bottole	13- 5
A049 6606	Left Door Hinge	13- 9
A049 6610	Key Counter Cover	83- 3
A049 6611	Upper Front Stay	77- 2
A049 6614	Operation Panel Support Plate	77- 1
A049 6617	Rear Exhaust Fan Bracket	85- 6
A049 6621	Upper Right Stay	83- 25
A049 6623	Right Cover - IPU Board	83- 24
A049 6626	Rear Stay	85- 14
A049 6631	Development Rear Cover	71- 25
A049 6636	Rear Cover - Paper Feed Unit	77- 28
A049 6645	Left Stay - Transfer Slide Rail	79- 1
A049 6651	Front Stay - Scanner Slide Rail	81- 22

Part No.	Description	Paper and Index No.
A049 6653	Rear Stay - Scanner Slide Rail	81- 27
A049 6661	Main Switch Cover	83- 33
A049 6666	Power Supply Cord Bracket (220/240V)	91- 7
A049 6675	Rear Cover Shielding Plate	73- 17
A049 6679	Shielding Plate Bracket	73- 18
A049 6681	Fusing Unit Relay Shaft	57- 23
A049 6686	Belt Tightener	57- 18
A049 6731	Toner Collection Joint Bracket	69- 38
A049 6732	Joint - Collection Bottle	69- 35
A049 6733	Joint - Cleaning	69- 33
A049 6735	Joint - Belt Cleaning	69- 31
A049 6737	Toner Coil Sensor Actuator	69- 36
A049 6738	Bearing - Toner Transport Coil	69- 29
A049 6739	Toner Collection Pipe	69- 25
A049 6756	Sensor Bracket	69- 4
A049 6766	Roller	69- 3
A049 6767	Toner Collection Pipe Bracket	69- 17
A049 6769	Joint - Shield	69- 24
A049 6777	Gear Bracket - Belt Cleaning	69- 7
A049 6810	Toner Collection Bottle Cover	13- 3
A049 6820	Base Plate - Toner Collection	87- 4
A049 6850	Left Stay	87- 5
A049 6855	Roller Bracket	69- 1
A049 6860	Pipe Knock Lever	69- 20
A049 6862	Cooling Fan Duct	91- 19
A049 6901	Ozone Neutrizer Casing	81- 20
A049 6905	Upper Cover - Ozone Filter Case	81- 4
A049 6907	Front Side Plate	81- 18
A049 6908	Rear Side Plate	81- 9
A049 6909	Shutter Solenoid	81- 5
A049 6915	Shutter	81- 1
A049 6917	Shutter Frame	81- 3
A049 6918	Ozone Unit Rail	81- 2
A049 6920	Filter Bracket	81- 19
A049 6923	Ozone Filter Casing	85- 4

Part No.	Description	Paper and Index No.
A049 6924	Ozone Neutrizer Casing	81- 13
A049 6931	Filter Right Casing	81- 17
A049 6932	Filter Left Casing	81- 15
A049 6936	Ozone Filter Stopper	85- 3
A049 6938	Inner Cover - Ozone Unit	83- 29
A049 9001	Toner Shield Glass : -40;C	27- 33
A049 9002	Toner Shield Glass : -30;C	27- 33
A049 9003	Toner Shield Glass : -20;C	27- 33
A049 9004	Toner Shield Glass : -10;C	27- 33
A049 9005	Toner Shield Glass : +2;C	27- 33
A049 9006	Toner Shield Glass : +10;C	27- 33
A049 9007	Toner Shield Glass : +20;C	27- 33
A049 9008	Toner Shield Glass : +30;C	27- 33
A049 9009	Toner Shield Glass : +40;C	27- 33
A049 9010	Exit Guide Set	43- 18
A049 9011	Cleaning Entrance Seal	67- 8
A049 9012	Entrance Seal - Belt Cleaning	55- 14
A053 1957	Flex Hinge - Platen Cover	17- 5
A053 2632	Knob - Transport Middle Guide	37- 58
A053 2915	Bottom Plate - Large	17- 18
A053 2916	Friction Pad - B	17- 19
A053 2917	Bottom Plate - Small	17- 18
A060 1865	Front Platen Cover	17- 6
A060 1866	Rear Platen Cover	17- 7
A382 1300	Multi Decal - French	141- *
A382 1301	Multi Decal - German	141- *
A382 1302	Multi Decal - Spanish	141- *
A382 1303	Multi Decal - Italian	141- *
A382 1305	Multi Decal - Operation - French	141- *
A382 1306	Multi Decal - Operation - German	141- *
A382 1307	Multi Decal - Operation - Spanish	141- *
A382 1308	Multi Decal - Operation - Italian	141- *
A382 1310	Multi Decal - Operation - French	141- *
A420 2761	Gear - 38T	45- 26
A420 3232	Connector Spring	77- 15

Part No.	Description	Paper and Index No.
A420 3232	Connector Spring	79- 32
A420 3232	Connector Spring	91- 17
A458 2479	Lock Pin Spring	69- 46
A464 4174	Stand	87- 16
A466 5121	Push Switch	13- 29
G000 1945	Cylinder	27- 19
G003 2630	Fiber Connector	127- 5
G003 4068	Spring	57- 25
G003 4068	Spring	73- 6
GC02 5001	F Theta Lens L1	29- 17
5053 0223	Bushing - 8mm	33- 30
5053 0223	Bushing - 8mm	35- 9
5053 0223	Bushing - 8mm	37- 34
5053 0223	Bushing - 8mm	65- 19
5053 0447	Bushing - 6mm	33- 19
5053 0447	Bushing - 6mm	37- 14
5053 0447	Bushing - 6mm	51- 18
5053 0447	Bushing - 6mm	55- 19
5053 0447	Bushing - 6mm	69- 6
5053 0447	Bushing - 6mm	71- 15
5053 0449	Collar - Shaft Fixing	73- 22
5171 1605	Pressure Spring	81- 6
5203 1159	Pressure Spring	69- 23
5203 1852	Bushing - 6x8x4mm	69- 21
5203 4146	Thermistor Spring	61- 30
5204 4505	Collar	57- 3
5205 1101	Sprocket - 12T	37- 8
5205 2612	Gear - 19Z	45- 45
5205 2644	Paper End Actuator	37- 51
5205 2680	Coupled Gear - 16T/53T	35- 11
5205 2681	Coupled Gear - 17T/50T	35- 10
5205 2697	Bushing - Upper Registration Roller	31- 18
5205 2697	Bushing - Upper Registration Roller	37- 60
5205 2697	Bushing - Upper Registration Roller	59- 14
5205 2734	Magnet - By-pass Table	33- 20

Part No.	Description	Paper and Index No.
5205 2777	Cushion - Lower Pick Up Guide	37- 20
5205 2865	Bushing - Paper Feed Roller	33- 15
5205 2865	Bushing - Paper Feed Roller	37- 5
5205 2866	Magnetic Clutch Collar	31- 20
5205 2869	Front Side Fence - Large	17- 20
5205 2893	Cushion - Sector Gear	45- 17
5205 2947	Rear Side Fence - Large	17- 22
5205 2953	Rear Fence	17- 14
5205 2959	Cassette Body Cushion	17- 24
5205 2960	Actuator - A3	17- 17
5205 2962	Actuator - A4R	17- 17
5205 2964	Actuator - A4S	17- 17
5205 2971	Actuator - 11x17	17- 17
5205 2979	Actuator - 11x8 1/2	17- 17
5205 2996	Actuator - 8 1/2x11	17- 17
5205 3863	Leaf Spring	21- 18
5205 3863	Leaf Spring	71- 11
5205 3863	Leaf Spring	77- 25
5205 3863	Leaf Spring	79- 10
5205 3863	Leaf Spring	85- 16
5205 4305	Spring - Hot Roller Stripper	59- 22
5205 5250	LED Sensor Type S	25- 24
5205 5251	LED Sensor Type - T	33- 5
5205 5251	LED Sensor Type - T	63- 4
5205 5253	Photointerruptor Pack	37- 25
5205 6492	Rear Side Fence - Small	17- 22
5205 6493	Front Side Fence - Small	17- 20
5205 9101	Gap Gauge	143- 9
5206 2687	Stud Screw - M3	57- 7
5206 2687	Stud Screw - M3	73- 16
5206 9600	Sensor Checker	143- 10
5207 7702	Photo Coupler - ON2509	31- 43
5208 2454	Stepped Screw - M4	79- 30
5208 2675	Spring	79- 29
5208 5331	Stepper Motor - DC 6V	31- 1

Part No.	Description	Paper and Index No.
5209 4470	Upper Exit Roller	59- 15
5211 2259	Spacer - M20 X 0.1	75- 15
5215 2621	Snap Ring - M6	47- 30
5215 2838	Rubber Magnet	17- 10
5215 2839	Spring	17- 12
5215 4116	Oil Blade Holder	61- 26
5215 4497	Exit Antistatic Brush	81- 24
5215 5230	Photointerruptor - L Type	35- 29
5215 5250	Thermistor	61- 29
5215 5304	Toner Overflow Sensor	13- 11
5215 5843	Spring	17- 13
5216 3133	Drive Spring - Toner End	51- 11
5216 4145	Thermofuse Decal	59- 13
5216 4145	Thermofuse Decal	141- 1
5216 5245	Photointerruptor - IL-G-3P-S3T2-E	69- 39
5219 3633	Collar	75- 50
5219 3712	Compression Spring	69- 9
5219 3712	Compression Spring	75- 27
5301 1662	Hexagon Bolt	87- 21
5304 1639	Bushing - 8mm	53- 25
5304 1639	Bushing - 8mm	71- 18
5353 1267	Decal - Laser Caution	27- 43
5353 1267	Decal - Laser Caution	141- 31
5353 5625	Thermistor	27- 24
5360 2575	Gear - 28Z	69- 16
5400 3404	Stepped Screw	29- 10
5400 3404	Stepped Screw	47- 31
5400 3404	Stepped Screw	49- 22
5400 3404	Stepped Screw	57- 33
5400 3404	Stepped Screw	59- 7
5400 3404	Stepped Screw	65- 11
5403 2075	Stepped Screw	19- 20
5403 2075	Stepped Screw	49- 20
5403 2075	Stepped Screw	51- 2
5403 2075	Stepped Screw	53- 24

Part No.	Description	Paper and Index No.
5403 2320	Guide Pin - Drum Stay	79- 4
5403 2817	Reverse Pin - Reverse Roller	45- 6
5413 1882	Stepped Screw	51- 12
5413 1882	Stepped Screw	57- 34
5413 1882	Stepped Screw	79- 27
5413 2596	Stud - Paper Feed Unit	71- 23
5413 2596	Stud - Paper Feed Unit	91- 25
5413 4835	Decal - Paper Level	17- 21
5413 4835	Decal - Paper Level	141- 2
5415 1053	Caster	87- 20
5415 2904	Stopper Pin	83- 28
5415 4125	Nylon Clip	61- 1
5415 4310	Valve - Oil Pump	61- 8
5419 5714	Stepped Screw - M4	19- 18
5419 5714	Stepped Screw - M4	65- 3
5420 9504	Thermo Meter - HLC	143- 2
5420 9505	Probe - HLC-30	143- 3
5420 9507	Digital Multimeter - Beckman	143- 4
5420 9508	Test Lead Kit	143- 5
5420 9550	Silicone Oil	143- 6
5424 2625	Spring - Connector	91- 16
5429 2830	Roller	37- 6
5434 7916	High Voltage Decal	73- 20
5434 7916	High Voltage Decal	75- 3
5434 7916	High Voltage Decal	141- 3
5442 1053	Rear Grip - Bottom Plate	87- 19
5442 2108	Spring - Corona Wire	39- 13
5442 2110	Plug - Corona Unit	39- 15
5442 2117	Shoulder Screw - Hinge	27- 5
5442 2165	Receptacle Housing - Main Corona	89- 4
5442 2754	Spring - Registration Roller	31- 19
5442 4495	Slip Clutch	63- 5
5442 9102	Light Shelding Bag	143- 1
5442 9103	Launa Oil 40	143- 7
5443 2668	Bushing	33- 64

Part No.	Description	Paper and Index No.
5443 2668	Bushing	37- 18
5443 2706	Plate - 12x220x1T	33- 46
5446 1086	Leveling Foot Guide	87- 17
5446 1817	Lens Guide Roller	69- 18
5446 2569	Spring - Detent	51- 7
5446 2569	Spring - Detent	53- 23
5446 3475	Developer - Receptacle	13- 14
5446 3648	Stepped Screw - M4	55- 11
5446 3648	Stepped Screw - M4	67- 16
5446 4577	Spring - Turn Plate	69- 19
5446 5832	Connector Guide Pin	77- 5
5446 5832	Connector Guide Pin	79- 21
5446 5832	Connector Guide Pin	91- 15
5447 2630	Spring - Registration Roller	49- 28
5447 2630	Spring - Registration Roller	75- 10
5447 2676	Output Hub	33- 66
5447 2676	Output Hub	37- 39
5447 2678	Slip Clutch Cover	33- 32
5447 2678	Slip Clutch Cover	37- 38
5447 2681	Snap Ring	33- 26
5447 2681	Snap Ring	37- 31
5447 2681	Snap Ring	51- 19
5447 2681	Snap Ring	55- 2
5447 2681	Snap Ring	63- 12
5447 2693	Separation Roller	33- 31
5447 2693	Separation Roller	37- 37
5447 2695	Input Hub	33- 60
5447 2695	Input Hub	37- 41
5447 2697	Cylindrical Spring	33- 69
5447 2697	Cylindrical Spring	37- 40
5447 2723	Pick-up Roller	33- 25
5447 2723	Pick-up Roller	37- 30
5447 2726	Paper Feed Roller	33- 28
5447 2726	Paper Feed Roller	37- 36
5447 2927	Friction Pad - B	33- 58

Part No.	Description	Paper and Index No.
5447 3200	Bushing - 6mm	45- 25
5447 3922	Gear - 16T	67- 21
5447 4241	Tube Clamp	61- 7
5447 4982	Decal - Open	75- 13
5447 4982	Decal - Open	141- 4
5447 5438	Anticondensation Heater - 115V	27- 36
5447 5638	Anticondensation Heater - 220/240V	27- 36
5447 9078	Heat Resisting Grease MT-78	143- 8
5506 6300	Shaft - Master Eject Command	27- 3
5507 4312	Stepped Screw - Etching	41- 14
5840 1632	Stepped Screw	59- 1
5840 1632	Stepped Screw	63- 2
5875 2088	Shoulder Screw - M4	19- 16
5887 4162	Screw - Driven Guide Plate	37- 11
5919 2201	Shoulder Screw - M4	13- 6
5937 2162	Magnetic Clutch Collar	49- 25
6754 3278	Stepped Screw	49- 21
6754 3278	Stepped Screw	87- 23

Part No.	Description	Paper and Index No.
0312 5100B	Philips Pan Head Screw - M2.5x10	23-104
0313 0040B	Philips Pan Head Screw - M3x4	21-109
0313 0050B	Philips Pan Head Screw - M3x5	41-102
0313 0050B	Philips Pan Head Screw - M3x5	45-104
0313 0060B	Philips Pan Head Screw - M3x6	31-109
0313 0060B	Philips Pan Head Screw - M3x6	33-102
0313 0060B	Philips Pan Head Screw - M3x6	43-103
0313 0060B	Philips Pan Head Screw - M3x6	51-104
0313 0060B	Philips Pan Head Screw - M3x6	55-105
0313 0060B	Philips Pan Head Screw - M3x6	61-102
0313 0060B	Philips Pan Head Screw - M3x6	69-105
0313 0060B	Philips Pan Head Screw - M3x6	71-105
0313 0060B	Philips Pan Head Screw - M3x6	75-108
0313 0080B	Philips Pan Head Screw - M3x8	37-111
0313 0080B	Philips Pan Head Screw - M3x8	45-107
0313 0100B	Philips Pan Head Screw - M3x10	45-110
0313 0140B	Philips Pan Head Screw - M3x14	91-104
0313 0350B	Philips Pan Head Screw - M3x35	85-105
0313 0350B	Philips Pan Head Screw - M3x35	91-107
0314 0040W	Philips Pan Head Screw - M4x4	79-104
0314 0040W	Philips Pan Head Screw - M4x4	81-103
0314 0050B	Philips Pan Head Screw - M4x5	49-102
0314 0060B	Philips Pan Head Screw - M4x6	31-113
0314 0060B	Philips Pan Head Screw - M4x6	33-113
0314 0060B	Philips Pan Head Screw - M4x6	41-103
0314 0060B	Philips Pan Head Screw - M4x6	43-104
0314 0060B	Philips Pan Head Screw - M4x6	45-102
0314 0060B	Philips Pan Head Screw - M4x6	51-103
0314 0060B	Philips Pan Head Screw - M4x6	53-107
0314 0080B	Philips Pan Head Screw - M4x8	65-103
0314 0080B	Philips Pan Head Screw - M4x8	73-104
0314 0080B	Philips Pan Head Screw - M4x8	75-107
0314 0080W	Philips Pan Head Screw - M4x8	35-104
0314 0100B	Philips Pan Head Screw - M4x10	31-114
0314 0100B	Philips Pan Head Screw - M4x10	33-104

Part No.	Description	Paper and Index No.
0314 0100B	Philips Pan Head Screw - M4x10	35-106
0314 0100B	Philips Pan Head Screw - M4x10	39-105
0314 0100B	Philips Pan Head Screw - M4x10	41-106
0314 0100B	Philips Pan Head Screw - M4x10	79-103
0314 0100W	Philips Pan Head Screw - M4x10	33-118
0314 0100W	Philips Pan Head Screw - M4x10	37-108
0314 0120B	Philips Pan Head Screw - M4x12	41-108
0314 0120B	Philips Pan Head Screw - M4x12	43-102
0314 0120B	Philips Pan Head Screw - M4x12	91-106
0314 0140B	Philips Pan Head Screw - M4x14	85-104
0314 0140B	Philips Pan Head Screw - M4x14	91-105
0314 0160B	Philips Pan Head Screw - M4x16	87-107
0314 0300B	Philips Pan Head Screw - M4x30	85-103
0314 0450B	Philips Pan Head Screw - M4x45	81-102
0314 0450B	Philips Pan Head Screw - M4x45	83-103
0314 0450B	Philips Pan Head Screw - M4x45	85-102
0315 0080B	Philips Pan Head Screw - M5x8	11-104
0315 0080B	Philips Pan Head Screw - M5x8	57-101
0315 0080M	Philips Pan Head Screw - M5x8	91-103
0323 0080B	Philips Sunk Screw - M3x8	45-109
0324 0060B	Philips Sunken Head Screw - M4x6	13-101
0324 0060W	Philips Sunken Head Screw - M4x6	35-108
0352 5050B	Screw - M2.5x5	21-111
0353 0040B	Screw - M3x4	21-110
0353 0050B	Philips Truss Head Screw M3x5	21-106
0353 0060B	Screw - M3x6	33-117
0353 0060B	Screw - M3x6	55-104
0353 0060B	Screw - M3x6	69-108
0353 0060B	Screw - M3x6	87-102
0353 0080B	Screw - M3x8	21-102
0354 0050W	Philips Pan Head Screw - M4x5	19-103
0354 0060B	Screw - M4x6	11-102
0354 0060B	Screw - M4x6	13-102
0354 0060B	Screw - M4x6	19-101
0354 0060B	Screw - M4x6	21-107

Part No.	Description	Paper and Index No.
0354 0060B	Screw - M4x6	23-101
0354 0060B	Screw - M4x6	25-101
0354 0060B	Screw - M4x6	27-105
0354 0060B	Screw - M4x6	29-101
0354 0060B	Screw - M4x6	31-102
0354 0060B	Screw - M4x6	33-101
0354 0060B	Screw - M4x6	35-111
0354 0060B	Screw - M4x6	39-103
0354 0060B	Screw - M4x6	41-104
0354 0060B	Screw - M4x6	45-101
0354 0060B	Screw - M4x6	47-102
0354 0060B	Screw - M4x6	49-101
0354 0060B	Screw - M4x6	51-101
0354 0060B	Screw - M4x6	53-101
0354 0060B	Screw - M4x6	55-101
0354 0060B	Screw - M4x6	57-112
0354 0060B	Screw - M4x6	59-101
0354 0060B	Screw - M4x6	61-101
0354 0060B	Screw - M4x6	63-105
0354 0060B	Screw - M4x6	65-101
0354 0060B	Screw - M4x6	69-101
0354 0060B	Screw - M4x6	71-101
0354 0060B	Screw - M4x6	73-101
0354 0060B	Screw - M4x6	75-105
0354 0060B	Screw - M4x6	77-101
0354 0060B	Screw - M4x6	79-102
0354 0060B	Screw - M4x6	81-101
0354 0060B	Screw - M4x6	83-101
0354 0060B	Screw - M4x6	85-101
0354 0060B	Screw - M4x6	87-101
0354 0060B	Screw - M4x6	89-101
0354 0060B	Screw - M4x6	91-101
0354 0060F	Philips Pan Head Screw - M4x6	11-101
0354 0060F	Philips Pan Head Screw - M4x6	41-109
0354 0060F	Philips Pan Head Screw - M4x6	45-108

Part No.	Description	Paper and Index No.
0354 0060F	Philips Pan Head Screw - M4x6	51-106
0354 0060F	Philips Pan Head Screw - M4x6	55-106
0354 0060F	Philips Pan Head Screw - M4x6	75-101
0354 0060F	Philips Pan Head Screw - M4x6	77-102
0354 0060F	Philips Pan Head Screw - M4x6	83-102
0354 0080B	Screw - M4x8	63-107
0354 0080B	Screw - M4x8	65-102
0354 0080F	Screw - M4x8	13-104
0354 0080W	Screw - M4X8	17-101
0354 0100B	Screw - M4x10	25-102
0354 0100B	Screw - M4x10	55-102
0354 0120B	Screw - M4x12	61-103
0354 0200B	Screw - M4x20	25-108
0354 0200W	Screw - M4x20	53-108
0355 0160B	Screw - M5x16	65-108
0413 0062B	Tapping Screw - M3x6	39-102
0413 0062B	Tapping Screw - M3x6	41-107
0413 0082B	Tapping Screw - M3x8	39-101
0414 0062B	Binding Self Tapping Screw - M4x6	11-103
0414 0062B	Screw - M4x6	15-103
0414 0082B	Binding Self Tapping Screw - M4x8	13-106
0414 0082B	Binding Self Tapping Screw - M4x8	39-104
0414 0082B	Binding Self Tapping Screw - M4x8	77-104
0414 0102B	Tapping Screw M4 x 10	41-101
0414 0102W	Tapping Screw - M4x10	17-102
0433 0040B	Screw - M3x4	67-101
0433 0050B	Tapping Screw - M3x5	37-112
0433 0060B	Philips Tapping Screw - M3x6	67-103
0433 0080B	Philips Screw - M3x8	67-102
0433 0100B	Philips Tapping Screw - M3X10	67-104
0434 0060B	Philips Tapping Screw - M4x6	13-103
0434 0060B	Philips Tapping Screw - M4x6	31-112
0434 0060B	Philips Tapping Screw - M4x6	33-105
0434 0060B	Philips Tapping Screw - M4x6	35-105
0434 0060B	Philips Tapping Screw - M4x6	37-103

Part No.	Description	Paper and Index No.
0434 0060B	Philips Tapping Screw - M4x6	71-102
0434 0060B	Philips Tapping Screw - M4x6	77-103
0434 0060B	Philips Tapping Screw - M4x6	79-101
0434 0060B	Philips Tapping Screw - M4x6	81-104
0434 0060B	Philips Tapping Screw - M4x6	87-105
0434 0060B	Philips Tapping Screw - M4x6	91-102
0434 0080W	Tapping Screw - M4x8	33-109
0434 0080W	Tapping Screw - M4x8	37-102
0443 0102W	Tapping Screw - M3 x 10 mm	45-105
0533 0040B	Hexagonal Set Screw - M3x4	21-104
0533 0040B	Hexagonal Set Screw - M3x4	31-105
0574 0040E	Hexagon Headless Set Screw - M4x4	31-108
0574 0040E	Hexagon Headless Set Screw - M4x4	49-103
0574 0040E	Hexagon Headless Set Screw - M4x4	57-102
0574 0040E	Hexagon Headless Set Screw - M4x4	71-108
0574 0040E	Hexagon Headless Set Screw - M4x4	73-102
0574 0040E	Hexagon Headless Set Screw - M4x4	75-115
0574 0050E	Hexagon Headless Set Screw - M4x5	25-104
0574 0050E	Hexagon Headless Set Screw - M4x5	31-110
0574 0050E	Hexagon Headless Set Screw - M4x5	33-110
0574 0050E	Hexagon Headless Set Screw - M4x5	37-101
0574 0050E	Hexagon Headless Set Screw - M4x5	47-104
0574 0050E	Hexagon Headless Set Screw - M4x5	49-105
0574 0050E	Hexagon Headless Set Screw - M4x5	57-113
0575 0050E	Hexagon Headless Set Screw - M5x5	73-108
0583 0141B	Hexagonal Head Bolt - M3x14	75-102
0593 0060B	Hexagonal Bolt - M3x6	57-103
0593 0120W	Hexagon Headless Set Screw - 3x12	73-106
0622 0100W	Parallel Pin - M2x10	33-112
0632 0120	Parallel Pin - M2x12	31-115
0701 0040W	Flat Washer - M4	69-107
0707 4050B	Bushing - 4x5	31-107
0708 0060B	Washer - M6	27-101
0710 0025B	Hexagon Nut - M2.5	23-105
0710 0030B	Hexagon Nut - M3	75-103

Part No.	Description	Paper and Index No.
0710 0050	Hexagonal Nut - M5	63-103
0712 0080Z	Hexagonal Nut - M8	73-105
0720 0025B	Retaining Ring - M2.5	41-105
0720 0025W	Retaining Ring - M2.5	45-114
0720 0030B	Retaining Ring - M3	11-105
0720 0030B	Retaining Ring - M3	13-107
0720 0030B	Retaining Ring - M3	21-103
0720 0030B	Retaining Ring - M3	33-114
0720 0030B	Retaining Ring - M3	37-115
0720 0030B	Retaining Ring - M3	43-105
0720 0030B	Retaining Ring - M3	45-112
0720 0030B	Retaining Ring - M3	51-105
0720 0030B	Retaining Ring - M3	59-103
0720 0030B	Retaining Ring - M3	69-104
0720 0030E	Retaining Ring - M3	35-101
0720 0030E	Retaining Ring - M3	79-107
0720 0040B	Retaining Ring - M4	25-105
0720 0040B	Retaining Ring - M4	35-110
0720 0040B	Retaining Ring - M4	43-101
0720 0040B	Retaining Ring - M4	45-111
0720 0040B	Retaining Ring - M4	49-106
0720 0040B	Retaining Ring - M4	53-105
0720 0040B	Retaining Ring - M4	55-103
0720 0040B	Retaining Ring - M4	57-109
0720 0040B	Retaining Ring - M4	61-106
0720 0040B	Retaining Ring - M4	63-102
0720 0040B	Retaining Ring - M4	65-107
0720 0040B	Retaining Ring - M4	67-105
0720 0040B	Retaining Ring - M4	69-102
0720 0040B	Retaining Ring - M4	71-107
0720 0040B	Retaining Ring - M4	73-107
0720 0040B	Retaining Ring - M4	75-109
0720 0040E	Retaining Ring - M4	31-103
0720 0040E	Retaining Ring - M4	33-108
0720 0040E	Retaining Ring - M4	35-102

Part No.	Description	Paper and Index No.
0720 0040E	Retaining Ring - M4	37-105
0720 0050B	Retaining Ring - M5	21-105
0720 0050B	Retaining Ring - M5	31-111
0720 0050B	Retaining Ring - M5	33-106
0720 0050B	Retaining Ring - M5	35-109
0720 0050B	Retaining Ring - M5	37-113
0720 0050B	Retaining Ring - M5	51-102
0720 0050B	Retaining Ring - M5	53-104
0720 0050B	Retaining Ring - M5	59-102
0720 0050B	Retaining Ring - M5	63-101
0720 0050B	Retaining Ring - M5	75-111
0720 0050B	Retaining Ring - M5	79-106
0720 0050B	Retaining Ring - M5	87-106
0720 0050E	Retaining Ring - M5	33-111
0720 0050E	Retaining Ring - M5	37-109
0720 0050E	Retaining Ring - M5	57-106
0720 0060B	Retaining Ring - M6	25-106
0720 0060B	Retaining Ring - M6	31-116
0720 0060B	Retaining Ring - M6	37-107
0720 0060B	Retaining Ring - M6	53-106
0720 0060B	Retaining Ring - M6	57-105
0720 0060B	Retaining Ring - M6	63-104
0720 0060B	Retaining Ring - M6	65-106
0720 0060B	Retaining Ring - M6	69-103
0720 0060B	Retaining Ring - M6	71-106
0720 0060B	Retaining Ring - M6	75-112
0720 0060E	Retaining Ring - M6	33-107
0720 0060E	Retaining Ring - M6	37-104
0720 0060E	Retaining Ring - M6	57-107
0720 0080B	Retaining Ring - M8	53-102
0720 0080B	Retaining Ring - M8	57-108
0725 0100E	Retaining Ring C - M10	47-103
0725 0100E	Retaining Ring C - M10	53-103
0725 0100E	Retaining Ring C - M10	79-105
0725 0120	Retaining Ring C - M12	43-106

Part No.	Description	Paper and Index No.
0725 0120E	Retaining Ring C - M12	65-104
0725 0120E	Retaining Ring C - M12	75-110
0725 0190E	Retaining Ring C - M19	75-106
0725 0200E	Retaining Ring C - M20	65-105
0740 3906	Bearing	75-104
0741 3008	Ball Bearing - 8x22	57-110
0741 3906	Bushing - M6	75-114
0742 3010	Ball Bearing - 10x26	57-111
0742 3808	Ball Bearing - 8x16	31-104
0742 3808	Ball Bearing - 8x16	37-106
0802 5131	Truss Head Screw - M4x8	17-103
0803 0018	Knob Screw	13-105
0803 0020	Stepped Screw	77-107
0805 3042	Ball Bearing - 6x10x3mm	33-119
0805 3042	Ball Bearing - 6x10x3mm	37-110
0805 3104	Ball Bearing - 8x22x7mm	65-109
0805 3205	Ball Bearing - 10x19x7mm	47-101
0805 3385	Bushing - 6mm	63-106
0805 3403	Bearing - DR18 - H6	21-108
0807 2036	Washer - M3	45-115
0807 7088	Spacer - 17.2x23x0.1	55-107
0930 0406A	Parallel Key	71-109
0950 4008B	Screw - M4x8	91-118
0951 3005	Philips Screw With Flat Washer - M3	61-104
0951 3005B	Philips Screw With Flat Washer M3x5	19-102
0951 3005B	Philips Screw With Flat Washer M3x5	23-102
0951 3005B	Philips Screw With Flat Washer M3x5	45-103
0951 3006B	Philips Screw with Flat Washer - M3	19-105
0951 3006B	Philips Screw with Flat Washer - M3	21-101
0951 3006B	Philips Screw with Flat Washer - M3	25-103
0951 3006B	Philips Screw with Flat Washer - M3	29-102
0951 3006B	Philips Screw with Flat Washer - M3	33-103
0951 3006B	Philips Screw with Flat Washer - M3	45-106
0951 3006B	Philips Screw with Flat Washer - M3	77-105
0951 3008B	Philips Screw With Flat Washer - M3	27-106

Part No.	Description	Paper and Index No.
0951 3008B	Philips Screw With Flat Washer - M3	49-104
0951 3010B	Philips Screw With Flat Washer - M3	45-113
0951 3025B	Philips Screw With Flatwasher - M3x	29-104
0951 4006B	Philips Screw with Flat Washer - M4	19-104
0951 4006B	Philips Screw with Flat Washer - M4	27-103
0951 4006B	Philips Screw with Flat Washer - M4	35-107
0951 4006B	Philips Screw with Flat Washer - M4	37-114
0951 4008B	Philips Screw With Flat Washer - M4	27-102
0951 4008B	Philips Screw With Flat Washer - M4	31-101
0951 4008B	Philips Screw With Flat Washer - M4	57-104
0951 4008B	Philips Screw With Flat Washer - M4	73-103
0951 4008B	Philips Screw With Flat Washer - M4	77-106
0951 4008B	Philips Screw With Flat Washer - M4	87-103
0951 4008F	Screw - M4x8	61-105
0951 4008F	Screw - M4x8	75-116
0951 4010B	Philips Screw With Flat Washer - M4	23-103
0951 4010B	Philips Screw With Flat Washer - M4	25-107
0951 4010B	Philips Screw With Flat Washer - M4	29-103
0951 4012B	Philips Screw With Flat Washer	27-104
0951 4014B	Philips Screw With Flat Washer M4	31-106
0951 4014B	Philips Screw With Flat Washer M4	87-104
0951 5012B	Philips Pan Head Screw - M5x12	71-103
0951 5018B	Screw - M5x18	75-113
0965 3006B	Tapping Screw With Flat Washer M3x6	27-107
0965 3008B	Tapping Screw With Washer - M3x8	33-116
0965 4008B	Tapping Screw - M4 x 8	31-117
0965 4008B	Tapping Screw - M4 x 8	71-104
0965 4012W	Philips Pan Head Screw - M4x12	17-104
1005 0528	Card Puller	95-101
1005 0528	Card Puller	113-101
1005 0528	Card Puller	115-101
1005 0528	Card Puller	117-101
1005 0528	Card Puller	119-101
1005 0528	Card Puller	121-101
1005 0528	Card Puller	127-101

Part No.	Description	Paper and Index No.
1005 0528	Card Puller	131-101
1005 0785	PCB Guide Rail	83-104
1005 0907	Rail - 50x6040	23-106
1100 0350	Closed Terminal	133-101
1100 0350	Closed Terminal	135-101
1100 0350	Closed Terminal	137-101
1100 0504	Closed Terminal - 44mm	135-102
1100 0844	Socket - Mate-N-Lock	135-103
1100 0853	Closed Terminal	133-102
1100 0853	Closed Terminal	135-104
1100 0853	Closed Terminal	137-102
1100 0916	Connector - 2P	133-103
1100 1041	Pin - Mate-N-Lock	133-104
1100 1042	Socket - Mate-N-Lock	133-105
1100 1043	Pin - Mate-N-Lock	137-103
1100 1090	Connector - 3P	105-101
1100 1093	Connector - 6P	101-101
1100 1093	Connector - 6P	105-102
1100 1159	Socket - Mate-N-Lock	135-105
1100 1171	Fastening Receptacle	133-106
1100 1172	Fastening Receptacle	133-107
1100 1172	Fastening Receptacle	135-106
1100 1182	Socket - Mate-N-Lock	135-107
1100 1182	Socket - Mate-N-Lock	137-104
1100 1238	Pin - Mate-N-Lock	135-108
1100 1238	Pin - Mate-N-Lock	137-105
1100 1239	Pin - Mate-N-Lock	133-108
1100 1239	Pin - Mate-N-Lock	135-109
1100 1239	Pin - Mate-N-Lock	137-106
1100 1240	Socket - Mate-N-Lock	133-109
1100 1240	Socket - Mate-N-Lock	135-110
1100 1241	Socket - Mate-N-Lock	135-111
1100 1241	Socket - Mate-N-Lock	137-107
1100 1247	Terminal	135-112
1100 1247	Terminal	137-108

Part No.	Description	Paper and Index No.
1100 1259	Socket - Mate-N-Lock	135-113
1100 1259	Socket - Mate-N-Lock	137-109
1100 1270	Fastening Receptacle	135-114
1100 1270	Fastening Receptacle	137-110
1100 1271	Fastening Receptacle	135-115
1100 1271	Fastening Receptacle	137-111
1100 1327	Contact	135-116
1100 1329	Socket Contact	137-112
1100 1339	Pin Contact	137-113
1100 1340	Terminal	137-114
1100 1344	Pin Contact	137-115
1100 1498	Connector - 1P	137-116
1100 1499	Connector - 1P	137-117
1100 1520	Connector - 1P	135-117
1100 1520	Connector - 1P	137-118
1100 1535	Pin Connect	135-118
1100 1535	Pin Connect	137-119
1100 1536	Connector - 1P	137-120
1101 0328	Connector Pin Contact	95-102
1101 0328	Connector Pin Contact	99-101
1101 0328	Connector Pin Contact	101-102
1101 0328	Connector Pin Contact	105-103
1101 0328	Connector Pin Contact	109-114
1101 0328	Connector Pin Contact	113-102
1101 0328	Connector Pin Contact	115-102
1101 0328	Connector Pin Contact	117-102
1101 0328	Connector Pin Contact	119-102
1101 0328	Connector Pin Contact	121-102
1101 0328	Connector Pin Contact	127-102
1101 0328	Connector Pin Contact	131-102
1101 0359	Terminal - 3P	91-110
1101 0382	Connector - 1P	95-103
1102 0185	Connector - 4P	135-119
1102 0782	Connector - 4P	133-110
1102 0958	Connector - 2P	101-103

Part No.	Description	Paper and Index No.
1102 0983	Connector - 2P	133-111
1102 0984	Connector - 2P	137-121
1102 0989	Connector - 9P	133-112
1102 0990	Connector - 9P	137-122
1102 0999	Connector - 9P	99-102
1102 1005	Connector - 1P	133-113
1102 1006	Pin Housing - 1P	133-114
1102 1089	Connector - 3P	137-123
1102 1091	Connector - 6P	137-124
1102 1094	Connector - 12P	137-125
1102 1307	Connector - 4P	135-120
1102 1401	Receptacle Housing - 1P	135-121
1102 1402	Receptacle Housing - 1P	133-115
1102 1402	Receptacle Housing - 1P	135-122
1102 1403	Receptacle Housing	133-116
1102 1403	Receptacle Housing	135-123
1102 1404	Connector - 1P	133-117
1102 1404	Connector - 1P	135-124
1102 1412	Connector - 2P	135-125
1102 1412	Connector - 2P	137-127
1102 1471	Connector - 7P	137-128
1102 1509	Connector - 4P	135-126
1102 1511	Connector - 9P	135-127
1102 1511	Connector - 9P	137-129
1102 1512	Connector - 12P	137-130
1102 1513	Connector - 15P	137-131
1102 1515	Connector - 2P	137-132
1102 1516	Connector - 3P	137-133
1102 1519	Connector - 9P	135-128
1102 1519	Connector - 9P	137-134
1102 1524	Connector - 2P	133-118
1102 1524	Connector - 2P	135-129
1102 1529	Connector - 12P	137-135
1102 1532	Connector - 2P	133-119
1102 1532	Connector - 2P	135-130

Part No.	Description	Paper and Index No.
1102 1741	Connector - 9P	135-131
1102 1785	Connector - 11P	135-132
1102 1878	Connector - 3P	137-136
1102 1911	Connector - 3P	135-133
1102 1982	Socket Housing - 2P	137-137
1102 1983	Connector - 3P	137-138
1102 2061	Connector - 6P	135-134
1102 2165	Connector - 1P	113-103
1102 2165	Connector - 1P	115-103
1102 2165	Connector - 1P	117-103
1102 2165	Connector - 1P	119-103
1102 2165	Connector - 1P	121-103
1102 2165	Connector - 1P	127-103
1102 2165	Connector - 1P	131-103
1102 2442	DIC Switch	95-104
1102 2549	Connector - 2P	137-139
1102 2845	Connector - 16P	95-105
1102 2979	Connector - 14P	109-101
1102 2986	Connector - 14P	109-115
1102 3981	Connector - 60P	137-140
1102 4052	Optional Connector	23-112
1102 4150	Connector - 4P	137-141
1102 4162	Optional Connector - 10P	137-142
1102 4173	Connector - 20P	99-103
1102 4402	Connector - 12P	137-143
1102 4404	Connector - 32P	137-144
1102 4869	Connector - 44P	127-104
1102 4869	Connector - 44P	131-104
1102 4873	Connector - 60P	115-104
1102 4874	Connector - 60P	105-104
1102 4879	Connector - 90P	95-106
1102 4931	Connector - 13P	137-145
1102 4932	Connector - 34P	135-135
1102 4933	Connector - 34P	137-146
1102 4935	Connector - 30P	137-147

Part No.	Description	Paper and Index No.
1102 4960	Optical Connector - Red	121-104
1102 4961	Optical Connector - Blue	121-139
1102 4962	Optical Connector - White	105-105
1102 4962	Optical Connector - White	121-105
1102 4963	Optical Connector - Red	131-105
1102 4964	Optical Connector - Blue	131-106
1102 4965	Optical Connector - White	127-105
1103 0402	Pin Header - 26P	115-105
1103 0402	Pin Header - 26P	117-104
1103 0402	Pin Header - 26P	119-104
1103 0428	Connector - 20P	101-104
1103 0428	Connector - 20P	105-106
1103 0649	Connector - 50P	109-116
1103 0650	Connector - 40P	99-104
1103 0650	Connector - 40P	105-107
1103 0651	Connector - 34P	109-117
1103 0652	Plug-26P	109-118
1103 0653	Connector - 34P	105-108
1103 0655	Connector - 16P	109-119
1103 0657	Connector - 50P	137-148
1103 0658	Connector - 40P	137-149
1103 0659	Connector - 34P	137-150
1103 0660	Connector - 16P	137-151
1103 0661	Connector	135-136
1103 0661	Connector	137-152
1103 0662	Connector - 20P	137-153
1103 0663	Connector - 16P	137-154
1103 0725	Connector - 3P	101-105
1103 0755	Connector - 50P	95-107
1103 0770	Connector - 9P	99-105
1103 0773	Connector - 8P	99-106
1103 0778	Connector - 2P	109-120
1103 0779	Connector - 2P	121-106
1103 0832	Connector - 7P	101-108
1103 1256	Connector	127-107

Part No.	Description	Paper and Index No.
1103 1256	Connector	131-108
1103 1317	Connector	113-104
1103 1317	Connector	127-106
1103 1317	Connector	131-107
1103 1489	Connector - 3P	95-108
1103 1489	Connector - 3P	113-105
1103 1489	Connector - 3P	119-105
1103 1608	Socket	123-101
1103 1614	Socket	121-107
1103 1622	Receptacle Housing - 17P	135-137
1104 0224	Relay Bracket	87-114
1104 0271	IC Socket - 28P	95-109
1104 0271	IC Socket - 28P	105-109
1104 0271	IC Socket - 28P	109-121
1104 0271	IC Socket - 28P	121-108
1104 0351	Fuse Holder	101-107
1104 0506	Connector - 2P	137-155
1104 0516	IC Socket - 28P	127-108
1104 0516	IC Socket - 28P	131-109
1105 0005	Nylon Clip - 3N	33-121
1105 0008	Nylon Clip - 2N	27-108
1105 0008	Nylon Clip - 2N	45-117
1105 0008	Nylon Clip - 2N	81-105
1105 0009	Nylon Clip - 5N	77-109
1105 0010	Nylon Clip - 6N	45-116
1105 0010	Nylon Clip - 6N	91-108
1105 0016	Nylon Clip - 4N	35-103
1105 0016	Nylon Clip - 4N	79-112
1105 0120	Wire Clip	37-116
1105 0120	Wire Clip	71-112
1105 0120	Wire Clip	89-104
1105 0159	PCB Stud	31-118
1105 0196	Harness Clamp	23-107
1105 0196	Harness Clamp	51-110
1105 0197	Wire Saddle	23-108

Part No.	Description	Paper and Index No.
1105 0199	Clamp	23-110
1105 0199	Clamp	51-108
1105 0199	Clamp	87-111
1105 0199	Clamp	91-112
1105 0201	Harness Clamp	21-112
1105 0201	Harness Clamp	23-109
1105 0229	Clamp	21-114
1105 0229	Clamp	23-113
1105 0229	Clamp	25-109
1105 0229	Clamp	75-117
1105 0229	Clamp	85-106
1105 0278	Harness Clamp	73-110
1105 0278	Harness Clamp	79-109
1105 0278	Harness Clamp	89-106
1105 0291	Wire Saddle	13-109
1105 0291	Wire Saddle	29-106
1105 0291	Wire Saddle	33-115
1105 0291	Wire Saddle	51-109
1105 0291	Wire Saddle	53-109
1105 0291	Wire Saddle	71-111
1105 0291	Wire Saddle	79-108
1105 0291	Wire Saddle	79-111
1105 0291	Wire Saddle	87-108
1105 0291	Wire Saddle	87-115
1105 0291	Wire Saddle	89-102
1105 0291	Wire Saddle	91-116
1105 0292	Wire Saddle	29-105
1105 0292	Wire Saddle	33-120
1105 0292	Wire Saddle	85-108
1105 0292	Wire Saddle	89-105
1105 0310	Wire Clamp	29-107
1105 0316	Clamp	69-106
1105 0316	Clamp	77-108
1105 0316	Clamp	85-107
1105 0316	Clamp	87-116

Part No.	Description	Paper and Index No.
1105 0316	Clamp	89-103
1105 0319	Harness Clamp	29-108
1105 0351	Clamp	83-106
1105 0397	PCB Stud	15-101
1105 0398	Spacer	15-102
1106 0241	Bushing - 6.7mm	21-113
1106 0241	Bushing - 6.7mm	23-114
1106 0310	Bushing	23-111
1106 0310	Bushing	51-107
1106 0350	Bushing - 29mm	91-115
1106 0430	Bushing - 13mm	71-110
1106 0430	Bushing - 13mm	79-110
1106 0430	Bushing - 13mm	91-117
1106 0458	Bushing - 9.9mm	73-109
1106 0458	Bushing - 9.9mm	91-111
1107 0388	Fuse - 2A (115V)	91-114
1107 0388	Fuse - 2A (115V)	101-109
1107 0392	Fuse - 6.3A (115V)	91-113
1107 0392	Fuse - 6.3A (115V)	101-110
1107 0550	Circuit Breaker - 10A (220/240V)	87-109
1107 0550	Circuit Breaker - 115V	87-109
1107 0673	Fuse - 6.3A/250V	91-113
1107 0673	Fuse - 6.3A/250V	101-110
1107 0739	Fuse - 2A (220/240V)	91-114
1107 0739	Fuse - 2A (220/240V)	101-109
1201 0039	Coil	99-107
1201 0039	Coil	101-111
1201 0039	Coil	121-109
1204 1015	DIP Switch	105-110
1204 1228	Switch	101-112
1204 1327	DIP Switch	95-162
1204 1373	Push Switch	13-108
1204 1422	DIP Switch	121-140
1204 1537	DIP Switch	101-113
1204 1541	DIP Switch	95-110

Part No.	Description	Paper and Index No.
1204 1545	Main Switch	83-107
1204 1570	DIP Switch	101-114
1204 2189	Digital Switch	95-111
1204 2189	Digital Switch	127-109
1204 2189	Digital Switch	131-110
1204 2190	DIP Switch	127-181
1204 2190	DIP Switch	131-182
1204 2191	Digital Switch	127-110
1204 2191	Digital Switch	131-111
1204 2192	Digital Switch	127-111
1204 2192	Digital Switch	131-112
1204 2193	Slide Switch	99-108
1204 2196	Rotary Switch	99-109
1206 0032	Lithium Cell - BR2325-1HC	109-102
1206 0032	Lithium Cell - BR2325-1HC	123-102
1208 0176	Solid State Relay - 240V	87-110
1208 0466	Solid State Relay - 120V	87-110
1208 1029	Power Relay	87-113
1400 0087	Transistor - 2SC1815	99-110
1400 0087	Transistor - 2SC1815	127-112
1400 0087	Transistor - 2SC1815	131-113
1400 0403	Transistor - 2SC1623/6	101-115
1400 0510	Transistor - 2SC1623	109-122
1401 0234	Transistor - 2SD686	105-111
1401 0296	Transistor - 2SA1162Y	109-103
1401 0296	Transistor - 2SA1162Y	109-123
1401 0296	Transistor - 2SA1162Y	123-103
1401 0298	Transistor - 2SC2712YT	109-104
1401 0298	Transistor - 2SC2712YT	123-104
1401 0445	Transistor - 2SA812M5	101-116
1401 0611	Diode - IS1588	99-111
1401 0611	Diode - IS1588	127-113
1401 0611	Diode - IS1588	131-114
1401 0826	Diode - 1SS181	109-166
1401 0855	Transistor - 2SJ143	99-112

Part No.	Description	Paper and Index No.
1401 0859	Transistor - 2SK815	101-117
1402 0247	Diode - W06B	105-112
1402 0269	Zener Diode - RD39FC	105-113
1402 0476	Diode - 1SS184	109-105
1402 0476	Diode - 1SS184	109-124
1402 0476	Diode - 1SS184	123-105
1402 0501	Zener Diode	105-114
1402 0501	Zener Diode	121-110
1402 0633	Diode - RD3.9MB2	109-125
1402 0682	Zener Diode - RD3.6M	109-106
1402 0682	Zener Diode - RD3.6M	123-106
1402 0688	Diode	109-126
1402 0696	Diode - MA704	109-127
1402 0894	Diode - RD12MB	101-118
1402 0977	Diode - 31DF1	101-119
1403 0416	LED - Red	99-175
1403 0652	LED - Red	127-114
1403 0652	LED - Red	131-115
1407 0537	IC - HD74LS30P	95-163
1407 0539	IC - SN74LS04N	95-112
1407 0539	IC - SN74LS04N	99-113
1407 0539	IC - SN74LS04N	127-115
1407 0539	IC - SN74LS04N	131-116
1407 0542	IC - SN74KS00N	95-164
1407 0542	IC - NS74LS00NS	99-114
1407 0610	IC - SN74LS32N	95-113
1407 0610	IC - SN74LS32N	121-111
1407 0610	IC - SN74LS32N	127-116
1407 0610	IC - SN74LS32N	131-117
1407 0612	IC - SN74LS138N	95-155
1407 0614	IC - SN74LS74AN	95-114
1407 0614	IC - SN74LS74AN	99-115
1407 0617	IC - SN74LS02N	99-116
1407 0621	IC - SN74LS08N	95-115
1407 0621	IC - SN74LS08N	99-117

Part No.	Description	Paper and Index No.
1407 0621	IC - SN74LS08N	121-112
1407 0623	IC - HD74LS175P	99-118
1407 0710	IC - HD74LS107	99-119
1407 0711	IC - 74LS151	95-116
1407 0711	IC - 74LS151	127-117
1407 0711	IC - 74LS151	131-118
1407 0714	IC - SN74LS163N	95-117
1407 0759	IC - SN74LS10N	99-176
1407 0760	IC - SN74LS14N	99-120
1407 0794	IC - SN74LS245N	95-118
1407 0796	IC - SN74LS374N	95-156
1407 0814	IC - HD74LS139P	95-119
1407 0816	IC - SN74LS157N	99-121
1407 0840	IC - SN74LS109N	95-157
1407 0842	TTL IC - SN74LS399N	95-120
1407 0887	IC - SN74LS244N	95-121
1407 0887	IC - SN74LS244N	99-122
1407 0887	IC - SN74LS244N	121-113
1407 0887	IC - SN74LS244N	127-118
1407 0887	IC - SN74LS244N	131-119
1407 0890	TTL IC:SN74LS273N	95-165
1407 0945	IC - SN74LS191	99-177
1407 1016	IC - D8255AC-2	95-122
1407 1016	IC - D8255AC-2	121-114
1407 1026	IC - SN74LS373N	95-123
1407 1026	IC - SN74LS373N	121-115
1407 1073	IC - SN74LS283N	95-124
1407 1073	IC - SN74LS283N	127-119
1407 1073	IC - SN74LS283N	131-120
1407 1130	IC - SN74LS204N	99-178
1407 1130	IC - SN74LS240N	127-182
1407 1130	IC - NS74LS240N	131-183
1407 1394	IC - SN74ALS32N	99-123
1407 1402	IC: TTL, SN74LS628N	127-120
1407 1402	IC: TTL, SN74LS628N	131-121

Part No.	Description	Paper and Index No.
1407 1431	TTLIC - 74F04PC	99-124
1407 1432	TTLIC - 74F08PC	99-125
1407 1450	TTLIC - 74F240PC	99-126
1407 1535	IC - TD62308AP	105-115
1407 1535	IC - TD62308AP	109-128
1407 1537	IC - TC74HC14P	95-125
1407 1584	IC - 74F151APC	99-127
1407 1586	IC - 74F175APC	99-128
1407 1600	IC - SN74LS244NS	105-116
1407 1600	IC - SN74LS244NS	109-129
1407 1600	IC - SN74LS244NS	113-106
1407 1600	IC - SN74LS244NS	115-106
1407 1600	IC - SN74LS244NS	117-105
1407 1600	IC - SN74LS244NS	119-106
1407 1723	IC - TC4052BF	109-130
1407 1730	IC - TC74HC154P	109-131
1407 1741	IC - SN74LS32NS	109-107
1407 1741	IC - SN74LS32NS	115-107
1407 1741	IC - SN74LS32NS	123-107
1407 1746	IC - SN74LS240NS	115-108
1407 1765	TTLIC - SN74S684N	95-166
1407 1783	IC - SN74LS02NS	117-106
1407 1792	IC - SN74LS374NS	117-121
1407 1792	IC - SN74LS374NS	119-123
1407 1879	IC - SN74LS86ANS	115-109
1407 1879	IC - SN74LS86ANS	117-107
1407 1880	IC - SN74LS04NS	113-107
1407 1880	IC - SN74LS04NS	115-110
1407 1880	IC - SN74LS04NS	117-108
1407 1880	IC - SN74LS04NS	119-107
1407 1883	IC - TC4050BF	105-117
1407 1964	IC - 62304AP	95-158
1407 1970	IC - SN74LS07N	95-159
1407 1970	IC - SN74LS07N	121-141
1407 1994	IC - SN74LS30NS	115-111

Part No.	Description	Paper and Index No.
1407 2028	IC - SN74LS06N	99-129
1407 2028	IC - SN74LS06N	127-121
1407 2028	IC - SN74LS06N	131-122
1407 2051	IC - SN74LS00NS	117-109
1407 2052	IC - NS74LS74ANS	105-118
1407 2052	IC - NS74LS74ANS	115-112
1407 2058	IC - 82C54FP-6	101-120
1407 2077	IC - SN74LS138NS	113-108
1407 2077	IC - SN74LS138NS	115-113
1407 2077	IC - SN74LS138NS	117-110
1407 2077	IC - SN74LS138NS	119-108
1407 2078	IC - TD62785P	105-119
1407 2081	IC - SN74LS08NS	113-109
1407 2081	IC - SN74LS08NS	115-114
1407 2081	IC - SN74LS08NS	119-109
1407 2187	IC - SN74LS07NS	101-121
1407 2187	IC - SN74LS07NS	105-120
1407 2187	IC - SN74LS07NS	109-132
1407 2247	IC - SN74LS164NS	115-115
1407 2247	IC - SN74LS164NS	117-111
1407 2249	IC - SN74LS174NS	115-116
1407 2252	IC - SN74LS257NS	117-112
1407 2252	IC - SN74LS257NS	119-125
1407 2304	IC - SN74LS161ANS	109-133
1407 2318	IC - SN74AS138N	121-116
1407 2347	IC - SN74LS161NS	115-117
1407 2348	IC - TC4051BF	109-134
1407 2386	IC - SN74LS163NS	117-113
1407 2510	IC - D78C10G	95-126
1407 2510	IC - D78C10G	105-121
1407 2510	IC - D78C10G	109-135
1407 2514	IC - TD62381P	105-122
1407 2544	IC - MB89371PF	105-123
1407 2558	IC - 1MX1BIT	113-110
1407 2671	IC - HM62256LP-15	105-124

Part No.	Description	Paper and Index No.
1407 2671	IC - HM62256LP-15	121-117
1407 2753	IC - D71051C	95-168
1407 2753	IC - D71051C	121-118
1407 2767	IC - MB89254-PF	105-125
1407 2767	IC - MB89254-PF	109-136
1407 2868	IC - MPD71059C	121-119
1407 2870	IC - MPD71054C	95-127
1407 2870	IC - MPD71054C	121-120
1407 2871	IC - MPD70116C-8	121-121
1407 2890	IC - CXK5864BM-70L	115-118
1407 2890	IC - CXK5864BM-70L	119-110
1407 2960	IC - TC5081AP	127-122
1407 2960	IC - TC5081AP	131-123
1407 3082	IC - SN74AS244NS	113-111
1407 3203	IC - TC74HC10AF	101-122
1407 3257	IC - TC74HC14A	101-123
1407 3257	IC - TC74HC14A	105-126
1407 3259	IC - TC74HC125AF	101-124
1407 3268	IC - UPD42505C-50H	95-128
1407 3268	IC - UPD42505C-50H	115-127
1407 3268	IC - UPD42505C-50H	117-114
1407 3268	IC - UPD42505C-50H	119-111
1407 3282	IC - TC74HC138AF	105-127
1407 3283	IC - TC74HC373AF	105-128
1407 3283	IC - TC74HC373AF	109-137
1407 3284	IC - TC74HC74AF	101-125
1407 3286	IC - TC74HC04AF	101-126
1407 3286	IC - TC74HC04AF	105-129
1407 3286	IC - TC74HC04AF	109-138
1407 3287	IC - TC74HC393AF	101-154
1407 3290	IC - 74HC02A	101-127
1407 3290	IC - 74HC02A	109-139
1407 3359	IC - RF5C60	105-130
1407 3359	IC - RF5C60	109-140
1407 3439	IC - TC5082P	127-123

Part No.	Description	Paper and Index No.
1407 3439	IC - TC5082P	131-124
1407 3440	IC - DS1000M-75	127-124
1407 3440	IC - DS1000M-75	131-125
1407 3441	IC - DS1000M-20	127-125
1407 3441	IC - DS1000M-20	131-126
1407 3442	IC - N74F133N	127-126
1407 3442	IC - N74F133N	131-127
1407 3448	IC - CKX5864BSP-70L	127-127
1407 3448	IC - CKX5864BSP-70L	131-128
1407 3449	IC - TC9122P	127-128
1407 3449	IC - TC9122P	131-129
1407 3450	IC - SN74LS19N	127-129
1407 3450	IC - SN74LS19N	131-130
1407 3451	IC - N74F175N	127-130
1407 3451	IC - N74F175N	131-131
1407 3452	IC - N74F74N	127-131
1407 3452	IC - N74F74N	131-132
1407 3453	IC - N74F20N	127-132
1407 3453	IC - N74F20N	131-133
1407 3454	IC - N74F10N	127-133
1407 3454	IC - N74F10N	131-134
1407 3456	IC - N74F374N	95-129
1407 3460	IC - SN74ALS34N	95-130
1407 3461	IC - SN74AS1805N	95-131
1407 3475	IC - MSM514221-6RS	95-132
1407 3475	IC - MSM514221-6RS	117-115
1407 3476	IC - UPB8284AD	121-122
1407 3477	IC - 74AC04	121-123
1407 3481	IC - SN74AS32NS	119-112
1407 3482	IC - SN74LS377NS	119-113
1407 3485	IC - M5M5256BFP-85L	115-119
1407 3486	IC - TC74HC153AF	101-128
1407 3509	IC - TC74HC11AF	101-129
1407 3509	IC - TC74HC11AF	105-131
1407 3510	IC - SLA5017	101-130

Part No.	Description	Paper and Index No.
1407 3511	IC - MPD43256AGU-15L	109-108
1407 3511	IC - MPD43256AGU-15L	123-108
1408 0199	IC - TL074CN	99-130
1408 0290	IC - LM311N	99-131
1408 0460	IC - HA17008RP	99-132
1408 0493	IC - NE556N	99-133
1408 0494	IC - MB3371P	95-133
1408 0494	IC - MB3371P	99-134
1408 0494	IC - MB3371P	121-124
1408 0537	IC - TL7705CPS	101-131
1408 0585	IC - AD67528J	109-141
1408 0595	IC - NJM2904M	101-132
1408 0611	IC - MB3771PF	105-132
1408 0611	IC - MB3771PF	109-142
1408 0722	IC - SN76514N	127-134
1408 0722	IC - SN76514N	131-135
1408 0763	IC - TL084-CNS	109-143
1408 0812	IC - AD847JN	127-135
1408 0812	IC - AD847JN	131-136
1408 0813	IC - TA78L005AP	99-135
1408 0813	IC - TA78L005AP	127-136
1408 0813	IC - TA78L005AP	131-137
1408 0814	IC - TA79L005P	127-137
1408 0814	IC - TA79L005P	131-138
1408 0815	IC - NJM360D	127-138
1408 0815	IC - NJM360D	131-139
1408 0817	IC - HA17012P-B	99-136
1503 0079	Oscillator - 10000MHz	105-133
1503 0181	Oscillator - 10MHz	95-134
1503 0182	Ceramic Oscillator - 12MHz	101-133
1503 0195	Oscillator - 24MHz	121-125
1503 0368	Oscillator - 3579.545KHz	127-139
1503 0368	Oscillator - 3579.545KHz	131-140
1503 0369	Oscillator - 6MHz	127-140
1503 0369	Oscillator - 6MHz	131-141

Part No.	Description	Paper and Index No.
1503 0370	Oscillator - 16.0224MHz	95-135
1503 0371	Oscillator - 5916.67MHz	95-136
1503 0406	Oscillator - 12MHz	109-144
1601 1871	Resistor - 220 Ω 1/4W $\pm 1\%$	109-145
1601 2925	Resistor - 2K Ω 0.5W	99-137
1601 7196	Resistor Array - 270 Ω	99-138
1601 7345	Resistor - 330 Ω	105-134
1601 7345	Resistor - 330 Ω	127-141
1601 7345	Resistor - 330 Ω	131-142
1601 7346	Resistor Array - 470 Ω $\pm 5\%$ 1/2W	113-112
1601 7347	Resistor - 680 Ω	105-135
1601 7347	Resistor - 680 Ω	127-142
1601 7347	Resistor - 680 Ω	131-143
1601 7348	Resistor Array - 470 Ω 1/8W $\pm 5\%$	121-126
1601 7351	Resistor Array - 3.3k Ω	119-114
1601 7352	Resistor Array - 4.7k Ω	95-137
1601 7352	Resistor Array - 4.7k Ω	109-146
1601 7353	Resistor Array - 6.8k Ω	119-115
1601 7354	Resistor Array - 10K Ω	105-136
1601 7354	Resistor Array - 10K Ω	109-147
1601 7367	Resistor Array - 330 Ω	105-137
1601 7367	Resistor Array - 330 Ω	127-143
1601 7367	Resistor Array - 330 Ω	131-144
1601 7368	Resistor Array - 470 Ω $\pm 5\%$ 1/8W	113-113
1601 7369	Resistor Array - 680 Ω	105-138
1601 7369	Resistor Array - 680 Ω	127-144
1601 7369	Resistor Array - 680 Ω	131-145
1601 7370	Resistor Array - 1k Ω	105-139
1601 7370	Resistor Array - 1k Ω	121-127
1601 7373	Resistor Array - 3.3k Ω	99-139
1601 7373	Resistor Array - 3.3k Ω	113-114
1601 7373	Resistor Array - 3.3k Ω	115-120
1601 7373	Resistor Array - 3.3k Ω	117-116
1601 7373	Resistor Array - 3.3k Ω	119-116
1601 7374	Resistor Arrey - 4.7K Ω	95-167

Part No.	Description	Paper and Index No.
1601 7374	Resistor Array - 4.7K Ω	109-148
1601 7374	Resistor Array - 4.7K Ω	127-145
1601 7374	Resistor Array - 4.7K Ω	131-146
1601 7375	Resistor Array - 6.8k Ω	99-140
1601 7375	Resistor Array - 6.8k Ω	113-115
1601 7375	Resistor Array - 6.8k Ω	115-121
1601 7375	Resistor Array - 6.8k Ω	117-117
1601 7375	Resistor Array - 6.8k Ω	119-117
1601 7376	Resistor Array - 10k Ω $\pm 5\%$ 1/8W	95-138
1601 7376	Resistor Array - 10k Ω $\pm 5\%$ 1/8W	105-140
1601 7376	Resistor Array - 10k Ω $\pm 5\%$ 1/8W	109-149
1601 7376	Resistor Array - 10k Ω $\pm 5\%$ 1/8W	121-128
1601 7376	Resistor Array - 10k Ω $\pm 5\%$ 1/8W	127-146
1601 7376	Resistor Array - 10k Ω $\pm 5\%$ 1/8W	131-147
1601 7422	Resistor - 2K Ω $\pm 5\%$	121-129
1601 7449	Resistor - 100 Ω $\pm 5\%$	99-141
1602 0911	Surge Killer - 0.01mF	95-139
1602 0911	Surge Killer - 0.01mF	105-141
1602 0922	Capacitor - 100pF $\pm 20\%$	121-130
1602 0946	Noise Filter - 220/240V	87-112
1602 0946	Noise Filter	91-119
1602 0987	Capacitor & Coil - 270pF 100V	95-140
1602 0991	Noise Filter - 115V	87-112
1602 7011	Capacitor - 270pF $\pm 20\%$ 50V	121-131
1602 7029	Noise Filter - 22000pF 50V	99-142
1602 7029	Noise Filter - 22000pF 50V	121-132
1604 0987	Capacitor - 10mF 16V	101-134
1604 1351	Capacitor - 22mF 10V	99-143
1604 1353	Capacitor - 47uF 10V	95-141
1604 1354	Capacitor - 100uF 10V	99-144
1604 1355	Capacitor - 220mF 10V	95-142
1604 1355	Capacitor - 220mF 10V	115-122
1604 1355	Capacitor - 220mF 10V	117-118
1604 1355	Capacitor - 220mF 10V	119-118
1604 1356	Capacitor - 330uF 10V	99-145

Part No.	Description	Paper and Index No.
1604 1357	Capacitor - 470mF, 10V	113-116
1604 1363	Capacitor - 10uF $\pm 20\%$ 25V	127-147
1604 1363	Capacitor - 10uF $\pm 20\%$ 25V	131-148
1604 1366	Capacitor - 47uF $\pm 20\%$ 25V	127-148
1604 1366	Capacitor - 47uF $\pm 20\%$ 25V	131-149
1604 1369	Capacitor - 330uF $\pm 20\%$	99-146
1604 1369	Capacitor - 330uF $\pm 20\%$	127-149
1604 1369	Capacitor - 330uF $\pm 20\%$	131-150
1604 1376	Capacitor - 0.33uF 50V	95-143
1604 1376	Capacitor - 0.33uF 50V	105-142
1604 1376	Capacitor - 0.33uF 50V	109-151
1604 1376	Capacitor - 0.33uF 50V	121-133
1604 1379	Capacitor - 2.2uF $\pm 20\%$ 50V	99-147
1604 1381	Capacitor - 4.7uF 50V	101-135
1604 1386	Capacitor - 100mF $\pm 20\%$ 50V	101-136
1604 1386	Capacitor - 100mF $\pm 20\%$ 50V	105-143
1604 1387	Capacitor - 220 uF 50V	101-137
1604 1388	Capacitor - 330uF 50V	99-148
1604 1388	Capacitor - 330uF 50V	109-150
1604 1728	Capacitor - 100uF 10V	109-167
1604 1783	Capacitor - 220uF 25V	101-138
1604 1783	Capacitor - 220uF 25V	127-150
1604 1783	Capacitor - 220uF 25V	131-151
1604 1986	Capacitor - 220mF 50V	121-134
1605 0108	Capacitor - 33pF	127-151
1605 0108	Capacitor - 33pF	131-152
1605 0142	Capacitor - 220pF 50V	127-152
1605 0142	Capacitor - 220pF 50V	131-153
1605 0283	Capacitor - 1uF	113-120
1605 0283	Capacitor - 1uF	115-128
1605 0283	Capacitor - 1uF	119-124
1605 0358	Capacitor - 6pF	127-153
1605 0358	Capacitor - 6pF	131-154
1605 0359	Capacitor - 22pF 50V	127-154
1605 0359	Capacitor - 22pF 50V	131-155

Part No.	Description	Paper and Index No.
1605 0369	Capacitor - 47pF 50V	127-155
1605 0369	Capacitor - 47pF 50V	131-156
1605 0468	Capacitor - 0.33uF $\pm 20\%$ 50V	99-149
1605 0517	Capacitor - 330pF +80 -20% 50V	105-144
1605 0517	Capacitor - 330pF +80 -20% 50V	127-156
1605 0517	Capacitor - 330pF +80 -20% 50V	131-157
1605 0534	Capacitor - 1000pF +80 -20%	101-139
1605 0647	Capacitor - 0.01uF	99-150
1606 0867	Capacitor - 3300pF 50V	95-144
1606 1140	Capacitor - 0.1uF +80%-20%	127-157
1606 1140	Capacitor - 0.1uF +80%-20%	131-158
1606 1311	Capacitor - 47pF 50V	99-151
1606 1321	Capacitor - 330pF 50V	99-152
1606 1332	Capacitor - 1000pF 50V	99-153
1606 1336	Capacitor - 10000pF -20% +80% 50V	95-145
1606 1336	Capacitor - 10000pF -20% +80% 50V	99-154
1606 1336	Capacitor - 10000pF -20% +80% 50V	121-135
1606 1451	Capacitor - 0.1uF 50V	101-140
1606 1451	Capacitor - 0.1uF 50V	105-145
1606 1451	Capacitor - 0.1uF 50V	109-152
1606 1451	Capacitor - 0.1uF 50V	113-117
1606 1451	Capacitor - 0.1uF 50V	115-123
1606 1451	Capacitor - 0.1uF 50V	117-119
1606 1451	Capacitor - 0.1uF 50V	119-119
1606 1452	Capacitor - 0.01uF 50V	101-141
1606 1454	Capacitor - 0.01uF 25V	105-146
1606 1454	Capacitor - 0.01uF 25V	109-109
1606 1454	Capacitor - 0.01uF 25V	109-153
1606 1454	Capacitor - 0.01uF 25V	123-109
1606 1455	Capacitor - 470pF 25V	109-154
1606 1511	Capacitor - 022mF 50V	99-155
1606 1584	Capacitor - 0.47uF 50V	127-158
1606 1584	Capacitor - 0.47uF 50V	131-159
1607 0026	SN Coil - SN-12-500	115-124
1607 0026	SN Coil - SN-12-500	119-120

Part No.	Description	Paper and Index No.
1607 0062	SN Coil - SN-5-400	113-121
1607 0062	SN Coil - SN-5-400	117-122
1607 0063	SN Coil - SN-8S-300	109-155
1607 0069	Fuse - BL02RN2-R62-PB	127-159
1607 0069	Fuse - BL02RN2-R62-PB	131-160
1607 0112	Inductor	95-146
1607 0152	Inductor - 47uH	127-160
1607 0152	Inductor - 47uH	131-161
1607 0196	SN Coil - SN3-200	109-168
1607 0216	Ferrite Core ESD-R-47	137-156
1607 0323	Ferrite Core	29-110
1607 0323	Ferrite Core - ESD-QR-25	137-126
1607 0332	Ferrite Core - TRCC-25-15-12	29-111
1607 0332	Ferrite Core	83-105
1607 0335	Choke - 40uH $\pm 3\%$ 3A	109-156
1607 0339	IC - DS1000M-50	95-160
1607 0339	IC - DS1000H-50	127-183
1607 0339	IC - DS1000H-50	131-184
1607 0353	Ferrite Core	91-109
1607 0426	SN Coil - SF-T3-20-01	127-161
1607 0426	SN Coil - SF-T3-20-01	131-162
1607 0427	SN Coil - SF-T10-30	95-161
1607 0427	SN Coil - SF-T10-30	99-156
1607 0427	SN Coil - SF-T10-30	127-162
1607 0427	SN Coil - SF-T10-30	131-163
1607 0428	SN Coil - SF-T10-30M	105-147
1607 0429	Coil - 154AN-42038N	127-163
1607 0429	Coil - 154AN-42038N	131-164
1607 0430	Ferrite Core - TRCC-23-11-14	29-109
1607 0489	IC - RWT020P-2	99-157
1607 0490	IC - RWT025P-2	99-158
1610 0025	Resistor - 22 Ω 1/8W $\pm 5\%$	101-142
1610 0025	Resistor - 22 Ω 1/8W $\pm 5\%$	113-118
1610 0026	Resistor - 24 Ω 1/8W	127-164
1610 0026	Resistor - 24 Ω 1/8W	131-165

Part No.	Description	Paper and Index No.
1610 0031	Resistor - 47 Ω 1/8W	127-165
1610 0031	Resistor - 47 Ω 1/8W	131-166
1610 0035	Resistor - 100 Ω 1/8W $\pm 5\%$	101-143
1610 0035	Resistor - 100 Ω 1/8W $\pm 5\%$	105-148
1610 0035	Resistor - 100 Ω 1/8W $\pm 5\%$	127-166
1610 0035	Resistor - 100 Ω 1/8W $\pm 5\%$	131-167
1610 0036	Resistor - 110 Ω 1/8W $\pm 5\%$	127-167
1610 0036	Resistor - 110 Ω 1/8W $\pm 5\%$	131-168
1610 0042	Resistor - 200 Ω 1/8W $\pm 5\%$	113-122
1610 0043	Resistor - 220 Ω 1/8W $\pm 5\%$	105-149
1610 0043	Resistor - 220 Ω 1/8W $\pm 5\%$	109-157
1610 0047	Resistor - 330 Ω 1/8W $\pm 5\%$	105-150
1610 0047	Resistor - 330 Ω 1/8W $\pm 5\%$	109-158
1610 0048	Resistor - 390 Ω 1/8W $\pm 5\%$	127-168
1610 0048	Resistor - 390 Ω 1/8W $\pm 5\%$	131-169
1610 0049	Resistor - 470 Ω 1/8W $\pm 5\%$	101-144
1610 0051	Resistor - 680 Ω 1/8W $\pm 5\%$	105-151
1610 0051	Resistor - 680 Ω 1/8W $\pm 5\%$	109-159
1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	101-145
1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	105-152
1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	109-160
1610 0053	Resistor - 1K Ω 1/8W $\pm 5\%$	115-125
1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	127-169
1610 0053	Resistor - 1k Ω 1/8W $\pm 5\%$	131-170
1610 0055	Resistor - 1.2k Ω 1/8W $\pm 5\%$	105-153
1610 0058	Resistor - 1.6 k Ω 1/8W $\pm 5\%$	127-170
1610 0058	Resistor - 1.6 k Ω 1/8W $\pm 5\%$	131-171
1610 0061	Resistor - 2.2k Ω 1/8W $\pm 5\%$	105-154
1610 0061	Resistor - 2.2k Ω 1/8W $\pm 5\%$	127-171
1610 0061	Resistor - 2.2k Ω 1/8W $\pm 5\%$	131-172
1610 0063	Resistor - 2.7k Ω 1/8W	127-172
1610 0063	Resistor - 2.7k Ω 1/8W	131-173
1610 0064	Resistor - 3k Ω 1/8W $\pm 5\%$	105-155
1610 0065	Resistor - 3.3K Ω 1/8W $\pm 5\%$	101-146
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	101-147

Part No.	Description	Paper and Index No.
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	105-156
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	109-110
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	109-161
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	113-119
1610 0067	Resistor - 4.7K Ω 1/8W $\pm 5\%$	115-126
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	123-110
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	127-173
1610 0067	Resistor - 4.7k Ω 1/8W $\pm 5\%$	131-174
1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	101-148
1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	105-157
1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	109-162
1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	127-174
1610 0071	Resistor - 10k Ω $\pm 5\%$ 1/8W	131-175
1610 0074	Resistor - 13k Ω 1/8W $\pm 5\%$	127-175
1610 0074	Resistor - 13k Ω 1/8W $\pm 5\%$	131-176
1610 0076	Resistor - 16K Ω 1/8W	127-176
1610 0076	Resistor - 16K Ω 1/8W	131-177
1610 0079	Resistor - 22k Ω 1/8W $\pm 5\%$	105-158
1610 0089	Resistor - 100k Ω 1/8W $\pm 5\%$	101-149
1610 0089	Resistor - 100k Ω 1/8W $\pm 5\%$	109-163
1610 0091	Resistor - 120k Ω	105-159
1610 0100	Resistor - 300K Ω 1/8W	127-177
1610 0100	Resistor - 300K Ω 1/8W	131-178
1610 0286	Capacitor - 100pF 50V $\pm 10\%$	101-150
1610 0286	Capacitor - 100pF 50V $\pm 10\%$	127-178
1610 0286	Capacitor - 100pF 50V $\pm 10\%$	131-179
1610 0649	Resistor - 620 Ω $\pm 5\%$ 1/8W	127-179
1610 0649	Resistor - 620 Ω $\pm 5\%$ 1/8W	131-180
1610 0652	Resistor - 3.6K Ω $\pm 5\%$ 1/8W	127-180
1610 0652	Resistor - 3.6K Ω $\pm 5\%$ 1/8W	131-181
1610 0890	Resistor - 160 Ω $\pm 5\%$ 1/8W	109-111
1610 0890	Resistor - 160 Ω $\pm 5\%$ 1/8W	123-111
1610 1032	Resistor - 1.0k Ω 1/4W	101-151
1610 1033	Resistor - 1.5k Ω 1/4W	101-152
1610 1133	Resistor - 150 Ω $\pm 5\%$ 1/4W	101-153

Part No.	Description	Paper and Index No.
1611 4101	Resistor - 100 Ω 1/4T $\pm 5\%$	99-159
1611 4102	Resistor - 1K Ω 1/4T $\pm 5\%$	95-147
1611 4102	Resistor - 1K Ω 1/4T $\pm 5\%$	99-160
1611 4102	Resistor - 1K Ω 1/4T $\pm 5\%$	121-136
1611 4103	Resistor - 10k Ω 1/4T $\pm 5\%$	99-161
1611 4105	Resistor - 1M Ω 1/4T $\pm 5\%$	99-162
1611 4154	Resistor - 150k Ω 1/4T $\pm 5\%$	99-163
1611 4181	Resistor - 180 Ω 1/4T $\pm 5\%$	99-164
1611 4183	Resistor - 18k Ω , 1/4T +5%	105-160
1611 4184	Resistor - 180k Ω , 1/4T +5%	99-165
1611 4202	Resistor - 2k Ω 1/4T $\pm 5\%$	95-148
1611 4203	Resistor - 20k Ω 1/4T	99-166
1611 4221	Resistor - 220 Ω 1/4T $\pm 5\%$	95-149
1611 4221	Resistor - 220 Ω 1/4T $\pm 5\%$	105-161
1611 4221	Resistor - 220 Ω 1/4T $\pm 5\%$	121-137
1611 4222	Resistor - 2.2K Ω 1/4T $\pm 5\%$	95-150
1611 4222	Resistor - 2.2K Ω 1/4T $\pm 5\%$	121-138
1611 4223	Resistor - 22k Ω 1/4T $\pm 5\%$	95-151
1611 4223	Resistor - 22k Ω 1/4T $\pm 5\%$	105-162
1611 4272	Resistor - 2.7k Ω 1/4T $\pm 5\%$	99-167
1611 4273	Resistor - 27k Ω 1/4T $\pm 5\%$	95-152
1611 4302	Resistor - 3.0k Ω 1/4T $\pm 5\%$	95-153
1611 4332	Resistor - 3.3K Ω 1/4T $\pm 5\%$	99-168
1611 4332	Resistor - 3.3K Ω 1/4T $\pm 5\%$	105-163
1611 4472	Resistor - 4.7k Ω $\pm 5\%$ 1/4W	95-154
1611 4472	Resistor - 4.7k Ω $\pm 5\%$ 1/4W	99-169
1611 4511	Resistor - 510 Ω 1/4T +5%	99-170
1611 4512	Resistor - 5.1k Ω 1/4T $\pm 5\%$	99-171
1611 4561	Resistor - 560 Ω 1/4T $\pm 5\%$	99-172
1611 4622	Resistor - 6.2k Ω 1/4W	95-155
1611 4682	Resistor - 6.8k Ω 1/4T $\pm 5\%$	99-173
1611 4751	Resistor - 750 Ω 1/4T $\pm 5\%$	99-174
1630 2102	Resistor - 1K Ω 1/8W $\pm 5\%$	119-121
1630 2103	Resistor - 10K Ω 1/8W	109-112
1630 2103	Resistor - 10K Ω 1/8W	123-112

Part No.	Description	Paper and Index No.
1630 2152	Resistor - 1.5K Ω 1/8W $\pm$ 5%	109-113
1630 2152	Resistor - 1.5K Ω 1/8W $\pm$ 5%	123-113
1630 2201	Resistor - 200 Ω $\pm$ 5% 1/8W	109-164
1630 2202	Resistor - 2K Ω 1/8W $\pm$ 5%	109-165
1630 2472	Resistor - 4.7K Ω 1/8W $\pm$ 5%	117-120
1630 2472	Resistor - 4.7K Ω 1/8W $\pm$ 5%	119-122

Part No.	Description	Paper and Index No.