

## For Users of This Product

---

The following is an additional explanation about this product's power consumption.

### **□ Regarding switching to Off mode based on the Weekly Timer's event setting**

Weekly Timer is a function that allows you to set the time to switch to and recover from Sleep mode or Off mode as an event each day.

By using the Weekly Timer to set to Off mode as a daily event, the power will be turned off automatically and can provide energy consumption of 1W or less.

In order to change the settings, refer to the manuals for your product.

When the Weekly Timer is set to Off mode as a daily event, the network function is disabled, thus the factory-set default value for the Weekly Timer is [Inactive] .

©2013

Printed in Japan

EN (US)

D181-2597



D1812597