

用户注意事项

请注意关于这些手册的以下修正。

◆ 用户指南

装入纸张 > 支持的纸张 > 纸张类型
附录 > 机器规格 > 常规功能规格 > 纸张类型

错误	正确
薄纸 (52-64 g/m ² (14-17 磅))	薄纸 (<u>60</u> -64 g/m ² (<u>16</u> -17 磅))
厚纸 (100-130 g/m ² (26.6-34 磅))	厚纸 (100- <u>105</u> g/m ² (26.6- <u>28</u> 磅))

Notes for Users

Please note the following corrections to this manual.

◆ User Guide

Loading Paper > Supported Paper > Paper Type
Appendix > Specifications of the Machine > General Function Specifications > Paper type

Wrong	Correct
Thin Paper (52-64 g/m ² (14-17 lb.))	Thin Paper (<u>60</u> -64 g/m ² (<u>16</u> -17 lb.))
Thick Paper (100-130 g/m ² (26.6-34 lb.))	Thick Paper (100- <u>105</u> g/m ² (26.6- <u>28</u> lb.))

