

RICOH

PARTS CATALOG
FOR
RICOH FAX 1000L/1010L
[K-100/101]

RICOH COMPANY, LTD.

3	Sep. 1, 1989	Third edition
2	Sep. 1, 1988	Second edition
1	April 1, 1988	First edition

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG

Section 1. Part Location and List

1. Exterior	1— 2
2. ADF, Scanner	1— 4
3. Upper Unit	1— 6
4. Laser Section	1— 8
5. Development	1—10
6. Transfer, PCBs	1—12
7. Paper Feed, Registration	1—14
8. Fusing, Transport	1—16
9. Main Drive	1—18
10. Cassette	1—20
Section 2. Parts Index	1—23




1. EXTERIOR

September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
*	H006 1055	ADF Pick-up Roller (Rubber)	1000L only
*	H006 4254	Operation Manual	
*	H006 4934	Operation Manual	
*	H006 4946	Quick Reference Guide	
1	H006 1181	Document Tray	1000L only 1010L only
2	H006 1182	Sub Document Tray	
3	H006 1183	Bracket - Sub Document Tray	
4	H006 4130	Upper Exit Cover	
5	H006 4242	Op-Port Cover - FAX1000L	
5	H006 4931	Op-Port Cover - FAX1010L	
6	H006 6032	PCB - Op-Port	
7	H006 3345	Right Set Plate - Op-Port	
3	H006 3342	Left Bracket - Op-Port	
9	H006 4154	Operation Panel	
10	H006 1186	Quick Dial List -White	
11	H006 1187	Quick Dial List - Gray	
12	H006 4104	Front Exit Cover	
13	H006 4299	Front Cover Ass'y	
14	H006 4142	Speaker Bracket	
15	H006 5230	Monitor Speaker	
16	H006 4198	Copy Tray	
17	H006 4112	Document Guide Gear	
18	H006 4120	Document Guide Ruck	
19	H006 3341	Op-Port Setscrew	
20	H006 4105	Rear Exit Cover	
21	H006 4129	Document Guide Base	
22	H006 4244	Front Document Guide	
23	H006 4167	Protect - Front Document Guide	
24	H006 4133	Document Table	
25	H006 4127	Rear Document Guide	
26	H006 4168	Protect - Rear Document Guide	
27	H006 5306	Hand Set : HAC	
28	H006 4124	Handset Holder	
29	H006 4126	Handset Holder Cover	
30	H006 4122	operation Manual Holder	

INDEX	PART NO.	DESCRIPTION	MODEL
31	H006 4202	Rear Cover	
32	H006 4243	Decal - NCU Cover	
33	H006 4121	NCU Cover	
34	H006 4169	Screw Holder - Upper Cover	
36	H006 4123	Upper Right Cover	
37	H006 4247	Toner Replacement Decal	
38	H006 4141	Upper Cover Plate	
39	H006 4114	Right Cover Bracket	
40	H006 4146	Right Cover Ass'y	
41	H006 4102	Right Cover Pin	
42	H006 4106	Front Bracket - Right Cover	
43	H006 4113	Right Cover Spring	
44	H006 4117	Right Cover Knob	
45	H006 4119	Right Cover Lever	
46	H006 4109	Rear Bracket - Right Cover	
47	H006 2689	Cleaning Pad	
48	5474 7287	Modular Code - 6P - 8P	
49	5471 5602	Power Cord	
50	H006 4627	Sub Document Table	
53	H001 4219	M Lock Washer	
54	H006 4170	Fulcrum Pin Bracket - Right Cover	
55	H006 4624	Bracket - Sub Document Table	
56	H006 1800	Decal : 3-1/2" x 11"	
57	H006 1801	Decal : 8-1/2" x 14"	
200	0313 0060B	Philips Pan Head Screw - M3 x 6	
201	0951 3005B	Philips Screw with Flat Washer - M3 x 5	
202	0951 3006B	Philips Screw with Flat Washer - M3 x 6	
203	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
204	0323 0060B	Philips Sunk Screw - M3 x 6	
205	0343 0080Z	Philips Truss Head Screw - M3 x 8	



2. ADF, SCANNER

September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 1184	Cover - Speed Dial Number List	
2	H006 4249	Speed Dial List	
3	H006 1151	Manual Feed Button	
4	H006 1650	Scanner Cover	
5	H006 1146	Front Hinge	
6	H006 1107	Upper Guide Earth Plate	
7	H006 5052	Earth Wire - Scanner	
8	H006 1149	Lever - Document Width Sensor	
9	H006 1190	Sensor Base	
10	H006 1106	Pressure Plate Spring	
11	H006 1092	Support - Manual Feed Lever	
12	H006 1093	Manual Feed Lever	
13	H006 1101	Manual Feed Spring	
14	H006 1046	Pressure Earth Plate	
15	H006 1147	Rear Hinge	
16	H006 1038	Scanner Pressure Roller	
17	H006 1199	Center Pressure Roller	
18	H006 1045	Long Pressure Roller	
19	H006 1044	Short Pressure Roller	
20	H006 1039	R1 : R2 Pressure Shaft	
21	H006 1115	Stopper Bracket Ass'y	
22	H006 1111	Stopper Ass'y	
23	H006 1057	Front Separate Lever	
24	H006 1094	ADF Separate Bracket	
25	H006 1102	Separate Friction	
26	H006 1095	Separate Sleeve	
27	H006 1070	ADF Friction Roller	
28	H006 1072	Rear Separate Spring	
29	H006 1061	ADF Separate Shaft	
31	H006 1127	Rear Lock Lever Ass'y	
33	H006 1100	Antistatic Brush - A3	
34	H006 1126	Lock Lever Spring	
35	H006 1125	Top Guide Plate	
36	H006 1096	Lock Lever Ass'y	
37	H006 1225	Contact Plate - Top Guide Plate	


INDEX	PART NO.	DESCRIPTION	MODEL
38	H006 1059	Front Pressure Plate Spring	
39	H006 1259	ADF Pressure Plate	
40	H006 1060	Rear Pressure Plate Spring	
41	H006 1064	Pressure Plate Shaft	
42	H006 7205	Sensor S2	
43	H006 1280	FL Guide	
44	H006 1283	Front FL Cap	
45	H006 1012	Front Mirror Holder	
46	H006 2528	Front FL Inner Cover	
47	H006 1168	Earth Plate - R2 Roller	
48	H006 1239	Earth Plate - R1 Roller	
49	H006 1083	Front Bracket Ass'y - Lock Lever	
50	H006 5217	Fluorescent Lamp	
51	H006 1036	R1 Roller	
52	5203 2613	Bushing - 6 x 10 x 10 mm	
53	5203 2611	Leaf Spring - 5 mm	
54	H006 1215	R1 Gear	
55	H006 1214	R1 Pulley	
56	H006 1219	R1 Idler Frange	
57	H006 1176	Rear Bracket Ass'y - Lock Lever	
58	H006 2553	Inner Cover - Scanner Cover - 2	
59	H006 1011	Scanner Mirror	
60	H006 1013	Rear Mirror Holder	
61	H006 1042	Idler Gear	
62	H006 2552	Inner Cover - Scanner Cover - 1	
63	H006 1281	Idler Bracket Ass'y	
64	H006 1197	Idler : 2 - 14T	
65	H006 1245	Belt Tention Idler	
66	H006 1235	Document Guide Bracket	
67	H006 1233	Document Feed Out Guide	
68	H006 5213	Stamper Ass'y	
69	H006 1033	R2 Pulley	
70	H006 3784	FL. Rear Inner Cover	
71	H006 2531	Inner Cover - Document Table	
72	H006 1037	R2 Roller	

INDEX	PART NO.	DESCRIPTION	MODEL
73	H006 1157	Rear Document Plate	
74	H006 1258	Fulcrum Pin	
75	H006 1053	Pick-up Spring Holder	
76	H006 1029	Pick-up Bracket Spring	
77	H006 6011	PCB - DSB	
78	5447 2681	Snap Ring	
79	H006 1054	Scanner Feed Roller	
80	H006 1623	ADF Pick-up Roller (Modified)	
81	H006 1050	Scanner Pick-up Bracket	
82	H006 1104	Pick-up Friction	
83	H006 1049	Stopper - Friction	
84	H006 1048	Drive Shaft	
85	H006 5214	ADF Clutch	
86	H006 1155	Shading Plate - F.L.	
87	H006 1270	Document Guide Plate Ass'y	
88	H006 1035	Pressure Bracket	
89	H006 1162	Fence - SI	
90	H006 1161	Paper Width Fence	
91	H006 1166	Front Support - Contact Glass	
92	H006 1120	Cover Open Pin	
93	H006 1121	Cover Open Spring	
94	H006 1119	Bushing - Cover Open	
95	H006 1001	Doc. Plate Earth Plate	
96	H006 1164	Rear Support - Contact Glass	
97	H006 1137	Mylar - Document Guide Plate	
98	H006 1108	Contact Glass Ass'y	
99	H006 1058	Rear Separate Lever	
100	H006 1056	Pick-up Belt	
101	H006 1091	Front Fulcrum Pin	
102	H006 1901	Lock Washer - M2	
103	H006 1223	Bushing - M6 - ADF	
104	H006 1222	Bushing Holder - ADF	
105	H006 1255	Mylar - Rear Document Plate	
106	H006 1253	Bracket - Rear Hinge Ass'y	
107	H006 1178	Front Bracket - Lock Lever	
108	H006 1279	Mylar - Center Pressure Roller	

INDEX	PART NO.	DESCRIPTION	MODEL
200	0313 0040B	Philips Pan Head Screw - M3 x 4	
201	0313 0050B	Philips Pan Head Screw - M3 x 5	
202	0313 0030B	Philips Pan Head Screw - M3 x 3	
203	0313 0080B	Philips Pan Head Screw - M3 x 8	
204	0313 0060B	Philips Pan Head Screw - M3 x 6	
205	0951 3005B	Philips Screw with Flat Washer - M3 x 5	
206	0951 3006B	Philips Screw with Flat Washer - M3 x 6	
207	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
208	0951 3010B	Philips Screw with Flat Washer - M3 x 10	
209	0965 3008B	Tapping Screw with Washer - M3 x 8	
210	0353 0050B	Philips Truss Head Screw - M3 x 5	
211	0533 0040E	Hexagon Headless Set Screw - M3 x 4	
212	0720 0025E	Retaining Ring - M2.5	
213	0720 0030E	Retaining Ring - M3	
214	0720 0040E	Retaining Ring - M4	
215	0720 0050E	Retaining Ring - M5	
216	5053 0447	Bushing - M6	
217	0805 0062	Blind Screw - M4 x 6	

3. UPPER UNIT

September 1, 1989



3. UPPER UNIT


September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 3425	First UIB Cover	
2	H006 3456	Support Strip - Cover - UIB	
3	H006 2512	Second UIB Cover	
4	H000 3292	Saddle Edge	
5	H006 5074	Harness - UIB	
6	H006 6029	PCB - UIB	
7	H006 3437	Harness Seal - FCU/UIB	
8	H006 3436	PMDR Harness Seal	
9	H006 3761	Upper Base Cover	
10	H006 3459	Fusing Interlock Spring	
11	H006 3427	Fusing Interlock Cover	
12	H006 5203	Eraser Ass'y	
14	H006 3415	Reinforce Plate - Front	
15	H006 5234	Scanner Stepping Motor	
16	H006 3428	Net LDDR	
17	G000 1945	LSD Cylindrical Lens	
18	H006 2506	Synchronize Holder	
19	H006 6001	PCB - LSD	
20	H006 5019	Harness - LSD	
21	H006 2557	Second Cylindrical Lens Ass'y	
22	H006 2536	Front Inner Cover	
23	H006 3759	Clear Copy Decal	
24	H008 2303	Cover - Second Cy. Lens Ass'y	
25	H006 3058	Bracket - H.P Sensor Ass'y	
26	H006 3250	Lever - Upper Base Interlock	
27	H006 3226	Fulcrum - Upper Base Front	
28	H006 2381	Toner Overflow Sensor Ass'y	
29	H006 3421	Pressure Arm - Drive Pulley	
30	H006 3212	Fulcrum Bar - Upper Base Rear	
31	H006 3407	Bias Terminal - Main Charge	
32	H006 3460	Pressure Arm Spring	
33	H006 3406	Front OBM Rail	
34	H006 3420	Master Earth Plate	
35	H006 3780	Upper Base	
36	H006 1220	Rear Earth Plate - Doc. Plate	

INDEX	PART NO.	DESCRIPTION	MODEL
37	H006 3468	Dumper Spring	
38	H006 3475	Idler Dumper Gear	
39	AA14 3047	Stepped Screw - M3	
40	H006 3480	Idler Bracket Ass'y	
41	H006 3402	Dumper	
42	H006 5221	Master Belt Motor	
43	H006 3381	Master Drive Bracket	
44	H006 3051	Tightner - Master Belt Ass'y	
45	H006 3384	Idle Gear - Master Drive - T20	
46	H006 1218	ADF Idler Gear - 48T	
47	H006 1213	ADF Idler Gear - 45T	
48	H006 1211	ADF Idler Gear - 40T	
49	H006 1236	ADF Bracket Ass'y	
50	H006 1210	R2 Idler Gear - 18T	
51	H006 1152	R1 Idler Frange	
52	H006 1208	R2 Clutch	
53	H006 1217	Reverse Idler Gear	
54	H006 1207	R1 Clutch	
55	H006 1041	226T Timing Belt	
56	H006 3492	Rear Inner Cover	
57	H006 3431	PMDR Connector Bracket	
58	H006 2457	Spring Holder	
59	H006 3405	Rear OBM Rail	
60	H006 2511	Document Table Bracket	
61	H006 3446	Upper Base Hadler	
62	H006 3486	Side Inner Cover	
63	H006 3493	Inner Cover - Side - Under	
64	H006 3760	OEM Decal	
65	H006 3408	Upper Base Hook	
66	H006 3409	Front Hook Pin	
67	H006 3438	Hook Spring	
68	H006 5020	Harness - Master Sensor	
69	H006 5033	Harness - Toner Overflow Sensor	
70	5353 1265	Decal - Laser	
71	H000 4523	Lock Washer	

INDEX	PART NO.	DESCRIPTION	MODEL
72	5413 1882	Stepped Screw	
73	H006 2524	Seal - OBM Motor	
75	H006 3757	Sector Gear - Master Lock	
76	H006 3756	Master Lock Slider	
77	H006 3758	Slider Spring	
78	H006 1171	Bracket - Front Hinge	
200	0313 0040B	Philips Pan Head Screw - M3 x 4	
201	0313 0050B	Philips Pan Head Screw - M3 x 5	
202	0313 0060B	Philips Pan Head Screw - M3 x 6	
203	0314 0060B	Philips Pan Head Screw - M4 x 6	
204	0951 3005B	Philips Screw with Flat Washer - M3 x 5	
205	0951 3006B	Philips Screw with Flat Washer - M3 x 6	
206	0314 0100B	Philips Pan Head Screw - M4 x 10	
207	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
208	0965 3006B	Tapping Screw with Flat Washer - M3 x 6	
209	0965 3008B	Tapping Screw with Washer - M3x8	
210	0965 3012B	Tapping Screw with Washer - M3 x 12	
211	0343 0050Z	Philips Truss Head Screw - M3 x 5	
212	0720 0030E	Retaining Ring - M3	
213	0720 0040E	Retaining Ring - M4	
214	0720 0050E	Retaining Ring - M5	
215	0720 0060E	Retaining Ring - M6	
216	0720 0025E	Retaining Ring - M2.5	
217	0710 0030B	Flat Washer - M3	

INDEX	PART NO.	DESCRIPTION	MODEL




4. LASER SECTION

September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 2525	F - Lens Bracket	
2	H006 2518	Top F - Lens Holder	
3	H000 2508	F1 Lens	
4	H000 2509	F2 Lens	
5	H006 2513	Holder - Second Synchronize Mirror	
6	H006 2509	Second Synchronize Mirror	
7	H000 2514	Holder - First Cylindrical Lens	
8	H006 2510	First Cylindrical Lens	
9	H006 5200	Pentagonal Mirror Motor	
10	H006 3485	Harness Inner Cover	
11	H006 5215	FL Stabilizer	
12	H006 5032	Harness - Pentagonal Motor	
13	H006 5202	Driver - Pentagonal Mirror Motor	
14	H006 5022	Harness - FL Stabilizer	
15	H006 3432	SMDR Shield Cover	
16	H006 3447	Earth Plate - Upper Base/Base	
17	H006 3484	Inner Cover - FL Stabilizer	
18	H006 3440	Master Unit Interlock	
19	H006 2679	Charge Wire Hook	
20	H006 5205	Hight Voltage Cord - C	
21	H006 2677	Rear End Block - Charge	
22	5203 2060	Stopped Screw - Charger	
23	5203 9001	Corona 'dire (10 pcs)	
24	H006 3451	Housing Charge Ass'y	
25	H006 2678	Front End Block - Charge	
26	H006 2681	Front End Cover - Charge	
27	H006 3439	Main Charger Duct	
28	H006 3453	Under Holder - Second Cy. Lens	
29	H006 3483	Inner Cover - LO Unit	
30	H006 3419	Earth Plate - Main Charge	
31	H006 3444	Varistor	
32	H006 3389	Master Drive Gear - T16	
33	H006 3390	Master Drive Arm	
34	H006 3388	Master Drive Shaft	
35	H006 3393	Master Drive Gear - T23	

INDEX	PART NO.	DESCRIPTION	MODEL
36	H006 3416	Reinforce Plate - Rear	
37	H006 3458	Main Charger	
38	H006 3385	Pulley - OBM Drive	
39	H000 3332	Bushing	
40	H006 3380	Master Drive Belt	
41	H006 2507	Mirror	
42	H000 2516	Right Mirror Holder	
43	H000 2517	Left Mirror Holder	
44	H006 5021	Harness - LDDR	
45	H006 2042	Laser Diode Unit	
46	H006 2556	Front F - Lens Holder	
47	H006 1194	Shield Plate - Laser Section	
48	H006 2554	Holder - First Synchronize Mirror	
49	H006 2508	First Synchronize Mirror	
50	H006 3398	Arm Bushing - Master Drive	
200	0313 0060B	Philips Pan Head Screw - M3 x 6	
201	0951 3006B	Philips Screw with Flat Washer - M3 x 6	
202	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
203	0313 0160B	Philips Pan Head Screw - M3 x 12	
204	0951 3020B	Philips Screw with Flat Washer - M3 x 8	
205	0443 0102B	Hexagon Head Tapping Screw - M3 x 8	
206	0343 0060Z	Philips Truss Head Screw - M3 x 6	
207	0720 0040E	Retaining Ring - M4	
208	0720 0050E	Retaining Ring - M5	
209	0313 0050B	Philips Pan Head Screw - M3 x 5	



5. DEVELOPMENT


September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 5207	Paper Sensor Ass'y	
2	H006 3623	Paper Sensor Sheet	
3	H006 3579	Stay - Paper Sensor Board	
4	H006 3661	Cover - Paper Sensor	
5	H006 5007	Harness - Paper Sensor	
6	H006 3600	Mylar - Feed	
7	H006 3269	Upper Base Guide	
8	H006 3311	Stay - Modular Jack Harness	
9	H006 3255	MJ Harness Clamp	
10	H006 4152	Button - Upper Base Open	
11	H006 2219	NCU Shield	
12	H006 3702	Spring - Transport Fusing Bracket	
13	H006 3690	Lever - Upper Base Open Ass'y	
14	H006 3270	Lever - Development Cover Open	
15	H006 5001	Harness - NCU	
16	H006 6030	PCB - AANCU - USA	
17	H006 3268	NCU Cover	
18	H006 2220	Inner Cover Bracket	
19	H006 2216	Inner Cover - Lens Block	
20	H006 5000	Harness - VPU	
21	H015 6029	PCB - VPU	
22	H006 1237	Shading Plate	
23	H006 1003	Lens Ass'y	
24	H006 1010	Lens Block	
25	H006 6017	PCB - SBU	
26	H006 1015	SBU Adjustment Knob	
27	H006 5015	Harness - SBU	
28	H006 5208	Toner Empty Sensor	
29	H006 5003	Harness - Toner Sensor	
30	H006 4165	Mylar - Lens Block Stay	
31	H006 2211	Lens Block Stay	
32	H006 2050	Development Hopper Ass'y	
33	H006 2437	Developing Roller	
34	H006 2401	Hopper Agitator	
35	H006 2404	Toner Supply Roller Ass'y	

INDEX	PART NO.	DESCRIPTION	MODEL
36	5216 3095	Mylar - Toner Supply Roller	
37	H006 2413	Blade Seal	
38	H006 2412	OBU Seal	
39	H006 2409	Toner Metering Blade Ass'y	
40	5203 3105	Nylon Rivet	
41	H006 2418	Antistatic Brush Cover	
42	H006 2400	Development Antistatic Brush	
43	H006 2438	Front Side Plate - Development	
44	H006 4149	Bracket - Development Inner Cover	
45	H006 4257	Screw - Development Inner Cover	
46	H006 4258	Development Inner Cover	
47	H006 4256	Stepped Screw - Development Cover	
48	5203 3127	Toner End Spring	
49	H006 2428	Agitator Gear	
50	5203 3130	Toner End Disk	
51	H006 2443	Rear Side Plate - Development	
52	H006 2051	Hopper Ass'y	
53	H006 2431	Sleeve Idle Gear	
54	H006 2432	Toner Supply Gear	
55	H006 2429	Sleeve Gear	
56	H006 2433	Front Development Gear	
57	H006 2419	Agitator Idle Gear	
58	H006 2407	Toner End Lever	
59	H006 2420	Rear Development Cover	
60	5203 3151	Roller Cover Spring	
61	H006 3336	Small Clamp	
62	5466 3198	Washer - SBU	
63	H006 3693	Roller - Upper Base Open	
64	H006 4171	Cushion - Development Inner Cover	
65	H006 2383	Snap Ring - Registration	

INDEX	PART No.	DESCRIPTION	MODEL
200	0313 0030B	Philips Pan Head Screw - M3 x 3	
201	0313 0040B	Philips Pan Head Screw - M3 x 4	
202	0313 0050B	Philips Pan Head Screw - M3 x 5	
203	0313 0060B	Philips Pan Head Screw - M3 x 6	
204	0951 3005B	Philips Screw with Flat Washer - M3 x 5	
205	0951 3006B	Philips Screw with Flat Washer - M3 x 6	
206	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
207	0951 4008B	Philips Screw with Flat Washer - M4 x 8	
208	0801 1167	Double Sens Screw - M3 x 8	
209	0954 3014	Double Sens Screw - M3 x 14	
210	0573 0040E	Hexagon Headless Set Screw - M3 x 4	
211	0954 4008B	Double Sens Screw - M4 x 8	
212	0720 0030E	Retaining Ring - M3	
213	0720 0040E	Retaining Ring - M4	
214	0720 0060E	Retaining Ring - M6	
215	0805 3162	Ball Bearing - 10 x 19 x 7 mm	

INDEX	PART NO.	DESCRIPTION	MODEL



6. TRANSFER, PCBs

September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 2453	Transfer Ventilate Guide	
2	H006 2454	Ventilate Guide Mylar	
3	H006 2450	Transfer Charger Ass'y	
4	H006 2451	Housing - Transfer Charger	
5	H006 5042	Earth Wire - T. Charge	
6	H006 2688	Rear End Cover - T. Charge	
7	0809 1013	Nylon Wire	
8	H006 2684	Front End Cover - T. Charge	
9	H006 2683	Front End Block - T. Charge	
10	5203 9001	Corona Wire (10 pcs)	
11	5203 2060	Stopped Screw - Charger	
12	H006 2687	Rear End Block - T. Charge	
13	H006 3312	Transfer Pressure Spring	
14	H006 3301	Front Stopper - Transfer Charger	
15	H006 3225	Left Op-Port Cover	
16	H006 5226	Push Switch Ass'y	
17	1204 1280	Push Switch	
18	H006 5047	Harness - Interlock Switch	
19	H006 5050	Harness - Interlock	
20	H006 3224	Op-Port Cover	
21	H006 3221	Interlock Switch Bracket	
22	H006 3338	FCU Support	
23	H006 2458	FCU Cable Duct	
24	H006 2459	UIB Harness Clamp	
25	H006 2467	Bracket - Interlock Switch Connector	
26	H006 6023	PCB - FCU	
27	H006 6018	PCB - DMU-1 - FAX1000L	1000L Only
27	H006 6072	PCB - DMU-1 - FAX1010L	1010L Only
28	H006 6010	PCB - MIF - JAPAN/USA	
29	H012 6038	V96F Modem - New Type	
30	H006 5010	Harness - LIB/SW1	
31	H006 5009	Harness - L18/P1	
32	H006 2307	DMU Clamp	
33	H006 2304	Op-port Cover - Stay - FAX1000L	1000L only
33	H006 4945	Op-port Cover - Stay - FAX1010L	1010L only

INDEX	PART NO.	DESCRIPTION	MODEL
34	H006 6031	PCB - MBU - USA - FAX1000L	1000L only
34	H006 6100	PCB - MBU - USA - FAX1010L	1010L only
35	H006 3262	Modem Clamp	
36	H006 3257	FCU Shield	
37	H006 3299	Right Stay - Op-Port	
38	H006 2462	Right Base Stay	
39	H006 3245	Center Base Stay	
40	H006 5011	Harness - Power Pack	
41	H006 5222	Power Pack	
42	H006 2460	Maintenance Cover - P.P.	
43	H006 3288	Bias Block - Main Charger	
44	H006 3302	Earth Plate - Paper Feed	
45	H006 3399	DRU Clamp	
46	H006 3365	Rear Bracket - Transfer Fan	
47	H006 5225	Rear Transfer Fan	
48	H006 5058	Harness - DRU	
49	H006 6027	PCB - DRU	
50	H006 5060	Harness - Solenoid	
51	H006 5075	Harness - Paper Feed	
52	H006 3326	DRU Cover	
53	H006 2456	Transfer Guide Spring	
54	H006 3363	Front Bracket - Transfer Fan	
55	H006 5224	Front Transfer Fan	
56	H006 2333	Front LCT Stay	
57	H006 3300	Rear Stopper - Transfer Charger	
58	H006 2309	FCU Support - R102	
60	H006 2334	Right FCU Shield	
61	H006 2335	C 1 amp - Development Inter Lock	

6. TRANSFER, PCBs

September 1, 1989

INDEX	PART No.	DESCRIPTION	MODEL
200	0313 0040B	Philips Pan Head Screw - M3 x 4	
201	0313 0250B	Philips Pan Head Screw - M3 x 25	
202	0951 300B	Philips Screw with Flat Washer - M3 x 5	
203	0951 3006B	Philips Screw with flat Washer - M3 x 6	
204	0314 0080B	Philips Pan Head Screw - M4 x 8	
205	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
206	0951 3012B	Philips Screw with Flat Washer - M3 x 12	
207	0951 4006B	Philips Screw with Flat Washer - M4 x 6	
208	0965 3006B	Tapping Screw with Flat Washer - M3 x 6	
209	0965 3008B	Tapping Screw with Washer - P13 x 8	
210	1105 0108	Wire Saddle - WS-ENS	

INDEX	PART NO.	DESCRIPTION	MODEL

7. PAPER FEED, REGISTRATION


September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 3605	Guide Plate - Transfer Charger	
2	H006 3603	Front Transfer Guide Plate	
3	H006 3644	Mylar Seal - Transfer Entrance	
4	H006 3751	Master Interlock Lever	
5	H006 3648	Pick-up Roller Stay	
6	H006 2318	Cover - Pick-up Roller Stay	
7	H006 3518	Clutch Hub - Paper Feed	
8	H006 3516	Feed Clutch Sleeve - 36T	
9	H006 3517	Clutch Spring - Paper Feed	
10	H006 3515	Paper Lift Pulley	
11	H006 3509	Paper Lift Lever	
12	H006 3601	Pulley Washer	
13	H006 3514	Boss - Paper Feed Shaft	
14	H006 3513	Pawl Spring	
15	H006 3512	Pawl Stepped Screw	
16	H006 3508	Pawl - Shaft Paper Feed	
17	H000 3332	Bushing	
18	H006 3612	Clutch Spring - Pulley	
19	H006 3519	Pick-up Cam	
20	H006 3647	Feed Roller Shaft	
21	H006 3523	Pick-up Bracket Spring	
22	H006 2323	Pick-up Roller Bracket	
23	H006 3646	Pick-up Roller Holder	
24	H006 3531	Pick-up Roller	
25	H006 3587	Spring - Upper Guide Plate	
26	5474 1140	Bushing - Pressure Roller	
27	H006 3533	Snap Ring	
28	H006 3530	Idle Gear - 15T	
29	H006 3532	Feed Roller	
30	H006 3586	Registration Roller	
31	H006 3588	Hold Spring - Upper Guide Plate	
32	H006 2043	Upper Regist Guide Plate Ass'y	
34	H006 2317	Pick-up Lever	
35	H006 2349	Lower Guide Plate Ass'y	
36	H006 2348	Registration Mylar	

INDEX	PART NO.	DESCRIPTION	MODEL
37	H006 3286	Development Bias Terminal	
38	H006 3285	Front Guide Rail - Development	
39	H006 3280	Spring - Pressure Upper Base	
40	H006 3279	Spring Clamp - Pressure Upper Base	
41	H006 3287	Bracket - Front Pressure Upper Base	
42	H006 2530	Lock Pin Collar - Upper Base	
43	H006 2203	Front Bracket - Paper Feed	
44	H006 3282	Front Lock Pin - Upper Base	
45	H006 3574	Front Cassette Guide	
46	H006 3591	Lower Registration Roller	
47	H006 3553	Paper Lift Shaft	
48	H006 3559	Tray Lift Arm	
49	1204 1603	Push Switch	
50	H006 5051	Harness - Development Switch	
51	H006 3660	Cover - Development Interlock	
52	H006 5008	Harness - Cassette Size Sensor	
53	AW50 0001	Push Switch - Paper Size 1	
54	H006 3560	Paper Feed Guide	
55	H006 3671	Friction Roller Bracket	
56	H006 3573	Friction Roller Spring	
57	H006 3572	Friction Roller Shaft	
58	H006 3571	Friction Roller Bracket	
59	H006 3565	Separation Roller Shaft	
60	H006 3566	Friction Roller	
61	H006 3567	Torque Limitter Clutch	
62	H006 3568	Torque Limitter Cover	
63	H006 3569	Torque Limitter Spring	
64	H006 3570	Friction Roller Stopper	
65	H006 3575	Rear Cassette Guide	
66	H006 2068	Feed Solenoid Ass'y	
67	H006 2214	Settle Plate - Harness/Solenoid	
69	H006 3551	Stopper Pawl	
69	H006 3541	Stopper Bracket	
70	H006 3545	Release Lever - Paper Lift	
71	H006 3549	Release Spring - Paper Lift	

INDEX	PART NO.	DESCRIPTION	MODEL
72	5447 2768	Stepped Screw - M3	
73	H006 3607	Release Pin Slider	
74	H006 3552	Ratchet Spring	
75	H006 3550	Ratchet Paw Pin	
76	H006 2063	Paper Lift Solenoid Ass'y	
77	H006 3556	Sector Gear Spring	
78	H006 3554	Sector Gear - Paper Lift	
79	H006 3557	Sector Gear Bracket	
80	H006 3558	Sector Gear Lock	
81	H006 3593	Registration Drive Bracket	
82	H006 3372	Belt Pulley	
83	H006 3598	Registration Drive Pulley	
84	H006 3597	Registration Clutch Gear	
85	H006 3596	Registration Shaft	
86	H006 3592	Registration Electromagnetic Clutch	
87	H006 2302	Rear Bracket - Pressure Upper Base	
88	H006 3334	Harness Cover - Fan Motor	
89	H006 5227	Development Clutch	
90	H006 2301	Development Drive Shaft	
91	H006 3366	Development Drive Gear - T24	
92	H006 2066	Pick Up Roller Ass'y	
93	H006 3281	Rear Guide Rail - Development	
94	H006 3606	Pin - Transfer Guide	
95	H006 3604	Adjust Plate - Guide Transfer Rear	
96	H0062 231	Rear Bracket - Paper Feed	
97	H006 3611	Clutch Hub - P	
98	H006 3616	Mylar - Lower Guide Plate	
99	H006 2371	Paper Guide Pad	
100	H006 2478	Bushing - Fan Motor	
101	H006 3635	Fulcrum Pin - Pick-up Ass'y	
102	H006 3645	Front Stay - Feed Shaft	
103	H006 3241	Washer - Middle Pulley	
104	H006 2316	Spacer - Pick-up Clutch	
105	H006 3755	Master Interlock Spring	
106	H006 3754	Master Interlock Support	

INDEX	PART NO.	DESCRIPTION	MODEL
107	H006 2337	Adjustment Bracket - Sector Gear	
108	H006 2383	Snap Ring - Registration	
109	H006 2382	Bushing - Registration	
200	0313 0030B	Philips Pan Head Screw - M3 x 3	
201	0313 0050B	Philips Pan Head Screw - M3 x 5	
202	0313 0060B	Philips Pan Head Screw - M3 x 6	
203	0314 0060B	Philips Pan Head Screw - M4 x 6	
204	0951 3006B	Philips Screw with Flat Washer - M3 x 6	
205	0951 3005B	Philips Screw with Flat Washer - M3 x 5	
206	0954 4012B	Double Sens Screw - M4 x 12	
207	0951 4016B	Philips Screw with Flat Washer - M4 x 16	
208	0965 3006B	Tapping Screw with Flat Washer - M3 x 6	
209	0533 0030Z	Hexagon Headless Set Screw - M3 x 3	
210	0533 0040Z	Hexagon Headless Set Screw - M3 x 4	
211	0720 0030E	Retaining Ring - M3	
212	0720 0040E	Retaining Ring - M4	
213	0720 0050E	Retaining Ring - M5	
214	0720 0060E	Retaining Ring - M6	
215	5053 0447	Bushing - M6	
216	1105 0106	Wire Saddle	
217	0957 3012B	Double Sens Screw - M3 x 12	
218	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
219	0313 0200B	Philips Pan Head Screw - M3 x 20	



8. FUSING, TRANSPORT


September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 2156	Exit Cover	
2	H006 2155	Exit Fusing Cover	
3	5203 4179	Caution Decal - High Temperature	
4	H006 2154	Exit Antistatic Brush	
5	H006 2123	Upper Exit Guide Ass'y	
6	H006 2131	Stripper Spring	
7	H006 2135	Bushing - M 4 x 6	
8	H006 2182	Exit Gear - T19	
9	H006 2130	Fusing Stripper	
10	H006 2127	Exit Bracket	
11	H006 2176	Exit Interlock Lever	
12	H006 2134	Fusing Exit Roller	
13	H006 2173	Stripper Release Spring	
14	H006 2172	Holder - Feed Out Spring	
15	H006 2170	Feed Out Hook	
16	H006 2138	Lower Exit Guide	
17	H006 2152	Lower Exit Roller	
18	H006 2151	Exit Roller Holder	
19	H006 3267	AC Line Cover	
20	5214 1221	Rubber Foot - Fan Motor	
21	H006 2477	Guide Plate - Fusing Front Ass'y	
22	H006 5012	Harness - PSU - p	
23	H006 5013	Harness - PSU - S	
24	N601 7048	PCB - PSU	
25	H006 5600	PSU Ass'y - USA	
26	H006 3346	Rear PSU Bracket	
27	H006 3218	Front Frame Bracket	
28	H006 3252	Main Motor Harness Clamp	
29	H006 4394	LCT Connector Cover	
30	H006 2315	Rubber Foot	
31	H006 3251	Left Base Stay	
32	H006 2455	Rubber Foot Plate	
33	H006 2473	Front Spring Plate - Fan Motor	
34	H006 3072	Printer Fan Ass'y	
35	H006 4252	Caution Decal - PSU	

INDEX	PART NO.	DESCRIPTION	MODEL
36	H006 3696	Rear Spring Plate - Fan Motor	
37	H006 3243	Ozone Filter	
38	H006 3374	Fan Drive Pulley - Small	
39	H006 2345	Fan Drive Pulley - Middle	
42	H006 2341	Bracket - Fan Drive Pulley (S)	
43	H006 2223	Bracket - Fan Drive Pulley (M)	
44	H006 2112	Pressure Roller	
45	H006 2113	Pressure Roller Bushing	
46	H006 2110	Hot Roller	
47	H006 2670	Fusing Lamp - 115V/410W	
48	H008 5207	Copy Out Sensor	
49	H006 3248	Front Fusing Bracket	
50	H006 2140	Front Heater Holder	
51	H006 2190	Fusing Entrance Mylar	
52	H006 2192	Upper Fusing Stay Ass'y	
53	H006 2174	Thermostat Case	
54	H006 5245	Thermostat Ass'y	
55	H006 5244	Harness - Fusing/Thermostat	
56	H006 2166	Thermostat Bracket	
57	H006 5241	Fusing Thermistor	
58	H006 5243	Fusing Connector	
59	H006 2332	Rear Fusing Bracket	
60	H006 3247	Rear Fusing Bracket	
61	H006 2142	Rear Heater Holder	
62	H006 2180	Fusing Gear - T35	
63	H006 2111	Rear Fusing Bushing	
64	H006 2181	Idle Gear - T19	
65	H006 2126	Rear Fusing Hook	
66	H006 2338	Pressure Spring	
67	H006 2490	Lower Fusing - Guide Plate	
68	H006 2115	Lower Fusing Stay	
69	H006 2125	Front Fusing Hook, 1	
70	H006 2331	Front Fusing Bracket	
71	H00 62109	Front Fusing Bushing	
72	H006 3271	Interlock Fusing Roller	

INDEX	PART NO.	DESCRIPTION	MODEL
73	H006 2236	Interlock Fusing Lever	
74	H006 3275	Interlock Fusing Spring	
75	H006 2237	Front Inner Cover - Fusing	
76	H006 2148	Exit Sensor Actuator	
77	H006 2139	Lower Exit Cover	
78	H006 4166	Fusing Inner Cover Ass'y	
79	H006 2054	Exit Sensor Slit Ass'y	
80	H006 3229	Frame Stay	
81	H006 3276	Interlock Fusing Cover	
82	H006 2171	Exit Stopped Screw	
83	H006 3241	Washer - Middle Pulley	
85	H006 2344	Fan Drive Pulley - M Ass'y	

INDEX	PART NO.	DESCRIPTION	MODEL
200	0313 0040B	Philips Pan Head Screw - M3 x 4	
201	0313 0050B	Philips Pan Head Screw - M3 x 5	
202	0313 0060B	Philips Pan Head Screw - M3 x 6	
203	0313 0080B	Philips Pan Head Screw - M3 x 8	
204	0314 0080B	Philips Pan Head Screw - M4 x 8	
205	0951 3005B	Philips Screw with Flat Washer - M3 x 5	
206	0343 0060Z	Philips Truss Head Screw - M3 x 6	
207	0951 3004B	Philips Screw with Flat Washer - M3 x 4	
208	0951 3008B	Philips Screw with Flat Washer - M3 x 8	
209	0951 3010B	Philips Screw with Flat Washer - M3 x 10	
210	0853 0061Z	Bolt - M3 X 6	
211	0805 3145	Ball Bearing - 6 x 1 2 x 4 mm	
212	0720 0030E	Retaining Ring - M3	
213	0720 0025E	Retaining Ring - M2.5	
214	0720 0040E	Retaining Ring - M4	
215	0720 0060E	Retaining Ring - M6	
216	5052 0269	Bushing - M4.2	
217	0725 0200B	Retaining Ring - C20	
218	0720 0050E	Retaining Ring - M5	
219	0807 4009	Washer - 5.2 x 11 x 0.3	




9. MAIN DRIVE

September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
	H006 5211	Modular Jack	
2	H006 3244	Modular Jack Bracket	
3	H006 3210	Upper Base Lock Hook	
4	H006 3211	Upper Base Lock Spring	
5	H006 3206	Dumper Gear	
6	H006 2238	Upper Base Limitter	
7	H006 3200	Rear Frame Bracket	
8	H006 3209	Dumper Gear Angle	
9	5214 1221	Rubber Foot - Fan Motor	
10	H006 3246	Rear Frame Bracket Cover	
11	H006 3352	Fusing Idle Gear - T33	
12	H006 3351	Idle Gear - T441T16	
13	H006 3364	Spring - Transport Fusing Bracket	
14	H006 3353	Transport Bracket	
15	H006 3356	Main Drive Idler - T51	
16	H006 3357	Main Drive Gear - T23	
17	H000 3332	Bushing	
18	H006 3358	Main Drive Shaft	
19	H006 3359	Main Drive Pulley	
20	H006 2475	Main Motor Cover Ass'y	
21	H006 2471	Fan Belt Tightener	
22	H006 3350	Main Drive Belt - S3M	
23	H006 2479	Tightner Spring	
24	H006 2472	Tightr Roller - M16	
25	5413 1882	Stepped Screw	
26	H006 3368	Tightner	
27	H006 3249	Fusing Earth Plate	
28	H006 4390	Base	
29	H006 3335	Harness Clamp - SCN Motor	
30	H006 3599	registration Stopper	
31	H006 3256	NCU Earth Plate	
32	H006 3307	Bracket - SCN Motor Connector	
33	H006 3310	Spring - SCN Motor Connector	
34	H006 5043	Harness - Scanner Motor - Relay	
35	H006 3309	Setscrew - SCN Motor Connector	
36	H006 2339	Inlet Base	

INDEX	PART NO.	DESCRIPTION	MODEL
37	H006 2339	Inlet Filter	
38	H006 5223	Main Switch	
39	H006 5031	Harness - Main Switch	
40	H006 5232	Master Belt Fan Motor	
41	H006 4135	Fan Motor Duct	
42	H006 3331	Inlet Cover	
43	H006 4128	Fun Motor Nut	
44	H006 2464	AC Line Cover	
45	H006 3610	Bracket - Main Drive Pulley	
46	H006 5220	Main Motor	
47	H006 3376	Fan Drive Pulley - Large	
48	H006 3377	Fan Drive Belt	
49	H006 5014	Harness - Main Motor	
50	H006 3694	Earth Plate - NCU	
51	H006 2340	Front Inlet Base	
52	H006 2468	Edging - Scanner Motor Bracket	
200	0313 0060B	Philips Pan Head Screw - M3 x 6	
201	0314 0080B	Philips Pan Head Screw - M4 x 8	
202	0951 3006B	Philips Screw with Flat Washer - M3 x 6	
203	0313 0100B	Philips Pan Head Screw - M3 x 10	
204	0951 4006B	Philips Screw with Flat Washer - M4 x 6	
205	0951 4008B	Philips Screw with Flat Washer - M4 x 8	
206	0720 0030E	Retaining Ring - M3	
207	0720 0050E	Retaining Ring - M5	
208	0720 0060E	Retaining Ring - M6	
209	0965 3008B	Tapping Screw with Washer - M3 x 8	
210	0323 0060	Philips Sunk Screw - M3 x 6	
211	0353 0050	Philips Truss Head Screw - M3 x 5	
212	0705 0040B	Bushing - M4 x 5	



10. CASSETTE

September 1, 1989

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 2319	Cassette Cover	
2	H006 2320	Bottom Plate - Cassette Ass'y	
3	H006 3638	Paper Size Detector Pin - B4	
3	H006 3640	Paper Size Detector Pin - Legal	
3	H006 3642	Paper Size Detector Pin - Letter	
4	H006 3665	Front Side Fence	
5	H006 2322	Cassette	
6	H006 3663	Cassette Decal	
7	5447 2941	Rear Fence	
8	5413 4835	Decal - Paper Level	
9	H006 3666	Rear Side Fence	
200	0965 4008W	Tapping Screw with Washer - M4 x 8	

INDEX	PART NO.	DESCRIPTION	MODEL

PARTS INDEX

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0002508	F1 Lens	9- 3
H0002509	F2 Lens	9- 4
H0002514	Holder - First Cylindrical Lens	9- 7
H0002516	Right Mirror Holder	9-42
H0002517	Left Mirror Holder	9-43
H0003292	Saddle Edge	7- 4
H0003332	Bushing	9-39
H0003332	Bushing	15-17
H0003332	Bushing	19-17
H0004523	Lock Washer	7-71
H0014219	M Lock Washer	3-53
H0061003	Lens Ass'y	11-23
H0061010	Lens Block	11-24
H0061011	Scanner Mirror	5-59
H0061012	Front Mirror Holder	5-45
H0061013	Rear Mirror Holder	5-60
H0061015	SBU Adjustment Knob	11-26
H0061029	Pick-up Bracket Spring	5-76
H0061033	R2 Pulley	5-69
H0061035	Pressure Bracket	5-88
H0061036	R1 Roller	5-51
H0061037	R2 Roller	5-72
H0061038	Scanner Pressure Roller	5-16
H0061039	R1 : R2 Pressure Shaft	5-20
H0061041	226T Timing Belt	7-55
H0061042	Idler Gear	5-61
H0061044	Short Pressure Roller	5-19
H0061045	Long Pressure Roller	5-18
H0061046	Pressure Earth Plate	5-14
H0061048	Drive Shaft	5-84
H0061049	Stopper - Friction	5-83
H0061050	Scanner Pick-up Bracket	5-81
H0061053	Pick-up Spring Holder	5-75
H0061054	Scanner Feed Roller	5-79
H0061055	ADF Pick-up Roller (Rubber)	3- *

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0061056	Pick-up Belt	5-100
H0061057	Front Separate Lever	5-23
H0061058	Rear Separate Lever	5-99
H0061059	Front Pressure Plate Spring	5-38
H0061060	Rear Pressure Plate Spring	5-40
H0061061	ADF Separate Shaft	5-29
H0061064	Pressure Plate Shaft	5-41
H0061070	ADF Friction Roller	5-27
H0061072	Rear Separate Spring	5-28
H0061081	Doc. Plate Earth Plate	5-95
H0061083	Front Bracket Ass'y - Lock Lever	5-49
H0061091	Front Fulcrum Pin	5-101
H0061092	Support - Manual Feed Lever	5-11
H0061093	Manual Feed Lever	5-12
H0061094	ADF Separate Bracket	5-24
H0061095	Separate Sleeve	5-26
H0061096	Lock Lever Ass'y	5-36
H0061100	Antistatic Brush - A3	5-33
H0061101	Manual Feed Spring	5-13
H0061102	Separate Friction	5-25
H0061104	Pick-up Friction	5-82
H0061106	Pressure Plate Spring	5-10
H0061107	Upper Guide Earth Plate	5- 6
H0061108	Contact Glass Ass'y	5-98
H0061111	Stopper Ass'y	5-22
H0061115	Stopper Bracket Ass'y	5-21
H0061119	Bushing - Cover Open	5-94
H0061120	Cover Open Pin	5-92
H0061121	Cover Open Spring	5-93
H0061125	Top Guide Plate	5-35
H0061126	Lock Lever Spring	5-34
H0061127	Rear Lock Lever Ass'y	5-31
H0061137	Mylar - Document Guide Plate	5-97
H0061146	Front Hinge	5- 5
H0061147	Rear Hinge	5-15

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0061149	Lever - Document Width Sensor	5- 8
H0061151	Manual Feed Button	5- 3
H0061152	R1 Idler Frange	7-51
H0061155	Shading Plate - F.L.	5-86
H0061157	Rear Document Plate	5-73
H0061161	Paper Width Fence	5-90
H0061162	Fence - SI	5-89
H0061164	Rear Support - Contact Glass	5-96
H0061166	Front Support - Contact Glass	5-91
H0061168	Earth Plate - R2 Roller	5-47
H0061171	Bracket - Front Hinge	7-78
H0061176	Rear Bracket Ass'y - Lock Lever	5-57
H0061178	Front Bracket - Lock Lever	5-107
H0061181	Document Tray	3- 1
H0061182	Sub Document Tray	3- 2
H0061183	Bracket - Sub Document Tray	3- 3
H0061184	Cover - Speed Dial Number List	5- 1
H0061186	Quick Dial List - White	3-10
H0061187	Quick Dial List - Gray	3-11
H0061190	Sensor Base	5- 9
H0061194	Shield Plate - Laser Section	9-47
H0061197	Idler : 2 - 14T	5-64
H0061199	Center Pressure Roller	5-17
H0061205	Sensor S2	5-42
H0061207	R1 Clutch	7-54
H0061208	R2 Clutch	7-52
H0061210	R2 Idler Gear - 18T	7-50
H0061211	ADF Idler Gear - 40T	7-48
H0061213	ADF Idler Gear - 45T	7-47
H0061214	R1 Pulley	5-55
H0061215	R1 Gear	5-54
H0061217	Reverse Idler Gear	7-53
H0061218	ADF Idler Gear - 48T	7-46
H0061219	R1 Idler Frange	5-56
H0061220	Rear Earth Plate - Doc. Plate	7-36

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0061222	Bushing Holder - ADF	5-104
H0061223	Bushing - M6 - ADF	5-103
H0061225	Contact Plate - Top Guide Plate	5-37
H0061233	Document Feed Out Guide	5-67
H0061235	Document Guide Bracket	5-66
H0061236	ADF Bracket Ass'y	7-49
H0061237	Shading Plate	11-22
H0061239	Earth Plate - R1 Roller	5-48
H0061245	Belt Tention Idler	5-65
H0061253	Bracket - Rear Hinge Ass'y	5-106
H0061255	Mylar - Rear Document Plate	5-105
H0061258	Fulcrum Pin	5-74
H0061259	ADF Pressure Plate	5-39
H0061270	Document Guide Plate Ass'y	5-87
H0061279	Mylar - Center Pressure Roller	5-108
H0061280	FL Guide	5-43
H0061281	Idler Bracket Ass'y	5-63
H0061283	Front FL Cap	5-44
H0061623	ADF Pick-up Roller (Modified)	5-80
H0061650	Scanner Cover	5- 4
H0061800	Decal : 8-1/2" x 11"	3-56
H0061801	Decal : 8-1/2" x 14"	3-57
H0061901	Lock Washer - M2	5-102
H0062042	Laser Diode Unit	9-45
H0062043	Upper Regist Guide Plate Ass'y	15-32
H0062050	Development Hopper Ass'y	11-32
H0062051	Hopper Ass'y	11-52
H0062054	Exit Sensor Slit Ass'y	17-79
H0062063	Paper Lift Solenoid Ass'y	15-76
H0062066	Pick Up Roller Ass'y	15-92
H0062068	Feed Solenoid Ass'y	15-66
H0062109	Front Fusing Bushing	17-71
H0062110	Hot Roller	17-46
H0062111	Rear Fusing Bushing	17-63
H0062112	Pressure Roller	17-44

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0062113	Pressure Roller Bushing	17-45
H0062115	Lower Fusing Stay	17-68
H0062123	Upper Exit Guide Ass'y	17- 5
H0062125	Front Fusing Hook, 1	17-69
H0062126	Rear Fusing Hook	17-65
H0062127	Exit Bracket	17-10
H0062130	Fusing Stripper	17- 9
H0062131	Stripper Spring	17- 6
H0062134	Fusing Exit Roller	17-12
H0062135	Bushing - M4 x 6	17- 7
H0062138	Lower Exit Guide	17-16
H0062139	Lower Exit Cover	17-77
H0062140	Front Heater Holder	17-50
H0062142	Rear Heater Holder	17-61
H0062148	Exit Sensor Actuator	17-76
H0062151	Exit Roller Holder	17-18
H0062152	Lower Exit Roller	17-17
H0062154	Exit Antistatic Brush	17- 4
H0062155	Exit Fusing Cover	17- 2
H0062156	Exit Cover	17- 1
H0062166	Thermostat Bracket	17-56
H0062170	Feed Out Hook	17-15
H0062171	Exit Stopped Screw	17-82
H0062172	Holder - Feed Out Spring	17-14
H0062173	Stripper Release Spring	17-13
H0062174	Thermostat Case	17-53
H0062176	Exit Interlock Lever	17-11
H0062180	Fusing Gear - T35	17-62
H0062181	Idle Gear - T19	17-64
H0062182	Exit Gear - T19	17- 8
H0062190	Fusing Entrance Mylar	17-51
H0062192	Upper Fusing Stay Ass'y	17-52
H0062203	Front Bracket - Paper Feed	15-43
H0062211	Lens Block Stay	11-31
H0062214	Settle Plate - Harness/Solenoid	15-67

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0062216	Inner Cover - Lens Block	11-19
H0062219	NCU Shield	11-11
H0062220	Inner Cover Bracket	11-18
H0062223	Bracket - Fan Drive Pulley (M)	17-43
H0062231	Rear Bracket - Paper Feed	15-96
H0062236	Interlock Fusing Lever	17-73
H0062237	Front Inner Cover - Fusing	17-75
H0062238	Upper Base Limiter	19- 6
H0062301	Development Drive Shaft	15-90
H0062302	Rear Bracket - Pressure Upper Base	15-87
H0062304	Op-Port Cover - Stay - FAX1000L	13-33
H0062307	DMU Clamp	13-32
H0062309	FCU Support - R102	13-58
H0062315	Rubber Foot	17-30
H0062316	Spacer - Pick-up Clutch	15-104
H0062317	Pick-up Lever	15-34
H0062318	Cover - Pick-up Roller Stay	15- 6
H0062319	Cassette Cover	21- 1
H0062320	Bottom Plate - Cassette Ass'y	21- 2
H0062322	Cassette	21- 5
H0062323	Pick-up Roller Bracket	15-22
H0062331	Front Fusing Bracket	17-70
H0062332	Rear Fusing Bracket	17-59
H0062333	Front LCT Stay	13-56
H0062334	Right FCU Shield	13-60
H0062335	Clamp - Development Inter Lock	13-61
H0062337	Adjustment Bracket - Sector Gear	15-107
H0062338	Pressure Spring	17-66
H0062339	Inlet Base	19-36
H0062339	Inlet Filter	19-37
H0062340	Front Inlet Base	19-51
H0062341	Bracket - Fan Drive Pulley (S)	17-42
H0062344	Fan Drive Pulley - M Ass'y	17-85
H0062345	Fan Drive Pulley - Middle	17-39
H0062348	Registration Mylar	15-36

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0062349	Lower Guide Plate Ass'y	15-35
H0062371	Paper Guide Pad	15-99
H0062381	Toner Overflow Sensor Ass'y	7-28
H0062382	Bushing - Registration	15-109
H0062383	Snap Ring - Registration	11-65
H0062383	Snap Ring - Registration	15-108
H0062400	Development Antistatic Brush	11-42
H0062401	Hopper Agitator	11-34
H0062404	Toner Supply Roller Ass'y	11-35
H0062407	Toner End Lever	11-58
H0062409	Toner Metering Blade Ass'y	11-39
H0062412	OBV Seal	11-38
H0062413	Blade Seal	11-37
H0062418	Antistatic Brush Cover	11-41
H0062419	Agitator Idle Gear	11-57
H0062420	Rear Development Cover	11-59
H0062428	Agitator Gear	11-49
H0062429	Sleeve Gear	11-55
H0062431	Sleeve Idle Gear	11-53
H0062432	Toner Supply Gear	11-54
H0062433	Front Development Gear	11-56
H0062437	Developing Roller	11-33
H0062438	Front Side Plate - Development	11-43
H0062443	Rear Side Plate - Development	11-51
H0062450	Transfer Charger Ass'y	13- 3
H0062451	Housing - Transfer Charger	13- 4
H0062453	Transfer Ventilate Guide	13- 1
H0062454	Ventilate Guide Mylar	13- 2
H0062455	Rubber Foot Plate	17-32
H0062456	Transfer Guide Spring	13-53
H0062457	Spring Holder	7-58
H0062458	FCU Cable Duct	13-23
H0062459	UIB Harness Clamp	13-24
H0062460	Maintenance Cover - P.P.	13-42
H0062462	Right Base Stay	13-38

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0062464	AC Line Cover	19-44
H0062467	Bracket - Interlock Switch Connector	13-25
H0062468	Edging - Scanner Motor Bracket	19-52
H0062471	Fan Belt Tightener	19-21
H0062472	Tighter Roller - M16	19-24
H0062473	Front Spring Plate - Fan Motor	17-33
H0062475	Main Motor Cover Ass'y	19-20
H0062477	Guide Plate - Fusing Front Ass'y	17-21
H0062478	Bushing - Fan Motor	15-100
H0062479	Tightner Spring	19-23
H0062490	Lower Fusing - Guide Plate	17-67
H0062506	Synchronize Holder	7-18
H0062507	Mirror	9-41
H0062508	First Synchronize Mirror	9-49
H0062509	Second Synchronize Mirror	9- 6
H0062510	First Cylindrical Lens	9- 8
H0062511	Document Table Bracket	7-60
H0062512	Second UIB Cover	7- 3
H0062513	Holder - Second Synchronize Mirror	9- 5
H0062518	Top F - Lens Holder	9- 2
H0062524	Seal - OBM Motor	7-73
H0062525	F - Lens Bracket	9- 1
H0062528	Front FL. Inner Cover	5-46
H0062530	Lock Pin Collar - Upper Base	15-42
H0062531	Inner Cover - Document Table	5-71
H0062536	Front Inner Cover	7-22
H0062552	Inner Cover - Scanner Cover - 1	5-62
H0062553	Inner Cover - Scanner Cover - 2	5-58
H0062554	Holder - First Synchronize Mirror	9-48
H0062556	Front F - Lens Holder	9-46
H0062557	Second Cylindrical Lens Ass'y	7-21
H0062670	Fusing Lamp - 115V/410W	17-47
H0062677	Rear End Block - Charge	9-21
H0062678	Front End Block - Charge	9-25
H0062679	Charge Wire Hook	9-19

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0062681	Front End Cover - Charge	9-26
H0062683	Front End Block - T. Charge	13- 9
H0062684	Front End Cover - T. Charge	13- 8
H0062687	Rear End Block - T. Charge	13-12
H0062688	Rear End Cover - T. Charge	13- 6
H0062689	Cleaning Pad	3-47
H0063051	Tightner - Master Belt Ass'y	7-44
H0063058	Bracket - H.P Sensor Ass'y	7-25
H0063072	Printer Fan Ass'y	17-34
H0063200	Rear Frame Bracket	19- 7
H0063206	Dumper Gear	19- 5
H0063209	Dumper Gear Angle	19- 8
H0063210	Upper Base Lock Hook	19- 3
H0063211	Upper Base Lock Spring	19- 4
H0063212	Fulcrum Bar - Upper Base Rear	7-30
H0063218	Front Frame Bracket	17-27
H0063221	Interlock Switch Bracket	13-21
H0063224	Op-Port Cover	13-20
H0063225	Left Op-Port Cover	13-15
H0063226	Fulcrum - Upper Base Front	7-27
H0063229	Frame Stay	17-80
H0063241	Washer - Middle Pulley	15-103
H0063241	Washer - Middle Pulley	17-83
H0063243	Ozone Filter	17-37
H0063244	Modular Jack Bracket	19- 2
H0063245	Center Base Stay	13-39
H0063246	Rear Frame Bracket Cover	19-10
H0063247	Rear Fusing Bracket	17-60
H0063248	Front Fusing Bracket	17-49
H0063249	Fusing Earth Plate	19-27
H0063250	Lever - Upper Base Interlock	7-26
H0063251	Left Base Stay	17-31
H0063252	Main Motor Harness Clamp	17-28
H0063255	MJ Harness Clamp	11- 9
H0063256	NCU Earth Plate	19-31

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0063257	FCU Shield	13-36
H0063262	Modem Clamp	13-35
H0063267	AC Line Cover	17-19
H0063268	NCU Cover	11-17
H0063269	Upper Base Guide	11- 7
H0063270	Lever - Development Cover Open	11-14
H0063271	Interlock Fusing Roller	17-72
H0063275	Interlock Fusing Spring	17-74
H0063276	Interlock Fusing Cover	17-81
H0063279	Spring Clamp - Pressure Upper Base	15-40
H0063280	Spring - Pressure Upper Base	15-39
H0063281	Rear Guide Rail - Development	15-93
H0063282	Front Lock Pin - Upper Base	15-44
H0063285	Front Guide Rail - Development	15-38
H0063286	Development Bias Terminal	15-37
H0063287	Bracket - Front Pressure Upper Base	15-41
H0063288	Bias Block - Main Charger	13-43
H0063299	Right Stay - Op-Port	13-37
H0063300	Rear Stopper - Transfer Charger	13-57
H0063301	Front Stopper - Transfer Charger	13-14
H0063302	Earth Plate - Paper Feed	13-44
H0063307	Bracket - SCN Motor Connector	19-32
H0063309	Setscrew - SCN Motor Connector	19-35
H0063310	Spring - SCN Motor Connector	19-33
H0063311	Stay - Modular Jack Harness	11- 8
H0063312	Transfer Pressure Spring	13-13
H0063326	DRU Cover	13-52
H0063331	Inlet Cover	19-42
H0063334	Harness Cover - Fan Motor	15-88
H0063335	Harness Clamp - SCN Motor	19-29
H0063336	Small Clamp	11-61
H0063338	FCU Support	13-22
H0063341	Op-Port Setscrew	3-19
H0063342	Left Bracket - Op-Port	3- 8
H0063345	Right Set Plate - Op-Port	3- 7

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0063346	Rear PSU Bracket	17-26
H0063350	Main Drive Belt - S3M	19-22
H0063351	Idle Gear - T441T16	19-12
H0063352	Fusing Idle Gear - T33	19-11
H0063353	Transport Bracket	19-14
H0063356	Main Drive Idler - T51	19-15
H0063357	Main Drive Gear - T23	19-16
H0063358	Main Drive Shaft	19-18
H0063359	Main Drive Pulley	19-19
H0063363	Front Bracket - Transfer Fan	13-54
H0063364	Spring - Transport Fusing Bracket	19-13
H0063365	Rear Bracket - Transfer Fan	13-46
H0063366	Development Drive Gear - T24	15-91
H0063368	Tightner	19-26
H0063372	Belt Pulley	15-82
H0063374	Fan Drive Pulley - Small	17-38
H0063376	Fan Drive Pulley - Large	19-47
H0063377	Fan Drive Belt	19-48
H0063380	Master Drive Belt	9-40
H0063381	Master Drive Bracket	7-43
H0063384	Idle Gear - Master Drive - T20	7-45
H0063385	Pulley - OBM Drive	9-38
H0063388	Master Drive Shaft	9-34
H0063389	Master Drive Gear - T16	9-32
H0063390	Master Drive Arm	9-33
H0063393	Master Drive Gear - T23	9-35
H0063398	Arm Bushing - Master Drive	9-50
H0063399	DRU Clamp	13-45
H0063402	Dumper	7-41
H0063405	Rear OBM Rail	7-59
H0063406	Front OBM Rail	7-33
H0063407	Bias Terminal - Main Charge	7-31
H0063408	Upper Base Hook	7-65
H0063409	Front Hook Pin	7-66
H0063415	Reinforce Plate - Front	7-14

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0063416	Reinforce Plate - Rear	9-36
H0063419	Earth Plate - Main Charge	9-30
H0063420	Master Earth Plate	7-34
H0063421	Pressure Arm - Drive Pulley	7-29
H0063425	First UIB Cover	7- 1
H0063427	Fusing Interlock Cover	7-11
H0063428	Net LDDR	7-16
H0063431	PMDR Connector Bracket	7-57
H0063432	SMDR Shield Cover	9-15
H0063436	PMDR Harness Seal	7- 8
H0063437	Harness Seal - FCU/UIB	7- 7
H0063438	Hook Spring	7-67
H0063439	Main Charger Duct	9-27
H0063440	Master Unit Interlock	9-18
H0063444	Varistor	9-31
H0063446	Upper Base Hadler	7-61
H0063447	Earth Plate - Upper Base/Base	9-16
H0063451	Housing Charge Ass'y	9-24
H0063453	Under Holder - Second Cy. Lens	9-28
H0063456	Support Strip - Cover - UIB	7- 2
H0063458	Main Charger	9-37
H0063459	Fusing Interlock Spring	7-10
H0063460	Pressure Arm Spring	7-32
H0063468	Dumper Spring	7-37
H0063475	Idler Dumper Gear	7-38
H0063480	Idler Bracket Ass'y	7-40
H0063483	Inner Cover - LD Unit	9-29
H0063484	Inner Cover - FL Stabilizer	9-17
H0063485	Harness Inner Cover	9-10
H0063486	Side Inner Cover	7-62
H0063492	Rear Inner Cover	7-56
H0063493	Inner Cover - Side - Under	7-63
H0063508	Pawl - Shaft Paper Feed	15-16
H0063509	Paper Lift Lever	15-11
H0063512	Pawl Stepped Screw	15-15

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0063513	Pawl Spring	15-14
H0063514	Boss - Paper Feed Shaft	15-13
H0063515	Paper Lift Pulley	15-10
H0063516	Feed Clutch Sleeve - 36T	15- 8
H0063517	Clutch Spring - Paper Feed	15- 9
H0063518	Clutch Hub - Paper Feed	15- 7
H0063519	Pick-up Cam	15-19
H0063523	Pick-up Bracket Spring	15-21
H0063530	Idle Gear - 15T	15-28
H0063531	Pick-up Roller	15-24
H0063532	Feed Roller	15-29
H0063533	Snap Ring	15-27
H0063541	Stopper Bracket	15-69
H0063545	Release Lever - Paper Lift	15-70
H0063549	Release Spring - Paper Lift	15-71
H0063550	Ratchet Paw Pin	15-75
H0063551	Stopper Pawl	15-68
H0063552	Ratchet Spring	15-74
H0063553	Paper Lift Shaft	15-47
H0063554	Sector Gear - Paper Lift	15-78
H0063556	Sector Gear Spring	15-77
H0063557	Sector Gear Bracket	15-79
H0063558	Sector Gear Lock	15-80
H0063559	Tray Lift Arm	15-48
H0063560	Paper Feed Guide	15-54
H0063565	Separation Roller Shaft	15-59
H0063566	Friction Roller	15-60
H0063567	Torque Limitter Clutch	15-61
H0063568	Torque Limitter Cover	15-62
H0063569	Torque Limitter Spring	15-63
H0063570	Friction Roller Stopper	15-64
H0063571	Friction Roller Bracket	15-58
H0063572	Friction Roller Shaft	15-57
H0063573	Friction Roller Spring	15-56
H0063574	Front Cassette Guide	15-45

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0063575	Rear Cassette Guide	15-65
H0063579	Stay - Paper Sensor Board	11- 3
H0063586	Registration Roller	15-30
H0063587	Spring - Upper Guide Plate	15-25
H0063588	Hold Spring - Upper Guide Plate	15-31
H0063591	Lower Registration Roller	15-46
H0063592	Registration Electromagnetic Clutch	15-86
H0063593	Registration Drive Bracket	15-81
H0063596	Registration Shaft	15-85
H0063597	Registration Clutch Gear	15-84
H0063598	Registration Drive Pulley	15-83
H0063599	Registration Stopper	19-30
H0063600	Mylar - Feed	11- 6
H0063601	Pulley Washer	15-12
H0063603	Front Transfer Guide Plate	15- 2
H0063604	Adjust Plate - Guide Transfer Rear	15-95
H0063605	Guide Plate - Transfer Charger	15- 1
H0063606	Pin - Transfer Guide	15-94
H0063607	Release Pin Slider	15-73
H0063610	Bracket - Main Drive Pulley	19-45
H0063611	Clutch Hub - P	15-97
H0063612	Clutch Spring - Pulley	15-18
H0063616	Mylar - Lower Guide Plate	15-98
H0063623	Paper Sensor Sheet	11- 2
H0063635	Fulcrum Pin - Pick-up Ass'y	15-101
H0063638	Paper Size Detector Pin - B4	21- 3
H0063640	Paper Size Detector Pin - Legal	21- 3
H0063642	Paper Size Detector Pin - Letter	21- 3
H0063644	Mylar Seal - Transfer Entrance	15- 3
H0063645	Front Stay - Feed Shaft	15-102
H0063646	Pick-up Roller Holder	15-23
H0063647	Feed Roller Shaft	15-20
H0063648	Pick-up Roller Stay	15- 5
H0063660	Cover - Development Interlock	15-51
H0063661	Cover - Paper Sensor	11- 4

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0063663	Cassette Decal	21- 6
H0063665	Front Side Fence	21- 4
H0063666	Rear Side Fence	21- 9
H0063671	Friction Roller Bracket	15-55
H0063690	Lever - Upper Base Open Ass'y	11-13
H0063693	Roller - Upper Base Open	11-63
H0063694	Earth Plate - NCU	19-50
H0063696	Rear Spring Plate - Fan Motor	17-36
H0063702	Spring - Transport Fusing Bracket	11-12
H0063751	Master Interlock Lever	15- 4
H0063754	Master Interlock Support	15-106
H0063755	Master Interlock Spring	15-105
H0063756	Master Lock Slider	7-76
H0063757	Sector Gear - Master Lock	7-75
H0063758	Slider Spring	7-77
H0063759	Clear Copy Decal	7-23
H0063760	OBM Decal	7-64
H0063761	Upper Base Cover	7- 9
H0063780	Upper Base	7-35
H0063784	FL. Rear Inner Cover	5-70
H0064102	Right Cover Pin	3-41
H0064104	Front Exit Cover	3-12
H0064105	Rear Exit Cover	3-20
H0064106	Front Bracket - Right Cover	3-42
H0064109	Rear Bracket - Right Cover	3-46
H0064112	Document Guide Gear	3-17
H0064113	Right Cover Spring	3-43
H0064114	Right Cover Bracket	3-39
H0064117	Right Cover Knob	3-44
H0064119	Right Cover Lever	3-45
H0064120	Document Guide Ruck	3-18
H0064121	NCU Cover	3-33
H0064122	Operation Manual Holder	3-30
H0064123	Upper Right Cover	3-36
H0064124	Handset Holder	3-28

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0064126	Handset Holder Cover	3-29
H0064127	Rear Document Guide	3-25
H0064128	Fun Motor Nut	19-43
H0064129	Document Guide Base	3-21
H0064130	Upper Exit Cover	3- 4
H0064133	Document Table	3-24
H0064135	Fan Motor Duct	19-41
H0064141	Upper Cover Plate	3-38
H0064142	Speaker Bracket	3-14
H0064146	Right Cover Ass'y	3-40
H0064149	Bracket - Development Inner Cover	11-44
H0064152	Button - Upper Base Open	11-10
H0064154	Operation Panel	3- 9
H0064165	Mylar - Lens Block Stay	11-30
H0064166	Fusing Inner Cover Ass'y	17-78
H0064167	Protect - Front Document Guide	3-23
H0064168	Protect - Rear Document Guide	3-26
H0064169	Screw Holder - Upper Cover	3-34
H0064170	Fulcrum Pin Bracket - Right Cover	3-54
H0064171	Cushion - Development Inner Cover	11-64
H0064198	Copy Tray	3-16
H0064202	Rear Cover	3-31
H0064242	Op-Port Cover - FAX1000L	3- 5
H0064243	Decal - NCU Cover	3-32
H0064244	Front Document Guide	3-22
H0064247	Toner Replacement Decal	3-37
H0064249	Speed Dial List	5- 2
H0064252	Caution Decal - PSU	17-35
H0064254	Operation Manual	3- *
H0064256	Stepped Screw - Development Cover	11-47
H0064257	Screw - Development Inner Cover	11-45
H0064258	Development Inner Cover	11-46
H0064299	Front Cover Ass'y	3-13
H0064390	Base	19-28
H0064394	LCT Connector Cover	17-29

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0064624	Bracket - Sub Document Table	3-55
H0064627	Sub Document Table	3-50
H0064931	Op-Port Cover - FAX1010L	3- 5
H0064934	Operation Manual	3- *
H0064945	Op-Port Cover - Stay - FAX1010L	13-33
H0064946	Quick Reference Guide	3- *
H0065000	Harness - VPU	11-20
H0065001	Harness - NCU	11-15
H0065003	Harness - Toner Sensor	11-29
H0065007	Harness - Paper Sensor	11- 5
H0065008	Harness - Cassette Size Sensor	15-52
H0065009	Harness - LIB/P1	13-31
H0065010	Harness - LIB/SW1	13-30
H0065011	Harness - Power Pack	13-40
H0065012	Harness - PSU - P	17-22
H0065013	Harness - PSU - S	17-23
H0065014	Harness - Main Motor	19-49
H0065015	Harness - SBU	11-27
H0065019	Harness - LSD	7-20
H0065020	Harness - Master Sensor	7-68
H0065021	Harness - LDDR	9-44
H0065022	Harness - FL Stabilizer	9-14
H0065031	Harness - Main Switch	19-39
H0065032	Harness - Pentagonal Motor	9-12
H0065033	Harness - Toner Overflow Sensor	7-69
H0065042	Earth Wire - T. Charge	13- 5
H0065043	Harness - Scanner Motor - Relay	19-34
H0065047	Harness - Interlock Switch	13-18
H0065050	Harness - Interlock	13-19
H0065051	Harness - Development Switch	15-50
H0065052	Earth Wire - Scanner	5- 7
H0065058	Harness - DRU	13-48
H0065060	Harness - Solenoid	13-50
H0065074	Harness - UIB	7- 5
H0065075	Harness - Paper Feed	13-51

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0065200	Pentagonal Mirror Motor	9- 9
H0065202	Driver - Pentagonal Mirror Motor	9-13
H0065203	Eraser Ass'y	7-12
H0065205	Hight Voltage Cord - C	9-20
H0065207	Paper Sensor Ass'y	11- 1
H0065208	Toner Empty Sensor	11-28
H0065211	Modular Jack	19- 1
H0065213	Stamper Ass'y	5-68
H0065214	ADF Clutch	5-85
H0065215	FL Stabilizer	9-11
H0065217	Fluorescent Lamp	5-50
H0065220	Main Motor	19-46
H0065221	Master Belt Motor	7-42
H0065222	Power Pack	13-41
H0065223	Main Switch	19-38
H0065224	Front Transfer Fan	13-55
H0065225	Rear Transfer Fan	13-47
H0065226	Push Switch Ass'y	13-16
H0065227	Development Clutch	15-89
H0065230	Monitor Speaker	3-15
H0065232	Master Belt Fan Motor	19-40
H0065234	Scanner Stepping Motor	7-15
H0065241	Fusing Thermister	17-57
H0065243	Fusing Connector	17-58
H0065244	Harness - Fusing/Thermostat	17-55
H0065245	Thermostat Ass'y	17-54
H0065306	Hand Set : HAC	3-27
H0065600	PSU Ass'y - USA	17-25
H0066001	PCB - LSD	7-19
H0066010	PCB - MIF - JAPAN/USA	13-28
H0066011	PCB - DSB	5-77
H0066017	PCB - SBU	11-25
H0066018	PCB - DMU-1 - FAX1000L	13-27
H0066023	PCB - FCU	13-26
H0066027	PCB - DRU	13-49

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
H0066029	PCB - UIB	7- 6
H0066030	PCB - AANCU - USA	11-16
H0066031	PCB - MBU - USA - FAX1000L	13-34
H0066032	PCB - Op-Port	3- 6
H0066072	PCB - DMU-1 - FAX1010L	13-27
H0066100	PCB - MBU - USA - FAX1010L	13-34
H0082303	Cover - Second Cy. Lens Ass'y	7-24
H0085207	Copy Out Sensor	17-48
H0126038	V96F Modem - New Type	13-29
H0156029	PCB - VPU	11-21
N6017048	PCB - PSU	17-24

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
AA143047	Stepped Screw - M3	7-39
AW500001	Push Switch - Paper Size 1	15-53
G0001945	LSD Cylindrical Lens	7-17

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
50520269	Bushing - M4.2	17-216
50530447	Bushing - M6	5-216
50530447	Bushing - M6	15-215
52032060	Stopped Screw - Charger	9-22
52032060	Stopped Screw - Charger	13-11
52032611	Leaf Spring - 6 mm	5-53
52032613	Bushing - 6 x 10 x 10 mm	5-52
52033105	Nylon Rivet	11-40
52033127	Toner End Spring	11-48
52033130	Toner End Disk	11-50
52033151	Roller Cover Spring	11-60
52034179	Caution Decal - High Temperature	17- 3
52039001	Corona Wire (10 pcs)	9-23
52039001	Corona Wire (10 pcs)	13-10
52141221	Rubber Foot - Fan Motor	17-20
52141221	Rubber Foot - Fan Motor	19- 9
52163095	Mylar - Toner Supply Roller	11-36
53531265	Decal - Laser	7-70
54131882	Stepped Screw	7-72
54131882	Stepped Screw	19-25
54134835	Decal - Paper Level	21- 8
54472681	Snap Ring	5-78
54472768	Stepped Screw - M3	15-72
54472941	Rear Fence	21- 7
54663198	Washer - SBU	11-62
54715602	Power Cord	3-49
54741140	Bushing - Pressure Roller	15-26
54747287	Modular Code - 6P - 8P	3-48

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
031300308	Philips Pan Head Screw - M3 x 3	5-202
031300308	Philips Pan Head Screw - M3 x 3	11-200
031300308	Philips Pan Head Screw - M3 x 3	15-200
031300408	Philips Pan Head Screw - M3 x 4	5-200
031300408	Philips Pan Head Screw - M3 x 4	7-200
031300408	Philips Pan Head Screw - M3 x 4	11-201
031300408	Philips Pan Head Screw - M3 x 4	13-200
031300408	Philips Pan Head Screw - M3 x 4	17-200
031300508	Philips Pan Head Screw - M3 x 5	5-201
031300508	Philips Pan Head Screw - M3 x 5	7-201
031300508	Philips Pan Head Screw - M3 x 5	9-209
031300508	Philips Pan Head Screw - M3 x 5	11-202
031300508	Philips Pan Head Screw - M3 x 5	15-201
031300508	Philips Pan Head Screw - M3 x 5	17-201
031300608	Philips Pan Head Screw - M3 x 6	3-200
031300608	Philips Pan Head Screw - M3 x 6	5-204
031300608	Philips Pan Head Screw - M3 x 6	7-202
031300608	Philips Pan Head Screw - M3 x 6	9-200
031300608	Philips Pan Head Screw - M3 x 6	11-203
031300608	Philips Pan Head Screw - M3 x 6	15-202
031300608	Philips Pan Head Screw - M3 x 6	17-202
031300608	Philips Pan Head Screw - M3 x 6	19-200
031300808	Philips Pan Head Screw - M3 x 8	5-203
031300808	Philips Pan Head Screw - M3 x 8	17-203
031301008	Philips Pan Head Screw - M3 x 10	19-203
031301608	Philips Pan Head Screw - M3 x 12	9-203
031302008	Philips Pan Head Screw - M3 x 20	15-219
031302508	Philips Pan Head Screw - M3 x 25	13-201
031400608	Philips Pan Head Screw - M4 x 6	7-203
031400608	Philips Pan Head Screw - M4 x 6	15-203
031400808	Philips Pan Head Screw - M4 x 8	13-204
031400808	Philips Pan Head Screw - M4 x 8	17-204
031400808	Philips Pan Head Screw - M4 x 8	19-201
031401008	Philips Pan Head Screw - M4 x 10	7-206
03230060	Philips Sunk Screw - M3 x 6	19-210

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
03230060B	Philips Sunk Screw - M3 x 6	3-204
03430050Z	Philips Truss Head Screw - M3 x 5	7-211
03430060Z	Philips Truss Head Screw - M3 x 6	9-206
03430080Z	Philips Truss Head Screw - M3 x 8	3-205
03530050	Philips Truss Head Screw - M3 x 5	19-211
03530050B	Philips Truss Head Screw - M3 x 5	5-210
04430102B	Hexagon Head Tapping Screw - M3 x 8	9-205
05330030Z	Hexagon Headless Set Screw - M3 x 3	15-209
05330040E	Hexagon Headless Set Screw - M3 x 4	5-211
05330040Z	Hexagon Headless Set Screw - M3 x 4	15-210
05730040E	Hexagon Headless Set Screw - M3 x 4	11-210
07050040B	Bushing - M4 x 5	19-212
07100030B	Flat Washer - M3	7-217
07200025E	Retaining Ring - M2.5	5-212
07200025E	Retaining Ring - M2.5	7-216
07200025E	Retaining Ring - M2.5	17-213
07200030E	Retaining Ring - M3	5-213
07200030E	Retaining Ring - M3	7-212
07200030E	Retaining Ring - M3	11-212
07200030E	Retaining Ring - M3	15-211
07200030E	Retaining Ring - M3	17-212
07200030E	Retaining Ring - M3	19-206
07200040E	Retaining Ring - M4	5-214
07200040E	Retaining Ring - M4	7-213
07200040E	Retaining Ring - M4	9-207
07200040E	Retaining Ring - M4	11-213
07200040E	Retaining Ring - M4	15-212
07200040E	Retaining Ring - M4	17-214
07200050E	Retaining Ring - M5	5-215
07200050E	Retaining Ring - M5	7-214
07200050E	Retaining Ring - M5	9-208
07200050E	Retaining Ring - M5	15-213
07200050E	Retaining Ring - M5	17-218
07200050E	Retaining Ring - M5	19-207
07200060E	Retaining Ring - M6	7-215

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
07200060E	Retaining Ring - M6	11-214
07200060E	Retaining Ring - M6	15-214
07200060E	Retaining Ring - M6	17-215
07200060E	Retaining Ring - M6	19-208
07250200B	Retaining Ring - C20	17-217
08011167	Double Sens Screw - M3 x 8	11-208
08050062	Blind Screw - M4 x 6	5-217
08053145	Ball Bearing - 6 x 12 x 4 mm	17-211
08053162	Ball Bearing - 10 x 19 x 7 mm	11-215
08074009	Washer - 5.2 x 11 x 0.3	17-219
08091013	Nylon Wire	13- 7
08530061Z	Bolt - M3 x 6	17-210
09513004B	Philips Screw with Flat Washer - M3 x 4	17-207
09513005B	Philips Screw with Flat Washer - M3 x 5	3-201
09513005B	Philips Screw with Flat Washer - M3 x 5	5-205
09513005B	Philips Screw with Flat Washer - M3 x 5	7-204
09513005B	Philips Screw with Flat Washer - M3 x 5	11-204
09513005B	Philips Screw with Flat Washer - M3 x 5	13-202
09513005B	Philips Screw with Flat Washer - M3 x 5	15-205
09513005B	Philips Screw with Flat Washer - M3 x 5	17-205
09513006B	Philips Screw with Flat Washer - M3 x 6	3-202
09513006B	Philips Screw with Flat Washer - M3 x 6	5-206
09513006B	Philips Screw with Flat Washer - M3 x 6	7-205
09513006B	Philips Screw with Flat Washer - M3 x 6	9-201
09513006B	Philips Screw with Flat Washer - M3 x 6	11-205
09513006B	Philips Screw with Flat Washer - M3 x 6	13-203
09513006B	Philips Screw with Flat Washer - M3 x 6	15-204
09513006B	Philips Screw with Flat Washer - M3 x 6	17-206
09513006B	Philips Screw with Flat Washer - M3 x 6	19-202
09513008B	Philips Screw with Flat Washer - M3 x 8	3-203
09513008B	Philips Screw with Flat Washer - M3 x 8	5-207
09513008B	Philips Screw with Flat Washer - M3 x 8	7-207
09513008B	Philips Screw with Flat Washer - M3 x 8	9-202
09513008B	Philips Screw with Flat Washer - M3 x 8	11-206
09513008B	Philips Screw with Flat Washer - M3 x 8	13-205

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.
09513008B	Philips Screw with Flat Washer - M3 x 8	15-218
09513008B	Philips Screw with Flat Washer - M3 x 8	17-208
09513010B	Philips Screw with Flat Washer - M3 x 10	5-208
09513010B	Philips Screw with Flat Washer - M3 x 10	17-209
09513012B	Philips Screw with Flat Washer - M3 x 12	13-206
09513020B	Philips Screw with Flat Washer - M3 x 8	9-204
09514006B	Philips Screw with Flat Washer - M4 x 6	13-207
09514006B	Philips Screw with Flat Washer - M4 x 6	19-204
09514008B	Philips Screw with Flat Washer - M4 x 8	11-207
09514008B	Philips Screw with Flat Washer - M4 x 8	19-205
09514016B	Philips Screw with Flat Washer - M4 x 16	15-207
09543014	Double Sens Screw - M3 x 14	11-209
09544008B	Double Sens Screw - M4 x 8	11-211
09544012B	Double Sens Screw - M4 x 12	15-206
09573012B	Double Sens Screw - M3 x 12	15-217
09653006B	Tapping Screw with Flat Washer - M3 x 6	7-208
09653006B	Tapping Screw with Flat Washer - M3 x 6	13-208
09653006B	Tapping Screw with Flat Washer - M3 x 6	15-208
09653008B	Tapping Screw with Washer - M3 x 8	5-209
09653008B	Tapping Screw with Washer - M3 x 8	7-209
09653008B	Tapping Screw with Washer - M3 x 8	13-209
09653008B	Tapping Screw with Washer - M3 x 8	19-209
09653012B	Tapping Screw with Washer - M3 x 12	7-210
09654008W	Tapping Screw with Washer - M4 x 8	21-200
11050106	Wire Saddle	15-216
11050108	Wire Saddle - WS-ENS	13-210
12041280	Push Switch	13-17
12041603	Push Switch	15-49

PARTS NO.	DESCRIPTION	PAGE AND INDEX NO.