

PARTS CATALOG

FOR

PAPER FEED UNIT

TYPE 1000L

PARTS CATALOG

INTRODUCTION


This chapter instructs you the numbers and names of the parts on this machine.

INDEX to PARTS CATALOG

Section 1. Parts Location and List

1. Paper Feed Unit I	2- 2
2. Paper Feed Unit II	2- 4
3. Paper Feed Unit III	2- 6
4. Cassette	2- 8
Section 2. Parts Index	2-10

1. PAPER FEED UNIT I




1. PAPER FEED UNIT

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 2910	Left Cover	Except F F
2	H006 2912	Lower Harness Cover	
3	H006 2932	Joint Bracket - Front Left	
4	H006 2904	Left Hinge - Front Cover	
5	H006 2902	Front Left Bracket - Support Cover	
6	H006 2937	Upper Harness Cover	
7	H006 2906	Left Inner Cover	
8	H006 2945	Front Cover Magnet	
9	H006 2905	Right Inner Cover	
10	H006 2690	Front Cover	
11	H006 2675	Jam Removal Decal	
11	H008 2455	Jam Removal Decal :F	
12	H006 2901	Front Right Bracket - Support Cover	
13	H006 2903	Right Hinge - Front Cover	
15	H006 2909	Right Cover	
17	H006 2812	Rear - Support	
18	H006 2908	Rear Cover	
19	H006 2934	Joint Bracket - Rear Left	
20	H006 2938	Joint Bracket - Front Right	
21	H006 2711	Installation Manual :E	

INDEX	PART NO.	DESCRIPTION	MODEL
100	0313 0060B	Philips Pan Head Screw - M3 x 6	
101	0314 0060W	Philips Pan Head Screw - M4 x 6	
102	0802 5094	Philips Truss Head Screw - M4 x 8	
103	1105 0196	Wire Saddle - WS-INSV-O	

2. PAPER FEED UNIT II




2. PAPER FEED UNIT II

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 5038	Harness - Paper Lift Motor	
2	H006 2831	Paper Lift Motor	
3	H020 2932	Paper Lift Motor Bracket	
4	5447 2805	Slide Pin Holder	
5	H006 5255	Paper End Sensor - LCT	
6	H006 2845	Bracket - Near End Sensor	
7	H006 2840	Gear Slide Spring	
8	H006 2838	Gear - 55T/16T	
9	H006 2837	Gear - 60T/16T	
10	H006 2960	Gear - 64T	
11	H006 2959	Bushing - M5	
12	H020 2934	Gear Support Plate	
13	H006 2897	Feed Roller Mylar	
14	H006 2895	Feed Roller Guide	
15	5447 2681	Snap Ring	
16	5447 2723	Pick-up Roller	
17	5447 2726	Paper Feed Roller	
18	5447 2720	Gear - 18T	
19	5447 2706	Gear - 15T	
20	H006 2878	Feed Roller Arm - LCT	
21	H006 2881	Feed Roller Bracket - LCT	
22	H006 2873	One Way Gear - 24T	
23	H006 2871	Feed Roller Shaft - LCT	
24	0804 3002	Parallel Key	
25	H006 2325	Solenoid Bracket	
26	5447 2744	Spring - Paper Pick-up	
27	5447 2737	Cam Catcher	
28	5447 2745	Spring - Paper Feed	
29	5447 2743	Lever Spring	
30	H006 2324	Paper Feed Solenoid - LCT	
31	H006 3676	Cam - Pressure Release Ass' y	
32	5447 2751	Feed Roller Hub - Ratchet	
33	H006 2847	Ratchet Sleeve - PaPer Feed	
34	H000 2483	Spring Clutch	
35	H006 2824	Timing Pulley - 50T	
36	H006 2829	Timing Belt - 300L	
37	H006 2823	Belt Tension Roller	
38	H006 2957	Plate Spring - Belt Tension	

INDEX	PART NO.	DESCRIPTION	MODEL
39	H006 2821	Drive Motor Bracket	
40	H006 2826	Timing Pulley - 18T	
41	H006 5252	Drive Motor - LCT	
42	5447 2746	Spring - Paper Feed	
43	H006 3674	Pressure Release Lever	
44	H006 5028	Harness - Feed Motor	
45	H020 2845	End Detector Bracket - LCT	
46	H006 2869	End Detector Lever - LCT	
47	5205 5250	L.E.D. Sensor Type S	
48	H006 5029	Harness - Paper Sensor - LCT	
49	H006 2813	Right Stay	
50	H006 2948	LCT Spacer	
51	H006 2951	Front Guide Mylar	
52	H020 2842	Rear Guide Mylar	
53	H020 2843	Front Upper Guide Plate - Paper Feed	
54	H006 2872	Bushing - M8/M4	
55	H020 2840	Rear Upper Guide Plate - Paper Feed	
100	0313 0040W	Philips Pan Head Screw - M3 x 4	
101	0313 0060W	Philips Pan Head Screw - M3 x 6	
102	0314 0140W	Philips Pan Head Screw - M4 x 14	
103	0314 0040W	Philips Pan Head Screw - M4 x 4	
104	0314 0060W	Philips Pan Head Screw - M4 x 6	
105	0314 0080W	Philips Pan Head Screw - M4 x 8	
106	0314 0100W	Philips Pan Head Screw - M4 x 10	
107	0720 0040E	Retaining Ring - M4	
108	0720 0050E	Retaining Ring - M5	
109	0720 0060E	Retaining Ring - M6	
110	1105 0196	Wire Saddle - WS-INSV-O	
111	0584 0061W	Bolt - M4 x 6	
112	5053 0223	Bushing -8 mm	
113	1105 0005	Nylon Clip - 3N	
114	0324 0060G	Philips Sunk Screw - M4 x 6	
115	0313 0040B	Philips Pan Head Screw M3 x 4	

3. PAPER FEED UNIT III




3. PAPER FEED UNIT III

INDEX	PART NO.	DESCRIPTION	MODEL
1	H006 5027	LIB Harness - S2	
2	H006 5026	LIB Harness - P2	
3	H006 6008	PCB - LIB	
4	H006 5254	Cover Sensor - LCT	
5	H006 2922	Cover Open Bracket - LCT	
6	H006 2802	Front Side Plate - LCT	
7	H006 2913	Edge Cover - LCT	
8	H006 2842	Paper Lift Lever	
9	H006 2921	Open Sensor Bracket - LCT	
10	H006 5251	Door Sensor - LCT	
11	H006 2854	Pin - Lever Cassette Detector	
12	H006 2851	Front Cassette Guide - Front	
13	H006 2855	Lever Spring - Cassette Detector	
14	H006 2853	Cassette Detector Lever	
15	H006 2818	Under Stay	
16	H006 2941	Rubber Foot - LCT	
17	H020 2931	LCT - Base	
18	H006 2955	Guide Plate Cushion	
19	H006 5061	Harness - LCT Cassette Sensor	
20	AW50 0001	Push Switch - Paper Size 1	
21	H006 2860	Separation Roller Cover - LCT	
22	H006 2861	Separation Shaft - LCT	
23	5447 2695	Input Hub	
24	H006 2235	Cylindrical Spring	
25	5447 2676	Output Hub	
26	5447 2678	Slip Clutch Cover	
27	5447 2693	Separation Roller	
28	5447 2681	Snap Ring	
29	H006 2893	Separation Cover	
30	H006 5062	Harness - LCT Cassette Sensor -2	
31	1204 1617	Cassette SW - LCT	
32	H006 2848	Cassette SW. Bracket	
33	H006 2844	Cushion - Paper Lift Arm	
34	H006 2967	Spring - Separation Roller	
35	H006 2966	Arm - Separation Roller	
36	H006 2856	Guide Plate - Paper Feed LCT	
37	H006 3672	Rear Side Plate - LCT	
38	H006 2852	Rear Cassette Guide - Rear	

INDEX	PART NO.	DESCRIPTION	MODEL
39	H006 2843	Pressure Arm - Paper Lift	
40	H006 2841	Paper Lift ShaFt	
41	H006 2874	Idle Gear - 16T	
42	H006 2887	Pressure Roller	
43	H006 2885	Shaft - Guide Plate Open	
44	H006 2890	Front Lock Spring - Guide Plate	
45	H006 2888	Locking Bracket - Guide Plate - F	
46	H006 2886	Release Lever - Guide Plate Guide	
47	5447 2751	Feed Roller Hub - Ratchet	
48	H006 2944	Roller Pressure Spring	
49	H006 2889	Locking Bracket - Guide Plate - R	
50	H006 2884	Guide Plate - Drive Roller	
51	H006 2882	Drive Roller	
52	H006 2875	Middle Roller Gear - 16T	
53	H006 2872	Bushing - M8/M4	
54	H006 2816	Left stay	
101	0313 0120W	Philips Pan Head Screw - M3 x 12	
102	0314 0040W	Philips Pan Head Screw - M4 x 4	
103	0314 0060W	Philips Pan Head Screw - M4 x 6	
104	0951 4008W	Philips Screw with Flat Washer - M4 x 8	
105	0965 4008W	Tapping Screw with Flat Washer - M4 x 8	
106	0720 0040E	Retaining Ring - M4	
107	0720 0080E	Retaining Ring - M8	
108	0720 0060E	Retaining Ring - M6	
109	5053 0223	Bushing -8 mm	
110	1105 0005	Nylon Clip - 3N	
111	0720 0030E	Retaining Ring - M3	

4. CASSETTE



4. CASSETTE

INDEX	PART NO.	DESCRIPTION	MODEL				
1	H020 4092	Cassette Cover :R					
2	H006 2972	Cassette Bottom Plate					
3	5447 2912	Bottom Plate Cushion					
4	H006 3641	Paper Size Detector Pin - A4					
4	H006 3638	Paper Size Detector Pin - B4					
6	H020 2823	Front Side Fence Ass'y					
7	H020 4332	Cassette - LCT :R					
8	H006 3663	Cassette Decal					
9	H006 2977	Paper Check Decal					
10	H006 2976	Rear Fence					
11	5413 4835	Decal - Paper Level					
12	H020 2828	Rear Side Fence					
13	H020 2829	Front Side Fence					
14	H020 2831	Front Paper Holder					
15	H020 2830	Rear Paper Holder					
16	5447 2927	Friction Pad - B					
200	0965 4008B	Philips Screw with Flat Washer - M4 x 8					
201	0720 0040E	Retaining Ring - M4					

PARTS INDEX

PARTS NO.	DESCRIPTION	MODEL	PAGE AND INDEX NO.
0313 0040B	Philips Pan Head Screw -M3x4		5-115
0313 0040W	Philips Pan Head Screw -M3x4		5-100
0313 0060W	Philips Pan Head Screw -M3x6		5-101
0313 0060B	Philips Pan Head Screw -M3x6		3-100
0313 0120W	Philips Pan HeadScrew -M3x12		7-101
0314 0040W	Philips Pan Head Screw - M4 x 4		5-103
0314 0040W	Philips Pan Head Screw - M4 x 4		7-102
0314 0060W	Philips Pan Head Screw - M4 x 6		3-101
0314 0060W	Philips Pan Head Screw - M4 x 6		5-104
0314 0060W	Philips Pan Head Screw - M4 x 6		7-103
0314 0080W	Philips Pan Head Screw - M4 x 8		5-105
0314 0100W	Philips Pan Head Screw - M4 x 10		5-106
0314 0140W	Philips Pan Head Screw - M4 x 14		5-102
0324 0060G	Philips Sunk Screw - M4 x 6		5-114
0584 0061W	Bolt - M4 x 6		5-111
0720 0030E	Retaining Ring - M3		7-111
0720 0040E	Retaining Ring - M4		5-107
0720 0040E	Retaining Ring - M4		7-106
0720 0040E	Retaining Ring - M4		9-201
0720 0050E	Retaining Ring - M5		5-108
0720 0060E	Retaining Ring - M6		7-108
0720 0060E	Retaining Ring - M6		5-109
0720 0080E	Retaining Ring - M8		7-107
0802 5094	Philips Truss Head Screw - M4 x 8		3-102
0804 3002	Parallel Key		5-24
0951 4008B	Philips Screw with Flat Washer - M4 x 8		9-200
0951 4008W	Philips Screw with Flat Washer - M4 x 8		7-104
0965 4008B	Philips Screw with Flat Washer - M4 x 8		9-200
0965 4008W	Tapping Screw with Flat Washer - M4 x 8		7-105
1105 0005	Nylon Clip - 3N		5-113
1105 0005	Nylon Clip - 3N		7-110
1105 0196	Wire Saddle - WS-INSV-O		3-103
1105 0196	Wire Saddle - WS-INSV-O		5-110
1204 1617	Cassette SW - LCT		7-31
5053 0223	Bushing -8 mm		5-112
5053 0223	Bushing -8 mm		7-109
5205 5250	L.E.D. Sensor Type S		5-47
5413 4835	Decal - Paper Level		9-11
5447 2676	Output Hub		7-25

PARTS NO.	DESCRIPTION	MODEL	PAGE AND INDEX NO.
5447 2678	Slip Clutch Cover		7-26
5447 2681	Snap Ring		5-15
5447 2681	Snap Ring		7-28
5447 2693	Separation Roller		7-27
5447 2695	Input Hub		7-23
5447 2706	Gear - 15T		5-19
5447 2720	Gear - 18T		5-18
5447 2723	Pick-up Roller		5-16
5447 2726	Paper Feed Roller		5-17
5447 2737	Cam Catcher		5-27
5447 2743	Lever Spring		5-29
5447 2744	Spring - Paper Pick-up		5-26
5447 2745	Spring - Paper Feed		5-28
5447 2746	Spring - Paper Feed		5-42
5447 2751	Feed Roller Hub - Ratchet		5-32
5447 2751	Feed Roller Hub - Ratchet		7-47
5447 2805	Slide Pin Holder		5-4
5447 2912	Bottom Plate Cushion		9-3
5447 2927	Friction Pad		) -16

PARTS NO.	DESCRIPTION	MODEL	PAGE AND INDEX NO.
AW50 0001	Push Switch - Paper Size 1		7-20

PARTS NO.	DESCRIPTION	MODEL	PAGE AND INDEX NO.
H000 2483	Spring Clutch		5-34
H006 2235	Cylindrical Spring		7-24
H006 2324	Paper Feed Solenoid - LCT		5-30
H006 2325	Solenoid Bracket		5-25
H006 2675	Jam Removal Decal		3-11
H006 2690	Front Cover		3-10
H006 2711	Installation Manual :E		3-21
H006 2802	Front Side Plate - LCT		7-6
H006 2812	Rear - Support		3-17
H006 2813	Right Stay		5-49
H006 2816	Left stay		7-54
H006 2818	Under Stay		7-15
H006 2821	Drive Motor Bracket		5-39
H006 2823	Belt Tension Roller		5-37
H006 2824	Timing Pulley - 50T		5-35
H006 2826	Timing Pulley - 18T		5-40
H006 2829	Timing Belt - 300L		5-36
H006 2831	Paper Lift Motor		5-2
H006 2837	Gear - 60T/16T		5-9
H006 2838	Gear - 55T/16T		5-8
H006 2840	Gear Slide Spring		5-7
H006 2841	Paper Lift Shaft		7-40
H006 2842	Paper Lift Lever		7-8
H006 2843	Pressure Arm - Paper Lift		7-39
H006 2844	Cushion - Paper Lift Arm		7-33
H006 2845	Bracket - Near End Sensor		5-6
H006 2847	Ratchet Sleeve - Paper Feed		5-33
H006 2848	Cassette SW. Bracket		7-32
H006 2851	Front Cassette Guide - Front		7-12
H006 2852	Rear Cassette Guide - Rear		7-38
H006 2853	Cassette Detector Lever		7-14
H006 2854	Pin - Lever Cassette Detector		7-11
H006 2855	Lever Spring - Cassette Detector		7-13
H006 2856	Guide Plate - Paper Feed LCT		7-36
H006 2860	Separation Roller Cover - LCT		7-21
H006 2861	Separation Shaft - LCT		7-22
H006 2869	End Detector Lever - LCT		5-46
H006 2871	Feed Roller Shaft - LCT		5-23
H006 2872	Bushing - M8/M4		7-53

PARTS NO.	DESCRIPTION	MODEL	PAGE AND INDEX NO.
H006 2872	Bushing - M8/M4		5-54
H006 2873	One Way Gear - 24T		5-22
H006 2874	Idle Gear - 16T		7-41
H006 2875	Middle Roller Gear - 16T		7-52
H006 2878	Feed Roller Arm - LCT		5-20
H006 2881	Feed Roller Bracket - LCT		5-21
H006 2882	Drive Roller		7-51
H006 2884	Guide Plate - Drive Roller		7-50
H006 2885	Shaft - Guide Plate Open		7-43
H006 2886	Release Lever - Guide Plate Guide		7-46
H006 2887	Pressure Roller		7-42
H006 2888	Locking Bracket - Guide Plate - F		7-45
H006 2889	Locking Bracket - Guide Plate - R		7-49
H006 2890	Front Lock Spring - Guide Plate		7-44
H006 2893	Separation Cover		7-29
H006 2895	Feed Roller Guide		5-14
H006 2897	Feed Roller Mylar		5-13
H006 2901	Front Right Bracket - Support Cover		3-12
H006 2902	Front Left Bracket - Support Cover		3-5
H006 2903	Right Hinge - Front Cover		3-13
H006 2904	Left Hinge - Front Cover		3-4
H006 2905	Right Inner Cover		3-9
H006 2906	Left Inner Cover		3-7
H006 2908	Rear Cover		3-18
H006 2909	Right Cover		3-15
H006 2910	Left Cover		3-1
H006 2912	Lower Harness Cover		3-2
H006 2913	Edge Cover - LCT		7-7
H006 2921	Open Sensor Bracket - LCT		7-9
H006 2922	Cover Open Bracket - LCT		7-5
H006 2932	Joint Bracket - Front Left		3-3
H006 2934	Joint Bracket - Rear Left		3-19
H006 2937	Upper Harness Cover		3-6
H006 2938	Joint Bracket - Front Right		3-20
H006 2941	Rubber Foot - LCT		7-16
H006 2944	Roller Pressure Spring		7-48
H006 2945	Front Cover Magnet		3-8
H006 2948	LCT Spacer		5-50
H006 2951	Front Guide Mylar		5-51

PARTS NO.	DESCRIPTION	MODEL	PAGE AND INDEX NO.
H006 2955	Guide Plate Cushion		7-18
H006 2957	Plate Spring - Belt Tension		5-38
H006 2959	Bushing - M5		5-11
H006 2960	Gear - 64T		5-10
H006 2966	Arm - Separation Roller		7-35
H006 2967	Spring - Separation Roller		7-34
H006 2972	Cassette Bottom Plate		9-2
H006 2976	Rear Fence		9-10
H006 2977	Paper Check Decal		9-9
H006 3638	Paper Size Detector Pin - B4		9-4
H006 3641	Paper Size Detector Pin - A4		9-4
H006 3663	Cassette Decal		9-8
H006 3672	Rear Side Plate - LCT		7-37
H006 3674	Pressure Release Lever		5-43
H006 3676	Cam - Pressure Release Ass' y		5-31
H006 5026	LIB Harness - P2		7-2
H006 5027	LIB Harness - S2		7-1
H006 5028	Harness - Feed Motor		5-44
H006 5029	Harness - Paper Sensor - LCT		5-48
H006 5038	Harness - Paper Lift Motor		5-1
H006 5061	Harness - LCT Cassette Sensor		7-19
H006 5062	Harness - LCT Cassette Sensor -2		7-30
H006 5251	Door Sensor - LCT		7-10
H006 5252	Drive Motor - LCT		5-41
H006 5254	Cover Sensor - LCT		7-4
H006 5255	Paper End Sensor - LCT		5-5
H006 6008	PCB - LIB		7-3
H008 2455	Jam Removal Decal :F	F	3-11
H020 2823	Front Side Fence Ass' y		9-6
H020 2828	Rear Side Fence Ass' y		9-12
H020 2829	Front Side Fence		9-13
H020 2830	Rear Paper Holder		9-15
H020 2831	Front Paper Holder		9-14
H020 2840	Rear Upper Guide Plate - Paper Feed		5-55
H020 2842	Rear Guide Mylar		5-52
H020 2843	Front Upper Guide Plate - Paper Feed		5-53
H020 2845	End Detector Bracket - LCT		5-45
H020 2931	LCT - Base		7-17
H020 2932	Paper Lift Motor Bracket		5-3

