

**Model L2a/L2b
(H914/H915)
PARTS CATALOG**

First edition, October 2006

Ricoh Company, LTD.

Release Information for RoHS-compliant

Model L2

Old Model Code	New Model Code	Item	Destination	RoHS Compliant	SERIAL NO.
H91427	H91467	220 – 240V, 50/60Hz	Europe	Yes	A4768720001 ~
H91429	H91469	220 – 240V, 50/60Hz	Asia	Yes	A4769040001 ~
H91425	H91465	220 – 240V, 50/60Hz	Oceania	Yes	A4768980001 ~
H91421	H91461	220 – 240V, 50/60Hz	China	Yes	A4700163683 ~
H91517	H91557	100 - 127V, 50/60Hz	America	Yes	A4868800001 ~
H91527	H91567	220 – 240V, 50/60Hz	Europe	Yes	A4868720001 ~
H91521	H91561	220 – 240V, 50/60Hz	China	Yes	A4800162969 ~
H91617	H91657	100 - 127V, 50/60Hz	America	Yes	A4968800002 ~

* Caution : Model Code was changed as above. The reason is mass production place was changed from Korea to China .

- The changes in this parts catalog are written in the following format:

Example:

Index No.	Parts No	Description	Qty
3	AA012125	Filter:Exhaust:Scanner (RoHs)	1
3	B0511329	Dust Filter - Scanner	1

- With "(RoHs)" at the end of the part name: **RoHs** compliant parts
- Below the parts: **Non-RoHs** compliant parts
- All screws and e-rings that already have suffixes were changed as follows on all models listed on page 2:
 - Screws: All suffixes were changed to suffix **N, P, or Q** (B, Z, H → N W → P Q → Q (was not changed))
 - E-rings: All suffixes were changed to suffix **E** (B, G → E).

IMPORTANT:

- To make sure the correct parts are used on the correct machines, please handle the parts as follows:

	RoHS Compliant Parts	Non-RoHS Compliant Parts
RoHS Compliant Machines	OK	DO NOT USE
Non-RoHS Compliant Machines	OK	OK

- **Continue using** non-RoHS compliant parts on non-ROHS compliant machines **until the stock of these parts runs out.**

Then, start using RoHS compliant parts on the non-RoHS compliant machines.

- **DO NOT use** non-RoHs compliant parts on RoHs compliant machines.

Note: This is to make sure that all machines are in full compliance with the RoHS Directive.

•

Model L2a/L2b
(H914/H915)

Model L2a/L2b (H914/H915)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior (H914/H915)	2
2.Top Cover (H914/H915)	4
3.Operation Panel (H914/H915)	6
4.Upper Scanner (H914/H915)	8
5.Paper Feed (H914/H915)	10
6.Fusing Unit (H914/H915)	12
7.Paper Exit (H914/H915)	14
8.Paper Cassette (H914/H915)	16
PARTS INDEX	20

October ,26 ' 2006


Exploded view diagram of a fax machine, showing the main body and various components. The components are numbered 1 through 22. A dashed box labeled "TonerCartridge" is shown at the bottom left.

1.Exterior (H914/H915)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H914 9675	Rx Drive Ass'y (RoHs)	1
1	B173 9526	Rx Drive Ass'y	1
2	H914 9676	Stepping Motor 28 (RoHs)	1
2	B173 9531	Stepping Motor	1
3	B173 9501	Laser Unit	1
4	H914 9677	Harness - LSU (RoHs)	1
4	H914 9500	Harness - LSU	1
5	H914 9674	Hook Switch Board (RoHs)	1
5	H914 9520	Hook Switch Board	1
6	H914 9678	Document Tray (RoHs)	1
6	H914 9501	Document Tray	1
7	H914 9679	Front Cover (RoHs)	1
7	H914 9502	Front Cover	1
8	H914 9650	Right Cover (RoHs)	1
8	H914 9503	Right Cover	1
9	H914 9652	Left Cover (RoHs)	1
9	H914 9541	Left Cover (100V)	1
9	H914 9651	Left Cover (RoHs)	1
9	H914 9504	Left Cover (220V)	1
10	H914 9653	Monitor Speaker (RoHs)	1
10	H914 9505	Monitor Speaker	1
11	H914 9655	Rear Cover (RoHs)	1
11	H914 9542	Rear Cover - L2a	1
11	H914 9654	Rear Cover - L2b	1
12	H914 9656	Face Up Door - Rear (RoHs)	1
12	B173 9509	Face Up Door - Rear	1
13	H914 9657	Cooling Fan (RoHs)	1
13	B173 9511	Cooling Fan	1
14	B173 9513	Transfer Roller Ass'y	1
15	H914 9662	Shield Plate (RoHs)	1
15	H914 9511	Shield Plate - Main Board	1
16	H914 9663	PSU - 100V (RoHs)	1
16	H914 9549	PSU - 100V	1
16	H914 9664	PSU - 200V (RoHs)	1
16	H914 9550	PSU - 200V	1

Index No.	Part No.	Description	Q'ty Per Assembly
17	H914 9665	Harness - Main Board (RoHs)	1
17	H914 9514	Harness - Main Board	1
18	H914 9666	Main Board L2a (RoHs)	1
18	H914 9543	Main Board - NA	1
18	H914 9667	Main Board L2b (RoHs)	1
18	H914 9515	Main Board	1
19	H914 9548	NCU - Oceania	1
19	H914 9669	NCU (RoHs)	1
19	H914 9669	NCU - CHN (RoHs)	1
19	H914 9544	NCU - CHN	1
19	H914 7500	NCU - EU (RoHs)	1
19	H914 9552	NCU - EU	1
19	H914 9670	NCU - NA / Asia (RoHs)	1
19	H914 9545	NCU - NA / Asia	1
20	H914 9672	Flat Cable (RoHs)	1
20	H914 9517	Flat Cable	1
21	H914 9673	Cradle - Handset (RoHs)	1
21	H914 9518	Cradle - Handset	1
22	H914 9519	Handset	1

2.Top Cover (H914/H915)




2.Top Cover (H914/H915)

Index No.	Part No.	Description	Q'ty Per Assembly
*	H914 9680	Top Cover Assy (RoHs)	1
*	H914 9521	Top Cover Assy	1
1	H914 9686	Paper Stack - Extension	1
2	H914 9688	TX Motor Assy (RoHs)	1
2	H914 9522	TX Motor Assy	1
3	H914 9689	TX Motor 7.2w Dc2 (RoHs)	1
3	H914 9523	TX Motor	1
4	H914 9690	Harness - Motor (RoHs)	1
4	H914 9525	Harness - Motor	1
5	H914 9691	ADF Roller (RoHs)	1
5	H914 9526	ADF Roller	1
6	H914 9681	Shaft - TX Motor (RoHs)	1
6	H914 9527	Shaft - TX Motor	1
7	H914 9682	Document Guide -left (RoHs)	1
7	H914 9528	Document Guide - L	1
8	H914 9683	Document Guide - Right (RoHs)	1
8	H914 9529	Document Guide - R	1
9	H914 9684	White Roller (RoHs)	1
9	H914 9530	White Roller	1
10	H914 9685	Contact Image Sensor (RoHs)	1
10	H914 9531	Contact Image Sensor	1
11	H914 9687	Document Support (RoHs)	1
11	H914 9532	Document Support Tray - A	1
12	H914 9553	White Roller Bushing	1
13	H914 9556	Bushing - Front_down	1

Index No.	Part No.	Description	Q'ty Per Assembly

3.Operation Panel (H914/H915)




3.Operation Panel (H914/H915)

Index No.	Part No.	Description	Q'ty Per Assembly
*	H914 9692	Op-port Unit (RoHs)	1
*	H914 9533	Op-port Unit (EU)	1
*	H914 9693	Op-port Unit Na/Asia (RoHs)	1
*	H914 9534	Op-port Unit (NA/ASIA)	1
*	H914 9694	Op-port Unit China (RoHs)	1
*	H914 9547	Op-port Unit - C	1
1	H914 9696	Quick Dial Cover (RoHs)	1
1	H914 9535	Quick Dial Sheet	1
2	H914 9695	OPU Board (RoHs)	1
2	H914 9536	OPU Board	1
3	H914 9551	Quick Dial Sheet	1

Index No.	Part No.	Description	Q'ty Per Assembly

4.Upper Scanner (H914/H915)




4.Upper Scanner (H914/H915)

Index No.	Part No.	Description	Q'ty Per Assembly
*	H914 9697	Scanner Upper Unit (RoHs)	1
*	H914 9537	Scanner Upper Unit	1
1	H914 9698	ADF Rubber Plate (RoHs)	1
1	H911 9559	ADF Rubber Plate	1
2	H914 9699	Holder - ADF Pad (RoHs)	1
2	H914 9538	Holder - ADF Pad	1
3	H914 9700	Antistatic Brush (RoHs)	1
3	H914 9539	Antistatic Brush	1


Index No.	Part No.	Description	Q'ty Per Assembly

5. Paper Feed (H914/H915)



11

6.Fusing Unit (H914/H915)




6.Fusing Unit (H914/H915)

Index No.	Part No.	Description	Q'ty Per Assembly
*	H914 9716	Fusing Unit - 220V (RoHs)	1
*	B173 9656	Fusing Unit - 220V	1
*	H914 9717	Fusing Unit - 110V (RoHs)	1
*	B173 9666	Fusing Unit - 110V	1
			
			

Index No.	Part No.	Description	Q'ty Per Assembly

7. Paper Exit (H914/H915)




7.Paper Exit (H914/H915)

Index No.	Part No.	Description	Q'ty Per Assembly
*	H916 9673	Exit Cover Unit (RoHs)	1
*	H916 9526	Exit Cover Unit	1
1	H914 9725	Exit Roller Pole (RoHs)	1
1	H914 9557	Exit Roller Pole	1
2	G144 9751	Exit Roller (RoHs)	4
2	G144 9576	Exit Roller	4
3	G144 9577	Rubber Kit	6

Index No.	Part No.	Description	Q'ty Per Assembly

8. Paper Cassette (H914/H915)



8.Paper Cassette (H914/H915)

Index No.	Part No.	Description	Q'ty Per Assembly
*	H914 9658	Cassette Ass'y (RoHs)	1
*	B173 9657	Cassette Ass'y	1
1	H914 9723	Extension - End (RoHs)	1
1	B173 9658	Extension - End	1
2	H914 9724	End Fence (RoHs)	1
2	B173 9659	End Fence	1
3	H914 9719	Side Fence - L (RoHs)	1
3	B173 9661	Side Fence - L	1
4	H914 9720	Side Fence - R (RoHs)	1
4	B173 9662	Side Fence - R	1
5	H914 9721	Lever - Paper Indicator (RoHs)	1
5	B173 9663	Lever - Paper Indicator	1
6	H914 9722	Friction Pad Ass'y (RoHs)	1
6	B173 9670	Friction Pad Ass'y	1
7	H914 9554	Locker Plate	1
8	B273 9732	Spring - Locker Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
H914 7500	NCU - EU (RoHs)	3 - 19
H914 9500	Harness - LSU	3 - 4
H914 9501	Document Tray	3 - 6
H914 9502	Front Cover	3 - 7
H914 9503	Right Cover	3 - 8
H914 9504	Left Cover (220V)	3 - 9
H914 9505	Monitor Speaker	3 - 10
H914 9511	Shield Plate - Main Board	3 - 15
H914 9514	Harness - Main Board	3 - 17
H914 9515	Main Board	3 - 18
H914 9517	Flat Cable	3 - 20
H914 9518	Cradle - Handset	3 - 21
H914 9519	Handset	3 - 22
H914 9520	Hook Switch Board	3 - 5
H914 9521	Top Cover Assy	5 - *
H914 9522	TX Motor Assy	5 - 2
H914 9523	TX Motor	5 - 3
H914 9525	Harness - Motor	5 - 4
H914 9526	ADF Roller	5 - 5
H914 9527	Shaft - TX Motor	5 - 6
H914 9528	Document Guide - L	5 - 7
H914 9529	Document Guide - R	5 - 8
H914 9530	White Roller	5 - 9
H914 9531	Contact Image Sensor	5 - 10
H914 9532	Document Support Tray - A	5 - 11
H914 9533	Op-port Unit (EU)	7 - *
H914 9534	Op-port Unit (NA/ASIA)	7 - *
H914 9535	Quick Dial Sheet	7 - 1
H914 9536	OPU Board	7 - 2
H914 9537	Scanner Upper Unit	9 - *
H914 9538	Holder - ADF Pad	9 - 2
H914 9539	Antistatic Brush	9 - 3
H914 9541	Left Cover (100V)	3 - 9
H914 9542	Rear Cover - L2a	3 - 11
H914 9543	Main Board - NA	3 - 18

Part No.	Description	Page and Index No.
H914 9544	NCU - CHN	3 - 19
H914 9545	NCU - NA / Asia	3 - 19
H914 9547	Op-port Unit - C	7 - *
H914 9548	NCU - Oceania	3 - 19
H914 9549	PSU - 100V	3 - 16
H914 9550	PSU - 200V	3 - 16
H914 9551	Quick Dial Sheet	7 - 3
H914 9552	NCU - EU	3 - 19
H914 9553	White Roller Bushing	5 - 12
H914 9554	Locker Plate	17 - 7
H914 9556	Bushing - Front_down	5 - 13
H914 9557	Exit Roller Pole	15 - 1
H914 9650	Right Cover (RoHs)	3 - 8
H914 9651	Left Cover (RoHs)	3 - 9
H914 9652	Left Cover (RoHs)	3 - 9
H914 9653	Monitor Speaker (RoHs)	3 - 10
H914 9654	Rear Cover - L2b	3 - 11
H914 9655	Rear Cover (RoHs)	3 - 11
H914 9656	Face Up Door - Rear (RoHs)	3 - 12
H914 9657	Cooling Fan (RoHs)	3 - 13
H914 9658	Cassette Ass'y (RoHs)	17 - *
H914 9662	Shield Plate (RoHs)	3 - 15
H914 9663	PSU - 100V (RoHs)	3 - 16
H914 9664	PSU - 200V (RoHs)	3 - 16
H914 9665	Harness - Main Board (RoHs)	3 - 17
H914 9666	Main Board L2a (RoHs)	3 - 18
H914 9667	Main Board L2b (RoHs)	3 - 18
H914 9669	NCU (RoHs)	3 - 19
H914 9669	NCU - CHN (RoHs)	3 - 19
H914 9670	NCU - NA / Asia (RoHs)	3 - 19
H914 9672	Flat Cable (RoHs)	3 - 20
H914 9673	Cradle - Handset (RoHs)	3 - 21
H914 9674	Hook Switch Board (RoHs)	3 - 5
H914 9675	Rx Drive Ass'y (RoHs)	3 - 1
H914 9676	Stepping Motor 28 (RoHs)	3 - 2

Part No.	Description	Page and Index No.
H914 9677	Harness - LSU (RoHs)	3 - 4
H914 9678	Document Tray (RoHs)	3 - 6
H914 9679	Front Cover (RoHs)	3 - 7
H914 9680	Top Cover Assy (RoHs)	5 - *
H914 9681	Shaft - TX Motor (RoHs)	5 - 6
H914 9682	Document Guide -left (RoHs)	5 - 7
H914 9683	Document Guide - Right (RoHs)	5 - 8
H914 9684	White Roller (RoHs)	5 - 9
H914 9685	Contact Image Sensor (RoHs)	5 - 10
H914 9686	Paper Stack - Extension	5 - 1
H914 9687	Document Support (RoHs)	5 - 11
H914 9688	TX Motor Assy (RoHs)	5 - 2
H914 9689	TX Motor 7.2w Dc2 (RoHs)	5 - 3
H914 9690	Harness - Motor (RoHs)	5 - 4
H914 9691	ADF Roller (RoHs)	5 - 5
H914 9692	Op-port Unit (RoHs)	7 - *
H914 9693	Op-port Unit Na/Asia (RoHs)	7 - *
H914 9694	Op-port Unit China (RoHs)	7 - *
H914 9695	OPU Board (RoHs)	7 - 2
H914 9696	Quick Dial Cover (RoHs)	7 - 1
H914 9697	Scanner Upper Uni (RoHs)	9 - *
H914 9698	ADF Rubber Plate (RoHs)	9 - 1
H914 9699	Holder - ADF Pad (RoHs)	9 - 2
H914 9700	Antistatic Brush (RoHs)	9 - 3
H914 9701	Actuator - Cover (RoHs)	11 - 1
H914 9702	Actuator - Feed (RoHs)	11 - 2
H914 9703	Actuator - Paper (RoHs)	11 - 3
H914 9704	Actuator - Bypass (RoHs)	11 - 4
H914 9705	Paper Pick-up Ass'y (RoHs)	11 - 5
H914 9706	Sponge Roller - Pick up (RoHs)	11 - 6
H914 9707	Holder - Quenching (RoHs)	11 - 7
H914 9708	Lens - Quenching (RoHs)	11 - 8
H914 9709	Feed Roller (RoHs)	11 - 9
H914 9710	Bushing - Transfer (RoHs)	11 - 10
H914 9711	Idle Shaft - Feed (RoHs)	11 - 11

Part No.	Description	Page and Index No.
H914 9712	Solenoid - Pick-up (RoHs)	11 - 12
H914 9713	Solenoid - Bypass (RoHs)	11 - 13
H914 9714	Gear - Pick-up (RoHs)	11 - 14
H914 9716	Fusing Unit - 220V (RoHs)	13 - *
H914 9717	Fusing Unit - 110V (RoHs)	13 - *
H914 9719	Side Fence - L (RoHs)	17 - 3
H914 9720	Side Fence - R (RoHs)	17 - 4
H914 9721	Lever - Paper Indicator (RoHs)	17 - 5
H914 9722	Friction Pad Ass'y (RoHs)	17 - 6
H914 9723	Extension - End (RoHs)	17 - 1
H914 9724	End Fence (RoHs)	17 - 2
H914 9725	Exit Roller Pole (RoHs)	15 - 1

Part No.	Description	Page and Index No.
B173 9501	Laser Unit	3 - 3
B173 9509	Face Up Door - Rear	3 - 12
B173 9511	Cooling Fan	3 - 13
B173 9513	Transfer Roller Ass'y	3 - 14
B173 9526	Rx Drive Ass'y	3 - 1
B173 9531	Stepping Motor	3 - 2
B173 9621	Actuator - Cover Open	11 - 1
B173 9625	Actuator - Feed	11 - 2
B173 9626	Actuator - Paper End	11 - 3
B173 9627	Actuator - Bypass	11 - 4
B173 9629	Paper Pick-up Ass'y	11 - 5
B173 9631	Sponge Roller - Pick-up	11 - 6
B173 9635	Holder - Quenching	11 - 7
B173 9636	Lens - Quenching	11 - 8
B173 9638	Feed Roller	11 - 9
B173 9639	Bushing - Transfer : R	11 - 10
B173 9641	Idle Shaft - Feed	11 - 11
B173 9646	Solenoid - Pick-up	11 - 12
B173 9647	Solenoid - Bypass	11 - 13
B173 9648	Gear - Pick-up : UPB	11 - 14
B173 9651	Feed Clutch Ass'y	11 - 15
B173 9655	PCB - Quenching	11 - 16
B173 9656	Fusing Unit - 220V	13 - *
B173 9657	Cassette Ass'y	17 - *
B173 9658	Extension - End	17 - 1
B173 9659	End Fence	17 - 2
B173 9661	Side Fence - L	17 - 3
B173 9662	Side Fence - R	17 - 4
B173 9663	Lever - Paper Indicator	17 - 5
B173 9666	Fusing Unit - 110V	13 - *
B173 9670	Friction Pad Ass'y	17 - 6
B273 9719	Feed Clutch Ass'y (RoHs)	11 - 15
B273 9732	Spring - Locker Plate	17 - 8
G144 9542	Cassette Cocker	11 - 17
G144 9567	Feed Shaft Gear	11 - 18

Part No.	Description	Page and Index No.
G144 9576	Exit Roller	15 - 2
G144 9577	Rubber Kit	15 - 3
G144 9747	Feed Shaft Gear (RoHs)	11 - 18
G144 9750	Cassette Cocker (RoHs)	11 - 17
G144 9751	Exit Roller (RoHs)	15 - 2
H911 9559	ADF Rubber Plate	9 - 1
H916 9526	Exit Cover Unit	15 - *
H916 9673	Exit Cover Unit (RoHs)	15 - *