


FAX180

PARTS CATALOG

1. EXTERIOR

Rev. 4/96



1. EXTERIOR

INDEX	PARTS NO.	DESCRIPTION	Note
*	H068 9300	Shading Sheet	
1	H068 1501	Document Transport Plate	
2	H068 1512	Spring - S1 Sensor	
3	H068 1511	Actuator - S2	
4	H068 1510	Actuator - S1	
5	H068 1513	Stopper - Pressure Shaft	
6	H068 1508	Shaft - Feed Roller	
7	H068 1509	Document Feed Roller	
8	H068 1504	Separation Pad	
9	H068 1503	Document Presssure Plate	
10	H068 1505	Spring - Pressure Plate	
11	H068 1506	Separation Plate	
12	H068 5319	Grounding Wire - ADF	
13	H068 4203	Decal - Clamper	
14	H068 2131	Left Mylar - Upper Cover	
15	H068 4202	Decal - Roll Paper	
16	H068 3109	Decurler	
17	H068 3141	Paper Guide	
17	H068 3142	Paper Guide (FAX180 CHINA)	
18	H068 2130	Right Mylar - Upper Cover	
19	H068 2105	Spring - Paper End Sensor	
20	H068 2106	Actuator - Paper End Sensor	
21	H068 2116	Mylar - Rear Cover	
22	H068 3105	Gear - Original Guide	
23	H068 2118	Harness Clamper	
24	H068 3122	Stopper - Printer Cover	
25	H068 3021	Printer Cover	
25	H068 3022	Printer Cover (FAX180 CHINA)	
26	H068 3103	Original Guide - Left	
26	H068 3126	Original Guide - Left (FAX180 CHINA)	
27	H068 3104	Original Guide - Right	
27	H068 3127	Original Guide - Right (FAX180 CHINA)	


INDEX	PARTS NO.	DESCRIPTION	Note
28	H068 4109	Document Tray	
29	H068 2122	Pressure Spring - Thermal Head -B4	
	H068 2101	Pressure Spring - Thermal Head -A4	
30	H068 2032	Thermal Head Ass'y - A4	
30	H068 2120	Thermal Head Ass'y - B4	
31	H068 5510	Harness - FCU-TPH (A4)	
31	H068 5511	Harness - FCU-TPH (B4)	
32	H068 4150	Copy Tray	
33	H068 5318	Grounding Wire - OPU	
34	H068 3123	Upper Cover (FAX180 CHINA)	
34	H068 3100	Upper Cover	
35	H068 4403	Handset (ASIA,GES)	
35	H068 4405	Handset (USA)	
35	H068 4450	Handset (FAX180 CHINA)	
35	H069 4450	Handset (FAX170 CHINA)	
38	H068 8601	Operation Manual (USA,ASIA)	
38	H068 8608	Operation Manual (CHINA English)	
38	H068 8609	Operation Manual (CHINA Chinese)	
38	H068 8621	Operation Manual (GES)	
39	H068 5508	Harness - FCU - OPU	
40	H068 5411	Operation Panel Ass'y (FAX180 CHINA English)	
40	H068 5412	Operation Panel Ass'y (FAX180 ASIA)	
40	H068 5413	Operation Panel Ass'y (USA)	
40	H068 5414	Operation Panel Ass'y (FAX180 CHINA Chinese)	
40	H068 5415	Operation Panel Ass'y (FAX180 GES)	
40	H069 5411	Operation Panel Ass'y (FAX170 ASIA)	
40	H069 5412	Operation Panel Ass'y (FAX170 CHINA English)	
40	H069 5413	Operation Panel Ass'y (FAX170 CHINA Chinese)	

INDEX	PARTS NO.	DESCRIPTION	Note
41	H068 1514	Pad - Pressure Plate	
42	H068 3134	Mylar - Paper Guide	
43	H068 3115	Spacer - Original Guide	
44	H068 2136	Paper Holder Shaft	
45	H068 2137	Mylar - Printer Cover	
48	H068 3108	Rear Cover	
48	H068 3128	Rear Cover (FAX180 CHINA)	
49	H068 1507	Pressure Shaft - Feed Roller	
50	H068 4108	Quick Dial Sheet	
51	H068 4212	Decal - Lock	
52	H068 4205	Decal - Stopper	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0450 3006B	Tapping Screw - M3x6	
102	0451 3005B	Tapping Screw - M3x5	
103	0453 3006W	Binding Self Tapping Screw - M3x6	
104	0951 3008W	Philips Screw With Flat Washer - M3x8	
105	0452 3008W	Binding Self Tapping Screw - M3 X 8	

2. DRIVE SECTION

Rev. 4/96




2. DRIVE SECTION

Rev. 4/96

INDEX	PARTS NO.	DESCRIPTION	Note
1	H068 3207	NCU Bracket	
2	H068 2102	Bushing - M6/M10 - 9	
3	H068 3205	ADF Stopper	
4	H068 3200	Left Side Plate	
5	H068 1117	Bushing M6/m10 - 6	
6	H068 1109	Gear - Scanner	
7	H068 1104	Scanner Roller	
8	H068 1102	R1 Roller	
9	H068 1101	ADF Roller	
10	H068 2100	Platen Roller	
11	H068 2020	Cutter Ass'y	
12	H068 5101	RX Motor	
13	H068 5100	TX Motor	
15	H068 1110	Idler Gear - Scanner	
16	H068 1111	Gear - ADF	
17	H068 2112	Idler Gear - Platen Roller	
18	H068 2111	Gear - Platen Roller	
19	H068 3201	Right Side Plate	
20	H068 1105	Left Clamper - Scanner Roller	
21	H068 1107	Right Clamper - Scanner Roller	
22	H068 5507	Harness - FCU - CIS	
23	H068 1122	Contact Image Sensor B4	
23	H068 1123	Contact Image Sensor A4	
24	H068 2113	Printer Jam Sensor	
26	H068 2107	Balancer - RX Motor	
27	H068 4210	Decal - Cutter	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0451 3005B	Tapping Screw - M3x5	
102	0720 0040E	Retaining Ring - M4	
103	0450 3006B	Tapping Screw - M3x6	

3. ELECTRICAL SECTION



3. ELECTRICAL SECTION

INDEX	PARTS NO.	DESCRIPTION	Note
1	H068 1126	Spring Plate - CIS	
2	H068 1116	Spring Plate - CIS2	
3	H068 5301	Harness - FCU - PSU	
4	H068 3101	Lower Cover	
4	H068 3124	Lower Cover (FAX180 CHINA)	
5	H068 6000	PCB - FCU (FAX180 ASIA,GES)	
5	H068 6001	PCB - FCU (FAX180 CHINA)	
5	H068 6080	PCB - FCU (USA)	
5	H069 6000	PCB - FCU (FAX170 ASIA,GES)	
5	H069 6001	PCB - FCU (FAX170 CHINA)	
6	H068 5000	PCB - PSU - 115V	
6	H068 5001	PCB - PSU - 220V	
7	H068 6003	PCB - NCU (ASIA,GES)	
7	H068 6006	PCB - NCU (USA,CHINA)	
8	H068 5509	Grounding Wire - NCU	
9	H068 5513	Power Cord (ASIA,GES)	
9	H068 5514	Power Cord (USA)	
9	H068 5330	Power Cord (CHINA)	
10	H068 3110	Battery Cover	
10	H068 3129	Battery Cover (FAX180 CHINA)	
11	H068 5500	Speaker	
12	H068 3113	Rubber Foot	
14	H068 1118	Untistatic Brush	
15	H068 7200	Programmed Rom (FAX180)	
15	H068 7201	Programmed Rom (FAX180 CHINA)	
15	H069 7200	Programmed Rom (FAX170 ASIA)	
15	H069 7211	Programmed Rom (FAX170 CHINA)	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0450 3006B	Tapping Screw - M3x6	
102	0313 0060B	Philips Pan Head Screw - M3x6	