



7. PARTS CATALOG

7-1. PARTS LAYOUT





7-2. PARTS LIST

In the following table, O in RF03(H095) or FAX250(H096) column indicates that a part is used in that machine.

Index	Part No.	PHILIPS P/#	Description	RF03 (H095)	FAX250 (H096)
1	H0953336	5103 507 58550	Op-port Cover - Norwegian: RF03	O	
	H0957950	5103 507 58400	Op-port Cover - German : RF03	O	
	H0957951	5103 507 58510	Op-port Cover - English : RF03	O	
	H0957952	5103 507 58530	Op-port Cover - Italian : RF03	O	
	H0957954	5103 507 58660	Op-port Cover - Spanish : RF03	O	
	H0957955	5103 507 58540	Op-port Cover - Swedish : RF03	O	
	H0963336	5103 507 58610	Op-port Cover - Norwegian: FAX250		O
	H0967950	5103 507 58410	Op-port Cover - German : FAX250		O
	H0967951	5103 507 58570	Op-port Cover - English : FAX250		O
	H0967952	5103 507 58590	Op-port Cover - Italian : FAX250		O
	H0967954	5103 507 58620	Op-port Cover - Spanish : FAX250		O
	H0967955	5103 507 58600	Op-port Cover - Swedish : FAX250		O
2	H0953350	5103 504 40860	OPU Rubber Mat - RF03	O	
	H0963350	5103 504 40870	OPU Rubber Mat - FAX250		O
3	H0938504	5103 508 05370	PCB - OPU	O	O
4	H0801501	RICOH	White Pressure Plate	O	O
5	H5041003	RICOH	Separation Rubber Plate Ass'y	O	O
6	H0801523	RICOH	Reinforcing Plate	O	O
7	H0801514	RICOH	Spring Plate - ADF	O	O
8	H0801503	RICOH	Upper R2 Roller	O	O
9	H0948102	5103 504 13120	Copy Tray - RF03/FAX240/250	O	O
11	H0937903	5103 504 13140	Rear Cover - RF01/02/03	O	
	H0947903	5103 504 13680	Rear Cover - FAX240/250		O
12	H0937904	5103 509 40240	Printer Cover - RF01/02/03	O	
	H0947904	5103 509 40250	Printer Cover - FAX240/250		O
13	H0102053	RICOH	Truss Screw - Thermal Head	O	O
*	H0937711*	2522 613 32009	Spring Washer - Thermal Head	O	O
*	H0937711*	2522 600 86126	Washer - Thermal Head	O	O
*	H0937702*	2522 178 20057	Screw - M3 x 5	O	O
14	H0937705	5103 501 41250	Bracket - Printer Cover	O	O
15	H0937702	5103 501 00510	Coil Spring - Thermal Head	O	O
16	H0962001	5103 501 41750	Bracket - Thermal Head	O	O
17	H0965200	RICOH	Thermal Head	O	O
18	H0937701	5103 501 00550	Spring Plate - Thermal Head	O	O
19	H0937910	5103 504 13360	Decurler Cover	O	O
20	H0937901	5103 504 13350	Scanner Cover - RF01/02/03	O	
	H0947901	5103 504 13670	Scanner Cover - FAX240/250		O
21	H0938140	5103 504 13370	Upper Cradle Cover - RF01/02/03	O	
	H0948140	5103 504 13610	Upper Cradle Cover - FAX240/250		O
22	H0938142	5103 504 13400	Hook Switch - RF01/02/03	O	
	H0948142	5103 504 13630	Hook Switch - FAX240/250		O
23	H0938507	5103 508 05560	PCB - HSB	O	O



Index	Part No.	PHILIPS P/#	Description	RF03 (H095)	FAX250 (H096)
24	H0938105	5103 508 73510	Curled Cord - 4p-4p - RF01/02/03	O	
	H0948105	5103 508 73700	Curled Cord - 4p-4p - FAX240/250		O
25	H0938141	5103 504 13210	Lower Cradle Cover - RF01/02/03	O	
	H0948141	5103 504 13620	Lower Cradle Cover - FAX240/250		O
27	H0938103	5103 508 73500	Handset - RF01/02/03	O	
	H0948103	5103 508 73690	Handset - FAX240/250		O
28	H0938143	5103 504 13210	Clear Cover - Cradle	O	O
29	H0938352	5103 503 90080	Harness Clamper	O	O
30	H0938351	5103 507 82340	Modular Jack - Handset : 4 p	O	O
32	H0805007	RICOH	Paper End Sensor (SB-4)	O	O
33	H0937908	5103 504 13340	Paper Holder - RF01/02/03	O	
	H0947907	5103 504 13600	Paper Holder - FAX240/250		O
34	H0937906	5103 504 13820	Slide Switch - LIU : RF01/02/03	O	
	H0947906	5103 504 13810	Slide Switch - LIU : FAX240/250		O
35	H0937902	5103 509 40260	Bottom Cover - RF01/02/03	O	
	H0947902	5103 509 40270	Bottom Cover - FAX240/250		O
100	H0801510	RICOH	ADF Feed Roller	O	O
101	H0801508	RICOH	Bushing - R2/Feed Roller	O	O
102	H0801511	RICOH	Lower R2 Roller	O	O
103	H0938302	5103 507 55130	LED Array Ass'y	O	O
104	H0801109	RICOH	Spring Plate - Feed Roller	O	O
105	H0801102	RICOH	Actuator-SB1	O	O
106	H0801103	RICOH	Actuator-SB2	O	O
107	H0801104	RICOH	White Reflector - SB-1/2	O	O
108	H0801101	RICOH	Scanner Base	O	O
109	H0801105	RICOH	1st Mirror	O	O
110	H0801107	RICOH	3rd Mirror	O	O
111	H0801110	RICOH	Spring Plate - 3rd Mirror	O	O
112	H0937704	5103 501 60060	Left Bushing - Platen Roller	O	O
113	H0802107	RICOH	Gear - Platen Roller	O	O
114	H0942120	5103 501 00533	Spring Clutch - Decurler	O	O
115	H0801504	RICOH	Idler Gear - ADF/Printer	O	O
116	H0945101	RICOH	Rx Motor	O	O
117	H0938301	5103 507 81900	Cover Switch	O	O
118	H0801517	RICOH	Spring Hook - Left	O	O
119	H0945100	RICOH	Tx Motor	O	O
120	H0801106	RICOH	2nd Mirror	O	O
121	H0801111	RICOH	Spring Plate - Lens	O	O
122	H0938506	5103 508 05030	PCB - SBU	O	O
123	H0801108	RICOH	Lens	O	O
124	H0942200	RICOH	Cutter Unit	O	O
125	H0805007	RICOH	Jam Sensor (SB-5)	O	O



Index	Part No.	PHILIPS P/#	Description	RF03 (H095)	FAX250 (H096)
126	H0958530	5103 508 08500	PCB - LIU : D	O	O
	H0958531	5103 508 05830	PCB - LIU : NL	O	O
	H0958532	5103 508 05860	PCB - LIU : I	O	O
	H0958533	5103 508 05890	PCB - LIU : GB	O	O
	H0958534	5103 508 06170	PCB - LIU : E	O	O
	H0958535	5103 508 06750	PCB - LIU : S	O	O
	H0958536	5103 508 06270	PCB - LIU : A	O	O
	H0958537	5103 508 06660	PCB - LIU : CH	O	O
	H0958538	5103 508 06570	PCB - LIU : B	O	O
	H0958539	5103 508 06840	PCB - LIU : DK	O	O
	H0958540	5103 508 07260	PCB - LIU : SF	O	O
	H0958541	5103 508 06900	PCB - LIU : N	O	O
	H0958543	5103 508 07080	PCB - LIU : P	O	O
127	H0958509	5103 509 42170	PCB - FCE - RF03 w/o ROM	O	
	H0968509	5103 509 42180	PCB - FCE - FAX250 w/o ROM		O
137	H0938350	5103 508 73650	Power Switch	O	O
138	H0938401	5103 507 82430	Power Cord - C type	O	O
	H0938402	5103 507 82450	Power Cord - BF type	O	O
	H0938403	5103 507 82470	Power Cord - CH type	O	O
139	H0938353	8203 235 24570	Power Cord Clamper	O	O
140	H0535028	RICOH	Monitor Speaker	O	O
141	H0801518	RICOH	Spring Hook - Right	O	O
142	H0801506	RICOH	Gear - ADF Feed Roller	O	O
143	H0801504	RICOH	Idler Gear - ADF/Printer	O	O
144	H0801505	RICOH	Idler Gear - ADF	O	O
145	H0801507	RICOH	Gear - R2 Roller	O	O
146	H0938354	5103 501 41220	Shield Plate - PSU	O	O
147	H0938505	5103 508 52480	PCB - PSU	O	O
148	H0968521	5103 508 08280	PCB - FDU: Type A (UK, D, NL, A, CH, B)	O	O
	H0968522	5103 508 08380	PCB - FDU : Type B (S, DK, N, SF)	O	O
	H0968523	5103 508 08410	PCB - FDU : Type C (I, E, P)	O	O
149	H0938355	5103 504 13230	Insulating Sheet	O	O
150	H0942100	RICOH	Platen Roller	O	O
151	H0937703	5103 501 60070	Right Bushing - Platen Roller	O	O
152	H0801115	RICOH	Spring-SB1	O	O
153	50530447	RICOH	Bushing - 6 mm	O	O
154	H0942121	5103 501 41243	Decurler Bracket	O	O
*	H0937907	5103 504 40460	Rubber Foot	O	O
*	H0967106	5103 508 51241	ROM	O	O
*	H0938303	5103 507 82160	Flat Cable - FDU-FCE : 22 p	O	O
*	H0938305	5103 507 82150	Flat Cable - LIU-FCE : 10 p	O	O
*	H0938306	5103 507 81870	Harness - OPU2-FCE : 6 p	O	O
*	H0938312	5103 507 81890	Harness - OPU2-LIU :	O	O
*	H0938307	5103 507 81820	Harness - PSU-FDU	O	O
*	H0938310	5103 507 81930	Harness - SB4-FDU	O	O
*	H0938311	5103 507 81940	Harness - SB5-FDU	O	O
*	H0938304	5103 507 81800	Harness - T/H-FCE	O	O

Index	Part No.	PHILIPS P/#	Description	RF03 (H095)	FAX250 (H096)
*	H0938308	5103 507 81780	Harness - T/H-FDU	O	O
*	H0938314	5103 507 81990	Harness - LIU-HSB - White : 2 p	O	O
*	H0938315	5103 507 82000	Harness - LIU-HSB - Blue : 2 p	O	O
*	H0938316	5103 507 81980	Harness - LIU-HSB : 6 p	O	O
*	H0968160	5103 506 11890	Operation Manual : Germany	O	O
	H0968161	5103 506 11900	Operation Manual : English	O	O
	H0968162	5103 506 11910	Operation Manual : Italian	O	O
	H0968163	5103 506 11950	Operation Manual : French	O	O
	H0968164	5103 506 11930	Operation Manual : Spanish	O	O
	H0968165	5103 506 11940	Operation Manual : Swedish	O	O
	H0968166	5103 506 11920	Operation Manual : Dutch	O	O
	H0968167	5103 506 11960	Operation Manual : Danish	O	O
	H0968168	5103 506 11970	Operation Manual : Norwegian	O	O
	H0968169	5103 506 11980	Operation Manual : Portuguese	O	O
*	H0938107*	5103 506 04910	Quick Dial Label	O	O
Service Tools					
	H0809600	RICOH	Scanner Adjustment Kit	O	O
	H0809602	RICOH	Scanner Adjustment Chart	O	O
	H0938309	5103 507 81840	Harness - SBU-FDU	O	O
	H0939600	RICOH	Scanner Adjustment PCB	O	O
	11024206	RICOH	7 Pin Connector	O	O
	54479078	RICOH	Heat-resistant Grease MT - 78	O	O

