


**PARTS CATALOG**  
**FOR**  
**RICOH FAX 2500L/3500L**  
**[CRO/CS1 North America]**

RICOH COMPANY, LTD.

|   |          |               |
|---|----------|---------------|
|   |          |               |
|   |          |               |
|   |          |               |
| 1 | April, 8 | First edition |

# 1. EXTERIOR




## 1. EXTERIOR

| INDEX | PART NO.  | DESCRIPTION                    | MODEL |
|-------|-----------|--------------------------------|-------|
| *     | H510 4707 | Facsimile Features Manual      |       |
| *     | H510 4300 | Operator's Manual              | CRO   |
| *     | H511 4301 | Operator's Manual              | CS1   |
| *     | H081 2487 | Sponge - Duct                  |       |
| 1     | H081 5540 | Power Supply Cord              | CS1   |
| 1     | H084 5020 | Power Supply Cord              | CRO   |
| 2     | H081 4140 | Bracket Handset Holder         |       |
| 3     | H081 4151 | Lower Bracket - Handset Holder |       |
| 4     | H081 4139 | Handset Holder                 |       |
| 5     | H081 4141 | Screw - Handset                |       |
| 6     | H082 4126 | Cover - Option                 |       |
| 7     | H081 4147 | Connector Cover                |       |
| 8     | H082 4103 | Rear Cover                     |       |
| 9     | H081 4122 | Document Tray                  |       |
| 10    | H081 3331 | Cassette Cover                 |       |
| 11    | H511 4200 | Op-Port Ass'y :                | CS1   |
| 11    | H510 4200 | OP-Port Ass'y                  | CRO   |
| 12    | H082 4104 | Right Cover Ass'y              |       |
| 13    | H081 4183 | Decal - ADF Open               |       |
| 15    | H081 1023 | Bracket - ADF Stopper          |       |
| 16    | H081 4113 | Left Cover                     |       |
| 17    | H510 4117 | NCU Cover                      |       |
| 18    | H081 4100 | Document Table Ass'y           |       |
| 19    | H081 4103 | Left Document Guide            |       |
| 20    | H081 4102 | Right Document Guide           |       |
| 21    | H081 4107 | Seal - Document Guide          |       |
| 22    | H081 4101 | Document Table                 |       |
| 23    | H081 4106 | Document Guide Rack            |       |
| 24    | H008 4560 | Plate Spring - Pinion          |       |
| 25    | 5474 1307 | Gear - ADF Tray                |       |
| 26    | H081 4105 | Lower Document Table           |       |

| INDEX | PART NO.  | DESCRIPTION                      | MODEL |
|-------|-----------|----------------------------------|-------|
| 27    | H081 4159 | Right Spring Plate - CTM         |       |
| 28    | H081 4158 | Left Spring Plate - CTM          |       |
| 29    | H081 4124 | Mylar - Document Table           |       |
| 30    | H081 4111 | Front Cover                      |       |
| 31    | H081 4135 | Front Cover Bracket              |       |
| 32    | H081 2167 | Lower Exit Roller                |       |
| 33    | H081 2151 | Exit Roller Holder               |       |
| 34    | H081 2129 | Lower Exit Guide Plate           |       |
| 35    | H510 2156 | Paper Exit Cover                 |       |
| 36    | H081 4109 | Sub Document Tray - 1            |       |
| 37    | H081 4110 | Sub Document Tray - 2            |       |
| 38    | H081 4178 | Sub Document Tray Ass'y          |       |
| 39    | H081 4212 | Copy Tray                        |       |
| 40    | H081 4121 | Sub Copy Tray                    |       |
| 41    | H081 4211 | Copy Tray Ass'y                  |       |
| 42    | H081 4154 | Rubber Cap - M3                  |       |
| 43    | H081 5700 | Modular Cord - 6P/6P             |       |
| 44    | H081 4156 | Sponge - Document Table - Right  |       |
| 45    | H081 4155 | Sponge - Document Table - Middle |       |
| 46    | H082 4105 | Speaker Bracket                  | CS1   |
| 47    | H004 5206 | Monitor Speaker                  | CS1   |
| 48    | H081 5520 | Harness - Speaker                | CS1   |
| 49    | H082 4130 | Speaker Holder                   | CS1   |
| 50    | H081 2157 | Spring Plate                     |       |
| 60    | H081 4180 | Handset Holder Ass'y             |       |
| 62    | H082 4127 | Cover - G4                       |       |
| 63    | H082 1061 | ADF Wire                         |       |

## 2. ADF, SCANNER



## 2. ADF, SCANNER

| INDEX | PART NO.  | DESCRIPTION                       | MODEL |
|-------|-----------|-----------------------------------|-------|
| 1     | H511 4167 | Cover Sheet - Quick Dial          | CS1   |
| 1     | H510 4167 | Cover Sheet - Quick Dial          | CRO   |
| 2     | H511 4255 | Quick Dial List : NA              | CS1   |
| 2     | H510 4255 | Quick Dial List : NA              | CRO   |
| 3     | H511 6006 | PCB - Op-Port                     | CS1   |
| 3     | H510 6006 | PCB - Op-Port                     | CRO   |
| 4     | H081 1139 | Pressure Spring Plate             |       |
| 5     | H081 1138 | Pressure Shaft                    |       |
| 6     | H081 1147 | Pressure Roller Ass'y             |       |
| 7     | H081 1165 | Antistatic Brush - Scanner        |       |
| 8     | H510 5002 | Document Sensor Ass'y             |       |
| 9     | H081 1115 | ADF Harness Holder                |       |
| 10    | H510 5304 | Harness - Op-Port                 |       |
| 11    | H081 1202 | ADF Stay Ass'y                    |       |
| 12    | H081 1123 | S1 Actuator                       |       |
| 13    | AA14 3287 | Stepped Screw - M3                |       |
| 14    | H081 1131 | MDF Button                        | CS1   |
| 15    | H081 1124 | Actuator Bracket                  |       |
| 16    | H081 1155 | MDF Bracket                       | CS1   |
| 17    | H081 1201 | Right Fulcrum Bracket - ADF Ass'y |       |
| 18    | H001 4221 | Harness Clamper                   |       |
| 19    | H081 1146 | S1 Spring                         |       |
| 20    | H081 1156 | S1 Bracket                        |       |
| 21    | H081 5040 | Ground Wire - ADF                 |       |
| 22    | H081 1125 | Shutter                           |       |
| 23    | H081 1128 | Bushing - Shutter                 |       |
| 24    | H081 5041 | Ground Wire - Guide               |       |
| 25    | H081 1200 | Left Fulcrum Bracket - ADF Ass'y  |       |
| 26    | 5447 2681 | Snap Ring                         |       |
| 27    | H081 1130 | Separation Stay                   |       |
| 28    | H081 1105 | Separation Roller Ass'y           |       |


| INDEX | PART NO.  | DESCRIPTION                         | MODEL |
|-------|-----------|-------------------------------------|-------|
| 29    | H081 1101 | Upper Document Guide                |       |
| 30    | H081 5519 | Harness - SBU                       |       |
| 31    | H081 6010 | PCB - SBU                           | CS1   |
| 31    | H510 6008 | PCB - SBU                           | CRO   |
| 32    | 5466 3198 | Washer - SBU                        |       |
| 33    | H081 1050 | Lens Holder                         |       |
| 34    | H041 1101 | Lens - 6/30 - 24                    |       |
| 36    | H081 1060 | Shading Plate                       |       |
| 37    | H081 1160 | Mylar - ADF Separation              |       |
| 38    | H081 1167 | Shutter Guide                       |       |
| 39    | H081 1114 | Separation Pressure Spring          |       |
| 40    | H081 1133 | Slider - Separation Torque Adjuster |       |
| 42    | H081 1135 | Pressure Plate - Pick-up            |       |
| 43    | H081 1137 | Spring Plate - Pressure Plate       |       |
| 44    | H081 1134 | Pin - Separation Torque Adjuster    |       |
| 45    | H510 5300 | Harness - Hexagonal Mirror Motor    |       |
| 46    | H510 5011 | Hexagonal Mirror Motor              |       |
| 47    | H081 1157 | Maintenance Decal - 1               |       |
| 48    | H511 6026 | PCB - MBU: USA                      | CS1   |
| 49    | H510 6100 | PCB - FCU: USA                      | CRO   |
| 49    | H511 6005 | PCB - FCU: USA                      | CS1   |
| 50    | H510 3528 | FCU Bracket                         |       |
| 51    | H081 2523 | Holder - Protection Glass           |       |
| 52    | H081 2507 | Dustproof Glass                     |       |
| 53    | H081 1194 | 2nd Mirror Holder - Left            |       |
| 54    | H081 1930 | 1st Mirror Holder - Left            |       |
| 55    | H081 1196 | 3rd Mirror Holder - Left            |       |
| 56    | H081 2512 | Holder - 1st Cylindrical Lens       |       |
| 57    | H081 2501 | Lens - CYL                          |       |
| 58    | H081 2502 | F0 Lens - L1                        |       |
| 59    | H081 2503 | F0 Lens - L2                        |       |

| INDEX | PART NO.  | DESCRIPTION                        | MODEL                                                                                                                                                                      |
|-------|-----------|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 60    | H081 2508 | 1st Cylindrical Mirror             | <br> |
| 61    | H081 2517 | Holder - 2nd Cylindrical Mirror    |                                                                                                                                                                            |
| 62    | H081 1195 | 2nd Mirror Holder - Right          |                                                                                                                                                                            |
| 63    | H081 1931 | 1st Mirror Holder - Right          |                                                                                                                                                                            |
| 64    | H081 1197 | 3rd Mirror Holder - Right          |                                                                                                                                                                            |
| 65    | H081 1062 | Scanner Mirror                     |                                                                                                                                                                            |
| 66    | H081 5006 | Xenon Lamp Stabilizer              |                                                                                                                                                                            |
| 68    | H081 2505 | 1st Mirror                         |                                                                                                                                                                            |
| 69    | H081 2515 | Right Holder - 1st Mirror          |                                                                                                                                                                            |
| 70    | H081 2518 | Right Holder - 2nd Mirror          |                                                                                                                                                                            |
| 71    | H081 2506 | 2nd Mirror                         |                                                                                                                                                                            |
| 73    | H082 1120 | White Plate                        |                                                                                                                                                                            |
| 74    | H081 1121 | Button - ADF Open                  |                                                                                                                                                                            |
| 75    | H081 1122 | Bracket - ADF Open                 |                                                                                                                                                                            |
| 76    | H081 2504 | Lens - BTL                         |                                                                                                                                                                            |
| 77    | H081 2514 | Left Holder - BTL                  |                                                                                                                                                                            |
| 78    | H081 2513 | Right Holder - BTL                 |                                                                                                                                                                            |
| 79    | H081 2558 | Cover - Laser Unit                 |                                                                                                                                                                            |
| 80    | H081 5000 | Xenon Lamp                         |                                                                                                                                                                            |
| 81    | H081 1053 | Xenon Lamp Holder - Right          |                                                                                                                                                                            |
| 83    | H081 1022 | Mainte. Cover - Pick-up Roller 1   |                                                                                                                                                                            |
| 84    | H081 1067 | Feed Shaft Ass'y                   |                                                                                                                                                                            |
| 86    | H510 1043 | Pick-up Roller Ass'y               |                                                                                                                                                                            |
| 87    | H081 1046 | Idler Gear - ADF Pick-up Roller    |                                                                                                                                                                            |
| 88    | H081 1030 | ADF Feed Roller                    |                                                                                                                                                                            |
| 89    | H081 1049 | Spring Clutch - ADF Pick-up Roller |                                                                                                                                                                            |
| 90    | H081 1045 | Feed Gear                          |                                                                                                                                                                            |
| 91    | H081 1066 | ADF Pick-up Roller Bracket         |                                                                                                                                                                            |
| 92    | H081 1070 | ADF Pick-up Roller Shaft           |                                                                                                                                                                            |
| 93    | H081 1031 | ADF Pick-up Roller                 |                                                                                                                                                                            |
| 94    | H081 1079 | Collar - Spring Clutch             |                                                                                                                                                                            |
| 95    | H081 1048 | Pick-up Roller Hub                 |                                                                                                                                                                            |
| 96    | H081 1047 | ADF Pick-up Roller Gear            |                                                                                                                                                                            |

| INDEX | PART NO.  | DESCRIPTION                 | MODEL |
|-------|-----------|-----------------------------|-------|
| 97    | H081 1063 | Exposure Glass Holder       | CS1   |
| 98    | H081 1054 | Exposure Glass Ass'y        |       |
| 99    | H081 1027 | R2 Roller Ass'y             |       |
| 100   | H081 1094 | Lens Cover                  |       |
| 101   | H110 3883 | Harness Clamp               |       |
| 102   | H081 1072 | Insuration Sheet : NCU      |       |
| 103   | H510 1092 | Harness Guide Ass'y         |       |
| 104   | H510 1034 | Tx Motor Cushion Ass'y      |       |
| 105   | H081 1042 | Timing Belt - Idler 1       |       |
| 106   | H510 5007 | Scanner Motor               |       |
| 107   | H081 1074 | Sheet - Protection          |       |
| 108   | H081 1026 | R1 Roller                   |       |
| 109   | H081 1203 | Right Fulcrum Bracket Ass'y |       |
| 110   | H081 1173 | Bracket Cover               |       |
| 114   | H081 1021 | Lower Document Guide        |       |
| 115   | H081 1096 | Sheet - Protection : 1      |       |
| 116   | H081 1032 | Idler - Tx Motor            |       |
| 117   | H081 1024 | Collar - Tx Motor           |       |
| 118   | H081 1025 | Timing Belt - Tx Motor      |       |
| 119   | H081 1019 | Timing Pulley - R2 Roller   |       |
| 120   | H081 1033 | Idler - ADF Gear            |       |
| 121   | H081 1016 | Timing Pulley - R1 Roller   |       |
| 122   | H081 1052 | Xenon Lamp Holder - Left    |       |
| 123   | H081 1065 | Timing Belt - Idler 2       |       |
| 124   | H081 1098 | Idler 2 Holder              |       |
| 125   | H081 1076 | Right Hook                  |       |
| 126   | H081 1078 | Shaft - Hook                |       |
| 127   | H081 1077 | Left Hook                   |       |
| 128   | H081 1175 | Spring Hook                 |       |
| 129   | H511 5005 | Stamper                     |       |
| 130   | H081 1041 | Joint Idle Gear             |       |
| 131   | H081 1071 | Idler Shaft Holder          |       |
| 132   | H081 1013 | Idler Shaft                 |       |

| INDEX | PART NO.                                                                                                                                                               | DESCRIPTION                                                                                        | MODEL      |
|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|------------|
| 133   | H081 1015                                                                                                                                                              | Torque Limitter - Shutter                                                                          | CS1<br>CRO |
| 134   | H081 1014                                                                                                                                                              | Shutter Lever                                                                                      |            |
| 135   | H081 1095                                                                                                                                                              | ADF Ground Plate - Lower                                                                           |            |
| 136   | H081 1204                                                                                                                                                              | Left Fulcrum Bracket Ass'y                                                                         |            |
| 138   | H081 1163                                                                                                                                                              | Stopper - S2 Sensor                                                                                |            |
| 139   | H081 5514                                                                                                                                                              | Harness - Driver                                                                                   |            |
| 139   | H510 5302                                                                                                                                                              | Harness - Driver                                                                                   |            |
| 140   |  16  |  hing - M6 : Cufe |            |

### 3. FUSING, DEVELOPMENT



### 3. FUSING, DEVELOPMENT




| INDEX | PART NO.  | DESCRIPTION                        | MODEL |
|-------|-----------|------------------------------------|-------|
| 1     | H081 2032 | Development Unit                   |       |
| 2     | H081 2412 | Development Unit Cover             |       |
| 3     | H081 2870 | Eraser Ass'y                       |       |
| 4     | H081 2448 | Snap Ring - Toner Transfer         |       |
| 5     | H081 2421 | Toner Transfer - Developper        |       |
| 6     | H081 2420 | Toner Torough                      |       |
| 7     | 5447 2681 | Snap Ring                          |       |
| 8     | H081 2438 | Shaft - Agitator                   |       |
| 9     | H081 2419 | Agitator                           |       |
| 10    | H081 2418 | Toner Supplying Roller             |       |
| 11    | H081 2400 | Hopper Ass'y                       |       |
| 12    | H081 2435 | Gear - Idler                       |       |
| 13    | H081 2422 | Lever - Toner End Detector         |       |
| 14    | H081 2436 | Gear - Toner Transfer              |       |
| 15    | H006 3533 | Snap Ring                          |       |
| 16    | H081 2462 | Spring - Toner End Lever           |       |
| 17    | H081 2434 | Spring - Toner End Detector        |       |
| 18    | H081 2432 | Disk - Toner End Detector          |       |
| 19    | H081 2427 | Gear - Toner Supplying Roller      |       |
| 20    | H081 2431 | Gear - Agitator                    |       |
| 21    | H081 2430 | Gear - Idler 2                     |       |
| 22    | H081 2475 | Bushing - Development Roller : M8  |       |
| 23    | H081 2459 | Gear - Development Roller          |       |
| 24    | H081 2429 | Gear - Idler 1                     |       |
| 25    | 5203 3105 | Nylon Rivet                        |       |
| 26    | H081 2458 | Cover - Antistatic Brush           |       |
| 27    | H081 2447 | Antistatic Brush - Develop. Roller |       |
| 28    | H082 2400 | Developmant Roller                 |       |
| 29    | H081 2413 | Development Blade                  |       |
| 30    | H081 2478 | Bushing - Development Roller : M6  |       |
| 31    | H081 2497 | Joint - Development Roller         |       |






| INDEX | PART NO.  | DESCRIPTION                    | MODEL |
|-------|-----------|--------------------------------|-------|
| 32    | H081 2451 | Shaft - Toner Supplying Roller |       |
| 33    | H081 2440 | Stopper - Guide Gear           |       |
| 34    | H081 2437 | Gear - Toner Guide             |       |
| 35    | H081 2463 | Bushing - Agitator             |       |
| 36    | H081 2495 | Spring - Guide Gear            |       |
| 37    | H081 2460 | Bushing - Toner Supply Roller  |       |
| 38    | 5419 5714 | Stepped Screw - M4             |       |
| 39    | H081 3116 | Left Fulcurm Pin - Base        |       |
| 40    | H081 3115 | Right Fulcurm Pin - Base       |       |
| 41    | H081 2124 | Fusing Cover                   |       |
| 42    | H081 2159 | Partition Plate - Fusing       |       |
| 43    | H081 2163 | Bushing - Actuator             |       |
| 44    | H081 2165 | Spring - Feed-out Sensor       |       |
| 45    | H081 2122 | Actuator - Copy Out Sensor     |       |
| 46    | H081 2145 | Cleaning Pad                   |       |
| 47    | H081 2174 | Upper Exit Guide               |       |
| 48    | H081 2137 | Thermistor                     |       |
| 49    | H081 5031 | Harness - Thermostat           |       |
| 50    | H081 2134 | Thermostat Ass'y : E           |       |
| 51    | H081 2153 | Thermostat Case                |       |
| 52    | H081 2144 | Bracket - Fusing Stripper      |       |
| 53    | H081 2120 | Fusing Stripper                |       |
| 54    | H081 2121 | Stripper Spring                |       |
| 55    | H081 2133 | Right Bracket - Fusing Lamp    |       |
| 56    | G003 6773 | Retaning Ring, Fusing          |       |
| 57    | H081 2102 | Bushing - Hot Roller           |       |
| 58    | H006 2135 | Bushing - M4x6                 |       |
| 59    | H081 2118 | Pressure Spring                |       |
| 60    | H081 2105 | Right Side Plate - Fusing      |       |
| 61    | H081 2917 | Cover - Right End Block        |       |
| 62    | H081 5034 | Transfer Charge Harness        |       |

| INDEX | PART NO.  | DESCRIPTION                     | MODEL      |
|-------|-----------|---------------------------------|------------|
| 63    | H081 9501 | Transfer Corona Wire            | CS1<br>CRO |
| 64    | 5203 2060 | Corona Wire Screw - M3x4        |            |
| 65    | H081 2915 | Right End Block                 |            |
| 66    | H081 2061 | Transfer Charger Unit           |            |
| 67    | H081 2921 | Transfer Charger Housing        |            |
| 68    | H081 2116 | Lower Fusing Stay               |            |
| 69    | H081 2132 | Exit Roller                     |            |
| 70    | H081 2103 | Bushing - Pressure Roller       |            |
| 71    | H081 2101 | Fusing Pressure Roller          |            |
| 72    | H081 2100 | Hot Roller                      |            |
| 73    | H081 5062 | Fusing Lamp - 115V              |            |
| 74    | H081 2109 | Left Side Plate - Fusing        |            |
| 75    | H081 2149 | Left Bracket - Fusing Lamp      |            |
| 76    | H081 2115 | Idle Gear - Z16                 |            |
| 77    | H081 2104 | Gear - Hot Roller               |            |
| 78    | H081 2916 | Cover - Left End Block          |            |
| 79    | H081 2908 | Spring - Transfer Charger       |            |
| 80    | H081 2914 | Left End Block                  |            |
| 81    | H081 2117 | Exit Roller Gear                |            |
| 82    | H081 2114 | Idle Gear - Z23                 |            |
| 84    | H081 2264 | Stopper - Side Plate - Copy Out |            |
| 85    | H081 5531 | Transfer Harness - Thermistor   |            |
| 86    | H510 5030 | Power Pack                      |            |
| 88    | H081 2281 | Left Connector Bracket          |            |
| 89    | AW02 0021 | Photointerruptor                |            |
| 90    | H081 2291 | Bracket - Photointerruptor      |            |
| 91    | H081 2280 | Gear Bracket                    |            |
| 92    | H081 2261 | Left Inner Cover - Copy Out     |            |
| 93    | H081 2273 | Pressure Spring - Master Unit   |            |
| 94    | H510 5326 | Left Ground Plate - Copy Out    |            |
| 95    | H511 5528 | Harness - CTM/SIF/Thermistor    |            |
| 95    | H081 5538 | Harness - CTM/SIF/Thermistor    |            |
| 96    | H081 2293 | Side Plate - Copy Out           |            |

| INDEX | PART NO.  | DESCRIPTION                         | MODEL      |
|-------|-----------|-------------------------------------|------------|
| 97    | H081 2912 | Stepped Screw - Transfer Charger    | CS1<br>CRO |
| 98    | H081 2913 | Pressure Spring - Transfer Charger  |            |
| 100   | H081 2274 | Stay - Copy Out                     |            |
| 101   | H081 2175 | Stay - Upper Exit Guide             |            |
| 102   | H081 5032 | Transfer Harness - Fusing Heater    |            |
| 103   | H081 2258 | Spring - Copy Out Cover Open        |            |
| 104   | H081 2262 | Right Inner Cover - Copy Out        |            |
| 105   | H081 2292 | Guide - Inter Lock Switch           |            |
| 106   | H081 2260 | Right Ground Plate - Copy Out       |            |
| 106   | H510 5325 | Right Ground Plate - Copy Out       |            |
| 107   | H081 2282 | Right Connector Bracket             |            |
| 108   | H081 5033 | Sensor - Copy Out Cover             |            |
| 109   | H081 2268 | Sensor Bracket - Copy Out Cover     |            |
| 110   | H081 2269 | Antistatic Brush - Copy Out         |            |
| 111   | H081 2924 | Antistatic Cloth - Transfer Charger |            |
| 114   | H081 2456 | Seal-Development Roller: Right      |            |
| 115   | H081 2406 | Seal-Development Roller: Left       |            |
| 116   | H081 2461 | Seal-Hopper: Upper                  |            |
| 117   | H081 2449 | Seal-M4-M8                          |            |

## 4. DRIVE AREA




## 4. DRIVE AREA

| INDEX | PART NO.  | DESCRIPTION                      | MODEL |
|-------|-----------|----------------------------------|-------|
| 1     | H081 3240 | Bracket - CTM Motor              |       |
| 3     | H081 3148 | Spring - Belt - 550              |       |
| 4     | H081 3257 | Tightener Bracket                |       |
| 5     | 5413 1882 | Stepped Screw                    |       |
| 6     | H081 3256 | Tightener Roller                 |       |
| 7     | H081 5077 | Main Motor                       |       |
| 8     | H081 5539 | Harness - PF/Motor/P.Pack/SIF 24 |       |
| 9     | H510 6013 | PCB - NCU: USA                   |       |
| 11    | H510 5301 | Harness - NCU                    |       |
| 16    | H081 3585 | Bracket - Left Cover             |       |
| 17    | H081 5015 | Spring Clutch - Paper Feed       |       |
| 18    | H020 3623 | Snap Ring - Registration Roller  |       |
| 19    | H081 5036 | CTM Motor                        |       |
| 20    | H081 3315 | Gear - 19/24                     |       |
| 21    | H081 3543 | Pulley/Gear - 35/24              |       |
| 22    | H081 3291 | Bushing - M6                     |       |
| 23    | H081 3417 | Bracket - Gear - 19/24           |       |
| 24    | H081 3149 | Spring - Left Guide              |       |
| 25    | H081 3217 | Shaft - Drive Arm - Fusing       |       |
| 26    | H081 3224 | Drive Gear - Fusing - Z25        |       |
| 27    | H081 3265 | Timing Belt - S3M-366            |       |
| 28    | H081 3228 | Idle Gear - Z28                  |       |
| 29    | H510 3268 | Drive Shaft Ass'y                |       |
| 30    | H081 3220 | Fusing Drive Gear - Z20          |       |
| 31    | H081 3230 | Drive Gear - Z75                 |       |
| 32    | H510 3269 | CTM Drive Gear - Z16             |       |
| 33    | H081 3262 | Bushing - M6                     |       |
| 34    | H081 3227 | Idle Gear - CTM                  |       |
| 35    | H081 3307 | Timing Belt - Tension            |       |
| 36    | H081 3270 | Timing Pulley - OPU - P36        |       |
| 37    | H081 3286 | Timing Pulley Holder             |       |

| INDEX | PART NO.  | DESCRIPTION                         | MODEL |
|-------|-----------|-------------------------------------|-------|
| 38    | H081 3275 | Timing Pulley - Joint - Development |       |
| 39    | H081 3274 | Joint Shaft - Development Unit      |       |
| 40    | H081 3277 | Development Drive Gear              |       |
| 42    | H081 3290 | Development Drive Shaft             |       |
| 43    | H081 3225 | Sub Side Plate - Driver Unit        |       |
| 44    | H081 3231 | Driver Gear - Z88                   |       |
| 45    | H081 3232 | Sector Gear - Z55                   |       |
| 46    | H081 3245 | Bracket - Drive Gear Ass'y          |       |
| 47    | H081 3109 | Stay - Left Side Plate              |       |
| 48    | H081 3266 | Development Bias Bushing            |       |
| 49    | H081 3267 | Development Bias Terminal           |       |
| 51    | H081 3319 | Barcket - Tension Roller            |       |
| 52    | H081 3322 | Tension Roller                      |       |
| 54    | 5447 2768 | Stepped Screw - M3                  |       |
| 55    | H081 3538 | Spring                              |       |
| 56    | H081 3311 | Bracket - Paper Feed Motor Ass'y    |       |
| 57    | AW50 0010 | Push Switch                         |       |
| 58    | H081 5506 | Harness - Paper Size Sensor         |       |
| 59    | H081 5017 | Paper Feed Motor                    |       |
| 60    | H081 5538 | Harness - CTM/SIF/Thermistor        | CRO   |
| 60    | H511 5528 | Harness - CTM/SIF/Thermistor        | CS1   |
| 61    | H081 3182 | Left Stay                           |       |
| 62    | H081 5532 | Transfer Harness - Copy Out Sensor  |       |
| 64    | H081 3291 | Bushing - Development Drive         |       |
| 65    | H081 3292 | Joint - Development Drive           |       |
| 66    | H081 3215 | Shaft Drive Arm - PCU               |       |
| 67    | H510 3235 | Joint Arm - Master Unit             |       |
| 68    | H081 3283 | Drive Gear - Master Unit : Roller   |       |
| 69    | H081 3284 | Drive Gear - Master Unit            |       |
| 71    | H081 3221 | Arm - Joint Gear - Fusing           |       |
| 72    | H081 3216 | Bushing - Fusing                    |       |



## 5. BASE




## 5. BASE

| INDEX | PART NO.  | DESCRIPTION                     | MODEL                                                                               | INDEX | PART NO.  | DESCRIPTION                         | MODEL |
|-------|-----------|---------------------------------|-------------------------------------------------------------------------------------|-------|-----------|-------------------------------------|-------|
| 1     | H081 3451 | Cassette Guide Rail - Left      |  | 32    | H510 5310 | Harness - Toner End Sensor/ PSU 5V  | CS1   |
| 2     | H081 3450 | Cassette Guide Rail - Right     |                                                                                     | 33    | H081 5526 | Harness - Interlock Switch - 5V     |       |
| 3     | H510 3413 | FCU Holder                      |                                                                                     | 34    | H081 5523 | Harness - Interlock Switch - 24V    |       |
| 4     | H510 3413 | FCU Holder                      |                                                                                     | 35    | H510 3107 | Lever - Interlock Switch            |       |
| 5     | H081 3326 | Actuator - Paper End Sensor     |                                                                                     | 36    | H510 3108 | Bracket - Interlock Switch - 24V    |       |
| 6     | H081 3346 | Pin - Paper End Actuator        |                                                                                     | 37    | H081 3110 | Stay - Right Side Plate             |       |
| 7     | H081 3584 | Bracket - Right Cover           |                                                                                     | 38    | H081 3120 | Snap Ring - CTM Guide               |       |
| 8     | H081 3421 | Fixing Plate - Right:Rear       |                                                                                     | 39    | 5413 1882 | Stepped Screw                       |       |
| 9     | H082 3300 | Base - Paper Feed               |                                                                                     | 40    | H081 3162 | Ozone Duct                          |       |
| 10    | H510 3400 | Fixing Plate - Left:Rear        |                                                                                     | 41    | H081 3169 | Ozone Filter Holder                 |       |
| 11    | H081 3399 | Fixing Plate - Left:Front       |                                                                                     | 42    | H081 3164 | Ozone Filter                        |       |
| 12    | H020 3623 | Snap Ring - Registration Roller |                                                                                     | 43    | H081 5038 | Ozone Fan                           |       |
| 13    | H081 3126 | Left Reinforce Bracket          |                                                                                     | 44    | H081 5043 | Interlock Switch - LD               |       |
| 14    | H081 3407 | Snap Ring - M2.5                |                                                                                     | 45    | H081 3114 | Bracket - Interlock Switch - LD     |       |
| 15    | H081 3303 | Paper Guide Plate               |                                                                                     | 46    | H081 3523 | Ground Plate                        |       |
| 16    | H081 3416 | Paper Feed Roller - A4          |                                                                                     | 48    | H081 3173 | Right Cover - Bias Terminal         |       |
| 17    | H081 3541 | Snap Ring - Paper Feed          |                                                                                     | 50    | H081 3121 | Bias Terminal Plate-Develop./Charge |       |
| 18    | H081 3589 | Shaft - Paper Feed Roller       |                                                                                     | 51    | H081 3172 | Bias Terminal                       |       |
| 19    | H081 3320 | Transfer Roller                 |                                                                                     | 52    | H081 3181 | Cover - Development                 |       |
| 20    | H081 3419 | Fixing Plate - Right:Front      |                                                                                     | 53    | H081 2511 | Holder - Cylindrical Lens Ass'y     |       |
| 21    | H081 3347 | Cassette Ground Plate           |                                                                                     | 55    | H081 2521 | Holder - Cylindrical Detector       |       |
| 22    | H081 3125 | Right Reinforce Bracket         |                                                                                     | 56    | H081 2556 | Harness Holder                      |       |
| 23    | H081 2865 | Master Unit Stopper             |                                                                                     | 57    | H081 2553 | Master Unit Guide - Right           |       |
| 24    | H081 3183 | Positioning Bracket             |                                                                                     | 59    | H081 3321 | Registration Roller                 |       |
| 25    | H081 3161 | Cover - Interlock SW            |                                                                                     | 60    | H081 2522 | Film - Regist                       |       |
| 26    | H081 3122 | Seal - Toner Duct               |                                                                                     | 61    | H081 5014 | Registration Sensor                 |       |
| 27    | H081 3131 | Spring - Right Side Plate - 750 |                                                                                     | 62    | H081 2408 | CTM Duct                            |       |
| 28    | H081 3113 | CTM Guide Rail - Right          |                                                                                     | 63    | H081 2560 | Base - Laser Unit                   |       |
| 29    | H081 3123 | CTM Guide                       |                                                                                     | 64    | H081 2568 | Holder - MBU                        |       |
| 30    | H081 3100 | Right Side Plate                |                                                                                     | 65    | H081 5024 | Zener Diode - 720V - 0.5W : NA      |       |
| 31    | AW02 0021 | Photointerruptor                |                                                                                     | 66    | H081 2530 | LD Unit                             |       |



## 6. CASSETTE





| INDEX | PART NO.   | DESCRIPTION                            | MODEL |
|-------|------------|----------------------------------------|-------|
| 200   | 0252 0080B | Screw - M2x8                           |       |
| 201   | 0313 0060B | Philips Pan Head Screw - M3x6          |       |
| 202   | 0313 0200B | Philips Pan Head Screw - M3x20         |       |
| 203   | 0313 0140B | Philips Pan Head Screw - M3x14         |       |
| 204   | 0314 0060B | Philips Pan Head Screw - M4x6          |       |
| 205   | 0323 0060B | Philips Sunk Screw - M3x6              |       |
| 206   | 0353 0060B | Philips Truss Head Screw M3x6          |       |
| 207   | 0353 0060Z | Philips Truss Head Screw - M3x6        |       |
| 208   | 0433 0062B | Tapping Pan Head Screw - M3x6          |       |
| 209   | 0433 0082B | Tapping Pan Head Screw - M3x8          |       |
| 210   | 0573 0040E | Hexagon Headless Set Screw - M3x4      |       |
| 211   | 0573 0060E | Hexagon Headless Set Screw - M3x6      |       |
| 212   | 0701 0060E | Washer - M6                            |       |
| 213   | 0720 0020E | Retaining Ring - M2                    |       |
| 214   | 0720 0030E | Retaining Ring - M3                    |       |
| 215   | 0720 0040E | Retaining Ring - M4                    |       |
| 216   | 0720 0050E | Retaining Ring - M5                    |       |
| 217   | 0802 5205B | Tapping Screw M3x6                     |       |
| 218   | 0802 5206B | Tapping Screw M3x8                     |       |
| 219   | 0950 3030B | Philips Screw with Lock Washer - M3x30 |       |
| 220   | 0950 3008B | Philips Screw with Lock Washer - M3x8  |       |
| 221   | 0951 3005B | Philips Screw with Flat Washer M3x5    |       |
| 222   | 0951 3006B | Philips Screw with Flat Washer - M3x6  |       |
| 223   | 0954 3008B | Double Sems Screw - M3x8               |       |
| 224   | 0954 3006B | Double Sems Screw - M4x8               |       |
| 225   | 0964 3006B | Tapping Screw - M3x6                   |       |
| 226   | 0965 3006B | Tapping Screw with Flat Washer M3x6    |       |
| 227   | 0965 3010B | Tapping Screw with Flat Washer M3x10   |       |
| 228   | 0965 3012B | Tapping Screw with Flat Washer M3x12   |       |
| 229   | 0965 3008B | Tapping Screw with Washer - M3x8       |       |
| 230   | 1102 5071  | Connector - 9P                         |       |
| 231   | 1102 5194  | Connector - 7P                         |       |
| 232   | 1102 4473  | CT Connector - 2P                      |       |

| INDEX | PART NO.   | DESCRIPTION             | MODEL |
|-------|------------|-------------------------|-------|
| 233   | 1105 0113  | Edge Saddle - EDS2      |       |
| 234   | 1105 0234  | Clamp                   |       |
| 235   | 1105 0246  | Spacer                  |       |
| 236   | 1105 0344  | Clamp                   |       |
| 237   | 1105 0260  | Wire Saddle             |       |
| 238   | 5053 0223  | Bushing - 8mm           |       |
| 239   | 5053 0447  | Bushing - 6mm           |       |
| 240   | 0964 3006Z | Tapping Screw - M3x6    |       |
| 241   | 0443 0060W | Tapping Screw - M3x6    |       |
| 242   | 1102 4431  | Connector - Sub Harness |       |
| 243   | 1102 4473  | CT Connector - 2P       |       |
| 244   | 1102 4559  | Connector - 3P          |       |
| 245   | 1102 4560  | CT Connector 6P         |       |
| 246   | 1102 5142  | Connector - 2P - Black  |       |
| 247   | 1102 5145  | Connector - 3P - Blue   |       |

# **PARTS INDEX**

| PART NO.   | DESCRIPTION                            | INDEX    |
|------------|----------------------------------------|----------|
| 0252 0080B | Screw - M2x8                           | 1-14-200 |
| 0313 0060B | Philips Pan Head Screw - M3x6          | 1-14-201 |
| 0313 0140B | Philips Pan Head Screw - M3x14         | 1-14-203 |
| 0313 0200B | Philips Pan Head Screw - M3x20         | 1-14-202 |
| 0314 0060B | Philips Pan Head Screw - M4x6          | 1-14-204 |
| 0323 0060B | Philips Sunk Screw - M3x6              | 1-14-205 |
| 0353 0060B | Philips Truss Head Screw M3x6          | 1-14-206 |
| 0353 0060Z | Philips Truss Head Screw - M3x6        | 1-14-207 |
| 0433 0062B | Tapping Pan Head Screw - M3x6          | 1-14-208 |
| 0433 0082B | Tapping Pan Head Screw - M3x8          | 1-14-209 |
| 0443 0060W | Tapping Screw - M3x6                   | 1-14-241 |
| 0573 0040E | Hexagon Headless Set Screw - M3x4      | 1-14-210 |
| 0573 0060E | Hexagon Headless Set Screw - M3x6      | 1-14-211 |
| 0701 0060E | Washer - M6                            | 1-14-212 |
| 0720 0020E | Retaining Ring - M2                    | 1-14-213 |
| 0720 0030E | Retaining Ring - M3                    | 1-14-214 |
| 0720 0040E | Retaining Ring - M4                    | 1-14-215 |
| 0720 0050E | Retaining Ring - M5                    | 1-14-216 |
| 0802 5205B | Tapping Screw M3x6                     | 1-14-217 |
| 0802 5206B | Tapping Screw M3x8                     | 1-14-218 |
| 0950 3008B | Philips Screw with Lock Washer - M3x8  | 1-14-220 |
| 0950 3030B | Philips Screw with Lock Washer - M3x30 | 1-14-219 |
| 0951 3005B | Philips Screw with Flat Washer M3x5    | 1-14-221 |
| 0951 3006B | Philips Screw with Flat Washer - M3x6  | 1-14-222 |
| 0954 3006B | Double Sems Screw - M4x8               | 1-14-224 |
| 0954 3008B | Double Sems Screw - M3x8               | 1-14-223 |
| 0964 3006B | Tapping Screw - M3x6                   | 1-14-225 |
| 0964 3006Z | Tapping Screw - M3x6                   | 1-14-240 |
| 0965 3006B | Tapping Screw with Flat Washer M3x6    | 1-14-226 |
| 0965 3008B | Tapping Screw with Washer - M3x8       | 1-14-229 |
| 0965 3010B | Tapping Screw with Flat Washer M3x10   | 1-14-227 |
| 0965 3012B | Tapping Screw with Flat Washer M3x12   | 1-14-228 |
| 1102 2435  | Connector - 6P                         | 1-11- 75 |

| PART NO.  | DESCRIPTION              | INDEX    |
|-----------|--------------------------|----------|
| 1102 4431 | Connector - Sub Harness  | 1-14-242 |
| 1102 4473 | CT Connector - 2P        | 1-14-232 |
| 1102 4473 | CT Connector - 2P        | 1-14-243 |
| 1102 4559 | Connector - 3P           | 1-14-244 |
| 1102 4560 | CT Connector 6P          | 1-14-245 |
| 1102 5071 | Connector - 9P           | 1-14-230 |
| 1102 5142 | Connector - 2P - Black   | 1-14-246 |
| 1102 5145 | Connector - 3P - Blue    | 1-14-247 |
| 1102 5194 | Connector - 7P           | 1-14-231 |
| 1105 0113 | Edge Saddle - EDS2       | 1-14-233 |
| 1105 0234 | Clamp                    | 1-14-234 |
| 1105 0246 | Spacer                   | 1-14-235 |
| 1105 0260 | Wire Saddle              | 1-14-237 |
| 1105 0344 | Clamp                    | 1-14-236 |
| 5053 0223 | Bushing - 8mm            | 1-14-238 |
| 5053 0447 | Bushing - 6mm            | 1-14-239 |
| 5203 2060 | Corona Wire Screw - M3x4 | 1-7- 64  |
| 5203 3105 | Nylon Rivet              | 1-7- 25  |
| 5413 1882 | Stepped Screw            | 1-9- 5   |
| 5413 1882 | Stepped Screw            | 1-11- 39 |
| 5419 5714 | Stepped Screw - M4       | 1-7- 38  |
| 5447 2681 | Snap Ring                | 1-5- 26  |
| 5447 2681 | Snap Ring                | 1-7- 7   |
| 5447 2768 | Stepped Screw - M3       | 1-9- 54  |
| 5466 3198 | Washer - SBU             | 1-5- 32  |
| 5474 1307 | Gear - ADF Tray          | 1-3- 25  |
| AA14 3287 | Stepped Screw - M3       | 1-5- 13  |
| AW02 0021 | Photointerruptor         | 1-7- 89  |
| AW02 0021 | Photointerruptor         | 1-9- 81  |
| AW02 0021 | Photointerruptor         | 1-11- 31 |
| AW50 0010 | Push Switch              | 1-9- 57  |
| G003 6773 | Retaning Ring, Fusing    | 1-7- 56  |
| H001 4221 | Harness Clamper          | 1-5- 18  |

| PART NO.  | DESCRIPTION                        | INDEX    |
|-----------|------------------------------------|----------|
| H004 5206 | Monitor Speaker                    | 1-3- 47  |
| H006 2135 | Bushing - M4x6                     | 1-7- 58  |
| H006 3533 | Snap Ring                          | 1-7- 15  |
| H008 4560 | Plate Spring - Pinion              | 1-3- 24  |
| H020 3623 | Snap Ring - Registration Roller    | 1-9- 18  |
| H020 3623 | Snap Ring - Registration Roller    | 1-11- 12 |
| H041 1101 | Lens - 6/30 - 24                   | 1-5- 34  |
| H053 1600 | Bushing - M6 : Cufe                | 1-5-140  |
| H081 1013 | Idler Shaft                        | 1-5-132  |
| H081 1014 | Shutter Lever                      | 1-5-134  |
| H081 1015 | Torque Limiter - Shutter           | 1-5-133  |
| H081 1016 | Timing Pulley - R1 Roller          | 1-5-121  |
| H081 1019 | Timing Pulley - R2 Roller          | 1-5-119  |
| H081 1021 | Lower Document Guide               | 1-5-114  |
| H081 1022 | Mainte. Cover - Pick-up Roller 1   | 1-5- 83  |
| H081 1023 | Bracket - ADF Stopper              | 1-3- 15  |
| H081 1024 | Collar - Tx Motor                  | 1-5-117  |
| H081 1025 | Timing Belt - Tx Motor             | 1-5-118  |
| H081 1026 | R1 Roller                          | 1-5-108  |
| H081 1027 | R2 Roller Ass'y                    | 1-5- 99  |
| H081 1030 | ADF Feed Roller                    | 1-5- 88  |
| H081 1031 | ADF Pick-up Roller                 | 1-5- 93  |
| H081 1032 | Idler - Tx Motor                   | 1-5-116  |
| H081 1033 | Idler - ADF Gear                   | 1-5-120  |
| H081 1041 | Joint Idle Gear                    | 1-5-130  |
| H081 1042 | Timing Belt - Idler 1              | 1-5-105  |
| H081 1045 | Feed Gear                          | 1-5- 90  |
| H081 1046 | Idler Gear - ADF Pick-up Roller    | 1-5- 87  |
| H081 1047 | ADF Pick-up Roller Gear            | 1-5- 96  |
| H081 1048 | Pick-up Roller Hub                 | 1-5- 95  |
| H081 1049 | Spring Clutch - ADF Pick-up Roller | 1-5- 89  |
| H081 1050 | Lens Holder                        | 1-5- 33  |
| H081 1052 | Xenon Lamp Holder - Left           | 1-5-122  |

| PART NO.  | DESCRIPTION                         | INDEX   |
|-----------|-------------------------------------|---------|
| H081 1053 | Xenon Lamp Holder - Right           | 1-5- 81 |
| H081 1054 | Exposure Glass Ass'y                | 1-5- 98 |
| H081 1060 | Shading Plate                       | 1-5- 36 |
| H081 1062 | Scanner Mirror                      | 1-5- 65 |
| H081 1063 | Exposure Glass Holder               | 1-5- 97 |
| H081 1065 | Timing Belt - Idler 2               | 1-5-123 |
| H081 1066 | ADF Pick-up Roller Bracket          | 1-5- 91 |
| H081 1067 | Feed Shaft Ass'y                    | 1-5- 84 |
| H081 1070 | ADF Pick-up Roller Shaft            | 1-5- 92 |
| H081 1071 | Idler Shaft Holder                  | 1-5-131 |
| H081 1072 | Insuration Sheet : NCU              | 1-5-102 |
| H081 1074 | Sheet - Protection                  | 1-5-107 |
| H081 1076 | Right Hook                          | 1-5-125 |
| H081 1077 | Left Hook                           | 1-5-127 |
| H081 1078 | Shaft - Hook                        | 1-5-126 |
| H081 1079 | Collar - Spring Clutch              | 1-5- 94 |
| H081 1094 | Lens Cover                          | 1-5-100 |
| H081 1095 | ADF Ground Plate - Lower            | 1-5-135 |
| H081 1096 | Sheet - Protection : 1              | 1-5-115 |
| H081 1098 | Idler 2 Holder                      | 1-5-124 |
| H081 1101 | Upper Document Guide                | 1-5- 29 |
| H081 1105 | Separation Roller Ass'y             | 1-5- 28 |
| H081 1114 | Separation Pressure Spring          | 1-5- 39 |
| H081 1115 | ADF Harness Holder                  | 1-5- 9  |
| H081 1121 | Button - ADF Open                   | 1-5- 74 |
| H081 1122 | Bracket - ADF Open                  | 1-5- 75 |
| H081 1123 | S1 Actuator                         | 1-5- 12 |
| H081 1124 | Actuator Bracket                    | 1-5- 15 |
| H081 1125 | Shutter                             | 1-5- 22 |
| H081 1128 | Bushing - Shutter                   | 1-5- 23 |
| H081 1130 | Separation Stay                     | 1-5- 27 |
| H081 1131 | MDF Button                          | 1-5- 14 |
| H081 1133 | Slider - Separation Torque Adjuster | 1-5- 40 |

| PART NO.  | DESCRIPTION                       | INDEX   |
|-----------|-----------------------------------|---------|
| H081 1134 | Pin - Separation Torque Adjuster  | 1-5- 44 |
| H081 1135 | Pressure Plate - Pick-up          | 1-5- 42 |
| H081 1137 | Spring Plate - Pressure Plate     | 1-5- 43 |
| H081 1138 | Pressure Shaft                    | 1-5- 5  |
| H081 1139 | Pressure Spring Plate             | 1-5- 4  |
| H081 1146 | S1 Spring                         | 1-5- 19 |
| H081 1147 | Pressure Roller Ass'y             | 1-5- 6  |
| H081 1155 | MDF Bracket                       | 1-5- 16 |
| H081 1156 | S1 Bracket                        | 1-5- 20 |
| H081 1157 | Maintenance Decal - 1             | 1-5- 47 |
| H081 1160 | Mylar - ADF Separation            | 1-5- 37 |
| H081 1163 | Stopper - S2 Sensor               | 1-5-138 |
| H081 1165 | Antistatic Brush - Scanner        | 1-5- 7  |
| H081 1167 | Shutter Guide                     | 1-5- 38 |
| H081 1173 | Bracket Cover                     | 1-5-110 |
| H081 1175 | Spring Hook                       | 1-5-128 |
| H081 1194 | 2nd Mirror Holder - Left          | 1-5- 53 |
| H081 1195 | 2nd Mirror Holder - Right         | 1-5- 62 |
| H081 1196 | 3rd Mirror Holder - Left          | 1-5- 55 |
| H081 1197 | 3rd Mirror Holder - Right         | 1-5- 64 |
| H081 1200 | Left Fulcrum Bracket - ADF Ass'y  | 1-5- 25 |
| H081 1201 | Right Fulcrum Bracket - ADF Ass'y | 1-5- 17 |
| H081 1202 | ADF Stay Ass'y                    | 1-5- 11 |
| H081 1203 | Right Fulcrum Bracket Ass'y       | 1-5-109 |
| H081 1204 | Left Fulcrum Bracket Ass'y        | 1-5-136 |
| H081 1930 | 1st Mirror Holder - Left          | 1-5- 54 |
| H081 1931 | 1st Mirror Holder - Right         | 1-5- 63 |
| H081 2032 | Development Unit                  | 1-7- 1  |
| H081 2061 | Transfer Charger Unit             | 1-7- 66 |
| H081 2100 | Hot Roller                        | 1-7- 72 |
| H081 2101 | Fusing Pressure Roller            | 1-7- 71 |
| H081 2102 | Bushing - Hot Roller              | 1-7- 57 |
| H081 2103 | Bushing - Pressure Roller         | 1-7- 70 |

| PART NO.  | DESCRIPTION                   | INDEX   |
|-----------|-------------------------------|---------|
| H081 2104 | Gear - Hot Roller             | 1-7- 77 |
| H081 2105 | Right Side Plate - Fusing     | 1-7- 60 |
| H081 2109 | Left Side Plate - Fusing      | 1-7- 74 |
| H081 2114 | Idle Gear - Z23               | 1-7- 82 |
| H081 2115 | Idle Gear - Z16               | 1-7- 76 |
| H081 2116 | Lower Fusing Stay             | 1-7- 68 |
| H081 2117 | Exit Roller Gear              | 1-7- 81 |
| H081 2118 | Pressure Spring               | 1-7- 59 |
| H081 2120 | Fusing Stripper               | 1-7- 53 |
| H081 2121 | Stripper Spring               | 1-7- 54 |
| H081 2122 | Actuator - Copy Out Sensor    | 1-7- 45 |
| H081 2124 | Fusing Cover                  | 1-7- 41 |
| H081 2129 | Lower Exit Guide Plate        | 1-3- 34 |
| H081 2132 | Exit Roller                   | 1-7- 69 |
| H081 2133 | Right Bracket - Fusing Lamp   | 1-7- 55 |
| H081 2134 | Thermostat Ass'y : E          | 1-7- 50 |
| H081 2137 | Thermistor                    | 1-7- 48 |
| H081 2144 | Bracket - Fusing Stripper     | 1-7- 52 |
| H081 2145 | Cleaning Pad                  | 1-7- 46 |
| H081 2149 | Left Bracket - Fusing Lamp    | 1-7- 75 |
| H081 2151 | Exit Roller Holder            | 1-3- 33 |
| H081 2153 | Thermostat Case               | 1-7- 51 |
| H081 2157 | Spring Plate                  | 1-3- 50 |
| H081 2159 | Partition Plate - Fusing      | 1-7- 42 |
| H081 2163 | Bushing - Actuator            | 1-7- 43 |
| H081 2165 | Spring - Feed-out Sensor      | 1-7- 44 |
| H081 2167 | Lower Exit Roller             | 1-3- 32 |
| H081 2174 | Upper Exit Guide              | 1-7- 47 |
| H081 2175 | Stay - Upper Exit Guide       | 1-7-101 |
| H081 2258 | Spring - Copy Out Cover Open  | 1-7-103 |
| H081 2260 | Right Ground Plate - Copy Out | 1-7-106 |
| H081 2261 | Left Inner Cover - Copy Out   | 1-7- 92 |
| H081 2262 | Right Inner Cover - Copy Out  | 1-7-104 |

| PART NO.  | DESCRIPTION                        | INDEX    |
|-----------|------------------------------------|----------|
| H081 2264 | Stopper - Side Plate - Copy Out    | 1-7- 84  |
| H081 2268 | Sensor Bracket - Copy Out Cover    | 1-7-109  |
| H081 2269 | Antistatic Brush - Copy Out        | 1-7-110  |
| H081 2273 | Pressure Spring - Master Unit      | 1-7- 93  |
| H081 2274 | Stay - Copy Out                    | 1-7-100  |
| H081 2280 | Gear Bracket                       | 1-7- 91  |
| H081 2281 | Left Connector Bracket             | 1-7- 88  |
| H081 2282 | Right Connector Bracket            | 1-7-107  |
| H081 2291 | Bracket - Photointerruptor         | 1-7- 90  |
| H081 2292 | Guide - Inter Lock Switch          | 1-7-105  |
| H081 2293 | Side Plate - Copy Out              | 1-7- 96  |
| H081 2400 | Hopper Ass'y                       | 1-7- 11  |
| H081 2406 | Seal-Development Roller: Left      | 1-7-115  |
| H081 2408 | CTM Duct                           | 1-11- 62 |
| H081 2412 | Development Unit Cover             | 1-7- 2   |
| H081 2413 | Development Blade                  | 1-7- 29  |
| H081 2418 | Toner Supplying Roller             | 1-7- 10  |
| H081 2419 | Agitator                           | 1-7- 9   |
| H081 2420 | Toner Torogh                       | 1-7- 6   |
| H081 2421 | Toner Transfer - Developper        | 1-7- 5   |
| H081 2422 | Lever - Toner End Detector         | 1-7- 13  |
| H081 2427 | Gear - Toner Supplying Roller      | 1-7- 19  |
| H081 2429 | Gear - Idler 1                     | 1-7- 24  |
| H081 2430 | Gear - Idler 2                     | 1-7- 21  |
| H081 2431 | Gear - Agitator                    | 1-7- 20  |
| H081 2432 | Disk - Toner End Detector          | 1-7- 18  |
| H081 2434 | Spring - Toner End Detector        | 1-7- 17  |
| H081 2435 | Gear - Idler                       | 1-7- 12  |
| H081 2436 | Gear - Toner Transfer              | 1-7- 14  |
| H081 2437 | Gear - Toner Guide                 | 1-7- 34  |
| H081 2438 | Shaft - Agitator                   | 1-7- 8   |
| H081 2440 | Stopper - Guide Gear               | 1-7- 33  |
| H081 2447 | Antistatic Brush - Develop. Roller | 1-7- 27  |

| PART NO.  | DESCRIPTION                       | INDEX    |
|-----------|-----------------------------------|----------|
| H081 2448 | Snap Ring - Toner Transfer        | 1-7- 4   |
| H081 2449 | Seal-M4-M8                        | 1-7-117  |
| H081 2451 | Shaft - Toner Supplying Roller    | 1-7- 32  |
| H081 2456 | Seal-Development Roller: Right    | 1-7-114  |
| H081 2458 | Cover - Antistatic Brush          | 1-7- 26  |
| H081 2459 | Gear - Development Roller         | 1-7- 23  |
| H081 2460 | Bushing - Toner Supply Roller     | 1-7- 37  |
| H081 2461 | Seal-Hopper: Upper                | 1-7-116  |
| H081 2462 | Spring - Toner End Lever          | 1-7- 16  |
| H081 2463 | Bushing - Agitator                | 1-7- 35  |
| H081 2475 | Bushing - Development Roller : M8 | 1-7- 22  |
| H081 2478 | Bushing - Development Roller : M6 | 1-7- 30  |
| H081 2487 | Sponge - Duct                     | 1-3- *   |
| H081 2495 | Spring - Guide Gear               | 1-7- 36  |
| H081 2497 | Joint - Development Roller        | 1-7- 31  |
| H081 2501 | Lens - CYL                        | 1-5- 57  |
| H081 2502 | F0 Lens - L1                      | 1-5- 58  |
| H081 2503 | F0 Lens - L2                      | 1-5- 59  |
| H081 2504 | Lens - BTL                        | 1-5- 76  |
| H081 2505 | 1st Mirror                        | 1-5- 68  |
| H081 2506 | 2nd Mirror                        | 1-5- 71  |
| H081 2507 | Dustproof Glass                   | 1-5- 52  |
| H081 2508 | 1st Cylindrical Mirror            | 1-5- 60  |
| H081 2511 | Holder - Cylindrical Lens Ass'y   | 1-11- 53 |
| H081 2512 | Holder - 1st Cylindrical Lens     | 1-5- 56  |
| H081 2513 | Right Holder - BTL                | 1-5- 78  |
| H081 2514 | Left Holder - BTL                 | 1-5- 77  |
| H081 2515 | Right Holder - 1st Mirror         | 1-5- 69  |
| H081 2517 | Holder - 2nd Cylindrical Mirror   | 1-5- 61  |
| H081 2518 | Right Holder - 2nd Mirror         | 1-5- 70  |
| H081 2521 | Holder - Cylindrical Detector     | 1-11- 55 |
| H081 2522 | Film - Regist                     | 1-11- 60 |
| H081 2523 | Holder - Protection Glass         | 1-5- 51  |

| PART NO.  | DESCRIPTION                         | INDEX    |
|-----------|-------------------------------------|----------|
| H081 2529 | LD Unit Cover                       | 1-11- 68 |
| H081 2530 | LD Unit                             | 1-11- 66 |
| H081 2553 | Master Unit Guide - Right           | 1-11- 57 |
| H081 2554 | Master Unit Guide - Left            | 1-11- 70 |
| H081 2556 | Harness Holder                      | 1-11- 56 |
| H081 2558 | Cover - Laser Unit                  | 1-5- 79  |
| H081 2560 | Base - Laser Unit                   | 1-11- 63 |
| H081 2568 | Holder - MBU                        | 1-11- 64 |
| H081 2865 | Master Unit Stopper                 | 1-11- 23 |
| H081 2870 | Eraser Ass'y                        | 1-7- 3   |
| H081 2908 | Spring - Transfer Charger           | 1-7- 79  |
| H081 2912 | Stepped Screw - Transfer Charger    | 1-7- 97  |
| H081 2913 | Pressure Spring - Transfer Charger  | 1-7- 98  |
| H081 2914 | Left End Block                      | 1-7- 80  |
| H081 2915 | Right End Block                     | 1-7- 65  |
| H081 2916 | Cover - Left End Block              | 1-7- 78  |
| H081 2917 | Cover - Right End Block             | 1-7- 61  |
| H081 2921 | Transfer Charger Housing            | 1-7- 67  |
| H081 2924 | Antistatic Cloth - Transfer Charger | 1-7-111  |
| H081 3100 | Right Side Plate                    | 1-11- 30 |
| H081 3109 | Stay - Left Side Plate              | 1-9- 47  |
| H081 3110 | Stay - Right Side Plate             | 1-11- 37 |
| H081 3113 | CTM Guide Rail - Right              | 1-11- 28 |
| H081 3114 | Bracket - Interlock Switch - LD     | 1-11- 45 |
| H081 3115 | Right Fulcurm Pin - Base            | 1-7- 40  |
| H081 3116 | Left Fulcurm Pin - Base             | 1-7- 39  |
| H081 3120 | Snap Ring - CTM Guide               | 1-9- 84  |
| H081 3120 | Snap Ring - CTM Guide               | 1-11- 38 |
| H081 3121 | Bias Terminal Plate-Develop./Charge | 1-11- 50 |
| H081 3122 | Seal - Toner Duct                   | 1-11- 26 |
| H081 3123 | CTM Guide                           | 1-11- 29 |
| H081 3125 | Right Reinforce Bracket             | 1-11- 22 |
| H081 3126 | Left Reinforce Bracket              | 1-11- 13 |

| PART NO.  | DESCRIPTION                     | INDEX    |
|-----------|---------------------------------|----------|
| H081 3128 | Joint Spring - Fusing           | 1-9- 74  |
| H081 3131 | Spring - Right Side Plate - 750 | 1-11- 27 |
| H081 3139 | Spring - PCU Set Lever          | 1-9- 85  |
| H081 3140 | Spring - Transfer Screw         | 1-9- 80  |
| H081 3148 | Spring - Belt - 550             | 1-9- 3   |
| H081 3149 | Spring - Left Guide             | 1-9- 24  |
| H081 3161 | Cover - Interlock SW            | 1-11- 25 |
| H081 3162 | Ozone Duct                      | 1-11- 40 |
| H081 3164 | Ozone Filter                    | 1-11- 42 |
| H081 3169 | Ozone Filter Holder             | 1-11- 41 |
| H081 3172 | Bias Terminal                   | 1-11- 51 |
| H081 3173 | Right Cover - Bias Terminal     | 1-11- 48 |
| H081 3181 | Cover - Development             | 1-11- 52 |
| H081 3182 | Left Stay                       | 1-9- 61  |
| H081 3183 | Positioning Bracket             | 1-11- 24 |
| H081 3200 | Left Side Plate                 | 1-9- 77  |
| H081 3215 | Shaft Drive Arm - PCU           | 1-9- 66  |
| H081 3216 | Bushing - Fusing                | 1-9- 72  |
| H081 3217 | Shaft - Drive Arm - Fusing      | 1-9- 25  |
| H081 3218 | Drive Gear - Fusing - Z18       | 1-9- 76  |
| H081 3219 | Drive Gear - Fusing - Z24       | 1-9- 73  |
| H081 3220 | Fusing Drive Gear - Z20         | 1-9- 30  |
| H081 3221 | Arm - Joint Gear - Fusing       | 1-9- 71  |
| H081 3224 | Drive Gear - Fusing - Z25       | 1-9- 26  |
| H081 3225 | Sub Side Plate - Driver Unit    | 1-9- 43  |
| H081 3227 | Idle Gear - CTM                 | 1-9- 34  |
| H081 3228 | Idle Gear - Z28                 | 1-9- 28  |
| H081 3230 | Drive Gear - Z75                | 1-9- 31  |
| H081 3231 | Driver Gear - Z88               | 1-9- 44  |
| H081 3232 | Sector Gear - Z55               | 1-9- 45  |
| H081 3240 | Bracket - CTM Motor             | 1-9- 1   |
| H081 3241 | Joint - Gear: CTM               | 1-9- 86  |
| H081 3242 | CTM Drive Gear - Z16            | 1-9- 78  |

| PART NO.  | DESCRIPTION                         | INDEX    |
|-----------|-------------------------------------|----------|
| H081 3245 | Bracket - Drive Gear Ass'y          | 1-9- 46  |
| H081 3250 | Left Guide Rail - CTM               | 1-9- 75  |
| H081 3251 | CTM Sensor Lever                    | 1-9- 83  |
| H081 3253 | Bracket - CTM Sensor                | 1-9- 82  |
| H081 3254 | Bushing - CTM                       | 1-9- 79  |
| H081 3256 | Tightener Roller                    | 1-9- 6   |
| H081 3257 | Tightener Bracket                   | 1-9- 4   |
| H081 3262 | Bushing - M6                        | 1-9- 33  |
| H081 3265 | Timing Belt - S3M-366               | 1-9- 27  |
| H081 3266 | Development Bias Bushing            | 1-9- 48  |
| H081 3267 | Development Bias Terminal           | 1-9- 49  |
| H081 3270 | Timing Pulley - OPU - P36           | 1-9- 36  |
| H081 3274 | Joint Shaft - Development Unit      | 1-9- 39  |
| H081 3275 | Timing Pulley - Joint - Development | 1-9- 38  |
| H081 3277 | Development Drive Gear              | 1-9- 40  |
| H081 3283 | Drive Gear - Master Unit : Roller   | 1-9- 68  |
| H081 3284 | Drive Gear - Master Unit            | 1-9- 69  |
| H081 3286 | Timing Pulley Holder                | 1-9- 37  |
| H081 3290 | Development Drive Shaft             | 1-9- 42  |
| H081 3291 | Bushing - M6                        | 1-9- 22  |
| H081 3291 | Bushing - Development Drive         | 1-9- 64  |
| H081 3292 | Joint - Development Drive           | 1-9- 65  |
| H081 3303 | Paper Guide Plate                   | 1-11- 15 |
| H081 3305 | Rubber Foot                         | 1-11- 77 |
| H081 3307 | Timing Belt - Tension               | 1-9- 35  |
| H081 3311 | Bracket - Paper Feed Motor Ass'y    | 1-9- 56  |
| H081 3315 | Gear - 19/24                        | 1-9- 20  |
| H081 3319 | Barcket - Tension Roller            | 1-9- 51  |
| H081 3320 | Transfer Roller                     | 1-11- 19 |
| H081 3321 | Registration Roller                 | 1-11- 59 |
| H081 3322 | Tension Roller                      | 1-9- 52  |
| H081 3325 | Sensor Bracket                      | 1-11- 69 |
| H081 3326 | Actuator - Paper End Sensor         | 1-11- 5  |

| PART NO.  | DESCRIPTION                         | INDEX    |
|-----------|-------------------------------------|----------|
| H081 3331 | Cassette Cover                      | 1-3- 10  |
| H081 3346 | Pin - Paper End Actuator            | 1-11- 6  |
| H081 3347 | Cassette Ground Plate               | 1-11- 21 |
| H081 3350 | Cassette - B4                       | 1-13- 8  |
| H081 3352 | Cassette Bottom Plate               | 1-13- 1  |
| H081 3354 | Pressure Spring - Cassette          | 1-13- 2  |
| H081 3355 | Cassette - A4                       | 1-13- 8  |
| H081 3357 | Right Side Fence                    | 1-13- 9  |
| H081 3361 | Left Side Fence                     | 1-13- 3  |
| H081 3364 | End Fence                           | 1-13- 7  |
| H081 3366 | Slider - Cassette                   | 1-13- 26 |
| H081 3367 | Slider Cover                        | 1-13- 27 |
| H081 3368 | Spring - Slider                     | 1-13- 25 |
| H081 3369 | Pressure Plate - End Fence          | 1-13- 6  |
| H081 3370 | Transfer Pressure Roller            | 1-13- 23 |
| H081 3371 | Shaft - Transfer Perssure Roller    | 1-13- 21 |
| H081 3376 | Guide Plate - Transfer Roller       | 1-13- 15 |
| H081 3377 | Registration Pressure Roller        | 1-13- 13 |
| H081 3378 | Shaft - Regist. Pressure Roller     | 1-13- 12 |
| H081 3379 | Holder - Registration Spring        | 1-13- 11 |
| H081 3381 | Registration Spring                 | 1-13- 10 |
| H081 3386 | Paper Size Detector Pin - Letter    | 1-13- 28 |
| H081 3388 | Paper Size Detector Pin - Legal     | 1-13- 28 |
| H081 3394 | Pressure Roller - Registration      | 1-13- 29 |
| H081 3395 | Cassette Retaining Shaft            | 1-13- 19 |
| H081 3397 | Pressure Plate - Cassette Ret.Shaft | 1-13- 20 |
| H081 3399 | Fixing Plate - Left:Front           | 1-11- 11 |
| H081 3403 | Pressure Plate - Transfer Roller    | 1-13- 22 |
| H081 3407 | Snap Ring - M2.5                    | 1-11- 14 |
| H081 3409 | Standard Pin                        | 1-11- 78 |
| H081 3410 | Spring Plate                        | 1-9- 87  |
| H081 3416 | Paper Feed Roller - A4              | 1-11- 16 |
| H081 3417 | Bracket - Gear - 19/24              | 1-9- 23  |

| PART NO.  | DESCRIPTION                      | INDEX    |
|-----------|----------------------------------|----------|
| H081 3419 | Fixing Plate - Right:Front       | 1-11- 20 |
| H081 3421 | Fixing Plate - Right:Rear        | 1-11- 8  |
| H081 3450 | Cassette Guide Rail - Right      | 1-11- 2  |
| H081 3451 | Cassette Guide Rail - Left       | 1-11- 1  |
| H081 3521 | Film - Regist Guide Plate - Side | 1-13- 17 |
| H081 3523 | Ground Plate                     | 1-11- 46 |
| H081 3526 | Registration Guide Plate         | 1-13- 16 |
| H081 3538 | Spring                           | 1-9- 55  |
| H081 3541 | Snap Ring - Paper Feed           | 1-11- 17 |
| H081 3543 | Pulley/Gear - 35/24              | 1-9- 21  |
| H081 3553 | Pulley 35                        | 1-11- 71 |
| H081 3558 | Connector - Cover                | 1-11- 82 |
| H081 3561 | Standard Pin - Stay              | 1-11- 79 |
| H081 3584 | Bracket - Right Cover            | 1-11- 7  |
| H081 3585 | Bracket - Left Cover             | 1-9- 16  |
| H081 3587 | Stopper - Left Cassette          | 1-11- 84 |
| H081 3588 | Stopper - Right Cassette         | 1-11- 76 |
| H081 3589 | Shaft - Paper Feed Roller        | 1-11- 18 |
| H081 4100 | Document Table Ass'y             | 1-3- 18  |
| H081 4101 | Document Table                   | 1-3- 22  |
| H081 4102 | Right Document Guide             | 1-3- 20  |
| H081 4103 | Left Document Guide              | 1-3- 19  |
| H081 4105 | Lower Document Table             | 1-3- 26  |
| H081 4106 | Document Guide Rack              | 1-3- 23  |
| H081 4107 | Seal - Document Guide            | 1-3- 21  |
| H081 4109 | Sub Document Tray - 1            | 1-3- 36  |
| H081 4110 | Sub Document Tray - 2            | 1-3- 37  |
| H081 4111 | Front Cover                      | 1-3- 30  |
| H081 4113 | Left Cover                       | 1-3- 16  |
| H081 4121 | Sub Copy Tray                    | 1-3- 40  |
| H081 4122 | Document Tray                    | 1-3- 9   |
| H081 4124 | Mylar - Document Table           | 1-3- 29  |
| H081 4135 | Front Cover Bracket              | 1-3- 31  |

| PART NO.  | DESCRIPTION                      | INDEX    |
|-----------|----------------------------------|----------|
| H081 4139 | Handset Holder                   | 1-3- 4   |
| H081 4140 | Bracket Handset Holder           | 1-3- 2   |
| H081 4141 | Screw - Handset                  | 1-3- 5   |
| H081 4141 | Screw - Handset                  | 1-11- 83 |
| H081 4147 | Connector Cover                  | 1-3- 7   |
| H081 4151 | Lower Bracket - Handset Holder   | 1-3- 3   |
| H081 4154 | Rubber Cap - M3                  | 1-3- 42  |
| H081 4155 | Sponge - Document Table - Middle | 1-3- 45  |
| H081 4156 | Sponge - Document Table - Right  | 1-3- 44  |
| H081 4158 | Left Spring Plate - CTM          | 1-3- 28  |
| H081 4159 | Right Spring Plate - CTM         | 1-3- 27  |
| H081 4178 | Sub Document Tray Ass'y          | 1-3- 38  |
| H081 4180 | Handset Holder Ass'y             | 1-3- 60  |
| H081 4183 | Decal - ADF Open                 | 1-3- 13  |
| H081 4211 | Copy Tray Ass'y                  | 1-3- 41  |
| H081 4212 | Copy Tray                        | 1-3- 39  |
| H081 4297 | Decal - Paper Set                | 1-13- 14 |
| H081 5000 | Xenon Lamp                       | 1-5- 80  |
| H081 5006 | Xenon Lamp Stabilizer            | 1-5- 66  |
| H081 5014 | Registration Sensor              | 1-11- 61 |
| H081 5015 | Spring Clutch - Paper Feed       | 1-9- 17  |
| H081 5017 | Paper Feed Motor                 | 1-9- 59  |
| H081 5024 | Zener Diode - 720V - 0.5W : NA   | 1-11- 65 |
| H081 5031 | Harness - Thermostat             | 1-7- 49  |
| H081 5032 | Transfer Harness - Fusing Heater | 1-7-102  |
| H081 5033 | Sensor - Copy Out Cover          | 1-7-108  |
| H081 5034 | Transfer Charge Harness          | 1-7- 62  |
| H081 5036 | CTM Motor                        | 1-9- 19  |
| H081 5038 | Ozone Fan                        | 1-11- 43 |
| H081 5040 | Ground Wire - ADF                | 1-5- 21  |
| H081 5041 | Ground Wire - Guide              | 1-5- 24  |
| H081 5043 | Interlock Switch - LD            | 1-11- 44 |
| H081 5062 | Fusing Lamp - 115V               | 1-7- 73  |

| PART NO.  | DESCRIPTION                         | INDEX    |
|-----------|-------------------------------------|----------|
| H081 5077 | Main Motor                          | 1-9- 7   |
| H081 5506 | Harness - Paper Size Sensor         | 1-9- 58  |
| H081 5512 | Harness - LDDR                      | 1-11- 67 |
| H081 5514 | Harness - Driver                    | 1-5-139  |
| H081 5519 | Harness - SBU                       | 1-5- 30  |
| H081 5520 | Harness - Speaker                   | 1-3- 48  |
| H081 5523 | Harness - Interlock Switch - 24V    | 1-11- 34 |
| H081 5526 | Harness - Interlock Switch - 5V     | 1-11- 33 |
| H081 5531 | Transfer Harness - Thermistor       | 1-7- 85  |
| H081 5532 | Transfer Harness - Copy Out Sensor  | 1-9- 62  |
| H081 5535 | Ground Wire - PSU                   | 1-11- 73 |
| H081 5538 | Harness - CTM/SIF/Thermistor        | 1-7- 95  |
| H081 5538 | Harness - CTM/SIF/Thermistor        | 1-11- 85 |
| H081 5538 | Harness - CTM/SIF/Thermistor        | 1-9- 60  |
| H081 5539 | Harness - P.F/Motor/P.Pack/SIF 24   | 1-9- 8   |
| H081 5539 | Harness - P.F/M.Motor/P.Pack/SIF 24 | 1-11- 81 |
| H081 5540 | Power Supply Cord                   | 1-3- 1   |
| H081 5700 | Modular Cord - 6P/6P                | 1-3- 43  |
| H081 6010 | PCB - SBU                           | 1-5- 31  |
| H081 9501 | Transfer Corona Wire                | 1-7- 63  |
| H082 1061 | ADF Wire                            | 1-3- 63  |
| H082 1120 | White Plate                         | 1-5- 73  |
| H082 2400 | Developmant Roller                  | 1-7- 28  |
| H082 3300 | Base - Paper Feed                   | 1-11- 9  |
| H082 4103 | Rear Cover                          | 1-3- 8   |
| H082 4104 | Right Cover Ass'y                   | 1-3- 12  |
| H082 4105 | Speaker Bracket                     | 1-3- 46  |
| H082 4126 | Cover - Option                      | 1-3- 6   |
| H082 4127 | Cover - G4                          | 1-3- 62  |
| H082 4130 | Speaker Holder                      | 1-3- 49  |
| H084 5020 | Power Supply Cord                   | 1-3- 1   |
| H110 3883 | Harness Clamp                       | 1-5-101  |
| H510 1034 | Tx Motor Cushion Ass'y              | 1-5-104  |

| PART NO.  | DESCRIPTION                        | INDEX    |
|-----------|------------------------------------|----------|
| H510 1043 | Pick-up Roller Ass'y               | 1-5- 86  |
| H510 1092 | Harness Guide Ass'y                | 1-5-103  |
| H510 2156 | Paper Exit Cover                   | 1-3- 35  |
| H510 3107 | Lever - Interlock Switch           | 1-11- 35 |
| H510 3108 | Bracket - Interlock Switch - 24V   | 1-11- 36 |
| H510 3235 | Joint Arm - Master Unit            | 1-9- 67  |
| H510 3268 | Drive Shaft Ass'y                  | 1-9- 29  |
| H510 3269 | CTM Drive Gear - Z16               | 1-9- 32  |
| H510 3400 | Fixing Plate - Left:Rear           | 1-11- 10 |
| H510 3413 | FCU Holder                         | 1-11- 3  |
| H510 3413 | FCU Holder                         | 1-11- 4  |
| H510 3528 | FCU Bracket                        | 1-5- 50  |
| H510 4117 | NCU Cover                          | 1-3- 17  |
| H510 4167 | Cover Sheet - Quick Dial           | 1-5- 1   |
| H510 4200 | OP-Port Ass'y                      | 1-3- 11  |
| H510 4255 | Quick Dial List : NA               | 1-5- 2   |
| H510 4300 | Operator's Manual                  | 1-3- *   |
| H510 4707 | Facsimile Features Manual          | 1-3- *   |
| H510 5001 | Push Switch                        | 1-11- 86 |
| H510 5002 | Document Sensor Ass'y              | 1-5- 8   |
| H510 5007 | Scanner Motor                      | 1-5-106  |
| H510 5011 | Hexagonal Mirror Motor             | 1-5- 46  |
| H510 5030 | Power Pack                         | 1-7- 86  |
| H510 5300 | Harness - Hexagonal Mirror Motor   | 1-5- 45  |
| H510 5301 | Harness - NCU                      | 1-9- 11  |
| H510 5302 | Harness - Driver                   | 1-5-139  |
| H510 5304 | Harness - Op-Port                  | 1-5- 10  |
| H510 5310 | Harness - Toner End Sensor/ PSU 5V | 1-11- 32 |
| H510 5325 | Right Ground Plate - Copy Out      | 1-7-106  |
| H510 5326 | Left Ground Plate - Copy Out       | 1-7- 94  |
| H510 5603 | PSU Ass'y - 115V                   | 1-11- 72 |
| H510 6006 | PCB - Op-Port                      | 1-5- 3   |
| H510 6008 | PCB - SBU                          | 1-5- 31  |

| PART NO.  | DESCRIPTION                  | INDEX    |
|-----------|------------------------------|----------|
| H510 6013 | PCB - NCU: USA               | 1-9- 9   |
| H510 6100 | PCB - FCU: USA               | 1-5- 49  |
| H511 4167 | Cover Sheet - Quick Dial     | 1-5- 1   |
| H511 4200 | Op-Port Ass'y :              | 1-3- 11  |
| H511 4255 | Quick Dial List : NA         | 1-5- 2   |
| H511 4301 | Operator's Manual            | 1-3- *   |
| H511 5005 | Stamper                      | 1-5-129  |
| H511 5528 | Harness - CTM/SIF/Thermistor | 1-9- 60  |
| H511 5528 | Harness - CTM/SIF/Thermistor | 1-7- 95  |
| H511 5528 | Harness - CTM/SIF/Thermistor | 1-11- 85 |
| H511 5601 | PSU Ass'y - 115V             | 1-11- 72 |
| H511 6005 | PCB - FCU: USA               | 1-5- 49  |
| H511 6006 | PCB - Op-Port                | 1-5- 3   |
| H511 6026 | PCB - MBU: USA               | 1-5- 48  |


| PART NO. | DESCRIPTION | INDEX |
|----------|-------------|-------|
|          |             |       |

## Part Number Information for FAX2600L Parts Catalog

| Item                               | New CRO   | CRO       | Parts Catalog Index |
|------------------------------------|-----------|-----------|---------------------|
| 1. Cassette                        | H081 3350 | H081 3355 | 1-13-8              |
| 2. Paper Size Detector Pin-LG      | H081 3388 | —         | 1-13-28             |
| 3. PCB - FCU                       | H081 6064 | H510 6110 | 1-5-49              |
| 4. Operators Manual                | H081 4444 | H510 4300 | 1-3-*               |
| 5. Op-Port ass'y                   | H081 4725 | H510 4200 | 1-3-11              |
| 6. Standard Pin                    | H081 3409 | —         | 1-11-78             |
| 7. Film - Regist Guide Rail - Left | H081 3521 | —         | 1-13-17             |
| 8. Connector - Cover               | H081 3558 | —         | 1-11-82             |
| 9. Quick Dial List: NA             | H081 4728 | H510 4255 | 1-3-2               |

## 6. PARTS CATALOG

### 6.1. PARTS LAYOUT



## 6.2. PARTS LIST

| Index | Part Number | Description                              |
|-------|-------------|------------------------------------------|
| 1     | H5105321    | Flat Cable: PIF - FCU                    |
| 2     | H5106005    | PCB: CNT: USA                            |
| 3     | H1443167    | Stud - PIF                               |
| 4     | H5105610    | PCB: PIF: USA                            |
| 5     | H5105320    | Flat Cable: PIF-CNT: USA                 |
| 6     | G0111250    | Screw: Con: NA: M                        |
| 7     | H1443168    | Cover - Option Memory Board              |
| 9     | H1444146    | Guide - Option Memory Card               |
| 10    | H0814141    | Screw - Handset                          |
| 11    | H1444145    | Rear Cover - Memory - PIF                |
| 12    | H1444111    | Rear Cover - Printer Option              |
| 13    | H1444144    | Cover - RS232C                           |
| 14    | H1444140    | Cover - Left - PIF: USA                  |
| *     | H1444141    | Cover - Cartridge                        |
| *     | H1444128    | Spring - Cover Cartridge                 |
| 100   | 09513006B   | Philips Screw with Flat Washer - M3 x 6  |
| 101   | 03530060Z   | Philips Truss Head Screw - M3 x 6        |
| 102   | 09513010B   | Philips Screw with Flat Washer - M3 x 10 |
| *     | H1444301    | Operator's Manual                        |
| *     | 09653008B   | Tapping Screw - M3 x 6                   |