



PARTS CATALOG

FOR


RICOH FAX 5600L

[CGO North America]

RICOH COMPANY, LTD.

1	May, 12	First edition


1. EXTERIOR



INDEX	PART NO.	DESCRIPTION	MODEL
*	H513 4302	Operator's Manual	
*	H081 2487	Sponge - Duct	
1	H081 5540	Power Supply Cord	
2	H081 4140	Bracket Handset Holder	
3	H081 4151	Lower Bracket - Handset Holder	
4	H081 4139	Handset Holder	
5	H081 4141	Screw - Handset	
6	H082 4126	Cover - Option	
7	H081 4147	Connector Cover	
8	H082 4103	Rear Cover	
9	H081 4122	Document Tray	
10	H081 3331	Cassette Cover	
11	H513 3103	OP-Port Ass'y	
12	H082 4104	Right Cover Ass'y	
13	H081 4183	Decal - ADF Open	
15	H081 1023	Bracket - ADF Stopper	
16	H513 3101	Left Cover	
17	H510 4117	NCU Cover	
18	H081 4100	Document Table Ass'y	
19	H081 4103	Left Document Guide	
20	H081 4102	Right Document Guide	
21	H081 4107	Seal - Document Guide	
22	H081 4101	Document Table	
23	H081 4106	Document Guide Rack	
24	H008 4560	Plate Spring - Pinion	
25	5474 1307	Gear - ADF Tray	
26	H081 4105	Lower Document Table	
27	H081 4159	Right Spring Plate - CTM	
28	H081 4158	Left Spring Plate - CTM	
29	H081 4124	Mylar - Document Table	
30	H081 4111	Front Cover	
31	H081 4135	Front Cover Bracket	
32	H081 2167	Lower Exit Roller	

INDEX	PART NO.	DESCRIPTION	MODEL
33	H081 2151	Exit Roller Holder	
34	H081 2129	Lower Exit Guide Plate	
35	H510 2156	Paper Exit Cover	
36	H081 4109	Sub Document Tray - 1	
37	H081 4110	Sub Document Tray - 2	
38	H081 4178	Sub Document Tray Ass'y	
39	H081 4212	Copy Tray	
40	H081 4121	Sub Copy Tray	
41	H081 4211	Copy Tray Ass'y	
43	H081 5700	Modular Cord - 6P/6P	
44	H081 4156	Sponge - Document Table - Right	
45	H081 4155	Sponge - Document Table - Middle	
46	H082 4105	Speaker Bracket	
47	H004 5206	Monitor Speaker	
48	H081 5520	Harness - Speaker	
49	H082 4130	Speaker Holder	
50	H081 2157	Spring Plate	
60	H081 4180	Handset Holder Ass'y	
62	H082 4127	Cover - G4	
63	H082 1061	ADF Wire	
70	H513 3102	Left Cover - OPC	

2. ADF, SCANNER




INDEX	PART NO.	DESCRIPTION	MODEL
1	H513 3142	Quick Dial Cover	
2	H513 3161	Quick Dial List : NA	
4	H081 1139	Pressure Spring Plate	
5	H081 1138	Pressure Shaft	
6	H081 1147	Pressure Roller Ass'y	
7	H081 1165	Antistatic Brush - Scanner	
8	H513 5001	Document Sensor Ass'y	
9	H081 1115	ADF Harness Holder	
10	H513 5125	Harness - Op-Port	
11	H082 1202	ADF Stay Ass'y	
12	H081 1123	S1 Actuator	
13	AA14 3287	Stepped Screw - M3	
14	H081 1131	MDF Button	
15	H081 1124	Actuator Bracket	
16	H081 1155	MDF Bracket	
17	H081 1201	Right Fulcurm Bracket - ADF Ass'y	
18	H001 4221	Harness Clamper	
19	H081 1146	S1 Spring	
20	H081 1156	S1 Bracket	
21	H081 5040	Ground Wire - ADF	
22	H081 1125	Shutter	
23	H081 1128	Bushing - Shutter	
24	H081 5041	Ground Wire - Guide	
25	H081 1200	Left Fulcurm Bracket - ADF Ass'y	
26	5447 2681	Snap Ring	
27	H081 1130	Separation Stay	
28	H513 1500	Separation Roller Ass'y	
29	H081 1101	Upper Document Guide	
30	H513 5111	Harness - SBU	
31	H513 6009	PCB - SBU	
32	5466 3198	Washer - SBU	
33	H513 1100	Lens Holder	
34	H513 1112	Lens - F5/23.9	

INDEX	PART NO.	DESCRIPTION	MODEL
36	H513 1111	Shading Plate	
37	H081 1160	Mylar - ADF Separation	
38	H081 1167	Shutter Guide	
39	H081 1114	Separation Pressure Spring	
40	H081 1133	Slider - Separation Torque Adjuster	
42	H081 1135	Pressure Plate - Pick-up	
43	H081 1137	Spring Plate - Pressure Plate	
44	H081 1134	Pin - Separation Torque Adjuster	
45	H510 5300	Harness - Hexagonal Mirror Motor	
46	H510 5011	Hexagonal Mirror Motor	
47	H081 1157	Maintenance Decal - 1	
48	H513 6014	PCB - MBU: USA	
49	H513 6020	PCB - FCU: USA	
50	H081 3528	FCU Bracket	
51	H081 2523	Holder - Protection Glass	
52	H081 2507	Dustproof Glass	
53	H081 1194	2nd Mirror Holder - Left	
54	H081 1930	1st Mirror Holder - Left	
55	H081 1196	3rd Mirror Holder - Left	
56	H081 2512	Holder - 1st Cylindrical Lens	
57	H081 2501	Lens - CYL	
58	H081 2502	F0 Lens - L1	
59	H081 2503	F0 Lens - L2	
60	H081 2508	1st Cylindrical Mirror	
61	H081 2517	Holder - 2nd Cylindrical Mirror	
62	H081 1195	2nd Mirror Holder - Right	
63	H081 1931	1st Mirror Holder - Right	
64	H081 1197	3rd Mirror Holder - Right	
65	H081 1062	Scanner Mirror	
66	H082 5006	Xenon Lamp Stabilizer	
68	H081 2505	1st Mirror	
69	H081 2515	Right Holder - 1st Mirror	
70	H081 2518	Right Holder - 2nd Mirror	

INDEX	PART NO.	DESCRIPTION	MODEL
71	H081 2506	2nd Mirror	
73	H082 1120	White Plate	
74	H081 1121	Button - ADF Open	
75	H081 1122	Bracket - ADF Open	
76	H081 2504	Lens - BTL	
77	H081 2514	Left Holder - BTL	
78	H081 2513	Right Holder - BTL	
79	H081 2558	Cover - Laser Unit	
80	H513 5008	Xenon Lamp	
81	H081 1053	Xenon Lamp Holder - Right	
83	H081 1022	Mainte. Cover - Pick-up Roller 1	
84	H081 1067	Feed Shaft Ass'y	
86	H510 1043	Pick-up Roller Ass'y	
87	H081 1046	Idler Gear - ADF Pick-up Roller	
88	H081 1030	ADF Feed Roller	
89	H081 1049	Spring Clutch - ADF Pick-up Roller	
90	H081 1045	Feed Gear	
91	H081 1066	ADF Pick-up Roller Bracket	
92	H081 1070	ADF Pick-up Roller Shaft	
93	H081 1031	ADF Pick-up Roller	
94	H081 1079	Collar - Spring Clutch	
95	H081 1048	Pick-up Roller Hub	
96	H081 1047	ADF Pick-up Roller Gear	
97	H082 1064	Exposure Glass Holder	
98	H082 1054	Exposure Glass Ass'y	
99	H082 1027	R2 Roller Ass'y	
100	H081 1094	Lens Cover	
101	H110 3883	Harness Clamp	
102	H081 1072	Insuration Sheet : NCU	
103	H510 1092	Harness Guide Ass'y	
104	H513 1101	Tx Motor Cushion Ass'y	
105	H081 1042	Timing Belt - Idler 1	
106	H513 5007	Scanner Motor	

INDEX	PART NO.	DESCRIPTION	MODEL
107	H081 1074	Sheet - Protection	
108	H082 1026	R1 Roller	
109	H082 1203	Right Fulcrum Bracket Ass'y	
110	H081 1173	Bracket Cover	
114	H513 1114	Lower Document Guide	
115	H081 1096	Sheet - Protection : 1	
116	H513 1108	Idler - Tx Motor	
117	H513 1109	Collar - Tx Motor	
118	H513 1110	Timing Belt - Tx Motor	
119	H081 1019	Timing Pulley - R2 Roller	
120	H081 1033	Idler - ADF Gear	
121	H081 1016	Timing Pulley - R1 Roller	
122	H081 1052	Xenon Lamp Holder - Left	
123	H081 1065	Timing Belt - Idler 2	
124	H081 1098	Idler 2 Holder	
125	H081 1076	Right Hook	
126	H081 1078	Shaft - Hook	
127	H081 1077	Left Hook	
128	H081 1175	Spring Hook	
129	H511 5006	Stamper	
130	H081 1041	Joint Idle Gear	
131	H081 1071	Idler Shaft Holder	
132	H081 1013	Idler Shaft	
133	H081 1015	Torque Limitter - Shutter	
134	H081 1014	Shutter Lever	
135	H081 1095	ADF Ground Plate - Lower	
136	H081 1204	Left Fulcrum Bracket Ass'y	
137	H510 1040	Protection Sheet - Shutter	
139	H082 5107	Harness - Driver	
140	H053 1600	Bushing - M6 : Cufe	
142	H510 5326	Left Ground Plate	
150	H081 1236	CTM Sheet	
151	H081 1237	Dust Protection Sheet	

3. FUSING, DEVELOPMENT



INDEX	PART NO.	DESCRIPTION	MODEL
1	H081 2033	Development Unit	 
2	H081 2412	Development Unit Cover	
3	H081 2854	Eraser Ass'y	
4	H081 2448	Snap Ring - Toner Transfer	
5	H081 2421	Toner Transfer - Developper	
6	H081 2420	Toner Torough	
7	5447 2681	Snap Ring	
8	H081 2438	Shaft - Agitator	
9	H081 2419	Agitator	
10	H081 2418	Toner Supplying Roller	
11	H081 2400	Hopper Ass'y	
12	H081 2435	Gear - Idler	
13	H081 2422	Lever - Toner End Detector	
14	H081 2436	Gear - Toner Transfer	
15	H006 3533	Snap Ring	
16	H081 2462	Spring - Toner End Lever	
17	H081 2434	Spring - Toner End Detector	
18	H081 2432	Disk - Toner End Detector	
19	H081 2427	Gear - Toner Supplying Roller	
20	H081 2431	Gear - Agitator	
21	H081 2430	Gear - Idler 2	
22	H081 2475	Bushing - Development Roller : M8	
23	H081 2459	Gear - Development Roller	
24	H081 2429	Gear - Idler 1	
25	5203 3105	Nylon Rivet	
26	H081 2458	Cover - Antistatic Brush	
27	H081 2447	Antistatic Brush - Develop. Roller	
28	H082 2402	Developmant Roller	
29	H081 2413	Development Blade	
30	H081 2478	Bushing - Development Roller : M6	
32	H081 2451	Shaft - Toner Supplying Roller	
33	H081 2440	Stopper - Guide Gear	
34	H081 2437	Gear - Toner Guide	


INDEX	PART NO.	DESCRIPTION	MODEL
35	H081 2463	Bushing - Agitator	
36	H081 2495	Spring - Guide Gear	
37	H081 2460	Bushing - Toner Supply Roller	
38	5419 5714	Stepped Screw - M4	
39	H081 3116	Left Fulcurm Pin - Base	
40	H081 3115	Right Fulcurm Pin - Base	
41	H081 2124	Fusing Cover	
42	H081 2159	Partition Plate - Fusing	
43	H081 2163	Bushing - Actuator	
44	H081 2165	Spring - Feed-out Sensor	
45	H081 2122	Actuator - Copy Out Sensor	
46	H081 2145	Cleaning Pad	
47	H081 2174	Upper Exit Guide	
48	H081 2137	Thermistor	
49	H081 5031	Harness - Thermostat	
50	H081 2134	Thermostat Ass'y	
51	H081 2153	Thermostat Case	
52	H081 2144	Bracket - Fusing Stripper	
53	H081 2120	Fusing Stripper	
54	H081 2121	Stripper Spring	
55	H081 2133	Right Bracket - Fusing Lamp	
56	G003 6773	Retaning Ring, Fusing	
57	H081 2102	Bushing - Hot Roller	
58	H006 2135	Bushing - M4x6	
59	H510 2118	Pressure Spring	
60	H081 2105	Right Side Plate - Fusing	
61	H081 2917	Cover - Right End Block	
62	H081 5034	Transfer Charge Harness	
63	H081 9501	Transfer Corona Wire	
64	5203 2060	Corona Wire Screw - M3x4	
65	H081 2915	Right End Block	
66	H513 2061	Transfer Charger Unit	
67	H081 2921	Transfer Charger Housing	



INDEX	PART NO.	DESCRIPTION	MODEL
68	H081 2116	Lower Fusing Stay	
69	H081 2132	Exit Roller	
70	H081 2103	Bushing - Pressure Roller	
71	H081 2101	Fusing Pressure Roller	
72	H081 2100	Hot Roller	
73	H510 5062	Fusing Lamp - 115V	
74	H081 2109	Left Side Plate - Fusing	
75	H081 2149	Left Bracket - Fusing Lamp	
76	H081 2115	Idle Gear - Z16	
77	H081 2104	Gear - Hot Roller	
78	H081 2916	Cover - Left End Block	
79	H081 2908	Spring - Transfer Charger	
80	H081 2914	Left End Block	
81	H081 2117	Exit Roller Gear	
82	H081 2114	Idle Gear - Z23	
84	H081 2264	Stopper - Side Plate - Copy Out	
85	H081 5531	Transfer Harness - Thermistor	
86	H510 5020	Power Pack	
88	H081 2281	Left Connector Bracket	
89	AW02 0021	Photointerruptor	
90	H081 2291	Bracket - Photointerruptor	
91	H081 2280	Gear Bracket	
92	H081 2261	Left Inner Cover - Copy Out	
93	H081 2273	Pressure Spring - Master Unit	
95	H511 5528	Harness - CTM/SIF/Thermistor	
96	H081 2293	Side Plate - Copy Out	
97	H081 2912	Stepped Screw - Transfer Charger	
98	H081 2913	Pressure Spring - Transfer Charger	
99	H513 2924	Antistatic Brush - Transfer Charger	
100	H081 2274	Stay - Copy Out	
101	H081 2175	Stay - Upper Exit Guide	
102	H081 5032	Transfer Harness - Fusing Heater	
103	H081 2258	Spring - Copy Out Cover Open	

INDEX	PART NO.	DESCRIPTION	MODEL
104	H081 2262	Right Inner Cover - Copy Out	
105	H081 2292	Guide - Inter Lock Switch	
106	H081 2260	Right Ground Plate - Copy Out	
107	H081 2282	Right Connector Bracket	
108	H081 5033	Sensor - Copy Out Cover	
109	H081 2268	Sensor Bracket - Copy Out Cover	
110	H081 2269	Antistatic Brush - Copy Out	
113	H081 2470	Seal - Development Roller: Lower	
114	H081 2456	Seal-Development Roller: Right	
115	H081 2406	Seal-Development Roller: Left	
116	H081 2461	Seal-Hopper: Upper	
117	H081 2449	Seal-M4-M8	
118	H081 2491	Guide Film	
119	H081 2488	Guide Seal - Right	
120	H081 2498	Guide Film	
121	H082 2425	Guide Film - Left	
122	H082 2426	Guide Seal - Left	

4. DRIVE AREA



INDEX	PART NO.	DESCRIPTION	MODEL
1	H513 2177	Bracket - CTM Motor	
3	H513 2175	Spring - Belt - 600	
4	H081 3257	Tightener Bracket	
5	5413 1882	Stepped Screw	
6	H081 3256	Tightener Roller	
7	H513 5077	Main Motor	
8	H081 5539	Harness - P.F/Motor/P.Pack/SIF 24	
9	H510 6013	PCB - NCU: USA	
11	H510 5301	Harness - NCU	
16	H081 3585	Bracket - Left Cover	
17	H081 5015	Spring Clutch - Paper Feed	
18	H020 3623	Snap Ring - Registration Roller	
19	H081 5036	CTM Motor	
20	H081 3315	Gear - 19/24	
21	H081 3543	Pulley/Gear - 35/24	
22	H081 3291	Bushing - M6	
23	H081 3417	Bracket - Gear - 19/24	
24	H081 3149	Spring - Left Guide	
25	H081 3217	Shaft - Drive Arm - Fusing	
26	H081 3224	Drive Gear - Fusing - Z25	
27	H513 2184	Timing Belt - S3M-369	
28	H081 3228	Idle Gear - Z28	
29	H510 3268	Drive Shaft Ass'y	
30	H081 3220	Fusing Drive Gear - Z20	
31	H081 3230	Drive Gear - Z75	
32	H510 3269	CTM Drive Gear - Z16	
33	H081 3262	Bushing - M6	
34	H081 3227	Idle Gear - CTM	
35	H081 3307	Timing Belt - Tension	
36	H081 3270	Timing Pulley - OPU - P36	
37	H081 3286	Timing Pulley Holder	
38	H081 3275	Timing Pulley - Joint - Development	
39	H081 3274	Joint Shaft - Development Unit	


INDEX	PART NO.	DESCRIPTION	MODEL
40	H081 3277	Development Drive Gear	
42	H081 3290	Development Drive Shaft	
43	H513 2102	Sub Side Plate - Driver Unit	
44	H081 3231	Driver Gear - Z88	
45	H081 3232	Sector Gear - Z55	
46	H081 3245	Bracket - Drive Gear Ass'y	
47	H081 3109	Stay - Left Side Plate	
48	H081 3266	Development Bias Bushing	
49	H081 3267	Development Bias Terminal	
51	H081 3319	Barcket - Tension Roller	
52	H081 3322	Tension Roller	
54	5447 2768	Stepped Screw - M3	
55	H081 3538	Spring	
56	H081 3311	Bracket - Paper Feed Motor Ass'y	
57	AW50 0010	Push Switch	
58	H081 5506	Harness - Paper Size Sensor	
59	H513 5017	Paper Feed Motor	
60	H511 5528	Harness - CTM/SIF/Thermistor	
61	H081 3182	Left Stay	
62	H081 5532	Transfer Harness - Copy Out Sensor	
64	5419 5714	Stepped Screw - M4	
65	H081 3292	Joint - Development Drive	
66	H513 2111	Shaft Drive Arm - PCU	
71	H081 3221	Arm - Joint Gear - Fusing	
72	H081 3216	Bushing - Fusing	
73	H081 3219	Drive Gear - Fusing - Z24	
74	H081 3128	Joint Spring - Fusing	
75	H081 3250	Left Guide Rail - CTM	
76	H081 3218	Drive Gear - Fusing - Z18	
77	H513 2100	Left Side Plate	
78	H081 3242	CTM Drive Gear - Z16	
79	H081 3254	Bushing - CTM	
80	H081 3140	Spring - Transfer Screw	



INDEX	PART NO.	DESCRIPTION	MODEL
81	AW02 0021	Photointerruptor	
82	H081 3253	Bracket - CTM Sensor	
83	H081 3251	CTM Sensor Lever	
84	H081 3120	Snap Ring - CTM Guide	
85	H081 3139	Spring - PCU Set Lever	
86	H081 3241	Joint - Gear: CTM	
87	H081 3410	Spring Plate	
88	H072 2220	Spacer - M6 x 10	
90	H081 3138	Joint Spring	
91	H513 2188	Bracket - OPU	
92	H513 2176	Spring Belt - OPU: 500	
93	H513 2187	Roller - OPU	
94	H053 1600	Bushing - M6: Cufe	
95	H513 2133	OPU Joint	
96	H513 2140	Bushing - IN: OPU	
97	H513 2135	OPU Shaft	
98	H513 2136	Spring Stopper	
99	H513 2138	Spring Sheet	
100	H513 2137	Friction Pad - OPU	
101	H513 2134	Spring Ring	
102	H513 2145	OPU Spring: 600	
103	H513 2141	Bushing - OUT: OPU	
104	H513 2132	OPU Bracket	
105	H513 2151	Joint Frame	
106	H028 4254	CS Stopper Ring: M3	
107	H513 2154	Joint Stopper	
108	H513 2153	Stepped Screw	
109	H513 2125	Timing Pulley - OPU	
110	H513 2183	Timing Belt - OPU	

INDEX	PART NO.	DESCRIPTION	MODEL

5. BASE



INDEX	PART NO.	DESCRIPTION	MODEL
1	H081 3451	Cassette Guide Rail - Left	
2	H081 3450	Cassette Guide Rail - Right	
3	H082 3413	FCU Holder	
4	H082 3413	FCU Holder	
5	H081 3326	Actuator - Paper End Sensor	
6	H081 3346	Pin - Paper End Actuator	
7	H081 3584	Bracket - Right Cover	
8	H081 3421	Fixing Plate - Right:Rear	
10	H510 3400	Fixing Plate - Left:Rear	
11	H081 3399	Fixing Plate - Left:Front	
12	H020 3623	Snap Ring - Registration Roller	
13	H081 3126	Left Reinforce Bracket	
14	H081 3407	Snap Ring - M2.5	
15	H081 3303	Paper Guide Plate	
16	H081 3416	Paper Feed Roller - A4	
17	H081 3541	Snap Ring - Paper Feed	
18	H081 3589	Shaft - Paper Feed Roller	
19	H510 3320	Transfer Roller	
20	H081 3419	Fixing Plate - Right:Front	
21	H081 3347	Cassette Ground Plate	
22	H081 3125	Right Reinforce Bracket	
23	H081 2865	Master Unit Stopper	
24	H081 3183	Positioning Bracket	
25	H081 3161	Cover - Interlock SW	
26	H081 3122	Seal - Toner Duct	
27	H081 3131	Spring - Right Side Plate - 750	
28	H081 3113	CTM Guide Rail - Right	
29	H081 3123	CTM Guide	
30	H081 3100	Right Side Plate	
31	AW02 0021	Photointerruptor	
32	H513 5105	Harness - Toner End Sensor/ PSU 5V	
33	H081 5526	Harness - Interlock Switch - 5V	
34	H081 5523	Harness - Interlock Switch - 24V	


INDEX	PART NO.	DESCRIPTION	MODEL
35	H510 3107	Lever - Interlock Switch	
36	H510 3108	Bracket - Interlock Switch - 24V	
49	H081 3110	Stay - Right Side Plate	
38	H081 3120	Snap Ring - CTM Guide	
39	5413 1882	Stepped Screw	
40	H081 3162	Ozone Duct	
41	H081 3169	Ozone Filter Holder	
42	H081 3164	Ozone Filter	
43	H081 5038	Ozone Fan	
44	H081 5043	Interlock Switch - LD	
45	H081 3114	Bracket - Interlock Switch - LD	
46	H081 3523	Ground Plate	
48	H081 3173	Right Cover - Bias Terminal	
50	H081 3121	Bias Terminal Plate-Develop./Charge	
51	H081 3172	Bias Terminal	
52	H081 3181	Cover - Development	
53	H081 2511	Holder - Cylindrical Lens Ass'y	
55	H081 2521	Holder - Cylindrical Detector	
56	H081 2556	Harness Holder	
57	H081 2553	Master Unit Guide - Right	
59	H513 3321	Registration Roller	
60	H081 2522	Film - Regist	
61	H081 5014	Registration Sensor	
62	H081 2408	CTM Duct	
63	H513 2560	Base - Laser Unit	
64	H513 2568	Holder - MBU	
65	H081 5024	Zener Diode - 720V - 0.5W : NA	
66	H081 2530	LD Unit	
67	H081 5512	Harness - LDDR	
68	H081 2529	LD Unit Cover	
69	H081 3325	Sensor Bracket	
70	H081 2554	Master Unit Guide - Left	
71	H081 3553	Pulley 35	



INDEX	PART NO.	DESCRIPTION	MODEL
72	H513 5100	PSU Ass'y - 115V	
73	H510 5306	Right Ground Wire	
75	1102 2435	Connector - 6P	
76	H513 3588	Stopper - Right Cassette	
77	H081 3305	Rubber Foot	
78	H081 3409	Standard Pin	
79	H081 3561	Standard Pin - Stay	
81	H081 5539	Harness - P.F/M.Motor/PPack/SIF 24	
82	H081 3558	Connector - Cover	
83	H081 4141	Screw - Handset	
84	H081 3587	Stopper - Left Cassette	
85	H511 5528	Harness - CTM/SIF/Thermistor	
86	H510 5001	Push Switch	
90	H513 5103	Right Ground Wire	
91	H082 3152	Bushing - 012	

INDEX	PART NO.	DESCRIPTION	MODEL


6. CASSETTE



INDEX	PART NO.	DESCRIPTION	MODEL
1	H081 3352	Cassette Bottom Plate	
2	H081 3354	Pressure Spring - Cassette	
3	H081 3361	Left Side Fence	
6	H081 3369	Pressure Plate - End Fence	
7	H081 3364	End Fence	
8	H081 3350	Cassette - B4	
9	H081 3357	Right Side Fence	
10	H081 3381	Registration Spring	
11	H081 3379	Holder - Registration Spring	
12	H081 3378	Shaft - Regist. Pressure Roller	
13	H081 3377	Registration Pressure Roller	
14	H081 4297	Decal - Paper Set	
15	H081 3376	Guide Plate - Transfer Roller	
16	H081 3526	Registration Guide Plate	
17	H081 3521	Film - Regist Guide Plate - Side	
19	H081 3395	Cassette Retaining Shaft	
20	H081 3397	Pressure Plate - Cassette Ret.Shaft	
21	H081 3371	Shaft - Transfer Perssure Roller	
22	H081 3403	Pressure Plate - Transfer Roller	
23	H081 3370	Transfer Pressure Roller	
25	H081 3368	Spring - Slider	
26	H081 3366	Slider - Cassette	
27	H081 3367	Slider Cover	
28	H081 3386	Paper Size Detector Pin - Letter	
28	H081 3388	Paper Size Detector Pin - Legal	
29	H081 3394	Pressure Roller - Registration	
40	H081 3353	Bottom Pad	

INDEX	PART NO.	DESCRIPTION	MODEL

7. OPTIONS





INDEX	PART NO.	DESCRIPTION	MODEL
1	H513 6016	PCB - OPHDIF	
2	H520 8200	Hard Disk Drive	
3	H520 6009	HDD Connector Board	
4	H513 6013	HDD Interface Board (PCB - HDIF)	
5	H513 5102	Hard Disk Cable	
6	H130 4012	Cover - Hard Disk	
7	H513 6017	PCB - OPIF	
8	H510 5321	Flat Cable - PIF/FCU	
9	H510 6005	PCB - PIF	
10	H144 3167	Stud - PIF	
11	H510 5610	Printer Controller (PCB - CNT)	
12	H510 5320	Flat Cable - PIF/CNT	
13	G011 1250	Stepped Screw - Controller	
14	H144 3168	Cover - Option Memory Board	
15	H144 4126	Guide - Memory Card Option	
16	H081 4141	Screw - Handset	
17	H144 4125	Rear Cover - Memory : PIF	
18	H144 4110	Rear Cover - Printer Option	
19	H144 4124	Cover - RS232C	
20	H144 4121	Cover - Cartridge	
21	H144 4128	Spring - Cover Cartridge	
22	H144 4120	Cover - Left : PIF	
23	H082 6034	PCB - CIG4	
24	H302 5700	ISDN Cable	
25	H143 4010	Cover - CIG4 Connector	
*	H150 4303	Operator's Manual - PIF	

INDEX	PART NO.	DESCRIPTION	MODEL

8. SCREWS, ETC.

INDEX	PART NO.	DESCRIPTION	MODEL
200	0252 0080B	Screw - M2x8	
201	0313 0060B	Philips Pan Head Screw - M3x6	
202	0313 0200B	Philips Pan Head Screw - M3x20	
203	0313 0140B	Philips Pan Head Screw - M3x14	
204	0314 0060B	Philips Pan Head Screw - M4x6	
205	0323 0060B	Philips Sunk Screw - M3x6	
206	0353 0060B	Philips Truss Head Screw M3x6	
207	0353 0060Z	Philips Truss Head Screw - M3x6	
208	0433 0062B	Tapping Pan Head Screw - M3x6	
209	0433 0082B	Tapping Pan Head Screw - M3x8	
210	0573 0040E	Hexagon Headless Set Screw - M3x4	
211	0573 0060E	Hexagon Headless Set Screw - M3x6	
212	0701 0060E	Washer - M6	
213	0720 0020E	Retaining Ring - M2	
214	0720 0030E	Retaining Ring - M3	
215	0720 0040E	Retaining Ring - M4	
216	0720 0050E	Retaining Ring - M5	
217	0802 5205B	Tapping Screw M3x6	
218	0802 5206B	Tapping Screw M3x8	
219	0952 3030B	Philips Screw with Lock Washer - M3x30	
220	0950 3008B	Philips Screw with Lock Washer - M3x8	
221	0951 3005B	Philips Screw with Flat Washer M3x5	
222	0951 3006B	Philips Screw with Flat Washer - M3x6	
223	0954 3008B	Double Sems Screw - M3x8	
224	0954 3006B	Double Sems Screw - M4x8	
225	0964 3006B	Tapping Screw - M3x6	
226	0965 3006B	Tapping Screw with Flat Washer M3x6	
227	0965 3010B	Tapping Screw with Flat Washer M3x10	
228	0965 3012B	Tapping Screw with Flat Washer M3x12	
229	0965 3008B	Tapping Screw with Washer - M3x8	
230	1102 5071	Connector - 9P	

INDEX	PART NO.	DESCRIPTION	MODEL
231	1102 5194	Connector - 7P	
232	1102 4473	CT Connector - 2P	
233	1105 0113	Edge Saddle - EDS2	
234	1105 0234	Clamp	
235	1105 0246	Spacer	
236	1105 0344	Clamp	
237	1105 0260	Wire Saddle	
238	5053 0223	Bushing - 8mm	
239	5053 0447	Bushing - 6mm	
240	0964 3006Z	Tapping Screw - M3x6	
241	0443 0060W	Tapping Screw - M3x6	
242	1102 4431	Connector - Sub Harness	
243	1102 4473	CT Connector - 2P	
244	1102 4559	Connector - 3P	
245	1102 4560	CT Connector 6P	
246	1102 5142	Connector - 2P - Black	
247	1102 5145	Connector - 3P - Blue	
250	0313 0040B	Philips Pan Head Screw - M3 x 4	
251	0433 0080B	Tapping Pan Head Screw - M3 x 8	
252	0433 0102B	Tapping Pan Head Screw - M3 x 10	
253	0801 0139	± W-Point Screw - M3 x 10	
254	5403 2075	Screw - Bush	
255	0433 0122B	Tapping Pan Head Screw - M3 x 12	
256	0313 0030B	Philips Pan Head Screw - M3 x 3	
257	0443 0060Z	Tapping Pan Head Screw - M3 x 6	
258	0954 3010B	Double Sems Screw - M3 x 10	
259	0353 0050B	Philips Truss Head Screw - M3 x 5	
260	0720 0070E	Retaining Ring - M7	
261	0353 0080Z	Philips Trass Head Screw - M3 x 8	
262	0964 3008B	Tapping Screw - M3 x 8	
263	0951 3010B	Philips Screw with Flat Washer - M3 x10	