

RICOH

PARTS CATALOG

FOR

**RICOH FAX2700L
[Asia]**

RICOH COMPANY, LTD.

1	May 31st, 1995	First edition

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.


INDEX to PARTS CATALOG

Section 1.Part Location and List

1.Exterior.....	1- 2
2.ADF (Lower Unit)	1- 6
3.Operation Panel / ADF (Upper Unit)	1- 4
4.Scanner.....	1- 8
5.Laser Unit.....	1-10
6.Development.....	1-12
7.Fusing	1-14
8.Main Frame 1	1-16
9.Main Frame 2.....	1-18
10.250 Sheet Cassette	1-20
11.100 Sheet Cassette (Optional).....	1-22

Section 2.Parts Index..... 2- 1

1. EXTERIOR




1.EXTERIOR

INDEX	PARTS NO.	DESCRIPTION	Note
*	H516 8609	Operating Insutructions - ASIA	
1	H516 4046	Cover - PIF - 2	
2	H516 4040	Cover - PIF	
3	H516 4045	Cover - Rear - 2	
4	H516 4047	Cover - NCU - E	
5	H516 4034	Document Tray	
6	H516 4026	Cover - Counter	
7	H516 4068	Cover - Rear - 1	
8	H515 2724	Clip - Laser Unit	
9	H521 2040	Laser Protter Unit	
10	H516 6006	PCB - FCE - ASIA	
11	H516 6005	PCB - FDU - FX6 - EUROPE	
12	5488 6040	PCB - NCU - EUROPE/ASIAUSA	
13	H516 1058	Cover - Scanner - Left	
14	H090 4025	Telephone Line - RIF	
15	H516 4070	Cover - Right	
16	H516 4048	Cover - 232C	
17	H516 4043	Cover - Connector	
18	H516 4023	Cover - IC Memory Card	
19	H516 4020	Cover - Left	
20	H516 5031	Monitor Speaker	
21	H516 4049	Guide - IC Card	
22	H515 3130	Cover - Power Pack	
23	H516 5047	Power Supply - Pack - A4	
24	H515 3116	Fulcrum - Fusing Unit	
25	H521 3164	Pin - Right Fulcrum	
26	H521 5402	PSU 220V	
27	H516 3134	Cover - PSU	
28	H516 4028	Document Table	
29	H516 4032	Copy Tray - A4	
30	H521 4033	Copy Tray Extension	
31	H521 5309	Harness - NCU	

INDEX	PARTS NO.	DESCRIPTION	Note
32	H516 5318	Harness - Power Pack	
33	H516 5308	Driver Harness	
34	H516 5316	Harness - Paper Feed Motor	
35	H516 5309	Harness - TX Motor	
36	H516 5313	Harness - Main Motor ETC.	
37	H521 5322	Harness - PSU	
38	H516 5322	Relay Harness - Fusing Unit	
39	H516 5301	Harness - Paper Size	
40	H515 2734	Bracket - Base	
41	G011 3275	Snap Ring	


2. ADF (Lower Unit)





1-5


3. OPERATION PANEL / ADF (Upper Unit)






1-7

4. SCANNER




INDEX	PARTS NO.	DESCRIPTION	Note

5. LASER UNIT



INDEX	PARTS NO.	DESCRIPTION	Note

6. DEVELOPMENT




6.DEVELOPMENT

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2414	Bearing - Dvlp. Roller - Left	
2	H515 2451	Gear	
3	H516 2519	Rubber Roller - Development - A4	
4	H515 2415	Bearing - Dvlp. Roller - Right	
5	H515 2405	Rubber Roller Ass'y - DNLP -B4	
6	H516 2401	Development Unit - A4	
7	H516 2500	Toner Duct - A4	
8	H516 2524	Film - Toner Duct - A4	
9	H515 2506	Seal - Duct - S	
10	H516 2505	Toner Duct Shield - A4 - 2	
11	H515 2506	Seal - Duct - S	
12	H516 2432	Cover - Toner Hopper - A4	
13	H515 2536	Seal - Development - C	
14	H516 2549	Seal - Toner Duct - Lower - A4	
15	H516 2544	Toner Agitator - Development	
16	H516 2516	Magnet Roller - Development - A4	
17	H515 2502	Seal - Roller	
18	H515 2535	Seal - B	
19	H515 2474	Terminal Plate - Development - L	
20	H515 2530	Terminal Plate - B	
21	H515 2481	Terminal Plate - A	
22	H516 5045	Cable - Charge Bias - A4	
23	H515 2478	Terminal Plate - Charge - M	
24	H516 2475	Terminal - Rubber Roller - A4	
25	H515 2473	Terminal Plate - Development - S	
26	H515 2534	Seal - Development - A	
27	H515 2471	Terminal Plate - Transfer - L	
28	H516 5046	Cable - Transfer Bias - A4	
29	H516 2548	Film - Toner Hopper - A4	
30	H516 2555	Lower Seal	
31	H515 2487	Stopper - Pin	
32	H515 2488	Stopper - Receptacle	

INDEX	PARTS NO.	DESCRIPTION	Note
33	H516 2412	Toner Metering Blade - A4	
34	H516 2528	Sheild - Rubber Roller - A4	
35	H516 2518	Antistatic Brush - Mag. Roller - A4	
36	H515 2452	Gear - Transfer Roller	
37	H515 2461	Transfer Roller	
38	H516 2419	Transfer Roller - A4	
39	H515 2455	Holder - Transfer Roller - Left	
40	H515 2485	Spring - Transfer Roller	
41	H515 2456	Holder - Transfer Roller - Right	
42	H515 2417	Terminal - Quenching Lamp	
43	H516 2431	Guide - Transfer Roller - A4	
44	H515 2469	Terminal Plate - Transfer - S	
45	H516 2460	Antistatic Brush - Separation - A4	
46	H515 2472	Terminal Plate - Separation	
47	H515 2468	Terminal Plate - Ground	
48	H515 2482	Terminal Plate - OPC Drum	
49	H515 2543	Holder - Terminal Plate - OPC Drum	
50	H515 2493	Drive Gear - Fusing	
51	H515 2450	Idler Gear 6	
52	H515 2467	Shaft - Idler 6	
53	H515 2492	Bracket - Fusing Drive Gear	
54	H515 2494	Shaft - Drive Gear - Fusing	
55	H515 2462	Shaft - Idler 1	
56	H515 2443	Idler Gear 1 - Small	
57	H515 2444	Idler Gear 1 - Large	
58	H515 2445	Idler Gear 2 - Large	
59	H515 2413	Gear - Agitator	
60	H515 2442	Gear - MAG. Roller	
61	H515 2411	Bearing - Mag. Roller - Right	
62	H515 2463	Shaft - Idler 2	
63	H515 2457	Bushing - Idler 2 - Large	
64	H515 2466	Shaft - Idler 5	

7. FUSING




7.FUSING

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2143	Holder - Thermistor	
2	H515 5015	Thermistor - Fusing	
3	H515 2149	Actuator - Fusing Exit Sensor	
4	H515 2161	Spring - Sensor Actuator	
5	H515 2153	Spring - Hot Roller Stripper	
6	H515 2181	Separation Hook - Fusing	
7	H516 2159	Cover - Thermistor	
8	H516 2112	Upper Case - Fusing - A4	
9	H515 2127	Idler Gear - Z18	
10	H515 2167	Holder - Fusing Lamp	
11	H515 2119	Cover - Gear	
12	H515 2128	Gear - Fusing Exit Roller	
13	H515 2139	Bushing - Fusing Exit Roller	
14	H515 2166	Roller - Exit Roller	
15	H516 2127	Spacer - Fusing Exit Roller - Left	
16	H516 2117	Fusing Exit Roller - A4	
17	H515 2125	Idler Gear - Z17	
18	H515 2124	Idler Gear - Z22-18	
19	H515 2189	Grounding Plate Holder	
20	H515 5017	Thermostat - Fusing	
21	H516 2146	Terminal Plate - Thermostat - 2	
22	H515 2145	Terminal Plate - Thermostat - 1	
23	H515 2137	Bearing - Hot Roller	
24	H515 2160	Stopper - Hot Roller	
25	H515 2141	Spacer - Hot Roller	
26	H516 2110	Roller - Fusing - A4	
27	H515 2126	Gear - Hot Roller	
28	H516 5017	Heater - A4 - 220V	
29	H515 5022	Harness - Fusing Lamp	
30	H515 2155	Fusing Right Cover	
31	AW02 0021	Photointerruptor - 175487-3	
32	H521 5312	Harness - Fusing Sensors	

INDEX	PARTS NO.	DESCRIPTION	Note
33	H515 2179	Cover - Connector	
34	H515 5018	Cover Switch - Fusing Exit	
35	H516 2198	Stopper - Fusing	
36	H515 2134	Lock Lever - Right	
37	H516 2119	Bracket - Table - Original	
38	H516 2152	Antistatic Brush - Fusing - A4	
39	H515 2135	Shaft - Lock Lever	
40	H515 2178	Bracket - Lamp Connector	
41	H515 2180	Bracket - Idler Gear	
42	H515 2157	Fusing Inner Cover - Right	
43	H515 2133	Lever - Lock - Left	
44	H515 2136	Spring - Lock Lever	
45	H516 2121	Inner Cover - A4	
46	H515 2176	Bracket - Pressure Roller - Right	
47	H516 2173	Guide - Fusing - A4	
48	H515 2154	Spring - Pressure Roller	
49	H515 2169	Bearing - Pressure Roller	
50	H515 2163	Spring Plate - Right	
51	H516 2111	Pressure Roller - A4	
52	H516 2116	Lower Case - Fusing - A4	
53	H515 2182	Stepped Screw	
54	H515 2177	Bracket - Pressure Roller - Left	
55	H515 2164	Spring Plate - Left	
56	H515 2171	Spring Plate - Pressure Roller	
57	H515 2156	Ground Plate - Hot Roller	
58	H515 5024	Ground Wire - Fusing	
59	H515 2158	Fusing Inner Cover - Left	
60	H515 2165	Fusing Left Cover	
61	H515 2121	Spring Plate - Fusing Exit	
62	H515 2122	Fusing Exit Roller	
63	H516 2126	Bracket - Fusing - A4	
64	H516 2120	Cover - Exit - A4	

8. MAIN FRAME 1




8.MAIN FRAME 1

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3131	Bracket - Rear	
2	H516 3133	Bracket - Rear - Left	
3	H516 3132	Bracket - PSU	
4	H516 3146	Bracket - Toner End Sensor	
5	H515 5050	Toner End Sensor	
6	H516 3128	Bracket - Cord Clamper	
8	H521 3144	Harness Clamp	
9	H515 3114	Slider - Interlock SW.	
10	H515 3111	Bracket - Interlock SW.	
11	H516 5315	Harness - Interlock SW. - 24V	
12	H521 5324	Relay Harness - Interlock - 5V	
13	H515 3112	Actuator - Interlock SW.	
14	H516 3137	Bracket - Top Cover Locking - Right	
15	H081 5043	Interlock Switch - LD	
16	H516 5319	Harness - Interlock SW. - 5V	
17	H516 5041	Cooling Fan Motor - DC24V;3.6W	
18	H516 3139	Bracket - Cooling Fan	
19	H521 3147	Sponge - Cooling Fan - 1	
20	H521 3148	Sponge - Cooling Fan - 2	
21	H521 3149	Sponge - Cooling Fan - 3	
22	H521 3150	Sponge - Cooling Fan - 4	
22	H516 3152	Sponge - 5	
23	H521 3145	Sponge - Lock - Front	
24	H516 3380	Mylar - Bracket - Registration	
25	H521 3379	Sponge - Bracket - Pressure Roller	
26	H516 3376	Ground Plate - Bracket - Regist.	
27	H521 5054	Registration Sensor	
28	H516 3358	Spring - Pressure Roller	
29	H521 3340	Pressure Roller - Registration	
30	H516 3434	Shaft - Pressure Roller	
31	H516 3345	Bracket - Pressure Roller	
32	H516 3152	Sponge - 5	

INDEX	PARTS NO.	DESCRIPTION	Note
33	H516 3116	Spacer - Development Unit - A4	
34	AW02 0021	Photointerruptor - 175487-3	
35	H516 5311	Sensor Harness	
36	H521 3160	Sponge - Base - Bottom	
37	H521 3162	Seal - Base - Bottom - 2	
38	H521 3161	Seal - Base - Bottom - 1	
39	H521 3157	Sponge - Registration - 2	
39	H515 2551	Seal - Duct - R	
40	H521 3159	Sponge - Power Pack - 2	
41	H515 3110	Base - Plotter	
42	H521 3158	Sponge - Power Pack - 1	
43	H521 3156	Sponge - Registration - 1	
44	H521 3352	Bracket - Plotter Base Connection	
45	H516 3135	Bracket - Top Cover Locking - Left	
46	H516 3141	Bracket - Ozone Filter	
47	H516 3142	Ozone Filter - 8	
48	H515 5041	Ozone Fan Motor - DC24V;1.44W	
49	H516 3140	Bracket - Ozone Fan	
50	H516 3155	Insulating Sheet - PSU	
51	H516 3156	Insulating Sheet - NCU	
52	H516 3153	Sponge - Cushion - Cooling Fan	
53	H516 3144	Bracket - PIF - 1	
54	H516 3145	Bracket - PIF - 2	
55	H516 3143	Sponge - Cushion - Ozone Fan	
56	H516 3129	Ground Plate - Left	
57	H515 2199	Front Fixing Plate	
58	H521 5310	Sensor Harness	
60	H516 3149	Sponge - 2	
61	H516 3150	Sponge - 3	
62	H516 3151	Sponge - 4	
63	H516 3148	Sponge - 1	
64	H521 3153	Sponge - Base - Left - Middle	

9. MAIN FRAME 2




9.MAIN FRAME 2

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 3374	Holder - FDU	
2	H516 3342	Base - Main Board	
3	H516 3335	Shaft - Feed Roller - Left	
4	H516 3373	Stay - Feed Roller	
5	H516 3370	Paper Feed Roller	
6	H516 3372	Shaft - Feed Roller - Right	
7	H516 3322	Side Plate - Right	
8	H516 3333	Lock - Cassette - Right	
9	H516 3332	Lock - Cassette - Left	
10	H516 3331	Rail - Cassette - Rear	
11	H516 5050	Paper End Sensor	
12	H516 3341	Bracket - Paper End Sensor	
13	H516 3379	Ground Plate - Paper Feed Motor	
14	H006 2383	Snap Ring	
15	H516 5052	Stepper Motor-paper Feed 24VDC13W	
16	H516 3301	Gear Box - Paper Feed	
17	H516 3359	Cover - Harness - Paper Size Sensor	
18	H516 3346	Bracket - Paper Size Sensor	
19	H516 3320	Guide - 100 Sheet Cassette - Right	
20	H516 5301	Harness - Paper Size	
21	H515 5054	Paper Size Sensor	
22	H516 3330	Rail - Cassette - Front	
23	H516 3328	Spacer - Cassette Entrance - Right	
24	H516 3329	Spacer - Cassette Entrance - Left	
25	H516 3361	Rubber Foot	
26	H516 3316	Bottom Base	
27	H516 3319	Guide - 100 Sheet Cassette - Left	
28	H516 3344	Ground Plate - Registration Roller	
29	H020 1234	Cord Clamp	
30	H515 5085	Harness - 100 Sheet Cassette	
31	H516 3326	Side Plate - Left	
32	H515 3544	E-ring - JR-E6	

INDEX	PARTS NO.	DESCRIPTION	Note
33	H516 5325	Grounding Wire - 190mm	
34	H516 3147	Harness Clamper - Base	

10. 250 SHEET CASSETTE




10.250 SHEET CASSETTE

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3438	Spring Plate - End Fence	
2	H516 3414	End Fence - Cassette	
3	H516 3439	Stopper - Fence	
4	H516 3471	Sponge - End Fence	
5	H516 3401	Cassette Base - Universal	
6	H516 3470	Decal - Paper Set - Cassette	
7	H516 3410	Bottom Plate - Cassette	
8	H516 3421	Friction Pad - Bottom Plate - Large	
9	H516 3450	Spring Bottom Plate	
10	H521 3419	Friction Pad - Bottom Plate - Small	
11	H516 3423	Paper Guide Plate - Regist. - Left	
12	H516 3424	Paper Guide Plate - Regist. - Right	
13	H516 3447	Spring - Registration Roller	
14	H516 3419	Gear - Registration Roller	
15	H516 3416	Registration Roller	
16	H516 3482	Spring Plate - Bracket -right	
17	H516 3462	Bracket - Pressure Roller - Cass.	
18	H516 3448	Spring - Pressure Roller	
19	H516 3435	Actuator - Bypass Feed Sensor	
20	H516 3449	Spring - Bypass Sensor Actuator	
21	H516 3434	Shaft - Pressure Roller	
22	H521 3340	Pressure Roller - Registration	
23	H516 3463	Guide - Pressure Roller - Cass.	
24	H516 3413	Separation Hook - Cassette - Right	
25	H516 3381	Ground Plate - Cassette - Left	
26	H516 3415	Paper Guide Plate - Bypass	
27	H516 3437	Manual Feed Table	
28	H516 3422	Paper Size Indicator - A5	
28	H516 3429	Paper Size Indicator - A4	
28	H516 3432	Paper Size Indicator - F/F4	
29	H516 3425	Lock - Bottom Plate	
30	H516 3426	Spring - Lock - Bottom Plate	

INDEX	PARTS NO.	DESCRIPTION	Note
31	H516 3444	Mylar - Paper Guide - 2	
32	H516 3411	Separation Hook - Cassette - Left	
33	H516 3583	Decal - Bypass Feed	
34	H516 3412	Side Fence - Cassette	
35	A048 6149	Decal - Manual Feed	
36	H516 3446	Mylar - Paper Guide - 4	
37	H516 3443	Mylar - Paper Guide - 1	
38	H516 3445	Mylar - Paper Guide - 3	
39	H516 3417	Bushing - Registration Roller	
41	H516 3469	Cover - Manual Feed Table	
42	H516 3465	Support Plate - End Fence	
43	H516 4088	Cover Cassette	

11. 100 SHEET CASSETTE (OPTIONAL)





11.100 SHEET CASSETTE (OPTIONAL)

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 3557	Paper Feed Roller	
2	H515 3529	Friction Pad - Large	
3	H515 3530	Friction Pad - Small	
4	H515 3517	Bottom Plate - Cassette	
5	H516 3532	Spring - Bottom Plate	
6	H515 3524	Corner Separator - Right	
7	H515 3556	Bracket - Paper End Sensor	
8	H515 5076	Paper End Sensor	
9	H515 3545	Cover - Paper End Sensor	
10	H515 3531	Bushing - Paper Feed Roller	
11	H515 5075	Paper Feed Clutch	
12	H515 3543	Retaining Ring - M4	
13	H515 3533	Spring - Gear Arm	
14	H515 3526	Bracket - Gear Arm	
15	H515 3528	Gear - Z26	
16	H515 3527	Gear - Z32	
17	H515 3544	E-ring - JR-E6	
18	H515 3555	Decal - Paper Set	
19	H515 3550	Cover - Bypass Feed	
20	H515 3552	Bypass Feed Table Ass'y	
21	H515 3518	Cover - Cassette	
22	H515 3540	Paper Tray Extension	
23	H515 3546	Lower Cover	
24	H515 3522	End Fence	
25	H515 3554	Decal - Paper Limit	
26	H515 3539	Spring Plate - Lock	
27	H516 3510	Paper Tray - 100 Sheet Cassette	
28	H515 5054	Paper Size Sensor	
29	H515 3519	Paper Size Indicator	
30	H515 3535	Spring - Paper Size Indicator	
31	H515 3538	Shaft - Paper Size Indicator	
32	H516 3426	Spring - Lock - Bottom Plate	

INDEX	PARTS NO.	DESCRIPTION	Note
33	H516 3425	Lock - Bottom Plate	
34	H515 5080	Relay Harness Assembly	
35	H515 3542	Rivet	
36	H515 3523	Corner Separator - Left	
37	H515 3521	Knob - Side Fence	
38	H515 3534	Spring - Side Fence	
39	H515 3520	Side Fence	
40	H516 3581	Decal - By-pass Feed (100 Cassette)	
41	H515 3541	Gear Cover	
42	H515 3553	Stopper - Corner Separator	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0313 0060B	Philips Pan Head Screw - M3x6	
102	0313 0080B	Philips Pan Head Screw - M3x8	
103	0353 0080Z	Philips Trass Head Screw - M3x8	
104	0413 0082W	Tapping Screw - M3x8	
105	0433 0102B	Tapping Screw - M3x10	
106	0443 0060W	Hexagon Head Tapping Screw - M3x6	
107	0632 0100G	Pin - 2x10mm	
108	0633 0120G	Parallel Pin - 3x12	
109	0707 3050B	Bushing - 3x5mm	
110	0720 0020E	Retaining Ring - M2	
111	0720 0025E	Retaining Ring - M2.5	
112	0720 0030E	Retaining Ring - M3	
113	0720 0040E	Retaining Ring - M4	
114	0720 0050E	Retaining Ring - M5	
115	0720 0060E	Retaining Ring - M6	
116	0802 5205	Tapping Screw - M3x6	
117	0802 5206	Tapping Screw - M3x8	
118	0802 5230	Tapping Screw - M3x10	
119	0805 3386	Bushing - 8mm	
120	0951 3006B	Philips Screw With Flat Washer-M3x6	
121	0951 3008B	Philips Screw With Flat Washer-M3x8	
122	0954 3006B	Screw - M3X6	
123	0957 3006B	Screw - M3X6	
124	0965 3006B	Tapping Screw With Flat Washer M3x6	
125	0965 3008B	Tapping Screw With Washer - M3x8	
126	0965 3010B	Tapping Screw With Flat WasherM3x6	
127	0965 3012B	Tapping Screw With Washer - M3x12	
128	1102 4681	Connector - 5557-02R-210	
129	1105 0243	Wire Saddle	
130	1105 0260	Wire Saddle	
131	1105 0283	Clamp	
132	1105 0344	Clamp	

INDEX	PARTS NO.	DESCRIPTION	Note
133	1204 2334	Safety Switch - FA1I-AA20	
134	1407 3952	IC - ANALOG SW- 4053	
135	0802 5210	Tapping Screw - M3x8	
136	1102 4473	CT Connector - 2P	
137	0313 0040B	Philips Pan Head Screw - M3x4	
138	0964 3006B	Tapping Screw - M3x6	

PARTS INDEX

PART N O.	DESCRIPTION	INDEX
H006 2383	Snap Ring	19- 14
H020 1234	Cord Clamp	19- 29
H053 1600	Bushing - M6 : CMFE	5- 9
H053 1600	Bushing - M6 : CMFE	9- 5
H081 1147	Pressure Roller Assy	7- 1
H081 2438	Shaft - Agitator	13- 81
H081 4052	Decal - Laser	11- 1
H081 5043	Interlock Switch - LD	17- 15
H090 4025	Telephone Line - RIF	3- 14
H515 1062	Bushing - R1/R2 Rollers	9- 1
H515 1204	ADF Feeder Unit	5- 1
H515 1205	Separation Plate Ass'y	7- 20
H515 1250	ADF Guide Plate - Upper	7- 16
H515 1251	Guide Plate - ADF - Lower	5- 8
H515 1263	Bracket - Grounding	7- 10
H515 1266	Pulley - R2 Roller	9- 6
H515 1267	Grounding Plate	7- 15
H515 1271	Shaft - Separetion Pressure	7- 14
H515 1277	Clip - Base - Shading Plate	7- 17
H515 1278	Shading Plate	7- 19
H515 1279	Base - Shading Plate	7- 18
H515 1282	Rack Gear - Document Guide	5- 19
H515 1283	Pinion Gear - Document Guide	5- 20
H515 1284	Shaft - Document Feed	5- 10
H515 1285	Gear - Document Feed	5- 4
H515 1290	Plumber Block - ADF Roller - Right	5- 5
H515 1291	Plumber Block - ADF Roller - Left	5- 3
H515 1292	Cover - ADF	5- 2
H515 1293	Pressure Plate - Pickup	7- 21
H515 1294	Shaft - Lock	5- 27
H515 1295	Sping - Lock	5- 13

PART N O.	DESCRIPTION	INDEX
H515 1296	Lever - Lock Release	5- 15
H515 1297	Lock Lever - Operation Panel	5- 16
H515 1298	Spring Plate - CTM	5- 17
H515 1301	Shaft - Pressure Roller	7- 5
H515 1303	Spring - Shading Plate	7- 26
H515 1304	Hook - Cover Lock - Right	5- 14
H515 1305	Hook - Cover Lock - Left	5- 21
H515 1306	Guide - Original - Right	5- 7
H515 1307	Guide - Original - Left	5- 6
H515 1312	Pressure Roller - R1	7- 7
H515 1313	Sponge Collar - R1	7- 6
H515 1318	Bracket - Top Cover	5- 23
H515 1321	Sponge - Fusing 1	5- 26
H515 1323	Spring Plate - R1/R2 - Left	7- 12
H515 1324	Spring Plate - R1/R2 - Right	7- 13
H515 1331	Mylar - ADF	7- 22
H515 1335	Ground Plate - ADF - Lower 2	5- 22
H515 1336	Spring	7- 25
H515 1337	Grownding Wire Holder	5- 25
H515 2119	Cover - Gear	15- 11
H515 2121	Spring Plate - Fusing Exit	15- 61
H515 2122	Fusing Exit Roller	15- 62
H515 2124	Idler Gear - Z22-18	15- 18
H515 2125	Idler Gear - Z17	15- 17
H515 2126	Gear - Hot Roller	15- 27
H515 2127	Idler Gear - Z18	15- 9
H515 2128	Gear - Fusing Exit Roller	15- 12
H515 2133	Lever - Lock - Left	15- 43
H515 2134	Lock Lever - Right	15- 36
H515 2135	Shaft - Lock Lever	15- 39
H515 2136	Spring - Lock Lever	15- 44

PART N O.	DESCRIPTION	INDEX
H515 2137	Bearing - Hot Roller	15- 23
H515 2139	Bushing - Fusing Exit Roller	15- 13
H515 2141	Spacer - Hot Roller	15- 25
H515 2143	Holder - Thermistor	15- 1
H515 2145	Terminal Plate - Thermostat - 1	15- 22
H515 2149	Actuator - Fusing Exit Sensor	15- 3
H515 2153	Spring - Hot Roller Stripper	15- 5
H515 2154	Spring - Pressure Roller	15- 48
H515 2155	Fusing Right Cover	15- 30
H515 2156	Ground Plate - Hot Roller	15- 57
H515 2157	Fusing Inner Cover - Right	15- 42
H515 2158	Fusing Inner Cover - Left	15- 59
H515 2160	Stopper - Hot Roller	15- 24
H515 2161	Spring - Sensor Actuator	15- 4
H515 2163	Spring Plate - Right	15- 50
H515 2164	Spring Plate - Left	15- 55
H515 2165	Fusing Left Cover	15- 60
H515 2166	Roller - Exit Roller	15- 14
H515 2167	Holder - Fusing Lamp	15- 10
H515 2168	Lock Spring - Cleaning Pad	15- 69
H515 2169	Bearing - Pressure Roller	15- 49
H515 2171	Spring Plate - Pressure Roller	15- 56
H515 2176	Bracket - Pressure Roller - Right	15- 46
H515 2177	Bracket - Pressure Roller - Left	15- 54
H515 2178	Bracket - Lamp Connector	15- 40
H515 2179	Cover - Connector	15- 33
H515 2180	Bracket - Idler Gear	15- 41
H515 2181	Separation Hook - Fusing	15- 6
H515 2182	Stepped Screw	15- 53
H515 2184	Decal - Warning	15- 66
H515 2189	Grounding Plate Holder	15- 19

PART N O.	DESCRIPTION	INDEX
H515 2199	Front Fixing Plate	17- 57
H515 2405	Rubber Roller Ass'y - DNLP -B4	13- 5
H515 2410	Bearing - Mag. Roller - Left	13- 76
H515 2411	Bearing - Mag. Roller - Right	13- 61
H515 2413	Gear - Agitator	13- 59
H515 2414	Bearing - Dvlp. Roller - Left	13- 1
H515 2415	Bearing - Dvlp. Roller - Right	13- 4
H515 2416	Main Motor Ass'y - DC24V;16.1W	13- 67
H515 2417	Terminal - Quenching Lamp	13- 42
H515 2442	Gear - MAG. Roller	13- 60
H515 2443	Idler Gear 1 - Small	13- 56
H515 2444	Idler Gear 1 - Large	13- 57
H515 2445	Idler Gear 2 - Large	13- 58
H515 2446	Drive Gear - Opc Drum	13- 75
H515 2447	Idler Gear 3	13- 69
H515 2448	Idler Gear 4	13- 70
H515 2449	Idler Gear 5	13- 65
H515 2450	Idler Gear 6	13- 51
H515 2451	Gear	13- 2
H515 2452	Gear - Transfer Roller	13- 36
H515 2455	Holder - Transfer Roller - Left	13- 39
H515 2456	Holder - Transfer Roller - Right	13- 41
H515 2457	Bushing - Idler 2 - Large	13- 63
H515 2458	Bushing - Idler 2 - Small	13- 73
H515 2461	Transfer Roller	13- 37
H515 2462	Shaft - Idler 1	13- 55
H515 2463	Shaft - Idler 2	13- 62
H515 2466	Shaft - Idler 5	13- 64
H515 2467	Shaft - Idler 6	13- 52
H515 2468	Terminal Plate - Ground	13- 47
H515 2469	Terminal Plate - Transfer - S	13- 44

PART N O.	DESCRIPTION	INDEX
H515 2471	Terminal Plate - Transfer - L	13- 27
H515 2472	Terminal Plate - Separation	13- 46
H515 2473	Terminal Plate - Development - S	13- 25
H515 2474	Terminal Plate - Development - L	13- 19
H515 2478	Terminal Plate - Charge - M	13- 23
H515 2481	Terminal Plate - A	13- 21
H515 2482	Terminal Plate - OPC Drum	13- 48
H515 2485	Spring - Transfer Roller	13- 40
H515 2487	Stopper - Pin	13- 31
H515 2488	Stopper - Receptacle	13- 32
H515 2491	Inner Cover - Development	13- 72
H515 2492	Bracket - Fusing Drive Gear	13- 53
H515 2493	Drive Gear - Fusing	13- 50
H515 2494	Shaft - Drive Gear - Fusing	13- 54
H515 2495	Spring - Bracket - Fusing Drive	13- 68
H515 2496	Terminal Plate - Grid	13- 74
H515 2502	Seal - Roller	13- 17
H515 2506	Seal - Duct - S	13- 9
H515 2506	Seal - Duct - S	13- 11
H515 2530	Terminal Plate - B	13- 20
H515 2534	Seal - Development - A	13- 26
H515 2535	Seal - B	13- 18
H515 2536	Seal - Development - C	13- 13
H515 2537	Seal - Development - D	13- 88
H515 2541	Deal - Shutter Guide	13- 66
H515 2542	Stopper - Bearing - M6	13- 77
H515 2543	Holder - Terminal Plate - OPC Drum	13- 49
H515 2547	Holder - Harness	13- 78
H515 2551	Seal - Duct - R	17- 39
H515 2552	Roller Seal - R	13- 80
H515 2554	Stopper Pin	13- 89

PART N O.	DESCRIPTION	INDEX
H515 2711	Mirror - Synchronization	11- 7
H515 2712	Laser Exposure Glass	11- 8
H515 2714	Cover - Laser Unit	11- 2
H515 2715	Laser Diode Unit	11- 16
H515 2717	Laser Sync.Detector	11- 10
H515 2719	Spring Plate - BTL - Left	11- 4
H515 2720	Spring Plate - BTL - Right	11- 3
H515 2721	Spring Plate - Mirror - Laser Sync.	11- 6
H515 2722	Spring Plate - Lens - Laser	11- 15
H515 2723	Spring Plate - Exposure Glass	11- 9
H515 2724	Clip - Laser Unit	3- 8
H515 2725	Cylindrical Lens - Laser	11- 5
H515 2725	Cylindrical Lens - Laser	11- 14
H515 2734	Bracket - Base	3- 40
H515 2831	Spring Plate - CTM	5- 24
H515 3110	Base - Plotter	17- 41
H515 3111	Bracket - Interlock SW.	17- 10
H515 3112	Actuator - Interlock SW.	17- 13
H515 3114	Slider - Interlock SW.	17- 9
H515 3116	Fulcrum - Fusing Unit	3- 24
H515 3130	Cover - Power Pack	3- 22
H515 3374	Holder - FDU	19- 1
H515 3517	Bottom Plate - Cassette	23- 4
H515 3518	Cover - Cassette	23- 21
H515 3519	Paper Size Indicator	23- 29
H515 3520	Side Fence	23- 39
H515 3521	Knob - Side Fence	23- 37
H515 3522	End Fence	23- 24
H515 3523	Corner Separator - Left	23- 36
H515 3524	Corner Separator - Right	23- 6
H515 3526	Bracket - Gear Arm	23- 14

PART N O.	DESCRIPTION	INDEX
H515 3527	Gear - Z32	23- 16
H515 3528	Gear - Z26	23- 15
H515 3529	Friction Pad - Large	23- 2
H515 3530	Friction Pad - Small	23- 3
H515 3531	Bushing - Paper Feed Roller	23- 10
H515 3533	Spring - Gear Arm	23- 13
H515 3534	Spring - Side Fence	23- 38
H515 3535	Spring - Paper Size Indicator	23- 30
H515 3538	Shaft - Paper Size Indicator	23- 31
H515 3539	Spring Plate - Lock	23- 26
H515 3540	Paper Tray Extension	23- 22
H515 3541	Gear Cover	23- 41
H515 3542	Rivet	23- 35
H515 3543	Retaining Ring - M4	15- 74
H515 3543	Retaining Ring - M4	23- 12
H515 3544	E-ring - JR-E6	19- 32
H515 3544	E-ring - JR-E6	23- 17
H515 3545	Cover - Paper End Sensor	23- 9
H515 3546	Lower Cover	23- 23
H515 3550	Cover - Bypass Feed	23- 19
H515 3552	Bypass Feed Table Ass'y	23- 20
H515 3553	Stopper - Corner Separator	23- 42
H515 3554	Decal - Paper Limit	23- 25
H515 3555	Decal - Paper Set	23- 18
H515 3556	Bracket - Paper End Sensor	23- 7
H515 3557	Paper Feed Roller	23- 1
H515 5002	Original Sensor - S1	7- 9
H515 5003	Original Sensor - S2	7- 8
H515 5004	Original Sensor - S3	7- 27
H515 5005	Original Sensor - S4	9- 16
H515 5015	Thermistor - Fusing	15- 2

PART N O.	DESCRIPTION	INDEX
H515 5017	Thermostat - Fusing	15- 20
H515 5018	Cover Switch - Fusing Exit	15- 34
H515 5022	Harness - Fusing Lamp	15- 29
H515 5024	Ground Wire - Fusing	15- 58
H515 5041	Ozone Fan Motor - DC24V;1.44W	17- 48
H515 5050	Toner End Sensor	17- 5
H515 5054	Paper Size Sensor	19- 21
H515 5054	Paper Size Sensor	23- 28
H515 5075	Paper Feed Clutch	23- 11
H515 5076	Paper End Sensor	23- 8
H515 5080	Relay Harness Assembly	23- 34
H515 5085	Harness - 100 Sheet Cassette	19- 30
H515 5324	Grounding Wire	5- 28
H515 5325	Grounding Wire	7- 11
H515 5396	Seal Sheet	13- 87
H516 1050	Scanner Base	9- 21
H516 1054	Bracket	9- 20
H516 1055	Bracket - R1 Roller	9- 18
H516 1057	Drive Cover	9- 26
H516 1058	Cover - Scanner - Left	3- 13
H516 1059	Ground Plate - Scanner	9- 10
H516 1062	Spacer - Image Sensor	9- 19
H516 1063	Image Sensor Sheet	9- 25
H516 1064	Spring Plate - Image Sensor	9- 17
H516 1065	Spacer - TX Idler Gear	9- 4
H516 1066	Contact Image Sensor - A4	9- 15
H516 1068	Bracket - Operation Panel	9- 24
H516 1250	R1 Roller	9- 3
H516 1251	R2 Roller	9- 2
H516 1253	Timing Belt - TX	9- 7
H516 1254	Pulley - R2 Roller	9- 8

PART N O.	DESCRIPTION	INDEX
H516 1255	Idler Gear - TX	9- 12
H516 1257	Idler Gear - Feed	5- 12
H516 1258	Bracket - TX Motor	9- 9
H516 1261	Spring Plate - Belt Tensioning	9- 13
H516 1262	Roller - Belt Tensioning	9- 14
H516 1263	Seal - Fusing 2	5- 18
H516 2110	Roller - Fusing - A4	15- 26
H516 2111	Pressure Roller - A4	15- 51
H516 2112	Upper Case - Fusing - A4	15- 8
H516 2116	Lower Case - Fusing - A4	15- 52
H516 2117	Fusing Exit Roller - A4	15- 16
H516 2118	Cover - Front - F16 - A4	15- 65
H516 2119	Bracket - Table - Original	15- 37
H516 2120	Cover - Exit - A4	15- 64
H516 2121	Inner Cover - A4	15- 45
H516 2126	Bracket - Fusing - A4	15- 63
H516 2127	Spacer - Fusing Exit Roller - Left	15- 15
H516 2130	Guide Plate - Fusing Exit - A4	15- 73
H516 2133	Terminal Plate - Thermofuse - 1	15- 77
H516 2134	Terminal Plate - Thermofuse - 2	15- 76
H516 2135	Grounding Plate - A4	15- 71
H516 2136	Cushion	15- 75
H516 2146	Terminal Plate - Thermostat - 2	15- 21
H516 2150	Cleaning Pad - Fusing	15- 68
H516 2152	Antistatic Brush - Fusing - A4	15- 38
H516 2159	Cover - Thermistor	15- 7
H516 2173	Guide - Fusing - A4	15- 47
H516 2198	Stopper - Fusing	15- 35
H516 2401	Development Unit - A4	13- 6
H516 2412	Toner Metering Blade - A4	13- 33
H516 2419	Transfer Roller - A4	13- 38

PART N O.	DESCRIPTION	INDEX
H516 2431	Guide - Transfer Roller - A4	13- 43
H516 2432	Cover - Toner Hopper - A4	13- 12
H516 2460	Antistatic Brush - Separation - A4	13- 45
H516 2475	Terminal - Rubber Roller - A4	13- 24
H516 2500	Toner Duct - A4	13- 7
H516 2501	Toner Duct Shield - A4 - 1	13- 82
H516 2505	Toner Duct Shield - A4 - 2	13- 10
H516 2516	Magnet Roller - Development - A4	13- 16
H516 2518	Antistatic Brush - Mag. Roller - A4	13- 35
H516 2519	Rubber Roller - Development - A4	13- 3
H516 2524	Film - Toner Duct - A4	13- 8
H516 2528	Sheield - Rubber Roller - A4	13- 34
H516 2544	Toner Agitator - Development	13- 15
H516 2548	Film - Toner Hopper - A4	13- 29
H516 2549	Seal - Toner Duct - Lower - A4	13- 14
H516 2555	Lower Seal	13- 30
H516 2561	Diffusion Plate - L	13- 83
H516 2562	Diffusion Plate - S1	13- 85
H516 2563	Diffusion Plate - S2	13- 86
H516 2564	Diffusion Plate Holder	13- 84
H516 3116	Spacer - Development Unit - A4	17- 33
H516 3128	Bracket - Cord Clamper	17- 6
H516 3129	Ground Plate - Left	17- 56
H516 3131	Bracket - Rear	17- 1
H516 3132	Bracket - PSU	17- 3
H516 3133	Bracket - Rear - Left	17- 2
H516 3134	Cover - PSU	3- 27
H516 3135	Bracket - Top Cover Locking - Left	17- 45
H516 3137	Bracket - Top Cover Locking - Right	17- 14
H516 3139	Bracket - Cooling Fan	17- 18
H516 3140	Bracket - Ozone Fan	17- 49

PART N O.	DESCRIPTION	INDEX
H516 3141	Bracket - Ozone Filter	17- 46
H516 3142	Ozone Filter - 8	17- 47
H516 3144	Bracket - PIF - 1	17- 53
H516 3145	Bracket - PIF - 2	17- 54
H516 3146	Bracket - Toner End Sensor	17- 4
H516 3147	Harness Clamper - Base	17- 68
H516 3147	Harness Clamper - Base	19- 34
H516 3148	Sponge - 1	17- 63
H516 3149	Sponge - 2	17- 60
H516 3150	Sponge - 3	17- 61
H516 3151	Sponge - 4	17- 62
H516 3152	Sponge - 5	17- 22
H516 3152	Sponge - 5	17- 32
H516 3153	Sponge - Cushion - Cooling Fan	17- 52
H516 3154	Sponge - Cushion - Ozone Fan	17- 55
H516 3155	Insulating Sheet - PSU	17- 50
H516 3156	Insulating Sheet - NCU	17- 51
H516 3157	Bushing - 66	17- 67
H516 3301	Gear Box - Paper Feed	19- 16
H516 3316	Bottom Base	19- 26
H516 3319	Guide - 100 Sheet Cassette - Left	19- 27
H516 3320	Guide - 100 Sheet Cassette - Right	19- 19
H516 3322	Side Plate - Right	19- 7
H516 3326	Side Plate - Left	19- 31
H516 3328	Spacer - Cassette Entrance - Right	19- 23
H516 3329	Spacer - Cassette Entrance - Left	19- 24
H516 3330	Rail - Cassette - Front	19- 22
H516 3331	Rail - Cassette - Rear	19- 10
H516 3332	Lock - Cassette - Left	19- 9
H516 3333	Lock - Cassette - Right	19- 8
H516 3335	Shaft - Feed Roller - Left	19- 3

PART N O.	DESCRIPTION	INDEX
H516 3341	Bracket - Paper End Sensor	19- 12
H516 3342	Base - Main Board	19- 2
H516 3344	Ground Plate - Registration Roller	19- 28
H516 3345	Bracket - Pressure Roller	17- 31
H516 3346	Bracket - Paper Size Sensor	19- 18
H516 3358	Spring - Pressure Roller	17- 28
H516 3359	Cover - Harness - Paper Size Sensor	19- 17
H516 3361	Rubber Foot	19- 25
H516 3370	Paper Feed Roller	19- 5
H516 3372	Shaft - Feed Roller - Right	19- 6
H516 3373	Stay - Feed Roller	19- 4
H516 3376	Ground Plate - Bracket - Regist.	17- 26
H516 3379	Ground Plate - Paper Feed Motor	19- 13
H516 3380	Mylar - Bracket - Registration	17- 24
H516 3381	Ground Plate - Cassette - Left	21- 25
H516 3384	Spring Plate - Lock	17- 65
H516 3401	Cassette Base - Universal	21- 5
H516 3411	Separation Hook - Cassette - Left	21- 32
H516 3412	Side Fence - Cassette	21- 34
H516 3413	Separation Hook - Cassette - Right	21- 24
H516 3414	End Fence - Cassette	21- 2
H516 3415	Paper Guide Plate - Bypass	21- 26
H516 3416	Registration Roller	21- 15
H516 3417	Bushing - Registration Roller	21- 39
H516 3419	Gear - Registration Roller	21- 14
H516 3421	Friction Pad - Bottom Plate - Large	21- 8
H516 3422	Paper Size Indicator - A5	21- 28
H516 3423	Paper Guide Plate - Regist. - Left	21- 11
H516 3424	Paper Guide Plate - Regist. - Right	21- 12
H516 3425	Lock - Bottom Plate	21- 29
H516 3425	Lock - Bottom Plate	23- 33

PART N O.	DESCRIPTION	INDEX
H516 3426	Spring - Lock - Bottom Plate	21- 30
H516 3426	Spring - Lock - Bottom Plate	23- 32
H516 3429	Paper Size Indicator - A4	21- 28
H516 3432	Paper Size Indicator - F/F4	21- 28
H516 3434	Shaft - Pressure Roller	17- 30
H516 3434	Shaft - Pressure Roller	21- 21
H516 3435	Actuator - Bypass Feed Sensor	21- 19
H516 3437	Manual Feed Table	21- 27
H516 3438	Spring Plate - End Fence	21- 1
H516 3439	Stopper - Fence	21- 3
H516 3443	Mylar - Paper Guide - 1	21- 37
H516 3444	Mylar - Paper Guide - 2	21- 31
H516 3445	Mylar - Paper Guide - 3	21- 38
H516 3446	Mylar - Paper Guide - 4	21- 36
H516 3447	Spring - Registration Roller	21- 13
H516 3448	Spring - Pressure Roller	21- 18
H516 3449	Spring - Bypass Sensor Actuator	21- 20
H516 3450	Spring Bottom Plate	21- 9
H516 3462	Bracket - Pressure Roller - Cass.	21- 17
H516 3463	Guide - Pressure Roller - Cass.	21- 23
H516 3465	Support Plate - End Fence	21- 42
H516 3469	Cover - Manual Feed Table	21- 41
H516 3470	Decal - Paper Set - Cassette	21- 6
H516 3471	Sponge - End Fence	21- 4
H516 3482	Spring Plate - Bracket -right	21- 16
H516 3510	Paper Tray - 100 Sheet Cassette	23- 27
H516 3532	Spring - Bottom Plate	23- 5
H516 3581	Decal - By-pass Feed (100 Cassette)	23- 40
H516 3583	Decal - Bypass Feed	21- 33
H516 4020	Cover - Left	3- 19
H516 4023	Cover - IC Memory Card	3- 18

PART N O.	DESCRIPTION	INDEX
H516 4026	Cover - Counter	3- 6
H516 4028	Document Table	3- 28
H516 4032	Copy Tray - A4	3- 29
H516 4034	Document Tray	3- 5
H516 4040	Cover - PIF	3- 2
H516 4043	Cover - Connector	3- 17
H516 4045	Cover - Rear - 2	3- 3
H516 4046	Cover - PIF - 2	3- 1
H516 4047	Cover - NCU - E	3- 4
H516 4048	Cover - 232C	3- 16
H516 4049	Guide - IC Card	3- 21
H516 4068	Cover - Rear - 1	3- 7
H516 4070	Cover - Right	3- 15
H516 4088	Cover Cassette	21- 43
H516 4241	Cover - Operation Panel - ASIA	7- 2
H516 4303	Shield Key Switch	7- 24
H516 4322	Cover - Quick Dial Keys	7- 23
H516 4323	Shield Key Switch - Spanish	7- 24
H516 5000	Stepper Motor - TX 24VDC 18.7W	9- 11
H516 5012	Ground Wire - Image Sensor	9- 22
H516 5012	Ground Wire - Image Sensor	15- 72
H516 5017	Heater - A4 - 220V	15- 28
H516 5018	Thermofuse	15- 78
H516 5031	Monitor Speaker	3- 20
H516 5041	Cooling Fan Motor - DC24V;3.6W	17- 17
H516 5045	Cable - Charge Bias - A4	13- 22
H516 5046	Cable - Transfer Bias - A4	13- 28
H516 5047	Power Supply - Pack - A4	3- 23
H516 5048	Zenor Diode - 732V:HVRD	13- 71
H516 5050	Paper End Sensor	19- 11
H516 5052	Stepper Motor-paper Feed 24VDC13W	19- 15

PART N O.	DESCRIPTION	INDEX
H516 5301	Harness - Paper Size	3- 39
H516 5301	Harness - Paper Size	19- 20
H516 5302	Harness - LDDR	11- 11
H516 5304	Harness - Image Sensor	9- 23
H516 5306	Harness - OPU	7- 4
H516 5308	Driver Harness	3- 33
H516 5309	Harness - TX Motor	3- 35
H516 5311	Sensor Harness	17- 35
H516 5313	Harness - Main Motor ETC.	3- 36
H516 5315	Harness - Interlock SW. - 24V	17- 11
H516 5316	Harness - Paper Feed Motor	3- 34
H516 5318	Harness - Power Pack	3- 32
H516 5319	Harness - Interlock SW. - 5V	17- 16
H516 5322	Relay Harness - Fusing Unit	3- 38
H516 5325	Grounding Wire - 190mm	19- 33
H516 6006	PCB - FCE - ASIA	3- 10
H516 6005	PCB - FDU - FX6 - EUROPE	3- 11
H516 6020	PCB - OPU - FX6	7- 3
H516 8609	Operating Insutructions - ASIA	3- *
H521 2040	Laser Protter Unit	3- 9
H521 3144	Harness Clamp	17- 8
H521 3145	Sponge - Lock - Front	17- 23
H521 3147	Sponge - Cooling Fan - 1	17- 19
H521 3148	Sponge - Cooling Fan - 2	17- 20
H521 3149	Sponge - Cooling Fan - 3	17- 21
H521 3150	Sponge - Cooling Fan - 4	17- 22
H521 3153	Sponge - Base - Left - Middle	17- 64
H521 3156	Sponge - Registration - 1	17- 43
H521 3157	Sponge - Registration - 2	17- 39
H521 3158	Sponge - Power Pack - 1	17- 42
H521 3159	Sponge - Power Pack - 2	17- 40

PART N O.	DESCRIPTION	INDEX
H521 3160	Sponge - Base - Bottom	17- 36
H521 3161	Seal - Base - Bottom - 1	17- 38
H521 3162	Seal - Base - Bottom - 2	17- 37
H521 3164	Pin - Right Fulcrum	3- 25
H521 3340	Pressure Roller - Registration	17- 29
H521 3340	Pressure Roller - Registration	21- 22
H521 3352	Bracket - Plotter Base Connection	17- 44
H521 3379	Sponge - Bracket - Pressure Roller	17- 25
H521 3419	Friction Pad - Bottom Plate - Small	21- 10
H521 4033	Copy Tray Extension	3- 30
H521 5042	Ground Wire - Lock - Front	17- 66
H521 5054	Registration Sensor	17- 27
H521 5061	Polygonal Motor - DC24V;0.3A	11- 12
H521 5309	Harness - NCU	3- 31
H521 5310	Sensor Harness	17- 58
H521 5312	Harness - Fusing Sensors	15- 32
H521 5321	Harness - Mirror Motor	11- 13
H521 5322	Harness - PSU	3- 37
H521 5324	Relay Harness - Interlock - 5V	17- 12
H521 5326	Heater Relay Harness	15- 70
H521 5402	PSU 220V	3- 26

PART N O.	DESCRIPTION	INDEX
AW02 0021	Photointerruptor - 175487-3	15- 31
AW02 0021	Photointerruptor - 175487-3	17- 34
G011 3275	Snap Ring	3- 41
A048 6149	Decal - Manual Feed	21- 35
5447 2681	Snap Ring	5- 11
5488 6040	PCB - NCU - EUROPE/ASIAUSA	3- 12

PART N O.	DESCRIPTION	INDEX
0313 0040B	Philips Pan Head Screw - M3x4	25-137
0313 0060B	Philips Pan Head Screw - M3x6	25-101
0313 0080B	Philips Pan Head Screw - M3x8	25-102
0353 0080Z	Philips Trass Head Screw - M3x8	25-103
0413 0082W	Tapping Screw - M3x8	25-104
0433 0102B	Tapping Screw - M3x10	25-105
0443 0060W	Hexagon Head Tapping Screw - M3x6	25-106
0632 0100G	Pin - 2x10mm	25-107
0633 0120G	Parallel Pin - 3x12	25-108
0707 3050B	Bushing - 3x5mm	25-109
0720 0020E	Retaining Ring - M2	25-110
0720 0025E	Retaining Ring - M2.5	25-111
0720 0030E	Retaining Ring - M3	25-112
0720 0040E	Retaining Ring - M4	25-113
0720 0050E	Retaining Ring - M5	25-114
0720 0060E	Retaining Ring - M6	25-115
0802 5205	Tapping Screw - M3x6	25-116
0802 5206	Tapping Screw - M3x8	25-117
0802 5210	Tapping Screw - M3x8	25-135
0802 5230	Tapping Screw - M3x10	25-118
0805 3386	Bushing - 8mm	25-119
0951 3006B	Philips Screw With Flat Washer-M3x6	25-120
0951 3008B	Philips Screw With Flat Washer-M3x8	25-121
0954 3006B	Screw - M3X6	25-122
0957 3006B	Screw - M3X6	25-123
0964 3006B	Tapping Screw - M3x6	25-138
0965 3006B	Tapping Screw With Flat Washer M3x6	25-124
0965 3008B	Tapping Screw With Washer - M3x8	25-125
0965 3010B	Tapping Screw With Flat WasherM3x6	25-126
0965 3012B	Tapping Screw With Washer - M3x12	25-127
1102 4473	CT Connector - 2P	25-136

