

R I C O H

PARTS CATALOG

FOR

FAX4700L [Taiwan]

RICOH COMPANY, LTD.

1	April 5th, 1996	First edition

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG


Section 1.Part Location and List

1.EXTERIOR 1	1 - 2
2.EXTERIOR 2	1 - 4
3.OPERATION PANEL	1 - 6
4.ADF	1 - 8
5.SCANNER	1 - 10
6.LASER UNIT	1 - 12
7.DEVELOPMENT	1 - 14
8.FUSING	1 - 16
9.BASE FRAME 1	1 - 18
10.BASE FRAME 2	1 - 22
11.BASE FRAME 3.....	1 - 24
12.250 SHEET CASSETTE.....	1 - 26

13.100 SHEET CASSETTE OPTION	1 - 28
14.ISDN	1 - 30
15.80 MB HDD.....	1 - 32
16.FOD	1 - 34

Section 2. Parts Index..... 2 - 1

1. EXTERIOR 1




1. EXTERIOR 1

INDEX	PARTS NO.	DESCRIPTION	Note
*	H515 8607	Operation Manual - Twn	
1	H515 4020	Cover - Left	
2	H516 4043	Cover - Connector	
3	H516 4023	Cover - IC Memory Card	
4	H516 5031	Monitor Speaker	
5	H515 3148	IC Card Guide	
6	H515 4030	Cover - G4	
7	H515 4029	Cover - V35	
8	H516 4046	Cover - Printer I/F - Upper	
9	H516 4026	Cover - MEXH Counter	
10	H515 4055	Guide Mylar	
11	H515 4032	Cover - RS232C	
12	H515 4035	Rear Cover	
13	H515 4031	Cover Right	
14	H516 1058	Cover - Scanner - Left	
15	H515 4025	Cover CT	
16	H516 4047	Cover - NCU	
17	H515 4024	Cover - Rear	
18	H081 5701	Telephone Line - RIF	
19	H516 4028	Document Table	
20	H521 4031	Copy Tray	
21	H516 4040	Cover Printer I/F - Lower	
22	H515 4028	Cover - Fan	
23	H521 4032	Copy Tray - B4	
24	H515 4036	Cassette Cover	
25	H516 4034	Document Tray	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0353 0060Z	Screw - M3X6	
102	0802 5230	Tapping Screw - M3x10	
103	0802 5206	Tapping Screw - M3x8	
104	0443 0060W	Hexagon Head Tapping Screw - M3x6	
105	0951 3006B	Philips Screw With Flat Washer-m3x6	
106	0965 3006B	Tapping Screw With Flat Washer M3x6	

2. EXTERIOR 2




2. EXTERIOR 2



INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 5033	Power Pack	
2	H515 3130	Cover - Power Pack	
3	H515 3116	Fulcrum - Fusing Unit	
4	H515 6013	PCB - MFDU	
5	H515 5320	Motor Harness	
6	H515 5311	Motor Harness - TX	
7	H515 5310	Motor Harness - RX	
8	H516 5308	Driver Harness	
9	H516 5303	Harness - PP - F	
10	H516 5302	Harness - LDDR	
11	H516 5322	Relay Harness - Fusing Unit	
12	H521 5322	Harness - PSU	
13	H515 3140	Spacer - 8mm	
14	H515 6220	PCB - MFCE	
15	H515 2042	Laser Unit Ass'y - FX4	
16	H515 2724	Clip - LASER UNIT	
17	H515 2734	Bracket - Base	
18	H516 1068	Bracket - Operation Panel	
19	H521 5309	Harness - NCU	
20	G011 3275	Snap Ring	
21	H518 5400	PCB - PSU - 115V	
22	H521 3164	Pin - Right Fulcrum	
23	5488 6020	PCB - NCU	
24	H515 3134	PSU Cover	
25	H515 5317	Exposure Lamp Harness	
26	H521 5321	Harness - Mirror Motor	
27	H515 5314	OPU Harness	
28	H516 5311	Sensor Harness	
29	H515 5312	SBU Harness	
30	H515 5085	Harness - 100 Sheet Cassette	
31	H516 5314	Safety Switch Harness	
32	H515 5319	Option Tray Harness	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0443 0060W	Hexagon Head Tapping Screw - M3x6	
102	0802 5206	Tapping Screw - M3x8	
103	0951 3006B	Philips Screw With Flat Washer-m3x6	
104	1105 0246	Spacer	
105	1104 0502	PS Holder	
106	0313 0060B	Philips Pan Head Screw - M3x6	
107	0353 0060Z	Screw - M3X6	
108	0353 0080Z	Philips Trass Head Screw - M3x8	
109	0443 0060W	Hexagon Head Tapping Screw - M3x6	
110	1102 4681	Connector - 5557-02R-210	

3. OPERATION PANEL




3. OPERATION PANEL

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 4308	Operating Seal - C	
2	H515 1263	Bracket - Grounding	
3	H515 5314	OPU Harness	
4	H515 1324	Spring Plate - R1/R2 - Right	
5	H515 1323	Spring Plate - R1/R2 - Left	
6	H515 1336	Spring - Ground (Earth) - Pipe	
7	H515 1267	Grounding Plate	
8	H081 1147	Pressure Roller Assy	
9	H515 1301	Shaft - Pressure Roller	
10	H515 1313	Sponge Collar - R1	
11	H515 1312	Pressure Roller - R1	
12	H515 4208	Operation Panel Ass'y	
13	H515 5004	Original Sensor - S3	
14	H515 5002	Original Sensor - S1	
15	H515 5003	Original Sensor - S2	
16	H515 5005	Document Sensor - S4	
17	H515 1271	Shaft - Separation Pressure	
18	H515 1277	Clip - Base - Shading Plate	
19	H515 1339	2nd Scanner Sheet	
20	H515 1303	Spring - Shading Plate	
21	H515 1279	Base - Shading Plate	
22	H515 1338	1st Scanner Sheet	
23	H515 1331	Mylar - ADF	
24	H515 1293	Pressure Plate - Pickup	
25	H515 1205	Separation Plate Ass'y	
26	H515 1250	ADF Guide Plate - Upper	
28	H515 4316	Quick Dial Sheet	
29	H515 4290	Quick Dial Plate	
30	H515 4307	Operating Seal - B	
31	H515 4259	Sheet - Operation Panel	
32	H515 4258	Case - Dial Sheet	
33	H515 1342	Antistatic Brush	

INDEX	PARTS NO.	DESCRIPTION	Note
34	H515 1340	Grounding Plate Spacer	
101	0965 3008B	Tapping Screw With Washer - M3x8	
102	0313 0040B	Philips Pan Head Screw - M3x4	
103	0802 5206	Tapping Screw - M3x8	
104	1105 0283	Clamp	

4. ADF




4. ADF

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 1287	Brake Gear	
2	H515 1292	Cover - ADF	
3	H515 1204	ADF Feeder Unit	
4	H515 1322	Seal 2	
5	H515 1298	Spring Plate - CTM	
6	H515 5324	Ground Wire - 350	
7	H515 1321	Sponge - Fusing 1	
8	H515 2831	Spring Plate - CTM	
9	H515 1318	Bracket - Top Cover	
10	H515 1335	Ground Plate - ADF - Lower 2	
11	H515 1337	Bracket - Plate - Ground Wire	
12	H515 1283	Pinion Gear - Document Guide	
13	H515 1282	Rack Gear - Document Guide	
14	H515 1305	Hook - Cover Lock - Left	
15	H515 1251	Top Cover	
16	H515 1307	Guide - Original - Left	
17	H515 1290	Plumber Block - ADF Roller - Right	
18	H515 1291	Plumber Block - ADF Roller - Left	
19	H515 1285	Gear - Document Feed	
20	5447 2681	Snap Ring	
21	H515 1284	Shaft - Document Feed	
22	H053 1600	Bushing - M6 : CuFE	
23	H515 1295	Spring - Lock	
24	H515 1304	Hook - Cover Lock - Right	
25	H515 1296	Lever - Lock Release	
26	H515 1294	Shaft - Lock	
27	H515 1297	Lock Lever - Operation Panel	
28	H515 1306	Guide Original - Right	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0353 0080Z	Philips Trass Head Screw - M3x8	
102	0965 3008B	Tapping Screw With Washer - M3x8	
103	0313 0040B	Philips Pan Head Screw - M3x4	
104	0965 3006B	Tapping Screw With Flat Washer M3x6	
105	0433 0102B	Tapping Screw - M3x10	


5. SCANNER



5. SCANNER

INDEX	PARTS NO.	DESCRIPTION	Note	INDEX	PARTS NO.	DESCRIPTION	Note
1	5466 3198	Washer - SBU		33	H516 1262	Roller - Belt Tensioning	
2	H515 6020	PCB - SBU		34	H515 1272	Motor Bracket	
3	H515 5312	SBU Harness		35	H515 1286	Development Gear - TX	
4	H515 5317	Exposure Lamp Harness		36	H515 1288	Brake Spacer	
5	H515 1077	Cover - Lens		37	H515 1058	Front Lamp Clip	
6	H515 1061	Lens Holder		38	H515 1069	Grounding Wire	
7	H014 1101	Lense - F22.6		39	H515 1317	Gear	
8	H515 1060	Shield Plate		40	H515 1075	Dvelopment Fixing Plate	
9	H515 1064	Rear Cover Bracket		41	H515 1266	Pulley - R2 Roller	
10	H515 1052	Exposure Glass Clip		42	H515 5012	Xenon Lamp - US	
11	H515 1081	Exposure Glass		43	H515 1265	Pulley - R1	
12	H515 1233	R2 Roller		44	H053 1600	Bushing - M6 : CμFE	
13	H515 1232	R1 Roller		45	H515 1070	Cover - Drive	
14	H515 1062	Bushing - R1/R2 Rollers		46	H515 1090	Left Holder - Exposuer Glass	
15	H515 1086	R2 Guide Mylar		47	H515 1091	Right Holder - Exposuer Glass	
16	H515 5011	Xenon Lamp Driver					
17	H515 1050	Scanner Base					
18	H515 3159	Wire - Clip					
19	H515 1056	Lamp Bracket					
20	H515 1073	Grounding Plate - Lamp Bracket					
21	H515 5324	Ground Wire - 350					
22	H515 1055	Mirror Clip					
23	H515 1076	Harness Bracket		101	0954 3010B	Philips Screw - M3x10	
24	H511 5005	Stamper		102	0802 5206	Tapping Screw - M3x8	
25	H515 5000	TX Motor - DC24V;0.9A		103	0965 3010B	Tapping Screw With Flat Washerm3x6	
26	H515 1065	Motor Cushion		104	0951 3008B	Philips Screw With Flat Washer-m3x8	
27	H515 1084	R1 Gide Mylar		105	0701 0030B	Flat Washer - M3	
28	H515 1054	2nd Mirror		106	0951 3006B	Philips Screw With Flat Washer-m3x6	
29	H515 1053	1st Mirror		107	0720 0030E	Retaining Ring - M3	
30	H515 1276	Timing Belt - TX		108	0720 0050E	Retaining Ring - M5	
31	H515 1072	Cover - Scanner		109	0802 5230	Tapping Screw - M3x10	
32	H515 1281	Spring Plate		110	0805 3386	Bushing - 8mm	

6. LASER UNIT




6. LASER UNIT



INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2042	Laser Unit Ass'y - FX4	
2	H521 4056	Decal LD	
3	H515 2714	Cover - Laser Unit	
4	H521 5321	Harness - Mirror Motor	
5	H515 5040	Polygonal Mirror Motor-DC24V;0.35A	
6	H515 2717	Laser Sync. Detector	
7	H515 2715	Laser Diode Unit	
8	H515 2712	Laser Exposure Glass	
9	H515 2723	Spring Plate - Exposure Glass	
10	H515 5044	Optical Fibre - Laser Sync.	
11	H515 2719	Spring Plate - BTL - Left	
12	H516 2710	BTL Lens	
13	H515 2720	Spring Plate - Btl - Right	
14	H515 2721	Spring Plate - Mirror - Laser Sync.	
15	H515 2711	Mirror - Synchronization	
16	H515 2725	Cylindrical Lens - Laser	
17	H515 2722	Spring Plate - Lens - Laser	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0802 5230	Tapping Screw - M3x10	

7. DEVELOPMENT



7. DEVELOPMENT

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2414	Bearing - DVLP. Roller - Left	
2	H515 2451	Gear	
3	H515 2519	Development (rubber) Roller - B4	
4	H515 2415	Bearing - DVLP. Roller - Right	
5	H515 2405	Rubber Roller Ass'y - DVLP -B4	
6	H515 2401	Development Unit - B4	
7	H515 2500	Seal - Duct - 1	
8	H515 2524	Film - Duct	
9	H515 2506	Seal - Duct - S	
10	H515 2505	Seal - Duct - L	
11	H515 2506	Seal - Duct - S	
12	H515 2432	Toner Duct - B4	
13	H515 2536	Seal - Development - C	
14	H516 2549	Seal - Toner Duct - Lower - A4	
15	H515 2544	Toner Supply Bar - B4	
16	H515 2516	Toner Application Roller - B4	
17	H515 2502	Seal - Roller	
18	H515 2535	Seal - B	
19	H515 2474	Terminal Plate - Development - L	
20	H515 2530	Terminal Plate - B	
21	H515 2481	Terminal Plate - A	
22	H515 5037	Bias Cable - Charge	
23	H515 2478	Terminal Plate - Charge - M	
24	H515 2475	Terminal Plate - Relay - S	
25	H515 2473	Terminal Plate - Development - S	
26	H515 2534	Seal - Development - A	
27	H515 2471	Terminal Plate - Transfer - L	
28	H515 5038	Bias Cable - Transfer	
29	H515 2548	Film - Hopper	
30	H516 2524	Film - Toner Duct - A4	
31	H515 2487	Stopper - Pin	
32	H515 2488	Stopper - Receptacle	


INDEX	PARTS NO.	DESCRIPTION	Note
33	H515 2412	Toner Metering Blade - B4	
34	H515 2528	Seal - Development Roller	
35	H515 2518	Antistatic Brush - Dvlp. - B4	
36	H515 2452	Gear - Transfer Roller	
37	H515 2461	Pulley - Transfer	
38	H515 2404	Transfer Roller - B4	
39	H515 2455	Holder - Transfer Roller - Left	
40	H515 2485	Spring - Transfer Roller	
41	H515 2456	Holder - Transfer Roller - Right	
42	H515 2417	Terminal - Quenching Lamp	
43	H515 2498	Guide Plate - Transfer	
44	H515 2469	Terminal Plate - Transfer - S	
45	H515 2460	Antistatic Brush - Transfer - B4	
46	H515 2472	Terminal Plate - Separation	
47	H515 2468	Terminal Plate - Ground	
48	H515 2482	Terminal Plate - OPC Drum	
49	H515 2543	Holder - Terminal Plate - OPC Drum	
50	H515 2493	Drive Gear - Fusing	
51	H515 2450	Idler Gear 6	
52	H515 2467	Shaft - Idler 6	
53	H515 2492	Bracket - Fusing Drive Gear	
54	H515 2494	Shaft - Drive Gear - Fusing	
55	H515 2462	Shaft - Idler 1	
56	H515 2443	Idler Gear 1 - Small	
57	H515 2444	Idler Gear 1 - Large	
58	H515 2445	Idler Gear 2 - Large	
59	H515 2413	Gear - Agitator	
60	H515 2442	Gear - Mag. Roller	
61	H515 2411	Bearing - Mag. Roller - Right	
62	H515 2463	Shaft - Idler 2	
63	H515 2457	Bushing - Idler 2 - Large	
64	H515 2466	Shaft - Idler 5	



INDEX	PARTS NO.	DESCRIPTION	Note
65	H515 2449	Idler Gear 5	
66	H515 2541	Deal - Shutter Guide	
67	H515 2416	Main Motor Ass'y - DC24V;16.1W	
68	H515 2495	Spring - Bracket - Fusing Drive	
69	H515 2447	Idler Gear 3	
70	H515 2448	Idler Gear 4	
71	H515 5034	Zenor Diode - 732V : HVRD	
72	H515 2491	Inner Cover - Development	
73	H515 2458	Bushing - Idler 2 - Small	
74	H515 2496	Terminal Plate - Grid	
75	H515 2446	Drive Gear - OPC Drum	
76	H515 2410	Bearing - Mag. Roller - Left	
77	H515 2542	Stopper - Bearing - M6	
78	H515 2547	Holder - Harness	
80	H515 2552	Shield - Roller - R	
81	H081 2438	Shaft - Agitator	
82	H515 2501	Seal - Duct - 2	
83	H515 2561	Instruction Sheet - B4 - L	
84	H515 2564	Plate - Instruction Sheet - B4	
85	H515 2562	Instruction Sheet - B4 - S - 1	
86	H515 2563	Instruction Sheet - B4 - S - 2	
87	H515 5396	Seal Sheet	
88	H515 2537	Seal - Development - D	
89	H515 2554	Stopper - Pin - L	
90	H515 2580	Guide Plate - Transfer Unit	
91	H515 2577	Sheet - Guide Plate	

INDEX	PARTS NO.	DESCRIPTION	Note
106	0443 0060W	Hexagon Head Tapping Screw - M3x6	
110	0720 0020E	Retaining Ring - M2	
111	0720 0025E	Retaining Ring - M2.5	
112	0720 0030E	Retaining Ring - M3	
113	0720 0040E	Retaining Ring - M4	
117	0802 5206	Tapping Screw - M3x8	
120	0951 3006B	Philips Screw With Flat Washer-m3x6	

8. FUSING



8. FUSING

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2143	Holder - Thermistor	
2	H515 5015	Thermistor - Fusing	
3	H515 2149	Actuator - Fusing Exit Sensor	
4	H515 2161	Spring - Sensor Actuator	
5	H515 2153	Spring - Hot Roller Stripper	
6	H515 2181	Separation Hook - Fusing	
7	H515 2159	Cover - Thermistor - B4	
8	H521 2112	Upper Case - Fusing - B4	
9	H515 2127	Idler Gear - Z18	
10	H515 2167	Holder - Fusing Lamp	
11	H515 2119	Cover - Gear	
12	H515 2128	Gear - Fusing Exit Roller	
13	H515 2139	Bushing - Fusing Exit Roller	
14	H515 2166	Roller - Exit Roller	
15	H516 2127	Spacer - Fusing Exit Roller - Left	
16	H515 2117	Fusing Exit Roller - B4	
17	H515 2125	Idler Gear - Z17	
18	H515 2124	Idler Gear - Z22-18	
19	H515 2189	Plate - Ground Plate	
20	H515 5017	Thermostat - Fusing	
21	H515 2146	Terminal Plate - Fusing - Rear	
22	H515 2145	Terminal Plate - Thermostat - 1	
23	H515 2137	Bearing - Hot Roller	
24	H515 2160	Stopper - Hot Roller	
25	H515 2141	Spacer - Hot Roller	
26	H515 2110	Hot Roller - B4	
27	H515 2126	Gear - Hot Roller	
28	H521 5016	Fusing Lamp - B4 - 115V	
29	H515 5022	Harness - Fusing Lamp	
30	H515 2155	Cover - Right - Fusing	
31	AW02 0021	Photointerruptor - 175487-3	
32	H521 5312	Harness - Fusing Sensors	


INDEX	PARTS NO.	DESCRIPTION	Note
33	H515 2179	Cover - Connector	
34	H515 5018	Cover Switch - Fusing Exit	
35	H516 2198	Stopper - Fusing - F	
36	H515 2134	Lock Lever - Right	
37	H516 2119	Bracket - Table - Original	
38	H515 2152	Antistatic Brush - Fusing - B4	
39	H515 2135	Shaft - Lock Lever	
40	H515 2178	Bracket - Lamp Connector	
41	H515 2180	Bracket - Idler Gear	
42	H515 2157	Fusing Inner Cover - Right	
43	H515 2133	Lever - Lock - Left	
44	H515 2136	Spring - Lock Lever	
46	H515 2176	Bracket - Pressure Roller - Right	
47	H515 2173	Guide - Fusing	
48	H521 2115	Spring - Pressure Roller	
49	H515 2169	Bearing - Pressure Roller	
50	H515 2163	Spring Plate - Right	
51	H521 2111	Pressure Roller - B4	
52	H515 2116	Lower Case - Fusing	
53	H515 2182	Stepped Screw	
54	H515 2177	Bracket - Pressure Roller - Left	
55	H515 2164	Spring Plate - Left	
56	H515 2171	Spring Plate - Pressure Roller	
57	H515 2156	Ground Plate - Hot Roller	
58	H515 5024	Ground Wire - Fusing	
59	H515 2158	Fusing Inner Cover - Left	
60	H515 2165	Cover - Left	
61	H515 2121	Spring Plate - Fusing Exit	
62	H515 2122	Fusing Exit Roller	
63	H515 2175	Stay - Protect - B4	
64	H515 2120	Cover - Exit	
65	H515 2118	Cover - Front	



INDEX	PARTS NO.	DESCRIPTION	Note
66	H521 2184	Decal - Warning	
67	H513 4353	Decal - Exit	
68	H515 2150	Cleaning Pad - Fusing - B4	
69	H515 2168	Lock Spring - Cleaning Pad	
70	H521 5326	Heater Relay Harness	
71	H515 2188	Ground Plate - Exit	
72	H516 5012	Ground Wire - Image Sensor	
73	H515 2186	Guide - Exit	
74	H515 3543	Retaining Ring - M4	
			

INDEX	PARTS NO.	DESCRIPTION	Note
101	0313 0060B	Philips Pan Head Screw - M3x6	
102	0313 0080B	Philips Pan Head Screw - M3x8	
116	0802 5205	Tapping Screw - M3x6	
117	0802 5206	Tapping Screw - M3x8	
120	0951 3006B	Philips Screw With Flat Washer-m3x6	
122	0954 3006B	Screw - M3X6	
136	1102 4473	CT Connector - 2P	

9. BASE FRAME 1




9. BASE FRAME 1

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3135	Bracket - Top Cover Locking - Left	
2	H516 3141	Bracket - Ozone Filter	
3	H516 3142	Ozone Filter - 8	
4	H515 3133	NCU Side Plate	
5	H515 5041	Ozone Fan Motor - DC24V;1.44W	
6	H516 3140	Bracket - Ozone Fan	
7	H516 3154	Sponge - Cushion - Ozone Fan	
8	H515 3144	PIF Bracket 1	
9	H515 3155	PIF Bracket 3	
10	H515 3145	PIF Bracket 2	
11	H515 3131	NCU Bracket	
12	H515 3167	NCU Bracket	
13	H521 5357	Power Cord - Twn	
15	H516 5314	Safety Switch Harness	
16	H521 3182	Bracket Interlock SW.	
17	H521 5324	Relay Harness - Interlock - 5V	
18	H516 5315	Harness - Interlock SW. - 24V	
20	H516 3137	Bracket - Top Cover Locking - Right	
21	H516 3139	Bracket - Cooling Fan	
22	H521 5042	Ground Wire - Lock - Front	
23	H516 3153	Sponge - Cushion - Cooling Fan	
24	H516 5041	Cooling Fan Motor - DC24V;3.6W	
25	H081 5043	Interlock Switch - LD	
26	H515 3121	Safety Switch Stopper Bracket	
27	H516 3128	Bracket - Cord Clamper	
28	H515 3155	PIF Bracket 3	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0802 5206	Tapping Screw - M3x8	
102	0313 0300B	Philips Pan Head Screw - M3x30	
103	0443 0060W	Hexagon Head Tapping Screw - M3x6	
104	0951 3006B	Philips Screw With Flat Washer-m3x6	
105	0701 0040B	Flat Washer - M4	
106	0950 4006B	Screw - M4x6	
107	0802 5210	Tapping Screw - M3x8	
108	1105 0344	Clamp	
109	1204 2334	Safety Switch - FA1I-AA20	
110	0313 0120B	Philips Pan Head Screw - M3x12	

10. BASE FRAME 2




10. BASE FRAME 2

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 2199	Stay - Front	
2	H521 3352	Bracket - Plotter Base Connection	
3	H516 3129	Ground Plate - Left	
4	H521 3153	Sponge - Base - Left - Middle	
5	H521 3145	Sponge - Lock - Front	
6	H521 3151	Sponge - Base - Upper Left (US)	
7	H521 3158	Sponge - Power Pack - 1	
8	H521 3159	Sponge - Power Pack - 2	
9	H516 3146	Bracket - Toner End Sensor	
10	H521 3156	Sponge - Registration - 1	
11	H516 5311	Sensor Harness	
12	H515 5050	Toner End Sensor	
13	H521 5310	Harness - Sen1	
14	H521 3157	Sponge - Registration - 2	
15	H521 3144	Harness Clamp	
16	H521 3149	Sponge - Cooling Fan - 3	
17	H521 3147	Sponge - Cooling Fan - 1	
18	H521 3150	Sponge - Cooling Fan - 4	
19	H515 5056	Registration Sensor	
20	H516 3376	Ground Plate - Bracket - Regist.	
21	H515 3362	Bracket - Pressure Roller	
22	H515 3110	Base - Plotter	
23	H516 3375	Spacer	
24	H521 3160	Sponge - Base - Bottom	
25	H521 3340	Pressure Roller - Registration	
26	H516 3434	Shaft - Pressure Roller	
27	H516 3358	Spring - Pressure Roller	
28	H515 3376	Film Stay	
29	AW02 0021	Photointerruptor - 175487-3	
30	H516 3384	Spring Plate - Lock	
31	H521 3379	Sponge - Bracket - Pressure Roller	
32	H521 3161	Seal - Base - Bottom - 1	

INDEX	PARTS NO.	DESCRIPTION	Note
33	H521 3162	Seal - Base - Bottom - 2	
34	H516 3149	Sponge - 2	
35	H521 3148	Sponge - Cooling Fan - 2	
36	H516 3151	Sponge - 4	
37	H516 3150	Sponge - 3	
38	H516 3116	Spacer - Development Unit - A4	
39	H516 3152	Sponge - 5	
40	H515 3363	Spring - Registration	
41	H515 3457	Pressuer Rollre - S	
42	H515 3456	Shaft - Pressuer Rollre	
101	0443 0060W	Hexagon Head Tapping Screw - M3x6	
102	0802 5206	Tapping Screw - M3x8	

11. BASE FRAME 3




11. BASE FRAME 3

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3147	Harness Clamper - Base (US)	
2	H516 3157	Bushing - 66	
3	H515 3122	PSU Bracket	
4	H516 3333	Lock - Cassette - Right	
5	H516 3379	Ground Plate - Paper Feed Motor	
6	H516 3341	Bracket - Paper End Sensor	
7	H516 5050	Paper End Sensor	
8	H516 3158	Plate - PSU	
9	H515 5014	Grounding Harness	
10	H515 3374	Holder - FDU	
11	H515 3375	FDU Cover	
12	H515 5085	Harness - 100 Sheet Cassette	
13	H516 3319	Holder - Cassette - Left	
14	H516 3332	Lock - Cassette - Left	
15	H516 5052	Stepper Motor-paper Feed 24VDC13W	
16	H006 2383	Snap Ring	
17	H516 3301	Gear Box - Paper Feed	
19	H516 3359	Cover - Harness - Paper Size Sensor	
20	H515 5054	Paper Size Sensor	
21	H516 3346	Bracket - Paper Size Sensor	
22	H516 3320	Holder - Cassette - Right	
23	H516 3330	Rail - Cassette - Front	
24	H516 3328	Spacer - Cassette Entrance - Right	
25	H516 3361	Rubber Foot	
26	H515 3693	Positioning Pin	
27	H516 3329	Spacer - Cassette Entrance - Left	
28	H516 3331	Rail - Cassette - Rear	
29	H515 3152	Oppf Relay Bracket	
30	H516 3335	Shaft - Feed Roller - Left	
31	H516 3373	Stay - Feed Roller	
32	H516 3372	Shaft - Feed Roller - Right	
33	H516 3370	Paper Feed Roller	

INDEX	PARTS NO.	DESCRIPTION	Note
34	H516 3385	Support Plate - Left Side Plate	
35	H516 3344	Ground Plate - Registration Roller	
36	H515 3544	E-ring - JR-E6	
37	H516 5301	Harness - Paper Size	
38	H515 5318	PFU Harness	
101	0965 3008B	Tapping Screw With Washer - M3x8	
102	0443 0060W	Hexagon Head Tapping Screw - M3x6	
103	0964 3006B	Tapping Screw - M3x6	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	0951 3006B	Philips Screw With Flat Washer-m3x6	
106	1105 0344	Clamp	
107	1105 0260	Wire Saddle	
108	0805 3386	Bushing - 8mm	
109	1105 0243	Wire Saddle	

12. 250 SHEET CASSETTE




12. 250 SHEET CASSETTE

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3470	Decal - Paper Set - Cassette	
2	H516 3410	Bottom Plate - Cassette	
3	H516 3421	Friction Pad - Bottom Plate - Large	
4	H521 3419	Friction Pad - Bottom Plate - Small	
5	H516 3450	Spring Bottom Plate	
6	H516 3471	Sponge - End Fence	
7	H516 3438	Spring Plate - End Fence	
8	H516 3414	End Fence - Cassette	
9	H516 3413	Separation Hook - Cassette - Right	
10	H515 3466	Plastic Rivet	
11	H515 3465	Supporting Plate	
12	H516 3412	Side Fence - Cassette	
13	H516 3439	Stopper - Fence	
14	H516 3411	Separation Hook - Cassette - Left	
15	H515 3459	Mylar - Guide Plate - 2	
16	H516 3426	Spring - Lock - Bottom Plate	
17	H516 3425	Lock - Bottom Plate	
18	H516 3401	Cassette	
19	H516 3415	Paper Guide Plate - Bypass	
20	H516 3583	Decal - Bypass Feed	
21	H516 3437	Manual Feed Table	
22	H516 3433	Paper Size Sensor	
22	H516 3429	Paper Size Sensor Board - A4	
23	H515 3460	Mylar - Guide Plate - 3	
24	H516 3443	Mylar - Paper Guide - 1	
25	H515 3461	Mylar - Guide Plate - 4	
26	A048 6149	Decal - Manual Feed	
27	H515 3453	Guide Plate - Registration - F14	
28	H515 3455	Guide Plate - Registration - Right	
29	H515 3454	Guide Plate - Registration - Left	
30	H516 3447	Spring - Registration Roller	
31	H516 3419	Gear - Registration Roller	

INDEX	PARTS NO.	DESCRIPTION	Note
32	H516 3417	Bushing - Registration Roller	
33	H515 3452	Registration Roller	
34	H516 3482	Spring Plate - Bracket -right	
35	H515 3420	Bracket - Pressure Roller - Cass.	
36	H515 3467	Mylar - Bracket	
37	H515 3456	Shaft - Pressure Roller	
38	H515 3458	Spring - Registration	
39	H515 3457	Pressure Roller - S	
40	H516 3434	Shaft - Pressure Roller	
41	H516 3448	Spring - Pressure Roller	
42	H516 3449	Spring - Bypass Sensor Actuator	
43	H516 3435	Actuator - Bypass Feed Sensor	
44	H515 3451	Guide Plate - Upper - Front - F14	
45	H521 3340	Pressure Roller - Registration	
46	H516 3381	Ground Plate - Cassette - Left	
47	H515 3469	Film	

13. 100 SHEET CASSETTE OPTION




13. 100 SHEET CASSETTE OPTION

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 3511	Paper Feed Roller	
2	H516 3529	Friction Pad - Large	
3	H516 3530	Friction Pad - Small	
4	H515 3517	Bottom Plate - Cassette	
5	H515 3532	Spring - Bottom Plate	
6	H515 3524	Corner Separator - Right	
7	H515 3525	Bracket - Paper End Sensor	
8	H515 5076	Paper End Sensor	
9	H515 3545	Cover - Paper End Sensor	
10	H515 3531	Bushing - Paper Feed Roller	
11	H515 5075	Paper Feed Clutch	
12	H515 3543	Retaining Ring - M4	
13	H515 3533	Spring - Gear Arm	
14	H515 3526	Bracket - Gear Arm	
15	H515 3528	Gear - Z26	
16	H515 3527	Gear - Z32	
17	H515 3544	E-ring - JR-E6	
18	H515 3555	Decal - Paper Set	
19	H515 3550	Cover - Bypass Feed	
20	H515 3552	Bypass Feed Table Ass'y	
22	H515 3540	Paper Tray Extension	
23	H515 3546	Lower Cover	
24	H515 3522	End Fence	
25	H515 3554	Decal - Paper Limit	
26	H515 3539	Spring Plate - Lock	
27	H516 3510	Paper Tray - 100 Sheet Cassette	
28	H515 5054	Paper Size Sensor	
29	H515 3519	Paper Size Indicator	
30	H515 3535	Spring - Paper Size Indicator	
31	H515 3539	Spring Plate - Lock	
32	H516 3426	Spring - Lock - Bottom Plate	
33	H516 3425	Lock - Bottom Plate	

INDEX	PARTS NO.	DESCRIPTION	Note
34	H515 5080	Relay Harness Assembly	
35	H515 3542	Rivet	
36	H515 3523	Corner Separator - Left	
37	H515 3521	Knob - Side Fence	
38	H515 3534	Spring - Side Fence	
39	H515 3520	Side Fence	
40	H516 3582	Decal - Bypass Feed	
41	H515 3541	Gear Cover	
42	H515 3553	Stopper - Corner Separator	
43	H515 3581	Spacer	
44	H515 3595	Spacer	
45	H515 3580	Grounding Plate	
46	H515 2394	CS Stopper	


14. ISDN



INDEX	PARTS NO.	DESCRIPTION	Note
1	H082 6035	Fax Control Board - 115V	
2	H513 4102	Decal - ISDN	
3	H143 5701	ISDN Harness	
4	H515 5014	Grounding Harness	
5	H515 3149	Board Bracket	
6	H515 5203	PCB G4 I/F	

INDEX	PARTS NO.	DESCRIPTION	Note

15. 80 MB HDD




15. 80 MB HDD



INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 5202	HDD I/F Cord	
2	H515 5357	HDD Harness - 4P	
3	H515 5358	HDD Harness - 44P	
4	H515 3156	HDD Bracket	
5	H515 7116	80M HDD	
6	H130 4015	Grounding Plate	
	 		

INDEX	PARTS NO.	DESCRIPTION	Note
101	1607 0638	Ferrite Core - TFC25-15-12	

16. FOD



16. FOD

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 5230	Microphone	
2	H132 4005	Cover - FOD	
3	H132 4004	Decal - FOD	

INDEX	PARTS NO.	DESCRIPTION	Note

PARTS INDEX

PART N O.	DESCRIPTION	INDEX
H515 1050	Scanner Base	11- 17
H515 1052	Exposure Glass Clip	11- 10
H515 1053	1st Mirror	11- 29
H515 1054	2nd Mirror	11- 28
H515 1055	Mirror Clip	11- 22
H515 1056	Lamp Bracket	11- 19
H515 1058	Front Lamp Clip	11- 37
H515 1060	Shield Plate	11- 8
H515 1061	Lens Holder	11- 6
H515 1062	Bushing - R1/R2 Rollers	11- 14
H515 1064	Rear Cover Bracket	11- 9
H515 1065	Motor Cushion	11- 26
H515 1069	Grounding Wire	11- 38
H515 1070	Cover - Drive	11- 45
H515 1072	Cover - Scanner	11- 31
H515 1073	Grounding Plate - Lamp Bracket	11- 20
H515 1075	Development Fixing Plate	11- 40
H515 1076	Harness Bracket	11- 23
H515 1077	Cover - Lens	11- 5
H515 1081	Exposure Glass	11- 11
H515 1084	R1 Guide Mylar	11- 27
H515 1086	R2 Guide Mylar	11- 15
H515 1090	Left Holder - Exposuer Glass	11- 46
H515 1091	Right Holder - Exposuer Glass	11- 47
H515 1204	ADF Feeder Unit	7- 3
H515 1205	Separation Plate Ass'y	9- 25
H515 1232	R1 Roller	11- 13
H515 1233	R2 Roller	11- 12
H515 1250	ADF Guide Plate - Upper	9- 26
H515 1251	Top Cover	7- 15
H515 1263	Bracket - Grounding	9- 2
H515 1265	Pulley - R1	11- 43
H515 1266	Pulley - R2 Roller	11- 41

PART N O.	DESCRIPTION	INDEX
H515 1267	Grounding Plate	9- 7
H515 1271	Shaft - Separation Pressure	9- 17
H515 1272	Motor Bracket	11- 34
H515 1276	Timing Belt - TX	11- 30
H515 1277	Clip - Base - Shading Plate	9- 18
H515 1279	Base - Shading Plate	9- 21
H515 1281	Spring Plate	11- 32
H515 1282	Rack Gear - Document Guide	7- 13
H515 1283	Pinion Gear - Document Guide	7- 12
H515 1284	Shaft - Document Feed	7- 21
H515 1285	Gear - Document Feed	7- 19
H515 1286	Development Gear - TX	11- 35
H515 1287	Brake Gear	7- 1
H515 1288	Brake Spacer	11- 36
H515 1290	Plumber Block - ADF Roller - Right	7- 17
H515 1291	Plumber Block - ADF Roller - Left	7- 18
H515 1292	Cover - ADF	7- 2
H515 1293	Pressure Plate - Pickup	9- 24
H515 1294	Shaft - Lock	7- 26
H515 1295	Spring - Lock	7- 23
H515 1296	Lever - Lock Release	7- 25
H515 1297	Lock Lever - Operation Panel	7- 27
H515 1298	Spring Plate - CTM	7- 5
H515 1301	Shaft - Pressure Roller	9- 9
H515 1303	Spring - Shading Plate	9- 20
H515 1304	Hook - Cover Lock - Right	7- 24
H515 1305	Hook - Cover Lock - Left	7- 14
H515 1306	Guide Original - Right	7- 28
H515 1307	Guide - Original - Left	7- 16
H515 1312	Pressure Roller - R1	9- 11
H515 1313	Sponge Collar - R1	9- 10
H515 1317	Gear	11- 39
H515 1318	Bracket - Top Cover	7- 9

PART N O.	DESCRIPTION	INDEX
H515 1321	Sponge - Fusing 1	7- 7
H515 1322	Seal 2	7- 4
H515 1323	Spring Plate - R1/R2 - Left	9- 5
H515 1324	Spring Plate - R1/R2 - Right	9- 4
H515 1331	Mylar - ADF	9- 23
H515 1335	Ground Plate - ADF - Lower 2	7- 10
H515 1336	Spring - Ground (Earth) - Pipe	9- 6
H515 1337	Bracket - Plate - Ground Wire	7- 11
H515 1338	1st Scanner Sheet	9- 22
H515 1339	2nd Scanner Sheet	9- 19
H515 1340	Grounding Plate Spacer	9- 34
H515 1342	Antistatic Brush	9- 33
H515 2042	Laser Unit Ass'y - FX4	5- 15
H515 2042	Laser Unit Ass'y - FX4	13- 1
H515 2110	Hot Roller - B4	19- 26
H515 2116	Lower Case - Fusing	19- 52
H515 2117	Fusing Exit Roller - B4	19- 16
H515 2118	Cover - Front	19- 65
H515 2119	Cover - Gear	19- 11
H515 2120	Cover - Exit	19- 64
H515 2121	Spring Plate - Fusing Exit	19- 61
H515 2122	Fusing Exit Roller	19- 62
H515 2124	Idler Gear - Z22-18	19- 18
H515 2125	Idler Gear - Z17	19- 17
H515 2126	Gear - Hot Roller	19- 27
H515 2127	Idler Gear - Z18	19- 9
H515 2128	Gear - Fusing Exit Roller	19- 12
H515 2133	Lever - Lock - Left	19- 43
H515 2134	Lock Lever - Right	19- 36
H515 2135	Shaft - Lock Lever	19- 39
H515 2136	Spring - Lock Lever	19- 44
H515 2137	Bearing - Hot Roller	19- 23
H515 2139	Bushing - Fusing Exit Roller	19- 13

PART N O.	DESCRIPTION	INDEX
H515 2141	Spacer - Hot Roller	19- 25
H515 2143	Holder - Thermistor	19- 1
H515 2145	Terminal Plate - Thermostat - 1	19- 22
H515 2146	Terminal Plate - Fusing - Rear	19- 21
H515 2149	Actuator - Fusing Exit Sensor	19- 3
H515 2150	Cleaning Pad - Fusing - B4	19- 68
H515 2152	Antistatic Brush - Fusing - B4	19- 38
H515 2153	Spring - Hot Roller Stripper	19- 5
H515 2155	Cover - Right - Fusing	19- 30
H515 2156	Ground Plate - Hot Roller	19- 57
H515 2157	Fusing Inner Cover - Right	19- 42
H515 2158	Fusing Inner Cover - Left	19- 59
H515 2159	Cover - Thermistor - B4	19- 7
H515 2160	Stopper - Hot Roller	19- 24
H515 2161	Spring - Sensor Actuator	19- 4
H515 2163	Spring Plate - Right	19- 50
H515 2164	Spring Plate - Left	19- 55
H515 2165	Cover - Left	19- 60
H515 2166	Roller - Exit Roller	19- 14
H515 2167	Holder - Fusing Lamp	19- 10
H515 2168	Lock Spring - Cleaning Pad	19- 69
H515 2169	Bearing - Pressure Roller	19- 49
H515 2171	Spring Plate - Pressure Roller	19- 56
H515 2173	Guide - Fusing	19- 47
H515 2175	Stay - Protect - B4	19- 63
H515 2176	Bracket - Pressure Roller - Right	19- 46
H515 2177	Bracket - Pressure Roller - Left	19- 54
H515 2178	Bracket - Lamp Connector	19- 40
H515 2179	Cover - Connector	19- 33
H515 2180	Bracket - Idler Gear	19- 41
H515 2181	Separation Hook - Fusing	19- 6
H515 2182	Stepped Screw	19- 53
H515 2186	Guide - Exit	19- 73

PART N O.	DESCRIPTION	INDEX
H515 2188	Ground Plate - Exit	19- 71
H515 2189	Plate - Ground Plate	19- 19
H515 2394	CS Stopper	31- 46
H515 2401	Development Unit - B4	15- 6
H515 2404	Transfer Roller - B4	15- 38
H515 2405	Rubber Roller Ass'y - DVLP -B4	15- 5
H515 2410	Bearing - Mag. Roller - Left	15- 76
H515 2411	Bearing - Mag. Roller - Right	15- 61
H515 2412	Toner Metering Blade - B4	15- 33
H515 2413	Gear - Agitator	15- 59
H515 2414	Bearing - DVLP. Roller - Left	15- 1
H515 2415	Bearing - DVLP. Roller - Right	15- 4
H515 2416	Main Motor Ass'y - DC24V;16.1W	15- 67
H515 2417	Terminal - Quenching Lamp	15- 42
H515 2432	Toner Duct - B4	15- 12
H515 2442	Gear - Mag. Roller	15- 60
H515 2443	Idler Gear 1 - Small	15- 56
H515 2444	Idler Gear 1 - Large	15- 57
H515 2445	Idler Gear 2 - Large	15- 58
H515 2446	Drive Gear - OPC Drum	15- 75
H515 2447	Idler Gear 3	15- 69
H515 2448	Idler Gear 4	15- 70
H515 2449	Idler Gear 5	15- 65
H515 2450	Idler Gear 6	15- 51
H515 2451	Gear	15- 2
H515 2452	Gear - Transfer Roller	15- 36
H515 2455	Holder - Transfer Roller - Left	15- 39
H515 2456	Holder - Transfer Roller - Right	15- 41
H515 2457	Bushing - Idler 2 - Large	15- 63
H515 2458	Bushing - Idler 2 - Small	15- 73
H515 2460	Antistatic Brush - Transfer - B4	15- 45
H515 2461	Pulley - Transfer	15- 37
H515 2462	Shaft - Idler 1	15- 55

PART N O.	DESCRIPTION	INDEX
H515 2463	Shaft - Idler 2	15- 62
H515 2466	Shaft - Idler 5	15- 64
H515 2467	Shaft - Idler 6	15- 52
H515 2468	Terminal Plate - Ground	15- 47
H515 2469	Terminal Plate - Transfer - S	15- 44
H515 2471	Terminal Plate - Transfer - L	15- 27
H515 2472	Terminal Plate - Separation	15- 46
H515 2473	Terminal Plate - Development - S	15- 25
H515 2474	Terminal Plate - Development - L	15- 19
H515 2475	Terminal Plate - Relay - S	15- 24
H515 2478	Terminal Plate - Charge - M	15- 23
H515 2481	Terminal Plate - A	15- 21
H515 2482	Terminal Plate - OPC Drum	15- 48
H515 2485	Spring - Transfer Roller	15- 40
H515 2487	Stopper - Pin	15- 31
H515 2488	Stopper - Receptacle	15- 32
H515 2491	Inner Cover - Development	15- 72
H515 2492	Bracket - Fusing Drive Gear	15- 53
H515 2493	Drive Gear - Fusing	15- 50
H515 2494	Shaft - Drive Gear - Fusing	15- 54
H515 2495	Spring - Bracket - Fusing Drive	15- 68
H515 2496	Terminal Plate - Grid	15- 74
H515 2498	Guide Plate - Transfer	15- 43
H515 2500	Seal - Duct - 1	15- 7
H515 2501	Seal - Duct - 2	15- 82
H515 2502	Seal - Roller	15- 17
H515 2505	Seal - Duct - L	15- 10
H515 2506	Seal - Duct - S	15- 9
H515 2506	Seal - Duct - S	15- 11
H515 2516	Toner Application Roller - B4	15- 16
H515 2518	Antistatic Brush - Dvlp. - B4	15- 35
H515 2519	Development (rubber) Roller - B4	15- 3
H515 2524	Film - Duct	15- 8

PART N O.	DESCRIPTION	INDEX
H515 2528	Seal - Development Roller	15- 34
H515 2530	Terminal Plate - B	15- 20
H515 2534	Seal - Development - A	15- 26
H515 2535	Seal - B	15- 18
H515 2536	Seal - Development - C	15- 13
H515 2537	Seal - Development - D	15- 88
H515 2541	Deal - Shutter Guide	15- 66
H515 2542	Stopper - Bearing - M6	15- 77
H515 2543	Holder - Terminal Plate - OPC Drum	15- 49
H515 2544	Toner Supply Bar - B4	15- 15
H515 2547	Holder - Harness	15- 78
H515 2548	Film - Hopper	15- 29
H515 2552	Shield - Roller - R	15- 80
H515 2554	Stopper - Pin - L	15- 89
H515 2561	Instruction Sheet - B4 - L	15- 83
H515 2562	Instruction Sheet - B4 - S - 1	15- 85
H515 2563	Instruction Sheet - B4 - S - 2	15- 86
H515 2564	Plate - Instruction Sheet - B4	15- 84
H515 2577	Sheet - Guide Plate	15- 91
H515 2580	Guide Plate - Transfer Unit	15- 90
H515 2711	Mirror - Synchronization	13- 15
H515 2712	Laser Exposure Glass	13- 8
H515 2714	Cover - Laser Unit	13- 3
H515 2715	Laser Diode Unit	13- 7
H515 2717	Laser Sync. Detector	13- 6
H515 2719	Spring Plate - BTL - Left	13- 11
H515 2720	Spring Plate - Btl - Right	13- 13
H515 2721	Spring Plate - Mirror - Laser Sync.	13- 14
H515 2722	Spring Plate - Lens - Laser	13- 17
H515 2723	Spring Plate - Exposure Glass	13- 9
H515 2724	Clip - LASER UNIT	5- 16
H515 2725	Cylindrical Lens - Laser	13- 16
H515 2734	Bracket - Base	5- 17

PART N O.	DESCRIPTION	INDEX
H515 2831	Spring Plate - CTM	7- 8
H515 3110	Base - Plotter	25- 22
H515 3116	Fulcrum - Fusing Unit	5- 3
H515 3121	Safety Switch Stopper Bracket	23- 26
H515 3122	PSU Bracket	27- 3
H515 3130	Cover - Power Pack	5- 2
H515 3131	NCU Bracket	23- 11
H515 3133	NCU Side Plate	23- 4
H515 3134	PSU Cover	5- 24
H515 3140	Spacer - 8mm	5- 13
H515 3144	PIF Bracket 1	23- 8
H515 3145	PIF Bracket 2	23- 10
H515 3148	IC Card Guide	3- 5
H515 3149	Board Bracket	33- 5
H515 3152	Oppf Relay Bracket	27- 29
H515 3155	PIF Bracket 3	23- 9
H515 3155	PIF Bracket 3	23- 28
H515 3156	HDD Bracket	35- 4
H515 3159	Wire - Clip	11- 18
H515 3167	NCU Bracket	23- 12
H515 3362	Bracket - Pressure Roller	25- 21
H515 3363	Spring - Registration	25- 40
H515 3374	Holder - FDU	27- 10
H515 3375	FDU Cover	27- 11
H515 3376	Film Stay	25- 28
H515 3420	Bracket - Pressure Roller - Cass.	29- 35
H515 3451	Guide Plate - Upper - Front - F14	29- 44
H515 3452	Registration Roller	29- 33
H515 3453	Guide Plate - Registration - F14	29- 27
H515 3454	Guide Plate - Registration - Left	29- 29
H515 3455	Guide Plate - Registration - Right	29- 28
H515 3456	Shaft - Pressuer Rollre	25- 42
H515 3456	Shaft - Pressure Roller	29- 37

PART N O.	DESCRIPTION	INDEX
H515 3457	Pressuer Rollre - S	25- 41
H515 3457	Pressure Roller - S	29- 39
H515 3458	Spring - Registration	29- 38
H515 3459	Mylar - Guide Plate - 2	29- 15
H515 3460	Mylar - Guide Plate - 3	29- 23
H515 3461	Mylar - Guide Plate - 4	29- 25
H515 3465	Supporting Plate	29- 11
H515 3466	Plastic Rivet	29- 10
H515 3467	Mylar - Bracket	29- 36
H515 3469	Film	29- 47
H515 3511	Paper Feed Roller	31- 1
H515 3517	Bottom Plate - Cassette	31- 4
H515 3519	Paper Size Indicator	31- 29
H515 3520	Side Fence	31- 39
H515 3521	Knob - Side Fence	31- 37
H515 3522	End Fence	31- 24
H515 3523	Corner Separator - Left	31- 36
H515 3524	Corner Separator - Right	31- 6
H515 3525	Bracket - Paper End Sensor	31- 7
H515 3526	Bracket - Gear Arm	31- 14
H515 3527	Gear - Z32	31- 16
H515 3528	Gear - Z26	31- 15
H515 3531	Bushing - Paper Feed Roller	31- 10
H515 3532	Spring - Bottom Plate	31- 5
H515 3533	Spring - Gear Arm	31- 13
H515 3534	Spring - Side Fence	31- 38
H515 3535	Spring - Paper Size Indicator	31- 30
H515 3539	Spring Plate - Lock	31- 26
H515 3539	Spring Plate - Lock	31- 31
H515 3540	Paper Tray Extension	31- 22
H515 3541	Gear Cover	31- 41
H515 3542	Rivet	31- 35
H515 3543	Retaining Ring - M4	19- 74

PART N O.	DESCRIPTION	INDEX
H515 3543	Retaining Ring - M4	31- 12
H515 3544	E-ring - JR-E6	27- 36
H515 3544	E-ring - JR-E6	31- 17
H515 3545	Cover - Paper End Sensor	31- 9
H515 3546	Lower Cover	31- 23
H515 3550	Cover - Bypass Feed	31- 19
H515 3552	Bypass Feed Table Ass'y	31- 20
H515 3553	Stopper - Corner Separator	31- 42
H515 3554	Decal - Paper Limit	31- 25
H515 3555	Decal - Paper Set	31- 18
H515 3580	Grounding Plate	31- 45
H515 3581	Spacer	31- 43
H515 3595	Spacer	31- 44
H515 3693	Positioning Pin	27- 26
H515 4020	Cover - Left	3- 1
H515 4024	Cover - Rear	3- 17
H515 4025	Cover CT	3- 15
H515 4028	Cover - Fan	3- 22
H515 4029	Cover - V35	3- 7
H515 4030	Cover - G4	3- 6
H515 4031	Cover Right	3- 13
H515 4032	Cover - RS232C	3- 11
H515 4035	Rear Cover	3- 12
H515 4036	Cassetto Cover	3- 24
H515 4055	Guide Mylar	3- 10
H515 4208	Operation Panel Ass'y	9- 12
H515 4258	Case - Dial Sheet	9- 32
H515 4259	Sheet - Operation Panel	9- 31
H515 4290	Quick Dial Plate	9- 29
H515 4307	Operating Seal - B	9- 30
H515 4308	Operating Seal - C	9- 1
H515 4316	Quick Dial Sheet	9- 28
H515 5000	TX Motor - DC24V;0.9A	11- 25

PART N O.	DESCRIPTION	INDEX
H515 5002	Original Sensor - S1	9- 14
H515 5003	Original Sensor - S2	9- 15
H515 5004	Original Sensor - S3	9- 13
H515 5005	Document Sensor - S4	9- 16
H515 5011	Xenon Lamp Driver	11- 16
H515 5012	Xenon Lamp - US	11- 42
H515 5014	Grounding Harness	27- 9
H515 5014	Grounding Harness	33- 4
H515 5015	Thermistor - Fusing	19- 2
H515 5017	Thermostat - Fusing	19- 20
H515 5018	Cover Switch - Fusing Exit	19- 34
H515 5022	Harness - Fusing Lamp	19- 29
H515 5024	Ground Wire - Fusing	19- 58
H515 5033	Power Pack	5- 1
H515 5034	Zenor Diode - 732V : HVRD	15- 71
H515 5037	Bias Cable - Charge	15- 22
H515 5038	Bias Cable - Transfer	15- 28
H515 5040	Polygonal Mirror Motor-DC24V;0.35A	13- 5
H515 5041	Ozone Fan Motor - DC24V;1.44W	23- 5
H515 5044	Optical Fibre - Laser Sync.	13- 10
H515 5050	Toner End Sensor	25- 12
H515 5054	Paper Size Sensor	27- 20
H515 5054	Paper Size Sensor	31- 28
H515 5056	Registration Sensor	25- 19
H515 5075	Paper Feed Clutch	31- 11
H515 5076	Paper End Sensor	31- 8
H515 5080	Relay Harness Assembly	31- 34
H515 5085	Harness - 100 Sheet Cassette	5- 30
H515 5085	Harness - 100 Sheet Cassette	27- 12
H515 5202	HDD I/F Cord	35- 1
H515 5203	PCB G4 I/F	33- 6
H515 5230	Microphone	37- 1
H515 5310	Motor Harness - RX	5- 7

PART N O.	DESCRIPTION	INDEX
H515 5311	Motor Harness - TX	5- 6
H515 5312	SBU Harness	5- 29
H515 5312	SBU Harness	11- 3
H515 5314	OPU Harness	5- 27
H515 5314	OPU Harness	9- 3
H515 5317	Exposure Lamp Harness	5- 25
H515 5317	Exposure Lamp Harness	11- 4
H515 5318	PFU Harness	27- 38
H515 5319	Option Tray Harness	5- 32
H515 5320	Motor Harness	5- 5
H515 5324	Ground Wire - 350	7- 6
H515 5324	Ground Wire - 350	11- 21
H515 5357	HDD Harness - 4P	35- 2
H515 5358	HDD Harness - 44P	35- 3
H515 5396	Seal Sheet	15- 87
H515 6013	PCB - μ FDU	5- 4
H515 6020	PCB - SBU	11- 2
H515 6220	PCB - μ FCE	5- 14
H515 7116	80M HDD	35- 5
H515 8607	Operation Manual - Twn	3- *

PART N O.	DESCRIPTION	INDEX
AW02 0021	Photointerruptor - 175487-3	19- 31
AW02 0021	Photointerruptor - 175487-3	25- 29
G011 3275	Snap Ring	5- 20
H006 2383	Snap Ring	27- 16
H014 1101	Lense - F22.6	11- 7
H053 1600	Bushing - M6 : CμFE	7- 22
H053 1600	Bushing - M6 : CμFE	11- 44
H081 1147	Pressure Roller Assy	9- 8
H081 2438	Shaft - Agitator	15- 81
H081 5043	Interlock Switch - LD	23- 25
H081 5701	Telephone Line - RIF	3- 18
H082 6035	Fax Control Board - 115V	33- 1
H130 4015	Grounding Plate	35- 6
H132 4004	Decal - FOD	37- 3
H132 4005	Cover - FOD	37- 2
H143 5701	ISDN Harness	33- 3
H511 5005	Stamper	11- 24
H513 4102	Decal - ISDN	33- 2
H513 4353	Decal - Exit	19- 67
H515 1050	Scanner Base	11- 17
H515 1052	Exposure Glass Clip	11- 10
H515 1053	1st Mirror	11- 29
H515 1054	2nd Mirror	11- 28
H515 1055	Mirror Clip	11- 22
H515 1056	Lamp Bracket	11- 19
H515 1058	Front Lamp Clip	11- 37
H515 1060	Shield Plate	11- 8
H515 1061	Lens Holder	11- 6
H515 1062	Bushing - R1/R2 Rollers	11- 14
H515 1064	Rear Cover Bracket	11- 9
H515 1065	Motor Cushion	11- 26
H515 1069	Grounding Wire	11- 38
H515 1070	Cover - Drive	11- 45

PART N O.	DESCRIPTION	INDEX
H515 1072	Cover - Scanner	11- 31
H515 1073	Grounding Plate - Lamp Bracket	11- 20
H515 1075	Dvelopment Fixing Plate	11- 40
H515 1076	Harness Bracket	11- 23
H515 1077	Cover - Lens	11- 5
H515 1081	Exposure Glass	11- 11
H515 1084	R1 Guide Mylar	11- 27
H515 1086	R2 Guide Mylar	11- 15
H515 1090	Left Holder - Exposuer Glass	11- 46
H515 1091	Right Holder - Exposuer Glass	11- 47
H515 1204	ADF Feeder Unit	7- 3
H515 1205	Separation Plate Ass'y	9- 25
H515 1232	R1 Roller	11- 13
H515 1233	R2 Roller	11- 12
H515 1250	ADF Guide Plate - Upper	9- 26
H515 1251	Top Cover	7- 15
H515 1263	Bracket - Grounding	9- 2
H515 1265	Pulley - R1	11- 43
H515 1266	Pulley - R2 Roller	11- 41
H515 1267	Grounding Plate	9- 7
H515 1271	Shaft - Separetion Pressure	9- 17
H515 1272	Motor Bracket	11- 34
H515 1276	Timing Belt - TX	11- 30
H515 1277	Clip - Base - Shading Plate	9- 18
H515 1279	Base - Shading Plate	9- 21
H515 1281	Spring Plate	11- 32
H515 1282	Rack Gear - Document Guide	7- 13
H515 1283	Pinion Gear - Document Guide	7- 12
H515 1284	Shaft - Document Feed	7- 21
H515 1285	Gear - Document Feed	7- 19
H515 1286	Development Gear - TX	11- 35
H515 1287	Brake Gear	7- 1
H515 1288	Brake Spacer	11- 36

PART N O.	DESCRIPTION	INDEX
H515 1290	Plumber Block - ADF Roller - Right	7- 17
H515 1291	Plumber Block - ADF Roller - Left	7- 18
H515 1292	Cover - ADF	7- 2
H515 1293	Pressure Plate - Pickup	9- 24
H515 1294	Shaft - Lock	7- 26
H515 1295	Sping - Lock	7- 23
H515 1296	Lever - Lock Release	7- 25
H515 1297	Lock Lever - Operation Panel	7- 27
H515 1298	Spring Plate - CTM	7- 5
H515 1301	Shaft - Pressure Roller	9- 9
H515 1303	Spring - Shading Plate	9- 20
H515 1304	Hook - Cover Lock - Right	7- 24
H515 1305	Hook - Cover Lock - Left	7- 14
H515 1306	Guide Original - Right	7- 28
H515 1307	Guide - Original - Left	7- 16
H515 1312	Pressure Roller - R1	9- 11
H515 1313	Sponge Collar - R1	9- 10
H515 1317	Gear	11- 39
H515 1318	Bracket - Top Cover	7- 9
H515 1321	Sponge - Fusing 1	7- 7
H515 1322	Seal 2	7- 4
H515 1323	Spring Plate - R1/R2 - Left	9- 5
H515 1324	Spring Plate - R1/R2 - Right	9- 4
H515 1331	Mylar - ADF	9- 23
H515 1335	Ground Plate - ADF - Lower 2	7- 10
H515 1336	Spring - Ground (Earth) - Pipe	9- 6
H515 1337	Bracket - Plate - Ground Wire	7- 11
H515 1338	1st Scanner Sheet	9- 22
H515 1339	2nd Scanner Sheet	9- 19
H515 1340	Grounding Plate Spacer	9- 34
H515 1342	Antistatic Brush	9- 33
H515 2042	Laser Unit Ass'y - FX4	5- 15
H515 2042	Laser Unit Ass'y - FX4	13- 1

PART N O.	DESCRIPTION	INDEX
H515 2110	Hot Roller - B4	19- 26
H515 2116	Lower Case - Fusing	19- 52
H515 2117	Fusing Exit Roller - B4	19- 16
H515 2118	Cover - Front	19- 65
H515 2119	Cover - Gear	19- 11
H515 2120	Cover - Exit	19- 64
H515 2121	Spring Plate - Fusing Exit	19- 61
H515 2122	Fusing Exit Roller	19- 62
H515 2124	Idler Gear - Z22-18	19- 18
H515 2125	Idler Gear - Z17	19- 17
H515 2126	Gear - Hot Roller	19- 27
H515 2127	Idler Gear - Z18	19- 9
H515 2128	Gear - Fusing Exit Roller	19- 12
H515 2133	Lever - Lock - Left	19- 43
H515 2134	Lock Lever - Right	19- 36
H515 2135	Shaft - Lock Lever	19- 39
H515 2136	Spring - Lock Lever	19- 44
H515 2137	Bearing - Hot Roller	19- 23
H515 2139	Bushing - Fusing Exit Roller	19- 13
H515 2141	Spacer - Hot Roller	19- 25
H515 2143	Holder - Thermistor	19- 1
H515 2145	Terminal Plate - Thermostat - 1	19- 22
H515 2146	Terminal Plate - Fusing - Rear	19- 21
H515 2149	Actuator - Fusing Exit Sensor	19- 3
H515 2150	Cleaning Pad - Fusing - B4	19- 68
H515 2152	Antistatic Brush - Fusing - B4	19- 38
H515 2153	Spring - Hot Roller Stripper	19- 5
H515 2155	Cover - Right - Fusing	19- 30
H515 2156	Ground Plate - Hot Roller	19- 57
H515 2157	Fusing Inner Cover - Right	19- 42
H515 2158	Fusing Inner Cover - Left	19- 59
H515 2159	Cover - Thermistor - B4	19- 7
H515 2160	Stopper - Hot Roller	19- 24

PART N O.	DESCRIPTION	INDEX
H515 2161	Spring - Sensor Actuator	19- 4
H515 2163	Spring Plate - Right	19- 50
H515 2164	Spring Plate - Left	19- 55
H515 2165	Cover - Left	19- 60
H515 2166	Roller - Exit Roller	19- 14
H515 2167	Holder - Fusing Lamp	19- 10
H515 2168	Lock Spring - Cleaning Pad	19- 69
H515 2169	Bearing - Pressure Roller	19- 49
H515 2171	Spring Plate - Pressure Roller	19- 56
H515 2173	Guide - Fusing	19- 47
H515 2175	Stay - Protect - B4	19- 63
H515 2176	Bracket - Pressure Roller - Right	19- 46
H515 2177	Bracket - Pressure Roller - Left	19- 54
H515 2178	Bracket - Lamp Connector	19- 40
H515 2179	Cover - Connector	19- 33
H515 2180	Bracket - Idler Gear	19- 41
H515 2181	Separation Hook - Fusing	19- 6
H515 2182	Stepped Screw	19- 53
H515 2186	Guide - Exit	19- 73
H515 2188	Ground Plate - Exit	19- 71
H515 2189	Plate - Ground Plate	19- 19
H515 2394	CS Stopper	31- 46
H515 2401	Development Unit - B4	15- 6
H515 2404	Transfer Roller - B4	15- 38
H515 2405	Rubber Roller Ass'y - DVLP -B4	15- 5
H515 2410	Bearing - Mag. Roller - Left	15- 76
H515 2411	Bearing - Mag. Roller - Right	15- 61
H515 2412	Toner Metering Blade - B4	15- 33
H515 2413	Gear - Agitator	15- 59
H515 2414	Bearing - DVLP. Roller - Left	15- 1
H515 2415	Bearing - DVLP. Roller - Right	15- 4
H515 2416	Main Motor Ass'y - DC24V;16.1W	15- 67
H515 2417	Terminal - Quenching Lamp	15- 42

PART N O.	DESCRIPTION	INDEX
H515 2432	Toner Duct - B4	15- 12
H515 2442	Gear - Mag. Roller	15- 60
H515 2443	Idler Gear 1 - Small	15- 56
H515 2444	Idler Gear 1 - Large	15- 57
H515 2445	Idler Gear 2 - Large	15- 58
H515 2446	Drive Gear - OPC Drum	15- 75
H515 2447	Idler Gear 3	15- 69
H515 2448	Idler Gear 4	15- 70
H515 2449	Idler Gear 5	15- 65
H515 2450	Idler Gear 6	15- 51
H515 2451	Gear	15- 2
H515 2452	Gear - Transfer Roller	15- 36
H515 2455	Holder - Transfer Roller - Left	15- 39
H515 2456	Holder - Transfer Roller - Right	15- 41
H515 2457	Bushing - Idler 2 - Large	15- 63
H515 2458	Bushing - Idler 2 - Small	15- 73
H515 2460	Antistatic Brush - Transfer - B4	15- 45
H515 2461	Pulley - Transfer	15- 37
H515 2462	Shaft - Idler 1	15- 55
H515 2463	Shaft - Idler 2	15- 62
H515 2466	Shaft - Idler 5	15- 64
H515 2467	Shaft - Idler 6	15- 52
H515 2468	Terminal Plate - Ground	15- 47
H515 2469	Terminal Plate - Transfer - S	15- 44
H515 2471	Terminal Plate - Transfer - L	15- 27
H515 2472	Terminal Plate - Separation	15- 46
H515 2473	Terminal Plate - Development - S	15- 25
H515 2474	Terminal Plate - Development - L	15- 19
H515 2475	Terminal Plate - Relay - S	15- 24
H515 2478	Terminal Plate - Charge - M	15- 23
H515 2481	Terminal Plate - A	15- 21
H515 2482	Terminal Plate - OPC Drum	15- 48
H515 2485	Spring - Transfer Roller	15- 40

PART N O.	DESCRIPTION	INDEX
H515 2487	Stopper - Pin	15- 31
H515 2488	Stopper - Receptacle	15- 32
H515 2491	Inner Cover - Development	15- 72
H515 2492	Bracket - Fusing Drive Gear	15- 53
H515 2493	Drive Gear - Fusing	15- 50
H515 2494	Shaft - Drive Gear - Fusing	15- 54
H515 2495	Spring - Bracket - Fusing Drive	15- 68
H515 2496	Terminal Plate - Grid	15- 74
H515 2498	Guide Plate - Transfer	15- 43
H515 2500	Seal - Duct - 1	15- 7
H515 2501	Seal - Duct - 2	15- 82
H515 2502	Seal - Roller	15- 17
H515 2505	Seal - Duct - L	15- 10
H515 2506	Seal - Duct - S	15- 9
H515 2506	Seal - Duct - S	15- 11
H515 2516	Toner Application Roller - B4	15- 16
H515 2518	Antistatic Brush - Dvlp. - B4	15- 35
H515 2519	Development (rubber) Roller - B4	15- 3
H515 2524	Film - Duct	15- 8
H515 2528	Seal - Development Roller	15- 34
H515 2530	Terminal Plate - B	15- 20
H515 2534	Seal - Development - A	15- 26
H515 2535	Seal - B	15- 18
H515 2536	Seal - Development - C	15- 13
H515 2537	Seal - Development - D	15- 88
H515 2541	Deal - Shutter Guide	15- 66
H515 2542	Stopper - Bearing - M6	15- 77
H515 2543	Holder - Terminal Plate - OPC Drum	15- 49
H515 2544	Toner Supply Bar - B4	15- 15
H515 2547	Holder - Harness	15- 78
H515 2548	Film - Hopper	15- 29
H515 2552	Shield - Roller - R	15- 80
H515 2554	Stopper - Pin - L	15- 89

PART N O.	DESCRIPTION	INDEX
H515 2561	Instruction Sheet - B4 - L	15- 83
H515 2562	Instruction Sheet - B4 - S - 1	15- 85
H515 2563	Instruction Sheet - B4 - S - 2	15- 86
H515 2564	Plate - Instruction Sheet - B4	15- 84
H515 2577	Sheet - Guide Plate	15- 91
H515 2580	Guide Plate - Transfer Unit	15- 90
H515 2711	Mirror - Synchronization	13- 15
H515 2712	Laser Exposure Glass	13- 8
H515 2714	Cover - Laser Unit	13- 3
H515 2715	Laser Diode Unit	13- 7
H515 2717	Laser Sync. Detector	13- 6
H515 2719	Spring Plate - BTL - Left	13- 11
H515 2720	Spring Plate - Btl - Right	13- 13
H515 2721	Spring Plate - Mirror - Laser Sync.	13- 14
H515 2722	Spring Plate - Lens - Laser	13- 17
H515 2723	Spring Plate - Exposure Glass	13- 9
H515 2724	Clip - LASER UNIT	5- 16
H515 2725	Cylindrical Lens - Laser	13- 16
H515 2734	Bracket - Base	5- 17
H515 2831	Spring Plate - CTM	7- 8
H515 3110	Base - Plotter	25- 22
H515 3116	Fulcrum - Fusing Unit	5- 3
H515 3121	Safety Switch Stopper Bracket	23- 26
H515 3122	PSU Bracket	27- 3
H515 3130	Cover - Power Pack	5- 2
H515 3131	NCU Bracket	23- 11
H515 3133	NCU Side Plate	23- 4
H515 3134	PSU Cover	5- 24
H515 3140	Spacer - 8mm	5- 13
H515 3144	PIF Bracket 1	23- 8
H515 3145	PIF Bracket 2	23- 10
H515 3148	IC Card Guide	3- 5
H515 3149	Board Bracket	33- 5

PART N O.	DESCRIPTION	INDEX
H515 3152	Oppf Relay Bracket	27- 29
H515 3155	PIF Bracket 3	23- 9
H515 3155	PIF Bracket 3	23- 28
H515 3156	HDD Bracket	35- 4
H515 3159	Wire - Clip	11- 18
H515 3167	NCU Bracket	23- 12
H515 3362	Bracket - Pressure Roller	25- 21
H515 3363	Spring - Registration	25- 40
H515 3374	Holder - FDU	27- 10
H515 3375	FDU Cover	27- 11
H515 3376	Film Stay	25- 28
H515 3420	Bracket - Pressure Roller - Cass.	29- 35
H515 3451	Guide Plate - Upper - Front - F14	29- 44
H515 3452	Registration Roller	29- 33
H515 3453	Guide Plate - Registration - F14	29- 27
H515 3454	Guide Plate - Registration - Left	29- 29
H515 3455	Guide Plate - Registration - Right	29- 28
H515 3456	Shaft - Pressuer Rollre	25- 42
H515 3456	Shaft - Pressure Roller	29- 37
H515 3457	Pressuer Rollre - S	25- 41
H515 3457	Pressure Roller - S	29- 39
H515 3458	Spring - Registration	29- 38
H515 3459	Mylar - Guide Plate - 2	29- 15
H515 3460	Mylar - Guide Plate - 3	29- 23
H515 3461	Mylar - Guide Plate - 4	29- 25
H515 3465	Supporting Plate	29- 11
H515 3466	Plastic Rivet	29- 10
H515 3467	Mylar - Bracket	29- 36
H515 3469	Film	29- 47
H515 3511	Paper Feed Roller	31- 1
H515 3517	Bottom Plate - Cassette	31- 4
H515 3519	Paper Size Indicator	31- 29
H515 3520	Side Fence	31- 39

PART N O.	DESCRIPTION	INDEX
H515 3521	Knob - Side Fence	31- 37
H515 3522	End Fence	31- 24
H515 3523	Corner Separator - Left	31- 36
H515 3524	Corner Separator - Right	31- 6
H515 3525	Bracket - Paper End Sensor	31- 7
H515 3526	Bracket - Gear Arm	31- 14
H515 3527	Gear - Z32	31- 16
H515 3528	Gear - Z26	31- 15
H515 3531	Bushing - Paper Feed Roller	31- 10
H515 3532	Spring - Bottom Plate	31- 5
H515 3533	Spring - Gear Arm	31- 13
H515 3534	Spring - Side Fence	31- 38
H515 3535	Spring - Paper Size Indicator	31- 30
H515 3539	Spring Plate - Lock	31- 26
H515 3539	Spring Plate - Lock	31- 31
H515 3540	Paper Tray Extension	31- 22
H515 3541	Gear Cover	31- 41
H515 3542	Rivet	31- 35
H515 3543	Retaining Ring - M4	19- 74
H515 3543	Retaining Ring - M4	31- 12
H515 3544	E-ring - JR-E6	27- 36
H515 3544	E-ring - JR-E6	31- 17
H515 3545	Cover - Paper End Sensor	31- 9
H515 3546	Lower Cover	31- 23
H515 3550	Cover - Bypass Feed	31- 19
H515 3552	Bypass Feed Table Ass'y	31- 20
H515 3553	Stopper - Corner Separator	31- 42
H515 3554	Decal - Paper Limit	31- 25
H515 3555	Decal - Paper Set	31- 18
H515 3580	Grounding Plate	31- 45
H515 3581	Spacer	31- 43
H515 3595	Spacer	31- 44
H515 3693	Positioning Pin	27- 26

PART N O.	DESCRIPTION	INDEX
H515 4020	Cover - Left	3- 1
H515 4024	Cover - Rear	3- 17
H515 4025	Cover CT	3- 15
H515 4028	Cover - Fan	3- 22
H515 4029	Cover - V35	3- 7
H515 4030	Cover - G4	3- 6
H515 4031	Cover Right	3- 13
H515 4032	Cover - RS232C	3- 11
H515 4035	Rear Cover	3- 12
H515 4036	Cassette Cover	3- 24
H515 4055	Guide Mylar	3- 10
H515 4208	Operation Panel Ass'y	9- 12
H515 4258	Case - Dial Sheet	9- 32
H515 4259	Sheet - Operation Panel	9- 31
H515 4290	Quick Dial Plate	9- 29
H515 4307	Operating Seal - B	9- 30
H515 4308	Operating Seal - C	9- 1
H515 4316	Quick Dial Sheet	9- 28
H515 5000	TX Motor - DC24V;0.9A	11- 25
H515 5002	Original Sensor - S1	9- 14
H515 5003	Original Sensor - S2	9- 15
H515 5004	Original Sensor - S3	9- 13
H515 5005	Document Sensor - S4	9- 16
H515 5011	Xenon Lamp Driver	11- 16
H515 5012	Xenon Lamp - US	11- 42
H515 5014	Grounding Harness	27- 9
H515 5014	Grounding Harness	33- 4
H515 5015	Thermistor - Fusing	19- 2
H515 5017	Thermostat - Fusing	19- 20
H515 5018	Cover Switch - Fusing Exit	19- 34
H515 5022	Harness - Fusing Lamp	19- 29
H515 5024	Ground Wire - Fusing	19- 58
H515 5033	Power Pack	5- 1

PART N O.	DESCRIPTION	INDEX
H515 5034	Zenor Diode - 732V : HVRD	15- 71
H515 5037	Bias Cable - Charge	15- 22
H515 5038	Bias Cable - Transfer	15- 28
H515 5040	Polygonal Mirror Motor-DC24V;0.35A	13- 5
H515 5041	Ozone Fan Motor - DC24V;1.44W	23- 5
H515 5044	Optical Fibre - Laser Sync.	13- 10
H515 5050	Toner End Sensor	25- 12
H515 5054	Paper Size Sensor	27- 20
H515 5054	Paper Size Sensor	31- 28
H515 5056	Registration Sensor	25- 19
H515 5075	Paper Feed Clutch	31- 11
H515 5076	Paper End Sensor	31- 8
H515 5080	Relay Harness Assembly	31- 34
H515 5085	Harness - 100 Sheet Cassette	5- 30
H515 5085	Harness - 100 Sheet Cassette	27- 12
H515 5202	HDD I/F Cord	35- 1
H515 5203	PCB G4 I/F	33- 6
H515 5230	Microphone	37- 1
H515 5310	Motor Harness - RX	5- 7
H515 5311	Motor Harness - TX	5- 6
H515 5312	SBU Harness	5- 29
H515 5312	SBU Harness	11- 3
H515 5314	OPU Harness	5- 27
H515 5314	OPU Harness	9- 3
H515 5317	Exposure Lamp Harness	5- 25
H515 5317	Exposure Lamp Harness	11- 4
H515 5318	PFU Harness	27- 38
H515 5319	Option Tray Harness	5- 32
H515 5320	Motor Harness	5- 5
H515 5324	Ground Wire - 350	7- 6
H515 5324	Ground Wire - 350	11- 21
H515 5357	HDD Harness - 4P	35- 2
H515 5358	HDD Harness - 44P	35- 3

PART N O.	DESCRIPTION	INDEX
H515 5396	Seal Sheet	15- 87
H515 6013	PCB - μ FDU	5- 4
H515 6020	PCB - SBU	11- 2
H515 6220	PCB - μ FCE	5- 14
H515 7116	80M HDD	35- 5
H515 8607	Operation Manual - Twn	3- 0
H516 1058	Cover - Scanner - Left	3- 14
H516 1068	Bracket - Operation Panel	5- 18
H516 1262	Roller - Belt Tensioning	11- 33
H516 2119	Bracket - Table - Original	19- 37
H516 2127	Spacer - Fusing Exit Roller - Left	19- 15
H516 2198	Stopper - Fusing - F	19- 35
H516 2199	Stay - Front	25- 1
H516 2524	Film - Toner Duct - A4	15- 30
H516 2549	Seal - Toner Duct - Lower - A4	15- 14
H516 2710	BTL Lens	13- 12
H516 3116	Spacer - Development Unit - A4	25- 38
H516 3128	Bracket - Cord Clamper	23- 27
H516 3129	Ground Plate - Left	25- 3
H516 3135	Bracket - Top Cover Locking - Left	23- 1
H516 3137	Bracket - Top Cover Locking - Right	23- 20
H516 3139	Bracket - Cooling Fan	23- 21
H516 3140	Bracket - Ozone Fan	23- 6
H516 3141	Bracket - Ozone Filter	23- 2
H516 3142	Ozone Filter - 8	23- 3
H516 3146	Bracket - Toner End Sensor	25- 9
H516 3147	Harness Clamper - Base (US)	27- 1
H516 3149	Sponge - 2	25- 34
H516 3150	Sponge - 3	25- 37
H516 3151	Sponge - 4	25- 36
H516 3152	Sponge - 5	25- 39
H516 3153	Sponge - Cushion - Cooling Fan	23- 23
H516 3154	Sponge - Cushion - Ozone Fan	23- 7

PART N O.	DESCRIPTION	INDEX
H516 3157	Bushing - 66	27- 2
H516 3158	Plate - PSU	27- 8
H516 3301	Gear Box - Paper Feed	27- 17
H516 3319	Holder - Cassette - Left	27- 13
H516 3320	Holder - Cassette - Right	27- 22
H516 3328	Spacer - Cassette Entrance - Right	27- 24
H516 3329	Spacer - Cassette Entrance - Left	27- 27
H516 3330	Rail - Cassette - Front	27- 23
H516 3331	Rail - Cassette - Rear	27- 28
H516 3332	Lock - Cassette - Left	27- 14
H516 3333	Lock - Cassette - Right	27- 4
H516 3335	Shaft - Feed Roller - Left	27- 30
H516 3341	Bracket - Paper End Sensor	27- 6
H516 3344	Ground Plate - Registration Roller	27- 35
H516 3346	Bracket - Paper Size Sensor	27- 21
H516 3358	Spring - Pressure Roller	25- 27
H516 3359	Cover - Harness - Paper Size Sensor	27- 19
H516 3361	Rubber Foot	27- 25
H516 3370	Paper Feed Roller	27- 33
H516 3372	Shaft - Feed Roller - Right	27- 32
H516 3373	Stay - Feed Roller	27- 31
H516 3375	Spacer	25- 23
H516 3376	Ground Plate - Bracket - Regist.	25- 20
H516 3379	Ground Plate - Paper Feed Motor	27- 5
H516 3381	Ground Plate - Cassette - Left	29- 46
H516 3384	Spring Plate - Lock	25- 30
H516 3385	Support Plate - Left Side Plate	27- 34
H516 3401	Cassette	29- 18
H516 3410	Bottom Plate - Cassette	29- 2
H516 3411	Separation Hook - Cassette - Left	29- 14
H516 3412	Side Fence - Cassette	29- 12
H516 3413	Separation Hook - Cassette - Right	29- 9
H516 3414	End Fence - Cassette	29- 8

PART N O.	DESCRIPTION	INDEX
H516 3415	Paper Guide Plate - Bypass	29- 19
H516 3417	Bushing - Registration Roller	29- 32
H516 3419	Gear - Registration Roller	29- 31
H516 3421	Friction Pad - Bottom Plate - Large	29- 3
H516 3425	Lock - Bottom Plate	29- 17
H516 3425	Lock - Bottom Plate	31- 33
H516 3426	Spring - Lock - Bottom Plate	29- 16
H516 3426	Spring - Lock - Bottom Plate	31- 32
H516 3429	Paper Size Sensor Board - A4	29- 22
H516 3433	Paper Size Sensor	29- 22
H516 3434	Shaft - Pressure Roller	25- 26
H516 3434	Shaft - Pressure Roller	29- 40
H516 3435	Actuator - Bypass Feed Sensor	29- 43
H516 3437	Manual Feed Table	29- 21
H516 3438	Spring Plate - End Fence	29- 7
H516 3439	Stopper - Fence	29- 13
H516 3443	Mylar - Paper Guide - 1	29- 24
H516 3447	Spring - Registration Roller	29- 30
H516 3448	Spring - Pressure Roller	29- 41
H516 3449	Spring - Bypass Sensor Actuator	29- 42
H516 3450	Spring Bottom Plate	29- 5
H516 3470	Decal - Paper Set - Cassette	29- 1
H516 3471	Sponge - End Fence	29- 6
H516 3482	Spring Plate - Bracket -right	29- 34
H516 3510	Paper Tray - 100 Sheet Cassette	31- 27
H516 3529	Friction Pad - Large	31- 2
H516 3530	Friction Pad - Small	31- 3
H516 3582	Decal - Bypass Feed	31- 40
H516 3583	Decal - Bypass Feed	29- 20
H516 4023	Cover - IC Memory Card	3- 3
H516 4026	Cover - MEXH Counter	3- 9
H516 4028	Document Table	3- 19
H516 4034	Document Tray	3- 25

PART N O.	DESCRIPTION	INDEX
H516 4040	Cover Printer I/F - Lower	3- 21
H516 4043	Cover - Connector	3- 2
H516 4046	Cover - Printer I/F - Upper	3- 8
H516 4047	Cover - NCU	3- 16
H516 5012	Ground Wire - Image Sensor	19- 72
H516 5031	Monitor Speaker	3- 4
H516 5041	Cooling Fan Motor - DC24V;3.6W	23- 24
H516 5050	Paper End Sensor	27- 7
H516 5052	Stepper Motor-paper Feed 24VDC13W	27- 15
H516 5301	Harness - Paper Size	27- 37
H516 5302	Harness - LDDR	5- 10
H516 5303	Harness - PP - F	5- 9
H516 5308	Driver Harness	5- 8
H516 5311	Sensor Harness	5- 28
H516 5311	Sensor Harness	25- 11
H516 5314	Safety Switch Harness	5- 31
H516 5314	Safety Switch Harness	23- 15
H516 5315	Harness - Interlock SW. - 24V	23- 18
H516 5322	Relay Harness - Fusing Unit	5- 11
H518 5400	PCB - PSU - 115V	5- 21
H521 2111	Pressure Roller - B4	19- 51
H521 2112	Upper Case - Fusing - B4	19- 8
H521 2115	Spring - Pressure Roller	19- 48
H521 2184	Decal - Warning	19- 66
H521 3144	Harness Clamp	25- 15
H521 3145	Sponge - Lock - Front	25- 5
H521 3147	Sponge - Cooling Fan - 1	25- 17
H521 3148	Sponge - Cooling Fan - 2	25- 35
H521 3149	Sponge - Cooling Fan - 3	25- 16
H521 3150	Sponge - Cooling Fan - 4	25- 18
H521 3151	Sponge - Base - Upper Left (US)	25- 6
H521 3153	Sponge - Base - Left - Middle	25- 4
H521 3156	Sponge - Registration - 1	25- 10

PART N O.	DESCRIPTION	INDEX
H521 3157	Sponge - Registration - 2	25- 14
H521 3158	Sponge - Power Pack - 1	25- 7
H521 3159	Sponge - Power Pack - 2	25- 8
H521 3160	Sponge - Base - Bottom	25- 24
H521 3161	Seal - Base - Bottom - 1	25- 32
H521 3162	Seal - Base - Bottom - 2	25- 33
H521 3164	Pin - Right Fulcrum	5- 22
H521 3182	Bracket Interlock SW.	23- 16
H521 3340	Pressure Roller - Registration	25- 25
H521 3340	Pressure Roller - Registration	29- 45
H521 3352	Bracket - Plotter Base Connection	25- 2
H521 3379	Sponge - Bracket - Pressure Roller	25- 31
H521 3419	Friction Pad - Bottom Plate - Small	29- 4
H521 4031	Copy Tray	3- 20
H521 4032	Copy Tray - B4	3- 23
H521 4056	Decal LD	13- 2
H521 5016	Fusing Lamp - B4 - 115V	19- 28
H521 5042	Ground Wire - Lock - Front	23- 22
H521 5309	Harness - NCU	5- 19
H521 5310	Harness - Sen1	25- 13
H521 5312	Harness - Fusing Sensors	19- 32
H521 5321	Harness - Mirror Motor	5- 26
H521 5321	Harness - Mirror Motor	13- 4
H521 5322	Harness - PSU	5- 12
H521 5324	Relay Harness - Interlock - 5V	23- 17
H521 5326	Heater Relay Harness	19- 70
H521 5357	Power Cord - Twn	23- 13

PART N O.	DESCRIPTION	INDEX
A048 6149	Decal - Manual Feed	29- 26
5447 2681	Snap Ring	7- 20
5466 3198	Washer - SBU	11- 1
5488 6020	PCB - NCU	5- 23

PART N O.	DESCRIPTION	INDEX
0313 0040B	Philips Pan Head Screw - M3x4	7-103
0313 0040B	Philips Pan Head Screw - M3x4	9-102
0313 0060B	Philips Pan Head Screw - M3x6	5-106
0313 0060B	Philips Pan Head Screw - M3x6	19-101
0313 0060B	Philips Pan Head Screw - M3x6	27-104
0313 0080B	Philips Pan Head Screw - M3x8	19-102
0313 0120B	Philips Pan Head Screw - M3x12	23-110
0313 0300B	Philips Pan Head Screw - M3x30	23-102
0353 0060Z	Screw - M3X6	3-101
0353 0060Z	Screw - M3X6	5-107
0353 0080Z	Philips Trass Head Screw - M3x8	5-108
0353 0080Z	Philips Trass Head Screw - M3x8	7-101
0433 0102B	Tapping Screw - M3x10	7-105
0443 0060W	Hexagon Head Tapping Screw - M3x6	3-104
0443 0060W	Hexagon Head Tapping Screw - M3x6	5-101
0443 0060W	Hexagon Head Tapping Screw - M3x6	5-109
0443 0060W	Hexagon Head Tapping Screw - M3x6	15-106
0443 0060W	Hexagon Head Tapping Screw - M3x6	23-103
0443 0060W	Hexagon Head Tapping Screw - M3x6	25-101
0443 0060W	Hexagon Head Tapping Screw - M3x6	27-102
0701 0030B	Flat Washer - M3	11-105
0701 0040B	Flat Washer - M4	23-105
0720 0020E	Retaining Ring - M2	15-110
0720 0025E	Retaining Ring - M2.5	15-111
0720 0030E	Retaining Ring - M3	11-107
0720 0030E	Retaining Ring - M3	15-112
0720 0040E	Retaining Ring - M4	15-113
0720 0050E	Retaining Ring - M5	11-108
0802 5205	Tapping Screw - M3x6	19-116
0802 5206	Tapping Screw - M3x8	3-103
0802 5206	Tapping Screw - M3x8	5-102
0802 5206	Tapping Screw - M3x8	9-103
0802 5206	Tapping Screw - M3x8	11-102

PART N O.	DESCRIPTION	INDEX
0802 5206	Tapping Screw - M3x8	15-117
0802 5206	Tapping Screw - M3x8	19-117
0802 5206	Tapping Screw - M3x8	23-101
0802 5206	Tapping Screw - M3x8	25-102
0802 5210	Tapping Screw - M3x8	23-107
0802 5230	Tapping Screw - M3x10	3-102
0802 5230	Tapping Screw - M3x10	11-109
0802 5230	Tapping Screw - M3x10	13-101
0805 3386	Bushing - 8mm	11-110
0805 3386	Bushing - 8mm	27-108
0950 4006B	Screw - M4x6	23-106
0951 3006B	Philips Screw With Flat Washer-m3x6	3-105
0951 3006B	Philips Screw With Flat Washer-m3x6	5-103
0951 3006B	Philips Screw With Flat Washer-m3x6	11-106
0951 3006B	Philips Screw With Flat Washer-m3x6	15-120
0951 3006B	Philips Screw With Flat Washer-m3x6	19-120
0951 3006B	Philips Screw With Flat Washer-m3x6	23-104
0951 3006B	Philips Screw With Flat Washer-m3x6	27-105
0951 3008B	Philips Screw With Flat Washer-m3x8	11-104
0954 3006B	Screw - M3X6	19-122
0954 3010B	Philips Screw - M3x10	11-101
0964 3006B	Tapping Screw - M3x6	27-103
0965 3006B	Tapping Screw With Flat Washer M3x6	3-106
0965 3006B	Tapping Screw With Flat Washer M3x6	7-104
0965 3008B	Tapping Screw With Washer - M3x8	7-102
0965 3008B	Tapping Screw With Washer - M3x8	9-101
0965 3008B	Tapping Screw With Washer - M3x8	27-101
0965 3010B	Tapping Screw With Flat Washerm3x6	11-103
1102 4473	CT Connector - 2P	19-136
1102 4681	Connector - 5557-02R-210	5-110
1104 0502	PS Holder	5-105
1105 0243	Wire Saddle	27-109
1105 0246	Spacer	5-104

PART N O.	DESCRIPTION	INDEX
1105 0260	Wire Saddle	27-107
1105 0283	Clamp	9-104
1105 0344	Clamp	23-108
1105 0344	Clamp	27-106
1204 2334	Safety Switch - FA1I-AA20	23-109
1607 0638	Ferrite Core - TFC25-15-12	35-101

PART N O.	DESCRIPTION	INDEX