

## 7. PARTS CATALOG

This section includes information of Europe (including France) and Asia models for Ricoh, NRG, and Infotec.


The following parts for the FR4 are different from the FX4.

Index	FX4	FR4	Description	Remarks
3-	H5158609	H5518609	Operation Manual - Ricoh Asia	(Asia only)
	H5158629	H5518639	Operation Manual - NRG Asia	(Asia only)
3-	----	H5518659	Quick Reference Guide - Asia	(Asia only)
5-4	H5156014	H5516012	PCB - MFDU (FR4) - EUR/Asia	
5-5	H5155320	----	Motor Harness	
5-6	H5155311	----	Motor Harness - TX	
5-7	H5155310	----	Motor Harness - RX	
5-8	H5165308	----	Driver Harness	
5-9	H5165318	H5515356	Harness - Power Pack	FDU CN21
5-10	H5165302	H5515339	Harness - LDDR	FDU CN22
5-11	H5165322	----	Relay Harness - Fusing Unit	
5-13	H5153140	H5513140	Spacer - 8 mm	
5-14	H5156283	H5516140	PCB - MFCE (FR4) - EUR/Asia	
5-15/ 13/1	H5152042	H5522042	Laser Plotter Unit	
5-19	H5215309	H5215339	Harness - NCU	
5-21	H5155600	H5515600	PCB - PSU - 230V	
5-23	54886040	54886050	PCB - NCU - EUR/Asia	
	54886060	54886070	PCB - NCU - France	
5-24	H5153146	H5513120	PSU Cover	
5-26/ 13-4	H5155323	H5525310	Harness - Polygon Mirror Motor	FDU CN14
5-27	H5155326	H5515338	OPU Harness	FDU CN20
5-30	H5155085	H5515363	Harness - 100 Sheet Cassette	FDU CN71
5-31	H5165314	H5515316	Safety Switch Harness	
5-33	H5155316	H5515362	NCU Harness2	FDU CN4 Note 1
7-12	H5154206	H5514206	Operation Panel Ass'y - Ricoh Asia	(Asia only)

Index	FX4	FR4	Description	Remarks
7-27	H5154312	H5514312	Operation Panel Sheet - Ricoh Asia	(Asia only)
	----	H5514303	Operation Panel Sheet - Nashua	(Asia only)
	----	H5514304	Operation Panel Sheet - Gestetner	(Asia only)
	----	H5514214	Operation Panel Sheet - Rex Rotary	(Asia only)
7-32	H5154252	----	Decal Case	(Asia only)
7-35	----	H5511600	Spacer - Pressure Plate	Note 2
13-5	H5155040	H5525040	Polygon Mirror Motor	
13-7	H5152715	H5522715	Laser Diode Unit	
21-	H5162101	H5512101	Fusing Unit Ass'y - 230V	
21-2	H5155015	H5525015	Thermistor - Fusing	
23-8	H5153142	H5513142	PIF Bracket 1	
23-10	H5153143	H5513143	PIF Bracket 2	
23-12	H5153141	H5513141	NCU Bracket	
23-29	----	H5513130	NCU Ground Plate	Note 3
27-2	H5163157	----	Bushing - 66	
27-3	H5153122	H5513122	PSU Bracket	
27-37	H5165301	----	Harness - Paper Size	
27-38	H5155318	H5515341	PFU Harness	FDU CN75
29-33	H5163583	H5513584	Decal - Bypass Feed	
		H5513189	Ground Plate - FCE	
		H5513190	FCE - Holder	
		H5514010	Quick Reference Guide Holder	
		H5515310	Harness - TX/RX Motor	FDU CN17
		H5515311	Relay Harness - Fusing/Paper Size	FDU CN6
		H5515312	Harness - Main Motor	FDU CN15
		H5515314	Harness - Driver	FDU CN16
		H5515315	Harness - Mech. Counter	FDU CN76
		H5533861	Decal - Super G3	


**NOTE:** Operation manuals for Europe are only available in the language kits. Please refer to the next page for the location of parts that are marked as “Note.”

Note 1: Index No. 5-33 P/N: H5515362: NCU Harness 2




H551A501.WMF

Note 2: Index No. 7-35 P/N: H5511600: Spacer - Pressure Plate



H551A502.WMF

Note 3: Index No. 23-29 P/N: H5513130: NCU Ground Plate



H551A503.WMF