

R I C O H

PARTS CATALOG

FOR

FAX4700L/4700LF

RICOH COMPANY, LTD.

1	October 31th, 1995	First edition

PARTS CATALOG

INTRODUCTION


This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG

Section 1.Part Location and List

1.EXTERIOR 1.....	1- 2	13.BASE FRAME 3.....	1-26
2.EXTERIOR 2.....	1- 4	14.250 SHEET CASSETTE	1-28
4.ADF.....	1- 6	15.100 SHEET CASSETTE OPTION	1-30
3.OPERATION PANEL.....	1- 8	16.ISDN.....	1-32
5.SCANNER	1-10	17.80 MB HDD	1-34
6.LASER UNIT.....	1-12	18.FOD.....	1-36
7.DEVELOPMENT 1.....	1-14	Section 2.Parts Index	2- 1
8.DEVELOPMENT 2.....	1-16		
9.FUSING 1	1-18		
10.FUSING 2	1-20		
11.BASE FRAME 1	1-22		
12.BASE FRAME 2.....	1-24		

1. EXTERIOR 1




1. EXTERIOR 1

INDEX	PARTS NO.	DESCRIPTION	Note
	*	H515 8600	Operation Manual - FX4 - US
	*	H515 8601	Operation Manual - English (EU)
	*	H515 8602	Operation Manual - German
	*	H515 8603	Operation Manual - Italian
	*	H515 8604	Operation Manual - Spanish
	*	H515 8605	Operation Manual - French
	*	H515 8606	Operation Manual - Swedish
	*	H515 8609	Operation Manual (ASIA)
	1	H515 4020	Cover - Left
	2	H516 4043	Cover - Connector
	3	H516 4023	Cover - IC Memory Card
	4	H516 5031	Monitor Speaker
	5	H515 3148	IC Card Guide
	6	H515 4030	Cover - G4
	7	H515 4029	Cover - V35
	8	H516 4046	Cover - Printer I/F - Upper
	9	H516 4026	Cover - MEXH Counter
	10	H515 4055	Guide Mylar
	11	H515 4032	Cover - RS232C
	12	H515 4033	Rear Cover - Upper
	13	H515 4031	Cover Right
	14	H516 1058	Cover - Scanner - Left
	15	H515 4025	Cover CT
	16	H516 4047	Cover - NCU
	17	H515 4024	Cover - Rear
	18	H081 5700	Modular Cord - 6p/6p
	19	H516 4028	Document Table
	20	H516 4031	Copy Tray (US/ASIA)
	21	H516 4040	Cover Printer I/F - Lower
	22	H515 4028	Cover - Fan
	24	H515 4036	Cassette Cover
	25	H516 4034	Document Tray

INDEX	PARTS NO.	DESCRIPTION	Note
101	0353 0060Z	Screw - M3X6	
102	0802 5230	Tapping Screw - M3x10	
103	0802 5206	Tapping Screw - M3x8	
104	0443 0060W	Hexagon Head Tapping Screw - M3x6	
105	0951 3006B	Philips Screw With Flat Washer-m3x6	
106	0965 3006B	Tapping Screw With Flat Washer M3x6	
	 	 	


2. EXTERIOR 2



2. EXTERIOR 2

INDEX	PARTS NO.	DESCRIPTION	Note	INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 5047	Power Supply - Pack - USA		27	H515 5314	OPU Harness	
1	H516 5049	Power Supply - Pack - EUR/ASIA		28	H516 5311	Sensor Harness	
2	H515 3130	Cover - Power Pack		29	H515 5312	SBU Harness	
3	H515 3116	Fulcrum - Fusing Unit		30	H515 5085	Harness - 100 Sheet Cassette	
4	H515 6011	PCB - μ FDU - FX4 - US		31	H516 5314	Safety Switch Harness	
4	H515 6014	PCB - μ FDU - EUR/ASIA		32	H515 5319	Option Tray Harness	
5	H515 5320	Motor Harness					
6	H515 5311	Motor Harness - TX					
7	H515 5310	Motor Harness - RX					
8	H516 5308	Driver Harness					
9	H516 5318	Harness - Power Pack					
10	H516 5302	Harness - LDDR					
11	H516 5322	Relay Harness - Fusing Unit					
12	H521 5322	Harness - PSU					
13	H515 3140	Spacer - 8mm					
14	H515 6200	PCB - MFCE - FX4 - US					
14	H515 6220	PCB - MFCE - EUR					
14	H515 6230	PCB - MFCE - Asia					
15	H515 2040	Laser Protter Unit					
16	H515 2724	Clip - LASER UNIT					
17	H515 2734	Bracket - Base					
18	H516 1068	Bracket - Operation Panel					
19	H521 5309	Harness - NCU		101	0443 0060W	Hexagon Head Tapping Screw - M3x6	
20	G011 3275	Snap Ring		102	0802 5206	Tapping Screw - M3x8	
21	H515 5400	PCB - PSU - 115V		103	0951 3006B	Philips Screw With Flat Washer-m3x6	
21	H515 5600	PCB - PSU - 220V		104	1105 0246	Spacer	
22	H521 3164	Pin - Right Fulcrum		105	1104 0502	PS Holder	
23	5488 6020	PCB - NCU - USA		106	0313 0060B	Philips Pan Head Screw - M3x6	
23	5488 6040	PCB - NCU : Europe/asia		107	0353 0060Z	Screw - M3X6	
24	H515 3134	PSU Cover		108	0353 0080Z	Philips Trass Head Screw - M3x8	
25	H515 5317	Exposure Lamp Harness		109	0443 0060W	Hexagon Head Tapping Screw - M3x6	
26	H521 5321	Harness - Mirror Motor		110	1102 4681	Connector - 5557-02R-210	


3. OPERATION PANEL



3. OPERATION PANEL

INDEX	PARTS NO.	DESCRIPTION	Note		INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 4308	Operating Seal - C			31	H515 4253	Operation Panel Case	
2	H515 1263	Bracket - Grounding			32	H515 4252	Decal - Case (USA)	
3	H515 5314	OPU Harness			33	H515 1342	Sheet - ADF Guide Plate	
4	H515 1324	Spring Plate - R1/R2 - Right			34	H515 1340	Grounding Plate Spacer	
5	H515 1323	Spring Plate - R1/R2 - Left						
6	H515 1336	Spring - Ground (Earth) - Pipe						
7	H515 1267	Grounding Plate						
8	H081 1147	Pressure Roller Assy						
9	H515 1301	Shaft - Pressure Roller						
10	H515 1313	Sponge Collar - R1						
11	H515 1312	Pressure Roller - R1						
12	H515 4202	Operation Panel Ass'y - FX4 - US						
12	H515 4204	Operation Panel Ass'y - EUR						
12	H515 4206	Operation Panel Ass'y (ASIA)						
13	H515 5004	Original Sensor - S3						
14	H515 5002	Original Sensor - S1						
15	H515 5003	Original Sensor - S2						
16	H515 5005	Document Sensor - S4						
17	H515 1271	Shaft - Separetion Pressure						
18	H515 1277	Clip - Base - Shading Plate						
19	H515 1339	2nd Scanner Sheet						
20	H515 1303	Spring - Shading Plate						
21	H515 1279	Base - Shading Plate						
22	H515 1338	1st Scanner Sheet						
23	H515 1331	Mylar - ADF						
24	H515 1293	Pressure Plate - Pickup						
25	H515 1205	Separation Plate Ass'y						
26	H515 1250	ADF Guide Plate - Upper						
27	H515 4312	Operating Seal - A (USA)			101	0965 3008B	Tapping Screw With Washer - M3x8	
28	H515 4316	Quick Dial Sheet			102	0313 0040B	Philips Pan Head Screw - M3x4	
29	H515 4290	Quick Dial Plate			103	0802 5206	Tapping Screw - M3x8	
30	H515 4307	Operating Seal - B (EUR)			104	1105 0283	Clamp	

4. ADF




4. ADF

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 1287	Brake Gear	
2	H515 1292	Cover - ADF	
3	H515 1204	ADF Feeder Unit	
4	H515 1322	Seal 2	
5	H515 1298	Spring Plate - CTM	
6	H515 5324	Ground Wire - 350	
7	H515 1321	Sponge - Fusing 1	
8	H515 2831	Spring Plate - CTM	
9	H515 1318	Bracket - Top Cover	
10	H515 1335	Ground Plate - ADF - Lower 2	
11	H515 1337	Bracket - Plate - Ground Wire	
12	H515 1283	Pinion Gear - Document Guide	
13	H515 1282	Rack Gear - Document Guide	
14	H515 1305	Hook - Cover Lock - Left	
15	H515 1251	Top Cover	
16	H515 1307	Guide - Original - Left	
17	H515 1290	Plumber Block - ADF Roller - Right	
18	H515 1291	Plumber Block - ADF Roller - Left	
19	H515 1285	Gear - Document Feed	
20	5447 2681	Snap Ring	
21	H515 1284	Shaft - Document Feed	
22	H053 1600	Bushing - M6 : CMFE	
23	H515 1295	Spring - Lock	
24	H515 1304	Hook - Cover Lock - Right	
25	H515 1296	Lever - Lock Release	
26	H515 1294	Shaft - Lock	
27	H515 1297	Lock Lever - Operation Panel	
28	H515 1306	Guide Original - Right	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0353 0080Z	Philips Trass Head Screw - M3x8	
102	0965 3008B	Tapping Screw With Washer - M3x8	
103	0313 0040B	Philips Pan Head Screw - M3x4	
104	0965 3006B	Tapping Screw With Flat Washer M3x6	
105	0433 0102B	Tapping Screw - M3x10	


5. SCANNER



5. SCANNER

INDEX	PARTS NO.	DESCRIPTION	Note	INDEX	PARTS NO.	DESCRIPTION	Note
1	5466 3198	Washer - SBU		33	H516 1262	Roller - Belt Tensioning	
2	H515 6020	PCB - SBU		34	H515 1272	Motor Bracket	
3	H515 5312	SBU Harness		35	H515 1286	Development Gear - TX	
4	H515 5317	Exposure Lamp Harness		36	H515 1288	Brake Spacer	
5	H515 1077	Cover - Lens		37	H515 1058	Front Lamp Clip	
6	H515 1061	Lens Holder		38	H515 1069	Grounding Wire	
7	H014 1101	Lense - F22.6		39	H515 1317	Gear	
8	H515 1060	Shield Plate		40	H515 1075	Dvelopment Fixing Plate	
9	H515 1064	Rear Cover Bracket		41	H515 1266	Pulley - R2 Roller	
10	H515 1052	Exposure Glass Clip		42	H515 5012	Xenon Lamp - US	
11	H515 1081	Exposure Glass		42	H515 5010	Xenon Lamp (EUR/ASIA)	
12	H515 1233	R2 Roller		43	H515 1265	Pulley - R1	
13	H515 1232	R1 Roller		44	H053 1600	Bushing - M6 : CMFE	
14	H515 1062	Bushing - R1/R2 Rollers		45	H515 1070	Cover - Drive	
15	H515 1086	R2 Guide Mylar		46	H515 1090	Left Holder - Exposuer Glass	
16	H515 5011	Xenon Lamp Driver		47	H515 1091	Right Holder - Exposuer Glass	
17	H515 1050	Scanner Base					
18	H515 3159	Wire - Clip					
19	H515 1056	Lamp Bracket					
20	H515 1073	Grounding Plate - Lamp Bracket					
21	H516 5012	Ground Wire - Image Sensor					
22	H515 1055	Mirror Clip					
23	H515 1076	Harness Bracket		101	0954 3010B	Philips Screw - M3x10	
24	H511 5005	Stamper		102	0802 5206	Tapping Screw - M3x8	
25	H515 5000	TX Motor - DC24V;0.9A		103	0965 3010B	Tapping Screw With Flat Washerm3x6	
26	H515 1065	Motor Cushion		104	0951 3008B	Philips Screw With Flat Washer-m3x8	
27	H515 1084	R1 Gide Mylar		105	0701 0030B	Flat Washer - M3	
28	H515 1054	2nd Mirror		106	0951 3006B	Philips Screw With Flat Washer-m3x6	
29	H515 1053	1st Mirror		107	0720 0030E	Retaining Ring - M3	
30	H515 1276	Timing Belt - TX		108	0720 0050E	Retaining Ring - M5	
31	H515 1072	Cover - Scanner		109	0802 5230	Tapping Screw - M3x10	
32	H515 1281	Spring Plate		110	0805 3386	Bushing - 8mm	

6. LASER UNIT



6. LASER UNIT



INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2040	Laser Protter Unit	
2	H521 4056	Decal LD	
3	H515 2714	Cover - Laser Unit	
4	H521 5321	Harness - Mirror Motor	
5	H515 5040	Polygonal Mirror Motor-DC24V;0.35A	
6	H515 2717	Laser Sync. Detector	
7	H515 2715	Laser Diode Unit	
8	H515 2712	Laser Exposure Glass	
9	H515 2723	Spring Plate - Exposure Glass	
10	H515 5044	Optical Fibre - Laser Sync.	
11	H515 2719	Spring Plate - BTL - Left	
12	H516 2710	BTL Lens	
13	H515 2720	Spring Plate - Btl - Right	
14	H515 2721	Spring Plate - Mirror - Laser Sync.	
15	H515 2711	Mirror - Synchronization	
16	H515 2725	Cylindrical Lens - Laser	
17	H515 2722	Spring Plate - Lens - Laser	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0802 5230	Tapping Screw - M3x10	





7. DEVELOPMENT 1




INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2414	Bearing - DVLP. Roller - Left	
2	H515 2550	Gear - Rubber Roller -Z18	
3	H516 2519	Rubber Roller - Development - A4	
4	H515 2415	Bearing - DVLP. Roller - Right	
5	H515 2405	Rubber Roller Ass'y - DVLP -B4	
6	H516 2401	Development Unit - A4	
7	H516 2500	Toner Duct - A4	
8	H516 2524	Film - Toner Duct - A4	
9	H515 2551	Seal - Duct - R	
10	H516 2505	Toner Duct Shield - A4 - 2	
11	H515 2506	Seal - Duct - S	
12	H516 2432	Cover - Toner Hopper - A4	
13	H515 2536	Seal - Development - C	
14	H516 2549	Seal - Toner Duct - Lower - A4	
15	H516 2544	Toner Agitator - Development	
16	H516 2516	Magnet Roller - Development - A4	
17	H515 2502	Seal - Roller	
18	H515 2535	Seal - B	
19	H515 2474	Terminal Plate - Development - L	
20	H515 2530	Terminal Plate - B	
21	H515 2559	Terminal Plate Ass'y - Contact	
22	H516 5045	Cable - Charge Bias - A4	
23	H515 2478	Terminal Plate - Charge - M	
24	H516 2475	Terminal - Rubber Roller - A4	
25	H515 2473	Terminal Plate - Development - S	
26	H515 2534	Seal - Development - A	
27	H515 2471	Terminal Plate - Transfer - L	
28	H516 5046	Cable - Transfer Bias - A4	
29	H516 2548	Film - Toner Hopper - A4	
30	H516 2555	Lower Seal	
31	H515 2487	Stopper - Pin	
32	H515 2488	Stopper - Receptacle	



INDEX	PARTS NO.	DESCRIPTION	Note
33	H516 2412	Toner Metering Blade - A4	
34	H516 2528	Sheild - Rubber Roller - A4	
35	H516 2518	Antistatic Brush - Mag. Roller - A4	
36	H515 2417	Terminal - Quenching Lamp	
37	H515 2468	Terminal Plate - Ground	
38	H515 2482	Terminal Plate - OPC Drum	
39	H515 2543	Holder - Terminal Plate - OPC Drum	
40	H515 2413	Gear - Agitator	
41	H515 2442	Gear - Mag. Roller	
42	H515 2411	Bearing - Mag. Roller - Right	
43	H515 2463	Shaft - Idler 2	
44	H515 2457	Bushing - Idler 2 - Large	
45	H515 2446	Drive Gear - OPC Drum	
46	H515 2410	Bearing - Mag. Roller - Left	
47	H515 2542	Stopper - Bearing - M6	
48	H515 2547	Holder - Harness	
49	H515 2552	Shield - Roller - R	
50	H081 2438	Shaft - Agitator	
51	H516 2501	Toner Duct Shield - A4 - 1	
52	H516 2561	Instruction Sheet - A4 - L	
53	H516 2564	Plate - Instruction Sheet - A4	
54	H516 2562	Instruction Sheet - A4 - S - 1	
55	H516 2563	Instruction Sheet - A4 - S - 2	
56	H515 5396	Seal Sheet	
57	H515 2571	Upper Seal - B4	
58	H515 2554	Stopper - Pin - L	
59	H516 2574	Spacer - Ball Bearing	
60	H515 2568	Stopper - Ball Bearing	
61	H515 2569	Shield - Toner Hopper - Drive - 1	
62	H515 2570	Shield - Toner Hopper - Drive - 2	

8. DEVELOPMENT 2




8. DEVELOPMENT 2

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2452	Gear - Transfer Roller	
2	H515 2461	Pulley - Transfer	
3	H516 2404	Transfer Roller - A4	
4	H515 2455	Holder - Transfer Roller - Left	
5	H515 2485	Spring - Transfer Roller	
6	H515 2456	Holder - Transfer Roller - Right	
7	H516 2580	Guide - Transfer Roller - Ass'y	
8	H515 2469	Terminal Plate - Transfer - S	
9	H516 2460	Antistatic Brush - Separation - A4	
10	H515 2472	Terminal Plate - Separation	
11	H515 2493	Drive Gear - Fusing	
12	H515 2450	Idler Gear 6	
13	H515 2467	Shaft - Idler 6	
14	H515 2492	Bracket - Fusing Drive Gear	
15	H515 2494	Shaft - Drive Gear - Fusing	
16	H515 2462	Shaft - Idler 1	
17	H515 2443	Idler Gear 1 - Small	
18	H515 2444	Idler Gear 1 - Large	
19	H515 2445	Idler Gear 2 - Large	
20	H515 2466	Shaft - Idler 5	
21	H515 2449	Idler Gear 5	
22	H515 2541	Deal - Shutter Guide	
23	H515 2416	Main Motor Ass'y - DC24V;16.1W	
24	H515 2495	Spring - Bracket - Fusing Drive	
25	H515 2447	Idler Gear 3	
26	H515 2448	Idler Gear 4	
27	H516 5048	Zener Diode - 698V - HVRD	
28	H515 2491	Inner Cover - Development	
29	H515 2458	Bushing - Idler 2 - Small	
30	H515 2496	Terminal Plate - Grid	
31	H515 2567	Sheet - Guide Plate	
32	H516 2407	Hopper - A4	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0443 0060W	Hexagon Head Tapping Screw - M3x6	
102	0720 0030E	Retaining Ring - M3	
103	0720 0020E	Retaining Ring - M2	

9. FUSING 1




9. FUSING 1

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2155	Cover - Right - Fusing	
2	AW02 0021	Photointerruptor - 175487-3	
3	H521 5312	Harness - Fusing Sensors	
4	H515 2179	Cover - Connector	
5	H516 2198	Stopper - Fusing - F	
6	H515 2144	Stopper - Fusing	
7	H515 2134	Lock Lever - Right	
8	H516 2119	Bracket - Table - Original	
9	H516 2152	Antistatic Brush - Fusing - A4	
10	H515 2135	Shaft - Lock Lever	
11	H515 2178	Bracket - Lamp Connector	
12	H515 2180	Bracket - Idler Gear	
13	H515 2157	Fusing Inner Cover - Right	
14	H515 2133	Lever - Lock - Left	
15	H515 2136	Spring - Lock Lever	
16	H516 2121	Inner Cover - A4	
17	H515 2158	Fusing Inner Cover - Left	
18	H515 2165	Cover - Left	
19	H515 2121	Spring Plate - Fusing Exit	
20	H515 2122	Fusing Exit Roller	
21	H516 2126	Bracket - Fusing - A4	
22	H516 2120	Cover - Exit - A4	
23	H516 2118	Cover - Front - F16 - A4	
24	H515 2184	Decal - Warning	
26	H516 2135	Ground Plate - Exit - A4 (US)	
27	H516 5012	Ground Wire - Image Sensor	
28	H516 2130	Guide Plate - Fusing Exit - A4	
29	H516 2136	Sponge - A4	
	 		

INDEX	PARTS NO.	DESCRIPTION	Note
100	0802 5206	Tapping Screw - M3x8	
101	0951 3006B	Philips Screw With Flat Washer-m3x6	
103	0313 0060B	Philips Pan Head Screw - M3x6	


10. FUSING 2



10. FUSING 2

INDEX	PARTS NO.	DESCRIPTION	Note	INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 2143	Holder - Thermistor		32	H515 2154	Spring - Pressure Roller	
2	H515 5015	Thermistor - Fusing		33	H515 2169	Bearing - Pressure Roller	
3	H515 2149	Actuator - Fusing Exit Sensor		34	H515 2163	Spring Plate - Right	
4	H515 2161	Spring - Sensor Actuator		35	H516 2111	Pressure Roller - A4	
5	H515 2153	Spring - Hot Roller Stripper		36	H516 2116	Lower Case - Fusing - A4	
6	H515 2148	Left Lock Lever		37	H515 2182	Stepped Screw	
7	H516 2159	Cover - Thermistor		38	H515 2177	Bracket - Pressure Roller - Left	
8	H516 2112	Upper Case - Fusing - A4		39	H515 2164	Spring Plate - Left	
9	H515 2127	Idler Gear - Z18		40	H515 2171	Spring Plate - Pressure Roller	
10	H515 2167	Holder - Fusing Lamp		41	H515 2156	Ground Plate - Hot Roller	
11	H515 2119	Cover - Gear		42	H515 5024	Ground Wire - Fusing	
12	H515 2128	Gear - Fusing Exit Roller		43	H516 2150	Cleaning Pad - Fusing	
13	H515 2139	Bushing - Fusing Exit Roller		44	H515 2168	Lock Spring - Cleaning Pad	
14	H515 2166	Roller - Exit Roller		45	H521 5326	Heater Relay Harness	
15	H516 2127	Spacer - Fusing Exit Roller - Left		46	H515 3543	Retaining Ring - M4	
16	H516 2117	Fusing Exit Roller - A4		47	H516 2134	Terminal Plate - Thermofuse - Front	
17	H515 2125	Idler Gear - Z17		48	H516 2133	Terminal Plate - Thermofuse - Rear	
18	H515 2124	Idler Gear - Z22-18		49	H516 5018	Thermofuse (EUR/ASIA)	
19	H515 2189	Plate - Ground Plate (US)					
20	H515 5017	Thermostat - Fusing					
21	H516 2146	Terminal Plate - Thermostat - 2					
22	H515 2145	Terminal Plate - Thermostat - 1					
23	H515 2137	Bearing - Hot Roller					
24	H515 2160	Stopper - Hot Roller					
25	H515 2141	Spacer - Hot Roller					
26	H516 2110	Roller - Fusing - A4					
27	H515 2126	Gear - Hot Roller					
28	H516 5016	Heater - A4 - 115V		101	0802 5206	Tapping Screw - M3x8	
28	H516 5017	Heater - A4 - 220V		102	0954 3006B	Screw - M3x6	
29	H515 5022	Harness - Fusing Lamp		103	0313 0080B	Philips Pan Head Screw - M3x8	
30	H515 2176	Bracket - Pressure Roller - Right		104	0802 5205	Tapping Screw - M3x6	
31	H516 2173	Guide - Fusing - A4		105	1102 4473	CT Connector - 2P	

11. BASE FRAME 1




11. BASE FRAME 1

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3135	Bracket - Top Cover Locking - Left	
2	H516 3141	Bracket - Ozone Filter	
3	H516 3142	Ozone Filter - 8	
4	H515 3133	NCU Side Plate	
5	H515 5041	Ozone Fan Motor - DC24V;1.44W	
6	H516 3140	Bracket - Ozone Fan	
7	H516 3154	Sponge - Cushion - Ozone Fan	
8	H515 3144	PIF Bracket 1	
9	H515 3155	PIF Bracket 3	
10	H515 3145	PIF Bracket 2	
11	H515 3131	NCU Bracket	
12	H515 3167	NCU Bracket	
13	H521 5327	Power Cord - 115V	
15	H516 5314	Safety Switch Harness	
16	H521 3182	Bracket Interlock SW.	
17	H521 5324	Relay Harness - Interlock - 5V	
18	H516 5315	Harness - Interlock SW. - 24V	
20	H516 3137	Bracket - Top Cover Locking - Right	
21	H516 3139	Bracket - Cooling Fan	
22	H521 5042	Ground Wire - Lock - Front	
23	H516 3153	Sponge - Cushion - Cooling Fan	
24	H516 5041	Cooling Fan Motor - DC24V;3.6W	
25	H081 5043	Interlock Switch - LD	
26	H515 3121	Safety Switch Stopper Bracket	
27	H516 3128	Bracket - Cord Clamper	
28	H515 3135	Sheet - NCU	


INDEX	PARTS NO.	DESCRIPTION	Note
101	0802 5206	Tapping Screw - M3x8	
102	0313 0300B	Philips Pan Head Screw - M3x30	
103	0443 0060W	Hexagon Head Tapping Screw - M3x6	
104	0951 3006B	Philips Screw With Flat Washer-m3x6	
105	0701 0040B	Flat Washer - M4	
106	0950 4006B	Screw - M4x6	
107	0802 5210	Tapping Screw - M3x8	
108	1105 0344	Clamp	
109	1204 2334	Safety Switch - FA1I-AA20	
110	0313 0120B	Philips Pan Head Screw - M3x12	

12. BASE FRAME 2





13. BASE FRAME 3




13. BASE FRAME 3


INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3147	Harness Clamper - Base (US)	
2	H516 3157	Bushing - 66	
3	H515 3122	PSU Bracket	
4	H516 3333	Lock - Cassette - Right	
5	H516 3379	Ground Plate - Paper Feed Motor	
6	H516 3341	Bracket - Paper End Sensor	
7	H516 5050	Paper End Sensor	
8	H516 3158	Plate - PSU	
9	H515 5014	Grounding Harness	
10	H515 3374	Holder - FDU	
11	H515 3375	FDU Cover	
12	H515 5085	Harness - 100 Sheet Cassette	
13	H516 3319	Holder - Cassette - Left	
14	H516 3332	Lock - Cassette - Left	
15	H516 5052	Stepper Motor-paper Feed 24VDC13W	
16	H516 3301	Gear Box - Paper Feed	
17	H006 2383	Snap Ring	
19	H516 3359	Cover - Harness - Paper Size Sensor	
20	H515 5054	Paper Size Sensor	
21	H516 3346	Bracket - Paper Size Sensor	
22	H516 3320	Holder - Cassette - Right	
23	H516 3330	Rail - Cassette - Front	
24	H516 3328	Spacer - Cassette Entrance - Right	
25	H516 3361	Rubber Foot	
26	H515 3693	Positioning Pin	
27	H516 3329	Spacer - Cassette Entrance - Left	
28	H516 3331	Rail - Cassette - Rear	
29	H515 3152	Oppf Relay Bracket	
30	H516 3335	Shaft - Feed Roller - Left	
31	H516 3373	Stay - Feed Roller	
32	H516 3372	Shaft - Feed Roller - Right	
33	H516 3370	Paper Feed Roller	

INDEX	PARTS NO.	DESCRIPTION	Note
34	H516 3385	Support Plate - Left Side Plate	
35	H516 3344	Ground Plate - Registration Roller	
36	H515 3544	E-ring - JR-E6	
37	H516 5301	Harness - Paper Size	
38	H515 5318	PFU Harness	
39	H516 3326	Side Plate - Left	
40	H515 3322	Side Plate - Right	
101	0965 3008B	Tapping Screw With Washer - M3x8	
102	0443 0060W	Hexagon Head Tapping Screw - M3x6	
103	0964 3006B	Tapping Screw - M3x6	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	0951 3006B	Philips Screw With Flat Washer-m3x6	
106	1105 0344	Clamp	
107	1105 0260	Wire Saddle	
108	0805 3386	Bushing - 8mm	
109	1105 0243	Wire Saddle	

14. 250 SHEET CASSETTE




15. 100 SHEET CASSETTE OPTION





16. ISDN






16. ISDN



INDEX	PARTS NO.	DESCRIPTION	Note
1	H082 6036	Fax Control Board - 115V	
1	H082 6035	Fax Control Board - 230V	
2	H513 4102	Decal - ISDN	
3	H543 5701	ISDN Harness	
4	H515 5014	Grounding Harness	
5	H515 3149	Board Bracket	
6	H515 5203	PCB G4 I/F	

INDEX	PARTS NO.	DESCRIPTION	Note

17. 80 MB HDD




17. 80 MB HDD



INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 5202	HDD I/F Cord	
2	H515 5357	HDD Harness - 4P	
3	H515 5356	HDD Harness - 44P	
4	H515 3156	HDD Bracket	
5	H515 7116	80M HDD	
6	H130 4015	Grounding Plate	
	 		

INDEX	PARTS NO.	DESCRIPTION	Note
101	1607 0638	Ferrite Core - TFC25-15-12	

18. FOD



INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 3230	Front Stay	
2	H132 4005	Cover - FOD	
3	H132 4004	Decal - FOD	

INDEX	PARTS NO.	DESCRIPTION	Note

PARTS INDEX

PART N O.	DESCRIPTION	INDEX
AW02 0021	Photointerruptor - 175487-3	19- 2
AW02 0021	Photointerruptor - 175487-3	25- 29
G011 3275	Snap Ring	5- 20
H006 2383	Snap Ring	27- 17
H014 1101	Lense - F22.6	11- 7
H053 1600	Bushing - M6 : CMFE	7- 22
H053 1600	Bushing - M6 : CMFE	11- 44
H081 1147	Pressure Roller Assy	9- 8
H081 2438	Shaft - Agitator	15- 50
H081 5043	Interlock Switch - LD	23- 25
H081 5700	Modular Cord - 6p/6p	3- 18
H082 6035	Fax Control Board - 230V	33- 1
H082 6036	Fax Control Board - 115V	33- 1
H130 4015	Grounding Plate	35- 6
H132 4004	Decal - FOD	37- 3
H132 4005	Cover - FOD	37- 2
H511 5005	Stamper	11- 24
H513 4102	Decal - ISDN	33- 2
H515 1050	Scanner Base	11- 17
H515 1052	Exposure Glass Clip	11- 10
H515 1053	1st Mirror	11- 29
H515 1054	2nd Mirror	11- 28
H515 1055	Mirror Clip	11- 22
H515 1056	Lamp Bracket	11- 19
H515 1058	Front Lamp Clip	11- 37
H515 1060	Shield Plate	11- 8
H515 1061	Lens Holder	11- 6
H515 1062	Bushing - R1/R2 Rollers	11- 14
H515 1064	Rear Cover Bracket	11- 9
H515 1065	Motor Cushion	11- 26
H515 1069	Grounding Wire	11- 38
H515 1070	Cover - Drive	11- 45
H515 1072	Cover - Scanner	11- 31

PART N O.	DESCRIPTION	INDEX
H515 1073	Grounding Plate - Lamp Bracket	11- 20
H515 1075	Dvelopment Fixing Plate	11- 40
H515 1076	Harness Bracket	11- 23
H515 1077	Cover - Lens	11- 5
H515 1081	Exposure Glass	11- 11
H515 1084	R1 Gide Mylar	11- 27
H515 1086	R2 Guide Mylar	11- 15
H515 1090	Left Holder - Exposuer Glass	11- 46
H515 1091	Right Holder - Exposuer Glass	11- 47
H515 1204	ADF Feeder Unit	7- 3
H515 1205	Separation Plate Ass'y	9- 25
H515 1232	R1 Roller	11- 13
H515 1233	R2 Roller	11- 12
H515 1250	ADF Guide Plate - Upper	9- 26
H515 1251	Top Cover	7- 15
H515 1263	Bracket - Grounding	9- 2
H515 1265	Pulley - R1	11- 43
H515 1266	Pulley - R2 Roller	11- 41
H515 1267	Grounding Plate	9- 7
H515 1271	Shaft - Separetion Pressure	9- 17
H515 1272	Motor Bracket	11- 34
H515 1276	Timing Belt - TX	11- 30
H515 1277	Clip - Base - Shading Plate	9- 18
H515 1279	Base - Shading Plate	9- 21
H515 1281	Spring Plate	11- 32
H515 1282	Rack Gear - Document Guide	7- 13
H515 1283	Pinion Gear - Document Guide	7- 12
H515 1284	Shaft - Document Feed	7- 21
H515 1285	Gear - Document Feed	7- 19
H515 1286	Development Gear - TX	11- 35
H515 1287	Brake Gear	7- 1
H515 1288	Brake Spacer	11- 36
H515 1290	Plumber Block - ADF Roller - Right	7- 17

PART N O.	DESCRIPTION	INDEX
H515 1291	Plumber Block - ADF Roller - Left	7- 18
H515 1292	Cover - ADF	7- 2
H515 1293	Pressure Plate - Pickup	9- 24
H515 1294	Shaft - Lock	7- 26
H515 1295	Sping - Lock	7- 23
H515 1296	Lever - Lock Release	7- 25
H515 1297	Lock Lever - Operation Panel	7- 27
H515 1298	Spring Plate - CTM	7- 5
H515 1301	Shaft - Pressure Roller	9- 9
H515 1303	Spring - Shading Plate	9- 20
H515 1304	Hook - Cover Lock - Right	7- 24
H515 1305	Hook - Cover Lock - Left	7- 14
H515 1306	Guide Origainal - Right	7- 28
H515 1307	Guide - Original - Left	7- 16
H515 1312	Pressure Roller - R1	9- 11
H515 1313	Sponge Collar - R1	9- 10
H515 1317	Gear	11- 39
H515 1318	Bracket - Top Cover	7- 9
H515 1321	Sponge - Fusing 1	7- 7
H515 1322	Seal 2	7- 4
H515 1323	Spring Plate - R1/R2 - Left	9- 5
H515 1324	Spring Plate - R1/R2 - Right	9- 4
H515 1331	Mylar - ADF	9- 23
H515 1335	Ground Plate - ADF - Lower 2	7- 10
H515 1336	Spring - Ground (Earth) - Pipe	9- 6
H515 1337	Bracket - Plate - Ground Wire	7- 11
H515 1338	1st Scanner Sheet	9- 22
H515 1339	2nd Scanner Sheet	9- 19
H515 1340	Grounding Plate Spacer	9- 34
H515 1342	Sheet - ADF Guide Plate	9- 33
H515 2040	Laser Protter Unit	5- 15
H515 2040	Laser Protter Unit	13- 1
H515 2119	Cover - Gear	21- 11

PART N O.	DESCRIPTION	INDEX
H515 2121	Spring Plate - Fusing Exit	19- 19
H515 2122	Fusing Exit Roller	19- 20
H515 2124	Idler Gear - Z22-18	21- 18
H515 2125	Idler Gear - Z17	21- 17
H515 2126	Gear - Hot Roller	21- 27
H515 2127	Idler Gear - Z18	21- 9
H515 2128	Gear - Fusing Exit Roller	21- 12
H515 2133	Lever - Lock - Left	19- 14
H515 2134	Lock Lever - Right	19- 7
H515 2135	Shaft - Lock Lever	19- 10
H515 2136	Spring - Lock Lever	19- 15
H515 2137	Bearing - Hot Roller	21- 23
H515 2139	Bushing - Fusing Exit Roller	21- 13
H515 2141	Spacer - Hot Roller	21- 25
H515 2143	Holder - Thermistor	21- 1
H515 2144	Stopper - Fusing	19- 6
H515 2145	Terminal Plate - Thermostat - 1	21- 22
H515 2148	Left Lock Lever	21- 6
H515 2149	Actuator - Fusing Exit Sensor	21- 3
H515 2153	Spring - Hot Roller Stripper	21- 5
H515 2154	Spring - Pressure Roller	21- 32
H515 2155	Cover - Right - Fusing	19- 1
H515 2156	Ground Plate - Hot Roller	21- 41
H515 2157	Fusing Inner Cover - Right	19- 13
H515 2158	Fusing Inner Cover - Left	19- 17
H515 2160	Stopper - Hot Roller	21- 24
H515 2161	Spring - Sensor Actuator	21- 4
H515 2163	Spring Plate - Right	21- 34
H515 2164	Spring Plate - Left	21- 39
H515 2165	Cover - Left	19- 18
H515 2166	Roller - Exit Roller	21- 14
H515 2167	Holder - Fusing Lamp	21- 10
H515 2168	Lock Spring - Cleaning Pad	21- 44

PART N O.	DESCRIPTION	INDEX
H515 2169	Bearing - Pressure Roller	21- 33
H515 2171	Spring Plate - Pressure Roller	21- 40
H515 2176	Bracket - Pressure Roller - Right	21- 30
H515 2177	Bracket - Pressure Roller - Left	21- 38
H515 2178	Bracket - Lamp Connector	19- 11
H515 2179	Cover - Connector	19- 4
H515 2180	Bracket - Idler Gear	19- 12
H515 2182	Stepped Screw	21- 37
H515 2184	Decal - Warning	19- 24
H515 2189	Plate - Ground Plate (US)	21- 19
H515 2405	Rubber Roller Ass'y - DVLP -B4	15- 5
H515 2410	Bearing - Mag. Roller - Left	15- 46
H515 2411	Bearing - Mag. Roller - Right	15- 42
H515 2413	Gear - Agitator	15- 40
H515 2414	Bearing - DVLP. Roller - Left	15- 1
H515 2415	Bearing - DVLP. Roller - Right	15- 4
H515 2416	Main Motor Ass'y - DC24V;16.1W	17- 23
H515 2417	Terminal - Quenching Lamp	15- 36
H515 2442	Gear - Mag. Roller	15- 41
H515 2443	Idler Gear 1 - Small	17- 17
H515 2444	Idler Gear 1 - Large	17- 18
H515 2445	Idler Gear 2 - Large	17- 19
H515 2446	Drive Gear - OPC Drum	15- 45
H515 2447	Idler Gear 3	17- 25
H515 2448	Idler Gear 4	17- 26
H515 2449	Idler Gear 5	17- 21
H515 2450	Idler Gear 6	17- 12
H515 2452	Gear - Transfer Roller	17- 1
H515 2455	Holder - Transfer Roller - Left	17- 4
H515 2456	Holder - Transfer Roller - Right	17- 6
H515 2457	Bushing - Idler 2 - Large	15- 44
H515 2458	Bushing - Idler 2 - Small	17- 29
H515 2461	Pulley - Transfer	17- 2

PART N O.	DESCRIPTION	INDEX
H515 2462	Shaft - Idler 1	17- 16
H515 2463	Shaft - Idler 2	15- 43
H515 2466	Shaft - Idler 5	17- 20
H515 2467	Shaft - Idler 6	17- 13
H515 2468	Terminal Plate - Ground	15- 37
H515 2469	Terminal Plate - Transfer - S	17- 8
H515 2471	Terminal Plate - Transfer - L	15- 27
H515 2472	Terminal Plate - Separation	17- 10
H515 2473	Terminal Plate - Development - S	15- 25
H515 2474	Terminal Plate - Development - L	15- 19
H515 2478	Terminal Plate - Charge - M	15- 23
H515 2482	Terminal Plate - OPC Drum	15- 38
H515 2485	Spring - Transfer Roller	17- 5
H515 2487	Stopper - Pin	15- 31
H515 2488	Stopper - Receptacle	15- 32
H515 2491	Inner Cover - Development	17- 28
H515 2492	Bracket - Fusing Drive Gear	17- 14
H515 2493	Drive Gear - Fusing	17- 11
H515 2494	Shaft - Drive Gear - Fusing	17- 15
H515 2495	Spring - Bracket - Fusing Drive	17- 24
H515 2496	Terminal Plate - Grid	17- 30
H515 2502	Seal - Roller	15- 17
H515 2506	Seal - Duct - S	15- 11
H515 2530	Terminal Plate - B	15- 20
H515 2534	Seal - Development - A	15- 26
H515 2535	Seal - B	15- 18
H515 2536	Seal - Development - C	15- 13
H515 2541	Deal - Shutter Guide	17- 22
H515 2542	Stopper - Bearing - M6	15- 47
H515 2543	Holder - Terminal Plate - OPC Drum	15- 39
H515 2547	Holder - Harness	15- 48
H515 2550	Gear - Rubber Roller -Z18	15- 2
H515 2551	Seal - Duct - R	15- 9

PART N O.	DESCRIPTION	INDEX
H515 2552	Shield - Roller - R	15- 49
H515 2554	Stopper - Pin - L	15- 58
H515 2559	Terminal Plate Ass'y - Contact	15- 21
H515 2567	Sheet - Guide Plate	17- 31
H515 2568	Stopper - Ball Bearing	15- 60
H515 2569	Shield - Toner Hopper - Drive - 1	15- 61
H515 2570	Shield - Toner Hopper - Drive - 2	15- 62
H515 2571	Upper Seal - B4	15- 57
H515 2711	Mirror - Synchronization	13- 15
H515 2712	Laser Exposure Glass	13- 8
H515 2714	Cover - Laser Unit	13- 3
H515 2715	Laser Diode Unit	13- 7
H515 2717	Laser Sync. Detector	13- 6
H515 2719	Spring Plate - BTL - Left	13- 11
H515 2720	Spring Plate - Btl - Right	13- 13
H515 2721	Spring Plate - Mirror - Laser Sync.	13- 14
H515 2722	Spring Plate - Lens - Laser	13- 17
H515 2723	Spring Plate - Exposure Glass	13- 9
H515 2724	Clip - LASER UNIT	5- 16
H515 2725	Cylindrical Lens - Laser	13- 16
H515 2734	Bracket - Base	5- 17
H515 2831	Spring Plate - CTM	7- 8
H515 3110	Base - Plotter	25- 22
H515 3116	Fulcrum - Fusing Unit	5- 3
H515 3121	Safety Switch Stopper Bracket	23- 26
H515 3122	PSU Bracket	27- 3
H515 3130	Cover - Power Pack	5- 2
H515 3131	NCU Bracket	23- 11
H515 3133	NCU Side Plate	23- 4
H515 3134	PSU Cover	5- 24
H515 3135	Sheet - NCU	23- 28
H515 3140	Spacer - 8mm	5- 13
H515 3144	PIF Bracket 1	23- 8

PART N O.	DESCRIPTION	INDEX
H515 3145	PIF Bracket 2	23- 10
H515 3148	IC Card Guide	3- 5
H515 3149	Board Bracket	33- 5
H515 3152	Oppf Relay Bracket	27- 29
H515 3155	PIF Bracket 3	23- 9
H515 3156	HDD Bracket	35- 4
H515 3159	Wire - Clip	11- 18
H515 3167	NCU Bracket	23- 12
H515 3230	Front Stay	37- 1
H515 3322	Side Plate - Right	27- 40
H515 3374	Holder - FDU	27- 10
H515 3375	FDU Cover	27- 11
H515 3376	Film Stay	25- 28
H515 3465	Supporting Plate (US/ASIA)	29- 43
H515 3466	Plastic Rivet (US/ASIA)	29- 44
H515 3517	Bottom Plate - Cassette	31- 4
H515 3518	Cover - Cassette	31- 21
H515 3519	Paper Size Indicator	31- 29
H515 3520	Side Fence	31- 39
H515 3521	Knob - Side Fence	31- 37
H515 3522	End Fence	31- 24
H515 3523	Corner Separator - Left	31- 36
H515 3524	Corner Separator - Right	31- 6
H515 3526	Bracket - Gear Arm	31- 14
H515 3527	Gear - Z32	31- 16
H515 3528	Gear - Z26	31- 15
H515 3529	Friction Pad - Large	31- 2
H515 3530	Friction Pad - Small	31- 3
H515 3531	Bushing - Paper Feed Roller	31- 10
H515 3533	Spring - Gear Arm	31- 13
H515 3534	Spring - Side Fence	31- 38
H515 3535	Spring - Paper Size Indicator	31- 30
H515 3538	Shaft - Paper Size Indicator	31- 31

PART N O.	DESCRIPTION	INDEX
H515 3539	Spring Plate - Lock	31- 26
H515 3540	Paper Tray Extension	31- 22
H515 3541	Gear Cover	31- 41
H515 3542	Rivet	31- 35
H515 3543	Retaining Ring - M4	21- 46
H515 3543	Retaining Ring - M4	31- 12
H515 3544	E-ring - JR-E6	27- 36
H515 3544	E-ring - JR-E6	31- 17
H515 3545	Cover - Paper End Sensor	31- 9
H515 3546	Lower Cover	31- 23
H515 3550	Cover - Bypass Feed	31- 19
H515 3552	Bypass Feed Table Ass'y	31- 20
H515 3553	Stopper - Corner Separator	31- 42
H515 3554	Decal - Paper Limit	31- 25
H515 3555	Decal - Paper Set	31- 18
H515 3556	Bracket - Paper End Sensor	31- 7
H515 3557	Paper Feed Roller	31- 1
H515 3693	Positioning Pin	27- 26
H515 4020	Cover - Left	3- 1
H515 4024	Cover - Rear	3- 17
H515 4025	Cover CT	3- 15
H515 4028	Cover - Fan	3- 22
H515 4029	Cover - V35	3- 7
H515 4030	Cover - G4	3- 6
H515 4031	Cover Right	3- 13
H515 4032	Cover - RS232C	3- 11
H515 4033	Rear Cover - Upper	3- 12
H515 4036	Cassette Cover	3- 24
H515 4055	Guide Mylar	3- 10
H515 4202	Operation Panel Ass'y - FX4 - US	9- 12
H515 4204	Operation Panel Ass'y - EUR	9- 12
H515 4206	Operation Panel Ass'y (ASIA)	9- 12
H515 4252	Decal - Case (USA)	9- 32

PART N O.	DESCRIPTION	INDEX
H515 4253	Operation Panel Case	9- 31
H515 4290	Quick Dial Plate	9- 29
H515 4307	Operating Seal - B (EUR)	9- 30
H515 4308	Operating Seal - C	9- 1
H515 4312	Operating Seal - A (USA)	9- 27
H515 4316	Quick Dial Sheet	9- 28
H515 5000	TX Motor - DC24V;0.9A	11- 25
H515 5002	Original Sensor - S1	9- 14
H515 5003	Original Sensor - S2	9- 15
H515 5004	Original Sensor - S3	9- 13
H515 5005	Document Sensor - S4	9- 16
H515 5010	Xenon Lamp (EUR/ASIA)	11- 42
H515 5011	Xenon Lamp Driver	11- 16
H515 5012	Xenon Lamp - US	11- 42
H515 5014	Grounding Harness	27- 9
H515 5014	Grounding Harness	33- 4
H515 5015	Thermistor - Fusing	21- 2
H515 5017	Thermostat - Fusing	21- 20
H515 5022	Harness - Fusing Lamp	21- 29
H515 5024	Ground Wire - Fusing	21- 42
H515 5040	Polygonal Mirror Motor-DC24V;0.35A	13- 5
H515 5041	Ozone Fan Motor - DC24V;1.44W	23- 5
H515 5044	Optical Fibre - Laser Sync.	13- 10
H515 5050	Toner End Sensor	25- 12
H515 5054	Paper Size Sensor	27- 20
H515 5054	Paper Size Sensor	31- 28
H515 5075	Paper Feed Clutch	31- 11
H515 5076	Paper End Sensor	31- 8
H515 5080	Relay Harness Assembly	31- 34
H515 5085	Harness - 100 Sheet Cassette	5- 30
H515 5085	Harness - 100 Sheet Cassette	27- 12
H515 5202	HDD I/F Cord	35- 1
H515 5203	PCB G4 I/F	33- 6

PART N O.	DESCRIPTION	INDEX
H515 5310	Motor Harness - RX	5- 7
H515 5311	Motor Harness - TX	5- 6
H515 5312	SBU Harness	5- 29
H515 5312	SBU Harness	11- 3
H515 5314	OPU Harness	5- 27
H515 5314	OPU Harness	9- 3
H515 5317	Exposure Lamp Harness	5- 25
H515 5317	Exposure Lamp Harness	11- 4
H515 5318	PFU Harness	27- 38
H515 5319	Option Tray Harness	5- 32
H515 5320	Motor Harness	5- 5
H515 5324	Ground Wire - 350	7- 6
H515 5356	HDD Harness - 44P	35- 3
H515 5357	HDD Harness - 4P	35- 2
H515 5396	Seal Sheet	15- 56
H515 5400	PCB - PSU - 115V	5- 21
H515 5600	PCB - PSU - 220V	5- 21
H515 6011	PCB - MFDU - FX4 - US	5- 4
H515 6014	PCB - MFDU - EUR/ASIA	5- 4
H515 6020	PCB - SBU	11- 2
H515 6200	PCB - MFCE - FX4 - US	5- 14
H515 6220	PCB - MFCE - EUR	5- 14
H515 6230	PCB - MFCE - Asia	5- 14
H515 7116	80M HDD	35- 5
H515 8600	Operation Manual - FX4 - US	3- 0
H515 8601	Operation Manual - English (EU)	3- 0
H515 8602	Operation Manual - German	3- 0
H515 8603	Operation Manual - Italian	3- 0
H515 8604	Operation Manual - Spanish	3- 0
H515 8605	Operation Manual - French	3- 0
H515 8606	Operation Manual - Swedish	3- 0
H515 8609	Operation Manual (ASIA)	3- 0
H516 1058	Cover - Scanner - Left	3- 14

PART N O.	DESCRIPTION	INDEX
H516 1068	Bracket - Operation Panel	5- 18
H516 1262	Roller - Belt Tensioning	11- 33
H516 2110	Roller - Fusing - A4	21- 26
H516 2111	Pressure Roller - A4	21- 35
H516 2112	Upper Case - Fusing - A4	21- 8
H516 2116	Lower Case - Fusing - A4	21- 36
H516 2117	Fusing Exit Roller - A4	21- 16
H516 2118	Cover - Front - F16 - A4	19- 23
H516 2119	Bracket - Table - Original	19- 8
H516 2120	Cover - Exit - A4	19- 22
H516 2121	Inner Cover - A4	19- 16
H516 2126	Bracket - Fusing - A4	19- 21
H516 2127	Spacer - Fusing Exit Roller - Left	21- 15
H516 2130	Guide Plate - Fusing Exit - A4	19- 28
H516 2133	Terminal Plate - Thermofuse - Rear	21- 48
H516 2134	Terminal Plate - Thermofuse - Front	21- 47
H516 2135	Ground Plate - Exit - A4 (US)	19- 26
H516 2136	Sponge - A4	19- 29
H516 2146	Terminal Plate - Thermostat - 2	21- 21
H516 2150	Cleaning Pad - Fusing	21- 43
H516 2152	Antistatic Brush - Fusing - A4	19- 9
H516 2159	Cover - Thermistor	21- 7
H516 2173	Guide - Fusing - A4	21- 31
H516 2198	Stopper - Fusing - F	19- 5
H516 2199	Stay - Front	25- 1
H516 2401	Development Unit - A4	15- 6
H516 2404	Transfer Roller - A4	17- 3
H516 2407	Hopper - A4	17- 32
H516 2412	Toner Metering Blade - A4	15- 33
H516 2432	Cover - Toner Hopper - A4	15- 12
H516 2460	Antistatic Brush - Separation - A4	17- 9
H516 2475	Terminal - Rubber Roller - A4	15- 24
H516 2500	Toner Duct - A4	15- 7

PART N O.	DESCRIPTION	INDEX
H516 2501	Toner Duct Shield - A4 - 1	15- 51
H516 2505	Toner Duct Shield - A4 - 2	15- 10
H516 2516	Magnet Roller - Development - A4	15- 16
H516 2518	Antistatic Brush - Mag. Roller - A4	15- 35
H516 2519	Rubber Roller - Development - A4	15- 3
H516 2524	Film - Toner Duct - A4	15- 8
H516 2528	Sheild - Rubber Roller - A4	15- 34
H516 2544	Toner Agitator - Development	15- 15
H516 2548	Film - Toner Hopper - A4	15- 29
H516 2549	Seal - Toner Duct - Lower - A4	15- 14
H516 2555	Lower Seal	15- 30
H516 2561	Instruction Sheet - A4 - L	15- 52
H516 2562	Instruction Sheet - A4 - S - 1	15- 54
H516 2563	Instruction Sheet - A4 - S - 2	15- 55
H516 2564	Plate - Instruction Sheet - A4	15- 53
H516 2574	Spacer - Ball Bearing	15- 59
H516 2580	Guide - Transfer Roller - As'y	17- 7
H516 2710	BTL Lens	13- 12
H516 3116	Spacer - Development Unit - A4	25- 38
H516 3128	Bracket - Cord Clamper	23- 27
H516 3129	Ground Plate - Left	25- 3
H516 3135	Bracket - Top Cover Locking - Left	23- 1
H516 3137	Bracket - Top Cover Locking - Right	23- 20
H516 3139	Bracket - Cooling Fan	23- 21
H516 3140	Bracket - Ozone Fan	23- 6
H516 3141	Bracket - Ozone Filter	23- 2
H516 3142	Ozone Filter - 8	23- 3
H516 3146	Bracket - Toner End Sensor	25- 9
H516 3147	Harness Clamper - Base (US)	27- 1
H516 3149	Sponge - 2	25- 34
H516 3150	Sponge - 3	25- 37
H516 3151	Sponge - 4	25- 36
H516 3152	Sponge - 5	25- 39

PART N O.	DESCRIPTION	INDEX
H516 3153	Sponge - Cushion - Cooling Fan	23- 23
H516 3154	Sponge - Cushion - Ozone Fan	23- 7
H516 3157	Bushing - 66	27- 2
H516 3158	Plate - PSU	27- 8
H516 3301	Gear Box - Paper Feed	27- 16
H516 3319	Holder - Cassette - Left	27- 13
H516 3320	Holder - Cassette - Right	27- 22
H516 3326	Side Plate - Left	27- 39
H516 3328	Spacer - Cassette Entrance - Right	27- 24
H516 3329	Spacer - Cassette Entrance - Left	27- 27
H516 3330	Rail - Cassette - Front	27- 23
H516 3331	Rail - Cassette - Rear	27- 28
H516 3332	Lock - Cassette - Left	27- 14
H516 3333	Lock - Cassette - Right	27- 4
H516 3335	Shaft - Feed Roller - Left	27- 30
H516 3341	Bracket - Paper End Sensor	27- 6
H516 3344	Ground Plate - Registration Roller	27- 35
H516 3345	Bracket - Pressure Roller	25- 21
H516 3346	Bracket - Paper Size Sensor	27- 21
H516 3358	Spring - Pressure Roller	25- 27
H516 3359	Cover - Harness - Paper Size Sensor	27- 19
H516 3361	Rubber Foot	27- 25
H516 3370	Paper Feed Roller	27- 33
H516 3372	Shaft - Feed Roller - Right	27- 32
H516 3373	Stay - Feed Roller	27- 31
H516 3375	Spacer	25- 23
H516 3376	Ground Plate - Bracket - Regist.	25- 20
H516 3379	Ground Plate - Paper Feed Motor	27- 5
H516 3381	Ground Plate - Cassette - Left (US/ASIA)	29- 25
H516 3384	Spring Plate - Lock	25- 30
H516 3385	Support Plate - Left Side Plate	27- 34
H516 3401	Cassette	29- 5
H516 3407	Cassette Base - A4	29- 5

PART N O.	DESCRIPTION	INDEX
H516 3410	Bottom Plate - Cassette	29- 7
H516 3411	Separation Hook - Cassette - Left	29- 32
H516 3412	Side Fence - Cassette	29- 34
H516 3413	Separation Hook - Cassette - Right	29- 24
H516 3414	End Fence - Cassette	29- 2
H516 3415	Paper Guide Plate - Bypass	29- 26
H516 3416	Registration Roller	29- 15
H516 3417	Bushing - Registration Roller	29- 39
H516 3419	Gear - Registration Roller	29- 14
H516 3421	Friction Pad - Bottom Plate - Large	29- 8
H516 3422	Paper Size Sensor Board - A5	29- 28
H516 3423	Guide Plate - Registration - Left	29- 11
H516 3424	Guide Plate - Registration - Right	29- 12
H516 3425	Lock - Bottom Plate	29- 29
H516 3425	Lock - Bottom Plate	31- 33
H516 3426	Spring - Lock - Bottom Plate	29- 30
H516 3426	Spring - Lock - Bottom Plate	31- 32
H516 3428	Paper Size Sensor Board - Letter	29- 28
H516 3429	Paper Size Sensor Board - A4	29- 28
H516 3430	Paper Size Sensor Board - Legal	29- 28
H516 3434	Shaft - Pressure Roller	25- 26
H516 3434	Shaft - Pressure Roller	29- 21
H516 3435	Actuator - Bypass Feed Sensor	29- 19
H516 3437	Manual Feed Table	29- 27
H516 3438	Spring Plate - End Fence	29- 1
H516 3439	Stopper - Fence	29- 3
H516 3443	Mylar - Paper Guide - 1	29- 37
H516 3444	Mylar - Paper Guide - 2	29- 31
H516 3445	Mylar - Paper Guide - 3	29- 38
H516 3446	Mylar - Paper Guide - 4	29- 36
H516 3447	Spring - Registration Roller	29- 13
H516 3448	Spring - Pressure Roller	29- 18
H516 3449	Spring - Bypass Sensor Actuator	29- 20

PART N O.	DESCRIPTION	INDEX
H516 3450	Spring Bottom Plate	29- 9
H516 3462	Bracket - Pressure Roller - Cass.	29- 17
H516 3463	Guide - Pressure Roller - Cass.	29- 23
H516 3465	Support Plate - End Fence	29- 42
H516 3469	Cover - Manual Feed Table	29- 41
H516 3470	Decal - Paper Set - Cassette	29- 6
H516 3471	Sponge - End Fence	29- 4
H516 3482	Spring Plate - Bracket -right (US/ASIA)	29- 16
H516 3510	Paper Tray - 100 Sheet Cassette	31- 27
H516 3532	Spring - Bottom Plate	31- 5
H516 3581	Decal - By-pass Feed (100 Cassette)	31- 40
H516 3583	Decal - Bypass Feed	29- 33
H516 4023	Cover - IC Memory Card	3- 3
H516 4026	Cover - MEXH Counter	3- 9
H516 4028	Document Table	3- 19
H516 4031	Copy Tray (US/ASIA)	3- 20
H516 4034	Document Tray	3- 25
H516 4040	Cover Printer I/F - Lower	3- 21
H516 4043	Cover - Connector	3- 2
H516 4046	Cover - Printer I/F - Upper	3- 8
H516 4047	Cover - NCU	3- 16
H516 5012	Ground Wire - Image Sensor	11- 21
H516 5012	Ground Wire - Image Sensor	19- 27
H516 5016	Heater - A4 - 115V	21- 28
H516 5017	Heater - A4 - 220V	21- 28
H516 5018	Thermofuse (EUR/ASIA)	21- 49
H516 5031	Monitor Speaker	3- 4
H516 5041	Cooling Fan Motor - DC24V;3.6W	23- 24
H516 5045	Cable - Charge Bias - A4	15- 22
H516 5046	Cable - Transfer Bias - A4	15- 28
H516 5047	Power Supply - Pack - USA	5- 1
H516 5048	Zener Diode - 698V - HVRD	17- 27
H516 5049	Power Supply - Pack - EUR/ASIA	5- 1

PART N O.	DESCRIPTION	INDEX
H516 5050	Paper End Sensor	27- 7
H516 5052	Stepper Motor-paper Feed 24VDC13W	27- 15
H516 5301	Harness - Paper Size	27- 37
H516 5302	Harness - LDDR	5- 10
H516 5308	Driver Harness	5- 8
H516 5311	Sensor Harness	5- 28
H516 5311	Sensor Harness	25- 11
H516 5314	Safety Switch Harness	5- 31
H516 5314	Safety Switch Harness	23- 15
H516 5315	Harness - Interlock SW. - 24V	23- 18
H516 5318	Harness - Power Pack	5- 9
H516 5322	Relay Harness - Fusing Unit	5- 11
H521 3144	Harness Clamp	25- 15
H521 3145	Sponge - Lock - Front	25- 5
H521 3147	Sponge - Cooling Fan - 1	25- 17
H521 3148	Sponge - Cooling Fan - 2	25- 35
H521 3149	Sponge - Cooling Fan - 3	25- 16
H521 3150	Sponge - Cooling Fan - 4	25- 18
H521 3151	Sponge - Base - Upper Left (US)	25- 6
H521 3153	Sponge - Base - Left - Middle	25- 4
H521 3156	Sponge - Registration - 1	25- 10
H521 3157	Sponge - Registration - 2	25- 14
H521 3158	Sponge - Power Pack - 1	25- 7
H521 3159	Sponge - Power Pack - 2	25- 8
H521 3160	Sponge - Base - Bottom	25- 24
H521 3161	Seal - Base - Bottom - 1	25- 32
H521 3162	Seal - Base - Bottom - 2	25- 33
H521 3164	Pin - Right Fulcrum	5- 22
H521 3182	Bracket Interlock SW.	23- 16
H521 3340	Pressure Roller - Registration	25- 25
H521 3340	Pressure Roller - Registration	29- 22
H521 3352	Bracket - Plotter Base Connection	25- 2
H521 3379	Sponge - Bracket - Pressure Roller	25- 31

PART N O.	DESCRIPTION	INDEX
H521 3419	Friction Pad - Bottom Plate - Small	29- 10
H521 4056	Decal LD	13- 2
H521 5042	Ground Wire - Lock - Front	23- 22
H521 5054	Registration Sensor	25- 19
H521 5309	Harness - NCU	5- 19
H521 5310	Harness - Sen1	25- 13
H521 5312	Harness - Fusing Sensors	19- 3
H521 5321	Harness - Mirror Motor	5- 26
H521 5321	Harness - Mirror Motor	13- 4
H521 5322	Harness - PSU	5- 12
H521 5324	Relay Harness - Interlock - 5V	23- 17
H521 5326	Heater Relay Harness	21- 45
H521 5327	Power Cord - 115V	23- 13
H543 5701	ISDN Harness	33- 3

PART N O.	DESCRIPTION	INDEX
A048 6149	Decal - Manual Feed	29- 35
5447 2681	Snap Ring	7- 20
5466 3198	Washer - SBU	11- 1
5488 6020	PCB - NCU - USA	5- 23
5488 6040	PCB - NCU : Europe/asia	5- 23

PART N O.	DESCRIPTION	INDEX
0313 0040B	Philips Pan Head Screw - M3x4	7-103
0313 0040B	Philips Pan Head Screw - M3x4	9-102
0313 0060B	Philips Pan Head Screw - M3x6	5-106
0313 0060B	Philips Pan Head Screw - M3x6	19-103
0313 0060B	Philips Pan Head Screw - M3x6	27-104
0313 0080B	Philips Pan Head Screw - M3x8	21-103
0313 0120B	Philips Pan Head Screw - M3x12	23-110
0313 0300B	Philips Pan Head Screw - M3x30	23-102
0353 0060Z	Screw - M3X6	3-101
0353 0060Z	Screw - M3X6	5-107
0353 0080Z	Philips Trass Head Screw - M3x8	5-108
0353 0080Z	Philips Trass Head Screw - M3x8	7-101
0413 0082W	Tapping Screw - M3x8	15-104
0433 0102B	Tapping Screw - M3x10	7-105
0443 0060W	Hexagon Head Tapping Screw - M3x6	3-104
0443 0060W	Hexagon Head Tapping Screw - M3x6	5-101
0443 0060W	Hexagon Head Tapping Screw - M3x6	5-109
0443 0060W	Hexagon Head Tapping Screw - M3x6	17-101
0443 0060W	Hexagon Head Tapping Screw - M3x6	23-103
0443 0060W	Hexagon Head Tapping Screw - M3x6	25-101
0443 0060W	Hexagon Head Tapping Screw - M3x6	27-102
0701 0030B	Flat Washer - M3	11-105
0701 0040B	Flat Washer - M4	23-105
0720 0020E	Retaining Ring - M2	17-103
0720 0025E	Retaining Ring - M2.5	15-101
0720 0030E	Retaining Ring - M3	11-107
0720 0030E	Retaining Ring - M3	17-102
0720 0040E	Retaining Ring - M4	15-103
0720 0040E	Retaining Ring - M4	29-101
0720 0050E	Retaining Ring - M5	11-108
0802 5205	Tapping Screw - M3x6	21-104
0802 5205	Tapping Screw - M3x6	31-101
0802 5206	Tapping Screw - M3x8	3-103

PART N O.	DESCRIPTION	INDEX
0802 5206	Tapping Screw - M3x8	5-102
0802 5206	Tapping Screw - M3x8	9-103
0802 5206	Tapping Screw - M3x8	11-102
0802 5206	Tapping Screw - M3x8	15-102
0802 5206	Tapping Screw - M3x8	19-100
0802 5206	Tapping Screw - M3x8	21-101
0802 5206	Tapping Screw - M3x8	23-101
0802 5206	Tapping Screw - M3x8	25-102
0802 5206	Tapping Screw - M3x8	31-102
0802 5210	Tapping Screw - M3x8	23-107
0802 5230	Tapping Screw - M3x10	3-102
0802 5230	Tapping Screw - M3x10	11-109
0802 5230	Tapping Screw - M3x10	13-101
0805 3386	Bushing - 8mm	11-110
0805 3386	Bushing - 8mm	27-108
0805 3386	Bushing - 8mm	31-103
0950 4006B	Screw - M4x6	23-106
0951 3006B	Philips Screw With Flat Washer-m3x6	3-105
0951 3006B	Philips Screw With Flat Washer-m3x6	5-103
0951 3006B	Philips Screw With Flat Washer-m3x6	11-106
0951 3006B	Philips Screw With Flat Washer-m3x6	15-105
0951 3006B	Philips Screw With Flat Washer-m3x6	19-101
0951 3006B	Philips Screw With Flat Washer-m3x6	23-104
0951 3006B	Philips Screw With Flat Washer-m3x6	27-105
0951 3006B	Philips Screw With Flat Washer-m3x6	29-102
0951 3008B	Philips Screw With Flat Washer-m3x8	11-104
0954 3006B	Screw - M3x6	21-102
0954 3010B	Philips Screw - M3x10	11-101
0964 3006B	Tapping Screw - M3x6	27-103
0965 3006B	Tapping Screw With Flat Washer M3x6	3-106
0965 3006B	Tapping Screw With Flat Washer M3x6	7-104
0965 3008B	Tapping Screw With Washer - M3x8	7-102
0965 3008B	Tapping Screw With Washer - M3x8	9-101

PART N O.	DESCRIPTION	INDEX
0965 3008B	Tapping Screw With Washer - M3x8	27-101
0965 3010B	Tapping Screw With Flat Washer M3x6	11-103
1102 4473	CT Connector - 2P	21-105
1102 4681	Connector - 5557-02R-210	5-110
1104 0502	PS Holder	5-105
1105 0243	Wire Saddle	27-109
1105 0246	Spacer	5-104
1105 0260	Wire Saddle	27-107
1105 0283	Clamp	9-104
1105 0283	Clamp	31-104
1105 0344	Clamp	23-108
1105 0344	Clamp	27-106
1204 2334	Safety Switch - FA1I-AA20	23-109
1607 0638	Ferrite Core - TFC25-15-12	35-101