

# **PAPER FEED UNIT TYPE 100S**

# **PARTS CATALOG**


## **INTRODUCTION**

This chapter instructs you the numbers and names of this parts on this machine.

## **INDEX to PARTS CATALOG**

|                                              |                |
|----------------------------------------------|----------------|
| <b>Section 1.Part Location and List.....</b> | <b>1-1</b>     |
| 1.EXTERIOR .....                             | 1-2            |
| 2.FRAME .....                                | 1-4            |
| 3.CASSETTE.....                              | 1-6            |
| <br><b>Section 2.Parts Index .....</b>       | <br><b>2-1</b> |

# 1. EXTERIOR




# 1. EXTERIOR

| INDEX | PARTS NO. | DESCRIPTION               | Note |
|-------|-----------|---------------------------|------|
| 1     | H515 3782 | Cover - Left              |      |
| 2     | H515 3787 | Cover - Upper             |      |
| 3     | H515 3783 | Cover - Rear              |      |
| 4     | H515 3784 | Cover - Connector - Upper |      |
| 5     | H515 3682 | Release Guide Plate       |      |
| 6     | H515 3684 | Pressure Shaft            |      |
| 7     | H515 3683 | Pressure Roller           |      |
| 8     | H515 3685 | Pressure Spring           |      |
| 9     | H515 3688 | Guide Link                |      |
| 10    | H515 3691 | Link Shaft                |      |
| 11    | H515 3689 | Bushing                   |      |
| 12    | H515 3690 | Link Spring               |      |
| 13    | H515 3785 | Cover - Open And Close    |      |
| 14    | H515 3716 | Cover Bracket             |      |
| 15    | AG07 0004 | Magnetic Catch            |      |
| 16    | H515 3781 | Cover - Right             |      |
| 17    | H515 3780 | Cover - Front             |      |
| 18    | H515 5070 | Disply - LED              |      |
| 19    | H515 3786 | Panel - Disply            |      |
| 20    | H515 3710 | Cover Hinge Pin           |      |
| 21    | H515 3702 | Base Holder               |      |
| 22    | H515 3790 | Joint Bracket             |      |
| 23    | H515 3694 | Right Pin Holder          |      |
| 24    | H515 3695 | Left Pin Holder           |      |

| INDEX | PARTS NO.  | DESCRIPTION                       | Note |
|-------|------------|-----------------------------------|------|
| 101   | 0353 0060Z | Screw - M3X6                      |      |
| 102   | 0802 5231  | Tapping Screw - M3x6              |      |
| 103   | 0353 0080Z | Philips Trass Head Screw - M3x8   |      |
| 104   | 0443 0060W | Hexagon Head Tapping Screw - M3x6 |      |
| 105   | 0434 0082B | Tapping Screw - M4x8              |      |



## 2. FRAME




## 2. FRAME

| INDEX | PARTS NO. | DESCRIPTION                     | Note |
|-------|-----------|---------------------------------|------|
| 1     | H515 5065 | P. F. Motor - PFU - DC24V;0.49A |      |
| 2     | H515 3699 | Left Cassette Stopper           |      |
| 3     | H515 3657 | Front Stay                      |      |
| 4     | H515 3721 | Front Cover Holder              |      |
| 5     | H515 3670 | Paper Feed Roller (EUR)         |      |
| 5     | H515 3713 | Paper Feed Roller - PFU - US    |      |
| 6     | H515 3673 | Registration Roller - PFU       |      |
| 7     | H515 3661 | Mortor Bracket                  |      |
| 8     | H515 5068 | Registration Sensor - PFU       |      |
| 9     | H515 3676 | Regist Roller Bushing           |      |
| 10    | H006 2383 | Snap Ring                       |      |
| 11    | H515 3658 | Rear Stay                       |      |
| 12    | H515 3709 | Edgeing                         |      |
| 13    | H515 3681 | Registration Gear               |      |
| 14    | H020 3623 | Snap Ring - Registration Roller |      |
| 15    | H515 5066 | Paper Feed Clutch               |      |
| 16    | H515 3707 | Connector Bracket               |      |
| 17    | H515 3666 | Paper End Sensor Bracket        |      |
| 18    | H515 5067 | Paper End Sensor - PFU          |      |
| 19    | H515 3715 | PCB Supporter                   |      |
| 20    | H515 6035 | PCB - PFU                       |      |
| 21    | H515 5331 | PFU LED Harness Y               |      |
| 22    | H515 5332 | Lower PFU Harness               |      |
| 23    | H515 5333 | Upper PFU Harness               |      |
| 24    | H515 5330 | PFU Sensor Harness Y            |      |
| 25    | H515 3656 | Rear Support Plate              |      |
| 26    | H515 5018 | Cover Switch - Fusing Exit      |      |
| 27    | H515 3706 | Guide Sheet                     |      |
| 28    | H515 3664 | Lower Guide Plate               |      |
| 29    | H515 3679 | Brake Gear                      |      |
| 30    | H515 3700 | Right Cassette Holder           |      |
| 31    | H515 5054 | Paper Size Sensor               |      |

| INDEX | PARTS NO.  | DESCRIPTION                         | Note |
|-------|------------|-------------------------------------|------|
| 32    | H515 3693  | Positioning Pin                     |      |
| 33    | H521 3350  | Rubber Foot                         |      |
| 34    | H515 3696  | Cassette Guide                      |      |
| 35    | H515 3697  | Cassette Rail                       |      |
| 36    | H515 3711  | Bottom Plate Lock Guide             |      |
| 37    | H515 3712  | Base Film                           |      |
| 38    | 5409 1238  | Rotary Catch                        |      |
| 39    | H515 3698  | Release Guide                       |      |
| 40    | H515 3655  | Front Support Plate                 |      |
| 41    | H515 3720  | Front Support Bracket               |      |
| 42    | H515 3680  | Idle Gear                           |      |
| 43    | H515 3717  | Guide Plate - Upper                 |      |
| 44    | H515 3653  | Side Plate - Right                  |      |
| 45    | H515 3654  | Side Plate - Left                   |      |
| 101   | 0443 0060W | Hexagon Head Tapping Screw - M3x6   |      |
| 102   | 0951 3006B | Philips Screw With Flat Washer-m3x6 |      |
| 103   | 1105 0113  | Edge - P108                         |      |
| 104   | 1105 0344  | Clamp                               |      |
| 105   | 1105 0260  | Wire Saddle                         |      |
| 106   | 0802 5231  | Tapping Screw - M3x6                |      |
| 107   | 0443 0080W | Hexagon Head Tapping Screw - M3x8   |      |
| 108   | 0805 3386  | Bushing - 8mm                       |      |
| 109   | 0805 3385  | Bushing - 6mm                       |      |



### 3. CASSETTE





**1-7**

# **PARTS INDEX**

| PART N O. | DESCRIPTION                     | INDEX |
|-----------|---------------------------------|-------|
| AG07 0004 | Magnetic Catch                  | 3- 15 |
| H006 2383 | Snap Ring                       | 5- 10 |
| H020 3623 | Snap Ring - Registration Roller | 5- 14 |
| H515 0101 | Side Fence Ass'y                | 7- 2  |
| H515 3610 | Option Cassette                 | 7- 1  |
| H515 3614 | End Fence                       | 7- 8  |
| H515 3615 | End Fence Spring                | 7- 10 |
| H515 3616 | Front Paper Holder              | 7- 3  |
| H515 3617 | Rear Paper Holder               | 7- 18 |
| H515 3618 | Sponge                          | 7- 20 |
| H515 3619 | Bottom Plate                    | 7- 12 |
| H515 3620 | Front Friction Pad              | 7- 13 |
| H515 3621 | Rear Friction Pad               | 7- 14 |
| H515 3622 | Pressure Spring                 | 7- 15 |
| H515 3623 | Decal - Upper Cassette          | 7- 6  |
| H515 3625 | End Fence Stopper               | 7- 7  |
| H515 3626 | Paper Holder Spring             | 7- 4  |
| H515 3627 | Bottom Plate Stopper            | 7- 16 |
| H515 3629 | Spring Stopper                  | 7- 11 |
| H515 3630 | Sponge                          | 7- 9  |
| H515 3632 | Stopper Spring                  | 7- 17 |
| H515 3653 | Side Plate - Right              | 5- 44 |
| H515 3654 | Side Plate - Left               | 5- 45 |
| H515 3655 | Front Support Plate             | 5- 40 |
| H515 3656 | Rear Support Plate              | 5- 25 |
| H515 3657 | Front Stay                      | 5- 3  |
| H515 3658 | Rear Stay                       | 5- 11 |
| H515 3661 | Mortor Bracket                  | 5- 7  |
| H515 3664 | Lower Guide Plate               | 5- 28 |
| H515 3666 | Paper End Sensor Bracket        | 5- 17 |
| H515 3670 | Paper Feed Roller (EUR)         | 5- 5  |
| H515 3673 | Registration Roller - PFU       | 5- 6  |
| H515 3676 | Regist Roller Bushing           | 5- 9  |

| PART N O. | DESCRIPTION                  | INDEX |
|-----------|------------------------------|-------|
| H515 3679 | Brake Gear                   | 5- 29 |
| H515 3680 | Idle Gear                    | 5- 42 |
| H515 3681 | Registration Gear            | 5- 13 |
| H515 3682 | Release Guide Plate          | 3- 5  |
| H515 3683 | Pressure Roller              | 3- 7  |
| H515 3684 | Pressure Shaft               | 3- 6  |
| H515 3685 | Pressure Spring              | 3- 8  |
| H515 3688 | Guide Link                   | 3- 9  |
| H515 3689 | Bushing                      | 3- 11 |
| H515 3690 | Link Spring                  | 3- 12 |
| H515 3691 | Link Shaft                   | 3- 10 |
| H515 3693 | Positioning Pin              | 5- 32 |
| H515 3694 | Right Pin Holder             | 3- 23 |
| H515 3695 | Left Pin Holder              | 3- 24 |
| H515 3696 | Cassette Guide               | 5- 34 |
| H515 3697 | Cassette Rail                | 5- 35 |
| H515 3698 | Release Guide                | 5- 39 |
| H515 3699 | Left Cassette Stopper        | 5- 2  |
| H515 3700 | Right Cassette Holder        | 5- 30 |
| H515 3702 | Base Holder                  | 3- 21 |
| H515 3706 | Guide Sheet                  | 5- 27 |
| H515 3707 | Connector Bracket            | 5- 16 |
| H515 3709 | Edgeing                      | 5- 12 |
| H515 3710 | Cover Hinge Pin              | 3- 20 |
| H515 3711 | Bottom Plate Lock Guide      | 5- 36 |
| H515 3712 | Base Film                    | 5- 37 |
| H515 3713 | Paper Feed Roller - PFU - US | 5- 5  |
| H515 3715 | PCB Supporter                | 5- 19 |
| H515 3716 | Cover Bracket                | 3- 14 |
| H515 3717 | Guide Plate - Upper          | 5- 43 |
| H515 3720 | Front Support Bracket        | 5- 41 |
| H515 3721 | Front Cover Holder           | 5- 4  |
| H515 3780 | Cover - Front                | 3- 17 |

| PART N O. | DESCRIPTION                       | INDEX |
|-----------|-----------------------------------|-------|
| H515 3781 | Cover - Right                     | 3- 16 |
| H515 3782 | Cover - Left                      | 3- 1  |
| H515 3783 | Cover - Rear                      | 3- 3  |
| H515 3784 | Cover - Connector - Upper         | 3- 4  |
| H515 3785 | Cover - Open And Close            | 3- 13 |
| H515 3786 | Panel - Disply                    | 3- 19 |
| H515 3787 | Cover - Upper                     | 3- 2  |
| H515 3790 | Joint Bracket                     | 3- 22 |
| H515 5018 | Cover Switch - Fusing Exit        | 5- 26 |
| H515 5054 | Paper Size Sensor                 | 5- 31 |
| H515 5065 | P. F. Motor - PFU - DC24V;0.49A   | 5- 1  |
| H515 5066 | Paper Feed Clutch                 | 5- 15 |
| H515 5067 | Paper End Sensor - PFU            | 5- 18 |
| H515 5068 | Registration Sensor - PFU         | 5- 8  |
| H515 5070 | Disply - LED                      | 3- 18 |
| H515 5330 | PFU Sensor Harness Y              | 5- 24 |
| H515 5331 | PFU LED Harness Y                 | 5- 21 |
| H515 5332 | Lower PFU Harness                 | 5- 22 |
| H515 5333 | Upper PFU Harness                 | 5- 23 |
| H515 6035 | PCB - PFU                         | 5- 20 |
| H516 3470 | Decal - Bottom Plate              | 7- 5  |
| H521 3350 | Rubber Foot                       | 5- 33 |
| H521 3424 | Paper Size Sensor Board - A4      | 7- 19 |
| H521 3425 | Paper Size Sensor Board - A5      | 7- 19 |
| H521 3429 | Paper Size Sensor Board - 81/2x11 | 7- 19 |
| H521 3431 | Paper Size Sensor Board - 81/2x14 | 7- 19 |
| H521 3433 | Paper Size Indicator - F/F4       | 7- 19 |

| PART N O. | DESCRIPTION         | INDEX |
|-----------|---------------------|-------|
| 5409 1238 | Rotary Catch        | 5- 38 |
| 5413 4835 | Decal - Paper Level | 7- 21 |

| PART N O.  | DESCRIPTION                         | INDEX |
|------------|-------------------------------------|-------|
| 0353 0060Z | Screw - M3X6                        | 3-101 |
| 0353 0080Z | Philips Trass Head Screw - M3x8     | 3-103 |
| 0434 0082B | Tapping Screw - M4x8                | 3-105 |
| 0443 0060W | Hexagon Head Tapping Screw - M3x6   | 3-104 |
| 0443 0060W | Hexagon Head Tapping Screw - M3x6   | 5-101 |
| 0443 0080W | Hexagon Head Tapping Screw - M3x8   | 5-107 |
| 0802 5231  | Tapping Screw - M3x6                | 3-102 |
| 0802 5231  | Tapping Screw - M3x6                | 5-106 |
| 0805 3385  | Bushing - 6mm                       | 5-109 |
| 0805 3386  | Bushing - 8mm                       | 5-108 |
| 0951 3006B | Philips Screw With Flat Washer-m3x6 | 5-102 |
| 1105 0113  | Edge - P108                         | 5-103 |
| 1105 0260  | Wire Saddle                         | 5-105 |
| 1105 0344  | Clamp                               | 5-104 |

| PART N O. | DESCRIPTION | INDEX |
|-----------|-------------|-------|
|           |             |       |