

RICOH

PARTS CATALOG
FOR
RICOH FAX 7000L

First edition June 1990

RICOH COMPANY, LTD.

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.


INDEX to PARTS CATALOG

1. Exterior	2	9. Transfer PCBs	18
2. ADF Unit	4	10. Fusing Unit	20
3. Scanner Unit	6	11. Main Drive	22
4. Laser Unit	8	12. Lower Exterior	24
5. Upper Unit	10	13. Lower Paper Feed Unit I	26
6. Cassette	12	14. Lower Paper Feed Unit II	28
7. Paper Feed Unit	14	15. Accessories	30
8. Development Unit	16	16. Parts for Optional Kit	32

Note:

The meaning of the indication in the Model column is as follows.

G : Germany version
UK : UK version
I : Italy version
F : France version
UN : Universal version



1. EXTERIOR

June 01, '90

Index NO .	Parts No.	Description	Model
1	H008 4031	Exit Front Cover	
2	H008 4004	Upper Exit Cover	
3	H008 4032	Exit Rear Cover	
4	H008 2227	Sub Document Tray	
5	H008 2228	Document Tray Bracket	
6	H008 2226	Document Tray	
7	H008 2282	Document Tray Hinge	
8	H008 4445	Rear Left Cover : R	
9	H008 4446	Rear Left Cover Support : E	
10	H008 4454	Microphone Jack Bracket : E	
11	H008 5360	Microphone Jack Harness : E	
12	H008 4047	Rear Small Cover Bracket	
13	H008 5361	Microphone-CCU Harness : E	
14	H008 4449	Rear Cover	
16	H009 4100	Rear Right Cover	
17	H008 4165	NCU Cover : R	
18	H008 4172	Brightness Adjustment Decal	UK, UN
18	H008 4173	Brightness Adjustment Decal : R-G	G
18	H008 4174	Brightness Adjustment Decal : R-I	I
18	H008 4175	Brightness Adjustment Decal : R-F	F
19	H008 4043	LCD Brightness Pin Bracket	
20	H008 5230	LCD Adjuster	
21	H008 1254	Scanner Clamper	
22	H008 4159	Upper Right Cover	
23	H008 4052	Harness Exit Cover	
24	H008 4161	Right Upper Cover	
25	H008 4012	Sub Document Table	
26	H008 4042	Copy Tray	
27	H008 4474	Switch Decal	Except G
27	H008 4428	Switch Decal : R-G	G
28	H008 4060	Right Cover	
29	H008 4026	Right Cover Spring Plate	
30	H008 4027	Right Lever Rear Bracket	
31	H008 4083	Toner Replacement Decal	
32	H008 4018	Right Cover Lever	


Index NO .	Parts No.	Description	Model
33	H008 4017	Right Cover Knob	
34	H008 4022	Right Fulcrum Pin Bracket	
35	H008 4025	Right Cover Earth Plate	
36	H008 4040	Right Cover Spring	
37	H008 4023	Right Lever Front Bracket	
38	H008 4019	Right Cover Fulcrum Pin	
39	H008 3223	Development Inner Cover Screw	
40	H008 3224	Development Inner Cover	
41	H008 4001	Front Right Cover	
43	H008 4030	Q.R.G. Catcher	
44	H008 4029	Q.R.G. Inner Cover	
45	H008 4100	Front Cover	
46	H008 4049	Rubber Cap - M3	
47	H008 3193	OPU Right Bracket	
48	H008 3192	OPU Left Bracket	
49	H008 2097	OPU Ass'y : R-G	G
49	H008 2098	OPU Ass'y : R-UK, UN	UK, UN
49	H008 2091	OPU Ass'y : R-I	I
49	H008 2092	OPU Ass'y : R-F	F
50	H008 4532	Upper Cassette Decal	UK, UN
50	H008 4535	Upper Cassette Decal : R-G	G
50	H008 4538	Upper Cassette Decal : R-I	I
50	H008 4541	Upper Cassette Decal : R-F	F
52	H008 4406	Quick Reference Guide : R-G	G
52	H008 4458	Quick Reference Guide : R-UK, UN	UK, UN
52	H008 4407	Quick Reference Guide : R-I	I
52	H008 4408	Quick Reference Guide : R-F	F
55	H008 4045	Right Cover Stepped Screw	
57	H008 4039	Document Tray	
58	H008 5332	LCP-5 Harness	
60	H008 4046	Rear Small Cover	

Index No.	Parts No.	Description	Model
101	0353 0050Z	Philips Truss Head Screw - M3 x 5	
102	0313 0050B	Philips Pan Head Screw - M3 x 5	
103	0951 3006B	Philips Screw With Flat Washer - M3 x 6	
104	0313 0040B	Philips Pan Head Screw - M3 x 4	
105	0314 0060B	Philips Pan Head Screw - M4 x 6	
106	0313 0080B	Philips Pan Head Screw - M3 x 8	

Index No.	Parts No.	Description	Model

2. ADF UNIT

June 01,'90



2. ADF UNIT


Index No.	Parts No.	Description	Model
1	H008 1232	Bar Code Cover Shaft	UK, UN
2	H008 1260	Bar Code Cover Clip - Middle	
3	H008 1262	Bar Code Holder	
4	H008 1263	Bar Code Rear Hinge	
5	H008 1295	Bar Code Cover	
5	H008 1300	Bar Code Cover : R-G	
5	H008 1297	Bar Code Cover : R-I	
5	H008 1298	Bar Code Cover : R-F	
6	H008 1278	Bar Code List - 1P.	
6	H008 1279	Bar Code List - 1P : R-G	
6	H008 1280	Bar Code List"- 1P : R-I	UK, UN
6	H008 1281	Bar Code List - 1P : R-F	
7	H008 1282	Bar Code List - 2P	
7	H008 1283	Bar Code List - 2P : R-G	
7	H008 1284	Bar Code List - 2P : R-I	
7	H008 1285	Bar Code List - 2P : R-F	
8	H008 1259	Bar Code Cover Clip - Front	
9	H008 1261	Bar Code Cover Clip - Rear	
11	H008 1220	MDF Cover	
12	H008 1190	Scanner Lock Collar	UK, UN
13	H008 1191	Scanner Lock Shaft	
14	H008 1241	Scanner Cover Hinge - Rear	
15	H008 1324	Scanner Cover : R-G	
15	H008 1325	Scanner Cover : R-UK, UN	
15	H008 1326	Scanner Cover : R-I	
15	H008 1327	Scanner Cover : R-F	
16	H008 6013	PCB - MDF	
17	H008 1195	MDF Button	
18	H008 1196	MDF Spring	
19	H008 1189	MDF Stay	UK, UN
20	H006 1190	Sensor Base	
21	H008 1243	Spring Plate	
22	H008 1267	Spring Plate - R1 Pressure	
23	H006 1149	Lever - Document Width Sensor	
24	H008 1242	Scanner Cover Hinge - Front	

Index No.	Parts No.	Description	Model
25	H008 1061	Scanner Cover Release Spring	UK, UN
26	H008 1194	Scanner Release Arm	
27	H008 1197	Scanner Release Spring	
28	H008 1192	Scanner Release Pin	
29	H008 1193	Scanner Release Bracket	
30	H008 1210	MDF Release Shaft	
31	H008 1198	MDF Bracket - Lower	
32	H008 1217	MDF Release Spring	
33	H008 1211	MDF Release Arm	
34	H008 1218	MDF Lock Spring	
35	H008 1216	Separation Pressure Spring	UK, UN
36	H008 1208	Separation Pressure Adjuster	
37	H008 1224	Separation Pressure Spacer	
38	H008 1201	MDF Bracket - Upper	
39	H008 1207	Separation Pressure Shaft	
40	H008 1212	Separation Roller Bracket	
41	H008 1209	Separation Roller Hub - Front	
42	H008 1221	Separation Roller Shaft	
43	H008 1205	Separation Roller Spacer	
44	H008 1206	Separation Roller Disc	
45	H008 1213	Scanner Separation Roller	UK, UN
46	H008 1215	Separation Torque Spring	
47	H008 1222	Separation Roller Hub - Rear	
48	H008 1223	Separation Torque Spacer	
49	H008 1252	Scanner Antistatic Brush	
50	H008 1135	Scanner Pressure Roller	
51	H008 1132	Scanner Pressure Roller Shaft	
52	H008 1133	R1 Pressure Roller	
53	H008 1233	Document Upper Plate	
54	H008 1239	Pressure Plate Spring - Front	
55	H008 1349	Pressure Plate	UK, UN
56	H008 1240	Pressure Plate Spring - Front	
57	H008 1237	Pressure Plate Shaft	
58	H008 1236	White Plate	
59	H008 4074	Front Document Guide	

1-5

3. SCANNER UNIT

June 01,'90



3. SCANNER UNIT


June 01, '90

Index No.	Parts No.	Description	Model
1	H008 1167	Document Feed Out Plate	
2	H008 1346	Document Guide Plate	
3	H006 1120	Cover Open Pin	
4	H006 1121	Cover Open Spring	
5	H006 1119	Bushing - Cover Open	
6	H008 1251	Antistatic Brush	
7	H008 5237	Stamper	
8	H008 1174	F.L. Guide Plate	
9	H008 2240	Upper Earth Plate	
10	H006 1011	Scanner Mirror	
11	H008 1159	Scanner Release Stopper	
12	5053 0447	Bushing - M6	
13	H008 1160	Scanner Lock Spring	
14	H008 1118	Mirror Holder - Front	
15	H008 1175	Scanner Hinge - Front	
16	H006 4523	CS Stopper	
17	H008 1179	Scanner Hinge - Rear	
18	H008 2201	Front Protector	
19	H008 2223	Rear Protector	
20	H008 1116	Exposure Glass	
21	H008 1171	Document Feed Out Stay	
22	H008 1309	R2 Roller	
23	H008 1308	R1 Roller	
24	H008 5218	R2 Clutch	
25	H008 1117	Mirror Holder - Rear	
26	H008 1125	R1 Idler	
27	H008 1122	R1 Roller Pulley	
28	H008 1150	Scanner Feed Roller	
29	5447 2681	Snap Ring	
30	H041 1567	Pick-up Roller: ADF	
31	H008 2270	Scanner Timing Belt Inner Cover	
32	H008 1151	Scanner Pick-up Idler	
33	H008 1332	Scanner Feed Bracket	
34	H008 1156	Scanner Release Lever - Front	
35	H008 1158	Scanner Release Shaft	

Index No.	Parts No.	Description	Model
36	H008 1157	Scanner Release Lever - Rear	
37	H008 5217	Paper Feed Clutch	
38	H008 1144	Feed Roller Shaft	
39	H008 1152	Scanner Pick-up Hub	
40	H001 1134	Torque Spring - 011.6	
41	H008 1153	Scanner Pick-up Sleeve	
42	H008 1143	Scanner Clamp	
43	H008 5221	S2 Sensor	
44	H008 1254	Scanner Clamper	
45	H008 1137	Feed Roller Frame	
46	H008 2206	Harness Guide	
47	H008 6004	PCB - DSB	
48	H008 1245	Paper Width Sensor Fence	
49	H008 1248	S1 Sensor Fence	
50	H008 2269	Scanner Inner Cover	
51	H008 2247	Rear Left Inner Cover	
52	H008 5320	DSB-3 Harness	
53	H008 5319	MDF Harness	
54	H008 5362	Scanner Cover Earth Wire	
55	H008 1253	Scanner Feed Bracket Spring	
101	0353 0060Z	Philips Truss Head Screw - M3 x 6	
102	0313 0050B	Philips Pan Head Screw - M3 x 5	
103	0720 0030E	Retaining Ring - M3	
104	0720 0040E	Retaining Ring - M4	
105	0951 3010B	Philips Screw With Flat Washer - M3 x 1	
106	0574 0040E	Hexagon Headless Set Screw - M4 x 4	
107	0573 0040E	Hexagon Headless Set Screw - M3 x 4	
108	0951 3004B	Philips Screw With Flat Washer - M3 x 4	

4. LASER UNIT

June 01,'90




4. LASER UNIT

Index No.	Parts No.	Description	Model
1	H020 3827	F. Lens Bracket Ass'y	
2	H006 2518	Top F. Lens Holder	
3	H000 2508	F1 Lens	
4	H000 2509	F2 Lens	
5	H006 2513	Holder - Second Synchronizer Mirror	
6	H006 2509	Second Synchronizer Mirror	
7	H006 2554	Holder - First Synchronizer Mirror	
8	H006 2508	First Synchronizer Mirror	
9	H006 2556	Front F. Lens Holder	
10	H006 2042	Laser Diode Unit	
11	H000 2517	Left Mirror Holder	
12	H006 2507	Mirror	
13	H000 2516	Right Mirror Holder	
14	H008 2264	Inner Cover - LO Unit	
15	H008 2205	Hinge Reinforcement Plate - Rear	
16	H006 3444	Varistor	
19	H006 3419	Earth Plate - Charge	
20	H006 3439	Charge Corona Unit Duct	
21	H006 3453	Under Holder - Second Cy. Lens	
22	H006 3458	Charger Corona Unit	
23	H006 2678	Front End Block - Charge	
24	H006 2681	Front End Cover - Charge	
25	5203 9001	Corona Wire (10pcs)	
26	H006 3451	Housing Charge Ass'y	
27	H006 2677	Rear End Block - Charge	
28	5203 2060	Corona Wire Screw - M3 x 4	
29	H006 2679	Charge Wire Hook	
30	H006 5205	High Voltage Cord - C	
31	H006 2380	Used Toner Sensor Bracket	
32	5205 5250	L.E.D. Sensor Type S	
33	H008 5240	Scanner Motor Driver	
34	H008 5223	F.L. Stabilizer	
35	H000 2514	Holder - First Cylindrical Lens	
36	H006 2510	First Cylindrical Lens	
37	H008 2243	Pentagonal Mirror Motor	

Index No.	Parts No.	Description	Model
38	H008 2209	Front Earth Frame	
39	H008 2234	Fusing Interlock Bracket	
40	H008 2287	Interlock Spring	
41	H008 5222	Fluorescent Lamp	
42	H008 2268	F.L. Inner Cover	
43	H008 2291	Front Right Inner Cover	UK, UN
43	H008 2292	Front Right Inner Cover : G	G
43	H008 2293	Front Right Inner Cover : I	I
43	H008 2294	Front Right Inner Cover : F	F
44	H008 2303	Cover - Second Cy. Lens Ass'y	
46	H008 2245	Rear Right Inner Cover	
47	H008 2266	SMDR Cover	
48	H008 5316	LDDR Harness	
49	H006 1194	Shield Plate - Laser Section	
101	0951 3006B	Philips Screw With Flat Washer - M3 x 6	
102	0951 3020B	Philips Screw With Flat Washer - M3 x 20	
103	0313 0050B	Philips Pan Head Screw - M3 x 5	
104	0951 3008B	Philips Screw With Flat Washer - M3 x 8	
105	0314 0100B	Philips Pan Head Screw - M4 x 10	
106	0353 0050Z	Philips Truss Head Screw - M3 x 5	
107	0313 0160B	Philips Pan Head Screw - M3 x 16	

5. UPPER UNIT

June 01,'90



5. UPPER UNIT


June 01,'90

Index No.	Parts No.	Description	Model
1	H008 2302	Upper Base Cover	UK, UN
2	H008 1143	Scanner Clamp	
3	H000 3292	Saddle Edge	
4	H008 6023	PCB - UIB	
5	H008 2255	UIB Cover	
6	H008 2235	Hinge Reinforcement Plate - Rear	
7	H008 5219	Scanner Stepping Motor	
8	H001 2109	Damper - RX Motor	
9	H008 1128	Scanner Motor Pulley	
10	H008 1129	Scanner Timing Pulley Bracket	
11	H008 1123	Scanner Timing Pulley	
12	H008 1126	Scanner Timing Belt - Left	
13	H008 1127	Scanner Timing Belt - Right	
14	H008 2230	Upper Base Reinforcement Bracket	
15	H006 3384	Idle Gear - Master Drive - T20	
16	H006 3051	Tightner Master Belt - Ass'y	
17	H006 3381	Master Drive Bracket	
18	H008 2286	Master Drive Motor	
19	H006 3380	Master Drive Belt	
20	H008 2248	Master Drive Pulley Bracket	
21	H006 2457	Spring Holder	
22	H000 3332	Bushing	
23	H006 3385	Pulley - Master Unit Drive	
24	H006 3388	Master Drive Shaft	
25	H006 3420	Master Earth Plate	
26	H006 3398	Arm Bushing - Master Drive	
27	H006 3405	Rear Master Unit Rail	
28	H006 3389	Master Drive Gear - T16	
29	H008 2271	Master Drive Arm	
30	H008 2258	Master Drive Gear - 223	
31	H008 2249	Document Table Bracket	
32	H006 3446	Upper Base Holder	
33	H008 2244	Side Inner Cover	
34	H006 3408	Upper Base Hook	
35	H006 3760	Master Unit Decal	

Index No.	Parts No.	Description	Model
35	H006 3772	Master Unit Decal : G	G
35	H006 3773	Master Unit Decal : I	I
35	H008 2290	Master Unit Decal : F	F
37	H006 3438	Hook Spring	G I F
38	H006 3409	Front Hook Pin	
39	H008 2252	Master Unit Interlock	
40	H006 3407	Bias Terminal - Charge	
41	H006 3406	Front Master Unit Rail	
42	H006 3421	Pressure Arm - Drive Pulley	
43	H006 3460	Pressure Arm Spring	
44	H006 3422	Master H.P. Sensor Bracket	
45	5214 5230	Master Sensor	
46	H008 5317	VIB-1 Harness	
47	H006 2557	Second Cylindrical Lens - Ass'y	
48	H006 6001	PCB - LSD	
49	H006 2506	Synchronizer Holder	
50	G000 1945	LSD Cylindrical Lens	
51	H008 5232	Eraser Unit	
52	H008 5312	VIB-3 Harness	
53	H008 5318	Pentagonal Dr. Harness	
54	H006 3757	Sector Gear - Master Lock	
55	H006 3756	Master Lock Slider	
56	H006 3758	Slider Spring	
101	0313 0050B	Philips Pan Head Screw - M3 x 5	
102	0951 4008B	Philips Screw With Flat Washer - M4 x 8	
103	0574 0040E	Hexagon Headless Set Screw - M4 x 4	
104	0720 0030E	Retaining Ring - M3	
105	0954 3008B	Philips Screw - M3 x 8	
106	0954 4012B	Double Sems Screw - M4 x 12	
107	0965 3012B	Tapping Screw With Washer - M3 x 12	
108	0313 0120B	Philips Pan Head Screw - M3 x 12	
109	0951 3006B	Philips Screw With Flat Washer - M3 x 6	

Index No.	Parts No.	Description	Model
110	0720 0040E	Retaining Ring - M4	
111	0313 0060B	Philips Pan Head Screw - M3 x 6	
112	0720 0050E	Retaining Ring - M5	
113	0965 4008B	Tapping Screw - M4 x 8	
114	0353 0050Z	Philips Truss Head Screw - M3 x 5	
115	0323 0100B	Philips Pan Head Screw - M3 x 100	
116	0951 3008B	Philips Screw With Flat Washer - M3 x 8	
117	0965 3006B	Tapping Screw With Flat Washer - M3 x 6	
118	0807 4113	Clutch Spacer	
119	0720 0020E	Retaining Ring - M2	
120	0710 0030B	Flat Washer - M3	

Index No.	Parts No.	Description	Model



6.CASSETTE


June01,'90

Index No.	Parts No.	Description	Model
1	H020 4092	Cassette Cover	
2	H006 2320	Bottom Plate - Cassette Ass'y	
3	H006 3638	Paper Size Detector Pin - B4	
4	H006 3641	Paper Size Detector Pin - A4	
5	H006 3640	Paper Size Detector Pin - Legal	
7	H006 3642	Paper Size Detector Pin - Letter	
9	H006 3665	Front Side Fence	
10	H006 2322	Cassette	
11	H006 3663	Cassette Decal	
12	5447 2941	Rear Fence	
13	5413 4835	Decal - Paper Level	
14	H006 3666	Rear Side Fence	
15	H006 2972	Cassette Bottom Plate	
16	H006 2979	Front Side Fence	
17	5447 2912	Bottom Plate Cushion	
18	H006 2976	Rear Fence	
19	H006 2982	Rear Fence - Cassette	
20	H020 4087	Cassette - LCT	
21	H006 2977	Paper Check Decal	
101	0965 4008B	Tapping Screw - M4 x 8	

Index No.	Parts No.	Description	Model

7. PAPER FEED UNIT

June 01,'90



7. PAPER FEED UNIT


June 01,'90

Index No.	Parts No.	Description	Model
1	H006 3648	Feed Shaft Stay	
2	H006 3645	Front Stay - Feed Shaft	
3	H006 3751	Master Interlock Lever	
4	H006 3645	Front Stay - Feed Shaft	
5	H008 3319	Pick-up Stay Bracket	
6	H006 3532	Feed Roller	
7	H006 3533	Snap Ring	
8	H006 3285	Front Guide Rail - Development	
9	H006 3286	Development Bias Terminal	
10	H006 3530	Idle Gear - 15T	
11	H006 3531	Pick-up Roller	
12	5053 0447	Bushing - M6	
13	H008 3317	Pick-up Shaft Bracket	
14	H008 3318	Pick-up Roller Spring	
15	H008 3310	Pick-up Roller Bracket	
16	H006 3662	Cover - Pick-up Roller Stay	
17	H008 3312	Feed Roller Shaft	
18	H008 3313	Pick-up Roller Sleeve	
19	H008 3316	Feed Roller Spring	
20	H008 3315	Pick-up Roller Boss	
21	H006 3587	Spring - Upper Guide Plate	
22	5474 1140	Bushing - Pressure Roller	
23	H006 3586	Registration Roller	
24	H006 3588	Hold Spring - Upper Guide Plate	
25	H006 3584	Registration Arm	
26	H006 3619	Registration Upper Guide Plate	
27	H008 2051	Registration Lower Guide Plate	
28	H006 2070	Transfer Front Guide Plate	
29	H008 3309	Lower Registration Roller	
30	H006 2371	Paper Guide Pad Ass'y	
31	H006 3560	Paper Feed Guide	
32	H006 3551	Stopper Pawl	
33	H006 3550	Ratchet Pawl Pin	
34	H006 3552	Ratchet Spring	
35	5447 2768	Stepped Screw - M3	

Index No.	Parts No.	Description	Model
36	H006 3607	Release Pin Slider	
37	H006 3549	Release Spring - Paper Lift	
38	H006 3545	Release Lever - Paper Lift	
39	H006 3541	Stopper Bracket	
40	H006 3281	Rear Guide Rail - Development	
41	H006 3558	Sector Gear Lock	
42	H008 3304	Paper Feed Rear Bracket	
43	H006 3575	Rear Cassette Guide	
44	H006 3568	Torque Limiter Cover	
45	H006 3567	Torque Limiter Clutch	
46	H006 3566	Separation Roller	
47	H006 3565	Separation Roller Shaft	
48	H006 3570	Separation Roller Stopper	
49	H006 3569	Torque Limiter Spring	
50	H006 3571	Separation Roller Bracket	
51	H006 3572	Separation Roller Shaft	
52	H006 3671	Separation Roller Bracket	
53	H006 3573	Separation Roller Spring	
54	AW50 0001	Push Switch - Paper Size 1	
55	H008 5306	C-1 Harness	
56	H008 3323	Paper Lift Shaft	
57	H006 3559	Tray Lift Arm	
58	5447 2912	Bottom Plate Cushion	
59	H008 3300	Paper Feed Front Bracket	
60	H006 3574	Front Cassette Guide	
61	H006 3280	Spring - Pressure Upper Base	
62	H006 3279	Spring Clamp - Pressure Upper Base	
63	H006 3287	Bracket - Front Pressure Upper Base	
64	H006 3755	Master Interlock Spring	
65	H006 3754	Master Interlock Support	

Index No .	Parts No.	Description	Model
101	0313 0060W	Philips Pan Head Screw - M3 x 6	
102	0313 0050B	Philips Pan Head Screw - M3 x 5	
103	0720 0040E	Retaining Ring - M4	
104	0720 0030E	Retaining Ring - M3	
105	0573 0040E	Hexagon Headless Set Screw - M3 x 4	
106	0951 3005B	Philips Screw With Flat Washer - M3 x 5	
107	0314 0060B	Philips Pan Head Screw - M4 x 6	
108	0720 0060E	Retaining Ring - M6	
109	0954 4012B	Double Sems Screw - M4 x 12	

Index No.	Parts No.	Description	Model




8. DEVELOPMENT UNIT

June 01,'90

Index No.	Parts No.	Description	Model
1	H006 5207	Paper Sensor Ass'y	
2	H008 5334	Paper Harness	
3	H006 3623	Paper Sensor Sheet	
4	H006 3579	Stay - Paper Sensor Board	
5	H006 3600	Mylar - Feed	
6	H008 5342	Handset-2 Harness	
7	H008 6046	PCB - G3NCU : E	
8	H008 3195	NCU Shield Cover : E	
9	H008 3245	NCU Small Cover	
10	H008 4034	Upper Base Open Button	
11	H006 3693	Roller - Upper Base Open	
12	H006 3702	Upper Base Spring	
13	H008 1100	Lens Ass'y	
14	H008 1115	Lens Adjuster	
15	H008 1114	Lens Block	
16	H008 6006	PCB - SBU	
17	H006 1015	SBU Adjustment Knob	
18	5466 3198	Washer - SBU	
19	H006 5208	Toner End Sensor	
20	H008 3260	Lens Block Stay	
21	H006 3336	Lens Block Stay Clamper	
22	H008 3156	Lens Block Inner Cover	
23	H008 3174	Fusing Support Pin	
24	H008 4066	Right Cover Lever	
25	H006 3269	Upper Base Guide	
26	H008 3189	OPU Right Stay	
27	H006 2050	Development Hopper Ass'y	
28	H006 2437	Developing Roller	
29	H006 2401	Hopper Agitator	
30	5216 3095	Mylar - Toner Supply Roller	
31	H006 2404	Toner Supply Roller Ass'y	
32	H006 2409	Toner Metering Blade Ass'y	
33	5203 3105	Nylon Rivet	
34	H006 2418	Antistatic Brush Cover	
35	H006 2400	Development Antistatic Brush	

Index No.	Parts No.	Description	Model
36	H006 2438	Front Side Plate - Development	
37	H006 2051	Hopper Ass'y	
38	H006 2443	Rear Side Plate - Development	
39	H006 2431	Sleeve Idle Gear	
40	H006 2432	Toner Supply Gear	
41	H006 2429	Sleeve Gear	
42	H006 2433	Front Development Gear	
43	H006 2419	Agitator Idle Gear	
44	H006 2407	Toner End Lever	
45	H006 2420	Rear Development Cover	
46	5203 3151	Roller Cover Spring	
47	5203 3130	Toner End Disk	
48	H006 2428	Agitator Gear	
49	5203 3127	Toner End Spring	
50	H008 1350	Lens Block Guard	
51	H008 4050	BSRU Bracket	
52	H008 6017	PCB - BSRU	
101	0951 3005B	Philips Screw With Flat Washer - M3 x 5	
102	0313 0050B	Philips Pan Head Screw - M3 x 5	
103	0951 3006B	Philips Screw With Flat Washer - M3 x 6	
104	0720 0040E	Retaining Ring - M4	
105	0954 3008B	Philips Screw - M3 x 8	
106	0954 4012B	Double Sems Screw - M4 x 12	
107	0954 3014B	Double Sems Screw - M4 x 8	
108	0314 0060B	Philips Pan Head Screw - M4 x 6	
109	0720 0030E	Retaining Ring - M3	
110	0720 0060E	Retaining Ring - M6	
111	0805 3162	Ball Bearing - 10 x 19 x 7mm	
112	0701 0050B	Flat Washer - M5	



9. TRANSFER • PCBs


June 01, '90

Index No.	Parts No.	Description	Model
1	H008 3191	PCB Shield Stay	
2	H008 5215	SPU Fan	
3	H008 3190	PCB Shield Cover	
4	H008 3194	Speaker Bracket	
5	H008 5216	Speaker	
6	H001 3736	Clamper - Speaker	
7	H008 5321	Interlock Harness	
8	H006 3221	Interlock SW Bracket	
9	H008 3219	SPU Shield Cover	
10	H008 3122	PCB Securing Screw	
11	H008 5302	SPU-1 Harness	
12	H008 6012	PCB - Modem (MMD 9624)	
13	H008 6042	PCB - G3 CCU : E	
14	H008 6007	PCB - VPU	
15	H008 5310	SBU Harness	
16	H008 6041	PCB - SPU	
17	H008 5361	Microphone - CCU Harness : E	
18	H008 3214	SCU Shield Cover	
19	H008 6000	PCB - SCU	
20	H008 5301	SCU-2 Harness	
21	H008 3188	OPU Left Stay	
22	H008 3185	OPU Left Reinforcement Stay	
23	H008 3186	OPU Reinforcement Stay Bracket	
24	H008 6031	PCB - MBU : R-G	G
24	H008 6032	PCB - MBU : R-UK	UK
24	H008 6033	PCB - MBU : R-I	I
24	H008 6034	PCB - MBU : R-F	F
24	H008 6035	PCB - MBU : R-UN	UN
27	H008 5212	Master Unit Fan Motor	
28	H006 4135	Fan Motor Duct	
29	H006 4128	Fan Motor Nut	
30	H006 2452	Transfer Ventilation Guide	
31	H006 2450	Transfer Corona Ass'y	Except UK
31	H006 4643	Transfer Corona Ass'y : UK	UK
32	H008 3257	Fusing Rear Stopper	

Index No.	Parts No.	Description	Model
33	H006 2688	Rear End Cover - Transfer	
34	H006 2687	Rear End Block - Transfer	
35	H006 2451	Housing - Transfer	
36	5203 9001	Corona Wire (10pcs)	
37	H006 5042	Earth Wire - Transfer	Except UK
37	H006 5603	Earth Wire - Transfer : UK	UK
38	H006 2684	Front End Cover - Transfer	
39	5203 2060	Corona Wire Screw - M3 x 4	
40	H006 2683	Front End Block - Transfer	
41	H006 5041	High Voltage Cable	
42	H006 3312	Transfer Pressure Spring	
43	H008 3173	Transfer Rear Holder	
44	H008 3172	Transfer Front Holder	
45	H008 3256	Fusing Front Stopper	
46	H008 5313	R - Sensor Harness	
47	H008 6009	PCB - R-Sensor	
48	H008 3176	Registration Harness Clamper	
49	H008 5211	Rear Transfer Fan	
50	H006 3365	Rear Bracket - Transfer Fan	
51	H008 5210	Front Transfer Fan	
52	H006 2456	Transfer Guide Spring	
53	H006 3326	DRU Cover	
54	H006 3288	Bias Block - Charge	
55	H006 3363	Front Bracket - Transfer Fan	
56	H006 5222	Power Pack	Except UK
56	H006 5602	Power Pack : UK	UK
57	H006 3660	Cover - Development Interlock	
58	H008 3252	PCB Fan Seal	
59	H008 3249	Shield Cover Earth Plate	
60	H008 3250	Shield Stay Earth Plate	
61	H008 3251	Shield Stay Lower Earth Plate	
62	H008 5325	G3 CCU - NCU Harness	
63	H008 5333	SPU-4 Harness	
64	H008 3268	Front G4 Connector Bracket	
65	H008 6052	Front G4 Connector	

Index No.	Parts No.	Description	Model
66	H008 5370	Harness: G4CCU-G4TMB	
67	H008 5331	Harness: G4I-TMB	
68	H008 6053	Rear G4 Connector	
69	H008 3269	Rear G4 Connector Bracket	
73	H008 3123	Rear Side Bracket	
74	H008 5344	Bar Code Reader Harness	

Index No.	Parts No.	Description	Model
101	0313 0050B	Philips Pan Head Screw - M3 x 5	
102	0313 0180B	Philips Pan Head Screw - M3 x 10	
103	1204 1280	Push Switch	
104	0314 0060B	Philips Pan Head Screw - M4 x 6	
105	0951 3006B	Philips Screw With Flat Washer - M3 x 6	
106	0951 3010B	Philips Screw With Flat Washer - M3 x 1	
107	0951 3005B	Philips Screw With Flat Washer - M3 x 5	
108	0313 0250W	Philips Pan Head Screw - M3 x 25	
109	0951 3008W	Philips Screw With Flat Washer - M3 x 8	
110	0809 1005	Nylon Wire	
111	0951 3025B	Philips Screw With Flat Washer - M3 x 25	
112	0314 0160B	Philips Pan Head Screw - M4 x 16	
113	1204 1603	Push Switch	
114	0951 4006W	Philips Screw With Flat Washer - M4x6	
115	0951 4006B	Philips Screw With Flat Washer - M4x6	



10. FUSING UNIT


June 01,'90

Index No.	Parts No.	Description	Model
1	H008 4005	Fusing Exit Cover	
3	H008 2123	Upper Exit Guide Ass'y	
4	H008 2102	Paper Exit Bracket	
5	H006 2131	Stripper Spring	
6	H006 2135	Bushing - M 4 x 6	
7	H006 2182	Exit Gear - T19	
8	H006 9001	Hot Roller Stripper (5pcs)	
9	H006 2173	Stripper Release Spring	
10	H006 2172	Holder - Feed Out Spring	
11	H006 2170	Feed Out Hook	
12	H006 2171	Exit Stepped Screw	
13	H008 2117	Exit Lower Guide Plate	
14	H006 2152	Lower Exit Roller	
15	H006 2151	Exit Roller Holder	
16	H006 2154	Exit Antistatic Brush	
17	H006 2176	Exit Interlock Lever	
18	H006 2134	Fusing Exit Roller	
19	H008 3187	Fusing Rear Inner Cover	
20	H008 3181	Fusing Side Stay	
21	H008 3144	Fusing Front Inner Cover	
22	H008 3146	Fusing Interlock Lever	
23	H008 3254	Fusing Interlock Spring	
24	H006 3271	Interlock Fusing Roller	
25	H008 2146	Front Fusing Hook	
26	H008 2107	Fusing Rear Bracket	
27	H006 2109	Front Fusing Bushing	
28	H006 2140	Front Heater Holder	
29	H006 3248	Fusing Support Bracket - Front	
30	H008 2122	Fusing Pressure Spring	
31	H008 2120	Paper Exit Cover	
32	H006 2148	Exit Sensor Actuator	
33	5052 0269	Bushing - 4.2mm	
34	H006 2149	Exit Sensor Shaft	
35	H006 2145	Exit Sensor Slit	
36	H008 2119	Fusing Lower Guide Plate	

Index No.	Parts No.	Description	Model
37	H006 2181	Idle Gear - T19	
38	H008 2112	Rear Fusing Bracket	
39	H008 2147	Rear Fusing Hook	
40	H008 2100	Lower Guide Plate	
41	H006 2111	Rear Fusing Bushing	
42	H006 2180	Fusing Gear - T35	
43	H006 2142	Rear Heater Holder	
44	H006 3247	Fusing Support Bracket - Rear	
45	H008 5364	Thermostat Harness : E	
46	H008 5248	Fusing Thermistor : E	
47	H006 2729	Upper Fusing Stay : E	
48	H006 2727	Thermostat Bracket : E	
49	H008 2148	Thermostat Ass'y : E	
50	H006 2728	Thermostat Case : E	
51	H006 2190	Fusing Entrance Mylar	
52	H006 2110	Hot Roller	
53	H008 5244	Fusing Lamp : E	
54	H006 2113	Pressure Roller Bushing	
55	H006 2112	Pressure Roller	
56	H006 2473	Front Spring Plate - Fan Motor	
57	H006 3325	Printer Fan Rear Seal	
58	H008 3113	Printer Fan	
59	H006 3243	Ozone Filter	
60	H006 3324	Printer Fan Front Seal	
61	H008 3212	Transport Guide Plate	
62	H008 5205	Fusing Connector	
63	H006 2689	Cleaning Pad	
64	H006 4252	Caution Decal - PSU	UK, UN
64	H006 4408	Caution Decal - PSU:G	G
64	H006 4409	Caution Decal - PSU : I	I
64	H008 4478	Caution Decal - PSU:F	F
65	H008 2142	Paper Exit Guard	

Index No.	Parts No.	Description	Model
101	0313 0050B	Philips Pan Head Screw - M3 x 5	
102	0353 0050Z	Philips Truss Head Screw - M3 x 5	
103	0720 0030E	Retaining Ring - M3	
104	0313 0060B	Philips Pan Head Screw - M3 x 6	
105	0951 3005B	Philips Screw With Flat Washer - M3 x 5	
106	0720 0040E	Retaining Ring - M4	
107	0725 0200E	Retaining Ring C - M20	
108	0807 4009	Washer - 5.2 x 11 x 0.3	
109	0720 0020E	Retaining Ring - M2	
110	0353 0060Z	Philips Truss Head Screw - M3 x 6	
111	0313 0120B	Philips Pan Head Screw - M3 x 12	
112	0720 0060E	Retaining Ring - M6	

Index No.	Parts No.	Description	Model



11. MAIN DRIVE

June 01,'90

Index No.	Parts No.	Description	Model
1	H008 3184	Gas Spring Boss	
2	H008 3232	Gas Spring Bushing	
3	H008 3233	Gas Spring Washer	
4	H008 3201	Gas Spring	
5	H008 5331	Harness - G4I - TMB	
6	H008 3101	Front Bracket	
7	5214 1221	Rubber Foot	
8	H008 3182	Front Fulcrum Pin	
9	H008 3230	Upper Base Interlock Lever	
10	5413 1882	Two Stepped Screw	
11	H008 5363	DRU-1 Harness : E	
12	H008 6005	PCB - DRU	
13	H008 5311	DRU-3 Harness	
14	H008 3138	DRU Bracket	
15	H008 3167	PSU Stay	
16	H008 3136	Rear HD Bracket	
17	H008 3137	Hard Disk Spacer	
18	H008 5401	PCB- PSU : E	
19	H008 3135	Front HD Bracket	
20	H008 5200	Hard Disk Unit	
21	H008 3161	PSU Case	
22	H008 3231	Front Right Joint Bracket	
24	H008 3169	Hard Disk Clamper	
25	H008 3100	Base	
26	H008 3117	Joint Bracket	
28	H008 3206	Paper Lift Sector Gear	
29	H008 3324	Sector Gear Support Bracket	
30	H008 3179	Small Clamp	
31	H008 3175	Fusing Front Guide Bracket	
32	H000 3332	Bushing	
33	H006 3366	Development Drive Gear - T24	
34	H008 3273	Large Clamp	
35	H008 5207	Copy Out Sensor	
36	H008 3177	Copy Tray Bracket	
37	H008 3174	Fusing Support Pin	


Index No.	Parts No.	Description	Model
38	H008 3130	Transport Bracket	
39	5053 0447	Bushing - M6	
40	H008 3132	Main Drive Shaft	
41	H008 3247	Main Drive Idler - Z51	
42	H008 3112	Idler Gear - Z44, Z16	
43	H006 3364	Spring - Transport Fusing Bracket	
44	H006 3352	Fusing Idle Gear - T33	
45	H008 3148	Rear Fulcrum Pin Bracket	
46	H006 2345	Fan Drive Pulley - Middle	
47	H006 2471	Fan Belt Tightener	
48	H006 3374	Fan Drive Pulley - Small	
49	H006 5220	Main Motor	
50	H006 3376	Fan Drive Pulley - Large	
51	H006 3377	Fan Drive Belt	
52	H008 3238	Tightener Pulley	
53	H008 3236	Tightener	
54	H006 2479	Tightener Spring	
55	H008 3225	Clamper Bracket	
56	H008 1143	Scanner Clamp	
57	H008 3205	Development Clutch Stopper	
58	H006 3280	Spring - Pressure Upper Base	
59	H006 3279	Spring Clamp - Pressure Upper Base	
60	H008 3111	Drive Gear - 223	
61	H006 2530	Lock Pin Collar - Upper Base	
62	H008 348	PSU-15 Harness	
63	H008 3234	Drive Pulley - 224	
64	H008 3133	Paper Feed Clutch Bushing	
65	H008 3211	Main Drive Belt	
66	H008 3202	Registration Drive Gear	
67	H008 5208	Registration Clutch	
68	H008 3134	Paper Feed Gear	
69	H008 3204	Development Drive Shaft	
70	H008 5213	Development Clutch	
71	H008 2016	Paper Feed Clutch Ass'y	
72	H008 2017	Paper Lift Solenoid	

Index No.	Parts No.	Description	Model
73	H008 3270	Harness Guide	
76	H006 4256	Stepped Screw - Development Cover	
77	H008 5304	HD-20 Harness	
78	H008 5305	HD-34 Harness	
79	H008 5308	PSU-2 Harness	
80	H008 5321	Interlock Harness	
81	H008 5347	PSU-14 Harness	
82	H008 3168	HD Joint Bracket	
83	H008 3178	Rubber Foot	

Index No.	Parts No.	Description	Model
101	0313 0050B	Philips Pan Head Screw - M3 x 5	
102	0720 0040E	Retaining Ring - M4	
103	0951 4008B	Philips Screw With Flat Washer - M4 x 8	
104	0720 0050E	Retaining Ring - M5	
105	0951 3006B	Philips Screw With Flat Washer - M3 x 6	
106	0314 0060B	Philips Pan Head Screw - M4 x 6	
107	0720 0060E	Retaining Ring - M6	
108	0805 3145	Ball Bearing - 6 x 12 x 4mm	
109	0314 0080B	Philips Pan Head Screw - M4 x 8	
110	0573 0040E	Hexagon Headless Set Screw - M3 x 4	
111	0720 0030E	Retaining Ring - M3	
112	0954 3008B	Philips Screw - M3 x 8	
113	0951 4010B	Philips Screw With Flat Washer - M4 x 10	
114	0313 0030B	Philips Pan Head Screw - M3x3	

12. LOWER EXTERIOR

June 01, '90




12. LOWER EXTERIOR

June 01,'90

Index No.	Parts No.	Description	Model
1	H008 2456	Lower Left Cover	UK, UN
1	H008 2457	Lower Left Cover : R-G	G
1	H008 2458	Lower Left Cover : R-I	I
1	H008 2459	Lower Left Cover : R-F	F
2	H008 4474	Switch Decal	Except G
2	H008 4428	Switch Decal : R-G	G
3	H008 4049	Rubber Cap - M3	
4	H008 2434	Lower Harness Cover: 2	
5	H008 2405	Lower Rear Left Support	
6	H008 2423	Damper	
7	H008 3120	Lower Rear Joint Bracket	
8	H008 2404	Lower Rear Right Support	
9	H008 2417	Lower Rear Cover	
10	H008 2435	Lower Right Cover Bracket	
11	H008 2415	Lower Right Cover	
12	H008 2413	Lower Front Right Cover	
13	H008 3119	Lower Front Right Joint Bracket	
15	H008 2418	Lower Right Support Bracket	
16	H008 4030	Q.R.G. Catcher	
17	H008 2432	Lower Base Support	
18	H008 5226	Lower Cover Open Switch	
19	H008 2419	Lower Light Support Bracket	
20	H008 2424	Lower Cover Hinge Bracket	
21	H008 2452	Lower Jam Removal Decal	UK, UN
21	H008 2453	Lower Jam Removal Decal : G	G
21	H008 2454	Lower Jam Removal Decal : I	I
21	H008 2455	Lower Jam Removal Decal : F	F
22	H008 2420	Lower Left Inner Cover	
23	H008 4062	Q.R.G. Catcher Plate	
24	H008 2427	Lower Harness Cover: 1	
25	H008 2414	Lower Front Left Cover	
26	H008 2428	Lower Cover Hinge Cover	
27	H008 2436	Lower Left Holder	
28	H008 2437	Lower Right Holder	
29	H008 3118	Lower Front Left Joint Bracket	

Index No.	Parts No.	Description	Model
30	H008 4544	Lower Cassette Decal	UK, UN
30	H008 4547	Lower Cassette Decal : R-G	G
30	H008 4550	Lower Cassette Decal : R-I	I
30	H008 4553	Lower Cassette Decal : R-F	F
101	0354 0060Z	Philips Truss Head Screw - M4 x 6	
102	0353 0050Z	Philips Truss Head Screw - M3 x 5	
103	0314 0060B	Philips Pan Head Screw - M4 x 6	
104	0323 0060W	Philips Sunken Head Screw - M3 x 6	
105	0353 0050Z	Philips Truss Head Screw - M3 x 5	
106	0313 0060B	Philips Pan Head Screw - M3 x 6	
107	0313 0120B	Philips Pan Head Screw - M3 x 12	
108	0434 0050B	Hexagonal Head Tapping Screw - M4 x 5	



13. LOWER PAPER FEED UNIT I

June 01,'90

Index No.	Parts No.	Description	Model
1	H008 2423	Damper	
2	H008 2411	Lower Front Support	
3	H008 6008	PCB - LIB	
4	H008 5326	LIB Harness	
5	H008 5327	LIB 2 Harness	
6	H008 5329	LIB-4 Harness	
7	H008 5328	LIB 3 Harness	
8	H006 2831	Paper Lift Motor	
9	H006 2833	Paper Lift Motor Bracket	
10	5447 2805	Slide Pin Holder	
11	H006 2837	Gear - 60T/16T	
12	H006 2838	Gear - 55T/16T	
13	H006 2840	Gear Slide Spring	
14	H006 5255	Paper End Sensor - LCT	
15	H006 2845	Near - End Sensor	
16	H006 2960	Gear - 64T	
17	H006 2959	Bushing - M5	
18	H006 2958	Gear Support Plate	
19	5447 2681	Snap Ring	
20	5447 2726	Paper Feed Roller	
21	5447 2720	Gear - 18T	
22	5053 0223	Bushing - 8mm	
23	5447 2706	Gear - 15T	
24	H006 2897	Feed Roller Mylar	
25	H006 2895	Feed Roller Guide	
26	5447 2723	Pick-up Roller	
27	H006 2878	Feed Roller Arm - LCT	
28	H006 2873	One Way Gear - 24T	
29	H006 2871	Feed Roller Shaft - LCT	
30	H006 3676	CAM - Pressure Release Ass'y	
31	H006 2872	Bushing - M8/M4	
32	5447 2751	Feed Roller Hub - Ratchet	
33	H006 2847	Ratchet Sleeve - Paper Feed	
34	H000 2483	Spring Clutch	
35	H006 2824	Timing Pulley - 50T	


Index No.	Parts No.	Description	Model
36	H006 2829	Timing Belt - 300L	
37	H006 2823	Belt Tension Roller	
38	H006 2957	Plate Spring - Belt Tension	
39	H006 2821	Drive Motor Bracket	
40	H008 5327	LIB 2 Harness	
41	H006 2826	Timing Pulley - 18T	
42	H006 3674	Pressure Release Lever	
43	H006 5252	Drive Motor - LCT	
44	5447 2746	Spring - Paper Feed	
45	H008 5001	Paper Feed Solenoid	
46	5447 2743	Lever Spring	
47	5447 2745	Spring - CAM Catcher Slide	
48	5447 2737	CAM Catcher	
49	5447 2744	Spring - Paper Pick-up	
50	H006 2325	Solenoid Bracket	
51	H006 2949	Upper Guide Plate Ass'y - Paper Feed	
52	H006 2952	Rear Guide Mylar	
53	H006 2881	Feed Roller Bracket - LCT	
54	H006 2950	Upper Guide Plate - Paper Feed	
55	H006 2951	Front Guide Mylar	
56	5205 5250	L.E.D. Sensor Type S	
57	H008 5328	LIB 3 Harness	
58	H006 2869	End Detector Lever - LCT	
59	H006 2865	End Detector Bracket - LCT	
60	H006 2813	Right Stay	

Index No.	Parts No.	Description	Model
101	0314 0060B	Philips Pan Head Screw - M4 x 6	
102	0584 0061E	Bolt - M4 x 6	
103	0720 0040E	Retaining Ring - M4	
104	0720 0060E	Retaining Ring - M6	
105	0313 0050W	Philips Pan Head Screw - M3 x 5	
106	0314 0120B	Philips Pan Head Screw - M4 x 12	
107	0720 0050E	Retaining Ring - M5	
108	0804 3002	Parallel Key	
109	0314 0100B	Philips Pan Head Screw - M4 x 10	
110	0951 4008B	Philips Screw With Flat Washer - M4 x 8	

Index No.	Parts No.	Description	Model

14. LOWER PAPER FEED UNIT II

June 01,'90



14. LOWER PAPER FEED UNIT II


June01,'90

Index No.	Parts No.	Description	Model
1	H008 2467	Lower Left Stay	
2	5442 2751	Paper Feed Hub - Ratchet	
3	H006 2944	Roller - Pressure Spring	
4	H006 2884	Guide Plate - Drive Roller	
5	H006 2890	Front Lock Spring - Guide Plate	
6	H006 2888	Locking Bracket - Guide Plate - F	
7	H006 2886	Release Lever - Guide Plate Drive	
8	H006 2885	Shaft - Guide Plate Open	
9	H006 2872	Bushing - M8/M4	
10	H006 2882	Drive Roller	
11	H006 2889	Locking Bracket - Guide Plate - R	
12	H008 2402	Lower Rear Side Bracket	
13	5053 0419	Bushing - 10mm	
14	H006 2874	Idle Gear - 16T	
15	H006 2875	Middle Roller Gear - 16T	
16	H006 2887	Pressure Roller	
17	H006 2841	Paper Lift Shaft	
18	H006 2852	Rear Cassette Guide - Rear	
19	H006 2843	Pressure Arm - Paper Lift	
20	H006 2844	Cushion - Paper Lift Arm	
21	H006 2856	Guide Plate - Paper Feed LCT	
22	H006 2966	Separation Roller Arm - LCT	
23	H006 2967	Pressure Spring - S Roller	
24	H006 2860	Separation Roller Cover - LCT	
25	AW50 0001	Push Switch - Paper Size - 1	
26	H008 5329	LIB-4 Harness	
27	H006 2861	Separation Shaft - LCT	
28	5447 2695	Input Hub	
29	H006 2235	Cylindrical Spring	
30	5447 2676	Output Hub	
31	5447 2678	Slip Clutch Cover	
32	5447 2693	Separation Roller	
33	5447 2681	Snap Ring	
34	H008 2431	Lower Separation Roller Cover	
35	H008 5225	Lower Cassette Sensor	

Index No.	Parts No.	Description	Model
36	H006 2848	Cassette SW Bracket	
37	H006 2955	Guide Plate Cushion	
38	H008 2408	Lower Left Bracket	
39	H006 2851	Cassette Guide - Front	
40	H006 2854	Pin - Lever Cassette Detector	
41	H006 2855	Lever Spring - Cassette Detector	
42	H006 2853	Cassette Detector Lever	
43	H008 5227	Lower JAM Removal Switch	
44	H006 2921	Open Sensor Bracket - LCT	
45	H008 2433	Lower Edge Cover	
46	H008 2400	Lower Front Side Bracket	
47	H006 2842	Paper Lift Lever	
48	H006 2941	Rubber Foot - LCT	
49	H006 2801	LCT - Base	
101	0313 0060B	Philips Pan Head Screw - M3 x 6	
102	0720 0040E	Retaining Ring - M4	
103	0720 0060E	Retaining Ring - M6	
104	0314 0060B	Philips Pan Head Screw - M4 x 6	
105	0720 0080E	Retaining Ring - M8	
106	0965 4008W	Tapping Screw With Flat Washer - M4 x 8	
107	0313 0120B	Philips Pan Head Screw - M3 x 12	
108	0951 4008B	Philips Screw With Flat Washer - M4 x 8	
109	0720 0030E	Retaining Ring - M3	
110	1105 0005	Nylon Clip - 3N	

15. ACCESSORIES

June 01,'90




15. ACCESSORIES

Index No.	Parts No.	Description	Model
1	H000 4230	Seal - Remote Terminal	
2	H006 2689	Cleaning Pad	
3	H008 4321	User Function Key Card	UK, UN
3	H008 4329	User Function Key Card : R-G	G
3	H008 4326	User Function Key Card : R-I	I
3	H008 4328	User Function Key Card : R-F	F
4	H008 4334	Quick Dial List	UK, UN
4	H008 4335	Quick Dial List : R-G	G
4	H008 4336	Quick Dial List : R-I	I
4	H008 4337	Quick Dial List : R-F	F
5	H008 4406	Quick Reference Guide : R-G	G
5	H008 4458	Quick Reference Guide : R-UK, UN	UK, UN
5	H008 4407	Quick Reference Guide : R-I	I
5	H008 4408	Quick Reference Guide : R-F	F
6	H008 4012	Sub Document Table	
7	H008 4039	Document Tray	
8	H008 4042	Copy Tray	
9	H008 4376	Operator's Manual : R-G	
9	H008 4377	Operator's Manual : R-UK	UK
9	H008 4378	Operator's Manual : R-I	I
9	H008 4379	Operator's Manual : R-F	F
9	H008 4380	Operator's Manual : R-UK	UK
10	H008 4352	User Function List : R-G	G
10	H008 4470	User Function List : R-UK, UN	UK, UN
10	H008 4353	User Function List : R-I	I
10	H008 4354	User Function List : R-F	F
11	H035 4682	Ink - Red	
12	2801 0031	Power Cord	Except UK
12	H022 5002	Power Cord : UK	UK
13	H008 5247	Microphone	
14	H006 3638	Paper Size Detector Pin - B4	
15	H006 3640	Paper Size Detector Pin - Legal	
16	H006 3642	Paper Size Detector Pin - Letter	
17	H041 1505	Pick-up Roller	
18	H006 3663	Cassette Decal	

Index No.	Parts No.	Description	Model

16. PARTS FOR OPTIONAL KIT

June 01,'90



16. PARTS FOR OPTIONAL KIT

June 01,'90

Index No.	Parts No.	Description	Model
1	H302 5306	Harness: SPU - G4CCU (G4 Kit)	
2	H008 6050	PCB - G4CCU (G4 Kit)	
3	H008 6051	PCB - G4TMB (G4 Kit)	
4	H008 4442	G4TMB Cover Bracket (G4 Kit)	
5	H008 4373	G4TMB Cover (G4 Kit)	
6	H008 4035	Rear Right Cover - Bar Code Reader (Bar Code Reader Kit)	

Index No.	Parts No.	Description	Model

PARTS INDEX

Parts No.	Description	Page and Index No.
H008 1061	Scanner Cover Release Spring	5-25
H008 1100	Lens Ass'y	17-13
H008 1114	Lens Block	17-15
H008 1115	Lens Adjuster	17-14
H008 1116	Exposure Glass	7-20
H008 1117	Mirror Holder - Rear	7-25
H008 1118	Mirror Holder - Front	7-14
H008 1122	R1 Roller Pulley	7-27
H008 1123	Scanner Timing Pulley	11-11
H008 1125	R1 Idler	7-26
H008 1126	Scanner Timing Belt - Left	11-12
H008 1127	Scanner Timing Belt - Right	11-13
H008 1128	Scanner Motor Pulley	11- 9
H008 1129	Scanner Timing Pulley Bracket	11-10
H008 1132	Scanner Pressure Roller Shaft	5-51
H008 1133	R1 Pressure Roller	5-52
H008 1135	Scanner Pressure Roller	5-50
H008 1137	Feed Roller Frame	7-45
H008 1143	Scanner Clamp	7-42
H008 1143	Scanner Clamp	11- 2
H008 1143	Scanner Clamp	23-56
H008 1144	Feed Roller Shaft	7-38
H008 1150	Scanner Feed Roller	7-28
H008 1151	Scanner Pick-up Idler	7-32
H008 1152	Scanner Pick-up Hub	7-39
H008 1153	Scanner Pick-up Sleeve	7-41
H008 1156	Scanner Release Lever - Front	7-34
H008 1157	Scanner Release Lever - Rear	7-36
H008 1158	Scanner Release Shaft	7-35
H008 1159	Scanner Release Stopper	7-11
H008 1160	Scanner Lock Spring	7-13
H008 1167	Document Feed Out Plate	7- 1
H008 1171	Document Feed Out Stay	7-21
H008 1174	F.L. Guide Plate	7- 8
H008 1175	Scanner Hinge - Front	7-15

Parts No.	Description	Page and Index No.
H008 1179	Scanner Hinge - Rear	7-17
H008 1189	MDF Stay	5-19
H008 1190	Scanner Lock Collar	5-12
H008 1191	Scanner Lock Shaft	5-13
H008 1192	Scanner Release Pin	5-28
H008 1193	Scanner Release Bracket	5-29
H008 1194	Scanner Release Arm	5-26
H008 1195	MDF Button	5-17
H008 1196	MDF Spring	5-18
H008 1197	Scanner Release Spring	5-27
H008 1198	MDF Bracket - Lower	5-31
H008 1201	MDF Bracket - Upper	5-38
H008 1205	Separation Roller Spacer	5-43
H008 1206	Separation Roller Disc	5-44
H008 1207	Separation Pressure Shaft	5-39
H008 1208	Separation Pressure Adjuster	5-36
H008 1209	Separation Roller Hub - Front	5-41
H008 1210	MDF Release Shaft	5-30
H008 1211	MDF Release Arm	5-33
H008 1212	Separation Roller Bracket	5-40
H008 1213	Scanner Separation Roller	5-45
H008 1215	Separation Torque Spring	5-46
H008 1216	Separation Pressure Spring	5-35
H008 1217	MDF Release Spring	5-32
H008 1218	MDF Lock Spring	5-34
H008 1220	MDF Cover	5-11
H008 1221	Separation Roller Shaft	5-42
H008 1222	Separation Roller Hub - Rear	5-47
H008 1223	Separation Torque Spacer	5-48
H008 1224	Separation Pressure Spacer	5-37
H008 1232	Bar Code Cover Shaft	5- 1
H008 1233	Document Upper Plate	5-53
H008 1236	White Plate	5-58
H008 1237	Pressure Plate Shaft	5-57
H008 1239	Pressure Plate Spring - Front	5-54

Parts No.	Description	Page and Index No.
H008 1240	Pressure Plate Spring - Front	5-56
H008 1241	Scanner Cover Hinge - Rear	5-14
H008 1242	Scanner Cover Hinge - Front	5-24
H008 1243	Spring Plate	5-21
H008 1245	Paper Width Sensor Fence	7-48
H008 1248	S1 Sensor Fence	7-49
H008 1251	Antistatic Brush	7- 6
H008 1252	Scanner Antistatic Brush	5-49
H008 1253	Scanner Feed Bracket Spring	7-55
H008 1254	Scanner Clamper	3-21
H008 1254	Scanner Clamper	7-44
H008 1259	Bar Code Cover Clip - Front	5- 8
H008 1260	Bar Code Cover Clip - Middle	5- 2
H008 1261	Bar Code Cover Clip - Rear	5- 9
H008 1262	Bar Code Holder	5- 3
H008 1263	Bar Code Rear Hinge	5- 4
H008 1267	Spring Plate - R1 Pressure	5-22
H008 1278	Bar Code List - 1P	5- 6
H0081279	Bar Code List - 1P : R-G	5- 6
H0081280	Bar Code List - 1P : R-I	5- 6
H0081281	Bar Code List - 1P : R-F	5- 6
H0081282	Bar Code List - 2P	5- 7
H0081283	Bar Code List - 2P : R-G	5- 7
H0081284	Bar Code List - 2P : R-I	5- 7
H0081285	Bar Code List - 2P : R-F	5- 7
H0081295	Bar Code Cover	5- 5
H0081297	Bar Code Cover : R-I	5- 5
H0081298	Bar Code Cover : R-F	5- 5
H0081300	Bar Code Cover : R-G	5- 5
H0081308	R1 Roller	7-23
H0081309	R2 Roller	7-22
H0081324	Scanner Cover : R-G	5-15
H0081325	Scanner Cover : R-UK, UN	5-15
H0081326	Scanner Cover : R-I	5-15
H008 1327	Scanner Cover : R-F	5-15

Parts No.	Description	Page and Index No.
H0081332	Scanner Feed Bracket	7-33
H0081346	Document Guide Plate	7- 2
H0081349	Pressure Plate	5-55
H0081350	Lens Block Guard	17-50
H0082016	Paper Feed Clutch Ass'y	23-71
H0082017	Paper Lift Solenoid	23-72
H0082051	Registration Lower Guide Plate	15-27
H0082091	OPU Ass'y : R-I	3-49
H0082092	OPU Ass'y : R-F	3-49
H0082097	OPU Ass'y : R-G	3-49
H0082098	OPU Ass'y : R-UK, UN	3-49
H0082100	Lower Guide Plate	21-40
H0082102	Paper Exit Bracket	21- 4
H0082107	Fusing Rear Bracket	21-26
H0082112	Rear Fusing Bracket	21-38
H0082117	Exit Lower Guide Plate	21-13
H0082119	Fusing Lower Guide Plate	21-36
H0082120	Paper Exit Cover	21-31
H0082122	Fusing Pressure Spring	21-30
H0082123	Upper Exit Guide Ass'y	21- 3
H0082142	Paper Exit Guard	21-65
H0082146	Front Fusing Hook	21-25
H0082147	Rear Fusing Hook	21-39
H0082148	Thermostat Ass'y : E	21-49
H0082201	Front Protector	7-18
H0082205	Hinge Reinforcement Plate - Rear	9-15
H0082206	Harness Guide	7-46
H0082209	Front Earth Frame	9-38
H0082223	Rear Protector	7-19
H0082226	Document Tray	3- 6
H0082227	Sub Document Tray	3- 4
H0082228	Document Tray Bracket	3- 5
H0082230	Upper Base Reinforcement Bracket	11-14
H0082234	Fusing Interlock Bracket	9-39
H0082235	Hinge Reinforcement Plate - Rear	11- 6

Parts No.	Description	Page and Index No.
H008 2240	Upper Earth Plate	7- 9
H008 2243	Pentagonal Mirror Motor	9-37
H008 2244	Side Inner Cover	11-33
H008 2245	Rear Right Inner Cover	9-46
H008 2247	Rear Left Inner Cover	7-51
H008 2248	Master Drive Pulley Bracket	11-20
H008 2249	Document Table Bracket	11-31
H008 2252	Master Unit Interlock	11-39
H008 2255	UIB Cover	11- 5
H008 2258	Master Drive Gear - Z23	11-30
H008 2264	Inner Cover - LO Unit	9-14
H008 2266	SMDR Cover	9-47
H008 2268	F.L. Inner Cover	9-42
H008 2269	Scanner Inner Cover	7-50
H008 2270	Scanner Timing Belt Inner Cover	7-31
H008 2271	Master Drive Arm	11-29
H008 2282	Document Tray Hinge	3- 7
H008 2286	Master Drive Motor	11-18
H008 2287	Interlock Spring	9-40
H008 2290	Master Unit Decal : F	11-35
H008 2291	Front Right Inner Cover	9-43
H008 2292	Front Right Inner Cover : G	9-43
H008 2293	Front Right Inner Cover : I	9-43
H008 2294	Front Right Inner Cover : F	9-43
H008 2302	Upper Base Cover	11- 1
H008 2303	Cover - Second Cy. Lens Ass'y	9-44
H008 2400	Lower Front Side Bracket	29-46
H008 2402	Lower Rear Side Bracket	29-12
H008 2404	Lower Rear Right Support	25- 8
H008 2405	Lower Rear Left Support	25- 5
H008 2408	Lower Left Bracket	29-38
H008 2411	Lower Front Support	27- 2
H008 2413	Lower Front Right Cover	25-12
H008 2414	Lower Front Left Cover	25-25
H008 2415	Lower Right Cover	25-11

Parts No.	Description	Page and Index No.
H008 2417	Lower Rear Cover	25- 9
H008 2418	Lower Right Support Bracket	25-15
H008 2419	Lower Light Support Bracket	25-19
H008 2420	Lower Left Inner Cover	25-22
H008 2423	Damper	25- 6
H008 2423	Damper	27- 1
H008 2424	Lower Cover Hinge Bracket	25-20
H008 2427	Lower Harness Cover: 1	25-24
H008 2428	Lower Cover Hinge Cover	25-26
H008 2431	Lower Separation Roller Cover	29-34
H008 2432	Lower Base Support	25-17
H008 2433	Lower Edge Cover	29-45
H008 2434	Lower Harness Cover: 2	25- 4
H008 2435	Lower Right Cover Bracket	25-10
H008 2436	Lower Left Holder	25-27
H008 2437	Lower Right Holder	25-28
H008 2452	Lower Jam Removal Decal	25-21
H008 2453	Lower Jam Removal Decal : G	25-21
H008 2454	Lower Jam Removal Decal : I	25-21
H008 2455	Lower Jam Removal Decal : F	25-21
H008 2456	Lower Left Cover	25- 1
H008 2457	Lower Left Cover : R-G	25- 1
H008 2458	Lower Left Cover : R-I	25- 1
H008 2459	Lower Left Cover : R-F	25- 1
H008 2467	Lower Left Stay	29- 1
H008 3100	Base	23-25
H008 3101	Front Bracket	23- 6
H008 3111	Drive Gear - Z23	23-60
H008 3112	Idler Gear - Z44, Z16	23-42
H008 3113	Printer Fan	21-58
H008 3117	Joint Bracket	23-26
H008 3118	Lower Front Left Joint Bracket	25-29
H008 3119	Lower Front Right Joint Bracket	25-13
H008 3120	Lower Rear Joint Bracket	25- 7
H008 3122	PCB Securing Screw	19-10

Parts No.	Description	Page and Index No.
H008 3123	Rear Side Bracket	19-73
H008 3130	Transport Bracket	23-38
H008 3132	Main Drive Shaft	23-40
H008 3133	Paper Feed Clutch Bushing	23-64
H008 3134	Paper Feed Gear	23-68
H008 3135	Front HD Bracket	23-19
H008 3136	Rear HD Bracket	23-16
H008 3137	Hard Disk Spacer	23-17
H008 3138	DRU Bracket	23-14
H008 3144	Fusing Front Inner Cover	21-21
H008 3146	Fusing Interlock Lever	21-22
H008 3148	Rear Fulcrum Pin Bracket	23-45
H008 3156	Lens Block Inner Cover	17-22
H008 3161	PSU Case	23-21
H008 3167	PSU Stay	23-15
H008 3168	HD Joint Bracket	23-82
H008 3169	Hard Disk Clamper	23-24
H008 3172	Transfer Front Holder	19-44
H008 3173	Transfer Rear Holder	19-43
H008 3174	Fusing Support Pin	17-23
H008 3174	Fusing Support Pin	23-37
H008 3175	Fusing Front Guide Bracket	23-31
H008 3176	Registration Harness Clamper	19-48
H008 3177	Copy Tray Bracket	23-36
H008 3178	Rubber Foot	23-83
H008 3179	Small Clamp	23-30
H008 3181	Fusing Side Stay	21-20
H008 3182	Front Fulcrum Pin	23- 8
H008 3184	Gas Spring Boss	23- 1
H008 3185	OPU Left Reinforcement Stay	19-22
H008 3186	OPU Reinforcement Stay Bracket	19-23
H008 3187	Fusing Rear Inner Cover	21-19
H008 3188	OPU Left Stay	19-21
H008 3189	OPU Right Stay	17-26
H008 3190	PCB Shield Cover	19- 3

Parts No.	Description	Page and Index No.
H008 3191	PCB Shield Stay	19- 1
H008 3192	OPU Left Bracket	3-48
H008 3193	OPU Right Bracket	3-47
H008 3194	Speaker Bracket	19- 4
H008 3195	NCU Shield Cover : E	17- 8
H008 3201	Gas Spring	23- 4
H008 3202	Registration Drive Gear	23-66
H008 3204	Development Drive Shaft	23-69
H008 3205	Development Clutch Stopper	23-57
H008 3206	Paper Lift Sector Gear	23-28
H008 3211	Main Drive Belt	23-65
H008 3212	Transport Guide Plate	21-61
H008 3274	SCU Shield Cover	19-18
H008 3219	SPU Shield Cover	19- 9
H008 3223	Development Inner Cover Screw	3-39
H008 3224	Development Inner Cover	3-40
H008 3225	Clamper Bracket	23-55
H008 3230	Upper Base Interlock Lever	23- 9
H008 3231	Front Right Joint Bracket	23-22
H008 3232	Gas Spring Bushing	23- 2
H008 3233	Gas Spring Washer	23- 3
H008 3234	Drive Pulley - 224	23-63
H008 3236	Tightener	23-53
H008 3238	Tightener Pulley	23-52
H008 3245	NCU Small Cover	17- 9
H008 3247	Main Drive Idler - 251	23-41
H008 3249	Shield Cover Earth Plate	19-59
H008 3250	Shield Stay Earth Plate	19-60
H008 3251	Shield Stay Lower Earth Plate	19-61
H008 3252	PCB Fan Seal	19-58
H008 3254	Fusing Interlock Spring	21-23
H008 3256	Fusing Front Stopper	19-45
H008 3257	Fusing Rear Stopper	19-32
H008 3260	Lens Block Stay	17-20
H008 3268	Front G4 Connector Bracket	19-64

Parts No.	Description	Page and Index No.
H008 3269	Rear G4 Connector Bracket	19-69
H008 3270	Harness Guide	23-73
H008 3273	Large Clamp	23-34
H008 3300	Paper Feed Front Bracket	15-59
H008 3304	Paper Feed Rear Bracket	15-42
H008 3309	Lower Registration Roller	15-29
H008 3310	Pick-up Roller Bracket	15-15
H008 3312	Feed Roller Shaft	15-17
H008 3313	Pick-up Roller Sleeve	15-18
H008 3315	Pick-up Roller Boss	15-20
H008 3316	Feed Roller Spring	15-19
H008 3317	Pick-up Shaft Bracket	15-13
H008 3318	Pick-up Roller Spring	15-14
H008 3319	Pick-up Stay Bracket	15- 5
H008 3323	Paper Lift Shaft	15-56
H008 3324	Sector Gear Support Bracket	23-29
H008 4001	Front Right Cover	3-41
H008 4003	Document Table	5-62
H008 4004	Upper Exit Cover	3- 2
H008 4005	Fusing Exit Cover	21- 1
H008 4012	Sub Document Table	3-25
H008 4012	Sub Document Table	31- 6
H008 4013	Document Guide Rack	5-63
H008 4015	Rear Document Guide	5-60
H008 4016	Document Guide Base	5-66
H008 4017	Right Cover Knob	3-33
H008 4018	Right Cover Lever	3-32
H008 4019	Right Cover Fulcrum Pin	3-38
H008 4022	Right Fulcrum Pin Bracket	3-34
H008 4023	Right Lever Front Bracket	3-37
H008 4025	Right Cover Earth Plate	3-35
H008 4026	Right Cover Spring Plate	3-29
H008 4027	Right Lever Rear Bracket	3-30
H008 4029	Q.R.G. Inner Cover	3-44
H008 4030	Q.R.G. Catcher	3-43

Parts No.	Description	Page and Index No.
H008 4030	Q.R.G. Catcher	25-16
H008 4031	Exit Front Cover	3- 1
H008 4032	Exit Rear Cover	3- 3
H008 4034	Upper Base Open Button	17-10
H008 4035	Rear Right Cover - Bar Code Reader (Bar Code Reader Kit)	33- 6
H008 4039	Document Tray	3-57
H008 4039	Document Tray	31- 7
H008 4040	Right Cover Spring	3-36
H008 4042	Copy Tray	3-26
H008 4042	Copy Tray	31- 8
H008 4043	LCD Brightness Pin Bracket	3-19
H008 4045	Right Cover Stepped Screw	3-55
H008 4046	Rear Small Cover	3-60
H008 4047	Rear Small Cover Bracket	3-12
H008 4049	Rubber Cap - M3	3-46
H008 4049	Rubber Cap - M3	25- 3
H008 4050	BSRU Bracket	17-51
H008 4052	Harness Exit Cover	3-23
H008 4060	Right Cover	3-28
H008 4062	Q.R.G. Catcher Plate	25-23
H008 4066	Right Cover Lever	17-24
H008 4074	Front Document Guide	5-59
H008 4075	Front Document Guide : R-G	5-59
H008 4076	Front Document Guide : R-I	5-59
H008 4077	Front Document Guide : R-F	5-59
H008 4083	Toner Replacement Decal	3-31
H008 4100	Front Cover	3-45
H008 4159	Upper Right Cover	3-22
H008 4161	Right Upper Cover	3-24
H008 4165	NCU Cover : R	3-17
H008 4172	Brightness Adjustment Decal	3-18
H008 4173	Brightness Adjustment Decal : R-G	3-18
H008 4174	Brightness Adjustment Decal : R-I	3-18
H008 4175	Brightness Adjustment Decal : R-F	3-18

Parts No.	Description	Page and Index No.
H008 4321	User Function Key Card	31- 3
H008 4326	User Function Key Card : R-I	31- 3
H008 4328	User Function Key Card : R-F	31- 3
H008 4329	User Function Key Card : R-G	31- 3
H008 4334	Quick Dial List	31- 4
H008 4335	Quick Dial List : R-G	31- 4
H008 4336	Quick Dial List : R-I	31- 4
H008 4337	Quick Dial List : R-F	31- 4
H008 4352	User Function List : R-G	31-10
H008 4353	User Function List : R-I	31-10
H008 4354	User Function List : R-F	31-10
H008 4373	G4TMB Cover (G4 Kit)	33- 5
H008 4376	Operator's Manual : R-G	31- 9
H008 4377	Operator's Manual : R-UK	31- 9
H008 4378	Operator's Manual : R-I	31- 9
H008 4379	Operator's Manual : R-F	31- 9
H008 4380	Operator's Manual : R-UK	31- 9
H008 4406	Quick Reference Guide : R-G	3-52
H008 4406	Quick Reference Guide : R-G	31- 5
H008 4407	Quick Reference Guide : R-I	3-52
H008 4407	Quick Reference Guide : R-I	31- 5
H008 4408	Quick Reference Guide : R-F	3-52
H008 4408	Quick Reference Guide : R-F	31- 5
H008 4428	Switch Decal : R-G	3-27
H008 4428	Switch Decal : R-G	25- 2
H008 4442	G4TMB Cover Bracket (G4 Kit)	33- 4
H008 4445	Rear Left Cover : R	3- 8
H008 4446	Rear Left Cover Support : E	3- 9
H008 4449	Rear Cover	3-14
H008 4454	Microphone Jack Bracket : E	3-10
H008 4458	Quick Reference Guide : R-UK, UN	3-52
H008 4458	Quick Reference Guide : R-UK, UN	31- 5
H008 4470	User Function List : R-UK, UN	31-10
H008 4474	Switch Decal	3-27
H008 4474	Switch Decal	25- 2

Parts No.	Description	Page and Index No.
H008 4478	Caution Decal - PSU : F	21-64
H008 4532	Upper Cassette Decal	3-50
H008 4535	Upper Cassette Decal : R-G	3-50
H008 4538	Upper Cassette Decal : R-I	3-50
H008 4541	Upper Cassette Decal : R-F	3-50
H008 4544	Lower Cassette Decal	25-30
H008 4547	Lower Cassette Decal : R-G	25-30
H008 4550	Lower Cassette Decal : R-I	25-30
H008 4553	Lower Cassette Decal : R-F	25-30
H008 4560	Plate Spring - Pinion	5-64
H008 5001	Paper Feed Solenoid	27-45
H008 5200	Hard Disk Unit	23-20
H008 5205	Fusing Connector	21-62
H008 5207	Copy Out Sensor	23-35
H008 5208	Registration Clutch	23-67
H008 5210	Front Transfer Fan	19-51
H008 5211	Rear Transfer Fan	19-49
H008 5212	Master Unit Fan Motor	19-27
H008 5213	Development Clutch	23-70
H008 5215	SPU Fan	19- 2
H008 5216	Speaker	19- 5
H008 5217	Paper Feed Clutch	7-37
H008 5218	R2 Clutch	7-24
H008 5219	Scanner Stepping Motor	11- 7
H008 5221	S2 Sensor	7-43
H008 5222	Fluorescent Lamp	9-41
H008 5223	F.L. Stabilizer	9-34
H008 5225	Lower Cassette Sensor	29-35
H008 5226	Lower Cover Open Switch	25-18
H008 5227	Lower JAM Removal Switch	29-43
H008 5230	LCD Adjuster	3-20
H008 5232	Eraser Unit	11-51
H008 5237	Stamper	7- 7
H008 5240	Scanner Motor Driver	9-33
H008 5244	Fusing Lamp : E	21-53

Parts No.	Description	Page and Index No.
H0085247	Microphone	31-13
H0085248	Fusing Thermistor : E	21-46
H0085301	SCU-2 Harness	19-20
H0085302	SPU-1 Harness	19-11
H0085304	HD-20 Harness	23-77
H0085305	HD-34 Harness	23-78
H0085306	C-1 Harness	15-55
H0085308	PSU-2 Harness	23-79
H0085310	SBU Harness	19-15
H0085311	DRU-3 Harness	23-13
H0085312	VIB-3 Harness	11-52
H0085313	R - Sensor Harness	19-46
H0085316	LDDR Harness	9-48
H0085317	VIB-1 Harness	11-46
H0085318	Pentagonal Dr. Harness	11-53
H0085319	MDF Harness	5-67
H0085319	MDF Harness	7-53
H0085320	DSB-3 Harness	7-52
H0085321	Interlock Harness	19- 7
H0085321	Interlock Harness	23-80
H0085325	G3 CCU - NCU Harness	19-62
H0085326	LIB Harness	27- 4
H0085327	LIB 2 Harness	27- 5
H0085327	LIB 2 Harness	27-40
H0085328	LIB 3 Harness	27- 7
H0085328	LIB 3 Harness	27-57
H0085329	LIB-4 Harness	27- 6
H0085329	LIB-4 Harness	29-26
H0085331	Harness: G4I-TMB	19-67
H0085331	Harness - G4I - TMB	23- 5
H0085332	LCP-5 Harness	3-58
H0085333	SPU-4 Harness	19-63
H0085334	Paper Harness	17- 2
H0085342	Handset-2 Harness	17- 6
H0085344	Bar Code Reader Harness	19-74

Parts No.	Description	Page and Index No.
H008 5347	PSU-14 Harness	23-81
H008 5348	PSU-15 Harness	23-62
H008 5360	Microphone Jack Harness : E	3-11
H008 5361	Microphone-CCU Harness : E	3-13
H008 5361	Microphone - CCU Harness : E	19-17
H008 5362	Scanner Cover Earth Wire	5-68
H008 5362	Scanner Cover Earth Wire	7-54
H008 5363	DRU-1 Harness : E	23-11
H008 5364	Thermostat Harness : E	21-45
H008 5365	Scanner Cover Earth Wire : UK	5-68
H008 5370	Harness: G4CCU-G4TMB	19-66
H008 5401	PCB - PSU : E	23-18
H008 6000	PCB - SCU	19-19
H008 6004	PCB - DSB	7-47
H008 6005	PCB - DRU	23-12
H008 6006	PCB - SBU	17-16
H008 6007	PCB - VPU	19-14
H008 6008	PCB - LIB	27- 3
H008 6009	PCB - R-Sensor	19-47
H008 6012	PCB -Modem (MMD 9624)	19-12
H008 6013	PCB - MDF	5-16
H008 6017	PCB - BSRU	17-52
H008 6023	PCB - UIB	11- 4
H008 6031	PCB - MBU : R-G	19-24
H008 6032	PCB - MBU : R-UK	19-24
H008 6033	PCB - MBU : R-I	19-24
H008 6034	PCB - MBU : R-F	19-24
H008 6035	PCB - MBU : R-UN	19-24
H008 6041	PCB - SPU	19-16
H008 6042	PCB - G3 CCU : E	19-13
H008 6046	PCB - G3NCU : E	17- 7
H008 6050	PCB - G4CCU (G4 Kit)	33- 2
H008 6051	PCB - G4TMB (G4 Kit)	33- 3
H008 6052	Front G4 Connector	19-65
H008 6053	Rear G4 Connector	19-68

Parts No.	Description	Page and Index No.
H000 2483	Spring Clutch	27-34
H0002508	F1 Lens	9- 3
H0002509	F2 Lens	9- 4
H0002514	Holder - First Cylindrical Lens	9-35
H0002516	Right Mirror Holder	9-13
H0002517	Left Mirror Holder	9-11
H0003292	Saddle Edge	11- 3
H0003332	Bushing	11-22
H0003332	Bushing	23-32
H0004230	Seal - Remote Terminal	31- 1
H0011134	Torque Spring -'011.6	7-40
H0012109	Damper - RX Motor	11- 8
H0013736	Clamper - Speaker	19- 6
H0061011	Scanner Mirror	7-10
H0061015	SBU Adjustment Knob	17-17
H0061119	Bushing - Cover Open	7- 5
H0061120	Cover Open Pin	7- 3
H0061121	Cover Open Spring	7- 4
H0061149	Lever - Document Width Sensor	5-23
H0061190	Sensor Base	5-20
H0061194	Shield Plate - Laser Section	9-49
H0062042	Laser Diode Unit	9-10
H0062050	Development Hopper Ass'y	17-27
H0062051	Hopper Ass'y	17-37
H0062070	Transfer Front Guide Plate	15-28
H0062109	Front Fusing Bushing	21-27
H0062110	Hot Roller	21-52
H0062111	Rear Fusing Bushing	21-41
H0062112	Pressure Roller	21-55
H0062113	Pressure Roller Bushing	21-54
H0062131	Stripper Spring	21- 5
H0062134	Fusing Exit Roller	21-18
H0062135	Bushing - M 4 x 6	21- 6
H0062140	Front Heater Holder	21-28
H0062142	Rear Heater Holder	21-43

Parts No.	Description	Page and Index No.
H006 2145	Exit Sensor Slit	21-35
H006 2148	Exit Sensor Actuator	21-32
H006 2149	Exit Sensor Shaft	21-34
H006 2151	Exit Roller Holder	21-15
H006 2152	Lower Exit Roller	21-14
H006 2154	Exit Antistatic Brush	21-16
H006 2170	Feed Out Hook	21-11
H006 2171	Exit Stepped Screw	21-12
H006 2172	Holder - Feed Out Spring	21-10
H006 2173	Stripper Release Spring	21- 9
H006 2176	Exit Interlock Lever	21-17
H006 2180	Fusing Gear - T35	21-42
H006 2181	Idle Gear - T19	21-37
H006 2182	Exit Gear - T19	21- 7
H006 2190	Fusing Entrance Mylar	21-51
H006 2235	Cylindrical Spring	29-29
H006 2320	Bottom Plate - Cassette Ass'y	13- 2
H006 2322	Cassette	13-10
H006 2325	Solenoid Bracket	27-50
H006 2345	Fan Drive Pulley - Middle	23-46
H006 2371	Paper Guide Pad Ass'y	15-30
H006 2380	Used Toner Sensor Bracket	9-31
H006 2400	Development Antistatic Brush	17-35
H006 2401	Hopper Agitator	17-29
H006 2404	Toner Supply Roller Ass'y	17-31
H006 2407	Toner End Lever	17-44
H006 2409	Toner Metering Blade Ass'y	17-32
H006 2418	Antistatic Brush Cover	17-34
H006 2419	Agitator Idle Gear	17-43
H006 2420	Rear Development Cover	17-45
H006 2428	Agitator Gear	17-48
H006 2429	Sleeve Gear	17-41
H006 2431	Sleeve Idle Gear	17-39
H006 2432	Toner Supply Gear	17-40
H006 2433	Front Development Gear	17-42

Parts No.	Description	Page and Index No.
H006 2437	Developing Roller	17-28
H006 2438	Front Side Plate - Development	17-36
H006 2443	Rear Side Plate - Development	17-38
H006 2450	Transfer Corona Ass'y	19-31
H006 2451	Housing - Transfer	19-35
H006 2452	Transfer Ventilation Guide	19-30
H006 2456	Transfer Guide Spring	19-52
H006 2457	Spring Holder	11-21
H006 2471	Fan Belt Tightener	23-47
H006 2473	Front Spring Plate - Fan Motor	21-56
H006 2479	Tightener Spring	23-54
H006 2506	Synchronizer Holder	11-49
H006 2507	Mirror	9-12
H006 2508	First Synchronizer Mirror	9- 8
H006 2509	Second Synchronizer Mirror	9- 6
H006 2510	First Cylindrical Lens	9-36
H006 2513	Holder - Second Synchronizer Mirror	9- 5
H006 2518	Top F. Lens Holder	9- 2
H006 2530	Lock Pin Collar - Upper Base	23-61
H006 2554	Holder - First Synchronizer Mirror	9- 7
H006 2556	Front F. Lens Holder	9- 9
H006 2557	Second Cylindrical Lens - Ass'y	11-47
H006 2677	Rear End Block - Charge	9-27
H006 2678	Front End Block - Charge	9-23
H006 2679	Charge Wire Hook	9-29
H006 2681	Front End Cover - Charge	9-24
H006 2683	Front End Block - Transfer	19-40
H006 2684	Front End Cover - Transfer	19-38
H006 2687	Rear End Block - Transfer	19-34
H006 2688	Rear End Cover - Transfer	19-33
H006 2689	Cleaning Pad	21-63
H006 2689	Cleaning Pad	31- 2
H006 2727	Thermostat Bracket : E	21-48
H006 2728	Thermostat Case : E	21-50
H006 2729	Upper Fusing Stay : E	21-47

Parts No.	Description	Page and Index No.
H006 2801	LCT - Base	29-49
H006 2813	Right Stay	27-60
H006 2821	Drive Motor Bracket	27-39
H006 2823	Belt Tension Roller	27-37
H006 2824	Timing Pulley - 50T	27-35
H006 2826	Timing Pulley - 18T	27-41
H006 2829	Timing Belt - 300L	27-36
H006 2831	Paper Lift Motor	27- 8
H006 2833	Paper Lift Motor Bracket	27- 9
H006 2837	Gear - 60T/16T	27-11
H006 2838	Gear - 55T/16T	27-12
H006 2840	Gear Slide Spring	27-13
H006 2841	Paper Lift Shaft	29-17
H006 2842	Paper Lift Lever	29-47
H006 2843	Pressure Arm - Paper Lift	29-19
H006 2844	Cushion - Paper Lift Arm	29-20
H006 2845	Near - End Sensor	27-15
H006 2847	Ratchet Sleeve - Paper Feed	27-33
H006 2848	Cassette SW Bracket	29-36
H006 2851	Cassette Guide - Front	29-39
H006 2852	Rear Cassette Guide - Rear	29-18
H006 2853	Cassette Detector Lever	29-42
H006 2854	Pin - Lever Cassette Detector	29-40
H006 2855	Lever Spring - Cassette Detector	29-41
H006 2856	Guide Plate - Paper Feed LCT	29-21
H006 2860	Separation Roller Cover - LCT	29-24
H006 2861	Separation Shaft - LCT	29-27
H006 2865	End Detector Bracket - LCT	27-59
H006 2869	End Detector Lever - LCT	27-58
H006 2871	Feed Roller Shaft - LCT	27-29
H006 2872	Bushing - M8/M4	27-31
H006 2872	Bushing - M8/M4	29- 9
H006 2873	One Way Gear - 24T	27-28
H006 2874	Idle Gear - 16T	29-14
H006 2875	Middle Roller Gear - 16T	29-15

Parts No.	Description	Page and Index No.
H006 2878	Feed Roller Arm - LCT	27-27
H006 2881	Feed Roller Bracket - LCT	27-53
H006 2882	Drive Roller	29-10
H006 2884	Guide Plate - Drive Roller	29- 4
H006 2885	Shaft - Guide Plate Open	29- 8
H006 2886	Release Lever - Guide Plate Drive	29- 7
H006 2887	Pressure Roller	29-16
H006 2888	Locking Bracket - Guide Plate - F	29- 6
H006 2889	Locking Bracket - Guide Plate - R	29-11
H006 2890	Front Lock Spring - Guide Plate	29- 5
H006 2895	Feed Roller Guide	27-25
H006 2897	Feed Roller Mylar	27-24
H006 2921	Open Sensor Bracket - LCT	29-44
H006 2941	Rubber Foot - LCT	29-48
H006 2944	Roller - Pressure Spring	29- 3
H006 2949	Upper Guide Plate Ass'y - Paper Feed	27-51
H006 2950	Upper Guide Plate - Paper Feed	27-54
H006 2951	Front Guide Mylar	27-55
H006 2952	Rear Guide Mylar	27-52
H006 2955	Guide Plate Cushion	29-37
H006 2957	Plate Spring - Belt Tension	27-38
H006 2958	Gear Support Plate	27-18
H006 2959	Bushing - M5	27-17
H006 2960	Gear - 64T	27-16
H006 2966	Separation Roller Arm - LCT	29-22
H006 2967	Pressure Spring - S Roller	29-23
H006 2972	Cassette Bottom Plate	13-15
H006 2976	Rear Fence	13-18
H006 2977	Paper Check Decal	13-21
H006 2979	Front Side Fence	13-16
H006 2982	Rear Fence - Cassette	13-19
H006 3051	Tightner Master Belt - Ass'y	11-16
H006 3221	Interlock SW Bracket	19- 8
H006 3243	Ozone Filter	21-59
H006 3247	Fusing Support Bracket - Rear	21-44

Parts No.	Description	Page and Index No.
H006 3248	Fusing Support Bracket - Front	21-29
H006 3269	Upper Base Guide	17-25
H006 3271	Interlock Fusing Roller	21-24
H006 3279	Spring Clamp - Pressure Upper Base	15-62
H006 3279	Spring Clamp - Pressure Upper Base	23-59
H006 3280	Spring - Pressure Upper Base	15-61
H006 3280	Spring - Pressure Upper Base	23-58
H006 3281	Rear Guide Rail - Development	15-40
H006 3285	Front Guide Rail - Development	15- 8
H006 3286	Development Bias Terminal	15- 9
H006 3287	Bracket - Front Pressure Upper Base	15-63
H006 3288	Bias Block - Charge	19-54
H006 3312	Transfer Pressure Spring	19-42
H006 3324	Printer Fan Front Seal	21-60
H006 3325	Printer Fan Rear Seal	21-57
H006 3326	DRU Cover	19-53
H006 3336	Lens Block Stay Clamper	17-21
H006 3352	Fusing Idle Gear - T33	23-44
H006 3363	Front Bracket - Transfer Fan	19-55
H006 3364	Spring - Transport Fusing Bracket	23-43
H006 3365	Rear Bracket - Transfer Fan	19-50
H006 3366	Development Drive Gear - T24	23-33
H006 3374	Fan Drive Pulley - Small	23-48
H006 3376	Fan Drive Pulley - Large	23-50
H006 3377	Fan Drive Belt	23-51
H006 3380	Master Drive Belt	11-19
H006 3381	Master Drive Bracket	11-17
H006 3384	Idle Gear - Master Drive - T20	11-15
H006 3385	Pulley - Master Unit Drive	11-23
H006 3388	Master Drive Shaft	11-24
H006 3389	Master Drive Gear - T16	11-28
H006 3398	Arm Bushing - Master Drive	11-26
H006 3405	Rear Master Unit Rail	11-27
H006 3406	Front Master Unit Rail	11-41
H006 3407	Bias Terminal - Charge	11-40

Parts No.	Description	Page and Index No.
H006 3408	Upper Base Hook	11-34
H006 3409	Front Hook Pin	11-38
H006 3419	Earth Plate - Charge	9-19
H006 3420	Master Earth Plate	11-25
H006 3421	Pressure Arm - Drive Pulley	11-42
H006 3422	Master H.P. Sensor Bracket	11-44
H006 3438	Hook Spring	11-37
H006 3439	Charge Corona Unit Duct	9-20
H006 3444	Varistor	9-16
H006 3446	Upper Base Holder	11-32
H006 3451	Housing Charge Ass'y	9-26
H006 3453	Under Holder - Second Cy. Lens	9-21
H006 3458	Charger Corona Unit	9-22
H006 3460	Pressure Arm Spring	11-43
H006 3530	Idle Gear - 15T	15-10
H006 3531	Pick-up Roller	15-11
H006 3532	Feed Roller	15- 6
H006 3533	Snap Ring	15- 7
H006 3541	Stopper Bracket	15-39
H006 3545	Release Lever - Paper Lift	15-38
H006 3549	Release Spring - Paper Lift	15-37
H006 3550	Ratchet Pawl Pin	15-33
H006 3551	Stopper Pawl	15-32
H006 3552	Ratchet Spring	15-34
H006 3558	Sector Gear Lock	15-41
H006 3559	Tray Lift Arm	15-57
H006 3560	Paper Feed Guide	15-31
H006 3565	Separation Roller Shaft	15-47
H006 3566	Separation Roller	15-46
H006 3567	Torque Limiter Clutch	15-45
H006 3568	Torque Limiter Cover	15-44
H006 3569	Torque Limiter Spring	15-49
H006 3570	Separation Roller Stopper	15-48
H006 3571	Separation Roller Bracket	15-50
H006 3572	Separation Roller Shaft	15-51

Parts No.	Description	Page and Index No.
H006 3573	Separation Roller Spring	15-53
H006 3574	Front Cassette Guide	15-60
H006 3575	Rear Cassette Guide	15-43
H006 3579	Stay - Paper Sensor Board	17- 4
H006 3584	Registration Arm	15-25
H006 3586	Registration Roller	15-23
H006 3587	Spring - Upper Guide Plate	15-21
H006 3588	Hold Spring - Upper Guide Plate	15-24
H006 3600	Mylar - Feed	17- 5
H006 3607	Release Pin Slider	15-36
H006 3619	Registration Upper Guide Plate	15-26
H006 3623	Paper Sensor Sheet	17- 3
H006 3638	Paper Size Detector Pin - B4	13- 3
H006 3638	Paper Size Detector Pin - B4	31-14
H006 3640	Paper Size Detector Pin - Legal	13- 5
H006 3640	Paper Size Detector Pin - Legal	31-15
H006 3641	Paper Size Detector Pin - A4	13- 4
H006 3642	Paper Size Detector Pin - Letter	13- 7
H006 3642	Paper Size Detector Pin - Letter	31-16
H006 3645	Front Stay - Feed Shaft	15- 2
H006 3645	Front Stay - Feed Shaft	15- 4
H006 3648	Feed Shaft Stay	15- 1
H006 3660	Cover - Development Interlock	19-57
H006 3662	Cover - Pick-up Roller Stay	15-16
H006 3663	Cassette Decal	13-11
H006 3663	Cassette Decal	31-18
H006 3665	Front Side Fence	13- 9
H006 3666	Rear Side Fence	13-14
H006 3671	Separation Roller Bracket	15-52
H006 3674	Pressure Release Lever	27-42
H006 3676	CAM - Pressure Release Ass'y	27-30
H006 3693	Roller - Upper Base Open	17-11
H006 3702	Upper Base Spring	17-12
H006 3751	Master Interlock Lever	15- 3
H006 3754	Master Interlock Support	15-65

Parts No.	Description	Page and Index No.
H006 3755	Master Interlock Spring	15-64
H006 3756	Master Lock Slider	11-55
H006 3757	Sector Gear - Master Lock	11-54
H006 3758	Slider Spring	11-56
H006 3760	Master Unit Decal	11-35
H006 3772	Master Unit Decal : G	11-35
H006 3773	Master Unit Decal : I	11-35
H006 4128	Fun Motor Nut	19-29
H006 4135	Fan Motor Duct	19-28
H006 4252	Caution Decal - PSU	21-64
H006 4256	Stepped Screw - Development Cover	23-76
H006 4408	Caution Decal - PSU : G	21-64
H006 4409	Caution Decal - PSU : I	21-64
H006 4523	CS Stopper	7-16
H006 4643	Transfer Corona Ass'y : UK	19-31
H006 5041	High Voltage Cable	19-41
H006 5042	Earth Wire - Transfer	19-37
H006 5205	High Voltage Cord - C	9-30
H006 5207	Paper Sensor Ass'y	17- 1
H006 5208	Toner End Sensor	17-19
H006 5220	Main Motor	23-49
H006 5222	Power Pack	19-56
H006 5252	Drive Motor - LCT	27-43
H006 5255	Paper End Sensor - LCT	27-14
H006 5602	Power Pack : UK	19-56
H006 5603	Earth Wire - Transfer : UK	19-37
H006 6001	PCB - LSD	11-48
H006 9001	Hot Roller Stripper (5Pcs)	21- 8
H009 4100	Rear Right Cover	3-16
H020 3827	F. Lens Bracket Ass'y	9- 1
H020 4087	Cassette - LCT	13-20
H020 4092	Cassette Cover	13- 1
H022 5002	Power Cord : UK	31-12
H035 4682	Ink - Red	31-11
H041 1505	Pick-up Roller	31-17

Parts No.	Description	Page and Index No.
H0411567	Pick-up Roller: ADF	7-30
H3025306	Harness: SPU - G4CCU (G4 Kit)	33- 1

Parts No.	Description	Page and Index No.
AW50 0001	Push Switch - Paper Size 1	15-54
AW50 0001	Push Switch - Paper Size - 1	29-25
G000 1945	LSD Cylindrical Lens	11-50

Parts No.	Description	Page and Index No.
5052 0269	Bushing - 4.2mm	21-33
5053 0223	Bushing - 8mm	27-22
5053 0419	Bushing - 10mm	29-13
5053 0447	Bushing - M6	7-12
5053 0447	Bushing - M6	15-12
5053 0447	Bushing - M6	23-39
5203 2060	Corona Wire Screw - M3 x 4	9-28
5203 2060	Corona Wire Screw - M3 x 4	19-39
5203 3105	Nylon Rivet	17-33
5203 3127	Toner End Spring	17-49
5203 3130	Toner End Disk	17-47
5203 3151	Roller Cover Spring	17-46
5203 9001	Corona Wire (10pcs)	9-25
5203 9001	Corona Wire (10pcs)	19-36
5205 5250	L.E.D. Sensor Type S	9-32
5205 5250	L.E.D. Sensor Type S	27-56
5214 1221	Rubber Foot	23- 7
5214 5230	Master Sensor	11-45
5216 3095	Mylar - Toner Supply Roller	17-30
5413 1882	Two Stepped Screw	23-10
5413 4835	Decal - Paper Level	13-13
5442 2751	Paper Feed Hub - Ratchet	29- 2
5447 2676	Output Hub	29-30
5447 2678	Slip Clutch Cover	29-31
5447 2681	Snap Ring	7-29
5447 2681	Snap Ring	27-19
5447 2681	Snap Ring	29-33
5447 2693	Separation Roller	29-32
5447 2695	Input Hub	29-28
5447 2706	Gear - 15T	27-23
5447 2720	Gear - 18T	27-21
5447 2723	Pick-up Roller	27-26
5447 2726	Paper Feed Roller	27-20
5447 2737	CAM Catcher	27-48
5447 2743	Lever Spring	27-46

Parts No.	Description	Page and Index No.
5447 2744	Spring - Paper Pick-up	27-49
5447 2745	Spring - CAM Catcher Slide	27-47
5447 2746	Spring - Paper Feed	27-44
5447 2751	Feed Roller Hub - Ratchet	27-32
5447 2768	Stepped Screw - M3	15-35
5447 2805	Slide Pin Holder	27-10
5447 2912	Bottom Plate Cushion	13-17
5447 2912	Bottom Plate Cushion	15-58
5447 2941	Rear Fence	13-12
5466 3198	Washer - SBU	17-18
5474 1140	Bushing - Pressure Roller	15-22
5474 1307	Gear - ADF Tray	5-65
5475 2047	Sheet - Rack Cover	5-61

Parts No.	Description	Page and Index No.
0313 0030B	Philips Pan Head Screw - M3x3	23-114
0313 0040B	Philips Pan Head Screw - M3 x 4	3-104
0313 0050B	Philips Pan Head Screw - M3 x 5	3-102
0313 0050B	Philips Pan Head Screw - M3 x 5	5-102
0313 0050B	Philips Pan Head Screw - M3 x 5	7-102
0313 0050B	Philips Pan Head Screw - M3 x 5	9-103
0313 0050B	Philips Pan Head Screw - M3 x 5	11-101
0313 0050B	Philips Pan Head Screw - M3 x 5	15-102
0313 0050B	Philips Pan Head Screw - M3 x 5	17-102
0313 0050B	Philips Pan Head Screw - M3 x 5	19-101
0313 0050B	Philips Pan Head Screw - M3 x 5	21-101
0313 0050B	Philips Pan Head Screw - M3 x 5	23-101
0313 0050W	Philips Pan Head Screw - M3 x 5	27-105
0313 0060B	Philips Pan Head Screw - M3 x 6	11-111
0313 0060B	Philips Pan Head Screw - M3 x 6	21-104
0313 0060B	Philips Pan Head Screw - M3 x 6	25-106
0313 0060B	Philips Pan Head Screw - M3 x 6	29-101
0313 0060W	Philips Pan Head Screw - M3 x 6	15-101
0313 0080B	Philips Pan Head Screw - M3 x 8	3-106
0313 0080B	Philips Pan Head Screw - M3 x 8	5-103
0313 0120B	Philips Pan Head Screw - M3 x 12	11-108
0313 0120B	Philips Pan Head Screw - M3 x 12	21-111
0313 0120B	Philips Pan Head Screw - M3 x 12	25-107
0313 0120B	Philips Pan Head Screw - M3 x 12	29-107
0313 0160B	Philips Pan Head Screw - M3 x 16	9-107
0313 0180B	Philips Pan Head Screw - M3 x 10	19-102
0313 0250W	Philips Pan Head Screw - M3 x 25	19-108
0314 0060B	Philips Pan Head Screw - M4 x 6	3-105
0314 0060B	Philips Pan Head Screw - M4 x 6	15-107
0314 0060B	Philips Pan Head Screw - M4 x 6	17-108
0314 0060B	Philips Pan Head Screw - M4 x 6	19-104
0314 0060B	Philips Pan Head Screw - M4 x 6	23-106
0314 0060B	Philips Pan Head Screw - M4 x 6	25-103
0314 0060B	Philips Pan Head Screw - M4 x 6	27-101
0314 0060B	Philips Pan Head Screw - M4 x 6	29-104

Parts No.	Description	Page and Index No.
0314 0080B	Philips Pan Head Screw - M4 x 8	23-109
0314 0100B	Philips Pan Head Screw - M4 x 10	9-105
0314 0100B	Philips Pan Head Screw - M4 x 10	27-109
0314 0120B	Philips Pan Head Screw - M4 x 12	27-106
0314 0160B	Philips Pan Head Screw - M4 x 16	19-112
0323 0060W	Philips Sunken Head Screw - M3 x 6	25-104
0323 0100B	Philips Pan Head Screw - M3 x 100	11-115
0353 0050Z	Philips Truss Head Screw - M3 x 5	3-101
0353 0050Z	Philips Truss Head Screw - M3 x 5	9-106
0353 0050Z	Philips Truss Head Screw - M3 x 5	11-114
0353 0050Z	Philips Truss Head Screw - M3 x 5	21-102
0353 0050Z	Philips Truss Head Screw - M3 x 5	25-102
0353 0050Z	Philips Truss Head Screw - M3 x 5	25-105
0353 0060Z	Philips Truss Head Screw - M3 x 6	7-101
0353 0060Z	Philips Truss Head Screw - M3 x 6	21-110
0354 0060Z	Philips Truss Head Screw - M4 x 6	25-101
0434 0050B	Hexagonal Head Tapping Screw - M4 x 5	25-108
0573 0040E	Hexagon Headless Set Screw - M3 x 4	5-104
0573 0040E	Hexagon Headless Set Screw - M3 x 4	7-107
0573 0040E	Hexagon Headless Set Screw - M3 x 4	15-105
0573 0040E	Hexagon Headless Set Screw - M3 x 4	23-110
0574 0040E	Hexagon Headless Set Screw - M4 x 4	7-106
0574 0040E	Hexagon Headless Set Screw - M4 x 4	11-103
0584 0061E	Bolt - M4 x 6	27-102
0701 0050B	Flat Washer - M5	17-112
0710 0030B	Flat Washer - M3	11-120
0720 0020E	Retaining Ring - M2	5-101
0720 0020E	Retaining Ring - M2	11-119
0720 0020E	Retaining Ring - M2	21-109
0720 0030E	Retaining Ring - M3	7-103
0720 0030E	Retaining Ring - M3	11-104
0720 0030E	Retaining Ring - M3	15-104
0720 0030E	Retaining Ring - M3	17-109
0720 0030E	Retaining Ring - M3	21-103
07200 030E	Retaining Ring - M3	23-111

Parts No.	Description	Page and Index No.
0720 0030E	Retaining Ring - M3	29-109
0720 0040E	Retaining Ring - M4	7-104
0720 0040E	Retaining Ring - M4	11-110
0720 0040E	Retaining Ring - M4	15-103
0720 0040E	Retaining Ring - M4	17-104
0720 0040E	Retaining Ring - M4	21-106
0720 0040E	Retaining Ring - M4	23-102
0720 0040E	Retaining Ring - M4	27-103
0720 0040E	Retaining Ring - M4	29-102
0720 0050E	Retaining Ring - M5	11-112
0720 0050E	Retaining Ring - M5	23-104
0720 0050E	Retaining Ring - M5	27-107
0720 0060E	Retaining Ring - M6	15-108
0720 0060E	Retaining Ring - M6	17-110
0720 0060E	Retaining Ring - M6	21-112
0720 0060E	Retaining Ring - M6	23-107
0720 0060E	Retaining Ring - M6	27-104
0720 0060E	Retaining Ring - M6	29-103
0720 0080E	Retaining Ring - M8	29-105
0725 0200E	Retaining Ring C - M20	21-107
0804 3002	Parallel Key	27-108
0805 3145	Ball Bearing - 6x12x4mm	23-108
0805 3162	Ball Bearing - 10 x 19 x 71mm	17-111
0807 4009	Washer - 5.2 X 11 x 0.3	21-108
0807 4113	Clutch Spacer	11-118
0809 1005	Nylon Wire	19-110
0951 3004B	Philips Screw With Flat Washer - M3 x 4	7-108
0951 3005B	Philips Screw With Flat Washer - M3 x 5	15-106
0951 3005B	Philips Screw With Flat Washer - M3 x 5	17-101
0951 3005B	Philips Screw With Flat Washer - M3 x 5	19-107
0951 3005B	Philips Screw With Flat Washer - M3 x 5	21-105
0951 3006B	Philips Screw With Flat Washer - M3 x 6	3-103
0951 3006B	Philips Screw With Flat Washer - M3 x 6	5-105
0951 3006B	Philips Screw With Flat Washer - M3 x 6	9-101
0951 3006B	Philips Screw With Flat Washer - M3 x 6	11-109

Parts No.	Description	Page and Index No.
0951 3006B	Philips Screw With Flat Washer - M3 x 6	17-103
0951 3006B	Philips Screw With Flat Washer - M3 x 6	19-105
0951 3006B	Philips Screw With Flat Washer - M3 x 6	23-105
0951 3008B	Philips Screw With Flat Washer - M3 x 8	9-104
0951 3008B	Philips Screw With Flat Washer - M3 x 8	11-116
0951 3008W	Philips Screw With Flat Washer - M3 x 8	19-109
0951 3010B	Philips Screw With Flat Washer - M3 x 1	7-105
0951 3010B	Philips Screw With Flat Washer - M3 x 1	19-106
0951 3020B	Philips Screw With Flat Washer - M3 x 20	9-102
0951 3025B	Philips Screw With Flat Washer - M3 x 25	19-111
0951 4006B	Philips Screw With Flat Washer - M4x6	19-115
0951 4006W	Philips Screw With Flat Washer - M4x6	19-114
0951 4008B	Philips Screw With Flat Washer - M4 x 8	11-102
0951 4008B	Philips Screw With Flat Washer - M4 x 8	23-103
0951 4008B	Philips Screw With Flat Washer - M4 x 8	27-110
0951 4008B	Philips Screw With Flat Washer - M4 x 8	29-108
0951 4010B	Philips Screw With Flat Washer - M4 x 10	23-113
0954 3008B	Philips Screw - M3 x 8	11-105
0954 3008B	Philips Screw - M3 x 8	17-105
0954 3008B	Philips Screw - M3 x 8	23-112
0954 3014B	Double Sems Screw - M4 x 8	17-107
0954 4012B	Double Sems Screw - M4 x 12	11-106
0954 4012B	Double Sems Screw - M4 x 12	15-109
0954 4012B	Double Sems Screw - M4 x 12	17-106
0965 3006B	Tapping Screw With Flat Washer - M3 x 6	11-117
0965 3012B	Tapping Screw With Washer - M3 x 12	11-107
0965 4008B	Tapping Screw - M4 x 8	11-113
0965 4008B	Tapping Screw - M4 x 8	13-101
0965 4008W	Tapping Screw With Flat Washer - M4 x 8	29-106
1105 0005	Nylon Clip - 3N	29-110
1204 1280	Push Switch	19-103
1204 1603	Push Switch	19-113
2801 0031	Power Cord	31-12

Parts No.	Description	Page and Index No.